


## Wire Harness Side



N

I11468


**INSPECTION****1. INSPECT POWER WINDOW MASTER SWITCH CIRCUIT****Connector disconnected:**

Disconnect the connectors from the switch and inspect connector on the wire harness side.

Tester Connection	Condition	Specified Condition
9 - Ground	Constant	Continuity
1, 5 - Ground	Constant	Battery voltage
2, 4 - Ground	Ignition switch LOCK	No voltage
2, 4 - Ground	Ignition switch ACC or ON	Battery voltage
15 - Ground (LHD)	Driver's door key lock and unlock switch LOCK	No continuity
15 - Ground (LHD)	Driver's door key lock and unlock switch UNLOCK	Continuity
16 - Ground	Each door courtesy switch ON (door opened)	No continuity
16 - Ground	Each door courtesy switch OFF (door closed)	Continuity
6 - Ground (RHD)	Driver's door key lock and unlock switch LOCK	No continuity
6 - Ground (RHD)	Driver's door lock and unlock switch UNLOCK	Continuity

If circuit is not as specified, replace the switch.

**2. INSPECT POWER WINDOW MASTER SWITCH CIRCUIT (See page DI-598)**




**3. INSPECT DOOR KEY LOCK AND UNLOCK SWITCH CONTINUITY**

( ): LHD models

Switch position	Tester connection	Specified condition
LOCK	3 - 5 (2 - 4)	Continuity
OFF	-	No continuity
UNLOCK	4 - 5 (2 - 3)	Continuity

If continuity is not as specified, replace the door lock assembly.



**4. w/o Double locking system: INSPECT DRIVER SIDE DOOR UNLOCK DETECTION SWITCH CONTINUITY**

( ): LHD models


Switch position	Tester connection	Specified condition
OFF (Door Lock set to LOCK)	-	No continuity
ON (Door Lock set to UNLOCK)	5 - 6 (3 - 4)	Continuity

If continuity is not as specified, replace the door lock assembly.

**5. w/o Double locking system: INSPECT PASSENGER DOOR UNLOCK DETECTION SWITCH CONTINUITY**

Switch position	Tester connection	Specified condition
OFF (Door Lock set to LOCK)	-	No continuity
ON (Door Lock set to UNLOCK)	1 - 2	Continuity


If continuity is not as specified, replace the door lock assembly.



**6. w/o Double locking system:  
INSPECT REAR DOOR UNLOCK DETECTION  
SWITCH CONTINUITY  
( ): LHD side**

Switch position	Tester connection	Specified condition
OFF (Door Lock set to LOCK)	-	No continuity
ON (Door Lock set to UNLOCK)	3 - 4 (1 - 2)	Continuity


If continuity is not as specified, replace the door lock assembly.



**7. w/ Double locking system:  
INSPECT FRONT DOOR UNLOCK DETECTION  
SWITCH CONTINUITY**

Switch position	Tester connection	Specified condition
OFF (Door Lock set to LOCK)	-	No continuity
ON (Door Lock set to UNLOCK)	1 - 5	Continuity

If continuity is not as specified, replace the door lock assembly.




### 8. w/ Double locking system: INSPECT REAR DOOR UNLOCK DETECTION SWITCH CONTINUITY

Switch position	Tester connection	Specified condition
OFF (Door Lock set to LOCK)	-	No continuity
ON (Door Lock set to UNLOCK)	1 - 5	Continuity

If continuity is not as specified, replace the door lock assembly.


### 9. INSPECT DOOR UNLOCK DETECTION SWITCH CIRCUIT (See page DI-595)



### 10. INSPECT DOOR LOCK MOTOR AND J/B CIRCUIT

- Remove the body ECU from the driver's side junction block.
- Connect the positive (+) lead from the battery to J/B terminal 9 and the negative (-) lead to J/B terminal 10, and check that the door lock link moves to LOCK position.
- Reverse the polarity and check that the door link moves to UNLOCK position.

If operation is not as specified, inspect door lock motor.



### 11. w/o Double locking system: INSPECT FRONT LEFT SIDE DOOR LOCK MOTOR OPERATION

( ): LHD models


- Connect the positive (+) lead from the battery to terminal 3 (5) and the negative (-) lead to terminal 4 (6), and check that the door lock link moves to LOCK position.
- Reverse the polarity and check that the door lock link moves to UNLOCK position.

If operation is not as specified, replace the door lock assembly.

### 12. w/o Double locking system: INSPECT FRONT RIGHT SIDE DOOR LOCK MOTOR OPERATION

- Connect the positive (+) lead from the battery to terminal 1 and the negative (-) lead to terminal 2, and check that the door lock link moves to LOCK position.
- Reverse the polarity and check that the door lock link moves to UNLOCK position.

If operation is not as specified, replace the door lock assembly.




**13. w/o Double locking system:  
INSPECT REAR DOOR LOCK MOTOR OPERATION  
( ): LHD models**

- (a) Connect the positive (+) lead from the battery to terminal 1 (3) and the negative (-) lead to terminal 2 (4), and check that the door lock link moves to LOCK position.
- (b) Reverse the polarity and check that the door lock link moves to UNLOCK position.

If operation is not as specified, replace the door lock assembly.


**14. INSPECT DOOR LOCK MOTOR CIRCUIT  
(See [page DI-592])**



**15. w/ Double locking system:  
INSPECT FRONT DOOR LOCK MOTOR OPERATION**

- (a) Connect the positive (+) lead from the battery to terminal 2 and the negative (-) lead to terminal 3, and check that the door lock link moves to LOCK position.
- (b) Reverse the polarity and check that the door lock link moves to UNLOCK position.

If operation is not as specified, replace the door lock assembly.


**16. w/ Double locking system:****INSPECT REAR DOOR LOCK MOTOR OPERATION**

- (a) Connect the positive (+) lead from the battery to terminal 2 and the negative (-) lead to terminal 3, and check that the door lock link moves to LOCK position.
- (b) Reverse the polarity and check that the door lock link moves to UNLOCK position.


If operation is not as specified, replace the door lock assembly.

**17. INSPECT DOOR LOCK MOTOR CIRCUIT**

(See page DI-592)

**18. INSPECT LUGGAGE COMPARTMENT DOOR OPENER MOTOR OPERATION**

Connect positive (+) lead to the terminal 1 and negative (-) lead to the opener motor body, and check that the motor operates. If operation is not as specified, replace the motor assembly.

**19. INSPECT LUGGAGE COMPARTMENT DOOR OPENER MOTOR CIRCUIT**

(See page DI-589)