


INSPECTION

1. INSPECT SLIDING ROOF SWITCH CONTINUITY

Switch position	Tester connection	Specified condition
SLIDE OPEN	1 - 6	Continuity
SLIDE OFF	-	No continuity
SLIDE CLOSE	2 - 6	Continuity
TILT DOWN	3 - 6	Continuity
TILT OFF	-	No continuity
TILT UP	4 - 6	Continuity

If continuity is not as specified, replace the switch.



2. INSPECT SLIDING ROOF CONTROL ASSEMBLY CIRCUIT

Disconnect the connector from the ECU and inspect the connector on the wire harness side, as shown in the chart.

Tester connection	Condition	Specified condition
5 - Ground	Sliding roof control switch (TILT) UP	Continuity
6 - Ground	Sliding roof control switch (TILT) DOWN	Continuity
1 - Ground	Sliding roof control switch (SLIDE) CLOSE	Continuity
2 - Ground	Sliding roof control switch (SLIDE) OPEN	Continuity
8, 7 - Ground	Constant	Continuity
10 - Ground	Front door is opened	Continuity
3 - Ground	Ignition switch LOCK or ACC	* No voltage
3 - Ground	Ignition switch ON	Battery voltage
4 - Ground	Constant	Battery voltage

*: Exceptions: During 60 second period after ignition switch ON → OFF (ACC) or until driver of passenger door is opened after ignition switch ON → OFF (ACC).

If circuit is as specified, replace the relay.