

<b>DTC</b>	<b>P0121/41</b>	<b>Throttle Pedal Position Sensor Circuit Range/Performance Problem</b>
------------	-----------------	---

## CIRCUIT DESCRIPTION

Refer to DTC P0120/41 on page DI-42.

DTC No.	DTC Detecting Condition	Trouble Area
P0121/41	Condition (a) continue for 2.0 seconds: (a) Difference between VTA and VTA2 is out of threshold	• Throttle position sensor

## INSPECTION PROCEDURE

### HINT:

Read freeze frame data using hand-held tester. Because freeze frame records the engine conditions when the malfunction is detected. When troubleshooting it is useful for determining whether the vehicle was running or stopped, the engine was warmed up or not, the air-fuel ratio was lean or rich, etc. at the time of the malfunction.

**Replace throttle position sensor (See page FI-37).**