

DTC	C1223/43	ABS Control System Malfunction
------------	-----------------	---------------------------------------

CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
C1223/43	ABS control system is abnormal.	• ABS control system

INSPECTION PROCEDURE

1	Check the DTC for the ABS (See page DI-223).
---	----------------------------------------------

*1

Repair ABS control system according to the code output.

*2

Check for ECU connected to malfunction indicator lamp.

*1: Output NG code

*2: Malfunction indicator lamp remains ON