

## Tachometer

### INSPECTION PROCEDURE

HINT:

If there is not the LEXUS hand-held tester, begin with STEP 2.

#### 1 Perform active test.

#### PREPARATION:

- (a) Connect the LEXUS hand-held tester to the DLC3.
- (b) Turn ignition switch ON and LEXUS hand-held tester main switch ON.
- (c) Select the ACTIVE TEST mode on the LEXUS hand-held tester.

#### CHECK:

Check that the probe moves as LEXUS hand-held tester directs in each range.

#### OK:

The probe operates normally.

OK

Proceed to next circuit inspection shown in problem symptoms table (See page DI-531).

NG

#### 2 Check tachometer (See page BE-83).

NG

Replace tachometer.

OK

#### 3 Check circuit plate (See page BE-83).

NG

Replace circuit plate.

OK

Check and replace combination meter (See page BE-77).