

Fuel gauge

INSPECTION PROCEDURE

HINT:

If there is not the LEXUS hand-held tester, begin with STEP 2.

1 Perform active test.

PREPARATION:

- Connect the LEXUS hand-held tester to the DLC3.
- Turn ignition switch ON and LEXUS hand-held tester main switch ON.
- Select the ACTIVE TEST mode on the LEXUS hand-held tester.

CHECK:

Check that the probe moves as LEXUS hand-held tester directs in each range.

OK:

The probe operates normally.

OK

Proceed to next circuit inspection shown in problem symptoms table. (See page DI-531).

NG

2 Check fuel receiver gauge (See page BE-83).

NG

Replace fuel receiver gauge.

OK

3 Check fuel sender gauge (See page BE-83).

NG

Replace fuel sender gauge.

OK

4 Check circuit plate (See page BE-83).

NG

Replace circuit plate.

OK

Check and replace combination meter (See page BE-77).