

DTC	B1241 / 41	Body ECU switch circuit diagnosis
------------	-------------------	--

CIRCUIT DESCRIPTION

These DTC notify how switch works as follows:

If DTC is not output when operating switch, it means failure of switch contact. If DTC is output when not operating switch, it means stick of switch. When something wrong is found by this diagnosis, inspect each switch. Then, replace the switch if there is a problem, or check the wireharness if there is no problem.

DTC No.	DTC Detecting Condition	Trouble Area
B1241/41	Stick of switch	• Power window master switch

HINT:

Please refer to BE section for switch inspection, and to each door system of DI section for wireharness inspection.