

# IDLE SPEED

EM118-01

## INSPECTION

### 1. INITIAL CONDITIONS

- (a) Engine at normal operating temperature
- (b) Air cleaner installed
- (c) All pipes and hoses of air induction system connected
- (d) All accessories switched OFF
- (e) All vacuum lines properly connected
- (f) EFI system wiring connectors fully plugged
- (g) Ignition timing checked correctly
- (h) Transmission in neutral position

### 2. CONNECT HAND-HELD TESTER (See page EM-15)

### 3. INSPECT IDLE SPEED

- (a) Race the engine speed at 2,500 rpm for approx. 90 seconds.
- (b) Check the idle speed.

**Idle speed: 650 ± 50 rpm**

If the idle speed is not as specified, check the throttle body.

### 4. DISCONNECT HAND-HELD TESTER