


INSPECTION

1. REMOVE AIR CLEANER INLET
2. REMOVE NO.3 CYLINDER HEAD COVER
3. REMOVE ALTERNATOR (See page CH-6)
4. REMOVE KNOCK SENSOR 1
 - (a) Disconnect the knock sensor connector.
 - (b) Using SST, remove the knock sensor.
SST 09816-30010
5. REMOVE OIL DIPSTICK AND GUIDE FOR A/T
6. REMOVE STARTER (See page ST-3)
7. REMOVE KNOCK SENSOR 2 (See step 2)



8. INSPECT KNOCK SENSORS

Using an Ohmmeter, check that there is no continuity between the terminal and body.

If there is continuity, replace the sensor.

9. REINSTALL KNOCK SENSORS

- (a) Using SST, install the knock sensor.
SST 09816-30010

Torque: 45 N·m (450 kgf·cm, 33 ft·lbf)

- (b) Connect the knock sensor connector.

10. REINSTALL STARTER (See page ST-17)

11. REINSTALL OIL DIPSTICK AND GUIDE FOR A/T

HINT:

Use a new O-ring.

12. REINSTALL ALTERNATOR (See page CH-15)

13. REINSTALL NO.3 CYLINDER HEAD COVER

14. REINSTALL AIR CLEANER INLET