

DISASSEMBLY

1. INSPECT EACH GEAR THRUST CLEARANCE


Using a feeler gauge, measure the thrust clearance of each gear.

Standard clearance:

1st gear: 0.15 – 0.40 mm (0.0059 – 0.0157 in.)

2nd and reverse gear:

0.10 – 0.45 mm (0.0039 – 0.0177 in.)




2. INSPECT EACH GEAR RADIAL CLEARANCE

Using a dial indicator, measure the radial clearance of each gear.

Standard clearance:


0.015 – 0.066 mm (0.00059 – 0.00260 in.)

If the clearance exceeds the standard, replace the gear, shaft or needle roller bearing.




3. REMOVE REVERSE GEAR

- (a) Using a snap ring expander, remove the snap ring.




- (b) Using SST and a press, remove the transmission clutch hub No. 3 and reverse gear, synchronizer ring No. 3 and reverse gear bearing.

SST 09950-00020, 09950-60010 (09951-00230),
09950-70010 (09951-07100)




4. REMOVE HUB SLEEVE NO.3


- (a) Cover the hub sleeve No.3 with a cloth, remove the hub sleeve No.3.
- (b) Remove the 3 shifting keys, 3 shifting springs and 3 shifting key balls.

**5. REMOVE 6TH GEAR**


- (a) Using 2 screwdrivers and hammer, remove the 6th gear shaft snap ring.




- (b) Using SST and press, remove the 6th gear.
SST 09950-00020

**6. REMOVE 1ST GEAR**

- (a) Using SST and press, remove the output shaft bearing RR.
SST 09950-00020
- (b) Remove the 1st gear bearing inner race 1st gear needle roller bearing and 1st shift restrict ball.

**7. REMOVE 2ND GEAR**

- Using SST and press, remove the 2nd gear, transmission clutch hub No. 1 and 2nd gear needle roller bearing.
SST 09950-00020

8. REMOVE SYNCHRONIZER RING SET NO. 1**9. REMOVE HUB SLEEVE NO. 1**

- (a) Cover the hub sleeve No. 1 with a cloth, remove the hub sleeve No.1.
- (b) Remove the 3 shifting keys, 3 shifting springs and 3 shifting key balls.