

REPLACEMENT

REPLACEMENT REQUIREMENTS

In the following cases, replace the front airbag sensor.

- □ If the SRS has been deployed in a collision. (Replace both the left and right airbag sensors.)
- □ If the front airbag sensor has been found to be faulty in troubleshooting.
- □ If the front airbag sensor has been found to be faulty during checking items.
(See page RS-60)
- □ If the front airbag sensor has been dropped.

CAUTION:

For removal and installation of the front airbag sensor, see page RS-59 and RS-62. Be sure to follow the correct procedure.