

## REPLACEMENT

### REPLACEMENT REQUIREMENTS

In the following cases, replace the side airbag sensor assembly.

- If the side airbag sensor assembly has been deployed in a collision.
- If the side airbag sensor assembly has been found to be faulty in troubleshooting.
- If the side airbag sensor assembly has been dropped.

### CAUTION:

For removal and installation of the side airbag sensor assembly, see page RS-64 and RS-67. Be sure to follow the correct procedure.