


TORQUE CONVERTER AND DRIVE PLATE INSPECTION


AT070-02

1. INSPECT ONE-WAY CLUTCH

- (a) Install SST so that it fits in the notch of the converter hub and outer race of the one-way clutch.
SST 09350-30020 (09351-32020)



- (b) Press on the serrations of stator with a finger and rotate the stator.
Check if it rotates smoothly when turned clockwise and locks up when turned counterclockwise.




2. MEASURE DRIVE PLATE RUNOUT AND INSPECT RING GEAR

Set up a dial indicator and measure the drive plate runout.

Maximum runout: 0.20 mm (0.0079 in.)

If the runout exceeds 0.20 mm (0.0079 in.) or if the ring gear is damaged, replace the drive plate. If installing a new drive plate, note the orientation of spacers and tighten the bolts.

Torque: 83 N·m (850 kgf·cm, 61 ft·lbf)



3. MEASURE TORQUE CONVERTER SLEEVE RUNOUT

- (a) Temporarily mount the torque converter to the drive plate.
Set up a dial indicator.

Maximum runout: 0.30 mm (0.0118 in.)

If the runout exceeds 0.30 mm (0.0118 in.), try to correct by re-orienting the installation of the torque converter.

If excessive runout cannot be corrected, replace the torque converter.

HINT:

Mark the position of the torque converter to ensure correct installation.

- (b) Remove the torque converter.