

DTC	P1645/82	Body ECU Malfunction
------------	-----------------	-----------------------------

CIRCUIT DESCRIPTION

ECU receives the operating condition (ON/OFF) of A/C from A/C ECU and it also receives the electrical pad information from the body ECU.

ECU uses these information to control the engine (idle up, etc.).

DTC No.	DTC Detecting Condition	Trouble Area
P1645/82	Condition (a) or (b) continues for 5.0 seconds or more. (a) No communication from body ECU (b) No communication from A/C ECU	<ul style="list-style-type: none"> • Body ECU • A/C ECU • Communication bus

INSPECTION PROCEDURE

Perform troubleshooting the Multiplex Communication System (See page DI-565).