

BODY

MA053-01

INSPECTION

1. TIGHTEN BOLTS AND NUTS ON CHASSIS AND BODY

(a) Where necessary, tighten all parts of the chassis.

- Front axle and suspension
- Driven train
- Rear axle and suspension
- Steering system
- Brake system
- Engine mounting etc.

(b) Where necessary, tighten all parts of the body.

- Seat belt system
- Seats
- Doors and hood
- Body mountings
- Fuel tank
- Exhaust pipe system etc.

2. CHECK TIRES AND INFLATION PRESSURE

(a) Check tires for abnormal abrasion or cracks.

(b) Check and adjust the tires inflation pressure.

Cold tire inflation pressure: (See page SA-1)

3. CHECK LIGHTS, HORNS, WIPERS AND WASHERS

Check the function of lights, horns, wipers and washers.

4. REPLACE AIR REFINER FILTER (See Pub. No. RM684E on page AC-96)

5. Except Europe:

CHECK AIR CONDITIONER REFRIGERANT AMOUNT

(See Pub. No. RM684E on page AC-3)

6. Europe:

CORROSION INSPECTION

7. Australia:

ROAD TEST

- (a) Check the engine and chassis for abnormal noises.
- (b) Check that the vehicle does not wander or pull to one side.
- (c) Check that the brakes work properly and do not drag.
- (d) Do setting of the parking brake shoes and drum.