

INSTALLATION

Installation is in the reverse order of removal. (See page ST-3)