


DTC**B1443/43****Air Outlet Damper Control Servo Motor Circuit****DESCRIPTION**

This circuit turns the servo motor and changes each damper position by receiving the signals from the A/C amplifier assembly.

The air outlet damper servo switches the air outlet by rotating the motor (normal, reverse) with electrical power from the A/C amplifier assembly.

When the AUTO switch is on, the A/C amplifier assembly changes the mode between "FACE", "BI-LEVEL" and "FOOT" according to the temperature setting.

DTC No.	DTC Detecting Condition	Trouble Area
B1443/43	Air outlet damper position sensor value does not change even if air conditioning amplifier assembly operated air outlet control servo motor.	<ul style="list-style-type: none"> Air outlet control servo motor Harness or connector between air outlet control servo motor and A/C amplifier assembly A/C amplifier assembly

WIRING DIAGRAM**1****READ VALUE OF INTELLIGENT TESTER**

- Connect the intelligent tester to the DLC3.
- Turn the ignition switch ON and push the intelligent tester main switch on.

- (c) Select the item below in the DATA LIST, and read the display on the intelligent tester.

DATA LIST / AIR CONDITIONER

Item	Measurement Item / Display (Range)	Normal Condition	Diagnostic Note
A/O DAMP POS	Air outlet damper position / min.: -14% max.: 113.5%	Damper is at "FACE": 0% Damper is at "FACE/FOOT": 33.5%	Open in the circuit: 50.0%
A/O DAMP TARG	Air outlet damper target position / min.: -14% max.: 113.5%	Damper is at "FOOT" (Manual): 53.5% Damper is at "FOOT" (Auto): 53.5% Damper is at "FACE/DEF": 73.5% Damper is at "DEF": 100%	


AC

OK:

When the target position is at the "FACE" (0%), the actual opening angle is 19.0% or less.
When the target position is at the "DEF" (100%), the actual opening angle is 81.0% or more.

Result


Result	Proceed to
NG	A
OK (Checking from the PROBLEM SYMPTOMS TABLE)	B
OK (Checking from the DTC)	C



PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE



REPLACE AIR CONDITIONING AMPLIFIER ASSEMBLY



2 PERFORM ACTIVE TEST BY INTELLIGENT TESTER

- (a) Connect the intelligent tester to the DLC3.
- (b) Turn the ignition switch ON and push the intelligent tester main switch on.
- (c) Select the item below in the ACTIVE TEST and then check that the air flow position by hand.

ACTIVE TEST / AIR CONDITIONER

Item	Test Details / Display (Range)	Diagnostic Note
A/O MODE DAMP-D	Air outlet damper position (Driver side) /min.: -14% max.: 113.5%	-

OK:

Air comes out from the selected air outlet.

Result

Result	Proceed to
NG	A
OK (Checking from the PROBLEM SYMPTOMS TABLE)	B
OK (Checking from the DTC)	C

B → **PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE**

C → **REPLACE AIR CONDITIONING AMPLIFIER ASSEMBLY**

A

3 **PERFORM ACTUATOR CHECK**

AC

- (a) Warm up the engine.
- (b) Set the actuator check mode (See page AC-11).
- (c) Press the UPDr switch and change to step operation.
- (d) Press the UPDr switch and check the air flow by hand.

Display Code	Air flow condition
0	FACE (0%)
1	FACE (0%)
2	FACE (0%)
3	FACE (0%)
4	B/L (33.5%)
5	FOOT (AUTO) (53.5%)
6	FOOT (MANUAL) (53.5%)
7	FOOT (MANUAL) (53.5%)
8	F/D (73.5%)
9	DEF (100%)

OK:
Air flow position changes in accordance with each display code.

Result

Result	Proceed to
NG	A
OK (Checking from the PROBLEM SYMPTOMS TABLE)	B
OK (Checking from the DTC)	C



B → **PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE**

C → **REPLACE AIR CONDITIONING AMPLIFIER ASSEMBLY**

A

4 INSPECT AIR OUTLET CONTROL SERVO MOTOR

Air Outlet Control Servo Motor Connector Front View:



H

E108927E04

- (a) Remove the air outlet control servo motor.
- (b) Disconnect the connector from the air outlet control servo motor.
- (c) Connect the positive (+) lead from the battery to terminal 4 and negative (-) lead to terminal 5 then check that the lever turns to "DEF" position smoothly.

OK:

Lever turns to "DEF" position smoothly.

- (d) Connect the positive (+) lead from the battery to terminal 5 and negative (-) lead to terminal 4 then check that the lever turn to "FACE" position smoothly.

OK:

Lever turns to "FACE" position smoothly.


NG **REPLACE AIR OUTLET CONTROL SERVO MOTOR**

AC


OK

5 CHECK HARNESS AND CONNECTOR (AIR OUTLET CONTROL SERVO MOTOR - A/C AMPLIFIER ASSEMBLY)

Air Outlet Control Servo Motor Connector Front View:



A/C Amplifier Assembly Connector Wire Harness View:



H

E109216E15

- (a) Disconnect the connector from the A/C amplifier assembly.
- (b) Measure the resistance according to the value(s) in the table below.

Standard resistance

Tester connection (Symbols)	Condition	Specified condition
A7-5 (AOF) - A19-5 (FACE)	Always	Below 1 Ω
A7-6 (AOD) - A19-4 (DEF)	Always	Below 1 Ω
A7-5 (AOF) - Body ground	Always	10 kΩ or higher
A7-6 (AOD) - Body ground	Always	10 kΩ or higher

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

REPLACE AIR CONDITIONING AMPLIFIER ASSEMBLY

AC