

<b>DTC</b>	<b>P0766</b>	<b>Shift Solenoid "D" Performance (Shift Solenoid Valve S4)</b>
------------	--------------	---

### SYSTEM DESCRIPTION

The ECM uses signals from the vehicle speed sensor to detect the actual gear position (1st, 2nd, 3rd, 4th or 5th gear).

Then the ECM compares the actual gear with the shift schedule in the ECM memory to detect mechanical problems of the shift solenoid valves, valve body or automatic transaxle (clutch, brake or gear etc.).

DTC No.	DTC Detecting Condition	Trouble Area
P0766	The gear required by the ECM does not match the actual gear when driving (2-trip detection logic)	<ul style="list-style-type: none"> <li>• Shift solenoid valve S4 remains open or closed</li> <li>• Valve body is blocked</li> <li>• Automatic transaxle (clutch, brake or gear etc.)</li> </ul>

### MONITOR DESCRIPTION

The ECM commands gear shifts by turning the shift solenoid valves "ON/OFF". According to the input shaft revolution, intermediate (counter) shaft revolution and output shaft revolution, the ECM detects the actual gear position (1st, 2nd, 3rd, 4th or 5th gear position). When the gear position commanded by the ECM and the actual gear position are not the same, the ECM illuminates the MIL and stores the DTC.

### MONITOR STRATEGY

Related DTCs	P0766: Shift solenoid valve S4/OFF malfunction Shift solenoid valve S4/ON malfunction
Required sensors/Components	Shift solenoid valve S4, Speed sensor (NT), Speed sensor (NC), Crankshaft position sensor (NE)
Frequency of operation	Continuous
Duration	OFF malfunction (A) and ON malfunction (B) 1 sec. OFF malfunction (B) 1.2 sec. ON malfunction (A) 0.8 sec.
MIL operation	2 driving cycles
Sequence of operation	None

### TYPICAL ENABLING CONDITIONS

All:

The monitor will run whenever this DTC is not present.	P0115 - P0118 (ECT sensor) P0125 (Insufficient ECT for closed loop) P0500 (VSS) P0748, P0778, P0798 (Shift solenoid valve (range))
ECT (Engine coolant temperature)	10°C (50°F) or more
Transmission range	"D"
TFT (Transmission fluid temperature)	-20°C (-4°F) or more
TFT sensor circuit	Not circuit malfunction
ECT sensor circuit	Not circuit malfunction
Turbine speed sensor circuit	Not circuit malfunction
Intermediate shaft speed sensor circuit	Not circuit malfunction
Output speed sensor circuit	Not circuit malfunction
Shift solenoid valve SL1 circuit	Not circuit malfunction
Shift solenoid valve SL2 circuit	Not circuit malfunction
Shift solenoid valve SL3 circuit	Not circuit malfunction

AX

Shift solenoid valve S4 circuit	Not circuit malfunction
Shift solenoid valve SR circuit	Not circuit malfunction
Shift solenoid valve DSL circuit	Not circuit malfunction
Electronic throttle system	Not circuit malfunction

**OFF malfunction (A):**

ECM selected gear	5th
Throttle valve opening angle	5% or more
Vehicle speed	10 km/h (6.2 mph) or more

**OFF malfunction (B):**

ECM lock-up command	ON
ECM selected gear	3rd, 4th or 5th
Throttle valve opening angle	10% or more
Vehicle speed	25 to 100 km/h (15.5 to 62.1 mph)

**ON malfunction (A):**

ECM selected gear	4th or 5th
Throttle valve opening angle	4.5% or more at engine speed 1,900 rpm (Varies with engine speed)

**ON malfunction (B):**

ECM selected gear	4th
Throttle valve opening angle	5% or more
Vehicle speed	10 km/h (6.2 mph) or more

**TYPICAL MALFUNCTION THRESHOLDS**

Either of the following conditions is met: OFF malfunction (A) and (B), or ON malfunction (A) and (B)

2 detections are necessary per driving cycle:

1st detection; temporary flag ON

2nd detection; pending fault code ON

**OFF malfunction (A):**

Intermediate shaft speed/Output speed	1.44 to 1.58
---------------------------------------	--------------

**OFF malfunction (B):**

Difference between engine speed and input (turbine) speed	Less than 35 rpm
---	------------------

**ON malfunction (A):**

Input (turbine) speed/Intermediate shaft speed	0.64 to 0.74
--	--------------

**ON malfunction (B):**

Intermediate shaft speed/Output speed	1.02 to 1.16
---------------------------------------	--------------

**HINT:**

Performing the ACTIVE TEST using the intelligent tester allows the relay, VSV, actuator and so on to operate without parts removal. Performing the ACTIVE TEST as the first step of troubleshooting is one method to shorten labor time.

It is possible to display the DATA LIST during the ACTIVE TEST.

**1. PERFORM ACTIVE TEST**

- (a) Warm up the engine.
- (b) Turn the ignition switch off.
- (c) Connect the intelligent tester to the DLC3.
- (d) Turn the ignition switch to the on position.

- (e) Turn on the tester.
- (f) Select the item "DIAGNOSIS / ENHANCED OBD II / ACTIVE TEST / SHIFT".
- (g) According to the display on the tester, perform the "ACTIVE TEST".

**HINT:**

While driving, the shift position can be forcibly changed with the intelligent tester.

Comparing the shift position commanded by the ACTIVE TEST with the actual shift position enables you to confirm the problem (See page AX-34).

Item	Test Details	Diagnostic Note
SHIFT	[Test Details] Operate the shift solenoid valve and set each shift position by yourself. [Vehicle Condition] Less than 50 km/h (31 mph) [Others] <ul style="list-style-type: none"> <li>• Press "→" button: Shift up</li> <li>• Press "←" button: Shift down</li> </ul>	Possible to check the operation of the shift solenoid valves.

**HINT:**

- This test can be conducted when the vehicle speed is 50 km/h (31 mph) or less.
- The shift position commanded by the ECM is shown in the DATA LIST/SHIFT display on the intelligent tester.

**1 CHECK OTHER DTCS OUTPUT (IN ADDITION TO DTC P0766)**

- (a) Connect the OBD II scan tool or the intelligent tester to the DLC3.
- (b) Turn the ignition switch to the on position and turn the OBD II scan tool or the intelligent tester main switch ON.
- (c) Select the item "DIAGNOSIS / ENHANCED OBD II / DTC INFO / CURRENT CODES".
- (d) Read the DTCs using the OBD II scan tool or the intelligent tester.

**Result:**

Display (DTC output)	Proceed to
Only "P0766" is output	A
"P0766" and other DTCs	B


**HINT:**

If any other codes besides "P0766" are output, perform the troubleshooting for those DTCs first.

**B** **GO TO DTC CHART**

**A**

**2 INSPECT SHIFT SOLENOID VALVE S4**



- (a) Remove the shift solenoid valve S4.
- (b) Measure the resistance according to the value(s) in the table below.

**Resistance**

Tester Connection	Specified Condition 20°C (68°F)
Solenoid Connector (S4) - Solenoid Body (S4)	11 to 15 Ω

- (c) Connect the positive (+) lead to the terminal of the solenoid connector, and the negative (-) lead to the solenoid body.

**OK:**  
The solenoid makes an operating sound.

**NG** → **REPLACE SHIFT SOLENOID VALVE (S4)**

**OK**

**3 INSPECT TRANSMISSION VALVE BODY ASSEMBLY**

**OK:**  
There are no foreign objects on each valve and they operate smoothly.

**NG** → **REPAIR OR REPLACE TRANSMISSION VALVE BODY ASSEMBLY**

**OK**

**AX**

**4 INSPECT TORQUE CONVERTER CLUTCH ASSEMBLY**

**OK:**  
The torque converter clutch operates normally.

**NG** → **REPLACE TORQUE CONVERTER CLUTCH ASSEMBLY**

**OK**

**REPAIR OR REPLACE AUTOMATIC TRANSAXLE ASSEMBLY**