

INSPECTION

1. INSPECT FRONT SPEED SENSOR

- (a) Make sure that there is no looseness at the connectors' locking part and connecting part of connector.
- (b) Disconnect the speed sensor connector.
- (c) Measure the resistance according to the value(s) in the table below.

Resistance:

LH

Tester Connection	Specified Condition
S2-2 (FL+) - S2-1 (FL-)	0.6 to 2.5 k Ω

RH

Tester Connection	Specified Condition
S3-2 (FR+) - S3-1 (FR-)	0.6 to 2.5 k Ω

- (d) Measure the resistance according to the value(s) in the table below.

Resistance:

LH

Tester Connection	Specified Condition
S2-2 (FL+) - Body ground	10 k Ω or higher
S2-1 (FL-) - Body ground	10 k Ω or higher

RH

Tester Connection	Specified Condition
S3-2 (FR+) - Body ground	10 k Ω or higher
S3-1 (FR-) - Body ground	10 k Ω or higher

NOTICE:

Check the speed sensor signal after replacement (See page [BC-16](#)).

INSTALLATION



1. INSTALL SPEED SENSOR FRONT LH


- (a) Install the speed sensor front with the bolt.

Torque: 8.0 N*m (82 kgf*cm, 71 in.*lbf)

NOTICE:

Prevent foreign matter from attaching to the sensor tip.





- (b) Install the speed sensor front with the 2 bolts and the clamp.

Torque: Bolt A

5.0 N*m (51 kgf*cm, 44 in.*lbf)

Bolt B

29 N*m (296 kgf*cm, 21 ft.*lbf)

NOTICE:

Do not twist the sensor wire when installing the sensor.

- (c) Connect the speed sensor connector.

2. INSTALL FRONT FENDER SPLASH SHIELD SUB-ASSEMBLY LH

3. INSTALL FRONT WHEEL

Torque: 103 N*m (1,050 kgf*cm, 76 ft.*lbf)

4. CHECK ABS SPEED SENSOR SIGNAL

HINT:

(See page [BC-21](#)).