

# FRONT DOOR LOCK

## INSPECTION

### 1. INSPECT FRONT DOOR LOCK ASSEMBLY LH

- (a) Apply battery voltage to the door lock and check operation of the motor.

**OK**

Measurement Condition	Specified Condition
Battery positive (+) → Terminal 4 Battery negative (-) → terminal 1	Lock
Battery positive (+) → Terminal 1 Battery negative (-) → Terminal 4	Unlock

**HINT:**

If the result is not as specified, replace the door lock assembly.

- (b) Measure the resistance according to the value(s) in the table below.

**Standard resistance**

Tester Connection	Door Lock Position	Specified Condition
7 - 8	Lock	10 kΩ or higher
7 - 8	Unlock	Below 1 Ω

**HINT:**

If the result is not as specified, replace the door lock assembly.


- (c) Measure the resistance according to the value(s) in the table below.

**Standard resistance**


Tester Connection	Condition	Specified Condition
7 - 9	ON (Door lock set to LOCK)	Below 1 Ω
7 - 9, 7 - 10	OFF (Free)	10 kΩ or higher
7 - 10	ON (Door lock set to UNLOCK)	Below 1 Ω


**HINT:**

If the result is not as specified, replace the door lock assembly.



**DL**





**2. INSPECT FRONT DOOR LOCK ASSEMBLY RH**

- (a) Apply battery voltage to the door lock and check operation of the motor.

**OK**

Measurement Condition	Specified Condition
Battery positive (+) → Terminal 4 Battery negative (-) → Terminal 1	Lock
Battery positive (+) → Terminal 1 Battery negative (-) → Terminal 4	Unlock

**HINT:**

If the result is not as specified, replace the door lock assembly.

- (b) Measure the resistance according to the value(s) in the table below.

**Standard resistance**

Tester Connection	Door Lock Position	Specified Condition
7 - 8	Lock	10 kΩ or higher
7 - 8	Unlock	Below 1 Ω

**HINT:**

If the result is not as specified, replace the door lock assembly.