## **DISASSEMBLY**

- 1. REMOVE REAR BUMPER ENERGY ABSORBER
- 2. REMOVE REAR BUMPER BAR
- 3. REMOVE REAR BUMPER REINFORCEMENT NO.1
  - (a) Remove the 6 nuts and reinforcement.
- 4. REMOVE REAR BUMPER SIDE SUPPORT
  - (a) Remove the screw and side support.
- 5. REMOVE REAR BUMPER SIDE RETAINER
  - (a) Remove the 2 screws and side retainer.
- 6. REMOVE REFLEX REFLECTOR ASSEMBLY
  - (a) Remove the bolt and reflector.

## REASSEMBLY

- 1. INSTALL REFLEX REFLECTOR ASSEMBLY
- 2. INSTALL REAR BUMPER SIDE RETAINER
- 3. INSTALL REAR BUMPER SIDE SUPPORT
- 4. INSTALL REAR BUMPER REINFORCEMENT NO.1
  - (a) Install the reinforcement with the 6 nuts. Torque: 27 N\*m (275 kgf\*cm, 20 ft.\*lbf)
- 5. INSTALL REAR BUMPER BAR
- 6. INSTALL REAR BUMPER ENERGY ABSORBER