



REMOVAL

1. DRAIN ENGINE COOLANT (See page [CO-7](#))
2. REMOVE FR WIPER ARM LH (See page [WW-37](#))
3. REMOVE FR WIPER ARM RH (See page [WW-37](#))
4. REMOVE FRONT FENDER TO COWL SIDE SEAL LH
5. REMOVE FRONT FENDER TO COWL SIDE SEAL RH
6. REMOVE COWL TOP VENTILATOR LOUVER SUB-ASSEMBLY (See page [WW-37](#))
7. REMOVE WINDSHIELD WIPER LINK ASSEMBLY (See page [WW-37](#))
8. REMOVE COWL TOP PANEL SUB-ASSEMBLY OUTER (See page [FU-10](#))
9. REMOVE V-BANK COVER SUB-ASSEMBLY (See page [ES-372](#))
10. REMOVE AIR CLEANER CAP SUB-ASSEMBLY (See page [FU-10](#))
11. REMOVE EMISSION CONTROL VALVE SET (See page [FU-11](#))
12. REMOVE INTAKE AIR SURGE TANK (See page [FU-11](#))
13. REMOVE INTAKE AIR CONTROL VALVE ASSEMBLY NO.2
 - (a) Remove the 3 bolts and nut.
 - (b) Rotate the lever to the closed position as shown in the illustration and pull out the intake air control valve No.2.
 - (c) Remove the gasket from the intake air surge tank.




INSPECTION

1. INSPECT INTAKE AIR CONTROL VALVE ASSEMBLY NO.2
 - (a) With 26.7 kPa (200 mmHg, 7.9 in.Hg) of vacuum applied to the actuator, check that the actuator rod moves.
 - (b) One minute after applying the vacuum, check that the actuator rod does not return.
 - (c) If the operation is not as specified, replace the intake air control valve assembly No.2.

NOTICE:


Do not adjust the adjust screw.



2. INSPECT INTAKE AIR CONTROL VALVE ASSEMBLY NO.3

(a) Inspect actuator operation

- (1) With 26.7 kPa (200 mmHg, 7.9 in.Hg) of vacuum applied to the actuator, check that the actuator rod moves.
- (2) One minute after applying the vacuum, check that the actuator rod does not return.
- (3) If the operation is not as specified, replace the intake air control valve No.3.




(b) Inspect VSV for continuity

- (1) Using an ohmmeter, check for continuity between the terminals.

Resistance:

37 to 44 Ω at 20°C (68°F)


If there is no continuity, replace the VSV.



(2) Inspect the VSV for ground.

- Using an ohmmeter, check that there is no continuity between each terminal and the body.

If there is continuity, replace the VSV.



(3) Inspect the VSV operation.

- Check that air flows from port E to the filter.
- Apply battery voltage across the terminals.
- Check that air flows from port E to F.

If operation is not as specified, replace the VSV.