


Door Courtesy Switch Circuit

DESCRIPTION

The body ECU detects the condition of the door courtesy switch assembly.

WIRING DIAGRAM



1 READ VALUE OF INTELLIGENT TESTER

- (a) Connect the intelligent tester to the DLC3.
- (b) Turn the ignition switch to the ON position and press the intelligent tester main switch ON.
- (c) Select the items below in the DATA LIST, and read the displays on the intelligent tester.

BODY

Item	Measurement Item/ Display (Range)	Normal Condition	Diagnostic Note
D DOR CTY SW	Driver's door courtesy SW signal/ ON or OFF OK	ON: Driver's door is open OFF: Driver's door is closed	-
P DOR CYT SW	Passenger's door courtesy SW signal/ON or OFF	ON: Front passenger door is open OFF: Front passenger door is closed	-

Item	Measurement Item/ Display (Range)	Normal Condition	Diagnostic Note
Rr DOR CTY SW	Rear slide door courtesy SW signal/ON or OFF	ON: Either right or left rear door is open OFF: Both the right and left doors are closed	-

NG

Go to step 2

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

2 INSPECT COURTESY LIGHT SWITCH

- (a) Inspect front door courtesy switch (See page [LI-235](#)).
- (b) Inspect rear door courtesy switch (See page [LI-236](#)).

NG


REPLACE COURTESY LIGHT SWITCH

OK


**3 CHECK HARNESS AND CONNECTOR (COURTESY LIGHT SWITCH - INSTRUMENT
PANEL J/B ASSEMBLY)**

- (a) Disconnect the 1O, B5 and B6 connectors from the instrument panel junction block assembly.
- (b) Measure the resistance according to the value(s) in the table below.

Instrument Panel Junction Block Assembly Front Side Wire Harness View:



Multiplex Network Body ECU:



E111818E02

Resistance

Tester connection	Condition	Specified condition
B6-14 - Body ground	Front driver door is OPEN Front driver door is CLOSE	Below 1 Ω 10 kΩ or higher
B5-23 - Body ground	Front passenger door is OPEN Front passenger door is CLOSE	Below 1 Ω 10 kΩ or higher
10-7 - Body ground	Rear LH door is OPEN Rear LH door is CLOSE	Below 1 Ω 10 kΩ or higher
B6-16 - Body ground	Rear RH door is OPEN Rear RH door is CLOSE	Below 1 Ω 10 kΩ or higher

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE