



Taillight Relay Circuit

DESCRIPTION

The body ECU controls TAIL relay when the signal is received from the headlight dimmer switch assembly.

WIRING DIAGRAM





*1: w/ Air Suspension System
 *2: w/o Air Suspension System

C

1 PERFORM ACTIVE TEST BY INTELLIGENT TESTER

- (a) Connect the intelligent tester to the DLC3.
- (b) Turn the ignition switch to the ON position and press the intelligent tester main switch ON.
- (c) Select the items below in the ACTIVE TEST and then check that the relay operates.

BODY

Item	Test Details	Diagnostic Note
TAIL LIGHT	Turn Tail light relay ON/OFF	-

NG → **Go to step 2**

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

2 INSPECT FUSE


- (a) Inspect TAIL fuse and GAUGE No.1 fuse in the instrument panel junction block assembly.

Resistance:
Below 1 Ω

NG → **REPLACE FUSE**

OK

3 INSPECT RELAY



- (a) Inspect TAIL relay continuity.
 - (1) Remove the TAIL relay from the instrument panel J/ B assembly.
 - (2) Measure the resistance according to the value(s) in the table below.

Resistance


Tester connection	Condition	Specified condition
3 - 5	Always	10 kΩ or higher
3 - 5	Apply B+ between the terminal 1 and 2	Below 1 Ω

NG → **REPLACE RELAY**

OK

4 INSPECT INSTRUMENT PANEL JUNCTION BLOCK ASSEMBLY (POWER SOURCE CIRCUIT)

(a) Measure the voltage according to the value(s) in the table below.



Voltage

Tester connection	Condition	Specified condition
1A-1 - Body ground	Always	10 to 14 V


NG REPAIR OR REPLACE HARNESS OR CONNECTOR (BATTERY - INSTRUMENT PANEL JUNCTION BLOCK ASSEMBLY)

OK

5 INSPECT INSTRUMENT PANEL JUNCTION BLOCK ASSEMBLY

(a) Measure the voltage according to the value(s) in the table below.

Instrument Panel Junction Block Assembly Front Side Wire Harness View:



Voltage

Tester connection	Condition	Specified condition
1C-4 - Body ground	Light control switch OFF → TAIL	Below 1 V → 10 to 14 V
1C-5 - Body ground	Light control switch OFF → TAIL	Below 1 V → 10 to 14 V
1D-6 - Body ground	Light control switch OFF → TAIL	Below 1 V → 10 to 14 V
1D-14 - Body ground	Light control switch OFF → TAIL	Below 1 V → 10 to 14 V
1P-8 - Body ground	Light control switch OFF → TAIL	Below 1 V → 10 to 14 V
1O-9 - Body ground	Ignition switch ON	Below 1 V → 10 to 14 V


NG → **PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE**

OK

6 INSPECT REAR JUNCTION BLOCK

- (a) Measure the voltage according to the value(s) in the table below.

Rear Junction Block Assembly Wire Harness View:



Voltage

Tester connection	Condition	Specified condition
5B-7 - Body ground	Ignition switch OFF → ON	Below 1 V → 10 to 14 V
5C-15 - Body ground	Light control switch OFF → TAIL	Below 1 V → 10 to 14 V


NG → **REPAIR OR REPLACE HARNESS OR CONNECTOR (INSTRUMENT PANEL J/B ASSEMBLY - REAR JUNCTION BLOCK)**

OK

7 INSPECT REAR JUNCTION BLOCK

- (a) Measure the voltage according to the value(s) in the table below.

Rear Junction Block Assembly Wire Harness View:



Voltage

Tester connection	Condition	Specified condition
5C-16 - Body ground	Headlight dimmer switch OFF → TAIL	Below 1 V → 10 to 14 V
5D-5 - Body ground	Headlight dimmer switch OFF → TAIL	Below 1 V → 10 to 14 V
5D-9 - Body ground	Headlight dimmer switch OFF → TAIL	Below 1 V → 10 to 14 V
5D-10 - Body ground	Headlight dimmer switch OFF → TAIL	Below 1 V → 10 to 14 V
5D-11 - Body ground	Headlight dimmer switch OFF → TAIL	Below 1 V → 10 to 14 V

NG

REPLACE REAR JUNCTION BLOCK

OK

REPAIR OR REPLACE HARNESS OR CONNECTOR