


Height Control Sensor Circuit

DESCRIPTION

The headlight beam level control ECU receives the height control sensor signal from the height control sensor sub-assembly or headlight control ECU.


The headlight beam level control ECU calculates a height value from the height control signal. The voltage at the power source of the height control sensor is corrected when SHF or SHR is detected.

WIRING DIAGRAM



1 INSPECT HEIGHT CONTROL SENSOR SUB-ASSEMBLY REAR RH

- Connect 3 dry cell batteries (1.5 V) in a series.
- Connect the positive (+) lead from the battery to terminal 1 and negative (-) lead from the battery to terminal 3.
- Measure voltage between terminal 2 and terminal 3 when slowly move the link up and down.



Voltage

Link Angle	Standard voltage
+45° (High)	4.5 V
0° (Normal)	2.5 V
-45° (Low)	0.5 V

NG

REPLACE HEIGHT CONTROL SENSOR SUB-ASSEMBLY REAR RH


OK




2 CHECK HARNESS AND CONNECTOR (HEIGHT CONTROL SENSOR REAR RH - LEVEL CONTROL ECU)

Wire Harness View:

Height Control Sensor Rear RH



Headlight Beam Level Control ECU



H

B110647E01

- (a) Disconnect the H26 connector of height control sensor sub-assembly and the H17 connector of headlight leveling ECU assembly.
- (b) Measure the resistance according to the value(s) in the table below.

Resistance

Tester connection	Condition	Specified condition
H17-16 (SGR) - H26-1 (SHG)	Always	Below 1 Ω
H17-18 (SHR) - H26-2 (SHRR)	Always	Below 1 Ω
H17-20 (SBR) - H26-3 (SHB)	Always	Below 1 Ω
H26-1 (SHG) - Body ground	Always	10 kΩ or higher
H26-2 (SHRR) - Body ground	Always	10 kΩ or higher
H26-3 (SHB) - Body ground	Always	10 kΩ or higher

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE