

DTC

B1188/56

Short to B+ in Front Passenger Side Squib 2nd Step Circuit**DESCRIPTION**

The front passenger side squib 2nd step circuit consists of the center airbag sensor assembly and the front passenger airbag assembly.

The circuit instructs the SRS to deploy when deployment conditions are met.

DTC B1188/56 is recorded when a short to B+ is detected in the front passenger side squib 2nd step circuit.


DTC No.	DTC Detecting Condition	Trouble Area
B1188/56	<ul style="list-style-type: none"> Short circuit in passenger side squib 2nd step wire harness (to B+) Passenger side squib 2nd step malfunction Center airbag sensor assembly malfunction 	<ul style="list-style-type: none"> Front passenger airbag assembly (Passenger side squib 2nd step) Center airbag sensor assembly Instrument panel wire

RS

WIRING DIAGRAM

See page [RS-258](#).

1

CHECK FRONT PASSENGER AIRBAG ASSEMBLY (PASSENGER SIDE SQUIB 2ND STEP)

- Turn the ignition switch to the LOCK position.
- Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- Disconnect the connectors from the front passenger airbag assembly.
- Connect the white wire side of SST (resistance 2.1 Ω) to the instrument panel wire.

CAUTION:

Never connect a tester to the front passenger airbag assembly (Front passenger side squib 2nd step) for measurement, as this may lead to a serious injury due to airbag deployment.

NOTICE:

Do not forcibly insert the SST into the terminals of the connector when connecting.

Insert the SST straight into the terminals of the connector.

SST 09843-18060

- Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- Clear the DTCs stored in memory (See page [RS-32](#)).
- Turn the ignition switch to the LOCK position.
- Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- Check the DTCs (See page [RS-32](#)).

OK:

DTC B1188/56 is not output.

HINT:

Codes other than DTC B1188/56 may be output at this time, but they are not related to this check.

NG


Go to step 2

OK

REPLACE FRONT PASSENGER AIRBAG ASSEMBLY

2 CHECK INSTRUMENT PANEL WIRE (PASSENGER SIDE SQUIB 2ND STEP CIRCUIT)

RS



- (a) Disconnect the connector from the center airbag sensor assembly.
- (b) Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- (c) Turn the ignition switch to the ON position.
- (d) Measure the voltage according to the value(s) in the table below.

Voltage


Tester connection	Condition	Specified condition
A24-2 (P2+) - Body ground	Ignition switch ON	Below 1 V
A24-1 (P2-) - Body ground	Ignition switch ON	Below 1 V

NG

REPAIR OR REPLACE INSTRUMENT PANEL WIRE

OK

3 CHECK CENTER AIRBAG SENSOR ASSEMBLY



- Turn the ignition switch to the LOCK position.
- Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- Connect the connectors to the front passenger airbag assembly and the center airbag sensor assembly.
- Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- Clear the DTCs stored in memory (See page RS-32).
- Turn the ignition switch to the LOCK position.
- Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- Check the DTCs (See page RS-32).

OK:

DTC B1188/56 is not output.

HINT:

Codes other than DTC B1188/56 may be output at this time, but they are not related to this check.

NG

REPLACE CENTER AIRBAG SENSOR ASSEMBLY

OK

USE SIMULATION METHOD TO CHECK