

DTC**B0101/14****Open in Driver Side Squib Circuit****DESCRIPTION**

The driver side squib circuit consists of the center airbag sensor assembly, the spiral cable and the steering pad.


The circuit instructs the SRS to deploy when deployment conditions are met.

DTC B0101/14 is recorded when an open circuit is detected in the driver side squib circuit.

DTC No.	DTC Detecting Condition	Trouble Area
B0101/14	<ul style="list-style-type: none"> Open circuit in D+ wire harness or D- wire harness of driver side squib Driver side squib malfunction Spiral cable malfunction Center airbag sensor assembly malfunction 	<ul style="list-style-type: none"> Steering pad (Driver side squib) Spiral cable Center airbag sensor assembly Instrument panel wire

RS**WIRING DIAGRAM**

See page [RS-41](#).

1**CHECK STEERING PAD (DRIVER SIDE SQUIB)**

- Turn the ignition switch to the LOCK position.
- Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- Disconnect the connectors from the steering pad.
- Connect the white wire side of SST (resistance 2.1 Ω) to the spiral cable.

CAUTION:

Never connect a tester to the steering pad (Driver side squib) for measurement, as this may lead to a serious injury due to airbag deployment.

NOTICE:

Do not forcibly insert the SST into the terminals of the connector when connecting.

Insert the SST straight into the terminals of the connector.

SST 09843-18060

- Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- Clear the DTCs stored in memory (See page [RS-32](#)).
- Turn the ignition switch to the LOCK position.
- Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- Check the DTCs (See page [RS-32](#)).

OK:

DTC B0101/14 is not output.

HINT:


Codes other than DTC B0101/14 may be output at this time, but they are not related to this check.

NG**Go to step 2**

OK

REPLACE SPIRAL CABLE

2 CHECK DRIVER SIDE SQUIB CIRCUIT



- (a) Disconnect the connector from the center airbag sensor assembly.
- (b) Measure the resistance according to the value(s) in the table below.

Resistance

Tester connection	Condition	Specified condition
D+ - D-	Always	Below 1 Ω


RS

NG

Go to step 4

OK

3 CHECK CENTER AIRBAG SENSOR ASSEMBLY



- (a) Connect the connectors to the steering pad and the center airbag sensor assembly.
- (b) Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- (c) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (d) Clear the DTCs stored in memory (See page RS-32).
- (e) Turn the ignition switch to the LOCK position.
- (f) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (g) Check the DTCs (See page RS-32).

OK:

DTC B0101/14 is not output.

HINT:

Codes other than code B0101/14 may be output at this time, but they are not related to this check.

NG


REPLACE CENTER AIRBAG SENSOR ASSEMBLY

OK

USE SIMULATION METHOD TO CHECK

4 CHECK INSTRUMENT PANEL WIRE

RS



- (a) Disconnect the instrument panel wire connector from the spiral cable.
- (b) Measure the resistance according to the value(s) in the table below.

Resistance


Tester connection	Condition	Specified condition
A25-1 (D+) - A25-2 (D-)	Always	Below 1 Ω

NG

REPAIR OR REPLACE INSTRUMENT PANEL WIRE

OK

5 CHECK SPIRAL CABLE



(a) Measure the resistance according to the value(s) in the table below.

Resistance

Tester connection	Condition	Specified condition
D+ - D-	Always	Below 1 Ω

NG → **REPLACE SPIRAL CABLE**

RS

OK

USE SIMULATION METHOD TO CHECK