

## PROBLEM SYMPTOMS TABLE

### AIR SUSPENSION SYSTEM

Symptom	Suspected area	See page
Vehicle height control function does not operate	1. Freezing of the air tube 2. Power source circuit 3. Crankshaft position sensor circuit 4. Height control OFF switch circuit 5. Height control switch circuit 6. Height control sensor circuit 7. Height control solenoid valve circuit 8. Exhaust solenoid valve circuit 9. AIR SUS relay circuit 10. Height control compressor circuit 11. Suspension control ECU	- <a href="#">SC-79</a> <a href="#">SC-87</a> <a href="#">SC-96</a> <a href="#">SC-93</a> <a href="#">SC-36</a> <a href="#">SC-48</a> <a href="#">SC-45</a> <a href="#">SC-54</a> <a href="#">SC-59</a> <a href="#">SC-76</a>
Height control indicator light does not switch to the correct position in accordance to height control switch operation	1. Power source circuit 2. Crankshaft position sensor sirsuit 3. Height control OFF switch circuit 4. Height control switch circuit 5. Height control sensor circuit 6. Height control solenoid valve circuit 7. Exhaust solenoid valve circuit 8. AIR SUS relay circuit 9. Height control compressor circuit 10. Speed sensor circuit 11. Suspension control ECU	<a href="#">SC-79</a> <a href="#">SC-87</a> <a href="#">SC-96</a> <a href="#">SC-93</a> <a href="#">SC-36</a> <a href="#">SC-48</a> <a href="#">SC-45</a> <a href="#">SC-54</a> <a href="#">SC-59</a> <a href="#">SC-84</a> <a href="#">SC-76</a>
Hunting of vehicle height occurs	1. Air leakage 2. Height control sensor circuit 3. Suspension control ECU	- <a href="#">SC-36</a> <a href="#">SC-76</a>
Vehicle height control operates, but vehicle height is uneven	1. Air leakage 2. Clogging of the Air tube 3. Height control sensor link sub-assembly 4. Height control sensor circuit 5. Height control soelnoid valve circuit 6. Suspension control ECU	- <a href="#">SC-124</a> <a href="#">SC-36</a> <a href="#">SC-48</a> <a href="#">SC-76</a>
Vehicle height control operates, but vehicle height is high or low. (Vehicle height in NORMAL mode differs from the standard value)	1. Height control sensor link sub-assembly 2. Height control sensor circuit 3. Suspension control ECU	<a href="#">SC-124</a> <a href="#">SC-36</a> <a href="#">SC-76</a>
When vehicle height control is adjusted, but it stops at extremely high or extremely low position	1. Height control sensor circuit 2. Height control sensor link sub-assembly 3. Suspension control ECU	<a href="#">SC-36</a> <a href="#">SC-124</a> <a href="#">SC-76</a>
Height control OFF indicator light condition is abnormal	1. Power source circuit 2. Height control OFF switch circuit 3. Height control OFF indicator light circuit 4. Suspension control ECU	<a href="#">SC-79</a> <a href="#">SC-96</a> <a href="#">SC-104</a> <a href="#">SC-76</a>
Height control indicator light condition is abnormal	1. Power source circuit 2. Height control indicator light circuit 3. Suspension control ECU	<a href="#">SC-79</a> <a href="#">SC-102</a> <a href="#">SC-76</a>
Access mode indicator light condition is abnormal	1. Power source circuit 2. Suspension control ECU	<a href="#">SC-79</a> <a href="#">SC-76</a>

SC

Symptom	Suspected area	See page
DTC check cannot be completed	1. Power source circuit	SC-79
	2. TC terminal circuit	SC-106
	3. Height control OFF indicator light circuit	SC-104
	4. Suspension control ECU	SC-76
Test mode cannot be completed	1. Power source circuit	SC-79
	2. TC terminal circuit	SC-106
	3. Suspension control ECU	SC-76
Vehicle height is extremely low when vehicle is parked	1. Air leakage	-
	2. Height control cylinder assembly rear	-
	3. Height control sensor link sub-assembly	SC-124
	4. Height control solenoid valve circuit	SC-48
	5. Exhaust solenoid valve circuit	SC-45
Compressor motor continues to operate	1. Air leakage	-
	2. Air tube clogged	-
	3. Pneumatic cylinder assembly	-
	4. Height control sensor link sub-assembly	SC-124
	5. Height control solenoid valve circuit	SC-48
	6. Exhaust solenoid valve circuit	SC-45
	7. Tank solenoid valve circuit	SC-67
	8. AIR SUS relay circuit	SC-54
	9. Height control compressor circuit	SC-59
	10. Suspension control ECU	SC-76