


## ECU Power Source Circuit

### DESCRIPTION

This circuit provides power for multiplex network body ECU operation.

### WIRING DIAGRAM



#### 1 INSPECT FUSE (ECU-B)

- (a) Remove the ECU-B fuse from the fusible link block.
- (b) Measure the resistance.

**Standard resistance:**

**Below 1 Ω**


NG

REPLACE FUSE

OK

#### 2 CHECK INSTRUMENT PANEL JUNCTION BLOCK ASSEMBLY (MULTIPLEX NETWORK BODY ECU) (POWER SOURCE)

- (a) Install the ECU-B fuse to the fusible link block.



- (b) Disconnect the 1D J/B connector.
- (c) Measure the voltage according to the value(s) in the table below.


**Standard voltage**

Symbol (Tester Connection)	Specified Condition
BECU (1D-10) - Body ground	10 to 14 V

**NG** → **REPAIR OR REPLACE HARNESS OR CONNECTOR**

**OK**

**3 CHECK HARNESS AND CONNECTOR (INSTRUMENT PANEL J/B (BODY ECU) - BODY GROUND)**



- (a) Disconnect the 1F and 1M J/B connectors.
- (b) Measure the resistance according to the value(s) in the table below.

**Standard resistance**

Symbol (Tester Connection)	Specified Condition
GND1 (1F-10) - Body ground	Below 1 Ω
GND2 (1M-9) - Body ground	

**NG** → **REPAIR OR REPLACE HARNESS OR CONNECTOR**

**OK**

**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE**

**TD**