

## Ambient Temperature Sensor Circuit


### DESCRIPTION

The ambient temperature sensor sends the outside temperature signal to the ECM. The ECM transmits the signal to the skid control ECU as a communication signal. The skid control ECU controls the tire pressure warning system, depending on the changes of the outside temperature.

HINT:

The signal sent from the ambient temperature sensor is also used in the A/C.

### WIRING DIAGRAM



## 1 CHECK DTC OUTPUT

- (a) Check if the normal code is output by SFI system (See page [ES-37](#) ).

OK:


Normal code is output.

NG

REPAIR CIRCUITS INDICATED BY OUTPUT DTCS

OK

**2 CHECK HARNESS AND CONNECTOR (BRAKE ACTUATOR ASSEMBLY - ECM)**



- (a) Disconnect the brake actuator assembly S1 connector and ECM E5 connector.
- (b) Measure the resistance between each terminal of brake actuator assembly and ECM wire harness side connectors.

**Resistance**

Tester connection	Specified condition
S1-9 (ENG+) - E5-24 (ENG+)	Below 1 Ω
S1-23 (ENG-) - E5-30 (ENG-)	Below 1 Ω

- (c) Measure the resistance between each terminal brake actuator assembly wire harness side connector and body ground.


**Resistance**

Tester connection	Specified condition
S1-9 (ENG+) - Body ground	10 kΩ or higher
S1-23 (ENG-) - Body ground	10 kΩ or higher

**NG** **REPAIR OR REPLACE HARNESS OR CONNECTOR**


**OK**

**3 INSPECT ECM (ENG+, ENG- OUTPUT)**



- (a) Connect the brake actuator assembly S1 connector and ECM E5 connector.
- (b) Remove the ECM with the connectors connected.
- (c) Turn the ignition switch to the ON position.
- (d) Using an oscilloscope, connect the terminals, as shown in the chart below.

Tester Connection
E5-24 (ENG+) - E7-1 (E1)



- (e) With the engine idling, check the output waveform.

**OK:**


**Signal waveform appears as shown in the illustration.**

**HINT:**

As the vehicle speed increases, the waveform cycle narrows.

- (f) Using an oscilloscope, connect the terminals, as shown in the chart below.

Tester Connection
E5-30 (ENG-) - E7-1 (E1)



(g) With the engine idling, check the output waveform.

**OK:**

**Signal waveform appears as shown in the illustration.**

**HINT:**

As the engine speed increases, the waveform cycle narrows.

**NG**

**REPLACE ECM**

**OK**

**REPLACE BRAKE ACTUATOR ASSEMBLY**