

# 1990 Mazda MX-5 Workshop Manual

## FORWARD

This workshop manual is intended for use by service technicians of Authorised Mazda Dealers to help them service Mazda vehicles. It can also be useful to owners and operators of Mazda vehicles in diagnosing some problems and performing limited repair and maintenance on Mazda vehicles.

For proper repair and maintenance a thorough familiarisation with this manual is important, and it should always be kept in a handy place for quick and easy reference.

All the contents of this manual, including drawing and specifications, are the latest available at the time of printing. As modifications affecting repair or maintenance occur, relevant information supplementary to this volume will be made available at Authorised Mazda dealers. This manual should be kept up-to-date.

Mazda Motor Corporation reserves the right to alter the specifications and contents of this manual without obligation or advance notice.

Mazda Motor Corporation  
HIROSHIMA, JAPAN

### APPLICATION:

This manual is applicable to vehicles beginning with the Vehicle Identification Numbers (VIN) shown on the following page.

## CONTENTS

Title	Section
General Information	GI
Pre-Delivery Inspection and Scheduled Maintenance Services	A
Engine	B
Lubrication System	D
Cooling System	E
Fuel and Emission Control Systems	F
Engine Electrical System	G
Clutch	H
Manual Transmission	J
Propeller Shaft	L
Front and Rear Axles	M
Steering System	N
Braking System	P
Wheels and Tires	Q
Suspension	R
Body	S
Body Electrical System	T
Heater and Air Conditioner Systems	U
Technical Data	TD
Special Tools	ST
Parts Index	PI

© 1989 Mazda Motor Corporation  
PRINTED IN JAPAN, MAR. '89  
1193-10-89C

# VEHICLE IDENTIFICATION NUMBERS (VIN)

JM1 NA351 \* L0 100001 ~

JM1 NA352 \* L0 100001 ~



# GENERAL INFORMATION

<b>IMPORTANT INFORMATION</b> .....	<b>GI- 2</b>
BASIC ASSUMPTIONS .....	<b>GI- 2</b>
SAFETY RISK .....	<b>GI- 2</b>
POSSIBLE LOSS OF WARRANTY .....	<b>GI- 2</b>
WARNING ON LUBRICANTS AND GREASES .....	<b>GI- 2</b>
<b>HOW TO USE THIS MANUAL</b> .....	<b>GI- 3</b>
PREPARATION .....	<b>GI- 3</b>
REPAIR PROCEDURE.....	<b>GI- 3</b>
SYMBOLS.....	<b>GI- 4</b>
NOTES, CAUTIONS, AND WARNINGS.....	<b>GI- 4</b>
<b>FUNDAMENTAL PROCEDURES</b> .....	<b>GI- 4</b>
PROTECTION OF VEHICLE .....	<b>GI- 4</b>
A WORD ABOUT SAFETY .....	<b>GI- 5</b>
PREPARATION OF TOOLS AND MEASURING EQUIPMENT.....	<b>GI- 5</b>
SPECIAL TOOLS.....	<b>GI- 5</b>
REMOVAL OF PARTS.....	<b>GI- 5</b>
DISASSEMBLY .....	<b>GI- 5</b>
REASSEMBLY .....	<b>GI- 6</b>
ADJUSTMENTS .....	<b>GI- 7</b>
RUBBER PARTS AND TUBING .....	<b>GI- 7</b>
<b>JACK AND SAFETY STAND POSITIONS</b> ....	<b>GI- 8</b>
<b>VEHICLE LIFT (2-SUPPORT TYPE) POSITIONS</b> .....	<b>GI- 8</b>
<b>TOWING</b> .....	<b>GI- 9</b>
<b>IDENTIFICATION NUMBER LOCATIONS</b> .....	<b>GI- 9</b>
<b>UNITS</b> .....	<b>GI-10</b>
<b>ABBREVIATIONS</b> .....	<b>GI-10</b>
<b>CAUTION</b> .....	<b>GI-11</b>
INSTALLATION OF MOBILE TWO-WAY RADIO SYSTEM .....	<b>GI-11</b>
SERVICE PRECAUTIONS CONCERNING AIR BAG SYSTEM .....	<b>GI-12</b>
BATTERY.....	<b>GI-13</b>
POWER CONNECTOR IN ENGINE COMPARTMENT.....	<b>GI-13</b>
AUDIO ANTI-THEFT SYSTEM.....	<b>GI-13</b>
ELECTRICAL TROUBLESHOOTING TOOLS	<b>GI-14</b>
CAUTION WITH ELECTRICAL PARTS.....	<b>GI-15</b>

**IMPORTANT INFORMATION****BASIC ASSUMPTIONS**

This workshop manual assumes that you have certain special tools that are necessary for the safe and efficient performance of service operations on Mazda vehicles and that you know how to use them properly. It also assumes that you are familiar with automobile systems and basic service and repair procedures. You should not attempt to use this manual unless these assumptions are correct and you understand the consequences described below.

**SAFETY RISK**

This manual contains certain notes, warnings, and other precautionary information that you should carefully read and follow to reduce the risk of personal injury to yourself or others and the risk of improper service that may damage the vehicle or render it unsafe. If there is no such information in regard to any specific service method, this does not mean there is no possibility that personal safety or vehicle safety will be jeopardized by the use of incorrect methods or tools.

**POSSIBLE LOSS OF WARRANTY**

The manufacturer's warranty on Mazda vehicles and engines can be voided if improper service or repairs are performed by persons other than those at an Authorized Mazda Dealer.

**WARNING ON LUBRICANTS AND GREASES**

Avoid all prolonged and repeated contact with mineral oils, especially used oils. Used oils contaminated during service (e.g., engine sump oils) are more irritating and more likely to cause serious effects, including skin cancer, in the event of gross and prolonged skin contact.

Wash skin thoroughly after work involving oil.

Protective hand cleaners may be of value provided they can be removed from the skin with water. Do not use gasoline, paraffin, or other solvents to remove oil from the skin.

Lubricants and greases may be slightly irritating to the eyes.

Repeated or prolonged skin contact should be avoided by wearing protective clothing. Particular care should be taken with used oils and greases containing lead. Do not allow work clothing to be contaminated with oil. Dry clean or launder such clothing at regular intervals.

05UGIX-002

## HOW TO USE THIS MANUAL

### PREPARATION

PREPARATION points out the needed **Special Service Tool (SST)** for the service operation that it proceeds. Gather all necessary **SST** before beginning work.

#### Example:

**N TIE-ROD END BOOT AND STEERING GEAR BOOT**

**TIE-ROD END BOOT AND STEERING GEAR BOOT**

**PREPARATION**

49 0118 850C Puller, ball joint	49 H028 301 Installer, boot
------------------------------------	--------------------------------

SST NUMBER 49 H028 301 Installer, boot	
--	--

SST NAME      SST ILLUSTRATION

05UGIX-003

### REPAIR PROCEDURE

1. Most repair operations begin with an overview illustration. It identifies the components, shows how the parts fit together, and describes visual parts inspections. If a damaged or worn part is found, repair or replace it as necessary.
2. Expendable parts, tightening torques, and symbols for oil, grease, and sealant are shown in the overview illustration.
3. Pages related to service procedures are shown under the illustration. Refer to this information when servicing the related part.

#### Example:

73-107 (7.4-10.9, 54-79)

128-284 (13-20, 54-610)

16-26 (1.6-2.6, 13-19)

N-m (m-kg, ft-lb)

\*2  
(7.0-8.5, 6.1-6.1)

REPLACE

SELECTIVE

SELECTIVE

REMOVAL

INSPECT FOR DAMAGE OR ROUGH CONDITION

page M-22

page M-24

page M-21

page M-22

page M-24

page M-21

page M-22







page M-24

\*1: The numbers (① ex.) refer to parts identification and where necessary servicing procedure.

\*2: Units are in N·m (m·kg, ft·lb) unless otherwise specified.

**SYMBOLS**

There are six symbols indicating oil, grease, and sealant. These symbols show the points of applying such materials during service.

Symbol	Meaning	Kind
	Apply oil	New engine oil or gear oil as appropriate
	Apply brake fluid	Only brake fluid
	Apply automatic transmission fluid	Only ATF
	Apply grease	Appropriate grease
	Apply sealant	Appropriate sealant
	Apply petroleum jelly	Appropriate petroleum jelly

05UGIX-005


**Note**

- When special oil or grease is needed, this is shown in the illustration.

**NOTES, CAUTIONS, AND WARNINGS**

As you read through the procedures, you will come across NOTES, CAUTIONS, and WARNINGS. Each one is there for a specific purpose. **NOTES** give you **added information** that will help you to complete a particular procedure. **CAUTIONS** are given to prevent you from making an error that could **damage the vehicle**. **WARNINGS** remind you to be especially careful in those areas where carelessness can cause **personal injury**. The following list contains some general WARNINGS you should follow when you work on a vehicle.


9MUGIX-036



05UGIX-006

**FUNDAMENTAL PROCEDURES****PROTECTION OF VEHICLE**

Always be sure to cover fenders, seats, and floor areas before starting work.




9MUGIX-003

**A WORD ABOUT SAFETY**

The following precautions must be followed when jacking up the vehicle.

1. Block the wheels.
2. Use only the specified jacking positions.
3. Support the vehicle with safety stands.


Start the engine only after making certain the engine compartment is clear of tools and people.



9MUGIX-038

**PREPARATION OF TOOLS AND MEASURING EQUIPMENT**


Be sure that all necessary tools and measuring equipment are available before starting any work.



47U0GX-005

**SPECIAL TOOLS**


Use special tools when they are required.



47U0GX-006

**REMOVAL OF PARTS**


While correcting a problem, try also to determine its cause. Begin work only after first learning which parts and subassemblies must be removed and disassembled for replacement or repair.



9MUGIX-039

**DISASSEMBLY**


If the disassembly procedure is complex, requiring many parts to be disassembled, all parts should be disassembled in a way that will not affect their performance or external appearance and identified so that reassembly can be performed easily and efficiently.



9MUGIX-040

### 1. Inspection of parts

When removed, each part should be carefully inspected for malfunctioning, deformation, damage, and other problems.




9MUGIX-041

### 2. Arrangement of parts

All disassembled parts should be carefully arranged for re-assembly.


Be sure to separate or otherwise identify the parts to be replaced from those that will be reused.



47U0GX-010

### 3. Cleaning parts for reuse

All parts to be reused should be carefully and thoroughly cleaned in the appropriate method.



9MUGIX-004

### REASSEMBLY


Standard values, such as torques and certain adjustments, must be strictly observed in the reassembly of all parts. Refer to STANDARD BOLT AND NUT TIGHTENING TORQUE in Section TD for tightening torques not mentioned in the main text.

If removed, these parts should be replaced with new ones:


- |                |                 |
|----------------|-----------------|
| 1. Oil seals   | 2. Gaskets      |
| 3. O-rings     | 4. Lock washers |
| 5. Cotter pins | 6. Nylon nuts   |

Depending on location:

1. Sealant should be applied to gaskets.
2. Oil should be applied to the moving components of parts.
3. Specified oil or grease should be applied at the prescribed locations (such as oil seals) before reassembly.




9MUGIX-042



67U0GX-002

## ADJUSTMENTS

Use suitable gauges and/or testers when making adjustments.



9MUGIX-005

## RUBBER PARTS AND TUBING

Prevent gasoline or oil from getting on rubber parts or tubing.


# GI JACK AND SAFETY STAND POSITIONS, VEHICLE LIFT (2-SUPPORT TYPE) POSITIONS

## JACK AND SAFETY STAND POSITIONS

### FRONT

#### Jack position:


At center of crossmember



05UGIX-007

#### Safety stand positions:

Side sills




9MUGIX-007

### REAR

#### Jack position:


At center of differential



05UGIX-008

#### Safety stand positions:

Side sills




9MUGIX-009

## VEHICLE LIFT (2-SUPPORT TYPE) POSITIONS

### FRONT

#### Frame

Side sills




05UGIX-009

### REAR


#### Frame

Side sills



05UGIX-010





05UGIX-011

**TOWING**

Proper towing equipment is necessary to prevent damage to the vehicle during any towing operation.

Laws and regulations applicable to vehicles in tow must always be observed.



Release the parking brake, place the shift lever in neutral, and set the ignition switch in the ACC position. As a rule, towed vehicles should be pulled with the driving wheels off the ground.

**WITH MANUAL TRANSMISSION**

If the transmission, rear axle, and steering system are not damaged, the vehicle may be towed on all four wheels. If any of these components is damaged, use a towing dolly.


**CAUTION**

- The power assists for the brakes and steering are inoperable while the engine is off.
- Do not use the tiedown hooks of the vehicle for towing. These hooks are designed ONLY for transport tiedown. If the tiedown hooks are used for towing, the front or rear skirt and bumper will be damaged.




**IDENTIFICATION NUMBER LOCATIONS**

VEHICLE IDENTIFICATION NUMBER (VIN)



ENGINE MODEL AND NUMBER



### UNITS

N-m (m-kg or cm-kg, ft-lb or in-lb).....	Torque
rpm.....	Revolutions per minute
A.....	Ampere(s)
V.....	Volt(s)
$\Omega$ .....	Ohm(s) (resistance)
kPa (kg/cm <sup>2</sup> , psi).....	Pressure (usually positive)
mmHg (inHg) .....	Pressure (usually negative)
W.....	Watt
liters (US qt, Imp qt) ....	Volume
mm (in).....	Length

89U0GX-006

### ABBREVIATIONS

ABDC .....	After bottom dead center
A/C .....	Air conditioner
ACC.....	Accessories
ATDC.....	After top dead center
BBDC .....	Before bottom dead center
BTDC.....	Before top dead center
DRL .....	Daytime running light
ECU.....	Engine control unit
EGI .....	Electronic gasoline injection
E/L .....	Electrical load
EX.....	Exhaust
IC.....	Integrated circuit
IN.....	Intake
INT.....	Intermittent
ISC.....	Idle-speed control
LH.....	Left hand
LSD.....	Limited slip differential
M.....	Motor, electric
MIL .....	Malfunction indicator lamp
M/T .....	Manual transmission
OFF .....	Switch off
ON.....	Switch on
PCV .....	Positive crankcase ventilation
PPF.....	Power plant frame
PRC .....	Pressure regulator control
P/S.....	Power steering
P/W.....	Power window
RH .....	Right hand
SST .....	Special service tool
TDC .....	Top dead center
VRIS.....	Variable resonance induction system

05UGIX-012


## CAUTION

## INSTALLATION OF MOBILE TWO-WAY RADIO SYSTEM


If a mobile two-way radio system is installed improperly or if a high-powered type is used, the EGI system and other systems may be affected.

When the vehicle is to be equipped with a mobile two-way radio, observe the following precautions:

1. Install the antenna at the farthest point from control units.
2. Install the antenna feeder as far as possible from the control unit harnesses (**at least 30 cm [11.8 in]**).
3. Ensure that the antenna and feeder are properly adjusted.
4. Do not install a high-powered mobile two-way radio system.



## SERVICE PRECAUTIONS CONCERNING AIR BAG SYSTEM



05UGIX-014

**Before Replacing any Components**

Before replacing of any air bag system components, or before disconnecting any connectors of the system, first disconnect the negative battery cable. Then remove the air bag module from the vehicle even if it has not failed.

**Prohibition of Component Disassembly and Wiring Harness Repair**

The components of the air bag system are not intended to be disassembled for service.

If a component failure is indicated by the diagnostic module, replace the suspected component after verifying the condition of the connections and the wire harness. **Do not disassemble any components.**

If an open circuit is found by a continuity test, replace the wire harness. **Do not attempt to repair the wiring.**

**Handling of Air Bag Module**

1. Do not use an ohmmeter for inspection of the air bag module; it may cause an accidental deployment.
2. When carrying a live air bag module, make sure the trim cover is pointed away from your body to prevent injury in the event of an accidental deployment.

- When placing a live air bag module on any surface, always face the trim cover upward. This will reduce the motion of the module if it is accidentally deployed.
- When handling a deployed air bag module, wear gloves and safety glasses because the deployed air bag module may display deposits of sodium hydroxide, a product of the gas generant combustion.
- An air bag module must be disposed of only by the proper procedure recommended for the specific situation. (Refer to page T-160.)

### Crash Sensor Installation

- The angle and direction of the sensor is very important for its proper operation. If a vehicle has been involved in a crash where the its front sheet metal has been damaged, inspect the body structure at the sensor mounting area for deformation. If damaged, restore it to its original shape.
- When installing a crash sensor, be sure to tighten the mounting bolts to the specified torque to ensure proper grounding. The ground circuit is made directly through the sensor's mounting plate.


### Adjustment of Clock Spring Connector

When the steering wheel is removed or the clock spring connector is replaced, the clockspring connector must be properly aligned.

Align the clock spring connector as follows:

- Set the front wheels straight ahead.
- Turn the clock spring connector clockwise until it stops. Do not force it.
- Return it 2.5 turns.
- Align (counterclockwise) the mark on the clock spring connector to the outer housing.
- Carefully install the steering wheel without disturbing the clockspring connector.


05UGIX-015



05UGIX-016

### BATTERY


- The battery is installed in the right rear of the trunk.
- The battery installed in the MX-5 Miata is unique. When a replacement battery is installed, install it with a Mazda genuine battery replacement kit or equivalent. (Refer to page G-10 for replacement.)



05UGIX-017

### POWER CONNECTOR IN ENGINE COMPARTMENT


- When using externally powered test equipment, connect it to the special power connector (Blue: 1-pin) for battery voltage.
- Do not ground the power connector terminal; the Wiper 20A fuse will be burned.




05UGIX-018

### AUDIO ANTI-THEFT SYSTEM


An audio with an anti-theft function is optionally available. Before removing the negative battery terminal or disconnecting the audio power source, obtain the code number and deactivate the audio anti-theft system. (Refer to page T-113.)




05UGIX-019




9MUGIX-020



05UGIX-020



05UGIX-021



05UGIX-022

## ELECTRICAL TROUBLESHOOTING TOOLS

### Test Light

The test light, as shown in the figure, uses a 12V bulb. The two lead wires should be connected to probes. The test light is used for simple voltage checks and for checking for short circuits.

#### Caution

- **When checking a control unit, never use a bulb over 3.4W.**

### Jumper Wire

The jumper wire is used for testing by shorting across switch terminals and ground connections.

#### Caution

- **Do not connect a jumper wire from the power source line to a body ground; this may cause burning or other damage to harnesses or electronic components.**

### Voltmeter

The DC voltmeter is used to measure circuit voltage. A voltmeter with a range of 15V or more is used by connecting the positive (+) probe (red lead wire) to the point where voltage is to be measured and the negative (-) probe (black lead wire) to a body ground.

### Diagnosis Connector

Insert the probe into the service hole when connecting a jumper wire to the diagnosis connector.

#### Caution


- **Do not insert the jumper wire probe into the diagnosis connector terminal, which may damage the terminal.**

### Ohmmeter

The ohmmeter is used to measure the resistance between two points in a circuit, and to check for continuity and short circuits.

#### Caution

- **Do not attempt to connect the ohmmeter to any circuit to which voltage is applied; this may burn or otherwise damage the ohmmeter.**




05UGIX-023

**CAUTION WITH ELECTRICAL PARTS**

**Battery Cable**

Before disconnecting connectors or removing electrical parts, disconnect the negative battery cable.




05UGIX-024

**Connectors**


**Disconnecting connectors**

Never pull on the wire harness when disconnecting connectors.



05UGIX-025


Connectors can be disconnected by pressing or pulling the lock lever as shown.



05UGIX-026

**Locking connectors**


When locking connectors, listen for a click that will indicate they are securely locked.



05UGIX-027

**Inspection**

1. When a tester is used to check for continuity or to measure voltage, insert the tester probe from the wire harness side.




05UGIX-028

2. Check the terminals of waterproof connectors from the connector side, as they cannot be accessed from the wire harness side.

#### Caution


- Use fine wire to prevent damage to the terminal.
- Do not damage the terminal when inserting the tester lead.



9MUGIX-027

#### Terminals Inspection

Pull lightly on individual wires to check that they are secured in the terminal.



9MUGIX-028

#### Replacement of terminals



Use the appropriate tools to remove the terminal as shown. When installing the terminal, be sure to insert it until it locks securely.

##### < Female >

Insert a thin piece of metal from the terminal side of the connector, and then, with the terminal locking tab pressed down, pull the terminal out from the connector.

##### < Male >

Same as the female type.




05UGIX-029

#### Sensors, Switches, and Relays

Handle sensors, switches, and relays carefully. Do not drop them or strike them against other objects.



**CAUTION**




**Wire Harness**

**Wiring color codes**


Two-color wires are indicated by a two-color code symbol. The first letter indicates the base color of the wire and the second the color of the stripe.

CODE	COLOR	CODE	COLOR
B	Black	O	Orange
BR	Brown	P	Pink
G	Green	R	Red
GY	Gray	V	Violet
L	Blue	W	White
LB	Light Blue	Y	Yellow
LG	Light Green	—	—



**Fuse Replacement**

1. When replacing a fuse, be sure to replace it with one of the specified capacity.  
If a fuse again fails after it has been replaced, the circuit probably has a short and the wiring should be checked.
2. Be sure the negative battery terminal is disconnected before replacing a main fuse (80A).



3. When replacing a pullout fuse, use the fuse puller supplied in the fuse box cover.

# PRE-DELIVERY INSPECTION AND SCHEDULED MAINTENANCE SERVICES

**PRE-DELIVERY INSPECTION** ..... A- 2  
PRE-DELIVERY INSPECTION TABLE ..... A- 2  
**SCHEDULED MAINTENANCE SERVICES** ..... A- 3  
SCHEDULE 1  
(NORMAL DRIVING CONDITIONS) ..... A- 3  
SCHEDULE 2  
(UNIQUE DRIVING CONDITIONS) ..... A- 6

05U0AX-001

## PRE-DELIVERY INSPECTION

## PRE-DELIVERY INSPECTION TABLE

**EXTERIOR**

**INSPECT** and **ADJUST**, if necessary, the following items to specification:

- Glass, exterior bright metal and paint for damage
- Convertible top and detachable hard top (if equipped) for damage
- Wheel lug nuts  
88—118 N·m (9—12 m·kg, 65—87 ft·lb)
- Tire pressure (Refer to Section Q)
- All weatherstrips for damage or detachment
- Operation of hood release and lock
- Operation of fuel lid
- Door operation and alignment
- Headlight aiming

**INSTALL** the following parts:

- Wheel caps or rings (if equipped)
- Outside rearview mirror(s)
- Mast antenna

**UNDER HOOD—ENGINE OFF**

**INSPECT** and **ADJUST**, if necessary, the following items to specification:

- Fuel, coolant and hydraulic lines, fittings, connections and components for leaks
- Engine oil level
- Power steering fluid level (if equipped)
- Brake and clutch master cylinder fluid level
- Windshield washer reservoir fluid level
- Radiator coolant level and specific gravity

Protection °C (°F)	Specific gravity at 20°C (68°F)
-16 (3)	1.054
-26 (-15)	1.066
-40 (-40)	1.078

- Tightness of water hose clamps (including heater hoses)
- Tightness of battery terminals
- Drive belt tensions (Refer to Section B)
- Accelerator cable and linkage for free movement

**CLEAN** spark plugs

**INTERIOR**

**INSTALL** the following parts:

- Fuse for accessories

**CHECK** operation of the following items:

- Seat controls (sliding and reclining)
- Door locks
- Seat belts and warning system
- Air bag system using indicator light (if equipped)  
(Refer to Section T)
- Ignition switch and steering lock
- Starter interlock switch (clutch pedal)
- All lights, including warning and indicator lights
- Audible warning system
- Horn, wipers and washer
- Audio system (if equipped)
- Cigarette lighter

- Power windows (if equipped)
- Heater, defroster and air conditioner at all mode selections (if equipped)

**CHECK** the following items:

- Presence of spare fuses
- Upholstery and interior finish

**CHECK** and **ADJUST**, if necessary, the following items:

- Operation and fit of windows
- Pedal height and free play of brake and clutch pedals

	Pedal height mm (in)	Free play mm (in)
Clutch pedal	175—185 (6.89—7.28) (with carpet)	0.6—3.1 (0.02—0.12)
Brake pedal	171—181 (6.73—7.13) (with carpet)	4—7 (0.16—0.28)

- Parking brake  
5—7 notches/98 N (10 kg, 22lb)

**UNDER HOOD—ENGINE RUNNING AT OPERATING TEMPERATURE**

**CHECK** the following items:

- Initial ignition timing  
10° ± 1° BTDC (with diagnosis connector TEN and GND terminals connected)  
(Refer to page F-75)
- Idle speed  
850 ± 50 rpm (with diagnosis connector TEN and GND terminals connected)  
(Refer to page F-76)

**ON HOIST**

**CHECK** the following items:

- Underside fuel, coolant and hydraulic lines, fittings, connections and components for leaks
- Tires for cuts or bruises
- Steering linkage, suspension, exhaust system and all underside hardware for looseness or damage
- Manual transmission oil level
- Rear axle oil level

**ROAD TEST**

**CHECK** the following items:

- Brake operation
- Clutch operation
- Steering control
- Operation of meters and gauges
- Squeaks, rattles and unusual noise
- Overall engine performance
- Seat belt emergency locking retractors
- Cruise control system (if equipped)

**AFTER ROAD TEST**

**REMOVE** seat and floor mat protective covers

**CHECK** for necessary owner information materials, tools and spare tire in vehicle

## SCHEDULED MAINTENANCE SERVICES

Follow Schedule 1 (Normal Driving Conditions) if the vehicle is mainly operated where none of the following conditions apply.  
Follow Schedule 2 (Unique Driving Conditions) if any of the conditions below apply:

- Repeated short-distance driving.
- Driving in dusty conditions.
- Driving with extended use of brakes.
- Driving in areas where road salt or other corrosive materials are used.
- Driving on rough and/or muddy roads.
- Extended periods of idling and/or low-speed operation.
- Driving for prolonged periods in cold temperatures and/or extremely humid climates.

### SCHEDULE 1 (NORMAL DRIVING CONDITIONS)

#### Chart symbols:

**I** : Inspect, and if necessary correct, clean or replace

**R** : Replace or change

**T** : Tighten

#### Remarks:

After 60 months or 60,000 miles (96,000 km), continue to follow the described maintenance at the recommended intervals.

As for \* marked items in this maintenance chart, note the following points:

- \*1 Replacement of the timing belt is required every 60,000 miles (96,000 km). Failure to replace the timing belt may result in damage to the engine.
- \*2 This maintenance is recommended by Mazda. However, it is not necessary for emission warranty coverage or manufacturer recall liability.
- \*3 This maintenance is required for all states except California. However, we recommend that it also be performed on California vehicles.

**SCHEDULED MAINTENANCE SERVICES**

**SCHEDULE 1 (NORMAL DRIVING CONDITIONS)**

Interval	Number of months or miles (km), whichever comes first										Service data and inspection point	Page					
	Months	7.5	15	22.5	30	37.5	45	52.5	60	60,000							
	Miles	7,500	15,000	22,500	30,000	37,500	45,000	52,500	60,000	60,000							
Kilometers	12,000	24,000	36,000	48,000	60,000	72,000	84,000	96,000	96,000								
<b>ENGINE</b>																	
Engine oil	R	R	R	R	R	R	R	R	R	R	R	<ul style="list-style-type: none"> <li>Oil pan capacity: 3.2 liters (3.4 US qt, 2.8 Imp qt)</li> </ul>	D-5				
Engine oil filter	R	R	R	R	R	R	R	R	R	R	R	<ul style="list-style-type: none"> <li>Oil filter capacity: 0.17 liters (0.18 US qt, 0.15 Imp qt)</li> </ul>	D-5				
Drive belts					I							<ul style="list-style-type: none"> <li>Cracks or damage</li> <li>Tension</li> </ul>	B-5 G-19				
Air cleaner element					R								F-75				
Engine timing belt *1												Replace every 60,000 miles (96,000 km)	B-12				
<b>IGNITION SYSTEM</b>																	
Spark plugs					R						R	<ul style="list-style-type: none"> <li>Plug gap: 1.0—1.1mm (0.039—0.043 in)</li> <li>Recommended spark plugs:</li> </ul> <table border="1" style="margin-left: 20px;"> <tr> <td>NGK</td> <td>BKR5E-11 BKR6E-11 BKR7E-11</td> </tr> <tr> <td>Nippon Denso</td> <td>K16PR-U11 K20PR-U11 K22PR-U11</td> </tr> </table>	NGK	BKR5E-11 BKR6E-11 BKR7E-11	Nippon Denso	K16PR-U11 K20PR-U11 K22PR-U11	G-3
NGK	BKR5E-11 BKR6E-11 BKR7E-11																
Nippon Denso	K16PR-U11 K20PR-U11 K22PR-U11																
<b>FUEL SYSTEM</b>																	
Idle speed					I*3							Idle speed: 850 ± 50 rpm	F-72				
Fuel filter													F-101				
Fuel lines					I*2							Fittings, connections and components for leaks	F-96				
<b>COOLING SYSTEM</b>																	
Cooling system					I							<ul style="list-style-type: none"> <li>Hoses for cracks or wear</li> <li>Coolant level</li> </ul>	E-4				
Engine coolant					R								E-4				

SCHEDULE 2 (UNIQUE DRIVING CONDITIONS) (Cont'd)

Interval	Number of months or miles (km), whichever comes first														Service data and inspection point	Page		
	Months	5	10	15	20	25	30	35	40	45	50	55	60					
	Miles (x1,000)	5	10	15	20	25	30	35	40	45	50	55	60					
Maintenance operation	Km (x1,000)	8	16	24	32	40	48	56	64	72	80	88	96					
<b>CHASSIS AND BODY</b>																		
Brake lines, hoses, and connections						I										I	• Proper attachment and connections	P-6
Disc brakes				I			I			I						I	• Disc plate thickness: 16.0mm (0.63 in)—Minimum • Pad thickness: 1.0mm (0.04 in)—Minimum	P-20, 24
Steering operation and linkages							I									I	• Free play: 0-30mm (0-1.18 in) • Operation and looseness • Fluid leakage or oozing	N-8
Front suspension ball joints							I									I	• Damage, looseness and grease leakage	R-15, 17
Manual transmission oil							R									R	• Oil capacity: 2.0 liters (2.1 US qt, 1.8 Imp qt)	J-3
Rear axle oil																R	• Oil capacity: 0.65 liters (0.69 US qt, 0.57 Imp qt)	M-23
Bolts and nuts on chassis and body																T	• Retighten all loose bolts and nuts	—
Exhaust system heat shield																I	• Insulator clearance between body and exhaust system	F-115
<b>AIR CONDITIONER SYSTEM</b>																		
Refrigerant																	• Refrigerant pressure: Low pressure: 147-294 kPa (1.5-3.0 kg/cm <sup>2</sup> , 21-43 psi) High pressure: 1,177-1,619 kPa (12.0-16.5 kg/cm <sup>2</sup> , 171-235 psi)	U-49
Compressor																	—	—

**SCHEDULE 2 (UNIQUE DRIVING CONDITIONS)****Chart symbols:**

- I** : Inspect, and if necessary correct, clean or replace
- R** : Replace or change
- T** : Tighten

**Remarks:**

After 60 months or 60,000 miles (96,000 km), continue to follow the described maintenance at the recommended intervals.

As for \* marked items in this maintenance chart note the following points:

- \*1 Replacement of the timing belt is required every 60,000 miles (96,000 km). Failure to replace the timing belt may result in damage to the engine.
- \*2 This maintenance is recommended by Mazda. However, it is not necessary for emission warranty coverage or manufacturer recall liability.
- \*3 This maintenance is required for all states except California. However, we recommend that it also be performed on California vehicles.

**SCHEDULE 2 (UNIQUE DRIVING CONDITIONS)**

Interval Maintenance operation	Number of months or miles (km), whichever comes first												Service data and inspection point	Page						
	Months	5	10	15	20	25	30	35	40	45	50	55			60					
	Miles (x1,000)	5	10	15	20	25	30	35	40	45	50	55			60					
Km (x1,000)	8	16	24	32	40	48	56	64	72	80	88	96								
<b>ENGINE</b>																				
Engine oil	R	R	R	R	R	R	R	R	R	R	R	R	R	R	• Oil pan capacity: 3.2 liters (3.4 US qt; 2.8 Imp qt)	D-5				
Engine oil filter	R	R	R	R	R	R	R	R	R	R	R	R	R	R	• Oil filter capacity: 0.17 liters (0.18 US qt, 0.15 Imp qt)	D-5				
Drive belts							I							I	• Cracks or damage	B-5 G-19				
Air cleaner element			I*3				R		I*3					R	• Tension	F-75				
Engine timing belt *1	Replace every 60,000 miles (96,000 km)														B-12					
<b>IGNITION SYSTEM</b>																				
Spark plugs														R	• Plug gap: 1.0–1.1mm (0.039–0.043 in) • Recommended spark plugs: <table border="1" style="margin-left: 20px;"> <tr> <td>NGK</td> <td>BKR5E-11 BKR6E-11 BKR7E-11</td> </tr> <tr> <td>Nippon Denso</td> <td>K16PR-U11 K20PR-U11 K22PR-U11</td> </tr> </table>	NGK	BKR5E-11 BKR6E-11 BKR7E-11	Nippon Denso	K16PR-U11 K20PR-U11 K22PR-U11	G-3
NGK	BKR5E-11 BKR6E-11 BKR7E-11																			
Nippon Denso	K16PR-U11 K20PR-U11 K22PR-U11																			
<b>FUEL SYSTEM</b>																				
Idle speed						I*3								I	• Idle speed: 850 ± 50 rpm	F-72				
Fuel filter														R		F-101				
Fuel lines														I	• Fittings, connections and components for leaks	F-96				
<b>COOLING SYSTEM</b>																				
Cooling system														I	• Hoses for cracks or wear	E-4				
Engine coolant														R	• Coolant level	E-4				



**SCHEDULED MAINTENANCE SERVICES**

**SCHEDULE 1 (NORMAL DRIVING CONDITIONS) (Cont'd)**

Interval	Number of months or miles (km), whichever comes first										Service data and inspection point	Page		
	Months	7,500	15,000	22,500	30,000	37,500	45,000	52,500	60,000	60				
	Miles Kilometers	7,500 12,000	15,000 24,000	22,500 36,000	30,000 48,000	37,500 60,000	45,000 72,000	52,500 84,000	60,000 96,000	60 96,000				
<b>CHASSIS AND BODY</b>														
Brake lines, hoses, and connections					I							I	<ul style="list-style-type: none"> <li>• Proper attachment and connections</li> </ul>	P-6
Disc brakes					I							I	<ul style="list-style-type: none"> <li>• Disc plate thickness: 16.0mm (0.63 in)—Minimum</li> <li>• Pad thickness: 1.0mm (0.04 in)—Minimum</li> </ul>	P-20, 24
Steering operation and linkages					I							I	<ul style="list-style-type: none"> <li>• Free play: 0-30mm (0-1.18 in)</li> <li>• Operation and looseness</li> <li>• Fluid leakage or oozing</li> </ul>	N-8
Front suspension ball joints					I							I	<ul style="list-style-type: none"> <li>• Damage, looseness and grease leakage</li> </ul>	R-15, 17
Manual transmission oil												R	<ul style="list-style-type: none"> <li>• Oil capacity: 2.0 liters (2.1 US qt, 1.8 Imp qt)</li> </ul>	J-3
Rear axle oil												R	<ul style="list-style-type: none"> <li>• Oil capacity: 0.65 liters (0.69 US qt, 0.57 Imp qt)</li> </ul>	M-23
Bolts and nuts on chassis and body					T							T	<ul style="list-style-type: none"> <li>• Retighten all loose bolts and nuts</li> </ul>	—
Exhaust system heat shield					I							I	<ul style="list-style-type: none"> <li>• Insulator clearance between body and exhaust system</li> </ul>	F-115
<b>AIR CONDITIONER SYSTEM</b>														
Refrigerant													<ul style="list-style-type: none"> <li>• Refrigerant pressure: Low pressure: 147-294 kPa (1.5-3.0 kg/cm<sup>2</sup>, 21-43 psi) High pressure: 1,177-1,619 kPa (12.0-16.5 kg/cm<sup>2</sup>, 171-235 psi)</li> </ul>	U-49
Compressor													<ul style="list-style-type: none"> <li>• Inspect refrigerant amount annually</li> <li>• Inspect operation annually</li> </ul>	—


# ENGINE

<b>INDEX</b> .....	<b>B- 2</b>	<b>INSPECTION / REPAIR</b> .....	<b>B-48</b>
<b>OUTLINE</b> .....	<b>B- 3</b>	<b>PREPARATION</b> .....	<b>B-48</b>
<b>SPECIFICATIONS</b> .....	<b>B- 3</b>	<b>CYLINDER HEAD</b> .....	<b>B-48</b>
<b>TROUBLESHOOTING GUIDE</b> .....	<b>B- 3</b>	<b>VALVE MECHANISM</b> .....	<b>B-49</b>
<b>ENGINE TUNE-UP PROCEDURE</b> .....	<b>B- 5</b>	<b>CAMSHAFT</b> .....	<b>B-52</b>
<b>PREPARATION</b> .....	<b>B- 5</b>	<b>HLA</b> .....	<b>B-54</b>
<b>ENGINE OIL</b> .....	<b>B- 5</b>	<b>CYLINDER BLOCK</b> .....	<b>B-54</b>
<b>ENGINE COOLANT</b> .....	<b>B- 5</b>	<b>OIL JET</b> .....	<b>B-55</b>
<b>DRIVE BELT</b> .....	<b>B- 5</b>	<b>PISTON, PISTON RING, AND</b>	
<b>HLA</b> .....	<b>B- 7</b>	<b>PISTON PIN</b> .....	<b>B-56</b>
<b>IGNITION TIMING, IDLE SPEED</b> .....	<b>B- 8</b>	<b>CONNECTING ROD</b> .....	<b>B-57</b>
<b>COMPRESSION</b> .....	<b>B-10</b>	<b>CRANKSHAFT</b> .....	<b>B-58</b>
<b>INSPECTION</b> .....	<b>B-10</b>	<b>BEARING</b> .....	<b>B-58</b>
<b>ON-VEHICLE MAINTENANCE</b> .....	<b>B-11</b>	<b>TIMING BELT</b> .....	<b>B-59</b>
<b>PREPARATION</b> .....	<b>B-11</b>	<b>TENSIONER, IDLER</b> .....	<b>B-59</b>
<b>TIMING BELT</b> .....	<b>B-12</b>	<b>TENSIONER SPRING</b> .....	<b>B-59</b>
<b>CYLINDER HEAD GASKET</b> .....	<b>B-16</b>	<b>PULLEY</b> .....	<b>B-59</b>
<b>HLA</b> .....	<b>B-20</b>	<b>ASSEMBLY</b> .....	<b>B-60</b>
<b>FRONT OIL SEAL</b> .....	<b>B-24</b>	<b>PREPARATION</b> .....	<b>B-60</b>
<b>REAR OIL SEAL</b> .....	<b>B-26</b>	<b>CYLINDER BLOCK</b>	
<b>REMOVAL</b> .....	<b>B-28</b>	<b>(INTERNAL PARTS)</b> .....	<b>B-61</b>
<b>PROCEDURE</b> .....	<b>B-28</b>	<b>CYLINDER BLOCK</b>	
<b>ENGINE STAND MOUNTING</b> .....	<b>B-33</b>	<b>(EXTERNAL PARTS)</b> .....	<b>B-66</b>
<b>PREPARATION</b> .....	<b>B-33</b>	<b>CYLINDER HEAD</b> .....	<b>B-70</b>
<b>PROCEDURE</b> .....	<b>B-34</b>	<b>TIMING BELT</b> .....	<b>B-74</b>
<b>DISASSEMBLY</b> .....	<b>B-36</b>	<b>AUXILIARY PARTS</b> .....	<b>B-78</b>
<b>PREPARATION</b> .....	<b>B-36</b>	<b>ENGINE STAND DISMOUNTING</b> .....	<b>B-82</b>
<b>AUXILIARY PARTS</b> .....	<b>B-37</b>	<b>PROCEDURE</b> .....	<b>B-82</b>
<b>TIMING BELT</b> .....	<b>B-38</b>	<b>INSTALLATION</b> .....	<b>B-84</b>
<b>CYLINDER HEAD</b> .....	<b>B-40</b>	<b>PROCEDURE</b> .....	<b>B-84</b>
<b>CYLINDER BLOCK</b>			
<b>(EXTERNAL PARTS)</b> .....	<b>B-43</b>		
<b>CYLINDER BLOCK</b>			
<b>(INTERNAL PARTS)</b> .....	<b>B-45</b>		

**INDEX**

**INTAKE MANIFOLD  
TIGHTENING TORQUE**  
19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)

**COMPRESSION  
INSPECTION, PAGE B—10**  
STANDARD : 1,324 kPa (13.5 kg/cm<sup>2</sup>, 192 psi)—300 rpm  
MINIMUM : 932 kPa (9.5 kg/cm<sup>2</sup>, 135 psi)—300 rpm



**DRIVE BELT  
ADJUSTMENT, PAGE B—6**

**EXHAUST MANIFOLD  
TIGHTENING TORQUE**  
38—46 N·m (3.9—4.7 m·kg, 28—34 ft·lb)

**ENGINE OIL INSPECTION,  
SERVICE, SECTION D**

**ENGINE COOLANT INSPECTION,  
SERVICE, SECTION E**

<b>DEFLECTION</b>		mm (in)	
<b>DRIVE BELT</b>	<b>NEW</b>	<b>USED</b>	
ALTERNATOR	8.0—9.0 (0.31—0.35)	9.0—10.0 (0.35—0.39)	
P/S, P/S + A/C	8.0—9.0 (0.31—0.35)	9.0—10.0 (0.35—0.39)	
A/C	8.0—9.0 (0.31—0.35)	9.0—10.0 (0.35—0.39)	

05U0BX-002

- 1. Timing belt  
Removal / Installation ..... page B—12
- 2. Cylinder head gasket  
Replacement ..... page B—16
- 3. HLA  
Removal / Installation ..... page B—20
- 4. Front oil seal  
Replacement ..... page B—24
- 5. Rear oil seal  
Replacement ..... page B—26

- 6. Engine  
Removal ..... page B—28  
Engine stand mounting ..... page B—33  
Disassembly ..... page B—36  
Inspection / Repair ..... page B—48  
Assembly ..... page B—60  
Engine stand dismounting ..... page B—82  
Installation ..... page B—84

OUTLINE

SPECIFICATIONS

Item		Engine	B6 DOHC
Type			Gasoline, 4-cycle
Cylinder arrangement and number			In-line, 4-cylinders
Combustion chamber			Pentroof
Valve system			DOHC, belt-driven
Displacement		cc (cu in)	1,597 (97.42)
Bore and stroke		mm (in)	78.0 x 83.6 (3.07 x 3.29)
Compression ratio			9.4
Compression pressure		kPa (kg/cm <sup>2</sup> , psi)-rpm	1,324 (13.5, 192)-300
Valve timing	IN	Open BTDC	5°
		Close ABDC	51°
	EX	Open BBDC	53°
		Close ATDC	15°
Valve clearance	IN		0: Maintenance-free
	EX		0: Maintenance-free
Idle speed		rpm	850 ± 50 (Neutral)*
Ignition timing		BTDC	10° ± 1°*
Firing order			1—3—4—2

\* With System Selector (49 B019 9A0) test switch at SELF TEST.

05U0BX-003

TROUBLESHOOTING GUIDE

Problem	Possible Cause	Remedy	Page
<b>Difficult starting</b>	<b>Malfunction of engine-related components</b> Burned valve Worn piston, piston ring, or cylinder Failed cylinder head gasket	• Replace Replace or repair Replace	B-49 B-54, 56 B-16
	<b>Malfunction of fuel system</b>	Refer to Section F	
	<b>Malfunction of ignition system</b>	Refer to Section G	
<b>Poor idling</b>	<b>Malfunction of engine-related components</b> Malfunction of HLA* Poor valve-to-valve seat contact Failed cylinder head gasket	Replace Replace or repair Replace	B-20 B-51 B-16
	<b>Malfunction of fuel system</b>	Refer to Section F	
	<b>Malfunction of ignition system</b>	Refer to Section G	
<b>Excessive oil consumption</b>	<b>Oil working up</b> Worn piston ring groove or sticking piston ring Worn piston or cylinder	Replace Replace or repair	B-56 B-54, 56
	<b>Oil working down</b> Worn valve seal Worn valve stem or guide	Replace Replace	B-40, 71 B-49
	<b>Oil leakage</b>	Refer to Section D	



Problem	Possible Cause	Remedy	Page
<b>Insufficient power</b>	<b>Insufficient compression</b> Malfunction of HLA* Compression leakage from valve seat Seized valve stem Weak or broken valve spring Failed cylinder head gasket Cracked or distorted cylinder head Sticking, damaged, or worn piston ring Cracked or worn piston	Replace Repair Replace Replace Replace Replace Replace Replace	B-20 B-51 B-49 B-52 B-16 B-48 B-56 B-56
	<b>Malfunction of fuel system</b>	Refer to Section F	
	<b>Malfunction of ignition system</b>	Refer to Section G	
	<b>Others</b> Slipping clutch Dragging brakes Wrong size tires	Refer to Section H Refer to Section P Refer to Section Q	
<b>Abnormal combustion</b>	<b>Malfunction of engine-related components</b> Malfunction of HLA* Sticking or burned valve Weak or broken valve spring Carbon accumulation in combustion chamber	Replace Replace Replace Eliminate carbon	B-20 B-49 B-52 —
	<b>Malfunction of fuel system</b>	Refer to Section F	
	<b>Malfunction of ignition system</b>	Refer to Section G	
<b>Engine noise</b>	<b>Crankshaft- or bearing-related parts</b> Excessive main bearing oil clearance Main bearing seized or heat-damaged Excessive crankshaft end play Excessive connecting rod bearing oil clearance Connecting rod bearing seized or heat-damaged	Replace or repair Replace Replace or repair Replace or repair Replace	B-63 B-58 B-64 B-65 B-58
	<b>Piston-related parts</b> Worn cylinder Worn piston or piston pin Seized piston Damaged piston ring Bent connecting rod	Replace or repair Replace Replace Replace Replace	B-54 B-57 B-56 B-56 B-57
	<b>Valves or timing-related parts</b> Malfunction of HLA* Broken valve spring Excessive valve guide clearance	Replace Replace Replace	B-20 B-52 B-49
	<b>Malfunction of cooling system</b>	Refer to Section E	
	<b>Malfunction of fuel system</b>	Refer to Section F	
	<b>Others</b> Malfunction of water pump bearing Improper drive belt tension Malfunction of alternator bearing Exhaust gas leakage Malfunction of timing belt tensioner	Refer to Section E Adjust Refer to Section G Refer to Section F Replace	B- 6    B-12

05U0BX-004


\* Tappet noise may occur if the engine has set idle for an extended period. The noise should dissipate after the engine has reached normal operating temperature. (HLA troubleshooting: Refer to page B-7)

ENGINE TUNE-UP PROCEDURE

PREPARATION  
SST

<p>49 9200 020 Tension gauge, V-ribbed belt</p> 	<p>For inspection of drive belt tension</p>	<p>49 B019 9A0 System selector</p> 	<p>For inspection of ignition timing and idle speed</p>
---	---	--	---

05U0BX-005




05U0BX-006

**ENGINE OIL  
Inspection**

1. Be sure the vehicle is on level ground.
2. Warm up the engine to normal operating temperature and stop it.
3. Wait for five minutes.
4. Remove the oil level gauge and check the oil level and condition.
5. Add or replace oil if necessary.

**Note**

- The distance between the L and F marks on the level gauge represents 0.8 liter (0.85 US qt, 0.70 Imp qt).



05U0BX-007

**ENGINE COOLANT  
Inspection**

**Coolant level (engine cold)**


**Warning**

- Never remove the radiator cap while the engine is hot.
- Wrap a thick cloth around the cap when removing it.

1. Verify that the coolant level is near the radiator filler neck.
2. Verify that the coolant level in the coolant reservoir is between the FULL and LOW marks.
3. Add coolant if necessary.

**Coolant quality**


1. Verify that there is no buildup of rust or scale around the radiator cap or radiator filler neck.
2. Verify that the coolant is free of oil.
3. Replace the coolant if necessary.



05U0BX-008

**DRIVE BELT  
Inspection**


1. Remove the air intake pipe.
2. Check the drive belts for wear, cracks, and fraying. Replace if necessary.
3. Verify that the drive belts are correctly mounted on the pulleys.




05U0BX-009

# B


## ENGINE TUNE-UP PROCEDURE




05U0BX-010




05U0BX-011



05U0BX-012



05U0BX-013



05U0BX-014

4. Check the drive belt deflection by applying moderate pressure (**98 N, 10 kg, 22 lb**) midway between the pulleys, as shown. Adjust if necessary.

### Deflection

mm (in)

Drive belt	New	Used
Alternator	8.0—9.0 (0.31—0.35)	9.0—10.0 (0.35—0.39)
P/S, P/S + A/C	8.0—9.0 (0.31—0.35)	9.0—10.0 (0.35—0.39)
A/C	8.0—9.0 (0.31—0.35)	9.0—10.0 (0.35—0.39)

5. Check the drive belt tension with the **SST** (tension gauge).

### Note

- Belt tension can be measured between any pulleys.

### Tension

N (kg, lb)

Drive belt	New	Used
Alternator	491—589 (50—60, 110—132)	422—491 (43—50, 95—110)
P/S, P/S + A/C	491—589 (50—60, 110—132)	422—491 (43—50, 95—110)
A/C	491—589 (50—60, 110—132)	422—491 (43—50, 95—110)

6. Install the air intake pipe.

### Adjustment

#### Caution

- If a new belt is used, adjust the belt deflection at the midpoint of new belt specification.

- (1) Alternator belt  
If necessary, loosen the alternator bolts (A) and (B) and adjust the belt deflection by turning the adjusting bolt (C).


#### Tightening torque

- A : 19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)
- B : 37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)

- (2) P/S belt, P/S + A/C belt  
If necessary, loosen the P/S oil pump bolt (A) and nuts (B) and (C) and adjust the belt deflection by turning the adjusting bolt (D).

#### Tightening torque

- A : 31—46 N·m (3.2—4.7 m·kg, 23—34 ft·lb)
- B : 36—54 N·m (3.7—5.5 m·kg, 27—40 ft·lb)
- C : 19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)



05U0BX-015

- (3) A/C belt  
If necessary, loosen the locknut and adjust the belt deflection by turning the adjusting bolt.


**Tightening torque:**  
**37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)**

## HLA


Problem	Possible Cause	Remedy
1. Tappet noise occurs when engine started immediately after engine oil replacement 2. Tappet noise occurs when engine started after setting more than one day 3. Tappet noise occurs when engine started after cranking by starter more than three seconds 4. Tappet noise occurs when engine started after HLA replaced	No oil in HLA	Tappet noise should dissipate from within a few seconds to ten minutes
5. Tappet noise continues more than ten minutes	Low oil pressure	Check oil pressure (Refer to Section D)
	Defective HLA	Inspect HLA (Refer to page B-54)
6. Tappet noise occurs at idle after high-speed driving	Low oil level	Add engine oil
	Degenerated oil	Replace engine oil

05U0BX-016







05U0BX-278




05U0BX-288



05U0BX-279



05U0BX-280



05U0BX-281

### IGNITION TIMING, IDLE SPEED

#### Preparation

1. Check the engine condition (spark plugs, leaks in hoses, etc.).
2. Warm up the engine to normal operating temperature.
3. Make sure all accessories are OFF.

#### Note

- When using an externally powered timing light and/or tachometer, connect it to the power connector (Blue: 1-pin).

#### Caution

- Do not ground the power connector terminal (Blue: 1-pin); the wiper 20A fuse will be burned.

4. Connect a timing light and a tachometer to the diagnosis connector terminal IG-.

#### Caution

- Be extremely careful when making connections to the diagnosis connector because a mistaken connection will cause a malfunction.

5. Connect the SST.

6. Set the SST switch (A) to 1 position and test switch to SELF TEST position.

#### Note

- If the SST is not used, jump across the (TEN) terminal and the (GND) terminal of the diagnosis connector.


### Ignition Timing Inspection / Adjustment

1. Check the idle speed and set it to specification if necessary.


**Idle speed: 850 ± 50 rpm (Neutral)**

2. Verify that the timing mark (Yellow) on the crankshaft pulley is aligned with the timing belt lower cover mark.


**Ignition timing: 10° ± 1° BTDC (at idle speed)**




05U0BX-282



05U0BX-283



05U0BX-284



05U0BX-285

3. If the marks are not aligned, loosen the crank angle sensor lock bolt and adjust by turning the crank angle sensor.
4. Tighten the crank angle sensor lock bolt.

**Tightening torque:**

**19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)**

5. After adjusting the ignition timing, disconnect the **SST** or jumper wire from the diagnosis connector.
6. Increase the engine speed and verify that the ignition timing advances.

**Idle Speed**

**Inspection / Adjustment**

1. Connect the **SST** or jumper wire to the diagnosis connector. (Refer to page B-8.)

2. Verify that the idle speed is within specification.

**Idle speed: 850 ± 50 rpm (Neutral)**


3. If the idle speed is not within specification, remove the blind cap from the air adjusting screw and adjust it.
4. After adjusting the idle speed, install the blind cap and disconnect the **SST** or jumper wire from the diagnosis connector.

## COMPRESSION


If the engine exhibits low power, poor fuel economy, or poor idle, check the following:

1. Ignition system (Refer to page G-17.)
2. Compression
3. Fuel system (Refer to page F-100.)

05U0BX-017



05U0BX-018



05U0BX-019

## INSPECTION

1. Check that the battery is fully charged. Recharge it if necessary. (Refer to page G-8.)
2. Warm up the engine to the normal operating temperature.
3. Turn the engine OFF.
4. Remove all spark plugs.
5. Disconnect the ignition coil connector.
6. Connect a compression gauge to the No.1 spark plug hole.
7. Fully depress the accelerator pedal and crank the engine.
8. Record the maximum gauge reading.
9. Check each cylinder.

**Compression:**

**1,324 kPa (13.5 kg/cm<sup>2</sup>, 192 psi) - 300 rpm**

**Minimum:**


**932 kPa (9.5 kg/cm<sup>2</sup>, 135 psi) - 300 rpm**

**Differential limit between cylinders:**

**196 kPa (2.0 kg/cm<sup>2</sup>, 28 psi)**

10. If the compression in one or more cylinders is low, pour a small amount of engine oil into the cylinder and recheck the compression.
  - (1) If the compression increases, the piston, piston rings, or cylinder wall may be worn.
  - (2) If the compression stays low, the valve may be stuck or seating improperly.
  - (3) If the compression in adjacent cylinders stays low, the cylinder head gasket may be defective or the cylinder head distorted.
11. Connect the ignition coil connector.
12. Apply antiseize compound or molybdenum-based lubricant to the spark plug threads.
13. Install the spark plugs.

05U0BX-020









05U0BX-021

**Tightening torque:**

**15—23 N·m (1.5—2.3 m·kg, 11—17 ft·lb)**

ON-VEHICLE MAINTENANCE

PREPARATION  
SST

<p>49 S120 710 Holder, coupling flange</p> 	<p>For removal and installation of timing belt pulley</p>	<p>49 B011 102 Lock tool, crankshaft</p> 	<p>For removal and installation of timing belt pulley</p>
<p>49 E301 060 Brake, ring gear</p> 	<p>For prevention of engine rotation</p>	<p>49 E301 061 Body (Part of 49 E301 060)</p> 	<p>For prevention of engine rotation</p>
<p>49 E301 062 Collar (Part of 49 E301 060)</p> 	<p>For prevention of engine rotation</p>	<p>49 SE01 310 Centering tool, clutch disc</p> 	<p>For installation of clutch disc</p>

05U0BX-022


### TIMING BELT

#### Removal / Installation

##### Caution


- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to page T-113.)
- Position the hose clamp in the original location on the hose, and squeeze the clamp lightly with large pliers to ensure a good fit.

1. Disconnect the negative battery cable.
2. Drain the engine coolant.
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Install in the reverse order of removal, referring to **Installation Note**.




05U0BX-023


- |  |                                  |
|--|----------------------------------|
| 1. Air intake pipe                             | 13. Cylinder head cover          |
| 2. Upper radiator hose                         | Installation Note..... page B-15 |
| 3. Water hoses (Connect to thermostat housing) | 14. Timing belt cover, upper     |
| 4. P/S and/or A/C drive belt                   | 15. Timing belt cover, middle    |
| Removal / Installation..... page B- 6          | 16. Timing belt cover, lower     |
| 5. Alternator drive belt                       | 17. Timing belt                  |
| Removal / Installation..... page B- 6          | Removal Note..... page B-13      |
| 6. Water pump pulley                           | Installation Note..... page B-13 |
| 7. Plate                                       | Inspection..... page B-59        |
| 8. Crankshaft pulley                           | 18. Tensioner, tensioner spring  |
| 9. Timing belt guide plate, outer              | Installation Note..... page B-13 |
| 10. Timing belt guide plate, inner             | Inspection..... page B-59        |
| Installation Note..... page B-15               | 19. Idler                        |
| 11. Ignition coil and high-tension lead        | Inspection..... page B-59        |
| 12. Spark plug                                 |                                  |
| Installation Note..... page B-15               |                                  |




05U0BX-024




05U0BX-025



05U0BX-026



05U0BX-027



05U0BX-028

**Removal note**

**Timing belt**

1. Turn the crankshaft and align the marks.

**Note**

- Mark the timing belt rotation for proper reinstallation.

2. Loosen the tensioner lock bolt.

**Caution**

- To prevent damage to the tensioner, secure it with a rag.

3. Temporarily secure the tensioner with the spring fully extended.
4. Remove the timing belt.


**Installation note**

**Tensioner, tensioner spring**

1. Install the tensioner and the tensioner spring.
2. Temporarily secure the tensioner with the spring fully extended.

**Timing belt**

1. Verify that the timing belt pulley mark is aligned with the timing mark.




05U0BX-029

2. Verify that the camshaft pulley marks are aligned with the seal plate marks.

**Caution**

- For intake side, align the E mark.
- For exhaust side, align the I mark.



05U0BX-030

3. Install the timing belt so that there is no looseness at the idler side or between the two camshaft pulleys.

**Caution**


- Do not turn the crankshaft counterclockwise.

4. Turn the crankshaft two turns clockwise, and align the timing belt pulley mark with the timing mark.


5. Verify that the camshaft pulley marks are aligned with the seal plate marks.

If not aligned, remove the timing belt and repeat from tensioner installation.

6. Turn the crankshaft 1 and 5/6 turn clockwise, and align the timing belt pulley mark with the tension set mark.



05U0BX-031



05U0BX-032


7. Loosen the tensioner lock bolt to apply tension to the timing belt.

8. Tighten the tensioner lock bolt.

**Tightening torque:**

**37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)**

9. Turn the crankshaft 2 and 1/6 turns clockwise and verify that the timing marks are correctly aligned.




05U0BX-033

10. Measure the timing belt deflection by applying moderate pressure (**98 N, 10 kg, 22 lb**) midway between the two camshaft pulleys.

If the deflection is not correct, repeat from Step 7 above.

**Deflection:**

**9.0—11.5mm (0.35—0.45 in) at 98 N (10 kg, 22 lb)**




05U0BX-034

**Cylinder head cover**

1. Apply silicone sealant to the shaded areas as shown in the figure.
2. Install the cylinder head cover.

**Tightening torque:**

**4.9—8.8 N·m (50—90 cm·kg, 43—78 in·lb)**




05U0BX-286

**Spark plug**

1. Apply antiseize compound or molybdenum-based lubricant to the spark plug threads.
2. Install the spark plugs.

**Tightening torque:**

**15—23 N·m (1.5—2.3 m·kg, 11—17 ft·lb)**



05U0BX-035

**Timing belt guide plate, inner****Caution**

- **Make sure the timing belt inner guide plate is installed in the proper direction.**

1. Install the timing belt inner guide plate.

**Steps After Installation**

1. Fill the radiator with the specified amount and type of engine coolant. (Refer to page E-5.)
2. Connect the negative battery cable.
3. Start the engine and check as follows:
  - (1) Engine coolant leakage.
  - (2) Ignition timing. (Refer to page B-8.)
4. Recheck the engine coolant levels.

05U0BX-036



### CYLINDER HEAD GASKET

#### Replacement


##### Warning

- Release the fuel pressure. (Refer to page F-101.)
- Keep sparks and open flame away from the fuel area.

##### Caution

- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to page T-113.)
- Position the hose clamp in the original location on the hose, and squeeze the clamp lightly with large pliers to ensure a good fit.

1. Disconnect the negative battery cable.
2. Drain the engine coolant.
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Install in the reverse order of removal, referring to **Installation Note**.




1. Air cleaner assembly	8. Front exhaust pipe
2. Accelerator cable	9. Manifold bracket
Installation Note..... page B-19	10. Cylinder head bolt
3. Hoses	Removal Note..... page B-18
Removal / Installation Note..... page B-17	Installation Note..... page B-19
4. Harnesses	11. Cylinder head
Removal / Installation Note..... page B-18	Disassembly..... page B-40
5. Exhaust manifold insulator	Inspection..... page B-48
6. Water bypass pipe	Assembly..... page B-70
Removal Note..... page B-18	12. Cylinder head gasket
7. Timing belt	
Removal / Installation..... page B-12	

05U0BX-038

**Removal / Installation note**

**Hoses**

1. Disconnect the hoses shown in the figure.



**WARNING**  
 • KEEP SPARKS AND OPEN FLAME AWAY FROM THE FUEL AREA.

**CAUTION**  
 • COVER THE HOSE WITH A RAG BECAUSE FUEL WILL SPRAY OUT WHEN DISCONNECTING.  
 • PLUG THE DISCONNECTED HOSES TO AVOID FUEL LEAKAGE.


05U0BX-039

# B


## ON-VEHICLE MAINTENANCE

### Harnesses

1. Disconnect the harness connectors shown in the figure.



05U0BX-040




05U0BX-041

#### Removal note

##### Water bypass pipe


1. Remove the exhaust manifold nut as shown in the figure.
2. Remove the water bypass pipe from the cylinder head assembly.



05U0BX-042

##### Cylinder head bolt

1. Loosen the cylinder head bolts in two or three steps in the order shown in the figure.
2. Remove the cylinder head bolts.



05U0BX-043

**Installation note****Cylinder head bolt**

1. Apply clean engine oil to the bolt threads and seat faces.
2. Install the cylinder head bolts.
3. Tighten the cylinder head bolts in two or three steps in the order shown in the figure.


**Tightening torque:**

**76—81 N·m (7.7—8.3 m·kg, 56—60 ft·lb)**

**Accelerator cable**

1. Install the accelerator cable.
2. Check the accelerator cable deflection.  
If the deflection is not correct, adjust by turning nut A.

**Deflection: 1—3mm (0.04—0.12 in)**



05U0BX-045

**Steps After Installation**

1. Fill the radiator with the specified amount and type of engine coolant. (Refer to page E-5.)
2. Connect the negative battery cable.
3. Start the engine and check as follows:
  - (1) Engine oil and engine coolant leakage.
  - (2) Ignition timing, idle speed. (Refer to page B-8.)
  - (3) Operation of emission control system.
4. Recheck the engine coolant levels.


05U0BX-046

### HLA Removal / Installation

#### Caution


- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to page T-113.)
- Position the hose clamp in the original location on the hose, and squeeze the clamp lightly with large pliers to ensure a good fit.

1. Disconnect the negative battery cable.
2. Drain the engine coolant.
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Install in the reverse order of removal, referring to **Installation Note**.



05U0BX-047

- |   |  |
|---|--|
| 1. Timing belt<br>Removal / Installation..... page B-12                               | 4. Camshaft<br>Removal Note..... page B-21<br>Installation Note..... page B-21                         |
| 2. Crank angle sensor<br>Installation Note..... page B-23                             | 5. HLA<br>Removal Note..... page B-21<br>Installation Note..... page B-21<br>Inspection..... page B-54 |
| 3. Camshaft pulley<br>Removal Note..... page B-21<br>Installation Note..... page B-22 |  |




05U0BX-048

**Removal note**

**Camshaft pulley**


1. Hold the camshaft with a wrench.
2. Remove the camshaft pulley lock bolt.
3. Remove the camshaft pulley.



05U0BX-049

**Camshaft**

1. Loosen the camshaft cap bolts in two or three steps in the order shown in the figure.
2. Remove the camshaft caps.
3. Remove the camshaft.
4. Remove the camshaft oil seal from the camshaft.




05U0BX-050

**HLA**

**Caution**

- Mark the HLA with a felt pen so that they can be reinstalled in the position from which they were removed.

1. Remove the HLA from the cylinder head.




05U0BX-051

**Installation note**

**HLA**

1. Apply clean engine oil to the friction surfaces.
2. If the HLA are being reused, install them in the position from which they were removed.
3. Verify that the HLA move smoothly in their bores.




05U0BX-052

**Camshaft**

**Note**

- The intake camshaft is grooved for the crank angle sensor drive.

1. Apply clean engine oil to the camshaft journals and bearings.
2. Install the camshaft in position.




05U0BX-053

**Caution**


- Do not allow any sealant on the camshaft journal surfaces.

3. Apply silicone sealant to the shaded areas shown in the figure.



05U0BX-054

4. Install the camshaft caps according to the cap number and arrow mark.




05U0BX-055

5. Install the camshaft cap bolts and tighten them in two or three steps in the order shown in the figure.

**Tightening torque:**

**11.3—14.2 N·m (1.15—1.45 m·kg, 100—126 in·lb)**



05U0BX-056

6. Apply a small amount of clean engine oil to the lip of a new camshaft oil seal.


7. Push the oil seal slightly in by hand.

**Caution**

- The oil seal must be tapped in until it is flush with the edge of the camshaft cap.

8. Tap the oil seal in evenly with a suitable pipe and a hammer.

**Oil seal outer diameter: 48mm (1.89 in)**




05U0BX-057

**Camshaft pulley**

1. Turn the camshafts until the camshaft dowel pins face straight up.

2. Install the camshaft pulleys with the I mark (intake side) or the E mark (exhaust side) straight up.




05U0BX-058

3. Install the camshaft pulley lock bolts.
4. Hold the camshaft with a wrench.
5. Tighten the camshaft pulley lock bolt.

**Tightening torque:**

**49—61 N·m (5.0—6.2 m·kg, 36—45 ft·lb)**



05U0BX-059

**Crank angle sensor**

1. Apply grease to a new O-ring and the blade.
2. Install the crank angle sensor and loosely tighten the installation bolt.
3. Connect the crank angle sensor connector.

**Steps After Installation**

1. Fill the radiator with the specified amount and type of engine coolant. (Refer to page E-5.)
2. Connect the negative battery cable.
3. Start the engine and check as follows:
  - (1) Engine coolant leakage.
  - (2) Ignition timing. (Refer to page B-8.)
4. Recheck the engine coolant levels.

05U0BX-036




### FRONT OIL SEAL Replacement

#### Caution

- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to page T-113.)
- Position the hose clamp in the original location on the hose, and squeeze the clamp lightly with large pliers to ensure a good fit.


1. Disconnect the negative battery cable.
2. Remove the under cover.
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Install in the reverse order of removal, referring to **Installation Note**.



N·m (m·kg, ft·lb)

05U0BX-060


- |  |  |
|--|--|
| 1. Timing belt<br>Removal / Installation..... page B-12                                | 3. Timing belt pulley<br>Removal Note..... page B-25<br>Installation Note..... page B-25 |
| 2. Pulley lock bolt<br>Removal Note..... page B-24<br>Installation Note..... page B-25 | 4. Oil seal<br>Removal Note..... page B-25<br>Installation Note..... page B-25           |



05U0BX-061

#### Removal note Pulley lock bolt

1. Hold the timing belt pulley with the **SST**.
2. Connect the **SST** and loosen the pulley lock bolt.
3. Remove the pulley lock bolt.




05U0BX-062

### Timing belt pulley

#### Note

- If necessary, remove the pulley with a steering wheel puller (commercially available).


1. Remove the timing belt pulley.
2. Remove the pulley Woodruff key.



05U0BX-063

### Oil seal

1. Cut the oil seal lip with a razor knife.
2. Remove the oil seal with a screwdriver protected with a rag.



05U0BX-064

### Installation note

#### Oil seal


1. Apply a small amount of clean engine oil to the lip of a new oil seal.
2. Push the oil seal slightly in by hand.

#### Caution

- The oil seal must be tapped in until it is flush with the edge of the oil pump body.

3. Tap the oil seal in evenly with a suitable pipe and a hammer.

**Oil seal outer diameter: 44mm (1.73 in)**



05U0BX-065

### Timing belt pulley

1. Install the timing belt pulley.
2. Install the pulley Woodruff key with the tapered side toward the oil pump body.

### Pulley lock bolt


1. Install the pulley lock bolt.
2. Tighten the pulley lock bolt using the two SST.

### Tightening torque:

**108—118 N·m (11.0—12.0 m·kg, 80—87 ft·lb)**

### Steps After Installation

1. Install the under cover.
2. Fill the radiator with the specified amount and type of engine coolant. (Refer to page E-5.)
3. Connect the negative battery cable.
4. Start the engine and check as follows:
  - (1) Engine coolant leakage.
  - (2) Ignition timing. (Refer to page B-8.)
5. Recheck the engine coolant levels.




05U0BX-066

### REAR OIL SEAL Replacement

#### Caution

- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to page T-113.)

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.




N-m (m-kg, ft-lb)

05U0BX-067

1. Transmission  
Service..... page J-10, 45
2. Clutch cover, clutch disc  
Service ..... page H-14


3. Flywheel  
Removal Note..... page B-26  
Installation Note..... page B-27
4. Oil seal  
Removal Note..... page B-27  
Installation Note..... page B-27




05U0BX-068

#### Removal note Flywheel


1. Hold the flywheel with the **SST**.
2. Remove the flywheel lock bolts.
3. Remove the flywheel.




05U0BX-063



05U0BX-069



05U0BX-070



05U0BX-071

**Oil seal**

1. Cut the oil seal lip with a razor knife.
2. Remove the oil seal with a screwdriver protected with a rag.

**Installation note****Oil seal**

1. Apply a small amount of clean engine oil to the lip of a new oil seal.
2. Push the oil seal slightly in by hand.

**Caution**

- **The oil seal must be tapped in until it is flush with the edge of the rear cover.**

3. Tap the oil seal in evenly with a suitable pipe and a hammer.

**Oil seal outer diameter: 100mm (3.94 in)**

**Flywheel**

1. Remove the sealant from the flywheel bolt holes in the crankshaft and from the flywheel bolts.

**Caution**

- **If all the previous sealant cannot be removed from a bolt, replace the bolt.**
- **Do not apply sealant if a new bolt is used.**

2. Set the flywheel onto the crankshaft.
3. Apply sealant to the flywheel bolts and install them.
4. Hold the flywheel with the **SST**.
5. Tighten the bolts in two or three steps in the order shown in the figure.

**Tightening torque:**

**96—103 N·m (9.8—10.5 m·kg, 71—76 ft·lb)**

**Steps After Installation**

1. Connect the negative battery cable.
2. Start the engine and perform engine adjustments as necessary.

05U0BX-072

### REMOVAL

#### Warning

- Release the fuel pressure. (Refer to page F-101.)


#### Caution

- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to page T-113.)

### PROCEDURE

1. Disconnect the negative battery cable.
2. Drain the engine coolant.
3. Remove the under cover.
4. Remove in the order shown in the figure, referring to **Removal Note**.


#### Step 1



05U0BX-073

- |                                      |                             |
|--------------------------------------|-----------------------------|
| 1. Air cleaner assembly              | 8. Alternator drive belt    |
| 2. Accelerator cable                 | Removal ..... page B- 6     |
| 3. Radiator hose                     | 9. P/S oil pump             |
| 4. Coolant reservoir hose            | Removal Note..... page B-29 |
| 5. Cooling fan connector             | 10. A/C compressor          |
| 6. Radiator and cooling fan assembly | Removal Note..... page B-29 |
| 7. P/S and/or A/C drive belt         |                             |
| Removal ..... page B- 6              |                             |

**REMOVAL**




05U0BX-074

**Removal note  
P/S oil pump**

**Caution**

- Do not damage the hoses.

1. Remove the P/S oil pump with the hoses still connected.
2. Position the pump away from the engine and affix it with wire.



05U0BX-075

**A/C compressor**


**Caution**

- Do not damage the hoses.

1. Remove the A/C compressor with the hoses still connected.
2. Position the compressor away from the engine and affix it with wire.

**Step 2**

1. Disconnect the harness connectors shown in the figure.



05U0BX-076


- |                         |                        |
|-------------------------|------------------------|
| 1. P/S pressure switch  | 7. Crank angle sensor  |
| 2. Water thermostswitch | 8. Ground              |
| 3. Throttle sensor      | 9. Injector            |
| 4. ISC                  | 10. Alternator         |
| 5. Oxygen sensor        | 11. Oil pressure gauge |
| 6. Ignition coil        | 12. Starter            |

# B

## REMOVAL


### Step 3

1. Disconnect the hoses shown in the figure.



05U0BX-077

- |                                |                                 |
|--------------------------------|---------------------------------|
| 1. Brake vacuum hose           | 4. Vacuum hose (Cruise control) |
| 2. Fuel hose                   | 5. Water inlet hose             |
| Removal Note..... page B-30    | 6. Heater hose                  |
| 3. Vacuum hose (Purge control) |                                 |



05U0BX-078

### Removal note Fuel hose

#### Warning


- Keep sparks and open flame away from the fuel area.

#### Caution

- Cover the hose with a rag because fuel will spray out when disconnecting.
- Plug the disconnected hoses to avoid fuel leakage.

1. Disconnect the fuel hoses.


Step 4



05U0BX-079

- 1. Exhaust pipe  
Service..... page F-115
- 2. Clutch release cylinder
- 3. Transmission harness

- 4. Shift knob, speedometer cable, propeller shaft, and power plant frame  
Service..... page J-10
- 5. Engine mount nut
- 6. Engine and transmission assembly  
Removal Note..... page B-31



05U0BX-080

**Removal note**  
**Engine and transmission assembly**

**Caution**

- Do not damage any components in the engine compartment.


- 1. Lift the engine and transmission assembly out as a unit.



# B

## REMOVAL

### Step 5











05U0BX-081

- 1. Starter
- 2. Transmission mounting bolt

- 3. Transmission
- 4. Engine assembly

## ENGINE STAND MOUNTING

### PREPARATION SST

<p>49 0107 680A Engine stand</p> 	<p>For disassembly and assembly of engine</p>	<p>49 L010 1A0 Hanger set, engine stand</p> 	<p>For disassembly and assembly of engine</p>
<p>49 L010 101 Plate (Part of 49 L010 1A0)</p> 	<p>For disassembly and assembly of engine</p>	<p>49 L010 102 Arms (Part of 49 L010 1A0)</p> 	<p>For disassembly and assembly of engine</p>
<p>49 L010 103 Hooks (Part of 49 L010 1A0)</p> 	<p>For disassembly and assembly of engine</p>	<p>49 L010 104 Nuts (Part of 49 L010 1A0)</p> 	<p>For disassembly and assembly of engine</p>
<p>49 L010 105 Bolts (Part of 49 L010 1A0)</p> 	<p>For disassembly and assembly of engine</p>	<p>49 L010 106 Bolts (Part of 49 L010 1A0)</p> 	<p>For disassembly and assembly of engine</p>

05U0BX-082


# B

## ENGINE STAND MOUNTING

### PROCEDURE


#### Step 1

1. Remove in the order shown in the figure.



05U0BX-083

- |                               |                         |
|-------------------------------|-------------------------|
| 1. Exhaust manifold insulator | 5. Water inlet pipe     |
| 2. Exhaust manifold           | 6. P/S oil pump bracket |
| 3. Water bypass pipe          | 7. Idler (A/C)          |
| 4. A/C compressor bracket     | 8. Left engine mount    |




05U0BX-084


#### Step 2

##### Caution


- When installing the SST (engine hanger), use the holes shown in the figure.




05U0BX-085




05U0BX-086



05U0BX-087



05U0BX-088



05U0BX-089

1. Install the **SST (arms)** to the holes as shown in the figure, and loosely tighten the **SST (bolts)**.

2. Assemble the **SST (bolts and plate)** in the specified position.

3. Assemble the **SST (nuts, hooks, and bolts)**.

4. Install the **SST** to the respective arms.

### Note








- Adjust the **SST (bolts)** so that less than 20mm (0.79 in) of thread is exposed.
- Make the **SST (plate and arms)** parallel by adjusting the **SST (bolts and nuts)**.

5. Tighten the **SST (bolts and nuts)** to affix the **SST** firmly.

6. Mount the engine on the **SST (engine stand)**.

### DISASSEMBLY

#### PREPARATION SST

<p>49 E301 060 Brake, ring gear</p> 	<p>For prevention of engine rotation</p>	<p>49 E301 061 Body (Part of 49 E301 060)</p> 	<p>For prevention of engine rotation</p>
<p>49 E301 062 Collar (Part of 49 E301 060)</p> 	<p>For prevention of engine rotation</p>	<p>49 0636 100A Arm, valve spring lifter</p> 	<p>For removal and installation of valves</p>
<p>49 B012 006 Pivot, valve spring lifter</p> 	<p>For removal and installation of valves</p>	<p>49 S120 170 Remover, valve seal</p> 	<p>For removal of valve seals</p>
<p>49 0221 061A Remover &amp; installer, piston pin</p> 	<p>For removal and installation of piston pins</p>	05U0BX-090	

1. Code all identical parts (such as piston, piston rings, connecting rods, and valve springs) so that they can be reinstalled in the cylinder from which they were removed.
2. Clean the parts with a steam cleaner. Blow off any remaining water with compressed air.


#### Note

- During disassembly of any part or system, be sure to study its order of assembly. Also, note any deformation, wear, or damage.

05U0BX-091

**AUXILIARY PARTS**

1. Drain the engine oil.
2. Disassemble in the order shown in the figure.




05U0BX-092

- |  |                                   |
|--|-----------------------------------|
| 1. Ignition coil and high-tension lead | 8. Oil filter                     |
| 2. Crank angle sensor                  | 9. Oil pressure gauge sender unit |
| 3. Manifold bracket                    | 10. Water outlet pipe             |
| 4. Intake manifold assembly            | 11. Spark plug                    |
| 5. Alternator                          | 12. Oil level gauge and pipe      |
| 6. Alternator bracket                  | 13. Engine hanger                 |
| 7. Right engine mount                  |                                   |


### TIMING BELT

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.



05U0BX-093


- |                                |           |
|--------------------------------|-----------|
| 1. Water pump pulley           |           |
| 2. Crankshaft pulley           |           |
| Disassembly Note .....         | page B-39 |
| 3. Cylinder head cover         |           |
| 4. Timing belt cover, upper    |           |
| 5. Timing belt cover, middle   |           |
| 6. Timing belt cover, lower    |           |
| 7. Timing belt                 |           |
| Disassembly Note .....         | page B-39 |
| Inspection .....               | page B-59 |
| 8. Tensioner, tensioner spring |           |
| Inspection .....               | page B-59 |
| 9. Idler                       |           |
| Inspection .....               | page B-59 |
| 10. Timing belt pulley         |           |
| Disassembly Note .....         | page B-39 |
| Inspection .....               | page B-59 |



05U0BX-094

**Disassembly Note****Crankshaft pulley**

1. Hold the flywheel with the **SST**.
2. Loosen the crankshaft pulley lock bolts.
3. Remove the plate, crankshaft pulley, timing belt outer guide plate, and timing belt inner guide plate.



05U0BX-095


**Timing belt**

1. Loosen the tensioner lock bolt.

**Caution**

- To prevent damage to the tensioner, secure it with a rag.

2. Temporarily secure the tensioner with the spring fully extended.




05U0BX-096

**Note**

- Mark the timing belt rotation for proper reinstallation.

3. Remove the timing belt.



05U0BX-097


**Timing belt pulley**

1. Hold the flywheel with the **SST**.
2. Loosen the pulley lock bolt.
3. Remove the pulley lock bolt.

**Note**

- If necessary, remove the pulley with a steering wheel puller (commercially available).

4. Remove the timing belt pulley.
5. Remove the pulley Woodruff key.




05U0BX-098




### CYLINDER HEAD

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.



05U0BX-099


- |  |  |
|--|--|
| 1. Camshaft pulley<br>Disassembly Note ..... page B-41<br>Inspection ..... page B-59 | 8. Cylinder head gasket  |
| 2. Camshaft<br>Disassembly Note ..... page B-41<br>Inspection ..... page B-52        | 9. Valve keeper<br>Disassembly Note ..... page B-41                              |
| 3. HLA<br>Disassembly Note ..... page B-41<br>Inspection ..... page B-54             | 10. Valve spring seat, upper   |
| 4. Seal plate  | 11. Valve spring<br>Inspection ..... page B-52                                   |
| 5. Thermostat housing  | 12. Valve spring seat, lower   |
| 6. Cylinder head bolt<br>Disassembly Note ..... page B-41                            | 13. Valve<br>Inspection ..... page B-49  |
| 7. Cylinder head<br>Inspection ..... page B-48                                       | 14. Valve seal<br>Disassembly Note ..... page B-42<br>Inspect for wear or damage |
|  | 15. Valve guide<br>Inspection ..... page B-49<br>Replacement ..... page B-50     |



05U0BX-100

**Disassembly Note****Camshaft pulley**


1. Hold the camshaft with a wrench.
2. Remove the camshaft pulley lock bolt.
3. Remove the camshaft pulley.



05U0BX-049

**Camshaft**

1. Loosen the camshaft cap bolts in two or three steps in the order shown in the figure.
2. Remove the camshaft caps.
3. Remove the camshaft.
4. Remove the camshaft oil seal from the camshaft.




05U0BX-050

**HLA****Caution**

- Mark the HLA with a felt pen so that they can be reinstalled in the position from which they were removed.


1. Remove the HLA from the cylinder head.



05U0BX-042

**Cylinder head bolt**

1. Loosen the cylinder head bolts in two or three steps in the order shown in the figure.
2. Remove the cylinder head bolts.




05U0BX-101

**Valve keeper**

1. Set the **SST** against the upper valve spring seat as shown in the figure.
2. Remove the valve keepers.

# B

## DISASSEMBLY




05U0BX-102

### Valve seal

1. Remove the valve seal with the **SST**.

**CYLINDER BLOCK (EXTERNAL PARTS)**

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.




05U0BX-103

- |   |   |
|---|---|
| <p>1. Clutch cover, clutch disc<br/>Service ..... page H-14</p> <p>2. Flywheel<br/>Disassembly Note ..... page B-44<br/>Inspect for wear or damage</p> <p>3. End plate</p> <p>4. Oil pan<br/>Disassembly Note ..... page B-44<br/>Inspect for damage</p> <p>5. Oil strainer</p> | <p>6. Oil pan baffle<br/>Disassembly Note ..... page B-44</p> <p>7. Water pump<br/>Service ..... page E- 9</p> <p>8. Oil pump<br/>Service ..... page D-11</p> <p>9. Front oil seal<br/>Disassembly Note ..... page B-44</p> <p>10. Rear cover</p> <p>11. Rear oil seal<br/>Disassembly Note ..... page B-44</p> |
|---|---|

# B


## DISASSEMBLY



05U0BX-104

### Disassembly Note Flywheel

1. Hold the flywheel with the **SST**.
2. Remove the flywheel lock bolts.
3. Remove the flywheel.



05U0BX-105


### Oil pan

1. Remove the oil pan mounting bolts.

#### Caution

- Do not force a prying tool between the cylinder block and the oil pan, which may damage the contact surfaces.
- Do not damage or scratch the contact surfaces when removing the old sealant.

2. Insert a screwdriver or a suitable tool only at the points shown in the figure.
3. Remove the oil pan.




05U0BX-106

### Oil pan baffle

#### Caution

- Do not bend the baffle when prying it loose.


1. Insert a screwdriver or a suitable tool between the cylinder block and the baffle to separate them.
2. Remove the baffle.



05U0BX-107

### Front oil seal

1. Remove the oil seal with a screwdriver protected with a rag.




05U0BX-108

### Rear oil seal

1. Remove the oil seal with a screwdriver protected with a rag.


**CYLINDER BLOCK (INTERNAL PARTS)**

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.



05U0BX-099


1. Connecting rod cap Disassembly Note .....	page B-46	7. Piston Inspection .....	page B-56
2. Connecting rod Disassembly Note .....	page B-46	8. Main bearing cap Disassembly Note .....	page B-47
Inspection .....	page B-57	9. Crankshaft Disassembly Note .....	page B-47
3. Connecting rod bearing Inspection .....	page B-58	Inspection .....	page B-58
4. Piston ring Disassembly Note .....	page B-46	10. Main bearing Inspection .....	page B-58
Inspection .....	page B-56	11. Thrust bearing	
5. Piston pin clip		12. Oil jet Inspection .....	page B-55
6. Piston pin Disassembly Note .....	page B-46	13. Cylinder block Inspection .....	page B-54
Inspection .....	page B-57		



05U0BX-110

### Disassembly Note Connecting rod cap


1. Before removing the connecting rod caps, measure the connecting rod side clearance. (Refer to page B-65.)



05U0BX-111

### Connecting rod

1. Before removing the connecting rods, measure the connecting rod oil clearance. (Refer to page B-65.)




05U0BX-112

2. Remove the Plastigage from the crankpin journals.

### Caution

- Do not scratch the crankshaft journal or the cylinder wall.

3. Use the handle of a hammer to remove the piston and connecting rod assembly through the top of the cylinder block.




05U0BX-113

### Piston ring

### Caution

- Do not apply excessive tension, which may cause the rings to snap out.

1. Remove the piston rings with a piston ring expander (commercially available).




05U0BX-114

### Piston pin


### Caution

- Mark the connecting rod direction for proper reassembly.


1. Remove the piston pin with the **SST**.



05U0BX-115



05U0BX-116



05U0BX-117

### Main bearing cap

1. Before removing the main bearing caps, measure the crankshaft end play. (Refer to page B-64.)

2. Loosen the main bearing cap bolts in two or three steps in the order shown in the figure.
3. Remove the main bearing caps.

### Crankshaft






1. Before removing the crankshaft, measure the main bearing oil clearances. (Refer to page B-63.)



### INSPECTION / REPAIR

#### PREPARATION

#### SST


<p>49 B012 005</p> <p>Remover &amp; installer, valve guide</p> 	<p>For removal of valve guide</p>	<p>49 L012 0A0</p> <p>Installer set, valve seal &amp; valve guide</p> 	<p>For installation of valve guide</p>
<p>49 L012 002</p> <p>Body (Part of 49 L012 0A0)</p> 	<p>For installation of valve guide</p>	<p>49 L012 003</p> <p>Installer (Part of 49 L012 0A0)</p> 	<p>For installation of valve guide</p>
<p>49 L012 004</p> <p>Nut (Part of 49 L012 0A0)</p> 	<p>For installation of valve guide</p>	05U0BX-118	

1. Clean all parts, being sure to remove all gasket fragments, dirt, oil or grease, carbon, moisture residue, and other foreign materials.
2. Inspection and repairs must be performed in the order specified.

#### Caution

- Do not damage the joints or friction surfaces of aluminum alloy components (such as the cylinder head or pistons).

05U0BX-119



05U0BX-120

#### CYLINDER HEAD

1. Inspect the cylinder head for damage, cracks, and leakage of water and oil. Replace the cylinder head if necessary.
2. Measure the cylinder head distortion in the six directions shown in the figure.

**Distortion: 0.15mm (0.006 in) max.**

#### Caution

- Before grinding the cylinder head, check the following and repair or replace the cylinder head as necessary.

**Sinking of valve seats**


**Damage of manifold contact surface**

**Camshaft oil clearances and end play**


3. If the cylinder head distortion exceeds specification, grind the cylinder head surface.  
If the cylinder head height is not within specification, replace it.

**Height: 133.8—134.0mm (5.268—5.276 in)**

**Grinding: 0.20mm (0.008 in) max.**



05U0BX-121




05U0BX-289

4. Measure the manifold contact surface distortion in the four directions shown in the figure.

**Distortion: 0.15mm (0.006 in) max.**

5. If distortion exceeds specification, grind the surface or replace the cylinder head.



05U0BX-122


### VALVE MECHANISM Valve and Valve Guide

1. Inspect each valve for the following. Replace or resurface the valve if necessary.
  - (1) Damaged or bent stem.
  - (2) Rough or damaged face.
  - (3) Damaged or unevenly worn stem tip.
2. Measure the valve head margin thickness of each valve. Replace the valve if necessary.

#### Margin thickness

**IN : 1.0mm (0.039 in)**

**EX: 1.0mm (0.039 in)**



05U0BX-123

3. Measure the length of each valve at the points shown.

#### Length

##### Standard


**IN : 105.29mm (4.1452 in)**

**EX: 105.39mm (4.1492 in)**

##### Minimum

**IN : 104.79mm (4.1256 in)**

**EX: 104.89mm (4.1295 in)**



05U0BX-124

4. Measure the stem diameter of each valve.

#### Diameter

**IN : 5.970—5.985mm (0.2350—0.2356 in)**


**EX: 5.965—5.980mm (0.2348—0.2354 in)**

5. Measure the inner diameter of each valve guide at the points shown.

#### Inner diameter

**IN : 6.01—6.03mm (0.2366—0.2374 in)**

**EX: 6.01—6.03mm (0.2366—0.2374 in)**



05U0BX-125

6. Calculate the valve stem to guide clearance. Subtract the outer diameter of the valve stem from the inner diameter of the corresponding valve guide.


#### Clearance

**IN : 0.025—0.060mm (0.0010—0.0024 in)**

**EX: 0.030—0.065mm (0.0012—0.0026 in)**

**Maximum: 0.20mm (0.008 in)**

7. If the clearance exceeds specification, replace the valve and/or valve guide.



05U0BX-126


8. Measure the height A of each valve guide. Replace the valve guide if necessary.

**Height: 16.8—17.4mm (0.661—0.685 in)**

### Replacement of valve guide

#### Note


- Although the shapes of the intake and exhaust valve guides are different, use the exhaust valve guide on both sides as a replacement.



05U0BX-127

### Removal

1. Remove the valve guide from the side opposite the combustion chamber with the **SST**.




9MU0B2-112

### Installation

1. Assemble the **SST** so that depth L is as specified.


**Depth L: 16.8—17.4mm (0.661—0.685 in)**

2. Tighten the locknut.




05U0BX-128


3. Tap the valve guide in from the side opposite the combustion chamber until the **SST** contacts the cylinder head.
4. Verify that the valve guide height is within specification.
5. If not within specification, repeat Steps 1—4.




05U0BX-129




05U0BX-130




05U0BX-131



05U0BX-132



05U0BX-133



05U0BX-134

### Valve Seat

1. Inspect the contact surface of each valve seat and valve face for the following:
  - (1) Roughness.
  - (2) Damage.
2. If necessary, resurface the valve seat with a **45°** valve seat cutter and/or resurface the valve face.


3. Apply a thin coat of Prussian blue to the valve face.
4. Inspect the valve seating by pressing the valve against the seat.
  - (1) If blue does not appear 360° around the valve face, replace the valve.
  - (2) If blue does not appear 360° around the valve seat, resurface the seat.

5. Measure the seat contact width.

**Width: 0.8—1.4mm (0.031—0.055 in)**

6. Verify that the valve seating position is at the center of the valve face.
  - (1) If the seating position is too high, correct the valve seat with a **75°** cutter and a **45°** cutter.
  - (2) If the seating position is too low, correct the valve seat with a **35° (IN)** or **15° (EX)** cutter and a **45°** cutter.
7. Seat the valve to the valve seat with lapping compound.

8. Inspect the sinking of the valve seat.




05U0BX-135

9. Measure the protruding length (dimension **L**) of the valve stem.

**Dimension L: 43.5mm (1.713 in)**

- (1) If **L** is **43.5—44.0mm (1.713—1.732 in)**, no correction needed.
- (2) If **L** is **44.1—45.0mm (1.736—1.772 in)**, adjust with washer on spring seat area of cylinder head.
- (3) If **L** is **45.1mm (1.776 in) or more**, replace cylinder head.



05U0BX-136

### Valve Spring

1. Inspect each valve spring for cracks or damage.
2. Measure the free length and out-of-square. Replace the valve spring if necessary.

#### Free length

##### Standard


**IN : 48.0mm (1.890 in)**

**EX : 48.3mm (1.902 in)**

##### Minimum

**IN : 47.0mm (1.850 in)**

**EX : 47.3mm (1.862 in)**




05U0BX-137

#### Out-of-square

**IN : 1.68mm (0.0661 in) max.**

**EX : 1.69mm (0.0665 in) max.**




05U0BX-138

### CAMSHAFT

1. Set the front and rear journals on V-blocks.
2. Measure the camshaft runout. Replace the camshaft if necessary.

**Runout: 0.03mm (0.0012 in) max.**



05U0BX-139

3. Inspect the camshaft for wear or damage. Replace the camshaft if necessary.
4. Measure the cam lobe heights at the two points as shown.

#### Height

##### Standard


**IN : 40.888mm (1.6098 in)**

**EX : 40.889mm (1.6098 in)**

##### Minimum

**IN : 40.688mm (1.6019 in)**

**EX : 40.689mm (1.6019 in)**




05U0BX-140

5. Measure the journal diameters in X and Y directions at the two points (A and B) shown.

**Diameter:**

**25.940—25.965mm (1.0213—1.0222 in)**

**Out-of-round: 0.05mm (0.002 in) max.**




05U0BX-141

6. Measure the camshaft journal oil clearances.

**Caution**

- **Do not install the HLA when measuring the oil clearance.**

- (1) Remove all foreign material and oil from the journals and bearing surface.
- (2) Set the camshaft onto the cylinder head.
- (3) Position Plastigage atop the journals in the axial direction.
- (4) Install the camshaft caps according to the cap number and arrow mark.




05U0BX-142

- (5) Install the camshaft cap bolts and tighten them in two or three steps in the order shown in the figure.


**Tightening torque:**

**11.3—14.2 N·m (1.15—1.45 m·kg, 100—126 in·lb)**




05U0BX-143

- (6) Loosen the camshaft cap bolts in two or three steps in the order shown in the figure.
- (7) Remove the camshaft caps.



05U0BX-144



05U0BX-145


(8) Measure the oil clearances.

**Oil clearance:**

**0.035—0.081mm (0.0014—0.0032 in)**

**Maximum: 0.15mm (0.006 in)**

(9) If the oil clearance exceeds specification, replace the cylinder head.




05U0BX-146

7. Measure the camshaft end play. If the end play exceeds specification, replace the camshaft and/or the cylinder head.

**End play : 0.07—0.19mm (0.0028—0.0075 in)**

**Maximum: 0.20mm (0.008 in)**




05U0BX-147

**HLA**

**Caution**

- Do not attempt to repair the HLA.

1. Inspect the HLA friction surfaces for wear or damage. Replace the HLA if necessary.
2. Hold the bucket body and press the plunger by hand. If the plunger moves, replace the HLA.



05U0BX-148

**CYLINDER BLOCK**


1. Inspect the cylinder block for the following. Repair or replace the cylinder block as necessary.
  - (1) Leakage damage.
  - (2) Cracks.
  - (3) Scoring of wall.
2. Measure the distortion of the top surface of the cylinder block in the six directions shown in the figure.

**Distortion: 0.15mm (0.006 in) max.**


3. If the distortion exceeds specification, repair by grinding or replace the cylinder block.

**Height : 221.5mm (8.720 in)**


**Grinding: 0.20mm (0.008 in) max.**




05U0BX-149




05U0BX-150




05U0BX-151



05U0BX-152



05U0BX-153



05U0BX-154

4. Measure the cylinder bores in X and Y directions at three levels (A, B, and C) in each cylinder as shown.

### Cylinder bore

mm (in)

Bore size	Diameter
Standard	78.006—78.013 (3.0711—3.0714)
0.25 (0.010) oversize	78.256—78.263 (3.0809—3.0812)
0.50 (0.020) oversize	78.506—78.513 (3.0908—3.0911)

### Caution

- The boring size should be based on the size of an oversize piston and be the same for all cylinders.

- (1) If the cylinder bore exceeds the maximum, rebore the cylinder to oversize.
- (2) If the difference between measurements A and C exceeds the maximum taper, rebore the cylinder to oversize.

**Taper: 0.019mm (0.0007 in) max.**

- (3) If the difference between measurements X and Y exceeds the maximum out-of-round, rebore the cylinder to oversize.


**Out-of-round: 0.019mm (0.0007 in) max.**

5. If the upper part of a cylinder wall shows uneven wear, remove the ridge with a ridge reamer.

### OIL JET

1. Push the check ball and verify that it moves smoothly.
2. Blow through the oil jet and verify that air flows.





05U0BX-155

### PISTON, PISTON RING, AND PISTON PIN

#### Piston

##### Caution


- If the piston is replaced, the piston rings must also be replaced.

1. Inspect the outer circumferences of all pistons for seizure or scoring. Replace the piston if necessary.
2. Measure the outer diameter of each piston at a right angle (90°) to the piston pin, **16.5mm (0.650 in)** below the oil ring land lower edge.

#### Piston diameter

mm (in)

Piston size	Diameter
Standard	77.954—77.974 (3.0690—3.0698)
0.25 (0.010) oversize	78.211—78.217 (3.0792—3.0794)
0.50 (0.020) oversize	78.461—78.467 (3.0890—3.0892)




05U0BX-156

3. Measure the piston-to-cylinder clearance.

**Clearance: 0.039—0.052mm (0.0015—0.0020 in)**  
**Maximum: 0.15mm (0.006 in)**

4. If the clearance exceeds the maximum, replace the piston or rebore the cylinders to fit oversize pistons.




05U0BX-157

#### Piston and Piston Rings


1. Measure the piston ring to ring land clearance around the entire circumference using a new piston ring.

**Clearance (Top and Second):**  
**0.03—0.07mm (0.0012—0.0028 in)**  
**Maximum: 0.15mm (0.006 in)**

2. If the clearance exceeds the maximum, replace the piston.
3. Inspect the piston rings for damage, abnormal wear, or breakage. Replace the piston rings if necessary.
4. Insert the piston ring into the cylinder by hand and use the piston to push it to the bottom of the ring travel.



05U0BX-287




05U0BX-158

5. Measure each piston ring end gap with a feeler gauge. Replace the piston ring if necessary.

**End gap**

**Top** : 0.15—0.30mm (0.006—0.012 in)  
**Second**: 0.15—0.30mm (0.006—0.012 in)  
**Oil rail** : 0.20—0.70mm (0.008—0.028 in)  
**Maximum** : 1.0mm (0.039 in)




05U0BX-159

**Piston and Piston Pin**

1. Measure each piston pin hole diameter in X and Y directions at four points.

**Diameter**: 19.988—20.000mm (0.7869—0.7874 in)



05U0BX-160


2. Measure each piston pin diameter in X and Y directions at four points.

**Diameter**: 19.987—19.993mm (0.7869—0.7871 in)

3. Calculate the piston pin-to-piston clearance.

**Clearance**: -0.005—0.013mm (-0.0002—0.0005 in)

4. If the clearance exceeds specification, replace the piston and/or piston pin.



05U0BX-161


**CONNECTING ROD**

1. Measure each connecting rod bushing inner diameter.

**Diameter**: 20.003—20.014mm (0.7875—0.7880 in)

2. Calculate the clearance between the connecting rod bushing and piston pin.


**Clearance**: 0.010—0.027mm (0.0004—0.0011 in)




05U0BX-162

3. Measure each connecting rod for bending. Repair or replace the connecting rod if necessary.


**Bending**: 0.075mm (0.0030 in) max./50mm (1.97 in)




05U0BX-163




05U0BX-164



05U0BX-165



05U0BX-166



05U0BX-167

### CRANKSHAFT

1. Check the journals and pins for damage, scoring, and oil hole clogging.
2. Set the crankshaft on V-blocks.
3. Measure the crankshaft runout at the center journal.  
Replace the crankshaft if necessary.

**Runout: 0.04mm (0.0016 in) max.**

4. Measure each journal diameter in X and Y directions at two points.

#### Main journal

**Diameter: 49.938—49.956mm (1.9661—1.9668 in)**

**Out-of-round: 0.05mm (0.0020 in) max.**

#### Crankpin journal

**Diameter: 44.940—44.956mm (1.7693—1.7699 in)**

**Out-of-round: 0.05mm (0.0020 in) max.**

#### Caution

- Do not remove the fillet roll area R when grinding.

5. If the diameter is less than the minimum, grind the journals to match an undersize bearing.

#### Undersize bearing:

**0.25mm (0.010 in), 0.50mm (0.020 in),**

**0.75mm (0.030 in)**

#### Main journal diameter undersize

mm (in)

Bearing size	Journal diameter
0.25 (0.010) undersize	49.704—49.708 (1.9568—1.9570)
0.50 (0.020) undersize	49.454—49.458 (1.9470—1.9472)
0.75 (0.030) undersize	49.204—49.208 (1.9372—1.9373)

#### Crankpin journal diameter undersize


mm (in)

Bearing size	Journal diameter
0.25 (0.010) undersize	44.690—44.706 (1.7594—1.7601)
0.50 (0.020) undersize	44.440—44.456 (1.7496—1.7502)
0.75 (0.030) undersize	44.190—44.206 (1.7398—1.7404)


### BEARING

#### Main Bearing and Connecting Rod Bearing


1. Check the main bearings and the connecting rod bearings for peeling, scoring, and other damage.




05U0BX-168




05U0BX-169



05U0BX-170



05U0BX-171



05U0BX-172

## TIMING BELT

### Caution

- Never forcefully twist, turn inside out, or bend the timing belt.
- Do not allow oil or grease on the belt.

1. Replace the timing belt if there is any oil or grease on it.
2. Check the timing belt for damage, wear, peeling, cracks, and hardening. Replace the timing belt if necessary.

## TENSIONER, IDLER

### Caution

- Do not clean the tensioner or idler with cleaning fluids. If necessary, use a soft rag to wipe them clean, and avoid scratching them.

1. Check the tensioner and idler for smooth rotation and abnormal noise. Replace the tensioner or idler if necessary.

## TENSIONER SPRING

1. Measure the free length of the tensioner spring. Replace the tensioner spring if necessary.

**Free length: 58.8mm (2.315 in)**

## PULLEY

### Timing Belt Pulley, Camshaft Pulley












### Caution

- Do not clean the pulleys with cleaning fluids. If necessary, use a soft rag to wipe them clean, and avoid scratching them.

1. Inspect the pulley teeth for wear, deformation, and other damage. Replace the pulley if necessary.

### ASSEMBLY

#### PREPARATION SST

<p>49 0221 061A</p> <p>Remover &amp; installer, piston pin</p> 	<p>For removal and installation of piston pin</p>	<p>49 E301 060</p> <p>Brake, ring gear</p> 	<p>For prevention of engine rotation</p>
<p>49 E301 061</p> <p>Body (Part of 49 E301 060)</p> 	<p>For prevention of engine rotation</p>	<p>49 E301 062</p> <p>Collar (Part of 49 E301 060)</p> 	<p>For prevention of engine rotation</p>
<p>49 SE01 310</p> <p>Centering tool, clutch disc</p> 	<p>For installation of clutch disc</p>	<p>49 L012 0A0</p> <p>Installer set, valve seal &amp; valve guide</p> 	<p>For installation of valve seal</p>
<p>49 L012 001</p> <p>Installer (Part of 49 L012 0A0)</p> 	<p>For installation of valve seal</p>	<p>49 L012 002</p> <p>Body (Part of 49 L012 0A0)</p> 	<p>For installation of valve seal</p>
<p>49 L012 005</p> <p>Spacer (Part of 49 L012 0A0)</p> 	<p>For installation of valve seal</p>	<p>49 0636 100A</p> <p>Arm, valve spring lifter</p> 	<p>For removal and installation of valve</p>
<p>49 B012 006</p> <p>Pivot, valve spring lifter</p> 	<p>For removal and installation of valve</p>	<p>05U0BX-173</p>	

1. Clean all parts before reinstallation.
2. Apply new engine oil to all sliding and rotating parts.
3. Replace plain bearings if they are peeling, burned, or otherwise damaged.
4. Tighten all bolts and nuts to the specified torques.


#### Caution

- Do not reuse gaskets or oil seals.


05U0BX-174

CYLINDER BLOCK (INTERNAL PARTS)

Torque Specifications




05U0BX-175




05U0BX-176

**Connecting Rod**


1. Install one piston pin clip into the clip groove in the piston.
2. Assemble the piston and the connecting rod in the direction from which they were disassembled.
3. Apply clean engine oil to the piston pin.
4. Install the piston pin from the side opposite the clip.
5. Tap the piston pin in with the **SST** until the pin contacts the clip.  
If the pin cannot be installed easily, replace the connecting rod.




05U0BX-177




05U0BX-178



05U0BX-179



05U0BX-180



05U0BX-181

6. Install the second clip into the clip groove in the piston.

7. Check the oscillation torque of the connecting rod. If the large end does not drop by its own weight, replace the piston and/or piston pin.

### Piston Ring

1. Install the three-piece oil rings on the pistons.
  - (1) Apply clean engine oil to the oil ring spacer and rails.
  - (2) Install the oil ring spacer with the ends upward.

#### Note

- The upper rail and lower rail are the same.
- The rails may be installed with either face upward.


(3) Install the upper rail and lower rail.

2. Verify that both rails are expanded by the spacer tangs as shown in the figure by making certain the rails turn smoothly in both directions.


#### Caution

- The rings must be installed with the R marks upward.
- The second ring must be installed with the scraper face downward.


3. Apply clean engine oil to the top and second piston rings.
4. Install the second ring to the piston; then install the top ring. Use a piston ring expander (commercially available).




05U0BX-182




05U0BX-183



05U0BX-184



05U0BX-185



05U0BX-186

5. Position the end gaps of the rings as shown in the figure.

## Oil Jet

1. Install the oil jets.

## Tightening torque:

12—18 N·m (1.2—1.8 m·kg, 104—156 in·lb)

## Crankshaft

1. Before installing the crankshaft, inspect the main bearing oil clearances as follows.

## Oil clearance inspection

(1) Remove all foreign material and oil from the journals and bearings.

## Caution

- Install the grooved upper main bearings in the cylinder block.
- Install the thrust bearings with the oil groove facing the crankshaft.

(2) Install the upper main bearings and thrust bearings.

(3) Set the crankshaft in the cylinder block.

## Caution

- Do not rotate the crankshaft when measuring the oil clearances.

(4) Position Plastigage atop the journals in the axial direction.


(5) Install the lower main bearings and the main bearing caps according to the cap number and  $\leftarrow$  mark.

(6) Tighten the main bearing cap bolts in two or three steps in the order shown in the figure.

## Tightening torque:

54—59 N·m (5.5—6.0 m·kg, 40—43 ft·lb)






05U0BX-187


- (7) Remove the main bearing caps, and measure the Plastigage at each journal at the widest point for the smallest clearance, and at the narrowest point for the largest clearance.
- (8) If the oil clearance exceeds specification, grind the crankshaft and use undersize main bearings. (Refer to page B-58.)

**Oil clearance: 0.018—0.036mm (0.0007—0.0014 in)**  
**Maximum: 0.10mm (0.004 in)**



05U0BX-188


- 2. Apply a liberal amount of clean engine oil to the main bearings, thrust bearings and main journals.
- 3. Install the crankshaft and the main bearing caps according to the cap number and ↵ mark.



05U0BX-189

- 4. Tighten the main bearing cap bolts in two or three steps in the order shown in the figure.


**Tightening torque:**  
**54—59 N·m (5.5—6.0 m·kg, 40—43 ft·lb)**



05U0BX-190

- 5. Measure the crankshaft end play.

**End play : 0.080—0.282mm (0.0031—0.0111 in)**  
**Maximum: 0.30mm (0.012 in)**




05U0BX-191


- 6. If the end play exceeds the maximum, grind the crankshaft and install an oversize thrust bearing or replace the crankshaft and thrust bearing.

**Thrust bearing width**


- Standard:**  
**2.500—2.550mm (0.0984—0.1004 in)**
- 0.25mm (0.010 in) oversize:**  
**2.625—2.675mm (0.1033—0.1053 in)**
- 0.50mm (0.020 in) oversize:**  
**2.750—2.800mm (0.1083—0.1102 in)**
- 0.75mm (0.030 in) oversize:**  
**2.875—2.925mm (0.1132—0.1152 in)**




05U0BX-192




05U0BX-193



05U0BX-194



05U0BX-195



05U0BX-196

### Piston and Connecting Rod Assembly

**Caution**

- Protect the connecting rod bolts with rubber sleeves to prevent damage to the crankpin journals.

1. Apply a liberal amount of clean engine oil to the cylinder walls, pistons, and piston rings.
2. Check the piston rings for correct end gap alignment.
3. Insert each piston assembly into the cylinder block with the **F** mark facing the front of the engine. Use a piston ring compressor (commercially available).

### Connecting Rod Cap

1. Measure the connecting rod bearing oil clearances using the same procedure as for the main bearing oil clearance.

**Caution**

- Align the matching marks on the cap and the connecting rod when installing the connecting rod cap.

**Tightening torque:**

50—54 N·m (5.1—5.5 m·kg, 37—40 ft·lb)

**Oil clearance: 0.028—0.068mm (0.0011—0.0027 in)**

**Maximum: 0.10mm (0.004 in)**


2. If the oil clearance exceeds the maximum, grind the crankshaft and use undersize bearings. (Refer to page B-58.)

3. Measure the connecting rod side clearances.

**Side clearance: 0.110—0.262mm (0.0043—0.0103 in)**

**Maximum: 0.30mm (0.012 in)**

4. If the clearance exceeds the maximum, replace the connecting rod and cap.





05U0BX-197

5. Apply a liberal amount of clean engine oil to the crankpin journals and connecting rod bearings.
6. Install the connecting rod caps with the matching marks aligned.
7. Tighten the connecting rod cap nuts in two or three steps.


**Tightening torque:**  
**50—54 N·m (5.1—5.5 m·kg, 37—40 ft·lb)**

**CYLINDER BLOCK (EXTERNAL PARTS)  
 Torque Specifications**







05U0BX-199




05U0BX-200



05U0BX-201



05U0BX-202



05U0BX-203

**Rear Cover**

1. Apply a small amount of clean engine oil to the lip of a new oil seal.
2. Push the oil seal slightly in by hand.

**Caution**

- **The oil seal must be pressed in until it is flush with the edge of the rear cover.**

3. Press the oil seal in evenly with a suitable pipe.

**Oil seal outer diameter: 100mm (3.94 in)**

4. Apply silicone sealant to the shaded area shown in the figure.

5. Install the rear cover.

**Tightening torque:**

**7.8—11 N·m (80—110 cm·kg, 69—95 in·lb)**

**Oil Pump**

1. Apply a small amount of clean engine oil to the lip of a new oil seal.
2. Push the oil seal slightly in by hand.

**Caution**

- **The oil seal must be pressed in until it is flush with the edge of the oil pump body.**


3. Press the oil seal in evenly with a suitable pipe.

**Oil seal outer diameter: 44mm (1.73 in)**

4. Install the oil pump and a new gasket.

**Tightening torque:**

**19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)**




05U0BX-204

### Caution

- Do not scratch the oil pump.

5. Cut away the portion of the gasket that projects from the body toward the oil pan side.




05U0BX-205

### Water Pump

1. Remove all foreign material from the water pump mounting surface.
2. Install the water pump and a new gasket.

### Tightening torque:

**19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)**



05U0BX-206


### Oil Pan Baffle

1. Remove all foreign material from the contact surfaces.

### Caution

- The oil pan must be secured within 30 minutes after the sealant is applied to the baffle.

2. Apply a continuous bead of silicone sealant to the baffle along the inside of the bolt holes.
3. Install the baffle.




05U0BX-207

### Oil Strainer

1. Install the oil strainer and a new gasket.

### Tightening torque:


**7.8—11 N·m (80—110 cm·kg, 69—95 in·lb)**



05U0BX-208


### Oil Pan

1. Remove all foreign material from the contact surfaces.
2. Apply silicone sealant to the shaded areas shown in the figure.



05U0BX-209

3. Install new gaskets onto the oil pump body and the rear cover with the projections in the notches shown in the figure.




05U0BX-210

4. Apply a continuous bead of silicone sealant to the oil pan along the inside of the bolt holes and overlap the ends.
5. Install the oil pan.

**Tightening torque:**

**7.8—11 N·m (80—110 cm·kg, 69—95 in·lb)**




05U0BX-211

**End Plate**

1. Install the end plate.

**Tightening torque:**

**7.8—11 N·m (80—110 cm·kg, 69—95 in·lb)**



05U0BX-070

**Flywheel**

1. Remove the sealant from the flywheel bolt holes in the crankshaft and from the flywheel bolts.

**Caution**


- If all the previous sealant cannot be removed from a bolt, replace the bolt.
- Do not apply sealant if a new bolt is used.

2. Set the flywheel onto the crankshaft.
3. Apply sealant to the flywheel bolts and install them.

4. Hold the flywheel with the **SST**.
5. Tighten the bolts in two or three steps in the order shown.

**Tightening torque:**

**96—103 N·m (9.8—10.5 m·kg, 71—76 ft·lb)**




05U0BX-071

**Clutch Disc and Clutch Cover**

1. Install the clutch disc and clutch cover using the **SST**.  
(Refer to page H-14.)

**Tightening torque:**


**18—26 N·m (1.8—2.7 m·kg, 13—20 ft·lb)**




05U0BX-212

**CYLINDER HEAD**


**Torque Specifications**




05U0BX-213




05U0BX-214




05U0BX-215



05U0BX-216



05U0BX-217



05U0BX-218

## Valve Seal

1. Assemble the **SST** so that depth **L** is as specified.

**Depth L: 18.3—18.5mm (0.720—0.728 in)**

2. Slide the valve seal onto the valve guide.
3. Set the **SST** against the valve seal.

## Caution

- Do not use a hammer.

4. Press the valve seal on until the **SST** contacts the cylinder head.

## Valve and Valve Spring

1. Install the lower spring seat.
2. Install the valve.

## Caution

- Install the spring with the closer pitch toward the cylinder head.


3. Install the valve spring and the upper spring seat.

4. Compress the valve spring with the **SST**, and install the valve keepers.
5. Remove the **SST**.
6. Tap the end of the valve stem lightly two or three times with a plastic hammer to verify that the keepers are all fully seated.



# B


## ASSEMBLY



05U0BX-219

### Cylinder Head Gasket

1. Remove all foreign material from the top of the cylinder block.
2. Place the new cylinder head gasket in position.




05U0BX-220

### Cylinder Head

1. Install the cylinder head.
2. Apply clean engine oil to the bolt threads and seat faces.
3. Tighten the cylinder head bolts in two or three steps in the order shown.

### Tightening torque:

**76—81 N·m (7.7—8.3 m·kg, 56—60 ft·lb)**




05U0BX-221

### Thermostat Housing

1. Remove all foreign material from the thermostat housing mounting surface.
2. Install a new O-ring and the thermostat housing.

### Tightening torque:

**19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)**




05U0BX-222

### Seal Plate

1. Install the seal plate on the cylinder head.

### Tightening torque:

**7.8—11 N·m (80—110 cm·kg, 69—95 in·lb)**




05U0BX-223


### HLA

1. Apply clean engine oil to the friction surfaces.
2. If the HLA are being reused, install them in the position from which they were removed.
3. Verify that the HLA move smoothly in their bores.


CRANK ANGLE SENSOR DRIVE GROOVE




05U0BX-224




05U0BX-054



05U0BX-055



05U0BX-056



05U0BX-225

## Camshaft

### Note

- The intake camshaft is grooved for the crank angle sensor drive.

1. Apply clean engine oil to the camshaft journals and bearings.
2. Install the camshaft in position.

### Caution

- Do not allow any sealant on the camshaft journal surfaces.

3. Apply silicone sealant to the shaded areas shown in the figure.
4. Install the camshaft caps according to the cap number and arrow mark.

5. Install the camshaft cap bolts, and tighten them in two or three steps in the order shown.

### Tightening torque:

**11.3—14.2 N·m (1.15—1.45 m·kg, 100—126 in·lb)**

6. Apply a small amount of clean engine oil to the lip of a new camshaft oil seal.
7. Push the oil seal slightly in by hand.

### Caution


- The oil seal must be tapped in until it is flush with the edge of the camshaft cap.

8. Tap the oil seal in evenly with a suitable pipe and a hammer.

**Oil seal outer diameter: 48mm (1.89 in)**

## Camshaft Pulley

1. Turn the camshafts until the camshaft dowel pins face straight up.
2. Install the camshaft pulleys with the I mark (intake side) or the E mark (exhaust side) straight up.



05U0BX-058


3. Install the camshaft pulley lock bolts.
4. Hold the camshaft with a wrench.
5. Tighten the camshaft pulley lock bolt.

### Tightening torque:


**49—61 N·m (5.0—6.2 m·kg, 36—45 ft·lb)**

### TIMING BELT


#### Torque Specifications




05U0BX-226




05U0BX-227




05U0BX-228



05U0BX-229



05U0BX-230



05U0BX-029

## Timing Belt Pulley

1. Reverse the direction of the **SST** on the flywheel.
2. Install the timing belt pulley.
3. Install the pulley Woodruff key with the tapered side toward the oil pump body.
4. Install the pulley lock bolt.
5. Tighten the pulley lock bolt.

### Tightening torque:

**108—118 N·m (11.0—12.0 m·kg, 80—87 ft·lb)**

## Idler

1. Install the idler.

### Tightening torque:

**37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)**

## Tensioner and Tensioner Spring


1. Install the tensioner and the tensioner spring.
2. Temporarily secure the tensioner with the spring fully extended.

## Timing Belt


1. Turn the crankshaft and align the timing belt pulley mark with the timing mark.
2. Verify that the camshaft pulley marks are aligned with the seal plate marks.

### Caution


- For intake side, align the **E** mark.
- For exhaust side, align the **I** mark.




05U0BX-030




05U0BX-031



05U0BX-032



05U0BX-033



05U0BX-231

3. Install the timing belt so that there is no looseness at the idler side or between the two camshaft pulleys.

### Caution

- Do not turn the crankshaft counterclockwise.

4. Turn the crankshaft two turns clockwise, and align the timing belt pulley mark with the timing mark.
5. Verify that the camshaft pulley marks are aligned with the seal plate marks.  
If not aligned, remove the timing belt and repeat from tensioner installation.
6. Turn the crankshaft 1 and 5/6 turn clockwise, and align the timing belt pulley mark with the tension set mark.

7. Loosen the tensioner lock bolt to apply tension to the timing belt.
8. Tighten the tensioner lock bolt.

### Tightening torque:

**37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)**

9. Turn the crankshaft 2 and 1/6 turns clockwise and verify that the timing marks are correctly aligned.
10. Measure the timing belt deflection by applying moderate pressure (**98 N, 10 kg, 22 lb**) midway between the two camshaft pulleys.  
If the deflection is not correct, repeat from Step 7 above.

### Deflection:


**9.0—11.5mm (0.35—0.45 in) at 98 N (10 kg, 22 lb)**

### Timing Belt Cover

1. Install the lower, middle, and upper covers.

### Tightening torque:

**7.8—11 N·m (80—110 cm·kg, 69—95 in·lb)**




05U0BX-232

**Cylinder Head Cover**

1. Apply silicone sealant to the shaded areas shown in the figure.
2. Install the cylinder head cover.

**Tightening torque:**

**4.9—8.8 N·m (50—90 cm·kg, 43—78 in·lb)**




05U0BX-233

**Crankshaft Pulley**

**Caution**


- Make sure the timing belt inner guide plate is installed in the proper direction.

1. Install the timing belt inner guide plate.



05U0BX-234

2. Install the timing belt outer guide plate.
3. Install the crankshaft pulley.
4. Install the plate.




05U0BX-235

5. Tighten the lock bolts with the **SST**.

**Tightening torque:**

**12—17 N·m (1.25—1.75 m·kg, 109—152 in·lb)**

6. Remove the **SST**.



05U0BX-236


**Water Pump Pulley**

1. Install the water pump pulley.


**Tightening torque:**

**7.8—11 N·m (80—110 cm·kg, 69—95 in·lb)**

### AUXILIARY PARTS Torque Specifications



05U0BX-237




05U0BX-238

#### Engine Hanger

1. Install the front and rear engine hangers.

#### Tightening torque:

**37-52 N-m (3.8-5.3 m-kg, 27-38 ft-lb)**



05U0BX-239


**Oil Level Gauge Pipe**

1. Apply a small amount of clean engine oil to the new O-ring.
2. Push the level gauge pipe into the oil pan.
3. Tighten the level gauge pipe bracket nut.

**Tightening torque:**

**7.8—11 N·m (80—110 cm·kg, 69—95 in·lb)**

4. Install the level gauge.




05U0BX-240

**Spark Plug**

1. Apply antiseize compound or molybdenum-based lubricant to the spark plug threads.
2. Install the spark plugs.

**Tightening torque:**

**15—23 N·m (1.5—2.3 m·kg, 11—17 ft·lb)**




05U0BX-241

**Water Outlet Pipe**

1. Remove all foreign material from the water outlet pipe mounting surface.
2. Install a new gasket and the water outlet pipe.

**Tightening torque:**

**19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)**




05U0BX-242

**Oil Pressure Gauge Sender Unit**

1. Install the oil pressure gauge sender unit.

**Tightening torque:**

**12—18 N·m (1.2—1.8 m·kg, 104—156 in·lb)**




05U0BX-243

**Oil Filter**

1. Remove all foreign material from the oil filter mounting surface.
2. Apply a small amount of clean engine oil to the rubber seal of the oil filter.
3. Install the oil filter and tighten it by hand until the rubber seal contacts the base.
4. Tighten the filter 1 and 1/6 turn with a filter wrench.




**ASSEMBLY**

05U0BX-244

**Right Engine Mount**


1. Install the right engine mount.

**Tightening torque:****36—54 N·m (3.7—5.5 m·kg, 27—40 ft·lb)**

05U0BX-245

**Alternator Bracket**


1. Install the alternator bracket.

**Tightening torque:****36—54 N·m (3.7—5.5 m·kg, 27—40 ft·lb)**

05U0BX-246

**Alternator**


1. Install the alternator and loosely tighten the mounting bolts.



05U0BX-247

**Intake Manifold Assembly**

1. Remove all foreign material from the intake manifold contact surface.
2. Install a new gasket and the intake manifold assembly.


**Tightening torque:****19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)**

05U0BX-248

**Manifold Bracket**

1. Install the manifold bracket.


**Tightening torque:****36—54 N·m (3.7—5.5 m·kg, 27—40 ft·lb)**



05U0BX-249

**Crank Angle Sensor**

1. Apply grease to a new O-ring and the blade.
2. Install the crank angle sensor and loosely tighten the installation bolt.



05U0BX-250

**Ignition Coil and High-tension Lead**

1. Install the ignition coil.

**Tightening torque:**

**19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)**


2. Connect the high-tension leads.

### ENGINE STAND DISMOUNTING

#### PROCEDURE

1. Remove the engine from the **SST (engine stand)**.
2. Remove the **SST (engine hanger)** from the engine.
3. Install the parts shown in the figure.

#### Torque Specifications




05U0BX-251

#### Left Engine Mount


1. Install the left engine mount.

#### Tightening torque:

**36-54 N-m (3.7-5.5 m-kg, 27-40 ft-lb)**



05U0BX-252



05U0BX-253

### P/S Oil Pump Bracket

1. Install the P/S oil pump bracket.

#### Tightening torque:


**37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)**

### Idler

1. Install the A/C idler.

#### Tightening torque:

**37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)**



05U0BX-254


### Water Inlet Pipe and Bypass Pipe

1. Remove all foreign material from the water inlet pipe mounting surface.
2. Install a new gasket and the water inlet pipe.

#### Tightening torque:

**19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)**

3. Apply a small amount of engine coolant to the new O-ring.
4. Install the water bypass pipe.



05U0BX-255


### A/C Compressor Bracket

1. Install the A/C compressor bracket.

#### Tightening torque:

**(A): 19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)**

**(B): 37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)**




05U0BX-256

### Exhaust Manifold

1. Remove all foreign material from the exhaust manifold contact surface.
2. Install a new gasket and the exhaust manifold.

#### Tightening torque:

**38—46 N·m (3.9—4.7 m·kg, 28—34 ft·lb)**



05U0BX-257

### Exhaust Manifold Insulator

1. Install the exhaust manifold insulator.

#### Tightening torque:

**7.8—11 N·m (80—110 cm·kg, 69—95 in·lb)**


### INSTALLATION

#### PROCEDURE


1. Tighten all bolts and nuts to the specified torques.

#### Step 1

#### Torque Specifications



05U0BX-258



05U0BX-259

#### Transmission

1. Join the engine and transmission.
2. Install the transmission mounting bolts.

#### Caution

- Install the exhaust pipe bracket as shown.

3. Tighten the bolts.

#### Tightening torque:

64—89 N-m (6.5—9.1 m-kg, 47—66 ft-lb)

#### Starter

1. Install the starter to the transmission housing.


#### Tightening torque:

37—52 N-m (3.8—5.3 m-kg, 27—38 ft-lb)

2. Install the starter bracket bolt.

#### Tightening torque:

37—52 N-m (3.8—5.3 m-kg, 27—38 ft-lb)




05U0BX-260

## Step 2


### Warning

- Be sure the vehicle is securely supported on safety stands.

### Torque Specifications



05U0BX-261



05U0BX-262


### Engine and transmission assembly

1. Suspend the engine and transmission assembly.

### Caution

- Do not damage any components in the engine compartment.

2. Install the engine with the transmission tilting downward.
3. Align the engine mounts with the crossmember mounting holes.
4. Support the transmission with a transmission jack.
5. Install the engine mount nuts and loosely tighten them.



05U0BX-263

### Power plant frame


1. Install the power plant frame. (Refer to page J-45.)

### Engine mount nut

1. Tighten the engine mount nuts.

### Tightening torque:

**57—78 N·m (5.8—8.0 m·kg, 42—58 ft·lb)**



05U0BX-264

### Propeller shaft, speedometer cable, and shift knob

1. Install the propeller shaft, speedometer cable, and shift knob. (Refer to page J-45.)

### Transmission harness

1. Connect the transmission harness.

### Clutch release cylinder

1. Install the clutch release cylinder.

### Tightening torque:

**19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)**

### Exhaust pipe


1. Install the exhaust pipe assembly. (Refer to page F-115.)

## Step 3

1. Connect the hoses shown in the figure.

### Caution


- Position the hose clamp in the original location on the hose, and squeeze the clamp lightly with large pliers to ensure a good fit.



05U0BX-267

## Step 4

1. Connect the harness connectors shown in the figure.




05U0BX-268




# B

## INSTALLATION

### Step 5 Torque Specifications



05U0BX-269




#### A/C compressor

1. Install the A/C compressor.


#### Tightening torque:

15—22 N-m (1.5—2.2 m-kg, 11—16 ft-lb)



#### P/S oil pump


1. Install the P/S oil pump and loosely tighten the mounting bolts.



05U0BX-272

### Drive belt

1. Install the alternator drive belt.
2. Install the P/S and/or A/C drive belt.
3. Adjust the drive belt deflections, and tighten the alternator and P/S mounting bolts and nuts. (Refer to page B-6.)



05U0BX-273

### Radiator and cooling fan assembly

1. Install the radiator and cooling fan assembly.

#### Tightening torque:

**19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)**

2. Tighten the A/C pipe bracket to the radiator.


#### Tightening torque:

**7.8—11 N·m (80—110 cm·kg, 69—95 in·lb)**

3. Connect the upper and lower radiator hoses.


#### Caution

- Position the hose clamp in the original location on the hose, and squeeze the clamp lightly with large pliers to ensure a good fit.



05U0BX-274

4. Connect the coolant reservoir hose.
5. Connect the cooling fan connector.




05U0BX-275

### Accelerator cable

1. Install the accelerator cable.
2. Adjust the cable deflection by turning nut A.

**Deflection: 1—3mm (0.04—0.12 in)**



05U0BX-276

### Air cleaner assembly

1. Install the air cleaner assembly.

#### Tightening torque

**19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)**

**Steps After Installation**

1. Install the under cover.
2. If the engine oil was drained, fill with the specified amount and type of engine oil.  
(Refer to page D-5.)
3. Fill the radiator with the specified amount and type of engine coolant.  
(Refer to page E-5.)
4. If the transmission oil was drained, fill with the specified amount and type of transmission oil.  
(Refer to page J-8.)
5. Connect the negative battery cable.
6. Start the engine and check the following.
  - (1) Engine oil, transmission oil, and engine coolant leakage.
  - (2) Ignition timing, idle speed. (Refer to page B-8.)
  - (3) Operation of emission control system.
7. Perform a road test.
8. Recheck the engine oil and engine coolant levels.


05U0BX-277

# LUBRICATION SYSTEM

<b>INDEX</b> .....	D- 2
<b>OUTLINE</b> .....	D- 3
SPECIFICATIONS.....	D- 3
<b>TROUBLESHOOTING GUIDE</b> .....	D- 3
<b>OIL PRESSURE</b> .....	D- 4
PREPARATION .....	D- 4
INSPECTION .....	D- 4
<b>ENGINE OIL</b> .....	D- 5
INSPECTION .....	D- 5
REPLACEMENT.....	D- 5
<b>OIL FILTER</b> .....	D- 5
REPLACEMENT.....	D- 5
<b>OIL PAN</b> .....	D- 6
REMOVAL / INSPECTION / INSTALLATION ..	D- 6
<b>OIL PUMP</b> .....	D- 9
PREPARATION .....	D- 9
REMOVAL / INSTALLATION .....	D- 9
DISASSEMBLY / INSPECTION / ASSEMBLY .	D-11

05U0DX-001

INDEX



05U0DX-002

1. Oil pressure Inspection.....	page D- 4	4. Oil pan Removal / Inspection / Installation .....	page D- 6
2. Engine oil Inspection.....	page D- 5	5. Oil pump Removal / Installation.....	page D- 9
Replacement .....	page D- 5	Disassembly / Inspection / Assembly.....	page D-11
3. Oil filter Replacement .....	page D- 5		


**OUTLINE**

**SPECIFICATIONS**

Item		Engine	B6 DOHC
Lubrication system			Force-fed type
Oil pump	Type		Trochoid gear
	Relief pressure	kPa (kg/cm <sup>2</sup> , psi)	343—441 (3.5—4.5, 50—64)
Oil filter	Type		Full-flow, paper element
	Relief pressure differential	kPa (kg/cm <sup>2</sup> , psi)	78—118 (0.8—1.2, 11—17)
Oil capacity	Total (dry engine)	liters (US qt, Imp qt)	3.6 (3.8, 3.2)
	Oil pan	liters (US qt, Imp qt)	3.2 (3.4, 2.8)
	Oil filter	liter (US qt, Imp qt)	0.17 (0.18, 0.15)
Engine oil			API service SF or SG

05U0DX-003

**Recommended SAE Viscosity**



Anticipated ambient temperature range before succeeding oil change, °C (°F).

05U0DX-004

**TROUBLESHOOTING GUIDE**


Problem	Possible Cause	Remedy	Page
<b>Engine hard starting</b>	Improper engine oil Insufficient engine oil	Replace Add oil	D- 5 D- 5
<b>Excessive oil consumption</b>	Oil working up or down Oil leakage	Refer to Section B Repair	—
<b>Oil pressure drop</b>	Insufficient oil Oil leakage Worn and/or damaged oil pump gear Worn plunger (inside oil pump) or weak spring Clogged oil strainer Excessive main bearing or connecting rod bearing clearance	Add oil Repair Replace Replace Clean Refer to Section B	D- 5 — D-11, 12 D-11, 12 —
<b>Oil pressure gauge (meter) does not operate</b>	Oil pressure drop Malfunction of oil pressure gauge Malfunction of electrical system	As described above Refer to Section T Refer to Section T	—

05U0DX-005


## OIL PRESSURE

## PREPARATION


## SST



05U0DX-006



05U0DX-007



05U0DX-008

## INSPECTION

1. Remove the oil pressure gauge sender unit.

2. Screw the **SST** into the oil pressure gauge sender unit installation hole.
3. Warm up the engine to normal operating temperature.
4. Run the engine at 1,000 rpm and 3,000 rpm, and note the gauge reading.

**Oil pressure:**


**196—294 kPa (2.0—3.0 kg/cm<sup>2</sup>, 28—43 psi)—1,000 rpm**  
**294—392 kPa (3.0—4.0 kg/cm<sup>2</sup>, 43—57 psi)—3,000 rpm**

5. If the pressure is not as specified, check for the cause and repair. (Refer to Troubleshooting Guide.)
6. Remove the **SST** and install the oil pressure gauge sender unit.


**Tightening torque:**

**12—18 N·m (1.2—1.8 m·kg, 104—156 in·lb)**

05U0DX-009




05U0DX-036




DRAIN PLUG


05U0DX-011



05U0DX-012



05U0DX-013



05U0DX-014

## ENGINE OIL

### INSPECTION

1. Be sure the vehicle is on level ground.
2. Warm up the engine to normal operating temperature and stop it.
3. Wait for five minutes.
4. Remove the oil level gauge and check the oil level and condition.
5. Add or replace oil as necessary.

### Note

- The distance between the L and F marks on the level gauge represents 0.8 liter (0.85 US qt, 0.70 Imp qt).

### REPLACEMENT

### Warning

- Be careful when draining; the oil is hot.

1. Warm up the engine to normal operating temperature and stop it.
2. Remove the oil filler cap and the oil pan drain plug.
3. Drain the oil into a suitable container.
4. Install a new gasket and the drain plug.

### Tightening torque:

29—41 N·m (3.0—4.2 m·kg, 22—30 ft·lb)

5. Refill the engine with the specified type and amount of engine oil.
6. Refit the oil filler cap.

**Oil pan capacity: 3.2 liters (3.4 US qt, 2.8 Imp qt)**

7. Run the engine and check for leaks.
8. Check the oil level and add oil if necessary.

## OIL FILTER

### REPLACEMENT

1. Remove the oil filter with a suitable wrench.
2. Use a clean rag to wipe off the mounting surface on the engine.
3. Apply a small amount of clean engine oil to the rubber seal of the new filter.
4. Install the oil filter and tighten it by hand until the rubber seal contacts the base.
5. Tighten the filter 1 and 1/6 turn with a filter wrench.
6. Start the engine and check for leaks.
7. Check the oil level and add oil if necessary.

**Oil filter capacity: 0.17 liter (0.18 US qt, 0.15 Imp qt)**




OIL PAN

REMOVAL / INSPECTION / INSTALLATION

Caution


- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to page T-113.)

1. Disconnect the negative battery cable.
2. Drain the engine oil.
3. Remove the under cover.
4. Remove in the order shown in the figure, referring to **Removal Note**.
5. Install in the reverse order of removal, referring to **Installation Note**.




05U0DX-015


- |   |  |
|---|--|
| <ol style="list-style-type: none"> <li>1. Oil level gauge and pipe</li> <li>2. Intermediate shaft</li> <li>3. Engine mount nut<br/>Removal Note ..... page D- 7</li> <li>4. Crossmember installation bolt and nut<br/>Removal Note ..... page D- 7</li> </ol> | <ol style="list-style-type: none"> <li>5. Oil pan<br/>Removal Note ..... page D- 7<br/>Inspect for cracks, deformation, and damage<br/>Installation Note ..... page D- 8</li> <li>6. Oil strainer</li> <li>7. Oil pan baffle<br/>Removal Note ..... page D- 7<br/>Installation Note ..... page D- 7</li> </ol> |
|---|--|




05U0DX-016




05U0DX-017



05U0BX-105



05U0BX-106



05U0DX-018

**Removal Note****Engine mount nut**

1. Loosen the oil pan mounting bolts.
2. Remove the engine mount nuts.
3. Lift the engine slightly with a hoist.

**Crossmember installation bolt and nut**

1. Support the crossmember with a transmission jack.
2. Remove the crossmember installation bolts and nuts.

**Caution**

- Do not damage the brake hoses, P/S hoses, and A/C hoses when lowering the crossmember.

**Note**

- Lower the crossmember after separating the steering intermediate shaft from the pinion shaft.

3. Lower the crossmember until the clearance between the oil pan and the steering gear housing exceeds **approx. 100mm (3.94 in)**.

**Oil pan**

1. Remove the oil pan mounting bolts.

**Caution**

- Do not force a prying tool between the cylinder block and the oil pan, which may damage the contact surfaces.
- Do not damage or scratch the contact surfaces when removing the old sealant.

2. Insert a screwdriver or a suitable tool only at the points shown in the figure.
3. Remove the oil pan.

**Oil pan baffle****Caution**

- Do not bend the baffle when prying it loose.

1. Insert a screwdriver or other suitable tool between the cylinder block and the baffle to separate them.
2. Remove the baffle.


**Installation Note****Oil pan baffle**

1. Remove all foreign material from the contact surfaces.


**Caution**

- The oil pan must be secured within 30 minutes after the sealant is applied to the baffle.


2. Apply a continuous bead of silicone sealant to the baffle along the inside of the bolt holes.
3. Install the baffle.




05U0DX-019



05U0BX-209



05U0DX-020



05U0DX-021

**Oil pan**

1. Remove all foreign material from the contact surfaces.
2. Apply silicone sealant to the shaded areas shown in the figure.
3. Install new gaskets onto the oil pump body and the rear cover with the projections in the notches shown in the figure.
4. Apply a continuous bead of silicone sealant to the oil pan along the inside of the bolt holes and overlap the ends.
5. Install the oil pan.

**Tightening torque:**



- Ⓐ: 7.8—11 N·m (80—110 cm·kg, 69—95 in·lb)  
 Ⓑ: 64—89 N·m (6.5—9.1 m·kg, 47—66 ft·lb)

**Steps After Installation**

1. Install the under cover.
2. Fill with the specified amount and type of engine oil. (Refer to page D-5.)
3. Connect the negative battery cable.
4. Start the engine and check for leaks.
5. Check the oil level and add oil if necessary.

## OIL PUMP

### PREPARATION SST

49 S120 710 Holder, coupling flange		For removal and installation of timing belt pulley	49 B011 102 Lock tool, crankshaft
			For removal and installation of timing belt pulley


05U0DX-023

### REMOVAL / INSTALLATION

#### Caution

- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to page T-113.)

1. Disconnect the negative battery cable.
2. Drain the engine oil.
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Install in the reverse order of removal, referring to **Installation Note**.




N·m (m·kg, ft·lb)

05U0DX-024

- |   |  |
|---|--|
| <ol style="list-style-type: none"> <li>1. Timing belt<br/>Service..... page B-12</li> <li>2. Oil pan<br/>Removal / Installation..... page D- 6</li> <li>3. Alternator</li> <li>4. A/C compressor<br/>Removal Note ..... page D-10</li> <li>5. A/C compressor bracket</li> </ol> | <ol style="list-style-type: none"> <li>6. Pulley lock bolt<br/>Removal Note ..... page D-10<br/>Installation Note..... page D-10</li> <li>7. Timing belt pulley<br/>Removal Note ..... page D-10<br/>Installation Note..... page D-10</li> <li>8. Oil pump<br/>Disassembly / Inspection /<br/>Assembly..... page D-11</li> </ol> |
|---|--|

## OIL PUMP




05U0DX-025

**Removal Note**  
**A/C compressor**
**Caution**

- Do not damage the hoses.


1. Remove the A/C compressor with the hoses still connected.
2. Position the compressor away from the engine and affix it with wire.



05U0DX-026

**Pulley lock bolt**

1. Hold the timing belt pulley with the **SST**.
2. Connect the **SST** and loosen the pulley lock bolt.
3. Remove the pulley lock bolt.




05U0BX-062

**Timing belt pulley****Note**

- If necessary, remove the pulley with a steering wheel puller (commercially available).


1. Remove the timing belt pulley.
2. Remove the pulley Woodruff key.



05U0DX-027

**Installation Note**  
**Timing belt pulley**

1. Install the timing belt pulley.
2. Install the pulley Woodruff key with the tapered side toward the oil pump body.



05U0DX-028

**Pulley lock bolt**

1. Install the pulley lock bolt.
2. Tighten the pulley lock bolt using the two **SST**.

**Tightening torque:**
**108—118 N·m (11.0—12.0 m·kg, 80—87 ft·lb)**

3. Remove the **SST**.


**Steps After Installation**

1. Install the under cover.
2. Fill with the specified amount and type of engine oil. (Refer to page D-5.)
3. Connect the negative battery cable.
4. Start the engine and check for leaks.
5. Check the oil level and add oil if necessary.

05U0DX-022

**DISASSEMBLY / INSPECTION / ASSEMBLY**


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



05U0DX-029

- |  |  |
|--|--|
| <ol style="list-style-type: none"> <li>1. Oil seal<br/>Disassembly Note ..... page D-12<br/>Assembly Note..... page D-13</li> <li>2. Pump cover<br/>Inspect for distortion or damage</li> <li>3. Outer rotor</li> <li>4. Inner rotor</li> <li>5. Roll pin</li> </ol> | <ol style="list-style-type: none"> <li>6. Spring seat</li> <li>7. Pressure spring<br/>Inspection..... page D-12</li> <li>8. Control plunger<br/>Inspect for wear or damage</li> <li>9. Pump body<br/>Inspect for distortion or damage</li> </ol> |
|--|--|

## OIL PUMP




05U0DX-030

### Disassembly Note

#### Oil seal

1. Remove the oil seal with a screwdriver protected with a rag.




05U0DX-031

### INSPECTION

#### Pressure Spring

1. Inspect the spring for weakness or breakage.
2. Measure the free length. Replace the spring if necessary.

**Free length: 45.5mm (1.791 in)**




05U0DX-032

#### Rotor Clearance


1. Measure the following clearances. Replace the rotor if necessary.

**Tooth tip clearance: 0.20mm (0.0079 in) max.**




05U0DX-033

**Outer rotor to pump body clearance:  
0.22mm (0.0087 in) max.**



05U0DX-034

**Side clearance: 0.14mm (0.0055 in) max.**



05U0DX-035

### Assembly Note

#### Oil seal

1. Apply a small amount of clean engine oil to the lip of a new oil seal.
2. Push the oil seal slightly in by hand.

#### Caution

- **The oil seal must be pressed in until it is flush with the edge of the oil pump body.**

3. Press the oil seal in evenly with a suitable pipe.


**Oil seal outer diameter: 44mm (1.73 in)**



# COOLING SYSTEM

<b>INDEX</b> .....	E- 2
<b>OUTLINE</b> .....	E- 3
SPECIFICATIONS .....	E- 3
<b>TROUBLESHOOTING GUIDE</b> .....	E- 3
<b>ENGINE COOLANT</b> .....	E- 4
PREPARATION .....	E- 4
INSPECTION .....	E- 4
REPLACEMENT .....	E- 5
<b>RADIATOR CAP</b> .....	E- 6
PREPARATION .....	E- 6
INSPECTION .....	E- 6
<b>RADIATOR</b> .....	E- 7
REMOVAL / INSPECTION / INSTALLATION ..	E- 7
<b>THERMOSTAT</b> .....	E- 8
REMOVAL / INSPECTION / INSTALLATION ..	E- 8
<b>WATER PUMP</b> .....	E- 9
REMOVAL / INSTALLATION .....	E- 9
<b>ELECTRIC COOLING FAN SYSTEM</b> .....	E-11
SYSTEM CIRCUIT .....	E-11
SYSTEM INSPECTION .....	E-11
<b>FAN MOTOR</b> .....	E-12
INSPECTION .....	E-12
REPLACEMENT .....	E-12
<b>WATER THERMOSWITCH</b> .....	E-13
REMOVAL / INSPECTION / INSTALLATION ..	E-13
<b>FAN RELAY</b> .....	E-14
INSPECTION .....	E-14

INDEX



05U0EX-002

1. Engine coolant		6. Electric cooling fan system	
Inspection .....	page E- 4	System circuit .....	page E-11
Replacement.....	page E- 5	System inspection.....	page E-11
2. Radiator cap		7. Fan motor	
Inspection .....	page E- 6	Inspection .....	page E-12
3. Radiator		Replacement.....	page E-12
Removal / Inspection /		8. Water thermostwitch	
Installation.....	page E- 7	Removal / Inspection /	
4. Thermostat		Installation.....	page E-13
Removal / Inspection /		9. Fan relay	
Installation.....	page E- 8	Inspection .....	page E-14
5. Water pump			
Removal / Installation.....	page E- 9		

**OUTLINE**

**SPECIFICATIONS**

Item		Engine	B6 DOHC	
Cooling system			Water-cooled, forced circulation	
Coolant capacity		liters (US qt, Imp qt)	6.0 (6.3, 5.3)	
Water pump	Type		Centrifugal	
	Water seal		Unified mechanical seal	
Thermostat	Type		Wax, two-stage	
	Opening temperature	°C (°F)	Main: 86.5—89.5 (188—193) Sub : 83.5—86.5 (182—188)	
	Full-open temperature	°C (°F)	100 (212)	
	Full-open lift	mm (in)	Main: 8.0 (0.31) min. Sub : 1.5 (0.06) min.	
Radiator	Type		Corrugated fin	
	Cap valve opening pressure	kPa (kg/cm <sup>2</sup> , psi)	74—103 (0.75—1.05, 11—15)	
Cooling fan	Type		Electric	
	Blade	Outer diameter	mm (in)	320 (12.6)
		Number		5
	Motor	Capacity	W-V	70-12
		Current	A	5.3—6.5

05U0EX-003

**TROUBLESHOOTING GUIDE**



Problem	Possible Cause	Remedy	Page
<b>Overheating</b>	Coolant level insufficient	Add	E— 5
	Coolant leakage	Repair	—
	Radiator fins clogged	Clean	E— 7
	Radiator cap malfunction	Replace	E— 6
	Cooling fan malfunction	Replace	E—11
	Thermostat malfunction	Replace	E— 8
	Water passage clogged	Clean	E— 5
	Water pump malfunction	Replace	E— 9
<b>Corrosion</b>	Impurities in coolant	Replace	E— 5

05U0EX-004

## ENGINE COOLANT

## PREPARATION

## SST

<p>49 9200 145</p> <p>Adapter set, radiator cap tester</p> 	<p>For inspection of cooling system pressure</p>	<p>49 9200 146</p> <p>Adapter A (Part of 49 9200 145)</p> 	<p>For inspection of cooling system pressure</p>
--	--	--	--


05U0EX-005

## INSPECTION

**Warning**

- Never remove the radiator cap while the engine is hot.
- Wrap a thick cloth around the cap when removing it.
- When removing the radiator cap, loosen it slowly to the first stop until the pressure in the radiator is released, and then remove it.


05U0EX-033



05U0EX-006

**Coolant Level (Engine cold)**


1. Verify that the coolant level is near the radiator filler neck.
2. Verify that the coolant level in the coolant reservoir is between the FULL and LOW marks. Add coolant if necessary.



05U0EX-007

**Coolant Quality**


1. Verify that there is no buildup of rust or scale around the radiator cap or radiator filler neck.
2. Verify that coolant is free of oil.  
Replace the coolant if necessary.




05U0EX-008

**Coolant Leakage**


1. Connect a radiator tester (commercially available) and the SST to the radiator filler neck.
2. Apply **103 kPa (1.05 kg/cm<sup>2</sup>, 15 psi)** pressure to the system.
3. Verify that the pressure is held.  
If not, check for coolant leakage.



05U0EX-009



05U0EX-011



05U0EX-012

## Coolant Protection

### Caution

- Do not use alcohol- or methanol-based coolant.
- Use only soft (demineralized) water in the coolant mixture.

1. Measure the coolant temperature and specific gravity with a thermometer and a hydrometer.
2. Determine the coolant protection by referring to the graph shown.  
If the coolant protection is not proper, add water or coolant.

## Antifreeze solution mixture percentage

Coolant protection	Volume percentage		Gravity at 20°C (68°F)
	Water	Coolant	
Above -16°C (3°F)	65	35	1.054
Above -26°C (-15°F)	55	45	1.066
Above -40°C (-40°F)	45	55	1.078

05U0EX-010

## REPLACEMENT

### Warning

- Never open the radiator cap while the engine is hot.
- Wrap a thick cloth around the cap when loosening.
- Use caution when draining hot coolant.

### Caution

- Do not use alcohol- or methanol-based coolant.
- Use only soft (demineralized) water in the coolant mixture.

1. Remove the radiator cap and loosen the drain plug.
2. Drain the coolant into a suitable container.
3. Flush the cooling system with water until all traces of color are gone, then let the system drain completely.
4. Install the drain plug.
5. Fill with the proper amount and mixture of ethylene glycol-based coolant by referring to the table above.



### Coolant capacity: 6.0 liters (6.3 US qt, 5.3 Imp qt)

6. Run the engine, with the radiator cap removed, until the upper radiator hose is hot.
7. With the engine idling, add coolant to the radiator until it reaches the bottom of the filler neck.
8. Install the radiator cap.


## RADIATOR CAP

## PREPARATION

## SST

<p>49 9200 145</p> <p>Adapter set, radiator cap tester</p> 	<p>For inspection of radiator cap valve</p>	<p>49 9200 147</p> <p>Adapter B (Part of 49 9200 145)</p> 	<p>For inspection of radiator cap valve</p>
--	---	---	---

05U0EX-014



05U0EX-015


## INSPECTION

## Radiator Cap Valve

1. Remove foreign material (such as water residue) from between the radiator cap valve and the valve seat.
2. Attach the radiator cap to a radiator cap tester (commercially available) with the **SST**. Apply pressure gradually to **74—103 kPa (0.75—1.05 kg/cm<sup>2</sup>, 11—15 psi)**.
3. Wait about **10 seconds**. Verify that the pressure has not decreased.

## Negative Pressure Valve

1. Pull the negative pressure valve to open it. Verify that it closes completely when released.
2. Check for damage on the contact surfaces and for cracked or deformed seal packing.
3. Replace the radiator cap if necessary.



05U0EX-013


**RADIATOR**

**REMOVAL / INSPECTION / INSTALLATION**

**Caution**

- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to page T-113.)
- Position the hose clamp in the original location on the hose, and squeeze the clamp lightly with large pliers to ensure a good fit.

1. Disconnect the negative battery cable.
2. Drain the engine coolant.
3. Remove the under cover.
4. Remove in the order shown in the figure.
5. Install in the reverse order of removal.




05U0EX-016

1. Radiator hose
2. Coolant reservoir hose
3. Cooling fan connector

4. Cooling fan and additional fan
5. Radiator

Inspection ..... page E-7



05U0EX-017

**INSPECTION**

Check for the following and repair or replace as necessary.

1. Cracks, damage, and water leakage.
2. Bent fins (repair with a screwdriver).
3. Distorted or bent radiator inlet.

**Steps After Installation**

1. Install the under cover.
2. Fill the radiator with the specified amount and type of engine coolant. (Refer to page E-5.)
3. Connect the negative battery cable.
4. Start the engine and check for leaks.


THERMOSTAT

REMOVAL / INSPECTION / INSTALLATION

Caution

- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to page T-113.)
- Position the hose clamp in the original location on the hose, and squeeze the clamp lightly with large pliers to ensure a good fit.


1. Disconnect the negative battery cable.
2. Drain the engine coolant.
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.



05U0EX-018

1. Radiator hose upper
2. Water thermostat connector
3. Thermostat cover

4. Thermostat  
Inspection ..... page E-8



05U0EX-019

INSPECTION

1. Visually check that the thermostat valve is airtight.
2. Place the thermostat and a thermometer in water.
3. Heat the water and check the following:

Initial-opening temperature

Main: 86.5—89.5°C (188—193°F)

Sub : 83.5—86.5°C (182—188°F)

Full-open temperature: 100°C (212°F)

Full-open lift

Main: 8.0mm (0.31 in) min.

Sub : 1.5mm (0.06 in) min.



## Steps After Installation

1. Fill the radiator with the specified amount and type of engine coolant. (Refer to page E-5.)
2. Connect the negative battery cable.
3. Start the engine and check for leaks.

05U0EX-020


## WATER PUMP

### REMOVAL / INSTALLATION

#### Caution

- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to page T-113.)
- Do not disassemble the water pump. If a problem is found, replace the pump as a unit.


1. Disconnect the negative battery cable.
2. Drain the engine coolant.
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Install in the reverse order of removal.



- |                   |           |
|-------------------|-----------|
| 1. Timing belt    |           |
| Service.....      | page B-12 |
| 2. P/S oil pump   |           |
| Removal Note..... | page E-10 |

- |                     |  |
|---------------------|--|
| 3. Water inlet pipe |  |
| 4. Water pump       |  |
|                     | Inspect for cracks, damaged mounting surface, bearing condition, and leakage |

05U0EX-021



05U0EX-022

**Removal Note**  
**P/S oil pump****Caution**

- Do not damage the hoses.

1. Remove the P/S oil pump with the hoses still connected.
2. Position the pump away from the engine and affix it with wire.


**Steps After Installation**

1. Fill the radiator with the specified amount and type of engine coolant. (Refer to page E-5.)
2. Connect the negative battery cable.
3. Start the engine and check for leaks.


05U0EX-020

ELECTRIC COOLING FAN SYSTEM


SYSTEM CIRCUIT



05U0EX-023




05U0EX-024




05U0EX-025

SYSTEM INSPECTION

1. Jump across the fan test (TFA) terminal and the ground (GND) terminal of the diagnosis connector.
2. Turn the ignition switch ON and verify that the fan operates. If the fan does not operate, inspect the cooling fan system components and wire harness.
3. Remove the radiator cap and place a thermometer in the radiator filler neck.
4. Start the engine.
5. Verify that the fan operates when the coolant temperature reaches **approx. 97°C (207°F)**. If the fan does not operate, check the water thermostats. (Refer to page E-13.)



05U0EX-026



05U0EX-027

### FAN MOTOR

#### INSPECTION

1. Check that the battery is fully charged.
2. Disconnect the fan motor connector.

3. Connect the battery and an ammeter to the fan motor connector.
4. Verify that current is as specified.

**Current: 5.3—6.5A**


5. If current is not within specification and/or the fan does not turn smoothly, replace the fan motor.

### REPLACEMENT

#### Caution

- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to page T-113.)

1. Disconnect the negative battery cable.
2. Drain the engine coolant.
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.



05U0EX-028

1. Cooling fan connector
2. Cooling fan

3. Radiator cowling
4. Fan motor


WATER THERMOSWITCH

REMOVAL / INSPECTION / INSTALLATION

Caution

- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to page T-113.)

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal, referring to **Installation Note**.




05U0EX-029

1. Water thermostat connector

2. Water thermostat

Inspection ..... page E-13  
 Installation Note ..... page E-13



05U0EX-030

**INSPECTION**

1. Place the switch and a thermometer in water.
2. Heat the water gradually and check continuity of the switch with an ohmmeter.

Coolant temperature °C (°F)	Continuity
More than 97 (207)	Yes
Less than 90 (194)	No

3. If not as specified, replace the water thermostat.

**Installation Note**

**Water thermostat**

1. Apply a small amount of engine coolant to the new O-ring.


**Caution**

- Do not use an impact wrench for installation.

2. Install the water thermostat.


**Tightening torque:**

**5.9—8.8 N·m (60—90 cm·kg, 52—78 in·lb)**




05U0EX-031

## FAN RELAY



05U0EX-032



05U0EX-034

## FAN RELAY

### INSPECTION

1. Check continuity as shown with an ohmmeter.


Terminal	Continuity
A—C	No
B—D	Yes

2. Apply 12V between terminals B and D.  
Check for continuity between terminals A and C.
3. If not as specified, replace the fan relay.

# FUEL AND EMISSION CONTROL SYSTEMS

<b>INDEX</b> .....	F- 2	<b>EXHAUST SYSTEM</b> .....	F-115
<b>OUTLINE</b> .....	F- 5	COMPONENTS.....	F-115
SYSTEM DIAGRAM .....	F- 5	<b>OUTLINE OF EMISSION CONTROL SYSTEM</b> .....	F-116
VACUUM HOSE ROUTING DIAGRAM .....	F- 6	STRUCTURAL VIEW.....	F-116
WIRING DIAGRAM.....	F- 7	<b>POSITIVE CRANKCASE VENTILATION (PCV) SYSTEM</b> .....	F-117
SPECIFICATIONS.....	F- 9	DESCRIPTION .....	F-117
COMPONENT DESCRIPTIONS.....	F- 10	PCV VALVE .....	F-117
<b>TROUBLESHOOTING GUIDE</b> .....	F- 12	<b>EVAPORATIVE EMISSION CONTROL SYSTEM</b> .....	F-118
ENGINE CONTROL OPERATION CHART.....	F- 12	DESCRIPTION .....	F-118
RELATIONSHIP CHART .....	F- 15	SOLENOID VALVE (PURGE CONTROL) .....	F-119
USING THIS SECTION.....	F- 16	TWO-WAY CHECK VALVE.....	F-119
DIAGNOSTIC INDEX .....	F- 18	FUEL VAPOR VALVE .....	F-119
PRECAUTION .....	F- 19	CHARCOAL CANISTER.....	F-120
SYMPTOM TROUBLESHOOTING....	F- 20	<b>DECELERATION CONTROL SYSTEM</b> .....	F-121
<b>ENGINE TUNE-UP</b> .....	F- 74	DESCRIPTION .....	F-121
BASIC INSPECTION .....	F- 74	DASHPOT .....	F-121
ADJUSTMENT.....	F- 75	<b>CATALYTIC CONVERTER SYSTEM</b> .....	F-122
<b>SELF-DIAGNOSIS FUNCTION</b> .....	F- 77	DESCRIPTION .....	F-122
DESCRIPTION .....	F- 77	CATALYTIC CONVERTER.....	F-122
PREPARATION .....	F- 78	<b>A/C CUT-OFF SYSTEM</b> .....	F-123
MALFUNCTION CODE NUMBER ...	F- 78	DESCRIPTION .....	F-123
SWITCH MONITOR FUNCTION .....	F- 89	<b>DECHOKE CONTROL SYSTEM</b> .....	F-124
<b>INTAKE AIR SYSTEM</b> .....	F- 92	DESCRIPTION .....	F-124
COMPONENTS.....	F- 92	<b>CONTROL SYSTEM</b> .....	F-125
SYSTEM OPERATION .....	F- 93	PREPARATION.....	F-125
THROTTLE BODY .....	F- 94	STRUCTURAL VIEW.....	F-126
INTAKE MANIFOLD .....	F- 95	ENGINE CONTROL UNIT.....	F-127
ACCELERATOR PEDAL AND CABLE.....	F- 96	CRANK ANGLE SENSOR.....	F-134
<b>IDLE SPEED CONTROL (ISC) SYSTEM</b> .....	F- 97	AIRFLOW METER .....	F-135
DESCRIPTION .....	F- 97	WATER THERMOSENSOR.....	F-136
PREPARATION.....	F- 98	THROTTLE SENSOR .....	F-136
SYSTEM OPERATION .....	F- 98	OXYGEN SENSOR .....	F-138
AIR VALVE .....	F- 98	MAIN RELAY .....	F-139
ISC VALVE .....	F- 99	CLUTCH SWITCH .....	F-139
<b>FUEL SYSTEM</b> .....	F-100	NEUTRAL SWITCH .....	F-140
DESCRIPTION .....	F-100	P/S PRESSURE SWITCH .....	F-140
PRECAUTION .....	F-101		
SYSTEM OPERATION .....	F-102		
FUEL TANK.....	F-104		
FUEL FILTER.....	F-106		
FUEL PUMP .....	F-107		
CIRCUIT OPENING RELAY.....	F-110		
PRESSURE REGULATOR.....	F-111		
INJECTOR .....	F-112		


INDEX



05U0FX-002


1. Air cleaner Removal / Inspection / Installation ..... page F- 92	6. Air valve Removal..... page F- 98 Inspection ..... page F- 99 Installation ..... page F- 99
2. Throttle body Removal..... page F- 94 Inspection ..... page F- 94 Installation ..... page F- 94	7. PCV valve Inspection ..... page F-117
3. Intake manifold Removal..... page F- 95 Installation ..... page F- 95	8. Solenoid valve (Purge control) Inspection ..... page F-119
4. Accelerator pedal and cable Inspection ..... page F- 96 Replacement..... page F- 96	9. Charcoal canister Inspection ..... page F-120
5. ISC valve Inspection ..... page F- 99 Replacement..... page F- 99	10. Dashpot Inspection ..... page F-121





05U0FX-003

<p>1. Fuel tank Removal / Inspection / Installation ..... page F-104</p> <p>2. Fuel filter Replacement..... page F-106</p> <p>3. Fuel pump Inspection ..... page F-107 Replacement..... page F-108</p> <p>4. Circuit opening relay Inspection ..... page F-110 Replacement..... page F-110</p>	<p>5. Pressure regulator Inspection ..... page F-111 Replacement..... page F-112</p> <p>6. Injector Inspection ..... page F-112 Removal..... page F-112 Installation ..... page F-113</p> <p>7. Two-way check valve Inspection ..... page F-119</p> <p>8. Fuel vapor valve Inspection ..... page F-119</p>
--	--




05U0FX-004

1. Catalytic converter  
Inspection / Replacement..... page F-122


2. Exhaust components  
Removal / Inspection /  
Installation..... page F-115

OUTLINE


SYSTEM DIAGRAM




VACUUM HOSE ROUTING DIAGRAM



WIRING DIAGRAM





**SPECIFICATIONS**

Item		Specification		
Idle speed	rpm	850 ± 50*		
Ignition timing	BTDC	10° ± 1°*		
<b>Throttle body</b>				
Type		Horizontal draft		
Throat diameter	mm (in)	55 (2.2)		
<b>Fuel pump</b>				
Type		Impeller (in-tank)		
Output pressure	kPa (kg/cm <sup>2</sup> , psi)	441—589 (4.5—6.0, 64—85)		
<b>Fuel filter</b>				
Type	Low-pressure side	Nylon element		
	High-pressure side	Paper element		
<b>Pressure regulator</b>				
Type		Diaphragm		
Regulating pressure	kPa (kg/cm <sup>2</sup> , psi)	265—314 (2.7—3.2, 38—46)		
<b>Injector</b>				
Type		High-ohmic		
Type of drive		Voltage		
Resistance	Ω	12—16 (at 20°C, 68°F)		
<b>ISC valve</b>				
Solenoid resistance	Ω	11—13 (at 20°C, 68°F)		
<b>Air valve</b>				
Opening temperature		Below 40°C (104°F)		
<b>Solenoid valve (Purge control)</b>				
Solenoid resistance	Ω	23—27 (at 20°C, 68°F)		
<b>Crank angle sensor</b>				
Type		Optical pickup		
<b>Airflow meter</b>				
Resistance	Ω	E2↔Vs	Fully closed	200—600
			Fully open	20—1,000
	E2↔THAA (Intake air thermosensor)		-20°C (-4°F)	13,600—18,400
			20°C (68°F)	2,210—26,900
			60°C (140°F)	493—667
	E1↔Fc		Fully closed	∞
			Fully open	0
<b>Water thermosensor</b>				
Resistance	kΩ		-20°C (-4°F)	14.6—17.8
			20°C (68°F)	2.2—2.7
			80°C (179°F)	0.29—0.35
<b>Circuit opening relay</b>				
Resistance	Ω		STA—E <sub>1</sub>	21—43
			B—Fc	109—226
			B—Fp	∞
<b>Fuel tank</b>				
Capacity	liters (US gal, Imp gal)			45 (11.9, 9.9)
<b>Air cleaner</b>				
Element type				Oil permeated
<b>Accelerator cable</b>				
Free play	mm (in)			1—3 (0.039—0.118)
<b>Fuel</b>				
Specification				Unleaded regular (RON 87 or higher)

\* ... With System Selector (49 B019 9A0) test switch at SELF TEST.

### COMPONENT DESCRIPTIONS

Component	Function	Remark
<b>Air cleaner</b>	Filters air entering throttle body	
<b>Airflow meter</b>	Detects amount of intake air; sends signal to engine control unit	<ul style="list-style-type: none"> <li>• Intake air thermosensor and fuel pump switch included</li> <li>• Use Vref (5 volt) as power source</li> </ul>
<b>Air valve</b>	When cold, supplies bypass air into dynamic chamber	<ul style="list-style-type: none"> <li>• Engine speed increased to shorten warm-up period</li> <li>• Thermowax type</li> </ul>
<b>Atmospheric pressure sensor</b>	Detects atmospheric pressure; sends signal to engine control unit	Built-in ECU
<b>Catalytic converter</b>	Reduces HC, CO, and NOx by chemical reaction	Monolith type
<b>Charcoal canister</b>	Stores gas tank fumes while engine stopped	
<b>Circuit opening relay</b>	Voltage for fuel pump while engine running	
<b>Clutch switch (M/T)</b>	Detects in-gear condition; sends signal to engine control unit	Switch OFF when clutch pedal released
<b>Diagnosis connector</b>	Concentrated service connector Concentrated terminals are: 1. EGI self-diagnosis terminal 2. Initial set terminal 3. Fuel pump check terminal 4. Cooling fan check terminal	21-pin (Black)
<b>Crank angle sensor G-signal</b>  <b>Ne-signal</b>	Detects No.1 cylinder TDC; sends signal to engine control unit Detects crank angle at 180° intervals; sends signal to control unit	
<b>Dynamic chamber</b>	Interconnects all cylinders	
<b>Engine control unit (ECU)</b>	<p><b>Detects the following:</b></p> <ol style="list-style-type: none"> <li>1. A/C operation</li> <li>2. Air/fuel ratio (Oxygen concentration)</li> <li>3. Atmospheric pressure</li> <li>4. Braking signal</li> <li>5. Cranking signal</li> <li>6. E/L operation</li> </ol> <ol style="list-style-type: none"> <li>7. Engine coolant temperature</li> <li>8. Engine speed</li> <li>9. In-gear condition</li> <li>10. Intake air amount</li> <li>11. Intake air temperature</li> <li>12. No.1 piston TDC</li> <li>13. P/S operation</li> <li>14. Initial set signal</li> <li>15. Throttle valve fully closed</li> <li>16. Throttle valve opening amount</li> </ol> <p><b>Controls operation of the following:</b></p> <ol style="list-style-type: none"> <li>1. A/C (Cut off)</li> <li>2. Fail-safe function</li> <li>3. Fuel injection system</li> <li>4. Idle speed control</li> <li>5. Ignition timing control system</li> <li>6. Monitor function</li> <li>7. Purge control system</li> </ol>	<ol style="list-style-type: none"> <li>1. A/C switch</li> <li>2. Oxygen sensor</li> <li>3. Atmospheric pressure sensor</li> <li>4. Stoplight switch</li> <li>5. Ignition switch (START position)</li> <li>6. Cooling fan relay Light and turn relay Blower motor switch</li> <li>7. Water thermosensor</li> <li>8. Crank angle sensor (Ne-signal)</li> <li>9. Neutral and clutch switches</li> <li>10. Airflow meter</li> <li>11. Intake air thermosensor</li> <li>12. Crank angle sensor (G-signal)</li> <li>13. P/S pressure switch</li> <li>14. Diagnosis connector</li> <li>15. Throttle sensor (IDL signal)</li> <li>16. Throttle sensor (POW signal)</li> </ol> <ol style="list-style-type: none"> <li>1. A/C relay</li> <li>2. Self-diagnosis checker and MIL</li> <li>3. Injector</li> <li>4. ISC valve</li> <li>5. Igniter</li> <li>6. Monitor lamp (Self-diagnosis checker)</li> <li>7. Solenoid valve (Purge control)</li> </ol>



<b>Fuel vapor valve</b>	Prevents fuel from entering canister during vehicle roll over	
<b>Fuel filter</b>	Filters particles from fuel	
<b>Fuel pump</b>	Provides fuel to injectors	<ul style="list-style-type: none"> <li>• Operates while engine running</li> <li>• Installed in fuel tank</li> </ul>
<b>Igniter</b>	Receives spark signal from engine control unit and generates high voltage in ignition coil Detects high voltage ignition; sends substitute ignition signal to engine control unit	
<b>Ignition switch (START position)</b>	Sends engine cranking signal to engine control unit	
<b>Injector</b>	Injects fuel into intake port	<ul style="list-style-type: none"> <li>• Controlled by signals from engine control unit</li> <li>• High-ohmic injector</li> <li>• Single port injector nozzle</li> </ul>
<b>Intake air thermosensor</b>	Detects intake air temperature; sends signal to engine control unit	Installed in airflow meter
<b>ISC valve</b>	Controls bypass air amount	<ul style="list-style-type: none"> <li>• Controlled by duty signal from engine control unit</li> <li>• Controls idle-up</li> </ul>
<b>Solenoid valve (Purge control)</b>	Controls evaporative fumes from canister to intake manifold	• Controlled by duty signal from engine control unit
<b>Main relay</b>	Supplies electric current to injectors, engine control unit, etc.	
<b>MIL (Malfunction indicator lamp)</b>	Lamp illuminates when input device malfunctions	(TEN) terminal of diagnosis connector
	Lamp flashes to indicate malfunction code number. of input and output devices	(TEN) terminal of diagnosis connector
<b>Neutral switch</b>	Detects in-gear condition; sends signal to engine control unit	Switch ON when in neutral
<b>Oxygen sensor</b>	Detects oxygen concentration; sends signal to engine control unit	Zirconia ceramic and platinum coating
<b>PCV valve</b>	Controls blowby gas amount introduced into engine	
<b>P/S pressure switch</b>	Detects P/S operation; sends signal to engine control unit	P/S: ON when steering wheel turned
<b>Pressure regulator</b>	Adjusts fuel pressure supplied to injectors	
<b>Resonance chamber</b>	Improves mid range torque characteristics	
<b>Stoplight switch</b>	Detects braking operation (deceleration); sends signal to engine control unit	
<b>Throttle body</b>	Controls intake air quantity	Integrated throttle sensor, ISC valve, and dashpot
<b>Throttle sensor IDL signal</b>	Detects position of the throttle valve fully closed; sends signal to engine control unit	
<b>Throttle sensor POW signal</b>	Detects the throttle valve opening at a preset angle; sends signal to engine control unit	
<b>Two-way check valve</b>	Controls pressure in fuel tank	
<b>Water thermosensor</b>	Detects coolant temperature; sends signal to engine control unit	

05U0FX-009

### TROUBLESHOOTING GUIDE

#### ENGINE CONTROL OPERATION CHART Input Devices and Engine Conditions

ENGINE CONDITIONS	INPUT DEVICES	APPROXIMATE TIME (BASED ON 10-16°C, or 50-60°F AMBIENT)	SENSORS								
			CRANK ANGLE SENSOR		AIRFLOW METER		WATER THERMO-SENSOR	OXYGEN SENSOR	IGF SIGNAL	ATMOSPHERIC PRESSURE SENSOR	
			G-SIGNAL	NE-SIGNAL	INTAKE AIR THERMO-SENSOR	POTENTIOMETER					
CRANKING —COLD ENGINE • COLD AIR • COLD COOLANT		ZERO			SIGNAL HAS NO EFFECT ON ECU	SIGNAL HAS NO EFFECT ON ECU		SIGNAL HAS NO EFFECT ON ECU			
COLD START —FAST IDLE • COLD AIR • COLD COOLANT		ONE MINUTE				LOW VOLUME AIRFLOW: (3.0V)	COOL TO WARM: MEDIUM VOLTAGE (2.3V and DROPPING)		SENSOR COLD: LOW TO HIGH VOLTAGE (0-0.8V)		
COLD DRIVEAWAY —PART THROTTLE • WARM AIR • WARM COOLANT		TWO MINUTES									
WARM DRIVEAWAY —PART THROTTLE • WARM AIR • WARM COOLANT		THREE MINUTES				MODERATE VOLUME AIRFLOW: LOW TO MEDIUM VOLTAGE (1-3.5V)	WARM: MEDIUM VOLTAGE (APPROX. 0.7V AND DROPPING)		SENSOR WARM: HIGH VOLTAGE (ABOVE 0.6V)		
HOT CRUISE • WARM AIR • WARM COOLANT									SENSOR HOT SWITCHING FROM HIGH VOLTAGE (ABOVE 0.6V RICH)		
HOT ACCELERATION —60% THROTTLE			SENDS No.1 CYLINDER TDC SIGNAL TO ECU	SENDS ENGINE SPEED SIGNAL TO ECU	COOL TO WARM: MEDIUM VOLTAGE (4.3-1.5V)				TO LOW VOLTAGE (BELOW 0.4V LEAN)	SENDS IGNITION SPARK SIGNAL TO ECU	SENDS VOLTAGE SIGNAL TO ECU THAT VARIES WITH ALTITUDE; VOLTAGE (APPROX. 4V)
HOT ACCELERATION —WIDE OPEN THROTTLE		MORE THAN FOUR MINUTES				MODERATE TO STRONG VOLUME AIRFLOW: (0.5-1.5V)	HOT: LOW VOLTAGE (APPROX. 0.4V)		HIGH VOLTAGE (ABOVE 0.6V RICH)		
DECELERATION —CLOSED THROTTLE									LOW VOLTAGE (BELOW 0.4V LEAN)		
HOT CURB IDLE —EXTENDED						LOW VOLUME AIRFLOW (3.0V)			SWITCHING FROM HIGH TO LOW VOLTAGE (0.4-0.6V)		
HOT ENGINE SHUTDOWN			OFF	OFF	OFF	OFF	OFF	OFF	SENSOR HOT: LOW VOLTAGE (0.1V LEAN) UNTIL SENSOR COOLS DOWN	OFF	OFF

SWITCHES										
THROTTLE SENSOR	THROTTLE SENSOR	A/C SWITCH	NEUTRAL AND CLUTCH SWITCHES	STOP-LIGHT SWITCH	HEAD-LIGHT SWITCH	BLOWER CONTROL SWITCH	COOLING FAN SWITCH	P/S PRESSURE SWITCH	IGNITION SWITCH	TEST TERMINAL
POWER TERMINAL	IDLE TERMINAL								START POSITION	
SEND SIGNAL TO ECU WHEN PEDAL DEPRESSED	SIGNAL HAS NO EFFECT ON ECU	SIGNAL HAS NO EFFECT ON ECU	SIGNAL HAS NO EFFECT ON ECU	SIGNAL HAS NO EFFECT ON ECU	SIGNAL HAS NO EFFECT ON ECU	SIGNAL HAS NO EFFECT ON ECU	SIGNAL HAS NO EFFECT ON ECU	SIGNAL HAS NO EFFECT ON ECU	SENDS SIGNAL TO ECU	SIGNAL HAS NO EFFECT ON ECU
↑ HIGH VOLTAGE SIGNAL TO ECU (APPROX. 5V) ↓ LOW VOLTAGE SIGNAL TO ECU (APPROX. 0V)	↑ LOW VOLTAGE SIGNAL TO ECU (BELOW 1.5V) ↑ HIGH VOLTAGE SIGNAL TO ECU (APPROX. 12V) ↓ LOW VOLTAGE SIGNAL TO ECU (APPROX. 0V)	↑ A/C SWITCH ON: SENDS SIGNAL TO ECU (APPROX. 0V) A/C SWITCH OFF: NO SIGNAL TO ECU (APPROX. 12V) ↓	↑ IN NEUTRAL: LOW VOLTAGE SIGNAL TO ECU (APPROX. 0V) ↓ DRIVING IN ANY GEAR: HIGH VOLTAGE SIGNAL TO ECU (APPROX. 12V) ↓ IN NEUTRAL: LOW VOLTAGE SIGNAL TO ECU (APPROX. 0V)	↑ NO SIGNAL TO ECU (BELOW 1.5V) ↓ BRAKE PEDAL DEPRESSED: SENDS SIGNAL TO ECU (APPROX. 12V) ↓	↑ HEAD-LIGHT SWITCH ON: HIGH VOLTAGE SIGNAL TO ECU (APPROX. 12V) HEAD-LIGHT SWITCH OFF: LOW VOLTAGE SIGNAL TO ECU (BELOW 1.5V) ↓	↑ BLOWER CONTROL SWITCH ON: LOW VOLTAGE SIGNAL TO ECU (APPROX. 0V) BLOWER CONTROL SWITCH OFF: HIGH VOLTAGE SIGNAL TO ECU (APPROX. 12V) ↓	↑ COOLING FAN SWITCH ON: LOW VOLTAGE SIGNAL TO ECU (APPROX. 0V) COOLING FAN SWITCH OFF: HIGH VOLTAGE SIGNAL TO ECU (APPROX. 12V) ↓	↑ STEERING WHEEL TURNED: LOW VOLTAGE SIGNAL TO ECU (APPROX. 0V) STEERING WHEEL STRAIGHT AHEAD: HIGH VOLTAGE SIGNAL TO ECU (APPROX. 12V) ↓	↑ NO SIGNAL TO ECU (BELOW 1.5V) ↓	↑ TERMINAL NOT GROUNDED: HIGH VOLTAGE TO ECU (APPROX. 12V) ↓ LOW VOLTAGE SIGNAL TO ECU WHEN CONNECTOR GROUNDED (BELOW 1.5V)
OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF

### Output Devices and Engine Conditions

ENGINE CONDITIONS	OUTPUT DEVICES	APPROXIMATE TIME (BASED ON 10-16°C or 50-60°F AMBIENT)	INJECTOR		ISC VALVE	SOLENOID VALVE (PURGE CONTROL)	A/C RELAY (A/C CUT-OFF)	MAIN RELAY	IGNITER
			INJECTION	INJECTION TIMING					
CRANKING —COLD ENGINE • COLD AIR • COLD COOLANT		ZERO		ALL CYLINDERS EACH No-SIGNAL			OFF (A/C CUT)		
COLD START —FAST IDLE • COLD AIR • COLD COOLANT		ONE MINUTE	RICH		LARGE AMOUNT OF BYPASS AIR	OFF (PURGE CUT)			
COLD DRIVEAWAY —PART THROTTLE • COLD AIR • COLD COOLANT		TWO MINUTES					ON (A/C ON)		
WARM DRIVEAWAY —PART THROTTLE • WARM AIR • WARM COOLANT		THREE MINUTES		2-GROUP					
HOT CRUISE • WARM AIR • WARM COOLANT			RICH AND LEAN		SMALL AMOUNT OF BYPASS AIR	OPERATES (DUTY VALUES [PURGE GAS AMOUNT] CHANGE)		ON	IGNITION SPARK ADVANCE SIGNAL
HOT ACCELERATION —60% THROTTLE									
HOT ACCELERATION —WIDE OPEN THROTTLE			RICH				OFF (A/C CUT)		
DECELERATION —CLOSED THROTTLE		MORE THAN FOUR MINUTES	FUEL CUT		LARGE AND SMALL AMOUNT OF BYPASS AIR	OFF (PURGE CUT)	ON (A/C ON)		
HOT CURB IDLE —EXTENDED			RICH AND LEAN	2-GROUP	SMALL AMOUNT OF BYPASS AIR				
HOT ENGINE SHUT DOWN		—	DOES NOT INJECT		OFF	OFF	OFF	OFF	OFF

05U0FX-011


RELATIONSHIP CHART

Output Devices		Injector		ISC Valve	Solenoid Valve (Purge Control)	A/C Relay (A/C Cut-Off)	Igniter (Ignition Timing Control)
		Fuel Injection Amount	Fuel Injection Timing				
Input Devices							
Test Terminal		×	×	○	×	×	○
Ignition Switch (Start Position)		○	○	○	○	○	○
P/S Pressure Switch		×	×	○	×	×	×
Cooling Fan Switch		×	×	○	×	×	×
Blower Control Switch		×	×	○	×	×	×
Headlight Switch		×	×	○	×	×	×
Stoplight Switch		○	×	×	×	×	×
Neutral and Clutch Switches		○	×	○	○	×	○
A/C Switch		×	×	○	×	○	×
Throttle Sensor	Idle Terminal (IDL)	○	×	○	○	×	○
	Power Terminal (POW)	○	×	×	×	○	×
Atmospheric Pressure Sensor		○	×	○	×	×	×
IGF Signal		○	×	×	×	×	×
Oxygen Sensor		○	×	×	○	×	×
Water Thermosensor		○	×	○	○	×	○
Airflow Meter	Potentiometer	○	×	×	○	×	○
	Intake Air Thermosensor	○	×	○	○	×	×
Crank Angle Sensor	Ne-Signal	○	○	○	○	×	○
	G-Signal	×	○	×	×	×	○

05U0FX-012



Troubleshooting chart

7		CRANKS NORMALLY BUT HARD TO START — AFTER WARM-UP	
<b>DESCRIPTION</b>		<ul style="list-style-type: none"> <li>• Engine cranks at normal speed but requires excessive cranking time (more than 5 sec.) before starting after running and hot soaked</li> <li>• Battery is normal condition</li> <li>• Engine starts normally when cold</li> </ul>	
<b>[TROUBLESHOOTING HINTS]</b>			
① Air/Fuel mixture too rich		② Vapor lock	
<ul style="list-style-type: none"> <li>• Insufficient fuel injection control</li> <li>• Injector fuel leakage</li> </ul>		<ul style="list-style-type: none"> <li>• Fuel pressure is not held in fuel line after engine stops</li> <li>• High RVP (winter) fuel is used in warm weather</li> </ul>	
STEP	INSPECTION		ACTION
1	Check if "00" is displayed on Self-Diagnosis Checker with ignition switch ON ☞ page F-78 	Yes	Go to next step
		No	<b>Malfunction Code No. displayed</b> Check for cause (Refer to specified check sequence) ☞ page F-78  <b>"88" flashes</b> Check ECU terminal 1F voltage ☞ page F-128  <b>Voltage: Approx. 12V (ignition switch ON)</b> ⇒ If OK, replace ECU ☞ page F-127 ⇒ If not OK, check wiring between ECU and Self-Diagnosis Checker ☞ page F-7
2	Check if ECU terminal voltages are OK (Especially 2D and 2Q)		☞ page F-128
3	Run		

05U0FX-015

**DESCRIPTION:**

Further describes the symptom. Confirm that the chart addresses the actual symptom before beginning troubleshooting.

**TROUBLESHOOTING HINTS:**

This describes the possible point of malfunction.

**STEP:**

This shows the order of troubleshooting. Proceed with troubleshooting as indicated.

**INSPECTION:**

This describes an inspection to quickly determine the malfunction of parts. If a detailed procedure is necessary to perform the INSPECTION, refer to the page shown by the "☞" mark.

**ACTION:**

This recommends the appropriate action to take as a result (Yes/No) of the INSPECTION. How to perform the action is described on the reference page shown by the "☞" mark.

05U0FX-016


## DIAGNOSTIC INDEX

No.	TROUBLESHOOTING ITEM	DESCRIPTION	PAGE
1	Will not crank or cranks slowly	Refer to Engine Electrical System	G- 4
2	Cranks normally but will not start (No combustion)	Engine cranks at normal speed but shows no sign of "firing"	F-20
3	Cranks normally but will not start (Partial combustion) — When engine is cold	Engine cranks at normal speed but shows partial combustion and will not continue to run	F-22
4	Cranks normally but will not start (Partial combustion) — After warm-up	Engine cranks at normal speed but shows partial combustion and will not continue to run after running and hot soaked	F-24
5	Cranks normally but hard to start — Always	Engine cranks at normal speed but requires excessive cranking time (more than 5 sec.) before starting	F-26
6	Cranks normally but hard to start — When engine is cold	Same condition as No.5 when engine is cold Restarts OK after warm-up	F-28
7	Cranks normally but hard to start — After warm-up	Same condition as No.5 after running and hot soaked Starts normally when cold	F-29
8	Rough idle — Always	Engine vibrates excessively at idle in every condition	F-30
9	Low idle speed/Rough idle — Before warm-up	Engine speed low or engine vibrates excessively at idle during warm-up	F-32
10	Low idle speed/Rough idle — After warm-up	Engine runs normally at idle during warm-up but vibrates excessively after warm-up	F-34
11	High idle speed — After warm-up	Engine idle excessive for operation mode	F-36
12	Low idle speed — When A/C, P/S, or E/L ON	Engine speed decreases at idle when A/C, P/S, or E/L is ON	F-38
13	Rough idle just after starting	Engine starts normally but vibrates excessively only just after starting	F-39
14	Idle moves up and down	Engine speed up and down periodically at idle	F-40
15	Engine stalls at idle — Always	Engine starts normally but vibrates excessively and stalls at idle in every condition	F-42
16	Engine stalls at idle — Before warm-up	Engine starts normally but vibrates excessively and stalls at idle before warm-up	F-44
17	Engine stalls at idle — After warm-up	Engine runs normally at idle during warm-up but becomes rough and stalls after warm-up	F-45
18	Engine stalls during start-up	Engine unexpectedly stops running while starting	F-46
19	Engine stalls on deceleration	Engine unexpectedly stops running while decelerating or after deceleration	F-48
20	Engine stalls at idle — When A/C, P/S, or E/L ON	Engine unexpectedly stops running at idle when A/C, P/S, or E/L is ON	F-50
21	Engine stalls suddenly (Intermittent)	Engine intermittently stops running	F-51
22	Hesitates/Stumbles on acceleration	Flat spot occurs just after accelerator is depressed or mild jerking occurs during acceleration	F-52
23	Surges while cruising	Unexpected, usually repetitive change in engine speed	F-54
24	Lack of power	Performance poor under load Maximum speed reduced	F-56
25	Poor acceleration	Performance poor while accelerating	F-60
26	Runs rough on deceleration/Backfire	Engine runs rough while decelerating and abnormal combustion in exhaust system	F-64
27	Knocking	Abnormal combustion accompanied by audible "pinging" noise	F-66
28	Fuel odor	Gasoline odor in cabin	F-68
29	Exhaust sulfur smell	Exhaust gas smells abnormal (rotten egg smell)	F-69
30	High oil consumption	Oil consumption excessive	F-69
31	Poor fuel economy	Fuel economy unsatisfactory	F-70




No.	TROUBLESHOOTING ITEM	DESCRIPTION	PAGE
32	MIL always ON	Self-Diagnosis Checker does not indicate Malfunction Code No. but MIL comes on	F-72
33	MIL never ON	Self-Diagnosis Checker indicates Malfunction Code No. of input device but MIL never ON	F-72
34	A/C does not work	Blower fan operates but no cool air discharged	F-73

05U0FX-017




9BU0F2-076




INSTALL CLAMPS

05U0FX-235



05U0FX-018



05U0FX-236

**PRECAUTION**

**Fuel Pressure Release and Servicing Fuel System**

Fuel in the fuel system remains under high pressure even when the engine is not running.

- a) Before disconnecting any fuel line, release the fuel pressure from the fuel system to reduce the possibility of injury or fire.
  1. Start the engine.
  2. Disconnect the circuit opening relay connector.
  3. After the engine stalls, turn off the ignition switch.
  4. Reconnect the circuit opening relay connector.

- b) Use a rag as protection from fuel spray when disconnecting the hoses. Plug the hoses after removal.
- c) When inspecting the fuel system, use a suitable fuel pressure gauge.

**Caution**

- Install hose clamps when securing the fuel pressure gauge to the fuel pipe and the fuel main hose to prevent fuel leakage.


















**Pinching Hose**




When pinching an air hose or fuel hose with pliers, wrap the hose with a rag to prevent damage.



**Checking ignition spark**

When checking ignition spark condition, hold the high-tension lead with insulated pliers.






STEP	INSPECTION		ACTION
4	Check if approx. 12V exists at fuel pump connector (L/R) wire with jumper wire connected (Step 3) 	Yes	Check continuity of fuel pump  page F-107
		No	Check circuit opening relay  page F-110
5	Check for injector operating sound while cranking engine 	Yes	Go to Step 7
		No	Go to Step 6
6	Check if approx. 12V exists at injector connector (W/R) wire with ignition switch ON 	Yes	Check ECU terminals 2A, 2U and 2V voltages  page F-129
		No	Check for open circuit in wiring between main relay and injector  page F- 7
7	Connect diagnosis connector terminals F/P and GND with jumper wire and check for correct fuel line pressure with ignition switch ON  page F-103  <b>Fuel Line pressure:</b> <b>265—314 kPa (2.7—3.2 kg/cm<sup>2</sup>, 38—46 psi)</b>   GND F/P INSTALL CLAMPS	Yes	Go to next step
		No	<b>Low pressure</b> Check fuel line pressure while pinching fuel return hose ⇒ If fuel line pressure quickly increases, check pressure regulator  page F-111 ⇒ If fuel line pressure gradually increases, check for clogging between fuel pump and pressure regulator If not clogged, check fuel pump maximum pressure  page F-108
8	Check for correct engine compression  page B-10  <b>Engine compression: 1,324—932 kPa (13.5—9.5 kg/cm<sup>2</sup>, 192—135 psi) - 300 rpm</b>	Yes	Go to next step
		No	Check engine condition  page B-10 • Worn piston, piston rings or cylinder wall • Defective cylinder head gasket • Distorted cylinder head • Improper valve seating • Valve sticking in guide
9	Check if spark plugs are OK WEAR AND CARBON BUILDUP PLUG GAP 1.0—1.1mm (0.039—0.043 in) 	Yes	Go to next step
		No	Repair, clean, or replace  page G-20
10	Try known good ECU and check if condition improves  page F-127		

3	<b>CRANKS NORMALLY BUT WILL NOT START (PARTIAL COMBUSTION) — WHEN ENGINE IS COLD</b>		
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>• Engine cranks at normal speed but shows partial combustion and will not continue to run</li> <li>• Battery in normal condition</li> <li>• Fuel in tank</li> </ul>		
<b>[TROUBLESHOOTING HINTS]</b>			
<p>① Air/Fuel mixture too rich <span style="float: right;">③ Low engine compression</span></p> <ul style="list-style-type: none"> <li>• Air cleaner element clogged</li> <li>• Airflow meter stuck</li> </ul> <p>② Air/Fuel mixture too lean</p> <ul style="list-style-type: none"> <li>• Fuel injection control malfunction (Correction for coolant temperature)</li> <li>• Low fuel line pressure</li> <li>• Air leakage of intake air system</li> </ul>			
STEP	INSPECTION	ACTION	
1	<p>Check if "00" is displayed on Self-Diagnosis Checker with ignition switch ON</p> <p style="text-align: right;">☞ <b>page F-78</b></p> 	<p>Yes</p> <p>No</p>	<p>Go to next step</p> <p><b>Malfunction Code No. displayed</b> Check for cause (Refer to specified check sequence) ☞ <b>page F-80</b></p> <p><b>"88" flashes</b> Check ECU terminal 1F voltage ☞ <b>page F-128</b></p> <p><b>Voltage: Approx. 12V (Ignition switch ON)</b></p> <p>⇒ If OK, replace ECU ☞ <b>page F-127</b></p> <p>⇒ If not OK, check wiring between ECU and Self-Diagnosis Checker ☞ <b>page F-7</b></p>
2	<p>Check if strong blue spark is visible at each disconnected high-tension lead while cranking engine</p> 	<p>Yes</p> <p>No</p>	<p>Go to next step</p> <p>Check ignition system (Refer to Troubleshooting "Misfire") ☞ <b>page G-18</b></p>
3	<p>Connect diagnosis connector terminal F/P and GND with jumper wire and check for correct fuel line pressure with ignition switch ON</p> <p style="text-align: right;">☞ <b>page F-103</b></p> <p><b>Fuel line pressure:</b> <b>265—314 kPa (2.7—3.2 kg/cm<sup>2</sup>, 38—46 psi)</b></p> 	<p>Yes</p> <p>No</p>	<p>Go to next step</p> <p><b>Low pressure</b> Check fuel line pressure while pinching fuel return hose</p> <p>⇒ If fuel line pressure quickly increases, check pressure regulator ☞ <b>page F-111</b></p> <p>⇒ If fuel line pressure gradually increases, check for clogging between fuel pump and pressure regulator</p> <p>If not clogged, check fuel pump maximum pressure ☞ <b>page F-108</b></p> <p><b>High pressure</b> Check if fuel return hose is clogged or restricted</p> <p>⇒ If OK, replace pressure regulator ☞ <b>page F-112</b></p> <p>⇒ If not OK, repair or replace</p>
4	<p>Check if ECU terminal voltages are OK (2D, 2O and 2Q)</p> <p style="text-align: right;">☞ <b>page F-129</b></p>	<p>Yes</p> <p>No</p>	<p>Go to next step</p> <p>Check for cause (Refer to "Check Point for Each Terminal") ☞ <b>page F-132</b></p>




STEP	INSPECTION	ACTION	
5	Check for air leakage of intake air system ☞ page F-93	Yes	Repair or replace
6	Check if airflow meter vane moves smoothly	Yes	Go to next step
7	Check for correct engine compression ☞ page B-10  <b>Engine compression: 1,324—932 kPa                      (13.5—9.5 kg/cm<sup>2</sup>, 192—135 psi) - 300 rpm</b>	Yes	Go to next step
		No	Check engine condition ☞ page B-10 <ul style="list-style-type: none"> <li>• Worn piston, piston rings or cylinder wall</li> <li>• Defective cylinder head gasket</li> <li>• Distorted cylinder head</li> <li>• Improper valve seating</li> <li>• Valve sticking in guide</li> </ul>
8	Check if spark plugs are OK  WEAR AND CARBON BUILDUP  PLUG GAP 1.0—1.1mm (0.039—0.043 in)	Yes	Go to next step
		No	Repair, clean, or replace ☞ page G-20
9	Try known good ECU and check if condition improves ☞ page F-127		

05U0FX-020

















4	<b>CRANKS NORMALLY BUT WILL NOT START (PARTIAL COMBUSTION) — AFTER WARM-UP</b>	
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>• Engine cranks at normal speed but shows partial combustion and will not continue to run after running and hot soaked</li> <li>• Battery in normal condition</li> <li>• Engine starts normally when cold</li> </ul>	
<b>[TROUBLESHOOTING HINTS]</b> ① Air/Fuel mixture too rich <ul style="list-style-type: none"> <li>• Fuel injection control malfunction (Correction for coolant temperature)</li> <li>• Injector fuel leakage</li> </ul> ② Vapor lock <ul style="list-style-type: none"> <li>• Fuel pressure not held in fuel line after engine stops</li> <li>• High RVP (winter) fuel used in warm weather</li> </ul>		
STEP	INSPECTION	ACTION
1	Check if "00" is displayed on Self-Diagnosis Checker with ignition switch ON ☞ page F-78 	Yes: Go to next step No: <b>Malfunction Code No. displayed</b> Check for cause (Refer to specified check sequence) ☞ page F-80 <b>"88" flashes</b> Check ECU terminal 1F voltage ☞ page F-128 <b>Voltage: Approx. 12V (Ignition switch ON)</b> ⇒ If OK, replace ECU ☞ page F-127 ⇒ If not OK, check wiring between ECU and Self-Diagnosis Checker ☞ page F-7
2	Check if ECU terminal voltages are OK (2D and 2Q) ☞ page F-129	Yes: Go to next step No: Check for cause (Refer to "Check Point for Each Terminal") ☞ page F-132
3	Connect diagnosis connector terminals F/P and GND with jumper wire and check for correct fuel line pressure with ignition switch ON ☞ page F-103 <b>Fuel line pressure:</b> <b>265—314 kPa (2.7—3.2 kg/cm<sup>2</sup>, 38—46 psi)</b> 	Yes: Go to next step No: <b>Low pressure</b> Check fuel line pressure while pinching fuel return hose ⇒ If fuel line pressure quickly increases, check pressure regulator ☞ page F-111 ⇒ If fuel line pressure gradually increases, check fuel line and filter for clogging If not clogged, check fuel pump maximum pressure ☞ page F-108 <b>High pressure</b> Check if fuel return hose is clogged or restricted ⇒ If OK, replace pressure regulator ☞ page F-112 ⇒ If not OK, repair or replace hose



STEP	INSPECTION	ACTION	
4	With condition of step 3, check if fuel line pressure is held after ignition switch is turned OFF ☞ <b>page F-102</b>  <b>Fuel line pressure: More than 147 kPa (1.5 kg/cm<sup>2</sup>, 21 psi) for 5 min.</b>  	Yes	Go to Step 6
		No	Go to Step 5
5	Check if fuel line pressure is held after ignition switch is turned OFF and blocking outlet of pressure regulator  ☞ <b>page F-111</b>  <b>Fuel line pressure: More than 147 kPa (1.5 kg/cm<sup>2</sup>, 21 psi) for 5 min.</b>	Yes	Replace pressure regulator ☞ <b>page F-112</b>
		No	Check fuel pump hold pressure ☞ <b>page F-107</b>  ⇒ If OK, check injector for fuel leakage ☞ <b>page F-113</b> ⇒ If not OK, replace fuel pump ☞ <b>page F-108</b>
6	Try known good ECU and check if condition improves  ☞ <b>page F-127</b>	Yes	Replace ECU
		No	Change fuel to another brand

05U0FX-021




5	<b>CRANKS NORMALLY BUT HARD TO START — ALWAYS</b>		
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>• Engine cranks at normal speed but requires excessive cranking time (more than 5 sec.) before starting</li> <li>• Battery in normal condition</li> </ul>		
<b>[TROUBLESHOOTING HINTS]</b>			
① Air/Fuel mixture too lean <ul style="list-style-type: none"> <li>• Fuel injection control malfunction (Correction for coolant temperature)</li> <li>• Low fuel line pressure</li> <li>• Air leakage</li> </ul>		② Air/Fuel mixture too rich <ul style="list-style-type: none"> <li>• Air cleaner element clogged</li> <li>• Airflow meter stuck</li> </ul> ③ Poor ignition spark	
STEP	INSPECTION		ACTION
1	Check if "00" is displayed on Self-Diagnosis Checker with ignition switch ON ☞ page F-78 	Yes  No	Go to next step  <b>Malfunction Code No. displayed</b> Check for cause (Refer to specified check sequence) ☞ page F-80  <b>"88" flashes</b> Check ECU terminal 1F voltage ☞ page F-128  <b>Voltage: Approx. 12V (Ignition switch ON)</b> ⇨ If OK, replace ECU ☞ page F-127 ⇨ If not OK, check wiring between ECU and Self-Diagnosis Checker ☞ page F-7
2	Check for correct intake manifold vacuum at idle <b>Vacuum: More than 450 mmHg (17.7 inHg)</b> 	Yes  No	Go to next step  Check for air leakage of intake air system components ☞ page F-93
3	Check if air cleaner element is clean ☞ page F-75	Yes  No	Go to next step  Replace air cleaner element ☞ page F-92
4	Check for correct fuel line pressure at idle ☞ page F-103 <b>Fuel line pressure: 265—314 kPa (2.7—3.2 kg/cm<sup>2</sup>, 38—46 psi) (Vacuum hose to pressure regulator disconnected)</b>  INSTALL CLAMPS	Yes  No	Go to next step  <b>Low pressure</b> Check fuel line pressure while pinching fuel return hose  ⇨ If fuel line pressure quickly increases, check pressure regulator ☞ page F-111 ⇨ If fuel line pressure gradually increases, check for clogging between fuel pump and pressure regulator If not clogged, check fuel pump maximum pressure ☞ page F-108























STEP	INSPECTION	ACTION	
5	Check if ECU terminal voltages are OK (2D, 2O and 2Q)  <b>page F-129</b>	Yes	Go to next step
		No	Check for cause (Refer to "Check Point for Each Terminal")  <b>page F-132</b>
6	Check if strong blue spark is visible at each disconnected high-tension lead while cranking engine 	Yes	Go to next step
		No	Check ignition system (Refer to Troubleshooting "Misfire")  <b>page G-18</b>
7	Check for injector operating sound at each injector at idle 	Yes	Go to Step 9
		No	Go to Step 8
8	Check if approx. 12V exists at injector connector (W/R) wire with ignition switch ON 	Yes	Check if injector resistance is OK  <b>page F-112</b>  <b>Resistance: Approx. 14Ω</b> ⇨ If OK, check wiring between injector and ECU  <b>page F-7</b> ⇨ If not OK, replace injector  <b>page F-112</b>
		No	Check wiring between main relay and injector  <b>page F-7</b>
9	Check for correct engine compression  <b>page B-10</b>  <b>Engine compression: 1,324—932 kPa (13.5—9.5 kg/cm<sup>2</sup>, 192—135 psi) - 300 rpm</b> 	Yes	Go to next step
		No	Check engine condition  <b>page B-10</b> <ul style="list-style-type: none"> <li>• Worn piston, piston rings or cylinder wall</li> <li>• Defective cylinder head gasket</li> <li>• Distorted cylinder head</li> <li>• Improper valve seating</li> <li>• Valve sticking in guide</li> </ul>
10	Check if spark plugs are OK WEAR AND CARBON BUILDUP PLUG GAP 1.0—1.1mm (0.039—0.043 in) 	Yes	Go to next step
		No	Repair, clean, or replace  <b>page G-20</b>
11	Try known good ECU and check if condition improves  <b>page F-127</b>		


6	<b>CRANKS NORMALLY BUT HARD TO START — WHEN ENGINE IS COLD</b>		
<b>DESCRIP- TION</b>	<ul style="list-style-type: none"> <li>• Engine cranks at normal speed but requires excessive cranking time before starting</li> <li>• Battery in normal condition</li> <li>• Restarts OK after warm-up</li> </ul>		
<b>[TROUBLESHOOTING HINTS]</b>			
<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>① Air/Fuel mixture too rich</p> <ul style="list-style-type: none"> <li>• Airflow meter stuck</li> <li>• Air cleaner element clogged</li> <li>• Idle speed control malfunction</li> </ul> </div> <div style="width: 45%;"> <p>② Air/Fuel mixture too lean</p> <ul style="list-style-type: none"> <li>• Fuel injection control malfunction (Correction for coolant temperature)</li> </ul> <p>③ Poor atomization of fuel</p> <ul style="list-style-type: none"> <li>• Low RVP (summer) fuel used in cold weather</li> </ul> </div> </div>			
STEP	INSPECTION		ACTION
1	Check if "00" is displayed on Self-Diagnosis Checker with ignition switch ON ☞ page F-78 	Yes  No	Yes: Go to next step  No: <b>Malfunction Code No. displayed</b> Check for cause (Refer to specified check sequence) ☞ page F-80  <b>"88" flashes</b> Check ECU terminal 1F voltage ☞ page F-128  <b>Voltage: Approx. 12V (Ignition switch ON)</b> ⇒ If OK, replace ECU ☞ page F-127 ⇒ If not OK, check wiring between ECU and Self-Diagnosis Checker ☞ page F-7
2	Check if ECU terminal voltages are OK (1C, 2D, 2O and 2Q) ☞ page F-128	Yes  No	Yes: Go to next step  No: Check for cause (Refer to "Check Point for Each Terminal") ☞ page F-131
3	Check if engine starts easily when depressing accelerator while cranking	Yes    No	Yes: Check if ISC valve is OK ☞ page F-99 ⇒ If OK, check air valve ☞ page F-99 ⇒ If not OK, replace ISC valve ☞ page F-99  No: Go to next step
4	Check for correct intake manifold vacuum at idle <b>Vacuum: More than 450 mmHg (17.7 inHg)</b> 	Yes  No	Yes: Go to next step  No: Check for air leakage of intake air system components ☞ page F-93
5	Check if air cleaner element is clean ☞ page F-75	Yes  No	Yes: Go to next step  No: Replace air cleaner element ☞ page F-92
6	Try known good ECU and check if condition improves ☞ page F-127	Yes  No	Yes: Replace ECU  No: Change fuel to another brand







8		ROUGH IDLE — ALWAYS	
<b>DESCRIPTION</b>		• Engine vibrates excessively at idle in every condition	
<b>[TROUBLESHOOTING HINTS]</b>			
① Air/Fuel mixture too lean		③ One or more spark plugs not sparking	
• Air leakage		④ Injection timing misadjustment	
• Fuel injection control malfunction		⑤ Low engine compression	
• Low fuel line pressure			
② One or more injectors not operating or clogged			
STEP	INSPECTION		ACTION
1	Check for correct intake manifold vacuum at idle  <b>Vacuum: More than 450 mmHg (17.7 inHg)</b>  	Yes	Go to next step
		No	Check for air leakage of intake air system components  ☞ <b>page F-93</b>
2	Check if air cleaner element is clean  ☞ <b>page F-75</b>	Yes	Go to next step
		No	Replace air cleaner element  ☞ <b>page F-92</b>
3	Check if "00" is displayed on Self-Diagnosis Checker with ignition switch ON  ☞ <b>page F-78</b>  	Yes	Go to next step
		No	<b>Malfunction Code No. displayed</b> Check for cause (Refer to specified check sequence)  ☞ <b>page F-80</b>
			<b>"88" flashes</b> Check ECU terminal 1F voltage  ☞ <b>page F-128</b>
			<b>Voltage: Approx. 12V (Ignition switch ON)</b>  ⇒ If OK, replace ECU ☞ <b>page F-127</b> ⇒ If not OK, check wiring between ECU and Self-Diagnosis Checker ☞ <b>page F-7</b>
4	Check switches for correct operation with Self-Diagnosis Checker Monitor Lamp and ignition switch ON  ☞ <b>page F-89</b>  	Yes	Go to next step
		No	<b>Lamp not ON/OFF with specified switch</b> Check for cause (Refer to specified check sequence)  ☞ <b>page F-90</b>
			<b>Lamp always ON</b> Check wiring between ECU terminal 1D and Self-Diagnosis Checker  ☞ <b>page F-7</b>
5	Check if ECU terminal voltages are OK (2D, 2O and 2Q)  ☞ <b>page F-129</b>	Yes	Go to next step
		No	Check for cause (Refer to "Check Point for Each Terminal")  ☞ <b>page F-132</b>

STEP	INSPECTION	ACTION			
6	Check for injector operating sound at idle with sound scope or screwdriver	Yes	Go to Step 8		
		No	Go to Step 7		
7	Check if approx. 12V exists at injector connector (W/R) wire	Yes	Check if injector resistance is OK  <b>page F-112</b>		
			<b>Resistance: Approx. 14Ω</b> ⇒ If OK, check wiring between ECU and injector  <b>page F-7</b> ⇒ If not OK, replace injector  <b>page F-112</b>		
8	Disconnect each high-tension lead at idle and check if engine speed decreases equally each time	Yes	Disconnect each injector connector at idle and check if engine speed decreases equally each time  ⇒ If OK, go to Step 10 ⇒ If not OK, check injector for fuel leakage  <b>page F-113</b>		
			No	Go to step 9	
9	Check if spark plugs are OK <b>WEAR AND CARBON BUILDUP</b>	Yes	Check for correct engine compression  <b>page B-10</b>  ⇒ If OK, replace injector  <b>page F-112</b> ⇒ If not OK, check for cause (Refer to Section B)  <b>page B-10</b>		
			No	Repair, clear, or replace  <b>page G-20</b>	
PLUG GAP 1.0—1.1mm (0.039—0.043 in)		10	Check for correct ignition timing at idle  <b>page F-75</b>	Yes	Check for correct idle speed  <b>page F-76</b>  <b>Idle speed: 850 ± 50 rpm</b>  ⇒ If OK, go to next step ⇒ If not OK, adjust idle speed  <b>page F-76</b>
					Ignition timing: 10° ± 1° BTDC
11	Check for correct fuel line pressure at idle  <b>page F-103</b>	Yes	Go to next step		
		No	<b>Low pressure</b> Check fuel line pressure while pinching fuel return hose  ⇒ If fuel line pressure quickly increases, check pressure regulator  <b>page F-111</b> ⇒ If fuel line pressure gradually increases, check for clogging between fuel pump and pressure regulator If not clogged, check fuel pump maximum pressure  <b>page F-108</b>		
<b>Fuel line pressure:</b> <b>265—314 kPa (2.7—3.2 kg/cm<sup>2</sup>, 38—48 psi)</b> <b>(Vacuum hose to pressure regulator disconnected)</b>		INSTALL CLAMPS	12	Try known good ECU and check if condition improves  <b>page F-127</b>	





9	LOW IDLE SPEED/ROUGH IDLE — BEFORE WARM-UP		
<b>DESCRIPTION</b>	• Engine speed low or engine vibrates excessively at idle during warm-up		
<b>[TROUBLESHOOTING HINTS]</b>			
① Low intake air amount <ul style="list-style-type: none"> <li>• Airflow meter stuck</li> <li>• Air cleaner element clogged</li> <li>• Idle speed control               <ul style="list-style-type: none"> <li>[Air valve</li> <li>[Correction for coolant temperature]</li> </ul> </li> </ul>		② Low fuel injection amount <ul style="list-style-type: none"> <li>• Fuel injection control malfunction (Correction for coolant temperature)</li> </ul> ③ Poor atomization of fuel <ul style="list-style-type: none"> <li>• Low RVP (summer) fuel used in cold weather</li> </ul>	
STEP	INSPECTION		ACTION
1	Check if "00" is displayed on Self-Diagnosis Checker with ignition switch ON ☞ page F-78 	Yes No	Yes: Go to next step No: <b>Malfunction Code No. displayed</b> Check for cause (Refer to specified check sequence) ☞ page F-80 <b>"88" flashes</b> Check ECU terminal 1F voltage ☞ page F-128 <b>Voltage: Approx. 12V (Ignition switch ON)</b> ⇒ If OK, replace ECU ☞ page F-127 ⇒ If not OK, check wiring between ECU and Self-Diagnosis Checker ☞ page F-7
2	Check switches for correct operation with Self-Diagnosis Checker Monitor Lamp and ignition switch ON ☞ page F-89 	Yes No	Yes: Go to next step No: <b>Lamp not ON/OFF with specified switch</b> Check for cause (Refer to specified check sequence) ☞ page F-90 <b>Lamp always ON</b> Check wiring between ECU terminal 1D and Self-Diagnosis Checker ☞ page F-7
3	Check if ECU terminal voltages are OK (2D, 2O and 2Q) ☞ page F-129	Yes No	Yes: Go to next step No: Check for cause (Refer to "Check Point for Each Terminal") ☞ page F-132
4	Check for correct intake manifold vacuum at idle <b>Vacuum: More than 450 mmHg (17.7 inHg)</b> 	Yes No	Yes: Go to next step No: Check for air leakage of intake air system components ☞ page F-93
5	Check if air cleaner element is clean ☞ page F-75	Yes No	Yes: Go next step No: Replace air cleaner element ☞ page F-92



STEP	INSPECTION		ACTION
6	Connect System Selector to diagnosis connector and set Test Switch to "SELF TEST" when engine is cold Check if engine speed decreases as engine warms up  <div style="text-align: right;">  </div>	Yes	Go to next step
		No	Check air valve <span style="float: right;">☞ page F-99</span>
7	With condition of Step 5 check for correct ignition timing at idle after warm-up  <div style="text-align: right;"> <span>☞ page F-75</span>  <b>Ignition timing: 10° ± 1° BTDC</b> </div>	Yes	Go to next step
		No	Adjust <span style="float: right;">☞ page F-75</span>
8	Try known good ECU and check if condition improves  <div style="text-align: right;"> <span>☞ page F-127</span> </div>	Yes	Replace ECU <span style="float: right;">☞ page F-127</span>
		No	Change fuel to another brand




05U0FX-026

10		LOW IDLE SPEED/ROUGH IDLE — AFTER WARM-UP	
<b>DESCRIPTION</b>		• Engine runs normally at idle during warm-up but vibrates excessively after warm-up	
<b>[TROUBLESHOOTING HINTS]</b>			
① Idle speed control malfunction ② Air/Fuel mixture too lean • Air leakage of intake air system • Low fuel line pressure		③ Air/Fuel mixture too rich • Fuel injection control malfunction (Correction for coolant temperature) ④ Poor ignition spark ⑤ Low engine compression	
STEP	INSPECTION	ACTION	
1	Check if "00" is displayed on Self-Diagnosis Checker with ignition switch ON ☞ page F-78 	Yes	Go to next step
		No	<b>Malfunction Code No. displayed</b> Check for cause (Refer to specified check sequence) ☞ page F-80
			<b>"88" flashes</b> Check ECU terminal 1F voltage ☞ page F-128  <b>Voltage: Approx. 12V (Ignition switch ON)</b>  ⇨ If OK, replace ECU ☞ page F-127 ⇨ If not OK, check wiring between ECU and Self-Diagnosis Checker ☞ page F-7
2	Check switches for correct operation with Self-Diagnosis Checker Monitor Lamp and ignition switch ON ☞ page F-89 	Yes	Go to next step
		No	<b>Lamp not ON/OFF with specified switch</b> Check for cause (Refer to specified check sequence) ☞ page F-90
			<b>Lamp always ON</b> Check wiring between ECU terminal 1D and Self-Diagnosis Checker ☞ page F-7
3	Disconnect ISC valve connector at idle and check if "clicking" is heard from ISC valve 	Yes	Go to next step
		No	Replace ISC valve ☞ page F-99
4	Check for correct intake manifold vacuum at idle <b>Vacuum: More than 450 mmHg (17.7 inHg)</b> 	Yes	Go to next step
		No	<b>Low vacuum</b> Check for air leakage of intake air system components ☞ page F-93










STEP	INSPECTION	ACTION	
5	Check if ECU terminal voltages are OK (2D, 2O and 2Q) ☞ page F-128	Yes	Go to next step
		No	Check for cause (Refer to "Check Point for Each Terminal") ☞ page F-132
6	Check for correct ignition timing at idle ☞ page F-75  <b>Ignition timing: 10° ± 1° BTDC</b>    CONNECT TERMINALS	Yes	Check for correct idle speed <b>Idle speed: 850 ± 50 rpm</b>  ⇒ If OK, go to next step ⇒ If not OK, adjust idle speed ☞ page F-76
		No	Adjust ☞ page F-75
7	Check for correct fuel line pressure at idle ☞ page F-103  <b>Fuel line pressure: 265—314 kPa (2.7—3.2 kg/cm<sup>2</sup>, 38—46 psi) (Vacuum hose to pressure regulator disconnected)</b>    INSTALL CLAMPS	Yes	Go to next step
		No	<b>Low pressure</b> Check fuel line pressure while pinching fuel return hose  ⇒ If fuel line pressure quickly increases, check pressure regulator ⇒ If fuel line pressure gradually increases, check for clogging between fuel pump and pressure regulator If not clogged, check fuel pump maximum pressure ☞ page F-111  ☞ page F-108
8	Check if strong blue spark is visible at each disconnected high-tension lead while cranking engine	Yes	Go to next step
		No	Check ignition system (Refer to Troubleshooting "Misfire") ☞ page G-18
9	Check for correct engine compression ☞ page B-10  <b>Engine compression: 1,324—932 kPa (13.5—9.5 kg/cm<sup>2</sup>, 192—135) - 300 rpm</b>  	Yes	Go to next step
		No	Check engine condition • Worn piston, piston rings or cylinder wall • Defective cylinder head gasket • Distorted cylinder head • Improper valve seating • Valve sticking in guide ☞ page B-10
10	Check if spark plugs are OK WEAR AND CARBON BUILDUP   PLUG GAP 1.0—1.1mm (0.039—0.043 in) BURNS DAMAGE AND DETERIORATION DAMAGE	Yes	Go to next step
		No	Repair, clear, or replace ☞ page G-20
11	Try known good ECU and check if condition improves ☞ page F-127		




11	HIGH IDLE SPEED — AFTER WARM-UP		
<p><b>[TROUBLESHOOTING HINTS]</b>            Excessive intake air supplied to engine</p> <ul style="list-style-type: none"> <li>① Throttle valve not fully closed</li> <li>② Idle speed control malfunction               <ul style="list-style-type: none"> <li>• Air valve not closing</li> <li>• ISC valve stuck</li> <li>• Incorrect coolant temperature signal</li> </ul> </li> </ul>			
STEP	INSPECTION		ACTION
1	Check if throttle valve is fully closed when accelerator released	Yes	Go to Step 3
		No	Check if throttle linkage is correctly installed and operates freely <span style="float: right;">☞ page F-96</span>  ⇨ If OK, go to Step 2 ⇨ If not OK, clean, adjust or replace linkage <span style="float: right;">☞ page F-96</span>
2	Check if dashpot is correctly adjusted <span style="float: right;">☞ page F-121</span>  <b>Dashpot set speed: 2,500 ± 150 rpm</b>	Yes	Check if throttle valve is contaminated  ⇨ If contaminated, clean throttle body <span style="float: right;">☞ page F-94</span> ⇨ If not contaminated, replace throttle body <span style="float: right;">☞ page F-94</span>
		No	Adjust <span style="float: right;">☞ page F-121</span>
3	Check if "00" is displayed on Self-Diagnosis Checker with ignition switch ON <span style="float: right;">☞ page F-78</span>  	Yes	Go to next step
		No	<b>Malfunction Code No. displayed</b> Check for cause (Refer to specified check sequence) <span style="float: right;">☞ page F-80</span>
			<b>"88" flashes</b> Check ECU terminal 1F voltage <span style="float: right;">☞ page F-128</span>  <b>Voltage: Approx. 12V (Ignition switch ON)</b>  ⇨ If OK, replace ECU <span style="float: right;">☞ page F-127</span> ⇨ If not OK, check wiring between ECU and Self-Diagnosis Checker <span style="float: right;">☞ page F-7</span>
4	Check switches for correct operation with Self-Diagnosis Checker Monitor Lamp and ignition switch ON <span style="float: right;">☞ page F-89</span>  	Yes	Go to next step
		No	<b>Lamp not ON/OFF with specified switch</b> Check for cause (Refer to specified check sequence) <span style="float: right;">☞ page F-90</span>
			<b>Lamp always ON</b> Check wiring between ECU terminal 1D and Self-Diagnosis Checker <span style="float: right;">☞ page F-7</span>






STEP	INSPECTION	ACTION	
5	<p>Connect System Selector to diagnosis connector and set Test Switch to "SELF TEST" when engine is cold Check if engine speed decreases as engine warms up</p> 	Yes	Go to next step
		No	Check air valve <span style="float: right;">☞ page F-99</span>
6	<p>Disconnect ISC valve connector at idle and check if "clicking" is heard from ISC valve</p> 	Yes	Go to next step
		No	Check ISC valve <span style="float: right;">☞ page F-99</span>
7	<p>Pinch PCV hose with pliers and check if engine speed decreases</p> 	Yes	Check PCV valve <span style="float: right;">☞ page F-117</span>
		No	Go to next step
8	<p>Check if ECU terminal voltages are OK (2D, 2O and 2Q)</p> <p style="text-align: right;">☞ page F-129</p>	Yes	Try known good ECU <span style="float: right;">☞ page F-127</span>
		No	Check for cause (Refer to "Check Point for Each Terminal") <span style="float: right;">☞ page F-132</span>

05U0FX-028

12	LOW IDLE SPEED — WHEN A/C, P/S, OR E/L ON	
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>• Engine speed decreases at idle when A/C, P/S, or E/L ON</li> <li>• A/C, P/S, headlights, blower fan and electric cooling fan operate normally</li> </ul>	
<b>[TROUBLESHOOTING HINTS]</b>		
① Idle speed control malfunction • Engine speed feedback control malfunction		• ISC valve stuck
STEP	INSPECTION	ACTION
1	Check if "00" is displayed on Self-Diagnosis Checker with ignition switch ON ☞ page F-78	Yes: Go to next step No: <b>Malfunction Code No. displayed</b> Check for cause (Refer to specified check sequence) ☞ page F-80
		<b>"88" flashes</b> Check ECU terminal 1F voltage ☞ page F-128 <b>Voltage: Approx. 12V (Ignition switch ON)</b> ⇨ If OK, replace ECU ☞ page F-127 ⇨ If not OK, check wiring between ECU and Self-Diagnosis Checker ☞ page F-7
	Check switches for correct operation with Self-Diagnosis Checker Monitor Lamp and ignition switch ON ☞ page F-89	Yes: Go to next step No: <b>Lamp not ON/OFF with specified switch</b> Check for cause (Refer to specified check sequence) ☞ page F-90
		<b>Lamp always ON</b> Check wiring between ECU terminal 1D and Self-Diagnosis Checker ☞ page F-7
3	Check if continuity exists between diagnosis connector terminal TEN and ground 	Yes: Check for short circuit in wiring between diagnosis connector terminal TEN and ground ☞ page F-7 No: Go to next step
4	Disconnect ISC valve connector at idle and check if "clicking" is heard from ISC valve 	Yes: Try known good ECU ☞ page F-127 No: Replace ISC valve ☞ page F-99





13	ROUGH IDLE JUST AFTER STARTING		
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>• Engine starts normally but vibrates excessively just after starting</li> </ul>		
<b>[TROUBLESHOOTING HINTS]</b>			
<ul style="list-style-type: none"> <li>① Fuel injection control and idle speed control malfunction</li> <li>• Start signal not input to ECU</li> </ul>		<ul style="list-style-type: none"> <li>② Idle speed misadjustment</li> <li>③ Ignition timing misadjustment</li> </ul>	
STEP	INSPECTION	ACTION	
1	Check if "00" is displayed on Self-Diagnosis Checker with ignition switch ON ☞ page F-78 	Yes	Go to next step
		No	<b>Malfunction Code No. displayed</b> Check for cause (Refer to specified check sequence) ☞ page F-80  <b>"88" flashes</b> Check ECU terminal 1F voltage ☞ page F-128  <b>Voltage: Approx. 12V (Ignition switch ON)</b>  ⇒ If OK, replace ECU ☞ page F-127 ⇒ If not OK, check wiring between ECU and Self-Diagnosis Checker ☞ page F-7
2	Check switches for correct operation with Self-Diagnosis Checker Monitor Lamp and ignition switch ON ☞ page F-89 	Yes	Go to next step
		No	<b>Lamp not ON/OFF with specified switch</b> Check for cause (Refer to specified check sequence) ☞ page F-90  <b>Lamp always ON</b> Check wiring between ECU terminal 1D and Self-Diagnosis Checker ☞ page F-7
3	Check if ECU terminal 1C voltage is OK ☞ page F-128  <b>Voltage: Approx. 10V (While cranking)</b>	Yes	Go to next step
		No	Check for cause (Refer to "Check Point for Each Terminal") ☞ page F-131
4	Check for correct ignition timing at idle ☞ page F-75  <b>Ignition timing: 10° ± 1° BTDC</b>  	Yes	Check for correct idle speed ☞ page F-76  <b>Idle speed: 850 ± 50 rpm</b>  ⇒ If OK, go to next step ⇒ If not OK, adjust idle speed ☞ page F-76
		No	Adjust ☞ page F-75
5	Try known good ECU and check if condition improves ☞ page F-127		




14	IDLE MOVES UP AND DOWN	
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>• Engine speed up and down periodically at idle</li> </ul>	
<b>[TROUBLESHOOTING HINTS]</b>		
<ul style="list-style-type: none"> <li>① Fuel cut occurs at idle               <ul style="list-style-type: none"> <li>• Air valve not closing after warm-up and idle speed reaches to fuel cut speed</li> </ul> </li> <li>② Fuel injection amount fluctuating               <ul style="list-style-type: none"> <li>• Bad contact point inside airflow meter</li> </ul> </li> <li>③ Air leakage of intake air system</li> <li>④ Poor ignition spark</li> <li>⑤ Air/Fuel mixture too rich               <ul style="list-style-type: none"> <li>• Evaporative emission control system malfunction</li> </ul> </li> <li>⑥ Low engine compression</li> </ul>		
STEP	INSPECTION	ACTION
1	<p>Check if "00" is displayed on Self-Diagnosis Checker with ignition switch ON</p> <p style="text-align: right;">☞ page F-78</p> 	<p>Yes: Go to next step</p> <p>No: <b>Malfunction Code No. displayed</b> Check for cause (Refer to specified check sequence) ☞ page F-80</p> <p><b>"88" flashes</b> Check ECU terminal 1F voltage ☞ page F-128</p> <p><b>Voltage: Approx. 12V (Ignition switch ON)</b></p> <ul style="list-style-type: none"> <li>⇒ If OK, replace ECU ☞ page F-127</li> <li>⇒ If not OK, check wiring between ECU and Self-Diagnosis Checker ☞ page F-7</li> </ul>
2	<p>Check for correct idle speed</p> <p style="text-align: right;">☞ page F-76</p> <p><b>Idle speed: 850 ± 50 rpm</b></p> 	<p>Yes: Go to next step</p> <p>No: Check if idle speed can be adjusted by turning air adjust screw</p> <ul style="list-style-type: none"> <li>⇒ If OK, adjust idle speed</li> <li>⇒ If not OK, check air valve ☞ page F-99</li> </ul>
3	<p>Check for correct ignition timing at idle</p> <p style="text-align: right;">☞ page F-75</p> <p><b>Ignition timing 10° ± 1° BTDC</b></p> 	<p>Yes: Go to next step</p> <p>No: Adjust ☞ page F-75</p>


STEP	INSPECTION		ACTION
4	<p>Check for correct intake manifold vacuum at idle</p> <p><b>Intake manifold vacuum: More than 450 mmHg (17.7 inHg)</b></p> 	Yes	Go to next step
		No	<p><b>Low vacuum</b> Check for air leakage of intake air system</p> <p>☞ page F-93</p>
5	Check for injector operating sound at idle with sound scope or screwdriver	Yes	Go to Step 7
		No	Go to Step 6
6	<p>Check if approx. 12V exists at injector connector (W/R) wire</p> 	Yes	<p>Check if injector resistance is OK</p> <p>☞ page F-112</p> <p><b>Resistance: Approx. 14Ω</b></p> <p>⇒ If OK, check wiring between ECU and injector</p> <p>☞ page F-7</p> <p>⇒ If not OK, replace injector</p> <p>☞ page F-112</p>
		No	Check wiring between ECU and injector <p>☞ page F-7</p>
7	<p>Disconnect each high-tension lead at idle and check if engine speed decreases equally each time</p> 	Yes	<p>Disconnect each injector connector at idle and check if engine speed decreases equally each time</p> <p>⇒ If OK, go to Step 9</p> <p>⇒ If not OK, check injector for fuel leakage</p> <p>☞ page F-113</p>
		No	Go to Step 8
8	<p>Check if spark plugs are OK</p> <p><b>WEAR AND CARBON BUILDUP</b></p> <p>PLUG GAP 1.0—1.1mm (0.039—0.043 in)</p> 	Yes	<p>Check for correct engine compression</p> <p>☞ page B-10</p> <p>⇒ If OK, replace injector</p> <p>☞ page F-112</p> <p>⇒ If not OK, check for cause (Refer to Section B)</p> <p>☞ page B-10</p>
		No	Repair, clear, or replace <p>☞ page G-20</p>
9	Check if ECU terminal voltages are OK (2D, 2Q and 2X) <p>☞ page F-128</p>	Yes	Go to next step
		No	Check for cause (Refer to "Check Point for Each Terminal") <p>☞ page F-132</p>
10	<p>Check if vacuum is felt at solenoid valve (purge control) at idle</p> 	Yes	Check solenoid valve <p>☞ page F-119</p>
		No	Go to next step
11	Try known good ECU and check if condition improves <p>☞ page F-127</p>		






STEP	INSPECTION		ACTION
5	Check if ECU terminal voltages are OK (2D, 2O and 2Q) <span style="float: right;">☞ page F-129</span>	Yes	Go to next step
		No	Check for cause (Refer to "Check Point for Each Terminal") <span style="float: right;">☞ page F-132</span>
6	Check if strong blue spark is visible at each disconnected high-tension lead while cranking engine 	Yes	Go to next step
		No	Check ignition system (Refer to Troubleshooting "Misfire") <span style="float: right;">☞ page G-18</span>
7	Check for injector operating sound at each injector at idle	Yes	Go to Step 9
		No	Go to Step 8
8	Check if approx. 12V exists at injector connector (W/R) wire with ignition switch ON 	Yes	Check if injector resistance is OK <span style="float: right;">☞ page F-112</span> <b>Resistance: Approx. 14Ω</b> ⇒ If OK, check wiring between injector and ECU ⇒ If not OK, replace injector <span style="float: right;">☞ page F-112</span>
		No	Check wiring between main relay and injector <span style="float: right;">☞ page F-7</span>
9	Check if spark plugs are OK <b>WEAR AND CARBON BUILDUP</b> PLUG GAP 1.0—1.1mm (0.039—0.043 in) 	Yes	Go to next step
		No	Repair or replace <span style="float: right;">☞ page G-20</span>
10	Connect diagnosis connector terminals F/P and GND with jumper wire and check for correct fuel line pressure with ignition switch ON <span style="float: right;">☞ page F-103</span> <b>Fuel line pressure:</b> <b>265—314 kPa (2.7—3.2 kg/cm<sup>2</sup>, 38—46 psi)</b> 	Yes	Go to next step
		No	<b>Low pressure</b> Check fuel line pressure while pinching fuel return hose ⇒ If fuel line pressure quickly increases, check pressure regulator <span style="float: right;">☞ page F-111</span> ⇒ If fuel line pressure gradually increases, check for clogging between fuel pump to pressure regulator If not clogged, check for fuel pump maximum pressure <span style="float: right;">☞ page F-108</span>
11	Try known good ECU and check if condition improves <span style="float: right;">☞ page F-127</span>		




16	ENGINE STALLS AT IDLE — BEFORE WARM-UP		
<b>DESCRIPTION</b>	• Engine starts normally but vibrates excessively and stalls at idle before warm-up		
<b>[TROUBLESHOOTING HINTS]</b>			
<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>① Low intake air amount</p> <ul style="list-style-type: none"> <li>• Idle speed control malfunction</li> <li>• Air cleaner element clogged</li> <li>• Airflow meter stuck</li> </ul> </div> <div style="width: 45%;"> <p>② Air/Fuel mixture too lean</p> <ul style="list-style-type: none"> <li>• Air leakage of intake air system</li> </ul> <p>③ Poor atomization of fuel</p> <ul style="list-style-type: none"> <li>• Low RVP (summer) fuel used in cold weather</li> </ul> </div> </div>			
STEP	INSPECTION		ACTION
1	<p>Check if "00" is displayed on Self-Diagnosis Checker with ignition switch ON</p> <p style="text-align: right;">☞ page F-78</p> 	<p>No</p> <p>No</p>	<p>Go to next step</p> <p><b>Malfunction Code No. displayed</b> Check for cause (Refer to specified check sequence) ☞ page F-80</p> <p><b>"88" flashes</b> Check ECU terminal 1F voltage ☞ page F-128</p> <p><b>Voltage: Approx. 12V (Ignition switch ON)</b></p> <p>⇒ If OK, replace ECU ☞ page F-127</p> <p>⇒ If not OK, check wiring between ECU and Self-Diagnosis Checker ☞ page F-7</p>
2	<p>Check switches for correct operation with Self-Diagnosis Checker Monitor Lamp with ignition switch ON</p> <p style="text-align: right;">☞ page F-89</p> 	<p>Yes</p> <p>No</p>	<p>Go to next step</p> <p><b>Lamp not ON/OFF with specified switch</b> Check for cause (Refer to specified check sequence) ☞ page F-90</p> <p><b>Lamp always ON</b> Check wiring between ECU terminal 1D and Self-Diagnosis Checker ☞ page F-7</p>
3	<p>Check if ECU terminal voltages are OK (2D, 2O and 2Q)</p> <p style="text-align: right;">☞ page F-129</p>	<p>Yes</p> <p>No</p>	<p>Go to next step</p> <p>Check for cause (Refer to "Check Point for Each Terminal") ☞ page F-132</p>
4	<p>Check for correct intake manifold vacuum at idle</p> <p><b>Vacuum: More than 450 mmHg (17.7 inHg)</b></p> 	<p>Yes</p> <p>No</p>	<p>Go to next step</p> <p>Check for air leakage of intake air system components ☞ page F-93</p>




STEP	INSPECTION		ACTION
5	Check if air cleaner element is clean ☞ <b>page F-75</b>	Yes	Go to next step
		No	Replace air cleaner element ☞ <b>page F-92</b>
6	Disconnect ISC valve connector when engine is cold and note idle speed Check if engine speed decreases after warm-up  	Yes	Go to next step
		No	Check air valve ☞ <b>page F-99</b>
7	Try known good ECU and check if condition improves ☞ <b>page F-127</b>	Yes	Replace ECU ☞ <b>page F-127</b>
		No	Change fuel to another brand




05U0FX-033








<b>17</b>	<b>ENGINE STALLS AT IDLE — AFTER WARM-UP</b>		
<b>DESCRIP- TION</b>	• Engine runs normally at idle during warm-up but becomes rough and stalls after warm-up		
<b>[TROUBLESHOOTING HINTS]</b>			
① Air/Fuel mixture too lean • Air leakage of intake air system		② Low intake air amount • Idle speed control malfunction	
STEP	INSPECTION		ACTION
1	Check if air is leaked from intake air system component ☞ <b>page F-93</b>	Yes	Repair or replace ☞ <b>page F-93</b>
		No	Go to next step
2	Disconnect ISC valve connector at idle and check if "clicking" is heard from ISC Valve  	Yes	Go to next step
		No	Replace ISC valve ☞ <b>page F-99</b>
3	Go to troubleshooting No.10 "LOW IDLE SPEED/ROUGH IDLE-AFTER WARM-UP" ☞ <b>page F-34</b>		

05U0FX-034





18		ENGINE STALLS DURING START-UP	
<b>DESCRIPTION</b>		• Engine unexpectedly stops running while starting	
<b>[TROUBLESHOOTING HINTS]</b>			
① Misfire occurs when depressing accelerator		② Lack of engine torque for start-up	
<ul style="list-style-type: none"> <li>• Air/Fuel mixture too rich or too lean</li> <li>• Incorrect ignition timing</li> <li>• Weak ignition</li> </ul>		<ul style="list-style-type: none"> <li>• Air/Fuel mixture too rich or too lean</li> <li>• Low intake air amount</li> <li>• Low engine compression</li> </ul>	
STEP	INSPECTION		ACTION
1	Check if brakes are dragging ☞ page P-29	Yes	Repair ☞ page P-29
		No	Go to next step
2	Check if "00" is displayed on Self-Diagnosis Checker with ignition switch ON ☞ page F-78 	No	Go to next step
		No	<b>Malfunction Code No. displayed</b> Check for cause (Refer to specified check sequence) ☞ page F-78
			<b>"88" flashes</b> Check ECU terminal 1F voltage ☞ page F-128  <b>Voltage: Approx. 12V (Ignition switch ON)</b>  ⇒ If OK, replace ECU ☞ page F-127 ⇒ If not OK, check wiring between ECU and Self-Diagnosis Checker ☞ page F-7
3	Check switches for correct operation with Self-Diagnosis Checker Monitor Lamp and ignition switch ON ☞ page F-89 	Yes	Go to next step
		No	<b>Lamp not ON/OFF with specified switch</b> Check for cause (Refer to specified check sequence) ☞ page F-90
			<b>Lamp always ON</b> Check wiring between ECU terminal 1D and Self-Diagnosis Checker ☞ page F-7
4	Disconnect oxygen sensor connector and check if condition improves 	Yes	Check oxygen sensor ☞ page F-138
		No	Go to next step
5	Check if ECU terminal voltages are OK ☞ page F-128	Yes	Go to next step
		No	Check for cause (Refer to "Check Point for Each Terminal") ☞ page F-131

STEP	INSPECTION		ACTION
6	Check if throttle linkage is correctly installed and operates freely	Yes	Go to next step
		No	Correct, clean, or replace as required any binding or damaged linkage and adjust cable deflection at throttle body <span style="float: right;">☞ page F-96</span>
7	Check for correct intake manifold vacuum at idle  <b>Vacuum: More than 450 mmHg (17.7 inHg)</b>  	Yes	Go to next step
		No	Check for air leakage of intake air system components <span style="float: right;">☞ page F-93</span>
8	Check if air cleaner element is clean <span style="float: right;">☞ page F-75</span>	Yes	Go to next step
		No	Replace air cleaner element <span style="float: right;">☞ page F-92</span>
9	Check for correct ignition timing at idle <span style="float: right;">☞ page F-76</span>  <b>Ignition timing: 10° ± 1° BTDC</b> GND    TEN  CONNECT TERMINALS	Yes	Check if ignition timing advances when accelerating  ⇒ If advances, go to next step ⇒ If no advance, replace ECU <span style="float: right;">☞ page F-127</span>
		No	Adjust <span style="float: right;">☞ page F-76</span>
10	Check for correct fuel line pressure at idle <span style="float: right;">☞ page F-103</span>  <b>Fuel line pressure: 265—314 kPa (2.7—3.2 kg/cm<sup>2</sup>, 38—46 psi) (Vacuum hose to pressure regulator disconnected)</b>   INSTALL CLAMPS	Yes	Check if fuel line pressure decreases when accelerating quickly  ⇒ If decreases, check fuel pump maximum pressure <span style="float: right;">☞ page F-108</span> If OK, check fuel line and filter for clogging ⇒ If no decrease, go to next step
		No	<b>Low pressure</b> Check for fuel line pressure while pinching fuel return hose  ⇒ If fuel line pressure quickly increases, check pressure regulator <span style="float: right;">☞ page F-111</span> ⇒ If fuel line pressure gradually increases, check for clogging between fuel pump and pressure regulator If not clogged, check fuel pump maximum pressure <span style="float: right;">☞ page F-108</span>
			<b>High pressure</b> Check if fuel return line is clogged  ⇒ If OK, replace pressure regulator <span style="float: right;">☞ page F-112</span> ⇒ If not OK, replace
11	Check for correct engine compression <span style="float: right;">☞ page B-10</span>  <b>Engine compression: 1,324—932 kPa (13.5—9.5 kg/cm<sup>2</sup>, 192—135 psi) - 300 rpm</b>	Yes	Go to next step
		No	Check engine condition <span style="float: right;">☞ page B-10</span> <ul style="list-style-type: none"> <li>• Worn piston, piston rings or cylinder wall</li> <li>• Defective cylinder head gasket</li> <li>• Distorted cylinder head</li> <li>• Improper valve seating</li> <li>• Valve sticking in guide</li> </ul>
12	Try known good ECU and check if condition improves <span style="float: right;">☞ page F-127</span>		


19	ENGINE STALLS ON DECELERATION	
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>• Engine unexpectedly stops running while decelerating or after deceleration</li> </ul>	
<p><b>[TROUBLESHOOTING HINTS]</b>            Engine speed drops too much when releasing accelerator</p> <p>① Idle speed control malfunction      ③ Engine feedback control malfunction            ② Fuel cut control malfunction      ④ Idle speed misadjustment</p>		
STEP	INSPECTION	ACTION
1	Check if "00" is displayed on Self-Diagnosis Checker with ignition switch ON ☞ page F-78 	Yes Go to next step
		No <b>Malfunction Code No. displayed</b> Check for cause (Refer to specified check sequence) ☞ page F-80  <b>"88" flashes</b> Check ECU terminal 1F voltage ☞ page F-128  <b>Voltage: Approx. 12V (Ignition switch ON)</b>  ⇨ If OK, replace ECU ☞ page F-127 ⇨ If not OK, check wiring between ECU and Self-Diagnosis Checker ☞ page F-7
2	Check switches for correct operation with Self-Diagnosis Checker Monitor Lamp and ignition switch ON ☞ page F-89 	Yes Go to next step
		No <b>Lamp not ON/OFF with specified switch</b> Check for cause (Refer to specified check sequence) ☞ page F-90  <b>Lamp always ON</b> Check wiring between ECU terminal 1D and Self-Diagnosis Checker ☞ page F-7
3	Disconnect oxygen sensor connector and check if condition improves 	Yes Check oxygen sensor ☞ page F-138
		No Go to next step
4	Check if ECU terminal voltages are OK (2D, 2O, 2U, 2V and 2Q) ☞ page F-129	Yes Go to next step
		No Check for cause (Refer to "Check Point for Each Terminal") ☞ page F-132

STEP	INSPECTION	ACTION	
5	Disconnect ISC valve connector at idle and check if "clicking" is heard from ISC valve 	Yes	Go to next step
		No	Replace ISC valve  page F-99
6	Check for correct idle speed  page F-76 Idle speed: 850 ± 50 rpm  CONNECT TERMINALS 	Yes	Go to next step
		No	Adjust  page F-76
7	Try known good ECU and check if condition improves  page F-127		




05U0FX-036




20	ENGINE STALLS AT IDLE — WHEN A/C, P/S, OR E/L ON		
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>• Engine unexpectedly stops running at idle when A/C, P/S, or E/L ON</li> <li>• A/C, P/S, headlight, blower fan and electric cooling fan OK</li> </ul>		
<b>[TROUBLESHOOTING HINTS]</b>			
① Idle speed control malfunction <ul style="list-style-type: none"> <li>• No input signal from switch</li> <li>• Idle speed misadjustment</li> <li>• ISC valve stuck</li> </ul>			
STEP	INSPECTION		ACTION
1	Check if "00" is displayed on Self-Diagnosis Checker with ignition switch ON ☞ <b>page F-78</b> 	Yes  No	Yes Go to next step  No <b>Malfunction Code No. displayed</b> Check for cause (Refer to specified check sequence) ☞ <b>page F-80</b>  <b>"88" flashes</b> Check ECU terminal 1F voltage ☞ <b>page F-128</b>  <b>Voltage: Approx. 12V (Ignition switch ON)</b>  ⇨ If OK, replace ECU ☞ <b>page F-127</b> ⇨ If not OK, check wiring between ECU and Self-Diagnosis Checker ☞ <b>page F-7</b>
2	Check switches for correct operation with Self-Diagnosis Checker Monitor Lamp and ignition switch ON ☞ <b>page F-89</b> 	Yes  No	Yes Go to next step  No <b>Lamp not ON/OFF with specified switch</b> Check for cause (Refer to specified check sequence) ☞ <b>page F-89</b>  <b>Lamp always ON</b> Check wiring between ECU terminal 1D and Self-Diagnosis Checker ☞ <b>page F-7</b>
3	Check if ECU terminal voltages are OK (1G, 1P, 1U, 2D, 2Q and 2W) ☞ <b>page F-128</b>	Yes  No	Yes Go to next step  No Check for cause (Refer to "Check Point for Each Terminal") ☞ <b>page F-131</b>
4	Check for correct idle speed ☞ <b>page F-76</b> <b>Idle speed: 850 ± 50 rpm</b> GND TEN  CONNECT TERMINALS	Yes  No	Yes Go to next step  No Adjust ☞ <b>page F-76</b>
5	Disconnect ISC valve connector at idle and check if "clicking" is heard from ISC valve 	Yes  No	Yes Go to next step  No Replace ISC valve ☞ <b>page F-99</b>
6	Try known good ECU and check if condition improves ☞ <b>page F-127</b>		









21	<b>ENGINE STALLS SUDDENLY (INTERMITTENT)</b>		
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>• Engine intermittently stops running</li> <li>• Before stalling, engine condition OK</li> </ul>		
<b>[TROUBLESHOOTING HINTS]</b> ① Intermittently no spark or no fuel injection <ul style="list-style-type: none"> <li>• Poor connection in wiring harness</li> </ul>			
<b>STEP</b>	<b>INSPECTION</b>		<b>ACTION</b>
1	Check if "00" is displayed on Self-Diagnosis Checker with ignition switch ON ☞ page F-78  	Yes  No	Go to next step  <b>Malfunction Code No. displayed</b> Check for cause (Refer to specified check sequence) ☞ page F-80  <b>Note</b> When checking wiring harness and connectors, tap, move, and wiggle suspect sensor and/or harness to recreate problem  <b>"88" flashes</b> Check ECU terminal 1F voltage ☞ page F-128  <b>Voltage: Approx. 12V (Ignition switch ON)</b>  ⇒ If OK, replace ECU ☞ page F-127 ⇒ If not OK, check wiring between ECU and Self-Diagnosis Checker ☞ page F-7
2	Check if ECU terminal voltages are OK (1B, 2A, 2B and 2C) ☞ page F-128  <b>Note</b> When checking voltages, tap, move, and wiggle harness and connector	Yes  No	Go to Troubleshooting No.2 "CRANKS NORMALLY BUT WILL NOT START (NO COMBUSTION)" ☞ page F-82  Check for cause (Refer to "Check Point for Each Terminal") ☞ page F-131
















05U0FX-038







22		HESITATES/STUMBLES ON ACCELERATION	
DESCRIP-TION		• Flat spot occurs just after accelerator depressed or mild jerking occurs during acceleration	
[TROUBLESHOOTING HINTS]			
① Air/Fuel mixture leaning when depressing accelerator			
<ul style="list-style-type: none"> <li>• Fuel injection control malfunction (Correction for accelerating condition)</li> <li>• Air leakage of intake air system</li> <li>• Fuel line pressure low</li> <li>• Spark advance control malfunction</li> </ul>			
STEP	INSPECTION	ACTION	
1	Check if "00" is displayed on Self-Diagnosis Checker with ignition switch ON ☞ page F-78 	Yes	Go to next step
		No	<b>Malfunction Code No. displayed</b> Check for cause (Refer to specified check sequence) ☞ page F-80
			<b>"88" flashes</b> Check ECU terminal 1F voltage ☞ page F-128  <b>Voltage: Approx. 12V (Ignition switch ON)</b>  ⇨ If OK, replace ECU ☞ page F-127 ⇨ If not OK, check wiring between ECU and Self-Diagnosis Checker ☞ page F-7
2	Check switches for correct operation with Self-Diagnosis Checker Monitor Lamp and ignition switch ON ☞ page F-89 	Yes	Go to next step
		No	<b>Lamp not ON/OFF with specified switch</b> Check for cause (Refer to specified check sequence) ☞ page F-90
			<b>Lamp always ON</b> Check wiring between ECU terminal 1D and Self-Diagnosis Checker ☞ page F-7
3	Disconnect oxygen sensor connector and check if condition improves 	Yes	Check oxygen sensor ☞ page F-138
		No	Go to next step
4	Check if ECU terminal voltages are OK ☞ page F-128	Yes	Go to next step
		No	Check for cause (Refer to "Check Point for Each Terminal") ☞ page F-131
5	Check if throttle linkage is correctly installed and operates freely	Yes	Go to next step
		No	Correct, clean, or replace as required any binding or damaged linkage and adjust cable deflection at throttle body ☞ page F-96




STEP	INSPECTION		ACTION
6	Check if air duct and air hoses are correctly installed <span style="float: right;">☞ page F-76</span>	Yes	Go to next step
		No	Repair <span style="float: right;">☞ page F-92</span>
7	Check for correct intake manifold vacuum at idle <b>Vacuum: More than 450 mmHg (17.7 inHg)</b> 	Yes	Go to next step
		No	Check for air leakage of intake air system components <span style="float: right;">☞ page F-93</span>
8	Check if air cleaner element is clean <span style="float: right;">☞ page F-75</span>	Yes	Go to next step
		No	Replace air cleaner element <span style="float: right;">☞ page F-92</span>
9	Check for correct ignition timing at idle <span style="float: right;">☞ page F-75</span> <b>Ignition timing: 10° ± 1° BTDC</b>  <p style="margin-left: 20px;">CONNECT TERMINALS</p>	Yes	Check if ignition timing advances when accelerating ⇒ If advances, go to next step ⇒ If no advance, replace ECU <span style="float: right;">☞ page F-127</span>
		No	Adjust <span style="float: right;">☞ page F-75</span>
10	Check for correct fuel line pressure at idle <span style="float: right;">☞ page F-103</span> <b>Fuel line pressure:                      265—314 kPa (2.7—3.2 kg/cm<sup>2</sup>, 38—46 psi)                      (Vacuum hose to pressure regulator disconnected)</b>  <p style="margin-left: 20px;">INSTALL CLAMPS</p>	Yes	Check if fuel line pressure decreases when accelerating quickly ⇒ If decreases, check fuel line and filter for clogging ⇒ If no decrease, go to next step
		No	<b>Low pressure</b> Check for fuel line pressure while pinching fuel return hose ⇒ If fuel line pressure quickly increases, check pressure regulator <span style="float: right;">☞ page F-111</span> ⇒ If fuel line pressure gradually increases, check for clogging between fuel pump and pressure regulator If not clogged, check fuel pump maximum pressure <span style="float: right;">☞ page F-108</span>
11	Check if exhaust system is restricted <span style="float: right;">☞ page F-115</span>	Yes	Repair or replace <span style="float: right;">☞ page F-115</span>
		No	Go to next step
12	Try known good ECU and check if condition improves <span style="float: right;">☞ page F-127</span>		

23		SURGES WHILE CRUISING	
DESCRIPTION		<ul style="list-style-type: none"> <li>• Unexpected change in engine speed which is usually repetitive</li> </ul>	
[TROUBLESHOOTING HINTS]			
① Air/Fuel mixture too lean or too rich <ul style="list-style-type: none"> <li>• Fuel injection control malfunction</li> <li>• Air leakage of intake air system</li> </ul>		<ul style="list-style-type: none"> <li>• Fuel line pressure low</li> <li>• Evaporative emission control malfunction</li> <li>• Spark advance control malfunction</li> </ul>	
STEP	INSPECTION		ACTION
1	Check if "00" is displayed on Self-Diagnosis Checker with ignition switch ON ☞ page F-78 	Yes	Go to next step
		No	<b>Malfunction Code No. displayed</b> Check for cause (Refer to specified check sequence) ☞ page F-80  <b>"88" flashes</b> Check ECU terminal 1F voltage ☞ page F-128  <b>Voltage: Approx. 12V (Ignition switch ON)</b>  ⇨ If OK, replace ECU ☞ page F-127 ⇨ If not OK, check wiring between ECU and Self-Diagnosis Checker ☞ page F-7
2	Check switches for correct operation with Self-Diagnosis Checker Monitor Lamp and ignition switch ON ☞ page F-89 	Yes	Go to next step
		No	<b>Lamp not ON/OFF with specified switch</b> Check for cause (Refer to specified check sequence) ☞ page F-90  <b>Lamp always ON</b> Check wiring between ECU terminal 1D and Self-Diagnosis Checker ☞ page F-7
3	Disconnect oxygen sensor connector and check if condition improves 	Yes	Check oxygen sensor ☞ page F-138
		No	Go to next step
4	Check if ECU terminal voltages are OK ☞ page F-128	Yes	Go to next step
		No	Check for cause (Refer to "Check Point for Each Terminal") ☞ page F-131
5	Check if throttle linkage is correctly installed and operates freely	Yes	Go to next step
		No	Correct, clean, or replace as required any binding or damaged linkage, and adjust cable deflection at throttle body ☞ page F-96




STEP	INSPECTION		ACTION
6	<p>Check for correct intake manifold vacuum</p> <p><b>Vacuum: More than 450 mmHg (17.7 inHg)</b></p> 	<p>Yes</p>	<p>Go to next step</p>
7	<p>Check if air cleaner element is clean</p> <p>☞ page F-75</p>	<p>Yes</p>	<p>Go to next step</p>
8	<p>Check for correct ignition timing at idle</p> <p>☞ page F-75</p> <p><b>Ignition timing: 10° ± 1° BTDC</b></p>  <p>CONNECT TERMINALS</p>	<p>Yes</p>	<p>Check if ignition timing advances when accelerating</p> <p>⇒ If advances, go to next step</p> <p>⇒ If no advance, replace ECU</p> <p>☞ page F-127</p>
9	<p>Check for correct fuel line pressure at idle</p> <p>☞ page F-103</p> <p><b>Fuel line pressure: 265—314 kPa (2.7—3.2 kg/cm<sup>2</sup>, 38—46 psi)</b> (Vacuum hose to pressure regulator disconnected)</p>  <p>INSTALL CLAMPS</p>	<p>Yes</p>	<p>Check if fuel line pressure decreases when accelerating quickly</p> <p>⇒ If decreases, check fuel line and filter for clogging</p> <p>⇒ If no decrease, go to next step</p>
10	<p>Check if exhaust system is restricted</p> <p>☞ page F-115</p>	<p>Yes</p>	<p>Repair or replace</p> <p>☞ page F-115</p>
11	<p>Try known good ECU and check if condition improves</p> <p>☞ page F-127</p>	<p>No</p>	<p>Go to next step</p>



24		LACK OF POWER	
<b>DESCRIPTION</b>		<ul style="list-style-type: none"> <li>• Performance poor under load</li> <li>• Reduced maximum speed</li> </ul>	
<b>[TROUBLESHOOTING HINTS]</b>			
① Factors other than engine malfunction <ul style="list-style-type: none"> <li>• Clutch slipping</li> <li>• Brake dragging</li> <li>• Low tire pressure</li> <li>• Unrecommended tire size</li> <li>• Overloaded</li> </ul>		③ Air/Fuel mixture too lean or too rich <ul style="list-style-type: none"> <li>• Fuel line pressure low or high</li> <li>• Insufficient fuel injection</li> </ul>	
② Low intake air amount <ul style="list-style-type: none"> <li>• Throttle valve not open fully</li> <li>• Clogged intake air system</li> </ul>		④ Poor ignition ⑤ Low engine compression	
STEP	INSPECTION	ACTION	
1	Check factors other than engine <ul style="list-style-type: none"> <li>• Clutch slipping  page H-3</li> <li>• Brake dragging  page P-27</li> <li>• Low tire pressure  page Q-3</li> <li>• Unrecommended tire size  page Q-2</li> </ul>	Yes	Go to next step
		No	Repair
2	Check if throttle valve fully opens when depressing accelerator fully	Yes	Go to next step
		No	Check if accelerator cable is correctly installed  page F-96  ⇨ If OK, check throttle body  page F-94 ⇨ If not OK, install accelerator cable correctly  page F-96
3	Check if "00" is displayed on Self-Diagnosis Checker with ignition switch ON  	Yes	Go to next step
		No	<b>Malfunction Code No. displayed</b> Check for cause (Refer to specified check sequence)  page F-80
		<b>"88" flashes</b> Check ECU terminal 1F voltage  page F-128  <b>Voltage: Approx. 12V (Ignition switch ON)</b>  ⇨ If OK, replace ECU  page F-127 ⇨ If not OK, check wiring between ECU and Self-Diagnosis Checker  page F-7	
4	Check switches for correct operation with Self-Diagnosis Checker Monitor Lamp and ignition switch ON  	Yes	Go to next step
		No	<b>Lamp not ON/OFF with specified switch</b> Check for cause (Refer to specified check sequence)  page F-90
			<b>Lamp always ON</b> Check wiring between ECU terminal 1D and Self-Diagnosis Checker  page F-7





STEP	INSPECTION		ACTION
5	<p>Check for correct ignition timing at idle  <span style="font-size: small;">☞ page F-75</span></p> <p><b>Ignition timing: 10° ± 1° BTDC</b></p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>GND    TEN</p>  </div> <div style="text-align: center;">  </div> </div> <p>CONNECT TERMINALS</p>	Yes	<p>Check if ignition timing advances when accelerating</p> <p>⇒ If advances, go to next step                  ⇒ If no advance, check ECU terminal voltages  <span style="float: right;">☞ page F-127</span></p>
		No	<p>Adjust  <span style="float: right;">☞ page F-75</span></p>
6	<p>Check if spark plugs are OK</p> <div style="text-align: center;"> <p>WEAR AND CARBON BUILDUP</p>  <p>BURNS</p> <p>DAMAGE AND DETERIORATION</p> <p>DAMAGE</p> <p>PLUG GAP                      1.0—1.1mm                      (0.039—0.043 in)</p> </div>	Yes	<p>Go to next step</p>
		No	<p>Repair, clean, or replace  <span style="float: right;">☞ page G-20</span></p>
7	<p>Check if resistance of high-tension leads are OK</p> <p><b>Resistance: 16 kΩ per 1m (3.28 ft)</b></p> 	Yes	<p>Go to next step</p>
		No	<p>Replace  <span style="float: right;">☞ page G-22</span></p>
8	<p>Check if resistance of ignition coil is OK  <span style="font-size: small;">☞ page G-21</span></p> <p><b>Resistance (at 20°C [68°F]):</b></p> <p>① Primary coil..... 0.78—0.94Ω                  ② Secondary coil.... 11.2—15.2 kΩ</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>①</p>  </div> <div style="text-align: center;"> <p>②</p>  </div> </div>	Yes	<p>Go to next step</p>
		No	<p>Replace  <span style="float: right;">☞ page G-21</span></p>




STEP	INSPECTION		ACTION
9	Check for correct engine compression ☞ <b>page B-10</b>  <b>Engine compression: 1,324—932 kPa</b> <b>(13.5—9.5 kg/cm<sup>2</sup>, 192—135 psi) - 300 rpm</b>  	Yes	Go to next step
		No	Check engine condition ☞ <b>page B-10</b> <ul style="list-style-type: none"> <li>• Worn piston, piston rings or cylinder wall</li> <li>• Defective cylinder head gasket</li> <li>• Distorted cylinder head</li> <li>• Improper valve seating</li> <li>• Valve sticking in guide</li> </ul>
10	Check for correct intake manifold vacuum at idle  <b>Intake manifold vacuum:</b> <b>More than 450 mmHg (17.7 inHg)</b>  	Yes	Go to next step
		No	Check for air leakage of intake air system components ☞ <b>page F-93</b>
11	Check if air cleaner element is clean ☞ <b>page F-75</b>	Yes	Go to next step
		No	Replace air cleaner element ☞ <b>page F-92</b>
12	Check for injector operating sound at idle	Yes	Go to Step 14
		No	Go to Step 13
13	Check if approx. 12V exists at injector connector (W/R) wire with ignition switch ON  	Yes	Check if injector resistance is OK ☞ <b>page F-99</b>  <b>Resistance: Approx. 14Ω</b>  ⇒ If OK, check wiring between ECU and injector ☞ <b>page F-7</b> ⇒ If not OK, check injector for fuel leakage ☞ <b>page F-113</b>
		No	Check wiring between ECU and injector ☞ <b>page F-7</b>
14	Check if ECU terminal voltages are OK (2D, 2O and 2Q) ☞ <b>page F-129</b>	Yes	Go to next step
		No	Check for cause (Refer to "Check Point for Each Terminal") ☞ <b>page F-132</b>


















STEP	INSPECTION		ACTION
15	<p>Check for correct fuel line pressure at idle  <span style="float: right;">☞ page F-103</span></p> <p><b>Fuel line pressure:</b>  <b>265—314 kPa (2.7—3.2 kg/cm<sup>2</sup>, 38—46 psi)</b>  <b>(Vacuum hose to pressure regulator dis-</b>  <b>connected)</b></p>  <p>INSTALL CLAMPS</p>	Yes	<p>Check if fuel line pressure decreases when accelerating quickly</p> <ul style="list-style-type: none"> <li>⇒ If decreases, check fuel pump maximum pressure <span style="float: right;">☞ page F-108</span></li> <li>⇒ If OK, check fuel line and filter for clogging</li> <li>⇒ If no decreases, go to next step</li> </ul>
		No	<p><b>Low pressure</b>                      Check for fuel line pressure while pinching fuel return hose</p> <ul style="list-style-type: none"> <li>⇒ If fuel line pressure quickly increases, check pressure regulator <span style="float: right;">☞ page F-111</span></li> <li>⇒ If fuel line pressure gradually increases, check for clogging between fuel pump and pressure regulator <span style="float: right;">☞ page F-112</span></li> <li>⇒ If not clogged, check fuel pump maximum pressure <span style="float: right;">☞ page F-108</span></li> </ul>
16	<p>Run engine several minutes at idle and check if fuel line pressure is held after ignition switch turned OFF  <span style="float: right;">☞ page F-102</span></p> <p><b>Fuel line pressure: More than 147 kPa (1.5 kg/cm<sup>2</sup>, 21 psi) for 5 min.</b></p> <p>PRESSURE</p>  <p>IGNITION SWITCH OFF      5 MIN.      TIME</p>	Yes	<p><b>High pressure</b>                      Check if vacuum hose to pressure regulator is damaged or poorly connected</p> <ul style="list-style-type: none"> <li>⇒ If OK, replace pressure regulator <span style="float: right;">☞ page F-112</span></li> <li>⇒ If not OK, repair or replace hose</li> </ul>
		No	<p>Check injector for fuel leakage <span style="float: right;">☞ page F-113</span></p>
17	<p>Disconnect each injector connector at idle and check if engine speed decreases equally each time</p> 	Yes	<p>Go to next step</p>
		No	<p>Replace injector <span style="float: right;">☞ page F-112</span></p>
18	<p>Try known good ECU and check if condition improves  <span style="float: right;">☞ page F-127</span></p>		




25	POOR ACCELERATION		
<b>DESCRIP- TION</b>	<ul style="list-style-type: none"> <li>• Performance poor while accelerating</li> </ul>		
<b>[TROUBLESHOOTING HINTS]</b>			
<ul style="list-style-type: none"> <li>① Factors other than engine malfunction                             <ul style="list-style-type: none"> <li>• Clutch slipping</li> <li>• Brake dragging</li> <li>• Low tire pressure</li> <li>• Unrecommended tire size</li> <li>• Overloaded</li> </ul> </li> <li>② Low intake air amount                             <ul style="list-style-type: none"> <li>• Throttle valve not open fully</li> <li>• Clogged intake air system</li> </ul> </li> <li>④ Air/Fuel mixture too lean or too rich                             <ul style="list-style-type: none"> <li>• Fuel line pressure low or high</li> <li>• Insufficient fuel injection</li> </ul> </li> <li>④ Poor ignition</li> <li>⑤ Low engine compression</li> </ul>			
STEP	INSPECTION	ACTION	
1	Check factors other than engine <ul style="list-style-type: none"> <li>• Clutch slipping <span style="float: right;">☞ page H-3</span></li> <li>• Brake dragging <span style="float: right;">☞ page P-27</span></li> <li>• Low tire pressure <span style="float: right;">☞ page Q-3</span></li> <li>• Unrecommended tire size <span style="float: right;">☞ page Q-2</span></li> </ul>	Yes	Go to next step
		No	Repair
2	Check if throttle valve fully opens when depressing accelerator fully	Yes	Go to next step
		No	Check if accelerator cable is correctly installed <span style="float: right;">☞ page F-96</span>  ⇒ If OK, check throttle body <span style="float: right;">☞ page F-94</span> ⇒ If not OK, install accelerator cable correctly <span style="float: right;">☞ page F-96</span>
3	Check if "00" is displayed on Self-Diagnosis Checker with ignition switch ON <span style="float: right;">☞ page F-78</span>  	Yes	Go to next step
		No	<b>Malfunction Code No. displayed</b> Check for cause (Refer to specified check sequence) <span style="float: right;">☞ page F-80</span>  <b>"88" flashes</b> Check ECU terminal 1F voltage <span style="float: right;">☞ page F-128</span>  <b>Voltage: Approx. 12V (Ignition switch ON)</b>  ⇒ If OK, replace ECU <span style="float: right;">☞ page F-127</span> ⇒ If not OK, check wiring between ECU and Self-Diagnosis Checker <span style="float: right;">☞ page F-7</span>
4	Check switches for correct operation with Self-Diagnosis Checker Monitor Lamp and ignition switch ON <span style="float: right;">☞ page F-89</span>  	Yes	Go to next step
		No	<b>Lamp not ON/OFF with specified switch</b> Check for cause (Refer to specified check sequence) <span style="float: right;">☞ page F-90</span>
			<b>Lamp always ON</b> Check wiring between ECU terminal 1D and Self-Diagnosis Checker <span style="float: right;">☞ page F-7</span>

STEP	INSPECTION	ACTION	
5	Check for correct ignition timing at idle ☞ page F-75  <b>Ignition timing: <math>10^{\circ} \pm 1^{\circ}</math> BTDC</b>	Yes	Check if ignition timing advances when accelerating  ⇒ If advances, go to next step ⇒ If no advance, check ECU terminal voltages ☞ page F-127
		No	Adjust ☞ page F-75
6	Check if spark plugs are OK	Yes	Go to next step
		No	Repair, clean, or replace ☞ page G-20
7	Check if resistance of high-tension leads are OK	Yes	Go to next step
		No	Replace ☞ page G-22
8	Check if resistance of ignition coil is OK ☞ page G-21	Yes	Go to next step
		No	Replace ☞ page G-21

STEP	INSPECTION		ACTION
9	Check for correct engine compression ☞ page B-10  <b>Engine compression: 1,324—932 kPa            (13.5—9.5 kg/cm<sup>2</sup>, 192—135 psi) - 300 rpm</b>  	Yes	Go to next step
		No	Check engine condition ☞ page B-10 <ul style="list-style-type: none"> <li>• Worn piston, piston rings or cylinder wall</li> <li>• Defective cylinder head gasket</li> <li>• Distorted cylinder head</li> <li>• Improper valve seating</li> <li>• Valve sticking in guide</li> </ul>
10	Check for correct intake manifold vacuum at idle  <b>Intake manifold vacuum:            More than 450 mmHg (17.7 inHg)</b>  	Yes	Go to next step
		No	Check for air leakage of intake air system components ☞ page F-93
11	Check if air cleaner element is clean ☞ page F-75	Yes	Go to next step
		No	Replace air cleaner element ☞ page F-92
12	Check for injector operating sound at idle	Yes	Go to Step 14
		No	Go to Step 13
13	Check if approx. 12V exists at injector connector (W/R) wire with ignition switch ON  	Yes	Check if injector resistance is OK ☞ page F-112  <b>Resistance: Approx. 14Ω</b>  ⇨ If OK, check wiring between ECU and injector ☞ page F-7 ⇨ If not OK, check injector for fuel leakage ☞ page F-113
		No	Check wiring between ECU and injector ☞ page F-7
14	Check if ECU terminal voltages are OK (2D, 2O and 2Q) ☞ page F-129	Yes	Go to next step
		No	Check for cause (Refer to "Check Point for Each Terminal") ☞ page F-132



STEP	INSPECTION		ACTION
15	<p>Check for correct fuel line pressure at idle   <b>page F-103</b></p> <p><b>Fuel line pressure:</b>  <b>265—314 kPa (2.7—3.2 kg/cm<sup>2</sup>, 38—46 psi)</b>  <b>(Vacuum hose to pressure regulator disconnected)</b></p>  <p>INSTALL CLAMPS</p>	Yes	<p>Check if fuel line pressure decreases when accelerating quickly</p> <ul style="list-style-type: none"> <li>⇒ If decreases, check fuel pump maximum pressure  <b>page F-108</b></li> <li>If OK, check fuel line and filter for clogging</li> <li>⇒ If no decreases, go to next step</li> </ul>
		No	<p><b>Low pressure</b>                      Check for fuel line pressure while pinching fuel return hose</p> <ul style="list-style-type: none"> <li>⇒ If fuel line pressure quickly increases, check pressure regulator  <b>page F-111</b></li> <li>⇒ If fuel line pressure gradually increases, check for clogging between fuel pump and pressure regulator</li> <li>If no clogged, check fuel pump maximum pressure  <b>page F-108</b></li> </ul>
16	<p>Run engine several minutes at idle and check if fuel line pressure is held after ignition switch turned OFF   <b>page F-102</b></p> <p><b>Fuel line pressure: More than 147 kPa (1.5 kg/cm<sup>2</sup>, 21 psi) for 5 min.</b></p>  <p>MINIMUM</p> <p>IGNITION SWITCH OFF      5 MIN.      TIME</p>	Yes	<p><b>High pressure</b>                      Check if vacuum hose to pressure regulator is damaged or poorly connected</p> <ul style="list-style-type: none"> <li>⇒ If OK, replace pressure regulator  <b>page F-112</b></li> <li>⇒ If not OK, repair or replace hose</li> </ul>
		No	<p>Check injector for fuel leakage  <b>page F-113</b></p>
17	<p>Disconnect each injector connector at idle and check if engine speed decreases equally each time</p> 	Yes	<p>Go to next step</p>
		No	<p>Replace injector  <b>page F-112</b></p>
18	<p>Try known good ECU and check if condition improves  <b>page F-127</b></p>		

26	<b>RUNS ROUGH ON DECELERATION/BACKFIRE</b>		
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>• Engine runs rough while decelerating and abnormal combustion occurs in exhaust system</li> </ul>		
<b>[TROUBLESHOOTING HINTS]</b>			
① Air/Fuel mixture too rich <ul style="list-style-type: none"> <li>• Air cleaner element clogged</li> <li>• Fuel injection control malfunction (Fuel cut control)</li> <li>• Injector fuel leakage</li> <li>• Ignition timing misadjustment</li> </ul>			
STEP	INSPECTION		ACTION
1	Check if "00" is displayed on Self-Diagnosis Checker with ignition switch ON ☞ <b>page F-78</b> 	Yes No	Yes: Go to next step No: <b>Malfunction Code No. displayed</b> Check for cause (Refer to specified check sequence) ☞ <b>page F-80</b> <b>"88" flashes</b> Check ECU terminal 1F voltage ☞ <b>page F-128</b> <b>Voltage: Approx. 12V (Ignition switch ON)</b> ⇨ If OK, replace ECU ☞ <b>page F-127</b> ⇨ If not OK, check wiring between ECU and Self-Diagnosis Checker ☞ <b>page F-7</b>
2	Check switches for correct operation with Self-Diagnosis Checker Monitor Lamp with ignition switch ON ☞ <b>page F-89</b> 	Yes No	Yes: Go to next step No: <b>Lamp not ON/OFF with specified switch</b> Check for cause (Refer to specified check sequence) ☞ <b>page F-90</b> <b>Lamp always ON</b> Check wiring between ECU terminal 1D and Self-Diagnosis Checker ☞ <b>page F-7</b>
3	Check for correct ignition timing at idle ☞ <b>page F-75</b> <b>Ignition timing: 10° ± 1° BTDC</b> 	Yes No	Yes: Go to next step No: Adjust ☞ <b>page F-75</b>




STEP	INSPECTION		ACTION
4	Check if fuel cut operation is OK during deceleration  <b>Fuel cut: Above 1,900 rpm after warm-up</b>  	Yes	Go to next step
		No	Try known good ECU <span style="float: right;">☞ page F-127</span>
5	Run engine several minutes at idle and check if fuel line pressure is held after ignition switch turned OFF  <span style="float: right;">☞ page F-102</span>  <b>Fuel line pressure: More than 147. kPa (1.5 kg/cm<sup>2</sup>, 21 psi) for 5 min.</b>   INSTALL CLAMPS	Yes	Go to next step
		No	Check injector for fuel leakage <span style="float: right;">☞ page F-113</span>
6	Check if air cleaner element is clean <span style="float: right;">☞ page F-75</span>  	Yes	Go to next step
		No	Replace <span style="float: right;">☞ page F-75</span>
7	Try known good ECU and check if condition improves <span style="float: right;">☞ page F-127</span>		








STEP	INSPECTION		ACTION
7	<p>Check for correct fuel line pressure at idle                      ☞ page F-103</p> <p><b>Fuel line pressure:</b>                      265—314 kPa (2.7—3.2 kg/cm<sup>2</sup>, 38—46 psi)                      (Vacuum hose to pressure regulator dis-                      connected)</p>  <p>INSTALL CLAMPS</p>	<p>Yes</p> <p>No</p>	<p>Check if fuel line pressure decreases when accelerating quickly</p> <ul style="list-style-type: none"> <li>⇒ If decreases, check for clogging between fuel pump and pressure regulator</li> <li>⇒ If no decrease, go to next step</li> </ul> <p><b>Low pressure</b>                      Check for fuel line pressure while pinching fuel return hose</p> <ul style="list-style-type: none"> <li>⇒ If fuel line pressure quickly increases, check pressure regulator ☞ page F-111</li> <li>⇒ If fuel line pressure gradually increases, check for clogging between fuel pump and pressure regulator</li> </ul> <p>If not clogged, check fuel pump maximum pressure ☞ page F-108</p>
8	<p>Check for correct ignition timing at idle                      ☞ page F-75</p> <p><b>Ignition timing: 10° ± 1° BTDC</b></p>  <p>GND TEN                      CONNECT TERMINALS</p>	<p>Yes</p> <p>No</p>	<p>Check if ignition timing advances when accelerating</p> <ul style="list-style-type: none"> <li>⇒ If advances, go to next step</li> <li>⇒ If no advance, replace ECU ☞ page F-127</li> </ul> <p>Adjust ☞ page F-75</p>
9	<p>Check if cooling system is OK                      ☞ page E-3</p>	<p>Yes</p> <p>No</p>	<p>Go to next step</p> <p>Repair or replace</p> <ul style="list-style-type: none"> <li>• Thermostat ☞ page E-8</li> <li>• Electric cooling fan ☞ page B-11</li> <li>• Radiator ☞ page E-7</li> </ul>
10	<p>Try known good ECU and check if condition improves                      ☞ page F-127</p>	<p>Yes</p> <p>No</p>	<p>Replace ECU</p> <p>Change fuel to another brand or use higher octane fuel</p>

05U0FX-044

28		FUEL ODOR	
<b>DESCRIPTION</b>		• Gasoline odor in cabin	
<b>[TROUBLESHOOTING HINTS]</b>			
① Poor connection or damaged fuel system or evaporative emission control system			
② Charcoal canister overflow due to evaporative emission control system malfunction			
STEP	INSPECTION		ACTION
1	Check if fuel leak or damage are visible at fuel system and evaporative emission control system	Yes	Repair or replace <span style="float:right">☞ page F-100</span>
		No	Go to next step
2	Check if "00" is displayed on Self-Diagnosis Checker with ignition switch ON <span style="float:right">☞ page F-78</span> 	Yes	Go to next step
		No	<b>Malfunction Code No. displayed</b> Check for cause (Refer to specified check sequence) <span style="float:right">☞ page F-80</span>
		<b>"88" flashes</b> Check ECU terminal 1F voltage <span style="float:right">☞ page F-128</span>  <b>Voltage: Approx. 12V (Ignition switch ON)</b>  ⇒ If OK, replace ECU <span style="float:right">☞ page F-127</span> ⇒ If not OK, check wiring between ECU and Self-Diagnosis Checker <span style="float:right">☞ page F-7</span>	
3	Check if vacuum is felt at solenoid valve (purge control) with engine running and throttle valve opened (Neutral switch connector disconnected)  	Yes	Go to Step 5
		No	Check for solenoid valve operating sound in this condition  ⇒ If OK, check vacuum hoses for clogging <span style="float:right">☞ page F-6</span> ⇒ If not OK, go to next step
4	Apply 12V and ground to solenoid valve (purge control) and check if air flows through valve  	Yes	Check ECU terminal 2X voltage <span style="float:right">☞ page F-130</span>
		No	Replace solenoid valve <span style="float:right">☞ page F-119</span>
5	Try known good ECU <span style="float:right">☞ page F-127</span>		




<b>29</b>	<b>EXHAUST SULFER SMELL</b>	
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>• Exhaust gas smells abnormal (Rotten egg smell)</li> </ul>	
<b>[TROUBLESHOOTING HINTS]</b>		
High sulfur content fuel used		
<b>STEP</b>	<b>INSPECTION</b>	<b>ACTION</b>
1	Change fuel to another brand	


05U0FX-046

<b>30</b>	<b>HIGH OIL CONSUMPTION</b>							
<b>[TROUBLESHOOTING HINTS]</b>								
① PCV system malfunction ② Engine malfunction (Oil working up, working down, or leakage)								
<b>STEP</b>	<b>INSPECTION</b>	<b>ACTION</b>						
1	Check if PCV hose, ventilation hose or their attaching nipples are separated, damaged, clogged, or restricted   <span style="float: right;">☞ page F-117</span>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 10%; text-align: center;">Yes</td> <td>Repair or replace</td> <td style="text-align: right;">☞ page F-117</td> </tr> <tr> <td style="text-align: center;">No</td> <td>Go to next step</td> <td></td> </tr> </table>	Yes	Repair or replace	☞ page F-117	No	Go to next step	
Yes	Repair or replace	☞ page F-117						
No	Go to next step							
2	Check if air pressure or oil is present at ventilation hose   AIR PRESSURE OR OIL  <span style="float: right;">☞ page F-117</span>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 10%; text-align: center;">Yes</td> <td>Go to next step</td> <td></td> </tr> <tr> <td style="text-align: center;">No</td> <td>                             Check engine condition                             <ul style="list-style-type: none"> <li>• Oil leakage</li> <li>• Worn valve seal</li> <li>• Worn valve stem</li> <li>• Worn valve guide</li> </ul> </td> <td style="text-align: right;">☞ page B-3</td> </tr> </table>	Yes	Go to next step		No	Check engine condition <ul style="list-style-type: none"> <li>• Oil leakage</li> <li>• Worn valve seal</li> <li>• Worn valve stem</li> <li>• Worn valve guide</li> </ul>	☞ page B-3
Yes	Go to next step							
No	Check engine condition <ul style="list-style-type: none"> <li>• Oil leakage</li> <li>• Worn valve seal</li> <li>• Worn valve stem</li> <li>• Worn valve guide</li> </ul>	☞ page B-3						
3	Check if vacuum is felt at PCV valve at idle   <span style="float: right;">☞ page F-117</span>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 10%; text-align: center;">Yes</td> <td>                             Check engine condition                             <ul style="list-style-type: none"> <li>• Worn piston ring groove</li> <li>• Stuck piston ring</li> <li>• Worn piston or cylinder</li> </ul> </td> <td style="text-align: right;">☞ page B-3</td> </tr> <tr> <td style="text-align: center;">No</td> <td>Replace PCV valve</td> <td style="text-align: right;">☞ page F-117</td> </tr> </table>	Yes	Check engine condition <ul style="list-style-type: none"> <li>• Worn piston ring groove</li> <li>• Stuck piston ring</li> <li>• Worn piston or cylinder</li> </ul>	☞ page B-3	No	Replace PCV valve	☞ page F-117
Yes	Check engine condition <ul style="list-style-type: none"> <li>• Worn piston ring groove</li> <li>• Stuck piston ring</li> <li>• Worn piston or cylinder</li> </ul>	☞ page B-3						
No	Replace PCV valve	☞ page F-117						


05U0FX-047





STEP	INSPECTION	ACTION	
6	Check if ECU terminal voltages are OK (2D, 2N, 2O, 2P, 2Q, 2U and 2V) ☞ page F-129	Yes	Go to next step
		No	Check for cause (Refer to "Check Point for Each Terminal") ☞ page F-132
7	Check if fuel cut operation is OK during deceleration  <b>Fuel cut: Above 1,900 rpm after warm-up</b>	Yes	Go to next step
		No	Try known good ECU ☞ page F-127
8	Check for correct ignition timing at idle ☞ page F-75  <b>Ignition timing: 10° ± 1° BTDC</b>   <p>CONNECT TERMINALS</p>	Yes	Go to next step
		No	Adjust ☞ page F-75
9	Check for correct fuel line pressure at idle ☞ page F-111  <b>Fuel line pressure: 216—265 kPa (2.2—2.7 kg/cm<sup>2</sup>; 31—38 psi)</b>   <p>INSTALL CLAMPS</p>	Yes	Go to next step
		No	<b>High pressure</b> Check if vacuum hose to pressure regulator is damaged or poorly connected  ⇨ If OK, replace pressure regulator ☞ page F-112 ⇨ If not OK, repair or replace hose
10	Run engine several minutes at idle and check if fuel line pressure is held after ignition switch turned OFF ☞ page F-102  <b>Fuel line pressure: More than 147 kPa (1.5 kg/cm<sup>2</sup>, 21 psi) for 5 min.</b>   <p>MINIMUM</p> <p>IGNITION SWITCH OFF 5 MIN. TIME</p>	Yes	Go to next step
		No	Check injector for fuel leakage ☞ page F-113
11	Change fuel to another brand		

32		MIL ALWAYS ON	
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>• Self-Diagnosis Checker does not indicate Malfunction Code No. but MIL always ON</li> </ul>		
<b>[TROUBLESHOOTING HINTS]</b>			
<ul style="list-style-type: none"> <li>• Short circuit in wiring harness</li> <li>• ECU malfunction</li> </ul>			
STEP	INSPECTION		ACTION
1	Disconnect (Y/B) wire from ECU and check if MIL goes off  	Yes	Replace ECU <span style="float: right;">☞ page F-127</span>
		No	Check for short circuit in wiring between combination meter and ECU <span style="float: right;">☞ page F-8</span>

05U0FX-049

33		MIL NEVER ON	
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>• Self-Diagnosis Checker indicates Malfunction code No. of input device but MIL never ON</li> <li>• Other indicator and warning lamps OK</li> </ul>		
<b>[TROUBLESHOOTING HINTS]</b>			
<ul style="list-style-type: none"> <li>• Bulb burned out</li> <li>• Open circuit in wiring harness</li> <li>• ECU malfunction</li> </ul>			
STEP	INSPECTION		ACTION
1	Ground (Y/B) wire at ECU with jumper wire and check if MIL comes on  	Yes	Check connection condition of ECU connector <span style="float: right;">☞ page F-128</span>  ⇨ If OK, replace ECU <span style="float: right;">☞ page F-127</span> ⇨ If not OK, repair ECU connector <span style="float: right;">☞ page F-127</span>
		No	Check if bulb is OK  ⇨ If OK, repair (Y/B) wire between ECU and combination meter <span style="float: right;">☞ page F-8</span> ⇨ If not OK, replace bulb <span style="float: right;">☞ page T-33</span>

05U0FX-050


34	A/C DOES NOT WORK		
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>• Blower fan operates but cool air not expelled</li> </ul>		
	<p><b>[TROUBLESHOOTING HINTS]</b></p> <ul style="list-style-type: none"> <li>• Open or short circuit in wiring harness</li> <li>• A/C relay malfunction</li> <li>• A/C switch malfunction</li> <li>• Magnetic clutch malfunction</li> <li>• ECU malfunction</li> </ul>		
STEP	INSPECTION		ACTION
1	Ground (L/B) wire at A/C relay with jumper wire and check if condenser fan operates when ignition switch turned ON  	Yes	Go to next step
		No	Go to A/C system Troubleshooting <b>page U-4</b>
2	Ground (L/B) wire at ECU with jumper wire and check if condenser fan operates when ignition switch turned ON  	Yes	Go to next step
		No	Repair (L/B) wire between ECU and A/C relay <b>page F-7</b>
3	Check if A/C switch is OK <b>page U-25</b>	Yes	Try known good ECU <b>page F-127</b>
		No	Check A/C switch and wiring <b>page U-25</b>

05U0FX-051


### ENGINE TUNE-UP

#### PREPARATION

##### SST

<p>49 B019 9A0 System Selector</p>		<p>For inspection of ignition timing and idle speed.</p>
--	---	--

05U0FX-052



05U0FX-053

#### BASIC INSPECTION Engine Oil

1. Be sure the vehicle is on level ground.
2. Warm up the engine to normal operating temperature and stop it.
3. Wait for five minutes.
4. Remove the oil level gauge and check the oil level and condition.
5. Add or replace oil if necessary.

#### Note

- The distance between the L and F marks on the level gauge represents 0.8 liter (0.85 US qt, 0.70 Imp qt).




05U0FX-054

#### Coolant Level (Cold engine)

#### Warning

- Never remove the radiator cap while the radiator and engine are hot.
- Wrap a thick cloth around the cap while carefully removing it.


1. Verify that the coolant level is at the bottom of the radiator filler neck.
2. Verify that the level in the coolant reservoir is between the FULL and LOW marks. Add coolant if necessary.



05U0FX-055

#### Battery


1. Check for loose or corroded terminals and connections.
2. Clean and tighten the connections as necessary.



05U0FX-056

3. Measure the battery voltage. If the voltage is **12.6V or less**, recharge the battery. (Refer to Section G.)






05U0FX-057

**Air Cleaner Element**

**Caution**

- Do not clean the air cleaner element with compressed air.

Visually check the air cleaner element for excessive dirt, damage, or oil. Replace if necessary.



POWER CONNECTOR  
(BLUE: 1-PIN)

05U0FX-058

**ADJUSTMENT**

**Preparation**



1. Check the condition of the engine (spark plugs, leaks in hoses, etc.).
2. Make sure all accessories are OFF.
3. Warm up the engine to normal operating temperature.

**Note**

- When using an externally powered timing light and/or tachometer connect it to the power connector (Blue: 1-pin).

**Warning**

- Do not ground the power connector terminal (Blue: 1-pin); the wiper 20A fuse will be burned.




05U0FX-059

4. Connect a timing light and tachometer to the diagnosis connector terminal IG-.


**Ignition Timing**

**Caution**

- Be extremely careful when making connections to the diagnosis connector as a mistaken connection will cause a malfunction.




49 B019 9A0



05U0FX-060

1. Connect the **SST** and set the TEST SW to "SELF TEST" or connect diagnosis connector terminals TEN and GND with a jumper wire.
2. Check the idle speed, and set it to specification if necessary. (Refer to page F-76.)


**Idle speed: 850 ± 50 rpm**



05U0FX-061

3. Verify that the timing mark (Yellow) on the crankshaft pulley and the timing belt cover are aligned.

**Ignition timing: 10° ± 1° BTDC (at idle)**




05U0FX-062

4. If the marks are not aligned, loosen the crank angle sensor lock bolt, and turn the crank angle sensor to make the adjustment.
5. Tighten the crank angle sensor lock bolt to the specified torque.

**Tightening torque:**


**19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)**



05U0FX-063

6. After adjusting the ignition timing, disconnect the **SST** or jumper wire from the diagnosis connector.

7. Increase the engine speed and verify that the ignition timing advances.




05U0FX-064

**Idle Speed**

1. Connect the **SST** and set the TEST SW to "SELF TEST" or connect diagnosis connector terminals TEN and GND with a jumper wire.

2. Verify that the idle speed is within specification.

**Idle speed: 850 ± 50 rpm**



05U0FX-065

3. If the idle speed is not within specification, remove the blind cap from the air adjusting screw and adjust it.
4. After adjusting the idle speed, install the blind cap and disconnect the **SST** or jumper wire from the diagnosis connector.


SELF-DIAGNOSIS FUNCTION

DESCRIPTION



When troubles occur in the main input devices or output devices, check for the cause using the **SST**. Failures of each input and output device are indicated and retrieved from the engine control unit as malfunction code numbers.

Note


- The engine control unit constantly checks for malfunction of the input devices.
- But, the engine control unit checks for malfunction of output devices only in a 3 second period after the ignition switch is turned ON and the diagnosis connector terminal (TEN) is grounded.




### PREPARATION SST

<p>49 H018 9A1</p> <p>Self-Diagnosis Checker</p> 	<p>For diagnosis</p>	<p>49 B019 9A0</p> <p>System Selector</p> 	<p>For diagnosis</p>
--	----------------------	--	----------------------


05U0FX-067



05U0FX-068



05U0FX-069



05U0FX-070

### MALFUNCTION CODE NUMBER

#### Caution

- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to page T-113.)

#### Inspection procedure

1. Connect the **SSTs** to the diagnosis connector and a ground.
2. Set the select switch to position A.
3. Set the System Selector to position 1 and SELF TEST as shown.
4. Turn the ignition switch ON.
5. Verify that **88** flashes on the digital display and that the buzzer sounds for **3 sec.** after turning the ignition switch ON.
6. If **88** does not flash, check the main relay, (Refer to page F-139.) power supply circuit, and check connector wiring.
7. If **88** flashes and the buzzer continues for more than **20 sec.**, check for a short circuit between the engine control unit terminal 1F and the diagnosis connector. Replace the engine control unit if necessary and perform Steps 3 and 4 again.
8. Note any code numbers and check for the causes by referring to the check sequences shown on pages F-81 to F-87. Repair as necessary.

#### Note

- Cancel the code numbers by performing the after-repair procedure following repairs. (Refer to page F-88.)


## Principle of Code Cycle

Malfunction codes are determined as shown below.

05U0FX-071

### 1. Code cycle break


The time between malfunction code cycles is 4.0 seconds (the time the lamp is off).



05U0FX-072

### 2. Second digit of malfunction code (ones position)

The digit in the ones position of the malfunction code represents the number of times the buzzer sounds 0.4 second during one cycle.




05U0FX-073

### 3. First digit of malfunction code (tens position)












The digit in the tens position of the malfunction code represents the number of times the buzzer is on 1.2 seconds during one cycle.

It should also be noted that the light goes off for 1.6 seconds between the long and short pulses of the buzzer.



05U0FX-074

### Code Numbers

Malfunction display		Sensor or subsystem	Self-diagnosis	Fail-safe
Code No.	Pattern of output signal (Self-Diagnosis Checker)			
01	ON OFF 	Ignition pulse	No IGf-signal	—
02	ON OFF 	Ne-signal	No Ne-signal	—
03	ON OFF 	G-signal	No G-signal	—
08	ON OFF 	Airflow meter	Open or short circuit	Basic fuel injection amount fixed as for two driving modes (1) Idle switch: ON (2) Idle switch: OFF
09	ON OFF 	Water thermosensor	Open or short circuit	Maintains constant 20°(68°F) command
10	ON OFF 	Intake air thermosensor (Airflow meter)	Open or short circuit	Maintains constant 20°C (68°F) command
14	ON OFF 	Atmospheric pressure sensor	Open or short circuit	Maintains constant command of sea level pressure
15	ON OFF 	Oxygen sensor	Sensor output continues less than 0.45V 180 sec. after engine exceeds 1,500 rpm	Cancels engine feedback operation
17	ON OFF 	Feedback system	Sensor output continues unchanged 20 sec. after engine exceeds 1,500 rpm	Cancels engine feedback operation
26	ON OFF 	Solenoid valve (Purge control)	—	—
34	ON OFF 	ISC valve		—

05U0FX-075

#### Caution

- If there is more than one failure present, the lowest number malfunction code is displayed first, the remaining codes are displayed in order.
- After repairing all failures, turn off the ignition switch, disconnect the negative battery cable, and depress the brake pedal for 5 seconds to erase the memory of a malfunction code from the engine control unit.


## Troubleshooting

If a malfunction code number is shown on the **SST**, check for the cause by using the chart related to the code number shown.

<b>CODE NO.01 IGF-SIGNAL</b>									
STEP	INSPECTION	ACTION							
1	Are there any poor connections at ignition coil connectors and igniter connectors?	Yes	Repair or replace connector						
		No	Go to next step						
2	Does tachometer operates?	Yes	Go to next step						
		No	Check for open circuit in wiring from igniter to ECU terminal 2I						
3	Is resistance of ignition coil OK? Resistance: Primary 0.78—0.94Ω Secondary 11.2—15.2 kΩ	Yes	Go to next step						
		No	Replace ignition coil (Refer to page G-21)						
4	Is there continuity between ignition coil and igniter?  <table border="1" style="margin: 5px auto; border-collapse: collapse; text-align: center;"> <tr> <td style="padding: 2px;">Ignition coil</td> <td style="padding: 2px;">Igniter</td> </tr> <tr> <td style="padding: 2px;">A (W)</td> <td style="padding: 2px;">A (W)</td> </tr> <tr> <td style="padding: 2px;">B (Y)</td> <td style="padding: 2px;">H (Y)</td> </tr> </table>	Ignition coil	Igniter	A (W)	A (W)	B (Y)	H (Y)	Yes	Go to next step
		Ignition coil	Igniter						
A (W)	A (W)								
B (Y)	H (Y)								
No	Check for open circuit in wiring from ignition coil to igniter								
5	Is ignition coil terminal wire (L) voltage OK? (Refer to page G-21)	Yes	Go to next step						
		No	Check for open circuit in wiring from ignition coil to ignition switch						
6	Is igniter terminal-wire (L) voltage OK? (Refer to page G-22)	Yes	Go to next step						
		No	Check for open circuit in wiring from igniter to ignition switch						
7	Is there continuity between igniter and ground?	Yes	Go to next step						
		No	Check for open circuit in wiring from igniter to ground						
8	Check igniter (Refer to page G-22)	Yes	Replace ECU (Refer to page F-127)						
		No	Replace igniter (Refer to page G-22)						

05U0FX-076

## Circuit Diagram



05U0FX-077

CODE NO.02 Ne-SIGNAL							
STEP	INSPECTION	ACTION					
1	Are there any poor connections in crank angle sensor circuit?	Yes	Repair or replace connector				
		No	Go to next step				
2	Is Code No.03 present at same time?	Yes	Go to next step				
		No	Go to Step 5				
3	Is there continuity between crank angle sensor terminal-wire (B/LG) and ground?	Yes	Go to next step				
		No	Check for open circuit in wiring from crank agnle sensor to ground				
4	Is there battery voltage at crank angle sensor terminal-wire (W/R)?	Yes	Go to next step				
		No	Check for open circuit in wiring from crank angle sensor to main relay				
5	Is there continuity between crank angle sensor and ECU?	Yes	Go to next step				
		No	Check for open circuit in wiring from crank angle sensor to ECU				
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%; text-align: center;">Crank angle sensor</td> <td style="width: 50%; text-align: center;">ECU</td> </tr> <tr> <td style="text-align: center;">C (W)</td> <td style="text-align: center;">2E</td> </tr> </table>		Crank angle sensor	ECU	C (W)	2E		
Crank angle sensor	ECU						
C (W)	2E						
6	Is there approx. 5V at ECU terminal 2E? (With crank angle sensor connector disconnected)	Yes	Go to next step				
		No	Replace ECU (Refer to page F-127)				
7	Is there approx. 5V at crank angle sensor terminal-wire (W)? (At harness-side connector with connector disconnected)	Yes	Replace crank angle sensor (Refer to page F-134)				
		No	Check for short circuit in wiring from crank angle sensor to ECU				


05U0FX-078

CODE NO.03 G-SIGNAL							
STEP	INSPECTION	ACTION					
1	Are there any poor connections in crank angle sensor circuit?	Yes	Repair or replace connector				
		No	Go to next step				
2	Is Code No.02 also present?	Yes	Go to next step				
		No	Go to Step 5				
3	Is there continuity between crank angle sensor terminal-wire (B/LG) and ground?	Yes	Go to next step				
		No	Check for open circuit in wiring from crank angle sensor to ground				
4	Is there battery voltage at crank angle sensor terminal-wire (W/R)?	Yes	Go to next step				
		No	Check for open circuit in wiring from crank angle sensor to main relay				
5	Is there continuity between crank angle sensor and ECU?	Yes	Go to next step				
		No	Check for open circuit in wiring from crank angle sensor to ECU				
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%; text-align: center;">Crank angle sensor</td> <td style="width: 50%; text-align: center;">ECU</td> </tr> <tr> <td style="text-align: center;">D (Y/L)</td> <td style="text-align: center;">2G</td> </tr> </table>		Crank angle sensor	ECU	D (Y/L)	2G		
Crank angle sensor	ECU						
D (Y/L)	2G						
6	Is there approx. 5V at ECU terminal 2E? (With crank angle sensor connector disconnected)	Yes	Go to next step				
		No	Replace ECU (Refer to page F-127)				
7	Is there approx. 5V at crank angle sensor terminal-wire (Y/L)? (At harness-side connector with connector disconnected)	Yes	Replace crank angle sensor (Refer to page F-134)				
		No	Check for short circuit in wiring from crank angle sensor to ECU				

05U0FX-079



Circuit Diagram




05U0FX-080

CODE NO.08 AIRFLOW METER												
STEP	INSPECTION	ACTION										
1	Are there any poor connections in airflow meter circuit?	Yes	Repair or replace connector									
		No	Go to next step									
2	Is Code No.10 present at same time?	Yes	Check for open circuit in wiring from airflow meter terminal-wire (B/LG) to ground									
		No	Go to next step									
3	Is resistance of airflow meter OK?	Yes	Go to next step									
		No	Replace airflow meter (Refer to page F-135)									
<table border="1"> <thead> <tr> <th>Airflow meter</th> <th>Fully closed <math>\Omega</math></th> <th>Fully open <math>\Omega</math></th> </tr> </thead> <tbody> <tr> <td>D (LG/R)-F (G/Y)</td> <td>200-600</td> <td>20-1,000</td> </tr> <tr> <td>D (LG/R)-C (B/LG)</td> <td colspan="2">200-400</td> </tr> </tbody> </table>		Airflow meter	Fully closed $\Omega$	Fully open $\Omega$	D (LG/R)-F (G/Y)	200-600	20-1,000	D (LG/R)-C (B/LG)	200-400			
Airflow meter	Fully closed $\Omega$	Fully open $\Omega$										
D (LG/R)-F (G/Y)	200-600	20-1,000										
D (LG/R)-C (B/LG)	200-400											
4	Is there continuity between airflow meter connector and ECU?	Yes	Go to next step									
		No	Check for open circuit in wiring from airflow meter to ECU									
<table border="1"> <thead> <tr> <th>Airflow meter</th> <th>ECU</th> </tr> </thead> <tbody> <tr> <td>D (LG/R)</td> <td>2K</td> </tr> <tr> <td>F (G/Y)</td> <td>2O</td> </tr> </tbody> </table>		Airflow meter	ECU	D (LG/R)	2K	F (G/Y)	2O					
Airflow meter	ECU											
D (LG/R)	2K											
F (G/Y)	2O											
5	Are ECU terminals 2D and 2K voltages OK? (Refer to page F-129)	Yes	Replace ECU (Refer to page F-127)									
		No	Check for short circuit in wiring from airflow meter to ECU									

05U0FX-081

### Circuit Diagram



05U0FX-082

<b>CODE NO.09 WATER THERMOSENSOR</b>											
<b>STEP</b>	<b>INSPECTION</b>	<b>ACTION</b>									
1	Are there any poor connections in water thermosensor circuit?	Yes	Repair or replace connector								
		No	Go to next step								
2	Is there continuity between water thermosensor and ECU?  <table border="1" style="width:100%; border-collapse: collapse;"> <tr> <td style="width:50%;">Water thermosensor</td> <td style="width:50%;">ECU</td> </tr> <tr> <td>A (L/W)</td> <td>2Q</td> </tr> <tr> <td>B (B/LG)</td> <td>2D</td> </tr> </table>	Water thermosensor	ECU	A (L/W)	2Q	B (B/LG)	2D	Yes	Go to next step		
		Water thermosensor	ECU								
A (L/W)	2Q										
B (B/LG)	2D										
		No	Check for open circuit in wiring from water thermosensor to ECU								
3	Is resistance of water thermosensor OK?  <table border="1" style="width:100%; border-collapse: collapse;"> <tr> <td style="width:50%;">Coolant temp.</td> <td style="width:50%;">Resistance</td> </tr> <tr> <td>-20°C ( -4°F)</td> <td>14.6—17.8 kΩ</td> </tr> <tr> <td>20°C ( 68°F)</td> <td>2.2—2.7 kΩ</td> </tr> <tr> <td>80°C (176°F)</td> <td>290—350Ω</td> </tr> </table>	Coolant temp.	Resistance	-20°C ( -4°F)	14.6—17.8 kΩ	20°C ( 68°F)	2.2—2.7 kΩ	80°C (176°F)	290—350Ω	Yes	Go to next step
		Coolant temp.	Resistance								
-20°C ( -4°F)	14.6—17.8 kΩ										
20°C ( 68°F)	2.2—2.7 kΩ										
80°C (176°F)	290—350Ω										
		No	Replace water thermosensor (Refer to page F-139)								
4	Is same Code No. present after performing after-repair procedure? (Refer to page F-88)	Yes	Go to next step								
		No	Water thermosensor and circuit OK								
5	Are ECU terminals 2Q and 2D voltages OK? (Refer to page F-129)	Yes	Replace ECU (Refer to page F-127)								
		No	Check for short circuit in wiring from water thermosensor to ECU								

05U0FX-083

<b>CODE NO.10 INTAKE AIR THERMOSENSOR (IN AIRFLOW METER)</b>													
<b>STEP</b>	<b>INSPECTION</b>	<b>ACTION</b>											
1	Are there any poor connections in intake air thermosensor circuit?	Yes	Repair or replace connector										
		No	Go to next step										
2	Is there continuity between intake air thermosensor (in airflow meter) and ECU?  <table border="1" style="width:100%; border-collapse: collapse;"> <tr> <td style="width:50%;">Intake air thermosensor</td> <td style="width:50%;">ECU</td> </tr> <tr> <td>C (B/LG)</td> <td>2D</td> </tr> <tr> <td>G (R/G)</td> <td>2P</td> </tr> </table>	Intake air thermosensor	ECU	C (B/LG)	2D	G (R/G)	2P	Yes	Go to next step				
		Intake air thermosensor	ECU										
C (B/LG)	2D												
G (R/G)	2P												
		No	Check for open circuit in wiring from intake air thermosensor (in airflow meter) to ECU										
3	Is resistance of intake air thermosensor (in airflow meter) OK?  <table border="1" style="width:100%; border-collapse: collapse;"> <tr> <td style="width:25%;">Terminal</td> <td style="width:25%;">Temperature</td> <td style="width:50%;">Resistance</td> </tr> <tr> <td rowspan="3">C (B/RG) -G (R/G)</td> <td>-20°C ( -4°F)</td> <td>13.6—18.4 kΩ</td> </tr> <tr> <td>20°C ( 68°F)</td> <td>2.21—2.69 kΩ</td> </tr> <tr> <td>60°C (140°F)</td> <td>493—667Ω</td> </tr> </table>	Terminal	Temperature	Resistance	C (B/RG) -G (R/G)	-20°C ( -4°F)	13.6—18.4 kΩ	20°C ( 68°F)	2.21—2.69 kΩ	60°C (140°F)	493—667Ω	Yes	Go to next step
		Terminal	Temperature	Resistance									
C (B/RG) -G (R/G)	-20°C ( -4°F)	13.6—18.4 kΩ											
	20°C ( 68°F)	2.21—2.69 kΩ											
	60°C (140°F)	493—667Ω											
		No	Replace airflow meter (Refer to page F-135)										
4	Is same Code No. present after performing after-repair procedure? (Refer to page F-88)	Yes	Go to next step										
		No	Intake air thermosensor and circuit OK										
5	Are engine control unit terminals 2P and 2D voltages OK? (Refer to page F-129)	Yes	Replace ECU (Refer to page F-127)										
		No	Check for short circuit in wiring from intake air thermosensor to ECU										

05U0FX-084

<b>CODE NO.14 ATMOSPHERIC PRESSURE SENSOR</b>	
Replace ECU (Refer to page F-127)	

05U0FX-085


CODE NO.15 OXYGEN SENSOR			
Note			
• If Code Nos.15 and 17 are both present, first perform the checking procedure for Code No.17			
STEP	INSPECTION	ACTION	
1	Are there any poor connections in oxygen sensor circuit?	Yes	Repair or replace connector
		No	Go to next step
2	Is oxygen sensor output voltage OK? (Refer to page F-138)	Yes	Go to next step
		No	Replace oxygen sensor (Refer to page F-138)
3	Is there continuity between oxygen sensor and ECU terminal 2N?	Yes	Go to next step
		No	Check for open circuit in wiring from oxygen sensor to ECU
4	Is ECU terminal 2N voltage OK?	Yes	Go to next step
		No	Check for short circuit in wiring from oxygen sensor to ECU
5	Is sensitivity of oxygen sensor OK? (Refer to page F-138)	Yes	Replace ECU (Refer to page F-127)
		No	Replace oxygen sensor (Refer to page F-138)

05U0FX-086

CODE NO.17 FEEDBACK SYSTEM			
STEP	INSPECTION	ACTION	
1	Warm up engine and run it at 2,500—3,000 rpm for 3 min.		
2	Does monitor lamp of Self-Diagnosis Checker illuminate at idle?	Yes	Go to next step
		No	Check for air leak in vacuum hoses or emission components Check for contaminated oxygen sensor Check for insufficient fuel injection
3	Are spark plugs clean?	Yes	Go to next step
		No	Clean or replace spark plugs
4	Is oxygen sensor voltage OK? (Refer to page F-138)	Yes	Go to next step
		No	Replace oxygen sensor (Refer to page F-138)
5	Is same Code No. present after performing after-repair procedure? (Refer to page F-88)	Yes	Go to next step
		No	Check for short circuit in wiring from oxygen sensor to ECU terminal 2N
6	Is there continuity between oxygen sensor and ECU terminal 2N?	Yes	Go to next step
		No	Check for open circuit in wiring from oxygen sensor to ECU
7	Is ECU terminal 2N voltage OK? (Refer to page F-127)	Yes	Replace ECU (Refer to page F-127)
		No	Check for short circuit in wiring from oxygen sensor to ECU

05U0FX-087

### Circuit Diagram



05U0FX-088


CODE NO.26 SOLENOID VALVE (PURGE CONTROL)							
STEP	INSPECTION	ACTION					
1	Are there any poor connections in solenoid valve circuit?	Yes	Repair or replace connector				
		No	Go to next step				
2	Is resistance of solenoid valve OK? <b>Resistance: 25 ± 2Ω</b>	Yes	Go to next step				
		No	Replace solenoid valve (Refer to page F-119)				
3	Is there battery voltage at terminal wire (W/R) of solenoid valve circuit?	Yes	Go to next step				
		No	Check for open circuit in wiring from solenoid valve to main relay				
4	Is there continuity between solenoid valve and ECU? <table border="1" style="margin: 5px auto; border-collapse: collapse; text-align: center;"> <tr> <td style="padding: 2px 10px;">Solenoid valve</td> <td style="padding: 2px 10px;">ECU</td> </tr> <tr> <td style="padding: 2px 10px;">B (Y/R)</td> <td style="padding: 2px 10px;">2X</td> </tr> </table>	Solenoid valve	ECU	B (Y/R)	2X	Yes	Go to next step
		Solenoid valve	ECU				
B (Y/R)	2X						
No	Check for open circuit in wiring from solenoid valve to ECU						
5	Is ECU terminal (2X) voltage OK? (Refer to page F-130)	Yes	Replace ECU (Refer to page F-127)				
		No	Check for short circuit in wiring from solenoid valve to ECU				

05U0FX-089


CODE NO.34 ISC VALVE							
STEP	INSPECTION	ACTION					
1	Are there any poor connections in ISC valve circuit?	Yes	Repair or replace connector				
		No	Go to next step				
2	Is resistance of ISC valve OK? <b>Resistance: 12 ± 1Ω</b>	Yes	Go to next step				
		No	Replace ISC valve (Refer to page F-99)				
3	Is there battery voltage at terminal-wire (W/R) of ISC valve circuit?	Yes	Go to next step				
		No	Check for open circuit in wiring from ISC valve to main relay				
4	Is there continuity between ISC valve and ECU? <table border="1" style="margin: 5px auto; border-collapse: collapse; text-align: center;"> <tr> <td style="padding: 2px 10px;">ISC valve</td> <td style="padding: 2px 10px;">ECU</td> </tr> <tr> <td style="padding: 2px 10px;">B (L/O)</td> <td style="padding: 2px 10px;">2W</td> </tr> </table>	ISC valve	ECU	B (L/O)	2W	Yes	Go to next step
		ISC valve	ECU				
B (L/O)	2W						
No	Check for open circuit in wiring from ISC valve to ECU						
5	Is ECU terminal 2W voltage OK? (Refer to page F-130)	Yes	Replace ECU (Refer to page F-127)				
		No	Check for short circuit in wiring from ISC valve to ECU				

05U0FX-090


### Circuit Diagram



05U0FX-091



05U0FX-092




05U0FX-093

**After-repair Procedure**

1. Cancel the memory of malfunctions by disconnecting the negative battery cable and depressing the brake pedal for **at least five seconds**. Reconnect the negative battery cable.
2. Connect the **SSTs** to the diagnosis connector as shown.
3. Turn the ignition switch ON, but do not start the engine for **six seconds**.
4. Start and warm up the engine, then run it at **2,000 rpm for three minutes**.
5. Verify that no code numbers are displayed.


**SWITCH MONITOR FUNCTION**  
**Inspection Procedure**



05U0FX-094

Switch	Self-Diagnosis Checker (Monitor lamp)		Remark
	Light ON	Light OFF	
Clutch switch	Pedal released	Pedal depressed	In gear
Neutral switch	In gear	Neutral	Clutch pedal released
Idle terminal	Pedal depressed (not fully)	Pedal released	—
Pow. terminal	Pedal depressed (not fully)	Pedal fully depressed	—
Stoplight switch	Pedal depressed	Pedal released	—
Headlight switch	ON	OFF	—
Blower switch	ON	OFF	Blower motor position: "medium" "high" or "super high" position
A/C switch	ON	OFF	Fan speed control: Low position
Water thermoswitch	Fan operating	Fan not operating	

05U0FX-095




05U0FX-096

1. Connect the **SSTs** to the diagnosis connector as shown.
2. Turn the ignition switch ON. Check if the monitor lamp illuminates when each switch is made to function as described below.


**Caution**

- If either of the switches remain activated, the monitor lamp will be illuminated.
- Do not start the engine.


### Procedure




### Neutral and Clutch switches




### Idle terminal



### Pow terminal




### Stoplight switch






### Headlight switch




05U0FX-102

### Blower switch



05U0FX-103

### A/C switch




05U0FX-104

### Water thermostwitch circuit (not included in switch inspection)

#### Warning

- The cooling fan operates when the diagnosis connector terminals TFA and GND are connected a jumper wire. Use caution.



05U0FX-237

### INTAKE AIR SYSTEM

#### COMPONENTS

#### Removal / Inspection / Installation


##### Warning

- Before removing the intake manifold, release the fuel pressure from the fuel system to reduce the possibility of injury or fire. (Refer to page F-101.)

##### Note

- Before disconnecting the water hoses, drain the engine coolant.
- Use new gaskets during reassembly.

1. Remove in the order shown in the figure.
2. Check the components for damage and repair or replace as necessary.
3. Install in the reverse order of removal.




05U0FX-105


- |                                |           |
|--------------------------------|-----------|
| 1. Air duct                    |           |
| 2. Air cleaner                 |           |
| Inspection .....               | page F-73 |
| 3. Airflow meter               |           |
| Inspection / Replacement ..... | page F-92 |
| 4. Air hose                    |           |
| 5. Resonance chamber           |           |
| 6. Air pipe                    |           |
| 7. Accelerator pedal/cable     |           |
| Inspection / Replacement ..... | page F-96 |
| 8. Throttle body               |           |
| Removal / Inspection /         |           |
| Installation .....             | page F-94 |
| 9. Intake manifold             |           |
| Removal / Installation .....   | page F-95 |

## SYSTEM OPERATION


### Inspection of Air Leakage

Check for possible air leakage at the points shown and repair or replace as necessary.







05U0FX-107




05U0FX-108



05U0FX-109



05U0FX-110



05U0FX-111

## THROTTLE BODY

### Caution

- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to page T-113.)

### Removal

1. Remove the negative battery terminal.
2. Remove the air pipe.
3. Remove the accelerator cable from the throttle lever.

### Note

- Before disconnecting the water hoses, drain the engine coolant.

4. Disconnect the water hoses.
5. Disconnect the connectors for the ISC valve and the throttle sensor.
6. Remove the throttle body.

### Inspection

1. Verify that the throttle valve is fully closed.
2. Verify that the throttle valve moves smoothly when the throttle lever is moved from fully closed to fully open.
3. Replace the throttle body if necessary.

### Caution

- Do not remove the thin seal coating from the throttle valve or bore.

### Installation


Install in the reverse order of removal.

### Note


- Use a new mounting gasket.

### Tightening torque:


19–25 N·m (1.9–2.6 m·kg, 14–19 ft·lb)



05U0FX-112



05U0FX-113



05U0FX-114

## INTAKE MANIFOLD

### Removal

#### Warning

- Before removal, release the fuel pressure from the fuel system to reduce the possibility of injury or fire. (Refer to page F-101.)

1. Remove the throttle body. (Refer to page F-94.)
2. Remove the air valve
3. Disconnect the vacuum hoses.

4. Remove the accelerator cable.
5. Disconnect the fuel hoses.
6. Disconnect the connectors from the injectors.
7. Remove the delivery pipe and injectors.
8. Remove the injector harness.

8. Remove the intake manifold bracket.
9. Remove the intake manifold.

### Installation

Install in the reverse order of removal.

#### Note

- Use a new mounting gasket.


#### Tightening torque:

Intake manifold and delivery pipe


19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)

Injector harness and bracket

7.8—11 N·m (80—110 cm·kg, 69—95 in·lb)



05U0FX-115



05U0FX-116

## ACCELERATOR PEDAL AND CABLE

### Accelerator Cable

#### Inspection


1. Check deflection of the cable. If deflection exceeds **1—3mm (0.039—0.118 in)**, adjust it by turning nut A.
2. Depress the accelerator pedal to the floor and verify that the throttle valve opens fully. Adjust with bolt B if necessary.

#### Replacement

1. Remove the accelerator cable from the throttle lever.
2. Loosen the throttle adjustment nuts and remove the cable from the bracket.
3. Compress the tabs of stay C and remove the accelerator cable from the pedal arm.
4. Compress the tabs of stay D and push the cable through the firewall.
5. Remove the accelerator cable.
6. Install in the reverse order of removal.
7. Adjust deflection of the cable after installation. (Refer to above.)


### Accelerator Pedal Replacement

1. Disconnect the accelerator cable.
2. Remove the accelerator pedal as shown in the figure.
3. Install in the reverse order of removal.



**IDLE SPEED CONTROL (ISC) SYSTEM**

**DESCRIPTION**




05U0FX-118


To improve idle smoothness, the ISC system controls the intake air amount by regulating amount of the bypass air that passes through the throttle valve. This system consists of the air valve that functions only when the engine is cold, the ISC valve that works throughout the entire engine speed range, and the control system.

## PREPARATION


## SST




05U0FX-119




05U0FX-120



05U0FX-121



05U0FX-122



05U0FX-123

## SYSTEM OPERATION

## Air Valve

—Perform this inspection when the engine is cold. (Engine coolant temperature below 20°C [68°F].)

## Note

- When using an externally powered tachometer connect it to the power connector (Blue: 1-pin).

## Warning

- Do not ground the power connector terminal (Blue: 1-pin); the wiper 20A fuse will be burned.

1. Connect a tachometer to the diagnosis connector terminal IG-.

## Caution

- Be extremely careful when making connections to the diagnosis connector as a mistaken connection will cause a malfunction.

2. Connect the **SST** and set the TEST SW to "SELF TEST" or connect diagnosis connector terminals TEN and GND with a jumper wire.
3. Verify that the engine speed gradually decreases as the engine warms up.
4. Remove the **SST** or the jumper wire.

## ISC Valve

1. Warm up the engine to the normal operating temperature and run it at idle.
2. Disconnect the ISC valve connector (Black: 2-pin) and verify that the valve clicks and the engine speed increases to **approx. 1,200 rpm**.
3. Reconnect the ISC valve connector.

## AIR VALVE


## Removal

## Note

- Before disconnecting the water hoses, drain the engine coolant.

1. Disconnect the water hoses.
2. Remove the air valve from the intake manifold.






05U0FX-124

## Inspection

1. Cool the air valve to **0°C (31°F)**.
2. Mark the shaft.
3. Warm the air valve with a hot air gun and verify that the shaft moves in the direction of arrow.
4. Replace the air valve if necessary.



05U0FX-125

## Installation


### Note

- Install a new gasket.

Install in the reverse order of removal.

### Tightening torque:

**4.9—7.8 N·m (50—80 cm·kg, 43—69 in·lb)**



05U0FX-126


## ISC VALVE

### Inspection

1. Disconnect the ISC valve connector.
2. Connect an ohmmeter between the terminals of the ISC valve and measure the resistance.

**Resistance (at 20°C [68°F]): 12 ± 1Ω**

3. If not as specified, replace the ISC valve.



05U0FX-127


## Replacement

1. Disconnect the ISC valve connector.
2. Remove the air pipe.

### Note

- Before disconnecting the water hose, drain the engine coolant.

3. Disconnect the water hose and the air hose.



05U0FX-128

4. Remove the ISC valve.

### Note

- Install a new gasket.

5. Install in the reverse order of removal.


### Tightening torque:

**2.8—4.0 N·m (29—41 cm·kg, 25—35 in·lb)**

### FUEL SYSTEM

#### DESCRIPTION


This system supplies the necessary fuel for combustion at a constant pressure to the fuel injectors. Fuel is metered and injected into the intake manifold according to the injection control signals from the engine control unit. The system consists of the fuel tank, the fuel pump, the fuel filters, the delivery pipe, the pressure regulator, the injectors, and the circuit opening relay.




05U0FX-129

- 1. Fuel tank  
Removal / Inspection /  
Installation ..... page F-104
- 2. Fuel filter  
Replacement..... page F-106
- 3. Fuel pump  
Inspection ..... page F-107  
Replacement..... page F-108
- 4. Delivery pipe


- 5. Circuit opening relay  
Inspection ..... page F-110  
Replacement..... page F-110
- 6. Pressure regulator  
Inspection ..... page F-111  
Replacement..... page F-111
- 7. Injector  
Inspection ..... page F-112  
Removal..... page F-112  
Installation ..... page F-113



05U0FX-130



05U0FX-131



05U0FX-132

## PRECAUTION

### Fuel Pressure Release and Servicing Fuel System

Fuel in the fuel system remains under high pressure even when the engine is not running.

- a) Before disconnecting any fuel line, release the fuel pressure from the fuel system to reduce the possibility of injury or fire.
  1. Start the engine.
  2. Disconnect the circuit opening relay connector.
  3. After the engine stalls, turn off the ignition switch.
  4. Reconnect the circuit opening relay connector.
- b) Use a rag as protection from fuel spray when disconnecting the hoses.
- c) Plug the hoses after removal.
- d) When inspecting the fuel system, use a suitable fuel pressure gauge.

## Caution

- **Install hose clamps when securing the fuel pressure gauge to the fuel pipe and the fuel main hose to prevent fuel leakage.**

## Priming Fuel System

After releasing the fuel system pressure for repairs or inspection, the system must be primed to avoid excessive cranking when first starting the engine. Follow the steps below.

1. Connect diagnosis connector terminals F/P and GND with a jumper wire.
2. Turn the ignition switch ON for **approx. 10 sec.** and check for fuel leaks.
3. Turn the ignition switch OFF and remove the jumper wire.

## SYSTEM OPERATION

## Caution

- Obtain the code number and deactivate the anti-theft system before disconnecting the battery. (Refer to page T-113.)

## Fuel Pressure Hold Inspection

## Warning

- Before performing the following operation, release the fuel pressure from the fuel system to reduce the possibility of injury or fire. (Refer to page F-101.)


1. Disconnect the negative battery terminal.
2. Install a fuel pressure gauge between the fuel pipe and the fuel main hose. (Install clamps as shown.)
3. Connect the negative battery terminal.

4. Connect diagnosis connector terminals F/P and GND with a jumper wire.
5. Turn the ignition switch ON for **10 sec.** to operate the fuel pump.
6. Turn the ignition switch OFF and disconnect the jumper wire.
7. Observe the fuel pressure **after 5 min.**


## Fuel pressure:

**More than 147 kPa (1.5 kg/cm<sup>2</sup>, 21 psi)**


8. If not as specified, perform the following inspections.
  - Fuel pump hold pressure (Refer to page F-107.)
  - Pressure regulator hold pressure (Refer to page F-111.)
  - Injector fuel leakage. (Refer to page F-113.)




05U0FX-133




05U0FX-134




05U0FX-135



05U0FX-136



05U0FX-137



05U0FX-138

**Fuel Line Pressure Inspection**

**Warning**

- Before performing the following operation, release the fuel pressure from the fuel system to reduce the possibility of injury or fire. (Refer to page F-101.)

1. Disconnect the negative battery terminal.
2. Install a fuel pressure gauge between the fuel pipe and the fuel main hose. (Install clamps as shown.)
3. Connect the negative battery terminal.
4. Connect diagnosis connector terminals F/P and GND with a jumper wire.
5. Turn the ignition switch ON.
6. Measure the fuel line pressure.

**Fuel line pressure:**

**265—314 kPa (2.7—3.2 kg/cm<sup>2</sup>, 38—46 psi)**

- Pressure low — Check fuel pump maximum pressure. (Refer to page F-108.) If as specified, fuel line or fuel filter might be clogged or restricted.
- Pressure high — Replace the pressure regulator. (Refer to page F-111.)

### FUEL TANK

#### Caution

- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to page T-113.)

#### Removal / Inspection / Installation


#### Warning

- Before performing the following operation, release the fuel pressure from the fuel system to reduce the possibility of injury or fire. (Refer to page F-101.)
- When removing the fuel tank, keep sparks, cigarettes, and open flames away from the tank.
- Before repairing the fuel tank, clean it thoroughly with steam to remove all explosive gas.

#### Note


- Drain the fuel from the fuel tank before removing the tank.

1. Disconnect the negative battery terminal.
2. Remove the main silencer. (Refer to page F-115.)
3. Remove the power plant frame. (Refer to page J-11.)
4. Remove in the order shown in the figure, referring to **Removal Note**.
5. Install in the reverse order of removal, referring to **Installation Note**.



- |                              |                              |
|------------------------------|------------------------------|
| 1. Fuel filler hoses         | 7. Battery cable             |
| 2. Fuel hoses                | Removal Note..... page F-105 |
| 3. Evaporative hoses         | 8. Rear crossmember assembly |
| 4. Fuel pump connector       | Removal Note..... page F-105 |
| 5. Fuel filter bolts         | 9. Fuel tank unit            |
| Removal Note..... page F-105 | 10. Tow-way check valve      |
| 6. Brake pipe joint          | 11. Fuel vapor valve         |
| Removal Note..... page F-105 | 12. Fuel tank                |


05U0FX-228



05U0FX-229

**Removal note**  
**Fuel filter bolts**

1. Remove the fuel filter cover.
2. Remove the fuel filter bolts.
3. Remove the fuel filter with the fuel hoses still connected.




PIPE JOINT

05U0FX-230

**Brake pipe joint**

1. Remove the brake pipe joint nuts.
2. Remove the brake pipe joint with the brake pipe and brake hose still connected.




BATTERY CABLE

05U0FX-231

**Battery cable**

1. Remove the battery cable clamp as shown in the figure.



05U0FX-232

**Rear crossmember assembly**

1. Support the rear crossmember assembly with a transmission jack.
2. Remove the rear crossmember mounting bolts and nuts.

**Caution**

- Do not damage the brake hose, brake pipe, or fuel hoses.

3. Lower the rear crossmember assembly.


**Installation note****Fuel hoses and fuel filler hoses**

- Push the ends of the main fuel hose, fuel return hose, and evaporation hose onto the fuel tank fittings **at least 25mm (1.0 in)**.
- Push the fuel filler hose onto the fuel tank pipe and filler pipe **at least 35mm (1.4 in)**.


**Power plant frame**

- Install the power plant frame referring to the installation procedure on page J-46.


05U0FX-140



05U0FX-141



05U0FX-142



05U0FX-143

**FUEL FILTER****Replacement****Low-pressure side (In-tank filter)****(Refer to page F-109.)****High-pressure side**

The fuel filter must be replaced at the intervals outlined in the maintenance schedule.

**Warning**

- **Before performing the following operation, release the fuel pressure from the fuel system to reduce the possibility of injury or fire. (Refer to page F-101.)**
- **When replacing fuel system components, keep sparks, cigarettes, and open flames away from the fuel.**

1. Raise the rear of the vehicle and support it with safety stands.
2. Remove the fuel filter protector.
3. Disconnect the fuel hoses from the fuel filter.
4. Remove the fuel filter and bracket.

**Note**


- **When installing the filter, push the fuel hoses fully onto the fuel filter.**

5. Install in the reverse order of removal.


**Tightening torque:**

**7.8—11 N·m (80—110 cm·kg, 69—95 in·lb)**







05U0FX-144




05U0FX-145



05U0FX-146



05U0FX-147



05U0FX-148

**FUEL PUMP**

**Caution**

- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to page T-113.)

**Inspection**

**Fuel pump operation**

1. Connect the diagnosis connector terminals F/P and GND with a jumper wire.
2. Remove the fuel filler cap.
3. Turn the ignition switch ON.
4. Listen for operational sound of the fuel pump at the filler inlet.
5. Install the fuel filler cap.
6. If no sound was heard, measure the voltage between the fuel pump connector wire to ground.
7. If not correct, check the circuit opening relay and its circuits. (Refer to page F-109.)
8. If the voltage is normal, check for continuity between fuel pump connector (B) and a ground.
9. If there is continuity, replace the fuel pump.
10. If no continuity, repair the ground circuit.

**Voltage: 12V**


**Hold pressure**

Perform this inspection if the fuel pressure hold inspection is not as specified. (Refer to page F-102.)

**Warning**

- Before performing the following operation, release the fuel pressure from the fuel system to reduce the possibility of injury or fire. (Refer to page F-101.)

1. Disconnect the negative battery terminal.
2. Connect a fuel pressure gauge to the fuel main pipe and plug the outlet of the fuel pressure gauge as shown. (Install clamps as shown.)
3. Connect the negative battery terminal.



05U0FX-149

4. Connect diagnosis connector terminals F/P and GND with a jumper wire.
5. Turn the ignition switch ON **for 10 sec.** to operate the fuel pump.
6. Turn the ignition switch OFF and disconnect the jumper wire.
7. Observe the fuel pressure **after 5 min.**


**Fuel pressure:**

**More than 343 kPa (3.5 kg/cm<sup>2</sup>, 50 psi)**

8. If not as specified, replace the fuel pump.


**Fuel pump maximum pressure****Warning**

- **Before performing the following operation, release the fuel pressure from the fuel system to reduce the possibility of injury or fire. (Refer to page F-101.)**



05U0FX-150

1. Disconnect the negative battery terminal.
2. Connect a fuel pressure gauge to the fuel main pipe and plug the outlet of the fuel pressure gauge as shown. (Install clamps as shown.)
3. Connect the negative battery terminal.




05U0FX-151

4. Connect diagnosis connector terminals F/P and GND with a jumper wire.
5. Turn the ignition switch ON to operate the fuel pump.
6. Measure the pump maximum pressure.

**Fuel pump maximum pressure:**

**441—589 kPa (4.6—6.0 kg/cm<sup>2</sup>, 64—85 psi)**


7. Turn the ignition switch OFF and disconnect the jumper wire.
8. If not as specified, replace the fuel pump.




05U0FX-152

**Replacement****Warning**

- **Before performing the following procedures, release the fuel pressure from the fuel system to reduce the possibility of injury or fire. (Refer to page F-101.)**
- **When replacing the fuel system parts, keep sparks, cigarettes, and open flames away from the fuel.**




05U0FX-153




05U0FX-154

1. Remove the rear package trim.
2. Remove the service hole cover.




05U0FX-155

4. Remove the fuel pump cover.
5. Disconnect the fuel pump connector.
6. Disconnect the fuel hoses.
7. Remove the fuel pump and fuel tank gauge sender unit assembly.



05U0FX-156

8. Remove the fuel pump.
9. Install in the reverse order of removal, referring to **Installation Note**.




05U0FX-157

### Installation note

#### O-ring set


1. Use a new O-ring set. (O-ring, cap, and spacer)
2. Apply oil or fuel to the O-ring set before installing.
3. To confirm sealing of the O-ring, after assembling the fuel pump and fuel tank gauge sender unit, blow air through the fuel main pipe and verify that no air flows. If air flows the check ball may be stuck. Shake the fuel pump 2 or 3 times and recheck.




05U0FX-233

#### Fuel pump


1. After installing the fuel pump to the bracket, pull down the fuel pump so that it is tight against the bracket.




9MU0F2-150




05U0FX-158



05U0FX-159



05U0FX-160



05U0FX-161

### CIRCUIT OPENING RELAY

#### Inspection

#### Switching operation

Apply 12V and a ground to the terminals below and check the circuit opening relay operation as described.

12V	Grounded	Correct result
STA	E1	B-Fp: Continuity
B	Fc	Fp: Battery voltage

If not as specified, replace the circuit opening relay.

#### Relay circuit

Measure voltage between the terminals and a ground with a voltmeter.

Condition	Terminal	Fp	Fc	B	STA	E1
Ignition switch: ON		0V	12V	12V	0V	0V
Ignition switch: START		12V	0V	12V	12V	0V
At idle		12V	0V	12V	0V	0V

If not as specified, check the related wiring harness.

#### Resistance


Measure resistance between the terminals with an ohmmeter.

Between terminals	Resistance (Ω)
STA-E1	21—43
B-Fc	109—226
B-Fp	∞


If not as specified, replace the circuit opening relay.

#### Replacement


1. Remove the undercover.
2. Remove the circuit opening relay.
3. Install in the reverse order of removal.




05U0FX-162




05U0FX-163



05U0FX-164



05U0FX-165



05U0FX-166

**PRESSURE REGULATOR**

**Caution**

- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to page T-113.)

**Inspection**

**Fuel line pressure**

**Warning**

- Before performing the following operation, release the fuel pressure from the fuel system to reduce the possibility of injury or fire. (Refer to page F-101.)

1. Disconnect the negative battery terminal.
2. Connect a fuel pressure gauge between the fuel main pipe and the fuel main hose. (Install clamps as shown.)
3. Connect the negative battery terminal.
4. Start the engine and run it at idle.
5. Measure the fuel line pressure.

**Fuel line pressure:**

**216—265 kPa (2.2—2.7 kg/cm<sup>2</sup>, 31—38 psi)**

**Hold pressure**

Perform this inspection if the fuel pressure hold inspection is not as specified. (Refer to page F-102.)

**Warning**

- Before performing the following operation, release the fuel pressure from the fuel system to reduce the possibility of injury or fire. (Refer to page F-101.)


1. Disconnect the negative battery terminal.
2. Install a fuel pressure gauge between the fuel pipe and the fuel main hose. (Install clamps as shown.)
3. Connect the negative battery terminal.

4. Connect diagnosis connector terminals F/P and GND with a jumper wire.
5. Turn the ignition switch ON **for 10 sec.** to operate the fuel pump.
6. Turn the ignition switch OFF and disconnect the jumper wire.
7. Block the outlet of the pressure regulator.
8. Observe the fuel pressure **for 5 min.**


**Fuel pressure:**

**More than 147 kPa (1.5 kg/cm<sup>2</sup>, 21 psi)**


9. If pressure is as specified, replace the pressure regulator.




05U0FX-167




05U0FX-168



05U0FX-169



05U0FX-170



05U0FX-171

## Replacement

### Warning

- Before performing the following operation, release the fuel pressure from the fuel system to reduce the possibility of injury or fire. (Refer to page F-101.)
- When replacing fuel system components, keep sparks, cigarettes, and open flames away from the fuel.

1. Disconnect the vacuum hose.
2. Disconnect the fuel return hose.
3. Remove the pressure regulator.

### Tightening torque:

**7.8—11 N·m (80—110 cm·kg, 69—95 in·lb)**

4. Use new O-ring.
5. Install in the reverse order of removal.

## INJECTOR

### Caution

- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to page T-113.)

### Inspection

#### Operation check

1. Warm up the engine and run it at idle.
2. Listen for operational sound of the injector with a screwdriver or a sound scope.
3. If no sound is heard, measure injector resistance.
4. If the injector resistance is OK, check wiring to the injector and engine control unit terminals 2A, 2U, and 2V voltages. (Refer to page F-130.)

### Injector resistance

1. Disconnect the injector harness.
2. Measure resistance of the injector with an ohmmeter.


**Resistance: 12—16Ω**

3. If not as specified, replace the injector.

## Removal


### Warning

- Before performing the following operation, release the fuel pressure from the fuel system to reduce the possibility of injury or fire. (Refer to page F-101.)
- When servicing the fuel system parts, keep sparks, cigarettes, and open flames away from the fuel.




05U0FX-172

1. Disconnect the negative battery terminal.
2. Remove the air valve. (Refer to page F-98.)
3. Remove the PCV hose.
4. Disconnect the vacuum hose.
5. Disconnect the injector connectors.



05U0FX-173

6. Remove the delivery pipe and the pressure regulator.
7. Remove the grommets, injectors, and insulators.




05U0FX-174

## Inspection


### Fuel leakage test

1. Remove the air valve.
2. Firmly affix the injectors to the delivery pipe with wire.
3. Disconnect the injector connectors.
4. Remove the delivery pipe and injectors together with the fuel hoses connected.



05U0FX-175

5. Connect diagnosis connector terminals (F/P) and (GND) with a jumper wire.




05U0FX-176

6. Turn the ignition switch ON.
7. Tilt the injectors **approx. 60 degrees** and verify that no fuel leaks from the injector nozzles.
8. If fuel leaks from an injector, replace it.

### Note

- **After 1 minute a drop of fuel from the injector is acceptable.**

9. Turn the ignition switch OFF and remove the jumper wire.



9MU0F2-172


### Installation

Install in the reverse order of removal, referring to **Installation Note**.

### Tightening torque:

#### Delivery pipe


**19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)**



05U0FX-177

### Installation note

1. Use new injector O-rings.
2. Apply a small amount of clean engine oil to the O-rings before installing.



05U0FX-238

3. Use new injector insulators.
4. Install the injectors and new injector insulators.



EXHAUST SYSTEM


COMPONENTS

Removal / Inspection / Installation

1. Remove in the sequence shown in the figure.
2. Check all components for damage, deterioration, and restriction and repair or replace as necessary.
3. Install in the reverse order of removal.

Note

- When installing the exhaust system components, tighten all fasteners to the specified torque.



05U0FX-178


- |  |   |
|--|---|
| <ol style="list-style-type: none"> <li>1. Main silencer<br/>Inspect for deterioration and restriction</li> <li>2. Catalytic converter<br/>Inspect..... page F-122</li> </ol> | <ol style="list-style-type: none"> <li>3. Front exhaust pipe<br/>Inspect for deterioration and restriction</li> <li>4. Exhaust manifold<br/>Inspect for damage</li> </ol> |
|--|---|

## OUTLINE OF EMISSION CONTROL SYSTEM

## STRUCTURAL VIEW

The following systems are employed to reduce CO, HC, and NO<sub>x</sub> emissions.

1. Positive crankcase ventilation (PCV) system.
2. Evaporative emission control system.
3. Catalytic converter.
4. Deceleration control system.




POSITIVE CRANKCASE VENTILATION (PCV) SYSTEM

**DESCRIPTION**


The PCV valve is operated by the intake manifold vacuum.

When the engine is running at idle the PCV valve is opened slightly and a small amount of blowby gas is drawn into the dynamic chamber to be burned.


At higher engine speeds the PCV valve is opened further, allowing a larger amount of blowby gas to be drawn into the dynamic chamber.



9MU0F2-182



05U0FX-180



05U0FX-181

**PCV VALVE Inspection**


1. Warm up the engine to the normal operating temperature and run it at idle.
2. Disconnect the PCV valve together with the ventilation hose from the cylinder head cover.
3. Block the PCV valve opening.
4. Verify that vacuum is felt.
5. Remove the PCV valve.
6. Blow through the valve from port A and verify that air comes out of port B.
7. Blow through the valve from port B and verify that no air comes out of port A.
8. Replace the PCV valve if necessary.

# F EVAPORATIVE EMISSION CONTROL SYSTEM

## EVAPORATIVE EMISSION CONTROL SYSTEM

### DESCRIPTION

The evaporative emission control system consists of the fuel vapor valve, the two-way check valve, the charcoal canister, the solenoid valve (purge control), the engine control unit, and the input devices. The amount of evaporative fumes introduced into the engine and burned is controlled by the solenoid valve in relation to the engine's operating conditions. To maintain the best engine performance, the solenoid valve is controlled by the engine control unit.




05U0FX-182


### Operation

The solenoid valve (purge control) is controlled by duty signals from the engine control unit to perform purging of the charcoal canister. Purging is done when these conditions are met:


- (1) After warm-up.
- (2) Driving in gear.
- (3) Accelerator pedal depressed (idle switch OFF).
- (4) Oxygen sensor functioning normally.




05U0FX-183




05U0FX-184



05U0FX-185



05U0FX-186



05U0FX-187

**SOLENOID VALVE (PURGE CONTROL)**

**On-vehicle Inspection**

1. Warm up the engine to normal operating temperature.
2. Run the engine at idle.
3. Disconnect the vacuum hose from the solenoid valve and verify that no vacuum is felt at the solenoid valve.
4. If not as specified, check the solenoid valve.

**Inspection**

1. Disconnect the vacuum hoses from the solenoid valve.
2. Verify that no air flows through the valve.

3. Disconnect the solenoid valve connector and connect **12V** and a ground to the terminals of the solenoid valve.
4. Verify that the air flows through the valve.
5. If not as specified, replace the solenoid valve.

**TWO-WAY CHECK VALVE**

**Inspection**

1. Remove the valve.
2. Check the operation of the valve with a vacuum pump.


Apply approx. 37 mmHg (1.46 inHg) vacuum at port A	Airflow
Apply approx. 44 mmHg (1.73 inHg) vacuum at port B	Airflow

**FUEL VAPOR VALVE**

**Inspection**


1. Remove the valve.
2. Blow through the valve and verify that air flows in the direction shown.

# F EVAPORATIVE EMISSION CONTROL SYSTEM



05U0FX-188

3. Turn the valve over and blow through the valve. Verify that no air flows.
4. Replace the valve if necessary.



05U0FX-189

## CHARCOAL CANISTER

### Inspection


Visually check for damage and replace the charcoal canister if necessary.

DECELERATION CONTROL SYSTEM


DESCRIPTION

The deceleration control system consists of the fuel cut operation and the dashpot.


1. Dashpot: To prevent the throttle valves from suddenly closing.
2. Fuel cut: To improve the fuel economy and to prevent engine bucking during deceleration.



05U0FX-239



05U0FX-190



05U0FX-191

**DASHPOT Inspection**

1. Open the throttle valve fully. Push the dashpot rod with a finger and verify that it goes into the dashpot slowly.
2. Release the rod and check that it comes out quickly.
3. Replace the dashpot if necessary.


4. Warm up the engine and run it at idle.
5. Connect a tachometer to the engine, and increase the engine speed to **4,000 rpm**.
6. Slowly decrease the engine speed and check that the lever touches the dashpot rod as specified.

**Specification: 2,500 ± 150 rpm**

7. If not as specified, loosen the locknut and turn the dashpot to adjust.

## CATALYTIC CONVERTER SYSTEM

## DESCRIPTION



05U0FX-192

**CATALYTIC CONVERTER****Inspection**

Check the catalytic converter for deterioration or restriction. Check for damage to the insulation covers welded to the catalytic converter. Replace the catalytic converter if necessary.

**Note**

- If the insulation cover touches the catalytic converter housing, excessive heat at the floor of the vehicle will occur.

**Replacement**

Refer to page F-115.


05U0FX-193



**A/C CUT-OFF CONTROL SYSTEM**

**DESCRIPTION**

An A/C cut-off system is used to improve idle smoothness after just starting the engine and to improve acceleration performance.




05U0FX-194

**After Engine Has Been Started**

The A/C is cut-off for **2 sec.** just after the engine is started.

**Acceleration**

The A/C is cut-off upon wide-open-throttle acceleration for **approx. 16 sec.**



05U0FX-195


**System Operation**

1. Start the engine.
2. Turn the blower switch and A/C switch ON.
3. Disconnect the throttle sensor connector.
4. Connect the throttle sensor connector terminals TL and POW with a jumper wire and verify that the condenser fan stops for **approx. 16 sec.**
5. If not correct, check engine control unit terminals 1Q and 2L voltages. (Refer to page F-129.)

DECHOKE CONTROL SYSTEM








DESCRIPTION

To clean out excess fuel in cylinders, as in the case of engine flooding, when the engine is cold, no fuel will be injected when the accelerator is held fully depressed while cranking the engine.




CONTROL SYSTEM

PREPARATION  
SST


<p>49 9200 162 Engine Signal Monitor</p> 	<p>For inspection of engine control unit</p>	<p>49 G018 903 Adapter harness</p> 	<p>For inspection of engine control unit</p>
<p>49 H018 9A1 Self-Diagnosis Checker</p> 	<p>For inspection of oxygen sensor</p>	<p>49 B019 9A0 System Selector</p> 	<p>For inspection of oxygen sensor</p>
<p>49 9200 165 Throttle Sensor Checker</p> 	<p>For inspection of oxygen sensor</p>	<p>49 9200 166 Adapter harness</p> 	<p>For inspection of oxygen sensor</p>
<p>49 G018 904 Sheet</p> 	<p>For inspection of engine control unit</p>	<p>05U0FX-197</p>	

### STRUCTURAL VIEW




05U0FX-198


- |                        |            |                                     |            |
|------------------------|------------|-------------------------------------|------------|
| 1. Engine control unit |            | 6. Oxygen sensor                    |            |
| Inspection .....       | page F-127 | Inspection .....                    | page F-138 |
| 2. Crank angle sensor  |            | Replacement.....                    | page F-139 |
| Removal.....           | page F-134 | 7. Main relay (Fuel injector relay) |            |
| Inspection .....       | page F-134 | Inspection .....                    | page F-139 |
| Installation.....      | page F-134 | 8. Clutch switch                    |            |
| 3. Airflow meter       |            | Inspection .....                    | page F-139 |
| Inspection .....       | page F-135 | Replacement.....                    | page F-139 |
| 4. Water thermosensor  |            | 9. Neutral switch                   |            |
| Removal.....           | page F-136 | Inspection .....                    | page F-140 |
| Inspection .....       | page F-136 | Replacement.....                    | page F-140 |
| Installation.....      | page F-136 | 10. Power steering pressure switch  |            |
| 5. Throttle sensor     |            | Inspection .....                    | page F-140 |
| Inspection .....       | page F-136 | Replacement.....                    | page F-140 |
| Adjustment.....        | page F-137 |                                     |            |
| Replacement.....       | page F-137 |                                     |            |




9MU0F2-207




05U0FX-199



05U0FX-234



05U0FX-200



9MU0F2-191

**ENGINE CONTROL UNIT**

**Inspection**

1. Lift up the floormat in front of the passenger's seat.
2. Remove the protector cover.

3. Connect the **Engine Signal Monitor** between the engine control unit and the wiring harness using the **Adapter** as shown.

4. Place the **SST (Sheet)** on the **SST**.
5. Measure the voltage at each terminal.  
(Refer to pages F-128 to F-130.)

5. If any engine control unit terminal voltage is incorrect, check the input or output device and related wiring.  
If they are normal, replace the engine control unit.  
(Refer to pages F-131 to F-133.)

**Caution**

- Never apply voltage to SST terminals A and B.

# F

## CONTROL SYSTEM

Terminal	Input	Output	Connection to	Test condition	Voltage	Remark
1A	—	—	Battery	Constant	Approx. 12V	For backup
1B	○		Main relay	Ignition switch OFF	Approx. 0V	
				Ignition switch ON	Approx. 12V	
1C	○		Ignition switch (Start position)	While cranking	Approx. 10V	
				Ignition switch ON	Approx. 0V	
1D		○	Self-Diagnosis Checker (Monitor lamp)	Test switch at "SELF-TEST" Lamp illuminated for 3 sec. after ignition switch OFF→ON	Approx. 5V	With Self-Diagnosis Checker and System Selector
				Lamp not illuminated after 3 sec.	Approx. 12V	
				Test switch at "O <sub>2</sub> MONITOR" at idle Monitor lamp illuminated	Approx. 5V	
				Test switch at "O <sub>2</sub> MONITOR" at idle Monitor lamp not illuminated	Approx. 12V	
1E		○	Malfunction indicator lamp	Lamp illuminated for 3 sec. after ignition switch OFF→ON	Below 2.5V	With System Selector test switch at "SELF-TEST"
				Lamp not illuminated after 3 sec.	Approx. 12V	
				Lamp illuminated	Below 2.5V	
				Lamp not illuminated	Approx. 12V	
1F		○	Self-Diagnosis Checker (Code number)	Buzzer sound for 3 sec. after ignition switch OFF→ON	Below 2.5V	<ul style="list-style-type: none"> <li>• With Self-Diagnosis Checker and System Selector</li> <li>• With System Selector test switch at "SELF-TEST"</li> </ul>
				Buzzer not sounded after 3 sec.	Approx. 12V	
				Buzzer sounded	Below 2.5V	
				Buzzer not sounded	Approx. 12V	
1G		○	Igniter	Ignition switch ON	Approx. 0V	
				Idle	Approx. 0.2V	
1H		○	Igniter	Ignition switch ON	Approx. 0V	
				Idle	Approx. 0.2V	
1I	—	—	—	—	—	—
1J		○	A/C relay	Ignition switch ON	Approx. 12V	
				A/C switch ON at idle	Below 2.5V	
				A/C switch OFF at idle	Approx. 12V	
1K	○		Diagnosis connector	System Selector test switch at "O <sub>2</sub> MONITOR"	Approx. 12V	
				System Selector test switch at "SELF-TEST"	Approx. 0V	
1L	—	—	—	—	—	—
1M	—	—	—	—	—	—
1N	○		Throttle sensor (Idle point)	Accelerator pedal released	Approx. 0V	Ignition switch ON
				Accelerator pedal depressed	Approx. 12V	
1O	○		Stoplight switch	Brake pedal released	0V	
				Brake pedal depressed	Approx. 12V	
1P	○		P/S pressure switch	Ignition switch ON	Approx. 12V	
				P/S ON (at idle)	0V	
				P/S OFF (at idle)	Approx. 12V	
1Q	○		A/C switch	A/C switch ON (Ignition switch ON)	Below 2.5V	Blower motor ON
				A/C switch OFF (Ignition switch ON)	Approx. 12V	

# CONTROL SYSTEM

F

Terminal	Input	Output	Connection to	Test condition	Voltage	Remark
1R	○		Fan switch	Fan operating (Engine coolant temperature over 97°C (207°F) or diagnosis connector terminal TFA grounded)	Approx. 0V	
				Fan not operating (Idle)	Approx. 12V	
1S	○		Blower control switch	Blower control switch at mid, high or super high position	Approx. 0V	Ignition switch ON
				Blower control switch OFF or low	Approx. 12V	
1T	—	—	—	—	—	
1U	○		Headlight switch	Headlights ON (Tail, parking, low beam/high beam)	Approx. 12V	
				Headlights OFF	0V	
1V	○		Neutral or clutch switch	Neutral position or clutch pedal depressed	Approx. 0V	
				Other conditions	Approx. 12V	
2A	—	—	Ground (Injector)	Constant	0V	
2B	—	—	Ground (Output)	Constant	0V	
2C	—	—	Ground (CPU)	Constant	0V	
2D	—	—	Ground (Input)	Constant	0V	
2E	○		Crank angle sensor (Ne-signal)	Ignition switch ON	Approx. 0V or 5V	
				Idle	Approx. 2V	
2F	—	—	—	—	—	
2G	○		Crank angle sensor (G-signal)	Ignition switch ON	Approx. 0V or 5V	
				Idle	Approx. 1.5V	
2H	○		Ground	California spec.	0V	
				Open	Federal and Canada spec.	
2I	○		Igniter	Ignition switch ON	Below 0.5V	
				Idle	Approx. 1V	
2J	○		Ground	Constant	0V	
2K		○	Airflow meter	Constant	4.5—5.5V	
2L	○		Throttle sensor (Power terminal)	Accelerator pedal released	Approx. 5V	
				Accelerator pedal fully depressed	Approx. 0V	
2M	—	—	—	—	—	
2N	○		Oxygen sensor	Ignition switch ON	0V	
				Idle (Cold engine)	0V	
				Idle (After warm-up)	0—1V	
				Increase engine speed (After warm-up)	0.5—1V	
				Deceleration	0—0.4V	
2O	○		Airflow meter	Ignition switch ON	Approx. 3.8V	
				Idle	Approx. 3.3V	
2P	○		Airflow sensor (Intake air thermosensor)	At 20°C (68°F)	Approx. 2.5V	
2Q	○		Water thermosensor	Engine coolant temperature 20°C (68°F)	Approx. 2.5V	
				After warm up	Approx. 0.4V	
2R	—	—	—	—	—	

Terminal	Input	Output	Connection to	Test condition	Voltage	Remark
2S	—	—	—	—	—	—
2T	—	—	—	—	—	—
2U		○	Injector (Nos.1, 3) (Nos.2, 4)	Ignition switch ON	Approx. 12V	* Engine Signal Monitor: Green and red lights flash
2V		○		Idle	Approx. 12V*	
2W		○	ISC valve	Deceleration from 3,000 rpm to 1,900 rpm (After warm up)	Approx. 12V	
2X		○		Solenoid valve (Purge control)	Ignition switch ON	Approx. 7V
2Y	—	—	—		Idle	Approx. 9V
2Z	—	—	—	Ignition switch ON	Approx. 12V	—
				Idle	Approx. 12V	—

05U0FX-201

### Terminal location

2Y	2W	2U	2S	2Q	2O	2M	2K	2I	2G	2E	2C	2A	1U	1S	1Q	1O	1M	1K	1I	1G	1E	1C	1A
2Z	2X	2V	2T	2R	2P	2N	2L	2J	2H	2F	2D	2B	1V	1T	1R	1P	1N	1L	1J	1H	1F	1D	1B




**Check Point for Each Terminal**

Terminal	Connection to	Abnormal voltage	Possible cause
1A	Battery	Always approx. 0V (Battery OK)	<ul style="list-style-type: none"> <li>ROOM 10A fuse burned</li> <li>Open circuit in wiring from ROOM 10A fuse to ECU terminal 1A</li> </ul>
1B	Main relay	Always approx. 0V	<ul style="list-style-type: none"> <li>Main relay malfunction (Refer to page F-139)</li> <li>Open circuit in wiring from main relay to ECU terminal 1B</li> </ul>
1C	Ignition switch (Start position)	Always approx. 0V (Starter turns)	<ul style="list-style-type: none"> <li>Open circuit in wiring from starter interlock switch to ECU terminal 1C</li> </ul>
1D	Self-Diagnosis Checker (Monitor lamp)	Always approx. 0V	<ul style="list-style-type: none"> <li>Main relay malfunction (Refer to page F-139)</li> <li>Open circuit in wiring from main relay to diagnosis connector terminal +B</li> <li>Open or short circuit in wiring from diagnosis connector terminal MEN to ECU terminal 1D</li> </ul>
		Always approx. 12V	<ul style="list-style-type: none"> <li>Poor connection at ECU connector</li> <li>ECU malfunction</li> </ul>
		Always approx. 5V	<ul style="list-style-type: none"> <li>ECU malfunction</li> </ul>
1E	Malfunction indicator lamp (MIL)	Always below 2.5V (MIL always ON)	<ul style="list-style-type: none"> <li>Short circuit in wiring from combination meter to ECU terminal 1E</li> <li>ECU malfunction</li> </ul>
		Always below 2.5V (MIL never ON)	<ul style="list-style-type: none"> <li>Open circuit in wiring from combination meter to ECU terminal 1E</li> </ul>
		Always approx. 12V	<ul style="list-style-type: none"> <li>Poor connection at ECU connector</li> <li>ECU malfunction</li> </ul>
1F	Self-Diagnosis Checker (Code No.)	Always below 2.5V (No display on Self-Diagnosis Checker)	<ul style="list-style-type: none"> <li>Main relay malfunction (Refer to page F-139)</li> <li>Open circuit in wiring from main relay to diagnosis connector terminal +B</li> </ul>
		Always below 2.5V ("88" is displayed and buzzer sounds continuously)	<ul style="list-style-type: none"> <li>Open or short circuit in wiring from diagnosis connector terminal FEN to ECU terminal 1F</li> </ul>
		Always approx. 12V	<ul style="list-style-type: none"> <li>Poor connection at ECU connector</li> <li>ECU malfunction</li> </ul>
1G 1H	Igniter	Always approx. 0V	Refer to Code No.01 troubleshooting (Refer to page F-81)
1J	A/C relay	Always below 2.5V (A/C does not operate)	<ul style="list-style-type: none"> <li>A/C relay malfunction (Refer to page U-39)</li> <li>Open circuit in wiring from main relay to A/C relay</li> <li>Open circuit in wiring from A/C relay to ECU terminal 1J</li> </ul>
		Always below 2.5V (A/C switch OFF but A/C operates)	<ul style="list-style-type: none"> <li>Short circuit in wiring from A/C relay to ECU terminal 1J</li> <li>ECU malfunction</li> </ul>
		Always approx. 12V	<ul style="list-style-type: none"> <li>A/C switch malfunction (Refer to page U-25)</li> <li>Poor connection at ECU connector</li> <li>ECU malfunction</li> </ul>
1K	Diagnosis connector (Terminal TEN)	Always approx. 0V	<ul style="list-style-type: none"> <li>Short circuit in wiring from ECU terminal 1K to diagnosis connector terminal TEN</li> </ul>
		Always approx. 12V	<ul style="list-style-type: none"> <li>Open circuit in wiring from ECU terminal 1K to diagnosis connector terminal TEN</li> <li>Open circuit in wiring from diagnosis connector terminal GND to ground</li> </ul>
1N	Throttle sensor (Idle terminal)	Always approx. 0V	<ul style="list-style-type: none"> <li>Throttle sensor misadjustment (Refer to page F-136)</li> <li>Short circuit in wiring from ECU terminal 1N to throttle sensor</li> <li>ECU malfunction</li> </ul>
		Always approx. 12V	<ul style="list-style-type: none"> <li>Throttle sensor misadjustment (Refer to page F-136)</li> <li>Open circuit in wiring from ECU terminal 1N to throttle sensor</li> <li>Open circuit in wiring from throttle sensor to ground</li> </ul>
1O	Stoplight switch	Always approx. 0V (Stoplights OK)	<ul style="list-style-type: none"> <li>Open circuit in wiring from stoplight switch to ECU terminal 1O</li> </ul>

Terminal	Connection to	Abnormal voltage	Possible cause
1P	P/S pressure switch	Always approx. 0V	<ul style="list-style-type: none"> <li>• P/S pressure switch malfunction (Refer to page F-140)</li> <li>• Short circuit in wiring from ECU terminal 1P to P/S pressure switch</li> <li>• ECU malfunction</li> </ul>
		Always approx. 12V	<ul style="list-style-type: none"> <li>• P/S pressure switch malfunction (Refer to page F-140)</li> <li>• Open circuit in wiring from ECU terminal 1P to P/S pressure switch</li> <li>• Open circuit in wiring from P/S pressure switch to ground</li> </ul>
1Q	A/C switch	Always approx. 0V (with blower switch ON)	<ul style="list-style-type: none"> <li>• A/C switch malfunction (Refer to page U-25)</li> <li>• Short circuit in wiring from ECU terminal 1Q to A/C switch</li> <li>• Poor connection at ECU connector</li> <li>• ECU malfunction</li> </ul>
		Always approx. 12V (with blower switch ON) (Blower fan OK)	<ul style="list-style-type: none"> <li>• A/C switch malfunction (Refer to page U-25)</li> <li>• Open circuit in wiring from ECU terminal 1Q to A/C switch</li> <li>• Open circuit in wiring from A/C switch to blower control switch</li> </ul>
1R	Fan switch	Always approx. 0V (Cooling fan OK)	<ul style="list-style-type: none"> <li>• Open or short circuit in wiring from electric cooling fan relay to ECU terminal 1R</li> <li>• ECU malfunction</li> </ul>
1S	Blower control switch	Always approx. 0V (Blower fan OK)	<ul style="list-style-type: none"> <li>• Short circuit in wiring from blower control switch to ECU terminal 1S</li> <li>• Poor connection at ECU connector</li> <li>• ECU malfunction</li> </ul>
		Always approx. 12V (Blower fan OK)	<ul style="list-style-type: none"> <li>• Open circuit in wiring from blower control switch to ECU terminal 1S</li> </ul>
1U	Headlight switch	Always approx. 0V (Headlights OK)	<ul style="list-style-type: none"> <li>• Open or short circuit in wiring from headlight relay to ECU terminal 1U</li> </ul>
1V	Neutral switch Clutch switch	Always approx. 0V	<ul style="list-style-type: none"> <li>• Neutral switch malfunction (Refer to page F-140)</li> <li>• Clutch switch malfunction (Refer to page F-139)</li> <li>• Short circuit in wiring from ECU terminal 1V to neutral or clutch switch</li> <li>• Poor connection at ECU connector</li> <li>• ECU malfunction</li> <li>• Open circuit in wiring from ECU terminal 1V to neutral and clutch switches</li> </ul>
2A 2B 2C 2D	Ground	More than 0V	<ul style="list-style-type: none"> <li>• Poor contact at ground terminal</li> <li>• Open circuit in wiring from ECU to ground</li> </ul>
2E	Crank angle sensor (Ne-signal)	Always approx. 0V or approx. 5V	<ul style="list-style-type: none"> <li>• Refer to Code No.02 troubleshooting (Refer to page F-82)</li> </ul>
2G	Crank angle sensor (G-signal)	Always approx. 0V or approx. 5V	<ul style="list-style-type: none"> <li>• Refer to Code No.03 troubleshooting (Refer to page F-82)</li> </ul>
2H	Ground (California)	Approx. 5V	<ul style="list-style-type: none"> <li>• Open circuit in wiring from ECU terminal 2H to ground</li> </ul>
	— (Federal and Canada)	Approx. 0V	<ul style="list-style-type: none"> <li>• Short circuit in wiring from ECU terminal 2H to ground</li> </ul>
2I	Igniter	Always Approx. 0V	<ul style="list-style-type: none"> <li>• Refer to Code No.01 troubleshooting (Refer to page F-81)</li> </ul>
2J	Ground	Approx. 5V	<ul style="list-style-type: none"> <li>• Open circuit in wiring from ECU terminal 2J to ground</li> </ul>

Terminal	Connection to	Abnormal voltage	Possible cause
2K	Airflow meter	Always approx. 0V	<ul style="list-style-type: none"> <li>• Short circuit in wiring from ECU terminal 2K to airflow meter</li> <li>• Poor connection at ECU connector</li> <li>• ECU malfunction</li> </ul>
		Below 4.5V or above 5.5V	<ul style="list-style-type: none"> <li>• ECU malfunction</li> </ul>
2L	Throttle sensor (Power terminal)	Always approx. 0V	<ul style="list-style-type: none"> <li>• Throttle sensor malfunction (Refer to page F-136)</li> <li>• Short circuit in wiring from ECU terminal 2L to throttle sensor</li> <li>• Poor connection at ECU connector</li> <li>• ECU malfunction</li> </ul>
		Always approx. 5V	<ul style="list-style-type: none"> <li>• Throttle sensor misadjustment (Refer to page F-136)</li> <li>• Open circuit in wiring from ECU terminal 2L to throttle sensor</li> <li>• Open circuit in wiring from throttle sensor to ground</li> </ul>
2N	Oxygen sensor	0V after warm-up	<ul style="list-style-type: none"> <li>• Refer to Code No.15 troubleshooting (Refer to page F-86)</li> </ul>
		Always approx. 1V after warm-up	<ul style="list-style-type: none"> <li>• Refer to Code No.17 troubleshooting (Refer to page F-86)</li> </ul>
2O	Airflow meter	Always approx. 0V or approx. 5V	<ul style="list-style-type: none"> <li>• Refer to Code No.08 troubleshooting (Refer to page F-84)</li> </ul>
2P	Airflow meter (Intake air thermosensor)	Always approx. 0V or approx. 5V	<ul style="list-style-type: none"> <li>• Refer to Code No.10 troubleshooting (Refer to page F-85)</li> </ul>
			<ul style="list-style-type: none"> <li>• Intake air thermosensor malfunction (Refer to page F-135)</li> </ul>
2Q	Water thermosensor	Always approx. 0V or approx. 5V	<ul style="list-style-type: none"> <li>• Refer to Code No.09 troubleshooting (Refer to page F-85)</li> </ul>
			<ul style="list-style-type: none"> <li>• Water thermosensor malfunction (Refer to page F-136)</li> </ul>
2U 2V	Injector	Always approx. 0V	<ul style="list-style-type: none"> <li>• Main relay malfunction (Refer to page F-139)</li> <li>• Open or short circuit in wiring from injector to ECU terminal 2U or 2V</li> </ul>
		Always approx. 12V	<ul style="list-style-type: none"> <li>• ECU malfunction</li> </ul>
2W	ISC valve	Always approx. 0V or approx. 12V	<ul style="list-style-type: none"> <li>• Refer to Code No.34 troubleshooting (Refer to page F-87)</li> </ul>
			<ul style="list-style-type: none"> <li>• ISC valve malfunction (Refer to page F-99)</li> </ul>
2X	Solenoid valve (Purge control)	Always approx. 0V or approx. 12V	<ul style="list-style-type: none"> <li>• Refer to Code No.26 troubleshooting (Refer to page F-87)</li> </ul>
			<ul style="list-style-type: none"> <li>• Solenoid valve (Purge control) malfunction (Refer to page F-119)</li> </ul>


05U0FX-202



05U0FX-203

**CRANK ANGLE SENSOR****Removal**


1. Disconnect the crank angle sensor connector
2. Remove the crank angle sensor.



05U0FX-204

**Inspection**


1. Visually check the crank angle sensor for damage.
2. Replace if necessary.



05U0FX-205

**Installation**

1. Apply grease to the new O-ring and the blade.



05U0FX-240


2. Install the crank angle sensor.

**Tightening torque:**


**19—27 N·m (1.9—2.6 m·kg, 14—20 ft·lb)**

3. Connect the crank angle sensor connector.
4. Adjust the ignition timing. (Refer to page F-75.)


AIRFLOW METER



69G04A-177



05U0FX-206




05U0FX-207

**Inspection**

1. Remove the airflow meter. (Refer to page F-92.)
2. Check the airflow meter body for cracks.
3. Verify that the measuring plate moves smoothly.
4. Disconnect the connector from the airflow meter.
5. Move the measuring plate and check for resistance between the terminals with an ohmmeter.

Terminal	Resistance ( $\Omega$ )	
	Fully closed	Fully open
E2↔Vs	200—600	20—1,000
E2↔Vc	200—400	
E2↔THAA (Intake air thermosensor)	-20°C (-4°F)	13,600—18,400
	20°C (68°F)	2,210—2,690
	60°C (140°F)	493—667
E1↔Fc	$\infty$	0

6. Connect the airflow meter connector after checking.




05U0FX-208

### WATER THERMOSENSOR

#### Removal

1. Remove the ignition coil assembly. (Refer to page G-21.)
2. Disconnect the water thermostensor connector.
3. Remove the water thermostensor.




05U0FX-209

#### Inspection

1. Place the sensor in water with a thermometer and heat the water gradually.
2. Measure resistance of the sensor with an ohmmeter.

Coolant	Resistance kΩ
-20°C ( -4°F)	14.6 — 17.8
20°C ( 68°F)	2.2 — 2.7
80°C (176°F)	0.29— 0.35

3. If not as specified, replace the water thermostensor.



05U0FX-210


#### Installation

1. Install the water thermostensor and a new washer.

#### Tightening torque:

**25—29 N·m (2.5—3.0 m·kg, 18—22 ft·lb)**

2. Connect the water thermostensor connector.
3. Install the ignition coil assembly. (Refer to page G-21.)





05U0FX-211

### THROTTLE SENSOR


#### Inspection

1. Disconnect the connector from the throttle sensor.
2. Connect the **(SSTs)** or an ohmmeter to the throttle sensor.







05U0FX-212




05U0FX-213



05U0FX-214



05U0FX-215



05U0FX-216

3. Insert a feeler gauge between the throttle stop screw and the stop lever.
4. Note the operation of the buzzer or the continuity between terminals.

Feeler gauge	Buzzer	Continuity between terminals	
		IDL↔TL	POW↔TL
0.4mm (0.016 in)	Yes	Yes	No
0.7mm (0.027 in)	No	No	No
Wide-open throttle	Yes	No	Yes

### Adjustment

1. Disconnect the connector from the throttle sensor and connect the **SSTs**.
2. Insert a **0.4mm (0.016 in)** feeler gauge between the throttle stop screw and the stop lever.

3. Loosen the two attaching screws.
4. Rotate the throttle sensor clockwise **approx. 30 degrees**, then rotate it back counterclockwise until the buzzer sounds.
5. Replace the feeler gauge with a **0.7mm (0.027 in)** gauge.
6. Verify that the buzzer does not sound.
7. If it sounds, repeat Steps 3 through 6.

8. Tighten the two attaching screws.

### Note

- **Do not move the throttle sensor from the set position when tightening the screws.**

9. Open the throttle valve fully a few times.
10. Recheck the adjustment of the throttle sensor.

### Replacement

1. Disconnect the throttle sensor connector.
2. Remove the throttle sensor mounting screws.
3. Remove the throttle sensor.
4. Install in the reverse order of removal.

### Tightening torque:

**1.6—2.4 N·m (16—24 cm·kg, 13.9—20.8 in·lb)**


## OXYGEN SENSOR

## Caution


- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to page T-113.)

## Inspection of Terminal Voltage


1. Warm up the engine and run it at idle.
2. Disconnect the oxygen sensor connector.
3. Connect a voltmeter between the oxygen sensor and a ground.
4. Run the engine **at 3,000 rpm** until the voltmeter indicates **approx. 0.55V**.
5. Increase and decrease the engine speed suddenly several times. Verify that when the speed is increased the meter reads **0.5V—1.0V**, and when the speed is decreased it reads **0V—0.4V**.
6. If not as specified, replace the oxygen sensor.



05U0FX-217



05U0FX-218




05U0FX-219


## Inspection of Sensitivity

1. Warm up the engine to normal operating temperature.
2. Connect the **SST** to the diagnosis connector.
3. Set the **SST** as shown.
4. Increase the engine speed to **between 2,000 and 3,000 rpm**, and verify that the monitor lamp flashes for **10 sec.**. If not as specified, replace the oxygen sensor. (Refer to page F-139.)

**Monitor lamp: Flashes more than 8 times/10 seconds**




05U0FX-220



05U0FX-221

5. Turn the ignition switch OFF.
6. Disconnect the negative battery terminal and depress the brake pedal for **at least 5 sec.** to eliminate the malfunction code that was created during inspection from the control unit memory.






05U0FX-222

**Replacement**

1. Disconnect the oxygen sensor connector.
2. Remove the oxygen sensor.
3. Install in the reverse order of removal.

**Tightening torque:**

**29—49 N·m (3—5 m·kg, 22—36 ft·lb)**



05U0FX-223


**MAIN RELAY (FUEL INJECTOR RELAY)**

**Inspection**

1. Verify that the main relay clicks when turning the ignition switch OFF → ON.
2. Apply **12V** to terminal A and ground terminal B of the main relay.
3. Use an ohmmeter to check continuity of the terminals as shown.

Terminals	12V not applied	12V applied
C—D	No continuity	Continuity

4. If not as specified, replace the main relay.



05U0FX-224


**CLUTCH SWITCH**

**Inspection**

1. Disconnect the clutch switch connector.
2. Connect an ohmmeter to the switch.
3. Check continuity of the switch.

Pedal	Continuity
Depressed	Yes
Released	No


4. If not as specified, replace the clutch switch.



05U0FX-225

**Replacement**

1. Disconnect the clutch switch connector.
2. Loosen the locknut.
3. Remove the clutch switch.
4. Install in the reverse order of removal.
5. Adjust the pedal height. (Refer to page H-5.)



05U0FX-226

### NEUTRAL SWITCH

#### Inspection


1. Disconnect the neutral switch connector.
2. Connect an ohmmeter to the switch.
3. Check continuity of the switch.

Transmission	Continuity
Neutral	Yes
Other ranges	No

4. If not as specified, replace the neutral switch.

#### Replacement

Replace the neutral switch as shown in the figure.



9MU0F2-240

### POWER STEERING PRESSURE SWITCH

#### Inspection


1. Disconnect the P/S pressure switch connector.
2. Connect an ohmmeter to the switch.
3. Start the engine and let it idle. Check continuity of the switch while turning the steering wheel.

P/S	Continuity
Turning	Yes
Not turning	No


4. If not as specified, replace the P/S pressure switch.

#### Replacement

Replace the P/S pressure switch as shown in the figure.



05U0FX-227




9MU0F2-242

# ENGINE ELECTRICAL SYSTEM

<b>INDEX</b> .....	G- 2
<b>OUTLINE</b> .....	G- 3
SPECIFICATIONS.....	G- 3
<b>TROUBLESHOOTING GUIDE</b> .....	G- 4
<b>CHARGING SYSTEM</b> .....	G- 6
PREPARATION .....	G- 6
CIRCUIT DIAGRAM .....	G- 6
TROUBLESHOOTING .....	G- 7
BATTERY.....	G- 8
ALTERNATOR .....	G-12
SELF-DIAGNOSIS SYSTEM .....	G-12
DRIVE BELT.....	G-15
<b>IGNITION SYSTEM</b> .....	G-17
PREPARATION .....	G-17
CIRCUIT DIAGRAM .....	G-17
TROUBLESHOOTING .....	G-18
IGNITION TIMING .....	G-19
SPARK PLUG.....	G-20
IGNITION COIL.....	G-21
IGNITER .....	G-22
HIGH-TENSION LEAD.....	G-22
<b>STARTING SYSTEM</b> .....	G-23
CIRCUIT DIAGRAM .....	G-23
TROUBLESHOOTING .....	G-23
STARTER.....	G-24
STARTER INTERLOCK SWITCH.....	G-29

## INDEX



05U0GX-002

- |   |  |  |
|---|--|--|
| <p>1. Battery<br/>           Inspection ..... page G- 8<br/>           Recharging ..... page G- 9<br/>           Replacement.... page G-10</p> <p>2. Alternator<br/>           Removal / Installation<br/>           ..... page G-12<br/>           Disassembly / Assembly<br/>           ..... page G-13<br/>           Inspection ..... page G-14</p> <p>3. Drive belt<br/>           Inspection ..... page G-15<br/>           Adjustment..... page G-16</p> | <p>4. Spark plug<br/>           Removal / Installation<br/>           ..... page G-20<br/>           Spark test ..... page G-20<br/>           Inspection ..... page G-20</p> <p>5. Ignition coil<br/>           Inspection ..... page G-21<br/>           Replacement.... page G-21</p> <p>6. Igniter<br/>           Inspection ..... page G-22</p> <p>7. High-tension lead<br/>           Inspection ..... page G-22</p> | <p>8 Starter<br/>           Removal / Installation<br/>           ..... page G-24<br/>           Performance inspection<br/>           ..... page G-25<br/>           Disassembly / Assembly<br/>           ..... page G-26<br/>           Inspection ..... page G-27</p> <p>9. Starter interlock switch<br/>           Inspection ..... page G-29</p> |
|---|--|--|

OUTLINE

SPECIFICATIONS


Item		Engine	B6 DOHC	
Battery	Voltage	V	12, Negative ground	
	Type and capacity (5-hour rate)		S46A24L(S) (32 Ah) Maintenance-free	
Dark current* <sup>1</sup>		mA	20.0	
Alternator	Type		A.C.	
	Output	V, A	12, 60	
	Regulator type		Transistorized (built-in IC regulator)	
	Regulated voltage		14.1—14.7	
	Brush length mm (in)	Standard		21.5 (0.85)
		Minimum		8 (0.31)
Drive belt tension mm (in)	New		8—9 (0.31—0.35)	
	Used		9—10 (0.35—0.39)	
Starter	Type		Conventional	
	Output	V-kW	12-0.95	
	Brush length mm (in)	Standard		17.0 (0.67)
		Minimum		11.5 (0.45)
Ignition system	Type		Electronic spark advance (ESA)	
	Spark advance control		Engine control unit controls spark advance	
Ignition timing		BTDC	10° ± 1° * <sup>2</sup>	
Ignition coil	Type		Molded	
	Primary coil winding	kΩ	0.78—0.94	
	Secondary coil winding	kΩ	11.2—15.2	
Spark plug	Type		NGK : BKR5E-11 BKR6E-11 BKR7E-11 Nippon Denso : K16PR-U11 K20PR-U11 K22PR-U11	
		Plug gap	mm (in)	1.0—1.1 (0.039—0.043)
	Firing order		1—3—4—2	

\*<sup>1</sup> Dark current is the constant flow of current while the ignition switch is OFF (i.e. engine control unit, audio, etc.)

05U0GX-003

\*<sup>2</sup> With System Selector (49 B019 9A0) test switch at SELF TEST.

Cylinder Arrangement



### TROUBLESHOOTING GUIDE

Problem	Page
Will not crank	G-4
Cranks slowly	G-4
Discharged battery	G-5
Misfire	G-5

#### Will not crank

Will not crank

##### Check 1

Check if engine cranks with fully charged battery

YES

Check charging system (Refer to page G-7)

NO

Check if click is heard from starter magnetic switch when ignition turned to START

YES


Check starting system (Refer to page G-23)

NO

Check ignition switch (Refer to page T-21) and starter interlock switch (Refer to page G-29)

05U0GX-004

##### Check 1



#### Cranks slowly

Cranks slowly

##### Check 1

Check if engine cranks with fully charged battery

YES


Check charging system (Refer to page G-7)

NO

Check starting system (Refer to page G-23)

05U0GX-005

##### Check 1



**Discharged battery**

Discharged battery

Check charging system (Refer to page G-7)

05U0GX-006

**Misfire**

Misfire


Check ignition system (Refer to page G-18)

05U0GX-007






## TROUBLESHOOTING



05U0GX-010

### Check 1




### Check 2

Terminal \ Ignition switch	OFF	ON	ON (Idle)
B	Approx. 12V	Approx. 12V	Approx. 14V
L	Approx. 0V	Approx. 1V	Approx. 14V
S	Approx. 12V	Approx. 12V	Approx. 14V

05U0GX-011

### Check 3



BATTERY


Caution

- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to page T-113.)

Inspection

Warning


- The negative battery cable must be removed first and installed last.



05U0GX-012

1. Disconnect the battery cables from the battery.
2. Connect a voltmeter to the battery.

VOLTAGE CHECK



**Terminal and cable**

1. Clean and tighten the battery terminals and cables.
2. Coat the terminals with grease.
3. Inspect for corroded or frayed battery cables.
4. Check the rubber protector on the positive terminal for proper coverage.

05U0GX-014

**Recharging**

Battery	Slow charge (A)	Quick charge (A)
S46A24L(S)	Under 3	Max. 20


**Warning**

- Before performing maintenance or recharging the battery, turn off all accessories and stop the engine.
- The negative battery cable must be removed first and installed last.

**Caution**

- Do not removed vent caps.  
Follow carefully the instructions of the battery charger to prevent overcharging.

1. Remove the battery cover.
2. Disconnect the battery cables from the battery.
3. Measure and record the voltage between the battery terminals.
4. Decide the charging current and charging time by referring to the figure below.
5. Charge the battery.



05U0GX-015

## Replacement


## Note

- The factory-installed battery in the MX-5 Miata cannot be purchased over the counter. When replacing the battery, replace it with a Mazda genuine battery (with vent manifold) or equivalent and use a Mazda genuine battery replacement kit (battery tray, battery clamp, and clamp bolt; Part number NAY1 56 020A) or equivalent.


05U0GX-016

Battery replacement using the Mazda genuine battery replacement kit is as follows.


1. Remove the battery cover.




05U0GX-017



05U0GX-018



05U0GX-019



05U0GX-020

## Warning

- The negative battery cable must be removed first and installed last.


2. Disconnect the battery cables from the battery.
3. Remove the battery clamp.
4. Remove the battery.
5. Disconnect the battery vent hoses.
6. Remove the battery tray.
7. Remove the battery bracket.

8. Reverse the battery clamp bracket as shown.
9. Change the position of the battery bracket (A) to (B) as shown.

## Warning


- Install the battery vent hoses correctly to reduce the possibility of injury or fire.

10. Install the new battery using the battery replacement kit (Part number NAY1 56 020A).




05U0GX-021

11. Trim off the shaded area of the battery cover as shown for proper fitting to new battery.



05U0GX-022

12. Install the battery cover as shown.




05U0GX-023


## ALTERNATOR

### Caution


- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to page T-113.)
- Be sure the battery connections are not reversed because this will damage the rectifier.
- Do not use high-voltage testers such as a megger because they will damage the rectifier.
- Remember that battery voltage is always applied to the alternator B terminal.
- Do not ground the L terminal while the engine is running.
- Do not start the engine while the connector is disconnected from the L and S terminals.



05U0GX-024



05U0GX-025



05U0GX-026

## SELF-DIAGNOSIS SYSTEM

The alternator has a self-diagnostic function to warn of problems in the charging system.

If any of the following problems arise, the alternator warning lamp illuminates.

1. S circuit open.
2. No voltage output.
3. Field circuit open.
4. B circuit open.
5. Voltage output too high.

## Removal / Installation

1. Disconnect the negative battery cable.
2. Disconnect the P/S pressure switch connector.
3. Disconnect the water thermostats connector.
4. Disconnect the ISC valve connector.
5. Remove the air pipe.
6. Disconnect the wire and connector from the alternator.
7. Remove the alternator bolts and nut.
8. Remove the alternator.
10. Install in the reverse order of removal.

## Tightening torque

### Bolt, Nut (1):

37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)

### Bolt (2):


19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)

### Nut (3):

9.8—15 N·m (100—150 cm·kg, 87—130 in·lb)

## Disassembly / Assembly


1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.




N-m (cm-kg, in-lb)

05U0GX-027


- |                           |                           |
|---------------------------|---------------------------|
| 1. Pulley nut             | 6. Brush holder assembly  |
| 2. Pulley                 | Inspection..... page G-15 |
| 3. Front cover            | 7. Brush                  |
| 4. Rotor                  | Inspection..... page G-14 |
| Inspection..... page G-14 | 8. Rectifier              |
| 5. Stator                 | Inspection..... page G-15 |
| Inspection..... page G-14 | 9. Rear cover             |




05U0GX-028




05U0GX-029



05U0GX-030



05U0GX-031



9MU0GX-025

### Inspection

#### Rotor

1. Winding damage
  - (1) Check the resistance between the slip rings with an ohmmeter.

**Specification: 3.5—4.5Ω/20°C (68°F)**

- (2) If it is not within specification, replace the rotor.

2. Ground of field coil

- (1) Check for continuity between each slip ring and the core with an ohmmeter.
- (2) Replace the rotor if there is continuity.

3. Slip ring surface

If the slip ring surface is rough, use fine sandpaper to repair it.

#### Stator

1. Wiring damage

- (1) Check for continuity between the stator coil leads with an ohmmeter.
- (2) Replace the stator if there is no continuity.

2. Ground of stator coil

- (1) Check for no continuity between the stator coil leads and the core with an ohmmeter.
- (2) Replace the stator if there is continuity.


#### Brush

If the brushes are worn almost to or beyond the limit, replace them.

**Standard: 21.5mm (0.846 in)**

**Minimum: 8.0mm (0.315 in)**





05U0GX-032

### Brush Spring

1. Measure the force of the brush spring with a spring pressure gauge.
2. Replace the spring if necessary.


#### Standard force:

**3.1—4.3 N (320—440 g, 11.3—15.5 oz)**

**Minimum: 1.6—2.4 N (160—240 g, 5.6—8.5 oz)**

#### Note

- Read the spring pressure gauge at a brush tip projection of 2mm (0.079 in).




05U0GX-033

### Rectifier


1. Check for continuity of the diodes with an ohmmeter.

Negative (Black)	Positive (Red)	Continuity
E	P <sub>1</sub> , P <sub>2</sub> , P <sub>3</sub>	Yes
B		No
T		No
P <sub>1</sub> , P <sub>2</sub> , P <sub>3</sub>	E	No
	B	Yes
	T	Yes

2. Replace the rectifier if necessary.



05U0GX-034




05U0BX-009

### DRIVE BELT

#### Inspection

1. Remove the air intake pipe.
2. Check the drive belts for wear, cracks, or fraying. Replace if necessary.
3. Verify that the drive belts are correctly mounted on the pulleys.
4. Check the drive belt deflection by applying moderate pressure (**98 N, 10 kg, 22 lb**) midway between the pulleys as shown in the figure. Adjust if necessary.




05U0BX-010


#### Deflection

mm (in)


Drive belt	New	Used
Alternator	8.0—9.0 (0.31—0.35)	9.0—10.0 (0.35—0.39)
P/S, P/S + A/C	8.0—9.0 (0.31—0.35)	9.0—10.0 (0.35—0.39)
A/C	8.0—9.0 (0.31—0.35)	9.0—10.0 (0.35—0.39)




05U0BX-011




05U0BX-012



05U0BX-013



05U0BX-014



05U0BX-015

5. Check the drive belt tension with a tension gauge.

#### Note

- Belt tension can be measured between any pulleys.

#### Tension

N (kg, lb)

Drive belt	New	Used
Alternator	491—589 (50—60, 110—132)	422—491 (43—50, 95—110)
P/S, P/S + A/C	491—589 (50—60, 110—132)	422—491 (43—50, 95—110)
A/C	491—589 (50—60, 110—132)	422—491 (43—50, 95—110)

6. Install the air intake pipe.

#### Adjustment

##### Caution

- If a new belt is used, adjust the belt deflection at the midpoint of new belt specification.

(1) Alternator belt

If necessary, loosen the alternator bolts (A) and (B) and adjust the belt deflection by turning the adjusting bolt (C).

##### Tightening torque

- (A) : 19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)  
 (B) : 37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)

(2) P/S belt, P/S + A/C belt

If necessary, loosen the P/S oil pump bolts (A) and (B) and nut (C), and adjust the belt deflection by turning the adjusting bolt (D).

##### Tightening torque

- (A) : 31—46 N·m (3.2—4.7 m·kg, 23—34 ft·lb)  
 (B) : 36—54 N·m (3.7—5.5 m·kg, 27—40 ft·lb)  
 (C) : 19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)

(3) A/C belt

If necessary, loosen the locknut and adjust the belt deflection by turning the adjusting bolt.

##### Tightening torque:


- 37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)

## IGNITION SYSTEM


### PREPARATION SST

49 F018 002 Igniter checker		For inspection of igniter	49 N018 001 Adapter harness		For inspection of igniter
49 B019 9A0 System selector		For inspection of ignition timing	05U0GX-035		

### CIRCUIT DIAGRAM




### TROUBLESHOOTING





05U0GX-037

**Check 1**




**Check 2**







05U0GX-038




05U0GX-039



05U0GX-040



05U0GX-041



05U0GX-042

**IGNITION TIMING**

1. Check the condition of the engine (spark plugs, leaks in hoses, etc.).
2. Verify that all accessories are OFF.
3. Warm up the engine to the normal operating temperature.

**Note**

- When using an externally powered timing light and/or tachometer connect it to the power connector (Blue: 1-pin).

**Warning**

- Do not ground the power connector terminal (Blue: 1-pin); the wiper 20A fuse will be burned.

4. Connect a timing light and tachometer to the diagnosis connector terminal (1G-).

**Caution**

- Be extremely careful when making connections to the diagnosis connector as a mistaken connection will cause a malfunction.

5. Connect the **SST** and set TEST SW to "SELF TEST" or connect diagnosis connector terminals (TEN) and (GND) with a jumper wire.
6. Check the idle speed, and set it to specification if necessary.

**Idle speed: 850 ± 50 rpm**

7. Check if the timing mark (Yellow) on the crankshaft pulley and the timing belt cover are aligned.


**Ignition timing: 10° ± 1° BTDC (at idle)**

8. If the marks are not aligned, loosen the crank angle sensor lock bolt, and turn the crank angle sensor to make the adjustment.
9. Tighten the crank angle sensor lock bolt to the specified torque.


**Tightening torque:**

**19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)**


10. After adjusting the ignition timing, disconnect the jumper wire or **SST** from the diagnosis connector.




05U0GX-043



05U0GX-044



05U0GX-045



05U0GX-046

- Increase the engine speed and verify that the ignition timing advances.

### SPARK PLUG

#### Removal / Installaion

Note the following points:

- When the high-tension lead is to be pulled off, be sure to pull on the boot, not the wire.
- Apply anti-seize compound or molybdenum-based lubricant to the spark plug threads before installing.
- Tighten the spark plugs to the specified torque.

#### Tightening torque:

**15—23 N·m (1.5—2.3 m·kg, 11—17 ft·lb)**

#### Spark Test


- Disconnect the high-tension lead from the spark plug.
- Connect a new spark plug to the high-tension lead.
- Hold with insulated pliers **approx. 5—10mm (0.20—0.39 in)** from a ground.
- Crank the engine and verify that a strong blue spark is visible.

#### Inspection

Check the following and replace the spark plugs as necessary.

- Damaged insulation.
- Worn electrodes.
- Carbon deposits.  
If cleaning is necessary, use a plug cleaner or a wire brush. Wipe upper insulator.
- Damaged gasket.

**Plug gap: 1.0—1.1mm (0.039—0.043 in)**




05U0GX-047

**IGNITION COIL****Inspection**

1. Disconnect the ignition coil connector.
2. Check for voltage at the positive (+) terminal of the ignition coil connector with the ignition switch in the ON position.

**Voltage: Approx. 12V**

3. If there is no voltage check the main fuse, ignition switch, and wire harness.




05U0GX-048

**Primary coil winding**

Measure resistance of the primary coil winding of each coil with an ohmmeter.

If not within specification, replace the coil.

**Primary coil winding resistance (at 20°C [68°F]):**  
**0.78—0.94Ω**




05U0GX-049

**Secondary coil winding**

Measure resistance of the secondary coil winding of each coil with an ohmmeter.

If not within specification, replace the coil.

**Secondary coil winding resistance (at 20°C [68°F]):**  
**11.2—15.2 kΩ**




05U0GX-050

**Installation of Case**

Use a **500V megger** tester to measure the insulation resistance between the primary terminal and the coil case.

**Resistance : 10 MΩ min.**




05U0GX-051

**Replacement**


1. Disconnect the high tension-leads and ignition coil connector.
2. Remove the installation bolts and the ignition coil.
3. Install in the reverse order of removal.

**Tightening torque:**


**19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)**




05U0GX-052



05U0GX-053



05U0GX-054



05U0GX-055

### IGNITER Inspection

1. Disconnect the igniter connector.

#### Warning

- Do not ground the power connector terminal (Blue: 1-pin), the wiper 20A fuse will be burned.

2. Connect the **SST** between the igniter and igniter connector as shown.
3. Connect the **SST** to the power connector (Blue: 1-pin).
4. Connect a voltmeter between the **SST** (brown wire) and a ground.
5. Turn the ignition switch ON.
6. Verify that there is **approx. 12V** at the terminal.  
If not as specified, check related wiring.

#### Caution

- Do not activate the **SW2** switch for more than 1 sec.

7. Push the **SW2** switch on the **SST** while observing the ohmmeter.
8. Verify that the voltmeter indicates **approx. 8V**.
9. If not as specified, replace the igniter.
10. Disconnect the voltmeter from the brown wire and connect it to the **SST** gray wire.
11. Repeat Steps 5 through 9.

### HIGH-TENSION LEAD Inspection


Use an ohmmeter to measure the resistance of each lead.

**Resistance: 16 k $\Omega$  per 1 m (3.28 ft)**




STARTING SYSTEM

CIRCUIT DIAGRAM




05U0GX-056

TROUBLESHOOTING




05U0GX-057



## Check 1



## Check 2



## Check 3



05U0GX-058

## STARTER

## Caution

- Obtain the code number and deactivate the auto anti-theft system before disconnecting the battery. (Refer to page T-113.)

## Removal / Installation

1. Disconnect the negative battery cable.
2. Disconnect the wiring from the starter.
3. Remove the starter bracket.
4. Raise the front of the vehicle and support it with safety stands.
5. Remove the bolts and the starter.
6. Install in the reverse order of removal.

## Tightening torque:

## Nut (1)


10—12 N·m (105—120 cm·kg, 91—104 in·lb)

## Bolt, Nut (2)


37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)

Bolt (3) 16—23 N·m (1.6—2.3 m·kg, 5.0—7.2 ft·lb)


Bolt (4) 37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)




05U0GX-059



05U0GX-060



05U0GX-061



05U0GX-062

## Performance Inspection

### Pull-out test

Verify that the pinion is pulled out with 12V connected to the S terminal and the starter body grounded.

### Pinion gap check

Measure the pinion gap while the pinion is pulled out.

**Specification: 0.5—2.0mm (0.02—0.08 in)**

Adjust the pinion gap with an adjustment washer (between drive housing front cover and magnetic switch) if it is not within specification.

### Return test

1. Disconnect the motor wire from the M terminal.
2. Connect 12V to the M terminal and ground to the body.
3. Pull out the overrunning clutch with a screwdriver. Verify that it returns to its original position when released.

### No-load test

1. After adjusting the pinion gap, form a test circuit with a voltmeter and an ammeter.

### Note

- Use heavy gauge wires and tighten each terminal fully.


2. Close switch K to run the starter.
3. Check for the following:

Starter type	kW	0.95
Voltage	V	11.5
Current	A	Max. 60
Gear shaft speed	rpm	Min. 6,600

4. If not as specified, check for the cause by referring to Inspection.


**Disassembly / Assembly**

1. Disassemble in the order shown in the figure.
2. Inspect and repair or replace parts as necessary.
3. Assemble in the reverse order of disassembly.




- 1. Magnetic switch  
Inspection..... page G-28
- 2. Rear housing
- 3. Front cover
- 4. Armature  
Inspection..... page G-27


- 5. Yoke assembly  
Inspection..... page G-28
- 6. Brush holder assembly  
Inspection..... page G-28
- 7. Drive pinion




05U0GX-064




05U0GX-065



05U0GX-066



05U0GX-067



05U0GX-068

## Inspection Armature

1. Ground of armature coil  
Check for no continuity between the commutator and the core with an ohmmeter. Check the entire circumference of the commutator. Replace the armature if there is continuity.
2. Insulation of armature coil  
Check for no continuity between the commutator and the shaft with an ohmmeter. Check the entire circumference of the commutator. Replace the armature if there is continuity.
3. Runout of commutator
  - (1) Place the armature on V blocks, and measure the runout with a dial gauge.
  - (2) Repair with a lathe if the runout is small or replace the armature if necessary.


**Runout: 0.03mm (0.001 in)**

4. Outer diameter of commutator  
Replace the armature if the outer diameter of the commutator is at the grind limit or less.
5. Roughness of commutator surface  
If the commutator surface is dirty, wipe it with a cloth; if it is rough, repair it with a lathe or fine sandpaper.


**Grind limit: 30.8mm (1.21 in)**

6. Segment groove depth  
If the depth of the molding between segments is at the depth limit or less, undercut the grooves to the standard depth.


**Standard depth: 0.5—0.8mm (0.020—0.031 in)**  
**Depth limit: 0.2mm (0.008 in)**




05U0GX-069




05U0GX-070



05U0GX-071



05U0GX-072



05U0GX-073

**Yoke assembly**

## 1. Wiring damage of field coil

- (1) Check for continuity between the connector and the brushes with an ohmmeter.
- (2) Replace the yoke assembly if there is no continuity.

## 2. Ground of field coil

- (1) Check for no continuity between the connector and the yoke with an ohmmeter.

- (2) Repair or replace the yoke assembly if there is continuity.

## 3. Installation of field coil

- Replace the yoke assembly if the field coil is loose.

**Magnetic Switch**

## 1. Wiring damage (S terminal — M terminal)

- Check for continuity between terminal S and terminal M with an ohmmeter. Replace the magnetic switch if there is no continuity.


## 2. Wiring damage (S terminal — body)

- Check for continuity between terminal S and the body with an ohmmeter.

- Replace the magnetic switch if there is no continuity.

**Brush and Brush Holder****Insulation of brush holder**

- Check for no continuity between each insulated brush and the plate with an ohmmeter. Replace the brush holder if there is continuity.



05U0GX-077


### Brush

If the brushes are worn beyond the wear limit or if the wear is near the limit, replace the brushes.

**Standard: 17mm (0.67 in)**


**Wear limit: 11.5mm (0.45 in)**

## STARTER INTERLOCK SWITCH



05U0GX-074

The clutch pedal must be depressed during starting for battery power to be supplied to the starter.



05U0GX-075

### Inspection

1. Disconnect the interlock switch connector.
2. Check continuity of the switch with an ohmmeter.

Pedal	Continuity
Depressed	Yes
Released	No


4. If not as specified, replace the interlock switch.

# CLUTCH

<b>INDEX</b> .....	H- 2
<b>OUTLINE</b> .....	H- 3
SPECIFICATIONS.....	H- 3
<b>TROUBLESHOOTING GUIDE</b> .....	H- 3
<b>CLUTCH FLUID</b> .....	H- 4
PREPARATION.....	H- 4
REPLACEMENT.....	H- 4
<b>CLUTCH PEDAL</b> .....	H- 5
ADJUSTMENT.....	H- 5
REMOVAL / INSPECTION / INSTALLATION ..	H- 6
<b>CLUTCH MASTER CYLINDER</b> .....	H- 7
PREPARATION.....	H- 7
REMOVAL / INSTALLATION.....	H- 8
AIR BLEEDING.....	H- 9
OVERHAUL.....	H-10
<b>CLUTCH RELEASE CYLINDER</b> .....	H-12
PREPARATION.....	H-12
REMOVAL / INSTALLATION.....	H-12
AIR BLEEDING (REFER TO PAGE H-9.)	
OVERHAUL.....	H-13
<b>CLUTCH UNIT</b> .....	H-14
PREPARATION.....	H-14
REMOVAL / INSTALLATION.....	H-14
<b>RELEASE BEARING</b> .....	H-17
INSPECTION.....	H-17
<b>CLUTCH COVER</b> .....	H-17
INSPECTION.....	H-17
<b>CLUTCH DISC</b> .....	H-17
INSPECTION.....	H-17
<b>PILOT BEARING</b> .....	H-18
INSPECTION.....	H-18
<b>FLYWHEEL</b> .....	H-18
INSPECTION.....	H-18



## INDEX



05U0HX-002

- |   |   |   |
|---|---|---|
| 1. Clutch pedal<br>Adjustment..... page H- 5<br>Removal /<br>Inspection / Installation<br>..... page H- 6                           | 4. Release bearing<br>Removal / Installation<br>..... page H-14<br>Inspection ..... page H-17 | 7. Clutch disc<br>Removal / Installation<br>..... page H-14<br>Inspection ..... page H-17   |
| 2. Clutch master cylinder<br>Removal / Installation<br>..... page H- 8<br>Overhaul ..... page H-10<br>Air bleeding ..... page H- 9  | 5. Release fork<br>Removal / Installation<br>..... page H-14                                  | 8. Pilot bearing<br>Removal / Installation<br>..... page H-14<br>Inspection ..... page H-18 |
| 3. Clutch release cylinder<br>Removal / Installation<br>..... page H-12<br>Overhaul ..... page H-13<br>Air bleeding ..... page H- 9 | 6. Clutch cover<br>Removal / Installation<br>..... page H-14<br>Inspection ..... page H-17    | 9. Flywheel<br>Removal / Installation<br>..... page H-14<br>Inspection ..... page H-18      |

OUTLINE

SPECIFICATIONS

Item	Engine/Transmission Model		B6 DOHC	
			M5M-D	
Clutch control			Hydraulic	
Clutch cover	Type		Diaphragm spring	
	Set load	N (kg, lb)	4,022 (410, 902)	
Clutch disc	Outer diameter	mm (in)	200 (7.87)	
	Inner diameter	mm (in)	130 (5.12)	
	Thickness	Pressure plate side	mm (in)	3.5 (0.14)
		Flywheel side	mm (in)	3.5 (0.14)
Clutch pedal	Type		Suspended	
	Pedal ratio		6.13	
	Full stroke	mm (in)	120 (4.72)	
	Height	mm (in)	175—185 (6.89—7.28)	
Master cylinder inner diameter	mm (in)		15.87 (0.625)	
Release cylinder inner diameter	mm (in)		19.05 (0.750)	
Clutch fluid			SAE J1703 or FMVSS116 DOT-3	

05U0HX-003


TROUBLESHOOTING GUIDE

Problem	Possible Cause	Action	Page
<b>Slipping</b>	Clutch disc facing worn excessively	Replace	H-14
	Clutch disc facing surface hardened or oil on surface	Repair or replace	H-14
	Pressure plate damaged	Repair or replace	H-14
	Diaphragm spring damaged or weak	Replace	H-14
	Insufficient clutch pedal play	Adjust	H- 5
	Clutch pedal sticking	Repair or replace	H- 6
	Flywheel damaged	Repair or replace	H-14
<b>Faulty disengagement</b>	Excessive runout or damaged clutch disc	Replace	H-14
	Clutch disc splines rusted or worn	Remove rust or replace	H-14
	Oil on facing	Repair or replace	—
	Diaphragm spring weak	Replace	H-14
	Excessive clutch pedal play	Adjust	H- 5
	Insufficient clutch fluid	Add fluid	H- 2
	Leakage of clutch fluid	Locate and repair or replace	—
<b>Clutch vibrates when accelerating</b>	Oil on facing	Repair or replace	H-14
	Torsion rubbers weak	Replace	H-14
	Clutch disc facing hardened or damaged	Repair or replace	H-14
	Clutch disc facing rivets loose	Replace	H-14
	Pressure plate damaged or excessive runout	Replace	H-14
	Flywheel surface hardened or damaged	Repair or replace	H-14
	Loose or worn engine mount	Tighten or replace	—
<b>Clutch pedal sticking</b>	Pedal shaft not properly lubricated	Lubricate or replace	H- 6
<b>Abnormal noise</b>	Clutch release bearing damaged	Replace	H-14
	Poor lubrication of release bearing sleeve	Lubricate or replace	H-14
	Torsion spring weak	Replace	H-14
	Excessive crankshaft end play	Repair	Refer to Section B
	Pilot bearing worn or damaged	Replace	H-14
	Worn pivot points of release fork	Repair or replace	H-14


05U0HX-004

## CLUTCH FLUID


## PREPARATION



05U0HX-005



9MU0HX-006



9MU0HX-007

## REPLACEMENT

## Note

- The fluid in the reserve tank must be maintained at the 3/4 level or higher during replacement.

## Caution


- Be careful not to spill clutch fluid on a painted surface. If this should happen, wash it off immediately.
- Do not mix different brands of clutch fluid.
- Do not reuse the clutch fluid which was drained out.

1. Draw the fluid from the reserve tank with a suction pump.
2. Remove the bleeder cap from the clutch release cylinder and attach a vinyl hose to the bleeder plug.
3. Place the other end of the vinyl hose in a container.
4. Slowly pump the clutch pedal several times.
5. With the clutch pedal depressed, loosen the bleeder screw with the **SST** to let fluid escape. Close the bleeder screw with the **SST**.
6. Repeat Steps 4 and 5 until only clean fluid is seen.
7. Tighten the bleeder screw.

## Tightening torque:

**5.9—8.8 N·m (60—90 cm·kg, 52—78 in·lb)**

8. Add fluid to the MAX mark.
9. Check for correct clutch operation.



## CLUTCH PEDAL

### ADJUSTMENT

#### Clutch Pedal Height Inspection

Measure the distance from the upper surface of the pedal pad to the carpet.

**Pedal height: 175—185mm (6.89—7.28 in)  
(With carpet)**

If necessary, adjust the pedal height.

#### Adjustment

1. Loosen locknut (A) and turn clutch switch (B) until the height is correct.
2. Tighten locknut (A).

#### Tightening torque:

**14—18 N-m (1.4—1.8 m-kg, 10—13 ft-lb)**

3. After adjustment, inspect the pedal free play.

### Clutch Pedal Free Play Inspection

#### Inspection

Depress the clutch pedal by hand until clutch resistance is felt.

**Pedal free play: 0.6—3.1mm (0.02—0.12 in)  
Total pedal free play: 5—13mm (0.20—0.51 in)**

If necessary, adjust the pedal free play.

#### Adjustment

1. Loosen locknut (C) and turn push rod (D) until pedal free play is correct.
2. Verify that the disengagement height as measured from the upper surface of the pedal to the carpet is correct when the pedal is fully depressed.

**Minimum disengagement height: 68mm (2.68 in)  
(With carpet)**

3. Tighten locknut (C).

#### Tightening torque:

**12—17 N-m (1.2—1.7 m-kg, 8.7—12 ft-lb)**

4. After adjustment, inspect the pedal height.


### REMOVAL / INSPECTION / INSTALLATION

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Inspect all parts and repair or replace as necessary.

#### Note


- Apply lithium based grease to the bushings and pin when installing.

3. Install in the reverse order of removal, referring to **Installation Note**.



05U0HX-007

- |   |  |                 |
|---|--|-----------------|
| 1. Spring<br>Removal Note.... page H-7<br>Installation Note, page H-7 | 5. Clutch pedal                                  | 9. Clip         |
| 2. Nut and lock washer  | 6. Bushings<br>Inspect for damage and<br>bending | 10. Wave washer |
| 3. Bolt   | 7. Push rod                                      | 11. Pin         |
| 4. Spacer   | 8. Nut   | 12. Spacer      |
|   |  | 13. Stop        |
|   |  | 14. Pedal pad   |




05U0HX-008

## Removal Note Spring

### Note

- Use pads in the vise to prevent damaging the clutch master cylinder bracket.

1. Place the clutch pedal assembly in the vise.
2. Pry the spring off the clutch pedal as shown in the figure.



05U0HX-009

## Installation Note Spring

### Note


- Use pads in the vise to prevent damaging the clutch master cylinder bracket.

1. Place the clutch pedal assembly in the vise.
2. Pry the spring on the clutch pedal as shown in the figure.
3. Adjust the clutch pedal height and free play after installation. (Refer to page H-5.)

## CLUTCH MASTER CYLINDER

### PREPARATION

#### SST

<p>49 0259 770B</p> <p>Wrench, flare nut</p> 	<p>For disconnecting and connecting clutch pipe</p>
--	---


05U0HX-010

### REMOVAL / INSTALLATION

#### Caution

- Clutch fluid will damage painted surfaces. Be sure to use a container or rags to collect it. If fluid does get on a painted surface, wipe it off immediately with a rag.


1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.



N·m (m·kg, ft·lb)

05U0HX-011

- |  |   |                  |
|--|---|------------------|
| <p>1. Clutch pipe<br/>Removal Note.. page H- 8<br/>Installation Note page H- 8</p> <p>2. Nut</p> | <p>3. Clutch master cylinder<br/>Check for fluid leakage<br/>from cylinder bore<br/>Overhaul..... page H-10<br/>Air bleeding .... page H- 9</p> | <p>4. Gasket</p> |
|--|---|------------------|



9MU0HX-013

#### Removal Note Clutch pipe

Disconnect the clutch pipe with the **SST**.

#### Installation Note Clutch pipe

Tighten the clutch pipe with the **SST**.

#### Tightening torque:


**13—22 N·m (1.3—2.2 m·kg, 9.4—16 ft·lb)**

#### Air Bleeding


After installation, bleed the clutch system.  
(Refer to page H-9.)

#### Inspection and Adjustment


**Clutch pedal height and free play**  
(Refer to page H-5.)



05U0HX-012



9MU0HX-049



49 0259 770B

97U0HX-010

**AIR BLEEDING**

The clutch hydraulic system must be bled to remove air introduced whenever a hydraulic line is disconnected.

**Note**

- The fluid in the reserve tank must be maintained at the 3/4 level or higher during air bleeding.

**Caution**

- Clutch fluid will damage a painted surface. If fluid does get on a painted surface, wipe it off immediately.
- Do not mix different brands of clutch fluid.
- Do not reuse the clutch fluid which was drained out.

1. Remove the bleeder cap from the clutch release cylinder and attach a vinyl hose to the bleeder plug.
2. Insert the other end of the vinyl hose in a clear container.
3. Slowly pump the clutch pedal several times.
4. While depressing the pedal, loosen the bleeder screw with the **SST** to let fluid and air escape.  
Close the bleeder screw with the **SST**.
5. Repeat Steps 3 and 4 until no air bubbles are seen in the fluid.
6. Tighten the bleeder screw.

**Tightening torque:**

**5.9—8.8 N·m (60—90 cm·kg, 52—78 in·lb)**

7. Check for correct clutch operation.
8. Verify that there is no fluid leakage.




### OVERHAUL

#### Caution


- Clean the disassembled parts in solvent and blow through all ports and passages with compressed air.

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




05U0HX-013

- |   |   |
|---|---|
| <ol style="list-style-type: none"> <li>1. Snap ring<br/>Disassembly Note ..... page H-11<br/>Assembly Note ..... page H-11</li> <li>2. Piston and secondary cup assembly<br/>Disassembly Note ..... page H-11<br/>Inspect for wear, scoring, and cracks<br/>Assembly Note ..... page H-11</li> <li>3. Spacer</li> <li>4. Primary cup<br/>Inspect for wear and cracks</li> </ol> | <ol style="list-style-type: none"> <li>5. Return spring</li> <li>6. Tank cap baffle</li> <li>7. Packing</li> <li>8. Reserve tank</li> <li>9. Bushing</li> <li>10. Master cylinder body<br/>Inspect cylinder bore for scoring and corrosion</li> </ol> |
|---|---|



9MU0HX-018



9MU0HX-019

### Disassembly Note Snap ring

#### Note

- Do not damage the push rod contact surface of the piston.

Press down on the piston and remove the snap ring with snap-ring pliers.

### Piston and secondary cup assembly

#### Caution

- Hold a rag over the master cylinder to prevent the piston and secondary cup assembly from jumping out.


Remove the piston and secondary cup assembly, spacer, and primary cup by applying compressed air through the clutch pipe installation hole.

### Assembly Note


#### Caution

- Before assembly, make sure all parts are completely clean.
- Do not mix different brands of clutch fluid.
- Do not reuse the clutch fluid which was drained out.
- Apply the specified clutch fluid to the piston and secondary cup assembly, spacer, primary cup, and cylinder bore before assembly.
- Replace parts with new ones whenever specified to do so.

9MU0HX-021



05U0HX-014



9MU0HX-023

### Piston and secondary cup assembly

Install the spring, primary cup, spacer, and piston and secondary cup assembly, noting the proper direction of the parts. (Refer to page H-10.)

### Snap ring


#### Note

- Do not damage the push rod contact surface of the piston.

While pressing the piston, install the snap ring.

### CLUTCH RELEASE CYLINDER

#### PREPARATION SST

<p>49 0259 770B</p> <p>Wrench, flare nut</p> 	<p>For disconnecting and connecting clutch pipe</p>
--	---


05U0HX-015

#### REMOVAL / INSTALLATION

##### Caution


- Clutch fluid will damage painted surfaces. Be sure to use a container or rags to collect it. If fluid does get on a painted surface, wipe it off immediately with a rag.

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.



05U0HX-016

- |   |   |
|---|---|
| <p>1. Clutch pipe</p> <p>Removal Note ..... page H-12</p> <p>Installation Note..... page H-13</p> | <p>3. Clutch release cylinder</p> <p>Remove boot and check for fluid leakage</p> <p>Overhaul..... page H-13</p> |
| <p>2. Bolt</p>  |   |




05U0HX-017

#### Removal Note Clutch pipe

##### Caution

- After disconnecting the clutch pipe, plug it to prevent fluid leakage.

Disconnect the clutch pipe with the **SST**.



05U0HX-018

### Installation Note

#### Clutch pipe

Tighten the clutch pipe with the **SST**.

#### Tightening torque:

**13—22 N·m (1.3—2.2 m·kg, 9.4—16 ft·lb)**

#### Air Bleeding

After installation, bleed the clutch system.


(Refer to page H-9.)

## OVERHAUL

### Caution

- Clean the disassembled parts in solvent and blow through all ports and passages with compressed air.
- Before assembly, make sure all parts are completely clean.
- Apply the specified clutch fluid to the piston and cup assembly and cylinder bore before assembly.

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly.




05U0HX-019

1. Boot
2. Push rod
3. Piston and cup assembly  
Disassembly  
Note..... page H-13  
Inspect for wear, scoring,  
and cracks

4. Spring
5. Bleeder cap
6. Bleeder screw
7. Steel ball

8. Release cylinder body  
Inspect cylinder bore for  
scoring and corrosion



05U0HX-020

### Disassembly Note

#### Piston and cup assembly

### Caution







- Hold a rag over the release cylinder to prevent the piston and cup assembly from jumping out.

Remove the piston and cup assembly by applying compressed air through the clutch pipe installation hole.

### CLUTCH UNIT

#### PREPARATION

#### SST

<p>49 E301 060 Brake, ring gear</p> 	<p>For holding ring gear</p>	<p>49 E301 061 Body (Part of 49 E301 060)</p> 	<p>For holding ring gear</p>
<p>49 E301 062 Collar (Part of 49 E301 060)</p> 	<p>For holding ring gear</p>	<p>49 SE01 310 Clutch disc centering tool</p> 	<p>For removal and installation of clutch disc</p>
<p>49 1285 071 Puller, bearing</p> 	<p>For removal of pilot bearing</p>	<p>49 1285 073 Chuck (Part of 49 1285 073)</p> 	<p>For removal of pilot bearing</p>

05U0HX-021


### REMOVAL / INSTALLATION

#### Note

- Remove the clutch release cylinder with the clutch pipe connected.
- Do not remove the pilot bearing if not necessary.


1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.

05U0HX-022



- 1. Clutch release cylinder
- 2. Transmission  
Service..... Section J
- 3. Boot
- 4. Release bearing  
Inspection..... page H-17
- 5. Release fork
- 6. Clutch cover  
Removal Note ..... page H-16  
Inspection..... page H-17  
Installation Note..... page H-17

- 7. Clutch disc  
Removal Note ..... page H-16  
Inspection..... page H-17  
Installation Note..... page H-17
- 8. Pilot bearing  
Inspection..... page H-18  
Removal Note ..... page H-16  
Installation Note..... page H-16
- 9. Flywheel  
Removal Note ..... page H-16  
Inspection..... page H-18  
Installation Note..... page H-16




97U0HX-016

### Removal Note

#### Clutch cover and disc

1. Install the **SST**.
2. Loosen each bolt one turn at a time in a crisscross pattern until spring tension is released. Then remove the clutch cover and disc.




05U0HX-024

### Flywheel

#### Note

- After removing the flywheel, inspect for oil leakage past the crankshaft rear oil seal. If necessary, replace the oil seal. (Refer to Section B.)


1. Hold the flywheel with the **SST**.
2. Remove the flywheel.



05U0HX-025

### Pilot bearing

Remove the pilot bearing with the **SST**, if necessary.



05U0HX-026


### Installation Note

#### Flywheel

1. Wipe the bolts clean, and apply sealant to the bolt threads.
2. Install the flywheel and **SST**.
3. Tighten the bolts in the pattern shown.

#### Tightening torque:

96—103 N·m (9.8—10.5 m·kg, 71—76 ft·lb)




05U0HX-027

### Pilot bearing


#### Note

- Install the pilot bearing flush with the flywheel.


Install the new bearing with a suitable pipe.




05U0HX-029




05U0HX-030



9MU0HX-040



05U0HX-031



05U0HX-032

## Clutch disc

1. Clean the clutch disc splines and main drive gear splines, and apply Mori White TA No.2 or equivalent organic molybdeum grease.
2. Hold the clutch disc in position with the **SST**.

## Clutch cover

1. Install the **SST**.
2. Align the dowel holes with the flywheel dowels.
3. Tighten the bolts evenly and gradually in the pattern shown.

### Tightening torque:

18—26 N·m (1.8—2.7 m·kg, 13—20 ft·lb)

## RELEASE BEARING

### INSPECTION

#### Note

- The clutch release bearing is a sealed bearing and must not be washed in solvent.

Turn the bearing while applying force in the axial direction. If the bearing sticks or has excessive resistance, replace it.

## CLUTCH COVER

### INSPECTION

#### Note

- Minor scoring or burning should be removed with emery paper.

1. Inspect the contact surface of the clutch disc for scoring, cracks, and burning, repair or replace as necessary.
2. Inspect the contact surface of the clutch release bearing for wear and cracks.
3. If there is wear or cracks, replace the clutch cover.

## CLUTCH DISC


### INSPECTION

#### Note

- Use sandpaper if the trouble is minor.

1. Inspect the lining surface for burning and oil contamination. Replace the clutch disc if it is badly burned or oil soaked.
2. Inspect for loose facing rivets or torsion rubbers. Replace the clutch disc if any are loose.






05U0HX-033

3. Measure the thickness of the lining at a rivet head on both sides with vernier calipers. Replace the clutch disc if less than minimum.


**Minimum thickness: 0.3mm (0.012 in)**



97U0HX-024

4. Measure the clutch disc runout with a dial indicator. Replace the clutch disc if runout is excessive.

**Maximum runout: 0.7mm (0.028 in)**




05U0HX-028

## PILOT BEARING

### INSPECTION

Turn the bearing while applying force in the axial direction. If the bearing sticks or has excessive resistance, replace it.



9MU0HX-046

## FLYWHEEL

### INSPECTION

#### Note


- **Minor scoring or burning should be removed with emery paper.**

1. Inspect the contact surface of the clutch disc for scoring, cracks, or burning, repair or replace as necessary.


#### Note

- **The beveled side of the ring gear must face the engine side.**

2. Inspect the ring gear teeth for wear or damage. If necessary, replace the ring gear as follows:
  - (1) Heat the ring gear with a blowtorch. Tap around the gear to remove it from the flywheel.
  - (2) Heat the new ring gear to **250—300°C (480—570°F)**; then fit it onto the flywheel.



9MU0HX-047



9MU0HX-048

3. Measure the flywheel runout with a dial indicator. Replace the flywheel if runout is excessive.


**Maximum runout: 0.2mm (0.008 in)**

# MANUAL TRANSMISSION

<b>INDEX</b> .....	J- 2
<b>OUTLINE</b> .....	J- 3
SPECIFICATIONS .....	J- 3
STRUCTURAL VIEW.....	J- 4
COMPONENTS .....	J- 5
POWERFLOW .....	J- 6
<b>TROUBLESHOOTING GUIDE</b> .....	J- 7
<b>TRANSMISSION OIL</b> .....	J- 8
INSPECTION.....	J- 8
REPLACEMENT .....	J- 8
<b>TRANSMISSION</b> .....	J- 9
PREPARATION.....	J- 9
REMOVAL .....	J-10
DISASSEMBLY .....	J-13
INSPECTION.....	J-23
ASSEMBLY.....	J-26
INSTALLATION .....	J-45

05U0JX-001

INDEX



OIL SPECIFICATION  
 API SERVICE GL-4 OR GL-5  
 ALL-SEASON TYPE: SAE 75W-90  
 ABOVE 10°C (50°F): SAE 80W-90  
 CAPACITY LITERS (US qt, Imp qt): 2.0 (2.1, 1.8)

05U0JX-002

1. Transmission	
Removal.....	page J-10
Disassembly.....	page J-13

Inspection.....	page J-23
Assembly.....	page J-26
Installation.....	page J-45



OUTLINE

SPECIFICATIONS

Item		Transmission model	M-type
Synchronization mechanism			Forward: Synchromesh Reverse: Synchromesh
Shift type			5-speed, floor shift
Shift pattern			
Gear ratio	1st		3.136
	2nd		1.888
	3rd		1.330
	4th		1.000
	5th		0.814
	Reverse		3.758
Oil	Grade		API service GL-4 or GL-5
	Viscosity	All-season	SAE 75W-90
		Above 10°C (50°F)	SAE 80W-90
	Capacity	liters (US qts, Imp qts)	2.0 (2.1, 1.8)

05U0JX-003

STRUCTURAL VIEW




VIEW A—A

9MU0JX-004

- 1. Main drive gear (4th gear)
- 2. 3rd gear
- 3. 2nd gear
- 4. 1st gear
- 5. 5th gear
- 6. Countershaft

- 7. Counter 5th gear
- 8. Mainshaft
- 9. Reverse gear
- 10. Reverse idler gear
- 11. Counter reverse gear







COMPONENTS



05U0JX-004

- |                                     |                                 |                          |
|-------------------------------------|---------------------------------|--------------------------|
| 1. Front cover                      | 6. Shift fork and rod (1st/2nd) | 12. Reverse idler gear   |
| 2. Transmission case                | 7. Shift fork and rod (3rd/4th) | 13. 5th gear             |
| 3. Intermediate housing             | 8. Mainshaft gear assembly      | 14. Reverse gear         |
| 4. Extension housing                | 9. Main drive gear              | 15. Counter 5th gear     |
| 5. Shift fork and rod (5th/Reverse) | 10. Bearing housing             | 16. Counter reverse gear |
|                                     | 11. Countershaft                |                          |

POWERFLOW





**TROUBLESHOOTING GUIDE**

Problem	Possible Cause	Action	Page
<b>Abnormal noise</b>	Insufficient oil	Add oil	J- 8
	Deterioration of oil quality	Replace with specified oil	J- 8
	Worn bearing	Replace	J-24
	Worn contact surface of countershaft gear	Replace	J-23
	Worn contact surface of gears	Replace	J-23
	Excessive gear backlash	Replace	—
<b>Difficult to shift</b>	Damaged gear teeth	Replace	J-23
	Insufficient oil	Add oil	J- 8
	Deterioration of oil quality	Replace with specified oil	J- 8
	Worn synchronizer ring	Replace	J-24
	Worn synchronizer cone of gear	Replace	J-24
	Poor contact of synchronizer ring and gear cone	Replace	J-24
<b>Jumps out of gear</b>	Excessive longitudinal play of gears	Replace	J-23
	Worn bearing	Replace	J-24
	Improper disengagement of clutch	Refer to Section H	—
	Weak detent ball spring	Replace	J-25
	Worn shift fork	Replace	J-24
	Worn clutch hub	Replace	J-23
<b>Vibration</b>	Worn clutch hub sleeve	Replace	J-23
	Worn gears	Replace	J-23
	Excessive gear backlash	Replace	—
	Worn bearing	Replace	J-24
	Incorrect installation of or loose power plant frame	Correct or tighten	J-45

05U0JX-005

## TRANSMISSION OIL

## INSPECTION

1. Remove check plug (A).
2. Verify that the oil is at the bottom of the check plug hole. If it is low, add the specified oil from check plug (A).
3. Wipe clean and apply sealant to the plug threads before installing.

## Tightening torque:

(A): 25—39 N·m (2.5—4.0 m·kg, 18—29 ft·lb)

## REPLACEMENT

## Note

- Replace drain plug (B) washer with a new one whenever the drain plug is removed.

1. Remove the plugs (A) and (B) with washer.
2. Drain the oil into a suitable container.
3. Wipe all plugs clean.
4. Apply sealant to plug thread (A).
5. Install the drain plug (B) with new washer.

## Tightening torque:

(B): 39—59 N·m (4.0—6.0 m·kg, 29—43 ft·lb)

6. Add the specified oil from check plug (A) port until the level reaches the bottom of check plug hole.

## Specified oil:

API service GL-4 or GL-5


All-season: SAE 75W-90

Above 10°C (50°F): SAE 80W-90


7. Install plug (A).

## Tightening torque:


(A): 25—39 N·m (2.5—4.0 m·kg, 18—29 ft·lb)




05U0JX-006



9BU0J1-006



















05U0JX-007



9BU0J1-008

## TRANSMISSION

### PREPARATION SST


<p>49 0839 425C</p> <p>Puller set, bearing</p> 	<p>For removal of bearing</p>	<p>49 0500 330</p> <p>Installer, transmission bearing</p> 	<p>For installation of bearing</p>
<p>49 0636 145</p> <p>Puller, fan pulley boss</p> 	<p>For removal of clutch hub assembly</p>	<p>49 0259 440</p> <p>Holder, mainshaft</p> 	<p>For holding mainshaft</p>
<p>49 0862 350</p> <p>Guide, shift fork</p> 	<p>For installation of interlock pin</p>	<p>49 1243 465A</p> <p>Wrench, mainshaft locknut</p> 	<p>For removal of locknut</p>
<p>49 H017 101</p> <p>Hook</p> 	<p>For removal of bearing</p>	<p>49 0710 520</p> <p>Puller, bearing</p> 	<p>For removal of bearing</p>
<p>49 0305 430</p> <p>Pusher, main drive shaft</p> 	<p>For removal of transmission case</p>	<p>49 0180 321A</p> <p>Installer, bearing</p> 	<p>For installation of bearing</p>
<p>49 0187 451A</p> <p>Guide, interlock pin</p> 	<p>For installation of spring and ball</p>	<p>49 F401 330B</p> <p>Installer set, bearing</p> 	<p>For installation of bearing</p>
<p>49 F401 331</p> <p>Body (Part of 49 F401 330B)</p> 	<p>For installation of clutch hub assembly</p>	<p>49 B025 0A0</p> <p>Installer, oil seal</p> 	<p>For installation of dust seal</p>
<p>49 G030 797</p> <p>Handle (Part of 49 B025 0A0)</p> 	<p>For installation of oil seal</p>	<p>49 B025 001</p> <p>Body (Part of 49 B025 0A0)</p> 	<p>For installation of oil seal</p>

### REMOVAL

#### Caution


- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to page T-111.)

1. Disconnect the negative battery cable.
2. Raise the vehicle and support it with safety stands.
3. Drain the transmission oil into a suitable container.
4. Remove in the order shown in the figure, referring to **Removal Note**.



05U0JX-009


- |                     |                            |                             |
|---------------------|----------------------------|-----------------------------|
| 1. Shift lever knob | 5. Exhaust pipe            | 9. Speedometer cable        |
| 2. Rear console     | 6. Propeller shaft         | 10. Power plant frame (PPF) |
| 3. Shift lever      | Removal Note... page J-11  | Removal Note... page J-11   |
| 4. Undercover       | 7. Clutch release cylinder | 11. Transmission            |
|                     | 8. Starter                 | Removal Note... page J-12   |



05U0MX-065


### Removal note Propeller shaft

1. Before removing the propeller shaft, mark the flanges for correct installation.



05U0MX-066


2. When the propeller shaft is removed from the extension housing, immediately install the **SST** to prevent oil leakage.



05U0MX-067


### Power plant frame (PPF)

1. Disconnect the wire harness from the PPF.
2. Support the transmission with a jack.




05U0MX-068

3. Remove the power plant frame bracket.




05U0MX-069


4. Remove the differential-side bolts, and pry out the spacer.



05U0MX-125



05U0MX-070



05U0MX-071

5. Remove the differential mounting spacer.

6. Turn a bolt (M14x1.5) into the sleeve.

7. Twist and pull the bolt downward.

8. Install a bolt (M6x1) into the hole in the block to hold the sleeve, and remove the long bolt (M14x1.5).

9. Remove the bolt (M6x1).

### Caution

- Do not remove the spacers shown in the figure from the PPF.
- If they are removed, replace the PPF as an assembly.

10. Remove the transmission-side bolts, and remove the PPF.

### Transmission

#### Caution

- Do not violently shake the transmission, the crank angle sensor may be damaged.

05U0JX-010

## DISASSEMBLY

### Precaution


1. Clean the transmission exterior thoroughly with a steam cleaner or cleaning solvent before disassembly.
2. Clean the removed parts (except sealed bearings) and all sealing surfaces with cleaning solvent, and dry with compressed air.  
Clean out all holes and passages with a compressed air, and check that there are no obstructions.
3. Wear eye protection when using compressed air to clean components.

### Housing Components

#### Note


- Do not remove the front and rear oil seals if not necessary.

Disassemble in the order shown in the figure, referring to **Disassembly Note**.



05U0JX-011


- |  |  |   |
|--|--|---|
| <ol style="list-style-type: none"> <li>1. Release bearing</li> <li>2. Release fork</li> <li>3. Boot</li> <li>4. Front cover</li> <li>5. Gasket</li> <li>6. Oil seal (front)<br/>Inspect for damage of oil seal lip. If necessary, replace it.</li> <li>7. Adjustment shim</li> </ol> | <ol style="list-style-type: none"> <li>8. Snap ring</li> <li>9. Speedometer driven gear</li> <li>10. Neutral switch</li> <li>11. Back-up light switch</li> <li>12. Extension housing<br/>Disassembly Note<br/>..... page J-14<br/>Disassembly ..... page J-22</li> <li>13. Transmission case<br/>Disassembly Note<br/>..... page J-14</li> </ol> | <ol style="list-style-type: none"> <li>14. Snap rings</li> <li>15. Speedometer drive gear</li> <li>16. Steel ball</li> <li>17. Oil seal (rear)<br/>Inspect for damage of oil seal lip<br/>If necessary, replace it.<br/>Replace (on-vehicle)<br/>..... page J-14</li> </ol> |
|--|--|---|



05U0JX-012

### Disassembly note Extension housing


Turn the extension housing to remove it.



9BU0J1-013

### Transmission case

Remove the transmission case from the intermediate housing and gear assembly with the **SST**.




05U0JX-013

### On-vehicle replacement Oil seal (rear)

#### Caution


- Do not damage the mainshaft splines.

1. Raise the vehicle and support it with safety stands.
2. Drain the transmission oil into a suitable container.
3. Remove the exhaust pipe.
4. Remove the propeller shaft. (Refer to Section L.)
5. Remove the oil seal from the extension housing.



05U0JX-014

6. Apply transmission oil to outer periphery.
7. Install a new oil seal with the **SST**.




05U0JX-015

8. Install the propeller shaft. (Refer to Section L.)
9. Install the exhaust pipe.
10. Add the specified oil from check plug (A) port until the level reaches the bottom of the check plug hole. (Refer to page J-8.)




**Shift Fork and Shift Rod Parts**

Disassemble in the order shown in the figure, referring to **Disassembly Note**.



05U0JX-016

- |                              |                            |                            |
|------------------------------|----------------------------|----------------------------|
| 1. Roll pin                  | 9. Clip                    | 17. Clip                   |
| 2. 1st/2nd shift rod end     | 10. 1st/2nd shift rod      | Disassembly Note           |
| 3. 3rd/4th shift rod end     | 11. Interlock pin          | ..... page J-15            |
| 4. 5th/Reverse shift rod end | 12. Clip                   | 18. Spacer                 |
| 5. Intermediate housing      | 13. 3rd/4th shift rod      | 19. Spring                 |
| Inspection ..... page J-25   | 14. 3rd/4th shift fork     | Inspection ..... page J-25 |
| 6. Roll pin                  | Inspection ..... page J-24 | 20. 5th/Reverse shift rod  |
| 7. Cap plug                  | 15. 1st/2nd shift fork     | 21. 5th/Reverse shift fork |
| 8. Spring and ball           | Inspection ..... page J-24 | Inspection ..... page J-24 |
| Inspection ..... page J-25   | 16. Interlock pin          | 22. Spring and ball        |
|                              |                            | Inspection ..... page J-25 |



97U0J1-016

**Disassembly note**

**Clip**


**Caution**

- Hold the spacer and spring to prevent it from jumping out.

Remove the clip, spacer, and spring from the 5th/Reverse shift rod.


### Mainshaft and Countershaft Parts

Disassemble in the order shown in the figure, referring to **Disassembly Note**.




- |  |  |  |
|--|--|--|
| <p>1. Snap ring<br/>2. Washer<br/>3. Retaining ring<br/>4. C-washer<br/>5. Mainshaft rear bearing<br/>    Disassembly Note<br/>    ..... page J-17<br/>    Inspection ..... page J-24<br/>6. Retaining ring<br/>7. C-washer<br/>8. Thrust lock washer<br/>9. Steel ball<br/>10. Locknut (Countershaft)<br/>    Disassembly Note<br/>    ..... page J-17<br/>11. Countershaft rear bearing<br/>    Disassembly Note<br/>    ..... page J-18<br/>    Inspection ..... page J-24<br/>12. Counter 5th gear<br/>    Inspection ..... page J-23<br/>13. Spacer<br/>14. 5th gear<br/>    Inspection ..... page J-23</p> | <p>15. Synchronizer ring (5th)<br/>    Inspection ..... page J-24<br/>16. Locknut (Mainshaft)<br/>    Disassembly Note<br/>    ..... page J-18<br/>17. Clutch hub assembly<br/>    (5th/Reverse)<br/>    Inspection ..... page J-23<br/>18. Synchronizer ring (Reverse)<br/>    Inspection ..... page J-24<br/>19. Reverse gear<br/>    Inspection ..... page J-23<br/>20. Needle bearing<br/>    Inspection ..... page J-24<br/>21. Inner race<br/>22. Washer<br/>23. Counter reverse gear<br/>    Inspection ..... page J-23<br/>24. Main drive gear bearing<br/>    Disassembly Note<br/>    ..... page J-18<br/>    Inspection ..... page J-24<br/>25. Snap ring</p> | <p>26. Countershaft front bearing<br/>    Disassembly Note<br/>    ..... page J-18<br/>    Inspection ..... page J-24<br/>27. Bearing housing assembly<br/>    Disassembly Note<br/>    ..... page J-18<br/>    Disassembly ..... page J-20<br/>28. Mainshaft gear assembly<br/>29. Main drive gear<br/>    Inspection ..... page J-23<br/>30. Synchronizer ring (4th)<br/>    Inspection ..... page J-24<br/>31. Needle bearing<br/>    Inspection ..... page J-24<br/>32. Washer<br/>33. Countershaft<br/>    Inspection ..... page J-23<br/>34. Synchronizer key spring<br/>35. Clutch hub sleeve<br/>36. Synchronizer key<br/>37. Clutch hub</p> |
|--|--|--|


05U0JX-017



05U0JX-018



97U0J1-020



97U0J1-021

### Disassembly note Mainshaft rear bearing

Remove the mainshaft rear bearing with the **SST**.

### Locknut (Countershaft)

1. Shift the clutch hub sleeves to first gear and reverse gear to put the gears in the double-engaged condition.

#### Caution


- Do not reuse the locknut.
- Do not damage the countershaft.

2. Use a suitable tool to uncrimp the tabs of the locknut.

#### Note

- Use pads in the vise to prevent damaging the **SST**.


3. Connect the **SST** to the mainshaft and tighten it securely in a vise.
4. Remove the locknut.



97U0J1-022

**Countershaft rear bearing**

Remove the countershaft rear bearing with the **SST**.



05U0JX-019


**Locknut (Mainshaft)**

1. Shift the clutch hub sleeves to first gear and reverse gear to put the gears in the double-engaged condition.

**Caution**

- Do not reuse the locknut.
- Do not damage the mainshaft and clutch hub assembly.

2. Use a suitable tool to uncrimp the tabs of the locknut.



97U0J1-024

**Note**


- Use pads in the vise to prevent damaging the bearing housing.

3. Secure the bearing housing in a vise.

4. Remove the locknut with the **SST**.

**Main drive gear bearing**


Remove the main drive gear bearing with a suitable pipe.



97U0J1-025

**Countershaft front bearing**

Remove the countershaft front bearing with the **SST**.




97U0J1-026

**Bearing housing assembly**

Remove the bearing housing by lightly tapping the countershaft with a copper hammer.


**Mainshaft Parts**

Disassemble in the order shown in the figure, referring to **Disassembly Note**.



05U0JX-020

- |  |  |   |
|--|--|---|
| 1. 1st gear<br>Inspection ..... page J-23  | 7. Synchronizer ring (3rd)<br>Inspection ..... page J-24                   | 12. Mainshaft<br>Inspection ..... page J-23 |
| 2. Needle bearing<br>Inspection ..... page J-24  | 8. 3rd gear<br>Inspection ..... page J-23                                  | 13. Synchronizer key spring                 |
| 3. Inner race  | 9. Clutch hub assembly<br>(1st/2nd)<br>Disassembly Note<br>..... page J-20 | 14. Clutch hub sleeve                       |
| 4. Synchronizer ring (1st)<br>Inspection ..... page J-24   | 10. Synchronizer ring (2nd)<br>Inspection ..... page J-24                  | 15. Synchronizer key                        |
| 5. Snap ring   | 11. 2nd gear<br>Inspection ..... page J-23                                 | 16. Clutch hub                              |
| 6. Clutch hub assembly<br>(3rd/4th)<br>Disassembly Note<br>..... page J-20<br>Inspection ..... page J-23 |  |   |



97U0J1-028

**Disassembly note**  
**Clutch hub assembly (3rd/4th)**

1. Position the **SST** between 2nd and 3rd gears.

**Caution**

- Hold the mainshaft with one hand so that it does not fall.


2. Press the mainshaft out of the clutch hub assembly (3rd/4th) and 3rd gear.

**Clutch hub assembly (1st/2nd)**

**Caution**

- Hold the mainshaft with one hand so that it does not fall.


Press the mainshaft out of the clutch hub assembly (1st/2nd) and 2nd gear.



97U0J1-029


**Bearing Housing Parts**

Disassemble in the order shown in the figure, referring to **Disassembly Note**.



05U0JX-021

- |   |   |  |
|---|---|--|
| 1. Snap ring  | 5. Reverse idler gear shaft<br>Disassembly Note | 8. Adjustment shim                                 |
| 2. Adjustment washer                                | ..... page J-21                                 | 9. Countershaft center bearing<br>Disassembly Note |
| 3. Reverse idler gear<br>Inspection ..... page J-24 | Inspection ..... page J-24                      | ..... page J-21                                    |
| 4. Thrust washer                                    | 6. Bearing cover                                | Inspection ..... page J-24                         |
|   | 7. Mainshaft front bearing<br>Disassembly Note  | 10. Adjustment shim                                |
|   | ..... page J-21                                 | 11. Bearing housing                                |
|   | Inspection ..... page J-24                      |  |



97U0J1-031


#### Disassembly note

#### Reverse idler gear shaft

#### Caution

- Support the reverse idler gear shaft with one hand so that it does not fall.

Press the reverse idler gear shaft out of the bearing housing.




97U0J1-032

#### Mainshaft front bearing

#### Caution

- Support the mainshaft front bearing with one hand so that it does not fall.

Remove the mainshaft front bearing with a suitable pipe.



97U0J1-033

#### Countershaft center bearing

#### Caution

- Support the countershaft center bearing with one hand so that it does not fall.


#### Note

- If countershaft center bearing is replaced, replace the spacer also.

Remove the countershaft center bearing with a suitable pipe.

**Extension Housing Parts**

Disassemble in the order shown in the figure.



05U0JX-022

- 1. Steel ball, spring, and spring cap
- 2. Select-lock spindle, spring, and spring cap
- 3. Plug, spring, and pushpin
- 4. Blind cover

- 5. Roll pin
- 6. Control lever
- 7. Control lever end
- 8. Change bushing
- 9. Wave washer

- 10. Change control case
- 11. Rod cover
- 12. Oil passage
- 13. Oil seal


Do not remove if not necessary



## INSPECTION

Inspect all parts and repair or replace as necessary.


05U0JX-023



05U0JX-065

### Each gear and main drive gear

1. Inspect the synchronizer cones for wear.
2. Inspect the individual gear teeth for wear and cracks.
3. Inspect the synchronizer ring matching teeth for damage and wear.
4. Inspect the main drive gear splines for damage and wear.



9MU0JX-056


### Mainshaft

1. Measure the mainshaft runout.

**Maximum runout: 0.03mm (0.0012 in)**

2. Inspect splines for damage or wear.
3. Measure the clearance between mainshaft and gear (or bush).


**Maximum clearance: 0.15mm (0.006 in)**



05U0JX-066

### Countershaft


1. Inspect the gear teeth for wear and cracks.
2. Inspect the splines for damage and wear.



9MU0JX-059

### Clutch hub assembly


1. Inspect the clutch hub sleeve and hub operation.
2. Inspect the individual gear teeth for damage, wear, and cracks.
3. Inspect the synchronizer key for damage, wear, and cracks.



9MU0JX-060

4. Measure the clearance between hub sleeve and shift fork.


**Standard clearance: 0.2—0.3mm (0.008—0.012 in)**  
**Maximum: 0.5mm (0.020 in)**



05U0JX-067

### Synchronizer ring

1. Inspect the individual synchronizer ring teeth for wear and cracks.
2. Inspect the taper surface for wear and cracks.




9MU0JX-062

### Note

- Set the synchronizer ring squarely in the gear; then measure around the circumference.

3. Measure the clearance between synchronizer ring and flank surface of gear.


**Standard clearance: 1.5mm (0.059 in)**  
**Minimum: 0.8mm (0.031 in)**



9MU0JX-063

### Bearing

Inspect for damage and rough rotation.




05U0JX-068

### Reverse idler gear and shaft

1. Inspect the gear teeth for wear and cracks.
2. Measure the clearance between the reverse idler gear bushing and shaft.

**Standard clearance:**  
**0.02—0.05mm (0.0008—0.0020 in)**  
**Maximum: 0.15mm (0.006 in)**



97U0J1-038

**Springs**


Measure the free length of the springs.

**Standard free length**

**Shift rod (5th/Reverse) spring: 75mm (2.953 in)**

**Detent ball spring (1st/2nd, 3rd/4th):  
22.5mm (0.886 in)**

**Detent ball spring (5th/Reverse): 17.0mm (0.669 in)**



97U0J1-039

**Intermediate housing**

Measure the intermediate housing pin height.


**Standard height: 9.0—10.0mm (0.354—0.394 in)**

### ASSEMBLY

#### Precaution

1. All O-rings and gasket must be replaced with the new ones included in the overhaul kit.
2. Before assembly, make sure all parts are completely clean.
3. Assemble the parts within 10 minutes after applying sealant. Allow all sealant to cure at least 30 minutes after assembly before filling the transmission with transmission oil.

05U0JX-024




9MU0JX-067

#### Clutch hub

##### Caution


- Align the synchronizer ring grooves with the clutch hub keys during installation.



05U0JX-025

##### Note

- The synchronizer rings all have the same basic shape. Carefully note these distinguishing features:
  - a) 5th and Reverse synchronizer rings are the smallest.
  - b) Reverse has 2 notches in the teeth.
  - c) 4th and 3rd are the next larger and are exactly the same.
  - d) 2nd and 1st are the biggest and are exactly the same.




97U0J1-041

- Press each clutch hub assembly onto the mainshaft in the proper direction.
- Install the clutch hubs with the chamfers of the inner gear teeth as shown.

## Extension Housing Parts


Assemble in the order shown in the figure, referring to **Assembly Note**.



N-m (cm-kg, in-lb)

05U0JX-026


- |   |  |   |
|---|--|---|
| 1. Oil seal<br>Assembly Note . page J-28  | 5. Wave washer                           | 10. Blind cover   |
| 2. Oil passage                            | 6. Change bushing                        | 11. Plug, spring, and pushpin   |
| 3. Rod cover<br>Assembly Note . page J-28 | 7. Control lever                         | 12. Select-lock spindle, spring,<br>and spring cap<br>Assembly Note . page J-28 |
| 4. Change control case                    | 8. Control lever end                     | 13. Steel ball, spring, and spring<br>cap                                       |
|   | 9. Roll pin<br>Assembly Note . page J-28 |   |



05U0JX-027

**Assembly note****Oil seal**


1. Apply transmission oil to outer periphery.
2. Install a new oil seal with the **SST**.



05U0JX-028

**Rod cover**

1. Apply transmission oil to rubbers on the rod cover.
2. Install the rod cover with the mark facing forward.




05U0JX-029

**Roll pin****Caution**

- Install the roll pin with the seam facing as shown in the figure.

Install a new roll pin into the control lever end.



05U0JX-030

**Select-lock spindle, spring, and spring cap**

1. Install the select-lock spindle, spring, and spring cap.

**Tightening torque:**

7.8—11 N·m (80—110 cm·kg, 69—95 in·lb)


**Note**

- If the select-lock spindle is not pushed down, the ball will not correctly engage the select-lock spindle.

2. Push the select-lock spindle down by pushing on the control rod.


**Bearing Housing Parts**

Assemble in the order shown in the figure, referring to **Assembly Note**.



05U0JX-031

- |   |  |                           |
|---|--|---------------------------|
| 1. Bearing housing  | 5. Mainshaft front bearing                               | 10. Adjustment washer     |
| 2. Adjustment shim<br>Assembly Note . page J-30             | Assembly Note . page J-30                                | Assembly Note . page J-30 |
| 3. Countershaft center bearing<br>Assembly Note . page J-29 | 6. Bearing cover   | 11. Snap ring             |
| 4. Adjustment shim<br>Assembly Note . page J-30             | 7. Reverse idler gear shaft<br>Assembly Note . page J-30 |                           |
|   | 8. Thrust washer   |                           |
|   | 9. Reverse idler gear                                    |                           |




05U0JX-032

**Assembly note**

**Countershaft center bearing**

Press the countershaft center bearing into the bearing housing with a suitable pipe.




05U0JX-033

**Adjustment shim**

Measure the clearance between the countershaft center bearing and the bearing housing. If not within specification, adjust the clearance by installing the correct adjustment shim(s).

**Standard clearance: 0—0.1mm (0—0.004 in)**


**Adjustment shim:  
0.1mm (0.004 in), 0.3mm (0.012 in)**



05U0JX-034

**Mainshaft front bearing**

Press the mainshaft front bearing into the bearing housing with a suitable pipe.




05U0JX-035

**Adjustment shim**

Measure the clearance between the mainshaft front bearing and the bearing housing. If not within specification, adjust the clearance by installing the correct adjustment shim(s).

**Standard clearance: 0—0.1mm (0—0.004 in)**

**Adjustment shim:  
0.1mm (0.004 in), 0.15mm (0.006 in),  
0.3mm (0.012 in)**




05U0JX-036

**Reverse idler gear shaft**

Press the reverse idler gear into the bearing housing.

**Tightening torque:**

**7.8—11 N·m (80—110 cm·kg, 69—95 in)**



05U0JX-037

**Adjustment washer**

Measure the clearance between the adjustment washer and snap ring. If not within specification, adjust the clearance by installing the correct adjustment washer.

**Maximum clearance: 0.1mm (0.004 in)**

**Adjustment washer:  
2.6mm (0.102 in), 2.8mm (0.110 in), 3.0mm (0.118 in)**






## Mainshaft Parts

Assemble in the order shown in the figure, referring to **Assembly Note**.




APPLY SPECIFIED OIL TO INDIVIDUAL PARTS




05UJX-038


- |  |   |   |
|--|---|---|
| 1. Clutch hub                            | 8. Clutch hub assembly<br>(1st/2nd)<br>Assembly Note . page J-32  | 12. Snap ring<br>Assembly Note . page J-32      |
| 2. Synchronizer key                      |   | 13. Synchronizer ring                           |
| 3. Clutch hub sleeve                     |   | 14. Inner race<br>Assembly Note . page J-32     |
| 4. Synchronizer key spring               | 9. 3rd gear<br>Assembly Note . page J-32                          | 15. Needle bearing<br>Assembly Note . page J-32 |
| 5. Mainshaft                             | 10. Synchronizer ring (3rd)                                       | 16. 1st gear<br>Assembly Note . page J-32       |
| 6. 2nd gear<br>Assembly Note . page J-32 | 11. Clutch hub assembly<br>(3rd/4th)<br>Assembly Note . page J-32 |   |
| 7. Synchronizer ring                     |   |   |




97U0J1-052



97U0J1-053



9MU0JX-073



97U0J1-054

### Assembly note Clutch hub assembly

1. Set the 2nd gear and the 1st/2nd clutch hub assembly on the mainshaft, then press in the mainshaft.

2. Set the 3rd gear and 3rd/4th clutch hub assembly on the mainshaft, then press on the 3rd/4th clutch hub assembly with the **SST**.

3. Install a new snap ring on the front of the mainshaft.

4. Install the inner race, needle bearing, and 1st gear.

---


MEMO

### Mainshaft and Countershaft Parts

Assemble in the order shown in the figure, referring to **Assembly Note**.




APPLY SPECIFIED OIL TO INDIVIDUAL PARTS EXCEPT LOCKNUTS




- |                             |                                 |                               |
|-----------------------------|---------------------------------|-------------------------------|
| 1. Clutch hub               | 15. Needle bearing              | 26. Mainshaft rear bearing    |
| 2. Synchronizer key         | 16. Reverse gear                | Assembly Note . page J-36     |
| 3. Clutch hub sleeve        | 17. Synchronizer ring (Reverse) | 27. C-washer                  |
| 4. Synchronizer key spring  | 18. Clutch hub assembly         | Assembly Note . page J-36     |
| 5. Synchronizer ring (4th)  | 19. Locknut (Mainshaft)         | 28. Retaining ring            |
| 6. Needle bearing           | Assembly Note . page J-35       | Assembly Note . page J-36     |
| 7. Main drive gear          | 20. Synchronizer ring (5th)     | 29. Washer                    |
| 8. Bearing housing assembly | 21. 5th gear                    | Assembly Note . page J-36     |
| 9. Washer                   | 22. Steel ball                  | 30. Snap ring                 |
| 10. Mainshaft gear assembly | 23. Thrust lock washer          | 31. Spacer                    |
| Assembly Note . page J-35   | Assembly Note . page J-36       | 32. Counter 5th gear          |
| 11. Countershaft            | 24. C-washer                    | 33. Countershaft rear bearing |
| Assembly Note . page J-35   | Assembly Note . page J-36       | Assembly Note . page J-36     |
| 12. Counter reverse gear    | 25. Retaining ring              | 34. Locknut (Countershaft)    |
| 13. Washer                  | Assembly Note . page J-36       | Assembly Note . page J-37     |
| 14. Inner race              |                                 |                               |


05U0JX-039



97U0J1-057



97U0J1-058



97U0J1-059

### Assembly note Mainshaft and countershaft

1. Place the mainshaft gear assembly and the countershaft on the bearing housing.
2. Use a suitable bar to press in the countershaft.

### Locknut (Mainshaft)

#### Note

- Use pads in the vise to prevent damaging the bearing housing.


1. Secure the bearing housing in a vise.
2. Slide the clutch hub sleeves onto 1st and reverse gears to lock the mainshaft.

3. Tighten a new locknut with the **SST**.

#### Tightening torque:

**128—235 N·m (13—24 m·kg, 94—174 ft·lb)**

4. Use a chisel to stake the locknut.



97U0J1-060

**Thrust lock washer**

1. Insert the steel ball and the thrust lock washer for 5th gear.

**Caution**

- Use only 3.0mm (0.118 in) C-washers, otherwise; it may not be possible to install the rear C-washers.
- The two C-washers must be the same thickness, or bearing failure will result.

2. Install the C-washers and hold them with the retaining ring.


3. Measure the clearance between the thrust lock washer and C-washers (5th gear end play).

If the end play is not within specification, adjust the clearance by installing the correct thrust lock washer.

**Standard play: 0.1—0.3mm (0.004— 0.012 in)**

**Thrust lock washer thickness:**


**6.2mm (0.244 in), 6.4mm (0.252 in),  
6.5mm (0.256 in), 6.6mm (0.260 in)**



05U0JX-040

**Mainshaft rear bearing**

1. Drive on the mainshaft rear bearing with the **SST**. Install the C-washers, retaining ring, and washer. Secure them with a new snap ring.



97U0J1-062

**Caution**


- Verify there is no clearance between the mainshaft rear bearing and the C-washers.

2. Measure the clearance between the C-washers and washer. If end play is not within specification, adjust the clearance by installing the proper C-washers.

**Standard play: 0—0.1mm (0—0.004 in)**

**C-washer thickness:**


**2.9mm (0.114 in), 3.0mm (0.118 in),  
3.1mm (0.122 in), 3.2mm (0.126 in)**




05U0JX-041

**Countershaft rear bearing**


Drive the countershaft rear bearing onto the countershaft with the **SST**.



97U0J1-064



97U0J1-065



05U0JX-042

**Locknut (Countershaft)**

1. Shift the clutch hub sleeves to 1st gear and reverse gear to put the gears in a double-engaged condition.

**Note**

- Use pads in the vise to prevent damaging the SST.

2. Connect the **SST** to the mainshaft and tighten it securely in a vise.
3. Tighten a new locknut.


**Tightening torque:**

**128—196 N·m (13—20 m·kg, 94—145 ft·lb)**

4. Use a chisel to stake the locknut.

**Shift Fork and Shift Rod Parts**

Assemble in the order shown in the figure, referring to **Assembly Note**.




N·m (m·kg, ft·lb)


05U0JX-043

- |  |   |   |
|--|---|---|
| 1. Spring and ball<br>Assembly Note . page J-39        | 7. 3rd/4th shift rod<br>Assembly Note . page J-40 | 15. Clip<br>Assembly Note . page J-40                 |
| 2. 5th/Reverse shift fork<br>Assembly Note . page J-39 | 8. Interlock pin<br>Assembly Note . page J-40     | 16. Clip<br>Assembly Note . page J-40                 |
| 3. 5th/Reverse shift rod<br>Assembly Note . page J-39  | 9. 1st/2nd shift rod                              | 17. Clip<br>Assembly Note . page J-40                 |
| 4. Interlock pin<br>Assembly Note . page J-39          | 10. Ball and spring                               | 18. Intermediate housing<br>Assembly Note . page J-41 |
| 5. 1st/2nd shift fork<br>Assembly Note . page J-40     | 11. Cap plug                                      | 19. 5th/Reverse shift rod end                         |
| 6. 3rd/4th shift fork<br>Assembly Note . page J-40     | 12. Roll pin<br>Assembly Note . page J-40         | 20. 3rd/4th shift rod end                             |
|  | 13. Spring<br>Assembly Note . page J-40           | 21. 1st/2nd shift rod end                             |
|  | 14. Spacer<br>Assembly Note . page J-40           | 22. Roll pin<br>Assembly Note . page J-41             |







05U0JX-044




05U0JX-045



05U0JX-046



05U0JX-047



05U0JX-048

## Assembly note Spring and ball

### Note

- There are 2 types of springs; be sure to install them correctly.


1. Insert the spring and ball (5th/Reverse) into the bearing housing.
2. Press the spring and ball (5th/Reverse) with a screwdriver and the **SST** to install the shift rod.

## Shift fork and rod

Install the 5th/Reverse shift fork and 5th/Reverse shift rod into the bearing housing.

## Interlock pin


1. Position the interlock pin into the bearing housing with the **SST**.
2. Verify that the interlock pin is correctly installed.



05U0JX-049

**Shift fork and rod, interlock pin**

1. Set the 1st/2nd shift fork onto the 1st/2nd clutch hub assembly.
2. Install the 3rd/4th shift fork and 3rd/4th shift rod, and install the interlock pin into the bearing housing as in Step 4.




05U0JX-050

**Roll pin**

**Caution**

- Install the roll pin with the seam facing as shown in the figure.


Install a new roll pin into each shift fork.



05U0JX-051


**Spring, spacer, clip**

1. Slide the spring and spacer onto the 5th/Reverse shift rod. While pressing the spacer, install a new clip.




05U0JX-052

2. Install new clips to the 3rd/4th shift rod and 1st/2nd shift rod.



05U0JX-053

3. Verify that the centers of the shift fork and clutch hub sleeve are aligned properly. If they are not, select the proper washer for between 1st gear and the mainshaft front bearing, and between reverse gear and the mainshaft front bearing.




05U0JX-054

**Caution**

- The total thickness of the front and rear washers should be 5.9—6.0mm (0.2323—0.2362 in).

4. The following washer thicknesses are available.


2.2mm (0.0866 in)	3.2mm (0.1260 in)
2.7mm (0.1063 in)	3.7mm (0.1457 in)
3.0mm (0.1181 in)	



97U0J1-080

**Intermediate housing**

1. Apply sealant to the contacting surfaces of the intermediate housing and bearing housing.
2. Mount the intermediate housing to the bearing housing by tapping it lightly with a plastic hammer.



05U0JX-055

**Roll pin**


**Caution**

- Install the roll pin with the seam facing forward.

Install a new roll pin into each shift rod end.

**Housing Components**


1. Assemble in the order shown in the figure, referring to **Assembly Note**.
2. Check the gearshift lever operation.



N-m (m-kg, ft-lb)

- |   |   |  |
|---|---|--|
| 1. Oil seal<br>Assembly Note . page J-43          | 8. Main drive gear bearing<br>Assembly Note . page J-43     | 14. Front cover                                  |
| 2. Snap ring                                      | 9. Snap ring  | 15. Speedometer driven gear                      |
| 3. Steel ball                                     | 10. Countershaft front bearing<br>Assembly Note . page J-43 | 16. Neutral switch                               |
| 4. Speedometer drive gear                         | 11. Snap ring   | 17. Back-up light switch                         |
| 5. Snap ring                                      | 12. Adjustment shim<br>Assembly Note . page J-44            | 18. Boot   |
| 6. Transmission case                              | 13. Gasket  | 19. Release fork<br>Assembly Note . page J-44    |
| 7. Extension housing<br>Assembly Note . page J-43 |   | 20. Release bearing<br>Assembly Note . page J-44 |

05U0JX-057




05U0JX-058

## Assembly note

### Oil seal

1. Apply transmission oil to outer periphery.
2. Install a new oil seal with the **SST**.




05U0JX-059

### Extension housing

1. Apply sealant to the contact surfaces of the bearing housing and transmission case.
2. Align the inner shift lever and shift rod end groove, and install the extension housing.
3. Apply sealant to the bolt threads, and install the bolts.

### Tightening torque:


**16—23 N·m (1.6—2.3 m·kg, 12—17 ft·lb)**



97U0J1-090

### Main drive gear bearing


Drive on the main drive gear bearing with the **SST**, and secure it with a new snap ring.





97U0J1-091

### Countershaft front bearing

Drive on the countershaft front bearing with the **SST**, and secure it with a new snap ring.



05U0JX-060



9MU0JX-110

### Adjustment shim

After measuring dimensions (A) and (B) shown in the figure, use an adjustment shim(s), as specified below, of the thickness corresponding to the value of (A) minus (B), so that bearing end play will be within specification.

**Bearing end play: 0—0.1mm (0—0.004 in)**

**Adjustment shim thickness:**


**0.10mm (0.004 in), 0.15mm (0.006 in),  
0.30mm (0.012 in)**

### Release fork

1. Apply Mori white TA No.2 or equivalent organic molybdenum grease to the shaded areas of the release bearing and release fork.
2. Install the release bearing and release fork.


## INSTALLATION

1. Raise the vehicle and support it with safety stands.
2. Install in the order shown in the figure, referring to **Installation Note**.
3. Add the specified amount of the specified transmission oil. (Refer to page J-8.)
4. Warm up the engine and transmission, and inspect for oil leakage and transmission operation.



05U0JX-061

- |   |   |   |
|---|---|---|
| 1. Transmission<br>Installation Note page J-46            | 4. Starter  | 8. Undercover                                 |
| 2. Power plant frame (PPF)<br>Installation Note page J-46 | 5. Clutch release cylinder                        | 9. Shift lever<br>Installation Note page J-47 |
| 3. Speedometer cable                                      | 6. Propeller shaft<br>Installation Note page J-47 | 10. Rear console                              |
|   | 7. Exhaust pipe                                   | 11. Shift lever knob                          |




05U0JX-062

### Installation note

#### Transmission

Tilt the engine by pushing up on the front of oil pan with a wooden block and a jack for easy installation of the transmission.



05U0MX-078

### Power plant frame (PPF)

1. Install the differential mounting spacer.

#### Tightening torque:

**37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)**


2. Support the transmission with a jack so that it is level.  
3. Position the PPF and snugly tighten the transmission-side bolts by hand.

4. Verify that the sleeve is installed into the block.

#### Note

- The reamer bolt is installed in the forward hole.

5. Install the spacer and bolts, then snugly tighten them.




05U0MX-079

6. Snugly install the power plant frame bracket.  
7. Tighten the transmission-side bolts.

#### Tightening torque:

**104—123 N·m (10.6—12.6 m·kg, 77—91 ft·lb)**




05U0MX-080

8. Tighten the differential-side bolts.


#### Tightening torque:

**104—123 N·m (10.6—12.6 m·kg, 77—91 ft·lb)**



05U0MX-081






05U0MX-082

9. Install the power plant frame bracket.

**Tightening torque:**

- Ⓐ 104—123 N·m (10.6—12.6 m·kg, 77—91 ft·lb)
- Ⓑ 36—54 N·m (3.7—5.5 m·kg, 27—40 ft·lb)

10. Remove the jack, and connect the wire harness.




05U0MX-083

**Propeller shaft**

Align the marks, and install the propeller shaft.

**Tightening torque:**

- 27—30 N·m (2.8—3.1 m·kg, 20—22 ft·lb)



05U0JX-063

**Shift lever**


**Note**

- Add the specified oil whenever the extension housing has been removed or the transmission has been overhauled.

1. Pour the specified amount of oil into the change control case.

**Specified oil:**

- Grade: API service GL-4 or GL-5
- All season: SAE 75W-90
- Above 10°C (50°F): SAE 80W-90
- Specified amount: 80—95 cc (4.9—5.8 cu in)



05U0JX-064

2. Apply oil to the shift lever as shown.

3. Apply sealant to the contact surfaces of the boot panel and change control case.

# PROPELLER SHAFT

**OUTLINE** ..... L- 2  
    SPECIFICATIONS ..... L- 2  
**TROUBLESHOOTING GUIDE** ..... L- 2  
**PROPELLER SHAFT** ..... L- 2  
    PREPARATION ..... L- 2  
    REMOVAL / INSPECTION / INSTALLATION .. L- 3

05U0LX-001




# L OUTLINE, TROUBLESHOOTING GUIDE, PROPELLER SHAFT

## OUTLINE

### SPECIFICATIONS

Engine/Transmission Model			B6 DOHC
			M5M-D
Length	mm (in)	L1	1,049 (41.30)
		L2	864 (34.02)
Outer diameter	mm (in)	D	57 ( 2.24)



05U0LX-002

## TROUBLESHOOTING GUIDE


Problem	Possible Cause	Action	Page
<b>Vibration</b>	Worn universal joint	Replace	L-3
	Bent propeller shaft	Replace	L-3
	Worn slip yoke splines	Replace	L-3
	Runout of propeller shaft	Replace	L-3
	Unbalanced propeller shaft	Replace	L-3
<b>Abnormal noise</b>	Worn or damaged universal joint	Replace	L-3
	Worn slip yoke splines	Replace	L-3

05U0LX-003

## PROPELLER SHAFT

### PREPARATION

#### SST

49 0259 440 Holder, main shaft		For prevention of oil leakage
--------------------------------------	---	-------------------------------------


05U0LX-004

# PROPELLER SHAFT

L

## REMOVAL / INSPECTION / INSTALLATION

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.




N-m (m-kg, ft-lb)

05UOLX-005

1. Exhaust pipe  
2. Nut

3. Lock washer  
4. Bolt


5. Propeller shaft  
Removal Note .. page L- 3  
Inspection..... page L- 4  
Installation Note page L- 4




05UOLX-006

### Removal Note Propeller shaft


1. Before removing the propeller shaft, mark the flanges for correct installation.




05U0LX-007




05U0LX-008



97U0LX-008



05U0LX-009



05U0LX-010

- When the propeller shaft is removed from the extension housing, immediately install the **SST** to prevent oil leakage.

### INSPECTION Propeller shaft

#### Note

- Clean the propeller shaft (except universal joints) thoroughly with a steam cleaner or cleaning solvent before inspection.

- Measure the propeller shaft runout with a dial indicator. Replace the propeller shaft if runout is excessive.

**Maximum runout: 0.4mm (0.016 in)**

- Move the universal joints in the directions shown, and check for universal joint looseness. If there is looseness, replace the propeller shaft.
- Check operation of the universal joint. If the universal joint has excessive resistance, replace the propeller shaft.

### Installation Note

- Align the marks, and install the propeller shaft.

#### Tightening torque:


**27—30 N·m (2.8—3.1 m·kg, 20—22 ft·lb)**

- Check that there is no abnormal noise or vibration when driving the vehicle. If noise or vibration occurs from the propeller shaft, replace the propeller shaft.

# FRONT AND REAR AXLES

<b>INDEX</b> .....	M- 2
<b>OUTLINE</b> .....	M- 3
SPECIFICATIONS.....	M- 3
<b>TROUBLESHOOTING GUIDE</b> .....	M- 3
FRONT AXLE .....	M- 3
REAR AXLE .....	M- 3
DIFFERENTIAL, STANDARD.....	M- 4
DIFFERENTIAL, VISCOUS LIMITED SLIP ....	M- 4
<b>FRONT AXLE</b> .....	M- 5
PREPARATION.....	M- 5
WHEEL HUB, STEERING KNUCKLE.....	M- 5
<b>REAR AXLE</b> .....	M- 9
PREPARATION.....	M- 9
DISC BRAKE TYPE .....	M-10
<b>DRIVESHAFT</b> .....	M-16
DOUBLE OFFSET JOINT .....	M-16
<b>DIFFERENTIAL</b> .....	M-22
PREPARATION.....	M-22
DIFFERENTIAL OIL .....	M-24
OIL SEAL (OUTPUT SHAFT).....	M-24
OPERATION INSPECTION.....	M-26
DIFFERENTIAL, STANDARD.....	M-27
DIFFERENTIAL, VISCOUS LIMITED SLIP (VISCOUS L.S.D.).....	M-27

## INDEX



05U0MX-002

- |  |   |
|--|---|
| <p>1. Front axle<br/>             Inspection / Removal /<br/>             Installation ..... page M- 5<br/>             Disassembly / Inspection /<br/>             Assembly ..... page M- 8</p> <p>2. Rear axle<br/>             Inspection / Removal /<br/>             Installation ..... page M-10<br/>             Disassembly / Inspection /<br/>             Assembly ..... page M-12</p> | <p>3. Driveshaft<br/>             Inspection / Removal /<br/>             Installation ..... page M-16<br/>             Overhaul ..... page M-18</p> <p>4. Differential<br/>             (Standard, Viscous limited slip differential)<br/>             Differential oil ..... page M-24<br/>             Oil seal (Output shaft) ..... page M-24<br/>             Operation inspection ..... page M-26<br/>             Removal / Installation ..... page M-27<br/>             Overhaul ..... page M-32</p> |
|--|---|

OUTLINE

SPECIFICATIONS

Item		Engine/Transmission Model		B6 DOHC		
				M5M-D		
Front axle	Type	Double-wishbone				
	Bearing	Angular ball bearing				
	Maximum wheel bearing play	mm (in)	0.05 (0.002)			
Rear axle	Type	Double-wishbone				
	Bearing	Angular ball bearing				
	Maximum wheel bearing play	mm (in)	0.05 (0.002)			
Differential	Type	Standard		Viscous L.S.D.		
	Reduction gear	Hypoid gear				
	Reduction ratio	4.300				
	Differential gear	Straight-bevel gear				
	Ring gear size	162.16 (6.384)				
	Oil	Grade	API service GL-5			
		Viscosity	Above -18°C (0°F): SAE 90 Below -18°C (0°F): SAE 80W			
Capacity		liter (US qt, Imp qt)	0.65 (0.69, 0.57)			
Driveshaft	Type	Constant velocity (double offset) joint				
	Length	mm (in)	659.3 (25.957)			

Viscous L.S.D.: Viscous Limited Slip Differential

05U0MX-003

TROUBLESHOOTING GUIDE

FRONT AXLE

Problem	Possible Cause	Action	Page
Steering wheel vibration	Worn or damaged wheel bearing	Replace	M- 5
Pulls or one-sided braking	Worn or damaged wheel bearing	Replace	M- 5

05U0MX-004

REAR AXLE

Problem	Possible Cause	Action	Page
Abnormal noise	Bent driveshaft	Replace	M-16
	Worn or damaged wheel bearing	Replace	M-12
	Worn driveshaft spline	Replace	M-16



## REAR AXLE (Cont'd)

Problem	Possible Cause	Action	Page
Body "rolls"	Worn or deteriorated upper arm bushing	Replace	M-12, Section R
Body leans	Weak upper arm bushing	Replace	M-12, Section R
Abnormal noise from suspension system	Worn or deteriorated upper arm bushing	Replace	M-12, Section R

05U0MX-005

## DIFFERENTIAL, STANDARD

Problem	Possible Cause	Action	Page
Abnormal noise	Insufficient differential oil	Add oil	M-24
	Incorrect differential oil	Replace	M-24
	Improperly adjusted ring gear backlash	Adjust	M-40
	Poor contact of ring gear teeth	Adjust	M-41
	Worn or damaged side bearing	Replace	M-32
	Worn or damaged ring gear	Replace	M-32
	Worn or damaged drive pinion bearing	Replace	M-32
	Worn or damaged pinion and side gear	Replace	M-32
	Seized side gear and case	Replace	M-32
	Worn side gear spline	Replace	M-32
	Worn pinion shaft	Replace	M-32
	Worn thrust washer	Replace	M-32
	Improperly adjusted side gear backlash	Adjust	M-40
	Improperly adjusted drive pinion gear preload	Adjust	M-38
Heat buildup	Insufficient differential oil	Add oil	M-24
	Insufficient gear backlash	Adjust	M-40
	Excessive bearing preload	Adjust	M-38,40
Oil leakage	Excessive differential oil	Remove oil	M-24
	Loose differential carrier	Tighten or repair	M-42
	Worn or damaged oil seal	Replace	M-32
No differential operation	Misassembled	Repair	M-32

05U0MX-006



## DIFFERENTIAL, VISCOUS LIMITED SLIP

Problem	Possible Cause	Action	Page
Abnormal noise	Insufficient differential oil	Add oil	M-24
	Incorrect differential oil	Replace	M-24
	Improperly adjusted ring gear backlash	Adjust	M-40
	Poor contact of ring gear teeth	Adjust	M-41
	Worn or damaged viscous limited slip differential oil seal	Replace	M-24,32
	Worn or damaged ring gear	Replace	M-32
	Worn or damaged drive pinion bearing	Replace	M-32
Heat buildup	Insufficient differential oil	Add oil	M-24
	Excessive bearing preload	Adjust	M-38,40
Oil leakage	Excessive differential oil	Remove oil	M-24
	Loose differential carrier	Tighten or repair	M-42
	Worn or damaged oil seal	Replace	M-24,32
No differential operation	Misassembled	Repair	M-32

05U0MX-007

FRONT AXLE

PREPARATION  
SST


<p>49 0118 850C Puller, ball joint</p> 	<p>For disconnection of tie-rod end and upper arm ball joint</p>	<p>49 0727 575 Puller, ball joint</p> 	<p>For disconnection of lower arm ball joint</p>
--	--	---	--

05U0MX-008

WHEEL HUB, STEERING KNUCKLE

Inspection / Removal / Installation


1. Inspect wheel bearing play, referring to **Inspection**.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Inspect all parts and repair or replace as necessary.
4. Install in the reverse order of removal, referring to **Installation Note**.



N-m (m-kg, ft-lb)

05U0MX-009

- |  |   |
|--|---|
| <ol style="list-style-type: none"> <li>1. Front wheel</li> <li>2. Brake caliper assembly<br/>Removal Note..... page M-6</li> <li>3. Hub cap</li> <li>4. Disc plate</li> <li>5. Locknut<br/>Installation Note..... page M-7</li> <li>6. Front wheel hub assembly<br/>Inspect for cracks and damage<br/>Disassembly / Inspection /<br/>Assembly..... page M-8</li> </ol> | <ol style="list-style-type: none"> <li>7. Tie-rod end<br/>Removal Note..... page M-6<br/>Service..... Section N</li> <li>8. Lower arm<br/>Removal Note..... page M-6<br/>Service..... Section R</li> <li>9. Upper arm<br/>Removal Note..... page M-6<br/>Service..... Section R</li> <li>10. Dust cover and knuckle spindle<br/>Inspect dust cover for damage and distortion<br/>Inspect knuckle spindle for cracks and damage</li> </ol> |
|--|---|




05U0MX-010

**Inspection****Wheel bearing play**

1. Remove the wheel, brake caliper assembly, and disc plate, referring to **Removal note** below.
2. Position a dial indicator against the wheel hub. Push and pull the wheel hub by hand in the axial direction and measure the wheel bearing play.  
If the bearing play exceeds specification, check and adjust the locknut torque or replace the wheel hub assembly if necessary.

**Maximum wheel bearing play: 0.05mm (0.002 in)**




05U0MX-011

**Removal note****Brake caliper assembly****Note**

- For easier installation, do not depress the brake pedal after removing the brake caliper assembly.

Suspend the brake caliper assembly with a rope.




49 0118 850C

05U0MX-012

**Tie-rod end**

Loosen the nut and disconnect the tie-rod end with the **SST**.




49 0727 575

9MU0MX-010

**Lower arm**

Loosen the nut and disconnect the lower arm with the **SST**.




49 0118 850C

05U0MX-013

**Upper arm**

Loosen the nut and disconnect the upper arm with the **SST**.



05U0MX-014

### Installation note

#### Locknut


Install a new locknut and stake it.

#### Tightening torque:

**167—216 N·m (17—22 m·kg, 123—159 ft·lb)**

### Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



05U0MX-015

1. Front wheel hub assembly
2. Dust cover
3. Knuckle spindle

4. Hub bolt

Disassembly Note..... page M-8  
Assembly Note ..... page M-8

### Disassembly note Hub bolts


#### Caution

- Do not remove the hub bolts if not necessary.
- Do not reuse the removed hub bolts.


Remove the hub bolts with a press.

### Assembly note Hub bolts

Install the new hub bolts with a press.
















05U0MX-016



05U0MX-017

REAR AXLE


PREPARATION  
SST

<p>49 F026 103 Puller, wheel hub</p> 	<p>For disassembly and assembly of rear axle</p>	<p>49 B026 1A0 Puller, wheel hub</p> 	<p>For disassembly and assembly of wheel hub</p>
<p>49 G033 102 Handle (Part of 49 B026 1A0)</p> 	<p>For removal and installation of rear wheel hub</p>	<p>49 G030 727 Attachment A (Part of 49 B026 1A0)</p> 	<p>For removal and installation of rear wheel hub</p>
<p>49 G030 795 Installer, oil seal</p> 	<p>For installation of oil seal</p>	<p>49 G030 797 Handle (Part of 49 G030 795)</p> 	<p>For removal and installation of wheel bearing</p>
<p>49 0636 145 Puller, fan pulley boss</p> 	<p>For removal of wheel bearing</p>	<p>49 G033 107 Installer, dust cover</p> 	<p>For installation of dust cover</p>
<p>49 F027 0A1 Installer set, bearing</p> 	<p>For installation of bearing</p>	<p>49 F027 005 Attachment 62 (Part of 49 F027 0A1)</p> 	<p>For assembly of rear axle</p>
<p>49 F027 007 Attachment 72 (Part of 49 F027 0A1)</p> 	<p>For assembly of rear axle</p>	<p>49 F027 009 Attachment 68 &amp; 77 (Part of 49 F027 0A1)</p> 	<p>For assembly of rear axle</p>
<p>49 V001 795 Installer, oil seal</p> 	<p>For installation of oil seal</p>	<p>05U0MX-018</p>	

### DISC BRAKE TYPE

#### Inspection / Removal / Installation


1. Inspect wheel bearing play, referring to **Inspection**.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Inspect all parts and repair or replace as necessary.
4. Install in the reverse order of removal, referring to **Installation Note**.
5. After installation, adjust the rear wheel alignment. (Refer to Section R.)



05UOMX-019

1. Rear wheel
2. Brake caliper assembly  
Removal Note..... page M-11
3. Disc plate
4. Locknut  
Installation Note ..... page M-11

5. Knuckle, wheel hub, and dust cover  
Inspect knuckle for cracks and damage  
Inspect wheel hub for cracks and damage  
Inspect dust cover for damage and distortion  
Disassembly / Inspection /  
Assembly ..... page M-12




05U0MX-020

## Inspection

### Wheel bearing play

1. Remove the wheel, brake caliper assembly, and disc plate, referring to **Removal note** below.
2. Position a dial indicator against the wheel hub. Push and pull the wheel hub by hand in the axial direction and measure the wheel bearing play.  
If the bearing play exceeds specification, check and adjust the locknut torque or replace the wheel bearing if necessary.

**Maximum wheel bearing play: 0.05mm (0.002 in)**



05U0MX-021


## Removal note

### Brake caliper assembly

#### Note

- **For easier installation, do not depress the brake pedal after removing the brake caliper assembly.**

Suspend the brake caliper assembly with a rope.



05U0MX-022

## Installation note

### Locknut

Install a new locknut and stake it.


### Tightening torque:

**216—294 N·m (22—30 m·kg, 159—217 ft·lb)**



### Disassembly / Inspection / Assembly


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



05U0MX-023

- |                            |           |
|----------------------------|-----------|
| 1. Oil seal                |           |
| Assembly Note .....        | page M-15 |
| 2. Rear wheel hub assembly |           |
| Disassembly Note .....     | page M-12 |
| Assembly Note .....        | page M-15 |
| 3. Retaining ring          |           |
| 4. Wheel bearing           |           |
| Disassembly Note .....     | page M-13 |
| Assembly Note .....        | page M-14 |

- |                        |           |
|------------------------|-----------|
| 5. Dust cover          |           |
| Disassembly Note ..... | page M-13 |
| Assembly Note .....    | page M-14 |
| 6. Knuckle             |           |
| 7. Bushing             |           |
| 8. Hub bolt            |           |
| Disassembly Note ..... | page M-14 |
| Assembly Note .....    | page M-14 |




#### Disassembly note

#### Rear wheel hub assembly

Press out the rear wheel hub assembly with the **SST**.


05U0MX-024



05U0MX-025

**Wheel bearing**

Press out the wheel bearing with the **SST**.




05U0MX-026

**Note**


- If the bearing inner race remains on the rear wheel hub assembly, remove as follows.

1. Move the bearing inner race away from the rear wheel hub assembly with a chisel.



9MU0MX-617

2. Press the bearing inner race off the wheel hub with the **SST**.




05U0MX-027

**Dust cover**

**Caution**


- Do not remove the dust cover if not necessary.
- Do not reuse the removed dust cover.

1. Mark the dust cover and knuckle for proper reassembly.



9MU0MX-014

2. Remove the dust cover with a chisel.




05U0MX-028

### Hub bolt

#### Caution

- Do not remove the hub bolts if not necessary.
- Do not reuse the removed hub bolts.

Press out the hub bolts.




9MU0MX-620

### Assembly note

#### Hub bolt


Press in new hub bolts.



05U0MX-029


### Dust cover

1. Mark the new dust cover as the removed one.



9MU0MX-622


2. Align the marks of the new dust cover and the knuckle.
3. Install the new dust cover with the **SST**.



05U0MX-030

### Wheel bearing


Press the new wheel bearing into the knuckle with the **SST**.



05U0MX-031

**Rear wheel hub assembly**

1. Apply grease to the wheel bearing inner race.
2. Press the rear wheel hub assembly in with the **SST**.



05U0MX-032

**Oil seal**


1. Apply grease to the new oil seal lip.
2. Install the new oil seal with the **SST**.

### DRIVESHAFT

#### DOUBLE OFFSET JOINT

#### Inspection / Removal / Installation

1. Inspect the driveshaft, referring to **Inspection**.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. After installation, adjust the rear wheel alignment. (Refer to Section R.)




N-m (m-kg, ft-lb)

05U0MX-033

1. Rear wheel
2. Locknut  
Installation Note ..... page M-17


- 3 Driveshaft  
Removal Note ..... page M-16  
Overhaul ..... page M-18



05U0MX-034

#### Inspection Driveshaft


1. Check the dust boot on the driveshaft for cracks, damage, leaking grease, and a loose boot band.
2. Check the driveshaft for bending, cracks, and wear of joints or splines.
3. Repair or replace the driveshaft if necessary.



05U0MX-035

#### Removal note Driveshaft


Before removing the driveshaft, mark the driveshaft and output shaft for proper installation.



05U0MX-036

**Note**

- If the driveshaft is stuck to the wheel hub, install a used locknut so that it is flush with the end of the shaft, and tap the nut with a plastic hammer.



05U0MX-037


**Installation note**

**Driveshaft**

Align the marks and install the driveshaft.

**Tightening torque:**

**54—64 N·m (5.5—6.5 m·kg, 40—47 ft·lb)**



05U0MX-038

**Locknut**

Install a new locknut and stake it.

**Tightening torque:**


**216—294 N·m (22—30 m·kg, 159—217 ft·lb)**

### Overhaul

#### Caution


- **Secure the joint in a vise with protective material (such as copper plates) on the vise jaws.**
- **Be careful that dust or other foreign material does not enter the joint while the work is being performed.**
- **Do not disassemble the wheel-side ball joint.**
- **Do not wash the joint unless it is being disassembled.**

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




05U0MX-039


- |   |  |
|---|--|
| 1. Boot bands<br>Disassembly Note..... page M-19<br>Assembly Note ..... page M-21 | 6. Inner ring<br>Disassembly Note..... page M-19<br>Assembly Note ..... page M-20  |
| 2. Clip<br>Disassembly Note..... page M-19  | 7. Cage<br>Disassembly Note..... page M-19<br>Assembly Note ..... page M-20  |
| 3. Outer ring<br>Inspect inside bore for wear, corrosion, and scoring             | 8. Boots<br>Disassembly Note..... page M-20<br>Assembly Note ..... page M-20   |
| 4. Snap ring<br>Disassembly Note..... page M-19                                   | 9. Dust cover  |
| 5. Balls<br>Disassembly Note..... page M-19<br>Assembly Note ..... page M-20      | 10. Shaft and ball joint assembly<br>Inspect splines for damage and wear<br>Inspect wheel-side joint for excessive play and rough rotation |




05U0MX-040




05U0MX-041



05U0MX-042



05U0MX-043



05U0MX-044

## Disassembly note

### Boot bands

To remove the boot bands, pry up the locking clip with a screwdriver, then raise the end of the band.

## Clip

### Note

- Mark with paint; do not use a punch.

1. Mark the driveshaft and outer ring for proper reassembly.
2. Remove the clip.

## Snap ring

### Note

- Mark with paint; do not use a punch.

1. Mark the driveshaft end and inner ring.
2. Remove the snap ring with snap ring pliers.

## Cage, inner ring, and balls

Disassemble in the following order:


1. Insert a screwdriver between the inner ring and cage to remove the balls.

### Note


- Mark with paint; do not use a punch.

2. Mark the inner ring and cage.
3. Turn the cage approximately 30°, then pull it away from the inner ring.







05U0MX-045




05U0MX-046



05U0MX-047



05U0MX-048



05U0MX-049

**Boots**

1. Wrap the shaft splines with tape.
2. Remove the boot.

**Assembly note****Boots**

Before putting the boot onto the shaft, wrap the shaft splines with tape.

**Note**

- The shape of the ball-joint boots at the wheel side and the differential side differ; be careful not to install them incorrectly.

**Outer diameter of large boot end**

Differential side: 87.4mm (3.441 in)

Wheel side : 90.8mm (3.575 in)

**Cage, inner ring, and balls**

1. Align the marks and install the balls to the inner ring.


**Caution**

- Do not use any other than the specified grease.
2. Apply the specified grease (**molybdenum disulfide**) to the joints and boots.


**Total quantity**

Differential side: 75—95 g (2.65—3.35 oz)


Wheel side : 55—75 g (1.94—2.65 oz)




05U0MX-050



05U0MX-051



05U0MX-052



05U0MX-053

3. Align the marks, then install a new clip.

**Boot bands**

**Caution**

- Be sure the boot is not dented or twisted.
- Carefully lift up the small end of the boot to release any trapped air.

1. Set the boots onto the rings.

2. Measure the driveshaft length.

**Standard length: 659.7—669.7mm (25.972—26.366 in)**

If not within specification, return to Step 1.

**Note**

- **Standard length (On-vehicle): 659.3mm (25.957 in)**

**Note**

















- Always use a new band.
- The band should be folded in the direction opposite the forward revolving direction of the driveshaft.









3. Fold the band back by pulling on the end of it with pliers.

4. Lock the end of the band by bending the locking clips.


### DIFFERENTIAL

#### PREPARATION SST

<p>49 0107 680A Engine stand</p> 	<p>For disassembly and assembly of differential</p>	<p>49 M005 561 Hanger, differential carrier</p> 	<p>For disassembly and assembly of differential</p>
<p>49 0636 145 Puller, fan pulley boss</p> 	<p>For removal of bearing inner race (side bearing)</p>	<p>49 N034 213 Installer, rubber bushing</p> 	<p>For installation of differential mounting rubber</p>
<p>49 G030 795 Installer, oil seal</p> 	<p>For installation of oil seal</p>	<p>49 G030 797 Handle (Part of 49 G030 795)</p> 	<p>For installation of bearing outer race</p>
<p>49 B001 795 Installer, oil seal</p> 	<p>For installation of oil seal (output shaft)</p>	<p>49 H033 101 Remover, bearing</p> 	<p>For installation of bearing outer race (front bearing)</p>
<p>49 F027 0A1 Installer set, bearing</p> 	<p>For installation of bearing</p>	<p>49 F027 005 Attachment <math>\phi 62</math> (Part of 49 F027 0A1)</p> 	<p>For installation of bearing outer race (rear bearing)</p>
<p>49 F027 0A0 Gauge set, pinion height adjustment</p> 	<p>For adjustment of pinion height</p>	<p>49 0727 570 Gauge body, pinion height (Part of 49 F027 0A0)</p> 	<p>For adjustment of pinion height</p>
<p>49 8531 565 Pinion model</p> 	<p>For adjustment of pinion height</p>	<p>49 8531 567 Collar A (Part of 49 8531 565)</p> 	<p>For adjustment of pinion height</p>
<p>49 H027 001 Collar</p> 	<p>For adjustment of pinion height</p>	<p>49 N027 001 Gauge block</p> 	<p>For adjustment of pinion height</p>

<p>49 D017 2A1 Installer set, bearing</p> 	<p>For installation of bearing</p>	<p>49 F401 336B Attachment B (Part of 49 D017 2A1)</p> 	<p>For installation of bearing inner race (rear bearing)</p>
<p>49 F401 331 Body (Part of 49 D017 2A1)</p> 	<p>For installation of bearing inner race (rear bearing)</p>	<p>49 F401 337A Attachment C (Part of 49 D017 2A1)</p> 	<p>For installation of bearing inner race (side bearing)</p>
<p>49 S120 710 Holder, coupling flange</p> 	<p>For removal and installation of companion flange</p>	<p>49 0839 425C Puller set, bearing</p> 	<p>For removal and installation of companion flange</p>
<p>49 U027 003 Installer, oil seal</p> 	<p>For installation of oil seal (companion flange)</p>	<p>49 0259 720 Wrench, differential side bearing adjusting nut</p> 	<p>For adjustment of drive pinion and ring gear backlash</p>


05U0MX-054



9MU0MX-033

**DIFFERENTIAL OIL****Inspection**


1. Remove the filler plug.
2. Verify that the oil is at the bottom of the filler plug hole.  
If it is low, add the specified oil.
3. Install the filler plug.

**Tightening torque:****39—54 N·m (4.0—5.5 m·kg, 29—40 ft·lb)**

97U0MX-048

**Replacement**

1. Remove the filler and drain plugs.
2. Drain the differential oil into a suitable container.
3. Wipe the plugs clean.
4. Install the drain plug and washer.


**Tightening torque:****39—54 N·m (4.0—5.5 m·kg, 29—40 ft·lb)**

05U0MX-055

5. Add the specified oil from the filler plug until the level reaches the bottom of the plug hole.

**Specified oil****Type:****Above -18°C (0°F): API GL-5, SAE 90****Below -18°C (0°F): API GL-5, SAE 80W****Capacity: 0.65 liter (0.69 US qt, 0.57 Imp qt)**

6. Install the filler plug.

**Tightening torque:****39—54 N·m (4.0—5.5 m·kg, 29—40 ft·lb)**


05U0MX-056

**OIL SEAL (OUTPUT SHAFT)****Replacement**

1. Jack up the vehicle and support it with safety stands.
2. Drain the differential gear oil.


**Note**

- Mark the driveshaft and output shaft flanges for proper reassembly.




05U0MX-057


3. Remove the upper arm installation bolt and nut.




05U0MX-058




05U0MX-059



05U0MX-060



05U0MX-061



05U0MX-062

- Separate the driveshaft from the differential and suspend it.

**Note**

- Use caution during the removal operation, because the shaft may suddenly drop.

- Remove the output shaft with two pry bars as shown in the figure.

- Remove the oil seal.

- Apply lithium-based grease to the new oil seal lip and install it with the **SST**.

- Install the new clips.

**Caution**

- With viscous L.S.D., the right output shaft is longer than the left shaft.

- Install the output shaft into the side gears by lightly tapping with a plastic hammer.

- Verify that the output shaft is hooked into the side gears by pulling it by hand.

- Align the marks and install the driveshaft.

**Tightening torque:**

**54—64 N·m (5.5—6.5 m·kg, 40—47 ft·lb)**


- Install the upper arm installation bolt and nut.

**Tightening torque:**

**46—67 N·m (4.7—6.8 m·kg, 34—49 ft·lb)**

- Add the specified oil.

- Adjust the rear wheel alignment. (Refer to Section R.)



05U0MX-063

**OPERATION INSPECTION****Viscous Limited Slip Differential**


1. Turn off the engine and shift the transmission into reverse.
2. Block the front wheels with wheel chocks.
3. Jack up the rear wheels and support the vehicle with safety stands.
4. Release the parking brake.
5. Using a torque wrench on a wheel lug nut, measure the time it takes to turn the wheel **90°** while applying the specified torque.

**Specified torque: 15 N·m (1.5 m·kg, 11 ft·lb)****Specified time: 4.0 sec. min.**

6. If not as specified, replace the viscous limited slip differential and fill the differential with new specified oil. (Refer to pages M-24, 32.)

## DIFFERENTIAL, STANDARD; DIFFERENTIAL, VISCOUS LIMITED SLIP (VISCOUS L.S.D.) Removal / Installation


1. Drain the differential oil.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. Add the specified oil to the specified level.



05U0MX-064

- |  |   |
|--|---|
| <ol style="list-style-type: none"> <li>1. Rear wheel</li> <li>2. Exhaust pipe</li> <li>3. Propeller shaft                     <ul style="list-style-type: none"> <li>Removal Note..... page M-28</li> <li>Installation Note..... page M-31</li> </ul> </li> <li>4. Speedometer cable</li> <li>5. Power plant frame (PPF)                     <ul style="list-style-type: none"> <li>Removal Note..... page M-28</li> <li>Installation Note..... page M-30</li> </ul> </li> </ol> | <ol style="list-style-type: none"> <li>6. Driveshaft                     <ul style="list-style-type: none"> <li>Removal Note..... page M-29</li> </ul> </li> <li>7. Differential                     <ul style="list-style-type: none"> <li>Removal Note..... page M-29</li> <li>Installation Note..... page M-30</li> <li>Overhaul..... page M-32</li> </ul> </li> </ol> |
|--|---|






05U0MX-065


### Removal note Propeller shaft

1. Before removing the propeller shaft, mark the flanges for correct installation.



05U0MX-066


2. When the propeller shaft is removed from the extension housing, immediately install the **SST** to prevent oil leakage.



05U0MX-067


### Power plant frame (PPF)

1. Disconnect the wire harness from the PPF.  
2. Support the transmission with a jack.




05U0MX-068

3. Remove the power plant frame bracket.




05U0MX-069


4. Remove the differential-side bolts, and pry out the spacer.




05U0MX-125




05U0MX-070



05U0MX-071



05U0MX-072



05U0MX-073

5. Remove the differential mounting spacer.

6. Turn a bolt (M14x1.5) into the sleeve.
7. Twist and pull the bolt downward.
8. Install a bolt (M6x1) into the hole in the block to hold the sleeve, and remove the long bolt (M14x1.5).
9. Remove the bolt (M6x1).

#### Caution

- Do not remove the spacers shown in the figure from the PPF.
- If they are removed, replace the PPF as an assembly.

10. Remove the transmission-side bolts, and remove the PPF.

#### Driveshaft

Mark the driveshaft and output shaft for proper installation.


#### Differential

1. Support the differential with a jack.
2. Down and move it forward.


#### Note

- If it is difficult to separate the driveshaft from the output shaft, remove one side upper arm installation bolt and nut.


3. Separate the driveshaft from the output shaft.




05U0MX-074




05U0MX-075



05U0MX-076



05U0MX-077



DIFFERENTIAL MOUNTING SPACER

05U0MX-078

**Note**

- After removing the differential, support the transmission as follows to prevent damaging the fire wall, crank angle sensor, and engine mount.

1. Prepare a steel plate as shown in the figure, a wooden block, bolts (8x1.25mm), and washers.

2. Install the parts as shown in the figure.

**Installation note  
Differential**

1. Connect the driveshaft to the output shaft with the marks aligned.

2. Install the differential.

**Tightening torque:**

- Ⓐ 83—98 N·m (8.5—10 m·kg, 61—72 ft·lb)
- Ⓑ 18—26 N·m (1.8—2.7 m·kg, 13—20 ft·lb)

**Caution**

- Adjust the rear wheel alignment after installation, if the upper arm installation bolt and nut are removed. (Refer to Section R.)


**Power plant frame (PPF)**

1. Install the differential mounting spacer.

**Tightening torque:**

- 37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)

2. Support the transmission with a jack so that it is level.  
3. Position the PPF and snugly tighten the transmission-side bolts by hand.




05U0MX-079

- Verify that the sleeve is installed into the block.

**Note**

- The reamer bolt is installed in the forward hole.

- Install the spacer and bolts and snugly tighten them.




05U0MX-080

- Snugly install the power plant frame bracket.
- Tighten the transmission-side bolts.

**Tightening torque:**

**104—123 N·m (10.6—12.6 m·kg, 77—91 ft·lb)**




05U0MX-081

- Tighten the differential-side bolts.

**Tightening torque:**

**104—123 N·m (10.6—12.6 m·kg, 77—91 ft·lb)**



05U0MX-082


- Install the power plant frame bracket.

**Tightening torque:**

**(A) 104—123 N·m (10.6—12.6 m·kg, 77—91 ft·lb)**

**(B) 36—54 N·m (3.7—5.5 m·kg, 27—40 ft·lb)**

- Remove the jack, and connect the wire harness.



05U0MX-083

**Propeller shaft**


- Remove the SST.
- Align the marks, and install the propeller shaft.

**Tightening torque:**


**27—30 N·m (2.8—3.1 m·kg, 20—22 ft·lb)**

### Overhaul

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



- |   |           |   |           |
|---|-----------|---|-----------|
| 1. Output shafts                                  |           | 18. Bearing outer race (Rear bearing)             |           |
| Disassembly Note.....                             | page M-34 | Disassembly Note.....                             | page M-35 |
| Assembly Note .....                               | page M-43 | Assembly Note .....                               | page M-36 |
| 2. Differential case                              |           | 19. Bearing outer race (Front bearing)            |           |
| Disassembly Note.....                             | page M-34 | Disassembly Note.....                             | page M-35 |
| Assembly Note .....                               | page M-42 | Assembly Note .....                               | page M-36 |
| 3. Differential gear assembly                     |           | 20. Differential carrier                          |           |
| Disassembly Note.....                             | page M-34 | 21. Ring gear                                     |           |
| 4. Lock plates                                    |           | Inspect individual gear teeth for wear and cracks |           |
| Assembly Note .....                               | page M-42 | Assembly Note .....                               | page M-40 |
| 5. Bearing caps                                   |           | 22. Roll pin (Standard)                           |           |
| Disassembly Note.....                             | page M-34 | Disassembly Note.....                             | page M-35 |
| Assembly Note .....                               | page M-42 | Assembly Note .....                               | page M-40 |
| 6. Adjusting nuts                                 |           | 23. Pinion shaft (Standard)                       |           |
| Disassembly Note.....                             | page M-34 | 24. Thrust washers (Standard)                     |           |
| Assembly Note .....                               | page M-40 | 25. Pinion gears (Standard)                       |           |
| 7. Bearing outer races (Side bearing)             |           | Inspect individual gear teeth for wear and cracks |           |
| 8. Locknut (Companion flange)                     |           | 26. Thrust washers (Standard)                     |           |
| Disassembly Note.....                             | page M-34 | Assembly Note .....                               | page M-40 |
| Assembly Note .....                               | page M-38 | 27. Side gears (Standard)                         |           |
| 9. Washer   |           | Inspect individual gear teeth for wear and cracks |           |
| 10. Companion flange                              |           | 28. Bearing inner races (Side bearing)            |           |
| Disassembly Note.....                             | page M-34 | Disassembly Note.....                             | page M-35 |
| Inspect splines for wear and damage               |           | Inspect for damage and rough rotation             |           |
| Assembly Note .....                               | page M-38 | Assembly Note .....                               | page M-40 |
| 11. Oil seal (Companion flange)                   |           | 29. Gear case (Standard)                          |           |
| Assembly Note .....                               | page M-38 | 30. Gear case (Viscous L.S.D.)                    |           |
| 12. Washer  |           | 31. Viscous L.S.D.                                |           |
| 13. Drive pinion                                  |           | 32. Final gear set                                |           |
| Disassembly Note.....                             | page M-35 | 33. Oil seal (Output shaft)                       |           |
| Inspect splines for wear and damage               |           | On-vehicle replacement.....                       | page M-24 |
| Inspect individual gear teeth for wear and cracks |           | Assembly Note .....                               | page M-36 |
| 14. Spacer  |           | 34. Baffle  |           |
| Assembly Note .....                               | page M-36 | 35. Breather                                      |           |
| 15. Bearing inner race (Front bearing)            |           | 36. Differential mounting rubber                  |           |
| Inspect for damage and rough rotation             |           | Disassembly Note.....                             | page M-36 |
| 16. Collapsible spacer                            |           | Assembly Note .....                               | page M-36 |
| 17. Bearing inner race (Rear bearing)             |           |   |           |
| Disassembly Note.....                             | page M-35 |   |           |
| Inspect for damage and rough rotation             |           |   |           |
| Assembly Note .....                               | page M-38 |   |           |




05U0MX-086

### Disassembly note

#### Output shafts

Remove the output shafts with two pry bars as shown in the figure.




05U0MX-087

### Differential case

#### Caution

- Do not strike the aluminum alloy differential case.

Strike the differential carrier with a copper hammer to separate it from the case.



05U0MX-088

### Differential gear assembly


Mount the differential gear assembly on the **SST**.

#### Bearing caps

Mark one bearing cap and the carrier.

#### Adjusting nuts


Mark one adjusting nuts and the carrier.



05U0MX-089

### Locknut (Companion flange)


Hold the companion flange with the **SST** and remove the locknut.



05U0MX-090

### Companion flange


Pull the companion flange off with the **SST**.



05U0MX-091

**Drive pinion**


Push out the drive pinion by attaching a miscellaneous locknut to the drive pinion, and tapping it with a copper hammer.



05U0MX-092

**Bearing outer races (Front, and rear bearing)**

Remove the bearing outer races using the two grooves in the carrier and alternately tapping the sides of the races.




05U0MX-093

**Bearing inner race (Rear bearing)****Note**

- Support the drive pinion by hand so that it will not fall.

Remove the bearing inner race (rear bearing) with the **SST**.




05U0MX-094

**Roll pin****Note**

- Use protective plates in the vise.
- Tap out toward the ring gear side.

Secure the gear case in a vise and remove the roll pin.




05U0MX-095

**Bearing inner races (Side bearing)****Note**


- Use protective plates in the vise.
- Identify the bearings so that they can later be reinstalled in the same position.

Remove the bearing inner races (side bearing) from the gear case with the **SST**.







97U0MX-068




97U0MX-069



05U0MX-096



05U0MX-097



05U0MX-098

### Differential mounting rubber

1. Drill holes around the differential mounting rubber.

#### Note

- Use a new mounting rubber when reassembling.

2. Hit the edge of the differential mounting rubber to remove it.

### Assembly note

#### Differential mounting rubber

#### Note

- Install the mounting rubber with the voids facing fore and aft.

Press in the new differential mounting rubber with the **SST**.


**Press force: 2,000 kg (2 tons)**

#### Oil seal (Output shaft)


Apply lithium based grease to the new oil seal lip and install it with the **SST**.

#### Adjustment of pinion height


1. Install the bearing outer race (front bearing) with the **SST**.




05U0MX-099



69G09X-169



05U0MX-100



05U0MX-101

2. Install the bearing outer race (rear bearing) with the **SST**.

3. Adjust the drive pinion height as follows with the **SST**.

#### Note

- Use the spacer that was removed.

4. Install the spacer and bearing inner race (rear bearing) onto the **SST**.

#### Note


- Use the same spacer and nut removed during disassembly.

5. Assemble the spacer, bearing inner race (rear bearing), and **SST**.


Secure the **SST** with the O-ring. Install this assembly in the carrier.

Install the bearing inner race (front bearing), the **SST**, companion flange, washer, and nut.


6. Tighten the nut just enough so that the companion flange can still be turned by hand.



69G09X-172



05U0MX-102



05U0MX-103

7. Place the **SST** on the surface plate and set the dial indicator to "Zero".
8. Place the **SST** atop the drive pinion model. Set the gauge body atop the gauge block.
9. Place the feeler of the dial indicator so that it contacts where the bearing inner race (side bearing) is installed in the carrier. Measure the lowest position on the left and right sides of the carrier.
10. Add the two (left and right) values obtained in Step 9 and divide the total by 2.

**Specification: 0mm (0 in)**

**Note**

- Spacers are available in increments of 0.03mm. Select the spacer thickness that is closest to that necessary.

11. If not within specification, adjust the pinion height by selection of a spacer.

Mark	Thickness	Mark	Thickness
08	3.08mm (0.1213 in)	29	3.29mm (0.1295 in)
11	3.11mm (0.1224 in)	32	3.32mm (0.1307 in)
14	3.14mm (0.1224 in)	35	3.35mm (0.1319 in)
17	3.17mm (0.1248 in)	38	3.38mm (0.1331 in)
20	3.20mm (0.1260 in)	41	3.41mm (0.1343 in)
23	3.23mm (0.1271 in)	44	3.44mm (0.1354 in)
26	3.26mm (0.1283 in)	47	3.47mm (0.1366 in)

05U0MX-104


**Adjustment of drive pinion preload**

1. Install the spacer.


**Note**

- Press on until the force required suddenly increases.
- Install the spacer selected for the pinion height adjustment, being careful that the installation direction is correct.


2. Press the bearing inner race (rear bearing) on with the **SST**.




05U0MX-105




05U0MX-106




05U0MX-107



05U0MX-108



05U0MX-109



05U0MX-110

3. Apply a light coat of grease to the end face of the companion flange.

4. Install a new collapsible spacer.
5. Install the drive pinion assembly.

**Note**

- Do not install the oil seal.

6. Install the companion flange, and tighten the locknut with the **SST**.

**Tightening torque: 118 N·m (12 m·kg, 87 ft·lb)**

7. Turn the companion flange several turns by hand to seat the bearing.

8. Measure the drive pinion preload. Adjust the preload by tightening the locknut and record the tightening torque.

**Preload:**


**0.3—0.7 N·m (3—7 cm·kg, 2.6—6.1 in·lb)**

**Tightening torque:**


**118—177 N·m (12—18 m·kg, 87—130 ft·lb)**

9. Remove the nut, washer, and companion flange.
10. Tap a new oil seal into the differential carrier with the **SST**.


11. Install the companion flange and washer, and tighten the locknut to the tightening torque recorded in Step 8.




05UOMX-111




05UOMX-112



05UOMX-113



05UOMX-114



05UOMX-115

### Adjustment of backlash

1. Check the backlash of the side gears and pinion gears. Adjust by inserting the proper thickness thrust washer at both sides. (Standard)  
If not within specification, replace the differential gear as an assembly. (Viscous L.S.D.)

**Standard backlash: 0—0.1mm (0—0.004 in)**

### Thrust washer thickness:

Identification mark	Thickness
0	1.95—2.00mm (0.0768—0.0787 in)
1	2.05—2.10mm (0.0807—0.0827 in)
2	2.15—2.20mm (0.0846—0.0866 in)

2. Install the knock pin to secure the pinion shaft. Stake the pin with a punch to prevent it from coming out of the case.

### Adjustment of drive pinion and ring gear backlash

#### Note

- Apply approx. 0.04 cc (0.0024 cu in) of thread-locking compound at each point.


1. Apply thread-locking compound to the bolt threads (A) and point (B) of the gear back face.
2. Install the ring gear onto the gear case.

#### Tightening torque:


**69—83 Nm (7.0—8.5 m-kg, 51—61 ft-lb)**

3. Press the bearing inner races (side bearing) on with the **SST**.


4. Install the differential gear assembly in the carrier.
5. Note the identification marks on the adjusting nuts, and install them on their respective sides.
6. Install the differential bearing caps, making sure that the identification mark on the cap corresponds with the one on the carrier with the **SST**.




05U0MX-116




05U0MX-117



05U0MX-118



99U09X-025



63G09X-385

7. Mark the ring gear at four points at approx.  $90^\circ$  intervals. Mount a dial indicator to the carrier so that the feeler comes in contact at a right angle with one of the ring gear teeth.
8. Turn both bearing adjusters equally with the **SST** until the backlash is **0.09—0.11mm (0.0035—0.0043 in)**.

9. Check the backlash at the three other marked points, and make sure the maximum backlash is less than **0.07mm (0.0028 in)**.

#### Note


- When adjusting the differential bearing preload, be careful not to affect the backlash of the drive pinion and ring gear.

10. Tighten the adjusting nuts equally until the distance between the pilot sections on the bearing caps is **150.20  $\pm$  0.72 mm (5.913  $\pm$  0.028 in)**.

#### Inspection and adjustment of teeth contact


1. Coat both surfaces of 6—8 teeth of the ring gear with a thin coat of red lead.
2. While moving the ring gear back and forth by hand, rotate the drive pinion several times and check the tooth contact.
3. If the tooth contact is good, wipe off the red lead.
4. If it is not good, adjust the pinion height, and then adjust the backlash.

- (1) Toe and flank contact  
Replace the spacer with a thinner one to move the drive pinion outward.



63G09X-386

- (2) Heel and face contact  
Replace the spacer with a thicker one to bring the drive pinion in.




05U0MX-119

### Bearing caps

1. Tighten the bearing cap bolts.

#### Tightening torque:

68—89 N·m (6.9—9.1 m·kg, 50—66 ft·lb)




99U09X-043

2. Install the lock plates on the bearing caps.

#### Tightening torque:

18—25 N·m (1.8—2.6 m·kg, 13—19 ft·lb)




05U0MX-120

### Differential case

1. Apply sealant to the housing face.
2. Tighten the bolts.

#### Tightening torque:

23—26 N·m (2.3—2.7 m·kg, 10—20 ft·lb)



05U0MX-121

### Output shaft

#### Caution

- With viscous L.S.D., the right output shaft is longer than the left shaft.

1. Install a new clip.
2. Install the output shafts into the side gears by lightly tapping them with a plastic hammer.
3. Verify that the output shafts are hooked into the side gears by pulling them by hand.

# STEERING SYSTEM


<b>INDEX</b> .....	<b>N- 2</b>
<b>OUTLINE</b> .....	<b>N- 4</b>
SPECIFICATIONS .....	<b>N- 4</b>
<b>MANUAL STEERING</b> .....	<b>N- 4</b>
PREPARATION .....	<b>N- 4</b>
TROUBLESHOOTING GUIDE .....	<b>N- 5</b>
BOOT .....	<b>N- 6</b>
STEERING WHEEL AND COLUMN .....	<b>N- 8</b>
STEERING GEAR AND LINKAGE .....	<b>N-12</b>
<b>ENGINE SPEED SENSING</b>	
<b>POWER STEERING</b> .....	<b>N-13</b>
PREPARATION .....	<b>N-13</b>
TROUBLESHOOTING GUIDE .....	<b>N-13</b>
AIR BLEEDING .....	<b>N-15</b>
POWER STEERING FLUID.....	<b>N-16</b>
STEERING WHEEL AND COLUMN .....	<b>N-18</b>
STEERING GEAR AND LINKAGE .....	<b>N-19</b>
POWER STEERING OIL PUMP .....	<b>N-21</b>
DRIVE BELT.....	<b>N-22</b>



## INDEX

### MANUAL STEERING

STEERING WHEEL PLAY:  
0—30mm (0—1.18 in)




05U0NX-002

- 1. Boot  
Replacement ..... page N- 6
- 2. Steering wheel and column  
On-vehicle inspection ..... page N- 8  
Removal / Installation ..... page N- 9  
Disassembly / Assembly /  
Inspection ..... page N-10

- 3. Steering gear and linkage  
Removal / Installation ..... page N-12

**POWER STEERING**

STEERING WHEEL PLAY:  
0—30mm (0—1.18 in)



DRIVE BELT DEFLECTION  
NEW : 8—9mm (0.31—0.35 in)  
USED: 9—10mm (0.35—0.39 in)

05U0NX-003

- |   |  |
|---|--|
| <p>1. Boot<br/>Replacement..... page N- 6</p> <p>2. Steering wheel and column<br/>On-vehicle inspection..... page N- 8, 15<br/>Removal / Installation..... page N- 9<br/>Assembly / Disassembly /<br/>Inspection..... page N-10</p> <p>3. Steering gear and linkage<br/>Removal / Installation..... page N-19<br/>Air bleeding..... page N-15</p> | <p>4. Power steering oil pump<br/>Removal / Installation..... page N-21<br/>Air bleeding..... page N-15<br/>Power steering fluid ..... page N-16</p> <p>5. Drive belt<br/>Inspection..... page N-22<br/>Adjustment ..... page N-22<br/>Replacement ..... page N-22</p> |
|---|--|

### OUTLINE

#### SPECIFICATIONS



Item		Type	Manual steering	Power steering
Steering wheel	Outer diameter	mm (in)	370 (14.6)	
	Lock-to-lock	turns	3.36	2.8
Steering shaft and joint	Shaft		Collapsible, non-tilt	
	Joint		2-cross joint	
Steering gear	Power assist		—	Engine speed sensing
	Gear		Rack-and-pinion	
	Gear ratio		∞ (infinite)	
	Rack stroke	mm (in)	121.0 (4.76)	
	Power steering fluid		—	ATF DEXRON II or M-III
	Fluid capacity	liters (US qt, Imp qt)	—	0.8 (0.85, 0.70)

05U0NX-004

### MANUAL STEERING

#### PREPARATION

##### SST

<p>49 0118 850C</p> <p>Puller, ball joint</p> 	<p>For removal of tie-rod end</p>	<p>49 1243 785</p> <p>Installer, boot</p> 	<p>For installation of tie-rod end boot</p>
---	-----------------------------------	---	---

05U0NX-005


## TROUBLESHOOTING GUIDE

Problem	Possible Cause	Action	Page/Section
<b>Steering heavy</b>	Poor lubrication, foreign material, or abnormal wear of steering ball joint Stuck or damaged lower arm ball joints Improper steering pinion preload Damaged steering gear Malfunction of steering shaft joint Improperly adjusted wheel alignment Malfunctioning steering gear Incorrect tire pressure	Lubricate or replace  Replace Replace gear Replace Replace Adjust Replace Adjust	N-12  Section R N-12 N-12 N- 9 Section R N-12 Section Q
<b>Steering wheel pulls to one side</b>	Incorrect tire pressure Unevenly worn tires Weak front spring Worn or damaged stabilizer and/or suspension arm bushings Dragging brake Loose lower arm Improperly adjusted wheel alignment	Adjust Replace Replace Replace  Repair Tighten Adjust	Section Q Section Q Section R Section R  Section P Section R Section R
<b>General instability while driving</b>	Incorrect tire pressure Damaged or unbalanced wheel Worn or damaged steering joints Improper steering pinion preload Weak front coil spring Worn or damaged stabilizer and/or suspension arm bushings Malfunctioning shock absorber Improperly adjusted wheel alignment	Adjust Adjust or replace Replace Replace gear Replace Replace  Replace Adjust	Section Q Section Q N- 9 N-12 Section R Section R  Section R Section R
<b>Shake (Steering wheel vibrates up/down)</b>	Excessive tire and/or wheel runout Loose lug nuts Unbalanced wheel(s) Cracked or worn engine mount rubber Cracked or worn transmission mount rubber	Replace Tighten Adjust or replace Replace Replace	Section Q Section Q Section Q Section B Section J
<b>Shimmy (Steering wheel vibrates left/right)</b>	Cracked or worn steering gear mount rubber Loose steering gear mounting bolts Stuck or damaged steering ball joint Excessive tire and/or wheel runout Loose lug nuts Unbalanced wheel(s) Incorrect tire pressure Unevenly worn tires Malfunction of shock absorber Loose shock absorber mounting bolts Stuck or damaged lower arm ball joint Cracked or worn suspension bushings Damaged or worn front wheel bearing Improperly adjusted front wheel alignment	Replace Tighten Replace Replace Tighten Adjust or replace Adjust Replace Replace Tighten Replace Replace Replace Adjust	N-12 N-12 N-14 Section Q Section Q Section Q Section Q Section Q Section R Section R Section R Section R Section M Section R
<b>Excessive steering wheel play</b>	Worn steering gear Worn or damaged steering joints Worn or damaged suspension arm bushings Loose steering gear mounting bolts Worn linkage or tie-rod ball joint	Replace Replace Replace Tighten Replace	N-12 N- 9 Section R N-12 N-12
<b>Poor steering wheel return</b>	Incorrect tire pressure Stuck or damaged steering joints Improperly adjusted front wheel alignment Improper steering pinion preload Ball joint not operating smoothly Steering shaft contacting something	Adjust Replace Adjust Replace gear Replace Repair	Section Q N- 9 Section R N-12 N-14 N- 9
<b>Abnormal noise from steering system</b>	Loose steering gear Malfunctioning steering gear Obstruction near steering column Loose steering linkage Worn steering joints	Tighten Replace Repair or replace Tighten or replace Replace	N-12 N-12 N-12 N-12 N- 9

### BOOT

#### Replacement


1. Loosen the wheel lug nuts.
2. Jack up the front of the vehicle and support it with safety stands.
3. Remove the wheel.
4. Remove in the order shown in the figure, referring to **Removal Note**.
5. Install in the reverse order of removal, referring to **Installation Note**.
6. After installation, check the steering angle and toe-in and adjust if necessary. (Refer to Section R.)



N-m (m-kg, ft-lb)

05U0NX-007

- |                                   |  |
|-----------------------------------|--|
| 1. Cotter pin                     | 5. Tie-rod end                             |
| 2. Nut                            | 6. Tie-rod end boot                        |
| 3. Tie-rod end / Steering knuckle | Removal / Installation Note..... page N- 7 |
| Removal Note ..... page N- 7      | 7. Boot clamp                              |
| 4. Locknut                        | 8. Boot wire                               |
| Removal Note ..... page N- 7      | 9. Steering gear boot                      |



9MU0NX-032

**Removal note**

**Tie-rod end**


- 1) Loosen the tie-rod nut.
- 2) With the nut protecting the tie-rod end stud, separate the tie-rod end from the steering knuckle with the **SST**.



9MU0NX-033

**Locknut**

Before loosening the locknut from the tie-rod end, make a mark for reference when tightening.




05U0NX-008

**Tie-rod end boot**

**Caution**

- Do not scar the part where the boot is attached to the tie-rod end.

Secure the tie-rod end in a vise. Place a chisel against the boot and hold it at the angle shown. Remove the boot by tapping it with a hammer.




05U0NX-009

**Installation note**

**Tie-rod end boot**

Put a small amount of grease (lithium base) into the new boot and set it onto the tie-rod end. Press the boot onto the tie-rod end with the **SST** and a press.

## STEERING WHEEL AND COLUMN



05U0NX-010

**Caution**

- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to page T-113.)


**On-vehicle Inspection****Steering wheel play**

With the wheels in the straight-ahead position, gently turn the steering wheel to the left and right and verify that the play is within specification.

**Play: 0—30mm (0—1.18 in)**

**Note**


- If the play exceeds specification, either the steering joints are worn or the backlash of the steering gear is excessive.



05U0NX-011

**Looseness or play of steering wheel**

Move the steering wheel in directions ①, ②, and ③ to check for column bearing wear, steering shaft joint play, steering wheel looseness, and column looseness.



05U0NX-012

**Steering wheel effort**

1. Jack up the front of the vehicle.
2. Turn the steering wheel fully to the left and right at least 5 times.
3. Move the steering wheel to put the wheels in the straight-ahead position.
4. Attach a pull scale to the outermost point of the steering wheel spoke.  
Then, starting with the wheels in the straight-ahead position, measure the effort required to turn the steering wheel to the left and to the right.

**Steering wheel effort:**

**4.9—29.4 N (0.5—3.0 kg, 1.1—6.6 lb)  
[during one turn of steering wheel]**


5. If not within specification, check the following: rotation starting torque of pinion, rotation torque of each ball joint, and steering joints.

Removal / Installation

Caution

- Do not remove the steering wheel of air bag equipped models (U.S. spec.) if not necessary.
- Adjust the clockspring connector after installing the combination switch. (U.S. spec.) (Refer to Section T.)


1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal.
4. Tighten all necessary nuts and bolts to the specified torque.
5. After installation, check if the horn sounds. If the horn does not sound, remove the air bag module and connect the module connectors. (Refer to Section T.)



05U0NX-013

- |  |  |
|--|--|
| 1. Air bag module<br>Removal / Installation..... Section T | 5. Combination switch<br>Removal / Installation..... Section T             |
| 1. Horn pad (without air bag)                              | 6. Lower panel   |
| 2. Locknut   | 7. Intermediate shaft bolt   |
| 3. Steering wheel  | 8. Steering shaft<br>Disassembly / Inspection /<br>Assembly..... page N-10 |
| Removal Note ..... page N-10                               |  |
| 4. Column cover  |  |





05U0NX-014

**Removal note**  
**Steering wheel**


**Caution**

- Do not remove the steering wheels of models with air bag systems if not necessary.
- Do not try to remove the steering wheel by hitting the shaft with a hammer. The column will collapse.

Remove the steering wheel with a suitable puller.

**Disassembly / Assembly / Inspection**


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



N-m (m-kg, ft-lb)

05U0NX-015

- |  |  |
|--|--|
| <p>1. Steering lock mounting bolts and bracket<br/>Disassembly Note ..... page N-11<br/>Assembly Note..... page N-11</p> | <p>3. Steering shaft<br/>Inspection..... page N-11</p>   |
| <p>2. Steering lock assembly</p>   | <p>4. Intermediate shaft<br/>Inspect universal joint for looseness, abnormal noise, and sticking</p> |




05U0NX-016

**Disassembly note**

**Steering lock mounting bolts and bracket**

Use a chisel to make a groove in the heads of the steering lock mounting bolts. Remove the bolts with a screwdriver. Remove the steering lock assembly.



05U0NX-017

**Inspection**


Check for the following and replace the column assembly if necessary.

**Steering shaft**

1. Column bearing damage.

2. Steering shaft length.

**Length: 583.3 ± 1.5mm (22.96 ± 0.06 in)**




05U0NX-018

**Assembly note**

**Steering lock mounting bolts and bracket**

Install the steering lock assembly on the jacket. Install the new steering lock mounting bolts. Tighten the bolts until the heads break off.




05U0NX-019

### STEERING GEAR AND LINKAGE Removal / Installation

#### Caution

- Disconnect/connect the pinion shaft from/to the intermediate shaft with the wheels in the straight-ahead position, and do not turn the steering wheel while the steering gear is removed. If not done correctly, adjust the clockspring connector. (U.S. spec.) (Refer to Section T.)

1. Loosen the wheel lug nuts.
2. Jack up the front of the vehicle and support it with safety stands.
3. Remove the wheel.
4. Remove the undercover.
5. Remove in the order shown in the figure, referring to **Removal Note**.
6. Install in the reverse order of removal.











- |                |                              |
|----------------|------------------------------|
| 1. Cotter pin  | 4. Intermediate shaft bolt   |
| 2. Locknut     | 5. Mounting bracket bolt     |
| 3. Tie-rod end | 6. Steering gear and linkage |

Removal Note ..... page N-7

ENGINE SPEED SENSING POWER STEERING

PREPARATION  
SST

<p>49 0118 850C Puller, ball joint</p> 	<p>For removal of tie-rod end</p>	<p>49 1243 785 Installer, boot</p> 	<p>For installation of tie-rod end boot</p>
<p>49 1232 670A Gauge set, power steering</p> 	<p>For inspection of power steering fluid pressure</p>	<p>49 1232 672 Gauge (Part of 49 1232 670A)</p> 	<p>For inspection of power steering fluid pressure</p>
<p>49 1232 673 Valve body (Part of 49 1232 670A)</p> 	<p>For inspection of power steering fluid pressure</p>	<p>49 H002 671 Adapter, power steering gauge</p> 	<p>For inspection of power steering fluid pressure</p>
<p>49 B032 302 Adapter, power steering gauge</p> 	<p>For inspection of power steering fluid pressure</p>	<p>49 9200 020 Tension gauge, V-ribbed belt</p> 	<p>For inspection of drive belt tension</p>

05U0NX-021


TROUBLESHOOTING GUIDE

Problem	Possible Cause	Action	Page/Section
<p><b>Steering feels heavy</b></p>	<p>Poor lubrication, foreign material, or abnormal wear of steering ball joint Stuck or damaged lower arm ball joints Improper steering pinion preload Damaged steering gear Malfunctioning steering shaft joint Improperly adjusted wheel alignment Malfunctioning steering gear Incorrect tire pressure Loose or damaged oil pump drive belt Low fluid level or air in fluid Leakage of fluid Insufficient oil pump pressure</p>	<p>Lubricate or replace Replace Replace gear Replace Replace Adjust Replace Adjust Adjust or replace Add fluid or bleed air Repair or replace Replace</p>	<p>N-19 Section R N-19 N-19 N- 9 Section R N-19 Section Q N-22 N-15,16 — N-21</p>
<p><b>Steering wheel pulls to one side</b></p>	<p>Incorrect tire pressure Unevenly worn tires Weak front spring Worn or damaged stabilizer and/or upper or lower arm bushing Dragging brake Loose lower arm Improperly adjusted wheel alignment</p>	<p>Adjust Replace Replace Replace Repair Tighten or replace Adjust</p>	<p>Section Q Section Q Section R Section R Section P Section R Section R</p>


## TROUBLESHOOTING GUIDE (Cont'd)

Problem	Possible Cause	Action	Page/Section
<b>General instability while driving</b>	Incorrect tire pressure Damaged or unbalanced wheel Worn or damaged steering joint(s) Improper steering pinion preload Weak front coil spring Worn or damaged stabilizer and/or upper or lower arm bushing Malfunctioning shock absorber Improperly adjusted wheel alignment	Adjust Adjust or replace Replace Replace gear Replace Replace Replace Adjust	Section Q Section Q N- 9 N-19 Section R Section R Section R Section R
<b>Shake (Steering wheel vibrates up/down)</b>	Excessive tire and/or wheel runout Loose lug nuts Unbalanced wheel(s) Cracked or worn engine mount rubber Cracked or worn transmission mount rubber	Replace Tighten Adjust or replace Replace Replace	Section Q Section Q Section Q Section B Section J
<b>Shimmy (Steering wheel vibrates left/right)</b>	Cracked or worn steering gear mount rubber Loose steering gear mounting bolts Stuck or damaged steering ball joint Excessive tire and/or wheel runout Loose lug nuts Unbalanced wheel(s) Incorrect tire pressure Unevenly worn tires Malfunctioning shock absorber Loose shock absorber mounting bolts Stuck or damaged lower arm ball joint Cracked or worn suspension bushings Damaged or worn front wheel bearing Improperly adjusted front wheel alignment	Replace Tighten Replace Replace Tighten Adjust or replace Adjust Replace Replace Tighten Replace Replace Replace Adjust	N-19 N-19 N-19 Section Q Section Q Section Q Section Q Section Q Section R Section R Section R Section R Section R Section M Section R
<b>Excessive steering wheel play</b>	Worn steering gear Worn or damaged steering joints Worn or damaged lower arm bushing Loose steering gear mounting bolts Worn linkage or tie-rod ball joint	Replace Replace Replace Tighten Replace	N-19 N- 9 Section R N-19 N-19
<b>Poor steering wheel return</b>	Incorrect tire pressure Stuck or damaged steering joints Improperly adjusted front wheel alignment Improper steering pinion preload Ball joint not operating smoothly Steering shaft contacting something	Adjust Replace Adjust Adjust Replace gear Replace Replace	Section Q N- 9 Section R N-19 N-19 N- 9
<b>Abnormal noise from steering system</b>	Loose oil pump Loose steering gear Loose oil pump bracket Drive belt loose/tight Air in system Malfunctioning steering gear Malfunctioning oil pump Obstruction near steering column or pressure hose Loose steering linkage Worn steering joints	Tighten Tighten Tighten Adjust Bleed air Replace Replace Replace Repair or replace Tighten or replace Replace	N-21 N-19 Section B N-22 N-15 N-19 N-21 N- 9 N-19 N- 9

05UONX-022




05U0NX-023



97U0NX-040

**AIR BLEEDING**

1. Check the fluid level. (Refer to page N-16.)
2. Turn the steering wheel fully to the left and right several times with the engine not running.
3. Recheck the fluid level. If it has dropped, add fluid.
4. Repeat Steps 2 and 3 until the fluid level stabilizes.
5. Start the engine and let it idle.
6. Turn the steering wheel fully to the left and right several times.
7. Verify that the fluid is not foamy and that the fluid level has not dropped.
8. Add fluid if necessary and repeat Steps 6 and 7.



05U0NX-024

### POWER STEERING FLUID

#### Inspection

#### Fluid level

Check the power steering fluid level. Add fluid to the specified level, if necessary.

#### Caution

- Use only the specified power steering fluid.

#### Fluid specification:

**ATF DEXRON-II or M-III**

### Fluid leakage


#### Caution


- To prevent damage to the steering system, do not keep the steering wheel in the fully turned position for more than 15 seconds.

Start the engine and let it idle. Turn the steering wheel fully to the left and right to apply fluid pressure. Check for fluid leakage.


#### Note

- The points where fluid leakage may occur are indicated in the figure.







05U0NX-026




05U0NX-027



9MU0NX-010



05U0NX-028



05U0NX-029

## Fluid pressure

1. Assemble the **SST** as shown in the figure.

### Tightening torque:

**39—49 N·m (4.0—5.0 m·kg, 29—36 ft·lb)**

### Note

- **Before disconnecting the hose, make marks at the connections for proper reinstallation.**

2. Disconnect the high-pressure hose from the oil pump. Attach the **SST**.
3. Bleed the air from the system. (Refer to page N-15.)

4. Open the gauge valve fully. Start the engine and turn the steering wheel fully left and right to raise the fluid temperature to **50—60°C (122—140°F)**.

### Caution


- **If the valve is left closed for more than 15 seconds, the fluid temperature will increase excessively and adversely affect the oil pump.**

5. Close the gauge valve completely. Increase the engine speed to **1,000—1,500 rpm** and measure the fluid pressure generated by the oil pump. If the pressure is not within specification, replace the oil pump assembly.


**Oil pump fluid pressure: 7,603—8,339 kPa (77.5—85.0 kg/cm<sup>2</sup>, 1,102—1,209 psi)**

6. Open the gauge valve fully and increase the engine speed to **1,000—1,500 rpm**.







05U0NX-030




05U0NX-031



05U0NX-032



97U0NX-016



05U0NX-033

**Caution**

- If the steering wheel is kept in the fully turned position for more than 15 seconds, the fluid temperature will rise excessively and adversely affect the oil pump.

7. Turn the steering wheel fully to the left and right and measure the fluid pressure generated by the gear housing. If the pressure is not within specification, replace the gear housing assembly.

**Gear housing fluid pressure: 7,603—8,339 kPa  
(77.5—85.0 kg/cm<sup>2</sup>, 1,102—1,209 psi)**

8. Remove the gauge set. Install and tighten the high-pressure hose to the specified torque.

**Tightening torque:**

**31—47 N·m (3.2—4.8 m·kg, 23—35 ft·lb)**

9. Bleed the air from the system. (Refer to page N-15.)

**STEERING WHEEL AND COLUMN****Caution**

- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to page T-113.)

**On-vehicle Inspection****Steering wheel effort**

1. With the vehicle on a hard, level surface, put the wheels in the straight-ahead position.
2. Start the engine and warm the power steering fluid to **50—60°C (122—140°F)**.

3. With the engine running at idle, attach a pull scale to the outermost point of the steering wheel spoke. Then, starting with the wheels in the straight-ahead position, measure the effort required to turn the steering wheel to the left and to the right.

**Steering wheel effort:**

**23.5—35.3 N (2.4—3.6 kg, 5.3—8.0 lb)  
[during one turn of the steering wheel]**

4. If not within specification, check the following: fluid level, air in system, fluid leakage at hose or connections, function of oil pump and gear box, and tire pressure.

**STEERING GEAR AND LINKAGE**

**Removal / Installation**

**Caution**


- **Disconnect/connect the pinion shaft from/to the intermediate shaft with the wheels in the straight-ahead position, and do not turn the steering wheel while the steering gear is removed. If not done correctly, adjust the clockspring connector. (U.S. spec.) (Refer to Section T.)**

1. Loosen the wheel lug nuts.
2. Jack up the front of the vehicle and support it with safety stands.
3. Remove the wheels.
4. Remove in the order shown in the figure, referring to **Removal Note**.

**Note**

- **Use a container or rags to collect the power steering fluid when disconnecting the pressure pipe and return hose.**


5. Install in the reverse order of removal, referring to **Installation Note**.
6. Tighten all necessary bolts and nuts to the specified torque.
7. After installation:
  - (1) Check for fluid leakage. (Refer to page N-16.)
  - (2) Bleed air from the system. (Refer to page N-15.)



N-m (m-kg, ft-lb)

05U0NX-034

- |                              |                              |
|------------------------------|------------------------------|
| 1. Cotter pin                | 5. Pressure pipe             |
| 2. Nut                       | Removal Note ..... page N-20 |
| 3. Tie-rod end               | 6. Return hose               |
| Removal Note ..... page N- 7 | 7. Mounting bracket bolt     |
| 4. Bolt                      | 8. Steering gear and linkage |



05U0NX-035

### **Removal note**

#### **Pressure pipe**

Before removing the pressure pipe, make marks for reference during installation.

**POWER STEERING OIL PUMP**

**Removal / Installation**

1. Remove in the order shown in the figure, referring to **Removal Note**.


**Note**

- Use a container or rags to collect the power steering fluid when disconnecting the pressure pipe and return hose.

2. Install in the reverse order of removal, referring to **Installation Note**.

3. After installation:

- (1) Check connections for fluid leakage. (Refer to page N-16.)
- (2) Bleed air from system. (Refer to page N-15.)




N-m (m-kg, ft-lb)

05U0NX-036

1. Drive belt
  - Inspection..... page N-22
  - Adjustment..... page N-22
  - Replacement..... page N-22
2. Power steering pressure switch connector

3. Pressure pipe
  - Removal Note ..... page N-22
4. Return hose
5. Oil pump assembly




05U0NX-037

### Removal note

#### Pressure pipe

Mark the pressure pipe for reference during installation before loosening.




05U0NX-038

### DRIVE BELT

#### Inspection

1. Check the drive belt for wear, cracks, and fraying. Replace if necessary.
2. Check the drive belt deflection by applying mode rate pressure (**98 N, 10 kg, 22 lb**) midway between the pulleys. Adjust if necessary.



05U0NX-039

#### Deflection (Depressed at 98 N [10 kg, 22 lb])

**New : 8—9mm (0.31—0.35 in)**

**Used: 9—10mm (0.35—0.39 in)**


#### Tension

**New : 491—589 N (50—60 kg, 110—132 lb)**

**Used: 422—491 N (43—50 kg, 95—110 lb)**

#### Note

- Belt tension can be measured between any pulleys.



05U0NX-040

### Adjustment


1. Loosen P/S oil pump bolt (A) and nuts (B) and (C). Adjust the belt deflection by turning the adjusting bolt (D).

#### Tightening torque:

**(A): 31—46 N·m (3.2—4.7 m·kg, 23—34 ft·lb)**

**(B): 36—54 N·m (3.7—5.5 m·kg, 27—40 ft·lb)**

**(C): 19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)**



05U0NX-041


### Replacement

1. Loosen bolt (A), nuts (B) and (C), and adjusting bolt (D).
2. Remove and replace the drive belt.
3. Adjust the deflection (tension). (Refer to above.)

# BRAKING SYSTEM

<b>INDEX</b> .....	<b>P- 2</b>
<b>OUTLINE</b> .....	<b>P- 3</b>
SPECIFICATIONS .....	<b>P- 3</b>
<b>BRAKE SYSTEM</b> .....	<b>P- 4</b>
PREPARATION .....	<b>P- 4</b>
TROUBLESHOOTING GUIDE .....	<b>P- 5</b>
AIR BLEEDING .....	<b>P- 6</b>
BRAKE HYDRAULIC LINE .....	<b>P- 6</b>
BRAKE FLUID .....	<b>P- 7</b>
BRAKE PEDAL .....	<b>P- 7</b>
MASTER CYLINDER .....	<b>P-10</b>
POWER BRAKE UNIT .....	<b>P-13</b>
PROPORTIONING BYPASS VALVE.....	<b>P-16</b>
FRONT BRAKE (DISC) .....	<b>P-18</b>
CALIPER .....	<b>P-21</b>
REAR BRAKE (DISC) .....	<b>P-22</b>
CALIPER .....	<b>P-25</b>
<b>PARKING BRAKE SYSTEM</b> .....	<b>P-27</b>
TROUBLESHOOTING GUIDE .....	<b>P-27</b>
PARKING BRAKE LEVER .....	<b>P-27</b>
PARKING BRAKE CABLE .....	<b>P-28</b>

INDEX



05U0PX-002

1. Brake hydraulic line		7. Front disc brake	
Inspection .....	page P- 6	Quick Inspection, On-vehicle.....	page P-18
Removal / Installation .....	page P- 6	Replacement (pad) .....	page P-18
2. Brake fluid		Removal / Installation .....	page P-19
Inspection .....	page P- 7	Inspection .....	page P-20
Replacement.....	page P- 7	8. Caliper	
3. Brake pedal		Disassembly / Inspection /	
On-vehicle inspection .....	page P- 9	Assembly .....	page P-21
Removal / Inspection / Installation	page P- 9	9. Rear disc brake	
4. Master cylinder		Quick Inspection, On-vehicle.....	page P-22
Removal / Installation .....	page P-10	Replacement (pad) .....	page P-22
Disassembly / Inspection /		Removal / Installation .....	page P-23
Assembly .....	page P-12	Inspection .....	page P-24
5. Power brake unit		10. Caliper	
Quick Inspection, On-vehicle.....	page P-13	Disassembly / Inspection /	
Removal / Installation .....	page P-15	Assembly .....	page P-25
6. Proportioning bypass valve (PBV)		11. Parking brake lever	
Inspection .....	page P-16	Inspection .....	page P-27
Replacement.....	page P-16	Adjustment	
		Removal / Inspection / Installation	page P-28
		12. Parking brake cable	
		Removal / Inspection / Installation	page P-29

**OUTLINE**

**SPECIFICATIONS**





Item		Specifications
Brake pedal	Type	Suspended
	Pedal level ratio	4.1 : 1
	Maximum stroke	mm (in) 133 (5.24)
Master cylinder	Type	Tandem (with level sensor)
	Bore	mm (in) 22.22 (0.875)
Front disc brake	Type	Disc (ventilated)
	Cylinder bore	mm (in) 51.1 (2.01)
	Pad dimensions (area x thickness)	mm <sup>2</sup> x mm (in <sup>2</sup> x in) 3,700 x 9.5 (5.73 x 0.37)
	Disc plate dimension (effective diameter x thickness)	mm (in) 235 x 18 (9.25 x 0.71)
Rear disc brake	Type	Disc (solid)
	Cylinder bore	mm (in) 31.75 (1.25)
	Pad dimensions (area x thickness)	mm <sup>2</sup> x mm (in <sup>2</sup> x in) 2,600 x 8.0 (4.03 x 0.31)
	Disc plate dimensions (effective diameter x thickness)	mm (in) 231 x 9 (9.09 x 0.35)
Power brake unit	Type	Vacuum multiplier
	Size	mm (in) 214 (8)
Braking force control device	Type	Proportioning bypass valve (PBV)
Brake fluid		SAE J1703 or FMVSS 116, DOT-3
Parking brake	Type	Mechanical, two rear brakes
	Operation system	Hand lever

05U0PX-504



### BRAKE SYSTEM

#### PREPARATION SST


<p>49 0259 770B</p> <p>Wrench, flare nut</p> 	<p>For removal and installation brake pipes</p>	<p>49 F043 001</p> <p>Adjust gauge</p> 	<p>For adjustment of push rod clearance</p>
<p>49 0221 600C</p> <p>Expand tool, disc brake</p> 	<p>For installation of disc pads</p>	<p>49 0208 701A</p> <p>Boot air out tool</p> 	<p>For removal of piston seal</p>

05U0PX-003


## TROUBLESHOOTING GUIDE

Problem	Possible cause	Action	Page
<b>Poor braking</b>	Leakage of brake fluid	Repair	—
	Air in lines	Air bleed	P- 6
	Worn pad	Replace	P-18,22
	Brake fluid, grease, oil, or water on pad	Clean or replace	P-18,22
	Hardening of pad surface or poor contact	Grind or replace	P-18,22
	Malfunction of disc brake piston	Replace	P-19,23
	Malfunction of master cylinder	Repair or replace	P-10
	Malfunction of power brake unit	Repair or replace	P-15
	Malfunction of check valve (vacuum hose)	Repair or replace	P-15
	Damaged vacuum hose	Replace	P-15
	Deterioration of flexible hose	Replace	P- 6
Malfunction of proportioning bypass valve (PBV)	Replace	P-16	
<b>Brakes pull to one side</b>	Worn pad	Replace	P-18,22
	Brake fluid, grease, oil, or water on pad	Clean or replace	P-18,22
	Hardening of pad surface or poor contact	Grind or replace	P-18,22
	Abnormal wear, distortion, or eccentricity of disc	Repair or replace	Section M
	Malfunction of automatic adjuster in rear brake	Repair	—
	Looseness or deformation of dust cover mounting bolt	Tighten or replace	Section M
	Malfunction of disc brake piston	Repair or replace	P-19,23
	Worn or improperly adjusted wheel bearing preload	Replace or adjust	Section M
	Improper adjustment of wheel alignment	Adjust	Section R
Unequal tire air pressure	Adjust	Section Q	
<b>Brakes do not release</b>	No brake pedal play	Adjust	P- 8
	Improper adjustment of push rod clearance	Adjust	P-11
	Clogged master cylinder return port	Clean	—
	Pad not returning properly	Repair	—
	Improper return or malfunction of brake caliper piston	Replace	P-21,25
	Excessive runout of disc plate	Replace	Section M
Improper adjustment of wheel bearing preload	Adjust or replace	Section M	
<b>Pedal goes too far (Too much pedal stroke)</b>	Air in system because of insufficient brake fluid	Add fluid and bleed air	P- 6
	Improper adjustment of pedal play	Adjust	P- 8
	Worn pad	Replace	P-18,22
	Air in lines	Bleed air	P- 6
<b>Abnormal noise or vibration during braking</b>	Worn pad	Replace	P-18,22
	Deterioration of pads	Grind or replace	P-18,22
	Brakes do not release	Repair	—
	Foreign material or scratches on disc plate contact surface	Clean	—
	Looseness of caliper mounting bolt(s)	Tighten	P-19,23
	Damage or deviation of disc contact surface	Replace	Section M
	Poor contact of pads	Repair or replace	P-18,22
	Insufficient grease on sliding parts	Apply grease	—

05U0PX-004



05U0PX-005




05U0PX-006

## AIR BLEEDING


### Caution

- The fluid in the reservoir must be maintained at the 3/4 level or higher during air bleeding.
- Do not spill brake fluid onto painted surfaces.

1. Jack up the vehicle and support it with safety stands.
2. Remove the bleeder cap and attach a vinyl tube to the bleeder screw.
3. Place the other end of the vinyl tube in a clear container and keep the tube end immersed in brake fluid during air bleeding.
4. Pump the brake pedal several times.
5. While the brake pedal is depressed, loosen the bleeder screw to let fluid and air escape.
6. Repeat Steps 4 and 5 until there are no air bubbles in the fluid.
7. Check for correct brake operation.
8. Check that there is no fluid leakage. Be sure to clean away any spilled fluid with rags.
9. After bleeding the air, add brake fluid to the specified level in the reservoir.



05U0PX-007



05U0PX-008

## BRAKE HYDRAULIC LINE


### Inspection

Check the following and replace parts as necessary.

1. Cracks, damage, and corrosion of the brake hose
2. Damage to the brake hose threads
3. Scars, cracks, and swelling of the flexible hose
4. All lines for fluid leakage

### Removal / Installation

1. When disconnecting the flexible hose and brake line, remove the clip after loosening the flare nut.
2. When connecting the flexible hose, do not tighten it too tight or twist it.
3. Check that the hose does not contact other parts when the vehicle bounces or when the steering wheel is turned all the way to the left or right.
4. Bleed the air from the brake system.



05U0PX-009

**BRAKE FLUID****Inspection**

Check the fluid level in the reservoir. It should be between MAX and MIN.


If the fluid level is extremely low, check the brake system for leaks.

**Fluid specification:**

**SAE J1703 or FMVSS 116, DOT-3**

**Caution**


- The fluid in the reservoir must be maintained at 3/4 level or higher during bleeding.
- Do not allow the brake fluid to get on painted surfaces.



05U0PX-010

**Replacement**

1. Remove the brake fluid from the reservoir with a suction pump.
2. Fill the reservoir with clean brake fluid.
3. Attach a vinyl tube to the bleeder screw and place the other end of the tube in a clear container.
4. Pump out the old brake fluid by loosening the bleeder screws one by one and pumping the brake pedal until only clean fluid is expelled.
5. Fill the reservoir to the specified level.



05U0PX-011


**BRAKE PEDAL****On-vehicle Inspection****Pedal height**

Check that the distance from the center of the upper surface of the pedal pad to the carpet is as specified.

**Pedal height: 171—181mm (6.93—7.13 in)**  
**(With carpet)**

**Adjustment**

1. Disconnect the stoplight switch connector.
2. Loosen locknut (B) and turn switch (A) until it does not contact the pedal.
3. Loosen locknut (D) and turn rod (C) to adjust the height.
4. Adjust the pedal free play and tighten operating rod locknut (D).
5. Turn the stoplight switch until it contacts the pedal; then turn an additional 1/2 turn. Tighten the locknut.




05U0PX-012

**Pedal play**

1. Depress the pedal a few times to eliminate the vacuum in the system.
2. Lightly depress the pedal by hand until resistance is felt, and check the free play.


**Free play: 4—7mm (0.16—0.28 in)**



05U0PX-013

**Adjustment**

1. Loosen locknuts (D) and turn rod (C) to adjust the free play.
2. Tighten locknuts (D).



05U0PX-014

**Pedal-to-floor clearance**

Check that the distance from the floor panel to the center of the upper surface of the pedal pad is as specified when the pedal is depressed with a force of **589 N (60 kg, 132 lb)**.

**Pedal-to-floor clearance: 95mm (3.74 in)  
(Without carpet)**


If the distance is less than specified, inspect for air in the brake system.

## Removal / Inspection / Installation

1. Remove in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal.
4. After installation, check and adjust the pedal height and free play if necessary.

### Caution

- **Apply grease to the inner surface of the bushing and to the contact surfaces of the clevis pin and spring.**



05U0PX-015

1. Spring clip
2. Clevis pin
3. Nut
4. Spring washer
5. Bolt

6. Return spring  
Inspect for weakness and damage
7. Brake pedal  
Inspect for bending
8. Guide pipe

9. Bushing  
Inspect for wear
10. Stopper rubber  
Inspect for wear
11. Pedal pad  
Inspect for wear and damage


MASTER CYLINDER

Removal / Installation

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.
3. After installation, add brake fluid, bleed air, and check for fluid leakage.

Caution

- Brake fluid will damage painted surfaces. If it does get on a painted surface, wipe it off immediately.




1. Fluid level sensor connector
2. Brake pipe  
Removal note..... below
3. Connector bolts


4. Nut and washer
5. Reservoir and master cylinder  
Disassembly / Assembly /  
Inspection ..... page P-12

Removal note


Brake pipe

Disconnect/connect the brake pipe from/to the master cylinder with the **SST**.







05U0PX-017




9MU0PX-022



05U0PX-018



05U0PX-019



9MU0PX-025

**Installation note**  
**Push rod clearance**

Measure the clearance between the push rod of the power brake unit and the piston of the master cylinder.

1. Place the **SST** atop the master cylinder. Turn the adjustment bolt until it bottoms in the piston.

2. Apply **500 mmHg (19.7 inHg)** vacuum to the power brake unit with a vacuum pump.

3. Invert the adjustment gauge used in Step 1, and place it on the power brake unit.

4. Measure the clearance between the end of the adjustment bolt and the push rod of the power brake unit.

If it is not **0mm (0 in)**, loosen the push rod locknut and turn the push rod to make the adjustment.

**Reference**

By making the above adjustment, the clearance between the push rod and piston (after installation of the brake master cylinder and the power brake unit) will be as shown in the table below.

	Clearance
When vacuum applied to unit is approx. 500 mmHg (19.7 inHg)	0.1—0.3mm (0.004—0.012 in)

**Inspection**

Fluid level sensor

1. Disconnect the sensor connector.
2. Connect an ohmmeter to the connector.
3. Starting with the fluid level above the MIN mark on the reservoir, verify that there is no continuity.
4. Remove the brake fluid and verify continuity when the level is below the MIN mark.
5. Replace the sensor if necessary.




### Disassembly / Assembly / Inspection

1. After removing the brake fluid, disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of removal, referring to **Assembly Note**.


### Caution

- **Secure the master cylinder flange in a vise when necessary.**
- **Replace the piston assembly if necessary.**
- **Do not let foreign material enter the cylinder, and do not scratch the inside of the cylinder or the outer surface of the piston.**




05U0PX-020


- |   |   |
|---|---|
| <ol style="list-style-type: none"> <li>1. Fluid level sensor</li> <li>2. Screw</li> <li>3. Reservoir assembly<br/>Inspect for damage and deformation</li> <li>4. Bushings</li> <li>5. Stopper screw and O-ring</li> <li>6. Snap ring</li> </ol> | <ol style="list-style-type: none"> <li>7. Primary piston assembly<br/>Inspect for abnormal wear, rust, and damage</li> <li>8. Secondary piston assembly<br/>Inspect for abnormal wear, rust, and damage</li> <li>9. Cylinder<br/>Inspect for abnormal wear, rust, and damage</li> </ol> |
|---|---|




05U0PX-021




05U0PX-022



05U0PX-023



9MU0PX-033



05U0PX-024

**POWER BRAKE UNIT****Quick Inspection, On-vehicle****Power brake unit function check  
(Simple method)****Step 1**

1. With the engine stopped, depress the pedal a few times.
2. With the pedal depressed, start the engine.
3. If immediately after the engine starts the pedal moves down slightly, the unit is operating.

**Step 2**

1. Start the engine and let it run **1 or 2 minutes**.
2. Stop the engine.
3. Depress the pedal with the usual force.
4. If the first pedal stroke is long and becomes shorter with subsequent strokes, the unit is operating.
5. If a problem is found, inspect for damage or improper connection of the check valve or vacuum hose. Repair if necessary, and inspect it once again.

**Step 3**

1. Start the engine.
2. Depress the pedal with the usual force.
3. Stop the engine with the pedal depressed.
4. Hold the pedal down for **about 30 seconds**.
5. If the pedal height does not change, the unit is operating.
6. If there is a problem, check for damage or improper connection of the check valve or vacuum hose. Repair if necessary, and check once again.

If the nature of the problem is still not clear after following the 3 steps above, follow the more detailed check described in "Method using tester," below.

**(Method using tester)**


Connect a pressure gauge, vacuum gauge, and pedal depression force gauge as shown in the figure. After bleeding the air from the pressure gauge, conduct the test as described in the 3 steps below.

**Note**


- Use commercially available gauges and pedal depression force gauge.

**a) Checking for vacuum loss****Unloaded condition**


1. Start the engine.
2. Stop the engine when the vacuum gauge indicates **500 mmHg (19.7 inHg)**.
3. Observe the vacuum gauge for **15 seconds**. If the gauge indicates **475—500 mmHg (18.7—19.7 inHg)**, the unit is operating.




05U0PX-025



05U0PX-026



05U0PX-027



05U0PX-028

**Loaded condition**

1. Start the engine.
2. Depress the brake pedal with a force of **196 N (20 kg, 44 lb)**.
3. With the brake pedal depressed, stop the engine when the vacuum gauge indicates **500 mmHg (19.7 inHg)**.
4. Observe the vacuum gauge for **15 seconds**. If the gauge indicates **475—500 mmHg (18.7—19.7 inHg)**, the unit is operating.

**b) Checking for hydraulic pressure**

1. If with the engine stopped (**vacuum 0 mmHg [0 inHg]**) the fluid pressure is within specification, the unit is operating.

Pedal force	Fluid pressure
196 N (20 kg, 44 lb)	1,079—1,177 kPa (11—12 kg/cm <sup>2</sup> , 156—171 psi)

2. Start the engine. Depress the brake pedal when the vacuum reaches **500 mmHg (19.7 inHg)**. If the fluid pressure is within specification, the unit is operating.

Pedal force	Fluid pressure
196 N (20 kg, 44 lb)	5,199—5,494 kPa (53—56 kg/cm <sup>2</sup> , 754—796 psi)

**Inspection of check valve**

**Note**

- The check valve is pressed into the vacuum hose. There is an arrow on the hose to indicate direction of hose installation.

**Inspection**


1. Disconnect the vacuum hose from the engine.
2. Apply suction and pressure to the hose from the engine side. Verify that air flows only toward the engine. If the air passes in both directions or not at all, replace the vacuum hose (along with the check valve).

## Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.
3. Take the following steps after installation:
  - (1) Check and adjust the push rod and piston clearance. (Refer to page P-11.)
  - (2) Add fluid and bleed the air. (Refer to page P-6.)
  - (3) Check all parts for fluid leakage.
  - (4) Make an on-vehicle check of the unit. (Refer to page P-13.)
  - (5) Check that the vacuum hose does not contact other parts.

### Caution


- Apply grease to the clevis pin.
- Apply sealant to the gasket contact surface.




05U0PX-029

1. Fluid level sensor connector
2. Brake pipe
3. Proportioning valve
4. Master cylinder

5. Vacuum hose with check valve
6. Clevis pin
7. Power brake unit
8. Gasket



05U0PX-030



05U0PX-031

**PROPORTIONING BYPASS VALVE**

**Inspection**

1. Connect two pressure gauges [9,810 kPa (100 kg/cm<sup>2</sup>, 1,422 psi)] to the pipes.
2. Measure the fluid pressure from the master cylinder and to the rear brake.

**Specification**

Fluid pressure kPa (kg/cm <sup>2</sup> , psi)			
A	A'	B	B'
2,943 (30, 427)	2,943 ± 196 (30 ± 2, 427 ± 28)	6,867 (70, 995)	4,120 ± 294 (42 ± 3, 597 ± 43)

**Caution**


- If not as specified, replace the valve assembly.
- After inspection:  
Add brake fluid and bleed the air.  
(Refer to page P-6.)  
Check the brake lines for fluid leakage.

**Replacement**

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.
3. After installation:
  - (1) Add brake fluid and bleed the air. (Refer to page P-6.)
  - (2) Check the brake lines for fluid leakage.

**Caution**


- Brake fluid will damage painted surfaces. If it does get on a painted surface, wipe it off immediately.



N-m (m-kg, ft-lb)

05U0PX-032

- |                               |           |
|-------------------------------|-----------|
| 1. Brake pipe                 |           |
| Removal.....                  | page P-17 |
| Installation.....             | page P-17 |
| 2. Bolt                       |           |
| 3. Proportioning bypass valve |           |




05U0PX-033

## Removal / Installation Note

### Brake pipe

Disconnect/connect the brake pipes with the **SST**.



05U0PX-034


**FRONT BRAKE (DISC)  
Quick Inspection, On-vehicle  
Disc pad**

1. Jack up the front of the vehicle and support it with safety stands.
2. Remove the wheels.
3. Sight through the caliper inspection hole and verify the remaining thickness of the pad.

**Thickness: 1.0mm (0.04 in) min.**

**Replacement  
Disc pad**

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal, referring to **Installation Note**.




**N-m (m-kg, ft-lb)**

05U0PX-035

- |                   |           |
|-------------------|-----------|
| 1. Lock bolt      |           |
| Removal.....      | page P-18 |
| 2. Disc pad       |           |
| Installation..... | page P-19 |


- |                |
|----------------|
| 3. Outer shim  |
| 4. Inner shim  |
| 5. Guide plate |



05U0PX-036

**Removal  
Lock bolt**

1. Remove the lower lock bolt.
2. Rotate the caliper upward and support it with a piece of rope.



05U0PX-037


**Installation**

**Disc pad**

1. Push the piston inward with the **SST**.
2. Install the new pads in the mounting support.

**Removal / Installation Caliper**


1. Jack up the front of the vehicle and support it with safety stands.
2. Remove the wheels; then remove components in the order shown in the figure.
3. Install in the reverse order of removal.
4. Tighten all nuts and bolts to the specified torques, referring to the figure.



05U0PX-038

- |  |                            |
|--|----------------------------|
| 1. Brake hose                          | 5. Bolt                    |
| 2. Lock bolt                           | 6. Mounting support        |
| 3. Brake caliper assembly              | 7. Disc plate              |
| Disassembly / Assembly ..... page P-21 | Inspection ..... page P-20 |
| 4. Disc pad assembly                   |                            |
| Inspection ..... page P-20             |                            |





05U0PX-039


**Inspection**

Check the following and repair or replace parts as necessary.

**Disc pad**

1. Oil or grease on facing.
2. Abnormal wear or cracks.
3. Deterioration or damage by heat.
4. Remaining lining thickness.

**Thickness: 1.0mm (0.04 in) min.**



05U0PX-040


**Disc plate**

1. Runout.

**Runout: 0.1mm (0.004 in) max.**

**Caution**

- There must be no wheel bearing looseness.
- The measurement must be taken at the outer edge of the disc plate surface.



05U0PX-041

2. Wear and damage.

**Thickness**


**Standard: 18mm (0.71 in)**

**Minimum: 16mm (0.63 in)**

**CALIPER**


**Disassembly / Inspection / Assembly**

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Install in the reverse order of removal.



05U0PX-042

- |  |  |
|--|--|
| <p>1. Dust seal<br/>Inspect for damage and poor sealing</p> <p>2. Piston<br/>Disassembly ..... page P-21<br/>Inspect for wear and rust</p> | <p>3. Piston seal<br/>4. Bleeder screw<br/>5. Caliper body<br/>Inspect for damage and cracks</p> |
|--|--|



9MU0PX-075


**Disassembly note**

**Piston**

Place a piece of wood in the caliper; then blow compressed air through the hole to force the piston out of the caliper.

**Caution**

- **Blow the compressed air slowly to prevent the piston from popping out.**



05U0PX-043

**REAR BRAKE (DISC)  
Quick Inspection, On-vehicle  
Disc pad**


1. Jack up the rear of the vehicle and support it with safety stands.
2. Remove the wheels.
3. Sight through the caliper inspection hole and verify the remaining thickness of the pad.

**Thickness: 1.0mm (0.04 in) min.**

**Replacement**

**Disc pad**


1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.



N-m (m-kg, ft-lb)

05U0PX-044

- |                              |                            |
|------------------------------|----------------------------|
| 1. Plug                      | 4. M-spring                |
| 2. Manual adjustment gear    | 5. Disc pad                |
| Removal ..... below          | Inspection ..... page P-24 |
| Installation ..... page P-23 | 6. Shim                    |
| 3. Lock bolt                 | 7. Guide plate             |




05U0PX-045

**Removal note**

**Manual adjustment gear**

Turn the manual adjustment gear counterclockwise with an Allen wrench to pull the brake caliper piston back.

ADJUSTING BRAKE PADS



05U0PX-046

### Installation note


#### Manual adjustment

1. Turn the manual adjustment gear clockwise until the brake pads just touch the disc plate.
2. Return the manual adjustment gear counterclockwise 1/3 turn.

### Removal / Installation

#### Caliper

1. Jack up the rear of the vehicle and support it with safety stands.
2. Remove the wheels; then remove components in the order shown in the figure.
3. Install in the reverse order of removal.
4. Tighten all nuts and bolts to the specified torques, referring to the figure.




N-m (m-kg, ft-lb)

05U0PX-047

1. Parking cable  
Removal / Inspection / Installation page P-29
2. Connecting bolt
3. Brake hose
4. Plug
5. Manual adjustment gear  
Removal..... page P-22  
Installation..... page P-23
6. Lock bolt

7. Caliper  
Disassembly / Assembly ..... page P-25
8. Disc pad assembly  
Replacement..... page P-22  
Inspection ..... page P-24
9. Bolt
10. Mounting support
11. Disc plate  
Inspection ..... page P-24



05U0PX-048


**Inspection**

Check the following and repair or replace parts as necessary.

**Disc pad**

1. Oil or grease on facing.
2. Abnormal wear or cracks.
3. Deterioration or damage by heat.
4. Remaining lining thickness.

**Thickness: 1.0mm (0.04 in) min.**



05U0PX-049


**Disc plate**

1. Runout.

**Runout: 0.1mm (0.004 in) max.**

**Caution**

- There must be no wheel bearing looseness.
- The measurement must be taken at the outer edge of the disc plate surface.



05U0PX-050

2. Wear or damage.

**Thickness**


**Standard: 9.0mm (0.35 in)**

**Minimum: 7.0mm (0.28 in)**

**CALIPER**


**Disassembly / Inspection / Assembly**

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Install in the reverse order of removal.



05U0PX-051

- |  |  |
|--|--|
| <ol style="list-style-type: none"> <li>1. Dust seal<br/>Inspect for damage and poor sealing</li> <li>2. Piston<br/>Disassembly ..... below<br/>Assembly ..... page P-26<br/>Inspect for wear and rust</li> <li>3. Manual adjustment gear</li> <li>4. Snap ring</li> <li>5. Adjusting bolt</li> </ol> | <ol style="list-style-type: none"> <li>6. O-ring</li> <li>7. Connecting link</li> <li>8. Piston seal</li> <li>9. Spring</li> <li>10. Operating lever</li> <li>11. Cap and bleeder screw</li> <li>12. Caliper body<br/>Inspect for damage and cracks</li> </ol> |
|--|--|




05U0PX-052

**Disassembly note**

**Piston**

1. Turn the adjustment gear clockwise with an Allen wrench to remove the piston from it. (Turn the adjustment gear until it turns easily.)




05U0PX-053

2. Place a piece of wood in the caliper; then blow compressed air through the hole to force the piston out of the caliper.

**Caution**

- **Blow the compressed air slowly to prevent the piston from popping out.**



05U0PX-054

**Assembly****Piston**


Insert the piston into the caliper and turn the adjustment gear counterclockwise with an Allen wrench to pull the piston in fully. (Turn the adjustment gear until it stops.)

**PARKING BRAKE SYSTEM**

**TROUBLESHOOTING GUIDE**

Problem	Possible cause	Action	Page
<b>Brakes do not release</b>	Improper return of parking brake cable or improper adjustment	Repair or adjust	P-29
<b>Parking brake does not hold well</b>	Excessive lever stroke Brake cable stuck or damaged Brake fluid or oil on pads Hardening of pad surfaces or poor contact	Adjust Repair or replace Clean or replace Grind or replace	P-27 P-29 P-18,22 P-18,22

05U0PX-055




05U0PX-056

**PARKING BRAKE LEVER**

**Inspection**

1. Depress the brake pedal several times.
2. Verify that the stroke is within specification when the parking brake lever is pulled with a force of **98 N (10 kg, 22 lb)**.

**Stroke: 5—7 notches**



05U0PX-057

**Adjustment**

1. Jack up the rear of the vehicle until the wheels are free to turn and support it with stands.
2. Depress the brake pedal several times.
3. Turn the adjusting nut to adjust the lever stroke.
4. Check that the parking brake warning light illuminates when the brake lever is pulled one notch.

**Caution**


- **Verify that the brakes do not drag.**

5. Lower the vehicle.




Removal / Inspection / Installation

1. Block the wheels firmly.
2. Release the parking brake.
3. Remove in the order shown in the figure.
4. Inspect all parts and repair or replace as necessary.
5. Install in the reverse order of removal, referring to **Installation Note**.
6. After installation:  
Adjust the parking lever stroke. (Refer to page P-27.)



05U0PX-058

- |                             |                               |
|-----------------------------|-------------------------------|
| 1. Screw                    | 6. Cap                        |
| 2. Cover                    | 7. Spring                     |
| 3. Bolt                     | Inspect for weakness          |
| 4. Parking brake switch     | 8. Bolt                       |
| Installation..... page P-28 | 9. Parking brake lever        |
| 5. Adjusting nut and clip   | Inspect for damage and cracks |



9MU0PX-110

Installation note


Parking brake switch

1. Install the parking brake switch so that it contacts the parking brake lever when the lever is fully released.
2. Turn the ignition switch ON, and check that the parking brake warning lamp illuminates with the lever pulled one notch.

## PARKING BRAKE CABLE

### Removal / Inspection / Installation

1. Block the wheels firmly.
2. Release the parking brake.
3. Remove the parking brake lever.
4. Jack up the vehicle and support it with safety stands.
5. Remove the parking brake cable in the order shown in the figure.
6. Install in the reverse order of removal.
7. After installation:
  - (1) Adjust the parking brake lever stroke.
  - (2) Depress the brake pedal a few times.
  - (3) Verify that the rear brakes do not drag while the wheels are rotated by hand.



19-26 (1.9-2.6, 14-19)

N-m (m-kg, ft-lb)

05U0PX-059

1. Adjusting nut and clip
2. Clip
3. Spring  
Inspect for weakness

4. Front cable  
Inspect for damage
5. Rear cable  
Inspect for damage

# WHEELS AND TIRES

<b>OUTLINE</b> .....	<b>Q- 2</b>
SPECIFICATIONS.....	<b>Q- 2</b>
<b>TROUBLESHOOTING GUIDE</b> .....	<b>Q- 2</b>
<b>WHEELS AND TIRES</b> .....	<b>Q- 3</b>
SPECIAL NOTES ABOUT WHEELS AND TIRES .....	<b>Q- 3</b>
NOTES REGARDING TIRE REPLACEMENT, INSPECTION / ADJUSTMENT.....	<b>Q- 3</b>
REMOVAL / INSTALLATION .....	<b>Q- 4</b>
TIRE ROTATION .....	<b>Q- 4</b>
WHEEL BALANCE ADJUSTMENT .....	<b>Q- 5</b>

05U0QX-001

### OUTLINE

#### SPECIFICATIONS

Item	Type	Standard	Temporary spare
Wheels	Size	14 x 5 1/2-JJ	14 x 4T
	Offset	mm (in)	45 (1.77)
	Pitch circle diameter	mm (in)	100 (3.94)
	Material	Aluminum Alloy	Steel
Tires	Size	185/60R14 82H	T115/70D14
	Air pressure	kPa (kgf/cm <sup>2</sup> , psi)	177 (1.8, 26)

05U0QX-002

### TROUBLESHOOTING GUIDE

Problem	Possible Cause	Action	Page
<b>Excessive or irregular tire wear</b>	Refer to page Q- 4 for details.		
<b>Premature tire wear</b>	Incorrect tire pressure	Adjust	Q- 3
<b>Tire squeal</b>	Incorrect tire pressure Tire deterioration	Adjust Replace	Q- 3 —
<b>Road noise or body vibration</b>	Insufficient tire pressure Unbalanced wheel(s) Deformed wheel(s) or tire(s) Irregular tire wear	Adjust Adjust Repair or replace Replace	Q- 3 Q- 5 — —
<b>Shake (Steering wheel vibrates up/down)</b>	Excessive tire and wheel runout Loose lug nuts Unbalanced wheel(s) Cracked or worn engine mount rubber Cracked or worn transmission mount rubber	Replace Tighten Adjust or replace Replace Replace	— Q- 4 Q- 5 Sections B1,B2 Sections K1,K2
<b>Shimmy (Steering wheel vibrates left/right)</b>	Cracked or worn steering gear mount rubber Loose steering gear mounting bolts Stuck or damaged steering ball joint Excessive tire and wheel runout Loose lug nuts Unbalanced wheel(s) Insufficient tire pressure Unevenly worn tires Malfunction of shock absorber Loose shock absorber mounting bolts Struck or damaged lower arm ball joint Cracked or worn suspension bushings Damaged or worn front wheel bearing Improperly adjusted front wheel alignment	Replace Tighten Replace Replace Tighten Adjust or replace Adjust Replace Replace Tighten Replace Replace Replace Replace Adjust	Section N Section N Section N — Q- 4 Q- 5 Q- 3 — Section R Section R Section R Section R Section R Section M Section R
<b>Uneven (one-sided) braking</b>	Unequal tire pressures	Adjust	Q- 3
<b>Steering wheel doesn't return properly or pulls to either left or right</b>	Incorrect tire pressure Irregular tire wear (left/right) Unequal tire pressures Different types or brands of tires mixed (left/right) Loose lug nuts	Adjust Replace Adjust Replace Tighten	Q- 3 — Q- 3 — Q- 4
<b>General driving instability</b>	Unequal tire pressures Damaged or unbalanced wheel(s) Loose lug nuts	Adjust Replace or adjust Tighten	Q- 3 Q- 5 Q- 4
<b>Excessive steering wheel play</b>	Loose lug nuts	Tighten	Q- 4

05U0QX-003

WHEELS AND TIRES

**SPECIAL NOTES ABOUT WHEELS AND TIRES**

1. Do not use wheels or tires other than the specified types.
2. Aluminum wheels are easily scratched. When washing them, use a soft cloth, never a wire brush. If the vehicle is steam cleaned, do not allow boiling water to contact the wheels.
3. If alkaline compounds (such as saltwater or road salts) get on aluminum wheels, wash them as soon as possible to prevent damage. Use only a neutral detergent.


9MU0QX-004

**NOTES REGARDING TIRE REPLACEMENT**


Note the following points when tires are to be removed from or mounted onto the wheels.

1. Be careful not to damage the tire bead, the rim bead, or the edge of the rim.
2. Apply a soapy solution to the tire bead and the edge of the rim.
3. Use a wire brush, sandpaper, or cloth to clean and remove all rust and dirt from the rim edge and the rim bead. For aluminum wheels, use only a cloth for this purpose; never use a wire brush or sandpaper.
4. Remove pebbles, glass, nails, and other foreign items embedded in the tire tread.
5. Be sure the air valve is installed correctly.
6. After mounting a tire onto a wheel, inflate it to 250—300 kPa (2.55—3.06 kg/cm<sup>2</sup>, 35.55—42.66 psi). Verify that the bead is seated correctly onto the rim and that there are no air leaks. Then reduce the pressure to the specified level.
7. If a tire iron is used to change a tire on an aluminum wheel, be sure to use a piece of rubber between the iron lever and the wheel to avoid damage to the wheel. Work should be done on a rubber mat, not on a hard or rough surface.


05U0QX-004



05U0QX-005



05U0QX-006



9MU0QX-008

**INSPECTION / ADJUSTMENT**

Check the following and adjust or replace as necessary.

1. Air pressure.  
Check the air pressure of all tires, including the spare tire, with an air pressure gauge.

**Air pressure:**

**Standard tires 177 kPa (1.8 kgf/cm<sup>2</sup>, 26 psi)**

**Temporary spare tires 412 kPa (4.2 kgf/cm<sup>2</sup>, 60 psi)**

**Caution**

- The air pressure must be measured when the tire is cold.

2. Wheel runout.  
Set the probe of a dial indicator against the wheel, and turn the wheel one full revolution.

**Wheel runout: Horizontal 2.0mm (0.079 in) max.  
Vertical 1.5mm (0.059 in) max.**

3. Tire wear.

**Specifications**


**Remaining tread**

**Ordinary tires: 1.6mm (0.063 in) min.**


(Tire should be replaced if wear indicators are exposed.)

**Snow tires: 50% of tread**


(Tire should be replaced if wear indicators are exposed.)




05U0QX-007



05U0QX-008



05U0QX-009



05U0QX-010

**Troubleshooting guide**

Abnormal tire wear patterns shown in the illustration can occur. Refer to the chart for the possible causes and actions.

	Possible cause	Action
(a)	<ul style="list-style-type: none"> <li>• Underinflation (both sides worn)</li> <li>• Incorrect camber (one side worn)</li> <li>• Hard cornering</li> <li>• Lack of rotation</li> </ul>	<ul style="list-style-type: none"> <li>• Measure and adjust pressure</li> <li>• Repair or replace suspension parts</li> <li>• Reduce speed</li> <li>• Rotate tires</li> </ul>
(b)	<ul style="list-style-type: none"> <li>• Overinflation</li> <li>• Lack of rotation</li> </ul>	<ul style="list-style-type: none"> <li>• Measure and adjust pressure</li> <li>• Rotate tires</li> </ul>
(c)	<ul style="list-style-type: none"> <li>• Incorrect toe-in</li> </ul>	<ul style="list-style-type: none"> <li>• Adjust toe-in</li> </ul>
(d)	<ul style="list-style-type: none"> <li>• Incorrect camber or caster</li> <li>• Malfunctioning suspension</li> <li>• Unbalanced wheel</li> <li>• Out-of-round brake drum or disc</li> <li>• Other mechanical conditions</li> <li>• Lack of rotation</li> </ul>	<ul style="list-style-type: none"> <li>• Repair or replace suspension parts</li> <li>• Repair or replace</li> <li>• Balance or replace</li> <li>• Correct or replace</li> <li>• Correct or replace</li> <li>• Rotate tires</li> </ul>

4. Cracks, damage, and foreign matter (such as metal pieces, nails, and stones) in the tire and cracks, deformation, and damage to the wheel.
5. Loose wheel lug nut(s).
6. Air leaking from valve stem.

**REMOVAL / INSTALLATION**

Tighten the lug nuts to the specified torque in a crisscross fashion.

**Tightening torque:**

**88—118 Nm (9—12 m-kg, 65—87 ft-lb)**

**Caution**


- **The wheel-to-hub contact surfaces must be clean.**
- **Never apply oil to the nuts, bolts, or wheels, which cause looseness or seizure of the lug nuts.**

**TIRE ROTATION**

To prolong tire life and assure uniform tire wear, rotate the tires every 6,000 km (3,750 miles), sooner if irregular wear develops.

**Caution**

- **Do not include “TEMPORARY USE ONLY” spare tire in rotation.**
- **After rotating the tires, adjust each tire to the specified air pressure. (Refer to page Q-3.)**




9MU0QX-012

## WHEEL BALANCE ADJUSTMENT

If a wheel becomes unbalanced or if a tire is replaced or repaired, the wheel must be rebalanced to within specification.

**Maximum unbalance (at rim edge): 10 g (0.35 oz)**



05U0QX-011

### Caution

- Do not use more than two balance weights on the inner or outer side of the wheel. If the total weight exceeds 100 g (3.5 oz), rebalance after moving the tire around on the rim.
- Attach the balance weights tightly so that they do not protrude more than 3mm (0.12 in) beyond the wheel edge.
- Select suitable balance weights for aluminum alloy wheels.

# SUSPENSION


<b>INDEX</b> .....	<b>R- 2</b>
<b>OUTLINE</b> .....	<b>R- 4</b>
SPECIFICATIONS .....	<b>R- 4</b>
<b>TROUBLESHOOTING GUIDE</b> .....	<b>R- 5</b>
<b>WHEEL ALIGNMENT</b> .....	<b>R- 6</b>
PRE-INSPECTION .....	<b>R- 6</b>
FRONT WHEEL ALIGNMENT .....	<b>R- 6</b>
REAR WHEEL ALIGNMENT .....	<b>R- 9</b>
<b>FRONT SUSPENSION (DOUBLE-WISHBONE)</b> .....	<b>R-11</b>
PREPARATION .....	<b>R-11</b>
SHOCK ABSORBER AND SPRING .....	<b>R-12</b>
LOWER ARM .....	<b>R-15</b>
UPPER ARM .....	<b>R-17</b>
STABILIZER .....	<b>R-19</b>
CROSSMEMBER .....	<b>R-20</b>
<b>REAR SUSPENSION (DOUBLE-WISHBONE)</b> .....	<b>R-21</b>
PREPARATION .....	<b>R-21</b>
SHOCK ABSORBER AND SPRING .....	<b>R-22</b>
LOWER ARM .....	<b>R-23</b>
UPPER ARM .....	<b>R-24</b>
STABILIZER .....	<b>R-25</b>
CROSSMEMBER .....	<b>R-26</b>

05U0RX-001



### INDEX

#### FRONT SUSPENSION




05U0RX-002

- 1. Shock absorber and spring  
Removal / Installation ..... page R-12  
Disassembly / Inspection /  
Assembly ..... page R-13
- 2. Lower arm  
Removal / Inspection / Installation page R-15

- 3. Upper arm  
Removal / Inspection / Installation page R-17
- 4. Stabilizer  
Removal / Inspection / Installation page R-19
- 5. Crossmember  
Removal / Inspection / Installation page R-20

REAR SUSPENSION



05U0RX-003

- 1. Shock absorber and spring  
Removal / Installation ..... page R-22  
Disassembly / Inspection /  
Assembly ..... page R-13
- 2. Lower arm  
Removal / Inspection / Installation page R-23

- 3. Upper arm  
Removal / Inspection / Installation page R-24
- 4. Stabilizer  
Removal / Inspection / Installation page R-25
- 5. Crossmember  
Removal / Inspection / Installation page R-26

## OUTLINE

SPECIFICATIONS  
Front Suspension

Item		Specifications	
Suspension type		Double-wishbone	
Stabilizer	Type	Torsion bar	
	Diameter mm (in)	19 (0.75)	
Shock absorber		Cylindrical double acting, low-pressure-gas charged	
Coil spring	Identification mark color	Red	
	Wire diameter mm (in)	10.8 (0.43)	
	Coil inner diameter mm (in)	83 (3.27)	
	Free length mm (in)	282.5 (11.12)	
	Coil number	5.91	
Front wheel alignment (Unloaded*1)	Total toe-in	mm (in)	$3 \pm 3 (0.12 \pm 0.12)$
		degree	$0^{\circ}18' \pm 18'$
	Maximum steering angle	Inner	$37^{\circ} 23' \pm 2^{\circ}$
		Outer	$32^{\circ} 32' \pm 2^{\circ}$
	Camber angle		$0^{\circ}24' \pm 45'^{*2}$
	Caster angle		$4^{\circ}30' \pm 45'$
	Kingpin angle		$11^{\circ}20'$

05U0RX-004

## Rear Suspension

Item		Specifications	
Suspension type		Double-wishbone	
Stabilizer	Type	Torsion bar	
	Diameter mm (in)	12 (0.47)	
Shock absorber		Cylindrical double acting, low-pressure-gas charged	
Coil springs	Identification mark color	Blue	
	Wire diameter mm (in)	10.1 (0.40)	
	Coil inner diameter mm (in)	83 (3.27)	
	Free length mm (in)	339.5 (13.37)	
	Coil number	7.68	
Rear wheel alignment (Unloaded*1)	Total toe-in	mm (in)	$3 \pm 3 (0.12 \pm 0.12)$
		degree	$0^{\circ}18' \pm 18'$
	Camber angle		$-0^{\circ}43' \pm 30'$

05U0RX-005


\*1 Fuel tank full; radiator coolant and engine oil at specified levels; spare tire, jack, and tools in designated positions.

\*2 Difference between left and right must not exceed 1°.


## TROUBLESHOOTING GUIDE

Problem	Possible cause	Action	Page
<b>General instability</b>	Weak coil spring Malfunction of shock absorber Worn or damaged stabilizer and/or suspension arm bushings  Worn or damaged upper or lower arm ball joint Improperly adjusted wheel alignment	Replace Replace Replace  Replace Adjust	R-13 R-12,22 R-16,18,19 23,24,25 Section M R-15,17 R- 6
<b>Body "rolls"</b>	Weak stabilizer Worn or damaged stabilizer and/or suspension arm bushings	Replace Replace	R-19,25 R-16,18,19 23,24,25 Section M
<b>"Heavy" steering wheel operation</b>	Insufficiently lubricated or stuck upper arm lower arm ball joint Improperly adjusted wheel alignment	Replace  Adjust	R-15,17  R- 6
<b>Steering wheel pulls to one side</b>	Weak coil spring Worn or damaged stabilizer and/or suspension arm bushings Deformed upper or lower arm or knuckle  Loose upper or lower arm bushing	Replace Replace  Replace  Replace	R-13 R-16,18,19 23,24,25 R-15,17 Section M R-16,18
<b>Excessive steering wheel play</b>	Worn or damaged upper or lower arm bushing Worn or damaged upper or lower arm ball joint	Replace Replace	R-16,18 R-15,17
<b>Body leans</b>	Weak coil spring Weak stabilizer and/or suspension arm bushings	Replace Replace	R-13 R-16,18,19 23,24,25 Section M
<b>Abnormal noise from suspension system</b>	Loose mounting component Poorly lubricated or worn upper or lower arm ball joint Malfunction of shock absorber Worn or damaged stabilizer and/or suspension arm bushings	Tighten Replace Replace Replace	— R-15,17 R-12,22 R-16,18,19 23,24,25 Section M
<b>Shake (Steering wheel vibrates up/down)</b>	Excessive tire or wheel runout Loose lug nuts Unbalanced wheel(s) Cracked or worn engine mounting rubber Cracked or worn transmission mounting rubber	Replace Tighten Adjust or replace Replace Replace	— Section Q Section Q Section B Section J
<b>Shimmy (Steering wheel vibrates left/right)</b>	Cracked or worn steering gear mounting rubber Loose steering gear mounting bolts Stuck or damaged steering ball joint Excessive tire or wheel runout Loose lug nuts Unbalanced wheel(s) Insufficient tire pressure Unevenly worn tires Malfunction of shock absorber Loose shock absorber mounting bolts Stuck or damaged upper or lower arm ball joint Cracked or worn suspension bushings Damaged or worn front wheel bearing Improperly adjusted front wheel alignment	Replace Tighten Replace Replace Tighten Adjust or replace Adjust Replace Replace Tighten Replace Replace Replace Replace Adjust	Section N Section N Section N — Section Q Section Q Section Q Section Q R-12,22 R-12,22 R-15,17 R-16,18,19 Section M R- 6

05U0RX-006



05U0RX-007



05U0RX-008

### WHEEL ALIGNMENT

#### PRE-INSPECTION

1. Check the tire inflations, and adjust to the recommended pressure if necessary.
2. Inspect the front wheel bearing paly and correct if necessary.
3. Inspect the wheel and tire runouts.
4. Inspect the ball joints and steering linkage for excessive looseness.
5. The vehicle must be on level ground and carry no luggage or passengers.
6. Measure the height from the center of the wheel to the fender brim. The difference between left and right must be not exceed **10mm (0.31 in)**, and the difference between front and rear must be **20mm ± 10mm (0.62 ± 0.31 in)**.

#### Caution

- The proper caster and camber angle vary depending on the vehicle height. Refer to the following and to page R-9 for the specifications.
- Inspection and adjustment of wheel alignment must be done with the vehicle unladed\*<sup>1</sup>.

### FRONT WHEEL ALIGNMENT Specifications (Unladed\*<sup>1</sup>)

Item		Specifications	
Total toe-in	mm (in)	3 ± 3 (0.12 ± 0.12)	
	degree	0°18' ± 18'	
Maximum steering angle	Inner	37°23' ± 2°	
	Outer	32°32' ± 2°	
Kingpin angle		11°20'	
Camber angle	Height from center of wheel to fender brim mm (in)	328—337 (12.9—13.3)	-0°20' ± 45' <sup>*2</sup>
		338—347 (13.3—13.7)	0°03' ± 45' <sup>*2</sup>
		348—357 (13.7—14.1)	0°24' ± 45' <sup>*2</sup>
		358—367 (14.1—14.4)	0°44' ± 45' <sup>*2</sup>
		368—377 (14.4—14.8)	1°02' ± 45' <sup>*2</sup>
Caster angle	Height from center of wheel to fender brim mm (in)	328—337 (12.9—13.3)	5°16' ± 45'
		338—347 (13.3—13.7)	5°02' ± 45'
		348—357 (13.7—14.1)	4°49' ± 45'
		358—367 (14.1—14.4)	4°35' ± 45'
		368—377 (14.4—14.8)	4°21' ± 45'

05U0RX-009

\*<sup>1</sup> Fuel tank full; radiator coolant and engine oil at specified levels; spare tire, jack, and tools in designated positions.

\*<sup>2</sup> Difference between left and right must not exceed 1°.

#### Adjustment


##### Maximum steering angle

1. Remove the steering gear boot clamp.
2. Loosen the tie-rod locknut.
3. Turn the tie-rod to provide the correct maximum steering angle.
4. After adjustment, tighten the locknut to the specified torque.


##### Tightening torque:

**34—39 Nm (3.5—4.0 m-kg, 25—29 ft-lb)**


5. Adjust the toe-in. (Refer to page R-8.)
6. Verify that the boot is not twisted, and install the boot clamp.




05U0RX-010




05U0RX-011




05U0RX-012



05U0RX-013



05U0RX-014



05U0RX-015

### Caster

Caster is adjusted by turning the front and/or rear adjusting cam bolt at the lower arm.

### Caution

- **Adjust the caster before adjusting the camber.**

1. Loosen the front and/or rear cam nut.
2. Turn the front and/or rear adjusting cam bolt to provide the correct caster angle.

Caster	Left wheel		Right wheel	
	Front cam	Rear cam	Front cam	Rear cam
Increase	Counter-clockwise	Counter-clockwise	Clockwise	Clockwise
Decrease	Clockwise	Clockwise	Counter-clockwise	Counter-clockwise

### Note

- **Turning the front cam one graduation on the scale changes the caster angle about 22' and the camber about 25'. Turning the rear cam one graduation changes the caster angle about 22' and the camber about 2'.**

3. Adjust the camber and the toe-in.

### Camber

Camber is adjusted by turning the front and rear adjusting cam bolts at the lower arm.

### Caution


- **Adjust the camber after adjusting the caster.**

1. Loosen the front and rear cam nuts.
2. Turn the front and rear adjusting cam bolts the same amount in the opposite direction to provide the correct camber angle.


Caster	Left wheel		Right wheel	
	Front cam	Rear cam	Front cam	Rear cam
Positive	Counter-clockwise	Clockwise	Clockwise	Counter-clockwise
Negative	Clockwise	Counter-clockwise	Counter-clockwise	Clockwise

### Note

- **Turning the front cam one graduation changes the camber about 25' and the caster about 22'. Turning the rear cam one graduation changes the camber about 2' and the caster about 22'.**



05U0RX-016



05U0RX-017

**Note**

- If the cam cannot be turned far enough to make the adjustment, begin again at adjustment of the caster using the other cam.

3. Tighten the nuts.

**Tightening torque:**

**73—95 N·m (7.4—9.7 m·kg, 54—70 ft·lb)**

4. Adjust the toe-in.

**Toe-in**

1. Remove the steering gear boot clamp.
2. Loosen the left and right tie-rod locknuts, and turn the tie-rods by the same amount.

**Caution**

- The left and right tie-rods are both right threaded. To increase the toe-in, turn the right tie-rod toward the front of the vehicle, and turn the left tie-rod by the same amount toward the rear.
- One turn of the tie-rod (one side) changes the toe-in by about 7mm (0.28 in).
- Adjust the toe-in after adjusting the steering angle.

3. Tighten the tie-rod locknuts to the specified torque.

**Tightening torque:**

**34—39 N·m (3.5—4.0 m·kg, 25—29 ft·lb)**


4. Verify that the boot is not twisted, and install the boot clamp.

## REAR WHEEL ALIGNMENT


### Specifications (Unladen\*)

Item		Specifications	
Total toe-in	mm (in)	3 ± 3 (0.12 ± 0.12)	
	degree	0°18' ± 18'	
Camber angle	Height from center of wheel to fender brim mm (in)	346—355 (13.6—14.0)	-1°08' ± 30'
		356—365 (14.0—14.4)	-0°54' ± 30'
		366—375 (14.4—14.8)	-0°43' ± 30'
		376—385 (14.8—15.2)	-0°35' ± 30'
		386—395 (15.2—15.6)	-0°30' ± 30'

\* Fuel tank full; radiator coolant and engine oil at specified levels; spare tire, jack, and tools in designated positions. 05U0RX-018



05U0RX-019



05U0RX-020

### Toe-in

Toe-in is adjusted by turning the front and/or rear adjusting cam bolt at the lower arm.

### Caution

- **Adjust the toe-in before adjusting the camber.**


1. Loosen the front and/or rear cam nut.
2. Turn the front and/or rear adjusting cam bolt to provide the correct toe-in.

Toe-in	Left wheel		Right wheel	
	Front cam	Rear cam	Front cam	Rear cam
Increase	Counter-clockwise	Counter-clockwise	Clockwise	Clockwise
Decrease	Clockwise	Clockwise	Counter-clockwise	Counter-clockwise

### Note

- **Turning the front cam one graduation changes the toe-in about 2.8mm (0.11 in) and the camber about 15'. Turning the rear cam one graduation changes the toe-in about 2.8mm (0.11 in) and the camber about 6'.**

3. Adjust the camber.



05U0RX-021

### Camber


Camber is adjusted by turning the front and rear cams at the lower arm.

### Caution


- **Adjust the camber after adjusting the toe-in.**

1. Loosen the front and rear cam nuts.
2. Turn the front and rear adjusting cam bolts the same amount in the opposite direction to provide the correct camber angle.





05U0RX-022



Camber	Left wheel		Right wheel	
	Front cam	Rear cam	Front cam	Rear cam
Positive	Counter-clockwise	Clockwise	Clockwise	Counter-clockwise
Negative	Clockwise	Counter-clockwise	Counter-clockwise	Clockwise

### Note

- Turning the front cam one graduation changes the camber about 15' and the toe-in about 2.8mm (0.11 in). Turning the rear cam one graduation changes the camber about 6' and the toe-in about 2.8mm (0.11 in).
- If the cam cannot be turned far enough to make the adjustment, begin again at adjustment of the toe-in using the other cam.









3. Tighten the nuts.

### Tightening torque:

**73—95 N·m (7.4—9.7 m·kg, 54—70 ft·lb)**

FRONT SUSPENSION (DOUBLE-WISHBONE)

PREPARATION  
SST

<p>49 0727 575 Puller, socket joint</p> 	<p>For removal of lower arm ball joint</p>	<p>49 0118 850C Puller, ball joint</p> 	<p>For removal of upper arm ball joint</p>
<p>49 0180 510B Attachment, steering worm bearing preload measuring</p> 	<p>For inspection of upper arm ball joint</p>	<p>49 H028 301 Installer, dust boot</p> 	<p>For installation of front lower arm boot</p>
<p>49 G034 1A0 Compressor, coil spring</p> 	<p>For removal and installation of coil spring</p>	<p>49 G034 101 Body (Part of 49 G034 1A0)</p> 	<p>For removal and installation of coil spring</p>
<p>49 G034 102 Screw (Part of 49 G030 1A0)</p> 	<p>For removal and installation of coil spring</p>	<p>49 G034 103 Arm (Part of 49 G030 1A0)</p> 	<p>For removal and installation of coil spring</p>

05U0RX-023

### SHOCK ABSORBER AND SPRING


#### Removal / Installation

1. Jack up the front of the vehicle and support it with safety stands.
2. Remove the undercover.
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Inspect all parts and repair or replace as necessary.
5. Install in the reverse order of removal.
6. Tighten all nuts and bolts to the specified torques, referring to the figure.

#### Note

- **Loosely tighten the shock absorber, upper arm, stabilizer control link, and stabilizer bracket bolts. Lower the vehicle and tighten all nuts and bolts to the specified torques with the vehicle unladen.**


7. Adjust the front wheel alignment. (Refer to page R-6.)



05U0RX-024

1. Wheel and tire
2. Stabilizer control link bolt
3. Upper arm ball joint  
Removal Note..... page R-17

4. Mounting plate nut  
Removal Note..... page R-13
5. Shock absorber and spring  
Disassembly / Assembly ..... page R-13



05U0RX-025

**Removal note**  
**Shock absorber and spring**


1. Loosen the lower arm bolts.
2. Lower the lower arm to remove the shock absorber.

**Caution**

- Do not lower the arm excessively, which may damage the brake hose.

**Disassembly / Inspection / Assembly**

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.
4. Tighten all nuts and bolts to the specified torques, referring to the figure.




N·m (m·kg, ft·lb)


05U0RX-026

1. Cap
2. Mounting plate
3. Bound stopper  
Inspect for damage


4. Coil spring  
Disassembly Note ..... page R-14  
Assembly Note ..... page R-14
5. Shock absorber  
Inspect for oil leakage and abnormal noise




05U0RX-027




05U0RX-028



05U0RX-029



05U0RX-030



05U0RX-031

**Disassembly note****Coil spring**

1. Loosen the piston rod upper nut several turns, but do not remove the nut.

**Caution**

- Do not remove the nut.
- Use copper or aluminum plates in the jaws of the vise.

2. Assemble the **SST**.
3. Compress the coil spring with the **SST**, and remove the upper nut.
4. Remove the coil spring.

**Assembly note****Coil spring and bound stopper**

1. Set the shock absorber in a vise.
2. Install the bound stopper on the shock absorber as shown.

3. Install the compressed coil spring (compressed with **SST**).
4. Install the mounting plate.

5. Remove the **SST**.
6. Secure the mounting plate in a vise.

**Caution**

- Use copper or aluminum plates in the jaws of the vise.

7. Tighten the piston rod upper nut.

**Tightening torque:**

**31—46 N·m (3.2—4.7 m·kg, 23—34 ft·lb)**

## LOWER ARM


### Removal / Inspection / Installation

1. Jack up the front of the vehicle and support it with safety stands.
2. Remove the undercover.
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Inspect all parts and repair or replace as necessary.
5. Install in the reverse order of removal, referring to **Installation Note**.
6. Tighten all nuts and bolts to the specified torques, referring to the figure.

### Note


- Loosely tighten the lower arm, shock absorber, and stabilizer control link bolts. Lower the vehicle and tighten all nuts and bolts to the specified torques with the vehicle unladen.

7. Adjust the front wheel alignment. (Refer to page R-6.)



05U0RX-032

- |  |  |
|--|--|
| <ol style="list-style-type: none"> <li>1. Wheel and tire</li> <li>2. Stabilizer control link bolt</li> <li>3. Shock absorber bolt</li> <li>4. Lower arm ball joint<br/>Removal Note..... page R-16<br/>Inspection ..... page R-16</li> </ol> | <ol style="list-style-type: none"> <li>5. Lower arm bushing (front and rear)<br/>Inspect for deterioration and wear</li> <li>6. Ball joint dust boot<br/>Removal Note..... page R-16<br/>Installation Note..... page R-16</li> <li>7. Lower arm<br/>Inspect for damage and cracks</li> </ol> |
|--|--|




49 0727 575

05U0RX-033

**Removal note****Lower arm ball joint**

Separate the ball joint from the knuckle with the **SST**.




05U0RX-034

**Ball joint dust boot**

Remove the dust boot with a chisel.

**Caution**

- Do not damage the ball joint stud.




49 H028 301

05U0RX-036

**Installation note****Ball joint dust boot**

1. Liberally coat the inside of the new dust boot with grease.
2. Press the dust boot onto the ball joint with the **SST**.



49 0180 510B

05U0RX-037

**Inspection****Lower arm ball joint****Ball joint rotation torque**

1. Shake the ball joint stud 5 times.
2. Connect the **SST** to the ball stud, and measure the rotation torque with a pull scale.

**Rotation torque:**

0.5—1.5 N·m (5—15 cm·kg, 4.3—13 in·lb)

**Pull scale reading:**

4.9—14.7 N (0.5—1.5 kg, 1.7—3.3 lb)

## UPPER ARM


### Removal / Inspection / Installation

1. Jack up the front of the vehicle and support it with safety stands.
2. Remove the undercover.
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Inspect all parts and repair or replace as necessary.
5. Install in the reverse order of removal, referring to **Installation Note**.
6. Tighten all nuts and bolts to the specified torques, referring the figure.

### Note

- **Loosely tighten the upper arm and shock absorber bolts. Lower the vehicle and tighten all nuts and bolts to the specified torques with the vehicle unladen.**


7. Adjust the front wheel alignment. (Refer to page R-6.)




05U0RX-038

- |  |  |
|--|--|
| <ol style="list-style-type: none"> <li>1. Wheel and tire</li> <li>2. Upper arm ball joint<br/>Removal Note..... page R-18</li> <li>3. Shock absorber bolt</li> <li>4. Upper arm bushing (front and rear)<br/>Inspect for deterioration and damage</li> </ol> | <ol style="list-style-type: none"> <li>5. Ball joint dust boot<br/>Removal Note..... page R-18<br/>Installation Note..... page R-18</li> <li>6. Upper arm<br/>Inspect for damage and cracks</li> </ol> |
|--|--|







05U0RX-039



05U0RX-040



05U0RX-042



05U0RX-043

**Removal note****Upper arm ball joint**

Separate the upper arm ball joint from the knuckle with the **SST**.

**Ball joint dust boot**

Remove the dust boot with a chisel.

**Caution**

- Do not damage the ball joint stud.

**Installation note****Ball joint dust boot**

1. Press the dust boot on with a **30mm (1 1/8 in)** socket until the dust boot contacts the seat.

**Caution**

- Install the dust boot squarely and do not press excessively; the inner metal ring will be deformed if not done correctly.

2. Verify that the clearance between the boot and the seat is less than **1mm (0.04 in)**.
3. Shake the ball joint stud several times to make sure there is no grease leakage.

**Inspection****Upper arm ball joint****Ball joint rotation torque**

1. Shake the ball joint stud 5 times.
2. Connect the **SST** to the ball stud, and measure the rotation torque with a pull scale.

**Rotation torque:**

**0.4—1.2 N·m (4—12 cm·kg, 3.5—10.0 in·lb)**

**Pull scale reading:**

**3.9—11.8 N (0.4—1.2 kg, 2.9—8.8 lb)**


**STABILIZER**

**Removal / Inspection / Installation**

1. Jack up the front of the vehicle and support it with safety stands.
2. Remove the undercover.
3. Remove in the order shown in the figure.
4. Inspect all parts and repair or replace as necessary.
5. Install in the reverse order of removal, referring to **Installation Note**.
6. Tighten all nuts and bolts to the specified torques, referring to the figure.


**Note**

- Loosely tighten the stabilizer control link and bracket bolts. Lower the vehicle and tighten all nuts and bolts to the specified torques with the vehicle unladen.



05U0RX-044

- |   |   |
|---|---|
| <ol style="list-style-type: none"> <li>1. Stabilizer bracket</li> <li>2. Stabilizer bushing<br/>Inspect for deterioration and wear<br/>Installation Note ..... below</li> </ol> | <ol style="list-style-type: none"> <li>3. Stabilizer<br/>Inspect for bending and damage</li> <li>4. Stabilizer control link<br/>Inspect for bending and damage</li> </ol> |
|---|---|



05U0RX-045

**Installation note**

**Stabilizer bushing**

Align the bushing with the installation mark on the stabilizer.

# R FRONT SUSPENSION (DOUBLE-WISHBONE)

## CROSSMEMBER


### Removal / Inspection / Installation

1. Jack up the vehicle.
2. Remove the wheels and the undercover.
3. Support the engine with a hoist.
4. Remove in the order shown in the figure.
5. Inspect all parts and repair or replace as necessary.

### Note

- Use a container or rags to collect the power steering fluid when disconnecting the power steering pipes.
- Lower the crossmember and other suspension parts as an assembly, and then separate the parts.
- Loosely tighten the stabilizer bracket, upper arm, and lower arm bolts when assembling before installation. Lower the vehicle and tighten all nuts and bolts to the specified torques with the vehicle unladen.

6. Install in the reverse order of removal.
7. Adjust the front wheel alignment. (Refer to page R-6.)
8. Bleed the air from the brake system. (Refer to Section P.)







N-m (m-kg, ft-lb)

05UORX-046

- |  |   |
|--|---|
| 1. Brake pipe<br>Removal / Installation..... Section P           | 5. Front crossmember assembly<br>Inspect for damage |
| 2. Pinion shaft bolt<br>Removal / Installation ..... Section N   | 6. Stabilizer bracket                               |
| 3. Power steering pipe<br>Removal / Installation ..... Section N | 7. Upper arm bolt                                   |
| 4. Shock absorber bolt   | 8. Lower arm bolt                                   |
|  | 9. Steering gear bracket bolt                       |

REAR SUSPENSION (DOUBLE-WISHBONE)

PREPARATION  
SST

<p>49 G030 1A0 Compressor, coil spring</p> 	<p>For removal and installation of coil spring</p>	<p>49 G030 101 Body (Part of 49 G030 1A0)</p> 	<p>For removal and installation of coil spring</p>
<p>49 G030 102 Screw (Part of 49 G030 1A0)</p> 	<p>For removal and installation of coil spring</p>	<p>49 G030 103 Arm (Part of 49 G030 1A0)</p> 	<p>For removal and installation of coil spring</p>

05U0RX-047

### SHOCK ABSORBER AND SPRING


#### Removal / Installation

1. Jack up the front of the vehicle and support it with safety stands.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Inspect all parts and repair or replace as necessary.
4. Install in the reverse order of removal.
5. Tighten all nuts and bolts to the specified torques, referring to the figure.

#### Note

- **Loosely tighten the stabilizer control link bolt. Lower the vehicle and tighten all nuts and bolts to the specified torques with the vehicle unladen.**


6. Adjust the rear wheel alignment. (Refer to page R-9.)



05U0RX-048

1. Filler pipe protector (left side)
2. Wheel and tire
3. Stabilizer control link bolt

4. Shock absorber and spring  
Removal Note..... page R-22  
Disassembly / Inspection /  
Assembly..... page R-13



05U0RX-049

#### Removal note

##### Shock absorber and spring

1. Loosen the upper and lower arm bolts.
2. Lower the upper and lower arms to remove the shock absorber and spring.

#### Caution

- **Do not lower the arms excessively, which may damage the brake hose.**

## LOWER ARM


### Removal / Inspection / Installation

1. Jack up the rear of the vehicle and support it with safety stands.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Inspect all parts and repair or replace as necessary.
4. Install in the reverse order of removal.

### Note

- **Loosely tighten the lower arm, shock absorber, and stabilizer control link bolts. Lower the vehicle and tighten all nuts and bolts to the specified torques with the vehicle unladen.**

5. Adjust the rear wheel alignment. (Refer to page R-9.)



05U0RX-050

- |  |   |
|--|---|
| <ol style="list-style-type: none"> <li>1. Wheel and tire</li> <li>2. Stabilizer control link bolt</li> <li>3. Shock absorber bolt</li> <li>4. Lower arm<br/>Inspect for damage and cracks</li> </ol> | <ol style="list-style-type: none"> <li>5. Lower arm bushing<br/>(crossmember side and knuckle side)<br/>Inspect for deterioration and wear</li> </ol> |
|--|---|

# R

## REAR SUSPENSION (DOUBLE-WISHBONE)

### UPPER ARM


#### Removal / Inspection / Installation

1. Jack up the rear of the vehicle and support it with safety stands.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Inspect all parts and repair or replace as necessary.
4. Install in the reverse of removal.

#### Note

- **Loosely tighten the upper arm bolts. Lower the vehicle and tighten all nuts and bolts to the specified torques with the vehicle unladen.**

5. Adjust the rear wheel alignment. (Refer to page R-9.)



05U0RX-052

1. Upper arm  
Inspect for damage and cracks

2. Upper arm bushing  
Inspect for deterioration and wear


## STABILIZER

### Removal / Inspection / Installation

1. Jack up the rear of the vehicle and support it with safety stands.
2. Remove in the order shown in the figure.
3. Inspect all parts and repair or replace as necessary.
4. Install in the reverse order of removal, referring to **Installation Note**.


### Note

- **Loosely tighten the stabilizer bracket and control link bolts. Lower the vehicle and tighten all nuts and bolts to the specified torques with the vehicle unladen.**



05UORX-054

- |   |  |
|---|--|
| <ol style="list-style-type: none"> <li>1. Stabilizer bracket</li> <li>2. Stabilizer bushing<br/>Inspect for deterioration and wear<br/>Installation Note ..... below</li> </ol> | <ol style="list-style-type: none"> <li>3. Stabilizer<br/>Inspect for bending and damage</li> <li>4. Control link<br/>Inspect for bending and damage</li> </ol> |
|---|--|



05UORX-055

### Installation note

#### Stabilizer bushing

Align the bushing with the installation mark on the stabilizer.



### CROSSMEMBER


#### Removal / Inspection / Installation

1. Jack up the vehicle and support it with safety stands.
2. Remove the wheels and tires.
3. Remove the differential and the power plant frame. (Refer to Section M.)
4. Remove in the order shown in the figure.

#### Note

- Lower the crossmember and other suspension parts as an assembly, and then separate the parts.
- Loosely tighten the stabilizer bracket, upper arm, and lower arm bolts when assembling before installation. Lower the vehicle and tighten all nuts and bolts to the specified torques with the vehicle unladen.

5. Inspect parts and repair or replace as necessary.
6. Install in the reverse order of removal.
7. Adjust the rear wheel alignment. (Refer to page R-9.)
8. Bleed the air from the brake system. (Refer to Section P.)



N-m (m-kg, ft-lb)


05U0RX-056

- |  |  |
|--|--|
| <ol style="list-style-type: none"> <li>1. Parking brake cable<br/>Removal / Installation..... Section P</li> <li>2. Brake pipe<br/>Removal / Installation..... Section P</li> <li>3. Brake pipe joint</li> <li>4. Battery cable bracket</li> </ol> | <ol style="list-style-type: none"> <li>5. Shock absorber bolt</li> <li>6. Rear crossmember assembly<br/>Inspect for damage</li> <li>7. Stabilizer bracket</li> <li>8. Upper arm bolt</li> <li>9. Lower arm bolt</li> </ol> |
|--|--|

## BODY


<b>INDEX</b> .....	S- 2	<b>WINDSHIELD</b> .....	S-38
<b>HOOD</b> .....	S- 5	<b>PREPARATION</b> .....	S-38
<b>COMPONENTS</b> .....	S- 5	<b>COMPONENTS</b> .....	S-38
<b>DOOR</b> .....	S- 7	<b>REAR WINDOW GLASS</b> .....	S-42
<b>COMPONENTS</b> .....	S- 7	<b>PREPARATION</b> .....	S-42
<b>WINDOW REGULATOR, GLASS, AND GUIDE</b> .....	S- 9	<b>COMPONENTS</b> .....	S-42
<b>COMPONENTS</b> .....	S- 9	<b>REAR WINDOW</b> .....	S-46
<b>DOOR LOCK AND OPENER</b> .....	S-15	<b>COMPONENTS</b> .....	S-46
<b>COMPONENTS</b> .....	S-15	<b>DASHBOARD AND CONSOLE</b> .....	S-50
<b>TRUNK LID</b> .....	S-16	<b>COMPONENTS</b> .....	S-50
<b>COMPONENTS</b> .....	S-16	<b>TRIM</b> .....	S-53
<b>TRUNK LID LOCK AND OPENER</b> .....	S-18	<b>COMPONENTS</b> .....	S-53
<b>COMPONENTS</b> .....	S-18	<b>FLOORMAT</b> .....	S-56
<b>POWER WINDOW SYSTEM</b> .....	S-19	<b>COMPONENTS</b> .....	S-56
<b>STRUCTURAL VIEW</b> .....	S-19	<b>SEAT BELT</b> .....	S-57
<b>TROUBLESHOOTING GUIDE</b> .....	S-20	<b>COMPONENTS</b> .....	S-57
<b>POWER WINDOW MAIN SWITCH</b> ....	S-22	<b>EMERGENCY LOCKING RETRACTOR</b> .....	S-58
<b>POWER WINDOW MOTOR</b> .....	S-22	<b>WEBBING</b> .....	S-58
<b>FUEL FILLER LID OPENER</b> .....	S-23	<b>BUCKLE SWITCH</b> .....	S-58
<b>COMPONENTS</b> .....	S-23	<b>SEAT</b> .....	S-59
<b>FRONT BUMPER</b> .....	S-24	<b>COMPONENTS</b> .....	S-59
<b>COMPONENTS</b> .....	S-24	<b>CONVERTIBLE TOP</b> .....	S-61
<b>REAR BUMPER</b> .....	S-25	<b>COMPONENTS</b> .....	S-61
<b>COMPONENTS</b> .....	S-25	<b>REPAIR OF TOP FABRIC</b> .....	S-68
<b>MOLDING AND GARNISH</b> .....	S-27	<b>DETACHABLE HARD TOP</b> .....	S-70
<b>COMPONENTS</b> .....	S-27	<b>COMPONENTS</b> .....	S-70
<b>DOOR MIRROR</b> .....	S-30	<b>UNDERBODY DIMENSIONS</b> .....	S-73
<b>COMPONENTS</b> .....	S-30	<b>UNDERBODY STRAIGHT-LINE</b> <b>DIMENSIONS</b> .....	S-73
<b>HORN</b> .....	S-30	<b>UNDERBODY PROJECTED</b> <b>DIMENSIONS</b> .....	S-74
<b>WINDSHIELD WIPER AND WASHER</b> .	S-31		
<b>TROUBLESHOOTING GUIDE</b> .....	S-31		
<b>WIPER MOTOR</b> .....	S-34		
<b>WASHER MOTOR</b> .....	S-34		
<b>FRONT WIPER AND WASHER</b> <b>SWITCH</b> .....	S-34		
<b>COMPONENTS</b> .....	S-35		

INDEX




05U0SX-002

1. Hood Removal / Installation ..... page S- 5	7. Door mirror Removal / Installation ..... page S-30
2. Door Removal / Installation ..... page S- 7	8. Horn Removal / Installation ..... page S-30
3. Window regulator, glass, and guide Removal / Installation ..... page S- 9	9. Windshield wiper and washer Troubleshooting guide..... page S-31 Inspection ..... page S-34 Removal / Installation ..... page S-35 Disassembly / Assembly ..... page S-37
4. Door lock and opener Removal / Installation ..... page S-15	10. Windshield Removal / Installation ..... page S-38
5. Front bumper Removal / Installation ..... page S-24	
6. Molding and garnish Removal / Installation ..... page S-27	



05U0SX-003

- |   |  |
|---|--|
| <p>1. Trunk lid<br/>Removal / Installation ..... page S-16</p> <p>2. Trunk lid lock and opener<br/>Removal / Installation ..... page S-18</p> <p>3. Fuel filler lid<br/>Removal / Installation ..... page S-23</p> <p>4. Rear bumper<br/>Removal / Installation ..... page S-25<br/>Disassembly / Assembly ..... page S-26</p> <p>5. Molding and garnish<br/>Removal / Installation ..... page S-27</p> | <p>6. Rear window glass (Detachable hard top)<br/>Removal / Installation ..... page S-42</p> <p>7. Rear window (Convertible top)<br/>Removal / Installation ..... page S-46</p> <p>8. Convertible top<br/>Removal / Installation ..... page S-61<br/>Disassembly / Assembly ..... page S-62</p> <p>9. Detachable hard top<br/>Disassembly / Assembly ..... page S-70</p> |
|---|--|



05U0SX-004


1. Power window system		5. Floor mat	
Structural view .....	page S-19	Removal / Installation .....	page S-56
Troubleshooting guide .....	page S-20	6. Seat belt	
Inspection .....	page S-22	Removal / Installation .....	page S-57
2. Fuel filler lid opener		Inspection .....	page S-58
Removal / Installation .....	page S-23	7. Seat	
3. Dashboard and console		Removal / Installation .....	page S-59
Removal / Installation .....	page S-50	Disassembly / Assembly .....	page S-60
4. Trim			
Removal / Installation .....	page S-53		

HOOD

COMPONENTS

Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.




N-m (m-kg, ft-lb)

05U0SX-005


1. Headlight seal
2. Side headlight seal
3. Washer pipe

4. Hood  
Adjustment ..... page S- 6
5. Hinge
6. Hood stay

7. Hood lock  
Adjustment ..... page S- 6
8. Release wire



05U0SX-159



05U0SX-006

**Adjustment****Hood**

Adjust the hood laterally and vertically by loosening the hood-to-hinge mounting bolts and repositioning the hood.

**Hood lock**

Adjust the hood lock after the hood has been aligned. Loosen the hood lock mounting bolts and nut, and align the lock with the striker on the hood.

**DOOR**

**COMPONENTS**

**Caution**


- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to Section T.)

**Removal / Installation**

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.

**Note**

- Remove the trim and door screen for removal of the door checker. (Refer to page S-9.)
- Adjust the door lock striker. (Refer to page S-8.)




N-m (m-kg, ft-lb)

05U0SX-007

- 1. Harness connector
- 2. Checker pin
- 3. Hinge

- 4. Door Adjustment..... page S-8
- 5. Checker






05U0SX-008

**Adjustment****Door lock striker**

1. Verify that the door can be closed easily and whether there is any looseness. If there is a problem, loosen the striker mounting screws and adjust by moving the striker vertically.
2. Verify the rear offset of the door to the body. If there is a problem, adjust by moving the door lock striker vertically.

**Tightening torque:**

**18—26 N·m (1.8—2.7 m·kg, 13—20 ft·lb)**



05U0SX-009

**Door**

Loosen the hinge bolts and adjust as shown in the figure. Tighten the bolts to the specified torque.

**Tightening torque:**

**22—30 N·m (2.2—3.1 m·kg, 16—22 ft·lb)**

WINDOW REGULATOR, GLASS, AND GUIDE

COMPONENTS

Caution

- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to Section T.)

Removal / Installation


1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.

Caution

- Remove the door screen carefully so that it may be reused.

Note


- Raise the door glass about 190mm (7.5 in) from fully-open position.



N-m (m-kg, ft-lb)

05U0SX-010


- |   |   |                             |
|---|---|-----------------------------|
| 1. Regulator handle<br>Removal Note .. page S-10<br>Installation Note page S-10 | 6. Inner handle   | 13. Glass guide             |
| 2. Inner handle cover   | 7. Sealing pad  | 14. Door weatherstrip       |
| 3. Arm rest   | 8. Door screen  | 15. Division channel        |
| 4. Speaker grille<br>Removal Note .. page S-55                                  | 9. Upper stop   | 16. Weatherstrip            |
| 5. Door trim<br>Removal Note .. page S-55                                       | 10. Front beltline molding<br>Removal Note .. page S-28 | 17. Quarter glass           |
|   | 11. Door glass<br>Adjustment ..... page S-10            | 18. Speaker (If necessary)  |
|   | 12. Window regulator                                    | 19. Dovetail (If necessary) |



05U0SX-011

### Removal Note Regulator handle

Remove the regulator handle clip with a rag, as shown.



05U0SX-012

### Installation Note Regulator handle


Install the regulator handle as shown.

### Note

- With door glass at fully-closed position.

### Adjustment Door glass

Adjustment of the door glass (convertible top and detachable hard top) is made as follows:



05U0SX-013

## 1. Vertical adjustment of door glass

Adjustment procedure






Remove the weatherstrip, and check alignment with the door glass in the fully-closed position.

(1) Loosen upper stop installation bolts (A).

(2) Adjust by moving the upper stop up or down so that the upper edge of the door glass is in the correct position, and then tighten bolts (A).

### Note

- When the door glass is raised, both glass stop must contact the upper stop simultaneously.
- Before an upper stop is moved for adjustment, lower the door glass slightly.



a	
(A)	$9.4 \pm 2.0$ ( $0.37 \pm 0.08$ )
(B)	$9.1 \pm 2.0$ ( $0.36 \pm 0.08$ )

mm (in)

2. Inboard/Outboard adjustment of door glass


Adjustment procedure

Remove the weatherstrip, and check alignment with the door glass in the fully-closed position.

- (1) Loosen window regulator installation nuts (B) and glass guide installation nut (C).
- (2) Adjust by moving the window regulator and the glass guide inward or outward so that the upper and side edges of the door glass are in the correct position, and then tighten nuts (B) and (C).

Note

- The window regulator and the glass guide should be tightened in approximately the same position in the slotted adjustment holes.
- The door glass must raise and lower smoothly with the door closed.



**3. Fore and aft adjustment of side edge of door glass**


Adjustment procedure

Remove the weatherstrip, and check alignment with the door glass in the fully-closed position.


- (1) Loosen window regulator installation nuts (D) and glass guide installation nut (E).
- (2) Adjust by moving the window regulator and the glass guide fore or aft equally so that the side edge of the door glass is in the correct position, and then tighten the nuts (D) and (E).

**Note**



- The window regulator and glass guide should be tightened in approximately the same position in the slotted adjustment holes.
- The door glass must raise and lower smoothly with the door closed.




**DETACHABLE HARD TOP**



**CONVERTIBLE TOP**



SEC. E-E



SEC. F-F



	d
Ⓒ	12.5 ± 2.0 (0.49 ± 0.08)
Ⓓ	12.0 ± 2.0 (0.47 ± 0.08)

mm (in)



**After completion of adjustment, verify the points below**

1. Verify the following with the weatherstrip removed.
  - (1) When the door glass is raised, the glass stop contact the upper stop simultaneously.
  - (2) The door glass is in the correct position when fully closed.
2. Verify the following with the weatherstrip installed.
  - (1) The door glass raises and lowers smoothly with the door closed.
  - (2) Alignment of the weatherstrip is correct (Convertible top only).

**CONVERTIBLE TOP**



**DETACHABLE HARD TOP**



	a	b
Ⓐ	9.4 ± 2.0 (0.37 ± 0.08)	9.3 ± 2.0 (0.37 ± 0.08)
Ⓑ	9.1 ± 2.0 (0.36 ± 0.08)	7.4 ± 2.0 (0.29 ± 0.08)

	c	d
Ⓒ	5.8 ± 2.0 (0.23 ± 0.08)	12.5 ± 2.0 (0.49 ± 0.08)
Ⓓ	11.1 ± 2.0 (0.44 ± 0.08)	12.0 ± 2.0 (0.47 ± 0.08)

mm (in)

## DOOR LOCK AND OPENER

## COMPONENTS

**Caution**

- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to Section T.)

**Removal / Installation**


1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.

**Caution**

- Remove the door screen carefully so that it may be reused.

**Note**

- Raise the door glass fully to remove the door lock assembly.



N-m (m-kg, ft-lb)

05U0SX-018

- |   |  |                       |
|---|--|-----------------------|
| 1. Regulator handle<br>Removal Note .. page S-10<br>Installation Note page S-10 | 4. Speaker grille<br>Removal Note .. page S-55 | 7. Sealing pad        |
| 2. Inner handle cover   | 5. Door trim<br>Removal Note .. page S-55      | 8. Door screen        |
| 3. Armrest  | 6. Inner handle                                | 9. Door lock assembly |
|   |  | 10. Outer handle      |
|   |  | 11. Key cylinder      |




### TRUNK LID

#### COMPONENTS

#### Removal / Installation


1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



N-m (m-kg, ft-lb)

05U0SX-019

- |                            |                            |              |
|----------------------------|----------------------------|--------------|
| 1. Wire harness            | 4. Balance spring          | 6. Set plate |
| 2. Trunk lid               | Removal Note .. page S-17  | 7. Hinge     |
| Adjustment ..... page S-17 | Adjustment ..... page S-17 |              |
| 3. Rod holder              | 5. Rear package trim       |              |




05U0SX-020

### Removal Note Balance spring

1. Lift the balance spring with a protected screwdriver.
2. Remove the balance spring.

### Warning


- Use care when removing the balance spring; personal injury could result.



05U0SX-021

### Adjustment Trunk lid

Loosen the trunk lid mounting nuts and adjust as shown.



05U0SX-022

### Balance spring

Slide the balance spring to the desired position as described below with a protected screwdriver.

Tension	Hinge	Set position	
		a	b
Standard	Left side		○
	Right side	○	
Increase	Left side	○	
	Right side	○	
Decrease	Left side		○
	Right side		○

○: Indicated position

### Warning


- Use care when moving the balance spring; personal injury could result.

TRUNK LID LOCK AND OPENER

COMPONENTS


Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



05U0SX-023

- |                            |                             |
|----------------------------|-----------------------------|
| 1. Trunk end trim          | 4. Rear finisher            |
| 2. Trunk lid lock assembly | Removal Note..... page S-28 |
| Adjustment..... below      | 5. Key cylinder             |
| 3. Rear combination light  | 6. Striker                  |
| Removal..... Section T     |                             |



**Adjustment**


**Trunk lid lock assembly**

Verify that the trunk lid can be closed easily and whether there is any looseness. If necessary, loosen the lock assembly mounting bolts and adjust the lock assembly.

05U0SX-024

POWER WINDOW SYSTEM

STRUCTURAL VIEW




05U0SX-025

- 1. Rear console  
Removal / Installation ..... page S-50
- 2. Power window main switch  
Removal / Installation ..... page S-50  
Inspection ..... page S-22

- 3. Power window regulator  
Removal / Installation ..... page S- 9

### TROUBLESHOOTING GUIDE


#### CIRCUIT DIAGRAM



DR1-01 POWER WINDOW MOTOR (L.H) (DR1)




I-15 POWER WINDOW MAIN SWITCH (I)




DR2-01 POWER WINDOW MOTOR (R.H) (DR2)




FI-01 FRONT (F) - INSTRUMENT PANEL (I)



[ ] ... FOR CANADA




FI-03 FRONT (F) - INSTRUMENT PANEL (I)




FDR2-01 FRONT (F) - DOOR NO. 2 (DR2)




FDR1-01 FRONT (F) - DOOR NO. 1 (DR1)






05U0SX-027



05U0SX-028

(( )): Passenger side



05U0SX-029

**POWER WINDOW MAIN SWITCH**


**Inspection**

1. Check for continuity between terminals of the switch with an ohmmeter.

Switch	Terminal	Driver side				Passenger side			
Position		a	b	c	d	a	b	e	f
UP		○—○		○—○		○—○		○—○	
OFF			○—○	○—○	○—○		○—○	○—○	○—○
DOWN		○—○			○—○	○—○			○—○

○—○: Indicates continuity

2. If not as specified, replace the switch.



05U0SX-030

**POWER WINDOW MOTOR**

**Inspection**

1. Connect 12V to terminal a and ground terminal b of the motor connector. Verify that the motor operates.
2. Reverse the above connections and check for reverse operation of the motor.
3. If not as specified, replace the motor.

FUEL FILLER LID OPENER


COMPONENTS

Removal / Installation

Note

- Remove the rear console for removal of the opener lever.
- Remove the rear end mat, rear package trim and bulkhead panel for removal of the cable.

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



05U05X-031

- |                              |           |                      |
|------------------------------|-----------|----------------------|
| 1. Rear console              |           | 4. Clip              |
| Removal / Installation ..... | page S-50 | 5. Filler lid opener |
| 2. Opener lever              |           | 6. Filler lid        |
| 3. Opener cable              |           |                      |



### FRONT BUMPER

#### COMPONENTS

##### Caution


- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to Section T.)

#### Removal / Installation

##### Note

- Raise the headlights.

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.



N-m (m-kg, ft-lb)

05U0SX-032

- |   |                 |                           |
|---|-----------------|---------------------------|
| 1. Front combination light<br>Removal ..... Section T | 4. Mud guard    | 9. Bumper reinforcement   |
| 2. Front side marker light<br>Removal ..... Section T | 5. Grille cover | 10. Spacer                |
| 3. Fender bracket                                     | 6. Set plate    | 11. Front bumper retainer |
|   | 7. Front fascia | 12. Front bumper bracket  |
|   | 8. Retainer     |                           |

REAR BUMPER


COMPONENTS

Caution

- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to Section T.)

Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.



N·m (m·kg, ft·lb)

05U05X-033

1. Rear side marker light


Removal..... Section T

2. Splash shield

3. Rear bumper

**Disassembly / Assembly**

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.



N·m (m·kg, ft·lb)

05UOSX-034

1. Rear fascia
2. Retainer
3. Bumper reinforcement


4. Bumper stay
5. Set plate

**MOLDING AND GARNISH**

**COMPONENTS**


**Removal / Installation**

1. Remove the parts as shown.
2. Install in the reverse order of removal.



05U0SX-035

1. Windshield molding Installation Note .....	page S-28	4. Beltline molding Removal Note .....	page S-28
2. Cowl grille Removal .....	page S-35	5. Rear window molding (Detachable hard top) Installation Note .....	page S-29
3. Front beltline molding Removal Note .....	page S-28	6. Rear finisher Removal Note .....	page S-28



05U0SX-036

**Removal Note****Front beltline molding**


1. Remove the door mirror. (Refer to page S-30.)
2. Remove the front beltline molding.

**Caution**

- Do not damage the body.

**Note**

- The clips are where shown in the figure.



05U0SX-037

**Rear finisher**


1. Remove the rear combination light. (Refer to Section T.)
2. Remove the rear finisher.

**Note**

- The clips are where shown in the figure.

**Beltline molding**

Remove the convertible top for removal of the beltline molding. (Refer to page S-61.)



05U0SX-038

**Installation Note****Windshield molding**


1. Remove the windshield. (Refer to page S-38.)
2. Install the windshield. (Refer to page S-38.)
3. Apply primer with a brush to the bonding area of the new upper molding, and allow it to dry for **approx. 30 minutes**.

**Caution**

- Keep the area free of dirt and grease. Do not touch the surface. If primer gets on the skin, remove it immediately.

**Caution**

- Lower the convertible top to prevent the glass from being pushed out by air pressure if a door is closed.




05U0SX-039


4. Align the center mark in the molding with the glass mark (①).
5. Install the upper portions of the molding into the body (②).
6. Push the corner of the molding into the body (③).
7. Push the side portions of the molding into the body, beginning from the bottom (④).
8. Check for water leaks. If a leak is found, wipe the water off well and repeat the installation.

**Hardening time of repair seal**


Temperature	Surface hardening time	Time required until car can be put into service
5°C (41°F)	Approx. 1.5 hr	12 hr
20°C (68°F)	Approx. 1hr	4 hr
35°C (95°F)	Approx. 10 min	2 hr



05U0SX-040



05U0SX-041



05U0SX-042

**Rear window molding (Detachable hard top)**

1. Remove the rear window glass. (Refer to page S-42.)
2. Install the rear window glass. (Refer to page S-42.)
3. Apply primer with a brush to the bonding area of the new rear window molding, and allow it to dry for **approx. 30 minutes**.

**Caution**

- **Keep the area free of dirt and grease. Do not touch the surface. If primer gets on the hand, remove it immediately.**

4. Install the rear window molding to the glass, as shown.

5. If the molding is too long, cut the excess molding **10mm (0.39 in)** inside the joint molding edge.

**Hardening time of repair seal**

Temperature	Surface hardening time	Time required until car can be put into service
5°C (41°F)	Approx. 1.5 hr	12 hr
20°C (68°F)	Approx. 1hr	4 hr
35°C (95°F)	Approx. 10 min	2 hr

6. Check for water leaks. If a leak is found, wipe the water off well and repeat the installation.


05U0SX-043

### DOOR MIRROR

#### COMPONENTS

##### Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



1. Mirror cover

2. Rearview mirror


05U0SX-044

### HORN

#### COMPONENTS

##### Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



1. Horn

2. Horn relay





Inspection ..... Section T

05U0SX-045


WINDSHIELD WIPER AND WASHER

TROUBLESHOOTING GUIDE


CIRCUIT DIAGRAM













05U0SX-047




05U0SX-048







05U0SX-054



05U0SX-055



05U0SX-056



05U0SX-057

**WIPER MOTOR**

**Inspection**

Check for continuity between the terminals with the wiper is in parked position.

Terminals	Continuity	Terminals	Continuity
a—b	No (Yes)	b—c	No (Yes)
a—c	Yes (Yes)	b—d	No (Yes)
a—d	Yes (Yes)	c—d	Yes (Yes)

( ): CANADA

Check operation by applying 12V and a ground to the terminals of the motor connector.

Terminal	Operation speed
12V	
a (c)	Low
c (a)	High

( ): CANADA

**WASHER MOTOR**

**Inspection**

Connect 12V to terminal B and a ground to terminal A, and verify that the motor operates.

**FRONT WIPER AND WASHER SWITCH**

**Inspection**

Refer to Section T.


## COMPONENTS

### Caution

- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to Section T.)

### Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.




N-m (m-kg, ft-lb)

05UOSX-058

1. Wiper arm and blade  
Adjustment ..... page S-36
2. Cowl grille
3. Baffle cover

4. Wiper motor  
Inspection ..... page S-34
5. Wiper link
6. Washer tank

7. Washer motor  
Inspection ..... page S-34
8. Washer nozzle  
Adjustment ..... page S-36
9. Washer pipe




05U0SX-059

**Adjustment**

**Arm height**

Set the arm height as shown.




05U0SX-060

**Washer nozzle**

Insert a needle or similar object into the nozzle hole and move the nozzle to adjust the spray direction.

**Disassembly / Assembly**

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.




1. Brush plate holder

2. Motor gear shaft

05U0SX-061

## WINDSHIELD

PREPARATION  
SST


## COMPONENTS

## Removal / Installation

## Note


- Use the SST (49 0305 870A) to remove and install the windshield.

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.




05U0SX-063


- |  |   |  |
|--|---|--|
| 1. Wiper arm and blade<br>Adjustment ..... page S-36 | 6. Sunvisor<br>Removal Note .. page S-54          | 10. Windshield<br>Removal Note .. page S-39<br>Installation Note page S-39 |
| 2. Cowl grille                                       | 7. Front header trim<br>Removal Note .. page S-54 | 11. Dam  |
| 3. Windshield molding<br>Installation Note page S-28 | 8. Weatherstrip                                   | 12. Upper protector  |
| 4. Rearview mirror and cover                         | 9. A-pillar trim<br>Removal Note .. page S-54     | 13. Spacer   |
| 5. Striker   |   |  |




9MU0SX-097




05U0SX-064



9MU0SX-099



05U0SX-065



05U0SX-160

### Removal Note Windshield

1. Apply protective tape along the edge of the body to protect it from damage.
2. Using an awl, make a hole through the sealant from the inside of the vehicle.
3. Pass piano wire through the hole.
4. Wind each end of the wire around a bar.
5. Working with another person, saw through the sealant around the edge of the glass. Then remove the glass.

### Caution

- Use a long sawing action to spread the work over the whole length of wire to prevent it from breaking.
- Be careful that the wire does not rub on the body or dashboard.

### Note

- If the glass is not to be reused, a tool like that shown in the figure may be used.

Insert the blade in the sealant, and pull on the bars.


### Installation Note Windshield

1. Cut away the old sealant with a razor knife so that **1 to 2mm (0.04 to 0.08 in)** thickness of sealant remains around the circumference of the frame. If all the sealant has come off in any one place, apply some primer after degreasing, and allow it **30 minutes** to dry. Then put on new sealant to create a **2mm (0.08 in)** layer.
2. Carefully clean an area **5 cm (1.97 in)** wide around the circumference of the glass and the bond on the body.
3. Apply primer with a brush to the bonding area of the glass and the body, and allow it to dry for **approx. 30 minutes**.

### Caution

- Keep the area free of dirt and grease. Do not touch the surface. If primer gets on the skin, remove it immediately.






05U0SX-066

- Bond a new dam along the circumference of the glass **7mm (0.28 in)** from the edge.

**Caution**

- **Bond the dam securely and allow it to dry.**




9MU0SX-103

- Install the spacers onto the body as shown.


**Caution**

- **Damaged spacers must be replaced.**



05U0SX-067

- Prepare the nozzle of the sealant tube so that it has a flange that can run along the edge of the glass and a V from which the sealant can flow. Once the primer is dry, apply **repair seal** (B001 77 739) around the entire circumference to fill the gap between the dam and the edge of the glass with a ridge of sealant **11mm (0.43 in)** high. Keep the bead of sealant smooth and even, reshaping it where necessary with a spatula.




05U0SX-068

- If the protector is damaged, bond a new protector onto the body, as shown.

**Caution**

- **Bond the protector securely and allow it to dry.**



05U0SX-069


- Install the glass, aligning the glass mark with the V notch in the spacer. Push it in lightly toward the vehicle to compress the sealant.

**Caution**

- **Lower the convertible top to prevent the glass from being pushed out by air pressure if a door is closed.**

**Hardening time of repair seal**

Temperature	Surface hardening time	Time required until car can be put into service
5°C (41°F)	Approx. 1.5 hr	12 hr
20°C (68°F)	Approx. 1 hr	4 hr
35°C (95°F)	Approx. 10 min	2 hr




9. Use a scraper to smooth away any sealant that oozes out. Add more sealant to any points of poor contact.
10. Install a new windshield molding. (Refer to page S-28.)

11. Check for water leaks.
12. If a leak is found, wipe the water off well and remove the molding and windshield. Reinstall the windshield and replace the molding with new molding. (Refer to page S-28.)

05U0SX-071

### REAR WINDOW GLASS (DETACHABLE HARD TOP)

#### PREPARATION SST




#### COMPONENTS

##### Removal / Installation

##### Note

- Use the SST (49 0305 870A) to remove and install the rear window glass.


1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.




1. Rear window molding  
Installation Note ..... page S-29
2. Rear window glass  
Removal Note ..... page S-43  
Installation Note ..... page S-43

3. Dam
4. Upper protector
5. Lower protector
6. Side protector


05U0SX-073




05U0SX-074




05U0SX-075



05U0SX-076



05U0SX-077



05U0SX-078

## Removal Note

### Rear window glass

1. Apply protective tape along the edge of the top to protect it from damage.
2. Remove the glass mounting nuts.
3. Using an awl, make a hole through the sealant from the inside of the vehicle.
4. Pass piano wire through the hole.
5. Wind each end of the wire around a bar.
6. Saw through the sealant around the edge of the glass. Then remove the glass.

## Caution

- Use a long sawing action to spread the work over the whole length of wire to prevent it from breaking.
- Be careful that the wire does not rub on the top.
- Use a razor knife to cut where the piano wire will not cut.

## Installation Note


### Rear window glass

1. Cut away the old sealant with a razor knife so that **1 to 2mm (0.04 to 0.08 in)** thickness of sealant remains around the circumference of the frame. If all the sealant has come off in any one place, apply some primer after degreasing, and allow it **30 minutes** to dry. Then put on new sealant to create a **2mm (0.08 in)** layer.
2. Carefully clean an area **5 cm (1.97 in)** wide around the circumference of the glass and the bond on the top.
3. Apply primer with a brush to the bonding area of the glass and the top, and allow it to dry for **approx. 30 minutes**.

## Caution

- Keep the area free of dirt and grease. Do not touch the surface. If primer gets on the skin, remove it immediately.

## REAR WINDOW GLASS




mm (in)

05U0SX-079

4. Bond a new dam along the circumference of the glass **8mm (0.31 in)** from the edge.

**Caution**

- **Bond the dam securely and allow it to dry.**



mm (in)


05U0SX-080

5. Prepare the nozzle of the sealant tube so that it has a flange that can run along the edge of the glass and a V from which the sealant can flow. Once the primer is dry, apply the sealant around the entire circumference to fill the gap between the dam and the edge of the glass with a ridge of sealant **11mm (0.43 in)** high. Keep the bead of sealant smooth and even, reshaping it where necessary with a spatula.

6. If protector is damaged bond a new protector onto the detachable hard top, as shown.

**Caution**

- **Bond the protector securely and allow it to dry.**




05U0SX-081

7. Align the studs of the glass with the detachable hard top and mount the glass.  
8. Push the glass lightly toward the front to compress the sealant.  
9. Tighten the glass mounting nuts.

**Tightening torque:**

**2.4—3.3 N·m (24—34 cm·kg, 20.8—29.5 in·lb)**




05U0SX-082

10. Use a scraper to smooth away any sealant that oozes out. Add more sealant to any points of poor contact.  
11. Install the new rear window molding. (Refer to page S-29.)

**Hardening time of repair seal**

Temperature	Surface hardening time	Time required until car can be put into service
5°C (41°F)	Approx. 1.5 hr	12 hr
20°C (68°F)	Approx. 1 hr	4 hr
35°C (95°F)	Approx. 10 min	2 hr



05U0SX-083

12. Check for water leaks.
13. If a leak is found, wiper the water off well and remove the molding and rear window glass. Reinstall the glass and replace the molding with new molding.  
(Refer to page S-29.)


05U0SX-084

### REAR WINDOW (CONVERTIBLE TOP)

#### COMPONENTS

#### Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.




05U0SX-085

1. Rear package trim
2. Set plate
3. Beltline cover
4. Beltline protector
5. Rain rail


6. Zipper stop
7. Rear window

Removal Note..... page S-47  
Installation Note..... page S-48


## REAR WINDOW




05U0SX-086




05U0SX-087



05U0SX-088



05U0SX-089



05U0SX-090

**Removal Note****Rear window**

1. Remove the rear package trim.
2. Remove the set plates.

**Note**

- Unzip the rear window, and lower the convertible top fully.

3. Remove the beltline covers.
4. Remove the beltline protectors.
5. Remove the rain rail mounting fasteners from the body.

**Note**

- Raise the convertible top completely.
- Leave the top latch assemblies in the unlocked position.

6. Remove the rain rail from the studs.
7. Remove the rivets from the link assembly with a drill.

**Drill size:  $\phi 4.0\text{mm}$  ( $\phi 0.16$  in)**

**Note**

- Remove any accumulated dirt, etc.


**Caution**

- Cover the body to prevent it from damage.

8. Remove the rain rail from the body.



**REAR WINDOW**




05U0SX-091

- Remove the rivets from the rain rail with a cutter, and remove the rain rail from the convertible top.

**Note**

- Do not damage the rain rail.




05U0SX-092

- Remove the rivets from the rear window with a cutter.

**Note**

- Do not damage the rear window.




05U0SX-093

- Peel apart the Velcro.
- Carefully remove the zipper stops from the rear window and top fabric, and remove the rear window.

**Note**

- Save the zipper stops for reuse.



05U0SX-094

**Installation Note**

**Rear window**


- Degrease the rain rail with ethyl alcohol.
- Install insulation tape to the rivet mounting holes of the rain rail.

**Insulation tape**

**Width : 20mm (0.79 in)**

**Height : 15mm (0.59 in)**

**Thick : 3mm (0.12 in)**




05U0SX-095

- Align the ends of the zipper, and install the zipper pull tab.

**Note**


- Do not damage the rear window.

- Zip the rear window into place.



05U0SX-096

5. Install the zipper stops to the rear window and the top fabric.
6. Affix the rear window to the top fabric with the Velcro.




05U0SX-097

7. Mount the outer rain rail to the studs.
8. Mount the top fabric to the studs.
9. Mount the rear window to the studs.
10. Mount the inner rain rail to the studs.
11. Loosely install the set plates.

**Note**

- Install the set plate beginning at the left side.




05U0SX-098

**Note**

- Unzip the rear window, and lower the convertible top fully.

12. Install the rain rail with the fasteners.
13. Install the beltline protectors.
14. Install the beltline cover.



05U0SX-099

**Note**

- Raise the convertible top completely, and lock the top latch assemblies.
- Zip the rear window into place.

15. Tighten the set plate mounting nuts.

**Tightening torque:**

**8.8—12 N·m (0.9—1.2 m·kg, 6.5—8.7 ft·lb)**

16. Rivet the top fabric to the link assembly.
17. Install the rear package trim.

18. If there is any sagging of the top fabric, remove the pull tab and realign the zipper.

## DASHBOARD AND CONSOLE

## COMPONENTS

## Caution


- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to Section T.)

## Removal / Installation

## Note

- Do not remove the steering wheel if not necessary (U.S. spec.). If it is removed, refer to Section T.
- Remove the control wires of the heater unit and blower unit for removal of the dashboard.
- If necessary, remove Nos. 10 and 11 shown in the figure.


1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.



N-m (m-kg, ft-lb)


05U0SX-101

- |                                 |   |                           |
|---------------------------------|---|---------------------------|
| 1. Ashtray                      | 3. Steering wheel and horn cap (Canada) | 9. Instrument cluster     |
| 2. Rear console assembly        | 4. Column cover (Canada)                | 10. Center panel assembly |
| a. Back plate                   | 5. Center lower panel assembly          | Removal Note .. page S-51 |
| b. Shift lever boot             | 6. Steering shaft                       | 11. Glove box assembly    |
| c. Power window switch          | 7. Meter hood assembly                  | 12. Hood release knob     |
| d. Cover (Without power window) | Removal Note .. page S-51               | 13. Center hole cover     |
| e. Console lock assembly        | 8. Speedometer cable                    | 14. Side cover            |
|                                 |   | 15. Dashboard             |




05U0SX-102

**Removal Note**  
**Center lower panel assembly**  
 The clips are where shown.




05U0SX-103

**Meter hood assembly**  
 The clips are where shown.



05U0SX-104

**Center panel assembly**  
 The clips are where shown.




05U0SX-105

**Adjustment Note**  
**Airflow mode wire**

1. Set the airflow mode control lever to VENT position.
2. Connect and clamp the wire with the shutter lever on the heater unit at its closest point.

**Caution**

- After installation, move the airflow mode control lever to be sure the wire is securely attached, and that it moves the full stroke from DEF to VENT.




05U0UX-161

**REC-FRESH wire**

1. Set the selector lever to FRESH position.
2. Connect and clamp the wire with the shutter lever on the blower unit at its closest point.

**Caution**

- After installation, move the REC-FRESH lever to be sure the wire is securely attached, and that it moves the full stroke from REC to FRESH.



05U0SX-106

**Temperature blend wire**

1. Set the temperature blend lever to MAX-HOT position.
2. Connect and clamp the wire with the shutter lever on the heater unit all the way to the right.

**Caution**


- After installation, move the temperature blend lever to be sure the wire is securely attached, and that it moves the full stroke from HOT to COLD.

TRIM

COMPONENTS

Removal / Installation

1. Remove as shown by prying out the trim clips.
2. Install in the reverse order of removal.




05U0SX-107

- |   |           |  |           |
|---|-----------|--|-----------|
| 1. Front header trim<br>Removal Note..... | page S-54 | 5. Quarter trim<br>Removal Note.....   | page S-54 |
| 2. A-pillar trim<br>Removal.....          | page S-54 | 6. Door trim<br>Removal Note.....      | page S-55 |
| 3. Front side trim<br>Removal Note.....   | page S-54 | 7. Speaker grille<br>Removal Note..... | page S-55 |
| 4. Scuff plate<br>Removal Note.....       | page S-54 | 8. Rear package trim                   |           |
|   |           | 9. Trunk end trim                      |           |

TRIM

**Removal Note**  
**Front header trim**


The clips and pin are where shown.



05U0SX-108

**A-pillar trim**


The clips and pin are where shown.



05U0SX-109

**Front side trim**


The clip and pins are where shown.



05U0SX-110

**Scuff plate**


The clips and pin are where shown.




05U0SX-111

**Quarter trim**

The clips and pins are where shown.




05U0SX-112



05U0SX-113

**Door trim**

The clips and pin are where shown.



05U0SX-114


**Speaker grille**

The clips and pins are where shown.



**FLOORMAT****COMPONENTS****Removal / Installation**

1. To remove the floormat, first remove the following.
  - a) Seats; (Refer to page S-59.)
  - b) Dashboard; (Refer to page S-50.)
  - c) Heater unit; (Refer to Section U.)
  - d) Front side trim, scuff plates, quarter trim, and rear package trim; (Refer to page S-53.)
  - e) Front seat belts and buckles; (Refer to page S-57.)
2. Remove the remaining parts in the order shown in the figure.
3. Install in the reverse order of removal.



1. Rear end mat  
2. Foot rest

3. Bracket  
4. Front floormat

05U0SX-115

**SEAT BELT**


**COMPONENTS**

**Removal / Installation**

1. Remove the quarter trim for removal of the seat belt. (Refer to page S-54.)
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.

**Caution**


- Do not disassemble the buckle or retractor assembly.



1. Seat belt  
Inspection ..... page S-58
2. Anchor cover

3. Bezel
4. Buckle
5. Tang

05U0SX-116




05U0SX-117

### EMERGENCY LOCKING RETRACTOR (ELR)

#### Inspection

1. Verify that the belt can be pulled out smoothly, and that it moves smoothly when worn.
2. Verify that the retractor locks when the belt is quickly pulled.




05U0SX-118

3. Remove the retractor.
4. Hold the retractor as it would be installed.
5. Slowly incline the retractor while pulling out the belt.
6. Verify that the retractor locks at **approx. 30 degrees** inclination.

### WEBBING

#### Inspection

Inspect the webbing for scars, tears, and wear and for deformation of the fittings.



05U0SX-119

### BUCKLE SWITCH

#### Inspection

1. Disconnect the seatbelt buckle switch connector.
2. Check continuity of the switch.

Seatbelt	Continuity
Buckled	No
Unbuckled	Yes

3. If continuity is not as specified, replace the switch.

**SEAT**


**COMPONENTS**

**Removal / Installation**

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.

**Note**


- **Disconnect the headrest speaker connector for removal of the seat (with headrest speaker).**



N·m (m·kg, ft·lb)

05U0SX-120

1. Front seat  
Inspection..... below




05U0SX-121

**SEAT Inspection**

1. Verify that the seat adjuster lever and reclining knuckle move smoothly.
2. Check the adjustment lever for wear.
3. Check the front seat mounting bolts for looseness.
4. Check grease on the seat slides.

### Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.



N-m (m-kg, ft-lb)

05U0SX-122

1. Side cover
2. Reclining knuckle cover
3. Reclining knuckle
4. Hog ring
5. Seatback trim

6. Pad
7. Back frame
8. Headrest speaker (If equipped)
9. Seat slide
10. Seat cushion


Inspection ..... Section T

CONVERTIBLE TOP

COMPONENTS

Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



N-m (m-kg, ft-lb)

05U0SX-123

1. Beltline cover
2. Beltline protector
3. Scuff plate

Removal Note .. page S-54


4. Seaming welt
5. Striker (if equipped)
6. Quarter trim

Removal Note .. page S-54

7. Rear package trim
8. Set plate
9. Convertible top

### Disassembly / Assembly


1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.




N-m (m-kg, ft-lb)

05U0SX-124



- |                          |  |   |
|--------------------------|--|---|
| 1. Beltline cover        | 11. Top latch assembly<br>Adjustment ..... page S-71 | 19. Open stopper                                      |
| 2. Beltline protector    | 12. Weatherstrip<br>Adjustment ..... page S-72       | 20. Top fabric<br>Disassembly Note<br>..... page S-63 |
| 3. Scuff plate           | 13. Retainer   | Assembly Note, page S-65                              |
| 4. Seaming welt          | 14. Set plate  | 21. Cable   |
| 5. Striker (If equipped) | 15. End plate  | 22. Cable guide                                       |
| 6. Quarter trim          | 16. Link assembly                                    | 23. Striker   |
| 7. Stopper               | 17. Protector  | 24. Cab side weatherstrip                             |
| 8. Rear package trim     | 18. Link stopper                                     |   |
| 9. Set plate             |  |   |
| 10. Top handle           |  |   |




05U0SX-125



05U0SX-126



05U0SX-127



05U0SX-128

**Disassembly Note**

**Top fabric**

1. Remove the convertible top from the body. (Refer to page S-61.)

**Note**

- **Set the convertible top upside down on a clean surface.**

2. Remove the set plate, weatherstrips, and retainers.

3. Remove the rivets from the link assembly with a drill.

**Drill size:  $\phi 4.0\text{mm}$  ( $\phi 0.16$  in)**

4. Remove the rivets with a drill and remove the screws from the link assembly. Remove the end plates.

**Drill size:  $\phi 4.0\text{mm}$  ( $\phi 0.16$  in)**


**Note**

- **Fold the convertible top.**

5. Remove the top fabric from the link assembly.

6. Remove the top fabric from the front header.






05U0SX-129

7. Remove the screws, and remove the cables from the rear of the link assembly.

**Note**


- **Unfold the convertible top.**



05U0SX-130


8. Remove the rivets from the link assembly with a drill, and remove the cables from the link assembly.

**Drill size:  $\phi 4.0\text{mm}$  ( $\phi 0.16$  in)**




05U0SX-131

9. Peel off the Velcro at the rear bow.  
 10. Pry back the bow retainers with a protected screwdriver.  
 11. Remove the top fabric from the bows.




05U0SX-132

12. Remove the cables from the cable guide.  
 13. Remove the top fabric and cables from the link assembly.




05U0SX-133


14. Remove the cables from the top fabric.




05U0SX-134




05U0SX-135



05U0SX-136



05U0SX-137



05U0SX-138

## Installation Note

### Top fabric

1. Remove the original double-sided adhesive tape from the front header.
2. Degrease the front header with ethyl alcohol.
3. Install new double-sided adhesive tape to the front header.

4. Thread the cables into the top fabric.

5. Place the link assembly over the top fabric.

### Note

- Install the top fabric to the bows, beginning from the rear bow. Perform Steps 6, 7, and 8.


6. Roll the top fabric over the bow retainer.
7. Hang the end of the top fabric on the bow retainer.

8. Clamp the top fabric to the bow with protected water pump pliers.

### Note

- Pull the top fabric by hand to verify that it is held securely.

9. Affix the top fabric to the rear bow with the Velcro.




05U0SX-139

**Note**

- Set the convertible top upright.

10. Rivet the cables to the front of the link assembly.



05U0SX-140

**Note**


- Turn the convertible top over and fold it.

11. Install the front of the top fabric to the front header.

**Note**


- Align the set plate and top fabric with the set plate mounting holes.

12. Install the set plate to the link assembly.




05U0SX-141

13. Pass the cables through the cable guides.



05U0SX-142


14. Install the cables to the rear of the link assembly.



05U0SX-143

15. Install the top fabric to the link assembly.

16. Install the end plates to the link assembly.





05U0SX-144

**Note**

- **Unfold the convertible top.**

17. Rivet the top fabric to the link assembly.



05U0SX-145

18. Install the retainers and weatherstrips to the link assembly.

**Adjusting Small Sag**

1. Raise the convertible top and lock the latch assemblies.
2. Use a steamer or steam wand to remove sags.
3. Allow top fabric to dry.

05U0SX-146

REPAIR OF TOP FABRIC

Note

- Repairing a hole in the top fabric differs from repairing a tear in the fabric. Refer to page S-69 for tear repair.

Repair of Hole in Top Fabric

1. Place the **repair sheet** (NAY1 R1 211) over the damaged section. Cut both the top fabric and the repair sheet with a razor knife.

2. Cut another piece of repair sheet larger than the first for use as a back repair sheet.  
3. Trim the top fabric and the repair sheets with scissors.

4. Degrease the repair sheets with ethyl alcohol.

5. Apply **adhesive agent** (K180 W0 313) or equivalent to the part being repaired, to the repair sheet, and to the back repair sheet.


Note

- Apply a substantial amount of the adhesive agent to the cloth.
- Let it stand for a few minutes.


6. Insert the repair sheet into the section of the top fabric being repaired. Then install the back repair sheet from the underside.

7. Press the repair sheets firmly together.


8. Let the top fabric stand until the adhesive agent is fully dry.




05U0SX-147




05U0SX-148




77A14X-028




05U0SX-149




05U0SX-150



05U0SX-151



97U0SX-239



05U0SX-152

**Repair of Tear in Top Fabric**

1. Cut a piece of **repair sheet** (NAY1 R1 211) larger than the damaged section for use as a back repair sheet.

2. Degrease the repair sheet with ethyl alcohol.

3. Apply **adhesive agent** (K180 W0 313) or equivalent to the part being repaired and to the back repair sheet.

**Note**

- **Apply a substantial amount of the adhesive agent to the cloth.**
- **Let it stand for a few minutes.**

4. Install the back repair sheet from the underside.

5. Press the repair sheets firmly together.


6. Let the top fabric stand until the adhesive agent is fully dry.

DETACHABLE HARD TOP

COMPONENTS

Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.



05U0SX-153

- |                             |                                       |
|-----------------------------|---------------------------------------|
| 1. Striker                  | 7. Rear window glass                  |
| 2. Top latch assembly       | Removal / Installation..... page S-42 |
| Adjustment..... page S-71   | 8. Rear deck latch assembly           |
| 3. Side latch assembly      | 9. Rear weatherstrip                  |
| Adjustment..... page S-71   | 10. Edge protector                    |
| 4. Weatherstrip             | 11. Detachable hard top               |
| Adjustment..... page S-72   | 12. Rear deck plate                   |
| 5. Retainer                 |                                       |
| 6. Rear window molding      |                                       |
| Installation..... page S-29 |                                       |

**CONVERTIBLE TOP, DETACHABLE HARD TOP**

**Adjustment**

**Convertible top/Detachable hard top**

The alignment of either top to the windshield header may be adjusted up, down, fore, and aft by turning the respective top latch assembly adjusting nut.

**Adjustment procedure**

1. Fold the protector away from the adjusting nut.
2. When the adjusting nut is turned clockwise:  
Clearance (A) and height (B) of the top become less.
3. When the adjusting nut is turned counterclockwise:  
Clearance (A) and height (B) of the top become greater.

**Caution**

- **Secure the adjusting nut with the protector after completing any adjustment.**

**Detachable hard top**


If engagement of the striker and the side latch assembly is too tight or too loose, adjustment is made through the latch assembly adjusting nut.

**Adjustment procedure**

1. Fold the protector away from the adjusting nut.
2. When the adjusting nut is turned clockwise:  
Engagement of the striker and the side latch assembly becomes tighter.
3. When the adjusting nut is turned counterclockwise:  
Engagement of the striker and the side latch assembly becomes looser.

**Caution**

- **Secure the adjusting nut with the protector after completing any adjustment.**






**Weatherstrip (Convertible top/Detachable hard top)**

If there is any misalignment (lateral or vertical), adjust by following the steps below:


**Adjustment procedure**

1. Remove the weatherstrip in question.
2. Loosen the retainer screw and adjust the retainer as necessary.
3. Tighten the screw, and reinstall the weatherstrip.
4. Recheck the alignment.





UNDERBODY PROJECTED DIMENSIONS



## UNDERBODY DIMENSIONS

**S**

- A : BUMPER BRACKET MOUNTING NUT
- B : FRAME REFERENCE HOLE  $\phi 16$  (0.63)
- C : STABILIZER MOUNTING NUT
- D : FRONT FENDER PANEL MOUNTING NUT
- E : SUSPENSION MOUNTING BOLT
- F : FRONT MOUNTING BLOCK
- G : FRAME REFERENCE HOLE 12x18 (0.47x0.71)
- H : CROSSMEMBER MOUNTING NUT
- I : FRONT FENDER PANEL MOUNTING NUT
- J : CROSSMEMBER MOUNTING NUT
- K : FRAME REFERENCE HOLE  $\phi 12$  (0.47)
- L : FRAME REFERENCE HOLE  $\phi 20$  (0.79)
- M : FRAME REFERENCE HOLE 12x18 (0.47x0.71)
- N : FRAME REFERENCE HOLE  $\phi 12$  (0.47)
- O : SUSPENSION MOUNTING BOLT
- P : SUSPENSION MOUNTING NUT
- Q : REAR MOUNTING BLOCK
- R : SUSPENSION MOUNTING BOLT
- S : FRAME REFERENCE HOLE 16x22 (0.63x0.87)
- T : BUMPER BRACKET REFERENCE HOLE  $\phi 7$  (0.28)
- U : BUMPER MOUNTING HOLE 12x14 (0.47x0.55)

mm (in)


05U0SX-158

# BODY ELECTRICAL SYSTEM

<b>INDEX</b> .....	T- 2	BRAKE FLUID LEVEL SENSOR .....	T- 43
SWITCHES .....	T- 2	PARKING BRAKE SWITCH.....	T- 43
FUSES AND RELAYS.....	T- 3	SEAT BELT BUCKLE SWITCH.....	T- 43
LIGHTS.....	T- 4	<b>LIGHTING SYSTEM</b> .....	T- 44
CRUISE CONTROL SYSTEM .....	T- 5	STRUCTURAL VIEW .....	T- 44
AUDIO SYSTEM .....	T- 6	HEADLIGHTS .....	T- 45
AIR BAG SYSTEM .....	T- 7	STOPLIGHTS .....	T- 58
TROUBLESHOOTING.....	T- 8	TURN AND HAZARD WARNING LIGHTS	T- 62
<b>OUTLINE</b> .....	T- 9	BACK-UP LIGHTS .....	T- 71
HOW TO USE THIS SECTION .....	T- 9	TAILLIGHTS, SIDE MARKER LIGHTS,	
ELECTRICAL TROUBLESHOOTING		PARKING LIGHTS AND LICENSE	
TOOLS.....	T- 9	PLATE LIGHTS .....	T- 74
GENERAL PRECAUTION .....	T- 10	DAYTIME RUNNING LIGHTS.....	T- 78
ELECTRICAL SYMBOLS .....	T- 11	REAR COMBINATION LIGHT LENS.....	T- 83
<b>FUSE</b> .....	T- 12	INTERIOR LAMPS .....	T- 85
STRUCTURAL VIEW .....	T- 12	ILLUMINATION LAMPS .....	T- 89
DESCRIPTION.....	T- 12	<b>HORN</b> .....	T- 91
SPECIFICATIONS .....	T- 13	STRUCTURAL VIEW .....	T- 91
REPLACEMENT .....	T- 14	CIRCUIT DIAGRAM.....	T- 92
<b>RELAY</b> .....	T- 15	TROUBLESHOOTING.....	T- 93
STRUCTURAL VIEW .....	T- 15	REMOVAL / INSTALLATION.....	T- 95
DESCRIPTION.....	T- 15	<b>CRUISE CONTROL SYSTEM</b> .....	T- 97
HEADLIGHT RETRACTOR RELAY.....	T- 16	STRUCTURAL VIEW .....	T- 97
TURN AND HAZARD WARNING		CIRCUIT DIAGRAM.....	T- 98
FLASHER UNIT .....	T- 16	TROUBLESHOOTING.....	T- 99
TIMER AND BUZZER UNIT.....	T- 17	INSPECTION OF CRUISE CONTROL	
DRL UNIT .....	T- 18	SYSTEM USING SELF-DIAGNOSTIC	
4-TERMINAL NORMALLY OPEN RELAY	T- 19	FUNCTION.....	T-102
<b>SWITCH</b> .....	T- 20	ACTUATOR .....	T-104
STRUCTURAL VIEW .....	T- 20	CRUISE CONTROL UNIT.....	T-105
DESCRIPTION.....	T- 20	ACTUATOR CABLE .....	T-106
STEERING LOCK .....	T- 21	CLUTCH SWITCH.....	T-106
COMBINATION SWITCH.....	T- 21	BRAKE SWITCH .....	T-107
HEADLIGHT RETRACTOR SWITCH		CRUISE CONTROL MAIN SWITCH.....	T-107
AND HAZARD WARNING SWITCH		CRUISE CONTROL SWITCH.....	T-107
ASSEMBLY .....	T- 25	SPEED SENSOR .....	T-107
<b>INSTRUMENT CLUSTER</b> .....	T- 26	<b>AUDIO</b> .....	T-108
STRUCTURAL VIEW .....	T- 26	STRUCTURAL VIEW .....	T-108
DESCRIPTION.....	T- 26	SYSTEM DIAGRAM.....	T-109
CIRCUIT DIAGRAM.....	T- 27	FEATURES .....	T-109
TROUBLESHOOTING.....	T- 28	FUNCTION AND OPERATING	
REMOVAL / INSTALLATION.....	T- 33	PROCEDURE .....	T-110
DISASSEMBLY / ASSEMBLY.....	T- 33	TROUBLESHOOTING.....	T-115
SPEEDOMETER .....	T- 34	REMOVAL / INSTALLATION.....	T-126
TACHOMETER.....	T- 34	INSPECTION .....	T-128
WATER TEMPERATURE GAUGE .....	T- 34	CONNECTOR TERMINAL	
FUEL GAUGE.....	T- 35	SPECIFICATIONS.....	T-128
OIL PRESSURE GAUGE .....	T- 35	PANASONIC SERVICE NETWORK.....	T-129
PRINTED CIRCUIT.....	T- 36	<b>AIR BAG SYSTEM</b> .....	T-130
SPEED SENSOR .....	T- 36	STRUCTURAL VIEW .....	T-130
WATER THERMOSENSOR .....	T- 36	COMPONENT DESCRIPTION .....	T-131
FUEL GAUGE SENDER UNIT		SYSTEM DIAGRAM.....	T-132
(IN FUEL TANK) .....	T- 36	SERVICE PRECAUTION.....	T-133
OIL PRESSURE SENSOR.....	T- 37	CIRCUIT DIAGRAM.....	T-136
SPEEDOMETER CABLE .....	T- 37	TROUBLESHOOTING GUIDE .....	T-138
<b>WARNING LAMP AND SENDER UNIT</b> ....	T- 38	REMOVAL / INSTALLATION.....	T-150
STRUCTURAL VIEW .....	T- 38	INSPECTION .....	T-157
CIRCUIT DIAGRAM.....	T- 39	AIR BAG MODULE DISPOSAL	
TROUBLESHOOTING.....	T- 40	PROCEDURE .....	T-160

INDEX


SWITCHES



05U0TX-002

1. Ignition switch		
Inspection .....	page T-21	
Replacement.....	page T-21	
2. Combination switch		
Removal / Installation .....	page T-21	
Inspection .....	page T-23	
3. Headlight retractor switch		
Removal / Installation .....	page T-25	
Inspection .....	page T-25	
4. Hazard warning switch		
Removal / Installation .....	page T-25	
Inspection .....	page T-25	
5. Parking brake switch		
Inspection .....	page T-43	
6. Seat belt buckle switch		
Inspection .....	page T-43	
7. Stoplight switch		
Adjustment.....	page T-61	
Inspection .....	page T-61	
8. Brake switch		
Removal / Installation .....	page T-107	
Inspection .....	page T-107	
9. Back-up light switch		
Inspection .....	page T- 73	
10. Door switch		
Inspection .....	page T- 88	
11. Interior lamp switch		
12. Panel lamp control switch		
Inspection .....	page T- 90	
13. Horn switch		
Removal / Installation .....	page T- 95	
14. Clutch switch		
Removal / Installation .....	page T-106	
Inspection .....	page T-106	
Adjustment.....	page T-106	


FUSES AND RELAYS



05U0TX-003

- |  |           |  |           |
|--|-----------|--|-----------|
| 1. Main fuse block<br>Fuse replacement.....      | page T-14 | 7. Circuit-opening relay                                     |           |
| 2. Fuse box<br>Fuse replacement.....             | page T-14 | 8. Cooling fan relay<br>Inspection .....                     | page T-19 |
| 3. Headlight relay<br>Inspection .....           | page T-19 | 9. Horn relay<br>Inspection .....                            | page T-19 |
| 4. TNS relay<br>Inspection .....                 | page T-19 | 10. Turn and hazard warning flasher unit<br>Inspection ..... | page T-16 |
| 5. Headlight retractor relay<br>Inspection ..... | page T-16 | 11. Timer and buzzer unit<br>Inspection .....                | page T-17 |
| 6. EGI main relay                                |           |  |           |

### LIGHTS




05U0TX-004

- |                                  |           |
|----------------------------------|-----------|
| 1. Retractable headlight         |           |
| Aiming.....                      | page T-55 |
| Removal / Installation .....     | page T-54 |
| 2. Headlight retractor motor     |           |
| Removal / Installation .....     | page T-54 |
| Inspection .....                 | page T-56 |
| 3. Stoplight                     |           |
| Removal / Installation .....     | page T-60 |
| 4. High-mount stoplight          |           |
| Removal / Installation .....     | page T-60 |
| 5. Turn and hazard warning light |           |
| Removal / Installation .....     | page T-69 |
| 6. Back-up light                 |           |
| Removal / Installation .....     | page T-73 |
| 7. License plate light           |           |
| Removal / Installation .....     | page T-77 |
| 8. Side marker light             |           |
| Removal / Installation .....     | page T-77 |
| 9. Taillight                     |           |
| Removal / Installation .....     | page T-77 |
| 10. Rear combination light lens  |           |
| Replacement.....                 | page T-83 |
| 11. Interior lamp                |           |




**CRUISE CONTROL SYSTEM**



05U0TX-005

- |  |   |
|--|---|
| <p>1. Cruise control unit<br/>             Removal / Installation ..... page T-105<br/>             Inspection ..... page T-105</p> <p>2. Actuator<br/>             Inspection ..... page T-104<br/>             Removal / Installation ..... page T-104</p> <p>3. Actuator cable<br/>             Removal / Installation ..... page T-106<br/>             Adjustment..... page T-106</p> | <p>4. Clutch switch<br/>             Removal / Installation ..... page T-106<br/>             Adjustment..... page T-106</p> <p>5. Brake switch<br/>             Removal / Installation ..... page T-107<br/>             Adjustment..... page T-107</p> <p>6. Cruise control main switch<br/>             Inspection ..... page T-107</p> <p>7. Cruise control switch<br/>             Inspection ..... page T-107</p> |
|--|---|

### AUDIO SYSTEM




05U0TX-006

- 1. Audio unit  
Removal / Installation ..... page T-126
- 2. Door speakers  
Removal / Installation ..... page T-127  
Inspection ..... page T-128

- 3. Headrest speakers  
Removal / Installation ..... page T-127  
Inspection ..... page T-128

**AIR BAG SYSTEM**



05U0TX-007

- |   |   |
|---|---|
| 1. Air bag module<br>Removal / Installation ..... page T-150  | 4. Backup battery<br>Removal / Installation ..... page T-151                              |
| 2. Clock spring connector<br>Removal / Installation ..... page T-152<br>Inspection ..... page T-159 | 5. Crash sensor<br>Removal / Installation ..... page T-154<br>Inspection ..... page T-157 |
| 3. Diagnostic module<br>Removal / Installation ..... page T-151                                     |   |

## TROUBLESHOOTING

System	Symptom	Reference page
<b>Instrument cluster</b>	<ul style="list-style-type: none"> <li>• Speedometer does not operate or indication is incorrect</li> <li>• Tachometer does not operate</li> <li>• Water temperature gauge does not operate</li> <li>• Fuel gauge does not operate</li> <li>• Oil pressure gauge does not operate</li> </ul>	T- 28 T- 29 T- 30 T- 31 T- 32
<b>Warning lamp and sender unit</b>	<ul style="list-style-type: none"> <li>• Brake warning lamp remains illuminated</li> <li>• Brake warning lamp does not illuminate when parking brake on</li> <li>• Brake warning lamp does not illuminate when brake fluid in reservoir below MIN</li> <li>• Seat belt warning lamp remains ON six seconds after ignition switch turned ON (Timer function does not operate)</li> <li>• Seat belt warning lamp does not illuminate when ignition switch first turned ON</li> </ul>	T- 40 T- 41 T- 41 T- 42 T- 42
<b>Lighting system</b>	<ul style="list-style-type: none"> <li>• Headlights do not illuminate (U.S. spec.)</li> <li>• Headlights do not illuminate (Canada spec.)</li> <li>• Headlight does not illuminate (right or left)</li> <li>• Headlight retractor motors do not operate</li> <li>• Headlight retractor motor does not operate (right or left)</li> <li>• Stoplights do not illuminate</li> <li>• Stoplight does not illuminate</li> <li>• Turn and hazard warning functions do not operate (U.S. spec.)</li> <li>• Turn and hazard warning function do not operate (Canada spec.)</li> <li>• Turn signal(s) flashes rapidly</li> <li>• Hazard warning function does not operate</li> <li>• Back-up light(s) does not illuminate</li> <li>• Taillights, side marker lights, and license plate lights do not illuminate (U.S. spec.)</li> <li>• Taillights, side marker lights, and license plate lights do not illuminate (Canada spec.)</li> <li>• Running lights do not illuminate</li> <li>• Running light function does not cancel</li> <li>• Interior lamp(s) do not illuminate</li> <li>• Interior lamp(s) remains illuminated</li> </ul>	T- 46 T- 48 T- 50 T- 51 T- 53 T- 59 T- 60 T- 63 T- 65 T- 67 T- 68 T- 72 T- 75  T- 79 T- 80 T- 86 T- 88
<b>Horn</b>	<ul style="list-style-type: none"> <li>• Horn does not sound</li> </ul>	T- 93
<b>Cruise control system</b>	<ul style="list-style-type: none"> <li>• Vehicle speed cannot be set (Cruise control unit will not hold vehicle speed)</li> </ul>	T- 99
<b>Audio</b>	<ul style="list-style-type: none"> <li>• Speaker(s) do not sound (System without headrest speakers)</li> <li>• Speaker(s) do not sound (System with headrest speakers)</li> <li>• Poor sound quality or noise (Radio)</li> <li>• Poor sound quality (Cassette tape player)</li> <li>• Cassette tape will not load</li> <li>• Cassette tape will not play</li> <li>• Compact disc will not load</li> <li>• Compact disc skips</li> </ul>	T-115 T-117 T-120 T-122 T-123 T-124 T-125 T-125
<b>Air bag system</b>	<ul style="list-style-type: none"> <li>• Air bag warning lamp flashes</li> </ul>	T-138


05U0TX-008

OUTLINE

HOW TO USE THIS SECTION

Information regarding removal and installation of electrical equipment is given in **SECTION S**. Understanding will be easier if this section is used in conjunction with the **WIRING DIAGRAMS**.

9MU0TX-008



05U0TX-273


ELECTRICAL TROUBLESHOOTING TOOLS

**Test Light**

The test light, as shown in the figure, uses a 12V bulb. The two leads should be connected to probes. The test light is used for simple voltage checks and to check for open circuits.

**Caution**

- **When checking a control unit, never use a bulb over 3.4W.**




61G15X-002

**Jumper Wire**

The jumper wire is used for testing by short-circuiting switch terminals and for verifying the condition of ground connections.

**Caution**


- **Do not connect the jumper wire between a power source line and body ground because this may cause burning or other damage to harnesses or electronic components.**



69G15X-003

**Voltmeter**

The DC voltmeter is used for measuring circuit voltage. A voltmeter with a range of 15V or more is used by connecting the positive (+) probe (red lead) to the point where voltage is to be measured and the negative (-) probe (black lead) to the body ground.




63U15X-005

**Ohmmeter**

The ohmmeter is used to measure the resistance between two points in a circuit, and is also used to check for continuity and diagnosis of short circuits.

**Caution**

- **Do not attempt to connect the ohmmeter to any circuit to which voltage is applied because this may burn or otherwise damage the ohmmeter.**



05U0TX-009

















**GENERAL PRECAUTION****Before Disconnecting Battery Cables**

The optional audio unit has an anti-theft function that is activated when the battery power is disconnected. Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to page T-113.)


















**ELECTRICAL SYMBOLS**

**Switches and Relays**

There is an NC (normally closed) and NO (normally open) indication for switches and relays that shows when no change of operation conditions has occurred.


	Relay		Switch	
	NO type relay	NC type relay	NO switch	NC switch
Not in operation (No power supply)	  STOP	  FLOW	  STOP	  FLOW
In operation (Power supply)	  FLOW	  STOP	  FLOW	  STOP

**Other Electrical Symbols**

		 HOLDER	 BOX	
BATTERY	BODY GROUND	FUSE		FUSIBLE LINK
				
MOTOR	COIL, SOLENOID	RESISTOR	VARIABLE RESISTOR	
				
THERMISTER	DIODE	CONDENSER	LIGHT	
				
TRANSISTOR	SPEAKER	CIGARETTE LIGHTER	HEATER	

## FUSE

### STRUCTURAL VIEW



1. Main fuse block

2. Fuse box

05U0TX-010

### DESCRIPTION

#### Main Fuse Block

The main fuse block is located on the right side of the engine compartment and it contains nine fuses and two relays.

#### Fuse Box

The fuse box is located above the dead pedal of the driver side. The fuse box cover shows the specified fuse locations.

A circuit breaker is contained in the fuse box for protection of the heater blower motor circuit.

05U0TX-011



## SPECIFICATIONS

### Main Fuse Block

Fuse	Amperes	Protected circuit
HEAD	30A	Headlight relay, Headlight switch
INJ	30A	Alternator, Diagnostic module (for air bag system)
MAIN	80A	Except circuits protected in main fuse block: INJ 30A, HEAD 30A, RETRACTOR 30A
BTN	40A	TNS relay, Headlight switch
COOLING FAN	30A	EGI main relay, Cooling fan relay
(AIR BAG)	10A	Backup battery (for air bag system)
(AD FAN)	20A	A/C relay
ST SIG	10A	Inhibitor relay, Circuit-opening relay
RETRACTOR	30A	Retractable headlight motors

05U0TX-506

### Fuse Box


Fuse	Amperes	Protected circuit
ENGINE	15A	EGI main relay, Cooling fan relay
METER	10A	Instrument cluster, Turn signal switch, Timer and buzzer unit, Cruise control main switch
(AIR BAG)	15A	Diagnostic module
(POWER WIND)	30A	Power window switch
WIPER	20A	Blower switch, Wiper switch
TAIL	15A	Taillights, Side marker lights, License plate lights, Parking lights
STOP	15A	Stoplight switch, Horn switch, Cruise control unit
HAZARD	15A	Turn and hazard warning flasher unit
ROOM	10A	ECU, Key reminder switch, Audio unit
CIGAR	15A	Cigarette lighter, Audio unit

05U0TX-507


### Fuse Color Code

Fuse amperes	Color code	Fuse type
10A	Red	Plate type
15A	Light blue	
20A	Yellow	
30A	Light green	
30A	Pink	Cartridge type
80A	Black	


05U0TX-012



05U0TX-013



05U0TX-014



05U0TX-015

## REPLACEMENT

### Note

- If a fuse again fails after it has been replaced, there is probably a short in the circuit.
- Check the circuit which is protected by the failed fuse, referring to the specifications table.

### Plate type


1. Disconnect the negative battery cable.
2. Using the fuse puller supplied in the fuse box, removed replace the failed fuse.
3. Reconnect the negative battery cable.

### Cartridge-type 80A fuse (Black)

1. Disconnect the negative battery cable.
2. Remove the fuse block mounting nuts, and remove the service cover.
3. Remove the fuse installation bolts, and pull out the fuse.
4. Install the new fuse and the fuse installation bolts.
5. Install the main fuse block.
6. Reconnect the negative battery cable.

RELAY

STRUCTURAL VIEW



05U0TX-016

- 1. Headlight relay
- 2. TNS relay
- 3. Retractor relay

- 4. EGI main relay
- 5. Circuit-opening relay
- 6. Cooling fan relay

- 7. Horn relay
- 8. Turn and hazard warning flasher unit
- 9. Timer and buzzer unit

**Note**

- For inspection of the following relays, refer to specified Section.
  - EGI main relay..... Refer to Section F
  - Circuit-opening relay..... Refer to Section F
  - A/C relay ..... Refer to Section U


**DESCRIPTION**

The DRL control unit which is equipped for Canada vehicles controls the turn lights operation. Except bellow conditions, whenever the ignition switch is in ON or START position, front turn signal lights will illuminate to be running lights.


- Headlight switch ON.
- Turn signal switch ON.
- Hazard switch ON.
- Parking brake switch ON.

05U0TX-017


RELAY



05U0TX-018



05U0TX-019



05U0TX-020

HEADLIGHT RETRACTOR RELAY

Inspection

1. Check continuity between terminals of the relay.

Terminal	Continuity
1—4	Yes
2—4	No
3—5	Yes

2. If not as specified, replace the retractor relay.

3. If correct, go to Step 4.

4. Apply 12V to terminal 3 and ground terminal 5. Check continuity between terminals of the relay.

Terminal	Continuity
1—4	No
2—4	Yes

5. If not as specified, replace the retractor relay.

TURN AND HAZARD WARNING FLASHER UNIT

Inspection

1. Check continuity between terminals of the flasher unit.


Note

- Set the ohmmeter to  $\times 1000\Omega$  range.


Terminal	Continuity	Terminal	Continuity	Terminal	Continuity
+ -		+ -		+ -	
a—c	X	d—e	X	f—g	X
a—d	X	d—f	X	f—h	X
a—e	○	d—g	X	g—a	X
a—f	○	d—h	X	g—c	X
a—g	X	e—a	X	g—d	X
a—h	X	e—c	X	g—e	X
c—a	○	e—d	X	g—f	X
c—d	○	e—f	X	g—h	X
c—e	○	e—g	X	h—a	○
c—f	○	e—h	X	h—c	○
c—g	○	f—a	X	h—d	○
c—h	○	f—c	X	h—e	○
d—a	X	f—d	X	h—f	○
d—c	X	f—e	X	h—g	○

○: Indicates continuity X: No continuity


2. If not as specified, replace the flasher unit.




05U0TX-021



05U0TX-022



05U0TX-023



05U0TX-024

**TIMER AND BUZZER UNIT**  
Inspection

**Note**

- While performing the following tests, apply 12V to terminal i and ground terminal j.

**Key remainder alarm test**

1. Apply 12V to terminal h and ground terminal c, and check if the buzzer sounds.

Terminal		Buzzer sounds
12V	Ground	
h	c	Yes

2. If the buzzer does not sound, replace the timer and buzzer unit.

**Seat belt alarm test**

1. Apply 12V to terminals f and h and ground terminal d, and check if the buzzer sounds for **approx. 6 sec.**

Terminal		Buzzer sounds
12V	Ground	
f and h	d	Approx. 6 sec.

2. If not as specified, replace the timer and buzzer unit.

**Seat belt warning lamp timer**

1. Connect a test light (1.4W) between terminals i and f.
2. Ground terminal d, and check that the test light illuminates for **Approx. 6 sec.**

Terminal		Test light illuminates
Test light between i and f		
d grounded		Approx. 6 sec.


3. If not as specified, replace the timer and buzzer unit.

RELAY


**DRL UNIT  
Inspection  
Voltage test**

**Note**


- While performing the following voltage tests, apply 12V to terminal j and ground terminal i.




05U0TX-025




05U0TX-026



05U0TX-027



05U0TX-028



05U0TX-274

1. Apply 12V to terminal c, and measure the voltage at terminals d and k.

Terminal	Voltage
d	12V
k	12V

2. If not as specified, replace the DRL unit.

3. Remove the 12V from terminal c.
4. Apply 12V to terminals f and h, and measure the voltage at terminals d and k.

Terminal	Voltage
d	12V
k	12V

5. If not as specified, replace the DRL unit.

6. Remove the 12V from terminals f and h.
7. Ground terminal b, and measure the voltage at terminals d and k.

Terminal	Voltage
d	12V
k	12V

8. If not as specified, replace the DRL unit.

**Continuity test**

1. Check for continuity between terminals of the DRL unit.

Terminal	Continuity
d—f	Yes
h—k	Yes

2. If not as specified, replace the DRL unit.


**4-TERMINAL NORMALLY OPEN RELAY (NO RELAY)**

**Inspection**

The relays listed below are 4-terminal normally open (NO) relays.

- Horn relay
- Headlight relay
- TNS relay
- Cooling fan relay

05U0TX-029




05U0TX-275

**Headlight relay and cooling fan relay**

1. Check continuity between terminals 3 and 4.

Terminal	Continuity
3—4	No

2. If not as specified, replace the relay.
3. If correct, go to Step 4.




9MU0TX-027

4. Apply 12V to terminal 1 and ground terminal 2. Check for continuity between terminals 3 and 4.

Terminal	Continuity
3—4	Yes

5. If not as specified, replace the relay.




05U0TX-276

**Horn relay and TNS relay**

1. Check continuity between terminals 1 and 3.

Terminal	Continuity
1—3	No

2. If not as specified, replace the relay.
3. If correct, go to Step 4.



05U0TX-277


4. Apply 12V to terminal 2 and ground terminal 4. Check for continuity between terminals 1 and 3.

Terminal	Continuity
1—3	Yes

5. If not as specified, replace the relay.

## SWITCH

## STRUCTURAL VIEW



05U0TX-030

1. Ignition switch
2. Combination switch


3. Headlight retractor switch
4. Hazard warning switch

**DESCRIPTION****Combination Switch (U.S. spec.)**


The combination switch equipped for U.S. specification vehicles includes a clock spring type electrical connector for supplying electrical current to the air bag module and horn switches.

When installing the combination switch, make sure the clock spring connector is properly aligned. If it is not, it may be broken or the steering wheel may not turn fully. (Refer to page T-22.)





05U0TX-032



05U0TX-033

**STEERING LOCK Replacement**

1. Disconnect the negative battery cable.
2. Remove the column covers.
3. Remove the screw and the ignition switch.
4. Install in the reverse order of removal.

**Inspection**

1. Check continuity between terminals of the switch.

Position	Terminal							
	B1	B2	ACC	IG1	IG2	ST	K1	K2
LOCK							○—○	○—○
ACC	○—○		○—○				○—○	○—○
ON	○—○	○—○	○—○	○—○	○—○		○—○	○—○
START	○—○	○—○		○—○		○—○	○—○	○—○

○—○: Indicates continuity

2. If not as specified, replace the combination switch.


**COMBINATION SWITCH Removal / Installation**

**Caution (U.S. spec.)**


- Before removing the clock spring connector, disconnect the negative battery cable.
- Before installing the steering wheel, reset the clock spring connector. (Refer to page T-22.)

Remove and install as shown in the figure.


**Canada spec.**




U.S. spec.



05U0TX-035



05U0TX-036




05U0TX-037


**Clock spring connector adjustment**

1. Set the front wheels straight ahead.
2. Turn the clock spring connector clockwise until it stops.  
**Do not force it.**


3. Return the connector 2.75 turns.
4. Align the marks on the clock spring connector and the outer housing.




05U0TX-038




05U0TX-039



05U0TX-040



05U0TX-041



05U0TX-042

**Inspection**

**U.S. spec.**

1. Disconnect the negative battery cable.
2. Remove the knee protector.
3. Disconnect the combination switch connector.
4. Check the continuity or the resistance between the terminals described with an ohmmeter.
5. If the continuity or resistance is not as specified, replace the combination switch as an assembly.

**Lights, dimmer, and passing switch**

Position		Terminal						
		E	HL	HU	TNS	HEAD	BA	B
Headlight	Low beam	○			○	○		
	High beam	○	○			○		
Passing				○				○
Tail, Parking		○			○			

○—○: Indicates continuity

**Turn signal switch**

Switch	Terminal		
	FU	TL	TR
Left	○	○	
Right	○		○

○—○: Indicates continuity

**Windshield wiper and washer switch**

Position	Terminal		AS	WIG	SWL	SWH	INT	SW
	One touch							
Wiper switch	OFF	OFF	○		○			
		ON		○	○			
	INT		○		○		○	
					○	○		
Washer switch ON			○					○

○—○: Indicates continuity

**Cruise control switch**


Position	Terminal		
	SE	RE	E
SET/COAST	○		○
RESUME/ACCEL		○	○

○—○: Indicates continuity


## SWITCH

### Canada spec.


1. Check the continuity or resistance between the terminals described.
2. If the continuity or resistance is not as specified, replace the combination switch.




05U0TX-043



9MU0TX-046



9MU0TX-047



05U0TX-044

### Lights, dimmer, and passing switch

Position		Terminal		HB	HL	HU	BA	BTN	TNS
Headlight	Low beam	○	○	○			○	○	○
	High beam	○	○	○			○	○	○
Passing						○	○		
Tail, Parking								○	○

○—○: Indicates continuity

### Turn signal switch

Position		Terminal		FU	TL	TR
Left		○	○			
Right		○	○			

○—○: Indicates continuity

### Windshield wiper and washer switch


Position		Terminal		AS	WIG	SWL	SWH	E	SW
Wiper switch	OFF	One touch OFF	○			○			
		ON				○	○		
	INT				○	○			
	I (Low)				○	○			
	II (High)						○	○	
Washer switch ON								○	○

○—○: Indicates continuity

**HEADLIGHT RETRACTOR SWITCH AND HAZARD WARNING SWITCH ASSEMBLY**

**Removal / Installation**

Remove and install as shown in the figure



05U0TX-046

**Inspection**

**Headlight retractor switch**

1. Remove the retractor switch.
2. Check for continuity between terminals of the switch.

Switch	Terminal		
	b	d	f
Off	○	—	○
On	—	○	○

○—○: Indicates continuity

3. If not as specified, replace the retractor and hazard switch as an assembly.


**Hazard warning switch**

1. Remove the hazard switch.
2. Check continuity between terminals of the switch.


Switch	Terminal	
	g	h
On	○	○
Off	—	—

○—○: Indicates continuity

3. If not as specified, replace the hazard and retractor switch as an assembly.




05U0TX-047



05U0TX-048

## INSTRUMENT CLUSTER (METER)

## STRUCTURAL VIEW



05U0TX-049

- |                            |                                |
|----------------------------|--------------------------------|
| 1. Speedometer             | 5. Oil pressure gauge          |
| 2. Tachometer              | 6. Warning and indicator lamps |
| 3. Water temperature gauge | 7. Trip meter                  |
| 4. Fuel gauge              | 8. Odometer                    |

**DESCRIPTION****Speedometer**

Two scales are shown on the speedometer face. The main scale for U.S. specification vehicles is MPH (0—130 MPH); the main scale for Canada specification vehicles is KM/H (0—210 KM/H). The odometer indication is the same as the main scale.

**Tachometer**

The tachometer has a RED STRIPED ZONE (6,500—7,000 rpm) that indicates momentary allowable engine speed. The engine should not be operated in the RED ZONE (7,000—8,000 rpm).

**Fuel Gauge**


The fuel gauge continues to indicate the amount of fuel remaining in the fuel tank after the ignition switch has been turned OFF.

05U0TX-050

# INSTRUMENT CLUSTER

T


## CIRCUIT DIAGRAM



## TROUBLESHOOTING

**Symptom: Speedometer does not operate or indication is incorrect.**

05U0TX-278




9MU0TX-067

**Step 1**

1. Verify that the speedometer cable is connected properly.
2. If the connections are OK, go to Step 2.

**Step 2 — Check speedometer cable**


1. Disconnect the speedometer cable from the instrument cluster and transmission case.
2. Verify that the cable and gear spin easily when turned by hand.
3. If the cable or gear is stiff, replace as necessary.
4. If the speedometer cable and gear are OK, replace the speedometer.





**Symptom: Tachometer does not operate.**


9MU0TX-069



05U0TX-280

**Step 1 — Preparation**

1. Remove the instrument cluster. (Refer to page T-33.)
2. Connect a test tachometer between terminals 1H and 2J of the harness side connector.



9MU0TX-071

**Step 2**


1. Start the engine.
2. Check that the test tachometer indicates engine speed.

Indicates rpm	Action
Yes	Replace tachometer
No	Repair wiring harness (Instrument cluster — Igniter)


**Symptom: Water temperature gauge does not operate.**

05U0TX-466


### Preparation SST




05U0TX-052




05U0TX-456



05U0TX-457



05U0TX-281



05U0TX-282

### Step 1

1. Disconnect the connector from the water thermosensor.
2. Connect the red lead of the **SST** to the connector, and the black lead to a body ground.

3. Set the **SST** to the resistance values shown in the figure.
4. Turn the ignition switch ON, and check that the needle indicates the correct values.

Gauge displays correct	Action
Yes	Replace water thermosensor
No	Go to Step 2

### Caution

- Continue the above checks for at least two minutes each to correctly judge the condition.
- The allowable indication error is twice the width of the needle.

### Step 2

1. Remove the instrument cluster. (Refer to page T-33.)
2. Apply 12V to terminal 2k and ground terminal 2j.
3. Connect the red lead of the **SST** to terminal 2l and the black lead to a ground.
4. Set the **SST** to the resistance values shown in the figure.
5. Verify that the needle indicates the correct values.

Indicates correct	Action
Yes	Repair wiring harness (Instrument cluster — Water thermosensor)
No	Replace water temperature gauge


### Caution

- Continue the above checks for at least two minutes each to correctly judge the condition.
- The allowable indication error is twice the width of the needle.


**Symptom: Fuel gauge does not operate.**

05U0TX-467

**Preparation**  
**SST**

49 0839 285  Checker, fuel and thermometer		For inspection of gauges
--	---	--------------------------


05U0TX-052



05U0TX-283

**Step 1**

1. Disconnect the connector from the fuel tank sender unit.
2. Connect the red lead of the **SST** to terminal-wire (Y) and the black lead to a body ground.




9MU0TX-079

3. Set the **SST** to the resistance values shown in the figure.
4. Turn the ignition switch ON, and verify that the needle indicates the correct values.

Indicates correct	Action
Yes	Replace fuel gauge sender unit (in fuel tank)
No	Go to Step 2

**Caution**

- Continue the above checks for at least two minutes each to correctly judge the condition.
- The allowable indication error is twice the width of the needle.




05U0TX-284

**Step 2**

1. Remove the instrument cluster. (Refer to page T-33.)
2. Apply 12V to terminal 2k and ground terminal 2j.
3. Connect the red lead of the **SST** to terminal 1a and the black lead to a ground.

4. Set the **SST** to the resistance values shown in the figure.
5. Verify that the needle indicates the correct values.

Indicates correct	Action
Yes	Repair wiring harness (Instrument cluster — fuel gauge sender unit)
No	Replace fuel gauge



05U0TX-285

**Caution**

- Continue the above checks for at least two minutes each to correctly judge the condition.
- The allowable indication error is twice the width of the needle.


Symptom: Oil pressure gauge does not operate.

05U0TX-468

Preparation  
SST

49 0839 285		For inspection of gauges
Checker, fuel and thermometer		


05U0TX-052



05U0TX-055

Step 1

1. Disconnect the connector from the oil pressure sensor.
2. Connect the red lead of the **SST** to terminal-wire (Y/R) and the black lead to a body ground.




05U0TX-056

3. Set the **SST** to the resistance values shown in the figure.
4. Turn the ignition switch ON, and verify that the needle indicates the correct values.

Indicates correct	Action
Yes	Replace oil pressure sensor
No	Go to Step 2

Caution


- Continue the above checks for at least two minutes each to correctly judge the condition.
- The allowable indication error is twice the width of the needle.



05U0TX-286

Step 2

1. Remove the instrument cluster. (Refer to page T-33.)
2. Apply 12V to terminal 2k and ground terminal 2j.
3. Connect the red lead of the **SST** to terminal 2b and the black lead to a ground.



05U0TX-057

4. Set the **SST** to the resistance values shown in the figure.
5. Verify that the needle indicates the correct values.


Indicates correct	Action
Yes	Repair wiring harness (Instrument cluster — oil pressure sensor)
No	Replace oil pressure gauge

Caution

- Continue the above checks for at least two minutes each to correctly judge the condition.
- The allowable indication error is twice the width of the needle.

## REMOVAL / INSTALLATION


Remove and install as shown in the figure.



05U0TX-058

## DISASSEMBLY / ASSEMBLY

Disassemble and assemble as shown in the figure.



05U0TX-059

Standard indication (km/h)	Allowable range (km/h)
40	40— 43
80	80— 84
120	120—126

Standard indication (mph)	Allowable range (mph)
30	30—32
50	50—53
80	80—84

05U0TX-060

Standard Indication (rpm)	Allowable range (rpm)
2,000	1,850—2,150
3,000	2,760—3,280
4,000	3,700—4,300
5,000	4,640—5,360


05U0TX-061

### WATER TEMPERATURE GAUGE


#### Inspection

#### Preparation


#### SST



05U0TX-062



05U0TX-063



9MU0TX-089

### SPEEDOMETER

#### Inspection

1. Using a speedometer tester, check the speedometer for allowable indication error, and check the operation of the odometer. Replace if necessary.
2. Check the speedometer for fluctuation and/or abnormal noise.

#### Caution

- If significant fluctuation occurs or the speedometer does not move at all, remove the speedometer cable. If it is normal, replace the speedometer assembly.
- Tire wear and improper inflation will increase speedometer error.

### TACHOMETER

#### Inspection

1. Connect a test tachometer to the engine, and start the engine.
2. Check the tachometer for allowable indication error. Replace if necessary.

#### Caution

- When removing or installing the tachometer, do not drop it or subject it to sharp shocks.

1. Remove the instrument cluster. (Refer to page T-33.)
2. Apply 12V to terminal 2k and ground terminal 2j.
3. Connect the red lead of the **SST** to terminal 2l and the black lead to a ground.


4. Set the **SST** to the resistance values shown in the figure.
5. Turn the ignition switch ON, and verify that the needle indicates the correct values.

#### Caution


- Continue the above checks for at least two minutes each to correctly judge the condition.
- The allowable indication error is twice the width of the needle.

## FUEL GAUGE

Inspection  
Preparation  
SST




05U0TX-064



05U0TX-065

1. Remove the instrument cluster. (Refer to page T-33.)
2. Apply 12V to terminal 2k and ground terminal 2j.
3. Connect the red lead of the **SST** to terminal 1a and the black lead to a ground.



9MU0TX-087


4. Set the **SST** to the resistance values shown in the figure.
5. Verify that the needle indicates the correct values.

### Caution


- Continue the above checks for at least two minutes each to correctly judge the condition.
- The allowable indication error is twice the width of the needle.

## OIL PRESSURE GAUGE

Inspection  
Preparation  
SST




05U0TX-066



05U0TX-065

1. Remove the instrument cluster. (Refer to page T-33.)
2. Apply 12V to terminal 2k and ground terminal 2j.
3. Connect the red lead of the **SST** to terminal 2b and the black lead to a ground.




9MU0TX-087

4. Set the **SST** to the resistance values shown in the figure.
5. Verify that the needle indicates the correct values.

### Caution

- Continue the above checks for at least two minutes each to correctly judge the condition.
- The allowable indication error is twice the width of the needle.




05U0TX-067

### PRINTED CIRCUIT

#### Inspection

1. Remove the instrument cluster. (Refer to page T-33.)
2. Check the printed circuit for damage or oxidization.
3. If necessary, replace the printed circuit.




05U0TX-287

### SPEED SENSOR

#### Inspection

1. Remove the instrument cluster.
2. Check continuity between terminals 2d and 2f while rotating the speedometer cable shaft.
3. If the correct number of pulsations fail to occur during each shaft rotation, replace the speed sensor. (Refer to page T-33.)

**Pulsation: 4/shaft rotation**




05U0TX-069

### WATER THERMOSENSOR

#### Inspection

1. Remove the sensor.
2. Place the sensor and a thermometer in water.
3. Heat the water gradually, and measure the resistance of the sensor with an ohmmeter.
4. If the resistance is not as specified, replace the sensor.

**Resistance: 190—260Ω at 50°C (122°F)**




05U0TX-070

### FUEL GAUGE SENDER UNIT (IN FUEL TANK)

#### Inspection

1. Remove the fuel tank gauge sender unit. (Refer to Section F.)
2. Disconnect the fuel gauge sender unit connector.
3. Check resistance between terminals a and b while slowly moving the unit arm from point F to point E.
4. If not correct, replace the fuel gauge sender unit.





05U0TX-071


## OIL PRESSURE SENSOR

### Inspection

1. Disconnect the oil pressure sensor connector.
2. Measure resistance between the oil pressure sensor and a body ground as shown.

Condition	Resistance
Engine stopped	110—130 $\Omega$
Engine running	13— 55 $\Omega$

3. If not as specified, replace the oil pressure sensor.



05U0TX-072


## SPEEDOMETER CABLE

### Inspection

1. Disconnect the speedometer cable from the instrument cluster and transmission case.
2. Verify that the cable and gear spin easily when turned by hand.
3. If the cable or gear is stiff, replace as necessary.

### WARNING LAMP AND SENDER UNIT

#### STRUCTURAL VIEW



05U0TX-073

- |                           |                                       |                                     |
|---------------------------|---------------------------------------|-------------------------------------|
| 1. Brake warning lamp     | 3. Air bag warning lamp               | 5. Alternator warning lamp          |
| 2. Seat belt warning lamp | 4. Headlight retractor indicator lamp | 6. MIL (Malfunction indicator lamp) |

#### Note

- Refer to the following tables concerning warning lamps information.

Warning indicator lamp	Reference page and Section
Air bag	T-138
Headlight retractor	T-53
Alternator	Section G
MIL (Malfunction indicator lamp)	Section F



### TROUBLESHOOTING


#### Note

- Check the **METER 10A** fuse in the fuse box before troubleshooting. If normal, refer to the following troubleshooting.

#### Brake Warning Lamp

**Symptom: Brake warning lamp remains illuminated.**

05U0TX-288




05U0TX-289

#### Step 1 — Check brake fluid level

Check brake fluid level.

Brake fluid level	Action
Below MIN	Check brake system (Refer to Section P)
Above MIN	Go to Step 2



05U0TX-075

#### Step 2 — Check parking brake switch

1. Disconnect the parking brake switch connector.
2. Check continuity between the terminal of the switch and a body ground.

Lever	Continuity
Pulled one notch	Yes
Released	No


3. If not as specified, adjust or replace the parking brake switch. (Refer to Section P.)
4. If the switch is OK, go to Step 3.

#### Step 3 — Check brake fluid level sensor

1. Check continuity of the sensor.

Brake fluid level	Continuity
Below MIN	Yes
Above MIN	No


2. If not as specified, replace the level sensor.
3. If the sensor is OK, repair the wiring harness.



05U0TX-290

**Symptom: Brake warning lamp does not come on when parking brake on. (Ignition switch ON.)**

9MU0TX-101



05U0TX-291

**Remedy**


1. Disconnect the parking brake switch connector.
2. Check continuity between the terminal of the switch and a body ground.

Lever	Continuity
Pulled one notch	Yes
Released	No

3. If not as specified, adjust or replace the parking brake switch.
4. If the switch is OK, repair the wiring harness.

**Symptom: Brake warning lamp does not come on when brake fluid in reservoir tank below MIN.**

05U0TX-292



05U0TX-293

**Remedy**

1. Disconnect the brake fluid level sensor connector.
2. Check continuity of the brake fluid level sensor.

Brake fluid level	Continuity
Below MIN	Yes
Above MIN	No

3. If not as specified, replace the level sensor.
4. If the sensor is OK, repair the wiring harness.


### Seat Belt Warning Lamp

#### Note

- The seat belt warning lamp is controlled by the timer and buzzer unit.

**Symptom: Seat belt warning lamp remains on six seconds after ignition switch turned ON. (Timer function does not operate.)**

05U0TX-076



05U0TX-077


#### Remedy

1. Disconnect the timer and buzzer unit connector.
2. Turn the ignition switch ON, and verify that the seat belt warning lamp illuminates.

Warning lamp illuminates	Action
No	Replace timer and buzzer unit
Yes	Repair wiring harness (Instrument cluster — timer and buzzer unit)

**Symptom: Seat belt warning lamp does not illuminate when ignition switch first turned ON.**

05U0TX-294




05U0TX-078

#### Step 1

1. Ground terminal J of the timer and buzzer unit connector.
2. Turn the ignition switch ON, and verify that the seat belt warning lamp illuminates.

Warning lamp illuminates	Action
No	Go to Step 2
Yes	Repair wiring harness (Timer and buzzer unit—body ground)




05U0TX-079

#### Step 2

1. Ground terminal D of the timer and buzzer unit connector.
2. Turn the ignition switch ON, and verify that the seat belt warning lamp illuminates.

Warning lamp illuminates	Action
Yes	Replace timer and buzzer unit
No	Check bulb of seat belt warning lamp If bulb is OK, repair wiring harness (Instrument cluster—timer and buzzer unit)



05U0TX-080


**BRAKE FLUID LEVEL SENSOR**

**Inspection**

1. Check continuity of the sensor.

Float level	Continuity
Below MIN	Yes
Above MIN	No

2. If continuity is not as specified, replace the level sensor.



05U0TX-081


**PARKING BRAKE SWITCH**

**Inspection**

1. Disconnect the parking brake switch connector.
2. Check for continuity between the switch connector and a body ground.

Lever	Continuity
Pulled one notch	Yes
Released	No

3. If continuity is not as specified, adjust or replace the parking brake switch.



05U0TX-082

**SEATBELT BUCKLE SWITCH**

**SEAT BELT BUCKLE SWITCH**

**Inspection**

1. Disconnect the seat belt buckle switch connector.
2. Check continuity of the switch.

Seat belt	Continuity
Seat belt buckled	No
Seat belt unbuckled	Yes

3. If continuity is not as specified, replace the buckle switch.

### LIGHTING SYSTEM

#### STRUCTURAL VIEW





05U0TX-083

- |                                  |                                 |
|----------------------------------|---------------------------------|
| 1. Retractable headlight         | 7. License plate light          |
| 2. Headlight retractor motor     | 8. Side marker light            |
| 3. Stoplight                     | 9. Taillight                    |
| 4. High-mount stoplight          | 10. Rear combination light lens |
| 5. Turn and hazard warning light | 11. Interior lamp               |
| 6. Back-up light                 |                                 |



## HEADLIGHTS Circuit Diagram



### Description

The headlight system consists of two halogen headlights mounted on retractable mechanisms, a headlight switch in the combination switch, and a retractor switch between the center ventilation outlets.

When the headlight switch is rotated to the second position, the headlights are activated and the headlight retractor motors lift the headlights. If only the retractor switch is turned ON, the headlights will raise to the upright position, but all lights will be off.

An emergency manual retractor knob is located atop each headlight retractor motor.

### Warning


- When using the manual control knob, the negative battery cable must be disconnected to prevent accidental movement of the headlight and possible injury.

05U0TX-085

### Troubleshooting

**Symptom: Headlights do not operate. (U.S. spec.)**


05U0TX-086



05U0TX-295

### Step 1

1. Check HEAD 30A fuse in the main fuse block.
2. If the fuse is burned, replace it. Check and repair the wiring harness, if necessary.
3. If the fuse is OK, go to Step 2.




05U0TX-087


### Step 2

1. Turn the headlight switch ON.
2. Measure the voltage at the following terminal-wires of the headlight relay connector.


Terminal-wire	Voltage	Action
(W/B)	12V	Go to Step 3
	0V	Next check wire (L/Y)
(L/Y)	12V	Go to Step 6
	0V	Next check wire (R/L)
(R/L: Terminal A)	12V	Next check wire (R/L)
	0V	Repair wire (R/L) (HEAD 30A—Headlight relay)
(R/L: Terminal D)	12V	Replace headlight relay
	0V	Repair wire (R/L) (HEAD 30A—Headlight relay)




05U0TX-088



05U0TX-089



05U0TX-090



05U0TX-091

**Step 3**

1. Turn the headlight switch ON.
2. Measure the voltage at the following terminal-wires of the headlight switch connector.

Wire	Headlight switch	Voltage	Action
(W/B)	—	12V	Next check wire (R/B)
		0V	Repair wire (W/B) (Headlight relay—Headlight switch)
(R/B)	Low beam	12V	Go to Step 4
		0V	Replace headlight switch
(R/W)	High beam	12V	Go to Step 4
		0V	Replace headlight switch

**Step 4**

1. Check the headlight bulbs.
2. If a bulb is burned, replace it.
3. If the bulbs are OK, go to Step 5.

**Step 5**

1. Disconnect the headlight connectors.
2. Turn the headlight switch ON, and measure the voltage at the following terminal-wires as shown.

Headlight	Wire	Headlight switch	Voltage	Remedical Action
Left	(R/B)	Low beam	12V	Repair ground wire (B)
			0V	Repair wire (R/B) (Headlight switch—Headlight)
	(R/W)	High beam	12V	Repair ground wire (B)
			0V	Repair wire (R/W) (Headlight switch—Headlight)
Right	(R/B)	Low beam	12V	Repair ground wire (B)
			0V	Repair wire (R/W) (Headlight switch—Headlight)
	(R/W)	High beam	12V	Repair ground wire (B)
			0V	Repair wire (R/W) (Headlight switch—Headlight)


**Step 6**

1. Turn the headlight switch ON.
2. Measure the voltage at the following terminal-wires of the headlight switch connector (in the combination switch).

Wire	Voltage	Action
(L/Y)	12V	Next check wire (B)
	0V	Repair wire (L/Y) (Headlight relay—Headlight switch)
(B)	12V	Repair ground wire (B)
	0V	Replace headlight switch

### Symptom: Headlights do not operate. (Canada spec.)


05U0TX-092



05U0TX-296

#### Step 1

1. Check HEAD 30A fuse in the main fuse block.
2. If the fuse is burned, replace it. Check and repair the wiring harness, if necessary.
3. If the fuse is OK, go to Step 2.




05U0TX-297

#### Step 2

1. Check the headlight bulbs.
2. If a bulb is burned, replace it.
3. If the bulbs are OK, go to Step 3.


#### Step 3

1. Turn the headlight switch ON.
2. Disconnect the headlight connector, and measure the voltage at the following terminal-wires as shown.




05U0TX-298

Headlight	Wire	Headlight switch	Voltage	Action
Left	(R/W)	High beam	12V	Next, check wire (R/B)
			0V	Go to Step 4
	(R/B)	Low beam	12V	Next, check wire (B)
			0V	Go to Step 4
	(B)	Any position	0V	Next, check right side
			12V	Repair ground wire (B)
Right	(R/W)	High beam	12V	Next, check wire (R/B)
			0V	Go to Step 4
	(R/B)	Low beam	12V	Next, check wire (B)
			0V	Go to Step 4
	(B)	Any position	0V	Check for poor connection of headlight connector
			12V	Go to Step 4



05U0TX-299



05U0TX-300

**Step 4**

1. Reconnect the headlight connector.
2. Remove the column cover.
3. Measure the voltage at the following terminal-wires of the headlight switch connectors (in the combination switch) as shown.

Wire	Headlight switch	Voltage	Action
(R/L)	Any position	12V	Next, check wire (W/R)
		0V	Repair wire (R/L) (HEAD 30A fuse—Headlight switch)
(W/R)	Any position	12V	Next, check wire (R/W)
		0V	Repair wire (W/R) (BTN 40A fuse—Headlight switch)
(R/W)	ON (High beam)	12V	Next, check wire (R/B)
		0V	Go to Step 5
(R/B)	ON (Low beam)	12V	Check for poor connection of headlight switch connector
		0V	Go to Step 5

**Step 5 — Headlight switch inspection**

1. Disconnect the headlight switch connectors.
2. Check for continuity between terminals as shown with an ohmmeter.


Position		Terminal					
		HB	HL	HU	BA	BTN	TNS
Headlight	Low beam	○—○			○	○—○	
	High beam	○		○	○	○—○	
Parking				○—○			
Tail, Parking						○—○	

○—○: Indicates continuity

3. If not as specified, replace the headlight switch.
4. If correct, check for a poor connection in the system.

**Symptom: Headlight does not operate (right or left).**


05U0TX-093



05U0TX-094

**Step 1**

1. Check the headlight bulbs.
2. If a bulb is burned replace it.
3. If the bulbs are OK, go to Step 2.



05U0TX-095

**Step 2**

1. Disconnect the headlight connectors of the faulty side.
2. Turn the headlight switch ON, and measure the voltage at the following terminal-wires as shown.

Headlight	Wire	Headlight switch	Voltage	Action
Left	(R/B)	Low beam	12V	Repair ground wire (B)
			0V	Repair wire (R/B) (Headlight switch—Headlight)
	(R/W)	High beam	12V	Repair ground wire (B)
			0V	Repair wire (R/W) (Headlight switch—Headlight)
Right	(R/B)	Low beam	12V	Repair ground wire (B)
			0V	Repair wire (R/B) (Headlight switch—Headlight)
	(R/W)	High beam	12V	Repair ground wire (B)
			0V	Repair wire (R/W) (Headlight switch—Headlight)


**Symptom: Headlight retractor motors do not operate (both sides).**

**Note**

- Before troubleshooting verify the symptom by activating the headlight switch and retractor switch.
- Check the system using the appropriate troubleshooting below.

Switch	Retractor motor(s) operate	Action
Headlight switch ON	Yes	Begin troubleshooting from Step 5
	No	Next, turn ON retractor switch
Retractor switch ON	Yes	Begin troubleshooting from Step 4
	No	Begin troubleshooting from Step 1


05U0TX-096



05U0TX-097

**Step 1**

1. Check RETRACT 30A and HEAD 30A fuses in the main fuse block.
2. If a fuse is burned, replace it. Check and repair the wire harness, if necessary.
3. If the fuses are OK, go to Step 2.




05U0TX-098

**Step 2**

1. Retract the headlights fully using the manual knobs.
2. Disconnect the retractor motor connectors.
3. Turn on the headlight switch and retractor switch.
4. Measure the voltage at the following terminal-wires of the retractor motor connectors.

Retractor motor	Wire	Voltage	Action
Left and Right	(R/Y)	12V	Go to Step 3
		0V	Go to Step 4




05U0TX-099

**Step 3**

1. Disconnect the retractor motor connectors.
2. Check for continuity between terminal-wire (B) of the retractor motor connectors and a body ground.

Retractor motor	Continuity	Action
Left and Right	No	Repair wire (B)
	Yes	Check retractor motor (Refer to page T-56)



**Step 4**


1. Turn off the retractor switch.
2. Turn on the headlight switch.
3. Measure the voltage at the following terminal-wires of the retractor relay connector.

**U.S. spec.**

Wire	Voltage	Action
(R/G)	12V	Next check wire (W/B)
	0V	Go to Step 5
(W/B)	12V	Next check wire (B)
	0V	Repair wire (W/B) (Headlight relay—Retractor relay)
(B)	12V	Repair ground wire (B)
	0V	Next check wire (R/Y)
(R/Y)	12V	Repair wire (R/Y) (Retractor relay—Retractor motor)
	0V	Replace retractor relay

**Canada spec.**

Wire	Voltage	Action
(R/G)	12V	Next check wire (W/R)
	0V	Go to Step 5
(W/R)	12V	Next check wire (B)
	0V	Repair wire (W/R) (Headlight switch—Retractor relay)
(B)	12V	Repair ground wire (B)
	0V	Next check wire (R/Y)
(R/Y)	12V	Repair wire (R/Y) (Retractor relay—Retractor motor)
	0V	Replace retractor motor



**Step 5**


Measure the voltage at the terminal-wires of the retractor switch.

Wire	Retractor switch	Voltage	Action
(R/L)	Any position	12V	Next check wire (R/G) and (R/Y)
		0V	Repair wire (R/L) (Retract 30A—Retractor switch)
(R/G)	OFF	12V	Repair wire (R/G) (Retractor switch—Retractor motor)
		0V	Replace retractor switch
(R/Y)	ON	12V	Repair wire (R/Y) (Retractor switch—Retractor motor)
		0V	Replace retractor switch




**Symptom: Headlight retractor motor does not operate (one side).**

05U0TX-102



05U0TX-103



05U0TX-104

**Step 1**

1. Retract the not working headlight fully using the manual knob.
2. Disconnect the retractor motor connector of the faulty side.
3. Turn on the headlight switch and retractor switch.
4. Check the voltage at the following terminal-wires of the retractor motor connector.

Wire	Voltage	Action
(R/Y)	12V	Go to Step 2
	0V	Repair wire (R/Y) (Retractor relay—Retractor motor)

**Step 2**

Check for continuity between terminal-wire (B) of the faulty retractor motor connector and a body ground.

Continuity	Action
No	Repair wire (B)
Yes	Check retractor motor (Refer to page T-56)

**Note**

- A retractor indicator lamp is included in the instrument cluster. The indicator lamp illuminates when the retractor motor is operating and should go out when the headlights are fully raised or retracted.

If the indicator lamp remains on, it may be due to pebbles, pieces of ice, etc. lodged between the headlight and the vehicle body. This should be corrected by the following procedure.

1. Turn the ignition switch OFF.

**Caution**


- Obtain the code number and deactivate the audio anti-theft function before disconnecting the battery. (Refer to page T-113.)

2. Disconnect the negative battery cable or remove RETRACTOR 30A fuse in the main fuse block.
3. Raise or lower the headlight by turning the emergency retractor knob.
4. Remove the obstruction.
5. After verifying that the headlight switch and the retractor switch are OFF, reconnect the negative battery cable.
6. Verify operation of the headlight retractor and the retractor indicator lamp.

05U0TX-458

**Removal / Installation**

Remove and install as shown in the figure.




05U0TX-105



- |                      |                    |
|----------------------|--------------------|
| 1. Bezel             | 4. Motor link      |
| 2. Headlight housing | 5. Retractor hinge |
| 3. Headlight         | 6. Retractor motor |

**Caution**


- Do not turn the adjusting screws during removal and installation.




05U0TX-106



05U0TX-107



05U0TX-108



05U0TX-109

**Adjustment**  
**Headlight aiming**

1. Adjust the tire air pressure to specification.
2. Turn on the retractor switch to raise the retractable headlights.
3. Position the unloaded vehicle on a flat, level surface.
4. Adjust the headlights to meet local regulations by turning the two adjusting screws.


**Retractor hinge**

1. Begin with the headlights fully retracted.

**Caution**

- Before disconnecting the negative battery cable, verify the ID code number of audio anti-theft function.
- If not, an audio unit may not operate after reconnecting the negative battery cable.

2. Disconnect the negative battery cable.
3. Disconnect the motor link.
4. Lower the retractor hinge until the hinge is stopped by the stop.
5. Adjust the stop so that the headlight lid is flush with the fender and hood.



05U0TX-110


### Inspection

#### Retractor motor

1. Disconnect the motor link.
2. Disconnect the retractor motor connector.
3. Connect 12V to terminal f and ground terminal a of the motor connector.
4. Check the motor operation when connecting 12V as shown.

Terminal		Motor operation
12V	Ground	
c	a	Motor rotates to raised position
d	a	Motor rotates to retracted position

5. If not as specified, replace the retractor motor.



05U0TX-111


#### Retractor switch

1. Remove the retractor switch.
2. Check for continuity between terminals of the switch.

Switch	Terminal		
	b	d	f
Off	○	○	○
On		○	○

○—○: Indicates continuity

3. If not as specified, replace the retractor switch.



05U0TX-112

#### Headlight switch


##### U.S. spec.

1. Remove the knee protector.
2. Disconnect the combination switch connector.
3. Check for continuity between terminals of the switch.


Position		Terminal					
		E	HL	HU	TNS	HEAD	BA
Headlight	Low beam	○			○		
	High beam	○			○		
Passing				○			○
Tail, Parking		○			○		

○—○: Indicates continuity


4. If not as specified, replace the combination switch as an assembly.




05U0TX-113




05U0TX-114



05U0TX-115



05U0TX-116



05U0TX-117

### Canada spec.

1. Remove the column cover and disconnect the headlight switch connectors.
2. Check for continuity between terminals of the switch.

Position		Terminal					
		HB	HL	HU	BA	BTN	TNS
Headlight	Low beam	○	○	○	○	○	○
	High beam	○	○	○	○	○	○
Passing				○	○		
Tail, Parking						○	○

○—○: Indicates continuity

### Headlight relay (U.S. spec.)

1. Check continuity between terminals 3 and 4.

Terminal	Continuity
3—4	No

2. If not as specified, replace the headlight relay.
3. If correct, go to Step 4.

4. Apply 12V to terminal 1 and ground terminal 2. Check for continuity between terminals 3 and 4.

Terminal	Continuity
3—4	Yes

5. If not as specified, replace the headlight relay.

### Headlight retractor relay

1. Check continuity between terminals of the relay.

Terminal	Continuity
1—4	Yes
2—4	No
3—5	Yes

2. If not as specified, replace the retractor relay.
3. If correct, go to Step 4.


4. Apply 12V to terminal 3 and ground terminal 5. Check continuity between terminals of the relay.

Terminal	Continuity
1—4	No
2—4	Yes


5. If not as specified, replace the retractor relay.

STOPLIGHTS  
Circuit Diagram

[FOR USA]




[FOR CANADA]




## Troubleshooting

**Symptom: Stoplights do not operate (all).**


05U0TX-119




05U0TX-120



05U0TX-121



05U0TX-122



05U0TX-123

### Step 1

Check STOP 15A fuse in the fuse box.

If the fuse is burned, replace it. Check and repair the wire harness, if necessary.

If the fuse is OK, go to Step 2.

### Step 2

Measure the voltage at the following terminal-wires of the stoplight switch connector.

Inspection condition	Wire	Voltage	Action
Constant	(W/G)	12V	Next check wire (G)
		0V	Repair wire (W/G) (STOP 15A fuse—Stoplight switch)
Brake pedal depressed	(G)	12V	Go to Step 3
		0V	Check stoplight switch

### Step 3

Check the stoplight bulbs.

If a bulb is burned replace it.

If the bulbs are OK, go to Step 4.


### Step 4

Measure the voltage at the following terminal-wires of the right and left stoplight connectors.

Inspection condition	Wire	Voltage	Action
Brake pedal depressed	(G)	12V	Next check wire (B)
		0V	Repair wire (G) (Stoplight switch—Stoplight)
	(B)	12V	Repair ground wire (B)
		0V	Check for poor connection of connectors

**Symptom: Stoplights does not operate (one only).**


05U0TX-124



05U0TX-125

**Step 1**

Check the stoplight bulb of the faulty side.  
If a bulb is burned replace it.  
If the bulb is OK, go to Step 2.



05U0TX-126


**Step 2**

Measure the voltage at the following terminal-wires of the faulty stoplight connector.

Inspection condition	Wire	Voltage	Action
Brake pedal depressed	(G)	12V	Next check wire (B)
		0V	Repair wire (G) (Stoplight switch—Stoplight)
	(B)	12V	Repair ground wire (B)
		0V	Check for poor connection of connectors


**Removal / Installation**

Remove and install as shown in the figure.




9MU0TX-158





05U0TX-127



05U0TX-128

**Adjustment  
Stoplight switch**

1. Adjust the brake pedal height. (Refer to Section P.)
2. Disconnect the stoplight switch connector.
3. Loosen the stoplight switch locknut.
4. Turn the stoplight switch until it contacts the pedal arm.  
Turn an additional 1/2 turn.
5. Tighten the locknut.

**Locknut tightening torque:**

**14—18 N·m (1.4—1.8 m·kg, 120—156 in·lb)**

**Inspection  
Stoplight switch**

1. Disconnect the stoplight switch connector.
2. Check continuity between terminals of the switch.

Inspection condition	Terminal	
	a	b
Brake pedal depressed	○ — ○	○ — ○
Brake pedal released		

○ — ○: Indicates continuity


3. If not as specified, replace the stoplight switch.




Troubleshooting

Symptom: Turn and hazard warning lights do not operate (U.S. spec.)

05U0TX-130



05U0TX-301



05U0TX-302

**Step 1**

1. Check HAZARD 15A fuse in the fuse box.
2. If the fuse is burned replace it. Check and repair the wire harness, if necessary.
3. If the fuse is OK, go to Step 2.

**Step 2 — Check turn and hazard warning flasher unit**

1. Remove the turn and hazard warning flasher unit.
2. Check continuity between terminals of the unit with an ohmmeter.

**Note**

- Set the ohmmeter to  $\times 1000\Omega$  range.

Terminal		Continuity	Terminal		Continuity	Terminal		Continuity
+	-		+	-		+	-	
a	-	X	d	-	X	f	-	X
a	-	X	d	-	X	f	-	X
a	-	O	d	-	X	g	-	X
a	-	O	d	-	X	g	-	X
a	-	X	e	-	X	g	-	X
a	-	X	e	-	X	g	-	X
c	-	O	e	-	X	g	-	X
c	-	O	e	-	X	g	-	X
c	-	O	e	-	X	h	-	O
c	-	O	e	-	X	h	-	O
c	-	O	f	-	X	h	-	O
c	-	O	f	-	X	h	-	O
d	-	X	f	-	X	h	-	O
d	-	X	f	-	X	h	-	O

O: Indicates continuity X: No continuity

3. If not as specified, replace the flasher unit.
4. If the flasher unit is OK, reconnect the connector and go to Step 3.


**Step 3**

1. Remove the knee protector, then disconnect the turn signal switch connector.
2. Check continuity between terminals of the switch.


Position	Terminal	FU	TL	TR
Left		O	O	
Right		O		O

O—O: Indicates continuity


3. If not as specified, replace the turn signal switch.
4. If the turn signal switch is OK, reconnect the connector and go to Step 4.




05U0TX-131




05U0TX-303



05U0TX-304



05U0TX-132



05U0TX-305

### Step 4

1. Check the bulbs.
2. If a bulb is burned, replace it.
3. If the bulbs are OK, go to Step 5.

### Step 5

1. Turn the ignition switch ON.
2. Measure the voltage at terminal-wire (B/Y) of the turn signal switch connector.

Wire	Voltage	Action
(B/Y)	12V	Go to Step 6
	0V	Repair wiring harness (HAZARD 15A fuse — Turn signal switch)

### Step 6

Measure the voltage at the terminal-wires of the turn and hazard warning flasher unit connector.


Wire	Condition	Voltage	Action
(B)	Constant	12V	Repair wire harness (Flasher unit — Body ground)
		0V	Next, check wire (G/R)
(G/R)	Turn signal switch right position	12V	Next, check wire (G/Y)
		0V	Repair wire harness (Turn signal switch — Flasher unit)
(G/Y)	Turn signal switch left position	12V	Next, check wire (B/R)
		0V	Repair wire harness (Turn signal switch — Flasher unit)
(B/R)	Constant	12V	Go to Step 7
		0V	Repair wire harness (HAZARD 15A fuse — Flasher unit)

### Step 7


1. Disconnect the turn signal light connectors.
2. Measure the voltage at the terminal-wires of the turn signal light connectors as shown.

Light	Wire	Condition	Voltage	Action
Front RH	(G/W)	Turn signal switch right position	12V	Repair wire harness (Bulb — Body ground)
			0V	Repair wire harness (Flasher unit — Bulb)
Rear RH			12V	Repair wire harness (Bulb — Body ground)
0V			Repair wire harness (Flasher unit — Bulb)	
Front LH	(G/B)	Turn signal switch left position	12V	Repair wire harness (Bulb — Body Ground)
			0V	Repair wire harness (Flasher unit — Bulb)
Rear LH			12V	Repair wire harness (Bulb — Body ground)
			0V	Repair wire harness (Flasher unit — Bulb)







05U0TX-308




05U0TX-309



05U0TX-134



05U0TX-135



**Step 4**

1. Check the bulbs.
2. If a bulb is burned, replace it.
3. If the bulbs are OK, go to Step 5.

**Step 5**

1. Turn the ignition switch ON.
2. Measure the voltage at terminal-wire (B/Y) of the turn signal switch connector.

Wire	Voltage	Action
(B/Y)	12V	Go to Step 6
	0V	Repair wire harness (HAZARD 15A fuse — Turn signal switch)

**Step 6**


Measure the voltage at the terminal-wires of the turn and hazard warning flasher unit connector.

Wire	Condition	Voltage	Action
(B)	Constant	12V	Repair wire harness (Flasher unit — Body ground)
		0V	Next, check wire (G)
(G/R)	Turn signal switch right position	12V	Next, check wire (G/R)
		0V	Repair wire harness (Turn signal switch — Flasher unit)
(G/Y)	Turn signal switch left position	12V	Next, check wire (Y/G)
		0V	Repair wire harness (Turn signal switch — Flasher unit)
(B/R)	Constant	12V	Go to Step 7
		0V	Repair wire harness (HAZARD 15A fuse — Flasher unit)

**Step 7**

Measure the voltage at the terminal-wires of the turn signal light connectors as shown.

Light	Wire	Condition	Voltage	Action
Front RH	(G/Y)	Turn signal switch right position	12V	Repair wire harness (Bulb — Body ground)
			0V	Go to Step 8
Rear RH	(G/W)		12V	Repair wire harness (Bulb — Body ground)
			0V	Repair wire harness (Flasher unit — Bulb)
Front LH	(G/O)	Turn signal switch left position	12V	Repair wire harness (Bulb — Body Ground)
			0V	Go to Step 8
Rear LH	(G/B)		12V	Repair wire harness (Bulb — Body ground)
			0V	Repair wire harness (Flasher unit — Bulb)



05U0TX-136


**Step 8**

Measure the voltage at the terminal-wires of the DRL connector as shown.

Wire	Condition	Voltage	Action
(G/W)	Turn signal switch right position	12V	Next, check wire (G/Y)
		0V	Repair wire (G/W) (Flasher unit—DRL unit)
(G/Y)	Turn signal switch right position	12V	Repair wire (G/Y) (DRL unit—Bulb)
		0V	Check DRL unit (Refer to page T-18)
(G/B)	Turn signal switch left position	12V	Next, check wire (G/O)
		0V	Repair wire (G/O) (Flasher unit—DRL unit)
(G/O)	Turn signal switch left position	12V	Repair wire (G/O) (DRL unit—Bulb)
		0V	Check DRL unit (Refer to page T-18)

**Symptom: Turn signal(s) flashes rapidly.**

9MU0TX-175



9MU0TX-176

**Remedy**


Check the bulbs and the wiring harness between each bulb and the body ground (rapidly flashing side).

**Note**

- **Rapid flashing is a flasher unit function to warn of a bad bulb or an open circuit.**

**Symptom: Hazard warning function does not operate.  
(Turn signals function normally.)**

05U0TX-310



05U0TX-137


**Step 1 — Check hazard warning switch.**

1. Remove the hazard warning switch.
2. Check continuity between terminals of the switch.

Switch	Terminal	
	g	h
ON	○—○	○—○
OFF		

○—○: Indicates continuity

3. If not as specified, replace the right cluster switch assembly.
4. If the cluster switch is OK, go to Step 2.




05U0TX-272

**Step 2**

Measure the voltage at the terminal-wires of the hazard warning switch connector as shown.

Wire	Voltage	Action
(O)	12V	Next, check wire (B)
	0V	Go to Step 3
(B)	12V	Repair wire harness (Hazard warning switch — Body ground)
	0V	Replace turn and hazard flasher unit



05U0TX-138

**Step 3**


Check the voltage at terminal-wire (O) of the turn and hazard flasher unit connector.

Wire	Voltage	Action
(O)	12V	Repair wire harness (Flasher unit — Hazard warning switch)
	0V	Replace turn and hazard flasher unit




**Removal / Installation**


Remove and install as shown in the figure.




05U0TX-139



05U0TX-140



05U0TX-141



05U0TX-142

**Inspection**

**Turn signal switch (U.S. spec.)**

1. Remove the knee protector.
2. Disconnect the combination switch connector.
3. Check continuity between terminals of the switch.

Switch	Terminal		
	FU	TL	TR
Left	○—○	○—○	
Right	○—○		○—○

○—○: Indicates continuity

4. If not as specified, replace the combination switch as an assembly.

**(Canada spec.)**

1. Remove the column cover, then disconnect the turn signal switch connector.
2. Check for continuity between terminals of the switch.

Terminal	Position	FU	TL	TR
		Left	○—○	○—○
Right		○—○		○—○

○—○: Indicates continuity

3. If not as specified, replace the turn signal switch.


**Hazard warning switch**

1. Remove the hazard switch.
2. Check continuity between terminals of the switch.

Switch	Terminal	
	g	h
On	○—○	○—○
Off		

○—○: Indicates continuity

3. If not as specified, replace the hazard switch and retractor switch as an assembly.



05U0TX-143

### Turn and hazard warning flasher unit

1. Check continuity between terminals of the flasher unit.

#### Note

- Set the ohmmeter to  $\times 1000\Omega$  range.

Terminal		Continuity	Terminal		Continuity	Terminal		Continuity
+	-		+	-		+	-	
a	c	X	d	e	X	f	g	X
a	d	X	d	f	X	f	h	X
a	e	○	d	g	X	g	a	X
a	f	○	d	h	X	g	c	X
a	g	X	e	a	X	g	d	X
a	h	X	e	c	X	g	e	X
c	a	○	e	d	X	g	f	X
c	d	○	e	f	X	g	h	X
c	e	○	e	g	X	h	a	○
c	f	○	e	h	X	h	c	○
c	g	○	f	a	X	h	d	○
c	h	○	f	c	X	h	e	○
d	a	X	f	d	X	h	f	○
d	c	X	f	e	X	h	g	○

○: Indicates continuity      X: No continuity


2. If not as specified, replace the flasher unit.



### Troubleshooting

**Symptom: Back-up light(s) does not operate.**

9MU0TX-185




05U0TX-311

#### Step 1

Check METER 10A fuse.

If the fuse is burned, replace it. Check and repair the wire harness, if necessary.

If the fuse is OK, go to Step 2.




05U0TX-313

#### Step 2

Check the back-up light bulbs.

If a bulb is burned, replace it.

If the bulbs are OK, go to Step 3.




05U0TX-313

#### Step 3

1. Turn the ignition switch ON, and shift the transmission to reverse.

2. Measure the voltage at the terminal-wires of the back-up light connectors.

Back-up light	Wire	Voltage	Action
Left	(R/G)	12V	Next, check wire (B)
		0V	Go to Step 4
	(B)	12V	Repair ground wire (B)
Right	(R/G)	12V	Next, check wire (B)
		0V	Go to Step 4
	(B)	12V	Repair ground wire (B)
		0V	Check for poor connection of back-up light connector



05U0TX-145


### Step 4

1. Disconnect the back-up light switch connectors.
2. Check continuity between terminals of the switch with the transmission in reverse.


Continuity	Action
Yes	Repair wire harness (METER 10A fuse — Back-up light switch — Back-up light)
No	Replace switch

### Removal / Installation

Remove and install as shown in the figure.



05U0TX-146



05U0TX-147

### Inspection

#### Back-up light switch


1. Disconnect the back-up light switch connectors.
2. Check continuity between terminals of the switch as shown.

Transmission	Continuity
Reverse	Yes
Others	No

3. If not as specified, replace the switch.

# LIGHTING SYSTEM


## TAILLIGHTS, SIDE MARKER LIGHTS, PARKING LIGHTS AND LICENSE PLATE LIGHTS Circuit Diagram






**Symptom: No lights illuminate (taillights, side marker lights, and license plate lights). (Canada spec.)**

05U0TX-319



05U0TX-320



05U0TX-321

**Step 1**

1. Check 15A and A fuses.
2. If the fuse is burned, replace it. Check and, if necessary, repair the wiring harness.
3. If the fuses are OK, go to Step 2.

**Step 2**

1. Turn the headlight switch ON.
2. Measure the voltage at the following terminal-wires of the combination switch connector.


Wire	Voltage	Action
(W/R)	12V	Next check wire (W/L)
	0V	Repair wire (W/R) (TAIL 15A fuse — combination switch)
(W/L)	12V	Repair the wiring harness (Combination switch — body ground of each light)
	0V	Replace headlight switch



## Removal / Installation


Remove and install as shown in the figures.

### Taillights




05U0TX-149

### Side marker lights




05U0TX-150

### Parking lights




05U0TX-151

### License plate lights



05U0TX-152

DAYTIME RUNNING LIGHTS (DRL) (Canada spec.)  
Circuit Diagram




**Symptom: Daytime running lights (DRL) do not operate. (Turn signals function normally.)**

**DRL operate with engine running and following switches are off:**

- Headlight switch
- Turn signal switch
- Hazard warning switch
- Parking brake switch (Parking brake released)

05U0TX-156



05U0TX-157

**Step 1**

**Warning**

- Position the vehicle on a flat surface and block the wheels to prevent vehicle movement.

1. Turn on the ignition switch.
2. Measure the voltage at the following terminal-wires of the DRL unit.
3. If correct, replace the DRL unit.

Wire	Connected to	Test condition	Specification	Action
(L)	WIPER 20A fuse	Constant	12V	Repair wire (L) (WIPER 20A—DRL unit)
(B)	Ground	Constant	0V	Repair wire (B) (DRL unit—Body ground)
(R)	Parking brake switch	Parking brake released	12V	Go to Step 2
(W/R)	Headlight switch	Headlight switch off	0V	Go to Step 3

05U0TX-158

**Step 2**

1. Disconnect the parking brake switch connector.
2. Check continuity between the terminal of the switch and a body ground.

Parking brake lever	Continuity
Pulled one notch	Yes
Released	No

3. If not as specified, adjust or replace the parking brake switch.
4. If correct, repair wires (R) and (L/Y). (Parking brake switch — DRL unit)


**Step 3**

1. Remove the column cover and disconnect the connectors of the headlight switch.
2. Check continuity between the terminals of the headlight switch connector.


Position	Terminal	
	BTN	TNS
Headlight switch ON	○—○	○—○
Headlight switch OFF		

○—○: Indicates continuity

3. If not as specified, replace the headlight switch.
4. If correct, repair wire (W/R). (Headlight switch — DRL unit)




05U0TX-159



05U0TX-160

**Symptom: Daytime running lights (DRL) function does not cancel.**

05U0TX-161



05U0TX-162

**Step 1**

1. Turn on the ignition switch ON.
2. Verify the symptom by operating the following switches; the DRL should cancel. Go to the specified Step.
  - Headlight switch.
  - Hazard warning switch.
  - Turn signal switch.
  - Parking brake switch (lever pulled one notch).

Symptom: DRL function not canceled when	Next Step
Headlight switch ON	Step 2
Hazard warning switch ON	Step 4
Turn signal switch ON	Step 4
Parking brake switch ON	Step 5

05U0TX-163

**Step 2**

1. Turn on the ignition switch.
2. Turn on the headlight switch.
3. Check the voltage at the terminal-wire (W/R) of the DRL unit connector.

Wire	Voltage
(W/R)	12V

4. If not as specified, go to Step 3.
5. If correct, replace the DRL unit.


**Step 3**

1. Remove the column cover and disconnect the connectors of the headlight switch.
2. Check continuity between the terminals of the headlight switch connector.


Position	Terminal	
	BTN	TNS
Headlight switch ON	○—○	○—○
Headlight switch OFF		

○—○: Indicates continuity


3. If not as specified, replace the headlight switch.
4. If correct repair wire (W/R). (Headlight switch — DRL unit)



05U0TX-164



05U0TX-165




05U0TX-166

**Step 4**

1. Turn on the ignition switch.
2. Turn on the headlight switch.
3. Check the voltage at the following terminal-wires of the DRL unit connector.

Wire	Voltage
(G/B)	Cycles 12V and 0V
(G/W)	Cycles 12V and 0V

4. If not as specified, repair the wire harness.  
(Turn and hazard warning flasher unit — DRL unit)
5. If correct, replace the DRL unit.




05U0TX-167

**Step 5**

1. Turn on the ignition switch.
2. Pull the parking brake lever more than one notch.
3. Check the voltage at terminal-wire (R) of the DRL unit connector.

Wire	Voltage
(R)	0V

4. If not as specified, go to Step 6.
5. If correct, replace the DRL unit.



05U0TX-168

**Step 6**

1. Disconnect the parking brake switch connector.
2. Check continuity between the terminal of the switch and a body ground.

Parking brake lever	Continuity
Pulled one notch	Yes
Released	No


3. If not as specified, adjust or replace the parking brake switch.
4. If correct, repair wires (R) and (L/Y). (Parking brake switch — DRL unit)

**Removal / Installation**


Refer to the following pages:

Item	Reference page
Headlight switch (in combination switch)	T-23
Hazard warning switch	T-25
Turn signal switch (in combination switch)	T-23
Daytime running lights (Front turn signal lights)	T-69


05U0TX-169




05U0TX-322




05U0TX-170



05U0TX-171



05U0TX-172



05U0TX-173

**Inspection**  
**DRL unit**

**Note**

- While performing the following inspection, apply 12V to terminal j and ground terminal i.

1. Apply 12V to terminal c, and measure the voltage at terminals d and k.

Terminal	Voltage
d	12V
k	12V

2. If not as specified, replace the DRL unit.
3. Remove 12V from terminal c.
4. Apply 12V to terminals f and h, and measure the voltage at terminals d and k.

Terminal	Voltage
d	12V
k	12V

5. If not as specified, replace the DRL unit.
6. Remove 12V from terminals f and h.
7. Ground terminal b, and check the voltage at terminals d and k.


Terminal	Voltage
d	12V
k	12V

8. If not as specified, replace the DRL unit.


9. Check for continuity between terminals of the DRL unit.

Terminal	Continuity
d—f	Yes
h—k	Yes


10. If not as specified, replace the DRL unit.




05U0TX-174




76U14X-034



05U0TX-323



86U14X-079



86U14X-080

**REAR COMBINATION LIGHT LENS  
Replacement of Rear Combination Light Lens**

1. Use a hot air blower to soften the "hot melt" (bonding agent) around the lens.

2. Remove the lens from the light housing by pushing the rear of the lens with a hammer handle or round bar.


3. Heat the light housing, and remove the "hot melt" and any fragments of the lens.

**Note**

- The "hot melt" should be reused if possible.
- If the "hot melt" can be reused, the Step 4 is unnecessary.

4. Put **Uni-sealer** (8531 77 739) adhesive in the light housing groove.

5. Fit the new lens onto the light housing. Press the lens firmly so that it will adhere.



76U14X-038

6. Immerse the combination light in water to check for leaks.






### Troubleshooting

**Symptom: Interior lamp(s) do not illuminate.**

05U0TX-176




05U0TX-177

#### Step 1

Verify the trouble symptom by operating the control switch and opening the doors. Go to the specified Step.

Symptom	Go to
Interior lamp(s) do not illuminate when control switches are in any position	Step 2
Interior lamp(s) illuminate when control switches are in ON position, but do not illuminate with door open when switches are in DOOR position	Step 5
Interior lamp(s) illuminate when control switches are in DOOR position, but do not illuminate when switches are in ON position	Step 7


05U0TX-178



05U0TX-179

#### Step 2


1. Check the ROOM 10A fuse.
2. If the fuse is burned, replace it. Check and repair the wire harness if necessary.
3. If the fuse is OK, go to Step 3.



05U0TX-180

### Step 3

1. Check the bulb of each lamp.
2. If a bulb is burned, replace it.
3. If the bulbs are OK, go to Step 4.




05U0TX-181

### Step 4

1. Set the control switches to ON position.
2. Measure the voltage at the following terminal-wires of each interior lamp connector.

Wire	Voltage	Action
(L/R)	12V	Next check wire (B)
	0V	Repair wire (L/R) (ROOM 10A fuse—Interior lamp)
(B)	12V	Repair wire (B) (Interior lamp—Body ground)
	0V	Replace interior lamp assembly




05U0TX-182

### Step 5

1. Open both doors, and set the control switches to DOOR position.
2. Measure the voltage at terminal-wire (R/W) of each interior lamp connector.

Wire	Voltage	Action
(R/W)	12V	Go to Step 6
	0V	Replace interior lamp assembly




05U0TX-183

### Step 6

1. Disconnect the door switch connector, and check continuity of each switch.

Switch	Continuity
Pushed	No
Released	Yes

2. If not as specified, replace the door switch.
3. If the switches are OK, repair wire (R/W). (Interior lamp-Door switch)



05U0TX-184


### Step 7

1. Set the control switches to ON position.
2. Measure the voltage at terminal-wire (B) of the interior lamp connector.

Wire	Voltage	Action
(B)	12V	Repair wire (B) (Interior lamp—Body ground)
	0V	Replace interior lamp assembly

**Symptom: Interior lamp(s) remains illuminated with doors closed.  
(Control switch: DOOR position)**

05U0TX-185




05U0TX-186

**Step 1**

1. Disconnect the door switch connectors, and check continuity of each switch as shown.

Switch	Continuity
Pushed	No
Released	Yes

2. If not as specified, replace the door switch.
3. If the switches are OK go to Step 2.




05U0TX-187

**Step 2**

1. Close both doors.
2. Disconnect the interior lamp connectors, and check continuity between terminal-wire (R/W) and a body ground.

Wire	Continuity	Action
(R/W)-Body ground	Yes	Repair wire (R/W) (Interior lamp—Door switch)
	No	Replace interior lamp assembly



05U0TX-188

**Inspection**

**Door switch**

1. Disconnect the door switch connector, and check continuity of the switch as shown.

Switch	Continuity
Pushed	No
Released	Yes


2. If not as specified, replace the door switch.

## ILLUMINATION LAMPS Circuit Diagram


I-01 METER ILLUMI (I)




I-03 FRONT FOG LIGHTS SWITCH ILLUMI (I)



I-04 HAZARD & RETRACTOR SWITCH ILLUMI (I)



I-05 PANEL LIGHTS CONTROL (I)




I-06 HEATER CONTROL SWITCH ILLUMI (I)






I-07 ASHTRAY ILLUMI (I)



I-08 CRUISE CONTROL MAIN SWITCH ILLUMI (I)




FI-02 FRONT (F) - INSTRUMENT PANEL (I)



### Troubleshooting

**Symptom: Illumination lamp control does not operate.**

05U0TX-325




05U0TX-326

#### Remedy

1. Turn the headlight switch ON.
2. Set the panel lamp control switch to Max. position.
3. Measure the voltage at the following terminal wires of the panel lamp control switch connector.

Wire	Voltage	Action
(B)	0V	Next check wire (R/B)
	Other 0V	Repair wire (B) (Panel lamp control switch — Body ground)
(R/B)	12V	Next check wire (R)
	0V	Repair wire (R/B) (TAIL 15A fuse — Panel lamp control switch)
(R)	0V	Repair wiring harness (Panel lamp control switch — Each lamp)
	Other 0V	Replace panel lamp control switch



05U0TX-327

#### Inspection

##### Panel lamp control switch


1. Remove the panel lamp control switch.
2. Apply 12V to terminal d and ground terminal g.
3. Check that the voltage at terminal a changes linealy when turning the control switch.

Switch	Voltage
Min. position	10V
Max. position	0V

4. If not as specified, replace the panel lamp control switch.

HORN

STRUCTURAL VIEW



1. Horn

2. Horn relay

3. Horn switch

05U0TX-328







## TROUBLESHOOTING

**Symptom: Horn does not sound.**


05U0TX-191




05U0TX-192



05U0TX-193



05U0TX-194



05U0TX-195

### Step 1

1. Check the STOP 15A fuse.
2. If the fuse is burned, replace it. Check and repair the wire harness, if necessary.
3. If the fuse is OK, go to Step 2.

### Step 2

1. Disconnect the horn connector.
2. Apply 12V to the horn, and check if the horn sounds.
3. If the horn sounds, go to Step 3.
4. If the horn does not sound, replace the horn.

### Step 3

1. Remove the knee protector.
2. Ground the terminal wire (G/O) of the horn relay connector.
3. If the horn sounds, go to Step 4.
4. If the horn does not sound, go to Step 6.

### Step 4

#### U.S. spec.

#### Warning

- Before removal of the air bag module, the negative battery cable must be disconnected to prevent accidental deployment.

1. Remove the air bag module. (Refer to page T-150.)
2. Check continuity between the terminal of the horn switch connector and the steering shaft.

Horn switch	Continuity
ON	Yes
OFF	No

3. If not as specified, replace the horn switch and steering wheel as an assembly.
4. If correct, go to Step 5.

#### Warning

- After installing of the air bag module, verify that the air bag system is operating normally by monitoring the air bag warning lamp. (Refer to page T-138.)

## HORN

### Canada spec.

1. Remove the steering shaft.
2. Check continuity between the horn conductor plate and the serration gear part.

Horn switch	Continuity
ON	Yes
OFF	No

3. If not as specified, replace the horn switch and steering wheel as an assembly.
4. If correct, repair wire (G/O) (Horn relay — horn switch).

### Step 5

1. Remove the knee protector.
2. Disconnect the clock spring connector.
3. Check continuity of the clock spring connector as shown in the figure.

Continuity	Action
Yes	Repair wire (G/O) (Horn relay — Clock spring connector)
No	Replace combination switch assembly


### Warning

- After installation of the air bag module, verify that the air bag system is operating normally by monitoring the air bag warning lamp.  
(Refer to page T-138.)


### Step 6

1. Ground the terminal wire (G/O) of the horn relay connector.
2. Measure the voltage at the following terminal wires of the horn relay connector.


Wire	Voltage	Action
Terminal A (G/W)	12V	Next check wire (G/W) of terminal D
	0V	Repair wire (G/W) (STOP 15A fuse — Horn relay)
Terminal D (G/W)	12V	Next check wire (G/R)
	0V	Repair wire (G/W) (STOP 15A fuse — Horn relay)
(G/R)	12V	Repair wire (G/R) (Horn relay — Horn)
	0V	Replace horn relay




05U0TX-196



05U0TX-197




05U0TX-198



05U0TX-203

**REMOVAL / INSTALLATION****Horn**

Remove and install as shown in the figure.




05U0TX-204

**Horn Switch  
U.S. spec.****Warning**

- Before removal of the air bag module, the negative battery cable must be disconnected to prevent accidental deployment of the air bag.

1. Disconnect the negative battery cable.
2. Remove the air bag module, then remove the steering wheel assembly.




05U0TX-205


**Warning**

- When carrying an air bag module, make sure the trim cover is pointed away from your body to prevent injury in the event of an accidental deployment.
- When placing an air bag module on any surface place it with the trim cover upward. This will reduce the motion of the module if it is accidentally deployed.

3. Before installation of the steering wheel reset the clock spring connector as follows:
  - (1) Set the front wheels straight ahead.
  - (2) Turn the clock spring connector clockwise until it stops.
  - (3) Return 2.75 turns.




05U0TX-206



05U0TX-207

- (4) Align the marks (counterclockwise) on the clock spring connector and the outer housing.



05U0TX-208


4. Install the steering wheel and the air bag module.

**Warning**

- After installation of the air bag module, verify that the air bag system is operating normally by monitoring the air bag warning lamp. (Refer to page T-138.)

CRUISE CONTROL SYSTEM

STRUCTURAL VIEW



05U0TX-209

- 1. Cruise control unit
- 2. Actuator
- 3. Actuator cable
- 4. Clutch switch

- 5. Brake switch
- 6. Cruise control main switch
- 7. Cruise control switch



TROUBLESHOOTING

**Symptom: Vehicle speed cannot be set. (Cruise control unit will not hold vehicle speed.)**


**Note**

• Before troubleshooting of the system, verify the following items:


1. Is system being correctly used by customer?
2. Is fuse OK?

Check the fuse. If the fuse is burned, replace it. Check the wire harness for a short circuit.


05U0TX-330



05U0TX-211



05U0TX-212



05U0TX-213

**Step 1**

1. Turn the ignition switch ON.
2. Turn the cruise control main switch ON.
3. Check that the main switch indicator lamp comes ON.
4. If the lamp does not come ON, go to Step 2.
5. If the lamp comes ON, go to Step 3.

**Step 2**

1. Check continuity between terminals of the cruise control main switch.

Position	Terminals					
	a	b	d	f	g	h
Neutral			○—○	○—○	○—○	○—○
Off					○—○	○—○
On	○—○	○—○	○—○	○—○		○—○

○—○: Indicates continuity

2. If not as specified, replace the switch.
3. If the switch is OK, repair the wire harness.  
(METER 10A fuse — Cruise control main switch — Ground)

**Step 3**


1. Measure the voltage at the following terminal-wires of the cruise control unit connector.
2. If all terminal voltage are OK, replace the cruise control unit.

Terminal	Wire color	Connected to	Test condition	Specification	Action
a	(G/Y)	Actuator	Main switch off	0V	Go to Step 8
			Main switch on	9V	
b	(G/B)	Actuator	Main switch off	0V	
			Main switch on	9V	
c	(G/O)	Actuator	Main switch off	0V	
			Main switch on	9V	
e	(R)	Main switch	Main switch off	12V	Repair wire (R)
			Main switch on	0V	(Main switch—Cruise control unit)
f	(Y/B)	Main switch	Main switch off	0V	Repair wire (Y/B)
			Main switch on	12V	(Main switch—Cruise control unit)

(cont'd)

Terminal	Wire color	Connected to	Test condition	Specification	Action
h	(Y)	Brake switch	Brake pedal depressed	0V	Go to Step 4
			Brake pedal released	9V	
j	(BR/W)	Clutch switch	Clutch pedal depressed	0V	Go to Step 5
			Clutch pedal released	12V	
l	(R/L)	Cruise control switch (Set switch and coast switch)	Main switch ON	12V	Go to Step 6
			While pushing set switch after main switch ON	0V	
m	(G)	Stoplight switch	Brake pedal depressed	12V	Go to Step 7
			Brake pedal released	0V	
n	(R/W)	Cruise control switch (Resume switch and accel switch)	Main switch ON	12V	Go to Step 6
			While pushing resume switch after main switch ON	0V	
o	(P)	Actuator	Main switch OFF	0V	Go to Step 8
			Main switch ON	9V	
p	(G/R)	Speed sensor	While rotating rear tires	Run out between 0—5V	Go to Step 9
s	(W/G)	Battery	Constant	12V	Repair wire (W/G)

05U0TX-214



05U0TX-215


### Step 4 — Inspection of brake switch

1. Disconnect the brake switch connector.
2. Check continuity between terminals of the switch.

Pedal position	Terminal	
	a	b
Pedal released	○	○
Pedal depressed	○—○	○—○

○—○: Indicates continuity

3. If not as specified, replace the brake switch.
4. If the switch is OK, repair the wire harness. (Fuse — Brake switch — Control unit)



05U0TX-331


### Step 5 — Inspection of clutch switch

1. Disconnect the clutch switch connector.
2. Check continuity between terminals of the switch.

Pedal position	Terminal	
	a	b
Pedal released		
Pedal depressed	○—○	○—○

○—○: Indicates continuity

3. If not as specified, replace the clutch switch.
4. If the switch is OK, repair the wire harness (Fuse — Clutch switch — Control unit)



05U0TX-216

### Step 6 — Inspection of cruise control switch


1. Remove the knee protector and disconnect the combination switch connector.
2. Check continuity between terminals of the combination switch connector.

Switch	Terminal		
	SE	RE	E
SET/COAST	○	○	○
RESUME/ACCEL	○—○	○—○	○—○

○—○: Indicates continuity

3. If not as specified, replace the cruise control switch.
4. If the switch is OK, repair the wire harness. (Cruise control switch — Control unit)





05U0TX-217


**Step 7 — Inspection of stoplight switch**

1. Disconnect the stoplight switch.
2. Check continuity between terminals of the switch.

Pedal position	Terminal	
	a	b
Pedal released		
Pedal depressed	○—○	○—○

○—○: Indicates continuity

3. If not as specified, replace the stoplight switch.
4. If the switch is OK, repair the wire harness. (Cruise control unit — Stoplight switch)




05U0TX-218

**Step 8 — Inspection of actuator**

1. Measure the actuator solenoid resistance using an ohmmeter.

Check terminals	Resistance
c — a	Approx. 25 to 55Ω
c — b	
c — d	

2. If not as specified, replace the actuator.
3. If continuity is OK, go to Step 8—4.
4. Disconnect the actuator cable from the accelerator pedal.
5. Run the engine at idle speed.




05U0TX-332

6. Apply 12V to the following terminals, and check actuator operation.

Order	Terminal condition				Operation of control cable
	a	b	c	d	
1	Ground	Ground	Power	Ground	Pull
2	Ground	—	Power	Ground	Hold
3	Ground	—	Power	—	Extend
4	—	—	—	—	Release

7. If not as specified, replace the actuator.



05U0TX-219


**Step 9 — Inspection of speed sensor**

1. Remove the instrument cluster.
2. Check continuity between terminals 2D and 2F while rotating the speedometer cable.
3. If there are not four pulses per shaft rotation, replace the speed sensor. (Refer to page T-33.)
4. If there are four pulses per rotation, check the wire harness (Instrument cluster — Control unit).
5. If the wiring is OK, replace the cruise control unit.

**INSPECTION OF CRUISE CONTROL SYSTEM USING SELF-DIAGNOSTIC FUNCTION**

Inspection of the cruise control system may also be done by using the self-diagnostic function integrated in the control unit and using a test light.

05U0TX-220




05U0TX-221

**Preparation**


1. Disconnect the cruise control unit connector.
2. Connect a test light between terminals d and s of the cruise control unit connector as shown.
3. Reconnect the cruise control unit connector.

**Inspection**

1. Turn the ignition switch ON.
2. Turn the cruise main switch ON.




05U0TX-222



05U0TX-223

3. Turn the cruise control switch to RESUME and hold it more than 3 seconds.
4. Release the switch.
5. The self-diagnostic function is now activated.



05U0TX-224

6. Read out and record the condition and operation code number(s) of the test light. (Refer to page T-104.)
7. Turn the main switch OFF to deactivate the self-diagnostic function. (The self-diagnostic function will also be canceled if the vehicle is driven at over 16 km/h (10mph)).
8. Check the system as per the results of the self-diagnostic test.


## Principle of code cycle

Condition and operation codes are determined by flashing of the CRUISE indicator as shown below.

05U0TX-225

### 1. Code cycle break


The time between condition/operation code cycles is 4.0 seconds (the time the lamp is off).



97U0TX-188

### 2. Second digit of condition/operation code (ones position)

The digit in the ones position of the condition/operation code represents the number of times the lamp is on 0.4 second during one cycle.




97U0TX-189

### 3. First digit of condition/operation code (tens position)

The digit in the tens position of the condition/operation code represents the number of times the lamp is on 1.2 seconds during one cycle.











The lamp remains off for 1.6 seconds between the long and short flashes.



97U0TX-190

### Condition/operation code numbers


The test light will flash if a malfunction is present.

Pattern of output signal (CRUISE indicator lamp)	Code No.	Possible Cause	Action
ON  OFF 	01	Defective wiring or ground Defective actuator Defective brake switch	Repair harness Inspect actuator (See below)
ON  OFF 	05	STOP 15A fuse blown	Replace fuse
ON  OFF 	07	Both stoplight switch and brake switch (for vehicle and cruise) are ON simultaneously	Inspect stoplight switch and brake switch (Refer to pages T-61 and T-107)
ON  OFF 	11	Defective cruise control switch	Inspect cruise control switch (Refer to page T-107)
ON  OFF 	15	Defective cruise control unit	Go to troubleshooting (Refer to page T-99)

05U0TX-226

#### Note

- If there is more than one malfunction, the code numbers will be indicated in numerical order lowest number first.



05U0TX-227

### ACTUATOR Inspection

- Measure the actuator solenoid resistance using an ohmmeter.

Check terminals	Resistance
c — a	Approx. 25 to 55Ω
c — b	
c — d	

- If not as specified, replace the actuator.
- Disconnect the actuator cable from the accelerator pedal.
- Run the engine at idle speed.
- Apply battery voltage to the following terminals, and check the actuator operation.

Order	Terminal condition				Operation of control cable
	a	b	c	d	
1	Ground	Ground	Power	Ground	Pull
2	Ground	—	Power	Ground	Hold
3	Ground	—	Power	—	Extend
4	—	—	—	—	Release


- If not as specified, replace the actuator.

### Removal


- Disconnect the accelerator cable and vacuum hose from the actuator.
- Remove the bolt and nuts and the actuator.

### Installation


Install in the reverse order of removal.



05U0TX-459



9MU0TX-262



9MU0TX-268


## CRUISE CONTROL UNIT

### Removal

1. Remove the passenger side kick panel.
2. Remove the nut and the control unit.

### Installation

Install in the reverse order of removal.




05U0TX-333

### Inspection

1. Check the terminal voltages of the control unit.
2. If the terminal voltages are correct, replace the control unit.

Terminal	Wire color	Connected to	Test condition	Specification	Action
a	(G/Y)	Actuator	Main switch OFF	0V	Check actuator (Refer to page T-104)
			Main switch ON	9V	
b	(G/B)	Actuator	Main switch OFF	0V	
			Main switch ON	9V	
c	(G/O)	Actuator	Main switch OFF	0V	
			Main switch ON	9V	
e	(R)	Main switch	Main switch OFF	12V	Check main switch (Refer to page T-107)
			Main switch ON	0V	
f	(Y/B)	Main switch	Main switch OFF	0V	
			Main switch ON	12V	
h	(Y)	Brake switch	Brake pedal depressed	0V	Check brake switch (Refer to page T-107)
			Brake pedal released	9V	
j	(BR/W)	Clutch switch	Clutch pedal depressed	0V	Check clutch switch (Refer to page T-106)
			Clutch pedal released	12V	
l	(R/L)	Cruise control switch (Set switch and Coast switch)	Main switch ON	12V	Check cruise control switch (Refer to page T-107)
			While pushing set switch Main switch ON	0V	
m	(G)	Stoplight switch	Brake pedal depressed	12V	Check stoplight switch (Refer to page T-61)
			Brake pedal released	0V	
n	(R/W)	Cruise control switch (Resume switch and Accel switch)	Main switch ON	12V	Check cruise control switch (Refer to page T-107)
			While pushing resume switch Main switch ON	0V	
o	(P)	Actuator	Main switch OFF	0V	Check actuator (Refer to page T-104)
			Main switch ON	9V	
p	(G/R)	Speed sensor	While rotating rear tires	Cycles 0-5V	Check speed sensor (Refer to page T-107)
s	(W/G)	Battery	Constant	12V	Repair wire

05U0TX-228



9MU0TX-263

**ACTUATOR CABLE**


**Removal**

1. Disconnect the actuator cable from the accelerator pedal.
2. Remove the clamp at the inside of the firewall.

3. Disconnect the actuator cable from the actuator.
4. Remove the clamps and the actuator cable.

**Installation**

Install in the reverse order of removal.




9MU0TX-264

**Adjustment**

Remove the clamp and adjust the nut so that actuator cable free play is as shown when the cable is pressed lightly.

**Cable play: 1—3mm (0.04—0.12 in)**



9MU0TX-265

**CLUTCH SWITCH**

**Removal**

Loosen the locknut and remove the switch.

**Installation**


Install in the reverse order of removal.

**Adjustment**

Adjust the switch to set the specified pedal height.

**Pedal height: 175—185mm (6.89—7.82 in)**

**Pedal freeplay: 0.6—3.1mm (0.02—0.12 in)**



05U0TX-460


**Inspection**

1. Disconnect the clutch switch connector.
2. Check continuity between terminals of the switch.


Pedal position	Terminal	
	a	b
Pedal released		
Pedal depressed	○—○	○—○

○—○: Indicates continuity


3. If not as specified, replace the clutch switch.




05U0TX-229




05U0TX-461




05U0TX-230



05U0TX-231



05U0TX-232



05U0TX-233

**BRAKE SWITCH**

**Removal**

Loosen the locknut and remove the switch.

**Installation**

Install in the reverse order of removal.

**Adjustment**

Adjust the switch to set the specified pedal height.

**Pedal height: 171—181mm (6.93—7.13 in)**

**Pedal free play: 4—7mm (0.16—0.28 in)**

**Inspection**

1. Disconnect the brake switch connector.
2. Check continuity between terminals of the switch.

Pedal position	Terminal	
	a	b
Pedal released	○	○
Pedal depressed		

○—○: Indicates continuity

3. If not as specified, replace the brake switch.
4. If the switch is OK, repair the wire harness (Fuse — Brake switch — Control unit).

**CRUISE CONTROL MAIN SWITCH**

**Inspection**

1. Check continuity between terminals of the cruise control main switch.

Position	Terminal					
	a	b	d	f	g	h
Neutral			○	○	○	○
Off					○	○
On	○		○	○	○	○

○—○: Indicates continuity

2. If not as specified, replace the cruise control main switch.

**CRUISE CONTROL SWITCH**

**Inspection**

1. Remove the knee protector and disconnect the combination switch connector.
2. Check continuity between terminals of the combination switch connector.

Switch	Terminal		
	SE	RE	E
SET/COAST	○		○
RESUME/ACCEL		○	○

○—○: Indicates continuity

3. If not as specified, replace the cruise control switch.


**SPEED SENSOR**

**Inspection**

1. Remove the instrument cluster.
2. Check continuity between terminals 1L and 2A while rotating the speedometer cable.
3. If there are not four pulses per shaft rotation, replace the speed sensor. (Refer to page T-33.)

### AUDIO

#### STRUCTURAL VIEW




- 1. Audio unit
- 2. Door speakers

- 3. Headrest speakers

05U0TX-234



## SYSTEM DIAGRAM



05U0TX-235

## FEATURES

This new audio system was developed especially for the Mazda MX-5 Miata. The main features are described below.

## 1. Anti-theft System

To deter theft of the audio unit, the system is designed to accept a code number that makes the audio unit inoperable if it is removed from the vehicle and then reconnected without inputting the correct code number.

When the anti-theft system is activated, the unit will not operate and code will flash on the display until the correct code is input.

## Caution

- If the vehicle's battery is disconnected, the anti-theft system is activated.
- Three consecutive errors in inputting a code number to a unit that has had the anti-theft system activated will render the unit completely inoperable. It must then be replaced.

## 2. Headrest Speaker

Headrest speakers are available.

## 3. Preset Memory

A total of 18 broadcasting stations on AM, FM1, and FM2 bands can be quickly and easily set.

## 4. Automatic Memory

By using the automatic memory function, which is independent from the preset memory, station selections can be easily made in an area where the broadcasting station frequencies are not known.

## 5. Clock

The clock display is incorporated within the audio display.

## 6. Metal Tape Automatic Detection


The tape player automatically detects the use of metal tape and automatically makes internal adjustments for metal tape playback. The word "METAL" is shown on the display.

## 7. Illumination Lamps


The unit's illumination can be switched ON or OFF as desired.

FUNCTION AND OPERATING PROCEDURE

RADIO AND CASSETTE TAPE PLAYER



COMPACT DISC (CD) PLAYER



**Note**

- Five seconds after completing an operation that is shown on the display, the indicator returns to clock mode.

**Radio**

Function	Operation and procedure	Display
To turn radio ON or OFF	<ul style="list-style-type: none"> <li>• Press VOLUME to turn ON</li> <li>• Press VOLUME again to turn OFF</li> </ul>	AM, FM1, or FM2 and frequency will be displayed
To adjust volume	<ul style="list-style-type: none"> <li>• Turn VOLUME to adjust</li> </ul>	
Treble control	<ul style="list-style-type: none"> <li>• Pull BASS/TREBLE</li> <li>• For more highs, turn BASS/TREBLE clockwise</li> <li>• For less highs, turn BASS/TREBLE counterclockwise</li> </ul>	
Bass control	<ul style="list-style-type: none"> <li>• Press BASS/TREBLE</li> <li>• For more lows, turn BASS/TREBLE clockwise</li> <li>• For less lows, turn BASS/TREBLE counterclockwise</li> </ul>	
Balance control	<ul style="list-style-type: none"> <li>• To shift sound to left, turn BALANCE clockwise</li> <li>• To shift sound to right, turn BALANCE counterclockwise</li> </ul>	
Headrest speaker control	<ul style="list-style-type: none"> <li>• To increase volume, turn H.R.SP clockwise</li> </ul>	
Band selector	<ul style="list-style-type: none"> <li>• To chose either AM or FM, press AM/FM (Pressing AM/FM alternates AM, FM1 and FM2)</li> </ul>	AM, FM1 or FM2 and frequency will be displayed
Manual tuning	<ul style="list-style-type: none"> <li>• To manually tune station, press Δ for higher frequency and press ∇ for lower frequency</li> </ul>	
Seek tuning	<ul style="list-style-type: none"> <li>• To seek tune station, press Δ or ∇ for more than one second</li> </ul>	
Scan tuning	<ul style="list-style-type: none"> <li>• Press SCAN to automatically sample strong stations (Scanning stops at each station for about five seconds)</li> <li>• To hold station, press SCAN again during five second interval</li> </ul>	
Channel preset tuning	To set frequency <ul style="list-style-type: none"> <li>• To select band, press AM/FM</li> <li>• To set station, press one channel number, and hold it until beep is heard</li> </ul> To tune preset channel <ul style="list-style-type: none"> <li>• Press desired channel preset button</li> </ul>	
Auto memory tuning	To set frequency <ul style="list-style-type: none"> <li>• Press and hold AUTO M for about two seconds</li> </ul> To tune automemory station <ul style="list-style-type: none"> <li>• Press and release AUTO M</li> </ul>	

05U0TX-237

**Cassette Tape Player**

Function	Operation and procedure	Display
Playing/Stopping tape	<ul style="list-style-type: none"> <li>• Insert cassette tape through cassette slot, open-edge to right (System automatically switches to tape operation)</li> <li>• At end of tape, system will automatically reverse tape play</li> <li>• To stop tape play during playback without ejecting it, press STOP/EJECT (Tape will be in pause mode)</li> <li>• To restart tape play, press STOP/EJECT again</li> <li>• To play tape directly from radio/compact disc mode, press PLAY/PRO (while tape is inserted)</li> </ul>	
Ejecting tape/Fast forward/ Rewind	<ul style="list-style-type: none"> <li>• To eject tape, press STOP/EJECT</li> <li>• To fast forward tape, push FF; to stop it, press STOP/EJECT or PLAY/PRO</li> <li>• To rewind tape, press REW; to stop it, press STOP/EJECT or PLAY/PRO</li> </ul>	
APC (Automatic program control)	<ul style="list-style-type: none"> <li>• To search for beginning of present or next program, press APC then FF (for next program) or REW (for present)</li> </ul>	

## Cassette Tape Player (cont'd)

Function	Operation and procedure	Display
Tape direction change	<ul style="list-style-type: none"> <li>To change tape-playing direction, press PLAY/PRO</li> </ul>	
Dolby B noise reduction	<ul style="list-style-type: none"> <li>Press when using tape encoded with Dolby NR</li> </ul>	

05U0TX-238

## Compact Disc (CD) Player

**Caution**

- The CD player cannot play 8 cm (3.1 in) CDs. The smaller CD may dislodge from the adapter and damage the disc or the player. Use only standard 12 cm (4.7 in) CDs.

Function	Operation and procedure	Display
Disc insert	<ul style="list-style-type: none"> <li>Push disc, label-side up, into slot. Auto-loading mechanism will take over to set disc and begin play</li> </ul> <p><b>Note</b> There will be short lapse of time between time disc is set and play begins. This is because period of time is necessary for disc player to read digital signal on disc. When CD is pressed while disc is being played, play will pause. Play will resume when CD is pressed again</p>	
Stopping/Playing CD	<ul style="list-style-type: none"> <li>To stop CD play during playback without ejecting it, press PLAY/STOP (CD will be in pause mode)</li> <li>To start playing CD again, press PLAY/STOP again</li> <li>To play loaded CD directly from radio or tape mode, press PLAY/STOP</li> </ul>	
Ejecting/Reloading CD	<ul style="list-style-type: none"> <li>To eject CD, press EJECT/RELOAD</li> <li>To reload ejected CD, press EJECT/RELOAD again</li> </ul>	
Fast forward/reverse	<ul style="list-style-type: none"> <li>To fast forward program, press FF</li> <li>To reverse program, press REW</li> </ul>	
Repeat play	<ul style="list-style-type: none"> <li>To listen to program repeatedly, press RPT during play of selection to be repeated</li> </ul>	
Music scan	<ul style="list-style-type: none"> <li>To scan play, press SCAN</li> <li>To cancel scan play, press SCAN again</li> </ul>	
Track search	<ul style="list-style-type: none"> <li>To search program tracks, press <math>\wedge</math> (for forward) or <math>\vee</math> (for reverse)</li> </ul>	

05U0TX-239

## Clock

**Note**

- The clock can be set while radio or tape/CD player is ON.


Function	Operation and procedure
Time display	Time is normally displayed. Pushing CLOCK will automatically display current radio frequency or mode for approx. five seconds before reverting to time mode.
Setting clock	<p>To adjust time, press CLOCK for approx. two seconds, current time will flash</p> <p>To advance hours, press <math>\Delta</math>, to advance minutes, press <math>\nabla</math></p> <p><b>Note</b> If time is not adjusted while clock's current time is flashing (if neither <math>\Delta</math> nor <math>\nabla</math> is pressed) and CLOCK is pressed second time, minutes will be set to 00. If clock's current time setting is within latter part of hour (from 30 to 59 min) hour setting will automatically advance one hour.</p> <p>To resume normal display, press CLOCK again</p>

05U0TX-240


## Anti-theft System

### Note


- The anti-theft system is activated if the electrical power source is ever disconnected from the audio unit. When the system is activated, the audio unit will not operate when reconnected to a power supply, and CODE will flash on the display unit the correct code number is input. If the anti-theft system is activated, reset the unit as described; refer to "If anti-theft system is activated".
- The anti-theft system is activated in the following conditions;
  1. Negative battery cable is disconnected.
  2. Battery is discharged.
  3. Audio unit connectors are disconnected.




05U0TX-242



05U0TX-243



05U0TX-244



05U0TX-245

### Setting procedure

1. Turn the audio unit off with the ignition switch ACC.
2. Push REW and FF simultaneously for approximately 2 seconds until CODE is on the display.

05U0TX-241

3. Again push REW and FF while CODE is displayed (within 10 seconds). The display will exhibit bars.

### Note

- Record the personal code number before attempting to input it.

4. While the bars are displayed, input the personal code number by pressing preset channel buttons 1, 2, 3 and 4. Press 1 for the first digit, 2 for the second, 3 for the third, and 4 for the last digit.


ex. Setting 2547

Press 1 three times, 2 six times. 3 five times and 4 eight times.


### Note

- If the display returns to time while inputting, begin from the Step 1.


5. With the code number is displayed, press REW and FF approximately 2 seconds until a beep is heard and CODE begin to flash.
6. After approximately 5 seconds, the display will change to time. This indicates the system is set.




05U0TX-334




05U0TX-335



05U0TX-246



05U0TX-247



05U0TX-248

### Canceling code number

1. Begin with the audio unit off and the ignition switch in ACC position (time displayed).
2. Press REW and FF simultaneously for approximately 2 seconds until CODE is displayed and flashes.
3. Again press REW and FF while CODE is flashing (within 10 seconds). The display will exhibit bars.
4. While the bars are displayed, input the current code number as described in setting procedure Step 4. (2547, for example).
5. With the code number on the display, press REW and FF for approximately 2 seconds until a beep is heard and CODE appears. After 5 seconds, CODE will disappear and the clock mode will appear. This indicates the code number is canceled.

#### Note

- If Err appears on the display, begin from Step 1.

### If anti-theft system is activated

#### Note

- If the anti-theft system is activated, CODE appear on the display until previous code number is inputted.

### To deactivate anti-theft system

1. Push REW and FF until bars are displayed.
2. While bars are displayed, input the code number as described in setting procedure.
3. Push REW and FF approximately 2 seconds until a beep is heard CODE is and displayed. CODE will flash for 5 seconds then disappears to indicate that the system is operable.
4. If Err (error) appears, try again from Step 1.

#### Note

- Three consecutive error will activate the anti-theft system, and the audio unit will be completely inoperable.
- Have the audio unit changed at listed panasonic service Co.


TROUBLESHOOTING

**Symptom: Speaker(s) do not operate.  
(Without headrest speakers.)**


**Note**

- Before troubleshooting, verify that the customer is using the audio system correctly. If not, advise or instruct in him/her the proper operating procedure. (Refer to page T-110.)


05U0TX-249




05U0TX-250



05U0TX-251



05U0TX-252



05U0TX-253

**Step 1**

Check if the anti-theft system has been activated. Turn the ignition switch to ACC and note the display.

Display	Action
CODE flashes	Deactive anti-theft system (Refer to page T-114.) <b>Note</b> If CODE appears when ignition switch is turned to ACC from OFF go to Step 2.
Err flashes	Have audio unit changed at a Panasonic service company
Clock	Go to Step 4
No indication	Go to Step 2

**Step 2**

1. Remove the audio unit. (Refer to page T-126.)
2. Check the connections of the ground wire and the short plug.
3. If a connection is poor or loose, repair or replace it.
4. If the connections are OK, go to Step 3.

**Step 3**

1. Turn the ignition switch to ACC.
2. Measure the voltage at the following terminal-wires of the audio unit connector.

Wire	Voltage	Action
(L/B)	12V	Next, check wire (L/R)
	0V	Check CIGAR 15A fuse If CIGAR 15A fuse OK, repair wiring harness (CIGAR 15A fuse — Audio unit)
(L/R)	12V	Replace audio unit
	0V	Check ROOM 10A fuse If ROOM 10A fuse OK, repair wiring harness (ROOM 10A fuse — Audio unit)


**Step 4**

- Locate the faulty speaker(s) by using the balance control.
1. Turn the ignition switch to ACC.
  2. Play a prerecorded tape, and set the volume to the center position.
  3. Set the balance control as shown in Table 1 (page T-116). Check operation of each speaker.
  4. From results of Table 1 testing, go to the next step.

Table 1

Speaker	Balance	Speaker operates	Judgement	Next Step
Left door	Left	Yes	Left door speaker circuit OK	—
		No	Left door speaker circuit faulty	Step 5
Right door	Right	Yes	Right door speaker circuit OK	—
		No	Right door speaker circuit faulty	Step 5


05U0TX-254



05U0TX-255

**Step 5**

1. Remove the faulty door speaker cover and speaker installation screws.
2. Check if the speaker is properly connected.
3. If necessary, repair or reconnect the connector.
4. If the connection is OK, go to Step 6.




05U0TX-256

**Step 6**

1. Disconnect the connector from the suspected faulty speaker.
2. Measure resistance between terminals of the speaker.

**Resistance: 4Ω**

3. If not as specified, replace the speaker.
4. If the resistance is OK, go to Step 7.



05U0TX-257

**Step 7**

1. Disconnect the 12-pin connector of the audio unit.
2. Disconnect both door speakers.
3. Check for continuity of the following wires of the door speakers wire harness.

Connectors	Wire	Continuity
Audio unit — Left door speaker	(R/W)	Yes
	(R/G)	Yes
Audio unit — Right door speaker	(L)	Yes
	(L/Y)	Yes

4. If not as specified, repair the faulty wiring.
5. If the wiring is OK, replace the audio unit.




**Symptom: Speaker(s) do not operate  
(With headrest speakers.)**


**Note**

- Before troubleshooting, verify that the customer is using the audio system correctly. If not, advise or instruct him/her in the proper operating procedure. (Refer to page T-110.)


05U0TX-258




05U0TX-250



05U0TX-251



05U0TX-252



05U0TX-259

**Step 1**

Check if the anti-theft system has been activated. Turn the ignition switch to ACC and note the display.

Display	Action
CODE flashes	Deactive anti-theft system (Refer to page T-114.) <b>Note</b> <b>If CODE appears when ignition switch is turned to ACC from OFF go to Step 2.</b>
Err flashes	Have audio unit changed at a Panasonic service company
Clock	Go to Step 4
No indication	Go to Step 2

**Step 2**

1. Remove the audio unit. (Refer to page T-126.)
2. Check the connections of the ground wire and the short plug.
3. If a connection is poor or loose, repair or replace it.
4. If the connections are OK, go to Step 3.

**Step 3**

1. Turn the ignition switch to ACC.
2. Measure the voltage at the following terminal-wires of the audio unit connector.

Wire	Voltage	Action
(L/B)	12V	Next, check wire (L/R)
	0V	Check CIGAR 15A fuse If CIGAR 15A fuse OK, repair wiring harness (CIGAR 15A fuse — Audio unit)
(L/R)	12V	Replace audio unit
	0V	Check ROOM 10A fuse If ROOM 10A fuse OK, repair wiring harness (ROOM 10A fuse — Audio unit)

**Step 4**


Locate the faulty speaker(s) by using the headrest speaker volume, and balance control.

1. Turn the ignition switch to ACC.
2. Play a prerecorded tape, and set the volume to the center position.
3. Set the head restraint speaker volume, and balance controls as shown in Table 2 (page T-118). Check operation of each speaker.
4. From results of Table 2 testing, go to the next step.

**Table 2**

Speaker	Balance	Head restraint speaker volume	Speaker operates	Judgement	Next Step
Left door	Left	Min	Yes	Left door speaker circuit OK	—
			No	Left door speaker circuit faulty	Step 5
Right door	Right	Min	Yes	Right door speaker circuit OK	—
			No	Right door speaker circuit faulty	Step 5
Left headrest (Driver seat)	—	Max	Yes	Left headrest speaker circuit (driver seat) OK	—
			No	Left headrest speaker circuit (driver seat) faulty	Step 8
Right headrest (Driver seat)	—	Max	Yes	Right headrest speaker circuit (driver seat) OK	—
			No	Right headrest speaker circuit (driver seat) faulty	Step 8
Left headrest (Passenger seat)	—	Max	Yes	Left headrest speaker circuit (passenger seat) OK	—
			No	Left headrest speaker circuit (passenger seat) faulty	Step 8
Right headrest (Passenger seat)	—	Max	Yes	Right headrest speaker circuit (passenger seat) OK	—
			No	Right headrest speaker circuit (passenger seat) faulty	Step 8


05U0TX-260



05U0TX-261

### Step 5

1. Remove the faulty door speaker cover and speaker installation screws.
2. Check if the speaker is properly connected.
3. If necessary, repair or reconnect the connector
4. If the connection is OK, go to Step 6.



05U0TX-256

### Step 6

1. Disconnect the connector from the suspected faulty speaker.
2. Measure resistance between terminals of the speaker.

**Resistance: 4Ω**


3. If not as specified, replace the speaker.
4. If the resistance is OK, go to Step 7.

### Step 7


1. Disconnect the 12-pin connector of the audio unit.
2. Disconnect both door speakers.
3. Check for continuity of the following wires of the door speakers wire harness.

Connectors	Wire	Continuity
Audio unit — Left door speaker	(R/W)	Yes
	(R/G)	Yes
Audio unit — Right door speaker	(L)	Yes
	(L/Y)	Yes

4. If not as specified, repair the faulty wiring.
5. If the wiring is OK, replace the audio unit.




05U0TX-257



05U0TX-262

**Step 8**

1. Check if the headrest speaker connector is properly connected.
2. If necessary, repair or reconnect the connector.
3. If the connection is OK, go to Step 9.




05U0TX-263

**Step 9**

1. Disconnect the headrest speaker connector.
2. Measure resistance between terminals of the headrest speaker connector as shown.

Terminal	Resistance
a—b	4Ω
c—d	

3. If not as specified, replace the speaker.
4. If the resistance is OK, go to Step 10.




05U0TX-264

**Step 10**

1. Disconnect the 8-pin connector of the audio unit.
2. Disconnect both headrest speaker connectors.
3. Check for continuity of the following wires of the headrest speakers wire harness.

Connectors	Wire	Continuity
Audio unit — Driver seat headrest speakers	(R/Y)	Yes
	(R/L)	Yes
	(L/W)	Yes
	(L/O)	Yes
Audio unit — Passenger seat headrest speakers	(R/Y)	Yes
	(R/L)	Yes
	(L/W)	Yes
	(L/O)	Yes




4. If not as specified, repair the faulty wiring.
5. If the wiring is OK, replace the audio unit.

## Radio

## Symptom: Poor sound quality or noise


05U0TX-462



05U0TX-336

**Step 1**


1. Tune to the strongest AM station using the automatic memory function. (Refer to pages T-111.)
2. If the automatic memory function does not operate, go to Step 4.
3. Compare sound quality with that of another vehicle that has the same type audio unit.
4. If the sound quality is inferior to the other unit, go to Step 2.
5. If the sound quality is the same as the other unit, the system is OK.



9MU0TX-391

**Step 2**

1. Play a known good cassette tape, and compare the sound quality with another vehicle that has the same type audio unit.
2. If the sound quality is inferior to the other unit, the malfunction may be in the speaker circuit. Go to Step 3.
3. If the sound quality is same as the other unit, the malfunction may be in the antenna circuit. Go to Step 4.




05U0TX-337

**Step 3**

1. Check for damage to the speakers.
2. Check for proper connection of speaker connectors.
3. Disconnect the speaker connectors, and measure resistance of each speaker.

**Resistance: 4Ω**


4. If a speaker has incorrect resistance or is damaged, replace it.
5. If the speakers are OK, replace the audio unit.



9MU0TX-393

**Step 4**


1. Check that there is no continuity (infinite ohms) between the mast antenna and a body ground.
2. If there is continuity, replace the antenna.
3. If there is no continuity, go to Step 5.



05U0TX-338

**Step 5**

1. Check for proper tightness of the antenna mounting nut.
2. If the nut is loose, tighten it.
3. If the nut is tight, go to Step 6.



05U0TX-339

**Step 6**

1. Remove the audio unit.
2. Check for proper connection of the antenna connector.
3. If necessary, repair or reconnect it.
4. If the connection is OK, replace the audio unit.


## Cassette Tape Player

**Symptom: Poor sound quality.**

**Note**

- Before troubleshooting, verify that the customer is using the audio system correctly. If not, instruct him/her in the proper operating procedure. (Refer to pages T-110.)
- If a speaker(s) do not operate, refer to "Speaker(s) do not operate". (pages T-115 or 117).


05U0TX-265



05U0TX-340

**Step 1**


1. Play a known good tape, and check the sound quality.
2. If sound quality is normal, the previous tape is defective. The system is OK.
3. If sound quality is still poor, go to Step 2.



9MU0TX-380

**Step 2**

1. Check for oxide or dirt on the head, capstan, and pinchroller.
2. If oxide or dirt is found, clean the parts with a head cleaner.
3. If there is no oxide or dirt, go to Step 3.




05U0TX-341

**Step 3**

1. Check for damage to the speakers.
2. Check for proper connection of the speaker connectors.
3. Disconnect all speaker connectors, and measure resistance of each speaker.

**Resistance: 4Ω**

4. If a speaker has incorrect resistance or is damaged, replace it.
5. If the speakers are OK, go to Step 4.




9MU0TX-382

**Step 4**


1. Compare sound quality with that of another vehicle that has the same type of audio system.
2. If the sound quality is inferior to the other unit, replace the audio unit.

**Symptom: Cassette tape will not load.**

05U0TX-342



9MU0TX-384



05U0TX-266

**Step 1**


1. Check if a known good cassette tape will load.
2. If the tape loads, the previous tape is defective. The system is OK.
3. If the tape will not load, go to Step 2.

**Step 2**

1. Check if radio operation is OK.
2. If radio operation is OK, replace the audio unit.
3. If the radio do not operate, there is a defect in the power supply circuit. (Refer to "Speaker(s) do not operate", pages T-115 or 117.)

**Symptom: Cassette tape will not play.**


9MU0TX-386



05U0TX-343

**Step 1**


1. Check if cassette tape will load.
2. If cassette tape will not load, see, "Cassette tape will not load". (Refer to page T-123.)
3. If cassette tape loads, go to Step 2.



05U0TX-463

**Step 2**

1. Play a known good tape, and check the sound quality.
2. If sound quality is normal, the previous tape is defective. The system is OK.
3. If sound quality is still poor, go to Step 3.



05U0TX-464

**Step 3**

1. Check for oxide or dirt on the head, capstan, and pinchroller.
2. If oxide or dirt is found, clean the parts with a head cleaner.
3. If after cleaning the parts, the tape still does not play, refer to "Speaker(s) do not operate", pages T-115 or 117.




## Compact Disc Player

## Symptom: Compact disc will not load.

## Note

- When a damaged or dirty compact disc is loaded, the audio unit detects such, and ejects the compact disc.


9MU0TX-405



9MU0TX-406

## Step 1

1. Check if a known good compact disc will load.
2. If the compact disc will load, the system is OK.
3. If the compact disc will not load, go to Step 2.



05U0TX-266

## Step 2

1. Check if the radio operates normally.
2. If the radio operates normally, replace the audio unit.
3. If the radio does not operate there is defective in the power supply circuit. (Refer to "Speaker(s) does not sound", pages T-115 or 117.)

## Symptom: Compact disc skips.

05U0TX-344

## Note

- Compact disc skipping may be hard to recreate because it is a result of the vehicle encountering sharp road shocks. This is a normal condition if skipping happens only infrequently.


## Remedy

1. Check with the driver if skipping occurs often.
2. If it occurs often, check that the audio unit is properly installed.
  - (1) If the audio unit is not installed properly, remedy it.
  - (2) If the audio unit is installed properly, replace the audio unit.

### REMOVAL / INSTALLATION


Remove and install as shown in the figure.

#### AUDIO UNIT




05U0TX-269


#### ANTENNA




DOOR SPEAKERS




HEADREST SPEAKERS





05U0TX-270



05U0TX-465

**INSPECTION**

**Door Speakers**

1. Disconnect the connector from the suspected faulty speaker.
2. Measure resistance between terminals of the speaker.

**Resistance: 4Ω**

3. If not as specified, replace the speaker.

**Headrest Speakers**

1. Disconnect the headrest speaker connector.
2. Measure resistance between terminals of the headrest speaker connector as shown.

Terminal	Resistance
a—b	4Ω
c—d	

3. If not as specified, replace the speaker.

**CONNECTOR TERMINAL SPECIFICATIONS**

Component	Connector	Terminal
Audio unit		a : Headrest speaker left ⊕ b : Headrest speaker left ⊖ c : NC d : NC f : Headrest speaker right ⊕ h : Headrest speaker right ⊖ i : NC j : NC
		a : ACC b : NC c : +B d : NC e : TNS (for illumination lamps) f : NC h : NC j : NC k : Door speaker left ⊕ l : Door speaker left ⊖ m : Door speaker right ⊕ n : Door speaker right ⊖
		1 : Left signal 2 : Left signal 3 : Right signal 4 : Right signal 5 : Signal ground 6 : Illumination signal 7 : ACC 8 : +B 9 : Amp control signal 10 : NC 11 : NC 12 : NC 13 : NC
Compact disc player		1 : Left signal 2 : Left signal 3 : Right signal 4 : Right signal 5 : Signal ground 6 : Illumination signal 7 : ACC 8 : +B 9 : Amp control signal 10 : NC 11 : NC 12 : NC 13 : NC


05U0TX-271

PANASONIC SERVICE NETWORK



AIR BAG SYSTEM

STRUCTURAL VIEW



05U0TX-346

- |                           |                   |
|---------------------------|-------------------|
| 1. Air bag module         | a. D-sensor (RH)  |
| 2. Steering wheel         | b. D-sensor (CNT) |
| 3. Clock spring connector | c. D-sensor (LH)  |
| 4. Diagnostic module      | d. S-sensor       |
| 5. Crush sensor           |                   |
|                           | 6. Backup battery |


The MX-5 Miata is equipped with a driver side supplementary air bag system, a first for Mazda vehicles. The air bag system is designed to provide increased accident protection for the driver when used in conjunction with the provided seat belt system. For optimum protection, the seat belts should be used by all vehicles occupants.

## COMPONENT DESCRIPTIONS

Component	Function	Remarks
Air bag system warning lamp	Lamp illuminates or flashes when problem or failure occurs in air bag system	Located in instrument cluster
Air bag module	Deploys air bag when current flows to integrated igniter	Air bag fills to volume of about 60 liters (15.9 US gal, 13.2 Imp gal)
Backup battery	Provides sufficient power to operate air bag system if battery power lost during crash	
Clock spring connector	Ensures uninterrupted electrical circuit to air bag module while allowing rotation of steering wheel	One of part of combination switch
Crash sensor	Detects frontal impact and completes circuit to send signal to air bag module	
	Two types of sensors used	
Diagnostic module	Monitors electrical system components and circuit	
	Indicates problem or failure in system by illuminating air bag system warning lamp	

05U0TX-347

SYSTEM DIAGRAM




05U0TX-348

The system diagram is as shown in figure. The battery, S-sensor, air bag module, and D-sensors are connected in series via diagnostic module.


When the S-sensor and one of the D-sensors are activated (closed) simultaneously, electric current flows to trigger the igniter in the air bag module.

The backup battery supplies the current to trigger the igniter if the battery or fuses fail during a collision. The diagnostic module is fitted to monitor the system for failures. It warns the driver of such by illuminating or flashing the air bag warning lamp.







05U0TX-349




05U0TX-350



05UTX-351



05U0TX-352



05U0TX-353

## SERVICE PRECAUTION

### 1. BEFORE COMPONENT REPLACEMENT

- Obtain the code number and deactivate the audio anti-theft function before disconnecting the battery. (Refer to page T-113.)
- Before replacement of any air bag system component or before disconnecting any connector of the system, first disconnect the negative battery cable; then disconnect the clock spring connectors (orange and blue).


### 2. PROHIBITION OF COMPONENT DISASSEMBLY AND WIRE HARNESS REPAIR

- The components of the air bag system are not intended to be disassembled for service. If a component failure is detected by the diagnostic module, replace the suspected component after checking the connections and the wire harness. Do not disassemble any component.


- If an open circuit is found by a continuity test, replace the wire harness. Do not try to repair the wiring.

### 3. HANDLING OF AIR BAG MODULE


- Do not use an ohmmeter for inspection of the air bag module, it may cause an accidental deployment of the air bag.
- When carrying a live (unactivated) air bag module, make sure the trim cover is pointed away from your body to prevent personal injury in the event of an accidental deployment.




05U0TX-354




05U0TX-355



05U0TX-356



05U0TX-357



05U0TX-358

- When placing a live air bag module on any surface, always face the trim cover upward to reduce the motion of the module if it is accidentally deployed.

- When handling a deployed air bag module, wear gloves and safety glasses, because the deployed air bag module may contain deposits of sodium hydroxide, a caustic by-product of the gas generant combustion.
- When an air bag module is to be disposed following the proper procedure recommended for the specific situation. (Refer to page T-160.)


#### 4. CRASH SENSOR INSTALLATION

- Crash sensor orientation is very important for proper operation. If a vehicle is involved in a collision where its front sheet metal is damaged, inspect the body structure at the sensor mounting area for deformation. If damaged, restore to its original shape.
- When installing a crash sensor, be sure to tighten the mounting bolts to the specified torque because the sensor is grounded through the crash sensor's mounting plate.

#### 5. ADJUSTMENT OF CLOCK SPRING CONNECTOR


- Whenever the steering wheel is removed, before reinstalling it, set the clock spring connector as follows:
  1. Set the front wheels straight ahead.
  2. Turn the clock spring connector clockwise until it stops. (Do not force it.)

3. Return the connector 2.75 turns.



05U0TX-359


4. Align the marks on the clock spring connector and the outer housing.



05U0TX-360

6. When Using Test Lead


- When using a test lead for testing, use a fine needle to prevent damage to the terminal.



05U0TX-361

7. Disconnecting Double Lock Type Connector


- The connectors in the air bag system use a double lock type connector.
- These connectors are disconnected as below.
  - 1) Press the orange knob and disconnect the orange connector.



05U0TX-362

2) Press the blue knob and disconnect the blue connector.

3) Connect the connectors in the reverse order of disconnecting.




05U0TX-363


8. After System Service

- After system service verify system operation by checking with the air bag system warning lamp. If the system is operating normally, the warning lamp will come on when the ignition switch is turned ON, then go off after approximately 6 seconds.
- Check if the horn sounds. If the horn does not sound, remove the air bag module and check the connections of the air bag module and horn switch connectors.

CIRCUIT DIAGRAM




F-42 DIAGNOSIS (F)





F-13 JOINT CONNECTOR (F)




F-58 AIR BAG CONTROL UNIT (F)



F-48 COMBINATION SWITCH (F)




F-59 JOINT CONNECTOR NO.1 (F)




F-60 S SENSOR (F)




F-61 BACKUP BATTERY (F)




F-62 D SENSOR (L. H.) (F)



F-63 D SENSOR (CENTER) (F)



F-64 D SENSOR (R. H.) (F)




F-65 COMBINATION SWITCH (F)




I-18 JOINT CONNECTOR NO.2 (I)




MO-01 AIR BAG MODULE






FI-01 FRONT (F) - INSTRUMENT PANEL (I)



FI-04 FRONT (F) - INSTRUMENT PANEL (I)



FE-07 FRONT (F) - ENGINE (E)




### TROUBLESHOOTING GUIDE

#### Troubleshooting Procedure

Troubleshooting of the air bag system is performed using the coded flashing of the air bag system warning lamp. The number of times the the warning lamp flashes is based on the type of fault being detected. Codes are prioritized in such a way that if two or more faults occur at the same time, the highest priority fault indication will dominate until corrected.

#### Work flow



#### Note

- When the ignition switch is turned ON, an audible alarm may be heard. If so, it indicates a simultaneous warning lamp failure and a problem in the air bag system.

05U0TX-365

#### Flash code table

Priority	Flash code	Possible cause	Flowchart No.
1	Remains ON	Faulty diagnostic module or poor connection of diagnostic module connector	1 (See page T-139)
2	Flashes three times	Open circuit or poor connection of power source circuit	2 (See page T-140)
3	Flashes five times	Faulty D-sensor (D-sensor remains ON)	3 (See page T-142)
4	Flashes ten times	Faulty diagnostic module (System-down fuse burned)	4 (See page T-143)
5	Flashes four times	Faulty S-sensor	5 (See page T-144)
6	Flashes six times	Faulty air bag module or poor connection of clock spring connector	6 (See page T-146)
7	Flashes eight times	Poor ground of D-sensor	7 (See page T-148)
8	Flashes nine times	Open circuit between diagnostic module and D-sensor	3 (See page T-142)
9	Flashes two times	Poor ground of all D-sensors	7 (See page T-148)


05U0TX-366

<b>Flowchart No.</b>	<ul style="list-style-type: none"> <li>• <b>Fault indication</b> ..... Warning lamp remains ON</li> <li>• <b>Possible cause</b> ..... Faulty diagnostic module or poor connection of diagnostic module connector</li> </ul>
<b>1</b>	


05U0TX-367

**Caution**

- Before troubleshooting, read **SERVICE PRECAUTION** on page T-133.



05U0TX-368



05U0TX-369

**Remedy**


1. Disconnect the negative battery cable.
2. Remove the knee protector, and disconnect the clock spring connectors (Orange and blue).
  
3. Check for proper connection of the diagnostic module connectors.
4. If the connector is loose or disconnected, reconnect it.
5. If the connection is OK, replace the diagnostic module.

<b>Flowchart No.</b>	<ul style="list-style-type: none"> <li>• <b>Fault indication .....</b> Warning lamp flashes three times</li> <li>• <b>Possible cause .....</b> Open circuit or poor connection of power source circuit</li> </ul>
2	

05U0TX-370

### Caution

- Before troubleshooting, read **SERVICE PRECAUTION** on page T-133.




05U0TX-371

### Step 1

Measure the battery voltage.

Battery voltage	Action
More than 9V	Go to Step 2
Less than 9V	Charge battery by recommended procedure (Refer to Section G)




05U0TX-372

### Step 2

1. Check the following fuses.

Fuse	Location
INJ 30A	Main fuse block
AIR BAG 15A	Fuse box
AIR BAG 10A	Main fuse block
ENGINE 15A	Fuse box


2. If a fuse burned, replace it.
3. If the fuses are OK, go to Step 3.



05U0TX-373

### Step 3


1. Disconnect the negative battery cable.
2. Remove the knee protector, and disconnect the clock spring connectors (Orange and blue).



05U0TX-374

3. Check for proper connection of the backup battery connector.
4. If the connector is loose or disconnected, reconnect it.
5. If the connection is OK, go to Step 4.






05U0TX-375

**Step 4**

1. Disconnect the backup battery connector.
2. Reconnect the negative battery cable.
3. Measure the voltage at terminal-wire (G/R) of the backup battery connector.

Wire	Voltage	Action
(G/R)	12V	Go to Step 5
	0V	Replace wire harness assembly



05U0TX-376

**Step 5**

1. Disconnect the negative battery cable.
2. Disconnect the diagnostic module connector.
3. Reconnect the negative battery cable.
4. Measure the voltage at the terminal-wires of the diagnostic module connector.


Terminal-wire	Voltage	Action
1L (W/G)	12V	Next, check terminal-wire 1J (G/Y)
	0V	Replace wire harness assembly
1J (G/Y)	12V	Replace diagnostic module
	0V	Replace wire harness assembly

<b>Flowchart No.</b>	<ul style="list-style-type: none"> <li>• <b>Fault indication</b> ..... Warning lamp flashes five times or nine times</li> <li>• <b>Possible cause</b> ..... Faulty D-sensor (CNT, LH or RH)</li> </ul>
3	


05U0TX-377

### Caution


- Before troubleshooting, read **SERVICE PRECAUTION** on page T-133.



05U0TX-378



05U0TX-379



05U0TX-380

### Step 1

1. Disconnect the negative battery cable.
2. Remove the knee protector, and disconnect the clock spring connectors (Orange and blue).

3. Disconnect all D-sensor (CNT, LH and RH) connectors, and measure the resistance of each sensor.

**Resistance: Approx. 1.2 kΩ**

4. If not as specified, replace the sensor.
5. If correct, go to Step 2.

### Step 2

1. Reconnect all D-sensor connectors.
2. Disconnect the diagnostic module connector.
3. Measure the resistance between the following terminal-wire of the diagnostic module connector and a body ground.


Terminal-wire	Resistance	Action
1C (BR/G)	Approx. 1.2 kΩ	Next, check terminal-wire 1A (BR/R)
	Other 1.2 kΩ	Replace wire harness
1A (BR/R)	Approx. 1.2 kΩ	Next, check terminal-wire 2L (BR/B)
	Other 1.2 kΩ	Replace wire harness
2L (BR/B)	Approx. 1.2 kΩ	Replace diagnostic module
	Other 1.2 kΩ	Replace wire harness

<b>Flowchart No.</b>	<ul style="list-style-type: none"> <li>• <b>Fault indication</b> ..... Warning lamp flashes ten times</li> <li>• <b>Possible cause</b> ..... Faulty diagnostic module (System down fuse burned)</li> </ul>
<b>4</b>	


05U0TX-381

**Caution**


- Before troubleshooting, read **SERVICE PRECAUTION** on page T-133.




05U0TX-382



05U0TX-383



05U0TX-384



05U0TX-385

**Step 1**

1. Disconnect the negative battery cable.
2. Remove the knee protector, and disconnect the clock spring connectors (Orange and blue).

3. Disconnect all D-sensor (CNT, LH and RH) connectors, and measure the resistance of each sensor.

**Resistance: Approx. 1.2 kΩ**

4. If not as specified, replace the sensor, then go to Step 3.
5. If correct, go to Step 2.

**Step 2**

1. Reconnect all D-sensor connectors.
2. Disconnect the diagnostic module connector.
3. Measure the resistance between the following terminal-wires of the diagnostic module connector and a body ground.

Terminal-wire	Resistance	Action
1C (BR/G)	Approx. 1.2 kΩ	Next, check terminal-wire 1A (BR/R)
	Other 1.2 kΩ	Replace wire harness, then go to Step 3
1A (BR/R)	Approx. 1.2 kΩ	Next, check terminal-wire 2L (BR/B)
	Other 1.2 kΩ	Replace wire harness, then go to Step 3
2L (BR/B)	Approx. 1.2 kΩ	Go to Step 3
	Other 1.2 kΩ	Replace wire harness, then go to Step 3

**Step 3**


1. Reconnect the diagnostic module connector.
2. Reconnect the clock spring connector.
3. Reconnect the negative battery cable.
4. Turn the ignition switch ON, and monitor the warning lamp operation.
5. If the warning lamp flashes ten times again, replace the diagnostic module.

<b>Flowchart No.</b>	<ul style="list-style-type: none"> <li>• <b>Fault indication</b> ..... Warning lamp flashes four times</li> <li>• <b>Possible cause</b> ..... Faulty S-sensor</li> </ul>
5	


05U0TX-386

### Caution


- Before troubleshooting, read **SERVICE PRECAUTION** on page T-133.




05U0TX-387



05U0TX-388



05U0TX-389



05U0TX-390

### Step 1

1. Disconnect the negative battery cable.
2. Remove the knee protector, and disconnect the clock spring connectors (Orange and blue).

3. Disconnect the diagnostic module connector.
4. Check continuity between terminal-wires of the diagnostic module connector.

Terminal-wire	Continuity	Action
2B (G/W) — 2D (G/W)	Yes	Go to Step 2
	No	Replace wire harness

### Step 2


1. Disconnect the diagnostic connector.
2. Check continuity between terminal-wire of diagnostic module connector and a body ground.

Terminal-wire	Continuity	Action
2C (G) — Body ground	Yes	Go to Step 3
	No	Go to Step 5

### Step 3

1. Disconnect the diagnostic module connectors.
2. Check continuity between terminal-wires of the diagnostic module connector.

Terminal-wire	Continuity	Action
1H (G/B) — 2C (G)	Yes	Go to Step 5
	No	Go to Step 4




05U0TX-391

**Step 4**

1. Disconnect the S-sensor connectors.
2. Check continuity between terminals of the sensor.


Terminal	Continuity	Action
(b)—(e)	Yes	Replace wire harness
	No	Replace S-sensor



05U0TX-392

**Step 5**

1. Verify that the S-sensor is installed properly.
2. If the installation is poor, clean the mounting and tighten the bolts.
3. If correct, go to Step 6.



05U0TX-393

**Step 6**

1. Disconnect the S-sensor connectors.
2. Check continuity between terminal of the sensor and a body ground.


Terminal	Continuity	Action
(a)— Body ground	Yes	Replace S-sensor
	No	Replace wire harness

<b>Flowchart No.</b>	<ul style="list-style-type: none"> <li>• <b>Fault indication</b> ..... Warning lamp flashes six times</li> <li>• <b>Possible cause</b> ..... Faulty air bag module or poor connection of clock spring connector</li> </ul>
6	


05U0TX-394

### Caution


- Before troubleshooting, read **SERVICE PRECAUTION** on page T-133.




05U0TX-395



05U0TX-396



05U0TX-397



05U0TX-398

### Step 1

1. Disconnect the negative battery cable.
2. Check for proper connection of the clock spring connectors (Orange and blue).
3. If a connector is loose or disconnected, reconnect it.
4. If the connections are OK, go to Step 2.

### Step 2

1. Remove the air bag module installation nuts.
2. Verify that the air bag module connector is properly connected.
3. If the connector is loose or disconnected, reconnect it.
4. If the connection is OK, go to Step 3.

### Step 3

1. Disconnect the air bag module and clock spring connector.
2. Check continuity between terminals of the clock spring connectors (blue) as shown.

Terminals		Continuity
Connector A	Connector B	
a	A	Yes
b	B	Yes


3. If not as specified, replace the clock spring connector.

### Step 4

1. Disconnect the diagnostic module connector.
2. Check continuity between the diagnostic module connector and the clock spring connector (wire harness side) as shown.

Terminal-wire	Continuity
(Diagnostic module) — (Clock spring connector)	
(2D : G/W)—(a : R)	Yes
(2F : G/Y)—(b : G/Y)	Yes

3. If not as specified, replace the wire harness assembly.
4. If correct, go to Step 5.



05U0TX-399

### Step 5

1. Check continuity between terminal-wire 2F (G/Y) of the diagnostic module connector and a body ground.

Terminal-wire	Continuity
2F (G/Y)—Body ground	No


2. If not as specified, replace the wire harness assembly.
3. If correct, replace the air bag module.

<b>Flowchart No.</b>	<ul style="list-style-type: none"> <li>• <b>Fault indication</b> ..... Warning lamp flashes two times or eight times</li> <li>• <b>Possible cause</b> ..... Poor ground of D-sensor</li> </ul>
<b>7</b>	


05U0TX-400

### Caution


- Before troubleshooting, read **SERVICE PRECAUTION** on page T-133.




05U0TX-401



05U0TX-402



05U0TX-403



05U0TX-404

### Step 1

1. Disconnect the negative battery cable.
2. Remove the knee protector, and disconnect the clock spring connectors (Orange and blue).
3. Disconnect the diagnostic module connector.
4. Check continuity between the following terminals of the diagnostic module connector and a body ground.

Terminal-wire	Continuity	Action
2J (BR/Y)— Body ground	Yes	Next, check between 2H (BR/W) and body ground
	No	Go to Step 2
2H (BR/W)— Body ground	Yes	Next, check between 2E (BR) and body ground
	No	Go to Step 3
2E (BR)— Body ground	Yes	Replace diagnostic module
	No	Go to Step 4

### Step 2

1. Disconnect the D-sensor (RH) connectors, and check continuity between terminals of the sensor connectors and a body ground.

Terminal	Continuity
b—Body ground	Yes

2. If not as specified, go to Step 5.
3. If correct, replace the wire harness assembly.


### Step 3

1. Disconnect the D-sensor (CNT) connectors, and check continuity between terminals of the sensor connector and a body ground.


Terminal	Continuity
b—Body ground	Yes

2. If not as specified, go to Step 5.
3. If correct, replace the wire harness assembly.





05U0TX-405



05U0TX-406

### Step 4

1. Disconnect the D-sensor (LH) connectors, and check continuity between terminals of the sensor connector and a body ground.

Terminal	Continuity
b—Body ground	Yes

2. If not as specified, go to Step 5.
3. If correct, replace the wire harness assembly.

### Step 5

1. Check that all D-sensors (CNT, LH and RH) are properly installed.
2. If an installation bolt is loose, tighten it.
3. If correct, replace the faulty D-sensor.


## REMOVAL / INSTALLATION

## Air Bag Module


1. Disconnect the negative battery cable.
2. Remove the nuts and remove the air bag module.

## Caution


- Do not try to disassemble the air bag module. The air bag module must only be replaced as an assembly.
- Do not use an ohmmeter for inspection of the air bag module, it may cause an accidental deployment of the air bag.
- When carrying a live (unactivated) air bag module, make sure the trim cover is pointed away from your body to prevent personal injury in the event of an accidental deployment.
- When placing a live air bag module on any surface, always face the trim cover upward to reduce the motion of the module if it is accidentally deployed.
- When handling a deployed air bag module, wear gloves and safety glasses, because the deployed air bag module may contain deposits of sodium hydroxide, a caustic by-product of the gas generant combustion.




05U0TX-407




05U0TX-408



05U0TX-409




05U0TX-410



05U0TX-411


- When an air bag module is to be disposed of, it must be disposed following the proper procedure recommended for the specific situation.

05U0TX-412



05U0TX-413


3. Install in the reverse order of removal.



05U0TX-414

### Diagnosis Module and Backup Battery

1. Disconnect the negative battery cable.
2. Remove the knee protector, and disconnect the clock spring connectors (Orange and blue).



05U0TX-415

3. Disconnect the diagnostic module and backup battery connectors.
4. Remove the nuts and remove the diagnostic module and backup battery as an assembly.
5. Install the diagnostic module and backup battery in the reverse order of removal.

### Clock Spring Connector Assembly

#### Note

- The clock spring connector assembly is part of the combination switch. When replacing the clock spring connector assembly, replace it with the combination switch as an assembly.

1. Disconnect the negative battery cable.
2. Remove the knee protector, and disconnect the clock spring and combination switch connectors.


3. Remove the nuts and remove the air bag module. (Refer to page T-150.)

#### Caution


- Do not strike the steering shaft with a hammer; the collapsible shaft may collapse.

4. Remove the nut and remove the steering wheel with a steering wheel puller.
5. Remove the screws and column cover.


6. Loosen the screws and remove the clock spring connector assembly with the combination switch.




05U0TX-416




05U0TX-417




05U0TX-418




05U0TX-419




05U0TX-420




05U0TX-421



05U0TX-422



05U0TX-423



05U0TX-424

7. Install the clock spring connector assembly and combination switch in the reverse order of removal, referring to **Installation Note**.

### Installation note


- Before installing the steering wheel, set the clock spring connector as follows:

1) Set the front wheels straight ahead.


2) Turn the clock spring connector clockwise until it stops. (Do not force it.)

3) Return the connector 2.75 turns.


4) Align the marks (counterclockwise) on the clock spring connector and the outer housing.




05U0TX-425



05U0TX-426



05U0TX-427



05U0TX-428

**D-sensor (RH)**

1. Disconnect the negative battery cable.
2. Remove the knee protector, and disconnect the clock spring connectors (Orange and blue).
3. Remove the nuts and the main fuse block.
4. Disconnect the D-sensor (RH) connectors.

5. Remove the undercover.

6. Remove the clips and remove the bolts and the D-sensor (RH).


7. Install the D-sensor (RH), in the reverse order of removal, referring to the **Installation Note**.

**Installation note**


- **Position the sensor with the arrow toward the front of the vehicle.**
- **Tighten the mounting bolts to the specific torque.**

**Tightening torque:**


**8.8—12.7 N·m (90—130 cm·kg, 78—113 in·lb)**




05U0TX-429



05U0TX-430



05U0TX-431



05U0TX-432

## D-sensor (LH)

1. Disconnect the negative battery cable.
2. Remove the knee protector, and disconnect the clock spring connectors (Orange and blue).
3. Remove the bolts and the relay box.
4. Disconnect the D-sensor (LH) connectors.

5. Remove the undercover.

6. Remove the clips and remove the bolts and the D-sensor (LH).


7. Install the D-sensor (LH), in the reverse order of removal, referring to the **Installation Note**.

### Installation note


- **Position the sensor with the arrow toward the front of the vehicle.**
- **Tighten the mounting bolts to the specific torque.**

### Tightening torque:


**8.8—12.7 N-m (90—130 cm-kg, 78—113 in-lb)**



05U0TX-433



05U0TX-434



05U0TX-435

**D-sensor (CNT)**

1. Disconnect the negative battery cable.
2. Disconnect the D-sensor (CNT) connectors.

3. Remove the wiring clips.
4. Remove the bolts and the D-sensor (CNT).
5. Install the D-sensor (CNT) in the reverse order of removal, referring to the **Installation Note**.

**Installation note**

- Position the sensor with the arrow toward the front of the vehicle.
- Tighten the mounting bolts to the specified torque.

**Tightening torque:**

8.8—12.7 N·m (90—130 cm·kg, 78—113 in·lb)

**S-sensor**

1. Disconnect the negative battery cable.
2. Remove the instrument panel. (Refer to Section S.)
3. Disconnect the S-sensor connectors.
4. Remove the bolts and S-sensor.
5. Install the S-sensor in the reverse order of removal, referring to the **Installation Note**.


**Installation note**

- Position the sensor with the arrow toward the front of the vehicle.
- Tighten the mounting bolts to the specified torque.


**Tightening torque:**

8.8—12.7 N·m (8.8—12.7 cm·kg, 78—113 in·lb)







05U0TX-436




05U0TX-437



05U0TX-438



05U0TX-439



05U0TX-440

**INSPECTION**

**D-sensor (LH)**

1. Disconnect the negative battery cable.
2. Remove the knee protector, and disconnect the clock spring connectors (Orange and blue).
3. Remove the bolts and the relay box.
4. Disconnect the D-sensor (LH) connector.

**Caution**

- **Do not connect an ohmmeter to the harness side connector. Connect the ohmmeter to the sensor side connectors only.**

5. Measure resistance between the terminals of the sensor connectors.

Terminals	Resistance
a (blue)—b (orange)	Approx. 1.2 kΩ

6. If not as specified, replace the sensor.

**Caution**

- **Do not try to repair the wire harness.**

**D-sensor (RH)**

1. Disconnect the negative battery cable.
2. Remove the knee protector, and disconnect the clock spring connectors (Orange and blue).
3. Remove the bolts and the main fuse block.
4. Disconnect the D-sensor (RH) connector.

**Caution**

- **Do not connect an ohmmeter to the harness side connector. Connect the ohmmeter to the sensor side connectors only.**


5. Measure resistance between the terminals of the sensor connectors.

Terminals	Resistance
a (blue)—b (orange)	Approx. 1.2 kΩ

6. If not as specified, replace the sensor.

**Caution**

- **Do not try to repair the wire harness.**




05U0TX-441

**D-sensor (CNT)**

1. Disconnect the negative battery cable.
2. Remove the knee protector, and disconnect the clock spring connectors (Orange and blue).
3. Disconnect the D-sensor (CNT) connectors.

**Caution**

- Do not connect an ohmmeter to the harness side connector. Connect the ohmmeter to the sensor side connectors only.



05U0TX-442


4. Measure resistance between the terminals of the sensor connectors.

Terminals	Resistance
a (blue)—b (orange)	Approx. 1.2 kΩ

5. If not as specified, replace the sensor.

**Caution**

- Do not try to repair the wire harness.




05U0TX-443

**S-sensor**

1. Disconnect the negative battery cable.
2. Remove the knee protector, and disconnect the clock spring connectors (Orange and blue).
3. Remove the instrument panel assembly.
4. Disconnect the S-sensor connectors.

**Caution**

- Do not connect an ohmmeter to the harness side connector. Connect the ohmmeter to the sensor side connectors only.



05U0TX-444


4. Check resistance between the terminals of the sensor connectors.

Terminals	Continuity
b—e	Yes
c—d	Yes
b—c	No


5. If not as specified, replace the sensor.

**Caution**


- Do not try to repair the wire harness.




05U0TX-445



05U0TX-446



05U0TX-447



05U0TX-448

## Clock Spring Connector Assembly

1. Disconnect the negative battery cable.
2. Remove the knee protector and disconnect the clock spring connectors (Orange and blue).

3. Remove the nuts and remove the air bag module.

4. Check continuity between terminals of the clock spring connectors (blue) as shown.

Terminals		Continuity
Connector A	Connector B	
a	A	Yes
b	B	Yes

5. If not as specified, replace the clock spring connector.

### Note


- The clock spring connector assembly is part of the combination switch. When replacing the clock spring connector assembly, replace it with combination switch as an assembly.

### AIR BAG MODULE DISPOSAL PROCEDURE

When an air bag module is to be disposed of, it must be disposed following the proper procedure recommended for the particular situation. These situations and the disposal recommendations are shown in the following table and described in detail below.

Condition	Disposal instruction
Faulty but live air bag module replaced	Air bag module must be return to location designated by Mazda
Vehicle to be scrapped with live air bag module	Air bag module must be deliberately deployed (See below)
Vehicle to be scrapped with deployed air bag module	Scrap air bag module with vehicle in usual manner
Deployed air bag module replaced	Scrap air bag module in usual manner

05U0TX-449




05U0TX-450

### Deployed Air Bag Module

To service a deployed air bag, it must be replaced with a new module. The deployed air bag module can be disposed of in the usual manner as any part to be scrapped.

#### Warning

- **When handling a deployed air bag module, wear gloves and safety glasses, because the deployed air bag module may contain deposits of sodium hydroxide, a caustic by product of the gas generant combustion.**




05U0TX-451

### Live Air Bag Module


When a live air bag module is scrapped with the vehicle, the module should be deployed before it is scrapped.

#### A deliberate deployment should be performed as follows:


1. Locate the vehicle outdoors away from other persons, and open the convertible top and doors.
2. Disconnect the negative battery cable.
3. Verify that the air bag module is firmly mounted to the steering wheel.
4. Remove the knee protector and disconnect the clock spring connectors.
5. Cut the clock spring connector (blue) wires.
6. Connect two jumper wires [6 m (20 ft) min] to the clock spring cut wires as shown.




05U0TX-452



05U0TX-453



05U0TX-454



05U0TX-455

### Warning

- All personnel should be at least 6 m (20 ft) away from the vehicle to ensure personnel safety and due to the loud sound that occurs when the air bag deploys.

7. From 6 m (20 ft), connect the jumper wires to the terminals of a 12V vehicle battery to trigger the igniter.

8. Allow at least 10 minutes before approaching the air bag to allow for cooling of the module and dissipation of the effluents.

### Warning

- When handling a deployed air bag module, wear gloves and safety glasses, because the deployed air bag module may contain deposits of sodium hydroxide, a caustic by product of the gas generant combustion.


9. Remove the deployed air bag module, and scrap it in the usual manner of any part to be scrapped.

# HEATER AND AIR CONDITIONER SYSTEMS

<b>INDEX</b> .....	<b>U- 2</b>
HEATER.....	<b>U- 2</b>
AIR CONDITIONER.....	<b>U- 3</b>
<b>TROUBLESHOOTING GUIDE</b> .....	<b>U- 4</b>
CIRCUIT DIAGRAM.....	<b>U- 4</b>
ELECTRICAL TROUBLESHOOTING TOOLS.....	<b>U- 6</b>
GENERAL PRECAUTION.....	<b>U- 6</b>
<b>HEATER</b> .....	<b>U-18</b>
STRUCTURAL VIEW.....	<b>U-18</b>
HEATER UNIT.....	<b>U-19</b>
BLOWER UNIT.....	<b>U-21</b>
HEATER CONTROL SWITCH ASSEMBLY....	<b>U-23</b>
<b>AIR CONDITIONER</b> .....	<b>U-26</b>
STRUCTURAL VIEW.....	<b>U-26</b>
REFRIGERANT SYSTEM.....	<b>U-27</b>
COOLING UNIT.....	<b>U-32</b>
CONDENSER AND RECEIVER/DRIER.....	<b>U-35</b>
REFRIGERANT LINES.....	<b>U-37</b>
CONDENSER FAN.....	<b>U-38</b>
A/C RELAY.....	<b>U-39</b>
REFRIGERANT PRESSURE SWITCH.....	<b>U-39</b>
COMPRESSOR.....	<b>U-40</b>

## INDEX

### HEATER




05U0UX-002

- 1. Heater unit
  - Removal / Installation..... page U-19
  - Disassembly / Assembly..... page U-20
  - Heater core (in heater unit)
    - Inspection..... page U-20
- 2. Blower unit
  - Removal / Installation..... page U-21
  - Disassembly / Assembly..... page U-22

- Blower motor (in blower unit)
  - Inspection..... page U-22
- Resistor assembly (in blower unit)
  - Inspection..... page U-22
- 3. Heater control switch assembly
  - Removal / Installation..... page U-23
  - Disassembly / Assembly..... page U-24
  - Inspection..... page U-25
  - Adjustment ..... page U-25

AIR CONDITIONER




05U0UX-003

- |  |   |
|--|---|
| <p>1. Cooling unit<br/>                 Removal / Installation..... page U-32<br/>                 Disassembly / Assembly..... page U-33</p> <p>2. Compressor<br/>                 Removal / Installation..... page U-40</p> | <p>3. Magnetic clutch<br/>                 Disassembly / Assembly..... page U-41</p> <p>4. Condenser<br/>                 Removal / Installation..... page U-35</p> <p>5. Receiver / drier<br/>                 Removal / Installation..... page U-35</p> |
|--|---|



TROUBLESHOOTING GUIDE

CIRCUIT DIAGRAM



FOR USA FOR CANADA

F-52 BLOWER UNIT (F)



F-53 MAGNETIC CLUTCH (F)



I-12 THERMOSWITCH (I)




I-13 HEATER CONTROL UNIT (I)



I-14 BLOWER UNIT (I)



AC-01 A/C RELAY (AC)



AC-02 ADDITIONAL FAN MOTOR (AC)




AC-03 REFRIGERANT PRESSURE SWITCH (AC)



BL-01 BLOWER MOTOR




FI-01 FRONT (F) - INSTRUMENT PANEL (I)




(I) WITH POWER WINDOW  
(F) ... FOR CANADA

FI-03 FRONT (F) - INSTRUMENT PANEL (I)



(F) WITH POWER WINDOW




FAC-01 FRONT (F) - A/C (AC)



Symptom	Reference page
Blower motor does not operate	U-7
Magnetic clutch does not operate	U-9
Additional (condenser) fan does not operate	U-11
Insufficient cooling No cooling Intermittent cooling	U-12

05U0UX-005



05U0UX-083


### ELECTRICAL TROUBLESHOOTING TOOLS

#### Jumper Wire

The jumper wire is used for testing by short-circuiting switch terminals and to verify the condition of ground connections.

#### Caution


- **Do not connect the jumper wire between a power source and a body ground. Doing so may cause burning or other damage to harnesses and electronic components.**



9MU0UX-009

#### Voltmeter

The DC voltmeter is used for measurement of circuit voltage. A voltmeter with a range of 15V or more must be used. It is used by connecting the positive (+) probe (red lead) to the point where voltage is to be measured and connecting the negative (-) probe (black lead) to a body ground.




9MU0UX-010

#### Ohmmeter

The ohmmeter is used to measure the resistance between two points in a circuit, to check for continuity, and to diagnose short circuits.

#### Caution

- **Never connect the ohmmeter to any circuit to which voltage is applied. Doing so may burn or otherwise damage the ohmmeter.**



05U0TX-009

### GENERAL PRECAUTION

#### Before Disconnecting Battery Cables


The optional audio unit has an anti-theft function that is activated when the battery power is disconnected. Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to page T-113.)

**Symptom: Blower motor does not operate.**


**Normal operation of blower motor**

Blower motor speed is controlled by the blower switch and a resistor assembly in the blower unit. When the blower switch is in the OFF position, the motor ground circuit is open and the blower motor does not operate. When the switch is in the first (Low) position, current flow from the blower motor is restricted by the three resistors in the resistor assembly, and the blower motor turns at low speed. Changing the blower switch to the second (Mid), third (High), or fourth (Super-high) position causes the circuit resistance to decrease, and the blower motor speed becomes correspondingly faster.

05U0UX-006



05U0UX-082



05U0UX-007

**Step 1**

1. Check the circuit breaker.


Circuit breaker	Amperage	Location
HEATER	30A	Fuse box

2. If the reset button is not out, go to Step 2.
3. If the reset button is out, check for a short circuit in the harness. Repair as necessary; then depress the reset button to reset the circuit breaker.

**Step 2**

1. Turn the ignition switch ON.
2. Turn the blower switch to the fourth position.
3. Measure the voltage at terminal-wire (L) of the blower motor connector.


Wire	Voltage	Action
(L)	12V	Go to Step 3
	0V	Repair wire harness (Circuit breaker—Blower motor)



### Step 3

1. Turn the ignition switch ON.
2. Turn the blower switch and A/C switch OFF.
3. Measure the voltage at the terminal-wires of the resistor assembly.


Wire	Voltage	Action
(L/R) (1-pin connector)	12V	Next, check wire (L/W)
	0V	Replace blower motor
(L/W)	12V	Next, check wire (L/R)
	0V	Replace resistor assembly
(L/R) (4-pin connector)	12V	Next, check wire (L/G)
	0V	Replace resistor assembly
(L/G)	12V	Next, check wire (L/Y)
	0V	Replace resistor assembly
(L/Y)	12V	Go to Step 4
	0V	Replace resistor assembly



### Step 4

1. Turn the ignition switch ON.
2. Turn the blower switch to the fourth position.
3. Measure the voltage at terminal-wire (B) of the blower switch connector.

Wire	Voltage	Action
(B)	0V	Go to Step 5
	12V	Repair wire harness (Blower switch—Body ground)



### Step 5

1. Turn the ignition switch ON.
2. Turn the blower switch and A/C switch OFF.
3. Measure the voltage at the terminal-wires of the blower switch connector.

Wire	Voltage	Action
(L/W)	0V	Repair wire harness (Resistor assembly—Blower switch)
	12V	Next, check wire (L/R)
(L/R)	0V	Repair wire harness (Resistor assembly—Blower switch)
	12V	Next, check wire (L/G)
(L/G)	0V	Repair wire harness (Resistor assembly—Blower switch)
	12V	Next, check wire (L/Y)
(L/Y)	0V	Repair wire harness (Resistor assembly—Blower switch)
	12V	Replace blower switch

**Symptom: Magnetic clutch does not operate.**

**Note**

- If the blower motor also does not operate, see “Blower motor does not operate”; page U-7.

**Normal operation of magnetic clutch**


The magnetic clutch is supplied with battery voltage as shown:

1. A/C and blower switches are turned ON.
2. ECU receives signal that A/C and blower switches are ON and creates ground circuit.
3. A/C relay is magnetized and contact is closed.
4. Battery voltage is applied to magnetic clutch and clutch locks.


**Note**

- The ECU also controls the additional fan and magnetic clutch operation depending on engine load. (Refer to Section F.)


05U0UX-011



05U0UX-084



05U0UX-012



05U0UX-013

**Step 1**

1. Check the following fuses.

Fuse	Amperage	Location
WIPER	20A	In fuse box
AD FAN	20A	In main fuse block

2. If the fuses are OK, go to Step 2.
3. If a fuse is burned, check for a short circuit in the harness before replacing it.

**Step 2**


1. Run the engine at idle.
2. Turn the A/C switch and blower switch ON.
3. Measure the voltage at terminal-wire (B/R) of the magnetic clutch connector.

Wire	Voltage	Action
(B/R)	12V	Go to Step 3
	0V	Go to Step 5


**Step 3**

1. Disconnect the thermoswitch connector.
2. Check for continuity of the thermoswitch.

Continuity	Action
Yes	Go to Step 4
No	Replace thermoswitch



05U0UX-014



05U0UX-015

### Step 4

1. Disconnect the magnetic clutch connector.
2. Check for continuity between the magnetic clutch connector and a body ground.

#### Note


- Set the ohmmeter to x1,000 range.

3. If there is no continuity, replace the magnetic clutch.
4. If there is continuity, adjust the magnetic clutch clearance or check the compressor for internal trouble.

### Step 5

1. Start the engine.
2. Turn the blower and A/C switches ON.
3. Measure the voltage at the following terminal-wires of the A/C relay connector.

Wire	Voltage	Action
(B/L)	12V	Go to Step 6
	0V	Next, check wire (L/Y)
(L/Y)	12V	Next, check wire (L/G)
	0V	Repair wire (L/G) (AD FAN 20A fuse—A/C relay)
(L)	12V	Next, check wire (L/B)
	0V	Repair wire (L/G) (WIPER 20A fuse—A/C relay)
(L/B)	12V	Check ECU terminal voltage
	0V	Replace A/C relay




05U0UX-016

### Step 6

1. Disconnect the refrigerant pressure switch connector.
2. Check continuity of the refrigerant pressure switch.

Continuity	Action
Yes	Repair wiring harness (A/C relay—Refrigerant pressure switch—Magnetic clutch)
No	Go to Step 7



05U0UX-017

### Step 7

1. Measure the refrigerant pressure. (Refer to page U-31.)

#### Normal pressure

##### Low-pressure side:

147—294 kPa (1.5—3.0 kg/cm<sup>2</sup>, 21—43 psi)

##### High-pressure side:

1,177—1,619 kPa (12.0—16.5 kg/cm<sup>2</sup>, 171—235 psi)

2. If not as specified, check the refrigerant system by referring to the troubleshooting information on page U-12.
3. If correct, replace the refrigerant pressure switch.

**Symptom: Additional (condenser) fan does not operate.**

**Note**

- If the magnetic clutch also does not operate, see “Magnetic clutch does not operate”; page U-9.

**Normal operation of additional fan**


The additional fan is supplied with battery voltage as shown:

1. A/C and blower switches are turned ON.
2. ECU receives signal that A/C and blower switches are ON and creates ground circuit.
3. A/C relay is magnetized and contact is closed.
4. Battery voltage is applied to additional fan and fan operates.

**Note**

- The ECU also controls the additional fan and magnetic clutch operation depending on engine load. (Refer to Section F.)

05U0UX-018



05U0UX-019


**Remedy**

1. Measure the voltage at the terminal-wire(s) of the additional fan.

Wire	Voltage	Action
(B/L)	12V	Next, check wire (B)
	0V	Repair wire (B/L) (A/C relay—Additional fan)
(B)	12V	Repair wire (B) (Additional fan—Body ground)
	0V	Replace additional fan



**Symptom: Insufficient cooling.  
No cooling.  
Intermittent cooling.**




05U0UX-020

### Step 1 Checking refrigerant charge

1. Run the engine at a fast idle.
2. Operate the air conditioner at maximum cooling for a few minutes.
3. Observe the sight glass to determine the amount of refrigerant and the related action as shown below.

Item	Symptom	Amount of refrigerant	Action
1	Bubbles present in sight glass	Insufficient refrigerant	Check refrigerant pressure, go to Step 2
2	No bubbles present in sight glass	Too much or proper amount of refrigerant	Turn air conditioner OFF, and watch bubbles (Refer to Items 3 and 4)
3	Immediately after air conditioner turned off, refrigerant in sight glass stays clear	Too much refrigerant	Check refrigerant pressure, go to Step 2
4	When air conditioner turned OFF, refrigerant foams, and then sight glass becomes clear	Proper amount of refrigerant	Refrigerant amount normal

9MU0UX-073



05U0UX-021

### Step 2 Checking refrigerant pressure

1. Connect the A/C manifold gauge set.
2. Operate the engine at 2,000 rpm and set the air conditioner to maximum cooling.
3. Measure the refrigerant pressure.

#### Normal pressure








##### Low-pressure side:

**147—294 kPa (1.5—3.0 kg/cm<sup>2</sup>, 21—43 psi)**

##### High-pressure side:

**1,177—1,619 kPa (12.0—16.5 kg/cm<sup>2</sup>, 171—235 psi)**

4. If the pressures are not as specified, refer to the chart on the next page and check the system.

Measured pressure	Possible cause	Action
 <p>LOW PRESSURE SIDE: 0.8 kg/cm<sup>2</sup> HIGH PRESSURE SIDE: 8-9 kg/cm<sup>2</sup></p>	<p>Low side: Below 78.5 kPa (0.8 kg/cm<sup>2</sup>, 11.4 psi) High side: 785-883 kPa (8-9 kg/cm<sup>2</sup>, 114-128 psi)</p>	<p>Insufficient refrigerant</p> <p>Case 1 (Refer to page U-14)</p>
 <p>LOW PRESSURE SIDE: 2.5 kg/cm<sup>2</sup> HIGH PRESSURE SIDE: 20 kg/cm<sup>2</sup></p>	<p>Low side: Above 245 kPa (2.5 kg/cm<sup>2</sup>, 35.6 psi) High side: Above 1,962 kPa (20 kg/cm<sup>2</sup>, 284 psi)</p>	<p>Excessive refrigerant or insufficient condenser cooling</p> <p>Case 2 (Refer to page U-15)</p>
 <p>LOW PRESSURE SIDE: 2.5 kg/cm<sup>2</sup> HIGH PRESSURE SIDE: 23 kg/cm<sup>2</sup></p>	<p>Low side: Above 245 kPa (2.5 kg/cm<sup>2</sup>, 35.6 psi) High side: Above 2,256 kPa (23 kg/cm<sup>2</sup>, 327 psi)</p>	<p>Air in system</p> <p>Case 3 (Refer to page U-15)</p>
 <p>LOW PRESSURE SIDE: 50 cmHg—1.5 kg/cm<sup>2</sup> HIGH PRESSURE SIDE: 7-15 kg/cm<sup>2</sup></p>	<p>Low side: 50 cmHg (2.0 inHg) of Vacuum—147 kPa (1.5 kg/cm<sup>2</sup>, 21.3 psi) High side: 687-1,472 kPa (7-15 kg/cm<sup>2</sup>, 100-213 psi)</p>	<p>Moisture in system</p> <p>Case 4 (Refer to page U-16)</p>
 <p>LOW PRESSURE SIDE: 76 cmHg HIGH PRESSURE SIDE: 6 kg/cm<sup>2</sup></p>	<p>Low side: 76 cmHg (3.0 inHg) of Vacuum High side: Below 589 kPa (6 kg/cm<sup>2</sup>, 85 psi)</p>	<p>No refrigerant circulation</p> <p>Case 5 (Refer to page U-16)</p>
 <p>LOW PRESSURE SIDE: 2.5 kg/cm<sup>2</sup> HIGH PRESSURE SIDE: 19-20 kg/cm<sup>2</sup></p>	<p>Low side: Above 245 kPa (2.5 kg/cm<sup>2</sup>, 35.6 psi) High side: 1,864-1,962 kPa (19-20 kg/cm<sup>2</sup>, 270-284 psi)</p>	<p>Expansion valve stuck open</p> <p>Case 6 (Refer to page U-17)</p>
 <p>LOW PRESSURE SIDE: 4-6 kg/cm<sup>2</sup> HIGH PRESSURE SIDE: 7-10 kg/cm<sup>2</sup></p>	<p>Low side: 392-589 kPa (4-6 kg/cm<sup>2</sup>, 57-85 psi) High side: 687-981 kPa (7-10 kg/cm<sup>2</sup>, 100-142 psi)</p>	<p>Faulty compressor</p> <p>Case 7 (Refer to page U-17)</p>

**Case 1: Insufficient refrigerant****Measured pressure**

**Low-pressure side: Less than 78.5 kPa (0.8 kg/cm<sup>2</sup>, 11.4 psi)**


**High-pressure side: 785—883 kPa (8—9 kg/cm<sup>2</sup>, 114—128 psi)**

**Condition**

- **Outlet air from vents not cold.**
- **Bubbles seen in sight glass.**

**Step 1**

1. Check for oil stains on the pipes, hoses and other parts. (Refer to illustration below.)
2. If oil staining is found at the connection of pipes or hoses, replace the O-ring; then, evacuate, charge, and test the system.
3. If oil staining is not found, go to Step 2.



05U0UX-023

**Step 2**

1. Check for leakage from the following connections with a gas leak tester.
  - Inlet and outlet of condenser.
  - Inlet and outlet of receiver/drier.
  - Inlet and outlet of compressor.
  - Sight glass.
  - Inlet and outlet of cooling unit.
2. If leakage is evident, go to Step 3.
3. If leakage cannot be found, evacuate, charge, and test the system. (System OK, but refrigerant leaked gradually over time.)

**Step 3**

1. Check tightening torque of the connection where leak was detected.
2. If the connection is loose, tighten the connection to the specified torque; then evacuate, charge, and test the system.
3. If the connection is properly tightened, replace the O-ring; then evacuate, charge, and test the system.

**Case 2: Excessive refrigerant or insufficient condenser cooling**

**Measured pressure**

Low-pressure side: Above 245 kPa (2.5 kg/cm<sup>2</sup>, 35.6 psi)

High-pressure side: Above 1,962 kPa (20 kg/cm<sup>2</sup>, 284 psi)


**Condition**

Insufficient cooling

**Note**

- If the condenser fan does not operate when the air conditioner is operating, see “Additional (condenser) fan does not operate”; page U–11, before proceeding.


05U0UX-024



9MU0UX-084

**Step 1**

1. Check the condenser for bent fins or damage. Repair or replace if necessary.
2. If the condenser is OK, go to Step 2.



05U0UX-025

**Step 2**

1. Discharge the excessive refrigerant. (Refer to page U–28.)

**Warning**

- Always wear gloves and eye protection when discharging the refrigerant.

2. Verify that the refrigerant pressure is normal.

**Case 3: Air in system**

**Measured pressure**


Low-pressure side: Above 245 kPa (2.5 kg/cm<sup>2</sup>, 35.6 psi)

High-pressure side: Above 2,256 kPa (23 kg/cm<sup>2</sup>, 327 psi)

**Condition**

Insufficient cooling

05U0UX-085



05U0UX-026

**Step 1**

Discharge the refrigeration system. (Refer to page U–28.)

**Step 2**

Evacuate the system to remove all air from it. (Refer to page U–29.)

**Step 3**

Charge the system with refrigerant. (Refer to page U–29.)

**Step 4**

After charging, measure the refrigerant pressure. (Refer to page U–31.)

**Step 5**

If low- and high-pressure sides are still too high, replace the receiver/drier.

### Case 4: Moisture in system

#### Measured pressure

Low-pressure side: 50 cmHg (2.0 inHg) [Vacuum]


High-pressure side: 687—1,472 kPa (7—15 kg/cm<sup>2</sup>, 100—213 psi)

#### Condition

Intermittent cooling

(Moisture in refrigeration system freezes in expansion valve and causes temporary blocking. After time, ice melts and condition returns to normal.)

05U0UX-086



05U0UX-027

#### Step 1

Discharge the refrigeration system. (Refer to page U-28.)

#### Step 2

Evacuate the system to remove all air and moisture from it. (Refer to page U-29.)

#### Step 3

Charge the system with refrigerant. (Refer to page U-28.)

#### Step 4

After charging, measure the refrigerant pressure. (Refer to page U-31.)

#### Step 5

If low- and high-pressure sides are still too high, replace the receiver/drier.

### Case 5: No refrigerant circulation

#### Measured pressure


Low-pressure side: 76 cmHg (3.0 inHg) [Vacuum]

High-pressure side: Below 589 kPa (6 kg/cm<sup>2</sup>, 85 psi)

#### Condition

Refrigerant flow obstructed by moisture or dirt, causing freezing or blockage of expansion valve

05U0UX-087



05U0UX-028

#### Step 1

Turn the air conditioner OFF for about 10 minutes. Turn the air conditioner ON to determine whether the blockage is due to moisture or dirt.

##### a) If caused by moisture

System will operate normally after being OFF for 10 minutes. (Ice melts and relieves blockage.)

Refer to "Moisture in system".

##### b) If caused by dirt

System remains abnormal after being OFF 10 minutes.

Go to Step 2.


#### Step 2

1. Remove the expansion valve. (Refer to page U-33.)

2. Blow out the dirt with compressed air.

3. If unable to remove the dirt, replace the expansion valve.

4. Evacuate, charge, and test the system.



05U0UX-029

## Case 6: Expansion valve stuck open

### Measured pressure


Low-pressure side: Above 245 kPa (2.5 kg/cm<sup>2</sup>, 35.6 psi)

High-pressure side: 1,864—1,962 kPa (19—20 kg/cm<sup>2</sup>, 270—284 psi)

### Condition

Insufficient cooling

05U0UX-088



05U0UX-030

1. Check whether there is frost or heavy dew on the suction pipe (between cooling unit and compressor).
2. If neither is found, refer to "Excessive refrigerant or insufficient condenser cooling"; page U-15.
3. If either is found, replace the expansion valve. (Refer to page U-33.)

## Case 7: Faulty compressor

### Measured pressure


Low-pressure side: 392—589 kPa (4—6 kg/cm<sup>2</sup>, 57—85 psi)

High-pressure side: 687—981 kPa (7—10 kg/cm<sup>2</sup>, 100—142 psi)

### Condition

No cooling

05U0UX-089




05U0UX-031

1. Run the engine at a first idle.
2. Verify that the magnetic clutch is ON when the A/C switch and blower switch are ON.
3. If the magnetic clutch remains OFF, refer to "Magnetic clutch does not operate"; page U-9.

### HEATER

#### STRUCTURAL VIEW



05U0UX-032


1. Heater unit		Blower motor	
Removal / Installation.....	page U-19	Inspection.....	page U-22
Disassembly / Assembly.....	page U-20	Resistor assembly	
Heater core		Inspection.....	page U-22
Inspection.....	page U-20	3. Heater control switch assembly	
2. Blower unit		Removal / Installation.....	page U-23
Removal / Installation.....	page U-21	Disassembly / Assembly.....	page U-24
Disassembly / Assembly.....	page U-22	Inspection.....	page U-25
		Adjustment .....	page U-25

**Note**

- Refer to Section E for engine coolant flow.

## HEATER UNIT Removal / Installation

1. Remove the dashpanel. (Refer to Section S.)
2. Remove the heater unit as shown in the figure.
3. Install the heater unit in the reverse order of removal.
4. Install the dashpanel.



1. Heater hose


2. Heater unit

05U0UX-033



## Disassembly / Assembly


Disassemble and assemble as shown in the figure.



05U0UX-034

- 1. Heater core
- 2. Temperature blend door

- 3. Airflow mode door




05U0UX-035

### Inspection Heater core

1. Check the heater core fins for blockage.
2. If the fins are clogged, clean them.
3. Check the fittings for cracks or other damage. Replace the heater core if necessary.

**BLOWER UNIT****Removal / Installation**

1. Remove the glove box.
2. Remove the blower unit as shown in the figure.
3. Install the blower unit in the reverse order of removal.
4. Install the glove box.




1. Blower unit

05U0UX-036

### Disassembly / Assembly


Disassemble and assemble as shown in the figure.



05U0UX-037

- 1. Blower motor
- 2. Resistor assembly

- 3. REC-FRESH door



05U0UX-038

### Inspection

#### Blower motor

1. Verify that the blower motor runs when connecting 12V to terminal a and grounding terminal b.
2. If the blower motor does not run, replace it.

#### Resistor assembly


1. Check for continuity between terminals of the resistor assembly.

Terminals	Continuity
C—Lo	Yes
C—Me	Yes
C—Mh	Yes
C—Hi	Yes

#### Note

- Set the ohmmeter to the x1,000 range.

2. If not as specified, replace the resistor assembly.




05U0UX-039

## HEATER CONTROL SWITCH ASSEMBLY

### Removal / Installation

Remove and install as shown in the figure.



05U0UX-040

- 1. Center console
- 2. Vent outlet


- 3. Switch panel
- 4. Rec-Fresh wire

### Installation note

- When installing the heater control switch assembly adjust the airflow mode, temperature blend, and Rec-Fresh wires. (Refer to page U-25.)


### Disassembly / Assembly

Disassemble and assemble as shown in the figure.



05U0UX-041

- |                           |                            |
|---------------------------|----------------------------|
| 1. Rec-Fresh wire         | 6. Temperature blend lever |
| 2. Airflow mode wire      | 7. Blower and A/C switch   |
| 3. Temperature blend wire | 8. Panel                   |
| 4. Rec-Fresh lever        | 9. Switch body             |
| 5. Airflow mode lever     |                            |



05U0UX-042

## Inspection Blower and A/C switch


1. Check continuity between terminals of the switch.

Position	Terminal							
	a	b	c	d	e	f	g	h
Blower switch	OFF							
	First	○	—	—	—	—	—	○
	Second			○	—	—	—	○
	Third					○	—	○
	Fourth		○	—	—	—	—	○
A/C switch	OFF							
	ON	○	—	○	—	—	○	

○—○ : Indicates continuity

○—○ : Indicates diode

2. If not as specified, replace the switch.



05U0UX-043


## Adjustment

### Temperature blend wire

1. Set the temperature blend lever to maximum hot position.
2. Connect and clamp the wire with the shutter lever on the heater unit all the way to the right.

### Caution

- After installation, move the temperature blend lever to be sure the wire is securely attached and that it moves the full stroke from **HOT** to **COLD**.




9MU0UX-232

### Airflow mode wire

1. Set the airflow mode control lever to VENT position.
2. Connect and clamp the wire with the shutter lever on the heater unit at its closest point.

### Caution

- After installation, move the airflow mode control lever to be sure the wire is securely attached and that it moves the full stroke from **DEF** to **VENT**.



05U0UX-044

### Rec-Fresh wire


1. Set the Rec-Fresh lever to FRESH position.
2. Connect and clamp the wire with the shutter lever on the blower unit at its closest point.

### Caution

- After installation, move the Rec-Fresh lever to be sure the wire is securely attached and that it moves the full stroke from **REC** to **FRESH**.

### AIR CONDITIONER


#### STRUCTURAL VIEW




05U0UX-045

- 1. Cooling unit  
Removal / Installation..... page U-32  
Disassembly / Assembly..... page U-33
- 2. Compressor  
Removal / Installation..... page U-40


- 3. Magnetic clutch  
Disassembly / Assembly..... page U-41
- 4. Condenser  
Removal / Installation..... page U-35
- 5. Reciver / drier  
Removal / Installation..... page U-35




9MU0UX-125




05U0UX-090



9MU0UX-127



9MU0UX-128



9MU0UX-129

**REFRIGERANT SYSTEM**

**Safety Precaution**


1. R-12 liquid refrigerant is highly volatile. A drop of it on the skin could result in localized frostbite. When handling the refrigerant, be sure to wear gloves.
2. If the refrigerant splashes into the eyes, wash them with clean water immediately. Always wear goggles or glasses to protect the eyes.
3. The R-12 container is a highly pressurized vessel. Never subject it to high heat, and be sure that the temperature where it is stored is below **52°C (125.6°F)**.
4. A halide leak detector is often used to check an A/C system for refrigerant leakage. Remember that R-12, upon coming into contact with the flame, produces phosgene, a toxic gas. Always provide adequate ventilation.

**Basic Procedure of Refrigerant System Service**


**Refrigerant container service valve**

1. Turn the handle fully counterclockwise before connecting the valve to the refrigerant container.
2. Turn the outlet valve counterclockwise until it reaches its highest position.
3. Turn the outlet valve fully clockwise by hand. Connect the center hose to the valve fitting.
4. Turn the handle clockwise to puncture the sealed can.
5. Turn the handle fully counterclockwise to fill the center hose. Do not open the high- or low-pressure manual valves.
6. Loosen the hose nut connected to the center fitting of the manifold gauge. Allow air to escape until gas is expelled; then retighten the nut.







05U0UX-091




05U0UX-046



05U0UX-092



05U0UX-093



05U0UX-094

### Installation of manifold gauge set

#### Note

- Fittings for attaching the manifold gauge set are on the high- and low-pressure pipes.

1. Close both hand valves of the manifold gauge set.
2. Connect the low-pressure hose to the low-pressure gauge fitting and high-pressure hose to the high-pressure gauge fitting.
3. Tighten the hose nuts by hand only.

### Leak test

After evacuating the system (refer to page U-29), check for leaks.

1. Connect a full refrigerant container to the service valve.
2. Open the high-pressure manual valve to charge the system with refrigerant gas.

3. When the low-pressure gauge reads **98 kPa (1 kg/cm<sup>2</sup>, 14 psi)**, close the high-pressure manual valve.
4. Use a gas leak detector to check the system for leaks. If a leak is found, repair the faulty component or connection; then evacuate the system again.


### Discharging

1. Connect the manifold gauge set to the refrigeration system.
2. Place the free end of the center hose on a shop towel.
3. Slowly open the high-pressure manual valve to allow the refrigerant to escape.


#### Caution

- **Open the valve only slightly. If refrigerant is allowed to escape too fast, the compressor oil will be drawn out of the system.**

4. Check the shop towel to make sure no oil is being discharged. If oil is present, partially close the manual valve.
5. After the manifold gauge reading drops below **343 kPa (3.5 kg/cm<sup>2</sup>, 50 psi)**, slowly open the low-pressure manual valve.
6. As the system pressure drops, gradually open both the high- and low-pressure manual valves until both gauges show **0 kPa (0 kg/cm<sup>2</sup>, 0 psi)**.



05U0UX-047



05U0UX-095


## Evacuation

Whenever the refrigeration system has been exposed to the atmosphere, it must be purged of moisture and air.

1. Connect the manifold gauge set. (Refer to page U-28.)
2. Connect the center hose of the gauge set to the vacuum pump inlet.
3. Start the vacuum pump and open both manual valves.
4. When the low-pressure gauge shows approximately **700 mmHg (27.6 inHg)**, close both manual valves and stop the vacuum pump.
5. Verify that the pressure remains the same for **5 minutes** or more. If the pressure changes, check the system for leaks, and repair as necessary.

6. If no leak is found, start the vacuum pump once again and open both manual valves to obtain **760 mmHg (29.9 inHg)**.
7. After the low-pressure gauge shows lower than **760 mmHg (29.9 inHg)**, continue evacuating for **20 minutes**.
8. Close both manual valves and stop the vacuum pump.
9. Disconnect the hose from the vacuum pump.

05U0UX-096



05U0UX-097

## Charging


1. Close the high- and low-pressure manual valves fully after the system is evacuated.
2. Install the refrigerant container service valve.
3. Open the low-pressure manual valve to charge the system with refrigerant gas.

## Note


- When charging of the system becomes slow, run the engine at fast idle and operate the air conditioner.

## Caution


- Be sure to keep the container in the upright position to prevent liquid refrigerant from being charged into the system through the suction side, possibly damaging the compressor.
- Never open the high-pressure manual valve while charging the system with the A/C ON. Doing so may cause the refrigerant can to explode.




96U16X-098



05U0UX-048



05U0UX-049



05U0UX-050

4. Charge the system with the specified amount of refrigerant.

**Specified amount: 800 g (28.24 oz)**

5. Close the low-pressure manual valve and the service valve of the refrigerant container.
6. Carry out a performance test (Refer to below.).
7. Stop the air conditioner and the engine.
8. Quickly disconnect both hoses from the gauge fittings.
9. Put the cap nuts on the gauge fittings.

**Performance test**

After finishing repairs, conduct a performance test of the air conditioning system as follows.

1. Connect the manifold gauge set. (Refer to page U-28.)
2. Start the engine and keep the engine speed at **1,500 rpm**.
3. Operate the air conditioner at maximum cooling.
4. Open all windows and doors.
5. Place a dry-bulb thermometer in the center ventilator outlet.
6. Place a dry and wet thermometer close to the blower inlet.

7. Wait until the air conditioner outlet temperature stabilizes.

**Stabilized condition**

**Blower inlet temperature: 25—35°C (77—95°F)**

**High-pressure side:**

**1,177—1,619 kPa (12.0—16.5 kg/cm<sup>2</sup>, 171—235 psi)**

**Note**

- If the high-pressure side becomes too high, pour cool water on the condenser. If it is too low, cover the front of the condenser.


8. After the air conditioner stabilizes, read the dry and wet thermometer at the air inlet.


9. Calculate the relative humidity from the chart below by comparing the wet- and dry-bulb readings.

05U0UX-051

**HOW TO READ THE GRAPH:**


AFTER MEASURING THE TEMPERATURES OF WET- AND DRY-BULB THERMOMETERS AT THE EVAPORATOR AIR INLET, RELATIVE HUMIDITY (%) CAN BE OBTAINED. EXAMPLE: SUPPOSING DRY- AND WET-BULB TEMPERATURES AT EVAPORATOR AIR INLET ARE 25°C AND 19.5°C RESPECTIVELY THE POINT OF INTERSECTION OF THE DOTTED LINES IN THE GRAPH, AND IS 60%.





96U16X-103

10. Read the dry thermometer at the air outlet, and calculate the difference between the inlet dry bulb and outlet dry bulb temperatures.
11. Verify that the intersection of the relative humidity and temperature difference is in the shaded zone.




9MU0UX-139

### Checking refrigerant charge

1. Run the engine at a fast idle.
2. Operate the air conditioner at maximum cooling for a few minutes.
3. Determine the amount of refrigerant as shown below by observing the sight glass.

Item	Symptom	Amount of refrigerant	Action
1	Bubbles present in sight glass	Insufficient refrigerant	Check refrigerant pressure
2	No bubbles present in sight glass	Too much or proper amount of refrigerant	Turn air conditioner off, and watch bubbles (Refer to Items 3 and 4)
3	Immediately after air conditioner turned off, refrigerant in sight glass stays clear	Too much refrigerant	Check refrigerant pressure
4	When air conditioner turned OFF, refrigerant foams, and then sight glass becomes clear	Proper amount of refrigerant	Refrigerant amount normal

9MU0UX-140



05U0UX-052

### Checking refrigerant pressure

1. Connect the manifold gauge set. (Refer to page U-28.)
2. Operate the engine at 1,500 rpm and set the air conditioner to maximum cooling.
3. Measure the low- and high-pressure sides.

#### Normal pressure

##### Low-pressure side:


147—294 kPa (1.5—3.0 kg/cm<sup>2</sup>, 21—43 psi)

##### High-pressure side:

1,177—1,619 kPa (12.0—16.5 kg/cm<sup>2</sup>, 171—235 psi)

**COOLING UNIT****Removal / Installation**

1. Discharge the refrigerant system. (Refer to page U-28.)
2. Remove the cooling unit as shown in the figure, referring to **Removal Note**.
3. Install the cooling unit in the reverse order of removal, referring to **Installation Note**.
4. Charge the refrigerant system. (Refer to page U-29.)



1. Cooling unit

2. Sealing plate

05U0UX-053

**Removal note**

- Immediately plug all open fittings to keep moisture out of the system.

**Installation note**

- Position the cooling unit so that its connections match those of the heater unit and the blower unit.
- Apply clean compressor oil to the O-rings before connecting the fittings.
- Do not apply compressor oil to the fitting nuts.
- If the evaporator is replaced, add compressor oil to the compressor.

Compressor oil: 50 cc (3.05 cu in)


- Tightening torque:

Inlet pipe	: 9.8—20 N·m (1.0—2.0 m·kg, 7.2—14 ft·lb)
Outlet pipe	: 20—29 N·m (2.0—3.0 m·kg, 14—22 ft·lb)

05U0UX-054

**Disassembly / Assembly**


Disassemble and assemble as shown in the figure.



05U0UX-055

- 1. Evaporator
- 2. Expansion valve

- 3. Thermoswitch



05U0UX-056

**Replacement  
Expansion valve**

**Note**

- Before replacement of the expansion valve, carefully check the refrigeration system, referring to the troubleshooting information on page U-12.

1. Remove the cooling unit. (Refer to page U-32.)
2. Disassemble the cooling unit. Remove the evaporator and expansion valve as an assembly.
3. Disconnect the inlet and outlet pipes.
4. Remove the capillary tube from the outlet pipe and remove the expansion valve.
5. Install in the reverse order of removal, noting the following.

**Note**

- Apply clean compressor oil to the O-rings before connecting the fittings.
- Do not apply compressor oil to the fitting nuts.


**Tightening torque:**

**Inlet pipe:**


12—15 N·m (1.2—1.5 m·kg, 8.7—11 ft·lb)

**Outlet pipe:**


29—34 N·m (3.0—3.5 m·kg, 22—25 ft·lb)




05U0UX-057



05U0UX-058



05U0UX-059



05U0UX-060

### On-vehicle Inspection Thermoswitch

1. Remove the glove box.
2. Run the engine at idle.
3. Turn OFF the A/C switch and set the blower switch to the highest position to operate the blower fan for a few minutes.

4. After a few minutes, turn OFF the blower switch and stop the engine.
5. Disconnect the thermoswitch connector and check for continuity between terminals of the switch.

Terminals	Continuity
a—b	Yes

6. If not as specified, replace the thermoswitch.

#### Note

- The thermoswitch contacts will be open if the evaporator temperature is below 0°C (32°F).

### Inspection Thermoswitch

1. Immerse the sensing bulb in a container of ice water.
2. Check continuity between terminals of the switch as specified.

Terminals	Temperature	Continuity
a—b	Above 0°C (32°F)	Yes
	Below 0°C (32°F)	No

3. If not as specified, replace the thermoswitch.

### Evaporator

1. Check the evaporator fins for blockage. If the fins are clogged, clean them with compressed air.

#### Caution


- Never use water to clean the evaporator.

2. Check the fittings for cracks and other damage. Replace the evaporator if necessary.

**CONDENSER AND RECEIVER/DRIER**

**Removal / Installation**

1. Raise the front of the vehicle at least 300mm (11.8 in) and support it on safety stands.
2. Discharge the refrigerant system. (Refer to page U-28.)
3. Remove the splash shield and air guide.
4. Remove the condenser and receiver/drier as an assembly as shown in the figure, referring to **Removal Note**.
5. Install the condenser and receiver/drier in the reverse order of removal, referring to **Installation Note**.
6. Install the air guide and splash shield.
7. Charge the refrigerant system. (Refer to page U-29.)



05U0UX-061

1. Condenser

2. Receiver/Drier

**Removal note**

- Immediately plug any open fittings to keep moisture out of the system.

**Installation note**

- Apply clean compressor oil to the O-rings before connecting the fittings.
- Do not apply compressor oil to the fitting nuts.
- If the condenser or receiver/drier is replaced, add the specified amount of compressor oil.


Replaced part	Compressor oil amount
Condenser	30 cc (1.83 cu in)
Receiver/drier	10 cc (0.61 cu in)

**Tightening torque:**


Receiver/drier inlet and outlet: 9.8—20 N·m (1.0—2.0 m·kg, 7.2—14 ft·lb)  
 Condenser inlet : 15—25 N·m (1.5—2.5 m·kg, 11—18 ft·lb)

05U0UX-062






05U0UX-063



9MU0UX-190



05U0UX-064

### On-vehicle Inspection

#### Condenser

1. Check for oil stains on the condenser or fittings.
2. If staining is found at a fitting, replace the O-ring at the fitting.
3. Charge the system and check for leaks.
4. If leakage is found at a fitting or the condenser, replace parts as necessary.

5. Check the condenser for the following and repair or replace as necessary.

- (1) Cracks or damage.
- (2) Bent fins.
- (3) Distorted or damaged condenser inlet or outlet.

#### Receiver / drier

1. Check for oil stains on the fittings.
2. If staining is found, replace the O-ring at the fitting.
3. Charge the system and check for leaks.
4. If leakage is found, check and replace the receiver/drier or piping.

## REFRIGERANT LINES

### On-vehicle Inspection

Check for leakage at connections by using a gas leak tester. Repair or replace as necessary.

### Replacement

1. Discharge the refrigerant system. (Refer to page U-28.)
2. Replace the faulty pipe or hose.


### Note

- Immediately plug any open fittings to keep moisture out of the system.

### Tightening torque (fittings):

Location	Tightening torque
①	9.8—20 N·m (1.0—2.0 m·kg, 7.2—14 ft·lb)
②	15—25 N·m (1.5—2.5 m·kg, 11—18 ft·lb)
③	20—29 N·m (2.0—3.0 m·kg, 14—22 ft·lb)
④	9.8—16 N·m (1.0—1.6 m·kg, 7.2—12 ft·lb)

3. Evacuate, charge, and test the refrigerant system.




### CONDENSER FAN Removal / Installation

#### Caution

- Obtain the code number and deactivate the audio anti-theft function before disconnecting the battery cable.


1. Disconnect the negative battery cable.
2. Disconnect the cooling fan connector.
3. Remove the bolts and cooling fan.
4. Remove the condenser fan as shown in the figure.
5. Install the condenser fan in the reverse order of removal.



05U0UX-066

1. Cooling fan

2. Condenser fan




05U0UX-067


#### Inspection

1. Disconnect the condenser fan connector.
2. Verify that the condenser fan motor runs when connecting 12V to terminal a and grounding terminal b.


Connection		Motor operation
12V	Ground	
a	b	Yes




05U0UX-068



05U0UX-069



05U0UX-070



05U0UX-071

**A/C RELAY Inspection**

1. Check continuity between terminals of the relay.

	Terminals					
	a	b	c	d	e	f
Continuity	○ — ○	○ — ○				
	○ — ○	○ — ○	○ — ○	○ — ○		
			○ — ○	○ — ○	○ — ○	
						○ — ○

○ — ○ : Indicates continuity  
 ○ — ◀ — ○ : Indicates diode

2. If not as specified, replace the relay.
3. If correct, go to the next step.
4. Apply 12V to terminal d and ground terminal a.
5. Check continuity between terminals of the relay.

	Terminals		
	c	e	f
Continuity	○ — ○	○ — ○	

○ — ○ : Indicates continuity

6. If not as specified, replace the relay.

**REFRIGERANT PRESSURE SWITCH Inspection**

1. Turn the ignition switch OFF.
2. Connect the manifold gauge set and measure the high-pressure side refrigerant pressure.

**High-pressure side:**  
**Above 216 kPa (2.2 kg/cm<sup>2</sup>, 31.2 psi)**


3. If not as specified, check the refrigerant system. (Refer to page U-12.)
4. If correct, go to the next step.
5. Disconnect the refrigerant pressure switch connector.
6. Check for continuity of the switch.

Terminals	Continuity
a—b	Yes

7. If not as specified, replace the switch and the suction pipe.

**COMPRESSOR****Removal / Installation**

1. Raise the front of the vehicle at least 300mm (11.8 in) and support it with safety stands.
2. Discharge the refrigerant system. (Refer to page U-28.)
3. Remove the splash shield and air guide.
4. Remove the compressor as shown in the figure, referring to **Removal Note**.
5. Install the compressor in the reverse order of removal, referring to **Installation Note**.
6. Install the air guide and splash shield.
7. Charge the refrigerant system. (Refer to page U-29.)



1. Suction hose
2. Discharge hose

3. Compressor

05U0UX-072

**Removal note**

- Immediately plug any open fittings to keep moisture out of the system.

**Installation note**


- Apply clean compressor oil to the O-rings before connecting the fittings.
- Do not apply compressor oil to the fitting nuts.
- Adjust the belt tension to specification. (Refer to page U-43.)

**Tightening torque:**


Compressor inlet and outlet: 9.8—16 N·m (1.0—1.6 m·kg, 7.2—12 ft·lb)

Compressor mounting bolt : 14.7—21.6 N·m (1.5—2.2 m·kg, 10.8—15.9 ft·lb)


05U0UX-073




05U0UX-074




9MU0UX-157



9MU0UX-158



9MU0UX-159



05U0UX-075

**Disassembly / Assembly  
Magnetic clutch**

1. Hold the clutch with the **SST** and remove the shaft nut.

2. Remove the pressure plate with the **SST**.

3. Remove the shims.


4. Remove the snap ring.

5. Remove the rotor by tapping it with a plastic hammer.

**Note**


- Do not damage the pulley when tapping the rotor.

6. Disconnect the stator wires from the compressor housing.



05U0UX-076

7. Remove the snap ring and the stator.



9MU0UX-162


8. Assemble in the reverse order of disassembly, referring to **Assembly note**.

### Assembly note


- **Adjust the clearance between the pressure plate and the rotor after referring to the table and selecting the proper shims.**

**Standard clearance: 0.4—0.6mm (0.016—0.024 in)**

Part No.	Thickness
KA10 61 L12	0.10mm (0.004 in)
KA10 61 L22	0.30mm (0.012 in)
KA10 61 L23	0.50mm (0.020 in)



05U0UX-077




05U0UX-078

### Adjustment Drive belt (With P/S)

1. Loosen P/S oil pump bolts (A) and (B) and nut (C).
2. Adjust the belt tension and deflection to specification by turning adjusting bolt (D).
3. Tighten bolts (A) and (B) and nut (C).


### Tightening torque:

- (A) : 31—46 N·m (3.2—4.7 m·kg, 23—34 ft·lb)
- (B) : 36—54 N·m (3.7—5.5 m·kg, 27—40 ft·lb)
- (C) : 19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)



05U0UX-079

	Specification	
	New	Used
Tension	491—589 N (50—60 kg, 110—132 lb)	422—491 N (43—50 kg, 95—110 lb)
Deflection when applying moderate pressure 98 N (10 kg, 22 lb)	8.0—9.0mm (0.31—0.35 in)	9.0—10.0mm (0.35—0.39 in)




05U0UX-080

### (Without P/S)

1. Loosen the locknut.
2. Adjust the belt tension and deflection to specification by turning the adjusting bolt.

### Tightening torque:

- 37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)



05U0UX-081

	Specification	
	New	Used
Tension	491—589 N (50—60 kg, 110—132 lb)	422—491 N (43—50 kg, 95—110 lb)
Deflection when applying moderate pressure 98 N (10 kg, 22 lb)	8.0—9.0mm (0.31—0.35 in)	9.0—10.0mm (0.35—0.39 in)



# **TECHNICAL DATA**

<b>MEASUREMENTS.....</b>	<b>TD- 2</b>
<b>ENGINE.....</b>	<b>TD- 2</b>
<b>LUBRICATING SYSTEM.....</b>	<b>TD- 4</b>
<b>COOLING SYSTEM.....</b>	<b>TD- 5</b>
<b>FUEL AND EMISSION CONTROL SYSTEMS</b>	<b>TD- 6</b>
<b>ENGINE ELECTRICAL SYSTEM .....</b>	<b>TD- 7</b>
<b>CLUTCH.....</b>	<b>TD- 7</b>
<b>MANUAL TRANSMISSION.....</b>	<b>TD- 8</b>
<b>PROPELLER SHAFT.....</b>	<b>TD- 8</b>
<b>FRONT AND REAR AXLES.....</b>	<b>TD- 9</b>
<b>STEERING SYSTEM .....</b>	<b>TD- 9</b>
<b>BRAKING SYSTEM.....</b>	<b>TD- 9</b>
<b>WHEELS AND TIRES.....</b>	<b>TD-10</b>
<b>SUSPENSION .....</b>	<b>TD-10</b>
<b>BODY ELECTRICAL SYSTEM.....</b>	<b>TD-11</b>
<b>HEATER AND AIR CONDITIONING</b>	
<b>SYSTEM.....</b>	<b>TD-12</b>
<b>STANDARD BOLT AND NUT TIGHTENING</b>	
<b>TORQUE .....</b>	<b>TD-12</b>

05UTDX-001



## A. MEASUREMENTS

Item		Measurements	
Overall length	mm (in)	3,948 (155.4)	
Overall width	mm (in)	1,676 (65.9)	
Overall height	mm (in)	1,224 (48.2)	
Wheelbase	mm (in)	2,266 (89.2)	
Tread	Front	mm (in)	1,410 (55.5)
	Rear	mm (in)	1,428 (56.2)

## B. ENGINE

Item		Engine	B6 DOHC	
Type			Gasoline, 4-cycle	
Cylinder arrangement and number			In-line, 4-cylinders	
Combustion chamber			Pentroof	
Valve system			DOHC, belt-driven 16 valves	
Bore x Stroke		mm (in)	78.0 x 83.6 (3.07 x 3.29)	
Total piston displacement		cc (cu in)	1,597 (97.42)	
Compression ratio			9.4	
Compression pressure kPa (kg/cm <sup>2</sup> , psi)-rpm	Standard		1,324 (13.5, 192)-300	
	Minimum		932 (9.5, 135)-300	
	Maximum difference between each cylinder		196 (2.0, 28)	
Valve timing	IN	Open BTDC	5°	
		Close ABDC	51°	
	EX	Open BBDC	53°	
		Close ATDC	15°	
Valve clearance	mm (in)	IN	0: Maintenance-free	
		EX	0: Maintenance-free	
<b>Cylinder head</b>				
Height		mm (in)	133.8—134.0 (5.268—5.276)	
Distortion		mm (in)	0.15 (0.006) max.	
Grinding		mm (in)	0.20 (0.008) max.	
Cylinder head-to-HLA clearance	mm (in)	Standard	0.025—0.066 (0.0010—0.0026)	
		Maximum	0.18 (0.0071)	
<b>Valve and valve guide</b>				
Valve head diameter	mm (in)	IN	30.9—31.1 (1.217—1.224)	
		EX	26.1—26.3 (1.028—1.035)	
Valve head margin thickness	mm (in)	IN	1.0 (0.039)	
		EX	1.0 (0.039)	
Valve face angle		IN	45°	
		EX	45°	
Valve length	mm (in)	IN	Standard	105.29 (4.1452)
			Minimum	104.79 (4.1256)
	EX	Standard	105.39 (4.1492)	
		Minimum	104.89 (4.1295)	
Valve stem diameter	mm (in)	IN	5.970—5.985 (0.2350—0.2356)	
		EX	5.965—5.980 (0.2348—0.2354)	
Guide inner diameter		mm (in)	6.01—6.03 (0.2366—0.2374)	
Valve stem-to-guide clearance	mm (in)	IN	0.025—0.060 (0.0010—0.0024)	
		EX	0.030—0.065 (0.0012—0.0026)	
		Maximum	0.20 (0.008)	
Guide projection (Height "A")	mm (in)	IN	16.8—17.4 (0.661—0.685)	
		EX	16.8—17.4 (0.661—0.685)	
<b>Valve seat</b>				
Seat angle		IN	45°	
		EX	45°	

Item		Engine	B6 DOHC	
Seat contact width		mm (in)	0.8—1.4 (0.031—0.055)	
Seat sinking		mm (in)	Standard	
		Standard	43.5 (1.713)	
		Maximum	45.0 (1.772)	
		Maximum	45.0 (1.772)	
<b>Valve spring</b>				
Free length		mm (in)	IN	
			Standard	48.0 (1.890)
		EX	Minimum	47.0 (1.850)
			Standard	48.3 (1.902)
Out-of-square		mm (in)	IN	
		EX	1.68 (0.0661) max.	
Setting load/height		N (kg, lb)/mm (in)	IN	
			EX	217—246 (22.1—25.1, 48.6—55.2)/40.0 (1.575)
			174—196 (17.7—20.0, 38.9—44.0)/40.0 (1.575)	
<b>Camshaft</b>				
Cam height		mm (in)	IN	
			Standard	40.888 (1.6098)
		EX	Minimum	40.688 (1.6019)
			Standard	40.889 (1.6098)
Journal diameter		mm (in)	EX	
			Minimum	40.689 (1.6019)
		mm (in)	Standard	
			Standard (No.1—No.5)	25.940—25.965 (1.0213—1.0222)
Camshaft bearing oil clearance		mm (in)	Out-of-round	
			Out-of-round	0.05 (0.002) max.
Camshaft runout		mm (in)	Standard	
			Standard (No.1—No.5)	0.035—0.081 (0.0014—0.0032)
Camshaft end play		mm (in)	Maximum	
			Maximum	0.15 (0.006)
			0.03 (0.0012) max.	
Camshaft end play		mm (in)	Standard	
			Standard	0.07—0.19 (0.0028—0.0075)
			0.20 (0.008)	
<b>Cylinder block</b>				
Height		mm (in)	221.5 (8.720)	
Distortion		mm (in)	0.15 (0.006) max.	
Grinding		mm (in)	0.20 (0.008) max.	
Cylinder bore diameter		mm (in)	Standard size	
			Standard size	78.006—78.013 (3.0711—3.0714)
			0.25 (0.010) oversize	78.256—78.263 (3.0809—3.0812)
Cylinder bore taper and out-of-round		mm (in)	0.50 (0.020) oversize	
			0.50 (0.020) oversize	78.506—78.513 (3.0908—3.0911)
			0.019 (0.0007) max.	
<b>Piston</b>				
Piston diameter		mm (in)	Standard size	
			Standard size	77.954—77.974 (3.0690—3.0698)
			0.25 (0.010) oversize	78.211—78.217 (3.0792—3.0794)
Piston-to-cylinder clearance		mm (in)	0.50 (0.020) oversize	
			0.50 (0.020) oversize	78.461—78.467 (3.0890—3.0892)
			Standard	
			Maximum	
			0.039—0.052 (0.0015—0.0020)	
			0.15 (0.006)	
<b>Piston ring</b>				
Thickness		mm (in)	Top	
			Top	1.47—1.49 (0.0579—0.0587)
End gap (Measured in cylinder)		mm (in)	Second	
			Second	1.47—1.49 (0.0579—0.0587)
Ring groove width in piston		mm (in)	Top	
			Top	0.15—0.30 (0.006—0.012)
			Second	0.15—0.30 (0.006—0.012)
			Oil (rail)	0.20—0.70 (0.008—0.028)
Piston ring-to-ring groove clearance		mm (in)	Maximum	
			Maximum	1.0 (0.039)
			Top	1.52—1.54 (0.0598—0.0606)
			Second	
			Oil	
			4.02—4.04 (0.1583—0.1591)	
Piston ring-to-ring groove clearance		mm (in)	Top	
			Top	0.03—0.07 (0.0012—0.0028)
			Second	0.03—0.07 (0.0012—0.0028)
			Maximum	
			0.15 (0.006)	
<b>Piston pin</b>				
Diameter		mm (in)	19.987—19.993 (0.7869—0.7871)	
Piston-to-piston pin clearance		mm (in)	−0.005—0.013 (−0.0002—0.0005)	
Connecting rod bush-to-piston pin clearance		mm (in)	0.010—0.027 (0.0004—0.0011)	

Item		Engine	B6 DOHC	
<b>Connecting rod and connecting rod bearing</b>				
Length (Center to center)		mm (in)	132.85—132.95 (5.230—5.234)	
Bending		mm (in)	0.075 (0.0030) max./50 (1.97)	
Small end bore (Bush inner diameter)		mm (in)	20.003—20.014 (0.7875—0.7880)	
Big end bore		mm (in)	48.000—48.016 (1.8898—1.8904)	
Big end width		mm (in)	21.838—21.890 (0.8598—0.8618)	
Connecting rod side clearance		mm (in)	Standard	0.110—0.262 (0.0043—0.0103)
			Maximum	0.30 (0.012)
<b>Crankshaft</b>				
Crankshaft runout		mm (in)	0.04 (0.0016) max.	
Main journal diameter		Standard size	Standard	49.938—49.956 (1.9661—1.9668)
			Minimum	49.904 (1.9647)
		0.25 (0.010) undersize	Standard	49.704—49.708 (1.9568—1.9570)
			Minimum	49.652 (1.9548)
		0.50 (0.020) undersize	Standard	49.454—49.458 (1.9470—1.9472)
			Minimum	49.402 (1.9450)
0.75 (0.030) undersize	Standard	49.204—49.208 (1.9372—1.9373)		
	Minimum	49.152 (1.9351)		
Main journal taper and out-of-round		mm (in)	0.05 (0.0020) max.	
Crankpin diameter		Standard size	Standard	44.940—44.956 (1.7693—1.7699)
			Minimum	44.908 (1.7680)
		0.25 (0.010) undersize	Standard	44.690—44.706 (1.7594—1.7601)
			Minimum	44.658 (1.7582)
		0.50 (0.020) undersize	Standard	44.440—44.456 (1.7496—1.7502)
			Minimum	44.408 (1.7483)
0.75 (0.030) undersize	Standard	44.190—44.206 (1.7398—1.7404)		
	Minimum	44.158 (1.7385)		
Crankpin taper and out-of-round		mm (in)	0.05 (0.0020) max.	
<b>Main bearing</b>				
Main journal bearing oil clearance		mm (in)	Standard	0.018—0.036 (0.0007—0.0014)
			Maximum	0.10 (0.004)
Available undersize bearing		mm (in)	0.25 (0.010), 0.50 (0.020), 0.75 (0.030)	
<b>Crankpin bearing</b>				
Crankpin bearing oil clearance		mm (in)	Standard	0.028—0.068 (0.0011—0.0027)
			Maximum	0.10 (0.004)
Available undersize bearing		mm (in)	0.25 (0.010), 0.50 (0.020), 0.75 (0.030)	
<b>Thrust bearing</b>				
Crankshaft end play		mm (in)	Standard	0.080—0.282 (0.0031—0.0111)
			Maximum	0.30 (0.012)
Bearing width		mm (in)	Standard size	2.500—2.550 (0.0984—0.1004)
			0.25 (0.010) oversize	2.625—2.675 (0.1033—0.1053)
			0.50 (0.020) oversize	2.750—2.800 (0.1083—0.1102)
			0.75 (0.030) oversize	2.875—2.925 (0.1132—0.1152)
<b>Timing belt</b>				
Belt deflection		mm (in)/98 N (10 kg, 22 lb)	9.0—11.5 (0.35—0.45)	

### D. LUBRICATION SYSTEM

Item		Engine	B6 DOHC	
Lubricating method			Force-fed	
<b>Oil pump</b>				
Type			Trochoid gear	
Relief pressure		kPa (kg/cm <sup>2</sup> , psi)	343—441 (3.5—4.5, 50—64)	
Oil pressure		kPa (kg/cm <sup>2</sup> , psi)	1,000 rpm	196—294 (2.0—3.0, 28—43)
			3,000 rpm	294—392 (3.0—4.0, 43—57)

Item		Engine	B6 DOHC
Inner rotor tooth tip to outer rotor clearance	mm (in)	Standard	0.02—0.16 (0.0008—0.0063)
		Maximum	0.20 (0.0079)
Outer rotor to body clearance	mm (in)	Standard	0.09—0.18 (0.0035—0.0071)
		Maximum	0.22 (0.0087)
Side clearance	mm (in)	Standard	0.03—0.11 (0.0012—0.0043)
		Maximum	0.14 (0.0055)
<b>Oil filter</b>			
Type		Full-flow, paper element	
Relief pressure differential		kPa (kg/cm <sup>2</sup> , psi)	78—118 (0.8—1.2, 11—17)
<b>Engine oil</b>			
Capacity liters (US qt, Imp qt)	Total (dry engine)		3.6 (3.8, 3.2)
	Oil pan		3.2 (3.4, 2.8)
	Oil filter		0.17 (0.18, 0.15)
Grade		API Service SF or SG	
Viscosity number	Above 30°C (86°F)		SAE 40
	0°C—40°C (32°F—104°F)		SAE 30
	–10°C—20°C (14°F—68°F)		SAE 20W-20
	Above –10°C (14°F)		SAE 20W-40 or 20W-50
	–25°C—30°C (–13°F—86°F)		SAE 10W-30
	Above –25°C (–13°F)		SAE 10W-40 or 10W-50
	Below 0°C (32°F)		SAE 5W-30
Below –20°C (–4°F)		SAE 5W-20	

**E. COOLING SYSTEM**

Item		Engine	B6 DOHC
Cooling method		Water-cooled, forced circulation	
<b>Water pump</b>			
Type		Centrifugal, V-belt driven	
Impeller diameter	mm (in)	75 (2.95)	
Number of impeller blades		6	
Speed ratio		1 : 1.05	
Water seal type		Unified mechanical seal	
<b>Thermostat</b>			
Type		Wax, two-stage	
Opening temperature	°C (°F)	Sub: 83.5—86.5 (182—188), Main: 86.5—89.5 (188—193)	
Full-open temperature	°C (°F)	100 (212)	
Full-open lift	mm (in)	Sub: 1.5 (0.06) min., Main: 8.0 (0.31) min.	
<b>Radiator</b>			
Type		Corrugated fin	
Cap valve opening pressure	kPa (kg/cm <sup>2</sup> , psi)	74—103 (0.75—1.05, 11—15)	
Cooling circuit checking pressure	kPa (kg/cm <sup>2</sup> , psi)	103 (1.05, 15)	
<b>Cooling fan</b>			
Type		Electric	
Number of blades		5	
Outer diameter	mm (in)	320 (12.6)	
Switching temperature OFF → ON	°C (°F)	97 (207)	
Capacity	W—V	70—12	
Current	A	5.3—6.5	
<b>Coolant</b>			
Capacity	liters (US qt, Imp qt)	6.0 (6.3, 5.3)	

Item		Engine	B6 DOHC		
Antifreeze solution	Coolant protection		Volume percentage %		Specific gravity at 20°C (68°F)
			Water	Coolant	
	Above -16°C (3°F)		65	35	1.054
	Above -26°C (-15°F)		55	45	1.066
	Above -40°C (-40°F)		45	55	1.078

## F. FUEL AND EMISSION CONTROL SYSTEMS

Item		Specification	
Idle speed	rpm	850 ± 50 *	
Ignition timing	BTDC	10° ± 1° *	
<b>Throttle body</b>			
Type		Horizontal draft	
Throat diameter	mm (in)	55 (2.2)	
<b>Dashpot</b>			
Adjustment speed	rpm	2,500 ± 150	
<b>Airflow meter</b>			
Resistance	E2 ↔ Vs	Fully closed	200—600
		Fully open	20—1,000
	E2 ↔ Vc		200—400
	E2 ↔ THAA (Intake air thermosensor)	-20°C (-4°F)	13,600—18,400
		20°C (68°F)	2,210—26,90
		60°C (140°F)	493—667
E1 ↔ Fc	Fully closed	∞	
	Fully open	0	
<b>Fuel pump</b>			
Type		Impeller (in-tank)	
Output pressure	kPa (kg/cm <sup>2</sup> , psi)	441—589 (4.5—6.0, 64—85)	
<b>Fuel filter</b>			
Type	Low-pressure side	Nylon element	
	High-pressure side	Paper element	
<b>Pressure regulator</b>			
Type		Diaphragm	
Regulating pressure	kPa (kg/cm <sup>2</sup> , psi)	265—314 (2.7—3.2, 38—46)	
<b>Injector</b>			
Type		High-ohmic	
Type of drive		Voltage	
Resistance	Ω	12—16 (at 20°C, 68°F)	
<b>ISC valve (Solenoid valve [Idle speed control])</b>			
Solenoid resistance	Ω	11—13 (at 20°C, 68°F)	
<b>Circuit opening relay</b>			
Resistance	Ω	STA — E1	21—43
		B — Fc	109—226
		B — FP	∞
<b>Solenoid valve (Purge control)</b>			
Solenoid resistance	Ω	23—27 (at 20°C, 68°F)	
<b>Crank angle sensor</b>			
Type		Optical pickup	
<b>Water thermosensor</b>			
Resistance	kΩ	-20°C (-4°F)	14.6—17.8
		20°C (68°F)	2.2—2.7
		80°C (176°F)	0.29—0.35
<b>Air valve</b>			
Opening temperature	°C (°F)	Below 40 (104)	
<b>Fuel tank</b>			
Capacity	liters (US gal, Imp gal)	45 (11.9, 9.9)	

\*...with system selector (49 B019 9A0) test switch at SELF TEST

Item	Specification
<b>Air cleaner</b>	
Element type	Oil permeated
<b>Accelerator cable</b>	
Free play	mm (in) 1—3 (0.039—0.118)
<b>Fuel</b>	
Specification	Unleaded regular (RON 87 or higher)

**G. ENGINE ELECTRICAL SYSTEM**

Item	Engine model	B6 DOHC	
Battery	Voltage	V 12, Negative ground	
	Type and capacity (5-hour rate)	S46A24L(S) (32Ah) Maintenance-free	
Dark current *	mA	20.0	
Alternator	Type	A.C.	
	Output	V-A 12-60	
	Regulator type	Transistorized (built-in IC regulator)	
	Regulated voltage	14.1—14.7	
	Brush length	mm (in)	Standard 21.5 (0.85)
			Minimum 8 (0.31)
Drive belt tension	mm (in)	New 8—9 (0.31—0.35)	
		Used 9—10 (0.35—0.39)	
Starter	Type	Conventional	
	Output	V-kW 12-0.95 (Others)	
	Brush length	mm (in)	Standard 17.0 (0.67)
			Minimum 11.5 (0.45)
Ignition system	Type	Electronic spark advance (ESA)	
	Spark advance control	Engine control unit controls sparks advance	
Ignition timing	BTDC	10° ± 1° (Test connector grounded)	
Ignition coil	Type	Molded	
	Primary coil winding	kΩ 0.78—0.94	
	Secondary coil winding	kΩ 11.2—15.2	
Spark plug	Type	NGK: BKR5E-11 NIPPON DENSO: K16PR-U11 BKR6E-11 K20PR-U11 BKR7E-11 K22PR-U11	
	Plug gap	mm (in) 1.0—1.1 (0.039—0.043)	
	Firing order	1—3—4—2	

\* Dark current is the constant flow of current while the ignition switch is OFF. (i.e. engine control unit, audio etc.)

**H. CLUTCH**

Item	Engine model	B6 DOHC
Clutch control		Hydraulic
<b>Clutch pedal</b>		
Type		Suspended
Pedal ratio		6.13
Full stroke	mm (in)	120 (4.72)
Height (with carpet)	mm (in)	175—185 (6.89—7.28)
Free play	mm (in)	0.6—3.1 (0.02—0.12)
Distance to carpet when clutch fully disengaged	mm (in) Minimum	68 (2.68)
<b>Flywheel</b>		
Runout limit	mm (in)	0.2 (0.008)
<b>Clutch disc</b>		
Type		Single dry plate

Item		Engine model	B6 DOHC
Runout limit		mm (in)	0.7 (0.028)
Wear limit		mm (in)	0.3 (0.012) from rivet head
Outer diameter		mm (in)	200 (7.87)
Inner diameter		mm (in)	130 (5.12)
Facing thickness	mm (in)	Flywheel side	3.5 (0.14)
		Pressure plate side	3.5 (0.14)
<b>Clutch cover</b>			
Type			Diaphragm spring
Set load		N (kg, lb)	4,022 (410, 902)

### J. MANUAL TRANSMISSION

Item		Transmission model		M-type (M5M-D)
Gear ratio	1st			3.136
	2nd			1.888
	3rd			1.330
	4th			1.000
	5th			0.814
	Reverse			3.758
Oil capacity		liters (US qt, Imp qt)		2.0 (2.1, 1.8)
Mainshaft	Runout	mm (in)	Maximun	0.03 (0.0012)
	Clearance between mainshaft and gear (or bush)	mm (in)	Wear limit	0.15 (0.006)
Reverse idle gear	Clearance between reverse idle gear bushing and shaft	mm (in)	Wear limit	0.15 (0.006)
Shift fork and rod	Clearance between shift fork and clutch sleeve	mm (in)	Wear limit	0.5 (0.020)
	Clearance between shift rod gate and control lever	mm (in)	Wear limit	0.8 (0.031)
Synchronizer ring	Clearance between synchronizer ring and side of gear when fitted	mm (in)	Standard	1.5 (0.059)
			Wear limit	0.8 (0.031)
Shift rod (5th/Reverse) spring	Free length	mm (in)		75 (2.953)
Detent ball spring (1st/2nd)	Free length	mm (in)		22.5 (0.886)
Detent ball spring (3rd/4th)	Free length	mm (in)		22.5 (0.886)
Detent ball spring (5th/Reverse)	Free length	mm (in)		17.0 (0.669)
Lubricant	Above 10°C (50°F)		API Service GL-4 or GL-5 SAE 80W-90	
	All seasons		API Service GL-4 or GL-5 SAE 75W-90	

### L. PROPELLER SHAFT

Item	Specification
Max. permissible run-out	mm (in) 0.4 (0.016)



**M. FRONT AND REAR AXLES**

Item		Transmission model		M5M-D		
Front axle	Type			Double-wishbone		
	Bearing			Angular ball bearing		
	Wheel bearing play	mm (in)	Maximum	0.05 (0.002)		
Rear axle	Type			Double-wishbone		
	Bearing			Angular ball bearing		
	Wheel bearing play	mm (in)	Maximum	0.05 (0.002)		
Differential	Type			Standard	Viscous L.S.D.	
	Reduction gear			Hypoid gear		
	Reduction ratio			4.300		
	Differential gear			Straight-bevel gear		
	Ring gear size	mm (in)		162.16 (6.38)		
	Oil	Grade			API service GL-5	
		Viscosity			Above -18°C (0°F): SAE 90 Below -18°C (0°F): SAE 80W	
		Capacity	liters (Us qt, Imp qt)		0.65 (0.69, 0.57)	
	Drive pinion preload (without oil seal)	N-m (cm-kg, in-lb)		0.3—0.7 (3—7, 2.6—6.1)		
	Backlash	mm (in)	Side gear and pinion gear	0—0.1 (0—0.004)		
			Final gear	0.09—0.11 (0.0035—0.0043)		
	Length (Pilot section to pilot section)	mm (in)		150.20 $\pm$ <sub>0.72</sub> <sup>0</sup> (5.913 $\pm$ <sub>0.028</sub> <sup>0</sup> )		

Viscous L.S.D.: Viscous Limited Slip Differential

**N. STEERING SYSTEM**

Item		Type	Manual steering	Power steering
<b>Steering wheel</b>				
Outer diameter	mm (in)		370 (14.6)	
Free play	mm (in)		0—30 (0—1.18)	
Wheel effort	N (kg, lb)		4.9—29.4 (0.5—3.0, 1.1—6.6)	23.5—35.3 (2.4—3.6, 5.3—8.0)
Lock-to-lock	turns		3.36	2.8
<b>Steering Shaft</b>				
Shaft type	Collapsible, non-tilt			
Joint type	2-cross joint			
<b>Power steering system</b>				
Power assist type	Engine speed sensing			
Gear type	Rack-and-pinion			
Gear ratio	$\infty$ (infinite)			
Rack stroke	mm (in)		121.0 (4.76)	
Power steering fluid	ATF DEXRON-II or M-III			
Fluid capacity	liter (Us qt, Imp qt)		0.8 (0.85, 0.70)	
Fluid pressure	kPa (kg/cm <sup>2</sup> , psi)		7,603—8,339 (77.5—85.0, 1,102—1,209)	

**P. BRAKING SYSTEM**

Item		Specifications
Brake pedal	Height (with carpet)	mm (in) 171—181 (6.73—7.13)
	Free play	mm (in) 4—7 (0.16—0.28)
	Reserve travel (without carpet, clearance when pedal is depressed at 589 N (60 kg, 132 lb))	mm (in) 95 (3.74)
Master cylinder	Type	Tandem
	Bore	mm (in) 22.22 (0.87)
	Fluid type	SAEJ1703 or FMVSS116, DOT-3

Item		Specifications	
Front brake (Disc)	Type	Disc	
	Thickness of pad mm (in)	Standard	9.5 (0.37)
		Limit	1.0 (0.04)
	Thickness of disc plate mm (in)	Standard	18.0 (0.71)
		Limit	16.0 (0.63)
Disc plate runout	mm (in)	0.1 (0.004) max.	
Wheel cylinder bore	mm (in)	51.1 (2.01)	
Rear brake (Disc)	Type	DISC	
	Thickness of pad mm (in)	Standard	8.0 (0.31)
		Limit	1.0 (0.04)
	Thickness of disc plate mm (in)	Standard	9 (0.35)
Limit		7 (0.28)	
Wheel cylinder bore	mm (in)	31.75 (1.25)	
Parking brake	Lever notches [Pulled at 98 N (10 kg, 22 lb)]	5—7	
Power brake unit	Type	Single diaphragm	
	Diameter	mm (in)	214 (8.0)
	Push rod-to-piston clearance	mm (in)	When vacuum applied to the unit is approx. 500 mmHg (19.7 inHg) 0.1—0.3mm (0.004—0.012 in)
	Fluid pressure per treading force	kPa (kg/cm <sup>2</sup> , psi)/N (kg, lb)	1,079—1,177 (11—12, 156—171)/196 (20, 44) at 0 mmHg (0 inHg) min. 5,199—5,494 (53—56, 754—796)/196 (20, 44) at 500 mmHg (19.7 inHg) min.
Rear wheel hydraulic control system	Type	PBV	
	Bend portion (Rear brake pressure)	kPa (kg/cm <sup>2</sup> , psi)	2,943 (30, 427)

### Q. WHEELS AND TIRES

Item	Type	Standard	Temporary spare
Wheel	Size	14 x 5 1/2-JJ	14 x 4T
	Offset	mm (in)	45 (1.77)
	Pitch circle diameter	mm (in)	100 (3.94)
	Material	Aluminum alloy	Steel
Tire	Size	P185/60R14 82H	T115/70D14
	Air pressure	kPa (kg/cm <sup>2</sup> , psi)	177 (1.8, 26) 412 (4.2, 60)
Wheel and tire	Runout limit mm (in)	Horizontal	2.0 (0.079)
		Vertical	1.5 (0.059)
	Maximum unbalance (at rim edge)	g (oz)	10 (0.35)

### R. SUSPENSION

Item		Specifications	
<b>Front suspension</b>			
Type		Double-wishbone	
Stabilizer	Type	Torsion bar	
	Diameter	mm (in)	19 (0.75)
Shock absorbers		Cylindrical double-acting, low-pressure gas charged	
Coil springs	Identification color		Red
	Wire diameter	mm (in)	10.8 (0.43)
	Coil inner diameter	mm (in)	83 (3.27)
	Free length	mm (in)	282.5 (11.12)
	Coil number		5.91

Item		Specifications	
<b>Rear suspension</b>			
Type		Double-wishbone	
Stabilizer	Type	Torsion bar	
	Diameter	12 (0.47) mm (in)	
Shock absorbers		Cylindrical double-acting, low-pressure gas charged	
Coil springs	Identification color	Blue	
	Wire diameter	10.1 (0.40) mm (in)	
	Coil inner diameter	83 (3.27) mm (in)	
	Free length	339.5 (13.37) mm (in)	
	Coil number	7.68	
<b>Wheel alignment</b>			
Front wheel alignment (Unladen* <sup>1</sup> )	Total toe-in	mm (in)	3 ± 3 (0.12 ± 0.12)
		degree	0°18' ± 18'
	Maximum steering angle	Inner	37°23' ± 2°
		Outer	32°32' ± 2°
	Camber angle		0°24' ± 45'* <sup>2</sup>
	Caster angle		4°30' ± 45'
King pin angle		11°20'	
Rear wheel alignment (Unladen* <sup>1</sup> )	Total toe-in	mm (in)	3 ± 3 (0.12 ± 0.12)
		degree	0°18' ± 18'
	Camber angle		-0°43' ± 30'

\*<sup>1</sup> Fuel tank full; radiator coolant and engine oil at specified level, and spare tire, jack, and tools in designated position.

\*<sup>2</sup> Difference between left and right must not exceed 1°.

**T. BODY ELECTRICAL SYSTEM**

Item	Wattage (Bulb trade number)
<b>Instrument cluster lamps</b>	
Beam	3.4
Turn (LH and RH)	3.4
Illumination	3.4
Engine check	1.4
Brake	1.4
Charge	1.4
Belts	1.4
Air bag	1.4
Retractor	1.4
<b>Exterior lights</b>	
Head lights	60/40
Front turn signal/parking lights	27/8 (1157 NA)
Front side marker lights	3.8 (194)
License plate lights	7.5
Rear turn signal lights	27 (1156)
Rear side marker lights	3.8 (194)
Stop/taillights	27/8 (1157)
Back-up lights	27 (1156)
High-mount stoplight	18.4 (921)
<b>Interior lamps</b>	
5	
<b>Illumination lamps</b>	
Ash tray	3.4
Heater control switch panel	1.4
A/C switch	1.4
Hazard switch	1.4
Cruise control main switch	1.4

### U. HEATER AND AIR CONDITIONING SYSTEM

Item		Specifications
Refrigerant amount	g (oz)	800 (28.24)
Compressor oil amount	cc (cc in)	80—100 (4.88—6.1)
Refrigerant normal pressure	kPa (kg/cm <sup>2</sup> , psi)	Low pressure: 147—294 (1.5—3.0, 21—43) High pressure: 1,177—1,619 (12.0—16.5, 171—235)

### STANDARD BOLT AND NUT TIGHTENING TORQUE

Diameter mm (in)	Pitch mm (in)	4T			6T			8T		
		N-m	m-kg	ft-lb	N-m	m-kg	ft-lb	N-m	m-kg	ft-lb
6 (0.236)	1 (0.039)	4.2—6.2	0.43—0.63	3.1—4.6	6.9—9.8	0.7—1.0	5.0—7.2	7.8—11.8	0.8—1.2	5.8—8.8
8 (0.315)	1.25 (0.049)	9.8—14.7	1.0—1.5	7.2—10.8	16—23	1.6—2.3	12—17	18—26	1.8—2.7	13—20
10 (0.394)	1.25 (0.049)	20—28	2.0—2.9	14—21	31—46	3.2—4.7	23—34	36—54	3.7—5.5	27—40
12 (0.472)	1.5 (0.059)	34—50	3.5—5.1	25—37	55—80	5.6—8.2	41—59	63—93	6.4—9.5	46—69
14 (0.551)	1.5 (0.059)	—	—	—	75—103	7.7—10.5	56—76	102—137	10—14	75—101
16 (0.630)	1.5 (0.059)	—	—	—	116—157	12—16	85—116	156—211	16—22	115—156
18 (0.709)	1.5 (0.059)	—	—	—	167—225	17—23	123—166	221—299	23—31	163—221
20 (0.787)	1.5 (0.059)	—	—	—	231—314	24—32	171—231	308—417	31—43	227—307
22 (0.866)	1.5 (0.059)	—	—	—	314—423	32—43	231—312	417—564	43—58	307—416
24 (0.945)	1.5 (0.059)	—	—	—	475—546	41—56	298—403	536—726	55—74	396—536

# **SPECIAL TOOLS**

**GENERAL INFORMATION ..... ST- 2**  
**ENGINE..... ST- 3**  
**CLUTCH AND MANUAL TRANSMISSION ST- 4**  
**DIFFERENTIAL ..... ST- 5**  
**FRONT AND REAR AXLES ..... ST- 6**  
**STEERING SYSTEM ..... ST- 6**  
**BRAKING SYSTEM..... ST- 7**  
**FRONT AND REAR SUSPENSIONS..... ST- 7**  
**CHECKERS AND OTHER EQUIPMENT ... ST- 8**

05USTX-001



### GENERAL INFORMATION

The letters A and B in the priority column indicate the degree of importance of each tool.

A.....Indispensable

The tools ranked A in this list are indispensable for performing operations satisfactorily, easily, safely, and efficiently. It is, therefore, advisable that all service shops have these tools.

B.....Selective







The tools ranked B are not as necessary as tools ranked A, but all service shops should have them to perform repairs more easily and efficiently.







#### **Note**

**When ordering tool sets that consist of several tools, check the List in the Parts Catalogue to make sure that some tools are not duplicated in other sets you may already have. If they are, instead of ordering the set, order only those new tools that are needed.**








05USTX-002








ENGINE

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 0107 680A Engine stand	A	
49 E301 060 Brake, ring gear	A	
49 0636 100A Arm, valve spring lifter	A	
49 B011 102 Lock tool, crankshaft	A	
49 S120 710 Holder, coupling flange	A	
49 9200 145 Adapter set, radiator cap tester	A	

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 L012 0A0 Installer set, valve seal & valve guide	A	
49 L010 1A0 Hanger set, engine stand	A	
49 B012 006 Pivot, valve spring lifter	A	
49 B012 005 Remover & installer, valve guide	A	
49 0221 061A Remover & installer, piston pin	B	
49 S120 170 Remover, valve seal	A	









### CLUTCH AND MANUAL TRANSMISSION








TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 SE01 310 Centering tool, clutch disc	A	
49 0259 440 Holder, mainshaft	A	
49 1243 465A Wrench, main- shaft lock nut	A	
49 0636 145 Puller, fan pulley boss	A	
49 0839 425C Puller set, bearing	A	
49 H017 101 Hook	A	
49 0180 321A Installer, main drive gear bearing	A	

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 1285 071 Puller, bearing	A	
49 0187 451A Guide, interlock pin assembly	B	
49 0862 350 Guide, shift fork assembly	B	
49 0500 330 Installer, bearing	A	
49 0305 430 Pusher, main drive shaft	A	
49 0710 520 Puller, bearing	A	
49 B025 0A0 Installer, dust seal	A	









DIFFERENTIAL

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 N027 001 Gauge block <b>NEW SST</b>	A	
49 N034 213 Installer, rubber bushing <b>NEW SST</b>	A	
49 M005 561 Hanger, differential carrier	A	
49 H027 002 Remover, bearing	A	
49 8531 565 Pinion model	A	
49 H027 001 Collar	A	
49 0727 570 Gauge body, pinion height	A	
49 B001 795 Installer, oil seal	A	




TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 U027 003 Installer, oil seal	A	
49 F027 005 Attachment φ62	A	
49 H033 101 Remover, bearing	A	
49 F401 331 Body	A	
49 F401 336B Attachment B	A	
49 F401 337A Attachment C	A	
49 0259 720 Adjustment wrench, side bearing	B	
—	—	—



### FRONT AND REAR AXLES

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 F026 103 Puller, wheel hub	A	
49 F027 007 Attachment $\phi 72$	A	
49 F027 009 Attachment $\phi 68$ & $\phi 77$	A	



TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 G030 727 Attachment A	A	
49 G033 102 Handle	A	
49 V001 795 Installer, oil seal	A	



### STEERING SYSTEM

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 0118 850C Puller, ball joint	B	
49 1243 785 Installer, dust boot	A	
49 B032 302 Adapter, power steering gauge	A	



TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 1232 670A Gauge set, power steering	A	
49 H002 671 Adapter, power steering gauge	A	
—	—	—



**BRAKING SYSTEM**

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 0221 600C Expand tool, disc brake	A	
49 F043 001 Adjust gauge	A	








TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 0259 770B Wrench, flare nut	A	
49 0208 701A Air out tool, boot	A	







**FRONT AND REAR SUSPENSIONS**

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 G034 1A0 Compressor, coil spring	B	
49 0180 510B Attachment, preload measuring	B	

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 0727 575 Puller, ball joint	B	
49 H028 301 Installer, dust boot	A	

### CHECKERS AND OTHER EQUIPMENT

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 N018 001 Adapter harness (Igniter checker) <b>NEW SST</b>	A	
49 B019 9A0 System Selector <b>NEW SST</b>	A	
49 G018 903 Adapter harness (Engine Signal Monitor) <b>NEW SST</b>	A	
49 G018 904 Sheet (Engine Signal Monitor) <b>NEW SST</b>	A	
49 H018 9A1 Self-Diagnosis Checker	A	
49 9200 020 Tension gauge, V-ribbed belt	B	
49 9200 162 Engine Signal Monitor	A	

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 0839 285 Checker, fuel and thermometer	A	
49 0305 870A Tool set, window	A	
49 F018 002 Igniter Checker	A	
49 9200 165 Tester, throttle sensor	A	
49 9200 166 Adapter, throttle sensor	A	
49 0187 280 Gauge, oil pressure	B	
—	—	—

# PARTS INDEX

## A

A/C RELAY.....	U-	39
ACCELERATOR PEDAL AND CABLE.....	F-	96
AIR BAG MODULE.....	T-	130,150,160
AIR CLEANER.....	F-	92
AIR VALVE.....	F-	98
AIRFLOW METER.....	F-	92,135
ALTERNATOR.....	G-	12
ANTENNA.....	T-	126
AUDIO.....	T-	108
AUDIO UNIT.....	T-	126

## B

BACKUP BATTERY.....	T-	130,151
BACK-UP LIGHT SWITCH.....	T-	73
BATTERY.....	G-	8
BLOWER MOTOR.....	U-	22
BLOWER UNIT.....	U-	21
BRAKE FLUID.....	P-	7
BRAKE PEDAL.....	P-	7

## C

CALIPER (FRONT).....	P-	21
CALIPER (REAR).....	P-	25
CATALYTIC CONVERTER.....	F-	122
CHARCOAL CANISTER.....	F-	120
CIRCUIT OPENING RELAY.....	F-	110
CLOCK SPRING CONNECTOR ...	T-	130,152,159
CLUTCH COVER.....	H-	15,17
CLUTCH DISC.....	H-	15,17
CLUTCH FLUID.....	H-	4
CLUTCH MASTER CYLINDER.....	H-	7
CLUTCH PEDAL.....	H-	5
CLUTCH RELEASE CYLINDER.....	H-	12
CLUTCH SWITCH.....	F-	139
COMPRESSOR.....	U-	40
CONDENSER.....	U-	35
CONDENSER FAN.....	U-	38
CONVERTIBLE TOP.....	S-	61
COOLING FAN.....	U-	38
COOLING FAN RELAY.....	T-	19
COOLING UNIT.....	U-	32
CRANK ANGLE SENSOR.....	F-	134
CRASH SENSOR.....	T-	130,154,157

## D

DASHBOARD AND CONSOLE.....	S-	50
ASHTRAY.....	S-	50
CENTER LOWER PANEL ASSEMBLY.....	S-	50
CENTER PANEL ASSEMBLY.....	S-	50

COLUMN COVER (CANADA).....	S-	50
DASHBOARD.....	S-	50
GLOVE BOX ASSEMBLY.....	S-	50
INSTRUMENT CLUSTER.....	S-	50
METER HOOD ASSEMBLY.....	S-	50
REAR CONSOLE ASSEMBLY.....	S-	50
DASHPOT.....	F-	121
DETACHABLE HARD TOP.....	S-	70
DIAGNOSTIC MODULE.....	T-	130,151
DIFFERENTIAL.....	M-	22
DIFFERENTIAL OIL.....	M-	24
DOOR.....	S-	7
ARMREST.....	S-	9
CHECKER.....	S-	7
DOOR.....	S-	7
DOOR GLASS.....	S-	9
DOOR LOCK ASSEMBLY.....	S-	15
DOOR LOCK STRIKER.....	S-	8
DOOR SCREEN.....	S-	9
DOOR TRIM.....	S-	9,53
GLASS GUIDE.....	S-	9
HINGE.....	S-	7
INNER HANDLE.....	S-	9
KEY CYLINDER.....	S-	15
OUTER HANDLE.....	S-	15
QUARTER GLASS.....	S-	9
REGULATOR HANDLE.....	S-	9
SPEAKER.....	S-	9
WINDOW REGULATOR.....	S-	9
DOOR MIRROR.....	S-	30
DOOR SPEAKERS.....	T-	127,128
DOOR SWITCH.....	T-	88
DRIVE BELT.....	G-	15
DRIVESHAFT.....	M-	16

## E

ENGINE.....	B-	1
BEARING.....	B-	58
CAMSHAFT.....	B-	20,40,52
CAMSHAFT PULLEY.....	B-	20,40,59
CONNECTING ROD.....	B-	57
CRANKSHAFT.....	B-	45,58
CYLINDER BLOCK.....	B-	43,54,66
(EXTERNAL PARTS).....	B-	43,54,66
(INTERNAL PARTS).....	B-	45,54,61
CYLINDER HEAD.....	B-	40,48,70
CYLINDER HEAD COVER.....	B-	12,38
CYLINDER HEAD GASKET.....	B-	16
DRIVE BELT.....	B-	5
ENGINE COOLANT.....	B-	5
ENGINE OIL.....	B-	5
FRONT OIL SEAL.....	B-	24
HLA.....	B-	7,20,54
OIL JET.....	B-	45,55
PISTON.....	B-	45,56

# PARTS INDEX

PISTON PIN.....	B-45,56
PISTON RING.....	B-45,56
PULLEY.....	B- 59
REAR OIL SEAL.....	B- 26
TENSIONER SPRING.....	B- 59
TENSIONER, IDLER.....	B- 59
TIMING BELT.....	B-12,38,59,74
TIMING BELT COVERS.....	B-12,38
VALVE.....	B-40,49
VALVE GUIDE.....	B-40,49
VALVE SEAL.....	B- 40
ENGINE CONTROL UNIT (ECU).....	F-127
ENGINE COOLANT.....	E- 4
ENGINE OIL.....	D- 5
EXHAUST COMPONENTS.....	F-115

## F

FAN MOTOR.....	E- 12
FAN RELAY.....	E- 14
FLOORMAT.....	S- 56
FRONT FLOORMAT.....	S- 56
REAR END MAT.....	S- 56
FLYWHEEL.....	H-15,18
FRONT AXLE.....	M- 5
FRONT BRAKE (DISC).....	P- 18
FRONT BUMPER.....	S- 24
FRONT COMBINATION LIGHT.....	S- 24
FRONT FASCIA.....	S- 24
FRONT SIDE MARKER LIGHT.....	S- 24
FRONT SUSPENSION.....	R- 11
CROSSMEMBER.....	R- 20
LOWER ARM.....	R- 15
SHOCK ABSORBER AND SPRING.....	R- 12
STABILIZER.....	R- 19
UPPER ARM.....	R- 17
FUEL FILLER LID OPENER.....	S- 23
FILLER LID.....	S- 23
FILLER LID OPENER.....	S- 23
OPENER CABLE.....	S- 23
OPENER LEVER.....	S- 23
FUEL FILTER.....	F-106
FUEL PUMP.....	F-107
FUEL TANK.....	F-104
FUEL VAPOR VALVE.....	F-119
FUSE.....	T- 12
FUSE BOX.....	T- 12

## H

HEADLIGHT RELAY.....	T- 19
HEADLIGHT RETRACTOR MOTOR.....	T- 54,56
HEADREST SPEAKERS.....	T-127
HEATER CONTROL SWITCH ASSEMBLY.....	U- 23
HEATER CORE.....	U- 20

HEATER UNIT..... <sup>1</sup>	U- 19
HIGH-MOUNT STOPLIGHT.....	T- 60
HIGH-TENSION LEAD.....	G- 22
HOOD.....	S- 5
HEADLIGHT SEAL.....	S- 5
HINGE.....	S- 5
HOOD.....	S- 5
HOOD LOCK.....	S- 5
RELEASE WIRE.....	S- 5
SIDE HEADLIGHT SEAL.....	S- 5
HORN.....	S- 30
HORN.....	T- 91
ACTUATOR.....	T-104
ACTUATOR CABLE.....	T-106
BRAKE SWITCH.....	T-107
CLUTCH SWITCH.....	T-106
CRUISE CONTROL MAIN SWITCH.....	T-107
CRUISE CONTROL SWITCH.....	T-107
CRUISE CONTROL UNIT.....	T-105
SPEED SENSOR.....	T-107
HORN RELAY.....	T- 19
HORN SWITCH.....	T- 95

## I

IGNITER.....	G- 22
IGNITION COIL.....	G- 21
IGNITION SWITCH.....	T- 21
INJECTOR.....	F-112
INSTRUMENT CLUSTER (METER).....	T- 26
FUEL GAUGE.....	T- 35
FUEL GAUGE SENDER UNIT (IN FUEL TANK).....	T- 36
OIL PRESSURE GAUGE.....	T- 35
OIL PRESSURE SENSOR.....	T- 37
PRINTED CIRCUIT.....	T- 36
SPEED SENSOR.....	T- 36
SPEEDOMETER.....	T- 34
SPEEDOMETER CABLE.....	T- 37
TACHOMETER.....	T- 34
WATER TEMPERATURE GAUGE.....	T- 34
WATER THERMOSENSOR.....	T- 36
INTAKE MANIFOLD.....	F- 95
INTERIOR LAMP SWITCH.....	T- 85
ISC VALVE.....	F- 99

## M

MAGNETIC CLUTCH.....	U- 41
MAIN FUSE BLOCK.....	T- 12
MAIN RELAY (FUEL INJECTOR RELAY)...	F-139
MANUAL STEERING.....	N- 4
BOOT.....	N- 6
STEERING GEAR AND LINKAGE.....	N- 12
STEERING WHEEL AND COLUMN.....	N- 8
MANUAL TRANSMISSION.....	J- 1

# PARTS INDEX

BEARING HOUSING .....	J-20,29
CHANGE CONTROL CASE.....	J- 27
CLUTCH HUB ASSEMBLY. J-16,19,23,31,34	
COUNTERSHAFT.....	J-16,23,34
EXTENSION HOUSING .....	J-13,22,27,42
INTERMEDIATE HOUSING .....	J-15,25,38
MAINSHAFT GEAR ASSEMBLY... J-16,31,34	
SHIFT FORK AND SHIFT ROD .....	J-15,38
SHIFT LEVER.....	J-10,45
SHIFT LEVER KNOB .....	J-10,45
TRANSMISSION CASE .....	J-13,42
TRANSMISSION OIL.....	J- 8
MASTER CYLINDER .....	P- 10
MOLDING AND GARNISH.....	S- 27
REAR FINISHER .....	S- 27

## N

NEUTRAL SWITCH .....	F-140
----------------------	-------

## O

OIL FILTER .....	D- 5
OIL PAN.....	D- 6
OIL PRESSURE.....	D- 4
OIL PUMP (ENGINE).....	D- 9
OXYGEN SENSOR .....	F-138

## P

PANEL LAMP CONTROL SWITCH.....	T- 90
PARKING BRAKE CABLE.....	P- 28
PARKING BRAKE LEVER .....	P- 27
PCV VALVE .....	F-117
PILOT BEARING .....	H-15,18
POWER BRAKE UNIT.....	P- 13
POWER PLANT FRAME (PPF).....	M-27,J-10
POWER STEERING.....	N- 13
BOOT .....	N- 6
DRIVE BELT.....	N- 22
POWER STEERING FLUID.....	N- 16
POWER STEERING OIL PUMP.....	N- 21
STEERING GEAR AND LINKAGE.....	N- 19
STEERING WHEEL AND COLUMN ...	N- 18
POWER STEERING PRESSURE SWITCH..	F-140
POWER WINDOW SYSTEM .....	S- 19
POWER WINDOW MAIN SWITCH ...	S-19,50
POWER WINDOW MOTOR .....	S- 22
POWER WINDOW REGULATOR .....	S-9,19
REAR CONSOLE .....	S-19,50
PRESSURE REGULATOR .....	F-111
PROPELLER SHAFT .....	L- 2
PROPORTIONING BYPASS VALVE (PBV).	P- 16

## R

RADIATOR.....	E- 7
RADIATOR CAP.....	E- 6
REAR AXLE .....	M- 9
REAR BRAKE (DISC).....	P- 22
REAR BUMPER .....	S- 25
REAR BUMPER.....	S- 25
REAR FASCIA.....	S- 26
REAR SIDE MARKER LIGHT .....	S- 25
REAR SUSPENSION .....	R- 21
CROSSMEMBER .....	R- 26
LOWER ARM.....	R- 23
SHOCK ABSORBER AND SPRING .....	R- 22
STABILIZER.....	R- 25
UPPER ARM .....	R- 24
REAR WINDOW (CONVERTIBLE TOP).....	S- 46
REAR WINDOW GLASS (DHT).....	S- 42
RECEIVER/DRIER.....	U- 35
REFRIGERANT PRESSURE SWITCH .....	U- 39
RELAY .....	T- 15
4-TERMINAL NORMALLY OPEN	
RELAY.....	T- 19
DAYTIME RUNNING LIGHTS	
(DRL) UNIT .....	T- 18
HEADLIGHT RETRACTOR RELAY ...	T-16,57
TIMER AND BUZZER UNIT .....	T- 17
TURN AND HAZARD WARNING	
FLASHER UNIT .....	T- 16
RELEASE BEARING.....	H-15,17
RELEASE FORK.....	H- 15
RESISTOR ASSEMBLY.....	U- 22
RESONANCE CHAMBER.....	F- 92
RETRACTABLE HEADLIGHT .....	T- 54

## S

SEAT .....	S- 59
SEAT BELT .....	S- 57
SOLENOID VALVE (PURGE CONTROL) ...	F-119
SPARK PLUG.....	G- 20
STARTER.....	G- 24
STARTER INTERLOCK SWITCH.....	G- 29
STOPLIGHT SWITCH .....	T- 61
SWITCH.....	T- 20
COMBINATION SWITCH .....	T- 21
HAZARD WARNING SWITCH .....	T- 25
HEADLIGHT RETRACTOR RELAY .....	T- 25
STEERING LOCK .....	T- 21

## T

THERMOSTAT .....	E- 8
THROTTLE BODY.....	F- 94
THROTTLE SENSOR .....	F-136

# PARTS INDEX

TNS RELAY .....	T- 19	WASHER MOTOR .....	S- 34
TRIM .....	S- 53	WASHER NOZZLE .....	S- 35
A-PILLAR TRIM.....	S-38,53	WASHER TANK.....	S- 35
DOOR TRIM.....	S-9,53	WIPER ARM AND BLADE .....	S- 35
FRONT HEADER TRIM .....	S-38,53	WIPER MOTOR .....	S- 34
FRONT SIDE TRIM .....	S- 53		
QUARTER TRIM .....	S- 53		
REAR PACKAGE TRIM .....	S-16,53		
SCUFF PLATE .....	S- 53		
SPEAKER GRILLE .....	S- 53		
TRUNK END TRIM .....	S-16,53		
TRUNK LID.....	S- 16		
BALANCE SPRING.....	S- 16		
HINGE.....	S- 16		
KEY CYLINDER.....	S- 18		
REAR COMBINATION LIGHT .....	S- 18		
REAR FINISHER.....	S-18,28		
REAR PACKAGE TRIM .....	S-16,53		
SET PLATE .....	S- 16		
STRIKER .....	S- 18		
TRUNK END TRIM .....	S-18,53		
TRUNK LID.....	S- 16		
TRUNK LID LOCK ASSEMBLY.....	S- 18		
WIRE HARNESS.....	S- 16		
TWO-WAY CHECK VALVE.....	F-119		

## W

WARNING LAMP AND SENDER UNIT .....	T- 38
BACK-UP LIGHTS .....	T- 71
BRAKE FLUID LEVEL SENSOR.....	T- 43
DAYTIME RUNNING LIGHTS (DRL) ...	T- 78
HEADLIGHTS .....	T- 45
ILLUMINATION LAMPS.....	T- 89
INTERIOR LAMPS .....	T- 85
LICENSE PLATE LIGHTS.....	T- 74
PARKING BRAKE SWITCH .....	T- 43
PARKING LIGHTS .....	T- 73
REAR COMBINATION LIGHT LENS....	T- 83
SEAT BELT BUCKLE SWITCH.....	T- 43
SIDE MARKER LIGHTS.....	T- 74
STOPLIGHTS .....	T- 58
TAILLIGHTS.....	T- 74
TURN AND HAZARD WARNING LIGHTS .....	T- 62
WATER PUMP.....	E- 9
WATER THERMOSENSOR.....	F-136
WATER THERMOSWITCH .....	E- 13
WHEELS AND TIRES .....	Q- 3
WINDSHIELD.....	S- 38
A-PILLAR TRIM.....	S-38,53
COWL GRILLE .....	S- 38
FRONT HEADER TRIM .....	S-38,53
SUNVISOR.....	S- 38
WINDSHIELD.....	S- 38
WINDSHIELD WIPER AND WASHER.....	S- 31
FRONT WIPER AND WASHER SWITCH	S- 34



# WIRING DIAGRAM

## SYSTEM INDEX

SYSTEM	SECTION	SYSTEM	SECTION
A/T CONTROL SYSTEM .....	H-1	<b>FEDERAL &amp; CALIFORNIA</b>	
A/T SHIFTLOCK SYSTEM .....	H-2	HEADLIGHTS .....	E-1
ABS (ANTI-LOCK BRAKE SYSTEM) .....	O	HEATER & AIR CONDITIONER.....	G
<b>FEDERAL &amp; CALIFORNIA</b>		HIGH MOUNT STOPLIGHT.....	F-1,2
AIR BAG CONTROL SYSTEM.....	S	HORN .....	F-1,2
AUDIO SYSTEM (TYPE1,2) .....	J-1	IGNITION SYSTEM .....	B-1a
AUDIO SYSTEM (TYPE3).....	J-2	ILLUMINATION LAMPS .....	E-5
BACK-UP LIGHTS .....	F-1,2	INSTRUMENT CLUSTERS .....	C
CHARGING SYSTEM .....	A	INTERIOR LAMPS .....	I
CIGARETTE LIGHTER .....	I	LICENSE PLATE LIGHTS.....	E-4
COOLING FAN SYSTEM .....	B-3	POWER WINDOW .....	K
CPU : SOUND WARNING UNIT .....	T	REAR SIDE MARKER LIGHTS .....	E-4
<b>FEDERAL &amp; CALIFORNIA</b>		STARTING SYSTEM.....	A
CRUISE CONTROL SYSTEM .....	Q	STOPLIGHTS .....	F-1,2
<b>FOR CANADA</b>		TAILLIGHTS .....	E-4
DAYTIME RUNNING LIGHT		<b>FEDERAL &amp; CALIFORNIA</b>	
CONTROL SYSTEM .....	E-3	TURN SIGNAL & HAZARD	
<b>FEDERAL &amp; CALIFORNIA</b>		FLASHER LIGHTS.....	F-1
ENGINE CONTROL SYSTEM .....	B-1a,1b,1c	<b>CANADA</b>	
FRONT FOG LIGHTS (OPTION).....	E-1,2	TURN SIGNAL & HAZAR	
FRONT PARKING LIGHTS .....	E-4	FLASHER LIGHTS.....	F-2
FRONT SIDE MARKER LIGHTS.....	E-4	<b>FEDERAL &amp; CALIFORNIA</b>	
FUEL CONTROL SYSTEM.....	B-2	WINDSHIELD WIPER & WASHER.....	D-1
HEADLIGHT RETRACTOR MOTOR.....	E-1,2	<b>CANADA</b>	
<b>CANADA</b>		WINDSHIELD WIPER & WASHER.....	D-2
HEADLIGHTS .....	E-2		

## WIRING COLOR CODE

Color	Code	Color	Code
Blue	L	Natural	N
Black	B	Orange	O
Brown	BR	Pink	P
Dark Blue	DL	Red	R
Dark Green	DG	Purple	PU
Green	G	Tan	T
Gray	GY	White	W
Light Blue	LB	Yellow	Y
Light Green	LG	Violet	V

# GENERAL INFORMATION

## Contents of and Using Electrical Wiring Diagrams

Contents of wiring diagrams .....	GI-2
Using wiring diagrams .....	GI-2

## Reading Wiring Diagrams

Ground points .....	GI-3
System circuit diagram/connector diagram .....	GI-4
Routing diagram .....	GI-6
Harness symbols .....	GI-7
Symbols .....	GI-8
Logic symbols .....	GI-10
Abbreviations used in this booklet .....	GI-10


## Troubleshooting

Precautions when servicing electrical system .....	GI-11
Handling connectors .....	GI-12
Using electrical test equipment .....	GI-13
Measuring voltage .....	GI-14
Measuring continuity/resistance .....	GI-15
Finding short circuits .....	GI-16

# Z-GI-2 Contents of and Using Electrical Wiring Diagrams

## Contents of wiring diagrams





- This document is composed of the 8 groups shown below. The main components are summarized in the components location diagram at the end of the document.



<b>GI</b>	<b>General information</b>	Tells how to: use and read wiring diagrams, use test equipment, check harnesses and connectors, and locate trouble spots.
<b>Y</b>	<b>Ground points</b>	Ground routes from and to the battery.
<b>W</b>	<b>Electrical wiring schematic</b>	Shows main and other fuses for each system.
<b>A-V</b>	<b>Circuit diagrams for individual systems</b>	Shows circuit and connector diagrams, component and connector location diagrams.
<b>X</b>	<b>Common connectors</b>	Shows connectors common throughout system.
<b>JB</b>	<b>Joint box diagrams</b>	Shows internal circuits and connectors.
<b>PL</b>	<b>Parts location</b>	Shows location of major electrical parts.
<b>PI</b>	<b>Index</b>	Gives page number of circuit diagram for each component.



## Using wiring diagrams

- The use of the wiring diagram depends on its intended application.

Application	Use	Application	Use
For checking circuits of individual systems	 <p>Open to page with circuit diagram and harness routing to be used and fold out common connector diagram or joint box diagram.</p>	For checking fuse connections	 <p>Open to electrical wiring schematic.</p>
For checking ground circuit of individual systems	 <p>Open to page with ground point diagram and fold out common connector diagram or joint box diagram.</p>	For locating page numbers of systems and components	<p>Parts Index      System Index</p>  <p>Open to parts index or system index.</p>

## Ground points

- This shows ground points of the harness.



**On circuit diagrams and ground points**

The ground connection numbers in system circuit diagrams correspond to those in the ground point diagram.

Z

## System circuit diagram/connector diagram

- These show the circuits for each system, from the power supply to the ground. The power supply side is at the top of the page and the ground side is at the bottom. The diagrams describe circuits with the ignition switch OFF.


Below is an explanation of the various points in the diagram.

Indicates operating conditions for switches, etc.

**Connector code.**

The prefix letter indicates the system in which the connector is used.


- JB: Joint box connections
- X : Common connectors
- A : Charging system/starting system connectors
- B : Engine control system connectors
- C : Gauge control system connectors
- D : Wiper system connectors
- E : Lighting system connectors
- F : Signal system connectors
- G : Air conditioning system connectors



**Ground numbers**

A harness ground is represented differently than a physical ground of a unit.

Types of ground	Symbol
<p><b>Harness grounded</b></p>	
<p><b>Unit grounded</b></p> <p>Sensor</p>	




### Connector symbols

- Male and female connectors are represented as follows in the circuit and connector diagrams.

	Circuit diagram symbol	Connector diagram symbol
Male		
Female		

- Like connectors are linked by broken lines between the connector symbols.
- Connector diagrams always show connectors on the harness side. The arrow indicates the view from the harness side.

(Example)




- Colors for connectors other than those that are off white are given in diagrams.
- Unused terminals are indicated by \*.

### Wire color code (harness symbol)

- Two-color wires are indicated by a Two-letter symbol. The first letter indicates the base color of the wire and the second indicates the color of the stripe. For example

W/R is a white wire with a red strip  
 BR/Y is a brown wire with a yellow strip



- The harness symbol is given in the ( ) following the wire color (Refer to GI-7.).


## Routing diagram

- This shows where electrical components are located on the system circuit diagram by lead and connector symbols.
- Specified values are listed beside the routing diagram or on the following page.

Connector symbol	
Shows the system that uses the connector.	
(Example)	
Connector	Symbol
Joint box	JB-04
Common connectors	X-19
System connectors	I-03

**Component name**  
Shows the names of components in routing diagrams.

**Ground symbol**  
Shows the ground in system diagrams.











Engine control unit terminal (unit side)

Terminal	Input	Output	Connection to	Test condition	Voltage	Remark
1X	○		Diagnosis Connector	AI System Selector test switch "O <sub>2</sub> MONITOR"	Approx. 12V	
1K	○		Throttle sensor (Idle point)	AI System Selector test switch "SELF-TEST"	Approx. 0V	Ignition switch ON
1D	○		Stoplight switch	Accelerator pedal released	Approx. 12V	
1P	○		Brake pedal depressed	Brake pedal released	0V	
1R	○		P/S pressure switch	Brake pedal depressed	Approx. 12V	
				Ignition switch ON	Approx. 12V	
				P/S ON (at idle)	0V	
				P/S OFF (at idle)	Approx. 12V	
1U	○		Fan switch	Fan operating / Engine coolant temperature (over 93°C (201°F) or diagnosis connector terminal TFA grounded)	Approx. 0V	
				Fan not operating (idle)	Approx. 12V	
1V	○		Headlight switch	Headlights ON (Fast parking, low beam or High beam)	Approx. 12V	
				Headlights OFF	Approx. 0V	
1W	○		Neutral or clutch switch	Neutral position or clutch pedal depressed	Approx. 12V	
				Other conditions	Approx. 12V	
2A	--	--	Ground (Injection)	Constant	0V	
2B	--	--	Ground (Output)	Constant	0V	
2C	--	--	Ground (CPU)	Constant	0V	
2D	--	--	Ground (Pump)	Constant	0V	
2E	○		Crank angle sensor (N <sub>e</sub> signal)	Ignition switch ON	Approx. 0V or 5V	
				Idle	Approx. 12V	
2G	○		Crank angle sensor (G signal)	Ignition switch ON	Approx. 0V or 5V	
				Idle	Approx. 1.5V	
2J	○		Ground	Constant	0V	
2K	○		Airflow meter	Constant	4.5 - 5.5V	
2L	○		Throttle sensor (Power terminal)	Accelerator pedal released	Approx. 5V	
				Accelerator pedal fully depressed	Approx. 0V	
2M	○		Oxygen sensor	Ignition switch ON	0V	
				Idle (Cold engine)	0V	
				Idle (After warm up)	0 - 1V	
				Increase engine speed (After warm up)	0.5 - 1V	
				Decrease engine speed	0 - 0.4V	
2O	○		Airflow meter	Ignition switch ON	Approx. 3.8V	
				Idle	Approx. 3.3V	
2P	○		Airflow sensor (Thermosensor)	At 20°C (68°F)	Approx. 2.5V	
2Q	○		Water thermosensor	Engine coolant temperature 20°C (68°F)	Approx. 2.5V	
				After warm up	Approx. 0.4V	

**Specified values**  
Shows values for determining whether an electrical component is good.























## Harness symbols


































DESCRIPTION OF HARNESS	COLOR	SYMBOL	DESCRIPTION OF HARNESS	SYMBOL
Front harness		(F)	Injection harness	(INJ)
Engine harness		(E)	Air conditioner harness	(AC)
Instrument panel harness		(I)	Door No.1 harness	(DR1)
Rear harness		(R)	Door No.2 harness	(DR2)













## Symbols

Symbol	Meaning	Symbol	Meaning																																																																										
<p>Battery</p> 	<ul style="list-style-type: none"> <li>Generates electricity through chemical reaction</li> <li>Supplies direct current to circuits</li> </ul>	<p>Resistance</p> 	<ul style="list-style-type: none"> <li>A resistor with a constant value</li> <li>Mainly used to protect electrical components in circuits by maintaining rated voltage</li> <li>Reading resistance values &lt;Colored type&gt;</li> </ul> 																																																																										
<p>Ground (1)</p> 	<ul style="list-style-type: none"> <li>Connecting point to vehicle body or other ground wire where current flows from positive to negative terminal of battery</li> <li>Ground (1) indicates a ground point to body through wire harness</li> <li>Ground (2) indicates point where component is grounded directly to body</li> </ul> <p>Remark</p> <ul style="list-style-type: none"> <li>Current will not flow through a circuit if ground is faulty</li> </ul>	<table border="1"> <thead> <tr> <th rowspan="2">Color</th> <th>No.1</th> <th>No.2</th> <th>No.3</th> <th>No.4</th> </tr> <tr> <th>Resistance values</th> <th>Multiplier</th> <th>Tolerance</th> <th></th> </tr> </thead> <tbody> <tr><td>Black</td><td>0</td><td>0</td><td><math>\times 10^0</math></td><td></td></tr> <tr><td>Brown</td><td>1</td><td>1</td><td><math>\times 10^1</math></td><td></td></tr> <tr><td>Red</td><td>2</td><td>2</td><td><math>\times 10^2</math></td><td></td></tr> <tr><td>Orange</td><td>3</td><td>3</td><td><math>\times 10^3</math></td><td></td></tr> <tr><td>Yellow</td><td>4</td><td>4</td><td><math>\times 10^4</math></td><td></td></tr> <tr><td>Green</td><td>5</td><td>5</td><td><math>\times 10^5</math></td><td></td></tr> <tr><td>Blue</td><td>6</td><td>6</td><td><math>\times 10^6</math></td><td></td></tr> <tr><td>Purple</td><td>7</td><td>7</td><td><math>\times 10^7</math></td><td></td></tr> <tr><td>Grey</td><td>8</td><td>8</td><td><math>\times 10^8</math></td><td></td></tr> <tr><td>White</td><td>9</td><td>9</td><td><math>\times 10^9</math></td><td></td></tr> <tr><td>Gold</td><td></td><td></td><td><math>\times 10^{-1}</math></td><td><math>\pm 5\%</math></td></tr> <tr><td>Silver</td><td></td><td></td><td><math>\times 10^{-2}</math></td><td><math>\pm 10\%</math></td></tr> <tr><td></td><td></td><td></td><td></td><td><math>\pm 20\%</math></td></tr> </tbody> </table>		Color	No.1	No.2	No.3	No.4	Resistance values	Multiplier	Tolerance		Black	0	0	$\times 10^0$		Brown	1	1	$\times 10^1$		Red	2	2	$\times 10^2$		Orange	3	3	$\times 10^3$		Yellow	4	4	$\times 10^4$		Green	5	5	$\times 10^5$		Blue	6	6	$\times 10^6$		Purple	7	7	$\times 10^7$		Grey	8	8	$\times 10^8$		White	9	9	$\times 10^9$		Gold			$\times 10^{-1}$	$\pm 5\%$	Silver			$\times 10^{-2}$	$\pm 10\%$					$\pm 20\%$
Color		No.1	No.2		No.3	No.4																																																																							
	Resistance values	Multiplier	Tolerance																																																																										
Black	0	0	$\times 10^0$																																																																										
Brown	1	1	$\times 10^1$																																																																										
Red	2	2	$\times 10^2$																																																																										
Orange	3	3	$\times 10^3$																																																																										
Yellow	4	4	$\times 10^4$																																																																										
Green	5	5	$\times 10^5$																																																																										
Blue	6	6	$\times 10^6$																																																																										
Purple	7	7	$\times 10^7$																																																																										
Grey	8	8	$\times 10^8$																																																																										
White	9	9	$\times 10^9$																																																																										
Gold			$\times 10^{-1}$	$\pm 5\%$																																																																									
Silver			$\times 10^{-2}$	$\pm 10\%$																																																																									
				$\pm 20\%$																																																																									
<p>Ground (2)</p> 		<p>&lt;Numerical type&gt;</p> 																																																																											
<p>Fuse (1)</p>  <p>(box)</p>	<ul style="list-style-type: none"> <li>Melts when current flow exceeds that specified for circuit, stopping current flow</li> </ul> <p>Precautions</p> <ul style="list-style-type: none"> <li>Do not replace with fuses exceeding specified capacity</li> </ul> <p>&lt;Box type&gt;      &lt;Cartridge type&gt;</p>  <p>&lt;Main fuse&gt;      &lt;Fusible link&gt;</p> 	<p>&lt;Numerical type&gt;</p> 																																																																											
<p>Fuse (2)</p>  <p>(Cartridge)</p>			<p>&lt;Numerical type&gt;</p> 																																																																										
<p>Main fuse/Fusible link</p> 			<p>&lt;Numerical type&gt;</p> 																																																																										
<p>Transistor (1)</p> 	<ul style="list-style-type: none"> <li>Electrical switching component</li> <li>Turns on when voltage is applied to the base(B)</li> </ul> 	<p>Motor</p> 	<ul style="list-style-type: none"> <li>Converts electrical energy into mechanical energy</li> </ul>																																																																										
<p>Transistor (2)</p> 		<p>Reading code</p> 		<p>Pump</p> 	<ul style="list-style-type: none"> <li>Pulls in and expels gases and liquids</li> </ul>																																																																								
<p>Lamp</p> 	<ul style="list-style-type: none"> <li>Emits light and generates heat when current flows through filament</li> </ul>	<p>Cigarette lighter</p> 	<ul style="list-style-type: none"> <li>Electrical coil that generates heat</li> </ul>																																																																										

Symbol	Meaning	Symbol	Meaning									
<p>Horn</p> 	<ul style="list-style-type: none"> <li>● Generates sound when current flows.</li> </ul>	<p>Switch (1)</p>  <p>Normally open (NO)</p>	<ul style="list-style-type: none"> <li>● Allows or breaks current flow by opening and closing circuits.</li> </ul>									
<p>Speaker</p> 		<p>Switch (2)</p>  <p>Normally closed (NC)</p>										
<p>Heater</p> 	<ul style="list-style-type: none"> <li>● Generates heat when current flows.</li> </ul>	<p>Harness</p>  <p>(Not connected)</p>	<ul style="list-style-type: none"> <li>● Unconnected intersecting harness.</li>  <li>● Connected intersecting harness.</li>  </ul>									
<p>Speed sensor</p> 		<ul style="list-style-type: none"> <li>● Movement of magnet in speedometer set turns contact within sensor on and off.</li> </ul>		<p>(Connected)</p> 								
<p>Ignition switch</p>  <p>Normally open (NO)</p>		<ul style="list-style-type: none"> <li>● Turning ignition key operates switch contacts to complete various circuits.</li> </ul>										
<p>Relay (1)</p> 	<ul style="list-style-type: none"> <li>● Current flowing through coil produces electromagnetic force causing contact to open or close.</li> </ul>	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th></th> <th style="width: 50%;">Open</th> <th style="width: 50%;">Closed</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Normally open relay (NO)</td> <td style="text-align: center;">  <p>No flow</p> </td> <td style="text-align: center;">  <p>Closed</p> </td> </tr> <tr> <td style="text-align: center;">Normally closed relay (NC)</td> <td style="text-align: center;">  <p>Flow</p> </td> <td style="text-align: center;">  <p>No flow</p> </td> </tr> </tbody> </table>			Open	Closed	Normally open relay (NO)	 <p>No flow</p>	 <p>Closed</p>	Normally closed relay (NC)	 <p>Flow</p>	 <p>No flow</p>
		Open	Closed									
Normally open relay (NO)	 <p>No flow</p>	 <p>Closed</p>										
Normally closed relay (NC)	 <p>Flow</p>	 <p>No flow</p>										
<p>Relay (2)</p>  <p>Normally closed (NC)</p>												
<p>Sensor (variable)</p> 	<ul style="list-style-type: none"> <li>● Resistor whose resistance changes with operation of other components.</li> </ul>	<p>Diode</p> 	<ul style="list-style-type: none"> <li>● Known as a semiconductor rectifier, diode allows current flow in one direction only</li> </ul> <p style="font-size: small;">Cathode(K) ← Anode(A) ← Flow of electric current</p> <p style="font-size: x-small;">K-□-A K-□-A K-□-A</p>									
<p>Sensor (thermistor)</p> 	<ul style="list-style-type: none"> <li>● Resistor whose resistance changes with temperature.</li> </ul>	<p>Light emitting diode (LED)</p> 	<ul style="list-style-type: none"> <li>● Diode that lights when current flows</li> <li>● Unlike ordinary light bulbs, diode does not generate heat when lit</li> </ul> <p style="font-size: small;">Cathode(K) ← Anode(A)</p>  <p style="font-size: small;">Cathode(K) Anode(A) Flow of electric current</p>									
<p>Capacitor</p> 	<ul style="list-style-type: none"> <li>● Component that temporarily stores electrical charge.</li> </ul>	<p>Reference(zener) diode</p> 	<ul style="list-style-type: none"> <li>● Allows current to flow in one direction up to a certain voltage, allows current to flow in other direction once that voltage is exceeded.</li> </ul>									
<p>Solenoid</p> 	<ul style="list-style-type: none"> <li>● Current flowing through coil generates electromagnetic force to operate plungers, etc.</li> </ul>											

## Logic symbols

Types of logic symbols	Operation	Expressing output	Simple relay circuits
<p>OR</p> 	Input to A or B will produce output at C	Low electrical potential (L) at A and B → No output (L) at C High electrical potential (H) at A or B → Output (H) at C	
<p>AND</p> 	Input to A and B will produce output at C	High electrical potential (H) at A and B → Output (H) at C Low electrical potential (L) at A or B → No output (L) at C	
<p>INV</p> 	No input to A will produce an output at B Input to A will not produce any output at B	Low electrical potential (L) at A → Ungrounds (H) B High electrical potential (H) at A → Grounds (L) B	
<p>PROCESS</p> 	Simplified representation of complex functions within circuit Describes main function 1.Signal detector for emission control unit, cooling unit and tachometer 2.Signal converter for turn and hazard flasher unit,breakerless transistor igniter unit, etc.		<p>(Examples)</p> <p>Breakerless transistor igniters</p> 

## Abbreviations used in this booklet

**A** Ampere  
**AAS** Auto Adjusting Suspension  
**ABS** Anti-lock Brake System  
**ACV** Air Control Valve  
**AE** Acoustic Equilibration  
**AIS** Air Injection System  
**ALL** Automatic Load Leveling  
**AS** Auto Stop  
**ASV** Air Supply Valve  
**A/C** Air Conditioner  
**A/F** Air Fuel  
**A/R** Auto Reverse  
**A/T** Automatic Transmission  
**ACC** Accessory  
**ACCEL** Accelerator  
**ADD** Additional  
**ALT** Alternator  
**AM** Amplitude Modulation  
**AMP** Amplifier  
**ANT** Antenna  
**ATP** Atmospheric Pressure  
**ATX** Automatic Transaxle  
**B** Battery  
**BAC** By-pass Air Control Valve  
**B/L** Bi-Level  
**CPU** Central Processing Unit  
**CSD** Cold Start Device  
**CARB** Carburetor  
**CCT** Circuit  
**CIGAR** Cigarette  
**COMBI** Combination  
**CON** Conditioner  
**CONT** Control  
**DOHC** Double Overhead Camshaft  
**DEF** Defroster  
**ECPS** Electronically Controlled Power Steering  
**EGR** Exhaust Gas Recirculation


**ELR** Emergency Locking Retractor  
**ELEC** Electric  
**ETR** Electronic Tuner  
**EXH** Exhaust  
**F** Front  
**FICB** Fast Idle Cam Breaker  
**FL** Front Left  
**FR** Front Right  
**F/B** Feedback  
**F/I** Fuel Injector  
**FM** Frequency Modulation  
**GEN** Generator  
**HEI** High Energy Ignition  
**H/D** Heat/Defroster  
**HEAT** Heater  
**HI** High  
**ISC** Idle Speed Control  
**IG** Ignition  
**ILLUMI** Illumination  
**INT** Intermittent  
**JB** Joint Box  
**LH** Left Hand  
**LCD** Liquid Crystal Display  
**LO** Low  
**LW** Low Wave  
**M** Motor  
**MIL** Malfunction Indicator Lamp  
**MTR** Mechanical Tuning Radio  
**M/T** Manual Transmission  
**MID** Middle  
**MIN** Minute  
**MIX** Mixture  
**MPX** Multiplex  
**MTX** Manual Transaxle  
**MW** Middle Wave  
**NC** Normally Closed  
**NO** Normally Open  
**OD** Over Drive  
**OFF** Switch Off

**ON** Switch On  
**P** Power  
**PRCV** Pressure Regulator Control  
**SOL** Solenoid Valve  
**PTC** Positive Temperature Coefficient Heater  
**P/S** Power Steering  
**PRG** Purge Solenoid Valve  
**QSS** Quick Start System  
**R** Rear  
**RH** Right Hand  
**RL** Rear Left  
**RPM** Revolution Per Minute  
**RR** Rear Right  
**REC** Recirculation  
**SOL** Solenoid  
**ST** Start  
**SW** Short Wave  
**SW** Switch  
**TCV** Twin Scroll Turbocharger Solenoid Valve  
**TICS** Triple Induction Control System  
**TEMP** Temperature  
**TR** Transistor  
**TWS** Total Wiring System  
**V** Volt  
**VRIS** Variable Resonance Induction System  
**VENT** Ventilation  
**VOL** Volume  
**W** Watt


## Precautions when servicing electrical system

- Note the following items when servicing the electrical system.
- Do not alter the wiring or electrical equipment in any way as this may damage the vehicle or cause a fire due to shorting or overcapacity of a circuit.

- Always disconnect the negative (-) battery cable first and reconnect it last when disconnecting the battery.



- Replace blown fuses with ones having the same designated capacity.




### Caution

- Be sure that the ignition and other switches are OFF before disconnecting or connecting the battery terminals. Failure to do so may damage the semi-conductor components.


### Caution

- Replacing a fuse with one of a larger capacity than designated may damage components or cause an electrical fire.


- Secure harnesses with a clamp when provided to take up any slack.



- Tape areas of the harness that may rub or bump against sharp edges to protect it from damage.



- Be sure that the harness is not caught or damaged when mounting components.







### Caution

- Clamp all harnesses near vibrating components (e.g. the engine) to remove any slack and prevent contact due to vibration.

- Disconnect heat sensitive parts (e.g. relays, ECU) when performing maintenance where temperatures may exceed 80°C (176°F) (i.e. welding).

- Make sure that the connectors are securely connected when installed.















































- Do not handle roughly or drop electrical components.














## Handling connectors

**Caution**

- Be sure to grasp the connectors, not the wires, when disconnecting them.


Connector removal		Checking connector engagement	Checking for loose terminal	Repairing terminal														
Push type		<p>Caution Improperly engaged connectors will cause poor terminal contact.</p> 	<p>Caution A loose terminal will cause poor terminal contact.</p> 	<p>&lt;CPU connector&gt;</p>  <ol style="list-style-type: none"> <li>1. Open the rear cover.</li> <li>2. Lift the tab with a small screwdriver and remove the terminal.</li> </ol>														
				<p>Using a matching male terminal make sure there is no looseness in the female terminal.</p> 	<p>Verify that terminals are not pushed out of the connector when engaged.</p> 	<p>&lt;General connector&gt;</p>  <p>Lift the tab with a small screwdriver and remove the terminal.</p>												
						<p>Using a matching male terminal make sure there is no looseness in the female terminal.</p> 	<p>Verify that terminals are not pushed out of the connector when engaged.</p> 	<p>&lt;Round connectors&gt;</p>  <ol style="list-style-type: none"> <li>1. Open the cover.</li> <li>2. Lift the terminal to remove it.</li> <li>3. Verify that the terminal is securely mounted in the connector when reinstalling.</li> </ol>										
								<p>Using a matching male terminal make sure there is no looseness in the female terminal.</p> 	<p>Verify that terminals are not pushed out of the connector when engaged.</p> 	<p>&lt;Common ground connector&gt;</p>  <ol style="list-style-type: none"> <li>1. Open the cover.</li> <li>2. Remove A.</li> <li>3. Lift the tab with a small screwdriver and remove the terminal.</li> </ol>								
										<p>Using a matching male terminal make sure there is no looseness in the female terminal.</p> 	<p>Verify that terminals are not pushed out of the connector when engaged.</p> 	<p>Lightly pull each wire to verify that the terminal does not pull out of the connector.</p> 						
													<p>Using a matching male terminal make sure there is no looseness in the female terminal.</p> 	<p>Verify that terminals are not pushed out of the connector when engaged.</p> 				
															<p>Using a matching male terminal make sure there is no looseness in the female terminal.</p> 	<p>Lightly pull each wire to verify that the terminal does not pull out of the connector.</p> 		
																	<p>Using a matching male terminal make sure there is no looseness in the female terminal.</p> 	<p>Lightly pull each wire to verify that the terminal does not pull out of the connector.</p> 
																		
Pull up type		<p>Using a matching male terminal make sure there is no looseness in the female terminal.</p> 	<p>Lightly pull each wire to verify that the terminal does not pull out of the connector.</p> 	<p>Lightly pull each wire to verify that the terminal does not pull out of the connector.</p> 														
					<p>Using a matching male terminal make sure there is no looseness in the female terminal.</p> 	<p>Lightly pull each wire to verify that the terminal does not pull out of the connector.</p> 												
							<p>Using a matching male terminal make sure there is no looseness in the female terminal.</p> 	<p>Lightly pull each wire to verify that the terminal does not pull out of the connector.</p> 										
									<p>Using a matching male terminal make sure there is no looseness in the female terminal.</p> 									
Spring type		<p>Using a matching male terminal make sure there is no looseness in the female terminal.</p> 	<p>Lightly pull each wire to verify that the terminal does not pull out of the connector.</p> 	<p>Lightly pull each wire to verify that the terminal does not pull out of the connector.</p> 														

## Using electrical test equipment

Equipment	Use	Operation	Handling precautions
<p>Test lamp</p> 	<p>Test for locating open or shorted circuits.</p>	<ul style="list-style-type: none"> <li>● Connect the test lamp between the circuit being measured and a ground.</li> <li>● The lamp will light if the circuit is energized to the point tested.</li> </ul> 	<ul style="list-style-type: none"> <li>● Test lamps use 12V 1.4 or 3.4W bulbs or light-emitting diodes (LED). Using a large capacity bulb may damage the CPU.</li> </ul>
<p>Jumper wire</p> 	<p>Used to create a temporary circuit.</p>	<ul style="list-style-type: none"> <li>● Connect the jumper wire between the terminals of a circuit to bypass a switch, etc.</li> </ul> 	<ul style="list-style-type: none"> <li>● Do not connect the power side directly to a ground as this may burn the harness or damage electrical components.</li> </ul>
<p>Voltmeter</p> 	<p>Used for measuring the voltage of a circuit to locate possible opens or shorts.</p>	<ul style="list-style-type: none"> <li>● Connect the positive (+) lead to where voltage is to be measured and the negative (-) lead to a ground.</li> </ul> 	<ul style="list-style-type: none"> <li>● Connect the voltmeter in parallel with the circuit.</li> <li>● Set the range to the desired voltage.</li> <li>● Use the service hole when measuring the voltage at the diagnosis connector.</li> <li>● Tie a thin wire to the positive (+) lead to access narrow terminals.</li> </ul> 
<p>Ohmmeter</p> 	<p>Used for locating opens and shorts in the circuit, confirming continuity of switches and checking sensor resistance.</p>	<ul style="list-style-type: none"> <li>● Zero the ohmmeter.</li> <li>● Verify that current is not flowing through the circuit.</li> <li>● Touch the leads to the check points.</li> </ul> 	<ul style="list-style-type: none"> <li>● Zero the meter after switching to the measuring range.</li> <li>● Before using the ohmmeter, make sure that the ignition switch is OFF or the negative (-) battery cable is disconnected to prevent burning the ohmmeter.</li> </ul>
<p>Ammeter</p> 	<p>Used for checking alternator output, current supplied to the starter, and dark current within a circuit.</p> <p>Note Dark current is the current flowing through the circuit when the ignition switch is OFF.</p>	<ul style="list-style-type: none"> <li>● Connect the ammeter in series with the circuit by touching the positive (+) lead to the power side terminal and the negative (-) lead to the ground - side terminal.</li> </ul> 	<ul style="list-style-type: none"> <li>● Set the range to the desired voltage.</li> <li>● Connect the ammeter in series with the circuit. The ammeter may be burned if it is connected in parallel.</li> </ul>

## Measuring voltage

### Checks




1. Use a voltmeter or test lamp to ascertain voltage at the measuring points.

Measuring points	Circuit operation		
	Ignition switch: OFF	Ignition switch: ON	
		Thermo switch: OFF	Thermo switch: ON
Ⓐ	0V ×	12V ☉	12V ☉
Ⓑ	0V ×	12V ☉	0V ×
Ⓒ	0V ×	0V ×	0V ×
Ⓓ	12V ☉	12V ☉	12V ☉
Ⓔ	0V ×	0V ×	12V ☉
Ⓕ	0V ×	0V ×	0V ×

☉ : Test lamp ON  
 × : Test lamp OFF


### Precautions during checks

#### Measuring voltage of connectors



A voltmeter lead may momentarily connect a terminal when inserted into the connector and give an erroneous reading when checking for improperly engaged connectors, poor terminal contacts, or loose terminals.


#### Measuring voltage of ground unit



Touch the voltmeter lead to the ground wire when checking the ground circuit.

## Measuring continuity/resistance


### Checking switches



Touch the ohmmeter leads to the switch terminals to check continuity.

**Caution**  
Verify the operating state of the switch before checking continuity because readings vary accordingly.

### Checking diodes




Continuity is checked according to the direction of the positive (+) and negative (-) leads of the ohmmeter in the circuit containing the diode.

Connection	Continuity
	Yes
	No

**Remark**  
The negative (-) lead of the ohmmeter is connected to the positive terminal of the internal ohmmeter battery. The positive (+) lead to the negative terminal of the battery.


### Checking sensors, solenoid valves



Connect the ohmmeter leads to the sensor or solenoid valve terminals to check resistance.

**Caution**  
Verify the operating state of the sensor before checking resistance because readings vary accordingly.

### Checking condensers



1. Short between the terminals with a jumper wire to discharge the capacitor.
2. Set the ohmmeter range to  $\times 10k \Omega$  and connect it to the capacitor terminals.
3. The capacitor is good if the needle of the ohmmeter swings once and returns to its original position.







## Finding short circuits

Shorts occur between the power(positive) and ground(negative) sides of a circuit.





Therefore, finding a short circuit requires determining how the circuit is routed.

### Circuits not connected to control unit

	Examples		Finding short circuit
	Short location	Indication	
Short (A)	<ul style="list-style-type: none"> <li>Fuse melts.</li> </ul> 	 <ol style="list-style-type: none"> <li>Remove the fuse and main fuse of the circuit.</li> <li>Disconnect all connectors of electrical components in the circuit.</li> <li>Attach a voltmeter or test lamp to the fuse box and reconnect each connector, beginning nearest the power source.</li> <li>Check the voltmeter or see if the test lamp lights as the connectors are connected.</li> </ol>	
Short (B)	<ul style="list-style-type: none"> <li>Main fuse melts.</li> </ul> 		
Short (C)	<ul style="list-style-type: none"> <li>The motor operates regardless of whether the is ON or OFF when the ignition switch is ON.</li> <li>The fuse is not melted.</li> </ul>		
Short (D)	<ul style="list-style-type: none"> <li>The main fuse melts when the ignition switch and thermo-switch are ON and the relay is operating.</li> </ul>		

A short has occurred where the voltmeter reading changes or the test lamp lights.

### Circuits connected to control unit

	Examples		Finding short circuit
	Short location	Indication	
Short (A)	<ul style="list-style-type: none"> <li>Fuse melts.</li> </ul> 	 <ol style="list-style-type: none"> <li>Remove the fuse and main fuse of the circuit.</li> <li>Disconnect all connectors of electrical components in the circuit.</li> <li>Attach a voltmeter or test lamp to the fuse box and reconnect each connector, beginning nearest the power source.</li> <li>Check the voltmeter or see if the test lamp lights as the connectors are connected.</li> </ol>	
Short (B)	<ul style="list-style-type: none"> <li>Solenoid A operates normally when the ignition switch is ON.</li> </ul>		
Short (C)	<ul style="list-style-type: none"> <li>The CPU transistor burns out when the ignition switch is turned ON.</li> </ul>		
Short (D)	<ul style="list-style-type: none"> <li>The CPU thinks the switch is ON because the same conditions exist as when the switch is ON.</li> </ul>		
Short (E)	<ul style="list-style-type: none"> <li>The CPU senses the sensor to be 0 Ω because the conditions exist as when resistance value is 0 Ω</li> <li>The CPU equipped with the self-diagnosis function outputs the malfunction code.</li> </ul>	 <ol style="list-style-type: none"> <li>Attach the test lamp or voltmeter to the CPU connector.</li> <li>Connect to the switch/sensor connector.</li> <li>Check the voltmeter or see if the test lamp lights.</li> </ol>	

A short has occurred where the voltmeter reading changes or the test lamp lights.

A short has occurred where voltmeter reads 0V or the test lamp goes out.




# Z WIRING DIAGRAM


FEDERAL & CALIFORNIA ■ JOINT CONNECTOR & GROUND CIRCUIT  
 WIRING ORDER INTO THE JOINT CONNECTOR MAY BE CHANGED

Y-1


JC-01 JOINT CONNECTOR (F)





JC-02 JOINT CONNECTOR (F)




JC-03 JOINT CONNECTOR (F)



JC-04 JOINT CONNECTOR (F)



Y-1




# Z WIRING DIAGRAM


CANADA ■ JOINT CONNECTOR & GROUND CIRCUIT  
 WIRING ORDER INTO THE JOINT CONNECTOR MAY BE CHANGED

Y-2


JC-01 JOINT CONNECTOR (F)





JC-02 JOINT CONNECTOR (F)







JC-03 JOINT CONNECTOR (F)



JC-04 JOINT CONNECTOR (F)



Y-2




# Z WIRING DIAGRAM

## FEDERAL & CALIFORNIA ELECTRICAL WIRING SCHEMATIC

NOTE: ——— CURRENT FROM BATTERY  
 - - - - - CURRENT FROM 101 TERMINAL OF IGNITION SWITCH  
 - - - - - CURRENT FROM 102 TERMINAL OF IGNITION SWITCH  
 - - - - - CURRENT FROM ACC TERMINAL OF IGNITION SWITCH  
 - - - - - OTHERS


W-1



# WIRING DIAGRAM Z

W-2 CANADA ■ ELECTRICAL WIRING SCHEMATIC

NOTE: ——— CURRENT FROM BATTERY  
 - - - - - CURRENT FROM I02 TERMINAL OF IGNITION SWITCH  
 - · - · - CURRENT FROM ACC TERMINAL OF IGNITION SWITCH  
 - · - · - OTHERS






# Z WIRING DIAGRAM

## STARTING SYSTEM ■ CHARGING SYSTEM


A



6

A-01 STARTER (E)	A-02 INHIBITOR SWITCH (E)	A-03 ALTERNATOR (E)	A-04 ALTERNATOR (E)	A-05 STARTER INTERLOCK SWITCH (F)		


WIRING DIAGRAM Z




# Z WIRING DIAGRAM

## ENGINE CONTROL SYSTEM ■ IGNITION SYSTEM

B-1a




<b>B1-01 ENGINE CONTROL UNIT (F)</b> <table border="1"> <tr> <td>R/B</td><td>L/O</td><td>LG/B</td><td>G</td><td>3M</td><td>1K</td><td>1Y</td><td>1G</td><td>1E</td><td>1C</td><td>1A</td> </tr> <tr> <td>BR/W</td><td>B/L</td><td>B/G</td><td>EL/Y</td><td>R</td><td>*</td><td>L/B</td><td>BR</td><td>W/Y</td><td>W/G</td><td>W/R</td> </tr> <tr> <td>1V</td><td>1I</td><td>1G</td><td>1H</td><td>1C</td><td>1B</td><td>2M</td><td>2X</td><td>2U</td><td>2V</td><td>2G</td><td>2E</td> </tr> <tr> <td>*</td><td>L/O</td><td>Y</td><td>*</td><td>L/W</td><td>R</td><td>(R/B)</td><td>LG/R</td><td>B/W</td><td>Y/L</td><td>W</td><td>B/LG</td><td>B</td> </tr> <tr> <td>*</td><td>Y/R</td><td>Y/B</td><td>*</td><td>*</td><td>R/G</td><td>R/L</td><td>LG/W</td><td>*</td><td>R/W</td><td>(B)</td><td>*</td><td>B/LG</td><td>B</td> </tr> <tr> <td>2Z</td><td>2A</td><td>2V</td><td>2I</td><td>2H</td><td>2F</td><td>2N</td><td>2L</td><td>2J</td><td>2P</td><td>2Q</td><td>2D</td><td>2A</td> </tr> </table> <p>( ) ... CANADA &lt; &gt; ... WITH POWER STEERING ( ) ... A/T</p>										R/B	L/O	LG/B	G	3M	1K	1Y	1G	1E	1C	1A	BR/W	B/L	B/G	EL/Y	R	*	L/B	BR	W/Y	W/G	W/R	1V	1I	1G	1H	1C	1B	2M	2X	2U	2V	2G	2E	*	L/O	Y	*	L/W	R	(R/B)	LG/R	B/W	Y/L	W	B/LG	B	*	Y/R	Y/B	*	*	R/G	R/L	LG/W	*	R/W	(B)	*	B/LG	B	2Z	2A	2V	2I	2H	2F	2N	2L	2J	2P	2Q	2D	2A	<b>B1-02 MAIN RELAY: IN THE RELAY &amp; MAIN FUSE BOX (E)</b> <table border="1"> <tr> <td>W/G</td><td>B/W</td> </tr> <tr> <td>W/R</td><td>B</td> </tr> </table>		W/G	B/W	W/R	B
R/B	L/O	LG/B	G	3M	1K	1Y	1G	1E	1C	1A																																																																															
BR/W	B/L	B/G	EL/Y	R	*	L/B	BR	W/Y	W/G	W/R																																																																															
1V	1I	1G	1H	1C	1B	2M	2X	2U	2V	2G	2E																																																																														
*	L/O	Y	*	L/W	R	(R/B)	LG/R	B/W	Y/L	W	B/LG	B																																																																													
*	Y/R	Y/B	*	*	R/G	R/L	LG/W	*	R/W	(B)	*	B/LG	B																																																																												
2Z	2A	2V	2I	2H	2F	2N	2L	2J	2P	2Q	2D	2A																																																																													
W/G	B/W																																																																																								
W/R	B																																																																																								
<b>B1-03 IGNITER (F)</b> <table border="1"> <tr> <td>R</td><td>BR</td><td>B</td><td>B/W</td><td>Y/L</td><td>L</td><td>BR/Y</td><td>W</td> </tr> <tr> <td>H</td><td>G</td><td>F</td><td>E</td><td>D</td><td>C</td><td>B</td><td>A</td> </tr> </table>			R	BR	B	B/W	Y/L	L	BR/Y	W	H	G	F	E	D	C	B	A	<b>B1-04 SOLENOID VALVE (PARGE) (F)</b> <table border="1"> <tr> <td>Y/R</td><td>W/R</td> </tr> </table>		Y/R	W/R	<b>B1-05 SOLENOID VALVE (ISC) (F)</b> <table border="1"> <tr> <td>L/O</td><td>W/R</td> </tr> </table>		L/O	W/R	<b>B1-06 INJECTOR NO. 1 (INJ)</b> <table border="1"> <tr> <td>Y</td><td>W/R</td> </tr> </table>		Y	W/R	<b>B1-07 INJECTOR NO. 2 (INJ)</b> <table border="1"> <tr> <td>Y/B</td><td>W/R</td> </tr> </table>		Y/B	W/R	<b>B1-08 INJECTOR NO. 3 (INJ)</b> <table border="1"> <tr> <td>Y</td><td>W/R</td> </tr> </table>		Y	W/R																																																			
R	BR	B	B/W	Y/L	L	BR/Y	W																																																																																		
H	G	F	E	D	C	B	A																																																																																		
Y/R	W/R																																																																																								
L/O	W/R																																																																																								
Y	W/R																																																																																								
Y/B	W/R																																																																																								
Y	W/R																																																																																								
<b>B1-09 INJECTOR NO. 4 (INJ)</b> <table border="1"> <tr> <td>Y/B</td><td>W/R</td> </tr> </table>		Y/B	W/R	<b>B1-10 CRANK ANGLE SENSOR (F)</b> <table border="1"> <tr> <td>Y/L</td><td>W</td><td>W/R</td><td>B/LG</td> </tr> </table>		Y/L	W	W/R	B/LG	<b>B1-11 POWER CONNECTOR (F)</b> <table border="1"> <tr> <td>*</td> </tr> <tr> <td>L</td><td>*</td> </tr> </table>		*	L	*	<b>B1-12 IGNITION COIL (F)</b> <table border="1"> <tr> <td>W</td><td>R</td><td>L</td> </tr> </table>		W	R	L	<b>B1-13 CONDENSER (F)</b> <table border="1"> <tr> <td>B</td><td>L</td> </tr> </table>		B	L																																																																		
Y/B	W/R																																																																																								
Y/L	W	W/R	B/LG																																																																																						
*																																																																																									
L	*																																																																																								
W	R	L																																																																																							
B	L																																																																																								



# Z WIRING DIAGRAM



## ENGINE CONTROL SYSTEM

B-1b





<p><b>B1-01 ENGINE CONTROL UNIT (F)</b></p> <table border="1"> <tr> <td>R/B</td><td>L/O</td><td>LG/B</td><td>G</td><td>*</td><td>LG/Y</td><td>*</td><td>BR/Y</td><td>Y/B</td><td>V</td><td>L/R</td> </tr> <tr> <td>BR/Y</td><td>B/L</td><td>*</td><td>B/G</td><td>*</td><td>R</td><td>*</td><td>L/B</td><td>BR</td><td>W/Y</td><td>W/R</td> </tr> <tr> <td>(V)</td><td>(L)</td><td>(L)</td><td>(L)</td><td>(L)</td><td>(L)</td><td>(L)</td><td>(L)</td><td>(L)</td><td>(L)</td><td>(L)</td> </tr> </table> <p>( ) ... CANADA &lt; &gt; ... WITH POWER STEERING (V) ... A/T</p>	R/B	L/O	LG/B	G	*	LG/Y	*	BR/Y	Y/B	V	L/R	BR/Y	B/L	*	B/G	*	R	*	L/B	BR	W/Y	W/R	(V)	(L)	(L)	(L)	(L)	(L)	(L)	(L)	(L)	(L)	(L)	<p><b>B1-14 POWER STEERING PRESSURE SWITCH (F)</b></p> <table border="1"> <tr> <td>*</td><td>L/O</td><td>Y</td><td>*</td><td>L/W</td><td>R</td><td>*</td><td>(R/B)</td><td>LG/R</td><td>B/W</td><td>Y/L</td><td>W</td><td>B/LG</td><td>B</td> </tr> <tr> <td>*</td><td>Y/R</td><td>Y/B</td><td>*</td><td>*</td><td>R/G</td><td>R/L</td><td>LG/W</td><td>(X)</td><td>*</td><td>R/W</td><td>(X)</td><td>*</td><td>B/LG</td><td>B</td> </tr> <tr> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> </table>	*	L/O	Y	*	L/W	R	*	(R/B)	LG/R	B/W	Y/L	W	B/LG	B	*	Y/R	Y/B	*	*	R/G	R/L	LG/W	(X)	*	R/W	(X)	*	B/LG	B															<p><b>B1-15 SHORT CONNECTOR (F)</b></p>	<p><b>B1-19 OXYGEN SENSOR (F)</b></p>
R/B	L/O	LG/B	G	*	LG/Y	*	BR/Y	Y/B	V	L/R																																																																					
BR/Y	B/L	*	B/G	*	R	*	L/B	BR	W/Y	W/R																																																																					
(V)	(L)	(L)	(L)	(L)	(L)	(L)	(L)	(L)	(L)	(L)																																																																					
*	L/O	Y	*	L/W	R	*	(R/B)	LG/R	B/W	Y/L	W	B/LG	B																																																																		
*	Y/R	Y/B	*	*	R/G	R/L	LG/W	(X)	*	R/W	(X)	*	B/LG	B																																																																	
<p><b>B1-16 AIRFLOW METER (F)</b></p>	<p><b>B1-17 WATER THERMOSENSOR (INJ)</b></p>	<p><b>B1-18 THROTTLE SENSOR (F)</b></p> <p>A/T</p>	<p>M/T</p>	<p><b>B1-19 OXYGEN SENSOR (F)</b></p>																																																																											

B-1b





B-1c





## Terminal Voltage

### MT

Terminal	Connection to	Abnormal voltage	Possible cause
1A	Battery	Always approx. 0V (Battery OK)	<ul style="list-style-type: none"> <li>ROOM 10A fuse burned</li> <li>Open circuit in wiring from ROOM 10A fuse to ECU terminal 1A</li> </ul>
1B	Main relay	Always approx. 0V	<ul style="list-style-type: none"> <li>Main relay malfunction (Refer to page F-140)</li> <li>Open circuit in wiring from main relay to ECU terminal 1B</li> </ul>
1C	Ignition switch (Starter turn)	Always approx. 0V	<ul style="list-style-type: none"> <li>Open circuit in wiring from starter interlock switch to ECU terminal 1C</li> </ul>
1D	Self Diagnose Checker (Monitor lamp)	Always approx. 0V	<ul style="list-style-type: none"> <li>Main relay malfunction (Refer to page F-140)</li> <li>Open circuit in wiring from main relay to diagnosis connector terminal MEN to ECU terminal 1D</li> <li>Open or short circuit in wiring from diagnosis connector terminal MEN to ECU terminal 1D</li> </ul>
		Always approx. 12V	<ul style="list-style-type: none"> <li>Poor connection at ECU connector</li> <li>ECU malfunction</li> </ul>
1E	Malfunction indicator lamp (MIL)	Always approx. 5V	<ul style="list-style-type: none"> <li>ECU malfunction</li> </ul>
		Always below 2.5V (MIL always ON)	<ul style="list-style-type: none"> <li>Short circuit in wiring from combination meter to ECU terminal 1E</li> <li>ECU malfunction</li> </ul>
		Always below 2.5V (MIL never ON)	<ul style="list-style-type: none"> <li>Open circuit in wiring from combination meter to ECU terminal 1E</li> </ul>
1F	Self Diagnose Checker (Code No.)	Always approx. 12V	<ul style="list-style-type: none"> <li>Poor connection at ECU connector</li> <li>ECU malfunction</li> </ul>
		Always below 2.5V (No display on Self Diagnose Checker)	<ul style="list-style-type: none"> <li>Main relay malfunction (Refer to page F-140)</li> <li>Open circuit in wiring from main relay to diagnosis connector terminal +S</li> </ul>
		Always below 2.5V ("88" is displayed and buzzer sounds continuously)	<ul style="list-style-type: none"> <li>Open or short circuit in wiring from diagnosis connector terminal FEN to ECU terminal 1F</li> <li>Poor connection at ECU connector</li> <li>ECU malfunction</li> </ul>
1G	Igniter	Always approx. 0V	Refer to Code No 01 troubleshooting (Refer to page F-81)
1J	A/C relay	Always below 2.5V (A/C does not operate)	<ul style="list-style-type: none"> <li>A/C relay malfunction (Refer to page U-30)</li> <li>Open circuit in wiring from main relay to A/C relay</li> <li>Open circuit in wiring from A/C relay to ECU terminal 1J</li> </ul>
		Always below 2.5V (A/C switch OFF but A/C operates)	<ul style="list-style-type: none"> <li>Short circuit in wiring from A/C relay to ECU terminal 1J</li> <li>ECU malfunction</li> </ul>
		Always approx. 12V	<ul style="list-style-type: none"> <li>A/C switch malfunction (Refer to page U-25)</li> <li>Poor connection at ECU connector</li> <li>ECU malfunction</li> </ul>
1K	Diagnosis connector (Terminal TEN)	Always approx. 0V	<ul style="list-style-type: none"> <li>Short circuit in wiring from ECU terminal 1K to diagnosis connector terminal TEN</li> </ul>
		Always approx. 12V	<ul style="list-style-type: none"> <li>Open circuit in wiring from ECU terminal 1K to diagnosis connector terminal TEN</li> <li>Open circuit in wiring from diagnosis connector terminal GND to ground</li> </ul>
1N	Throttle sensor (Idle terminal)	Always approx. 0V	<ul style="list-style-type: none"> <li>Throttle sensor misadjustment (Refer to page F-136)</li> <li>Short circuit in wiring from ECU terminal 1N to throttle sensor</li> <li>ECU malfunction</li> </ul>
		Always approx. 12V	<ul style="list-style-type: none"> <li>Throttle sensor misadjustment (Refer to page F-136)</li> <li>Open circuit in wiring from ECU terminal 1N to throttle sensor</li> <li>Open circuit in wiring from throttle sensor to ground</li> </ul>
1O	Stoplight switch	Always approx. 0V (Stoplights ON)	<ul style="list-style-type: none"> <li>Open circuit in wiring from stoplight switch to ECU terminal 1O</li> </ul>
1P	P/S pressure switch	Always approx. 0V	<ul style="list-style-type: none"> <li>P/S pressure switch malfunction (Refer to page F-140)</li> <li>Short circuit in wiring from ECU terminal 1P to P/S pressure switch</li> <li>ECU malfunction</li> </ul>
		Always approx. 12V	<ul style="list-style-type: none"> <li>P/S pressure switch malfunction (Refer to page F-140)</li> <li>Open circuit in wiring from ECU terminal 1P to P/S pressure switch</li> <li>Open circuit in wiring from P/S pressure switch to ground</li> </ul>
1Q	A/C switch	Always approx. 0V (with blower switch ON)	<ul style="list-style-type: none"> <li>A/C switch malfunction (Refer to page U-25)</li> <li>Short circuit in wiring from ECU terminal 1Q to A/C switch</li> <li>Poor connection at ECU connector</li> <li>ECU malfunction</li> </ul>
		Always approx. 12V (with blower switch ON) (Blower fan ON)	<ul style="list-style-type: none"> <li>A/C switch malfunction (Refer to page U-25)</li> <li>Open circuit in wiring from ECU terminal 1Q to A/C switch</li> <li>Open circuit in wiring from A/C switch to blower control switch</li> </ul>
1R	Fan switch	Always approx. 0V (Cooling fan ON)	<ul style="list-style-type: none"> <li>Open or short circuit in wiring from electric cooling fan relay to ECU terminal 1R</li> <li>ECU malfunction</li> </ul>
1S	Blower control switch	Always approx. 0V (Blower fan ON)	<ul style="list-style-type: none"> <li>Short circuit in wiring from blower control switch to ECU terminal 1S</li> <li>Poor connection at ECU connector</li> <li>ECU malfunction</li> </ul>
		Always approx. 12V (Blower fan ON)	<ul style="list-style-type: none"> <li>Open circuit in wiring from blower control switch to ECU terminal 1S</li> </ul>

Terminal	Connection to	Abnormal voltage	Possible cause																			
1U	Headlight switch	Always approx. 0V (Headlights ON)	<ul style="list-style-type: none"> <li>Open or short circuit in wiring from headlight relay to ECU terminal 1U</li> </ul>																			
1V	Neutral switch (Clutch switch (NUT))	Always approx. 0V (NUT)	<ul style="list-style-type: none"> <li>Neutral switch malfunction (Refer to page F-140)</li> <li>Clutch switch malfunction (Refer to page F-139)</li> <li>Short circuit in wiring from ECU terminal 1V to neutral or clutch switch</li> </ul>																			
		Always approx. 12V (NUT)	<ul style="list-style-type: none"> <li>Neutral switch malfunction (Refer to page F-140)</li> <li>Clutch switch malfunction (Refer to page F-139)</li> <li>Open circuit in wiring from ECU terminal 1V to neutral or clutch switch</li> <li>Poor connection at ECU connector</li> </ul>																			
	Inhibitor switch (HAT)	Always approx. 0V (HAT)	<ul style="list-style-type: none"> <li>Inhibitor switch malfunction (Refer to Section K)</li> <li>Short circuit in wiring from inhibitor switch to ECU terminal 1V</li> </ul>																			
		Always approx. 12V (HAT)	<ul style="list-style-type: none"> <li>Inhibitor switch malfunction (Refer to Section K)</li> <li>Open circuit in wiring from inhibitor switch to ECU terminal 1V</li> </ul>																			
2A	Ground	More than 0V	<ul style="list-style-type: none"> <li>Poor contact at ground terminal</li> <li>Open circuit in wiring from ECU to ground</li> </ul>																			
2B																						
2C	2D	2E	2F	2G	2H	2I	2J	2K	2L	2M	2N	2O	2P	2Q	2R	2S	2T	2U	2V	2W	2X	2Y
2A	Ground	More than 0V	<ul style="list-style-type: none"> <li>Poor contact at ground terminal</li> <li>Open circuit in wiring from ECU to ground</li> </ul>																			
2C	Crank angle sensor (NE signal)	Always approx. 0V or approx. 5V	Refer to Code No 02 troubleshooting (Refer to page F-82)																			
2D	Crank angle sensor (G signal)	Always approx. 0V or approx. 5V	Refer to Code No 03 troubleshooting (Refer to page F-82)																			
2H	Ground	Approx. 5V	<ul style="list-style-type: none"> <li>Open circuit in wiring from ECU terminal 2H to ground</li> </ul>																			
	(Federal and Canada)	Approx. 0V	<ul style="list-style-type: none"> <li>Short circuit in wiring from ECU terminal 2H to ground</li> </ul>																			
2I	Igniter	Always Approx. 0V	Refer to Code No 01 troubleshooting (Refer to page F-81)																			
2K	Airflow meter	Always approx. 0V	<ul style="list-style-type: none"> <li>Short circuit in wiring from ECU terminal 2K to airflow meter</li> <li>Poor connection at ECU connector</li> <li>ECU malfunction</li> </ul>																			
		Below 4.5V or above 5.5V	<ul style="list-style-type: none"> <li>ECU malfunction</li> </ul>																			
2L	Throttle sensor (Power terminal) (MT)	Always approx. 0V	<ul style="list-style-type: none"> <li>Throttle sensor malfunction (Refer to page F-136)</li> <li>Short circuit in wiring from ECU terminal 2L to throttle sensor</li> <li>Poor connection at ECU connector</li> <li>ECU malfunction</li> </ul>																			
		Always approx. 5V	<ul style="list-style-type: none"> <li>Throttle sensor misadjustment (Refer to page F-136)</li> <li>Open circuit in wiring from ECU terminal 2L to throttle sensor</li> <li>Open circuit in wiring from throttle sensor to ground</li> </ul>																			
2M	Throttle sensor (HAT)	Always constant	<ul style="list-style-type: none"> <li>Open circuit in wiring from ECU terminal 2M to throttle sensor</li> <li>Open circuit in wiring from ECU terminal 2K to throttle sensor</li> <li>Open circuit in wiring from ECU terminal 2O to throttle sensor</li> </ul>																			
		Always above 1V	<ul style="list-style-type: none"> <li>Throttle sensor misadjustment</li> </ul>																			
2N	Oxygen sensor	0V after warm-up	Refer to Code No 15 troubleshooting (Refer to page F-88)																			
2O	Airflow meter	Always approx. 1V after warm-up	Refer to Code No 17 troubleshooting (Refer to page F-88)																			
		Always approx. 0V or approx. 5V	Refer to Code No 08 troubleshooting (Refer to page F-84)																			
2P	Airflow meter (break at thermometer)	Always approx. 0V or approx. 5V	Refer to Code No 10 troubleshooting (Refer to page F-85)																			
			<ul style="list-style-type: none"> <li>Intake air thermometer malfunction (Refer to page F-133)</li> </ul>																			
2Q	Water thermometer	Always approx. 0V or approx. 5V	Refer to Code No 09 troubleshooting (Refer to page F-85)																			
2U	Injector	Always approx. 0V	<ul style="list-style-type: none"> <li>Main relay malfunction (Refer to page F-140)</li> <li>Open or short circuit in wiring from injector to ECU terminal 2U or 2V</li> </ul>																			
		Always approx. 12V	<ul style="list-style-type: none"> <li>ECU malfunction</li> </ul>																			
2W	ISC valve	Always approx. 0V or approx. 12V	Refer to Code No 34 troubleshooting (Refer to page F-97)																			
			<ul style="list-style-type: none"> <li>ISC valve malfunction (Refer to page F-99)</li> </ul>																			
2X	Solenooid valve (Purge control)	Always approx. 0V or approx. 12V	Refer to Code No 28 troubleshooting (Refer to page F-87)																			
			<ul style="list-style-type: none"> <li>Solenooid valve (purge control) malfunction (Refer to page F-119)</li> </ul>																			
2Y	4AT control unit	Always approx. 12V	<ul style="list-style-type: none"> <li>ECU malfunction</li> </ul>																			

**Terminal Voltage  
AT**


Terminal	Input	Output	Connection to	Test condition	Voltage	Remark
1A	--	--	Battery	Constant	Approx. 12V	For backup
1B	○	--	Main relay	Ignition switch OFF	Approx. 0V	
1C	○	--	Ignition switch (Start position)	Ignition switch ON	Approx. 12V	
				While cranking	Approx. 10V	
1D	○	○	Self-Diagnosis Checker (Monitor lamp)	Ignition switch ON	Approx. 0V	With Self-Diagnosis Checker and System Selector
				Test switch at "SELF-TEST"	Approx. 5V	
				Lamp illuminated for 3 sec. after ignition switch OFF→ON	Approx. 12V	
				Lamp not illuminated after 3 sec.	Approx. 12V	
				Test switch at "O <sub>2</sub> MONITOR" at idle	Approx. 5V	
1E	○	○	Malfunction indicator lamp	Ignition switch ON	Approx. 12V	With System Selector test switch at "SELF-TEST"
				Lamp illuminated for 3 sec. after ignition switch OFF→ON	Below 2.5V	
				Lamp not illuminated after 3 sec.	Approx. 12V	
				Lamp illuminated	Below 2.5V	
1F	○	○	Self-Diagnosis Checker (Code number)	Ignition switch ON	Approx. 12V	• With Self-Diagnosis Checker and System Selector • With System Selector test switch at "SELF-TEST"
				Buzzer sound for 3 sec. after ignition switch OFF→ON	Below 2.5V	
				Buzzer not sounded after 3 sec.	Approx. 12V	
				Buzzer sounded -	Below 2.5V	
1G	○	○	Igniter	Ignition switch ON	Approx. 0V	
				Idle	Approx. 0.2V	
				Ignition switch ON	Approx. 0V	
1H	○	○	Igniter	Idle	Approx. 0.2V	
1I	--	--	--	--	--	--
1J	○	○	A/C relay	Ignition switch ON	Approx. 12V	
				A/C switch ON at idle	Below 2.5V	
				A/C switch OFF at idle	Approx. 12V	
1K	○	○	Diagnosis connector	System Selector test switch at "O <sub>2</sub> MONITOR"	Approx. 12V	
				System Selector test switch at "SELF-TEST"	Approx. 0V	
1L	--	--	--	--	--	--
1M	--	--	--	--	--	--
1N	○	○	Throttle sensor (I/A point)	Accelerator pedal released	Approx. 0V	Ignition switch ON
				Accelerator pedal depressed	Approx. 12V	
1O	○	○	Stoplight switch	Brake pedal released	0V	
				Brake pedal depressed	Approx. 12V	
1P	○	○	P/S pressure switch	Ignition switch ON	Approx. 12V	
				P/S ON (at idle)	0V	
				P/S OFF (at idle)	Approx. 12V	
1Q	○	○	A/C switch	A/C switch ON (Ignition switch ON)	Below 2.5V	Blower motor ON
				A/C switch OFF (Ignition switch ON)	Approx. 12V	
1R	○	○	Fan switch	Fan operating (Engine coolant temperature over 97°C (207°F) or diagnosis connector terminal TFA grounded)	Approx. 0V	
				Fan not operating (idle)	Approx. 12V	
1S	○	○	Blower control switch	Blower control switch at mid, high or super high position	Approx. 0V	Ignition switch ON
				Blower control switch OFF or low	Approx. 12V	
				--	--	
1T	○	○	Headlight switch	Headlights ON (Tail, parking, low beam/ high beam)	Approx. 12V	
				Headlights OFF	0V	
1V	○	○	Neutral or clutch switch (N/T)	Neutral position or clutch pedal depressed	Approx. 0V	
				Other conditions	Approx. 12V	
				Inhibitor switch (4A/T)	Approx. 0V	
	○	○	Inhibitor switch (4A/T)	N or P range	Approx. 0V	
				Other conditions	Approx. 12V	

Terminal	Input	Output	Connection to	Test condition	Voltage	Remark
2A	--	--	Ground (Injector)	Constant	0V	
2B	--	--	Ground (Output)	Constant	0V	
2C	--	--	Ground (CPU)	Constant	0V	
2D	--	--	Ground (Input)	Constant	0V	
2E	○	○	Crank angle sensor (No-signal)	Ignition switch ON	Approx. 0V or 5V	
				Idle	Approx. 2V	
2F	--	--	--	--	--	--
2G	○	○	Crank angle sensor (G-signal)	Ignition switch ON	Approx. 0V or 5V	
				Idle	Approx. 1.5V	
2H	○	○	Ground	Constant	0V	
2I	○	○	Igniter	Federal and Canada spec	Approx. 2V	
				Ignition switch ON	Below 0.5V	
2K	○	○	Airflow meter	Idle	Approx. 1V	
				Constant	4.5-5.5V	
2L	○	○	Throttle sensor (Power terminal)	Accelerator pedal released	Approx. 5V	
				Accelerator pedal fully depressed	Approx. 0V	
2M	○	○	Throttle sensor (4A/T)	Accelerator pedal released	Approx. 0.5V	
				Accelerator pedal fully depressed	Approx. 4.0V	
2N	○	○	Oxygen sensor	Ignition switch ON	0V	
				Idle (Cold engine)	0V	
				Idle (After warm-up)	0-1V	
				Increase engine speed (After warm-up)	0.5-1V	
				Deceleration	0-0.4V	
2O	○	○	Airflow meter	Ignition switch ON	Approx. 3.8V	
				Idle	Approx. 3.3V	
2P	○	○	Airflow sensor (Intake air thermosensor)	At 20°C (68°F)	Approx. 2.5V	
				--	--	
2Q	○	○	Water thermosensor	Engine coolant temperature 20°C (68°F)	Approx. 2.5V	
				After warm-up	Approx. 0.4V	
2R	--	--	--	--	--	--
2S	--	--	--	--	--	--
2T	--	--	--	--	--	--
2U	○	○	Injector (Nos.1, 3) (Nos.2, 4)	Ignition switch ON	Approx. 12V	* Engine Signal Monitor: Green and red lights flash
				Idle	Approx. 12V*	
2V	○	○	ISC valve	Deceleration from 3,000 rpm to 1,900 rpm (After warm-up)	Approx. 12V	
2W	○	○	ISC valve	Ignition switch ON	Approx. 7V	
				Idle	Approx. 9V	
2X	○	○	Solenoid valve (Purge control)	Ignition switch ON	Approx. 12V	
				Idle	Approx. 12V	
2Y	--	--	--	--	--	--
2Z	○	○	4A/T control unit	Ignition switch ON	Approx. 0V	


Z WIRING DIAGRAM

■ FUEL CONTROL SYSTEM

B-2




B2-01 CIRCUIT OPENING RELAY (F)



B2-02 FUEL TANK UNIT (R)




B-2






Z WIRING DIAGRAM


■ COOLING FAN SYSTEM

B-3



<p>B3-01 COOLING FAN RELAY (E) (IN THE RELAY &amp; MAIN FUSE BLOCK)</p> 	<p>B3-02 WATER THERMO-SWITCH (FAN) (F)</p> 	<p>B3-03 COOLING FAN MOTOR (F)</p> 



B-3




# Z WIRING DIAGRAM

## INSTRUMENT CLUSTERS

C









# Z WIRING DIAGRAM

## FEDERAL & CALIFORNIA ■ WINDSHIELD WIPER & WASHER

D-1




<p>D-01 WINDSHIELD WASHER MOTOR (F)</p> <p>WITHOUT ABS</p> <p>WITH ABS</p>	<p>D-02 WINDSHIELD WIPER MOTOR (F)</p>	<p>D-03 COMBINATION SWITCH (WINDSHIELD WIPER &amp; WASHER) (F)</p>
--	--	--



# Z WIRING DIAGRAM


CANADA ■ WINDSHIELD WIPER & WASHER

D-2



D-01 WINDSHIELD WASHER MOTOR (F)	D-02 WINDSHIELD WIPER MOTOR (F)	D-03 COMBINATION SWITCH (WINDSHIELD WIPER & WASHER) (F)
WITHOUT ABS WITH ABS 		


D-2




# Z WIRING DIAGRAM

FEDERAL & CALIFORNIA ■ HEADLIGHTS ■ FRONT FOG LIGHTS (OPTION) ■ HEADLIGHT RETRACTOR MOTOR

E-1




<p>E1-01 HEADLIGHT LH (F)</p>	<p>E1-02 HEADLIGHT RH (F)</p>	<p>E1-03 HEADLIGHT RELAY (LIGHT) (F)</p>	<p>E1-04 HEADLIGHT RETRACTOR MOTOR LH (F)</p>	<p>E1-05 HEADLIGHT RETRACTOR MOTOR RH (F)</p>	<p>E1-06 RETRACTOR RELAY (F)</p>	<p>E1-08 RETRACTOR SWITCH (I)</p>
<p>E1-09 FRONT FOG LIGHTS (F)</p>	<p>E1-10 FRONT FOG LIGHT SWITCH (I)</p>	<p>E1-11 TNS RELAY (F)</p>	<p>D-03 COMBINATION SWITCH (LIGHT) (F)</p>			




# Z WIRING DIAGRAM

CANADA ■ HEADLIGHTS ■ FRONT FOG LIGHTS (OPTION) ■ HEADLIGHT RETRACTOR MOTOR

E-2



<p>E2-01 HEADLIGHT LH (F)</p>	<p>E2-02 HEADLIGHT RH (F)</p>	<p>E2-03 COMBINATION SWITCH (LIGHT) (F)</p>	<p>E2-04 HEADLIGHT RETRACTOR MOTOR LH (F)</p>	<p>E2-05 HEADLIGHT RETRACTOR MOTOR RH (F)</p>	<p>E2-06 RETRACTOR RELAY (F)</p>	<p>E2-07 COMBINATION SWITCH (LIGHT) (F)</p>
<p>E2-08 RETRACTOR SWITCH (I)</p>	<p>E2-09 FRONT FOG LIGHTS (F)</p>	<p>E2-10 FRONT FOG LIGHT SWITCH (I)</p>				






# Z WIRING DIAGRAM

## CANADA ■ DAYTIME RUNNING LIGHT CONTROL SYSTEM

E-3




E3-01 DAYTIME RUNNING LIGHT CONTROL UNIT (F)




E3-02 FRONT TURN SIGNAL LIGHTS LH (F)




E3-03 FRONT TURN SIGNAL LIGHTS RH (F)



E3-04 PARKING BRAKE SWITCH (I)




E-3



# Z WIRING DIAGRAM


- FRONT PARKING LIGHTS ■ LICENSE PLATE LIGHTS ■ TAILLIGHTS
- FRONT SIDE MARKER LIGHTS ■ REAR SIDE MARKER LIGHTS

E-4



E4-01 FRONT SIDE MARKER LIGHT LH (F) 	E4-02 FRONT SIDE MARKER LIGHT RH (F) 	E3-02 FRONT PARKING LIGHT LH (F) E4-03 	E3-03 FRONT PARKING LIGHT RH (F) E4-03 	E4-05 TAILLIGHT LH (R) 	E4-06 TAILLIGHT RH (R) 	E4-07 LICENSE PLATE LIGHT LH (R) 
E4-08 LICENSE PLATE LIGHT RH (R) 	E4-09 REAR SIDE MARKER LIGHTS (R) 					


E-4



# Z WIRING DIAGRAM



## ■ ILLUMINATION LAMPS

E-5



<p>E1-08 HAZARD &amp; RETRACTOR SWITCH ILLUMI (I) E2-08</p> <table border="1"> <tr> <td>D</td> <td>R</td> <td>R/B</td> </tr> <tr> <td>B</td> <td>R/L</td> <td>R/Y/R/G</td> </tr> </table>	D	R	R/B	B	R/L	R/Y/R/G	<p>E1-10 FRONT FOG LIGHT SWITCH ILLUMI (I) E2-10</p> <table border="1"> <tr> <td>*</td> <td>R/B</td> <td>R/B</td> </tr> <tr> <td>*</td> <td>G/Y</td> <td>R</td> </tr> </table>	*	R/B	R/B	*	G/Y	R			
D	R	R/B														
B	R/L	R/Y/R/G														
*	R/B	R/B														
*	G/Y	R														
<p>E5-01 PANEL LAMP CONTROL SWITCH (I)</p> <table border="1"> <tr> <td>B</td> <td><del>X</del></td> <td>R</td> </tr> <tr> <td>*</td> <td>*</td> <td>R/B</td> </tr> </table>	B	<del>X</del>	R	*	*	R/B	<p>E5-02 HEATER CONTROL SWITCH ILLUMI (I)</p> <table border="1"> <tr> <td>R/B</td> </tr> <tr> <td>R</td> </tr> </table>	R/B	R	<p>E5-03 ASHTRAY ILLUMI (I)</p> <table border="1"> <tr> <td><del>X</del></td> <td>R</td> <td>R/B</td> </tr> </table>	<del>X</del>	R	R/B			
B	<del>X</del>	R														
*	*	R/B														
R/B																
R																
<del>X</del>	R	R/B														
<p>H-04 A/T SELECT ILLUMI (I)</p> <table border="1"> <tr> <td><del>X</del></td> <td>L/B</td> <td>B/Y</td> </tr> <tr> <td>R</td> <td>R/B</td> <td></td> </tr> </table>	<del>X</del>	L/B	B/Y	R	R/B		<p>G-05 CRUISE CONTROL MAIN SWITCH ILLUMI (I)</p> <table border="1"> <tr> <td>R/B</td> <td><del>X</del></td> <td>Y/B</td> </tr> <tr> <td>R</td> <td>B/Y</td> <td>R</td> </tr> <tr> <td></td> <td></td> <td>B</td> </tr> </table>	R/B	<del>X</del>	Y/B	R	B/Y	R			B
<del>X</del>	L/B	B/Y														
R	R/B															
R/B	<del>X</del>	Y/B														
R	B/Y	R														
		B														


E-5



# Z WIRING DIAGRAM


FEDERAL & CALIFORNIA ■ TURN SIGNAL & HAZARD FLASHER LIGHTS ■ STOPLIGHTS  
 ■ BACK-UP LIGHTS ■ HORN ■ HIGH MOUNT STOPLIGHT

F-1



<b>F-01 SHORT CONNECTOR (F)</b> 	<b>F-02 TURN SIGNAL &amp; HAZARD FLASHER UNIT (F)</b> 	<b>F-03 STOPLIGHT SWITCH (F)</b> 	<b>F-04 HORN RELAY (F)</b> 	<b>F-05 HORN (F)</b> 	<b>F-06 BACK-UP LIGHT SWITCH (E)</b> 	
<b>F-07 HIGH MOUNT STOPLIGHT (R)</b> 	<b>E2-08 HAZARD SWITCH (I)</b> 	<b>E4-03 FRONT TURN SIGNAL LIGHT LH (F)</b> 	<b>E4-04 FRONT TURN SIGNAL LIGHT RH (F)</b> 	<b>D-03 COMBINATION SWITCH (TURN SIGNAL) (F)</b> 		<b>S-07 COMBINATION SWITCH (F)</b> 
<b>E4-05 REAR COMBINATION LIGHT LH (R)</b> 	<b>E4-06 REAR COMBINATION LIGHT RH (R)</b> 	<b>D-03 COMBINATION SWITCH (TURN SIGNAL) (F)</b> 				<b>S-07 COMBINATION SWITCH (F)</b> 

F-1






# Z WIRING DIAGRAM

CANADA ■ TURN SIGNAL & HAZARD FLASHER LIGHTS ■ STOPLIGHTS  
 ■ BACK-UP LIGHTS ■ HORN ■ HIGH MOUNT STOPLIGHT


F-2



BLUB TRADE NUMBER  
 REAR TURN SIGNAL LIGHTS: 1156 (27W)  
 BACK-UP LIGHTS: 1156 (27W)  
 STOPLIGHTS: 1157 (27W)  
 HIGH MOUNT STOPLIGHT: 921 (18.4W)

<p>F-01 COMBINATION SWITCH (TURN SIGNAL) (F)</p> <table border="1"> <tr><td>G/Y</td><td>*</td><td>*</td><td>*</td></tr> <tr><td>B/Y</td><td>G/R</td><td>*</td><td>*</td></tr> </table>	G/Y	*	*	*	B/Y	G/R	*	*	<p>F-02 TURN SIGNAL &amp; HAZARD FLASHER UNIT (F)</p> <table border="1"> <tr><td>G/W</td><td>G/R</td><td>O</td><td>B</td></tr> <tr><td>B/R</td><td>G/Y</td><td>G/B</td><td>*</td></tr> </table>	G/W	G/R	O	B	B/R	G/Y	G/B	*	<p>F-03 STOPLIGHT SWITCH (F)</p> <table border="1"> <tr><td>W/G</td></tr> <tr><td>G</td></tr> </table>	W/G	G	<p>F-04 HORN RELAY (F)</p> <table border="1"> <tr><td>W/G</td></tr> <tr><td>W/G/G/O</td></tr> <tr><td>G/R</td></tr> </table>	W/G	W/G/G/O	G/R	<p>F-05 HORN (F)</p> <table border="1"> <tr><td>G/R</td></tr> </table>	G/R	<p>F-06 BACK-UP LIGHT SWITCH (E)</p> <table border="1"> <tr><td>M/T</td></tr> <tr><td>B/Y</td><td>R/G</td></tr> </table>	M/T	B/Y	R/G		
G/Y	*	*	*																													
B/Y	G/R	*	*																													
G/W	G/R	O	B																													
B/R	G/Y	G/B	*																													
W/G																																
G																																
W/G																																
W/G/G/O																																
G/R																																
G/R																																
M/T																																
B/Y	R/G																															
<p>F-07 HIGH MOUNT STOPLIGHT (R)</p> <table border="1"> <tr><td>B</td><td>G</td></tr> </table>	B	G	<p>E2-08 HAZARD SWITCH (I)</p> <table border="1"> <tr><td>O</td><td>R</td><td>R/B</td></tr> <tr><td>B</td><td>R/L</td><td>R/Y</td><td>R/G</td></tr> </table>	O	R	R/B	B	R/L	R/Y	R/G	<p>E2-07 COMBINATION SWITCH (HORN) (F)</p> <table border="1"> <tr><td>R/W</td><td>R/B</td><td>W/L</td></tr> <tr><td>G/O</td><td>W/B</td><td>*</td></tr> </table>	R/W	R/B	W/L	G/O	W/B	*	<p>E4-05 REAR COMBINATION LIGHT LH (R)</p> <table border="1"> <tr><td>*</td><td>R/G</td><td>G/B</td></tr> <tr><td>B</td><td>R/B</td><td>G</td></tr> </table>	*	R/G	G/B	B	R/B	G	<p>E4-06 REAR COMBINATION LIGHT RH (R)</p> <table border="1"> <tr><td>*</td><td>R/G</td><td>G/W</td></tr> <tr><td>B</td><td>R/B</td><td>G</td></tr> </table>	*	R/G	G/W	B	R/B	G	
B	G																															
O	R	R/B																														
B	R/L	R/Y	R/G																													
R/W	R/B	W/L																														
G/O	W/B	*																														
*	R/G	G/B																														
B	R/B	G																														
*	R/G	G/W																														
B	R/B	G																														


F-2



# Z WIRING DIAGRAM


## HEATER & AIR CONDITIONER

G



<p>G-01 BLOWER UNIT (F)</p> <p>( ) ... CANADA</p>	<p>G-02 MAGNETIC CLUTCH (F)</p>	<p>G-03 THERMOSWITCH (I)</p>	<p>G-04 HEATER CONTROL UNIT (I)</p>	<p>G-05 BLOWER UNIT (I)</p>	<p>G-06 A/C RELAY (AC)</p>
<p>G-07 ADDITIONAL FAN MOTOR (AC)</p>	<p>G-08 REFRIGERANT PRESSURE SWITCH (AC)</p>	<p>G-09 BLOWER MOTOR</p>	<p>G-10 JOINT CONNECTOR (F)</p>	<p>G-11 BLOWER MOTOR RELAY (F)</p>	


WIRING DIAGRAM Z



# Z WIRING DIAGRAM



## A/T CONTROL SYSTEM

H-1



<p>H-01 A/T CONTROL UNIT (F)</p> <table border="1"> <tr> <td>10</td><td>1M</td><td>1K</td><td></td><td>1E</td><td>1C</td><td>1A</td> </tr> <tr> <td>*</td><td>L/O</td><td>L/Y</td><td></td><td>L/R</td><td>L/B</td><td>B/Y</td> </tr> <tr> <td>*</td><td>L</td><td>G/R</td><td></td><td>L/W</td><td>B/O</td><td>B</td> </tr> <tr> <td>1P</td><td>1N</td><td>1L</td><td>1J</td><td>1H</td><td>1F</td><td>1D</td><td>1B</td> </tr> </table>	10	1M	1K		1E	1C	1A	*	L/O	L/Y		L/R	L/B	B/Y	*	L	G/R		L/W	B/O	B	1P	1N	1L	1J	1H	1F	1D	1B	<p>H-02 KICKDOWN &amp; 4-3 SWITCH (F)</p> <table border="1"> <tr> <td>L/R</td><td>B/Y</td><td>A</td> </tr> <tr> <td>B/O</td><td>B/Y</td><td>B</td> </tr> </table>	L/R	B/Y	A	B/O	B/Y	B	<p>H-03 KICKDOWN RELAY (F)</p> <table border="1"> <tr> <td>B/Y</td><td>A</td> </tr> <tr> <td>L/O</td><td>B/Y</td><td>B</td> </tr> <tr> <td>W/B</td><td></td><td></td> </tr> </table>	B/Y	A	L/O	B/Y	B	W/B			<p>H-04 OD OFF SWITCH (I)</p> <table border="1"> <tr> <td>L/B</td><td>B/Y</td> </tr> <tr> <td>R</td><td>R/B</td> </tr> </table>	L/B	B/Y	R	R/B	<p>H-05 OIL PRESSURE SWITCH (E)</p> <table border="1"> <tr> <td>L/W</td> </tr> </table>	L/W	<p>H-06 OD CANCEL SOLENOID (E)</p> <table border="1"> <tr> <td>B/Y</td><td>L/Y</td> </tr> </table>	B/Y	L/Y
10	1M	1K		1E	1C	1A																																																	
*	L/O	L/Y		L/R	L/B	B/Y																																																	
*	L	G/R		L/W	B/O	B																																																	
1P	1N	1L	1J	1H	1F	1D	1B																																																
L/R	B/Y	A																																																					
B/O	B/Y	B																																																					
B/Y	A																																																						
L/O	B/Y	B																																																					
W/B																																																							
L/B	B/Y																																																						
R	R/B																																																						
L/W																																																							
B/Y	L/Y																																																						
<p>H-07 LOCKUP SOLENOID (E)</p> <table border="1"> <tr> <td>L</td><td>B/Y</td> </tr> </table>	L	B/Y	<p>H-08 KICKDOWN SOLENOID (E)</p> <p>( ) ... WITH ABS</p> <table border="1"> <tr> <td>W/B</td><td>G</td> </tr> </table>	W/B	G																																																		
L	B/Y																																																						
W/B	G																																																						

H-1




**Terminal Voltage**

Terminal	Connected to	Voltage	Condition	
1A (Battery power)	Battery	Approx. 12V	Ignition switch ON	
		Below 1.5V	Ignition switch OFF	
1B (Ground)	—	Below 1.5V	—	
1C (Input)	OD OFF switch	Approx. 12V	OD OFF switch released •OD not available	
		Below 1.5V	OD OFF switch depressed •OD available	
1D (Input)	Kickdown switch	Approx. 12V	Switch ON: •Throttle opening 7/8—8/8	
		Below 1.5V	Switch OFF: •Other than conditions above	
1E (Input)	4-3 switch	Approx. 12V	Switch ON: •Throttle opening 6/8—8/8	
		Below 1.5V	Switch OFF: •Other than conditions above	
1F (Input)	Oil pressure switch	Approx. 12V	Switch OFF: •1st, 2nd, and 3rd gear positions in forward ranges •P, R, and N ranges	
		Below 1.5V	Switch ON: •OD gear position	
1H (Input)	Engine control unit	Below 1.5V	Ignition switch ON	
1I	—	—	—	
1J (Input)	Cruise control unit	Approx. 12V	Normal conditions	
		Below 1.5V	Set or Resume switch ON, or vehicle speed 8 km/h (5 mph) lower than preset speed (Driving vehicle: cruise control operation)	
1K (Output)	OD cancel solenoid	Approx. 12V	Solenoid OFF: •OD gear position	
		Below 1.5V	Solenoid ON: •1st, 2nd, and 3rd gear positions in forward ranges •P, R, and N ranges	
1L (Input)	Speed sensor	1.5—7V	During driving	
		Approx. 7V or below 1.5V	Vehicle stopped	
1M (Input)	Kickdown relay	Approx. 12V	Kickdown relay OFF: •Other than conditions below	
		Below 1.5V	Kickdown relay ON: •Kickdown switch ON (throttle opening more than 7/8)	
1N (Output)	Lockup solenoid	Approx. 12V	Solenoid OFF: •Lockup prohibition	Ignition switch ON
		Below 1.5V	Solenoid ON: •Lockup	Engine running

# Z WIRING DIAGRAM

## A/T ■ SHIFTLOCK SYSTEM


H-2



<p>H-09 SHIFTLOCK ACUTUATOR (I)</p> <p>(I)</p> <table border="1"> <tr> <td>G</td> <td>B</td> <td>B/Y</td> <td>L/R</td> </tr> </table> <table border="1"> <tr> <td>R</td> <td>Y</td> <td>B</td> <td>L</td> </tr> </table>	G	B	B/Y	L/R	R	Y	B	L	<p>H-10 P RANGE SWITCH</p> <table border="1"> <tr> <td>B</td> <td>B</td> </tr> </table>	B	B		
G	B	B/Y	L/R										
R	Y	B	L										
B	B												




H-2




# Z WIRING DIAGRAM

- CIGAR LIGHTER
- INTERIOR LAMPS

I




<p>I-01 CIGAR LIGHTER (I)</p>	<p>I-02 INTERIOR LAMP LH (I)</p>	<p>I-03 INTERIOR LAMP RH (I)</p>	<p>I-04 DOOR SWITCH LH (R)</p>
<p>I-05 DOOR SWITCH RH (R)</p>			



# Z WIRING DIAGRAM


## AUDIO SYSTEM (TYPE 1, 2)

J-1



<p>J-01 AM/FM RADIO &amp; CASSETTE PLAYER (I)</p> <table border="1"> <tr> <td>L/Y</td> <td>R/G</td> <td>R/B</td> <td>L/R</td> <td>L/B</td> </tr> <tr> <td>L</td> <td>R/W</td> <td>*</td> <td>*</td> <td>*</td> </tr> </table>	L/Y	R/G	R/B	L/R	L/B	L	R/W	*	*	*	<p>J-02 DOOR SPEAKER LH (DR2)</p> <table border="1"> <tr> <td>R/W</td> </tr> <tr> <td>R/G</td> </tr> </table>	R/W	R/G	<p>J-03 DOOR SPEAKER RH (DR1)</p> <table border="1"> <tr> <td>R/W</td> </tr> <tr> <td>R/G</td> </tr> </table>	R/W	R/G	<p>J-04 AM/FM RADIO &amp; CASSETTE PLAYER (I)</p> <table border="1"> <tr> <td>*</td> <td>L/W</td> <td>L/O</td> <td>*</td> <td>R/L</td> </tr> <tr> <td>*</td> <td></td> <td></td> <td>*</td> <td>R/Y</td> </tr> </table>	*	L/W	L/O	*	R/L	*			*	R/Y	<p>J-05 HEADREST SPEAKER (DRIVER SIDE) (R)</p> <table border="1"> <tr> <td>L/O</td> <td>R/L</td> </tr> <tr> <td>L/W</td> <td>R/Y</td> </tr> </table>	L/O	R/L	L/W	R/Y
L/Y	R/G	R/B	L/R	L/B																												
L	R/W	*	*	*																												
R/W																																
R/G																																
R/W																																
R/G																																
*	L/W	L/O	*	R/L																												
*			*	R/Y																												
L/O	R/L																															
L/W	R/Y																															
<p>J-06 HEADREST SPEAKER (PASSENGER SIDE) (R)</p> <table border="1"> <tr> <td>L/O</td> <td>R/L</td> </tr> <tr> <td>L/W</td> <td>R/Y</td> </tr> </table>	L/O	R/L	L/W	R/Y																												
L/O	R/L																															
L/W	R/Y																															


J-1



# Z WIRING DIAGRAM


## AUDIO SYSTEM (TYPE 3)

J-2



AM/FM RADIO & CASSETTE PLAYER  
+ COMPACT DISC PLAYER + 4 SPEAKER


<p>J-01 AM/FM RADIO &amp; CASSETTE PLAYER (I)</p> <table border="1"> <tr> <td>L/Y</td> <td>R/G</td> <td></td> <td>R/B</td> <td>L/R</td> <td>L/B</td> </tr> <tr> <td>L</td> <td>R/W</td> <td>*</td> <td>*</td> <td>*</td> <td>*</td> </tr> </table>	L/Y	R/G		R/B	L/R	L/B	L	R/W	*	*	*	*	<p>J-02 DOOR SPEAKER LH (DR2)</p> <table border="1"> <tr> <td>R/W</td> </tr> <tr> <td>R/G</td> </tr> </table>	R/W	R/G	<p>J-03 DOOR SPEAKER RH (DR1)</p> <table border="1"> <tr> <td>R/W</td> </tr> <tr> <td>R/G</td> </tr> </table>	R/W	R/G	<p>J-04 AM/FM RADIO &amp; CASSETTE PLAYER (I)</p> <table border="1"> <tr> <td>*</td> <td></td> <td>*</td> <td>R/L</td> </tr> <tr> <td>*</td> <td>L/W</td> <td>L/O</td> <td>R/Y</td> </tr> </table>	*		*	R/L	*	L/W	L/O	R/Y	<p>J-05 HEADRESTRAINT SPEAKER (DRIVER SIDE) (R)</p> <table border="1"> <tr> <td></td> </tr> <tr> <td>L/O</td> <td>R/L</td> </tr> <tr> <td>L/W</td> <td>R/Y</td> </tr> </table>		L/O	R/L	L/W	R/Y
L/Y	R/G		R/B	L/R	L/B																												
L	R/W	*	*	*	*																												
R/W																																	
R/G																																	
R/W																																	
R/G																																	
*		*	R/L																														
*	L/W	L/O	R/Y																														
L/O	R/L																																
L/W	R/Y																																
<p>J-06 HEADRESTRAINT SPEAKER (PASSENGER SIDE) (R)</p> <table border="1"> <tr> <td></td> </tr> <tr> <td>L/O</td> <td>R/L</td> </tr> <tr> <td>L/W</td> <td>R/Y</td> </tr> </table>		L/O	R/L	L/W	R/Y																												
L/O	R/L																																
L/W	R/Y																																



# Z WIRING DIAGRAM

## POWER WINDOW


K



K-01 POWER WINDOW MAIN SWITCH (I)	K-02 POWER WINDOW MOTOR LH (DR1)	K-03 POWER WINDOW MOTOR RH (DR2)											
<table border="1"> <tr> <td>R/B</td> <td>G/R</td> <td>B/W</td> </tr> <tr> <td>R/G</td> <td>G</td> <td>B</td> </tr> </table>	R/B	G/R	B/W	R/G	G	B	<table border="1"> <tr> <td>G/R</td> </tr> <tr> <td>G</td> </tr> </table>	G/R	G	<table border="1"> <tr> <td>G/R</td> </tr> <tr> <td>G</td> </tr> </table>	G/R	G	
R/B	G/R	B/W											
R/G	G	B											
G/R													
G													
G/R													
G													




WIRING DIAGRAM Z



# Z WIRING DIAGRAM

## ABS (ANTI-LOCK BRAKE SYSTEM)

0




<b>0-01 ABS CONTROL UNIT (F)</b> 2I 2G 2E 2C 2A 1Y 1W 1U 1S 1Q 1O 1M 1K 1I 1G 1E 1C 1A Y/G V * W/B R/Y * * Y B Y/L LG * W * R * B/W B/Y BR B * G/Y * * L/Y L/O B/L L G R/W * * O B * 2H 2F 2D 2B 1Z 1X 1V 1T 1R 1P 1N 1L 1J 1H 1F 1D 1B			
<b>0-04 SPEED SENSOR FRONT (LH) (F)</b> 	<b>0-05 SPEED SENSOR FRONT (RH) (F)</b> 	<b>0-06 SPEED SENSOR REAR (LH) (R)</b> 	<b>0-07 SPEED SENSOR REAR (RH) (R)</b> 
<b>0-09 JOINT CONNECTOR (R)</b> 			

<b>0-02 HYDRAULIC UNIT (F)</b> 
------------------------------------

<b>0-03 HYDRAULIC UNIT (F)</b> 
<b>0-08 JOINT CONNECTOR (F)</b> 


WIRING DIAGRAM Z



# Z WIRING DIAGRAM

## FEDERAL & CALIFORNIA ■ CRUISE CONTROL SYSTEM

Q



Q-01 CRUISE CONTROL UNIT (F)

S	Q	D	M	G	E	C	A
W/G	*	P	G	R/W	R	G/O	G/Y
B	*	G/R	R/W	R/L	R/W (B/L)	L	Y/B
T	R	P	N	L	J	H	F

( ) ...A/T

Q-02 CRUISE CONTROL MAIN SWITCH (I)

R/B	Y/B
R	B

Q-03 CRUISE CONTROL SWITCH (F)


R/W	R/L
B	*

Q-04 BRAKE SWITCH (F)

P	Y
---	---

Q-05 CRUISE CONTROL ACTUATOR (F)

P	G/O
G/Y	G/B




**Terminal Voltage**

Terminal	Wire color	Connected to	Test condition	Specification	Action
a	(G/Y)	Actuator	Main switch off	0V	Go to Step 8
			Main switch on	9V	
b	(G/B)	Actuator	Main switch off	0V	
			Main switch on	9V	
c	(G/O)	Actuator	Main switch off	0V	
			Main switch on	9V	
e	(R)	Main switch	Main switch off	12V	Repair wire (R)
			Main switch off	0V	(Main switch—Cruise control unit)
f	(Y/B)	Main switch	Main switch off	0V	Repair wire (Y/B)
			Main switch on	12V	(Main switch—Cruise control unit)
g	(LG/B)	AT control unit	Ignition switch off	0V	Go to page K-
			Ignition switch on	12V	
h	(Y)	Brake switch	Brake pedal depressed	0V	Go to Step 4
			Brake pedal released	9V	
j	(B/L)	Inhibitor switch	Shift to "N" or "P" range	0V	Go to page K-
			Shift to other range	5V	
	(BR/W)	Clutch switch	Clutch pedal depressed	0V	Go to Step 5
		Clutch pedal released	12V		
l	(R/L)	Cruise control switch (Set switch and coast switch)	Main switch ON	12V	Go to Step 6
			While pushing set switch after main switch ON	0V	
m	(G)	Stoplight switch	Brake pedal depressed	12V	Go to Step 7
			Brake pedal released	0V	
n	(R/W)	Cruise control switch (Resume switch and accel switch)	Main switch ON	12V	Go to Step 6
			While pushing resume switch after main switch ON	0V	
o	(P)	Actuator	Main switch OFF	0V	Go to Step 8
			Main switch ON	9V	
p	(G/R)	Speed sensor	While rotating rear tires	Run out between 0—5V	Go to Step 9
s	(W/G)	Battery	Constant	12V	Repair wire (W/G)
t	(B)	Ground	Constant	0V	Repair wire (B)





WIRING DIAGRAM Z





# Z WIRING DIAGRAM








**PARTS LOCATION Z**

**PL**



# PARTS INDEX


PARTS NAME	SECTION	PARTS NAME	SECTION
<b>A</b> A/C RELAY .....	G	<b>H</b> HAZARD & RETRACTOR SWITCH ILLUMI.....	E-5
A/T CONTROL UNIT .....	H-1	HAZARD SWITCH .....	F-1,2
A/T SELECT ILLUMI .....	E-5	HEADLIGHT RELAY .....	E-1
ABS CONTROL UNIT .....	O	HEADLIGHT RETRACTOR MOTOR .....	E-1,2
ADDITIONAL FAN MOTOR .....	G	HEADLIGHTS .....	E-1,2
AIR BAG CONTROL UNIT .....	S	HEADRESTRAINT SPEAKER .....	J-1,2
AIR BAG MODULE .....	S	HEATER CONTROL SWITCH ILLUMI .....	E-5
AIRFLOW METER .....	B-1b	HEATER CONTROL UNIT .....	G
ALTERNATOR .....	A	HIGH MOUNT STOPLIGHT .....	F-1,2
AM/FM RADIO & CASSETTE PLAYER.....	J-1,2	HORN RELAY .....	F-1,2
ASHTRAY ILLUMI .....	E-5	HORN .....	F-1,2
		HYDRAULIC PUMP MOTOR .....	O
		HYDRAULIC UNIT .....	O
<b>B</b> BACK-UP LIGHT SWITCH .....	F-1,2		
BACK-UP LIGHTS .....	F-1,2	<b>I</b> IGNITION KEY REMINDER SWITCH .....	T
BACKUP BATTERY .....	S	IGNITION SWITCH .....	W~T
BATTERY .....	W~T	IGNITER .....	B-1a
BLOWER MOTOR RELAY .....	G	INHIBITOR SWITCH .....	A
BLOWER UNIT .....	G	INJECTOR .....	B-1a
BRAKE FLUID LEVEL SENSOR .....	C	INSTRUMENT CLUSTERS .....	C
BRAKE SWITCH .....	Q	INTERIOR LAMPS .....	I
BUCKLE SWITCH .....	T		
		<b>J</b> JOINT CONNECTOR .....	G,O
		JOIT CONNECTOR .....	S
<b>C</b> CIGARETTE LIGHTER .....	T		
CIRCUIT OPENING RELAY .....	B-2	<b>K</b> KICKDOWN RELAY .....	H-1
CLUTCH SWITCH .....	B-1c	KICKDOWN SOLENOID .....	H-1
<b>COMBINATION SWITCH</b>		KICKDOWN SWITCH .....	H-1
(HORN) .....	F-1,2		
(LIGHT) .....	E-1,2	<b>L</b> LICENSE PLATE LIGHTS .....	E-4
(TURN SIGNAL) .....	F-1,2	LOCKUP SOLENOID .....	H-1
(WINDSHIELD WIPER & WASHER) .....	D-1,2		
COMPACT DISK PLAYER .....	J-2	<b>M</b> MAGNETIC CLUTCH .....	G
CONDENSER .....	B-1a	MAIN RELAY .....	B-1a
COOLING FAN MOTOR .....	B-3		
COOLING FAN RELAY .....	B-3	<b>N</b> NEUTRAL SWITCH .....	B-1c
CPU : SOUND WARNING UNIT .....	T		
CRANK ANGLE SENSOR .....	B-1a	<b>O</b> OD CANSEL SOLENOID .....	H-1
CRUISE CONTROL ACTUATOR .....	Q	OD OFF SWITCH .....	H-1
CRUISE CONTROL MAIN SWITCH ILLUMI .....	E-5	OIL PRESSURE SENSOR .....	C
CRUISE CONTROL MAIN SWITCH .....	Q	OIL PRESSURE SWITCH .....	H-1
CRUISE CONTROL SWITCH .....	Q	OXYGEN SENSOR .....	B-1b
CRUISE CONTROL UNIT .....	Q		
		<b>P</b> P RANGE SWITCH .....	H-2
<b>D</b> D SENSOR .....	S	PANEL LAMP CONTROL SWITCH .....	E-5
DAYTIME RUNNING CONTROL UNIT .....	E-3	PARKING BRAKE SWITCH .....	C,E-3
DIAGNOSIS CONNECTOR .....	B-1c	POWER STEERINR PRESSURE SWITCH .....	B-1b
DOOR SPEAKER .....	J-1,2	POWER WINDOW MAIN SWITCH .....	K
DOOR SWITCH .....	I	POWER WINDOW MOTOR .....	K
		PUMP MOTOR RELAY .....	O
<b>E</b> ENGINE CONTROL UNIT .....	B-1a,1b,1c		
		<b>R</b> REAR SIDE MARKER LIGHTS .....	E-4
<b>F</b> FRONT FOG LIGHT SWITCH ILLUMI .....	E-5	REAR TURN SIGNAL LIGHTS .....	F-1,2
FRONT FOG LIGHT SWITCH .....	E-1,2	REFRIGERANT PRESSURE SWITCH .....	G
FRONT FOG LIGHTS .....	E-1,2	RELAY & MAIN FUSE BLOCK .....	X
FRONT PARKING LIGHTS .....	E-4	RETRACTOR RELAY .....	E-1,2
FRONT SIDE MARKER LIGHTS .....	E-4	RETRACTOR SWITCH .....	E-1,2
FRONT TURN SIGNAL LIGHTS .....	F-1		
FUEL LEVEL SENSOR .....	B-2	<b>S</b> S SENSOR .....	S
FUEL PUMP .....	B-2	SHIFTLOCK ACTUATOR .....	H-2
FUEL TANK UNIT .....	B-2		
FUSE BOX .....	X		

# PARTS INDEX

PARTS NAME	SECTION	PARTS NAME	SECTION
SHORT CONNECTOR.....	B- 1b		
<b>SOLENOID VALVE</b>			
(ISC) .....	B- 1a		
(PURGE).....	B- 1a		
SPEED SENSOR.....	0		
STARTER .....	A		
STARTER INTERLOCK SWITCH.....	A		
STOPLIGHT SWITCH.....	F- 1,2		
STOPLIGHTS.....	F- 1,2		
<b>T</b> TAILLIGHTS .....	E- 4		
THERMOSWITCH.....	G		
THROTTLE SENSOR .....	B- 1b		
TNS RELAY .....	E- 1		
TURN SIGNAL & HAZARD FLASHER UNIT ...	F- 1,2		
<b>V</b> VALVE RELAY .....	0		
<b>W</b> WASHER LEVEL SENSOR .....	C		
WATER THERMOSENSOR.....	B- 1b,C		
WATER THERMOSWITCH (FAN).....	B- 3		
WINDSHIELD WASHER MOTOR.....	D- 1,2		
WINDSHIELD WIPER MOTOR .....	D- 1,2		
4-3 SWITCH .....	H- 1		

# Parts Catalog

Mazda MX-5 MIATA  
U.S.A.  
( '90)




NA35\*\*-100001-200000

Feb. '92 (FINAL)  
Catalog No. AU-NA/J1-07

**MAZDA**  
© 1992 Mazda Motor Corporation




















## LAYOUT OF CONTENTS

- The following is a typical example of the layout of contents on Mazda microfiche parts catalog:



- |                                      |                          |                                   |
|--------------------------------------|--------------------------|-----------------------------------|
| ① • Layout of contents               | ② • Pictorial Index      | ③ • Master Section No. Index      |
| ④ • Section No. Index for the Column | ⑤ • Illustration & Text  | ⑥ • Part No. Index                |
| ⑦ • Alphabetical Index               | ⑧ • Model Identification | ⑨ • Vehicle Identification System |
















# PICTORIAL INDEX

<p><b>1000</b></p>  <p><b>1010</b></p>  <p>CYLINDER HEAD &amp; COVER</p>	<p><b>2</b> 1030</p>  <p>CYLINDER BLOCK</p>	<p><b>3</b> 1040</p>  <p>OIL PAN &amp; TIMING COVER</p>	<p><b>4</b> 1100</p>  <p>PISTON, CRANKSHAFT &amp; FLYWHEEL</p>	<p><b>5</b> 1200</p>  <p>VALVE SYSTEM</p>
<p><b>SHORT ENGINE &amp; GASKET SETS</b></p> 	<p><b>ENGINE (1/2)</b></p> 			<p><b>6</b> 1400</p>  <p>OIL PUMP &amp; FILTER</p>
<p><b>17</b> 3900</p> <p>Given in Chassis Group</p>  <p>ENGINE &amp; T/MISSION MOUNTINGS</p>				<p><b>7</b> 1600</p>  <p>CLUTCH DISC &amp; COVER (MANUAL)</p>
<p><b>16</b> 1960</p>  <p>GASKET &amp; SEAL KIT (AUTOMATIC)</p>				<p><b>8</b> 1700</p>  <p>TRANSMISSION CASE (MANUAL)</p>
<p><b>15</b> 1950</p>  <p>MANUAL LINKAGE SYSTEM (AUTOMATIC)</p>	<p><b>14</b> 1940</p>  <p>GOVERNOR, LOW &amp; REVERSE PISTON (AUTOMATIC)</p>	<p><b>13</b> 1930</p>  <p>CLUTCH &amp; PLANETARY GEARS (AUTOMATIC)</p>	<p><b>12</b> 1920 1925</p>  <p>TRANSMISSION CASE &amp; MAIN CONTROL SYSTEM (AUTOMATIC)</p>	<p><b>11</b> 1910</p>  <p>TORQUE CONVERTER, OIL PUMP &amp; PIPINGS (AUTOMATIC)</p>
				<p><b>10</b> 1720</p>  <p>CHANGE CONTROL SYSTEM (MANUAL)</p>

As this illustration is prepared to be applicable to all models, some parts are different in specifications from the parts listed in this parts Catalog.

























PICTORIAL INDEX

<p><b>1</b> 1300</p>  <p>INLET MANTFOLD</p>	<p><b>2</b> 1310</p>  <p>EXHAUST MANIFOLD</p>	<p><b>3</b> 1320</p>  <p>FUEL SYSTEM</p>	<p><b>4</b> 1325</p>  <p>FUEL DISTRIBUTOR</p>	<p><b>5</b> 1330</p>  <p>AIR CLEANER</p>	<p><b>6</b> 1364</p>  <p>THROTTLE BODY</p>
<p><b>18</b> 4000</p>  <p>Given in Chassis Group</p> <p>EX. SYSTEM</p>	<p><b>ENGINE (2/2)</b></p> 				<p><b>7</b> 1370</p>  <p>EMISSION CONTROL SYSTEM (INLET SIDE)</p>
<p><b>17</b> 1850</p>  <p>BATTERY</p>					<p><b>8</b></p>
<p><b>16</b> 1840</p>  <p>STARTER</p>					<p><b>9</b> 1399</p>  <p>CAP &amp; HOSE CLIP 'INLET &amp; EXHAUST SIDE'</p>
<p><b>15</b> 1830</p>  <p>ALTERNATOR</p>					<p><b>10</b> 1500</p>  <p>COOLING SYSTEM</p>
<p><b>14</b></p>					<p><b>13</b> 1800</p>  <p>ENGINE ELECTRICAL SYSTEM</p>













As this illustration is prepared to be applicable to all models, some parts are different in specifications from the parts listed in this parts Catalog.

# PICTORIAL INDEX

<p><b>1</b> 2505</p>  <p>REAR PROPELLER SHAFT</p>	<p><b>2</b> 2550</p>  <p>REAR DRIVE SHAFTS</p>	<p>2600</p>  <p>REAR AXLE</p>	<p><b>3</b> 2610</p>  <p>REAR BRAKE MECHANISMS</p>	<p><b>4</b> 2710</p>  <p>REAR DIFFERENTIALS</p>	<p><b>5</b> 2800 2810</p>  <p>REAR SUSPENSION MECHANISMS</p>			
<p><b>16</b> 4600</p>  <p>CHANGE CONTROL SYSTEM (AUTOMATIC)</p>	<p><b>17</b> 1720</p> <p>Given in Engine Group</p>  <p>CHANGE CONTROL SYSTEM (MANUAL)</p>	<h2 style="margin: 0;">CHASSIS (1/2)</h2> 			<p>2801</p>  <p>REAR SPRING &amp; DAMPER</p>			
<p><b>15</b> 4000</p>  <p>EXHAUST SYSTEM</p>				<p>2830</p>  <p>REAR LOWER ARMS &amp; SUB FRAME</p>				
<p><b>14</b> 3900</p>  <p>ENGINE &amp; T/MISSION MOUNTINGS</p>				<p><b>6</b> 3200</p>  <p>STEERING WHEEL</p>				
<p><b>13</b> 3410</p>  <p>CROSSMEMBER &amp; STABILIZER</p>				<p><b>7</b> 3210</p>  <p>STEERING COLUMN &amp; SHAFTS</p>				
<p><b>12</b> 3401</p>  <p>FRONT SPRING &amp; DAMPER</p>				<p>3400</p>  <p>FRONT SUSPENSION MECHANISMS</p>	<p><b>11</b> 3310</p>  <p>FRONT BRAKE MECHANISMS</p>	<p><b>10</b> 3300</p>  <p>FRONT AXLE</p>	<p><b>9</b> 3240</p>  <p>POWER STEERING SYSTEM</p>	<p><b>8</b> 3220</p>  <p>STEERING GEAR</p>



















As this illustration is prepared to be applicable to all models, some parts are different in specifications from the parts listed in this parts Catalog

# PICTORIAL INDEX

<p><b>1</b> 3700</p>  <p>TIRES &amp; JACK</p>	<p><b>2</b> 4140</p>  <p>CLUTCH RELEASE &amp; MASTER CYLINDERS (MANUAL TRANSMISSION)</p>	<p>4145</p>  <p>CLUTCH PIPINGS (MANUAL TRANSMISSION)</p>	<p><b>3</b> 4160</p>  <p>ACCELERATOR CONTROL SYSTEM</p>	<p><b>4</b> 4200</p>  <p>FUEL TANK</p>	<p><b>5</b> 4300</p>  <p>CLUTCH &amp; BRAKE PEDALS</p>
<h2>CHASSIS (2/2)</h2> 					
<p><b>6</b> 4340</p>  <p>BRAKE MASTER CYLINDER &amp; POWER BRAKE</p> <p><b>7</b> 4360</p>  <p>BRAKE PIPINGS</p> <p><b>8</b> 4400</p>  <p>PARKING BRAKE SYSTEM</p> <p><b>9</b> 4500</p>  <p>FUEL PIPINGS</p> <p><b>11</b> 4370</p>  <p>ANTILOCK BRAKE SYSTEM</p>					




















As this illustration is prepared to be applicable to all models, some parts are different in specifications from the parts listed in this parts Catalog

PICTORIAL INDEX

<p><b>1</b> 0900</p>  <p>KEY SETS</p>	<p><b>2</b></p>	<p><b>3</b> 5100</p>  <p>HEAD LAMPS</p>	<p><b>4</b> 5103</p>  <p>HEAD LAMP RETRACTORS</p>	<p><b>5</b> 5105</p>  <p>FRONT COMBINATION LAMPS</p>	<p><b>6</b> 5110</p>  <p>REAR COMBINATION LAMPS</p>
<p><b>19</b> 6704</p>  <p>WIRING HARNESS CLAMPS</p>	<p><b>20</b> 6720</p>  <p>WINDSHIELD WASHER</p>	<p><b>21</b> 6730</p>  <p>WINDSHIELD WIPERS</p>			<p><b>7</b> 5120</p>  <p>LICENSE LAMPS</p>
<p><b>18</b> 6703</p>  <p>WIRING HARNESSSES (DOOR, FLOOR/CEILING)</p>	<p style="text-align: center;"><b>BODY (1/4)</b></p> 				<p><b>8</b></p>
<p><b>17</b> 6702</p>  <p>WIRING HARNESSSES (DASHBOARD)</p>					<p><b>9</b></p>
<p><b>16</b> 6701</p>  <p>WIRING HARNESSSES (ENGINE &amp; T/MISSION)</p>					<p><b>10</b> 6600</p>  <p>SWITCHES &amp; RELAYS (ENGINE)</p>
<p><b>15</b> 6700</p>  <p>WIRING HARNESSSES (FRONT &amp; REAR)</p>	<p><b>14</b> 6640</p>  <p>AUTO CRUISE CONTROL SYSTEM</p>	<p><b>13</b> 6635</p>  <p>DOOR SWITCH &amp; HORNS</p>	<p><b>12</b> 6630</p>  <p>RELAYS &amp; UNIT (BODY)</p>	<p><b>11</b></p>	














As this illustration is prepared to be applicable to all models, some parts are different in specifications from the parts listed in this parts Catalog





# PICTORIAL INDEX




<b>1</b> 5000  FRONT BUMPER	<b>2</b>	<b>3</b> 5010  REAR BUMPER	<b>4</b> 5030  WINDOW MOULDING & COWL GRILLES	<b>5</b>	<b>6</b>
<b>20</b> 5840  FRONT DOOR THIMS & RELATED PARTS	<b>21</b>	<b>22</b> 6300  WINDOW GLASSES	<b>23</b> 6330  SUNROOF	<b>24</b> 7900  ACCESSORIES	<b>7</b>
<b>19</b> 5830  FRONT DOOR MECHANISMS	<b>BODY (2/4)</b> 				<b>8</b> 5180  REAR FINISHER
<b>18</b> 5800  FRONT DOORS					<b>9</b> 5230  BONNET
<b>17</b> 5390 5380  FLOOR ATTACHMENTS					<b>10</b> 5260  TRUNK LID
<b>16</b> 5370  BODY PANELS (FLOOR)	<b>15</b>	<b>14</b> 5340  BODY PANELS (SIDE)	<b>18</b> 5330  BODY PANELS (DASH & COWL PANEL)	<b>12</b> 5320  BODY PANELS (FLENDER & WHEEL APRON)	<b>11</b> 5310  BODY PANELS (FRONT)

As this illustration is prepared to be applicable to all models, some parts are different in specifications from the parts listed in this parts Catalog

PICTORIAL INDEX























<p><b>1</b> 5500</p>  <p>DASHBOARD EQUIPMENTS</p>	<p><b>2</b> 5520</p>  <p>METER HOOD</p>	<p><b>3</b> 5530</p>  <p>SPEEDOMETER CABLE</p>	<p><b>4</b> 5540</p>  <p>METER COMPONENTS</p>	<p><b>5</b> 5560</p>  <p>DASHBOARD &amp; RELATED PARTS</p>	<p><b>6</b> 5570</p>  <p>CONSOLE</p>					
<p><b>BODY (3/4)</b></p> 										
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td data-bbox="211 1727 980 2023"></td> <td data-bbox="988 1727 1368 2023"></td> <td data-bbox="1377 1727 1757 2023"></td> <td data-bbox="1765 1727 2145 2023"> <p><b>10</b> 6611</p>  <p>COMBINATION SWITCH</p> </td> <td data-bbox="2153 1727 2534 2023"> <p><b>9</b> 6610</p>  <p>DASHBOARD SWITCHES</p> </td> </tr> </table>									<p><b>10</b> 6611</p>  <p>COMBINATION SWITCH</p>	<p><b>9</b> 6610</p>  <p>DASHBOARD SWITCHES</p>
			<p><b>10</b> 6611</p>  <p>COMBINATION SWITCH</p>	<p><b>9</b> 6610</p>  <p>DASHBOARD SWITCHES</p>						

<p><b>7</b></p>  <p>6120</p>  <p>6100</p>  <p>6110</p>  <p>6115</p> <p>HEATER</p>
--

<p><b>8</b> 6130</p>  <p>6135</p>  <p>6140</p>  <p>6135</p> <p>6150</p> <p>AIR CONDITIONER</p>
---

As this illustration is prepared to be applicable to all models, some parts are different in specifications from the parts listed in this part, (Cont.)

PICTORIAL INDEX

<p><b>1</b> 5580</p>  <p>VENTILATOR</p>	<p><b>2</b> 5700</p>  <p>SEATS</p>	<p><b>3</b></p>	<p><b>4</b> 5790</p>  <p>SEAT BELTS</p>	<p><b>5</b> 6680</p>  <p>AUDIO SYSTEMS (RADIO &amp; TAPE DECK)</p>	<p><b>6</b> 6682</p>  <p>AUDIO SYSTEMS (ANTENNA &amp; SPEAKER)</p>						
<p><b>BODY (4/4)</b></p> 											
<p><b>17</b> 7250</p>  <p>REAR WINDOW GLASSES &amp; TRIMS</p>					<p><b>7</b> 6684</p>  <p>AUDIO SYSTEMS (NOISE SUPPRESSOR &amp; EARTH CORD)</p>						
<table border="1"> <tr> <td data-bbox="203 1736 611 2046"> <p><b>16</b> 6930</p>  <p>CAUTION PLATES &amp; LABELS</p> </td> <td data-bbox="611 1736 991 2046"> <p><b>15</b> 6900</p>  <p>VISORS, ASSIST HANDLES &amp; MIRRORS</p> </td> <td data-bbox="991 1736 1371 2046"> <p><b>14</b> 6870</p>  <p>SERVICE TOOLS</p> </td> <td data-bbox="1371 1736 1751 2046"> <p><b>13</b></p> </td> <td data-bbox="1751 1736 2132 2046"> <p><b>12</b> 6860</p>  <p>FLOOR MATS &amp; PADS</p> </td> <td data-bbox="2132 1736 2539 2046"> <p><b>11</b></p> </td> </tr> </table>						<p><b>16</b> 6930</p>  <p>CAUTION PLATES &amp; LABELS</p>	<p><b>15</b> 6900</p>  <p>VISORS, ASSIST HANDLES &amp; MIRRORS</p>	<p><b>14</b> 6870</p>  <p>SERVICE TOOLS</p>	<p><b>13</b></p>	<p><b>12</b> 6860</p>  <p>FLOOR MATS &amp; PADS</p>	<p><b>11</b></p>
<p><b>16</b> 6930</p>  <p>CAUTION PLATES &amp; LABELS</p>	<p><b>15</b> 6900</p>  <p>VISORS, ASSIST HANDLES &amp; MIRRORS</p>	<p><b>14</b> 6870</p>  <p>SERVICE TOOLS</p>	<p><b>13</b></p>	<p><b>12</b> 6860</p>  <p>FLOOR MATS &amp; PADS</p>	<p><b>11</b></p>						
<p><b>9</b> 6820</p>  <p>FRONT HEADER TRIM &amp; PILLAR TRIMS</p>											
<p><b>10</b> 6840</p>  <p>TRIMS &amp; SCUFF PLATES</p>											

As this illustration is prepared to be applicable to all models, some parts are different in specifications from the parts listed in this parts Catalog.

## SECTION NAME INDEX (ENGINE)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
1-C03	1000	SHORT ENGINE & GASKET SETS						
1-D03	1010	CYLINDER HEAD & COVER						
1-G03	1030	CYLINDER BLOCK						
1-I03	1040	OIL PAN & TIMING COVER						
1-K03	1100	PISTON, CRANKSHAFT & FLYWHEEL						
1-N03	1200	VALVE SYSTEM						
1-D04	1300	INLET MANIFOLD						
1-E04	1310	EXHAUST MANIFOLD						
1-F04	1320	FUEL SYSTEM						
1-H04	1325	FUEL DISTRIBUTOR						
1-I04	1330	AIR CLEANER						
1-K04	1364	THROTTLE BODY						
1-L04	1370	EMISSION CONTROL SYSTEM (INLET SIDE)						
1-M04	1399	CAP & HOSE CLIP (INLET & EXHAUST SIDE)						
1-N04	1400	OIL PUMP & FILTER						
1-C05	1500	COOLING SYSTEM						
1-G05	1580	BRACKET, PULLEY & BELT						
1-C06	1600	CLUTCH DISC & COVER (MANUAL)						
1-D06	1700	TRANSMISSION CASE (MANUAL)						
1-E06	1710	TRANSMISSION GEARS (MANUAL)						
1-J06	1720	CHANGE CONTROL SYSTEM (MANUAL)						
1-M06	1800	ENGINE ELECTRICAL SYSTEM						
1-C07	1830	ALTERNATOR						
1-E07	1840	STARTER						
1-G07	1850	BATTERY						
1-H07	1910	TORQUE CONVERTER, OIL PUMP & PIPINGS (AUTOMATIC)						
1-K07	1920	TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)						
1-E08	1925	CONTROL VALVE (AUTOMATIC)						
1-I08	1930	CLUTCHES & PLANETARY GEARS (AUTOMATIC)						
1-D09	1940	GOVERNOR, LOW & REVERSE PISTON (AUTOMATIC)						
1-G09	1950	MANUAL LINKAGE SYSTEM (AUTOMATIC)						
1-I09	1960	GASKET & SEAL KIT (AUTOMATIC)						



## SECTION NAME INDEX (CHASSIS)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
1-C11	2505	REAR PROPELLER SHAFT	1-J16	4400	PARKING BRAKE SYSTEM			
1-D11	2550	REAR DRIVE SHAFT	1-L16	4500	FUEL PIPINGS			
1-E11	2600	REAR AXLE	2-C03	4600	CHANGE CONTROL SYSTEM (AT)			
1-F11	2610	REAR BRAKE MECHANISMS						
1-H11	2710	REAR DIFFERENTIALS (NORMAL DIFF.)						
1-L11	2710 A	REAR DIFFERENTIALS (LIMITED SLIP DIFF.)						
1-D12	2800	REAR SUSPENSION MECHANISMS						
1-E12	2801	REAR SPRING & DAMPER						
1-F12	2810	REAR STABILIZER						
1-G12	2830	REAR LOWER ARMS & SUB FRAME						
1-I12	3200	STEERING WHEEL						
1-L12	3210	STEERING COLUMN & SHAFTS						
1-M12	3220	STEERING GEAR (W/O POWER STEERING)						
1-C13	3220 A	STEERING GEAR (W/ POWER STEERING)						
1-F13	3240	POWER STEERING SYSTEM						
1-H13	3303	FRONT AXLE						
1-I13	3310	FRONT BRAKE MECHANISMS						
1-K13	3400	FRONT SUSPENSION MECHANISMS						
1-M13	3401	FRONT SPRING & DAMPER						
1-N13	3410	CROSSMEMBER & STABILIZER						
1-C14	3700	TIRES & JACK						
1-C15	3900	ENGINE & T/MISSION MOUNTINGS						
1-D15	4000	EXHAUST SYSTEM						
1-F15	4140	CLUTCH RELEASE & MASTER CYLINDERS (MANUAL TRANSMISSION)						
1-G15	4145	CLUTCH PIPINGS (MANUAL TRANSMISSION)						
1-H15	4160	ACCELERATOR CONTROL SYSTEM						
1-I15	4200	FUEL TANK						
1-M15	4300	CLUTCH & BRAKE PEDALS (MANUAL TRANSMISSION)						
1-D16	4300A	BRAKE PEDALS (AUTOMATIC TRANSMISSION)						
1-F16	4340	BRAKE MASTER CYLINDER & POWER BRAKE						
1-H16	4360	BRAKE PIPINGS						

## SECTION NAME INDEX (BODY)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
2-C05	0900	KEY SETS	2-E12	6115	HEATER CONTROLS COMPONENTS	3-C03	7900	ACCESSORIES
2-E05	5000	FRONT BUMPER	2-F12	6120	HEATER BLOWER COMPONENTS			
2-H05	5010	REAR BUMPER	2-G12	6130	AIR CONDITIONER			
2-J05	5030	WINDOW MOULDING & COWL GRILLES	2-K12	6135	O RING SET, PIPING			
2-L05	5100	HEAD LAMPS	2-L12	6140	COMPRESSOR COMPONENTS (AIR CON DITIONER)			
2-M05	5103	HEAD LAMP RETRACTORS	2-N12	6150	COOLING UNIT (AIR CONDITIONER)			
2-D06	5105	FRONT COMBINATION LAMPS	2-C13	6300	WINDOW GLASSES			
2-F06	5110	REAR COMBINATION LAMPS	2-D13	6330	SUNROOF			
2-I06	5120	LICENSE LAMPS	2-M13	6600	SWITCHES & RELAYS (ENGINE)			
2-J06	5180	REAR FINISHER	2-D14	6610	DASHBOARD SWITCHES			
2-L06	5230	BONNET	2-E14	6611	COMBINATION SWITCH			
2-N06	5260	TRUNK LID	2-F14	6630	RELAYS & UNIT (BODY)			
2-D07	5310	BODY PANELS (FRONT)	2-G14	6635	DOOR SWITCH & HORNS			
2-E07	5320	BODY PANELS (FENDER & WHEEL AP RON)	2-H14	6640	AUTO CRUISE CONTROL SYSTEM			
2-H07	5330	BODY PANELS (DASH & COWL PANEL )	2-I14	6680	AUDIO SYSTEMS (RADIO & TAPE DE CK)			
2-I07	5340	BODY PANELS (SIDE)	2-K14	6682	AUDIO SYSTEMS (ANTENNA & SPEAK ER)			
2-C08	5370	BODY PANELS (FLOOR)	2-L14	6700	WIRING HARNESES (FRONT & REAR )			
2-F08	5380	FLOOR ATTACHMENTS (HOLE COVERS )	2-N14	6701	WIRING HARNESES (ENGINE & T/MI SSION)			
2-G08	5390	FLOOR ATTACHMENTS	2-D15	6702	WIRING HARNESES (DASHBOARD)			
2-C09	5500	DASHBOARD EQUIPMENTS	2-E15	6703	WIRING HARNESES (DOOR, FLOOR/CE ILING)			
2-E09	5520	METER HOOD	2-F15	6704	WIRING HARNESS CLAMPS			
2-F09	5530	SPEEDOMETER CABLE	2-I15	6720	WINDSHIELD WASHER			
2-G09	5540	METER COMPONENTS	2-K15	6730	WINDSHIELD WIPERS			
2-I09	5560	DASHBOARD & RELATED PARTS	2-M15	6740	WIPER MOTOR COMPONENTS (FRONT)			
2-L09	5570	CONSOLE	2-N15	6820	FRONT HEADER TRIM & PILLAR TRI MS			
2-C10	5580	VENTILATOR	2-C16	6840	TRIMS & SCUFF PLATES			
2-D10	5700	SEATS	2-E16	6860	FLOOR MATS & PADS			
2-K10	5790	SEAT BELTS	2-G16	6870	SERVICE TOOLS			
2-L10	5800	FRONT DOORS	2-H16	6900	VISORS, ASSIST HANDLES & MIRROR S			
2-C11	5830	FRONT DOOR MECHANISMS	2-J16	6930	CAUTION PLATES & LABELS			
2-F11	5840	FRONT DOOR TRIMS & RELATED PAR TS	2-L16	7250	QUARTER WINDOW & TRIMS			
2-C12	6100	HEATER						
2-D12	6110	HEATER UNIT COMPONENTS						

## SECTION NAME INDEX (ENGINE)


LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
1-C03	1000	SHORT ENGINE & GASKET SETS						
1-D03	1010	CYLINDER HEAD & COVER						
1-G03	1030	CYLINDER BLOCK						
1-I03	1040	OIL PAN & TIMING COVER						
1-K03	1100	PISTON, CRANKSHAFT & FLYWHEEL						
1-N03	1200	VALVE SYSTEM						
1-D04	1300	INLET MANIFOLD						
1-E04	1310	EXHAUST MANIFOLD						
1-F04	1320	FUEL SYSTEM						
1-H04	1325	FUEL DISTRIBUTOR						
1-I04	1330	AIR CLEANER						
1-K04	1364	THROTTLE BODY						
1-L04	1370	EMISSION CONTROL SYSTEM (INLET SIDE)						
1-M04	1399	CAP & HOSE CLIP (INLET & EXHAUST SIDE)						
1-N04	1400	OIL PUMP & FILTER						
1-C05	1500	COOLING SYSTEM						
1-G05	1580	BRACKET, PULLEY & BELT						
1-C06	1600	CLUTCH DISC & COVER (MANUAL)						
1-D06	1700	TRANSMISSION CASE (MANUAL)						
1-E06	1710	TRANSMISSION GEARS (MANUAL)						
1-J06	1720	CHANGE CONTROL SYSTEM (MANUAL)						
1-M06	1800	ENGINE ELECTRICAL SYSTEM						
1-C07	1830	ALTERNATOR						
1-E07	1840	STARTER						
1-G07	1850	BATTERY						
1-H07	1910	TORQUE CONVERTER, OIL PUMP & PIPINGS (AUTOMATIC)						
1-K07	1920	TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)						
1-E08	1925	CONTROL VALVE (AUTOMATIC)						
1-I08	1930	CLUTCHES & PLANETARY GEARS (AUTOMATIC)						
1-D09	1940	GOVERNOR, LOW & REVERSE PISTON (AUTOMATIC)						
1-G09	1950	MANUAL LINKAGE SYSTEM (AUTOMATIC)						
1-I09	1960	GASKET & SEAL KIT (AUTOMATIC)						



1000 SHORT ENGINE & GASKET SETS

10-271S


- 1-SEAL, VALVE.....(16)
- 2-GASKET, HEAD COVER.....(1)
- 3-GASKET, CYLINDER HEAD.....(1)
- 4-GASKET, IN. MANIFOLD.....(1)
- 5-GASKET, EX. MANIFOLD.....(1)
- 6-GASKET, EX. MANIFOLD.....(1)
- 7-GASKET, THERMOSTAT COVER.....(2)
- 8-GASKET, OIL PAN.....(1)
- 9-GASKET, OIL PAN.....(1)
- 10-GASKET, T. B. COVER LWR.....(1)
- 11-GASKET (L).....(2)
- 12-GASKET (INN), TIMING BELT (L).....(1)
- 13-GASKET (C), TIMING BELT (L).....(1)
- 14-GASKET, T. BELT COVER-C.....(1)
- 15-RUBBER, SEAL-SEAL PLATE.....(1)
- 16-SEAL, OIL.....(1)
- 17-SEAL, OIL.....(2)
- 18-SEAL, OIL-CDRANKSHAFT.....(1)
- 19-GASKET, OIL PUMP.....(1)
- 20-GASKET, WATER PUMP.....(1)
- 21-GASKET, W. PUMP INLET.....(1)
- 22-RING, O -WATER BY-PASS.....(1)



23-800

- 1-SEAL, VALVE.....(16)
- 2-GASKET, HEAD COVER.....(1)
- 3-GASKET, CYLINDER HEAD.....(1)
- 4-GASKET, IN. MANIFOLD.....(1)
- 5-GASKET, EX. MANIFOLD.....(1)
- 6-GASKET, EX. MANIFOLD.....(1)
- 7-GASKET, THERMOSTAT COVER.....(1)

10-235S




1000 -1 M SHORT ENGINE & GASKET SETS

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
10-235S		GASKET SET, CYL. HEAD			
8AN1-10-235	1				
10-271S		GASKET SET, ENGINE			
8AN1-10-271	1				
23-800		ENGINE, SHORT			
B64E-02-200 A (B64E-02-200A)	1				-9A04
B64J-02-200 A (B64J-02-200A)	1				-0222
B64E-02-200A A (B64E-02-200B)	1				9A04-0222
B64E-02-2008	1	(IT)			0222-
B64J-02-200A	1	(A)			0222-

9A04 NA35MM-12322  
0222 NA35MM-140861

1010 CYLINDER HEAD & COVER


1010 -1 CYLINDER HEAD & COVER



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
10-100		HEAD,CYLINDER			
B61P-10-100A AN(B61P-10-100B)	1				-9901
B61P-10-100B	1				9901-
10-106		CLIP,VALVE GUIDE			
B660-10-106	16				
10-119		STUD			
FE4J-13-146	3				
10-126		BOLT,CAMSHAFT CAP			
B660-10-126	20				
10-135		BOLT,CYLINDER HEAD			
B660-10-135A	10				
10-138		WASHER,PLAIN CYL. HE AD			
B630-10-138A	10				
10-142		STUD,EX. MANIFOLD			
B660-10-104A	9				
10-22X		PLATE,OIL BAFFLE-IN. SIDE			
B61P-10-22X	1				
10-22Y		PLATE,OIL BAFFLE-EX.			
B6S7-10-22Y	1				
10-220		COVER,CYLINDER HEAD			
B61P-10-210B A (B61P-10-210C)	1				-9904
B61P-10-210C	1				9904-
10-227		PLATE,BAFFLE			
B61P-10-227	1				
10-229A		PLATE,OIL BAFFLE			
B6S7-10-225	2				
10-235		GASKET,HEAD COVER			

9901 NA35MM-119257  
9904 NA35MM-119498

1010 CYLINDER HEAD & COVER




1010 -2 CYLINDER HEAD & COVER

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
B61P-10-235	1	NON ASBESTOS			
10-241B		PROTECTOR, HT. CORD-S. TANK			
B660-10-241	2				
10-244		BOLT, CYLINDER HEAD COVER			
B660-10-244	11				
10-250		CAP, OIL FILLER			
0453-10-250A	1				
10-252		GASKET			
0324-10-252	1				
10-271		GASKET, CYLINDER HEAD			
B6F4-10-271A	1	NON ASBESTOS			
10-561		HANGER, ENGINE			
B660-10-561	2				-9801
B660-10-561	1				9801-
10-561B		HANGER, ENGINE-REAR			
B61P-10-565	1				9801-
10-945B		BOLT			
B61P-13-366	2				
13-104H		CAP, BLIND			
F667-13-104	1				-9801
13-104T		CAP, SEALING			
FEA7-13-104	1				9801-
13-338		SEAL, RUBBER			
E301-13-338A	1				
13-342A		PIPE, VENTILATION			
B61P-13-74XA	1				

9801 NA35MM-116316  
9801 NA35MM-126490

1010 CYLINDER HEAD & COVER


1010 -3 M CYLINDER HEAD & COVER



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
13-740 B61P-13-740A	1	HOSE, VENT.-PURGE CON T. V.			
13-742B B61P-13-742A	1	HOSE, VENTILATION			
13-743 B61P-13-743A	1	HOSE, VENTILATION			
13-890 BP05-13-890	1	VALVE, P.C.V.			
13-895B B61P-13-741	1	HOSE, P.C.V.			
13-986D B61P-13-986	1	ORIFICE			
15-538 JF02-15-538	1	CLAMP, WATER HOSE			
23-080 B620-10-280	8	GUIDE, VALVE			
23-090 B620-10-290	8	GUIDE, VALVE			

1030 CYLINDER BLOCK

1030 -1 CYLINDER BLOCK



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
10-300		BLOCK, CYLINDER			
B6A7-10-300G	1				-9330
B64J-10-300	1				9330-
10-304		JET, OIL			
B660-10-580A	4				
10-305A		PLUG			
B366-10-305	1				9330-
10-306		PIN, TUBULAR			
B630-10-306	2				
10-316		PLUG, OIL CONTROL			
B630-10-305	1				-9330
10-319		JOINT			
B630-10-319	1				
10-325		PIPE, OIL LEVEL GAUGE			
B61P-10-440	1				
10-327		PLUG, BLIND			
0221-10-327	2				
10-328		COVER, BLIND-CYL. BLOCK			
B660-10-328	1				
10-352		BOLT, BEARING CAP			
B630-10-352	10				
10-450		GAUGE, OIL LEVEL			
B61P-10-450B A (B61P-10-450C)	1				-9825
B61P-10-450C	1				9825-
10-460J		RING, 'O'			
79541-00907	1				
10-715A		GASKET, OIL JET			
SE01-10-715	8				


9330 NA35MM-100072  
9825 NA35MM-118378

CAT. AUNA01-07

1992-02



1030 CYLINDER BLOCK



1030 -2 M CYLINDER BLOCK


PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
10-730A		VALVE, OIL JET			
SE01-10-730	4				
15-612		PLUG			
SE01-15-612	1				
18-291B		CLAMP, HOSE			
R230-15-538	1				

CAT. AUNA01-07

1992-02

1040 OIL PAN & TIMING COVER

1040 -1 OIL PAN & TIMING COVER




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
10-308		PIN, TUBULAR			
B6F4-10-308	1				
10-400		PAN, OIL			
B6Y0-10-400B A (B6Y0-10-400C)	1				-0201
B6Y0-10-400C	1				0201-
10-404		PLUG, DRAIN			
B6S7-10-404 (B6S7-10-404A)	1				-0201
B6S7-10-404A	1				0201-
10-406A		PLATE, OIL BAFFLE-CYL BLK			
B61P-10-40YA	1				
10-426		BOLT			
B6S7-10-465	2				
10-427		GASKET, OIL PAN			
B6F4-10-427	1				
10-428		GASKET, OIL PAN			
B6F4-10-428	1				
10-501B		COVER, TIMING BELT-LW R			
B660-10-501D	1				
10-502B		GASKET, T.B. COVER LWR			
B660-10-502B	1	NON ASBESTOS			
10-510A		COVER(UP.), TIMING CH AIN			
B61P-10-510	1				
10-512		GASKET(L)			
B61P-10-512	1	NON ASBESTOS			
10-513D		GASKET(INN), TIMING B ELT(L)			
B61P-10-513	1	NON ASBESTOS			
0201 NA35MM-137180					

CAT. AUNA01-07

1992-02

1040 OIL PAN & TIMING COVER


1040 -2 \* OIL PAN & TIMING COVER



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM TO
10-514D B61P-10-514	1	GASKET(C),TIMING BELT(L) NON ASBESTOS			
10-521A B660-10-521A AN(B660-10-521B)	1	COVER,TIMING BELT-C.			-9626
B660-10-521B	1				9626-
10-522 B660-10-522	1	GASKET,T.BELT COVER-C. NON ASBESTOS			
10-540 B61P-10-540B	1	PLATE,SEAL-T.BELT COVER U			
10-544 B61P-10-544	1	RUBBER,SEAL-SEAL PLATE			
10-602A F801-10-602	2	SEAL,OIL			
10-901 B61P-10-901 A (B61P-10-901A)	1	PLATE,END			-9701
B61P-10-901A	1	(MT)			9701-
10-910 B64J-10-901	1	COVER,END PLATE			
B64J-10-903	1	(AT)			
11-310 B366-11-310 A (B366-11-310B)	1	COVER,REAR			-9701
B366-11-310B	1				9701-
11-399A B630-11-312	1	SEAL,OIL-CRANKSHAFT			
23-0451 8527-77-739	1	TUBE,SILICON			
9626 NA35MM-111021 9701 NA35MM-111969					


CAT. AUNA01-07

1992-02



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
11-205		CLIP			
0221-11-205	8				
11-210		ROD, CONNECTING			
B6S7-11-210D	4				
11-215		NUT, CONNECTING ROD			
B6S7-11-215A	8				
11-301		CRANKSHAFT			
B616-11-300B	1				
11-301J		KEY, WOODRUFF-PULLEY			
B630-11-317 A (B630-11-317A)	1				-0101
B630-11-317A	1				0101-
11-321		PULLEY, TIMING BELT			
B366-11-321A	1				
11-371		PULLEY, CRANKSHAFT			
B6S7-11-401A	1				
11-376		BOLT, PULLEY			
B631-11-405	4				
11-404		PLATE, TIMING BELT GUIDE			
B541-11-404	1				
11-406		BOLT, LOCK-C. SHAFT PULLEY			
B630-11-406C	1				
11-408		PLATE, CRANKSHAFT PULLEY			
B630-11-408B	1				
11-414		PLATE (OUT), TIMING BELT			
B631-11-414	1				
11-500		WHEEL, FLY			
B61P-11-500	1 (MT)				

0101 NA35MM-133591




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
11-500J	1	BEARING, BALL-FLY WHEEL			
F801-11-303	1	(MT)			
11-502	1	GEAR, RING-FLY WHEEL			
B367-11-502	1	(MT)			
11-511	6	BOLT, LOCK-FLY WHEEL			
F201-11-511	6	(MT)			
23-105	1	METAL SET, CONN. ROD			
B6Y1-11-SE0	1	STD.			
B6Y1-11-SFX	1	O.S. 0.50			
B6Y1-11-SFY	1	O.S. 0.75			
B6Y1-11-SF0	1	O.S. 0.25			
23-130	1	RING SET, PISTON			
B6Y3-11-SC0	1	STD. (AT)			
B6Y3-11-SDX	1	O.S. 0.50 (AT)			
B6Y3-11-SD0	1	O.S. 0.25 (AT)			
B6Y4-11-SC0	1	STD.			
A (B6Y4-11-SC0A)	1				-9A04
B6Y4-11-SDX	1	O.S. 0.50			
A (B6Y4-11-SDXA)	1				-9A04
B6Y4-11-SD0	1	O.S. 0.25			
A (B6Y4-11-SD0A)	1				-9A04
B6Y4-11-SC0A	1	STD. (MT)			9A04-
B6Y4-11-SDXA	1	O.S. 0.50 (MT)			9A04-
B6Y4-11-SD0A	1	O.S. 0.25 (MT)			9A04-
23-151	1	METAL SET, MAIN BRG.			
B6Y2-11-SG0	1	STD.			
B6Y1-11-SHX	1	O.S. 0.50			


9A04 NA35NW-123222

1100 PISTON, CRANKSHAFT & FLYWHEEL

1100 -3 X PISTON, CRANKSHAFT & FLYWHEEL



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
B6Y1-11-SHO	1	O.S. 0.25			
23-200		PISTON SET			
B6Z5-11-SAO	4	STD. (AT)			
B6Z5-11-SBX	4	O.S. 0.50 (AT)			
B6Z5-11-SBO	4	O.S. 0.20 (AT)			
B6Z2-11-SAOB A (B6Z2-11-SAOC)	4	STD			-9601
B6Z2-11-SBXB A (B6Z2-11-SBXC)	4	O.S. 0.50			-9601
B6Z2-11-SBOB A (B6Z2-11-SBOC)	4	O.S. 0.25			-9601
B6Z2-11-SAOC	4	STD. (MT)			9601-
B6Z2-11-SBXC	4	O.S. 0.50 (MT)			9601-
B6Z2-11-SBOC	4	O.S. 0.25 (MT)			9601-
23-201		METAL SET, THRUST			
B6Y0-11-SJO A (B6Y1-11-SJO)	1	STD.			-0405
B6Y0-11-SKX A (B6Y1-11-SKX)	1	O.S. 0.50			-0405
B6Y0-11-SKY	1	O.S. 0.75			-0405
B6Y0-11-SKO A (B6Y1-11-SKO)	1	O.S. 0.25			-0405
B6Y1-11-SJO	1	STD.			0405-
B6Y1-11-SKX	1	O.S. 0.50			0405-
B6Y1-11-SKY	1	O.S. 0.75			0405-
B6Y1-11-SKO	1	O.S. 0.25			0405-
9601 NA35MM-106797 0405 NA35MM-147140					



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
10-155		SEAL, VALVE			
B660-10-155	16				
12-101		ADJUSTER, HYDRAULIC LASH			
B660-12-101	16	NITTAN VALVE			
12-111		VALVE, INLET			
B6S7-12-111	8				
12-112A		SEAT, VALVE SPG-UP.			
BJ01-12-113	8				
B660-12-113	8				
12-114		COTTER, VALVE			
B660-12-114	32				
12-114A		SPRING, OUT.-VALVE			
B61P-12-125	8				
12-114B		SPRING, VALVE			
BJ01-12-125	8				
12-116A		SEAT, VALVE SPG.-LWR			
B660-12-123	16				
12-121		VALVE, EXHAUST			
B660-12-121	8				
12-205		BELT, TIMING			
B6S7-12-205A	1				
12-420		CAMSHAFT			
B64J-12-420	1 (AT)				
B660-12-420C	1 (MT)				
12-425A		PULLEY, CAMSHAFT			
B6S7-12-425A	2				
12-440		CAMSHAFT, EXHAUST			
B6A7-12-440A	1 (AT)				


## SECTION NAME INDEX (ENGINE)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
1-C03	1000	SHORT ENGINE & GASKET SETS						
1-D03	1010	CYLINDER HEAD & COVER						
1-G03	1030	CYLINDER BLOCK						
1-I03	1040	OIL PAN & TIMING COVER						
1-K03	1100	PISTON, CRANKSHAFT & FLYWHEEL						
1-N03	1200	VALVE SYSTEM						
1-D04	1300	INLET MANIFOLD						
1-E04	1310	EXHAUST MANIFOLD						
1-F04	1320	FUEL SYSTEM						
1-H04	1325	FUEL DISTRIBUTOR						
1-I04	1330	AIR CLEANER						
1-K04	1364	THROTTLE BODY						
1-L04	1370	EMISSION CONTROL SYSTEM (INLET SIDE)						
1-M04	1399	CAP & HOSE CLIP (INLET & EXHAUST SIDE)						
1-N04	1400	OIL PUMP & FILTER						
1-C05	1500	COOLING SYSTEM						
1-G05	1580	BRACKET, PULLEY & BELT						
1-C06	1600	CLUTCH DISC & COVER (MANUAL)						
1-D06	1700	TRANSMISSION CASE (MANUAL)						
1-E06	1710	TRANSMISSION GEARS (MANUAL)						
1-J06	1720	CHANGE CONTROL SYSTEM (MANUAL)						
1-M06	1800	ENGINE ELECTRICAL SYSTEM						
1-C07	1830	ALTERNATOR						
1-E07	1840	STARTER						
1-G07	1850	BATTERY						
1-H07	1910	TORQUE CONVERTER, OIL PUMP & PIPINGS (AUTOMATIC)						
1-K07	1920	TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)						
1-E08	1925	CONTROL VALVE (AUTOMATIC)						
1-I08	1930	CLUTCHES & PLANETARY GEARS (AUTOMATIC)						
1-D09	1940	GOVERNOR, LOW & REVERSE PISTON (AUTOMATIC)						
1-G09	1950	MANUAL LINKAGE SYSTEM (AUTOMATIC)						
1-T09	1960	GASKET & SEAL KIT (AUTOMATIC)						





1200 VALVE SYSTEM




1200 -2 M VALVE SYSTEM

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
B61P-12-440	1	(MT)			
12-700		TENSIONER, T. BELT			
B660-12-700C	1				
12-711		SPRING, TENSIONER			
B660-12-711C	1				
12-730		IDLER, TIMING BELT			
B660-12-730B	1				

1300 INLET MANIFOLD

1300 -1 M INLET MANIFOLD



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
13-100		MANIFOLD, INLET			
B61P-13-100B A (B61P-13-100C)	1				-9417
B61P-13-100C AN(B61P-13-100D)	1				9417-0404
B61P-13-100D	1				0404-
13-111		GASKET, IN. MANIFOLD NON ASBESTOS			
B61P-13-111	1				
13-121B		STAY, MANIFOLD			
B61P-13-121	1				
13-140		BRKT. SURGE TANK			
B61P-13-140	1				
13-665B		BRACKET, ACCEL WIRE			
B61P-13-665	1				


9417 NA35MM-100773  
0404 NA35MM-146945

\* NOTES : REFER TO SECT. NO. 1399 AS FOR CAPS.

AUNA01

CAT. AUNA01-07


1992-02



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
13-380		INSULATOR, HEAT			
B61P-13-380A	1				-9C01
B61P-13-380B	1				9C01-
13-450		MANIFOLD, EXHAUST			
B61P-13-450	1				-9714
A (B61P-13-450A)					
B61P-13-450A	1				9714-
13-456		STUD			
2306-13-456	3				
13-461		NUT, EX. MANIFOLD			
B6S7-13-465	9				
13-462		GASKET, EX. MANIFOLD			
B695-13-460	1	NON ASBESTOS			-9801
A (B695-13-460A)					
B695-13-460A	1	NON ASBESTOS			9801-
13-462A		GASKET, EX. MANIFOLD			
B695-13-462	1				
13-5122		BRACKET, EX. MANIFOLD			
B61P-13-468	1				9C01-

9714 NA35MM-113830  
 9801 NA35MM-116316  
 9C01 NA35MM-130310

1320 FUEL SYSTEM



1320 -1 FUEL SYSTEM


PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
13-ZE0		PUMP, FUEL			
B61P-13-ZE0	1				
13-ZE1		FILTER, FUEL PUMP			
B61P-13-ZE1	1				
13-ZE4		WASHER, LOCK-PUMP FILTER DENSO			
FEH2-13-ZE4	1				
13-ZE5		RING, 'O'-FUEL PUMP			
BJ04-13-ZE5	1				-9511
B61P-13-ZE5	1				9511-
13-350		PUMP, FUEL			
B61P-13-350B	1				
13-363I		RUBBER, INSULATION			
N326-13-363B	2 (AT)				
13-428		PROTECTOR			
B61P-13-428	2				
13-480		FILTER, FUEL			
B61P-20-490	1				
13-945F		CONNECTOR			
JE16-13-298	1				
13-960A		BRACKET, CANISTER			
B61P-13-960	1				
13-970		CANISTER			
B61P-13-970	1				
13-971A		HOSE, VACUUM			
B61P-13-971	1				
13-972		HOSE, EVAPORATION			
B61P-13-972A	1				

9511 NA35MM-103176

CAT. AUNA01-07

DISTRIBUTOR, FUEL  
(REFER TO SECT. NO. 1325)

VALVE, THREE WAY  
(REFER TO SECT. NO. 6600)




\* NOTES : REFER TO SECT. NO. 1399 AS FOR HOSE CLIPS.

AUNA01

1992-02

1320 FUEL SYSTEM




1320 -2 M FUEL SYSTEM

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
13-973		HOSE, DRAIN			
B61P-13-97YA	1				
13-973A		HOSE, EVAPORATION			
B61P-13-973A	1				
20-361A		TUBE, VACUUM			
B61P-20-361	1				
66-773A		GASKET			
NA01-60-962	1				
93-5104		HOSE			
99351-04999	1				
93-5908		HOSE			
99359-0840	1				
99359-0840M	1				

DISTRIBUTOR, FUEL  
(REFER TO SECT. NO. 1325)

VALVE, THREE WAY  
(REFER TO SECT. NO. 6600)



\* NOTES : REFER TO SECT. NO. 1399 AS FOR HOSE CLIPS.


AUNA01

CAT. AUNA01-07

1992-02


1325 FUEL DISTRIBUTOR

1325 -1 \* FUEL DISTRIBUTOR



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
13-150A		DISTRIBUTOR, FUEL			
B61P-13-150	1				
13-158		INSULATOR, FUEL DIST.			
B675-13-158	2				
13-164		BOLT, FUEL DISTRIBUTOR			
F883-13-164	2				
13-250A		INJECTOR, FUEL			
B6S7-13-250	4				
13-252		GROMMET			
8574-13-252	4				
13-253		RING, 'O'			
G601-13-253	1				
8574-13-253	4				
13-257		INSULATOR, INJECTION			
JE06-13-257	4				
13-280A		PRESSURE RG., FUEL			
B61P-13-280	1				

1330 AIR CLEANER



1330 -1 AIR CLEANER

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
13-19X		CHAMBER, RESONANCE			
B61P-13-19XA	1	(MT)			
B64J-13-19X	1	(AT)			
13-206		HOSE, AIR			
B61P-13-206A	1				
13-210A		METER, AIR FLOW			
B6S7-13-210A	1				
13-211		GASKET			
B6S7-13-211A	1	NON ASBESTOS			
13-221A		HOSE, AIR			
B61P-13-221B	1				
13-225		DUCT, FRESH AIR			
B61P-13-200A A (B61P-13-200B)	1				-9926
B61P-13-200B	1				9926-
13-245		JOINT, RUBBER			
B61P-13-245	1				
13-302		BOLT, AIR CLEANER			
F201-13-302A	5				
13-310A		BRKT, AIR FLOW METER			
B61P-13-311B	1				
13-320		CLEANER, AIR			
B61P-13-320 A (B61P-13-320A)	1				9825-
B61P-13-320A	1				9825-
13-3302		TUBE, AIR INTAKE			
B61P-13-330E	1	(MT)			
B64J-13-330	1	(AT)			
13-3312		PIPE, AIR INTAKE			

9825 NA35MM-118378  
9926 NA35MM-122894

\* NOTES : REFER TO SECT. NO. 1399 AS FOR HOSE CLIPS.


AUNA01

CAT. AUNA01-07

1992-02

1330 AIR CLEANER

1330 -2 M AIR CLEANER



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
B61P-13-331B	1				
13-3382		SPACER			
FE51-13-329	3				
13-345B		BRACKET, AIR CLEANER			
B61P-20-211	1				
13-3482		SPACER, AIR INT. PIPE			
V115-13-348	1				
SLA1-13-321	1				
13-3492		INSULATOR			
S501-13-349	1				
13-363N		RUBBER, MOUNTING			
FE51-13-363	3				
13-765A		HOSE, AIR			
B61R-13-765	1				
15-202		RUBBER, MOUNT			
E501-15-202	1	DENSO			
23-603		ELEMENT, AIR CLEANER			
B6S7-13-240	1				
23-6731		COVER, AIR CLEANER			
B61P-13-201	1				
67-CC1		CLIP, HARNESS			
NA02-67-CH1	1				

-0201  
0201-

0201 NA35MM-137180

\* NOTES : REFER TO SECT. NO. 1399 AS FOR HOSE CLIPS.

AUNA01

CAT. AUNA01-07


1942-02

1-J-4



1364 THROTTLE BODY


1364 -1 M THROTTLE BODY




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
13-W75 B551-13-W75A	1	SCREW SET, IDLE ADJUST-THR			
13-W8X B551-13-W8X	1	SCREW & WASHER SET			
13-W80 B61P-13-W80	1	BRACKET SET, DASH POT-THRO			
13-W89 B551-13-W89	1	GASKET, THERMO			
13-104H B551-13-104	1	CAP, BLIND			
13-650E B61P-13-640B B64J-13-640	1 1 (MT) 1 (AT)	BODY, THROTTLE			
18-9101 B6S8-18-911 B630-18-911	1 1 (AT) 1 (MT)	SENSOR, THROTTLE			
20-660 B61P-20-660	1	VALVE, BY-PASS AIR CONTROL			

1370 EMISSION CONTROL SYSTEM (INLET SIDE)


1370 -1 M EMISSION CONTROL SYSTEM (INLET SIDE)



93-5104		99351-04999	D=4MM

BODY, THROTTLE  
(REFER TO SECT. NO. 1364)

MANIFOLD, INLET  
(REFER TO SECT. NO. 1300)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
13-2C7		RING, 'O'-AIR VALVE			
B6S7-13-2C7	1				
13-190A		VALVE, AIR			
B61P-13-190A	1	(AT)			
B64J-13-190	1	(AT)			
13-611		BRACKET			
B61P-13-685A	1				
13-655A		GASKET			
B6S7-13-655	1	NON ASBESTOS			
13-672		HOSE, WATER			
B61P-13-682A	1				
13-681A		HOSE, WATER			
B61P-13-681B	1				
13-691B		HOSE, WATER			
B61P-13-691A	1				
20-371B		TUBE, VACUUM			
B61P-20-371	1				
93-5104		HOSE			
99351-04999	1				

\* NOTES : REFER TO SECT. NO. 1399 AS FOR HOSE CLIPS.

AUNA01


CAT. AUNA01-07

1992-02


1399 CAP & HOSE CLIP (INLET & EXHAUST SIDE)

1399 -1 \* CAP & HOSE CLIP (INLET & EXHAUST SIDE)

(REFER TO SECT.NO.1320)




(REFER TO SECT.NO.1370)



(REFER TO SECT.NO.1330)



(REFER TO SECT.NO.1300)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
13-104J		CAP, BLIND			
1010-13-104	1				
13-157A		CLIP			
8574-13-157	4				
13-225A		CLAMP, HOSE			
ESA1-13-225	1				
B61P-13-735	1				
13-447C		CLAMP, HOSE			
B61P-13-447	2				
13-736A		CLAMP, HOSE-A. I. P./A. CLNR			
B630-13-736	1				
13-736B		CLAMP, HOSE			
F249-13-736	1				
15-538		CLAMP, WATER HOSE			
JF02-15-538	6				
42-307		CAP			
0223-42-307	1 (MT)				

1400 OIL PUMP & FILTER

1400 -1 M OIL PUMP & FILTER



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
10-602A		SEAL, OIL			
B630-10-602	1				
14-100		PUMP, OIL			
B630-14-100E	1				
14-113		GASKET, OIL PUMP ASBESTOS			
B630-14-113	1				
14-115		PLUNGER, CONTROL			
0221-14-115	1				
14-116		SPRING, PRESSURE			
0324-14-116A	1				
14-118		SHEET, SPRING			
0222-14-118	1				
14-120		COVER, OIL PUMP			
B630-14-121	1				
14-124		SCREW, OIL PUMP COVER			
FE1H-14-124	6				
14-132B		GEAR, INNER			
B660-14-132	1				
14-141		GEAR, OUTER			
B660-14-141	1				
14-1711		GASKET, OIL STRAINER ASBESTOS			
0810-14-171A	1				
14-240		STRAINER, OIL			
B61P-14-240	1				
23-802		CARTRIDGE, OIL FILTER			
B6Y1-14-302	1				

CAT. AUNA01-07


1992-02

## SECTION NAME INDEX (ENGINE)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SFCTION NAME
1-C03	1000	SHORT ENGINE & GASKET SETS						
1-D03	1010	CYLINDER HEAD & COVER						
1-G03	1030	CYLINDER BLOCK						
1-I03	1040	OIL PAN & TIMING COVER						
1-K03	1100	PISTON, CRANKSHAFT & FLYWHEEL						
1-N03	1200	VALVE SYSTEM						
1-D04	1300	INLET MANIFOLD						
1-E04	1310	EXHAUST MANIFOLD						
1-F04	1320	FUEL SYSTEM						
1-H04	1325	FUEL DISTRIBUTOR						
1-I04	1330	AIR CLEANER						
1-K04	1364	THROTTLE BODY						
1-L04	1370	EMISSION CONTROL SYSTEM (INLET SIDE)						
1-M04	1399	CAP & HOSE CLIP (INLET & EXHAUST SIDE)						
1-N04	1400	OIL PUMP & FILTER						
1-C05	1500	COOLING SYSTEM						
1-G05	1580	BRACKET, PULLEY & BELT						
1-C06	1600	CLUTCH DISC & COVER (MANUAL)						
1-D06	1700	TRANSMISSION CASE (MANUAL)						
1-E06	1710	TRANSMISSION GEARS (MANUAL)						
1-J06	1720	CHANGE CONTROL SYSTEM (MANUAL)						
1-M06	1800	ENGINE ELECTRICAL SYSTEM						
1-C07	1830	ALTERNATOR						
1-E07	1840	STARTER						
1-G07	1850	BATTERY						
1-H07	1910	TORQUE CONVERTER, OIL PUMP & PIPINGS (AUTOMATIC)						
1-K07	1920	TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)						
1-E08	1925	CONTROL VALVE (AUTOMATIC)						
1-I08	1930	CLUTCHES & PLANETARY GEARS (AUTOMATIC)						
1-D09	1940	GOVERNOR, LOW & REVERSE PISTON (AUTOMATIC)						
1-G09	1950	MANUAL LINKAGE SYSTEM (AUTOMATIC)						
1-I09	1960	GASKET & SEAL KIT (AUTOMATIC)						

1500 COOLING SYSTEM


1500 -1 COOLING SYSTEM



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
15-T52 B6S8-15-T52	3	SCREW, MOTOR-ELECTRIC FAN			
15-010S 8AB8-15-010	1	PUMP SET, WATER NON ASBESTOS			
15-104 B61P-15-261A	1	HOSE, WATER BY-PASS			
15-106A B61P-15-106	1	RING, 'O'-WATER PUMP			
15-116 B621-15-116A	1	GASKET, WATER PUMP NON ASBESTOS			
15-131 B366-15-131 AN(B366-15-131A)	1	PULLEY, WATER PUMP			-9901
15-140 B6S6-15-140A	1	FAN, COOLING CALSONIC (AT)			9901-
15-160A B61P-15-160	1	INLET, WATER PUMP			
15-160C B61P-15-170A A (B61P-15-170B)	1	PIPE, WATER PUMP			-9401
15-165 B61P-15-170B	1	GASKET, W. PUMP INLET NON ASBESTOS			9401-
15-171S 8AN1-15-171	1	THERMOSTAT SET NON ASBESTOS			
9401 NA35NN-100090 9901 NA35NN-119257					



1500 COOLING SYSTEM



NOTE  
 ① ... ② → 15-0105  
 THE D-CODE OF 15-0105 CONSISTS OF  
 FIGURE NUMBERS ① THROUGH ②.

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
15-207		COCK, DRAIN			
N326-15-203	1				
15-210A		COWLING, RADIATOR			
B61P-15-210A	1				
15-2101		FAN DRIVE			
B61P-15-150A	1	(MT)			
B64J-15-150	1	(AT)			
15-224A		RUBBER, SEAL			
B660-10-543B	1				
15-287		RING, 'O'-WATER BY-PASS			
E301-15-287	1				
15-290		PIPE, BY PASS			
B61P-15-290	1				-9A01
AN(B61P-15-290A)					
B61P-15-290A	1				9A01-0301
AN(B61P-15-290B)					
B61P-15-290B	1				0301-
15-350		TANK, SUB-RADIATOR			
B61P-15-350A	1				-9419
A (B61P-15-350B)					
B61P-15-350B	1				9419-9901
AN(B61P-15-350C)					
B61P-15-350C	1				9901-
15-355A		CAP, SUB TANK			
B61P-15-355	1				-9901
AN(B61P-15-355A)					
B61P-15-355A	1				9901-
15-388		CLIP, HOSE-SUB T. & WATER H			
B61P-15-547	1				
F201-15-388	1				-9401
A (F201-15-388A)					
F201-15-388A	1				9401-

- 9401 NA35MM-100090
- 9419 NA35MM-101038
- 9901 NA35MM-119257
- 9A01 NA35MM-122908
- 0301 NA35MM-141901


AUN/01

CAT. AUNA01-07

1992-02



1500 COOLING SYSTEM





NOTE  
 ① ... ② ⇨ 15-010S  
 THE D-CODE OF 15-010S CONSISTS OF  
 FIGURE NUMBERS ① THROUGH ②.



1500 -4 M COOLING SYSTEM

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
15-538		CLAMP, WATER HOSE			
JF02-15-538	2				
93-2407		HOSE, WATER			
99324-07630	1				-9419
99324-07610	1				9419-

9419 NA35MM-101038



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
15-906 B63H-15-908	1	BELT 'V' L=953 4PK RIB.V			
B61P-15-907 AN(B61P-15-907A)	1	L=865 4PK RIB.BELT			-9626
B61P-15-907A	1	L=855 4PK RIB.BELT (W/P.S.)			9626-
15-907 B63H-15-909	1	BELT 'V' L=855 4PK RIB.V			
15-920 B61P-15-810A	1	BRACKET,COMPRESSOR (A)			
15-930 BP01-15-951	1	BRACKET, IDLE PULLEY (A)			
15-932 B631-15-932	1	SHAFT, PULLEY (A)			
15-933A BP01-15-933	1	COLLAR (A)			
15-940 BP01-15-940	1	PULLEY, IDLE (A)			
15-942A E564-15-942	1	COLLAR (A)			
15-966 E564-15-934	1	BOLT, ADJUST (A)			
15-970 BP01-15-930	1	PULLEY, IDLE (A)			
18-363		SPACER, STRAP			
9626 NA35MM-111021					



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D F201-18-363	1	(W/P.S.)			



## SECTION NAME INDEX (ENGINE)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
1-C03	1000	SHORT ENGINE & GASKET SETS						
1-D03	1010	CYLINDER HEAD & COVER						
1-G03	1030	CYLINDER BLOCK						
1-I03	1040	OIL PAN & TIMING COVER						
1-K03	1100	PISTON, CRANKSHAFT & FLYWHEEL						
1-N03	1200	VALVE SYSTEM						
1-D04	1300	INLET MANIFOLD						
1-E04	1310	EXHAUST MANIFOLD						
1-F04	1320	FUEL SYSTEM						
1-H04	1325	FUEL DISTRIBUTOR						
1-I04	1330	AIR CLEANER						
1-K04	1364	THROTTLE BODY						
1-L04	1370	EMISSION CONTROL SYSTEM (INLET SIDE)						
1-M04	1399	CAP & HOSE CLIP (INLET & EXHAUST SIDE)						
1-N04	1400	OIL PUMP & FILTER						
1-C05	1500	COOLING SYSTEM						
1-G05	1580	BRACKET, PULLEY & BELT						
1-C06	1600	CLUTCH DISC & COVER (MANUAL)						
1-D06	1700	TRANSMISSION CASE (MANUAL)						
1-E06	1710	TRANSMISSION GEARS (MANUAL)						
1-J06	1720	CHANGE CONTROL SYSTEM (MANUAL)						
1-M06	1800	ENGINE ELECTRICAL SYSTEM						
1-C07	1830	ALTERNATOR						
1-E07	1840	STARTER						
1-G07	1850	BATTERY						
1-H07	1910	TORQUE CONVERTER, OIL PUMP & PIPINGS (AUTOMATIC)						
1-K07	1920	TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)						
1-E08	1925	CONTROL VALVE (AUTOMATIC)						
1-I08	1930	CLUTCHES & PLANETARY GEARS (AUTOMATIC)						
1-D09	1940	GOVERNOR, LOW & REVERSE PISTON (AUTOMATIC)						
1-G09	1950	MANUAL LINKAGE SYSTEM (AUTOMATIC)						
1-I09	1960	GASKET & SEAL KIT (AUTOMATIC)						




1600 CLUTCH DISC & COVER (MANUAL)

1600 -1 M CLUTCH DISC & COVER (MANUAL)




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
16-102 0603-16-102B	1	PIN, PIVOT-CLUTCH REL. FORK			
16-214 FE86-16-214	1	COVER, DUST-CLUTCH FORK			
16-220 B622-16-220	1	COVER, FRONT CLUTCH			
16-225 FE50-16-225A	1	GASKET, FRONT COVER			
16-232A 1416-16-232A	1	SUPPORTER, FORK			
16-410 B622-16-410	1	COVER, CLUTCH			
16-460 B622-16-460 A (B622-16-460A)	1	DISC, CLUTCH ASBESTOS			-9330
B622-16-460A	1	ASBESTOS			9330-
16-510 B622-16-510	1	COLLAR, CLUTCH REL.			
16-520 B622-16-520	1	FORK, CLUTCH RELEASE			
17-155 H501-17-103	1	SEAL, OIL			

9330 NA35MM-100072



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
17-100 M526-17-100	1	CASE, T/MISSION			
17-122 0810-17-121	1	PLUG, MAGNET			
17-325 8086-17-326	1	COVER, BEARING			
17-330 M5Y1-17-330	1	HOUSING, EXTENSION			
17-335 M507-17-335	1	SEAL, OIL			
17-441 1472-17-441A	1	GEAR, DRIVEN N=23			
17-442 1669-17-442B	1	SLEEVE, SPEEDOMETER			
17-442J 1011-17-443	1	RING, 'O'			
17-442K 99586-08166	1	SEAL, OIL			
17-530 0884-17-530	1	BREATHER, AIR-T/MISSION			
17-540 M509-17-540	1	PASS, OIL			
17-543 M501-17-543A	1	RUBBER, SEAL			
60-076 B092-60-076A	1	GASKET, GUIDE SEAL-SP EEDD.			



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
17-201		GEAR, MAIN DRIVE			
M516-17-201	1				
17-201J		BEARING, BALL-MAIN DRIVE GEAR			
M502-17-295C	1				
17-203		BEARING, NEEDLE			
M501-17-210	1				
17-204		BEARING, BALL-MAIN SHAFT			
M503-17-204	1				
17-205		BEARING, ROLLER			
R502-17-306A	1				
17-205F		RING, RETAINING			
M501-17-205	1				
17-221		SHAFT, MAIN			
M505-17-221B	1				
17-225		RING, SNAP			
0317-17-225	1				
17-230		GEAR, 3RD			
M513-17-231	1				
17-240		HUB SET, CLUTCH-3RD & 4TH			
M502-17-240B A (M502-17-240C)	1				-9701
M502-17-240C	1				9701-
17-241		HUB, CLUTCH			
M501-17-241B	1				
17-242A		SLEEVE, CLUTCH HUB			
F401-17-242A	1				
17-243		KEY, SYNCHRONIZER			
F401-17-243A	9				

9701 NA35MM-111969




















PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
13-348C		SPACER			
B61P-13-348	1				
13-363N		RUBBER, MOUNTING			
B61P-13-363A	1				
15-966		BOLT, ADJUST			
FE38-15-966	1				
18-10X		COIL & IGNITER			
B61P-18-10XB	1				-0521
AN(B61P-18-10XC)					
B61P-18-10XC	1				0521-
18-110		PLUG, SPARK			
BP01-18-110	4	BKR5E11 NGK (OPTION HOT TYPE)			
BP02-18-110	4	K16PR-U11 DENSO (OPTION HOT TYPE)			
BP03-18-110	4	BKR6E-11 NGK (STD.)			
BP04-18-110	4	K20PR-U11 DENSO (STD.)			
BP05-18-110	4	BKR7E11 NGK (OPTION COLD TYPE)			
BP06-18-110	4	K22PR-U11 DENSO (OPTION COLD TYPE)			
18-113		BOLT			
B61P-18-1A5A	1				
18-140		CORD SET, HI. TENSION			
B61P-18-140B	1				
18-160		CORD NO. 1, HI. TENSION			
B61P-18-160B	1				
18-170		CORD NO. 2, HI. TENSION			
B61P-18-170B	1				
18-180		CORD NO. 3, HI. TENSION			
B61P-18-180B	1				


0521 NA35MM-152930

AUNA01

CAT. AUNA01-07

1992-02

ALTERNATOR  
(REFER TO SECT. NO. 1830)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
18-190		CORD NO. 4, HI. TENSION			
361P-18-190B	1				
18-265		CLIP, COUPLER			
B61R-18-266 A (B61R-18-266A)	1				-9A13
D61R-18-266A	1				9A13-
18-361		STRAP, ALTERNATOR			
B61P-18-360 A (B61P-18-360A)	1				-9B01
B61P-18-360A	1				9B01-
18-363		SPACER, STRAP			
F201-18-363	1				
18-381		BELT 'V'			
B6S7-18-381A A (B6S7-18-381B)	1	AUTO-FLEX-3 A-34.7			-0308
B6S7-18-381B	1	AUTO-FLEX-3 A-34.7			0308-
18-401C		BRACKET, STARTER			
B61P-18-410	1				
B660-18-411C	1				


9A13 NA35MM-124217  
9B01 NA35MM-126490  
0308 NA35MM-142998




## SECTION NAME INDEX (ENGINE)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
1-C03	1000	SHORT ENGINE & GASKET SETS						
1-D03	1010	CYLINDER HEAD & COVER						
1-G03	1030	CYLINDER BLOCK						
1-I03	1040	OIL PAN & TIMING COVER						
1-K03	1100	PISTON, CRANKSHAFT & FLYWHEEL						
1-N03	1200	VALVE SYSTEM						
1-D04	1300	INLET MANIFOLD						
1-E04	1310	EXHAUST MANIFOLD						
1-F04	1320	FUEL SYSTEM						
1-H04	1325	FUEL DISTRIBUTOR						
1-I04	1330	AIR CLEANER						
1-K04	1364	THROTTLE BODY						
1-L04	1370	EMISSION CONTROL SYSTEM (INLET SIDE)						
1-M04	1399	CAP & HOSE CLIP (INLET & EXHAUST SIDE)						
1-N04	1400	OIL PUMP & FILTER						
1-C05	1500	COOLING SYSTEM						
1-G05	1580	BRACKET, PULLEY & BELT						
1-C06	1600	CLUTCH DISC & COVER (MANUAL)						
1-D06	1700	TRANSMISSION CASE (MANUAL)						
1-E06	1710	TRANSMISSION GEARS (MANUAL)						
1-J06	1720	CHANGE CONTROL SYSTEM (MANUAL)						
1-M06	1800	ENGINE ELECTRICAL SYSTEM						
1-C07	1830	ALTERNATOR						
1-E07	1840	STARTER						
1-G07	1850	BATTERY						
1-H07	1910	TORQUE CONVERTER, OIL PUMP & PIPINGS (AUTOMATIC)						
1-K07	1920	TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)						
1-E08	1925	CONTROL VALVE (AUTOMATIC)						
1-I08	1930	CLUTCHES & PLANETARY GEARS (AUTOMATIC)						
1-D09	1940	GOVERNOR, LOW & REVERSE PISTON (AUTOMATIC)						
1-G09	1950	MANUAL LINKAGE SYSTEM (AUTOMATIC)						
1-I09	1960	GASKET & SEAL KIT (AUTOMATIC)						






PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
18-W25		COVER, FRONT-ALTERNATOR			
B61P-18-W25	1				
18-W10		COVER, REAR-ALTERNATOR			
B61P-18-W10	1 (MT)				
B64J-18-W50	1 (AT)				
18-W51		COVER, REAR-ALTERNATOR			
B366-18-W51	1				
18-W59		PLUG			
B675-18-W59	1				
18-300		ALTERNATOR			
B61P-18-300D	1 (MT)				
B64J-18-300A	1 (AT)				
24-501		STATOR			
B366-18-W45	1 (AT)				
G608-18-W45	1 (MT)				
24-503		BEARING, BALL-ALT. REAR			
N336-18-W36	1				
24-510		RECTIFIER			
B366-18-W60	1 (AT)				
B61P-18-W60	1 (MT)				
24-514		BEARING, BALL-ALT. FRONT			
F811-18-W27	1				
24-520		REGULATOR			
B61P-18-W70	1				
24-521		SPRING, BRUSH			
8599-24-521	2				
24-522		BRUSH			
FE2H-18-W77	2				



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
24-526		SCREW SET			
RF71-18-W26	1				
24-530		PULLEY			
B366-18-W10	1				
24-533		NUT SET			
8028-24-533	1				
24-535		SCREW SET			
RF71-18-W20	1				
24-540		ROTOR			
B61P-18-W35	1 (MT)				
B366-18-W35 A (B366-18-W35A)	1				-0601
B366-18-W35A	1 (AT)				0601-
24-590		TERMINAL SET			
N337-18-W80	1				


0601 NA35WW-154752



NOTE  
 ① ... ② ⇔ 24-725  
 THE D-CODE OF 24-725 CONSISTS OF  
 FIGURE NUMBERS ① THROUGH ②.

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
18-400		STARTER			
B61R-18-400 A (B61R-18-400A)	1	ASBESTOS			-9B21
B61R-18-400A	1	NON ASBESTOS			9B21-
24-701		YOKE			
B61R-18-X65	1				
24-710		BRACKET, FRONT			
B61R-18-X00	1				
24-712		STOPPER SET			
E356-18-X30	1				
24-720		ARMATURE			
F210-18-X60	1	ASBESTOS			-9B21
B6S8-18-X60	1	NON ASBESTOS			9B21-
24-722		CLUTCH, OVER RUNNING			
B630-18-X45	1				
24-7222		SLEEVE, BEARING-REAR			
E356-18-X81	1				
24-725		SCREW SET			
E356-18-X95					
24-726		WASHER SET			
E356-18-X92	1				
24-730		LEVER			
E356-18-X05	1				
24-731		BOLT SET			
B630-18-X90	2				
24-740		BRACKET, REAR			
E356-18-X80	1				


9B21 NA35MM-129010



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
24-7432		SLEEVE, BEARING-FRONT			
F210-18-X01	1				
24-750		HOLDER, BRUSH			
B61R-18-X70	1				
24-752		SPRING, BRUSH			
0222-24-752A	4				
24-753		BRUSH, YOKE			
B630-18-X66	2				
24-753A		BRUSH			
B660-18-X66	2				
24-760		SWITCH			
E356-18-X10	1				

NOTE  
 ① ... ② ⇒ 24-725  
 THE D-CODE OF 24-725 CONSISTS OF  
 FIGURE NUMBERS ① THROUGH ②.

1850 BATTERY



1850 -1 M BATTERY

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
18-520		BATTERY			
B61R-18-520A AN(B61R-18-520B)	1	S46A24L(S) PANASONIC			-0201
B61R-18-520B	1	S46A24L(S) PANASONIC			0201-
18-526		CONNECTOR, TUBE-BATTERY			
B61P-18-526	1				
20-346		TUBE, VACUUM			
FE4J-20-346	1				-9901
B61P-18-524	1				9901-
56-030		CLAMP, BATTERY			
NA01-56-03XA	1				
56-032		BRACKET, BATTERY CLAMP			
NA01-56-032A	1	(W/STD. BATTERY)			
56-033		BRACKET, STOPPER-BATTERY			
NA01-56-033A	1	(W/STD. BATTERY)			
56-863A		TRAY, BATTERY			
B095-56-032	1				
66-879B		JOINT			
U813-66-879	1				
70-985A		BOLT, CLAMP			
0259-54-292A	1				
93-5104		HOSE			
99351-04999	1				
9901 NA35MM-119257					
0201 NA35MM-137180					

AUNA01

CAT. AUNA01-07

1992-02








1910 -3 \* TORQUE CONVERTER, OIL PUMP & PIPINGS (AUTOMATIC)


1910 TORQUE CONVERTER, OIL PUMP & PIPINGS (AUTOMATIC)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D BU55-19-934A	1				
19-970		BRACKET			
BU55-19-970A	1				
19-980A		SUPPORT, OIL PIPE			
BU29-19-980	2				
19-985A		CLIP, OIL PIPE			
BU29-19-985	2				
20-318A		BOLT			
BU27-19-838	1				
21-5C0		BREATHER			
BU55-21-5C0A	1				
21-660		TUBE, GOVERNOR			
BU55-21-660	1				
21-665		WASHER, SEAL			
BU01-21-665	4				
21-666		BOLT, CONNECTOR			
BU01-21-666	1				
BU17-21-666	1				
21-677		RTNG, 'O'			
BU01-21-677	1				
93-4405		HOSE			
99344-05150	1				

1920 TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)

1920 -1 TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
10-460J		RING, 'O'			
99541-01201	1				
17-335		SEAL, OIL			
M507-17-335	1				
17-441		GEAR, DRIVEN			
BU55-17-441	1				
17-442		SLEEVE, SPEEDOMETER			
BU55-17-442	1				
17-442J		RING, 'O'			
1011-17-443	1				
17-442K		SEAL, OIL			
99586-08166	1				
19-256		RING, SEAL			
BU01-19-256	4				
19-257		RING, SEAL			
BU01-19-257	2				
19-258		SEAL, CUT RING			
0338-19-258	1				
19-3C8		BOLT, BUFFLE PLATE			
BU55-19-3C8	1				
19-310		CASE, T/MISSION			
BU55-19-310A	1				
19-331		PLUG, SQUARE HEAD			
BV11-19-3C4	2				
19-332		CONNECTOR, STRAIGHT			
BU01-19-332A	1				
19-341		BOLT, ANCHOR END			
0338-19-341	1				

AUNA01


CAT. AUNA01-07

1992-02

1-K-7

1920 TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)

1920 -2 TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
19-361		STRUT, BAND			
0338-19-361B	2				
19-363A		SPRING, PISTON RETURN			
BU55-19-3F3	1				
BU17-19-363	1				
19-368		SPRING, CUSHION-PSTN. STEM			
BU20-19-368	1				
19-381		PISTON, BAND SERVO			
BU06-19-381	1				
BV03-19-381	1				
19-384A		SEAL, PISTON			
BU10-19-384	1				
BU55-19-384	1				
19-385		SEAL, PISTON			
FT03-19-385	1	D=44MM			
0842-19-385	1	D=36MM			
19-386		STEM, PISTON			
0338-19-386A	1				
19-388		WASHER, PLAIN			
0338-19-388A	2				
19-389		NUT			
0338-19-389	2				
19-391		RETAINER, SERVO			
BU06-19-391	1				
19-392		COVER, SERVO			
1758-19-392A	1				
19-394		SEAL, LATHE CUT			
0842-19-394	1				

NOTE  
 ① ... ④ ⇨ 19-310  
 THE D-CODE OF 19-310 CONSISTS OF FIGURE NUMBERS ① THROUGH ④.

AUNA01


CAT. AUNA01-0

1972-02

1-L 7

1920 TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)

1920 -3 TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
19-395		RING, 'O'			
0338-19-395	1				
19-396A		GASKET ASBESTOS			
1758-19-394A	1				
19-397		BOLT			
1758-19-397	3				
19-398		BOLT			
0338-19-398	3				
19-700		HOUSING, EXTENSION			
BUY2-19-7A0	1				
19-710		HOUSING, EXTENSION			
BU55-19-710	1				
19-735		GASKET, EXTENSION ASBESTOS			
0338-19-735	1				
19-737		BOLT			
0338-19-737	8				
19-739		WASHER, PLAIN			
0338-19-739	8				
19-822		SEAL, O-RING			
0338-19-822	2				
19-823		DIAPHRAGM, VACUUM			
BU55-19-823	1				
19-825		ROD, DIAPHRAGM			
BU55-19-825	1	L=29.75MM			
0338-19-825	1	L=30MM			
0338-19-826	1	L=31MM			


AUNA01

CAT. AUNA01-07

1992-02

1-M 7

1920 TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)



PAR' NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
0338-19-827	1	L=30.5MM			
0338-19-828	1	L=29MM			
0338-19-829	1	L=29.5MM			
19-831		BOLT, CONTROL VALVE			
0338-19-831	2				
19-832		BOLT, CONTROL VALVE			
0338-19-832	2				
19-833		BOLT, CONTROL VALVE			
0338-19-833	3				
19-835		GASKET, OIL PAN			
0338-19-835B	1	ASBESTOS			
19-836		PAN, OIL			
0338-19-836A	1				
19-837		BOLT, OIL PAN			
0338-19-837	17				
19-870A		TUBE, FILLER			
BU55-19-870	1				
19-870J		RING, 'O'			
99541-01601	1				
19-880		GAUGE, OIL LEVEL			
BU17-19-880B	1				
19-890		TUBE, OIL FILTER-UPPER			
BU55-19-890	1				
19-980		BRACKET			
BU55-19-980A	1				
19-986A		BUSH, RUBBER			

AUNA01

CAT. AUNA01-07

1992-02


1-N-74

## SECTION NAME INDEX (ENGINE)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
1-C03	1000	SHORT ENGINE & GASKET SETS						
1-D03	1010	CYLINDER HEAD & COVER						
1-G03	1030	CYLINDER BLOCK						
1-I03	1040	OIL PAN & TIMING COVER						
1-K03	1100	PISTON, CRANKSHAFT & FLYWHEEL						
1-N03	1200	VALVE SYSTEM						
1-D04	1300	INLET MANIFOLD						
1-E04	1310	EXHAUST MANIFOLD						
1-F04	1320	FUEL SYSTEM						
1-H04	1325	FUEL DISTRIBUTOR						
1-I04	1330	AIR CLEANER						
1-K04	1364	THROTTLE BODY						
1-L04	1370	EMISSION CONTROL SYSTEM (INLET SIDE)						
1-M04	1399	CAP & HOSE CLIP (INLET & EXHAUST SIDE)						
1-N04	1400	OIL PUMP & FILTER						
1-C05	1500	COOLING SYSTEM						
1-G05	1560	BRACKET, PULLEY & BELT						
1-C06	1600	CLUTCH DISC & COVER (MANUAL)						
1-D06	1700	TRANSMISSION CASE (MANUAL)						
1-E06	1710	TRANSMISSION GEARS (MANUAL)						
1-J06	1720	CHANGE CONTROL SYSTEM (MANUAL)						
1-M06	1800	ENGINE ELECTRICAL SYSTEM						
1-C07	1830	ALTERNATOR						
1-E07	1840	STARTER						
1-G07	1850	BATTERY						
1-H07	1910	TORQUE CONVERTER, OIL PUMP & PIPINGS (AUTOMATIC)						
1-K07	1920	TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)						
1-E08	1925	CONTROL VALVE (AUTOMATIC)						
1-I08	1930	CLUTCHES & PLANETARY GEARS (AUTOMATIC)						
1-D09	1940	GOVERNOR, LOW & REVERSE PISTON (AUTOMATIC)						
1-G09	1950	MANUAL LINKAGE SYSTEM (AUTOMATIC)						
1-I09	1960	GASKET & SEAL KIT (AUTOMATIC)						



1920 TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-10
CONT'D					
BV01-19-986	1				
21-182		BRACKET			
BU55-21-182	1				
21-212		RING, 'O'			
BU01-21-212	2				
21-250		SUPPORT, DRUM			
BU55-21-250	1				
21-253		GASKET, DRUM SUPPORT			
BU01-21-253	1	ASBESTOS			
21-255		BOLT			
BU01-21-255	5				
21-273		PLUG, ACCUMLATOR			
BU01-21-273	1				
21-274		SEAL, 'O' RING			
BU01-21-274	1				
21-277		RING, 'O'			
BU01-21-277	1				
21-294A		RING, SEAL			
BU55-21-293	1				
21-381		PISTON, ACCUMLATOR			
BU55-21-381	1				
21-320		CASE, OVER DRIVE			
BU55-21-320	1				
21-322		GASKET, O/DRIVE CASE			
BU01-21-322	1				
21-330		VALVE, ONE WAY			
BV01-21-330	1				

NOTE  
 1 ... 4 ⇔ 19-310  
 THE D-CODE OF 19-310 CONSISTS OF  
 FIGURE NUMBERS 1 THROUGH 4.


AUNA01

CAT. AUNA01-07

1992-J2

1920 TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)

1920 -6 M TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
21-386		STEM, PISTON BAND			
BU01-21-386	1				
21-390		SERVO, OVER DRIVE			
BU20-21-390	1				
21-395		RING, 'O'			
BU01-21-395	2				



AUNA01

CAT. AUNA01-07

1992-02



1-D-8







a		19-8A3	D=1.1MM
b		19-8B1	D=2.0MM
c		19-807	D=1.5MM (BU01-19-807)
d		19-807	D=1.8MM (BU17-19-807)
e		19-808	D=4.77MM, L=15.5MM
f		19-814	D=5.6MM, L=20.9MM
g		19-816	M5, L=25MM
h		19-817	M5, L=40MM
i		19-818	M6, L=57MM
j		19-819	
k		99611-2000	

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
19-750		VALVE, CONTROL			
BU55-19-750	1				
19-760		BODY, CONTROL VALVE-U			
BU55-19-760	1				
19-768		VALVE, MANUAL			
0338-19-768	1				
19-771		VALVE, REGULATOR			
BU01-19-771	1				
19-772		SPRING, REGULATOR			
0338-19-772	1				
19-773		SEAT, REGULATOR SPRING			
0338-19-773	1				
19-774		PLUG, REGULATOR			
BU55-19-774	1				
19-775		SLEEVE, REGULATOR PLUG			
BU55-19-775	1				
19-777		VALVE, SECOND LOCK			
0338-19-777	1				
19-778		SPRING, SECOND LOCK			
0338-19-778	1				
19-781		PLATE, SIDE 'D'			
1758-19-781	1				
19-782		SCREW			
0338-19-782	9				
19-785		VALVE, 1-2 SHIFT			
BU55-19-785	1				
19-786		SPRING, 1-2 SHIFT			
BU55-19-786	1				





a		19-8A3	D=1.1MM
b		19-8B1	D=2.0MM
c		19-807	D=1.5MM (BU01-19-807)
d		19-807	D=1.8MM (BU17-19-807)
e		19-808	D=4.77MM, L=15.5MM
f		19-814	D=5.6MM, L=26.8MM
g		19-816	M5, L=25MM
h		19-817	M5, L=40MM
i		19-818	M6, L=57MM
j		19-819	
k		99611-2000	

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
19-787		VALVE, 2-3 SHIFT			
BU55-19-787	1				
19-788		SPRING, 2-3 SHIFT			
FT21-19-788	1				
19-789		PLUG, 2-3 SHIFT			
FT13-19-789	1				
19-791		VALVE, MODIFIER			
FT27-19-791A	1				
19-792		SPRING, MODIFIER			
FT37-19-792	1				
19-793		PLATE, SIDE 'A'			
0338-19-793A	1				
19-795		VALVE, THROTTLE			
0338-19-795B	1				
19-797		VALVE, THROTTLE BACK-UP			
0338-19-797	1				
19-798		SPRING, THROTTLE BACK-UP			
0338-19-798	1				
19-8A3		VALVE, ORIFICE CHECK			
BV01-19-8A3	1				
19-8B1		VALVE, ORIFICE CHECK			
BV01-19-8B1	1				
19-801		VALVE, DOWN SHIFT			
0338-19-801	1				
19-802		SPRING, DOWN SHIFT			
0338-19-802	1				
19-803		PLATE, SIDE 'B'			
BU01-19-803A	1				



a		19-8A3	D=1.1MM
b		19-8B1	D=2.0MM
c		19-807	D=1.5MM (BU01-19-807)
d		19-807	D=1.8MM (BU17-19-807)
e		19-808	D=4.77MM, L=15.5MM
f		19-814	D=5.6MM, L=26.8MM
g		19-816	M5, L=25MM
h		19-817	M5, L=40MM
i		19-818	M6, L=57MM
j		19-819	
k		99611-2000	

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
19-805		PLATE, SEPARATOR			
BU55-19-805	1				
19-807		VALVE, ORIFICE CHECK			
BU01-19-807	1				
BU17-19-807	1				
19-808		SPRING			
0338-19-808	4				
19-811		BODY, VALVE LWR			
BU10-19-811	1				
19-814		SPRING			
0338-19-814	1				
19-815		STRAINER, OIL			
BU01-19-815	1				
19-816		SCREW			
0338-19-816	7				
19-817		SCREW			
0338-19-817	10				
19-818		BOLT			
0338-19-818	2				
19-819		NUT			
0338-19-819	2				
21-681		VALVE, SHIFT 3-4			
BU35-21-681A	1				
21-682		SPRING, 3-4 SHIFT			
BU35-21-682	1				
21-683		PLUG, 3-4 SHIFT			
BU03-21-683A	1				





a		19-8A3	D=1.1MM
b		19-8B1	D=2.0MM
c		19-807	D=1.5MM (BU01-19-807)
d		19-807	D=1.8MM (BU17-19-807)
e		19-808	D=4.77MM, L=15.5MM
f		19-814	D=5.6MM, L=26.8MM
g		19-816	M5, L=25MM
h		19-817	M5, L=40MM
i		19-818	M6, L=57MM
j		19-819	
k		99611-2000	


PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
BU35-21-684	1	21-684A SLEEVE, 3-4 SHIFT			
BU17-21-815	1	21-815 SPRING, 3-2 TIMING			

(THIS ILLUSTRATION CONSISTS OF 2 PAGES)

(THIS ILLUSTRATION CONSISTS OF 2 PAGES)




(THIS ILLUSTRATION CONSISTS OF 2 PAGES)




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
19-360		BAND, BRAKE			
0338-19-360B	2				
19-460		CLUTCH, FRONT			
BU55-19-460	1				
19-470		DRUM, CLUTCH			
BU55-19-470	1				
19-475		SEAL, O'RING			
0338-19-475	3				
19-476		SEAL, LATHE CUT			
BV01-19-476	1				
0338-19-476	2				
19-480		PISTON, CLUTCH			
BV01-19-480	1				
0338-19-480	2				
19-486		SPRING, PISTON RETURN			
0338-19-486	28				
19-487		RETAINER, SPRING			
0338-19-487	3				
19-488		RING, SNAP			
0338-19-488	3				
19-498		PLATE, DISHED			
0338-19-498	1				
19-498A		PLATE, DISHED			
BU17-19-498	1				
19-499		PLATE, DRIVEN			
BU55-19-499	5				
FT01-19-499	8				
19-500B		PLATE, DRIVEN			

(THIS ILLUSTRATION CONSISTS OF 2 PAGES)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
BU55-19-5J0	4				
BU17-19-500	8				
19-503		PLATE, RETAINING			
3959-19-503	1	T=5MM			
3959-19-504	1	T=5.2MM			
3959-19-505	1	T=5.4MM			
3959-19-506	2	T=5.6MM			
3959-19-507	2	T=5.8MM			
3959-19-508	2	T=6MM			
3959-19-509	3	T=6.2MM			
19-503A		PLATE, RETAINING			
1758-19-503	1	T=7.2MM			
1758-19-504	1	T=7.4MM			
1758-19-505	1	T=7.6MM			
19-503B		PLATE, RETAINING			
BV02-19-505	1	T=6.4MM			
BV02-19-506	1	T=6.6MM			
BV02-19-507	1	T=6.8MM			
BV02-19-508	1	T=7MM			
19-506A		PLATE, RETAINING			
BU05-21-528	1	T=7MM			
19-509		RING, SNAP			
BV01-19-509	1				
0338-19-509	3				


(THIS ILLUSTRATION CONSISTS OF 2 PAGES)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
19-510		CLUTCH, REAR			
BV01-19-510	1				
19-511		DRUM, REAR CLUTCH			
1758-19-511	1				
19-530		HUB, REAR CLUTCH			
BV04-19-530	1				
19-531		HUB, REAR CLUTCH			
BV04-19-531	1				
19-533		GEAR, INTERNAL			
BV01-19-533	1				
BV04-19-533	1				
19-534		RING, SNAP			
0338-19-534	1				
19-534B		RING, SNAP			
BU03-19-534	1				
19-540		CARRIER, FRONT			
BV01-19-540A	1				
19-560		GEAR, SUN			
BV04-19-560	1				
19-565		SHELL, CONNECTING			
BV04-19-565	1				
19-566		RACE, SHELL BEARING			
BV04-19-566	1				
19-567		RING, SNAP			
BU02-19-567	1				
19-570		CARRIER, REAR			
BV01-19-570A	1				



(THIS ILLUSTRATION CONSISTS OF 2 PAGES)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
19-598		RING, SNAP			
0338-19-598	1				
19-621		BEARING, NEEDLE			
0338-19-621	2				
19-622		BEARING, NEEDLE			
FT01-19-622	1				
19-623		BEARING, NEEDLE			
0338-19-623	5				
A (0338-19-623A)					
0338-19-623A	5				
19-624		BEARING, NEEDLE			
0338-19-624	3				
19-631		RACE, BRG. PUMP COVER			
0338-19-631	1	T=1.2MM			
0338-19-632	1	T=1.4MM			
0338-19-633	1	T=1.6MM			
0338-19-634	1	T=1.8MM			
0338-19-635	1	T=2MM			
0338-19-636	1	T=2.2MM			
19-639A		RACE, BEARING			
0338-19-639	4				
19-641A		WASHER			
0338-19-641	2	T=1.9MM			
0338-19-642	2	T=2.1MM			
0338-19-643	2	T=2.3MM			
0338-19-644	2	T=2.5MM			

0401 NA35MM-146561




## SECTION NAME INDEX (ENGINE)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
1-C03	1000	SHORT ENGINE & GASKET SETS						
1-D03	1010	CYLINDER HEAD & COVER						
1-G03	1030	CYLINDER BLOCK						
1-I03	1040	OIL PAN & TIMING COVER						
1-K03	1100	PISTON, CRANKSHAFT & FLYWHEEL						
1-N03	1200	VALVE SYSTEM						
1-D04	1300	INLET MANIFOLD						
1-E04	1310	EXHAUST MANIFOLD						
1-F04	1320	FUEL SYSTEM						
1-H04	1325	FUEL DISTRIBUTOR						
1-I04	1330	AIR CLEANER						
1-K04	1364	THROTTLE BODY						
1-L04	1370	EMISSION CONTROL SYSTEM (INLET SIDE)						
1-M04	1399	CAP & HOSE CLIP (INLET & EXHAUST SIDE)						
1-N04	1400	OIL PUMP & FILTER						
1-C05	1500	COOLING SYSTEM						
1-G05	1580	BRACKET, PULLEY & BELT						
1-C06	1600	CLUTCH DISC & COVER (MANUAL)						
1-D06	1700	TRANSMISSION CASE (MANUAL)						
1-E06	1710	TRANSMISSION GEARS (MANUAL)						
1-J06	1720	CHANGE CONTROL SYSTEM (MANUAL)						
1-M06	1800	ENGINE ELECTRICAL SYSTEM						
1-C07	1830	ALTERNATOR						
1-E07	1840	STARTER						
1-G07	1850	BATTERY						
1-H07	1910	TORQUE CONVERTER, OIL PUMP & PIPINGS (AUTOMATIC)						
1-K07	1920	TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)						
1-E08	1925	CONTROL VALVE (AUTOMATIC)						
1-I08	1930	CLUTCHES & PLANETARY GEARS (AUTOMATIC)						
1-D09	1940	GOVERNOR, LOW & REVERSE PISTON (AUTOMATIC)						
1-G09	1950	MANUAL LINKAGE SYSTEM (AUTOMATIC)						
1-I09	1960	GASKET & SEAL KIT (AUTOMATIC)						

CATLOG-NO= AUNA01-07


DATE. 1992-02

(THIS ILLUSTRATION CONSISTS OF 2 PAGES)




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONY'D BU03-21-567	1				
21-590		CLUTCH, ONE WAY			
BV01-21-533	1				
21-631		RACE, BRG. HUB CLUTCH			
BU01-21-631	1	L=1.2MM			
BU01-21-632	1	L=1.4MM			
BU01-21-633	1	L=1.6MM			
BU01-21-634	1	L=1.8MM			
BU01-21-635	1	L=2MM			
BU01-21-636	2	L=2.2MM			
21-679		SHAFT, INTERMEDIATE			
BU01-21-679	1				
21-821		PLATE, RETAINING			
BV01-21-821A	1				






PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
19-596		RING, SNAP			
0338-19-596	2				
19-601		PISTON, LOW & REVERSE			
BT08-19-600	1				
19-603		SEAL, PISTON			
0338-19-603	1				
19-604		SEAL, 'O'RING			
0338-19-604	1				
19-606		SPRING, PISTON			
0338-19-606	1				
19-607		RING, SNAP			
0338-19-607	1				
19-609		PLATE, DRIVEN			
0338-19-609	4				
19-610		PLATE, DRIVEN			
BU17-19-610	4				
19-613		PLATE, RETAINING			
1758-19-613	1	T=7.8MM			
1758-19-614	1	T=8MM			
1758-19-615	1	T=8.2MM			
1758-19-616	1	T=8.4MM			
1758-19-617	1	T=8.6MM			
1758-19-618	1	T=8.8MM			
19-619		RING, SNAP			
0338-19-619	1				
19-622		BEARING, NEEDLE			



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D FT01-19-622	1				
19-650		DISTRIBUTOR, OIL			
BU55-19-650	1				
19-655		RING, SEAL			
0338-19-655	3				
19-660A		VALVE, GOVERNOR			
BU55-19-660	1				
19-661		BODY			
BU55-19-661	1				
19-663		VALVE			
0338-19-663	1				
19-664		SPRING			
0338-19-664	1				
19-665		VALVE			
BU55-19-665	1				
19-666		SPRING, GOVERNOR			
BU55-19-666	1				
19-667		PLATE, RETAINER			
0338-19-667	3				
19-670		SHAFT			
BU55-19-670	1				
19-676		RING			
0338-19-676	1				

1950 MANUAL LINKAGE SYSTEM (AUTOMATIC)




1950 -1 MANUAL LINKAGE SYSTEM (AUTOMATIC)

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
19-031		LEVER, SELECT			
BU55-19-031	1				
19-431		SHAFT, MANUAL			
BU67-19-431	1				
19-432		RING, 'O'			
0338-19-432	1				
19-440		PLATE, MANUAL			
BU55-19-440	1				
19-449		RING, SNAP			
0338-19-449	1				
19-450		ROD, PARKING			
BU17-19-450	1				
19-701		SUPPORTER, ACTUATOR			
0338-19-701A	1				
19-702		PLATE, RETAINING			
0338-19-702A	1				
19-703		SPRING, BALL PARK			
0338-19-703	2				
19-704		RETAINER			
0338-19-704	1				
19-706		BOLT			
0338-19-706	1				
19-731		SHAFT, PARKING PAWL			
0338-19-731	1				
19-732		PAWL, PARKING			
BU17-19-732	1				
19-733		SPRING, PAWL RETURN			
0338-19-733C	1				




1950 MANUAL LINKAGE SYSTEM (AUTOMATIC)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
19-734		SPACER, DOWEL			
0338-19-734A	1				

22-900

- |                           |                                |
|---------------------------|--------------------------------|
| 1-SEAL,OIL.....(1)        | 15-GASKET,EXTENSION.....(1)    |
| 2-GASKET,OIL PUMP.....(1) | 16-SEAL,"O"RING.....(2)        |
| 3-SEAL,OIL.....(1)        | 17-GASKET,OIL PAN.....(1)      |
| 4-SEAL,CUT RING.....(2)   | 18-RING,"O".....(1)            |
| 5-SEAL,PISTON.....(1)     | 19-GASKET,DRUM SUPPORT.....(1) |
| 6-SEAL,PISTON.....(1)     | 20-SEAL,"O"RING.....(1)        |
| 7-SEAL,LATHE CUT.....(1)  | 21-SEAL,"O"RING.....(1)        |
| 8-RING,"O".....(1)        | 22-RING,"O".....(1)            |
| 9-RING,"O".....(1)        | 23-RING,"O".....(1)            |
| 10-RING,"O".....(1)       | 24-RING,"O".....(1)            |
| 11-SEAL,"O"RING.....(3)   | 25-GASKET,O/DRIVE CASE.....(1) |
| 12-SEAL,LAHTE CUT.....(3) | 26-RING,"O".....(1)            |
| 13-SEAL,PISTON.....(1)    | 27-RING,"O".....(1)            |
| 14-SEAL,"O"RING.....(1)   |                                |



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
22-900 BU01-99-190A	1	GASKET & SEAL KIT ASBESTOS			



**ENGINE**

**CHASSIS**

**ENGINE**

**CHASSIS**

**ENGINE**

**CHASSIS**



**ENGINE**



**CHASSIS**

**ENGINE**

**CHASSIS**

**ENGINE**

**CHASSIS**





**ENGINE**

**CHASSIS**

**ENGINE**

**CHASSIS**



**ENGINE**



**CHASSIS**

**ENGINE**

**CHASSIS**

**ENGINE**

**CHASSIS**



**ENGINE**



**CHASSIS**

**ENGINE**

**CHASSIS**

## SECTION NAME INDEX (CHASSIS)


LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
1-C11	2505	REAR PROPELLER SHAFT	1-J16	4400	PARKING BRAKE SYSTEM			
1-D11	2550	REAR DRIVE SHAFT	1-L16	4500	FUEL PIPINGS			
1-E11	2600	REAR AXLE	2-C03	4600	CHANGE CONTROL SYSTEM (AT)			
1-F11	2610	REAR BRAKE MECHANISMS						
1-H11	2710	REAR DIFFERENTIALS (NORMAL DIFF.)						
1-L11	2710 A	REAR DIFFERENTIALS (LIMITED SLIP DIFF.)						
1-D12	2800	REAR SUSPENSION MECHANISMS						
1-E12	2801	REAR SPRING & DAMPER						
1-F12	2810	REAR STABILIZER						
1-G12	2830	REAR LOWER A/MS & SUB FRAME						
1-I12	3200	STEERING WHEEL						
1-L12	3210	STEERING COLUMN & SHAFTS						
1-M12	3220	STEERING GEAR (W/O POWER STEERING)						
1-C13	3220 A	STEERING GEAR (W/ POWER STEERING)						
1-F13	3240	POWER STEERING SYSTEM						
1-H13	3300	FRONT AXLE						
1-I13	3310	FRONT BRAKE MECHANISMS						
1-K13	3400	FRONT SUSPENSION MECHANISMS						
1-M13	3401	FRONT SPRING & DAMPER						
1-N13	3410	CROSSMEMBER & STABILIZER						
1-C14	3700	TIRES & JACK						
1-C15	3900	ENGINE & T/MISSION MOUNTINGS						
1-D15	4000	EXHAUST SYSTEM						
1-F15	4140	CLUTCH RELEASE & MASTER CYLINDERS (MANUAL TRANSMISSION)						
1-G15	4145	CLUTCH PIPINGS (MANUAL TRANSMISSION)						
1-H15	4160	ACCELERATOR CONTROL SYSTEM						
1-I15	4200	FUEL TANK						
1-M15	4300	CLUTCH & BRAKE PEDALS (MANUAL TRANSMISSION)						
1-D16	4300A	BRAKE PEDALS (AUTOMATIC TRANSMISSION)						
1-F16	4340	BRAKE MASTER CYLINDER & POWER BRAKE						
1-H16	4360	BRAKE PIPINGS						



2505 REAR PROPELLER SHAFT





2505 -1 \* REAR PROPELLER SHAFT

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
25-100A M091-25-100	1	SHAFT, PROPELLER			
25-123 N010-25-123	4	BOLT			
25-125 1456-25-125	4	NUT			




2550 REAR DRIVE SHAFT

2550 -1 \* REAR DRIVE SHAFT



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
22-510B M090-22-510	2	JOINT SET, OUTER			
22-520B M090-22-520	2	JOINT SET(R), INNER			
22-530 M090-22-530	2	BOOT SET, OUTER JOINT			
22-540 M090-22-540	2	BOOT SET, INNER JOINT			
22-550A M090-22-550	2	CLIP SET, DRIVE SHAFT			
25-124 1368-25-124	8	NUT			
25-500 M090-25-500	2	SHAFT, DRIVE			


2600 REAR AXLE



2600 -1 M REAR AXLE

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
26-110A		↓-----↓			
NA01-26-130 A (NA01-26-130A)	1	↓-----↓	↓-----↓		-9901
NA01-26-130A	1	↓-----↓			9901-
26-110Y		↓-----↓			
NA01-26-140 A (NA01-26-140A)	1	↓-----↓	↓-----↓		-9901
NA01-26-140A	1	↓-----↓			9901-
26-251B		↓-----↓			
*NA01-26-251A	2	↓-----↓	↓-----↓		
26-261		↓-----↓			
NA01-26-261 A (NA01-26-261A)	2	↓-----↓	↓-----↓		-9901
NA01-26-261A	2	↓-----↓			9901-
33-042		↓-----↓			
NA01-33-042A	2	↓-----↓	↓-----↓		
33-047		↓-----↓			
B455-33-047A	2	↓-----↓	↓-----↓		
33-048		↓-----↓			
H260-33-048	2	↓-----↓	↓-----↓		
33-061		↓-----↓			
B455-33-061	2	↓-----↓	↓-----↓		
33-062		↓-----↓			
B455-33-062	8	↓-----↓	↓-----↓		
33-065		↓-----↓			
G304-33-065	2	↓-----↓	↓-----↓		


9901 NA35MM-119257



NOTE  
 ① ... ⑥ → 49-240A  
 THE D-CODE OF 49-240A CONSISTS OF  
 FIGURE NUMBERS ① THROUGH ⑥.

THROUGH ILLUSTRATIONS OF D-CODE 49-240A, 49-250A, AND 26-432 ARE  
 FOR LEFT SIDE ONLY. QUANTITIES OF THESE D-CODES IN THE TEXT  
 ARE FOR ONE VEHICLE.

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
26-28X NA10-26-28X	1	SUPPORT(R), MOUNTING			
26-29X NA10-26-29X	1	SUPPORT(L), MOUNTING			
26-43Z NAY1-26-43Z	1	PAD SET, RR CALIPER ASBESTOS			
26-668 BWOH-26-668	1	SPRING(R), LEVER			
26-668Z BWOH-26-669	1	SPRING(L), LEVER			
26-680 BWOH-26-680	2	BOLT			
26-683A BWOH-26-683	2	PROTECTOR			
26-700 BWOH-26-700	2	PLUG, SCREW			
26-731 BWOH-26-731	2	SPINDLE, ADJUSTER			
26-733 BWOH-26-733	2	GEAR, ADJUST			
26-800 BWOH-26-800	1	LEVER(R), OPERATING			
26-800Z BWOH-26-810	1	LEVER(L), OPERATING			
26-812A BWOH-26-812	2	ROD, PUSH-FRT CALIPER			
26-816		RING, SNAP-RR CALIPER			




NOTE  
 ① ... ⑥ → 49-240A  
 THE D-CODE OF 49-240A CONSISTS OF  
 FIGURE NUMBERS ① THROUGH ⑥.

THOUGH ILLUSTRATIONS OF D-CODE 49-240A, 49-250A, AND 26-43Z ARE  
 FOR LEFT SIDE ONLY, QUANTITIES OF THESE D-CODES IN THE TEXT  
 ARE FOR ONE VEHICLE.

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
BWOH-26-816	2				
26-851		BRACKET(R), CABLE			
BWOH-26-851	1				
26-851Z		BRACKET(L), CABLE			
BWOH-26-861	1				
26-980		CALIPER(R), RR BRAKE			
NA01-26-980A	1				
26-980Z		CALIPER(L), RR BRAKE			
NA01-26-990A	1				
26-998		PIN, GUIDE			
BWOH-26-998A	2				
33-691A		SCREW, BLEEDER			
BWOH-26-691	2				
33-693A		CAP, BLEEDER SCREW			
0259-33-693	2				
49-240A		SEAL KIT, CALIPER-RR			
NAY1-26-44Z	1				
49-250A		BOOT KIT, RR CALIPER			
BWYH-26-45Z	1				

2710 REAR DIFFERENTIALS  
(NORMAL DIFF.)

2710 -1 REAR DIFFERENTIALS  
(NORMAL DIFF.)




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
17-122	1	PLUG, MAGNET			
0810-17-121	1				
25-421	2	CLIP			
F001-25-421A	2				
26-060	1	BREATHER			
U730-26-060	1				
27-012	1	WASHER			
3919-27-012	1				
27-018	1	SEAL, OIL			
T020-27-165	1				
27-020	1	FLANGE, COMPANION			
T002-27-120A AN(T002-27-120B)	1				-9721
T002-27-120B	1				9721-
27-030	1	NUT, LOCK			
3919-27-130	1				
27-100	1	DRIVING & DIFF.			-9721
T020-27-100H AN(T020-27-100J)	1				9721-9801
T020-27-100J A (T020-27-100K)	1				9801-
T020-27-100K	1				
27-110	1	GEAR SET, FINAL R=4.300			
T020-27-110B	1				
27-141	1	BEARING, PINION			
0755-27-210	1				
27-141A	1	BEARING, PINION			
3919-27-220	1				
27-150B	1	CARRIER, DIFFERENTIAL-F RT			-9801
T020-27-150C	1				

9721 NA35MM-114922  
9801 NA35MM-116316

2710 REAR DIFFERENTIALS  
(NORMAL DIFF.)


2710 -2 REAR DIFFERENTIALS  
(NORMAL DIFF.)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
A (T020-27-150D)					
T020-27-150D	1				9801-
27-158		SPACE			
T020-27-158A	1				
27-159		PIN, TUBULAR			
T020-27-159A	1				
27-171		PIECE, DISTANCE			
T020-27-171	1				
27-230		CASE			
T005-27-231	1				
27-235		BOLT, RING GEAR			
3919-27-235	8	D=10.2MM			
3919-27-236	8	D=10MM			
27-238		SEAL, OIL			
T020-27-238	2				
27-251		GEAR, DIFF. SIDE			
F035-27-251	2				
27-252		WASHER			
F001-27-252	2	T=2MM			
F001-27-253	2	T=2.1MM			
F001-27-254	2	T=2.2MM			
27-255		PINION, DIFFERENTIAL			
T020-27-255	2				
27-261		SHAFT, DIFF. PINION			
F001-27-261A	1				
27-262		PIN			

9801 NA35MM-116316

2710 REAR DIFFERENTIALS  
(NORMAL DIFF.)




2710 -3 REAR DIFFERENTIALS  
(NORMAL DIFF.)

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
0114-27-262	1				
27-270A		SHAFT, OUT PUT			
T005-27-270B	2				
27-301A		SCREW, ADJUST			
0180-27-301A	2				
27-302		PLATE, LOCK			
0290-27-302	2				
27-305		BEARING			
0249-27-350	2				
27-401		SPACER			
0259-27-401	1	T=3.08MM			
0259-27-402	1	T=3.11MM			
0259-27-403	1	T=3.14MM			
0259-27-404	1	T=3.17MM			
0259-27-405	1	T=3.2MM			
0259-27-406	1	T=3.23MM			
0259-27-407	1	T=3.26MM			
0259-27-408	1	T=3.29MM			
0259-27-409	1	T=3.32MM			
0259-27-411	1	T=3.35MM			
0259-27-412	1	T=3.38MM			
0259-27-413	1	T=3.41MM			
0259-27-414	1	T=3.44MM			
0259-27-415	3	T=3.47MM			
T020-27-401A		L=50.850			

1-J11



2710 REAR DIFFERENTIALS  
(NORMAL DIFF.)




2710 -4 \* REAR DIFFERENTIALS  
(NORMAL DIFF.)

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D	1				-0401
T020-27-402A	1	L=50.875			-0401
T020-27-403A	1	L=50.900			-0401
T020-27-404A	1	L=50.925			-0401
T020-27-405A	1	L=50.950			-0401
T020-27-406A	1	L=50.975			-0401
T020-27-407A	1	L=51.000			-0401
T020-27-408A	1	L=51.025			-0401
T020-27-409A	1	L=51.050			-0401
27-431		SPACER			
T001-27-431	1				
27-600		CASING, DIFFERENTIAL			
T020-27-600D A (T020-27-600E)	1				-9609
T020-27-600E A (T020-27-600F)	1				9609-9926
T020-27-600F	1				9926-
27-604		BOLT, CARRIER			
GOA0-27-604A	2				
27-609		PLATE, BAFFLE-DIFF CASING			
MOA1-27-609A	1				
28-890A		RUBBER, SUB FRAME MTG			
NA01-28-890	2				

9609 NA35MM-108360  
9926 NA35MM-122890  
0401 NA35MM-146561

2710 A REAR DIFFERENTIALS  
(LIMITED SLIP DIFF.)




2710 A-1 REAR DIFFERENTIALS  
(LIMITED SLIP DIFF.)

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
17-122	1	PLUG, MAGNET			
0810-17-121	1				
25-421	2	CLIP			
F001-25-421A	2				
26-060	1	BREATHER			
0730-26-060	1				
27-012	1	WASHER			
3919-27-012	1				
27-018	1	SEAL, OIL			
T020-27-165	1				
27-020	1	FLANGE, COMPANION			
T002-27-120A AN(T002-27-120B)	1				-9721
T002-27-120B	1				9721-
27-030	1	NUT, LOCK			
3919-27-130	1				
27-100	1	DRIVING & DIFF.			
T025-27-100F A (T025-27-100G)	1				-9405
T025-27-100G AN(T025-27-100H)	1				9405-9721
T025-27-100H A (T025-27-100J)	1				9721-9801
T025-27-100J	1				9801-
27-110	1	GEAR SET, FINAL			
T020-27-110B	1	R=4.300			
27-141	1	BEARING, PINION			
0755-27-210	1				
27-141A	1	BEARING, PINION			
3919-27-220	1				
9405 NA35**	130118				
9721 NA35**	114922				
9801 NA35**	116316				

2710 A REAR DIFFERENTIALS  
(LIMITED SLIP DIFF.)

2710 A-2 REAR DIFFERENTIALS  
(LIMITED SLIP DIFF.)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
27-150B	1	CARRIER, DIFFERENTIAL-FRT			-9801
T020-27-150C A (T020-27-150D)	1				9801-
27-158	1	SPACE			
T020-27-158A	1				
27-159	1	PIN, TUBULAR			
T020-27-159A	1				
27-171	1	PIECE, DISTANCE			
T020-27-171	1				
27-200	1	DIFFERENTIAL			-9405
T016-27-200A A (T016-27-200B)	1				9405-
T016-27-200B	1				
27-235	8	BOLT, RING GEAR			
3919-27-235	8	D=10.2MM			
3919-27-236	8	D=10MM			
27-238	2	SEAL, OIL			
T020-27-238	2				
27-270B	1	SHAFT (R), OUTPUT			
T015-27-270	1				
27-280	1	SHAFT (L), OUTPUT			
T015-27-280	1				
27-301A	2	SCREW, ADJUST			
0180-27-301A	2				
27-302	2	PLATE, LOCK			
0290-27-302	2				
27-305	2	BEARING			
0249-27-350	2				
9405 NA35MM-100118					
9801 NA35MM-116316					

1-M11




## SECTION NAME INDEX (CHASSIS)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
1-C11	2505	REAR PROPELLER SHAFT	1-J16	4400	PARKING BRAKE SYSTEM			
1-D11	2550	REAR DRIVE SHAFT	1-L16	4500	FUEL PIPINGS			
1-E11	2600	REAR AXLE	2-C03	4600	CHANGE CONTROL SYSTEM (AT)			
1-F11	2610	REAR BRAKE MECHANISMS						
1-H11	2710	REAR DIFFERENTIALS (NORMAL DIFF.)						
1-L11	2710 A	REAR DIFFERENTIALS (LIMITED SLIP DIFF.)						
1-D12	2800	REAR SUSPENSION MECHANISMS						
1-E12	2801	REAR SPRING & DAMPER						
1-F12	2810	REAR STABILIZER						
1-G12	2830	REAR LOWER ARMS & SUB FRAME						
1-I12	3200	STEERING WHEEL						
1-L12	3210	STEERING COLUMN & SHAFTS						
1-M12	3220	STEERING GEAR (W/O POWER STEERING)						
1-C13	3220 A	STEERING GEAR (W/ POWER STEERING)						
1-F13	3240	POWER STEERING SYSTEM						
1-H13	3300	FRONT AXLE						
1-I13	3310	FRONT BRAKE MECHANISMS						
1-K13	3400	FRONT SUSPENSION MECHANISMS						
1-M13	3401	FRONT SPRING & DAMPER						
1-N13	3410	CROSSMEMBER & STABILIZER						
1-C14	3700	TIRES & JACK						
1-C15	3900	ENGINE & T/MISSION MOUNTINGS						
1-D15	4000	EXHAUST SYSTEM						
1-F15	4140	CLUTCH RELEASE & MASTER CYLINDERS (MANUAL TRANSMISSION)						
1-G15	4145	CLUTCH PIPINGS (MANUAL TRANSMISSION)						
1-H15	4160	ACCELERATOR CONTROL SYSTEM						
1-I15	4200	FUEL TANK						
1-M15	4300	CLUTCH & BRAKE PEDALS (MANUAL TRANSMISSION)						
1-D16	4300A	BRAKE PEDALS (AUTOMATIC TRANSMISSION)						
1-F16	4340	BRAKE MASTER CYLINDER & POWER BRAKE						
1-H16	4360	BRAKE PIPINGS						



2710 A REAR DIFFERENTIALS  
(LIMITED SLIP DIFF.)


2710 A-4 \* REAR DIFFERENTIALS  
(LIMITED SLIP DIFF.)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D T020-27-409A	1	L=51.050			-0401
27-431		SPACER			
T001-27-431	1				
27-600		CASING, DIFFERENTIAL			
T020-27-600D A (T020-27-600E)	1				-9609
T020-27-600E A (T020-27-600F)	1				9609-9926
T020-27-600F	1				9926-
27-604		BOLT, CARRIER			
GOA0-27-604A	2				
27-609		PLATE, BAFFLE-DIFF CASING			
MOA1-27-609A	1				
28-890A		RUBBER, SUB FRAME MTG			
NA01-28-890	2				
<p>9609 NA35MM-108360                      9926 NA35MM-122890                      0401 NA35MM-146561</p>					

2800 REAR SUSPENSION MECHANISMS

2800 -1 M REAR SUSPENSION MECHANISMS




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
28-013A		SHEET, RUBBER			
G030-28-013A	2				9330-
28-111B		STOPPER, BUMP			
NA01-28-111	2				
28-333A		NUT, FLANGE			
H001-28-333	4				
28-380		RUBBER, MOUNTING			
NA01-28-380A	2				

9330 NA35MM-100072

2801 REAR SPRING & DAMPER

2801 -1 M REAR SPRING & DAMPER




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
28-010A		SPRING, COIL-REAR			
NA01-28-011B	2	(MT)			
NA03-28-011	2	(AT)			
28-700		DAMPER, REAR			
NA01-28-700	2				




2810 REAR STABILIZER

2810 -1 \* REAR STABILIZER




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
28-101 NA01-28-151A	1	STABILIZER, RR			
28-102 FB01-28-156	2	BUSH, STABILIZER-RR			
28-155 FB01-28-155	2	PLATE, STABILIZER-RR			



NOTE  
 ① ... ⑤ ⇔ 28-300  
 28-300Z  
 THE D-CODE OF 28-300 CONSISTS OF  
 28-300Z  
 FIGURE NUMBERS ① THROUGH ⑤.

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
28-091		NUT			
B037-28-091	8				
28-092		BOLT, CONTROL LINK			
NA01-28-092	2				
28-113		BOLT			
NA01-28-113	2				
28-2A0		ARM, UPPER-REAR			
NA01-28-2A0B	2				
28-300		ARM(R), LOWER-REAR			
NA01-28-300	1				
28-300Z		ARM(L), LOWER-REAR			
NA01-28-350	1				
28-4A0		BOLT, ADJUST			
NA01-28-4A0	4				
28-460		BUSHING, RUBBER-LOWER ARM			
NA01-28-460	2				
28-4D0		BUSHING, RUBBER-LOWER ARM			
NA01-28-4D0	2				
28-460		BUSHING, LOWER ARM			
NA01-28-460	4				
28-473		PLATE, C/P-M-SUB FRAME			
NA01-28-473	4				
28-800B		BUSHING, RUBBER			
NA01-28-800B	6				
28-800A		MEMBER, CROSS			
NA01-28-800B	1				
28-880A		WASHER, STOP			
NA01-28-880B	2				



NOTE  
 ① ... ⑤ ⇨ 28-300  
 28-300Z  
 THE D-CODE OF 28-300  
 28-300Z CONSISTS OF  
 FIGURE NUMBERS ① THROUGH ⑤.




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
34-091		NUT			
FB01-34-091	4				
34-170A		LINK, CONTROL-STAB			
NA01-34-170	2				
34-222		NUT			
8871-34-222	6				

((URETHANE)+(W/AIR BAG))  
(LEATHER)

(THIS ILLUSTRATION CONSISTS OF 2 PAGES)

((URETHANE)+(W/O AIR BAG))

(THIS ILLUSTRATION CONSISTS OF 2 PAGES)





3200 STEERING WHEEL

(1/2)

(( URETHANE)+(W/AIR BAG)  
(LEATHER)

(THIS ILLUSTRATION CONSISTS OF 2 PAGES)




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
32-016C		PLATE, CONTACT			
B461-32-020	1	BASE, (W/O AIR BAG)			0701-
32-017A		PLATE, CONTACT			
B461-32-030	1	BASE, (W/O AIR BAG)			0701-
32-019		BRACKET, COUPLER			
NA01-32-019	1	PKG-OPT, V-SPECIAL, (W/AIR BAG)			
32-040		COVER, ST. WHEEL BOSS			
B461-32-040	1	BASE, (W/O AIR BAG)			0701-
32-049		COVER, WHEEL CORE			
NA01-32-049	1	PKG-OPT, V-SPECIAL, (W/AIR BAG)			
32-740C		PARTS SET, ST. WHEEL			
NA01-32-750	1	PKG-OPT, V-SPECIAL, (W/AIR BAG)			
B461-32-750	1	BASE, (W/O AIR BAG)			0701-
32-740D		PARTS SET, HORN CAP			
B461-32-740	1	BASE, (W/O AIR BAG)			0701-
32-800		CAP, HORN			
B461-32-800A	1	BASE, (W/O AIR BAG)			0701-
32-980		BOSS, STEERING WHEEL			
NA01-32-980B	1	(URETHANE+W/AIR BAG)			
NA02-32-980B	1	PKG-OPT, V-SPECIAL, (LEATHER)			
B461-32-980	1	(URETHANE+W/O AIR BAG)			0701-
56-181K		COVER(R), SENSOR-AIR BAG			
NA01-56-191A	1	(W/AIR BAG)			

0701 NA35MM-200041

((URETHANE)+(W/O AIR BAG))

(THIS ILLUSTRATION CONSISTS OF 2 PAGES)




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
56-191D NA01-56-181A	1	COVER(L), SENSOR-AIR BAG (W/AIR BAG)			
57-K00 NA01-57-K00A 00	1	MODULE, AIR BAG (W/AIR BAG) NA0 BLACK			
57-K10 NA01-57-K10G A (NA01-57-K10H)	1	SENSOR(C), AIR BAG			-9601
57-K10 NA01-57-K10H	1	(W/AIR BAG)			9601-
57-K2X NA01-57-K2XJ	1	SENSOR(R), AIR BAG (W/AIR BAG)			
57-K2Y NA01-57-K2YJ	1	SENSOR(L), AIR BAG (W/AIR BAG)			
57-K40 NA01-57-K40D	1	SENSOR, AIR BAG-INNER (W/AIR BAG)			
57-K45 NA01-57-K45B	1	COVER(R), SENSOR (W/AIR BAG)			
57-K46 NA01-57-K46B	1	COVER(L), SENSOR (W/AIR BAG)			
57-K47 NA01-57-K47B	1	COVER(C), SENSOR (W/AIR BAG)			
57-K9Z NA01-57-K9ZA A (NA01-57-K9ZB)	1	BRACKET, CLIP			-9516
57-K9Z NA01-57-K9ZB	1	(W/AIR BAG)			9516-
69-885D NA01-56-145	8	FASTENER (W/AIR BAG)			

9516 NA35\*\*-103924  
9601 NA35\*\*-106797

3210 STEERING COLUMN & SHAFTS

3210 -1 \* STEERING COLUMN & SHAFTS




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
32-AZ0 NA01-32-AZ0A (NA01-32-AZ2A)	1	COVER, JOINT			-9410
32-AZ1 NA01-32-AZ1B	1	COVER, JOINT-UPPER			9401-
32-AZ2 NA01-32-AZ2A	1	COVER, JOINT-LOWER			9410-
32-090B NA01-32-090A AN(NA01-32-090B)	1	SHAFT, INTERMED.			-0301
NA02-32-090A AN(NA02-32-090B)	1				-0301
NA01-32-090B	1	(W/O P.S.+W/AIR BAG)			0301-
NA02-32-090B	1	(W/P.S.+W/AIR BAG)			0301-
NA07-32-090A	1	(W/O P.S.+W/O AIR BAG)			0701-
NA08-32-090A	1	(W/P.S.+W/O AIR BAG)			0701-
32-099 B455-32-099	3	BOLT, SHAFT			
32-100 NA01-32-100B NA07-32-100A	1	SHAFT, ENGY. ABSORBER			0701-
32-217 NA01-32-217	1	GROMMET			
32-850 NA01-32-850	1	JOINT, STEERING			

9410 NA35MM-100262  
 0301 NA35MM-141901  
 0701 NA35MM-200041

3220 STEERING GEAR  
(W/O POWER STEERING)

3220 -1 STEERING GEAR  
(W/O POWER STEERING)




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
32-110		GEAR, STEERING			
NA01-32-110	1				
32-111		YUKE, SUPPORT			
GJ21-32-111	1				
32-115		BEARING, ST. GEAR			
G030-32-115	1				
32-118E		COVER, DUST, ST. GEAR			
NA01-32-118	1				
32-119E		RACK, STEERING GEAR			
NA01-32-119	1				
32-12X		BOOT SET, ST. GEAR			
NA01-32-12X	2				
32-120		HOUSING, GEAR			
NA01-32-120	1				
32-122C		PINION, STEERING GEAR			
NA01-32-122	1				
32-123		RUBBER, MOUNTING			
NA01-32-123	1				
32-124		RUBBER, MOUNTING			
NA01-32-124	1				
32-126		SEAL, SHAFT			
G030-32-126	1				
32-129B		PLUG, PINION			
HE01-32-129	1				
32-130B		NUT, LOCK			
S083-32-137	1				
32-133		PLATE, CLAMP			
BC51-32-133	1				



3220 STEERING GEAR  
(W/O POWER STEERING)

3220 -2 \* STEERING GEAR  
(W/O POWER STEERING)




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-10
32-134		PLATE, CLAMP			
NA01-32-134	1				
32-136A		COVER, REAR			
G030-32-136	1				
32-137		NUT, LOCK			
S030-32-137	1				
32-146B		WASHER			
HA14-32-146	2				
32-147A		BEARING, PINION			
G030-32-147	1				
32-201A		BUSHING, RACK-ST. GEAR			
HE01-32-201	1				
HE09-32-201	1				
32-240A		JOINT, BALL			
NA01-32-240	2				
32-279		SEAL, DUST-BALL JOINT			
B455-32-279	2				
32-280S		JOINT SET, BALL			
8AN1-32-280	2				
32-961		BOLT			
G030-32-961	4				

## SECTION NAME INDEX (CHASSIS)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
1-C11	2505	REAR PROPELLER SHAFT	1-J16	4400	PARKING BRAKE SYSTEM			
1-D11	2550	REAR DRIVE SHAFT	1-L16	4500	FUEL PIPINGS			
1-E11	2600	REAR AXLE	2-C03	4600	CHANGE CONTROL SYSTEM (AT)			
1-F11	2610	REAR BRAKE MECHANISMS						
1-H11	2710	REAR DIFFERENTIALS (NORMAL DIFF.)						
1-L11	2710 A	REAR DIFFERENTIALS (LIMITED SLIP DIFF.)						
1-D12	2800	REAR SUSPENSION MECHANISMS						
1-E12	2801	REAR SPRING & DAMPER						
1-F12	2810	REAR STABILIZER						
1-G12	2830	REAR LOWER ARMS & SUB FRAME						
1-I12	3200	STEERING WHEEL						
1-L12	3210	STEERING COLUMN & SHAFTS						
1-M12	3220	STEERING GEAR (W/O POWER STEERING)						
1-C13	3220 A	STEERING GEAR (W/ POWER STEERING)						
1-F13	3240	POWER STEERING SYSTEM						
1-H13	3300	FRONT AXLE						
1-I13	3310	FRONT BRAKE MECHANISMS						
1-K13	3400	FRONT SUSPENSION MECHANISMS						
1-M13	3401	FRONT SPRING & DAMPER						
1-N13	3410	CROSSMEMBER & STABILIZER						
1-C14	3700	TIRES & JACK						
1-C15	3900	ENGINE & T/MISSION MOUNTINGS						
1-D15	4000	EXHAUST SYSTEM						
1-F15	4140	CLUTCH RELEASE & MASTER CYLINDERS (MANUAL TRANSMISSION)						
1-G15	4145	CLUTCH PIPINGS (MANUAL TRANSMISSION)						
1-H15	4160	ACCELERATOR CONTROL SYSTEM						
1-I15	4200	FUEL TANK						
1-M15	4300	CLUTCH & BRAKE PEDALS (MANUAL TRANSMISSION)						
1-D16	4300A	BRAKE PEDALS (AUTOMATIC TRANSMISSION)						
1-F16	4340	BRAKE MASTER CYLINDER & POWER BRAKE						
1-H16	4360	BRAKE PIPINGS						

3220 A STEERING GEAR  
(W/ POWER STEERING)



3220 A-1 STEERING GEAR  
(W/ POWER STEERING)


PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
32-11X		YOKE SET, SUPPORT-ST. GEAR			
NA02-32-11X	1				
32-110		GEAR, STEERING			
NA02-32-110	1				
32-112		COVER, DUST			
NA02-32-112	1				
32-114D		COVER, DUST-ST. GEAR			
NA02-32-114	1				
32-115		BEARING, ST. GEAR			
NA02-32-115	1				
32-117A		SPACER, STEERING GEAR			
NA02-32-121	1				
32-119E		RACK, STEERING GEAR			
NA02-32-119	1				
32-120		HOUSING, GEAR			
NA02-32-120	1				
32-123		RUBBER, MOUNTING			
NA02-32-123	1				
32-124		RUBBER, MOUNTING			
NA02-32-124	1				
32-125B		BODY, RACK			
NA02-32-125	1	(FOR RIGHT)			
NA02-32-135	1	(FOR LEFT)			
32-129B		PLUG, PINION			
NA02-32-129	1				
32-131A		NUT, LOCK-RACK			
NA02-32-131	1				






3240 POWER STEERING SYSTEM

3240 -1 POWER STEERING SYSTEM



PART NO.	QTY	MODEL/RES/RICTION	MODEL/RESTRICTION	MODEL/PESTRICITION	FROM-TO
32-C24		CLAMP, HOSE-P.S.			
Q238-32-C24	2				
32-230		SWITCH, PRESSURE-P.S.			
B456-32-230	1				
32-410C		PIPE, RETURN			
NA02-32-410 AN(NA02-32-410A)	1				-0508
NA02-32-410A	1				0508-
32-490		HOSE, PRESSURE			
NA02-32-490A A (NA02-32-490B)	1				-0201
NA02-32-490B	1				0201-
32-5M0		PIPE, SUCTION			
N002-32-5M0	1				
32-600		PUMP, VANE			
N002-32-600A AN(N002-32-600B)	1				-0301
N002-32-600B	1				0301-
32-609		BRACKET, VANE PUMP			
NA02-32-609	1	KUROISHI TEKKO			
N002-32-609	1	NIHON POWER STEERING			
32-610		SEAL KIT, VANE PUMP			
N002-32-610	1				
32-613		NIPPLE, VANE PUMP			
N002-32-613	1				
32-615A		BOLT			
B456-32-615	2				
32-616		BOLT, VANE PUMP			
B456-32-616	2				
0201 NA35MM-137180 0301 NA35MM-141901 0508 NA35MM-150838					

3240 POWER STEERING SYSTEM




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
32-680		BRACKET, VANE PUMP			
NA02-32-680	1				
32-682		HOSE, RETURN			
NA02-32-682	2				
32-684		HOSE, RETURN			
NA02-32-684B	1				
32-690		TANK, VANE PUMP			
NA02-32-690	1				-9B20
A (NA02-32-690A)					
NA02-32-690A	1				9B20-
9B20 NA35MM-128848					

AUNA01


CAT. AUNA01-07

1992-02



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
26-071		CAP, HUB			
B455-26-071	2				
33-020		KNUCKLE(R), STEERING			
NA01-33-020A	1				
33-020Z		KNUCKLE(L), STEERING			
NA01-33-030A	1				
33-042		NUT			
NA01-33-042A	2	W/WASHER			
33-061		HUB, WHEEL			
NA01-33-04X	2				
33-062		BOLT, HUB			
B455-33-062	8				
33-251A		PLATE, DISC			
NA01-33-25X	2				
33-261		COVER(R), DUST			
NA01-33-261	1				
33-261Z		COVER(L), DUST			
NA01-33-271	1				






THOUGH ILLUSTRATIONS OF D-CODE 49-240C, 49-250B AND 33-23Z ARE FOR LEFT SIDE ONLY, QUANTITIES OF THESE D-CODES IN THE TEXT ARE FOR ONE VEHICLE.

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
33-23Z	1	PAD SET, FRT CALIPER			-9601
NAY1-33-23Z A (NAY1-33-23ZA)	1				9601-0519
NAY1-33-23ZA	1	NON ASBESTOS			0519-
NAY0-33-23ZA	1				
33-280B	1	SUPPORT(R), MOUNTING			
NA01-33-281	1				
33-280X	1	SUPPORT(L), MOUNTING			
NA01-33-291	1				
33-610	1	BODY & PISTON(R), CALIPER			
NA01-33-61X	1				
33-610Z	1	BODY & PISTON(L), CALIPER			
NA01-33-71X	1				
33-691	2	SCREW, BLEEDER			
B001-33-691	2				
33-693A	2	CAP, BLEEDER SCREW			
0259-33-693	2				
33-679C	2	PIN, LOCK			-9615
NA01-33-69G	2				
33-980	1	CALIPER(R), FRT BRAKE			-0519
*NA01-33-980 A (NA01-33-980A)	1				0519-
*NA01-33-980A	1				
33-980Z	1	CALIPER(L), FRT BRAKE			-0519
*NA01-33-990 A (NA01-33-990A)	1				0519-
*NA01-33-990A	1				
49-114A	2	PIN, SLIDER			
8173-49-114	2				
8239-49-114	2				

9601 NA35MM-106797  
9615 NA35MM-109485  
0519 NA35MM-152765

3310 FRONT BRAKE MECHANISMS




THOUGH ILLUSTRATIONS OF D-CODE 49-240C, 49-250B AND 33-23Z ARE FOR LEFT SIDE ONLY. QUANTITIES OF THESE D-CODES IN THE TEXT ARE FOR ONE VEHICLE.

3310 -2 \* FRONT BRAKE MECHANISMS

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
49-240C		SEAL KIT,CALIPER-FRT			
NAY1-33-24Z	1				
49-250B		BOOT KIT,FRT CALIPER			
NAY1-33-25Z	1				

3400 FRONT SUSPENSION MECHANISMS

3400 -1 FRONT SUSPENSION MECHANISMS



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
28-013A		SHEET, RUBBER			9411-
G030-28-013A	2				
28-091		NUT			9405-
B037-28-091	6				
LA01-28-091	2				
28-111B		STOPPER, BUMP			
NA01-28-111	2				
28-333A		NUT, FLANGE			
H001-28-333	4				
28-380		RUBBER, MOUNTING			
NA01-28-380A	2				
28-4A0		BOLT, ADJUST			
NA01-28-4A0	4				
28-448		SEAL, DUST-BALL JOINT			
H266-28-448	2				
28-473		PLATE, CAM-SUB FRAME			
NA01-28-473	4				
34-019		CAP, DAMPER			
NA01-34-019	2				
34-112A		BOLT			
NA01-34-112	2				
34-117A		WASHER			
NA01-34-117A	4				
34-200B		ARM, UPPER-FRT			-9511
NA01-34-200 A (NA01-34-200A)	2				
NA01-34-200A	2				9511-
34-310		ARM(R), LOWER			
NA01-34-300A	1				

9405 NA35MM-100118  
 9411 NA35MM-100333  
 9511 NA35MM-103176

AUNA01


CAT. AUNA01-07

1992-02

1-K13


3400 FRONT SUSPENSION MECHANISMS

3400 -2 M FRONT SUSPENSION MECHANISMS



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
34-310Z		ARM(L), LOWER			
NA01-34-350A	1				
34-460		BUSH, RUBBER-LWR ARM			
NA01-34-460A	2				
34-480		BUSHING, RUBBER-LOWER ARM			
NA01-34-480	4				-9511
NA01-34-430A	4				9511-
34-490A		BUSHING, RUBBER			
NA01-34-490	2				
34-550		BALL JOINT, LOWER			
NA01-34-550	2				
34-565		SEAL, DUST			
NA01-34-548	2				
9511 NA35MM-103176					

3401 FRONT SPRING & DAMPER




3401 -1 M FRONT SPRING & DAMPER

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
34-011		SPRING, COIL-FRONT			
NA01-34-011A	2	(M)			
NA03-34-011	2	(AT)			
34-700		DAMPER, FRONT			
NA01-34-700	2				

3410 CROSSMEMBER & STABILIZER

3410 -1 \* CROSSMEMBER & STABILIZER



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
34-09X		BOLT			
NA01-34-09XA	4				
34-091		NUT			
FB01-34-091	4				
34-151		STABILIZER, FRONT			
NA01-34-151A	1				
34-155		PLATE, STABILIZER			
FB01-34-155	2				
34-156A		RUBBER, STAB - PART			
NA01-34-156A	2				
34-170A		LINK, CONTROL-STAB			
NA01-34-170	2				
34-800		MEMBER, CROSS			
NA01-34-800 A (NA01-34-800A)	1				-9330
NA01-34-800A	1				933.1-

9330 NA35MM-100072


## SECTION NAME INDEX (CHASSIS)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
1-C11	2505	REAR PROPELLER SHAFT	1-J16	4400	PARKING BRAKE SYSTEM			
1-D11	2550	REAR DRIVE SHAFT	1-L16	4500	FUEL PIPINGS			
1-E11	2600	REAR AXLE	2-C03	4600	CHANGE CONTROL SYSTEM (AT)			
1-F11	2610	REAR BRAKE MECHANISMS						
1-H11	2710	REAR DIFFERENTIALS (NORMAL DIFF.)						
1-L11	2710 A	REAR DIFFERENTIALS (LIMITED SLIP DIFF.)						
1-D12	2800	REAR SUSPENSION MECHANISMS						
1-E12	2801	REAR SPRING & DAMPER						
1-F12	2810	REAR STABILIZER						
1-G12	2830	REAR LOWER ARMS & SUB FRAME						
1-I12	3200	STEERING WHEEL						
1-L12	3210	STEERING COLUMN & SHAFTS						
1-M12	3220	STEERING GEAR (W/O POWER STEERING)						
1-C13	3220 A	STEERING GEAR (W/ POWER STEERING)						
1-F13	3240	POWER STEERING SYSTEM						
1-H13	3300	FRONT AXLE						
1-I13	3310	FRONT BRAKE MECHANISMS						
1-K13	3400	FRONT SUSPENSION MECHANISMS						
1-M13	3401	FRONT SPRING & DAMPER						
1-N13	3410	CROSSMEMBER & STABILIZER						
1-C14	3700	TIRES & JACK						
1-C15	3900	ENGINE & T/MISSION MOUNTINGS						
1-D15	4000	EXHAUST SYSTEM						
1-F15	4140	CLUTCH RELEASE & MASTER CYLINDERS (MANUAL TRANSMISSION)						
1-G15	4145	CLUTCH PIPINGS (MANUAL TRANSMISSION)						
1-H15	4160	ACCELERATOR CONTROL SYSTEM						
1-I15	4200	FUEL TANK						
1-M15	4300	CLUTCH & BRAKE PEDALS (MANUAL TRANSMISSION)						
1-D16	4300A	BRAKE PEDALS (AUTOMATIC TRANSMISSION)						
1-F16	4340	BRAKE MASTER CYLINDER & POWER BRAKE						
1-H16	4360	BRAKE PIPINGS						

CATLOG-NO= AUNA01-07

DATE. 1992-02

1-B14




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
26-161A		NUT, HUB			
0603-26-161	16	NON BRIGHT			
8002-37-160	16	PLATED			
37-190		CAP, CENTER			
B455-37-190	4				
NA01-37-190	4				
37-192B		EMBLEM, CENTER			
B001-37-192	4				
37-600		WHEEL, DISC STEEL			
9965B-95540	4	5.5JX14 P=100/O=45			
99651-54040	1	4TX14 P=100/O=45			
37-600A		TIRE			
90620-47614	1	T155/70D14			
90623-06684	4	P185/60R14			
90624-26684	4	P185/60R14			
37-600C		VALVE, AIR			
99636-04130	1	TR413			
99636-04140	4	TR414			
37-600E		WEIGHT, DISC WHEEL-ST EEL			
99655-30005	4	5G			
99655-30010	4	10G			
99655-30015	4	15G			
99655-30020	4	20G			
99655-30025	4	25G			

9A01 NA35HW-122908

1-C14






PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
99655-30030	4	30G			
99655-30035	4	35G			
99655-30040	4	40G			
99655-30045	4	45G			
99655-30050	4	50G			
99655-30055	4	55G			
99655-30060	4	60G			
99655-90005	4	WEIGHT, DISC WHEEL-ALUMI 5G FOR 1-PIECE WHL			
99655-90010	4	10G FOR 1-PIECE WHL			
99655-90015	4	15G FOR 1-PIECE WHL			
99655-90020	4	20G FOR 1-PIECE WHL			
99655-90025	4	25G FOR 1-PIECE WHL			
99655-90030	4	30G FOR 1-PIECE WHL			
99655-90035	4	35G FOR 1-PIECE WHL			
99655-90040	4	40G FOR 1-PIECE WHL			
99655-90045	4	45G FOR 1-PIECE WHL			
99655-90050	4	50G FOR 1-PIECE WHL			
99655-90055	4	55G FOR 1-PIECE WHL			
99655-90060	4	60G FOR 1-PIECE WHL			
8BN1-37-600	4	WHEEL SET, DISC-ALUMI 5.5JX14 NKK MAKE			
8BN3-37-600	4	5.5JX14 ENKEI MAKE			

0201 NA35MM-137180

0201-

3700 TIRES & JACK

3700 -3 M TIRES & JACK



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
56-170A		BOLT, JACK SET			
B001-56-170C	1				
56-211A		PLATE, CLAMP-JACK			
1219-56-211	1				
68-800A		JACK			
B455-37-790 A (B455-37-790A)	1				-9901
B455-37-790A	1				9901-
68-810A		HANDLE, JACK			
GJ21-37-810	1				
9901 NA35MM-119257					


## SECTION NAME INDEX (CHASSIS)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
1-C11	2505	REAR PROPELLER SHAFT	1-J16	4400	PARKING BRAKE SYSTEM			
1-D11	2550	REAR DRIVE SHAFT	1-L16	4500	FUEL PIPINGS			
1-E11	2600	REAR AXLE	2-C03	4600	CHANGE CONTROL SYSTEM (AT)			
1-F11	2610	REAR BRAKE MECHANISMS						
1-H11	2710	REAR DIFFERENTIALS (NORMAL DIFF.)						
1-L11	2710 A	REAR DIFFERENTIALS (LIMITED SLIP DIFF.)						
1-D12	2800	REAR SUSPENSION MECHANISMS						
1-E12	2801	REAR SPRING & DAMPER						
1-F12	2810	REAR STABILIZER						
1-G12	2830	REAR LOWER ARMS & SUB FRAME						
1-I12	3200	STEERING WHEEL						
1-L12	3210	STEERING COLUMN & SHAFTS						
1-M12	3220	STEERING GEAR (W/O POWER STEERING)						
1-C13	3220 A	STEERING GEAR (W/ POWER STEERING)						
1-F13	3240	POWER STEERING SYSTEM						
1-H13	3300	FRONT AXLE						
1-I13	3310	FRONT BRAKE MECHANISMS						
1-K13	3400	FRONT SUSPENSION MECHANISMS						
1-M13	3401	FRONT SPRING & DAMPER						
1-N13	3410	CROSSMEMBER & STABILIZER						
1-C14	3700	TIRES & JACK						
1-C15	3900	ENGINE & T/MISSION MOUNTINGS						
1-D15	4000	EXHAUST SYSTEM						
1-F15	4140	CLUTCH RELEASE & MASTER CYLINDERS (MANUAL TRANSMISSION)						
1-G15	4145	CLUTCH PIPINGS (MANUAL TRANSMISSION)						
1-H15	4160	ACCELERATOR CONTROL SYSTEM						
1-I15	4200	FUEL TANK						
1-M15	4300	CLUTCH & BRAKE PEDALS (MANUAL TRANSMISSION)						
1-D16	4300A	BRAKE PEDALS (AUTOMATIC TRANSMISSION)						
1-F16	4340	BRAKE MASTER CYLINDER & POWER BRAKE						
1-H16	4360	BRAKE PIPINGS						



3900 ENGINE & T/MISSION MOUNTINGS

3900 -1 \* ENGINE & T/MISSION MOUNTINGS




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
34-222		NUT			
3871-34-222	4				
39-020A		BRACKET(R), ENGINE			
NA01-39-020	1				
39-030A		BRACKET(L), ENGINE			
NA01-39-030	1				
39-040A		RUBBER, ENGINE MT.			
NA01-39-040	2				
39-045		CASING, STOPPER			
NA01-39-041	2 (MT)				
S231-39-041	2 (AT)				
39-710		FRAME, POWER PLANT			
NA01-39-710	1 (MT)				
NA03-39-710	1 (AT)				
39-721		BOLT, PLANT FRAME			
NA01-39-721	3				
39-722		BOLT, PLANT FRAME			
NA01-39-722	1				
39-723		SPACER, PLANT FRAME			
NA01-39-723	1				
39-724		WASHER, PLAIN-FRAME			
NA01-39-724	3 (AT)				
	4 (MT)				
39-730		BRACKET, PLANT FRAME			
NA01-39-730	1				-9407
A (NA01-39-730A)					
NA01-39-730A	1 (MT)				9407 -

9407 NA35MM-100180

4000 EXHAUST SYSTEM

4000 -1 EXHAUST SYSTEM




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
20-305 B690-40-305	1	GASKET, EXH. PIPE-CONVERTER NON ASBESTOS			
20-500A B61P-20-690	1	CONVERTER, CATALYST			
40-050A B690-40-500A	1	PIPL, EXHAUST-FRONT			
40-061C RF03-40-061	5	HANGER, SILENCER			
40-081 B690-40-080A	1	BRACKET, HANGER			
40-230 B690-40-690	1	BRACKET, HANGER			
40-305A B322-40-305	1	GASKET NON ASBESTOS			
40-355A 2158-40-355	3	NUT			
40-355B JE10-40-355	4	NUT			
40-356B B6A5-40-356	2	BAND			
40-356C B690-40-356	1	BAND			
40-450 B690-40-450	1	GASKET, CONVERTER NON ASBESTOS			
40-500 B690-40-100D A (B690-40-100E)	1	SILENCER, MAIN			-9B20

9B20 NA35MM-128848

4000 EXHAUST SYSTEM

4000 -2 H EXHAUST SYSTEM




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
B6B4-40-100A A (B6B4-40-100B)	1				-0401
B690-40-100E A (B690-40-100F)	1				9B20-0401
B6B4-40-100B	1 (AT)				0401-
B690-40-100F	1 (MT)				0401-


9B20 NA35MM-128848  
0401 NA35MM-146561

4140 CLUTCH RELEASE & MASTER CYLINDERS (MANUAL TRANSMISSION)

4140 -1 M CLUTCH RELEASE & MASTER CYLINDERS (MANUAL TRANSMISSION)



41-920




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
17-341J		BALL, STEEL			
99611-1500	1				
33-691		SCREW, BLEEDER			
0259-33-691	1				
33-693A		CAP, BLEEDER SCREW			
0259-33-693	1				
41-341		ROD, PUSH			
H266-41-341	1				
41-470		SPRING			
B312-41-470	2				
41-920		CYL., CLUTCH RELEASE			
HE29-41-920A	1				-9701
NA01-41-920	1				9701-
41-990		CYL., CLUTCH MASTER			
NA01-41-400A	1				
43-552S		CAP SET, RESERVE TANK			
B093-49-580	1				
49-460		PARTS KIT, INNER			
H005-49-460	1				
49-470		SEAL KIT			
H005-49-470	1				
49-686B		BUSH, ELBOW JOINT			
0305-49-686B	1				

9701 NA35MN-111969

4145 CLUTCH PIPINGS (MANUAL TRANSMISSION)

4145 -1 M CLUTCH PIPINGS (MANUAL TRANSMISSION)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
41-360		HOLDER, CLUTCH			
NA01-41-370A	1	SUMINO KOGYO			
8871-41-370	1				-0701
NA02-41-370	1	MIDORI			0701-
41-370		PIPE, CLUTCH			
NA01-41-370A	1				
41-380		HOSE, FLEXIBLE			
GK67-41-380A	1				
41-390		HOLDER, PIPE			
NA01-41-390	1				
43-635A		CLIP, FLEXIBLE HOSE			
0136-43-635	2				
45-510		PIPE, CLUTCH			
NA01-45-510B AN(NA01-45-510C)	1				-9601
NA01-45-510C	1				9601-
45-919C		CLIP, PIPE			
G030-45-919	1				



9601 NA35M-106797  
0701 NA35M-200041

AUNA01

CAT. AUNA01-07

1992-02






PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
41-610B		PEDAL & ARM			
NA01-41-610 A (NA01-41-610A)	1				-0701
NA02-41-610 A (NA02-41-610A)	1				-0701
NA01-41-610A	1	BASE, (W/O AUTO CRUISE CON T.)			0701-
NA02-41-610A	1	PKG-OPT, (W/AUTO CRUISE CONT)			0701-
41-613		ROLLER			
B104-41-114	1	PKG-OPT, (W/AUTO CRUISE CONT)			
41-619		SPRING, RETURN			
NA01-41-619	1				
41-644		BUSH			
B092-41-644	2	OIRES KOGYO			
0259-41-644	2	ONDO KOSAKUSHO PKG-OPT, (W/AUTO CRUISE CONT)			
41-660		CABLE, ACCEL.			
NA01-41-660A	1				
41-780		LEVER, ACCELERATOR			
NA01-41-130A	1	PKG-OPT, (W/AUTO CRUISE CONT)			
0701 NA35MM-200041					



4200 FUEL TANK



4200 -2 FUEL TANK

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
42-280	1	VALVE, NON RETURN			-9901
GB53-42-270	1				9901-
H260-42-270	1				
42-290A	1	PROTECTOR 'A', FILLER PIPE			
NA01-42-291A	1				
42-408	2	STOPPER, FILLER LID			
0187-70-491	2				
42-410	1	LID, FUEL FILLER			-9801
NA01-42-410 AN (NA01-42-410A)	1				
NA01-42-410A	1				9801-
42-431	1	SPRING LIFT, LID			
H043-42-431D	1				
42-441	1	WASHER, LID OPENER			
NA01-56-896	1				
42-480	1	OPENER, FILLER LID			
NA01-56-850A	1				
B095-56-890A	1				
42-561C	1 (AT)	HOSE NO. 1, BREATHER			
NA03-42-561	1 (AT)				
42-562	1 (AT)	HOSE NO. 2, BREATHER			
NA03-42-562	1 (AT)				
42-563A	1 (AT)	HOSE NO. 3, BREATHER			
NA03-42-563	1 (AT)				
42-564	1 (AT)	HOSE NO. 4, BREATHER			
NA03-42-564	1 (AT)				
42-571	1 (MT)	HOSE, VENT			
NA01-42-561	1 (MT)				
		9901 NA35MM-119257			
		9801 NA35MM-126490			

AUNA01

CAT. AUNA01-07

1992-02


1-J15






4300 CLUTCH & BRAKE PEDALS (MANUAL TRANSMISSION)

4300 -1 CLUTCH & BRAKE PEDALS (MANUAL TRANSMISSION)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
18-660B		SWITCH, CLUTCH			
LA01-66-490A	1				
41-023A		BUSH			
0727-41-023	1				
41-030		PEDAL, CLUTCH			
NA01-41-030B	1				
41-061		SPACER			
0727-41-061	1				
41-070		BRACKET, MASTER CYL.			
NA01-41-070A	1				
41-081A		SPRING, RETURN			
BR70-41-081	1				
41-131		ROD, PUSH			
0824-41-131	1				
41-140		FORK, CLUTCH			
NA01-41-140B	1				
41-443		GASKET			
NA01-41-443	1				
41-682		RUBBER, STOP			
1456-41-682	1	PKG-OPT, (W/AUTO CRUISE CONT)			
43-028		PAD, PEDAL			
8092-43-028	2				
43-029		RUBBER, STOPPER			
B001-43-029	5				-9901
B001-43-029	4				9901-
G030-43-029	1				9901-
43-030		PEDAL, BRAKE			
9901 NA35MM-119257					

4300 CLUTCH & BRAKE PEDALS (MANUAL TRANSMISSION)



4300 -2 CLUTCH & BRAKE PEDALS (MANUAL TRANSMISSION)

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
NA01-43-030	1				
43-041		REST, FOOT			
NA01-43-041	1				
43-061A		PIPE, PEDAL			
0866-43-062	1				
43-065A		SPACER			
BR70-43-065	2				
43-070		BRACKET, MASTER CYL.			
NA01-43-070A	1	BASE, (W/O AUTO CRUISE CONT.)			
NA02-43-070A	1	PKG-OPT, (W/AUTO CRUISE CONT)			
43-081A		SPRING, RETURN-BRAKE			
092-41-081	1				
43-140		FORK, BRAKE			
1524-43-140	1				
43-152		PIN, SNAP			
D001-43-152	1				
43-302		GRUMMET, BRAKE PEDAL			
B180-43-302	1				
46-085		BUSH			
1015-46-085	4				
46-683A		PIN			
0223-46-683	1				
66-400		SWITCH, CLUTCH CUT			
FB01-66-400	1				
67-210		SWITCH, LIGHT-BRAKE			
BR70-66-490A	1	PKG-OPT, (W/AUTO CRUISE CONT)			

## SECTION NAME INDEX (CHASSIS)


LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
1-C11	2505	REAR PROPELLER SHAFT	1-J16	4400	PARKING BRAKE SYSTEM			
1-D11	2550	REAR DRIVE SHAFT	1-L16	4500	FUEL PIPINGS			
1-E11	2600	REAR AXLE	2-C03	4600	CHANGE CONTROL SYSTEM (AT)			
1-F11	2610	REAR BRAKE MECHANISMS						
1-H11	2710	REAR DIFFERENTIALS (NORMAL DIFF.)						
1-L11	2710 A	REAR DIFFERENTIALS (LIMITED SLIP DIFF.)						
1-D12	2800	REAR SUSPENSION MECHANISMS						
1-E12	2801	REAR SPRING & DAMPER						
1-F12	2810	REAR STABILIZER						
1-G12	2830	REAR LOWER ARMS & SUB FRAME						
1-I12	3200	STEERING WHEEL						
1-L12	3210	STEERING COLUMN & SHAFTS						
1-M12	3220	STEERING GEAR (W/O POWER STEERING)						
1-C13	3220 A	STEERING GEAR (W/ POWER STEERING)						
1-F13	3240	POWER STEERING SYSTEM						
1-H13	3300	FRONT AXLE						
1-I13	3310	FRONT BRAKE MECHANISMS						
1-K13	3400	FRONT SUSPENSION MECHANISMS						
1-M13	3401	FRONT SPRING & DAMPER						
1-N13	3410	CROSSMEMBER & STABILIZER						
1-C14	3700	TIRES & JACK						
1-C15	3900	ENGINE & T/MISSION MOUNTINGS						
1-D15	4000	EXHAUST SYSTEM						
1-F15	4140	CLUTCH RELEASE & MASTER CYLINDERS (MANUAL TRANSMISSION)						
1-G15	4145	CLUTCH PIPINGS (MANUAL TRANSMISSION)						
1-H15	4160	ACCELERATOR CONTROL SYSTEM						
1-I15	4200	FUEL TANK						
1-M15	4300	CLUTCH & BRAKE PEDALS (MANUAL TRANSMISSION)						
1-D16	4300A	BRAKE PEDALS (AUTOMATIC TRANSMISSION)						
1-F16	4340	BRAKE MASTER CYLINDER & POWER BRAKE						
1-H16	4360	BRAKE PIPINGS						





4300 CLUTCH & BRAKE PEDALS (MANUAL TRANSMISSION)


4300 -3 \* CLUTCH & BRAKE PEDALS (MANUAL TRANSMISSION)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM TO
CONT'D					
B001-66-490A	1	BASE, (W/O AUTO CRUISE CON T.)			
68-615B		NUT, FLANGE-CAP			
B100-68-615	1				

4300A BRAKE PEDALS (AUTOMATIC TRANSMISSION)


4300A -1 BRAKE PEDALS (AUTOMATIC TRANSMISSION)




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
18-660		SWITCH, KICK DOWN			
H118-66-470	1				
41-443		GASKET			
NA01-41-443	1				
43-028		PAD, PEDAL			
0268-43-028	1				
43-029		RUBBER, STOPPER			
B001-43-029	2				
43-030		PEDAL, BRAKE			
NA03-43-030	1				
43-041		REST, FOOT			
NA01-43-041	1				
43-061A		PIPE, PEDAL			
0866-43-062	1				
43-070		BRACKET, MASTER CYL. BASE, (W/O AUTO CRUISE CONT.)			
NA01-43-070A	1				
NAU2-43-070A	1	(PKG-OPT, (W/AUTO CRUISE CONT))			
43-081A		SPRING, RETURN-BRAKE			
B092-41-081	1				
43-090		PLATE			
NA03-43-090	1				
43-099		HOLDER, PLATE			
HF23-43-099	1				
43-140		FORK, BRAKE			
1F24-43-140	1				
43-152		PIN, SNAP			

4300A BRAKE PEDALS (AUTOMATIC TRANSMISSION)

4300A -2 \* BRAKE PEDALS (AUTOMATIC TRANSMISSION)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D 0001-43-152	1				
46-085		BUSH			
1015-46-085	2				
67-210		SWITCH, LIGHT-BRAKE			
BR70-66-490A	1	PKG-OPT, (W/AUTO CRUISE CONT)			
B001-66-490A	1	BASE, (W/O AUTO CRUISE CON T.)			




Component parts of REPAIR KIT are under establishment now. Parts numbers will be informed you by the Parts Engineering Change Bulletin as soon as established.


PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
43-443 H001-43-443	1	GASKET, VAC POWER ASSIST NON ASBESTOS			
43-481 NA01-43-481	1	HOSE, VACUUM			
43-504 W023-43-504	1	JOINT, PIPE			
43-505 W023-43-505	1	BOLT, CONNECTOR			
43-540A GA97-43-540	1	SENSOR, RESERVE TANK			
43-542 3597-43-542	1	FLOAT			
43-550S B216-49-680 A (B216-49-680A)	1	TANK SET, RESERVE			-0701
43-552S D001-49-650 A (D001-49-650A)	1	CAP SET, RESERVE TANK			0701-
43-638 GA02-49-638	1	RING, RETAINING			-0701
43-640 NA01-43-640	1	HOSE, VACUUM			0701-
43-750A NA01-43-750	1	HOLDER, P. B. VALVE			
43-800 NA01-43-800	1	VACUUM POWER ASSIST			

0701 NA35MM-200041





PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
43-360		PIPE, BRAKE			
NA01-43-360A	1				
43-370		PIPE, BRAKE			
NA01-43-370	1				
43-635		CLIP, FLEXIBLE HOSE			
W023-43-635	3				
43-670		PIPE, BRAKE-REAR			
NA01-43-670A	1				
43-694A		BOLT, CONNECTOR			
B001-43-694A	4				
43-900		VALVE, DUAL PROPORTIONING			
NA01-43-900	1				
43-980A		HOSE (R), FLEXIBLE-FRT			
NA01-43-810A	1				
43-980B		HOSE (R), FLEXIBLE-RR			
NA01-43-980	1				
43-980X		HOSE (L), FLEXIBLE-RR			
NA01-43-990	1				
43-980Y		HOSE (L), FLEXIBLE-FRT			
NA01-43-820A	1				
45-280		PIPE (R), BRAKE-FRONT			
NA01-45-280B	1				
45-320		PIPE (L), BRAKE-FRONT			
NA01-45-320B	1				
45-360		PIPE NO. 2, BRAKE-REAR			
NA01-45-360B	1				
45-911C		CLIP, PIPE			
NA01-45-911	1				




(a)	(b)	(c)
45-916	45-911C	45-915A
(d)	(e)	(f)
45-915B	45-919	45-919
	(B001-45-919B)	(NA01-45-916)

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
45-915A		HOLDER, PIPE			
B001-45-915	2				
45-915B		HOLDER, PIPE			
NA01-45-915A	1				
45-916		HOLDER, PIPE			
B001-45-916	1				
45-919		CLIP, PIPE			
NA01-45-916	1				-9801
B001-45-919B	3				-9801
B001-45-919B	4				9801-
9801 NA35MM-116316					

4400 PARKING BRAKE SYSTEM

4400 -1 PARKING BRAKE SYSTEM




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
41-081A		SPRING, RETURN			
0750-41-308	1				
43-635		CLIP, FLEXIBLE HOSE			
W023-43-635	2				
44-010		LEVER, PARKING BRAKE			
NA01-44-010	1				
44-031		SPRING, PARKING REVER			
G030-44-031	1				
44-032		ROD, RELEASE			
NA01-44-032	1				
44-033		BUTTON, RELEASE			
FB01-44-033	1				
44-034		CAP, PARK BRAKE LEVER			
FB01-44-034	1				
44-061A		COVER			
FB01-44-061B	1				
44-062		COVER			
FB01-44-062A	1				
44-063		SPACER			
FC01-44-063	1				
44-150		CABLE, PARKING-FRT			
NA01-44-1503	1				
44-187		SCREW, ADJUST			
0866-44-187A	1				
44-189		CLIP			
0866-44-189	1				
44-410		CABLE(R), R.-PARK.			
NA01-44-410B	1				




4400 PARKING BRAKE SYSTEM

4400 -2 M PARKING BRAKE SYSTEM




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
44-410A NA01-44-420B	1	CABLE(L),R.-PARK.			
44-439 1011-44-439	1	CLIP,CABLE			
66-840 GJ21-66-450A	1	SWITCH,PARKING LAMP			



a	b	c	d	e	f	g
45-912D	45-912D	45-913	45-913A	45-914	45-915	45-921
H266-45-912		H266-45-912				
93-5106				99351-06999	L=180MM	
93-5808				99358-08999	L=220MM	

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
13-157A		CLIP			
8574-13-157	6				
45-111		PIPE, FUEL-MAIN			
NA01-45-111	1				
45-112		PIPE, FUEL-MAIN			
NA01-45-112A	1				
45-125		HOSE, FUEL			
99359-0815	2				-9801
99359-0815	1				9801-
45-611		PIPE, FUEL-RETURN			
NA01-45-611	1				
45-711		PIPE, EVAPORATION			
NA01-45-711A	1				
45-910E		HOLDER, PIPE			
H266-45-910A	2				
45-912D		HOLDER 'A'			
H260-45-912	1				
H266-45-912	5				
45-913		HOLDER, PIPE			
NA01-45-912	1				
45-913A		CLIP, PIPE			
NA01-45-913	1				
45-914		HOLDER, PIPE			
F801-45-914	1	WIFUKO			
45-915		CLIP, PIPE			
NA01-45-914	1				
45-920A		HOLDER 'B', PIPE			
H266-45-920A	1				
9801 NA35MM-126490					



a	b	c	d	e	f	g
45-912D	45-912D	45-913	45-913A	45-914	45-915	45-921
H260-45-912 H266-45-912						
93-5106		99351-0C999		L=180MM		
93-5808		99358-08999		L=220MM		


PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM TO
45-921		CLIP, PIPE			
8210-45-917	1				
45-930		HOLDER 'C', PIPE			
H260-45-930	1				
H266-45-930A	1				
93-5106		HOSE			
99351-06999	1				
93-5808		HOSE			
99358-08999	1				
93-5908		HOSE			
99359-0817	1				
99359-0816	1				

9801-

9801 NA35MM-126490

# Parts Catalog

Mazda MX-5 MIATA  
U.S.A.  
(90)



NA36\*\*100001-200000

Feb. '92 (FINAL)


Catalog No. AU-NA01-07

**mazda**

© 1992 Mazda Motor Corporation






















## LAYOUT OF CONTENTS

- The following is a typical example of the layout of contents on Mazda microfiche parts catalog



















- |                                      |                          |                                   |
|--------------------------------------|--------------------------|-----------------------------------|
| ① • Layout of contents               | ② • Pictorial Index      | ③ • Master Section No. Index      |
| ④ • Section No. Index for the Column | ⑤ • Illustration & Text  | ⑥ • Part No. Index                |
| ⑦ • Alphabetical Index               | ⑧ • Model Identification | ⑨ • Vehicle Identification System |

PICTORIAL INDEX

<p>1000</p> 	<p><b>1</b> 1010</p>  <p>CYLINDER HEAD &amp; COVER</p>	<p><b>2</b> 1030</p>  <p>CYLINDER BLOCK</p>	<p><b>3</b> 1040</p>  <p>OIL PAN &amp; TIMING COVER</p>	<p><b>4</b> 1100</p>  <p>PISTON, CRANKSHAFT &amp; FLYWHEEL</p>	<p><b>5</b> 1200</p>  <p>VALVE SYSTEM</p>
<p>SHORT ENGINE &amp; GASKET SETS</p> 	<p style="text-align: center;">ENGINE (1/2)</p> 				<p><b>6</b> 1400</p>  <p>OIL PUMP &amp; FILTER</p>
<p>ENGINE &amp; T/MISSION MOUNTINGS</p> 					<p><b>7</b> 1600</p>  <p>CLUTCH DISC &amp; COVER (MANUAL)</p>
<p><b>17</b> 3900</p> <p>Given in Chassis Group</p> 					<p><b>8</b> 1700</p>  <p>TRANSMISSION CASE (MANUAL)</p>
<p><b>16</b> 1960</p> <p>GASKET &amp; SEAL KIT (AUTOMATIC)</p> 					<p><b>9</b> 1710</p>  <p>TRANSMISSION GEARS (MANUAL)</p>
<p><b>15</b> 1950</p> <p>MANUAL LINKAGE SYSTEM (AUTOMATIC)</p> 					<p><b>10</b> 1720</p>  <p>CHANGE CONTROL SYSTEM (MANUAL)</p>
<p><b>14</b> 1940</p>  <p>GOVERNOR, LOW &amp; REVERSE PISTON (AUTOMATIC)</p>	<p><b>13</b> 1930</p>  <p>CLUTCH &amp; PLANETARY GEARS (AUTOMATIC)</p>	<p><b>12</b> 1920 1925</p>  <p>TRANSMISSION CASE &amp; MAIN CONTROL SYSTEM (AUTOMATIC)</p>	<p><b>11</b> 1910</p>  <p>TORQUE CONVERTER, OIL PUMP &amp; PIPINGS (AUTOMATIC)</p>		




















As this illustration is prepared to be applicable to all models, some parts are different in specifications from the parts listed in this parts Catalog.

PICTORIAL INDEX

<p><b>1</b> 1300</p>  <p>INLET MANIFOLD</p>	<p><b>2</b> 1310</p>  <p>EXHAUST MANIFOLD</p>	<p><b>3</b> 1320</p>  <p>FUEL SYSTEM</p>	<p><b>4</b> 1325</p>  <p>FUEL DISTRIBUTOR</p>	<p><b>5</b> 1330</p>  <p>AIR CLEANER</p>	<p><b>6</b> 1364</p>  <p>THROTTLE BODY</p>			
<p><b>18</b> 4000</p>  <p>Given in Chassis Group</p> <p>EX. SYSTEM</p>	<p><b>ENGINE (2/2)</b></p> 				<p><b>7</b> 1370</p>  <p>EMISSION CONTROL SYSTEM (INLET SIDE)</p>			
<p><b>17</b> 1850</p>  <p>BATTERY</p>					<p><b>8</b></p>			
<p><b>16</b> 1840</p>  <p>STARTER</p>					<p><b>9</b> 1399</p>  <p>CAP &amp; HOSE CLIP 'INLET &amp; EXHAUST SIDE'</p>			
<p><b>15</b> 1830</p>  <p>ALTERNATOR</p>					<p><b>13</b> 1800</p>  <p>ENGINE ELECTRICAL SYSTEM</p>	<p><b>12</b></p>	<p><b>11</b> 1580</p>  <p>BRACKET, PULLEY &amp; BELT</p>	<p><b>10</b> 1500</p>  <p>COOLING SYSTEM</p>













As this illustration is prepared to be applicable to all models, some parts are different in specifications from the parts listed in this parts Catalog.

# PICTORIAL INDEX

<p><b>1</b> 2505</p>  <p>REAR PROPELLER SHAFT</p>	<p><b>2</b> 2550</p>  <p>REAR DRIVE SHAFTS</p>	<p>2600</p>  <p>REAR AXLE</p>	<p><b>3</b> 2610</p>  <p>REAR BRAKE MECHANISMS</p>	<p><b>4</b> 2710</p>  <p>REAR DIFFERENTIALS</p>	<p><b>5</b> 2800 2810</p>  <p>REAR SUSPENSION MECHANISMS REAR STABILIZER</p>
<p><b>16</b> 4600</p>  <p>CHANGE CONTROL SYSTEM (AUTOMATIC)</p>	<p><b>17</b> 1720</p> <p>Given in Engine Group</p>  <p>CHANGE CONTROL SYSTEM (MANUAL)</p>	<h2 style="margin: 0;">CHASSIS (1/2)</h2> 			<p>2801</p>  <p>REAR SPRING &amp; DAMPER</p>
<p><b>15</b> 4000</p>  <p>EXHAUST SYSTEM</p>				<p>2830</p>  <p>REAR LOWER ARMS &amp; SUB FRAME</p>	
<p><b>14</b> 3900</p>  <p>ENGINE &amp; T/MISSION MOUNTINGS</p>				<p><b>6</b> 3200</p>  <p>STEERING WHEEL</p>	
<p><b>13</b> 3410</p>  <p>CROSSMEMBER &amp; STABILIZER</p>				<p><b>7</b> 3210</p>  <p>STEERING COLUMN &amp; SHAFTS</p>	
<p><b>12</b> 3401</p>  <p>FRONT SPRING &amp; DAMPER</p>				<p>3400</p>  <p>FRONT SUSPENSION MECHANISMS</p>	<p><b>11</b> 3310</p>  <p>FRONT BRAKE MECHANISMS</p>

As this illustration is prepared to be applicable to all models, some parts are different in specifications from the parts listed in this parts Catalog

















# PICTORIAL INDEX

<p><b>1</b> 3700</p>  <p style="text-align: center;">TIRES &amp; JACK</p>	<p><b>2</b> 4140</p>  <p style="text-align: center;">CLUTCH RELEASE &amp; MASTER CYLINDERS (MANUAL TRANSMISSION)</p>	<p>4145</p>  <p style="text-align: center;">CLUTCH PIPINGS (MANUAL TRANSMISSION)</p>	<p><b>3</b> 4160</p>  <p style="text-align: center;">ACCELERATOR CONTROL SYSTEM</p>	<p><b>4</b> 4200</p>  <p style="text-align: center;">FUEL TANK</p>	<p><b>5</b> 4300</p>  <p style="text-align: center;">CLUTCH &amp; BRAKE PEDALS</p>
<h2 style="margin: 0;">CHASSIS (2/2)</h2> 					
<p><b>6</b> 4340</p>  <p style="text-align: center;">BRAKE MASTER CYLINDER &amp; POWER BRAKE</p>					
<p><b>7</b> 4360</p>  <p style="text-align: center;">BRAKE PIPINGS</p>					
<p><b>8</b> 4400</p>  <p style="text-align: center;">PARKING BRAKE SYSTEM</p>					
<p><b>9</b> 4500</p>  <p style="text-align: center;">FUEL PIPINGS</p>					
<p><b>11</b> 4370</p>  <p style="text-align: center;">ANTILOCK BRAKE SYSTEM</p>					

As this illustration is prepared to be applicable to all models, some parts are different in specifications from the parts listed in this parts Catalog






















PICTORIAL INDEX

<p><b>1</b> 0900</p>  <p>KEY SETS</p>	<p><b>2</b></p>	<p><b>3</b> 5100</p>  <p>HEAD LAMPS</p>	<p><b>4</b> 5103</p>  <p>HEAD LAMP RETRACTORS</p>	<p><b>5</b> 5105</p>  <p>FRONT COMBINATION LAMPS</p>	<p><b>6</b> 5110</p>  <p>REAR COMBINATION LAMPS</p>
<p><b>19</b> 6704</p>  <p>WIRING HARNESS CLAMPS</p>	<p><b>20</b> 6720</p>  <p>WINDSHIELD WASHER</p>	<p><b>21</b> 6730</p>  <p>WINDSHIELD WIPERS</p>			<p><b>7</b> 5120</p>  <p>LICENSE LAMPS</p>
<p><b>18</b> 6703</p>  <p>WIRING HARNESSES (DOOR, FLOOR/CEILING)</p>	<p style="text-align: center;"><b>BODY (1/4)</b></p> 				<p><b>8</b></p>
<p><b>17</b> 6702</p>  <p>WIRING HARNESSES (DASHBOARD)</p>					<p><b>9</b></p>
<p><b>16</b> 6701</p>  <p>WIRING HARNESSES (ENGINE &amp; TRANSMISSION)</p>					<p><b>10</b> 6600</p>  <p>SWITCHES &amp; RELAYS (ENGINE)</p>
<p><b>15</b> 6700</p>  <p>WIRING HARNESSES (FRONT &amp; REAR)</p>					<p><b>14</b> 6640</p>  <p>AUTO CRUISE CONTROL SYSTEM</p>












As this illustration is prepared to be applicable to all models, some parts are different in specifications from the parts listed in this parts Catalog

# PICTORIAL INDEX

<p><b>1</b> 5000</p>  <p>FRONT BUMPER</p>	<p><b>2</b></p>	<p><b>3</b> 5010</p>  <p>REAR BUMPER</p>	<p><b>4</b> 5030</p>  <p>WINDOW MOULDING &amp; COWL GRILLES</p>	<p><b>5</b></p>	<p><b>6</b></p>
<p><b>20</b> 5840</p>  <p>FRONT DOOR TRIMS &amp; RELATED PARTS</p>	<p><b>21</b></p>	<p><b>22</b> 6300</p>  <p>WINDOW GLASSES</p>	<p><b>23</b> 6330</p>  <p>SUNROOF</p>	<p><b>24</b> 7900</p>  <p>ACCESSORIES</p>	<p><b>7</b></p>
<p><b>19</b> 5830</p>  <p>FRONT DOOR MECHANISMS</p>	<p><b>BODY (2/4)</b></p> 				<p><b>8</b> 5180</p>  <p>REAR FINISHER</p>
<p><b>18</b> 5800</p>  <p>FRONT DOORS</p>					<p><b>9</b> 5230</p>  <p>BONNET</p>
<p><b>17</b> 5390 5380</p>  <p>FLOOR ATTACHMENTS</p>					<p><b>10</b> 5260</p>  <p>TRUNK LID</p>
<p><b>16</b> 5370</p>  <p>BODY PANELS (FLOOR)</p>	<p><b>15</b></p>	<p><b>14</b> 5340</p>  <p>BODY PANELS (SIDE)</p>	<p><b>13</b> 5330</p>  <p>BODY PANELS (DASH &amp; COWL PANEL)</p>	<p><b>12</b> 5320</p>  <p>BODY PANELS (FENDER &amp; WHEEL APRON)</p>	<p><b>11</b> 5310</p>  <p>BODY PANELS (FRONT)</p>















As this illustration is prepared to be applicable to all models, some parts are different in specifications from the parts listed in this parts Catalog

PICTORIAL INDEX

<p><b>1</b> 5500</p>  <p>DASHBOARD EQUIPMENTS</p>	<p><b>2</b> 5520</p>  <p>METER HOOD</p>	<p><b>3</b> 5530</p>  <p>SPEEDOMETER CABLE</p>	<p><b>4</b> 5540</p>  <p>METER COMPONENTS</p>	<p><b>5</b> 5560</p>  <p>DASHBOARD &amp; RELATED PARTS</p>	<p><b>6</b> 5570</p>  <p>CONSOLE</p>	
<p><b>BODY (3/4)</b></p> 						<p><b>7</b></p>  <p>6120</p> <p>6100</p> <p>6110</p> <p>6115</p> <p>HEATER</p>
<p><b>8</b> 6130</p>  <p>6135</p> <p>6140</p> <p>6135</p> <p>6150</p> <p>AIR CONDITIONER</p>						<p><b>9</b> 6610</p>  <p>DASHBOARD SWITCHES</p>
				<p><b>10</b> 6611</p>  <p>COMBINATION SWITCH</p>		

As this illustration is prepared to be applicable to all models, some parts are different in specific stores from the parts listed in this parts Catalog.

PICTORIAL INDEX

<p><b>1</b> 5580</p>  <p>VENTILATOR</p>	<p><b>2</b> 5700</p>  <p>SEATS</p>	<p><b>3</b></p>	<p><b>4</b> 5790</p>  <p>SEAT BELTS</p>	<p><b>5</b> 6680</p>  <p>AUDIO SYSTEMS (RADIO &amp; TAPE DECK)</p>	<p><b>6</b> 6682</p>  <p>AUDIO SYSTEMS (ANTENNA &amp; SPEAKER)</p>	
<p><b>BODY (4/4)</b></p> 						<p><b>7</b> 6684</p>  <p>AUDIO SYSTEMS (NOISE SUPPRESSOR &amp; EARTH CORD)</p>
						<p><b>8</b></p>
<p><b>17</b> 7250</p>  <p>REAR WINDOW GLASSES &amp; TRIMS</p>						<p><b>9</b> 6820</p>  <p>FRONT HEADER TRIM &amp; PILLAR TRIMS</p>
<p><b>16</b> 6930</p>  <p>CAUTION PLATES &amp; LABELS</p>						<p><b>10</b> 6840</p>  <p>TRIMS &amp; SCUFF PLATES</p>
<p><b>15</b> 6900</p>  <p>VISORS, ASSIST HANDLES &amp; MIRRORS</p>		<p><b>14</b> 6870</p>  <p>SERVICE TOOLS</p>		<p><b>13</b></p>		<p><b>12</b> 6860</p>  <p>FLOOR MATS &amp; PADS</p>

As this illustration prepared, it may not be applicable to all models, some parts are different in specifications from the parts listed in this part Catalog.

## SECTION NAME INDEX (ENGINE)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
1-C03	1000	SHORT ENGINE & GASKET SETS						
1-D03	1010	CYLINDER HEAD & COVER						
1-G03	1030	CYLINDER BLOCK						
1-I03	1040	OIL PAN & TIMING COVER						
1-K03	1100	PISTON, CRANKSHAFT & FLYWHEEL						
1-N03	1200	VALVE SYSTEM						
1-D04	1300	INLET MANIFOLD						
1-E04	1310	EXHAUST MANIFOLD						
1-F04	1320	FUEL SYSTEM						
1-H04	1325	FUEL DISTRIBUTOR						
1-I04	1330	AIR CLEANER						
1-K04	1364	THROTTLE BODY						
1-L04	1370	EMISSION CONTROL SYSTEM (INLET SIDE)						
1-M04	1399	CAP & HOSE CLIP (INLET & EXHAUST SIDE)						
1-N04	1400	OIL PUMP & FILTER						
1-C05	1500	COOLING SYSTEM						
1-G05	1580	BRACKET, PULLEY & BELT						
1-C06	1600	CLUTCH DISC & COVER (MANUAL)						
1-D06	1700	TRANSMISSION CASE (MANUAL)						
1-E06	1710	TRANSMISSION GEARS (MANUAL)						
1-J06	1720	CHANGE CONTROL SYSTEM (MANUAL)						
1-M06	1800	ENGINE ELECTRICAL SYSTEM						
1-C07	1830	ALTERNATOR						
1-E07	1840	STARTER						
1-G07	1850	BATTERY						
1-H07	1910	TORQUE CONVERTER, OIL PUMP & PIPINGS (AUTOMATIC)						
1-K07	1920	TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)						
1-E08	1925	CONTROL VALVE (AUTOMATIC)						
1-I08	1930	CLUTCHES & PLANETARY GEARS (AUTOMATIC)						
1-D09	1940	GOVERNOR, LOW & REVERSE PISTON (AUTOMATIC)						
1-G09	1950	MANUAL LINKAGE SYSTEM (AUTOMATIC)						
1-I09	1960	GASKET & SEAL KIT (AUTOMATIC)						

## SECTION NAME INDEX (CHASSIS)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
1-C11	2505	REAR PROPELLER SHAFT	1-J16	4400	PARKING BRAKE SYSTEM			
1-D11	2550	REAR DRIVE SHAFT	1-L16	4500	FUEL PIPINGS			
1-E11	2600	REAR AXLE	2-C03	4600	CHANGE CONTROL SYSTEM (AT)			
1-F11	2610	REAR BRAKE MECHANISMS						
1-H11	2710	REAR DIFFERENTIALS (NORMAL DIFF.)						
1-L11	2710 A	REAR DIFFERENTIALS (LIMITED SLIP DIFF.)						
1-D12	2800	REAR SUSPENSION MECHANISMS						
1-E12	2801	REAR SPRING & DAMPER						
1-F12	2810	REAR STABILIZER						
1-G12	2830	REAR LOWER ARMS & SUB FRAME						
1-I12	3200	STEERING WHEEL						
1-L12	3210	STEERING COLUMN & SHAFTS						
1-M12	3220	STEERING GEAR (W/O POWER STEERING)						
1-C13	3220 A	STEERING GEAR (W/ POWER STEERING)						
1-F13	3240	POWER STEERING SYSTEM						
1-H13	3300	FRONT AXLE						
1-I13	3310	FRONT BRAKE MECHANISMS						
1-K13	3400	FRONT SUSPENSION MECHANISMS						
1-M13	3401	FRONT SPRING & DAMPER						
1-N13	3410	CROSSMEMBER & STABILIZER						
1-C14	3700	TIRES & JACK						
1-C15	3900	ENGINE & T/MISSION MOUNTINGS						
1-D15	4000	EXHAUST SYSTEM						
1-F15	4140	CLUTCH RELEASE & MASTER CYLINDERS (MANUAL TRANSMISSION)						
1-G15	4145	CLUTCH PIPINGS (MANUAL TRANSMISSION)						
1-H15	4160	ACCELERATOR CONTROL SYSTEM						
1-I15	4200	FUEL TANK						
1-M15	4300	CLUTCH & BRAKE PEDALS (MANUAL TRANSMISSION)						
1-D16	4300A	BRAKE PEDALS (AUTOMATIC TRANSMISSION)						
1-F16	4340	BRAKE MASTER CYLINDER & POWER BRAKE						
1-H16	4360	BRAKE PIPINGS						


## SECTION NAME INDEX (BODY)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
2-C05	0900	KEY SETS	2-E12	6115	HEATER CONTROLS COMPONENTS	3-C03	7900	ACCESSORIES
2-E05	5000	FRONT BUMPER	2-F12	6120	HEATER BLOWER COMPONENTS			
2-H05	5010	REAR BUMPER	2-G12	6130	AIR CONDITIONER			
2-J05	5030	WINDOW MOULDING & COWL GRILLES	2-K12	6135	O RING SET,PIPING			
2-L05	5100	HEAD LAMPS	2-L12	6140	COMPRESSOR COMPONENTS (AIR CON DITIONER)			
2-M05	5103	HEAD LAMP RETRACTORS	2-N12	6150	COOLING UNIT (AIR CONDITIONER)			
2-D06	5105	FRONT COMBINATION LAMPS	2-C13	6300	WINDOW GLASSES			
2-F06	5110	REAR COMBINATION LAMPS	2-D13	6330	SUNROOF			
2-I06	5120	LICENSE LAMPS	2-M13	6600	SWITCHES & RELAYS (ENGINE)			
2-J06	5180	REAR FINISHER	2-D14	6610	DASHBOARD SWITCHES			
2-L06	5230	BONNET	2-E14	6611	COMBINATION SWITCH			
2-N06	5260	TRUNK LID	2-F14	6630	RELAYS & UNIT (BODY)			
2-D07	5310	BODY PANELS (FRONT)	2-G14	6635	DOOR SWITCH & HORNS			
2-E07	5320	BODY PANELS (FENDER & WHEEL AP RON)	2-H14	6640	AUTO CRUISE CONTROL SYSTEM			
2-H07	5330	BODY PANELS (DASH & COWL PANEL )	2-I14	6680	AUDIO SYSTEMS (RADIO & TAPE DE CK)			
2-I07	5340	BODY PANELS (SIDE)	2-K14	6682	AUDIO SYSTEMS (ANTENNA & SPEAK ER)			
2-C08	5370	BODY PANELS (FLOOR)	2-L14	6700	WIRING HARNESSSES(FRONT & REAR )			
2-F08	5380	FLOOR ATTACHMENTS (HOLE COVERS )	2-N14	6701	WIRING HARNESSSES(ENGINE & T/MI SSION)			
2-G08	5390	FLOOR ATTACHMENTS	2-D15	6702	WIRING HARNESSSES(DASHBOARD)			
2-C09	5500	DASHBOARD EQUIPMENTS	2-E15	6703	WIRING HARNESSSES(DOOR,FLOOR/CE ILING)			
2-E09	5520	METER HOOD	2-F15	6704	WIRING HARNESS CLAMPS			
2-F09	5530	SPEEDOMETER CABLE	2-I15	6720	WINDSHIELD WASHER			
2-G09	5540	METER COMPONENTS	2-K15	6730	WINDSHIELD WIPERS			
2-I09	5560	DASHBOARD & RELATED PARTS	2-M15	6740	WIPER MOTOR COMPONENTS(FRONT)			
2-L09	5570	CONSOLE	2-N15	6820	FRONT HEADER TRIM & PILLAR TRI MS			
2-C10	5580	VENTILATOR	2-C16	6840	TRIMS & SCUFF PLATES			
2-D10	5700	SEATS	2-E16	6860	FLOOR MATS & PADS			
2-K10	5790	SEAT BELTS	2-G16	6870	SERVICE TOOLS			
2-L10	5800	FRONT DOORS	2-H16	6900	VISORS,ASSIST HANDLES & MIRROR S			
2-C11	5830	FRONT DOOR MECHANISMS	2-J16	6930	CAUTION PLATES & LABELS			
2-F11	5840	FRONT DOOR TRIMS & RELATED PAR TS	2-L16	7250	QUARTER WINDOW & TRIMS			
2-C12	6100	HEATER						
2-D12	6110	HEATER UNIT COMPONENTS						

## SECTION NAME INDEX (CHASSIS)


LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
1-C11	2505	REAR PROPELLER SHAFT	1-J16	4400	PARKING BRAKE SYSTEM			
1-D11	2550	REAR DRIVE SHAFT	1-L16	4500	FUEL PIPINGS			
1-E11	2600	REAR AXLE	2-C03	4600	CHANGE CONTROL SYSTEM (AT)			
1-F11	2610	REAR BRAKE MECHANISMS						
1-H11	2710	REAR DIFFERENTIALS (NORMAL DIFF.)						
1-L11	2710 A	REAR DIFFERENTIALS (LIMITED SLIP DIFF.)						
1-D12	2800	REAR SUSPENSION MECHANISMS						
1-E12	2801	REAR SPRING & DAMPER						
1-F12	2810	REAR STABILIZER						
1-G12	2830	REAR LOWER ARMS & SUB FRAME						
1-I12	3200	STEERING WHEEL						
1-L12	3210	STEERING COLUMN & SHAFTS						
1-M12	3220	STEERING GEAR (W/O POWER STEERING)						
1-C13	3220 A	STEERING GEAR (W/ POWER STEERING)						
1-F13	3240	POWER STEERING SYSTEM						
1-H13	3300	FRONT AXLE						
1-I13	3310	FRONT BRAKE MECHANISMS						
1-K13	3400	FRONT SUSPENSION MECHANISMS						
1-M13	3401	FRONT SPRING & DAMPER						
1-N13	3410	CROSSMEMBER & STABILIZER						
1-C14	3700	TIRES & JACK						
1-C15	3900	ENGINE & T/MISSION MOUNTINGS						
1-D15	4000	EXHAUST SYSTEM						
1-F15	4140	CLUTCH RELEASE & MASTER CYLINDERS (MANUAL TRANSMISSION)						
1-G15	4145	CLUTCH PIPINGS (MANUAL TRANSMISSION)						
1-H15	4160	ACCELERATOR CONTROL SYSTEM						
1-I15	4200	FUEL TANK						
1-M15	4300	CLUTCH & BRAKE PEDALS (MANUAL TRANSMISSION)						
1-D16	4300A	BRAKE PEDALS (AUTOMATIC TRANSMISSION)						
1-F16	4340	BRAKE MASTER CYLINDER & POWER BRAKE						
1-H16	4360	BRAKE PIPINGS						





PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
43-152		PIN, SNAP			
D001-43-152	1				
FB02-43-152A	1				
46-AT0		ACTUATOR, SHIFT LOCK			
NA03-46-AT0A	1				
46-AT1		TAG, CAUTION-CHANGE			
GN52-46-AT1B	1				
46-AT8		SCREW			
H338-46-AT8	2				
46-AT9		NUT			
H338-46-AT9	2				
46-010		LEVER, SELECT			
NA03-46-100C A (NA03-46-100E)	1				-0402
NA03-46-100E	1				0402-
46-027		CAM, CHANGE LEVER			
H338-46-027	1				
46-030		KNOB, CHANGE LEVER			
NA03-46-030A A (NA03-46-030B)	1				-0110
NA03-46-030B	1				0110-
46-040		SWITCH, OVER DRIVE CONTROL			
NA03-46-040A A (NA03-46-040B)	1				-0110
NA03-46-040B	1				0110-
46-058		SCREW, CHANGE LEVER KNOB			
FB02-46-058C	2				
46-082C		COVER, SELECT LEVER			
NA03-46-088	1				
46-300		CABLE, INTER LOCK			

0110 NA35MM-133859  
0402 NA35MM-146561



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
NA03-46-300A AN(NA03-46-300B)	1				-0101
NA03-46-300B	1				0101-
46-302		CLIP			
NA03-46-302	1				-0501
NA16-46-302	1				0501-
46-570A		ROD, SELECTOR-REAR			
NA03-46-570	1				
46-684		BUSH			
1015-46-684A	1				
55-280A		BULB & SOCKET			
NA03-55-280A	1				
64-340A		INDICATOR			
NA03-64-350B A (NA03-64-350C)	1				-0110
NA03-64-350C	1				0110-

0101 NA35MM-133591  
0110 NA35MM-133859  
0501 NA35MM-150679

**CHASSIS**


**BODY**

**CHASSIS**

**BODY**

**CHASSIS**

**BODY**



**CHASSIS**



**BODY**

**CHASSIS**

**BODY**

**CHASSIS**

**BODY**



**CHASSIS**

**BODY**

**CHASSIS**

**BODY**

**CHASSIS**

**BODY**

**CHASSIS**

**BODY**



**CHASSIS**

**BODY**



**CHASSIS**



**BODY**


**CHASSIS**

**BODY**

## SECTION NAME INDEX (BODY)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
2-C05	0900	KEY SETS	2-E12	6115	HEATER CONTROLS COMPONENTS	3-C03	7900	ACCESSORIES
2-E05	5000	FRONT BUMPER	2-F12	6120	HEATER BLOWER COMPONENTS			
2-H05	5010	REAR BUMPER	2-G12	6130	AIR CONDITIONER			
2-J05	5030	WINDOW MOULDING & COWL GRILLES	2-K12	6135	O RING SET, PIPING			
2-L05	5100	HEAD LAMPS	2-N12	6140	COMPRESSOR COMPONENTS (AIR CONDITIONER)			
2-M05	5103	HEAD LAMP RETRACTORS	2-N12	6150	COOLING UNIT (AIR CONDITIONER)			
2-D06	5105	FRONT COMBINATION LAMPS	2-C13	6300	WINDOW GLASSES			
2-F06	5110	REAR COMBINATION LAMPS	2-D13	6330	SUNROOF			
2-I06	5120	LICENSE LAMPS	2-M13	6600	SWITCHES & RELAYS (ENGINE)			
2-J06	5180	REAR FINISHER	2-D14	6610	DASHBOARD SWITCHES			
2-L06	5230	BONNET	2-E14	6611	COMBINATION SWITCH			
2-N06	5260	TRUNK LID	2-F14	6630	RELAYS & UNIT (BODY)			
2-D07	5310	BODY PANELS (FRONT)	2-G14	6635	DOOR SWITCH & HORNS			
2-E07	5320	BODY PANELS (FENDER & WHEEL ARCH)	2-H14	6640	AUTO CRUISE CONTROL SYSTEM			
2-H07	5330	BODY PANELS (DASH & COWL PANEL)	2-I14	6680	AUDIO SYSTEMS (RADIO & TAPE DECK)			
2-I07	5340	BODY PANELS (SIDE)	2-K14	6682	AUDIO SYSTEMS (ANTENNA & SPEAKER)			
2-C08	5370	BODY PANELS (FLOOR)	2-L14	6700	WIRING HARNESSSES (FRONT & REAR)			
2-F08	5380	FLOOR ATTACHMENTS (HOLE COVERS)	2-N14	6701	WIRING HARNESSSES (ENGINE & TRANSMISSION)			
2-G08	5390	FLOOR ATTACHMENTS	2-C15	6702	WIRING HARNESSSES (DASHBOARD)			
2-C09	5500	DASHBOARD EQUIPMENTS	2-E15	6703	WIRING HARNESSSES (DOOR, FLOOR/CEILING)			
2-E09	5520	METER HOOD	2-F15	6704	WIRING HARNESS CLAMPS			
2-F09	5530	SPEEDOMETER CABLE	2-I15	6720	WINDSHIELD WASHER			
2-G09	5540	METER COMPONENTS	2-K15	6730	WINDSHIELD WIPERS			
2-I09	5560	DASHBOARD & RELATED PARTS	2-M15	6740	WIPER MOTOR COMPONENTS (FRONT)			
2-L09	5570	CONSOLE	2-N15	6820	FRONT HEADER TRIM & PILLAR TRIMS			
2-C10	5580	VENTILATOR	2-C16	6840	TRIMS & SCUFF PLATES			
2-D10	5700	SEATS	2-E16	6860	FLOOR MATS & PADS			
2-K10	5790	SEAT BELTS	2-G16	6870	SERVICE TOOLS			
2-L10	5800	FRONT DOORS	2-H16	6900	VISORS, ASSIST HANDLES & MIRRORS			
2-C11	5830	FRONT DOOR MECHANISMS	2-J16	6930	CAUTION PLATES & LABELS			
2-F11	5840	FRONT DOOR TRIMS & RELATED PARTS	2-L16	7250	QUARTER WINDOW & TRIMS			
2-C12	6100	HEATER						
2-D12	6110	HEATER UNIT COMPONENTS						






PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
09-010		KEY SET			
NA01-09-010B AN(NA01-09-010C)	1				-0201
00		NA0 BLACK			
NA03-09-010 AN(NA03-09-010A)	1				-0201
00		NA0 BLACK			
NA01-09-010C	1	(MT)			0201-
00		NA0 NA1 BLACK			
NA03-09-010A	1	(AT)			0201-
00		NA0 NA1 BLACK			
58-315D		CLIP (R)			
G030-58-315	2				
58-492		KEY, PRIMARY			
BR75-58-492	2	KEY NO. IS REQUIRED			
58-492A		KEY, SECONDARY			
LA02-58-493	1	KEY NO. IS REQUIRED			
59-315		CLIP			
G030-59-315	1				
60-436		BOLT, SET			
H043-66-154	2				
66-155		SWITCH, IGNITION			
D001-66-151	1				
75-158		KEY, BLANK			
LA02-76-202	1				
75-910		KEY SUB SET(R), DOOR			
NA01-76-210	1				
75-920		KEY SUB SET(L), DOOR			
NA01-76-220	1				

0201 NA35MM-137180

0900 KEY SETS

0900 -2 M KEY SETS




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
75-930 NA01-76-230	1	KEY SUB SET, TRUNK			
75-950 NA01-76-250	1	KEY SUB SET, GLOVE			
00		NA0 BLACK			
75-990 NA01-76-290 AN(NA01-76-290A)	1	KEY SUB SET, ST. LOCK			-0201
NA03-76-290 AN(NA03-76-290A)	1				-0201
NA01-76-290A	1	(MT)			0201-
NA03-76-290A	1	(AT)			0201-
76-280 NA01-76-280	1	KEY SUB SET, CONSOL			
00		NA0 NA1 BLACK			
76-201A BR75-76-201 B545-76-201	1	KEY, BLANK-PRIMARY			-9C01
	1				9C01-

9C01 NA35MM-130310  
0201 NA35MM-137180

5000 FRONT BUMPER

5000 -1 FRONT BUMPER




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
33-693A		CAP, BLEEDER SCREW			
0259-33-693	2				
50-A20		GUIDE, AIR			
NA01-50-A20A	1				
50-0G8A		SEAL, RUBBER-FRONT BUMPER			
NA01-50-0G9	2				
50-0J1		RETAINER(R), FRONT BUMPER (AT)			
NA01-50-0J1	1				
50-0J5		RETAINER(L), FRONT BUMPER			
NA01-50-0J5	1				
50-0K0		RETAINER, FASCIA			
NA01-50-0K0B	1				
50-015C		BOLT			
FB01-50-132	2				
50-015D		BOLT			
NA01-50-022	8				
50-030		HOLDER, NO. PLATE			
NA01-50-180 A (NA01-50-180A)	1				-9A01
NA01-50-180A	1				9A01-
50-031		BUMPER, FRONT			
NAY1-50-030	1				
50-036C		FASTEN R			
BF67-50-033	2				
50-036E		CLIP			
KA01-50-1Q2	6				
50-040		REINFORCEMENT, BUMPER			
NA01-50-070	1	(W/AIR BAG)			
NA07-50-070	1	(W/O AIR BAG)			0701-

9A01 NA35\*\*N-122908  
0701 NA35\*\*N-200041

5000 FRONT BUMPER

5000 -2 FRONT BUMPER




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
50-043E		SLIDE 'A', BUMPER			
B092-50-032	2				
50-068		CLIP			
NA01-50-068	6				
50-1AY		PLATE, SET NO.1			
NA01-50-1AYA	1				-9912
NA01-50-1AYB	1				9912-
50-180		PLATE NO.2(R), SET-F. BUMPER			
NA01-50-180	1				
50-180A		PLATE NO.2(L), SET-F. BUMPER			
NA01-50-180	1				
50-1E2		BOLT			
NA01-50-1E2	2				
NA01-50-1E3	4				
50-1ZY		BRACKET, FENDER			
NA01-50-1ZY	2				
50-101A		COVER, GRILLE			
NA01-50-101A	3				
50-114A		SPACER, E.A. FOAM			
NA01-50-114	1				
50-160D		BRACKET(L), F. BUMPER SIDE			
NA01-50-160	2				
50-18X		BRACKET, LICENCE PLATE			
NA01-50-18X	2				
50-180E		PROTECTOR, NO. PLATE			
FB01-50-144	1				
50-2A0		SET PLATE NO.1(R), RR BUMPER			
NA01-50-2A0	1				-9912

9912 NA35MM 20552

5000 FRONT BUMPER


9000 -3 M FRONT BUMPER



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CCNT'D NA01-50-2A0A	1				991<-
50-233C		FASTENER, REAR BUMBER			
BF82-50-233	3				
50-318		TAPE, ENG Y ABS. FORM-R R BUM			
NA01-50-318	2				
50-335		NUT, CLIP			
FB01-50-133	4				
51-711C		ORNAMENT, MAKER NAME-FRONT			
NA04-51-711	1				
14		SU UC DU HU LIGHT GRAY			
18		3L DARK GRAY			
9912 NA35MM-120552					

5010 REAR BUMPER

5010 -1 REAR BUMPER




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
50-0G9A NA01-50-0G8	2	SEAL, RUBBER-REAR BUMPER			
50-032B GJ21-50-032	2	SLIDE 'UP.', BUMPER			
50-036C BF67-50-033	11	FASTENER			
50-2C6 NA01-50-2C6	6	BOLT			
50-2S4 NA01-50-2S4	1	SHILD(R), SPLASH-R. BUMPER			
50-2S4A NA01-50-2S5	1	SHILD(L), SPLASH-R. BUMPER			
50-221 NAY1-50-220 A (NAY1-50-220A)	1	BUMPER, REAR			-9330
50-230 NA01-50-260	1	REINFORCEMENT, BUMPER			9330-
50-233C BF82-50-233	5	FASTENER, REAR BUMPER			0701-
50-260D NA01-50-2J0	1	RETAINER, R. BUMPER			
50-270 NA01-50-280A	1	STAY(R), RR. BUMPER			
50-270Z NA01-50-290A	1	STAY(L), RR. BUMPER			
50-28X NA01-50-28XC	2	PLATE SET			

9330 NA35\*\*-100072  
0701 NA35\*\*-200041

5010 REAR BUMPER


5010 -2 \* REAR BUMPER



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
50-28Y		PLATE SET			
NA01-50-28YC	2				
50-335		NUT, CLIP			
NA01-50-133	6				

5030 WINDOW MOULDING & COWL GRILLES

5030 -1 WINDOW MOULDING & COWL GRILLES



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
50-501A		MOULD(UP), FRT. WINDOW			
NAY1-50-601	1				
50-6B1B		PROTECTOR, MOULD-FRT WIND			
NA01-50-6B1	1				
NA01-50-6B2	2				9421-
50-781		PROTECTOR, COWL GRILL			
NA01-50-792 A (NA01-50-792A)	1				-9701
NA01-50-792A	1				9701-
50-791		GRILLE, COWL			
NA01-50-790A A (NA01-50-790B)	1				-9412
NA01-50-790B A (NA01-50-790C)	1				9412-9701
NA01-50-790C A (NA01-50-790D)	1				9701-9912
NA01-50-790D	1				9912-
50-794		PROTECTOR			
NA01-50-788	1				
50-796B		CAP			
B455-50-796	5				
50-797A		CAP			
NA01-50-797	2				
50-798		SCREW, GROMMET			
NA01-50-798	2				
50-841G		GROMMET, SCREW			
F044-51-912	5				-9412
NA01-51-789	5				9412-
50-854A		PROTECTOR			
NA01-50-794	4				
51-RC6		SCREW, SIDE GARNISH			




9412 NA35\*\*-100416  
 9421 NA35\*\*-101369  
 9701 NA35\*\*-111969  
 9912 NA35\*\*-120552

2-35




5030 WINDOW MOULDING & COWL GRILLES

5030 -2 M WINDOW MOULDING & COWL GRILLES



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CUNT'D H272-51-RC6	2				9418-


9418 NA35MM-100895



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
51-029		GROMMET, SCREW			
0483-66-061A	4				
51-030		LAMP SET(R), HEAD			
8BN1-51-030	1				
51-030Z		LAMP SET(L), HEAD			
8BN1-51-040	1				
51-032A		UNIT, HEAD LAMP			
NA02-51-031	2				
51-039		SCREW			
B481-51-0E3	6				
51-046C		SPRING			
NA01-51-046	2				
66-024		RING, RETAINING			
NA01-51-033	2				
87-014		RING(R) MOUNTING			
NA01-51-032	1				
87-015		RING(L) MOUNTING			
NA01-51-034	1				
87-016		SCREW, ADJUST			
NA01-51-037	4				

5103 HEAD LAMP RETRACTORS

5103 -1 HEAD LAMP RETRACTORS



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
50-744B		GROMMET, SCREW			
B481-50-744	8				
51-SAX		MOTOR(R), RETRACTABLE HEAD			
NA01-51-SAX	1				
51-SA5		ROD, RETRACTABLE			
NA01-51-SA5	2				
51-SA7		BRACKET, CLIP			
NA01-51-SA7	1				
51-SA8		WASHER			
NA01-51-SA8	6				
51-SBX		MOTOR(L), RETRACTABLE HEAD			
NA01-51-SBX	1				
51-SC6		NUT, STOPPER-LAMP HINGE			
KA01-51-SC6	4				
51-SE1		PROTECTOR(R), RETRA H/L			
NA01-51-SE1	1				
51-SE2		PROTECTOR(L), RETRA. H/L			
NA01-51-SE2	1				
51-SJ2		PROTECTOR(L), RETRA. FRONT			
NA01-51-SJ2	2				
51-SJ3		CLIP			
NA01-51-SJ3	6				
51-SK2		PROTECTOR(L), RETRA. SIDE			
NA01-51-SK2	1				
51-S25		BOLT, LAMP LID			
BS34-51-S25A	8				
51-408A		LABEL, COUTION-RETRAL TABLE			
NA04-51-S02	1				




## SECTION NAME INDEX (BODY)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
2-C05	0900	KEY SETS	2-E12	6115	HEATER CONTROLS COMPONENTS	3-C03	7900	ACCESSORIES
2-E05	5000	FRONT BUMPER	2-F12	6120	HEATER BLOWER COMPONENTS			
2-H05	5010	REAR BUMPER	2-G12	6130	AIR CONDITIONER			
2-J05	5030	WINDOW MOULDING & COWL GRILLES	2-K12	6135	O RING SET, PIPING			
2-L05	5100	HEAD LAMPS	2-L12	6140	COMPRESSOR COMPONENTS (AIR CON DITIONER)			
2-M05	5103	HEAD LAMP RETRACTORS	2-N12	6150	COOLING UNIT (AIR CONDITIONER)			
2-D06	5105	FRONT COMBINATION LAMPS	2-C13	6300	WINDOW GLASSES			
2-F06	5110	REAR COMBINATION LAMPS	2-D13	6330	SUNROOF			
2-I06	5120	LICENSE LAMPS	2-M13	6600	SWITCHES & RELAYS (ENGINE)			
2-J06	5180	REAR FINISHER	2-E13	6610	DASHBOARD SWITCHES			
2-L06	5230	BONNET	2-E14	6611	COMBINATION SWITCH			
2-N06	5260	TRUNK LID	2-F14	6630	RELAYS & UNIT (BODY)			
2-D07	5310	BODY PANELS (FRONT)	2-G14	6635	DOOR SWITCH & HORNS			
2-E07	5320	BODY PANELS (FENDER & WHEEL AP RON)	2-H14	6640	AUTO CRUISE CONTROL SYSTEM			
2-H07	5330	BODY PANELS (DASH & COWL PANEL )	2-I14	6680	AUDIO SYSTEMS (RADIO & TAPE DE CK)			
2-I07	5340	BODY PANELS (SIDE)	2-K14	6682	AUDIO SYSTEMS (ANTENNA & SPEAK ER)			
2-C08	5370	BODY PANELS (FLOOR)	2-L14	6700	WIRING HARNESSSES (FRONT & REAR )			
2-F08	5380	FLOOR ATTACHMENTS (HOLE COVERS )	2-N14	6701	WIRING HARNESSSES (ENGINE & T/MI SSION)			
2-G08	5390	FLOOR ATTACHMENTS	2-D15	6702	WIRING HARNESSSES (DASHBOARD)			
2-C09	5500	DASHBOARD EQUIPMENTS	2-E15	6703	WIRING HARNESSSES (DOOR, FLOOR/CE ILING)			
2-E09	5520	METER HOOD	2-F15	6704	WIRING HARNESS CLAMPS			
2-F09	5530	SPEEDOMETER CABLE	2-I15	6720	WINDSHIELD WASHER			
2-G09	5540	METER COMPONENTS	2-K15	6730	WINDSHIELD WIPERS			
2-I09	5560	DASHBOARD & RELATED PARTS	2-M15	6740	WIPER MOTOR COMPONENTS (FRONT)			
2-L09	5570	CONSOLE	2-N15	6820	FRONT HEADER TRIM & PILLAR TRI MS			
2-C10	5580	VENTILATOR	2-C16	6840	TRIMS & SCUFF PLATES			
2-D10	5700	SEATS	2-E16	6860	FLOOR MATS & PADS			
2-K10	5790	SEAT BELTS	2-G16	6870	SERVICE TOOLS			
2-L10	5800	FRONT DOORS	2-H16	6900	VISORS, ASSIST HANDLES & MIRROR S			
2-C11	5830	FRONT DOOR MECHANISMS	2-J16	6930	CAUTION PLATES & LABELS			
2-F11	5840	FRONT DOOR TRIMS & RELATED PAR TS	2-L16	7250	QUARTER WINDOW & TRIMS			
2-C12	6100	HEATER						
2-D12	6110	HEATER UNIT COMPONENTS						


5103 HEAD LAMP RETRACTORS

5103 -3 \* HEAD LAMP RETRACTORS



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
51-610A		BEZEL (R), HEAD LAMP			
NA01-50-741	1				
51-610Y		BEZEL (L), HEAD LAMP			
NA01-50-751	1				
51-611A		SCREW, HEAD LAMP BEZEL			
8481-50-75X	8				
51-665		BOLT, MOTOR-RETRACT H/LAMP			
FB01-51-665	6				
51-669		BOOTS, MOTOR-RETRACT H/L			
NA01-51-669	2				
67-056K		RIVET			
UB39-50-795	8				

5105 FRONT COMBINATION LAMPS




5105 -1 FRONT COMBINATION LAMPS

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
50-803A		NUT, SIDE PROTECTOR			
G158-50-803	8				
51-051		SCREW			
NA01-51-051	2				-0301
51-053		SCREW			
NA01-51-053	2				-0301
51-054		CORD, FRONT COMB.			
NA07-51-054	2 (W/O AIR BAG)				0701-
51-060		LAMP SET(R), FRT COMB			
8BN1-51-060	1 (W/AIR BAG)				
8BN2-51-060	1 (W/O AIR BAG)				0701-
51-060Z		LAMP SET(L), FRT COMB			
8BN1-51-070	1 (W/AIR BAG)				
8BN2-51-070	1 (W/O AIR BAG)				0701-
51-065G		SOCKET, F. COMB. LAMP			
NA01-51-064	2 (W/AIR BAG)				
NA07-51-064	2 (W/O AIR BAG)				0701-
51-069A		TUBE, HEAD LAMP			
NA01-51-069	2				
51-080		LENS & HOUSING(R)			
NA01-51-06X A (NA01-51-06XA)	1				-9601
NA01-51-06XA	1				9601-
51-080Z		LENS & HOUSING(L)			
NA01-51-07X A (NA01-51-07XA)	1				-9601
NA01-51-07XA	1				9601-
51-110J		BULB			
99701-6038	2	12V 3.8W			
9601 NA35**-106797 0301 NA35**-141901 0701 NA35**-200041					

5105 FRONT COMBINATION LAMPS

5105 -2 W FRONT COMBINATION LAMPS




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
51-120B		LAMP SET(R),SIDE TUR			
8BN1-51-120	1				
51-120X		LAMP SET(L),SIDE TUR			
8BN1-51-130	1				
51-121		LENS & BODY(R)			
NA01-51-5E1B A (NA01-51-5E1C)	1				-9401
NA01-51-5E1C	1				9401-9901
NA01-51-5EX	1				9901-
51-121Z		LENS & BODY(L)			
NA01-51-5F1B A (NA01-51-5F1C)	1				-9401
NA01-51-5F1C	1				9401-9901
NA01-51-5FX	1				9901-
51-123		GASKET,SIDE TURN			
NA01-51-5D3	2				9901-
51-124A		SOCKET,SIDE TURN			
NA01-51-5E2	2				
51-150K		BULB			
99701-4278Y	2	A12V 27/8W			

9401 NA35MM-100090  
9901 NA35MM-119257



5110 REAR COMBINATION LAMPS

5110 -1 REAR COMBINATION LAMPS



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
50-803A		NUT, SIDE PROTECTOR			
G158-50-803	4				
51-060G		BULB			
99701-4278	2	12V 27W/8W			
51-064J		SCREW, TAPPING			
NA01-51-1E6	2				
51-070K		BULB			
99700-7180	1	A12V 18.4W			
99701-3270	4	12V 27W			
51-110J		BULB			
99701-6038	2	12V 3.8W			
51-124A		SOCKET, SIDE TURN			
BJ38-51-584	1				
51-150		LAMP SET(R), RR. COMB.			
8RN1-51-150	1				
51-150Z		LAMP SET(L), RR. COMB.			
8BN1-51-160	1				
51-153A		SOCKET(R), RR. COMB.			
N001-51-155A	1				
51-153Y		SOCKET(L), RR. COMB.			
N001-51-165A	1				
51-159		PROTECTOR(R), 'A'			
NA01-51-159	1				
51-161		LENS(R), RR. COMB.			
NA01-51-15XB	1				
51-161A		LENS & BODY(R), RR CO MB.			


AUNA01

CAT. AUNA01-07

1992-02

5110 REAR COMBINATION LAMPS

5110 -2 REAR COMBINATION LAMPS




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
NA01-51-170B	1				
51-161Y		LENS & BODY(L),RR CO MB.			
NA01-51-180B	1				
51-161Z		LENS(L),RR.COMB.			
NA01-51-16XB	1				
51-164A		GASKET,RR.COMB.			
NA01-51-158	2				
51-169A		PROTECTOR(L),'A'			
NA01-51-169	1				
51-172B		CAP			
G030-51-172	3				
51-173B		PROTECTOR(R),'B'			
NA01-51-173	1				
51-183C		PROTECTOR(L),'B'			
NA01-51-183	1				
51-599		CLIP			
NA01-51-599	8				
51-5H1		LENS & BODY(R),RR SI DE TURN			-9401
NA01-51-5H1A A (NA01-51-5H1B)	1				
NA01-51-5H1B	1				9401-
51-5H2		SOCKET(R),RR SIDE TU RN			
NA01-51-5H2A	1				
51-5J1A		LENS & BODY(L),RR SI DE TURN			-9401
NA01-51-5J1A A (NA01-51-5J1B)	1				
NA01-51-5J1B	1				9401-
51-5J2		SOCKET(L),RR SIDE TU RN			
NA01-51-5J2A	1				

9401 NA35MH-100090

5110 REAR COMBINATION LAMPS


5110 -3 M REAR COMBINATION LAMPS




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
51-550B	1	LAMP SET(R),SIDE TUR N-RR			
8BN1-51-550					
51-550C	1	LAMP SET(L),SIDE TUR N-RR			
8BN1-51-560					
51-580	1	LAMP,STOP-HI.MOUNT.			
NA01-51-580B					
51-582	1	GASKET,STOP LAMP-HI.MOUNT			
NA01-51-592B					
51-583	1	LENS,STOP LAMP-HI.MOUNT			
NA01-51-58XA					
51-599	1	FASTENER,STOP LAMP-HI.			
NA01-51-599					

5120 LICENSE LAMPS


5120 -1 M LICENSE LAMPS



51-270




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
51-270		LAMP, LICENSE			
8BF1-51-270	2				
51-270J		BULB			
99701-2070	2	12V 7.5W			
51-273G		GASKET, LICENSE LAMP			
FB67-51-273	2				
51-276		SHADE, LAMP-LICENSE			
FB67-51-276	2				
51-276G		SOCKET, LICENSE LAMP			
FB67-51-272	2				




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
50-742C		CLIP			
G043-50-742	3				
50-753A		FASTENER			
G043-50-753	4				
50-786C		GASKET			
G030-50-786	2				
50-850		FINISHER, REAR			
NA01-50-850A A (NA01-50-850C)	1				-9901
DU		DU MARINER BLUE			
SU		SU CLASSIC RED			
UC		UC CRYSTAL WHITE			
3L		3L SILVER STONE METALLIC			
NA01-50-850C A (NA01-50-850D)	1				9901-9914
DU		DU MARINER BLUE			
SU		SU CLASSIC RED			
UC		UC CRYSTAL WHITE			
3L		3L SILVER STONE METALLIC			
NA01-50-850D	1				9914-
DU		DU MARINER BLUE			
HU		HU NED GREEN			
SU		SU CLASSIC RED			
UC		UC CRYSTAL WHITE			
3L		3L SILVER STONE METALLIC			
DU		SILVER STONE METALLIC			
HU		SILVER STONE METALLIC			
SU		SILVER STONE METALLIC			
UC		SILVER STONE METALLIC			
3L		SILVER STONE METALLIC			
50-852F		REINFORCEMENT			
NA01-50-852	1				

9901 NA35MM-119257  
9914 NA35MM-120856




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
50-853E LA01-50-853	4	BOLT, GARNISH-RR			
50-850B B388-50-855	4	GASKET, REAR FINISHER			
51-711B NA01-51-711	1	ORNAMENT, MAKER NAME-REAR			
51-781 NA01-51-721	1	ORNAMENT, REAR			




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
45-919A		HOLDER, PIPE			
H115-45-916A	1				
52-310		BONNET			
NAY1-52-310 A (NAY1-52-310A)	1				-9406
NAY1-52-310A	1				9406-
52-410		HINGE (R), BONNET			
NA01-52-410A	1				
52-460		HINGE (L), BONNET			
NA01-52-420A	1				
52-510		STAY, BONNET			
NA01-56-650	1				
52-514		HOLDER, ROD			
G030-56-693	1				
56-620		LOCK, BONNET			
NA01-56-620A	1				
56-631		FASTENER, BONNET RELEASE			
LA01-56-631	1				
56-710		WIRE, RELEASE-BONNET			
NA01-56-720A A (NA01-56-720B)	1				-9601
NA01-56-720B AN (NA01-56-720C)	1				9601-9C01
NA01-56-720C	1				9C01-
56-786		RUBBER (C), CUSHION-BONNET			
NA01-56-787	2				
56-787B		RUBBER, CUSHION-BONNET FRT			
FB01-56-787A	2				
56-788		RUBBER, CUSHION-BONNET RR			
NA01-56-78X	2				

9406 NA35MM-100142  
 9601 NA35MM-106797  
 9C01 NA35MM-130310



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
56-795B NA01-56-760	1	WEATHERSTRIP, BONNET-REAR			
67-519 G030-67-519	1	CLIP, PIPE			
76-403E B092-52-518	1	HOLDER, ROD			






PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
43-095		GROMMET			
H001-43-095	2				-9516
52-610		LID, TRUNK			
NAY1-52-610	1				
52-710		HINGE(R), TRUNK LID			
NA01-52-710 AN(NA01-52-710A)	1				-9901
NA01-52-710A	1				9901-
52-720		HINGE(L), TRUNK LID			
NA01-52-720 AN(NA01-52-720A)	1				-9901
NA01-52-720A	1				9901-
52-761		SPRING(R), BALANCE			
NA01-52-791A	1				
52-771		SPRING(L), BALANCE			
NA01-52-792A	1				
56-615M		PLUG, DRAIN			
NA01-56-051	2				9516-
56-786A		RUBBER, CUSHION			
NA01-56-784	2				-9A04
B481-56-786	2				9A04-
56-801		CUSHION, LID HINGE			
NA01-56-802	2				-9C01
NA01-56-803	2				9C01-
56-805A		HOLDER, BALANCE SPRING			
NA01-56-805	1				
56-820		LOCK, LID			
NA01-56-820 A (NA01-56-820A)	1				-9901
NA01-56-820A	1				9901-

9516 NA35MM-103924  
 9901 NA35MM-119257  
 9A04 NA35MM-123222  
 9C01 NA35MM-130310

## SECTION NAME INDEX (BODY)


LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
2-C05	0900	KEY SETS	2-E12	6115	HEATER CONTROLS COMPONENTS	3-C03	7900	ACCESSORIES
2-E05	5000	FRONT BUMPER	2-F12	6120	HEATER BLOWER COMPONENTS			
2-H05	5010	REAR BUMPER	2-G12	6130	AIR CONDITIONER			
2-J05	5030	WINDOW MOULDING & COWL GRILLES	2-K12	6135	O RING SET, PIPING			
2-L05	5100	HEAD LAMPS	2-L12	6140	COMPRESSOR COMPONENTS (AIR CON DITIONE?)			
2-M05	5103	HEAD LAMP RETRACTORS	2-N12	6150	COOLING UNIT (AIR CONDITIONER)			
2-D06	5105	FRONT COMBINATION LAMPS	2-C13	6300	WINDOW GLASSES			
2-F06	5110	REAR COMBINATION LAMPS	2-D13	6330	SUNROOF			
2-I06	5120	LICENSE LAMPS	2-M13	6600	SWITCHES & RELAYS (ENGINE)			
2-J06	5180	REAR FINISHER	2-D14	6610	DASHBOARD SWITCHES			
2-L06	5230	BONNET	2-E14	6611	COMBINATION SWITCH			
2-N06	5260	TRUNK LID	2-F14	6630	RELAYS & UNIT (BODY)			
2-D07	5310	BODY PANELS (FRONT)	2-G14	6635	DOOR SWITCH & HORNS			
2-E07	5320	BODY PANELS (FENDER & WHEEL AP RON)	2-H14	6640	AUTO CRUISE CONTROL SYSTEM			
2-H07	5330	BODY PANELS (DASH & COWL PANEL )	2-K14	6680	AUDIO SYSTEMS (RADIO & TAPE DE CK)			
2-I07	5340	BODY PANELS (SIDE)	2-L14	6700	AUDIO SYSTEMS (ANTENNA & SPEAK ER)			
2-C08	5370	BODY PANELS (FLOOR)	2-N14	6701	WIRING HARNESSSES (FRONT & REAR )			
2-F08	5380	FLOOR ATTACHMENTS (HOLE COVERS )	2-D15	6702	WIRING HARNESSSES (ENGINE & T/MI SSION)			
2-G08	5390	FLOOR ATTACHMENTS	2-E15	6703	WIRING HARNESSSES (DASHBOARD)			
2-C09	5500	DASHBOARD EQUIPMENTS	2-F15	6704	WIRING HARNESSSES (DOOR, FLOOR/CE ILING)			
2-E09	5520	METER HOOD	2-I15	6720	WIRING HARNESS CLAMPS			
2-F09	5530	SPEEDOMETER CABLE	2-K15	6730	WINDSHIELD WASHER			
2-G09	5540	METER COMPONENTS	2-M15	6740	WINDSHIELD WIPERS			
2-I09	5560	DASHBOARD & RELATED PARTS	2-N15	6820	WIPER MOTOR COMPONENTS (FRONT)			
2-L09	5570	CONSOLE	2-C16	6840	FRONT HEADER TRIM & PILLAR TRI MS			
2-C10	5580	VENTILATOR	2-E16	6860	TRIMS & SCUFF PLATES			
2-D10	5700	SEATS	2-G16	6870	FLOOR MATS & P/JS			
2-K10	5790	SEAT BELTS	2-H16	6900	SERVICE TOOLS			
2-L10	5800	FRONT DOORS	2-J16	6930	VISORS, ASSIST HANDLES & MIRROR S			
2-C11	5830	FRONT DOOR MECHANISMS	2-L16	7250	CAUTION PLATES & LABELS			
2-F11	5840	FRONT DOOR TRIMS & RELATED PAR TS			QUARTER WINDOW & TRIMS			
2-C12	6100	HEATER						
2-D12	6110	HEATER UNIT COMPONENTS						



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
56-880 NA01-56-840	1	STRIKER, LID			
56-991E NA01-56-951	1	WEATHERSTRIP, LID			
59-315 0030-59-315	1	CLIP			



5310 BODY PANELS (FRONT)

5310 -1 \* BODY PANELS (FRONT)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
15-240C B61P-15-240	1	BRACKET(R), RADIATOR			
15-250A B61P-15-250	1	BRACKET(L), RADIATOR			
53-100 NA01-53-100B G (NA01-53-100D)	1	PANEL, RAD. SHROUD			-9501
NA01-53-100D AN(NA01-53-100E)	1				9501-9B01
NA01-53-100E A (NA01-53-100F)	1				9801-0401
NA01-53-100F	1				0401-
53-160B NA01-53-16XA AN(NA01-53-16XB)	1	MEMBER, CROSS			-9701
NA01-53-16XB A (NA01-53-16XC)	1				9701-0701
NA01-53-16XC	1				0701-
53-210A NA01-54-180	2	BRACKET, BUMPER			
56-220A NA01-56-221A AN(NA01-56-221B)	1	STAY, LOCK-BONNET			-9601
NA01-56-221B	1				9601-
<p>9501 NA35MM-102613                      9601 NA35MM-106797                      9701 NA35MM-111969                      9801 NA35MM-126490                      0401 NA35MM-146561                      0701 NA35MM-200041</p>					

5320 BODY PANELS (FENDER & WHEEL APRON)





5320 -1 BODY PANELS (FENDER & WHEEL APRON)

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
28-89XA		BOLT, CROSS MEMBER			
GJ21-28-89X	6				
52-110		PANEL (R), FENDER-FRT.			
NAY1-52-110	1				
52-210		PANEL (L), FENDER-FRT.			
NAY1-52-210	1				
52-841A		NUT, CLIP			
LA01-56-135	10				
53-210		PANEL (R), WHEEL APRON			
NAY1-53-200 AN (NAY1-53-200A)	1				-0601
NAY1-53-200A C (NAY1-53-200B)	1				0601-0701
NAY1-53-200B	1				0701-
53-210B		PANEL (R), WHEEL APRON			
NA01-53-210A C (NA01-53-210B)	1				-0701
NA01-53-210B	1				0701-
53-210X		PANEL (L), WHEEL APRON			
NA01-54-210A C (NA01-54-210B)	1				-0701
NA01-54-210B	1				0701-
53-27X		BRKT, AIR CLNR-WHL AP RON			
NA01-54-36X	1				
53-330A		BRACKET (R), STABILIZE R			
NA01-53-330	1				
53-37Y		FRAME (UP., R), FRONT-F RT			
NA01-53-37Y	1				
53-37Z		FRAME (UP. R), FRONT-RE AR			
NA01-53-37Z	1				-0701
NA01-53-37ZA	1				0701-
NAY1-53-200A C NAY1-53-200B 8001-56-051		8001-56-051 90786-0616	1 1	0601 NA35MM-154752 0701 NA35MM-200041	
NA01-53-210A NA01-53-210B 8001-56-051	1				
NA01-54-210A C NA01-54-210B					



5320 BODY PANELS (FENDER & WHEEL APRON)

5320 -2 BODY PANELS (FENDER & WHEEL APRON)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
53-380		REINFORCEMENT(R)			
NA01-53-380	1				
53-391		BOX(R), TORQUE			
NA01-53-391	1				
53-59X		REINF.(R), WHEEL APRON			
NA01-53-591	1				
53-59XZ		REINF.(L), WHEEL APRON			
NA01-54-590	1				
53-883		REINF.(R), TIE DOWN HOOK			
NA01-53-32YA AN(NA01-53-32XB)	1				-9701
NA01-53-32XB	1				9701-
54-210		PANEL(L), WHEEL APRON			
NAY1-54-200 AN(NAY1-54-200A)	1				-0601
NAY1-54-200A C(NAY1-54-200B)	1				0601-0701
NAY1-54-200B	1				0701-
54-330A		BRACKET(L), STABILIZER			
NA01-54-330	1				
54-37Y		FRAME(UP.,L), FRONT-FRONT			
NA01-54-37Y	1				
54-37Z		FRAME(UP.L), FRONT-REAR			
NA01-54-37ZA	1				
54-380		FRAME(L), FRONT-REAR			
NA01-54-380	1				
54-391		BOX(L), TORQUE			
NA01-54-391	1				
54-883		REINF.(L), TIE DOWN HOOK			
NA01-54-32XA AN(NA01-54-32XB)	1				-9701
NAY1-54-200A C NAY1-54-200B 8001-56-051 90786-0616			9701 NA35MM-111969 0601 NA35MM-154752 0701 NA35MM-200041		

5320 BODY PANELS (FENDER & WHEEL APRON)




5320 -3 M BODY PANELS (FENDER & WHEEL APRON)

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
NA01-54-32XB A (NA01-54-32XC)	1				9701-0601
NA01-54-32XC	1				0601-
56-130		GUARD(R),MUD			
NA01-56-131A	1				
56-140A		GUARD(L),MUD			
NA01-56-141A A (NA01-56-141C)	1				-0703
NA01-56-141C	1				0703-
56-149		SCREW,TAPPING-MUD GUARD			
8455-56-149	10				-9C20
56-340A		HOOK(R),TIE DOWN-FRONT			
NA01-56-34XA AN(NA01-56-34XC)	1				-9621
NA01-56-34XC	1				9621-
56-360		HOOK(L),TIE DOWN-FRONT			
NA01-56-34YA AN(NA01-56-34YC)	1				-9621
NA01-56-34YC	1				9621-
69-885D		FASTENER			
NA01-56-145	10				
9621	NA35**	-110426			
9701	NA35**	-111969			
9C20	NA35**	-132500			
0601	NA35**	-154752			
0703	NA35**	-200041			
	NA35**	-200204			

5330 BODY PANELS (DASH & COWL PANEL)

5330 -1 \* BODY PANELS (DASH & COWL PANEL)





PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
50-841G		GROMMET, SCREW			
F044-51-912	1				
53-400		PANEL, DASH-LOWER			
NA01-54-400B A (NA01-54-400D)	1				-9401
NA01-54-400D AN (NA01-54-400E)	1				9401-9601
NA01-54-400E (NA01-54-400G)	1				9601-9801
NA01-54-400G	1				9801-
53-510		PANEL, DASH-UPPER			
NA01-53-510 AN (NA01-53-510A)	1				-9413
NA01-53-510A A (NA01-53-510D)	1				9413-9701
NA01-53-510D	1				9701-
54-480		JUNCTION, DASH SIDE-S .SILL			
NA01-54-480	2				
56-355		GROMMET, SCREW-BAFFLE			
G211-96-355A	4				
56-511A		COVER, BAFFLE-COWL PA NEL			
NA01-56-351	1				
56-724		CLIP 'B', WIRE-BONNET			
H260-56-724	1				
68-865		FASTENER			
8040-68-865A	2				
00		NA0 BLACK			
70-620A		PANEL, COWL-FRONT			
NA01-70-62YA	1				-0701
NA01-70-62YB	1				0701-

9401 NA35\*\*-100090  
 9413 NA35\*\*-100500  
 9601 NA35\*\*-106797  
 9701 NA35\*\*-111969  
 9801 NA35\*\*-116316  
 0701 NA35\*\*-200041



5340 BODY PANELS (SIDE)





5340 -1 BODY PANELS (SIDE)

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
53-314A		BRACKET(R), INST.			
NA01-70-071 G (NA01-70-071A)	1				-9901
NA01-70-071A	1				9901-
53-960B		SILL(FRT.R), SIDE-INNER			
NA01-53-960A A (NA01-53-960B)	1				-0101
NA01-53-960B	1				0101-
53-980B		SILL(RR.R), SIDE-INNER			
NA01-53-980 G (NA01-53-980B)	1				-9801
NA01-53-980B	1				9801-
54-314A		BRACKET(L), INST.			
NA01-71-071 G (NA01-71-071A)	1				-9901
NA01-71-071A	1				9901-
54-96X		SILL(FRT.L), SIDE-INNER			
NA01-54-96XA A (NA01-54-96XB)	1				-0101
NA01-54-96XB	1				0101-
54-971		SILL(C), SIDE-INNER			
NA01-54-971	2				
54-980A		SILL(RR.L), SIDE-INNER			
NA01-54-980 G (NA01-54-980B)	1				-9801
NA01-54-980B	1				9801-
56-070		PANEL, BULK HEAD			
NA01-56-39Y	1				
NA01-70-51Y	1				
56-772A		PIPE, DRAIN-RR FENDER			
NA01-56-772	1				
56-991A		COVER, SERVICE HOLE			
NA01-56-971	1				

9801 NA35MM-116316  
 9901 NA35MM-119257  
 0101 NA35MM-133591

5340 BODY PANELS (SIDE)

5340 -2 BODY PANELS (SIDE)





PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
68-6N1	1	INSULATOR, BALK HEAD PANEL			
NA01-68-6N1	1				
70-020	1	PANEL (R), COWL SIDE			
NA01-70-020B	1				
70-10X	1	PANEL (R), QUARTER			
NA01-70-111	1				-9701
AN(NA01-70-111A)	1				
NA01-70-111A	1				9701-
70-100	1	PANEL (R), QUARTER			
NA01-70-100D	1				-9701
AN(NA01-70-100E)	1				
NA01-70-100E	1				9701-9901
G (NA01-70-100F)	1				
NA01-70-100F	1				9901-9C01
AN(NA01-70-100G)	1				
NA01-70-100G	1				9C01-
70-100B	1	PANEL (R), INSIDE			
NA01-70-19XB	1				
70-113A	1	PLATE (R), SEAL			
NA01-70-112	1				
70-114	1	PLATE (R), END			
NA01-70-12XA	1				
70-118	1	PROTECTOR (R), SPLASH			
NA01-70-15X	1				
70-17X	1	BRKT, BATT. CLAMP-QTR PANEL			
NA01-70-17X	1				-9C01
AN(NA01-70-17XA)	1				
NA01-70-17XA	1				9C01-
70-210A	1	PILLAR (R), HINGE			
NA01-70-230	1				
70-260	1	PILLAR (R), FRT.-INNER			
NA01-70-240A	1				-9901

9701 NA35MM-111969  
 9901 NA35MM-119257  
 9C01 NA35MM-130310

5340 BODY PANELS (SIDE)



5340 -3 BODY PANELS (SIDE)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FPOM-TO
CONT'D					
G (NA01-70-240B)					
NA01-70-240B	1				9901-
70-274		GUSSET (R), SIDE SILL OUTER			
NA01-70-274	1				
70-276		REINF. (R), SIDE SILL			
NA01-70-275	1				
70-365		REINF. (R), BELT LINE-C.PIL			
NA01-70-116A	1				
70-365Z		REINF. (L), BELT LINE-C.PIL			
NA01-71-116B	1				
70-390B		REINF. (R), STRIKER			
NA01-70-460	1				
70-445		GUSSET (R), REAR FENDER-RR			
NA01-70-445	1				
70-451C		SILL (R), SIDE OUT.			
NA01-70-270A AN (NA01-70-270B)	1				-9801
NA01-70-270B	1				9801-
70-451E		HOUSING (R), LAMP-RR FENDER			
NA01-70-J30	1				
70-490		RAIL (R), RAIN-REAR			
NA01-70-440A	1				
70-521		PANEL, REAR DECK			
NA01-70-521 A (NA01-70-521A)	1				-9330
NA01-70-521A	1				9330-
70-530A		MEMBER, REAR DECK			
NA01-70-530A	1				
70-615A		BRACKET, FENDER			

9330 NA35\*\*--100072  
 9801 NA35\*\*--116316  
 9901 NA35\*\*--119257

2-K 7





PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D B092-70-070A	2				
70-640		HEADER, FRONT			
NA01-70-640	1				
70-650B		HEADER, FRONT-UPPER			
NA01-70-650	1				
70-670		PLATE(R), CLOSING-QTR PANEL			
NA01-70-670	1				
70-750		PANEL, REAR END			
NA01-70-750C A (NA01-70-750D)	1				-9501
NA01-70-750D G (NA01-70-750E)	1				9501-9905
NA01-70-750E AN (NA01-70-750F)	1				9905-0601
NA01-70-750F	1				0601-
71-020		PANEL(L), COWL SIDE			
NA01-71-020B	1				
71-10X		PANEL(L), QUARTER			
NA01-71-11X AN (NA01-71-11XA)	1				-0321
NA01-71-11XA	1				0321-
71-100		PANEL(L), QUARTER			
NA01-71-100E AN (NA01-71-100F)	1				-9701
NA01-71-100F G (NA01-71-100G)	1				9701-9901
NA01-71-100G	1				9901-
71-100B		PANEL(L), INSIDE			
NA01-71-19XB	1				
71-113		PLATE(L), SEAL			
NA01-71-11Z	1				
71-114A		JUNCTION(L), CORNER-Q /PANE			

9501 NA35MM-102613  
 9701 NA35MM-111969  
 9901 NA35MM-119257  
 9905 NA35MM-119643  
 0321 NA35MM-145170  
 0601 NA35MM-154752

5340 BODY PANELS (SIDE)


5340 -5 BODY PANELS (SIDE)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
NA01-71-12XA	1				
-----+   71-118   +-----		PROTECTOR(L), SPLASH			
NA01-71-15X AN(NA01-71-15XA)	1				-0321
NA01-71-15XA	1				0321-
-----+   71-192   +-----		BRKT,CAP-QUARTER PAN EL			
NA01-71-192	2				
-----+   71-210A   +-----		PILLAR(L),HINGE			
NA01-71-230	1				
-----+   71-260   +-----		PILLAR(L),FRT.-INNER			
NA01-71-240A G (NA01-71-240B)	1				-9901
NA01-71-240B	1				9901-
-----+   71-274   +-----		GUSSET(L),SIDE SILL OUTER			
NA01-71-274	1				
-----+   71-276   +-----		REINF.(L),SIDE SILL			
NA01-71-275	1				
-----+   71-390B   +-----		REINF.(L),STRIKER			
NA01-71-460	1				
-----+   71-405B   +-----		PANEL(L),RR FENDER-L OWER			
NA01-71-421	1				
-----+   71-445   +-----		GUSSET(L),REAR FENDE R-RR			
NA01-71-445	1				
-----+   71-451B   +-----		SILL(L),SIDE OUT.			
NA01-71-270A AN(NA01-71-270B)	1				-9801
NA01-71-270B	1				9801-
-----+   71-451E   +-----		HOUSING(L),LAMP-RR F ENDER			
NA01-71-J30	1				

9801 NA35\*\*-116316  
9901 NA35\*\*-119257  
0321 NA35\*\*-145170

5340 BODY PANELS (SIDE)



5340 -6 \* BODY PANELS (SIDE)

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
71-453A	1	BRKT(L), TRK. BOARD-FENDER			
NA01-71-453	1				
71-490	1	RAIL(L), RAIN-REAR			
NA01-71-440A	1				
71-670	1	PLATE(L), CLOSING-QTR PANEL			
NA01-71-670	1				
74-090	1	PILLAR(R), HINGE-OUT.			
NA01-70-280B	1				
74-090A	1	PILLAR(R), FRONT-OUT.			
NA01-70-210	1				
74-100	1	PANEL(R), FENDER-REAR			-9330
NAY1-70-400 A (NAY1-70-400A)	1				9330-
NAY1-70-400A	1				
74-120	1	PILLAR(L), HINGE-OUT.			
NA01-71-280B	1				
74-120A	1	PILLAR(L), FRONT-OUT.			
NA01-71-210	1				
74-130	1	PANEL(L), FENDER-REAR			-9330
NAY1-71-400 A (NAY1-71-400A)	1				9330-
NAY1-71-400A	1				

9330 NA35MM-190072


9-1-7

## SECTION NAME INDEX (BODY)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
2-C05	0900	KEY SETS	2-E12	6115	HEATER CONTROLS COMPONENTS	3-C03	7900	ACCESSORIES
2-E05	5000	FRONT BUMPER	2-F12	6120	HEATER BLOWER COMPONENTS			
2-H05	5010	REAR BUMPER	2-G12	6130	AIR CONDITIONER			
2-J05	5030	WINDOW MOLDING & COWL GRILLES	2-K12	6135	O RING SET, PIPING			
2-L05	5100	HEAD LAMPS	2-L12	6140	COMPRESSOR COMPONENTS (AIR CONDITIONER)			
2-M05	5102	HEAD LAMP RETRACTORS	2-N12	6150	COOLING UNIT (AIR CONDITIONER)			
2-D06	5105	FRONT COMBINATION LAMPS	2-C13	6300	WINDOW GLASSES			
2-F06	5110	REAR COMBINATION LAMPS	2-D13	6330	SUNROOF			
2-I06	5120	LICENSE LAMPS	2-M13	6600	SWITCHES & RELAYS (ENGINE)			
2-J06	5180	REAR FINISHER	2-D14	6610	DASHBOARD SWITCHES			
2-LJ6	5230	BONNET	2-E14	6611	COMBINATION SWITCH			
2-N06	5260	TRUNK LID	2-F14	6630	RELAYS & UNIT (BODY)			
2-D07	5310	BODY PANELS (FRONT)	2-G14	6635	DOOR SWITCH & HORNS			
2-E07	5320	BODY PANELS (FENDER & WHEEL ARCH)	2-H14	6640	AUTO CRUISE CONTROL SYSTEM			
2-H07	5330	BODY PANELS (DASH & COWL PANEL)	2-I14	6680	AUDIO SYSTEMS (RADIO & TAPE DECK)			
2-I07	5340	BODY PANELS (SIDE)	2-K14	6682	AUDIO SYSTEMS (ANTENNA & SPEAKER)			
2-C08	5370	BODY PANELS (FLOOR)	2-L14	6700	WIRING HARNESSSES (FRONT & REAR)			
2-F08	5380	FLOOR ATTACHMENTS (HOLE COVERS)	2-J14	6701	WIRING HARNESSSES (ENGINE & TRANSMISSION)			
2-G08	5390	FLOOR ATTACHMENTS	2-D15	6702	WIRING HARNESSSES (DASHBOARD)			
2-L09	5500	DASHBOARD EQUIPMENTS	2-E15	6703	WIRING HARNESSSES (DOOR, FLOOR/CEILING)			
2-LJ9	5520	METER HOOD	2-F15	6704	WIRING HARNESS CLAMPS			
2-F09	5530	SPEEDOMETER CABLE	2-I15	6720	WINDSHIELD WASHER			
2-G09	5540	METER COMPONENTS	2-K15	6730	WINDSHIELD WIPERS			
2-I09	5560	DASHBOARD & RELATED PARTS	2-M15	6740	WIPER MOTOR COMPONENTS (FRONT)			
2-L09	5570	CONSOLE	2-N15	6820	FRONT HEADER TRIM & PILLAR TRIMS			
2-C10	5580	VENTILATOR	2-C16	6840	TRIMS & SCUFF PLATES			
2-D10	5700	SEATS	2-E16	5860	FLOOR MATS & PADS			
2-K10	5790	SEAT BELTS	2-G16	6870	SERVICE TOOLS			
2-L10	5800	FRONT DOORS	2-H16	6900	VISORS, ASSIST HANDLES & MIRRORS			
2-C11	5830	FRONT DOOR MECHANISMS	2-J16	6930	CAUTION PLATES & LABELS			
2-F11	5840	FRONT DOOR TRIMS & RELATED PARTS	2-L16	7250	QUARTER WINDOW & TRIMS			
2-C12	6100	HEATER						
2-D12	6110	HEATER UNIT COMPONENTS						



5370 BODY PANELS (FLOOR)



5370 -1 BODY PANELS (FLOOR)

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
53-581 NA01-53-482	1	JUNCTION(R), FRT. FLOOR			
53-600 NA01-53-600 A (NA01-53-600A)	1	PAN, FLOOR-FRONT			-0501
53-600C NA01-53-600A	1	PAN, FLOOR-CENTER			0501-
53-650 NA01-53-650	1	MEMBER NO.2(R), CROSS-FLOOR			
53-670 NA01-53-670	1	BRKT(R), SEAT-F. FLOOR PAN			
53-700 NA01-53-710A C (NA01-53-710B)	1	PAN, FLOOR-REAR			-0701
53-725A NA01-53-725A	1	GUSSET NO.3(R), C.FLOOR PAN			0701-
53-750B NA01-53-750	1	PLATE(R), SIDE-REAR FLOOR			
53-76Y NA01-53-760	2	PLATE, NUT-TRUNK FLOOR PAN			
53-810 NA01-53-810C G (NA01-53-810D)	1	FRAME(R), REAR SIDE			-9901
53-819 NA01-53-819	1	BRACKET, PARKING CABLE-FLOOR			9901-
53-900 NA01-53-900	1	MEMBER NO.3, CROSS			
NA01-53-710A C NA01-53-710B 8001-56-051	2		9901 NA35MM-119257 0501 NA35MM-150679 0701 NA35MM-200041		


AUNA01

CAT. AUNA01-07

1992-02



5370 BODY PANELS (FLOOR)




5370 -2 BODY PANELS (FLOOR)

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
53-940 NA01-53-931	1	MEMBER NO.4,CROSS			
53-98X NA01-53-880	1	GUSSET,FRONT FLOOR PAN			
54-581 NA01-54-482	1	JUNCTION(L),FRT. FLOOR			
54-650 NA01-54-650	1	MEMBER NO.2(L),CROSS-FLOOR			
54-660C NA01-54-660	2	FRAME,FRONT-FRT FLOOR PAN			
54-670 NA01-54-670	1	BRKT(L),SEAT-F.FLOOR PAN			
54-725 NA01-54-725A	1	GUSSET NO.3(L),C.FLOOR PAN			
54-750C NA01-54-750	1	PLATE(L),SIDE-REAR FLOOR			
54-810 NA01-54-810C G (NA01-54-810G)	1	FRAME(L),REAR SIDE			-9901
54-810 NA01-54-810D	1				9901-
56-150A NA01-53-602	1	PAN(R),FLOOR			
56-250A NA01-54-610	1	PAN(L),FLOOR			
56-980 NA01-53-830A A (NA01-53-830C)	1	BRKT(R),BUMPER-RR SKIRT			-9330
56-990B NA01-53-830C	1	BRKT(L),BUMPER-RR SKIRT			9330-

9330 NA35MM-100072  
9901 NA35MM-119257

5370 BODY PANELS (FLOOR)




5370 -3 M BODY PANELS (FLOOR)

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D NA01-54-830A A (NA01-54-830C)	1				-9330
NA01-54-830C	1				9330-
70-450B		PANEL (R), FLOOR SIDE			
NA01-53-740B	1				
71-450B		PANEL (L), FLOOR SIDE			
NA01-54-740 AN (NA01-54-740A)	1				-9801
NA01-54-740A	1				9801-
9330 NA35MM-100072 9801 NA35MM-116316					

5380 FLOOR ATTACHMENTS (HOLE COVERS)


5380 -1 X FLOOR ATTACHMENTS (HOLE COVERS)



- a 56-051
- b 56-061A (HOLE  $\phi$ 65)
- c 56-241 (HOLE  $\phi$ 30)
- d 56-241B (HOLE  $\phi$ 29)
- e 56-241J
- f 56-242 (HOLE  $\phi$ 22)
- g 56-615F (HOLE  $\phi$ 40)
- h 56-615M (HOLE  $\phi$ 15)
- i 56-971 (HOLE  $\phi$ 100)
- j 56-052 (8092-56-052)
- k 56-112B
- l 56-052 (F801-56-056)


PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
56-051		COVER, HOLE			
1011-56-051	4				
56-052		PLUG, DRAIN			
B092-56-052	9	D=12MM			
F801-56-056	4				0701-
56-061A		COVER, HOLE			
8545-56-052	4				
56-112B		PLUG, DRAIN			
B092-56-053	3				-9516
56-241		PLUG, DRAIN			
0118-56-241	6				
56-241B		PLUG			
B001-56-051	6				
56-241J		PLUG, DRAIN			
8477-56-241	6				-9516
8477-56-241	9				9516-
56-242		PLUG, DRAIN			
0118-56-242B	18				
56-615F		PLUG, DRAIN			
0208-56-615	2				
56-615M		PLUG, DRAIN			
NA01-56-051	2				
56-971		COVER, HOLE			
8545-56-053	2				

9516 NA35MM-103924  
0701 NA35MM-200041



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
13-284A		COVER, FUEL FILTER			
NA01-56-241A A (NA01-56-241D)	1				-9801
NA01-56-241B	1				9801-
52-841A		NUT, CLIP			
B455-56-135	1				9601-
56-111		COVER, UNDER			
NA01-56-111 AN(NA01-56-111A)	1				-9601
NA01-56-111A AN(NA01-56-111B)	1				9601-9621
NA01-56-111B AN(NA01-56-111C)	1				9621-0701
NA01-56-111C	1				0701-
56-149		SCREW, TAPPING-MUD GUARD			
B455-56-149	1				9601-
56-171B		PROTECTOR(R), RR FENDER			
NA01-56-171A	1				
56-181K		COVER(R), SENSOR-AIR BAG			
NA01-56-181A	1				-9501
56-191		SHIELD, SPLASH			
NA01-56-112	1				
56-191D		COVER(L), SENSOR-AIR BAG			
NA01-56-191A	1				-9501
56-241A		SHIELD(R), SPLASH-REAR			
NA01-56-311	1				
56-242B		SHIELD(L), SPLASH-REAR			
NA01-56-321	1				
56-291D		HOOK(R), TIE DOWN			
NA01-56-29XC	1				

9501 NA35MM-102613  
 9601 NA35MM-106797  
 9621 NA35MM-110426  
 9801 NA35MM-126490  
 0701 NA35MM-200041



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
56-291E		HOOK(L), TIE DOWN			
NA01-56-290C	1				
56-294		SCREW, TIE DOWN HOOK			
NA01-56-294	4				
56-410		INSULATOR, HEAT-FRONT			
NA01-56-411	1				
56-451		INSULATOR			
NA01-56-451	1				
69-885D		FASTENER			
NA01-56-145	15				
NA01-56-145	7				

-9501  
9501-


9501 NA35MM-102613

## SECTION NAME INDEX (BODY)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
2-C05	0900	KEY SETS	2-E12	6115	HEATER CONTROLS COMPONENTS	3-C03	7900	ACCESSORIES
2-E05	5000	FRONT BUMPER	2-F12	6120	HEATER BLOWER COMPONENTS			
2-H05	5010	REAR BUMPER	2-G12	6130	AIR CONDITIONER			
2-J05	5030	WINDOW MOULDING & COWL GRILLES	2-K12	6135	O RING SET, PIPING			
2-L05	5100	HEAD LAMPS	2-L12	6140	COMPRESSOR COMPONENTS (AIR CONDITIONER)			
2-M05	5103	HEAD LAMP RETRACTORS	2-N12	6150	COOLING UNIT (AIR CONDITIONER)			
2-D06	5105	FRONT COMBINATION LAMPS	2-C13	6300	WINDOW GLASSES			
2-F06	5110	REAR COMBINATION LAMPS	2-D13	6330	SUNROOF			
2-I06	5120	LICENSE LAMPS	2-M13	6600	SWITCHES & RELAYS (ENGINE)			
2-J06	5180	REAR FINISHER	2-D14	6610	DASHBOARD SWITCHES			
2-L06	5230	BONNET	2-E14	6611	COMBINATION SWITCH			
2-N06	5260	TRUNK LID	2-F14	6630	RELAYS & UNIT (BODY)			
2-D07	5310	BODY PANELS (FRONT)	2-G14	6635	DOOR SWITCH & HORNS			
2-E07	5320	BODY PANELS (FENDER & WHEEL ARCH)	2-H14	6640	AUTO CRUISE CONTROL SYSTEM			
2-H07	5330	BODY PANELS (DASH & COWL PANEL)	2-I14	6680	AUDIO SYSTEMS (RADIO & TAPE DECK)			
2-I07	5340	BODY PANELS (SIDE)	2-K14	6682	AUDIO SYSTEMS (ANTENNA & SPEAKER)			
2-C08	5370	BODY PANELS (FLOOR)	2-L14	6700	WIRING HARNESSSES (FRONT & REAR)			
2-F08	538C	FLOOR ATTACHMENTS (HOLE COVERS)	2-N14	6701	WIRING HARNESSSES (ENGINE & TRANSMISSION)			
2-G08	5390	FLOOR ATTACHMENTS	2-D15	6702	WIRING HARNESSSES (DASHBOARD)			
2-C09	5500	DASHBOARD EQUIPMENTS	2-E15	6703	WIRING HARNESSSES (DOOR, FLOOR/CEILING)			
2-E09	5520	METER HOOD	2-F15	6704	WIRING HARNESS CLAMPS			
2-F09	5530	SPEEDOMETER CABLE	2-G15	6720	WINDSHIELD WASHER			
2-G09	5540	METER COMPONENTS	2-K15	6730	WINDSHIELD WIPERS			
2-I09	5560	DASHBOARD & RELATED PARTS	2-M15	6740	WIPER MOTOR COMPONENTS (FRONT)			
2-L09	5570	CONSOLE	2-N15	6820	FRONT HEADER TRIM & PILLAR TRIMS			
2-C10	5580	VENTILATOR	2-C16	6840	TRIMS & SCUFF PLATES			
2-D10	5700	SEATS	2-E16	6860	FLOOR MATS & PADS			
2-K10	5790	SEAT BELTS	2-G16	6870	SERVICE TOOLS			
2-L10	5800	FRONT DOORS	2-H16	6900	VISORS, ASSIST HANDLES & MIRRORS			
2-C11	5830	FRONT DOOR MECHANISMS	2-J16	6930	CAUTION PLATES & LABELS			
2-F11	5840	FRONT DOOR TRIMS & RELATED PARTS	2-L16	7250	QUARTER WINDOW & TRIMS			
2-C12	6100	HEATER						
2-D12	6110	HEATER UNIT COMPONENTS						

5500 DASHBOARD EQUIPMENTS

5500 -1 DASHBOARD EQUIPMENTS




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
51-330J	2	BULB			
99701-5050		12V 5W			
51-490G	2	LAMP, PERSONAL			-9902
NA01-51-490 A (NA01-51-490B)					
00		NA0 BLACK			
NA01-51-490B	2				9902-
00		NA0 BLACK			
51-491	2	LENS, PERSONAL LAMP			
H197-51-491A					
00		BLACK			
55-220	1	PANEL, CENTER			-9801
NA01-55-210 A (NA01-55-210A)					
00		NA0 BLACK			
NA01-55-210A	1				9801-
00		NA0 BLACK			
55-428	3	SPRING, METER HOOD			
GJ21-55-428					
55-431	1	BULB, RESISTER			
BR70-55-431					
55-610	1	RESISTOR, PANEL LIGHT			
BR70-55-490					
60-210	1	COVER, COLUMN-UPPER			
NA01-60-220					
00		NA0 BLACK			
60-210A	1	COVER, COLUMN-LOWER			
NA01-60-210A					
00		NA0 BLACK			
60-223C	1	CAP, COLUMN COVER			

9801 NA35MM-116316  
9902 NA35MM-119435

5500 DASHBOARD EQUIPMENTS

5500 -2 \* DASHBOARD EQUIPMENTS




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
NA01-60-223	1				
00		NA0 NA1 BLACK			
64-271		PANEL,CENTER-LOWER			
NA01-64-270B	1				-9401
00		NA0 BLACK			
NA01-64-270C	1				9401-
00		NA0 BLACK			
64-285		SPRING,ASH TRAY			
NA01-64-612	2				
64-613		SCREW,ASH TRAY			
NA01-64-617	4				
64-617A		LID,ASH TRAY			
NA01-64-617	1				
00		NA0 NA1 BLACK			
64-618		PLATE,ASH TRAY			
NA01-64-618	1				
64-620		TRAY,ASH			
NA01-64-610	1				
00		NA0 BLACK			
NA01-64-610A	1				0A01-0C01
64-622		LIGHT,PLATE-ASH TRAY			
NA01-64-622	1				
64-623		CASE 'OUT',ASH TRAY			
NA01-64-623	1				
00		NA0 BLACK			

9401 NA35\*\*~100090  
 0A01 NA35\*\*~213219  
 0C01 NA35\*\*~220813




5520 METER HOOD

5520 -1 \* METER HOOD




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
55-182		RUBBER, BLIND			
NA01-55-182	1				9609-
55-410		HOOD, METER			
NA01-55-420A	1				-9609
00		NA0 NA1 BLACK			
NA01-55-420B	1	(STD COAT BLACK/BLACK)			9609-
00		NA0 NA1 BLACK			
55-428		SPRING, METER HOOD			
GJ21-55-428	3				
9609 NA35MM-108360					




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
60-070		CABLE, SPEEDOMETER			
NA03-60-070	1	(AT)			
NA01-60-070A G (NA01-60-070B)	1				-9613
NA01-60-070B	1	(MT)			9613-
60-071C		CLIP			
UB40-60-071	2				-0201
NA03-60-071	2				0201-
60-075		CLIP 'A', SPEEDOMETER CABLE			
NA01-60-075	1				

9613 NA35MM-109017  
0201 NA35MM-137180




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
51-030J		BULB			
3625-75-139	5	12V 1.4W, FOR WARNING (MT)			
	6	(AT)			
99701-6030	3	12V 3.4W			
55-261		SOCKET			
1316-55-261	7	12V 3.4W			
8548-55-261	5	12V 1.4W BLACK (MT)			
	6	(AT)			
55-4A1A		METER, OIL PRESSURE			
NA01-55-4A1	1				
55-430		METER SET			
NA01-55-430A	1				-9820
AN(NA01-55-430B)					
NA03-55-430A	1				-0701
A (NA03-55-430B)					
NA01-55-430B	1				9820-0701
A (NA01-55-430C)					
NA01-55-430C	1	(MT)			0701-
NA03-55-430B	1	(AT)			0701-
55-431		BULB, RESISTER			
NA01-55-431	1				
55-432		SOCKET, METER SET			
NA01-55-432	1				
55-437A		GROMMET, KNOB-METER SET			
NA01-55-437	1				
55-441A		CASE, METER			
NA01-55-441	1				-9820
NA01-55-441A	1				9820-0701
NA01-55-441B	1				0701-

9820 NA35MM-128048  
0701 NA35MM-200041




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
55-442A		PLATE, PRINT			
NA01-55-442	1	(MT)			-9B20
NA03-55-442A G (NA03-55-442B)	1				-0701
NA01-55-442A G (NA01-55-442B)	1				9B20-0701
NA01-55-442B	1	(MT)			0701-
NA03-55-442B	1	(AT)			0701-
55-446A		PLATE, WINDOW			
NA01-55-446	1				-0701
NA01-55-446A	1				0701-
55-456B		RESISTOR, METER			
NA01-55-476	1	(MT)			-9B20
55-461		TACHOMETER			
NA01-55-461 G (NA01-55-461A)	1				-0701
NA03-55-461 G (NA03-55-461A)	1				-0701
NA01-55-461A	1	(MT)			0701-
NA03-55-461A	1	(AT)			0701-
55-471		SPEEDMETER			
NA01-55-471 A (NA01-55-471A)	1				-0701
NA01-55-471A	1				0701-
55-481		METER, FUEL			
NA01-55-481	1				
55-491D		METER, THERMO			
NA01-55-491	1				
75-139A		BULB			
B491-55-431	4				

9B20 NA35NM-128848  
0701 NA35NM-200041



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
50-H90A LA01-50-H90	1	SCREW, MOULD-FRT WIND			9801-
55-241A NA01-55-241A	3	BOX, INSTRUMENT PANEL			
00		NA0 NA1 BLACK			
55-561 B455-55-561	1	BOLT, INST. PANEL			
56-905A B092-60-408	4	NUT, SPRING			
58-612 B092-64-046	3	CUSHION, RUBBER			
60-35X NA01-60-35X	1	PAD, INSTRUMENT PANEL			
00		NA0 BLACK			
60-350 NA01-60-350	1	PAD, CRUSH			
00		NA0 BLACK			
60-407A NA01-60-407	2	SPRING, NO.1			
60-409A NA01-60-409	2	SPRING, NO.2			
60-410A NA01-60-401B A (NA01-60-401C)	1	PANEL, INSTRUMENT			-9807
00		NA0 BLACK			
NA01-60-401C	1	(STD COAT BLACK/BLACK)			9807-
00		NA0 BLACK			
60-420A NA01-60-420D	1	FRAME, INST. PANEL			


9801 NA35\*\*-116316  
9807 NA35\*\*-127226



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
60-430B		MEMBER(R), INST. PANE			
NA01-60-430A A (NA01-60-430B)	1				-9701
NA01-60-430B A (NA01-60-430C)	1				9701-0202
NA01-60-430C	1				0202-
60-435A		BRACKET, MEMBER			
NA01-60-435	1				
60-462		BRACKET, INST. PANEL			
NA01-60-462 A (NA01-60-462A)	1				-9801
NA01-60-462A	1				9801-
60-463		BRACKET, CRUSH PAD			
NA01-60-463	1				
64-030		BOX, GLOVE			
NA01-64-030C A (NA01-64-030D)	1				-9801
00		NAO BLACK			
NA01-64-030D	1				9801-
00		NAO BLACK			
64-032		COVER, BOX			
NA01-64-032A A (NA01-64-032B)	1				-9801
00		NAO BLACK			
NA01-64-032B	1				9801-
00		NAO BLACK			
64-071B		HINGE(R), GLOVE LID			
NA01-64-03X	1				
64-072		HINGE(L), GLOVE LID			
NA01-64-03Y	1				
64-101		STRIKER			
NA01-64-101	1				
9701 NA35MM-111969					
9801 NA35MM-116316					
0202 NA35MM-137399					

5560 DASHBOARD & RELATED PARTS

5560 -3 M DASHBOARD & RELATED PARTS




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
64-905B		COVER, HOLE-(C)			
NA01-64-905	1	(STD COAT BLACK/BLACK)			
00		NA0 BLACK			
64-912		COVER, SIDE			
NA01-64-912	6				
00		NA0 BLACK			
64-996		NUT, EXPANSION			
GJ21-64-996	8				
64-999A		SCREW, TAPPING			
W201-64-999	37				
68-AA5		FASTENER, DOOR TRIM			
W201-68-AA5	4				
00		NA0 BLACK			

AUNA01

CAT. AUNA01-07

1992-02


2 K 9



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
51-030J	1	BULB			
3625-75-139		12V 1.4W, FOR WARNING			
55-280	1	BULB & SOCKET			
NA01-55-280		(MT)			
NA01-55-280	1	(AT)			-0125
NA06-55-280	1	(AT)			0125-
58-612	2	CUSHION, RUBBER			
B092-64-046					
60-376	2	NUT, TOP-CRUSH PAD			
B092-60-376					
64-331	1	BOOT, CHANGE			
NA01-64-331		(MT)			
00		NA0 BLACK			
64-344	1	PLATE, BACK-BOOTS RING			
NA01-64-344B		(MT)			
64-345A	1	BOX, COIN-CONSOLE			
NA01-64-437		BASE, (W/O POWER WIND)			
00		NA0 BLACK			
64-41X	1	BRACKET, REAR CONSOLE			
NA01-64-416					
64-410	1	CONSOLE, REAR			
NA01-64-410B		BASE, (URETHANE KNOB, W/O POWER WIND.)			
00		(MT)			
00		NA0 BLACK			
NA02-64-410B	1	PKG-OPT, (URETHANE KNOB, W/POWER WIND.)			
00		(MT)			
00		NA0 BLACK			
NA03-64-410A	1	BASE, (URETHANE KNOB, W/O P			


0125 NA35MM-136059





PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
00		OWER WIND.) (AT)			
NA06-64-410B	1	NA0 BLACK PKG-OPT, (URETHANE KNOB,W/POW ER WIND.) (AT)			
00		NA0 BLACK			
64-419		CLIP, HARNESS-HAND BR AKE			
H260-64-419	1				
64-425		CASE, LAMP			
NA01-64-414	1				
64-430A		LOCK, CONSOLE-REAR			
FB01-64-430	1				
64-450		LID, CONSOLE			
NA01-64-450A	1				
00		NA0 BLACK			
64-470		HINGE			
NA01-64-45XA	2				
00		NA0 BLACK			
64-481		INSULATOR NO.1, CHAN GE			
NA01-64-481 A (NA01-64-481A)	1				
NA01-64-481A	1	(MT)			-9616 9616-
64-481A		STOPPER, CONSOLE LID			
NA01-64-452	1				
00		NA0 NA0 NA1 BLACK			
64-493A		PACK, SILENT			
H001-64-493	1	(MT)			
64-494		PAD, CHANGE BOOT			
FB01-64-495	1	(MT)			

9616 NA35MM-109700




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
66-350		SWITCH, POWER WINDOW			
NA01-66-350A	1	PKG-OPT, V-SPECIAL, (W/POWER WINDOW) (MT)			
00		NA0 BLACK			
NA03-66-350	1	PKG-OPT, V-SPECIAL, (W/POWER WINDOW) (AT)			
00		NA0 BLACK			

240

## SECTION NAME INDEX (BODY)



LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LG.NO	SEC.NO	SECTION NAME
2-C05	0900	KEY SETS	2-E12	6115	HEATER CONTROLS COMPONENTS	3-C02	7900	ACCESSORIES
2-H05	5000	FRONT BUMPER	2-F12	6120	HEATER BLOWER COMPONENTS			
2-H05	5010	REAR BUMPER	2-G12	6130	AIR CONDITIONER			
2-J05	5030	WINDOW MOULDING & COWL GRILLES	2-K12	6135	O RING SET, PIPING			
2-L05	5100	HEAD LAMPS	2-L12	6140	COMPRESSOR COMPONENTS (AIR CON DITIONER)			
2-M05	5103	HEAD LAMP RETRACTORS	2-N12	6150	COOLING UNIT (AIR CONDITIONER)			
2-D06	5105	FRONT COMBINATION LAMPS	2-C13	6300	WINDOW GLASSES			
2-F06	5110	REAR COMBINATION LAMPS	2-D13	6330	SUNROOF			
2-I06	5120	LICENSE LAMPS	2-M13	6600	SWITCHES & RELAYS (ENGINE)			
2-J06	5180	REAR FINISHER	2-D14	6610	DASHBOARD SWITCHES			
2-L06	5230	BONNET	2-E14	6611	COMBINATION SWITCH			
2-H06	5260	TRUNK LID	2-F14	6630	RELAYS & UNIT (BODY)			
2-D07	5310	BODY PANELS (FRONT)	2-G14	6635	DOOR SWITCH & HORNS			
2-E07	5320	BODY PANELS (FENDER & WHEEL AP RON)	2-H14	6640	AUTO CRUISE CONTROL SYSTEM			
2-H07	5330	BODY PANELS (DASH & COWL PANEL )	2-I14	6680	AUDIO SYSTEMS (RADIO & TAPE DE CK)			
2-I07	5340	BODY PANELS (SIDE)	2-K14	6682	AUDIO SYSTEMS (ANTENNA & SPEAK ER)			
2-C08	5370	BODY PANELS (FLOOR)	2-L14	6700	WIRING HARNESES (FRONT & REAR )			
2-F08	5380	FLOOR ATTACHMENTS (HOLE COVERS )	2-N14	6701	WIRING HARNESES (ENGINE & T/MI SSION)			
2-G08	5390	FLOOR ATTACHMENTS	2-D15	6702	WIRING HARNESES (DASHBOARD)			
2-C09	5500	DASHBOARD EQUIPMENTS	2-E15	6703	WIRING HARNESES (DOOR, FLOOR/CE ILING)			
2-E09	5520	METER HOOD	2-F15	6704	WIRING HARNESS CLAMPS			
2-F09	5530	SPEEDOMETER CABLE	2-I15	6720	WINDSHIELD WASHER			
2-G09	5540	METER COMPONENTS	2-K15	6730	WINDSHIELD WIPERS			
2-I09	5560	DASHBOARD & RELATED PARTS	2-M15	6740	WIPER MOTOR COMPONENTS (FRONT)			
2-L09	5570	CONSOLE	2-N15	6820	FRONT HEADER TRIM & PILLAR TRI MS			
2-C10	5580	VENTILATOR	2-I16	6840	TRIMS & SCUFF PLATES			
2-D10	5700	SEATS	2-E16	6860	FLOOR MATS & PADS			
2-K10	5790	SEAT BELTS	2-G16	6870	SERVICE TOOLS			
2-I10	5800	FRONT DOORS	2-H16	6900	VISORS, ASSIST HANDLES & MIRROR S			
2-C11	5830	FRONT DOOR MECHANISMS	2-J16	6930	CAUTION PLATES & LABELS			
2-F11	5840	FRONT DOOR TRIMS & RELATED PAR TS	2-L16	7250	QUARTER WINDOW & TRIMS			
2-C12	6100	HEATER						
2-D12	6110	HEATER UNIT COMPONENTS						




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
60-120		NOZZLE(R), DEFROSTER			
NA01-60-121	1				
60-120Z		NOZZLE(L), DEFROSTER			
NA01-60-141	1				
60-161		GRILLE(R), DEMISTER			
NA01-60-161	1	(STD COAT BLACK/BLACK)			
00		NA0 BLACK			
60-161Z		GRILLE(L), DEMISTER			
NA01-60-171	1	(STD COAT BLACK/BLACK)			
00		NA0 BLACK			
60-181A		DUCT(R), SIDE DEMIST.			
NA01-60-183	1				
60-181Y		DUCT(L), SIDE DEMIST.			
NA01-60-193	1				
61-161		DUCT, CENTER			
NA01-61-161	1				
61-253C		HOSE(C), DEFROSTER			
NA01-61-253	1				
64-771A		DUCT NO.1(R)			
NA01-64-741	1				
64-771Y		DUCT NO.1(L)			
NA01-64-841	1				
64-815B		LOUVER, VENTILATOR			
NA01-64-31X	4				
00		NA0 BLACK			

(THIS ILLUSTRATION CONSISTS OF 2 PAGES)

(THIS ILLUSTRATION CONSISTS OF 2 PAGES)




(THIS ILLUSTRATION CONSISTS OF 2 PAGES)




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
57-05X		BOLT, LINK			
8455-57-05X	8				9401-
57-051D		BOLT, SET			
UB40-57-05X	8				-9401
57-100		SEAT(R), FRONT			
NA01-57-100B A (NA01-57-100D)	1				-9701
00		NAO BLACK			
NA02-57-100B A (NA02-57-100D)	1				-9701
00		NAO BLACK			
NA01-57-100D A (NA01-57-100E)	1				9701-0201
00		NAO BLACK			
NA02-57-100D A (NA02-57-100E)	1				9701-0201
00		NAO BLACK			
NA01-57-100E A (NA01-57-100F)	1				0201-0601
00		NAO BLACK			
NA02-57-100E A (NA02-57-100F)	1				0201-0601
00		NAO BLACK			
NA01-57-100F	1	BASE, (CLOTH, W/O HEAD SPK.)			0601-
00		NAO BLACK			
NA02-57-100F	1	PKG-OPT, (CLOTH, W/HEAD SPK.)			0601-
00		NAO BLACK			
57-150		SEAT(L), FRONT			
NA01-57-150B A (NA01-57-150D)	1				-9701
00		NAO BLACK			
NA02-57-150B A (NA02-57-150D)	1				-9701
00		NAO BLACK			
NA01-57-150D A (NA01-57-150E)	1				9701-0201
9401	NA35NN-100090				
9701	NA35NN-111969				
0201	NA35NN-137180				
0601	NA35NN-154752				

(THIS ILLUSTRATION CONSISTS OF 2 PAGES)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
00		NAO BLACK			
NA02-57-150D A (NA02-57-150E)	1				9701-0201
00		NAO BLACK			
NA01-57-150E A (NA01-57-150F)	1				0201-0601
00		NAO BLACK			
NA02-57-150E A (NA02-57-150F)	1				0201-0601
00		NAO BLACK			
NA01-57-150F	1	BASE, (CLOTH,W/O HEAD SPK.)			0601-
00		NAO BLACK			
NA02-57-150F	1	PKG-OPT, (CLOTH,W/HEAD SPK.)			0601-
00		NAO BLACK			
66-960P		SPEAKER,PILLOW-SEAT			
NA04-66-960A	2	PKG-OPT, (W/HEAD SPEAKER)			
88-024		PROTR(R),SEAT BELT			
NA01-88-033	1				
88-025A		KNOB(R),KNUCKLE			
NA01-88-034	1				
00		NAO BLACK			
88-074		PROTR(L),SEAT BELT			
NA01-88-083	1				
88-081B		KNOB(L),KNUCKLE			
NA01-88-084	1				
00		NAO BLACK			
88-101		KNUCKLE(R),RECLINING			
NA01-88-101 A (NA01-88-101A)	1				-0601
NA01-88-101A	1				0601-
9701 NA35MM-111969 0201 NA35MM-137180 0601 NA35MM-154752					


(THIS ILLUSTRATION CONSISTS OF 2 PAGES)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
88-102		ADJUSTER, NO.1			
NA01-88-102 A (NA01-88-102A)	1				-0201
NA01-88-102A	1				0201-
88-103		ADJUSTER, NO.2			
NA01-88-103 A (NA01-88-103A)	1				-0201
NA01-88-103A	1				0201-
88-105B		BOLT, LINK			
H260-88-105	8				
88-105G		BUSH, HINGE			
H260-88-108	2				
02		NAO BLACK			
88-106T		WIRE, CONNECT			
NA01-88-106	1				
88-108E		COVER(R), SEAT BACK			
NA01-88-036	1				
00		NAO BLACK			
88-109K		SCREW, KNUCKLE			
H260-88-109	8				
88-110		CUSHION(R), FRT SEAT			
NA01-88-110	1	BASE, PKG-OPT, (CLOTH)			
00		NAO BLACK			
88-111		TRIM(R), SEAT CUSHION			
NA01-88-111	1	BASE, PKG-OPT, (CLOTH)			
00		NAO BLACK			
88-112A		PAD(R), CUSHION-FRT			
NA01-88-112	1				
88-113A		FRAME(R), CUSHION-FRT			
0201 NA35MM-137180					




(THIS ILLUSTRATION CONSISTS OF 2 PAGES)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
NA01-88-113	1				
88-116		COVER(R), KNUCKLE			
NA01-88-031	1				
00		NA0 BLACK			
88-117		SCREW, KNUCKLE			
H260-88-107	2				
88-130		BACK(R), FRONT SEAT			
NA01-88-130	1	BASE, (CLOTH, W/O HEAD SPK.)			
00		NA0 BLACK			
NA02-88-130	1	PKG-OPT, (CLOTH, W/HEAD SPK.)			
00		NA0 BLACK			
88-131		TRIM(R), SEAT BACK			
NA01-88-131	1	BASE, PKG-OPT, (CLOTH)			
00		NA0 BLACK			
88-132A		PAD(R), BACK-FRT			
NA01-88-132	2				
88-151		KNUCKLE(L), RECLINING			
NA01-88-151	1				-0601
A (NA01-88-151A)					0601-
NA01-88-151A	1				
88-152		ADJUSTER NO.3			
NA01-88-152	1				-0201
A (NA01-88-152A)					0201-
NA01-88-152A	1				
88-153		ADJUSTER NO.4			
NA01-88-153	1				-0201
A (NA01-88-153A)					0201-
NA01-88-153A	1				
88-154C		COVER, HEAD REST			


0201 NA35MM-137180  
0601 NA35MM-154752

(THIS ILLUSTRATION CONSISTS OF 2 PAGES)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D NA01-88-137	2				
88-156D		WIRE,CONNECT			
NA01-88-156	1				
88-158G		COVER(L),SEAT BACK			
NA01-88-086	1				
00		NA0 BLACK			
88-160		CUSHION(L),FRT SEAT			
NA01-88-160	1	BASE, PKG-OPT, (CLOTH)			
00		NA0 BLACK			
88-161		TRIM(L),SEAT CUSHION			
NA01-88-161	1	BASE, PKG-OPT, (CLOTH)			
00		NA0 BLACK			
88-162A		PAD(L),CUSHION-FRT			
NA01-88-162	1	BASE, PKG-OPT, (CLOTH)			
00		NA0 BLACK			
88-163A		FRAME(L),CUSHION-FRT			
NA01-88-163	1				
88-166		COVER(L),KNUCKLE			
NA01-88-081	1				
00		NA0 BLACK			
88-178C		COVER(R),HINGE			
NA01-88-035	1				
00		NA0 BLACK			
88-180		BACK(L),FRONT SEAT			
NA02-88-180	1	BASE, (CLOTH,W/O HEAD SPK.)			
00		NA0 BLACK			
NA02-88-180	1	PKG-OPT, (CLOTH,W/HEAD SPK.)			
00		NA0 BLACK			


(THIS ILLUSTRATION CONSISTS OF 2 PAGES)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-10
88-181		TRIM(L), SEAT BACK			
NA01-88-181	1	BASE, PKG-OPT, (CLOTH)			
00		NAO BLACK			
88-188A		COVER(L), HINGE			
NA01-88-085	1				
00		NAO BLACK			
88-732A		PAD'B'(R), BACK-FRT			
NA01-88-732	1				
88-782		PAD'B'(L), BACK-FRT			
NA01-88-782	1				


5790 SEAT BELTS

5790 -1 \* SEAT BELTS



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
57-620		BELT 'A', FRONT SEAT			
NA01-57-620	1				
00		NA0 BLACK			
57-630A		BELT 'B' (R), FRT SEAT			
NA01-57-630C	1				
00		NA0 BLACK			
57-631		COVER, ANCHOR			
NA01-57-631B	2				
00		NA0 BLACK			
57-680		BELT 'A', FRONT SEAT			
NA01-57-680	1				
00		NA0 NA1 BLACK			
57-680A		BELT 'B' (L), FRT SEAT			
NA01-57-690A	1	(W/AIR BAG)			
00		NA0 BLACK			
NA07-57-690	1	(W/O AIR BAG)			0701-
00		NA0 BLACK			


0701 NA35\*\*-200041



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
58-010	1	BODY(R), FRONT DOOR			
NAY1-58-020					
58-010Z	1	BODY(L), FRONT DOOR			
NAY1-59-020					
58-020	1	PANEL(R), OUT.-FRT DOOR			-9413
NA01-58-030 AN(NA01-58-030A)					9413-
NA01-58-030A					
58-020Z	1	PANEL(L), OUT.-FRT DOOR			-9413
NA01-59-030 AN(NA01-59-030A)					9413-
NA01-59-030A					
58-201	4	SHIM, HINGE-DOOR			-9901
B092-58-201 AN(B092-58-201A)					9901-
B092-58-201A					
58-210	1	HINGE(R), DOOR-UPPER			
FB01-58-210					
58-210Z	1	HINGE(L), DOOR-UPPER			
FB01-59-210					
58-225	8	BOLT, SETTING-HINGE LOWER			
B455-58-225					
58-226	4	WASHER, SETTING			-9510
BA56-72-226					9510-
GJ21-58-226					
58-240	1	HINGE(R), DOOR-LOWER			
B156-58-240					
58-240Z	1	HINGE(L), DOOR-LOWER			
B156-59-240					
58-495		BOLT, SET			
9413 NA35MM-100500 9510 NA35MM-102968 9901 NA35MM-119257					

5800 FRONT DOORS


5800 -2 FRONT DOORS



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
BA54-58-225	4				
S085-58-225	4				
58-500		GLASS(R), DOOR-FRT			
NA01-58-510	1				
58-500Z		GLASS(L), DOOR-FRT			
NA01-59-510	1				
58-502C		GROMMET, SCREW			
B235-58-502	2				
58-502D		GROMMET, SCREW-DOOR GLASS			
UB39-58-502A	4				
58-505C		SCREW, WINDOW REGULATOR			
B092-58-505	6				
58-602		GUIDE 'B' (R), GLASS			
NA01-58-603A	1				
58-602Z		GUIDE 'B' (L), GLASS			
NA01-59-603A	1				
58-604		CHANNEL (R), DIVISION-DOOR			
NA01-58-604B	1				
58-604Z		CHANNEL (L), DIVISION-DOOR			
NA01-59-604B	1				
58-651		WEATHERSTRIP (R)			
NA01-58-651A	1				
58-651Z		WEATHERSTRIP (L)			
NA01-59-651A	1				
58-661		GLASS (R), VENTILATOR			
NA01-58-661	1				
58-661Z		GLASS (L), VENTILATOR			
NA01-59-661	1				

5800 FRONT DOORS

5800 -3 \* FRONT DOORS



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
58-760		WEATHERSTRIP(R), DOOR			
NA01-58-760C A (NA01-58-760D)	1				-9403
NA01-58-760D	1				9403-
58-760Z		WEATHERSTRIP(L), DOOR			
NA01-59-760C A (NA01-59-760D)	1				-9403
NA01-59-760D	1				9403-
58-762		FASTENER			
G031-58-762	42				
58-772A		FASTENER			
1011-58-772	4				
58-910		STOPPER, GLASS			
H272-58-911	4				
68-911		WELT, SEAMING			
NA01-68-911	2				
00		NA0 BLACK			


9403 NA35MM-100090

2-N10


## SECTION NAME INDEX (BODY)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
2-C05	0900	KEY SETS	2-E12	6115	HEATER CONTROLS COMPONENTS	3-C03	7900	ACCESSORIES
2-E05	5000	FRONT BUMPER	2-F12	6120	HEATER BLOWER COMPONENTS			
2-H05	5010	REAR BUMPER	2-G12	6130	AIR CONDITIONER			
2-J05	5030	WINDOW MOULDING & COWL GRILLES	2-K12	6135	O RING SET, PIPING			
2-L05	5100	HEAD LAMPS	2-L12	6140	COMPRESSOR COMPONENTS (AIR CON DITIONER)			
2-M05	5103	HEAD LAMP RETRACTORS	2-N12	6150	COOLING UNIT (AIR CONDITIONER)			
2-D06	5105	FRONT COMBINATION LAMPS	2-C13	6300	WINDOW GLASSES			
2-F06	5110	REAR COMBINATION LAMPS	2-D13	6330	SUNROOF			
2-I06	5120	LICENSE LAMPS	2-M13	6600	SWITCHES & RELAYS (ENGINE)			
2-J06	5180	REAR FINISHER	2-D14	6610	DASHBOARD SWITCHES			
2-L06	5230	BONNET	2-E14	6611	COMBINATION SWITCH			
2-I06	5260	TRUNK LID	2-F14	6630	RELAYS & UNIT (BODY)			
2-D07	5310	BODY PANELS (FRONT)	2-G14	6635	DOOR SWITCH & HORNS			
2-E07	5320	BODY PANELS (FENDER & WHEEL AP RON)	2-H14	6640	AUTO CRUISE CONTROL SYSTEM			
2-H07	5330	BODY PANELS (DASH & COWL PANEL )	2-I14	6680	AUDIO SYSTEMS (RADIO & TAPE DE CK)			
2-I07	5340	BODY PANELS (SIDE)	2-K14	6682	AUDIO SYSTEMS (ANTENNA & SPEAK ER)			
2-C08	5370	BODY PANELS (FLOOR)	2-L14	6700	WIRING HARNESES (FRONT & REAR )			
2-F08	5380	FLOOR ATTACHMENTS (HOLE COVERS )	2-N14	6701	WIRING HARNESES (ENGINE & T/MI SSION)			
2-G08	5390	FLOOR ATTACHMENTS	2-D15	6702	WIRING HARNESES (DASHBOARD)			
2-C09	5500	DASHBOARD EQUIPMENTS	2-E15	6703	WIRING HARNESES (DOOR, FLOOR/CE ILING)			
2-E09	5520	METER HOOD	2-F15	6704	WIRING HARNESS CLAMPS			
2-F09	5530	SPEEDOMETER CABLE	2-I15	6720	WINDSHIELD WASHER			
2-G09	5540	METER COMPONENTS	2-K15	6730	WINDSHIELD WIPERS			
2-I09	5560	DASHBOARD & RELATED PARTS	2-M15	6740	WIPER MOTOR COMPONENTS (FRONT)			
2-L09	5570	CONSOLE	2-N15	6820	FRONT HEADER TRIM & PILLAR TRI MS			
2-C10	5580	VENTILATOR	2-C16	6840	TRIMS & SCUFF PLATES			
2-D10	5700	SEATS	2-E16	6860	FLOOR MATS & PADS			
2-K10	5790	SEAT BELTS	2-G16	6870	SERVICE TOOLS			
2-L10	5900	FRONT DOORS	2-I16	6900	VISORS, ASSIST HANDLES & MIRROR S			
2-C11	5830	FRONT DOOR MECHANISMS	2-J16	6930	CAUTION PLATES & LABELS			
2-F11	5840	FRONT DOOR TRIMS & RELATED PAR TS	2-L16	7250	QUARTER WINDOW & TRIMS			
2-C12	6100	HEATER						
2-D12	6110	HEATER UNIT COMPONENTS						






PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
56-242		PLUG, DRAIN			
0118-56-242B	2				
58-265A		PIN, CHECKER			
H260-58-265C	2				
58-270A		CHECKER, DOOR			
NA01-58-270A	2				
58-303B		COVER, INNER HANDLE			
NA01-58-303	2				
00		NA0 NA1 BLACK			
58-310		LOCK (R), DOOR			
NA01-58-310B	1				
58-310Z		LOCK (L), DOOR			
NA01-59-310B	1				
58-314B		JOINT			
H043-72-411	2				
58-3150		CLIP (R)			
G030-58-315	4				
58-316A		CLIP			
B001-59-335	1				
58-321		HANDLE (R), INNER			
NA01-58-330A	1				
00		NA0 NA1 BLACK			
58-321Z		HANDLE (L), INNER			
NA01-59-330A	1				
00		NA0 NA1 BLACK			
58-335Z		CLIP (L), INNER HANDLE			
FB01-58-335	1				
58-370		HANDLE, REGULATOR			




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
B092-58-580	2	BASE, (W/O POWER WIND)			
00		NA0 NA1 BLACK			
58-375		ESCUTCHEON			
B001-58-582A	2	BASE, (W/O POWER WIND)			
00		NA0 NA1 BLACK			
58-420		HANDLE(R), OUT.			
NA01-58-410A AN(NA01-58-410D)	1				-9413
NA01-58-410B A (NA01-58-410C)	1				9413-9627
NA01-58-410C	1				9627-
58-420Z		HANDLE(L), OUT.			
NA01-59-410A AN(NA01-59-410B)	1				-9413
NA01-59-410B A (NA01-59-410C)	1				9413-9627
NA01-59-410C	1				9627-
58-505E		CAP			
B092-58-355	2	BASE, (W/O POWER WIND)			
58-560		REGULATOR(R), WINDOW			
NA01-58-560B	1	BASE, (W/O POWER WIND)			
NA02-58-560B	1	PKG-OPT, V-SPECIAL, (W/POWER WIND)			
58-560Z		REGULATOR(L), WINDOW			
NA01-59-560B	1	BASE, (W/O POWER WIND)			
NA02-59-560B	1	PKG-OPT, V-SPECIAL, (W/POWER WIND)			
58-569		GASKET, WINDOW REGULA TOR			
B092-58-569	2	BASE, (W/O POWER WIND)			
58-570A		STRIKER			
9413 NA35MM-100500 9627 NA35MM-111215					



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
B001-58-361A	2				
58-586		RING, SNAP			
B001-58-585	2	BASE, (W/O POWER WIND)			
58-608		PAD			
B092-58-863A	2	BASE, (W/O POWER WIND)			
58-861C		SCREEN(R), FRONT DOOR			
NA01-58-861A	1	BASE, (W/O POWER WIND)			
NA02-58-861A	1	PKG-OPT, V-SPECIAL, (W/POWER WIND)			
59-315		CLIP			
G030-59-315	4				
59-861		SCREEN(L), FRONT DOOR			
NA01-59-861A	1	BASE, (W/O POWER WIND)			
NA02-59-861A	1	PKG-OPT, V-SPECIAL, (W/POWER WIND)			
62-671		DOVETAIL, LIFT GATE			
S084-62-671	2				
62-681B		WEDGE, DOOR-FRONT			
NA01-62-681	2				
62-682		SCREW, WEDGE-LIFT GATE			
B216-62-682	4				
62-868A		COVER, HOLE-LIFT GATE			
B499-62-868	2				
76-448A		CLIP			
G030-76-448	2				

5840 FRONT DOOR TRIMS & RELATED PARTS

5840 -1 FRONT DOOR TRIMS & RELATED PARTS




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
58-772A		FASTENER			
1011-58-772	4				
58-811		WEATHERSTRIP(R), OUT.			
NA01-58-810B AN(NA01-58-810C)	1				-9607
NA01-58-810C AN(NA01-58-810D)	1				9607-0306
NA01-58-810D	1				0306-
58-811Z		WEATHERSTRIP(L), OUT.			
NA01-59-810B AN(NA01-59-810C)	1				-9607
NA01-59-810C AN(NA01-59-810D)	1				9607-0306
NA01-59-810D	1				0306-
58-815A		CLIP, WEATHERSTRIP-OUTER			
D156-58-815	12				-9607
NA01-58-815	12				9607-
58-815B		CLIP 'A', WEATHERSTRIP-OUT			
B157-58-815	2				
59-185		WEATHERSTRIP NO.1			
NA01-58-821	2				
59-186		WEATHERSTRIP NO.2			
NA02-58-821	2				
68-AB1		FASTENER			
G351-68-ABX	10				9C01-0601
68-4H1		GRILLE(R), SPEAKER			
NA01-68-4H0	1				
00		NA0 NA1 BLACK			
68-4T1		GRILLE(L), SPEAKER			
NA01-68-4W0	1				
00		NA0 NA1 BLACK			

9607 NA35MM-107883  
 9C01 NA35MM-130310  
 0306 NA35MM-142598  
 0601 NA35MM-154752

5840 FRONT DOOR TRIMS & RELATED PARTS

5840 -2 \* FRONT DOOR TRIMS & RELATED PARTS




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
68-401		FASTENER, DOOR TRIM			
W201-68-401	12				
B100-68-401	10				-9C01
B160-68-401	10				0601-
68-420		TRIM(R), DOOR			
NA01-68-420B	1	BASE, (W/O POWER WIND)			
00		NA0 BLACK			
NA02-68-420B	1	PKG-OPT, V-SPECIAL, (W/POWER WIND)			
00		NA0 BLACK			
68-420Z		TRIM(L), DOOR			
NA01-68-450B	1	BASE, (W/O POWER WIND)			
00		NA0 BLACK			
NA02-68-450B	1	PKG-OPT, V-SPECIAL, (W/POWER WIND)			
00		NA0 BLACK			
69-361		GROMMET, SCREW			
B316-69-361	6				
69-371		REST(R), ARM			
BF70-69-370C	1				
00		NA0 NA1 BLACK			
69-371Z		REST(L), ARM			
BF70-69-390C	1				
00		NA0 NA1 BLACK			
69-374		CAP(R), PULL HANDLE			
BF70-69-372	1				
00		NA0 NA1 BLACK			
69-374Z		CAP(L), PULL HANDLE			
BF70-69-392	1				
00		NA0 NA1 BLACK			

9C01 NA35MM-130310  
0601 NA35MM-154752


## SECTION NAME INDEX (BODY)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
2-C05	0900	KEY SETS	2-E12	6115	HEATER CONTROLS COMPONENTS	3-C03	7900	ACCESSORIES
2-E05	5000	FRONT BUMPER	2-F12	6120	HEATER BLOWER COMPONENTS			
2-H05	5010	REAR BUMPER	2-G12	6130	AIR CONDITIONER			
2-J05	5030	WINDOW MOULDING & COWL GRILLES	2-K12	6135	O RING SET, PIPING			
2-L05	5101	HEAD LAMPS	2-L12	6140	COMPRESSOR COMPONENTS (AIR CON DITIONER)			
2-M05	5103	HEAD LAMP RETRACTORS	2-N12	6150	COOLING UNIT (AIR CONDITIONER)			
2-D06	5106	FRONT COMBINATION LAMPS	2-C13	6300	WINDOW GLASSES			
2-F06	5110	REAR COMBINATION LAMPS	2-D13	6330	SUNROOF			
2-I06	5120	LICENSE LAMPS	2-M13	6600	SWITCHES & RELAYS (ENGINE)			
2-J06	5180	REAR FINISHER	2-D14	6610	DASHBOARD SWITCHES			
2-L06	5230	BONNET	2-E14	6611	COMBINATION SWITCH			
2-N06	5260	TRUNK LID	2-F14	6630	RELAYS & UNIT (BODY)			
2-D07	5310	BODY PANELS (FRONT)	2-G14	6635	DOOR SWITCH & HORNS			
2-E07	5320	BODY PANELS (FENDER & WHEEL AP RON)	2-H14	6640	AUTO CRUISE CONTROL SYSTEM			
2-H07	5330	BODY PANELS (DASH & COWL PANEL )	2-I14	6680	AUDIO SYSTEMS (RADIO & TAPE DE CK)			
2-I07	5340	BODY PANELS (SIDE)	2-K14	6682	AUDIO SYSTEMS (ANTENNA & SPEAK ER)			
2-C08	5370	BODY PANELS (FLOOR)	2-L14	6700	WIRING HARNESSSES (FRONT & REAR )			
2-F08	5380	FLOOR ATTACHMENTS (HOLE COVERS )	2-N14	6701	WIRING HARNESSSES (ENGINE & T/MI SSION)			
2-G08	5390	FLOOR ATTACHMENTS	2-D15	6702	WIRING HARNESSSES (DASHBOARD)			
2-C09	5500	DASHBOARD EQUIPMENTS	2-E15	6703	WIRING HARNESSSES (DOOR, FLOOR/CE ILING)			
2-E09	5520	METER HOOD	2-F15	6704	WIRING HARNESS CLAMPS			
2-F09	5530	SPEEDOMETER CABLE	2-I15	6720	WINDSHIELD WASHER			
2-G09	5540	METER COMPONENTS	2-K15	6730	WINDSHIELD WIPERS			
2-I09	5560	DASHBOARD & RELATED PARTS	2-M15	6740	WIPER MOTOR COMPONENTS (FRONT)			
2-L09	5570	CONSOLE	2-N15	6820	FRONT HEADER TRIM & PILLAR TRI MS			
2-C10	5580	VENTILATOR	2-C16	6840	TRIMS & SCUFF PLATES			
2-D10	5700	SEATS	2-E16	6860	FLOOR MATS & PADS			
2-K10	5790	SEAT BELTS	2-G16	6870	SERVICE TOOLS			
2-L10	5800	FRONT DOORS	2-H16	6900	VISORS, ASSIST HANDLES & MIRROR S			
2-C11	5830	FRONT DOOR MECHANISMS	2-J16	6930	CAUTION PLATES & LABELS			
2-F11	5840	FRONT DOOR TRIMS & RELATED PAR TS	2-7250		QUARTER WINDOW & TRIMS			
2-C12	6100	HEATER						
2-D12	6110	HEATER UNIT COMPONENTS						



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
61-150		DUCT,AIR			
NA01-61-150 G (NA01-61-150A)	1				-9A01
NA01-61-150A	1				9A01-
61-211		HOSE NO.1,WATER			
NA01-61-211	1				
61-212		HOSE NO.2,WATER			
NA01-61-212 A (NA01-61-212A)	1				-9601
NA01-61-212A	1				9601-
61-479		GROMMET			
8871-61-219A	2				


9601 NA35NM-106797  
9A01 NA35NM-122908




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
61-A01		CASE 'A', HEATER UNIT			
NA01-61-A01	1				
61-A02		CASE 'B', HEATER UNIT			
NA01-61-A02	1				
61-A10		CORE, HEATER UNIT			
NA01-61-A10	1				
61-A20		LINK SET, TEMP			
NA01-61-A20	1				
61-A30		LINK SET, MODE			
NA01-61-A30	1				
61-130		HEATER UNIT			
NA01-61-130 G (NA01-61-130A)	1				-9A01
NA01-61-130A	1				9A01-

9A01 NA35MM-122908






PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
61-C04		PANEL, PLATE-MODE CONTROL			
NA01-61-C04	1				
61-C09		CLIP, HEATER CONTROL			
H260-61-C09	1				
61-C25		WIRE, TEMP. CONTROL			
NA01-61-C25	1				
61-C35		WIRE, MODE CONTROL			
NA01-61-C35	1				
61-C45		WIRE, RECYCLE & FRESH			
NA01-61-C45	1				
61-C50		SWITCH, FAN-HEATER CONTROL			
NA01-61-C50	1				
61-C95		BULB, MODE CONTROL			
NA01-61-C95	2				
NA02-61-C95	1				
NA03-61-C95	1				
61-D22		SCREW, RR HEATER UNIT			
NA01-61-D22	3				
61-190		CONTROL, HEATER			
NA01-61-190A	1				
61-191A		KNOB NO.1			
NA01-61-191	3				
61-195B		KNOB, FAN SWITCH			
NA01-61-195	1				
76-514		CLIP			
B001-76-526	2				



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
61-B01		CASE 'A', BLOWER UNIT			
NA01-61-B01	1				
61-B02		CASE 'B', BLOWER UNIT			
NA01-61-B02	1				
61-B10		MOTOR, FAN-BLOWER UNIT			
NA01-61-B10	1				
61-B15		RESISTOR, BLOWER UNIT			
NA01-61-B15	1				
61-B20		LINK, RECYCLE & FRESH			
NA01-61-B20	1				
61-140		BLOWER UNIT			
NA01-61-140A	1				






PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
61-463	1	PIPE NO.1, COOLER			-0116
NA02-61-466B AN(NA02-61-466C)	1	(A)			0116-
NA02-61-466C	1	(A)			
61-464	1	PIPE NO.2, COOLER			
NA01-61-466	1	(A)			
61-466	1	PIPE NO.4, COOLER			-0529
NA01-61-467A	1	(A)			0529-0615
NA01-61-467B C (NA01-61-467C)	1	(A)			0615-
NA01-61-467C	1	(A)			
61-467	1	PIPE NO.5, COOLER			
NA01-61-468A	1	(A)			
61-470A	1	BRACKET, HOSE			-0116
NA02-61-470A AN(NA02-61-470B)	1	(A)			0116-
NA02-61-470B	1	(A)			
61-471	1	CLIP, PIPE			
BF67-61-471	1	(A)			
61-472E	1	BRACKET, CLAMP			-9731
NA01-61-472	1	(A)			9731-
NA02-61-472 A (NA02-61-472A)	1	(A)			
NA02-61-472A	1	(A)			
61-474G	1	BRACKET, PIPE			
NA01-61-474	1	(A)			
NA02-61-474A	1	(A)			

9731 NA35MM-116114  
 0116 NA35MM-134600  
 0529 NA35MM-154173  
 0615 NA35MM-157507




6130 AIR CONDITIONER

6130 -4 M AIR CONDITIONER




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
61-558A BF67-61-558	1	GROMMET (A)			
61-559A BF67-61-559	1	GROMMET (A)			
61-695A NA01-61-695	1	BRACKET, RELAY (A)			
61-710A NA01-61-710	1	FAN, CONDENSER (A)			
61-731A B111-61-731	4	BOLT, AIR CON.			
67-740F B462-67-740	1	RELAY, COOLING FAN 20A TR			
67-7404 B458-67-740	1	RELAY, TRANSFER 20A TR			



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
61-J1X GJY1-61-J1X	1	RING, 'O'-NO.1 (A)			
61-J1XA GJY2-61-J1X	1	RING, 'O'-NO.2 (A)			
61-J1XB GJY3-61-J1X	1	RING, 'O'-NO.3 (A)			
76-700 NA01-76-700	1	RING SET, 'O'-AIR CON (A)			

2-K12




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
61-K00 NA02-61-K00	1	COMPRESSOR, AIR CON. (A)			
61-K10 NA02-61-K10	1	SHAFT, CYL -COMPRESSOR (A)			
61-K11 NA02-61-K11	1	HEAD, CYL. -COMPRESSOR (A)			
61-K12 NA02-61-K12	1	HEAD, CYL. -COMPRESSOR (A)			
61-K19 F065-61-K19	1	SEAL, SHAFT-COMPR.			
61-K20 NA02-61-K2X	1	GASKET KIT, COMPRESSOR (A)			
61-K23 NA02-61-K23	1	PLUG, COMPRESSOR (A)			
61-K24 NA02-61-K24	1	GASKET, COMPRESSOR (A)			
61-K25 F065-61-K25	5	BOLT, COMPRESSOR-AIR CON.			
61-K28 NA02-61-K28	5	WASHER, COMPRESSOR (A)			
61-K31 F065-61-K31	2	BOLT, COMPRESSOR			
61-K35 NA02-61-K35	1	HARNES. COMPRESSOR (A)			



6140 COMPRESSOR COMPONENTS (AIR CONDITIONER)

6140 -2 \* COMPRESSOR COMPONENTS (AIR CONDITIONER)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
61-K39	1	OIL,COMPRESSOR			
NA02-61-K39		(A)			
61-L10	1	CLUTCH,MAGNET			
NA02-61-L10		(A)			
61-L11	1	ARMATURE,MAGNET CLUTCH			
F065-61-L11					
61-L12	1	PULLEY,MAGNET CLUTCH			
NA02-61-L12		(A)			
61-L13	1	COIL,FIELD-MAGNET CLUTCH			
F065-61-L13					
61-L14	1	BOLT,MAGNET CLUTCH			
F065-61-L14					
61-L16	1	RING,SNAP-MAGNET CLUTCH			
F065-61-L16					
61-450	1	COMPRESSOR			
NA02-61-450A		(A)			
76-833B	1	WASHER			
B001-76-734					
76-877A	1	RING,SNAP			
B001-76-725					


AUNA01

CAT. AUNA01-07

1992-02

2-M12

6150 COOLING UNIT (AIR CONDITIONER)



6150 -1 \* COOLING UNIT (AIR CONDITIONER)

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
61-J01 NA01-61-J01	1	CASE 'A', COOLING UNIT (A)			
61-J02 NA01-61-J02	1	CASE 'B', COOLING UNIT (A)			
61-J04 NA01-61-J04	1	SEAL, COOLING UNIT (A)			
61-J10 NA01-61-J10	1	EVAPORATOR (A)			
61-J14 NA01-61-J14	1	VALVE, EXPANSION (A)			
61-J15 NA01-61-J15	1	PIPE, COOLING UNIT (A)			
61-J20 NA01-61-J20	1	THERMOSTAT, COOLING UNIT (A)			
61-520 NA01-61-520B	1	UNIT, COOLING (A)			



## SECTION NAME INDEX (BODY)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
2-C05	0900	KEY SETS	2-E12	6115	HEATER CONTROLS COMPONENTS	3-C03	7900	ACCESSORIES
2-E05	5000	FRONT BUMPER	2-F12	6120	HEATER BLOWER COMPONENTS			
2-H05	5010	REAR BUMPER	2-G12	6130	AIR CONDITIONER			
2-J05	5030	WINDOW MOULDING & COWL GRILLES	2-K12	6135	O RING SET, PIPING			
2-L05	5100	HEAD LAMPS	2-L12	6140	COMPRESSOR COMPONENTS (AIR CONDITIONER)			
2-M05	5103	HEAD LAMP RETRACTORS	2-N12	6150	COOLING UNIT (AIR CONDITIONER)			
2-D06	5105	FRONT COMBINATION LAMPS	2-C13	6300	WINDOW GLASSES			
2-F06	5110	REAR COMBINATION LAMPS	2-D13	6300	SUNROOF			
2-I06	5120	LICENSE LAMPS	2-M13	6600	SWITCHES & RELAYS (ENGINE)			
2-J06	5180	REAR FINISHER	2-D14	6610	DASHBOARD SWITCHES			
2-L06	5230	BONNET	2-E14	6611	COMBINATION SWITCH			
2-N06	5260	TRUNK LID	2-F14	6630	RELAYS & UNIT (BODY)			
2-D07	5310	BODY PANELS (FRONT)	2-G14	6635	DOOR SWITCH & HORNS			
2-E07	5320	BODY PANELS (FENDER & WHEEL ARCH)	2-H14	6640	AUTO CRUISE CONTROL SYSTEM			
2-H07	5330	BODY PANELS (DASH & COWL PANEL)	2-I14	6680	AUDIO SYSTEMS (RADIO & TAPE DECK)			
2-I07	5340	BODY PANELS (SIDE)	2-K14	6682	AUDIO SYSTEMS (ANTENNA & SPEAKER)			
2-C08	5370	BODY PANELS (FLOOR)	2-L14	6700	WIRING HARNESES (FRONT & REAR)			
2-F08	5380	FLOOR ATTACHMENTS (HOLE COVERS)	2-N14	6701	WIRING HARNESES (ENGINE & TRANSMISSION)			
2-G08	5390	FLOOR ATTACHMENTS	2-D15	6702	WIRING HARNESES (DASHBOARD)			
2-C09	5500	DASHBOARD EQUIPMENTS	2-E15	6703	WIRING HARNESES (DOOR, FLOOR/CEILING)			
2-E09	5520	METER HOOD	2-F15	6704	WIRING HARNESS CLAMPS			
2-F09	5530	SPEEDOMETER CABLE	2-I15	6720	WINDSHIELD WASHER			
2-G09	5540	METER COMPONENTS	2-K15	6730	WINDSHIELD WIPERS			
2-I09	5560	DASHBOARD & RELATED PARTS	2-M15	6740	WIPER MOTOR COMPONENTS (FRONT)			
2-L09	5570	CONSOLE	2-N15	6820	FRONT HEADER TRIM & PILLAR TRIMS			
2-C10	5580	VENTILATOR	2-C16	6840	TRIMS & SCUFF PLATES			
2-D10	5700	SEATS	2-E16	6860	FLOOR MATS & PADS			
2-K10	5790	SEAT BELTS	2-G16	6870	SERVICE TOOLS			
2-L10	5800	FRONT DOORS	2-H16	6900	VISORS, ASSIST HANDLES & MIRRORS			
2-C11	5830	FRONT DOOR MECHANISMS	2-J16	6930	CAUTION PLATES & LABELS			
2-F11	5840	FRONT DOOR TRIMS & RELATED PARTS	2-L16	7250	QUARTER WINDOW & TRIMS			
2-C12	6100	HEATER						
2-D12	6110	HEATER UNIT COMPONENTS						

CATLOG-NO= AUNA01-07

DATE. 1992-02



2-B13



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
50-611 NAY1-63-930	1	MOULD, RR. WINDOW OPTION, (W/DETACHABLE TOP-B. COLOR,)			
50-615A NA01-63-934	1	JOINT, B'CK WIND MOUL D OPTION, (W/DETACHABLE TOP-B. COLOR,)			
50-894 NA01-50-894	1	DUM, FRONT-WIND.			
50-899 NA01-63-895	1	DUM, REAR-WIND. OPTION, (W/DETACHABLE TOP-B. COLOR,)			
63-901 NA01-63-901	1	GLASS, WINDSHIELD			
63-931 NA01-63-931C	1	GLASS, BACK WINDOW OPTION, (W/DETACHABLE TOP-B. COLOR,)			
63-936 NA01-63-936A	1	PROTR, BACK WINDOW-UP PER OPTION, (W/DETACHABLE TOP-B. COLOR,)			-9916
63-936 NA01-63-936A	2	OPTION, (W/DETACHABLE TOP-B. COLOR,)			9916-
63-937A NA01-63-937	2	PROTR, BACK WINDOW-SI DE OPTION, (W/DETACHABLE TOP-B. COLOR,)			-9916
63-938 NA01-63-938	1	PROTR, BACK WINDOW-LO WER OPTION, (W/DETACHABLE TOP-B. COLOR,)			-9916
70-448A GJ21-50-891	2	SPACER 'B'			


9916 NA35MM-121163

(W/O DETACHABLE TOP)






(THIS ILLUSTRATION CONSISTS OF 2 PAGES)




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D NA01-R1-272	1				0601-
┌ R1-281 ┐ └────────┘ NA01-R1-281	1	WELT, SEAMING-SOFT TO P			
┌ R1-310A ┐ └────────┘ NA02-R1-310A A (NA02-R1-310B)	2	LOCK, DETACHABLE TOP			-0101
NA02-R1-310B	2	OPTION, (W/DETACHABLE TOP-B. COLOR,)			0101-
┌ R1-331A ┐ └────────┘ NA01-R1-331	1	HANDLE, SOFT TOP			
┌ R1-38X ┐ └────────┘ NA01-R1-38XA A (NA01-R1-38XB)	2	HOOK, SOFT TOP-REAR D ECK			-9801
NA01-R1-38XB	2				9801-
┌ R1-381 ┐ └────────┘ NA01-R1-381A C (NA01-R1-381B)	1	PLATE (R), HOOK-REAR D ECK			-9609
NA01-R1-381B	1				9609-
┌ R1-382 ┐ └────────┘ NA01-R1-382 A (NA01-R1-382A)	2	SCREW, HOOK-REAR DECK			-9609
NA01-R1-382A	2				9609-
┌ R1-391 ┐ └────────┘ NA01-R1-391A C (NA01-R1-391B)	1	PLATE (L), HOOK-REAR D ECK			-9609
NA01-R1-391B	1				9609-
┌ R1-411 ┐ └────────┘ NA01-R1-461	1	RETAINER 'A' (R), WTHST P			
┌ R1-412 ┐ └────────┘ NA01-R1-462	1	RETAINER 'B' (R), WTHST P			
┌ R1-413 ┐ └────────┘ NA01-R1-463	1	RETAINER 'C' (R), WTHST P			
NA01-R1-381A C NA01-R1-381B NA01-R1-382A			9609 NA35MM-108360 9801 NA35MM-126490 0101 NA35MM-133591 0601 NA35MM-154752		



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
RI-421	1	RETAINER 'A' (L), WTHST P			
NA01-RI-471	1				
RI-422	1	RETAINER 'B' (L), WTHST P			
NA01-RI-472	1				
RI-423	1	RETAINER 'C' (L), WTHST P			
NA01-RI-473	1				
RI-451	1	WTHSTP NO.1(R), LINK			
NA01-RI-411B	1				
RI-452	1	WTHSTP NO.2(R), LINK			
NA01-RI-412B	1				
RI-453	1	WTHSTP NO.3(R), LINK			
NA01-RI-413B	1				
RI-461	1	WTHSTP NO.1(L), LINK			
NA01-RI-421B	1				
RI-462	1	WTHSTP NO.2(L), LINK			
NA01-RI-422B	1				
RI-463	1	WTHSTP NO.3(L), LINK			
NA01-RI-423B	1				
RI-491	16	GROMMET, SCREW-RAIL INNER			
NA01-RI-491	16				
RI-560	1	RAIL, RAIN-SOFT TOP REAR			
NA01-RI-560C	1				
RI-581	1	PLATE (C), SET-TOP FABRIC			
NA01-RI-581B	1				
RI-582	1	PLATE (R), SET-TOP FABRIC			
NA01-RI-582A	1				
RI-592	1	PLATE (L), SET-TOP FABRIC			
NA01-RI-592A	1				



(THIS ILLUSTRATION CONSISTS OF 2 PAGES)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
RI-711 NA01-R1-711B	1	WTHSTP, FRONT HEADER			
RI-721A NA01-R1-721A A (NA01-R1-721B)	1	WTHSTP(R), CAB SIDE			-0116
RI-721B NA01-R1-721B	1				0116-
RI-731 NA01-R1-731A A (NA01-R1-731B)	1	WTHSTP(L), CAB SIDE			-0116
RI-731B NA01-R1-731B	1				0116-
RI-741 NA01-R1-741A A (NA01-R1-741B)	1	PROTR(R), MOULD-BELT LINE			-9601
RI-741B NA01-R1-741B	1				9601-
RI-742 NA01-R1-742A A (NA01-R1-742B)	1	PROTR(L), MOULD-BELT LINE			-9601
RI-742B NA01-R1-742B	1				9601-
RI-750 NA01-R1-750B A (NA01-R1-750C)	1	MOULD, BELTLINE-REAR			-9601
RI-750C NA01-R1-750C AN(NA01-R1-750D)	1				9601-0403
RI-750D NA01-R1-750D	1				0403-
RI-780 NA01-R1-780C	1	COVER(R), DRAIN-SOFT TOP			
RI-786 NA01-R1-786 AN(NA01-R1-786A)	2	GROMMET, DRAIN HOSE-TOP			-9420
RI-786A NA01-R1-786A	2				9420-
RI-790 NA01-R1-790C	1	COVER(L), DRAIN-SOFT TOP			
RI-810A NA01-R1-810A	1	PANEL, ROOF			

9420 NA35MM-101198  
 9601 NA35MM-106797  
 0116 NA35MM-134600  
 0403 NA35MM-146744


AUNA01

CAT. AUNA01-07

1992-02




(THIS ILLUSTRATION CONSISTS OF 2 PAGES)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
A (NA01-R1-361B)					
NA02-R1-361A	1				-0201
A (NA02-R1-361B)					
NA01-R1-361B	1				0201-
NA02-R1-361B	1				0201-
+					
R1-882		STRIKER(L), LOCK-TOP			
+					
NA01-R1-371A	1				-0201
A (NA01-R1-371B)					
NA02-R1-371A	1				-0201
A (NA02-R1-371B)					
NA01-R1-371B	1				0201-
NA02-R1-371B	1				0201-
+					
R1-882A		RETAINER(R), WTHSTP-D			
+					
NA01-R1-882	1	.TOP			
+					
R1-89X		WEATHERSTRIP, D. TOP-R			
+					
NA01-R1-89XA	1	EAR			
+					
R1-892		RETAINER(L), WTHSTP-D			
+					
NA01-R1-892	1	.TOP			
+					
R1-926		WASHER, HOOK-HOOD COV			
+					
FB67-R1-926A	4	ER			-9701
+					
R1-931		COVER(R), BELT LINE			
+					
NA01-R1-931A	1				
+					
R1-935		PROTECTOR(C), EDGE-D.			
+					
NA01-R1-935A	1	TOP			
+					
R1-936		PROTECTOR(R), EDGE-D.			
+					
NA01-R1-936	1	TOP			
+					
R1-941A		COVER(L), BELT LINE			
+					
NA01-R1-941A	1				
+					
R1-946		PROTECTOR(L), EDGE-D.			
+					
NA01-R1-946	1	TOP			

9701 NA35MM-111969  
0201 NA35MM-137180

(W/O DETACHABLE TOP)




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
RI-951A		WTHSTP(R), ROOF PANEL			
NA01-RI-881B	1				
RI-952A		WTHSTP(L), ROOF PANEL			
NA01-RI-891B	1				
RI-953		HOOK, HOOD-REAR CORNER			
B235-RI-953	4				
RI-958		WASHER, HOOK 'A' & 'B'			
B235-RI-958A	7				
RI-96X		COVER, TOP FABRIC			
NA01-RI-96XA	1				-9C01
A (NA01-RI-96XB)					
NA01-RI-96XB	1				9C01-
RI-970		HOOK, REAR DECK			
NA01-RI-970	4				-9701
A (NA01-RI-970A)					
NA01-RI-970A	4				9701-
RI-972		WASHER, HOOK 'A'			
NA01-RI-926	4				9701-
RI-981		STOPPER, SOFT TOP			
NA01-RI-981A	2				
RI-982		BOLT, STOPPER-SOFT TOP			
NA01-RI-982A	2				
50-841B		GROMMET, SCREW			
H260-50-841	2				
55-225B		COVER, HOLE			
G030-55-225	6				
00		NA0 NA1 BLACK			
56-376		NUT, SELF LOCK			
B001-56-376	13				


9701 NA35MM-111969  
9C01 NA35MM-130310

2-K13

(THIS ILLUSTRATION CONSISTS OF 2 PAGES)



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
68-865C		FASTENER			
68-865A	2				9301-
00		NAO BLACK			
68-865Q		FASTENER			
GJ21-68-885A AN(GJ21-68-885B)	2				-9526
00		NAO BLACK			
GJ21-68-885B	2				9526-9801
00		NAO BLACK			
9526 NA35**-105742 9801 NA35**-116316					



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
11-373J	1	RING, 'O'			
99541-03801	1				
13-363N	1	RUBBER, MOUNTING			
0222-13-363	1				
17-630	1	SWITCH			
8118-17-640A A (8118-17-640B)	1				-9501
8118-17-640B	1	(MT)			9501-
17-640	1	SWITCH, BACK UP LAMP			
1391-17-640	1	(MT)			-9831
M506-17-640	1	(MT)			9831-
18-T41	1	RING, 'O'-WATER THERM O SW.			
F885-18-T41	1				
18-113	1	BOLT			
B366-18-1A5	1				
18-230	1	SENSOR, CRANK ANGLE			
B61P-18-230	1				
18-501	1	SWITCH, OIL PRESSURE			
B61P-18-501	1				
18-510	1	UNIT, HEAT GAUGE			
B541-18-51X	1				
18-7012	1	UNIT, CONTROL			
B64J-18-780A A (B64J-18-780B)	1				-0401
B64J-18-780B	1	(AT)			0401-
18-741A	1	VALVE, THREE WAY			
JE16-18-741	1	NITROGEN OIL SEAL			
18-772	1	BRACKET, IGNITER			
B61P-18-2FOA	1				-9A01
9501	NA35**	-102613			
9831	NA35**	-119088			
9A01	NA35**	-122908			
0401	NA35**	-146561			




## SECTION NAME INDEX (BODY)


LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
2-C05	0900	KEY SETS	2-E12	6115	HEATER CONTROLS COMPONENTS	3-C03	7900	ACCESSORIES
2-E05	5000	FRONT BUMPER	2-F12	6120	HEATER BLOWER COMPONENTS			
2-H05	5010	REAR BUMPER	2-G12	6130	AIR CONDITIONER			
2-J05	5030	WINDOW MOULDING & COWL GRILLES	2-K12	6135	O RING SET, PIPING			
2-L05	5100	HEAD LAMPS	2-L12	6140	COMPRESSOR COMPONENTS (AIR CONDITIONER)			
2-M05	5103	HEAD LAMP RETRACTORS	2-N12	6150	COOLING UNIT (AIR CONDITIONER)			
2-D06	5105	FRONT COMBINATION LAMPS	2-C13	6300	WINDOW GLASSES			
2-F06	5110	REAR COMBINATION LAMPS	2-D13	6330	SUNROOF			
2-I06	5120	LICENSE LAMPS	2-M13	6600	SWITCHES & RELAYS (ENGINE)			
2-J06	5180	REAR FINISHER	2-D14	6610	DASHBOARD SWITCHES			
2-L06	5230	BONNET	2-E14	6611	COMBINATION SWITCH			
2-N06	5260	TRUNK LID	2-F14	6630	RELAYS & UNIT (BODY)			
2-D07	5310	BODY PANELS (FRONT)	2-G14	6635	DOOR SWITCH & HORNS			
2-E07	5320	BODY PANELS (FENDER & WHEEL ARCH)	2-H14	6640	AUTO CRUISE CONTROL SYSTEM			
2-H07	5330	BODY PANELS (DASH & COWL PANEL)	2-I14	6680	AUDIO SYSTEMS (RADIO & TAPE DECK)			
2-I07	5340	BODY PANELS (SIDE)	2-K14	6682	AUDIO SYSTEMS (ANTENNA & SPEAKER)			
2-C08	5370	BODY PANELS (FLOOR)	2-L14	6700	WIRING HARNESSSES (FRONT & REAR)			
2-F08	5380	FLOOR ATTACHMENTS (HOLE COVERS)	2-N14	6701	WIRING HARNESSSES (ENGINE & TRANSMISSION)			
2-G08	5390	FLOOR ATTACHMENTS	2-D13	6702	WIRING HARNESSSES (DASHBOARD)			
2-C09	5500	DASHBOARD EQUIPMENTS	2-E15	6703	WIRING HARNESSSES (DOOR, FLOOR/CEILING)			
2-E09	5520	METER HOOD	2-F15	6704	WIRING HARNESS CLAMPS			
2-F09	5530	SPEEDOMETER CABLE	2-I15	6720	WINDSHIELD WASHER			
2-G09	5540	METER COMPONENTS	2-K15	6730	WINDSHIELD WIPERS			
2-I09	5560	DASHBOARD & RELATED PARTS	2-M15	6740	WIPER MOTOR COMPONENTS (FRONT)			
2-L09	5570	CONSOLE	2-N15	6820	FRONT HEADER TRIM & PILLAR TRIMS			
2-C10	5580	VENTILATOR	2-C16	6840	TRIMS & SCUFF PLATES			
2-D10	5700	SEATS	2-E16	6860	FLOOR MATS & PADS			
2-K10	5790	SEAT BELTS	2-G16	6870	SERVICE TOOLS			
2-L10	5800	FRONT DOORS	2-H16	6900	VISORS, ASSIST HANDLES & MIRRORS			
2-C11	5830	FRONT DOOR MECHANISMS	2-J16	6930	CAUTION PLATES & LABELS			
2-F11	5840	FRONT DOOR TRIMS & RELATED PARTS	2-L16	7250	QUARTER WINDOW & TRIMS			
2-C12	6100	HEATER						
2-D12	6110	HEATER UNIT COMPONENTS						








PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
19-446		RING, 'O'			
0338-19-446	1	(AT)			
19-821		SOLENOID, DOWN SHIFT			
BU55-19-821	1	(AT)			
19-838		BOLT-HEX, HD WASHER			
1758-19-838	2				
21-291		SWITCH, OIL PRESSURE			
BU55-21-2J1	1	(AT)			
21-292		RING, 'O'			
BU01-21-292A	1	(AT)			
21-293		SOLENOID, OVER DRIVE			
BU55-21-2J3	1	(AT)			
21-294		RING, 'O'			
BU01-21-294	1	(AT)			
21-295		RING, 'O'			
BU01-21-295	1	(AT)			
21-296		SOLENOID, LOCK UP CONTROL			
BU55-21-3A5	1	(AT)			
24-910		IGNITER SET			
B61P-18-251	1				
66-991F		CONDENSER			
B376-66-991	1				
67-132A		CONNECTOR, SHORT			
HB23-67-741	1	(CALIF.)			
67-7403		RELAY, N.O.			
LA10-67-740	1	10A			



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
60-721 B092-66-241A	1	PROTECTOR			
66-170A NA01-66-170	1	SWITCH(R), CLUSTER			
66-250 B150-66-250	1	LIGHTER, CIGAR			
66-251 B001-66-251	1	RING, ILLUMINATION			
66-340 NA01-66-340A	1	SWITCH, MAIN PKG-OPT, (W/AUTO CRUISE CONT)			
66-462 NA01-66-462	2	BULB 'B', SWITCH-RR DE FOGER			
66-600 B481-55-225	1	COVER, HOLE PKG-OPT, (W/AUTO CRUISE CONT)			
	2	BASE, (W/O AUTO CRUISE CON T.)			

6611 COMBINATION SWITCH


6611 -1 \* COMBINATION SWITCH



Component parts of COMBINATION SWITCH  
are under establishment now.  
Parts numbers will be informed you  
by the Parts Engineering Change  
Bulletin as soon as established.

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
66-110		SWITCH, COMBINATION			
NA01-66-120A	1	BASE, (W/O AUTO CRUISE CON T.)			
NA02-66-120A	1	PKG-OPT, (W/AUTO CRUISE CONT)			

2 E14




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
13-745		BRACKET, RELAY			
NA02-67-9A1	1				
66-830B		UNIT, FLASHER			
HE01-66-830	1				
67-7F0		UNIT, DIAGNOSIS-AIR BAG			
NA01-67-7F0	1				-9A01
NA01-67-7F0A	1				9A01-
67-7GD		UNIT, BACK UP POWER-AIR BAG			
NA01-67-7GD	1				-0302
AN(NA01-67-7G0A)					
NA01-67-7G0A	1				0302-
67-720C		TIMER & BUZZER			
NA02-67-720	1				
67-7403		RELAY, N.O.			
H300-67-740	1	30A (HEAD LAMP RELAY)			
LA10-67-740	2	10A (HORN RELAY) (SMALL LAMP RELAY) (MT)			
LA12-67-740	3	(HORN RELAY) (SMALL LAMP RELAY) (KICK DOWN RELAY) (AT)			
67-7404		RELAY, TRANSFER			
HD22-67-740	1	(W/AIR BAG)			
67-9A1A		BRACKET, RELAY			
NA01-67-9A1	1				
67-9A1B		BRKT, DIAGNOSIS UNIT			
NA06-67-9A1B	1				
67-9A1C		BRKT, DIAGNOSIS/POWER UNIT			
NA05-67-9A1B	1				

9A01 NA35MM-122908  
0302 NA35MM-142105


6635 DOOR SWITCH & HORNS

6635 -1 M DOOR SWITCH & HORNS



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
66-546 LA01-66-546	2	SCREW, DOOR SWITCH			
66-790 SA59-66-790	1	HORN, LOW TONE			
66-820 B455-66-540	2	SWITCH, DOOR			

2014




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
66-3A1 LA01-66-3A1	1	BRACKET,ACTUATER-A.C. .C.			
66-3A2 NA01-66-3A2A	1	BRACKET,ACTIATOR-FRO NT			
66-310B LA01-66-310A	1	ACTUATOR,A.C.C.			
66-311 NA01-66-311A	1	WIRE,A.C.C.			
66-320 NA01-66-320 NA03-66-320	1 1 (MT) 1 (AT)	BOX,A.C.C.			
66-361 NA01-66-361	1	PIPE,AUTO CRUISE CON TROL			
66-370A NA01-66-3A3A	1	BRACKET,ACTUATER			
66-772 8092-41-661	1	GROMMET BASE, (W/O AUTO CRUISE CON T.)			

6680 AUDIO SYSTEMS (RADIO & TAPE DECK)


(W/O AUDIO)

99864-0410




(ANTI THEFT LABEL)

66-201B



(W/O C.DISC)



55-230

66-870J

66-AC0

66-914

66-912A

66-902A

66-901A

66-904C

66-991N

99864-0410

66-870J

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B

66-201B


66-201B

66-201B


66-201B

6680 AUDIO SYSTEMS (RADIO & TAPE DECK)


(W/O AUDIO)




(ANTI THEFT LABEL)



(W/O C.DISC)



(W/C.DISC)




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
66-904C		BRACKET, LOW			
NA01-66-AT6	1	BASE, PKG-OPT, (W/O C.DISC)			
66-912A		KNOB, TONE-TUNER			
NA01-66-BR2	1	PKG-OPT, (W/AUDIO)			
66-914		KNOB, VOLUME-TUNER			
NA01-66-BR1	1	PKG-OPT, (W/AUDIO)			
66-991N		CORD, EARTH			
NA01-66-997	1				





6700 WIRING HARNESSSES(FRONT & REAR )

6700 -1 WIRING HARNESSSES(FRONT & REAR )




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
66-495		FUSE(10A)			
99705-1110	2				
66-496		FUSE(15A)			
99705-1115	6				
66-497		FUSE(20A)			
99705-1120	1				
66-497B		FUSE(30A)			
99705-1130	1				
66-730		BLOCK, FUSE			
NA01-66-730C	1				
66-732D		COVER, FUSE BLOCK			
NA01-66-731A	1	FURUKAWA			
66-732E		LABEL, CAUTION-FUSE COVER			
NA01-66-732A	1				
66-733A		BREAKER			
H001-66-733	1				
66-740		HOLDER, FUSE			
H001-66-739	1				
67-B71		BRACKET, HARNESS			
NA05-67-BW13	1	(W/AIR BAG)			
67-B73		BRACKET, HARNESS			
NA05-67-BW2	1	(W/AIR BAG)			
67-B74		BRACKET, HARNESS			
NA05-67-BW0A	1				
67-010A		HARNESS, FRONT			
NA03-67-010D	1	(W/AIR BAG) (AT)			
NA01-67-010J AN(NA01-67-010L)	1				-9701

9701 NA35MM-111969


6700 WIRING HARNESSSES(FRONT & REAR )

6700 -2 \* WIRING HARNESSSES(FRONT & REAR )



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D NA02-67-010J AN(NA02-67-010L)	1				-9701
NA01-67-010L	1	BASE, (W/O HEAD SPEAKER) (MT)			9701-9901
NA02-67-010L	1	PKG-OPT, (W/HEAD SPEAKER) (MT)			9701-9901
NA01-67-010U AN(NA01-67-010W)	1				9901-9A01
NA02-67-010U AN(NA02-67-010W)	1				9901-9A01
NA01-67-010W AN(NA04-67-010 )	1				9A01-9C01
NA02-67-010W AN(NA05-67-010 )	1				9A01-9C01
NA04-67-010 AN(NA04-67-010A)	1				9C01-0401
NA05-67-010 AN(NA05-67-010A)	1				9C01-0401
NA04-67-010A	1	BASE, (W/O HEAD SPEAKER) (MT)			0401-
NA05-67-010A	1	PKG-OPT, (W/HEAD SPEAKER) (MT)			0401-
NA08-67-010	1	(W/O AIR BAG) (MT)			0701-
NA09-67-010D	1	(W/O AIR BAG) (AT)			0701-
----- 67-050 -----		HARNESS,REAR			
NA01-67-050C AN(NA01-67-050D)	1				-9A01
NA02-67-050C AN(NA02-67-050D)	1				-9A01
NA01-67-050D	1	BASE, (W/O HEAD SPEAKER)			9A01-
NA02-67-050D	1	PKG-OPT, (W/HEAD SPEAKER)			9A01-
----- 67-990F -----		BRACKET,HARNESS			
NA01-67-BJ0	1				

- 9701 NA35\*\*-111969
- 9901 NA35\*\*-119257
- 9A01 NA35\*\*-122908
- 9C01 NA35\*\*-130310
- 0401 NA35\*\*-146561
- 0701 NA35\*\*-200041




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
66-136		FUSE(30A)			
H115-67-099	3				
66-136A		FUSE(40A)			
H116-67-099	1				
66-136B		FUSE(80A)			
H117-67-099	1				
66-495		FUSE(10A)			
99705-1110	2				
66-497		FUSE(20A)			
99705-1120	1				
66-497B		FUSE(30A)			
99705-1130	1				
66-760		BLOCK,MAIN FUSE			
NA01-66-760B	1				
66-761		COVER,MAIN FUSE BLOK			
NA02-66-762B	1	YAZAKI			
66-766		COVER,UNDER-MAIN FUS			
B465-66-767	1	E BLK			9701-
66-9912		WIRE,EARTH			
NA01-67-EW1A	1				-9601
AN(NA01-67-EW1B)					
NA01-67-EW1B	1				9601-
67-B22		BRACKET,HARNESS			
NA01-67-B20A	1				-9A13
67-B74		BRACKET,HARNESS			
NA01-67-B80A	1				
67-020J		HARNESS,INJECTOR			
NA01-67-080B	1				-9701
AN(NA01-67-080C)					

9601 NA35\*\*-106797  
 9701 NA35\*\*-111969  
 9A13 NA35\*\*-124217

SECTION NAME INDEX (BODY)


LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
2-C05	0900	KEY SETS	2-E12	6115	HEATER CONTROLS COMPONENTS	3-C03	7900	ACCESSORIES
2-E05	5000	FRONT BUMPER	2-F12	6120	HEATER BLOWER COMPONENTS			
2-H05	5010	REAR BUMPER	2-G12	6130	AIR CONDITIONER			
2-J05	5030	WINDOW MOULDING & COWL GRILLES	2-K12	6135	O RING SET, PIPING			
2-L05	5100	HEAD LAMPS	2-L12	6140	COMPRESSOR COMPONENTS (AIR COND ITIONER)			
2-M05	5103	HEAD LAMP RETRACTORS	2-N12	6150	COOLING UNIT (AIR CONDITIONER)			
2-D06	5105	FRONT COMBINATION LAMPS	2-C13	6300	WINDOW GLASSES			
2-F06	5110	REAR COMBINATION LAMPS	2-D13	6330	SUNROOF			
2-I06	5120	LICENSE LAMPS	2-M13	6600	SWITCHES & RELAYS (ENGINE)			
2-J06	5180	REAR FINISHER	2-D14	6610	DASHBOARD SWITCHES			
2-L06	5230	BONNET	2-E14	6611	COMBINATION SWITCH			
2-N06	5260	TRUNK LID	2-F14	6630	RELAYS & UNIT (BODY)			
2-D07	5310	BODY PANELS (FRONT)	2-G14	6635	DOOR SWITCH & HORNS			
2-E07	5320	BODY PANELS (FENDER & WHEEL AP RON)	2-H14	6640	AUTO CRUISE CONTROL SYSTEM			
2-H07	5330	BODY PANELS (DASH & COWL PANEL )	2-I14	6680	AUDIO SYSTEMS (RADIO & TAPE DE CK)			
2-I07	5340	BODY PANELS (SIDE)	2-K14	6682	AUDIO SYSTEMS (ANTENNA & SPEAK ER)			
2-C08	5370	BODY PANELS (FLOOR)	2-L14	6700	WIRING HARNESES (FRONT & REAR )			
2-F08	5380	FLOOR ATTACHMENTS (HOLE COVERS )	2-N14	6701	WIRING HARNESES (ENGINE & T/MI SSION)			
2-G08	5390	FLOOR ATTACHMENTS	2-D15	6702	WIRING HARNESES (DASHBOARD)			
2-C09	5500	DASHBOARD EQUIPMENTS	2-E15	6703	WIRING HARNESES (DOOR, FLOOR/CE ILING)			
2-E09	5520	METER HOOD	2-F15	6704	WIRING HARNESS CLAMPS			
2-F09	5530	SPEEDOMETER CABLE	2-I15	6720	WINDSHIELD WASHER			
2-G09	5540	METER COMPONENTS	2-K15	6730	WINDSHIELD WIPERS			
2-I09	5560	DASHBOARD & RELATED PARTS	2-M15	6740	WIPER MOTOR COMPONENTS (FRONT)			
2-L09	5570	CONSOLE	2-N15	6820	FRONT HEADER TRIM & PILLAR TRI MS			
2-C10	5580	VENTILATOR	2-C16	6840	TRIMS & SCUFF PLATES			
2-D10	5700	SEATS	2-E16	6860	FLOOR MATS & PADS			
2-K10	5790	SEAT BELTS	2-G16	6870	SERVICE TOOLS			
2-L10	5800	FRONT DOORS	2-H16	6900	VISORS, ASSIST HANDLES & MIRROR S			
2-C11	5830	FRONT DOOR MECHANISMS	2-J16	6930	CAUTION PLATES & LABELS			
2-F11	5840	FRONT DOOR TRIMS & RELATED PAR TS	2-L16	7250	QUARTER WINDOW & TRIMS			
2-C12	6100	HEATER						
2-D12	6110	HEATER UNIT COMPONENTS						





PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D NA01-67-080C	1				9701-
67-033A		BRACKET, WIRING			
NA01-67-810B	1				
67-070		HARNES, ENGINE			
NA03-67-070C	1	(W/AIR BAG) (AT)			
NA01-67-070F AN(NA01-67-070H)	1				-9701
NA01-67-070H AN(NA01-67-070J)	1				9701-9801
NA01-67-070J	1	(W/AIR BAG) (MT)			9801-
NA07-67-070J	1	(W/O AIR BAG) (MT)			0701-
NA09-67-070C	1	(W/O AIR BAG) (AT)			0701-

9701 NA35\*\*-111969  
 9801 NA35\*\*-116316  
 0701 NA35\*\*-200041




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
67-B25		BRACKET, HARNESS			
NA01-67-B31	1	(MT)			
67-030		HARNESS, INSTRUMENT			
NA03-67-030C	1	(AT)			
NA01-67-030D A (NA01-67-030H)	1				-9701
NA02-67-030D A (NA02-67-030H)	1				-9701
NA01-67-030H AN(NA01-67-030K)	1				9701-9A01
NA02-67-030H AN(NA02-67-030K)	1				9701-9A01
NA01-67-030K	1	BASE, (W/O HEAD SPEAKER) (MT)			9A01-
NA02-67-030K	1	PKG-OPT, (W/HEAD SPEAKER) (MT)			9A01-

9701 NA35 HW-111969  
9A01 NA35 HW-122908

2 D15


6703 WIRING HARNESSES(DOOR,FLOOR/CEILING)

6703 -1 W WIRING HARNESSES(DOOR,FLOOR/CEILING)




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
67-190G		HARNESS, DOOR			
NA01-67-190 AN(NA01-67-190A)	2				-9701
NA02-67-190 AN(NA02-67-190A)	2				-9701
NA01-67-190A	2	PKG-OPT, (W/O POWER WIND,W/AU DIO)			9701-
NA02-67-190A	2	PKG-OPT, V-SPECIAL, (W/POWER WIND)			9701-
9701 NA35KH-111969					































① 18-996A 	② 67-CS1  99786-0612	③ 67-013A 	④ 67-013D 	⑤ 67-014F  99786-0620	⑥ 67-022 
⑦ 67-026 	⑧ 67-048A  99786-0612	⑨ 67-051E 	⑩ 	⑪ 67-051J 	⑫ 67-052H 
⑬ 67-062B  99786-0612	⑭ 67-073  90845-0612	⑮ 67-073A 	⑯ 67-073B  99940-0603	⑰ 67-074  99786-0612	⑱ 67-191 
⑲ 13-447C 	⑳ 14-726 	㉑ 45-961B 	㉒ 67-CT2 	㉓ 67-011C 	㉔ 67-072H  99786-0620
㉕ 67-076 	㉖ 68-865 				




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
13-447C		CLAMP, HOSE			
B61P-13-447	1				--9701
14-726		BAND			
N304-14-726	1				
18-996A		CLIP			
BF67-67-996	1				
45-961B		CAP			
H002-45-961	2				9401-
67-CS1		CLIP, HARNESS			
N001-67-CS1B AN(N001-67-CS1C)	1				-9601
N001-67-CS1C	1				9601-
67-CT2		CLIP, HARNESS			
NA01-67-CH5	1				
67-011C		CLIP			
E356-18-141	1				9701-
67-013A		CLIP			
UB42-67-013	1				
67-013D		PROTECTOR, HARNESS			
NA01-67-P54	3				
67-014F		PROTECTOR, HARNESS			
NA01-67-P71	1				
67-022		CLIP, HARNESS			
NA01-67-CW5A	4				
67-026		CLIP, HARNESS			
NA02-67-CW5A	4				
67-048A		CLIP, HARNESS			
NA01-67-CS1	1				

9401 NA35MM-100090  
 9601 NA35MM-106797  
 9701 NA35MM-111969

(THIS ILLUSTRATION CONSISTS OF 2 PAGES)


① 18-996A 	② 67-CS1  99786-0612	③ 67-013A 	④ 67-013D 	⑤ 67-014F  99786-0620	⑥ 67-022 
⑦ 67-026 	⑧ 67-048A  99786-0612	⑨ 67-051E 	⑩ 	⑪ 67-051J 	⑫ 67-052H 
⑬ 67-062B  99786-0612	⑭ 67-073  90845-0612	⑮ 67-073A 	⑯ 67-073D  99940-0603	⑰ 67-074  99786-0612	⑱ 67-191 
⑲ 13-447C 	⑳ 14-726 	㉑ 45-961B 	㉒ 67-CT2 	㉓ 67-011C 	㉔ 67-072H  99786-0620
㉕ 67-076 	㉖ 68-865 				

PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
67-051E UB42-67-051	1	CLIP			
67-051J G031-67-053A	2	CLIP			
67-052H G030-67-018A G030-67-018A	4 3	CLIP			-9701 9701-
67-062B NA02-67-CS1A	1	CLIP, HARNESS			
67-072H NA01-67-CS6	1	CLIP, ENGINE HARNESS			
67-073 UB73-67-073A	1	CLIP			
67-073A NA01-67-CH7	1	CLIP			
67-073B H261-67-073	1	CLIP			
67-074 NA01-67-CS5	2	CLIP, HARNESS			
67-076 NA01-67-CH8	1	CLIP, ENGINE HARNESS			
67-191 B300-67-HD1	4	GROMMET			
68-865 B003-68-865	8	FASTENER			
00		NA0 BLACK			
81		NA1 BEIGE			
9701 NA35MM-111969					




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
42-452A		GRUNT .T			-0904
0111-41-692	1				
42-453		PROTECTOR, CABLE			0904-
6048-42-453	1				
56-775A		CLIP, WASHER HOSE			
LA01-67-505A	1				
66-941A		CLIP			
GB08-66-941	4				
67-480		TANK, WASHER-FRONT			
NA01-67-480	1	BASE, (W/WASHER TANK 2.2L)			
NA04-67-480A	1	PKG-OPT, (W/WASHER TANK 4.5L)			
67-501E		PIPE, NOZZLE-FRONT WA SHER			-9601
NA04-67-501A AN(NA01-67-501A)	1				
67-502A		JOINT, HOSE			
NA01-67-502	2				
67-502B		JOINT, HOSE			
H001-67-502	1				
4116-67-502	1	PKG-OPT, (W/WASHER TANK 4.5L)			
67-502E		JOINT, ELBOW-W. TANK			
S084-67-502	1	PKG-OPT, (W/WASHER TANK 4.5L)			
67-504		HOSE 'C', WASHER			9601-
NA01-67-501A	1				
67-508		VALVE, CHECK			
FA54-67-508	1				

9601 NA35\*\*-106797  
0904 NA35\*\*-209115




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
67-510		NOZZLE, WASHER-F. WIND			
NA01-67-510	2				
67-521		BRACKET, WASHER TANK			
NA01-67-520	1	BASE, (W/WASHER TANK 2.2L)			
NA04-67-520	1	PKG-OPT, (W/WASHER TANK 4.5L)			
67-521A		BRACKET			
S095-67-521	1	PKG-OPT, (W/WASHER TANK 4.5L)			
76-671		TANK, WASHER			
NA01-67-481	1	BASE, (W/WASHER TANK 2.2L)			
NA04-67-481	1	PKG-OPT, (W/WASHER TANK 4.5L)			
76-672		PUMP, WASHER			
S084-76-672	1				
76-672A		CAP, TANK			
UB39-51-815	1				
76-677A		GROMMET, WASHER TANK			
S084-76-677	1				



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
67-321C NA01-67-321	1	ARM, WIPER-DRIVER SIDE			
67-321D NA02-67-321	1	ARM, WIPER-CO DRIVER SIDE			
67-330 BM90-67-330 A (BM90-67-330A)	1	BLADE, WIPER-FRONT			-9A01
67-330C BR71-67-330 NA02-67-330	1	BLADE (R), WIPER-FRONT			9A01-
67-350 NA01-67-340A	1	MOTOR, WIPER			-0701
NA04-67-340	1	(EXC COLD SPEC.)			-0701
NA01-67-340B	1	(COLD SPEC.)			0701-
NA04-67-340A	1	(EXC. COLD SPEC.)			0701-
NA12-67-340A	1	(W/AIR BAG+COLD SPEC.)			0701-
67-410 B455-67-369	4	BOLT			
76-601 NA01-67-360A	1	LINK, WIPER			
76-631 B490-67-331 A (BM90-67-331A)	1	RUBBER, BLADE-FRONT			-9A01
KA02-67-331A	1	(PASSENGER SIDE)			-9A01
BM90-67-331A	1	(DRIVER SIDE)			9A01-
NA02-67-331	1	(PASSENGER SIDE)			9A01-
76-641 LA01-67-395 A (LA01-67-395A)	2	COVER, WIPER ARM-FRONT			-9601
LA01-67-395A	2				9601-


9601 NA35\*\*-106797  
9A01 NA35\*\*-102908  
0701 NA35\*\*-200041



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
76-657		SHAFT, DRIVE NO. 1			
NA01-67-363	1				
76-658		SHAFT, DRIVE NO. 2			
NA01-67-364	1				
76-659		ARM NO. 1, LINK			
NA01-67-361	1				
76-659A		ARM NO. 2, LINK			
NA01-67-362	1				

6740 WIPER MOTOR COMPONENTS(FRONT)

COMPONENTS OF NA01-67-340B  
 NA04-67-340A  
 NA12-67-340A



6740 -1 \* WIPER MOTOR COMPONENTS(FRONT)




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
67-345	1	SCREW, EARTH SET-MOTOR BRK			
NA01-67-345	1				
67-346	2	SCREW, BRACKET-WIPER MOTOR			
NA01-67-346	2				
NA23-67-346	1				0701-
76-612	1	PLATE, HOLDER-BRUSH			
NA01-67-351	1	(EXC. COLD SPEC.)			--0701
NA04-67-351	1	(COLD SPEC.)			-0701
NA17-67-351	1	(W/O AIR BAG+COLD SPEC.)			0701-
NA23-67-351	1	(EXC. COLD SPEC.)			0701-
NA26-67-351	1	(W/AIR BAG+COLD SPEC.)			0701-
76-619	1	PARTS SET			
H043-76-619A	1				
76-661	1	GEAR, SHAFT			
B455-67-354	1	(EXC. COLD SPEC.)			-9801
NA04-67-354	1	(COLD SPEC.)			-9801
B455-67-354	1				9801-0701
GJ21-67-354	1	(W/O AIR BAG+COLD SPEC.)			0701-
NA23-67-354	1	(EXC. COLD SPEC.) (W/AIR BAG+COLD SPEC.)			0701-
76-662	1	WASHER			
B094-76-662	1				
76-663	1	WASHER, TOOTHED			
B094-76-663	1				

9801 NA35MM-116316  
 0701 NA35MM-200041



6820 FRONT HEADER TRIM & PILLAR TRIMS



6820 -1 \* FRONT HEADER TRIM & PILLAR TRIMS



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
68-AD2		CLIP			
B455-68-AD2	2				
68-061D		TRIM, FRONT HEADER			
NA01-68-090	1				-9330
00		NA0 BLACK			
NA01-68-090A	1				9330-
00		NA0 BLACK			
68-160		TRIM(R), 'A' PILLAR			
NA01-68-160	1				
00		NA0 BLACK			
68-160Z		TRIM(L), 'A' PILLAR			
NA01-68-170	1				
00		NA0 BLACK			
68-865S		CLIP TRIM			
GJ12-68-865	4				
68-865U		CLIP, TRIM			
GJ21-68-865	4				
9330 NA35MM-100072					



## SECTION NAME INDEX (BODY)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
2-C05	0900	KEY SETS	2-E12	6115	HEATER CONTROLS COMPONENTS	3-C03	7900	ACCESSORIES
2-E05	5000	FRONT BUMPER	2-F12	6120	HEATER BLOWER COMPONENTS			
2-H05	5010	REAR BUMPER	2-G12	6130	AIR CONDITIONER			
2-J05	5030	WINDOW MOULDING & COWL GRILLES	2-K12	6135	O RING SET, PIPING			
2-L05	5100	HEAD LAMPS	2-L12	6140	COMPRESSOR COMPONENTS (AIR CONDITIONER)			
2-M05	5103	HEAD LAMP RETRACTORS	2-N12	6150	COOLING UNIT (AIR CONDITIONER)			
2-D06	5105	FRONT COMBINATION LAMPS	2-C13	6300	WINDOW GLASSES			
2-F06	5110	REAR COMBINATION LAMPS	2-D13	6330	SUNROOF			
2-I06	5120	LICENSE LAMPS	2-M13	6600	SWITCHES & RELAYS (ENGINE)			
2-J06	5180	REAR FINISHER	2-D14	6610	DASHBOARD SWITCHES			
2-L06	5230	BONNET	2-E14	6611	COMBINATION SWITCH			
2-N06	5260	TRUNK LID	2-F14	6630	RELAYS & UNIT (BODY)			
2-D07	5310	BODY PANELS (FRONT)	2-G14	6635	DOOR SWITCH & HORNS			
2-E07	5320	BODY PANELS (FENDER & WHEEL ARCH)	2-H14	6640	AUTO CRUISE CONTROL SYSTEM			
2-H07	5330	BODY PANELS (DASH & COWL PANEL)	2-I14	6680	AUDIO SYSTEMS (RADIO & TAPE DECK)			
2-I07	5340	BODY PANELS (SIDE)	2-K14	6682	AUDIO SYSTEMS (ANTENNA & SPEAKER)			
2-C08	5370	BODY PANELS (FLOOR)	2-L14	6700	WIRING HARNESSSES (FRONT & REAR)			
2-F08	5380	FLOOR ATTACHMENTS (HOLE COVERS)	2-N14	6701	WIRING HARNESSSES (ENGINE & TRANSMISSION)			
2-G08	5390	FLOOR ATTACHMENTS	2-D15	6702	WIRING HARNESSSES (DASHBOARD)			
2-C09	5500	DASHBOARD EQUIPMENTS	2-E15	6703	WIRING HARNESSSES (DOOR, FLOOR/Ceiling)			
2-E09	5520	METER HOOD	2-F15	6704	WIRING HARNESS CLAMPS			
2-F09	5530	SPEEDOMETER CABLE	2-I15	6720	WINDSHIELD WASHER			
2-G09	5540	METER COMPONENTS	2-K15	6730	WINDSHIELD WIPERS			
2-I09	5560	DASHBOARD & RELATED PARTS	2-M15	6740	WIPER MOTOR COMPONENTS (FRONT)			
2-L09	5570	CONSOLE	2-N15	6820	FRONT HEADER TRIM & PILLAR TRIMS			
2-C10	5580	VENTILATOR	2-C16	6840	TRIMS & SCUFF PLATES			
2-D10	5700	SEATS	2-E16	6860	FLOOR MATS & PADS			
2-K10	5790	SEAT BELTS	2-G16	6870	SERVICE TOOLS			
2-L10	5800	FRONT DOORS	2-H16	6900	VISORS, ASSIST HANDLES & MIRRORS			
2-C11	5830	FRONT DOOR MECHANISMS	2-J16	6930	CAUTION PLATES & LABELS			
2-F11	5840	FRONT DOOR TRIMS & RELATED PARTS	2-L16	7250	QUARTER WINDOW & TRIMS			
2-C12	6100	HEATER						
2-D12	6110	HEATER UNIT COMPONENTS						










PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
68-320 NA01-68-3F1B	1	TRAY, REAR PACKAGE			
00		NA0 BLACK			
68-371 NA01-68-370	1	TRIM(R), FRONT SIDE			
00		NA0 BLACK			
68-371Z NA01-68-390	1	TRIM(L), FRONT SIDE			
00		NA0 BLACK			
68-402B FA54-68-719B	8	GROMMET, SCREW			
68-711 NA01-68-710	1	PLATE(R), FRONT SCUFF BASE, (PLASTIC TYPE)			
00		NA0 BLACK			
68-711Z NA01-68-720	1	PLATE(L), FRONT SCUFF BASE, (PLASTIC TYPE)			
00		NA0 BLACK			
68-712B B235-68-712	4	CLIP BASE, (PLASTIC TYPE)			
68-86Y KA01-68-86Y	3	CAP, SEAL-TRUNK END T RIM			
68-865C G032-68-865A	20	FASTENER			
00		NA0 BLACK			
68-865Q GJ21-68-885A AN(GJ21-68-885B)	9	FASTENER			-9526
00		NA0 BLACK			
GJ21-68-885B	9				9526-

9526 NA35MM-105742









PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
00		NAO BLACK			
68-865S		CLIP, TRIM			
GJ12-68-865	2				
68-890		TRIM, TRUNK END			
NA01-68-891	1				
00		NAO BLACK			


(a)	(b)	(c)	(d)	(e)	(f)
68-615B 	68-615B 	68-866C 	68-865C 	68-865D 	68-865 
(NA01-68-615)	(B100-68-615)				



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
68-6L1A NA01-68-6L1	1	COVER(R),HOLE			
68-6L6A NA01-68-6L6	1	COVER(L),HOLE			
68-6N2 NA01-68-6N2	2	INSULATOR,RR FLOOR			
68-6N4 NA01-68-6N4	1	PAD,RR FENDER			
68-615B B100-68-615 NA01-68-615	5 1	NUT,FLANGE-CAP			
68-630A NA01-68-631A A (NA01-68-631B) NA01-68-631B	1 1 1	INSULATOR,DASHBOARD			-0701 0701-
68-651F FB01-68-652	1	PAD,FRONT FLOOR			
68-664 NA01-68-664A	1	CUSHION,UNIT COVER			0701-
68-671A NA01-68-671 A (NA01-68-67XB) 00 NA01-68-67XB 00	1 1 1 1	MAT,FLOOR NA0 BLACK BLACK			-0401 0401-
68-693D NA01-68-693 00	1 1	MAT,REAR END (BLACK-USA) NA0 BLACK			
68-695 NA01-68-811	1	MAT,TRUNK ROOM			

0401 NA35\*\*-146561  
0701 NA35\*\*-200041


(a)	(b)	(c)	(d)	(e)	(f)
68-615B 	68-615B 	68-866C 	68-865C 	68-865D 	68-865 
(NA01-68-615)	(8100-68-615)				



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
00		NA0 BLACK			
68-819		COVER, BATTERY			
NA01-68-819B	1				
00		NA0 BLACK			
68-820A		COVER, SPARE TIRE			
NA01-68-8P9A	1				
68-865		FASTENER			
B003-68-865	2				
00		NA0 BLACK			
68-865C		FASTENER			
G032-68-865A	4				
00		NA0 BLACK			
68-865D		FASTENER			
S083-68-865A	6				
00		NA0 BLACK			
68-866C		FASTENER, SEAL			
B235-68-865A	6				
76-071		SILENCER, FLOOR			
0208-76-071	1	30CMX30CM			


6870 SERVICE TOOLS

6870 -1 M SERVICE TOOLS



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
68-070		WRENCH, HUB NUT			
0810-68-070D	1				-9421
NA01-68-070	1				9421-
68-660A		TOOL SET			
NA01-69-650	1				
68-670		BAG, TOOL			
8173-69-670	1				-9601
NA01-69-670	1				9601-


9421 NA35MM-101369  
 9601 NA35MM-106797



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
69-110A		MIRROR(R), DOOR			
NA05-69-120	1				
DU		DU MARINER BLUE			
HU		HU NEO GREEN			
SU		SU CLASSIC RED			
UC		UC CRYSTAL WHITE			
3L		3L SILVER STONE METALLIC			
69-110Y		MIRROR(L), DOOR			
NA05-69-180	1				
DU		DU MARINER BLUE			
HU		HU NEO GREEN			
SU		SU CLASSIC RED			
UC		UC CRYSTAL WHITE			
3L		3L SILVER STONE METALLIC			
69-170		MIRROR, INTERIOR			
NA01-69-220	1				
00		NA0 BLACK			
69-210		SUN VISOR(R)			
NA01-69-270A AN(NA01-69-270B)	1				-9601
02		NA0 BLACK			
NA01-69-270B	1				9601-
02		NA0 BLACK			
69-210Z		SUN VISOR(L)			
NA01-69-320B AN(NA01-69-320C)	1				-9601
02		NA0 BLACK			
NA01-69-320C	1	(W/AIR BAG)			9601-
02		NA0 BLACK			
NA07-69-320B	1	(W/O AIR BAG)			0701-
02		NA0 BLACK			


9601 NA35M\*-106797  
0701 NA35M\*-200041






PART NO	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
69-225		COVER, INTERIOR MIRROR			
GJ21-69-225	1				
00		NAO BLACK			
69-240A		BASE, INTERIOR MIRROR			
NA01-69-240	1				

2-116.




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
15-031		LABEL, CAUTION			
B660-15-031	1				
E508-15-031	1				
15-201		PLATE, CAUTION			
0488-15-201	1				
15-201A		LABEL, CAUTION-RADTOR			
8791-15-201	1				
57-K91		LABEL 'A', CAUTION-A/B			
NA01-57-K91	1	(W/AIR BAG)			-0701
57-K92		LABEL 'B', CAUTION-A/B			
NA01-57-K92	1	(W/AIR BAG)			-0701
67-MX1		LABEL, CAUTION-AIR BAG			
NA01-67-MX1	1	(W/AIR BAG)			
69-A13		RIVET, BUND-MODEL PLATE			
GJ21-69-A13	2				0701-
69-C61		LABEL, UNLEADED FUEL			
UB40-69-C61	1				
69-013		LABEL, OIL			
NA01-69-021A	1				-0201
A (NA01-69-021C)					
NA01-69-D21C	1				0201-
69-014		LABEL, TIRE			
NA01-69-014	1				
69-014A		LABEL, TEMPORARY TIRE			
BF68-69-073	1	ENGLISH			
69-021A		PLATE, CAUTION			
NA01-69-021A	1	(VIN PLATE-USA)			
69-041		LABEL, EMISSION			

0201 NA35\*\*-157180  
0701 NA35\*\*-230041



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
CONT'D					
NA01-69-036A	1				-9C20
A (NA01-69-036C)					
NA04-69-036A	1				-9C20
A (NA04-69-036B)					
NA01-69-036C	1	(CALIF)			9C20-0701
NA04-69-036B	1	(FED)			9C20-0701
NA01-69-036D	1	(CALIF)			0701-
NA04-69-036C	1	(FED)			0701-
69-044A		LABEL, VAC. DIAPHRAGM			
NA01-69-044	1	(CALIF)			-0701
69-064		LABEL, BATTERY			
FA01-69-064A	1	(W/BATTERY LABEL)			
FA03-69-C72A	1				-9728
A (FA03-69-C72A)					
FA03-69-C72A	1	(W/BATTERY LABEL)			9728-
9728 NA35MM-115823					
9C20 NA35MM-132500					
0701 NA35MM-200041					




PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
68-222A		COVER, HOLE			
NA01-68-222A	2				
00		NA0 NA1 BLACK			
68-520A		TRIM(R), QUARTER			
NA01-68-520A	1	BASE, (W/O DETACHABLE TOP)			
00		NA0 NA1 BLACK			
NA02-68-520A	1	OPTION, (W/DETACHABLE TOP)			
00		NA0 NA1 BLACK			
68-520Y		TRIM(L), QUARTER			
NA01-68-550A	1	BASE, (W/O DETACHABLE TOP)			
00		NA0 NA1 BLACK			
NA02-68-550A	1	OPTION, (W/DETACHABLE TOP)			
00		NA0 NA1 BLACK			
68-865Q		FASTENER			
GJ21-68-885A AN(GJ21-68-885B)	2				-9526-
00		NA0 BLACK			
GJ21-68-885B	2				9526-
00		NA0 BLACK			
68-865U		CLIP, TRIM			
GJ21-68-865	4				

9526 NA35MM-105742

# Parts Catalog

Mazda MX-5 MIATA  
U.S.A.  
( '90)




NA35\*\*100001-200000

Feb. '92 (FINAL)  
Catalog No. AU-NA01-07

**MAZDA**  
© 1992 Mazda Motor Corporation




















## LAYOUT OF CONTENTS

- The following is a typical example of the layout of contents on Mazda microfiche parts catalog:



















- |  |                            |                                     |
|--|----------------------------|-------------------------------------|
| (1) - Layout of contents               | (2) - Pictorial Index      | (3) - Master Section No. Index      |
| (4) - Section No. Index for the Column | (5) - Illustration & Text  | (6) - Part No. Index                |
| (7) - Alphabetical Index               | (8) - Model Identification | (9) - Vehicle Identification System |

# PICTORIAL INDEX

<p><b>1000</b></p>  <p><b>1010</b></p>  <p>CYLINDER HEAD &amp; COVER</p>	<p><b>1030</b></p>  <p>CYLINDER BLOCK</p>	<p><b>1040</b></p>  <p>OIL PAN &amp; TIMING COVER</p>	<p><b>1100</b></p>  <p>PISTON, CRANKSHAFT &amp; FLYWHEEL</p>	<p><b>1200</b></p>  <p>VALVE SYSTEM</p>
<p><b>SHORT ENGINE &amp; GASKET SETS</b></p> 	<p><b>ENGINE (1/2)</b></p> 			<p><b>1400</b></p>  <p>OIL PUMP &amp; FILTER</p>
<p><b>17 3900</b></p>  <p>Given in Chassis Group</p> <p>ENGINE &amp; T/MISSION MOUNTINGS</p>				<p><b>1600</b></p>  <p>CLUTCH DISC &amp; COVER (MANUAL)</p>
<p><b>16 1960</b></p>  <p>GASKET &amp; SEAL KIT (AUTOMATIC)</p>				<p><b>1700</b></p>  <p>TRANSMISSION CASE (MANUAL)</p>
<p><b>15 1950</b></p>  <p>MANUAL LINKAGE SYSTEM (AUTOMATIC)</p>	<p><b>14 1940</b></p>  <p>GOVERNOR, LOW &amp; REVERSE PISTON (AUTOMATIC)</p>	<p><b>13 1930</b></p>  <p>CLUTCH &amp; PLANETARY GEARS (AUTOMATIC)</p>	<p><b>12 1920 1925</b></p>  <p>TRANSMISSION CASE &amp; MAIN CONTROL SYSTEM (AUTOMATIC)</p>	<p><b>11 1910</b></p>  <p>TORQUE CONVERTER, OIL PUMP &amp; PIPINGS (AUTOMATIC)</p>
				<p><b>10 1720</b></p>  <p>CHANGE CONTROL SYSTEM (MANUAL)</p>




















As this illustration is prepared to be applicable to all models, some parts are different in specifications from the parts listed in this parts Catalog.

PICTORIAL INDEX

<p><b>1</b> 1300</p>  <p>INLET MANIFOLD</p>	<p><b>2</b> 1310</p>  <p>EXHAUST MANIFOLD</p>	<p><b>3</b> 1320</p>  <p>FUEL SYSTEM</p>	<p><b>4</b> 1325</p>  <p>FUEL DISTRIBUTOR</p>	<p><b>5</b> 1330</p>  <p>AIR CLEANER</p>	<p><b>6</b> 1364</p>  <p>THROTTLE BODY</p>	
<p><b>18</b> 4000</p>  <p>Given in Chassis Group</p> <p>EX. SYSTEM</p>	<p style="text-align: center;"><b>ENGINE (2/2)</b></p> 			<p><b>7</b> 1370</p>  <p>EMISSION CONTROL SYSTEM (INLET SIDE)</p>	<p><b>8</b></p>	
<p><b>17</b> 1850</p>  <p>BATTERY</p>				<p><b>9</b> 1399</p>  <p>CAP &amp; HOSE CLIP 'INLET &amp; EXHAUST SIDE'</p>		
<p><b>16</b> 1840</p>  <p>STARTER</p>				<p><b>10</b> 1500</p>  <p>COOLING SYSTEM</p>		
<p><b>15</b> 1830</p>  <p>ALTERNATOR</p>				<p><b>13</b> 1800</p>  <p>ENGINE ELECTRICAL SYSTEM</p>	<p><b>12</b></p>	<p><b>11</b> 1580</p>  <p>BRACKET, PULLEY &amp; BELT</p>
<p><b>14</b></p>						

As this illustration is prepared to be applicable to all models, some parts are different in specifications from the parts listed in this parts Catalog.













# PICTORIAL INDEX

<p><b>1</b> 2505</p>  <p>REAR PROPELLER SHAFT</p>	<p><b>2</b> 2550</p>  <p>REAR DRIVE SHAFTS</p>	<p>2600</p>  <p>REAR AXLE</p>	<p><b>3</b> 2610</p>  <p>REAR BRAKE MECHANISMS</p>	<p><b>4</b> 2710</p>  <p>REAR DIFFERENTIALS</p>	<p><b>5</b> 2800 2810</p>  <p>REAR SUSPENSION MECHANISMS REAR STABILIZER</p>
<p><b>16</b> 4600</p>  <p>CHANGE CONTROL SYSTEM (AUTOMATIC)</p>	<p><b>17</b> 1720</p> <p>Given in Engine Group</p>  <p>CHANGE CONTROL SYSTEM (MANUAL)</p>	<h2 style="margin: 0;">CHASSIS (1/2)</h2> 			<p>2801</p>  <p>REAR SPRING &amp; DAMPER</p>
<p><b>15</b> 4000</p>  <p>EXHAUST SYSTEM</p>				<p>2830</p>  <p>REAR LOWER ARMS &amp; SUB FRAME</p>	
<p><b>14</b> 3900</p>  <p>ENGINE &amp; T/MISSION MOUNTINGS</p>				<p><b>6</b> 3200</p>  <p>STEERING WHEEL</p>	
<p><b>13</b> 3410</p>  <p>CROSSMEMBER &amp; STABILIZER</p>				<p><b>7</b> 3210</p>  <p>STEERING COLUMN &amp; SHAFTS</p>	
<p><b>12</b> 3401</p>  <p>FRONT SPRING &amp; DAMPER</p>				<p>3400</p>  <p>FRONT SUSPENSION MECHANISMS</p>	<p><b>11</b> 3310</p>  <p>FRONT BRAKE MECHANISMS</p>

As this illustration is prepared to be applicable to all models, some parts are different in specifications from the parts listed in this parts Catalog



















# PICTORIAL INDEX

<p><b>1</b> 3700</p>  <p style="text-align: center;">TIRES &amp; JACK</p>	<p><b>2</b> 4140</p>  <p style="text-align: center;">CLUTCH RELEASE &amp; MASTER CYLINDERS (MANUAL TRANSMISSION)</p>	<p>4145</p>  <p style="text-align: center;">CLUTCH PIPINGS (MANUAL TRANSMISSION)</p>	<p><b>3</b> 4160</p>  <p style="text-align: center;">ACCELERATOR CONTROL SYSTEM</p>	<p><b>4</b> 4200</p>  <p style="text-align: center;">FUEL TANK</p>	<p><b>5</b> 4300</p>  <p style="text-align: center;">CLUTCH &amp; BRAKE PEDALS</p>
<h2 style="margin: 0;">CHASSIS (2/2)</h2> 					
<p><b>6</b> 4340</p>  <p style="text-align: center;">BRAKE MASTER CYLINDER &amp; POWER BRAKE</p>					
<p><b>7</b> 4360</p>  <p style="text-align: center;">BRAKE PIPINGS</p>					
<p><b>8</b> 4400</p>  <p style="text-align: center;">PARKING BRAKE SYSTEM</p>					
<p><b>9</b> 4500</p>  <p style="text-align: center;">FUEL PIPINGS</p>					
<p><b>11</b> 4370</p>  <p style="text-align: center;">ANTILOCK BRAKE SYSTEM</p>					




















As this illustration is prepared to be applicable to all models, some parts are different in specifications from the parts listed in this parts Catalog

PICTORIAL INDEX

<p><b>1</b> 0900</p>  <p>KEY SETS</p>	<p><b>2</b></p>	<p><b>3</b> 5100</p>  <p>HEAD LAMPS</p>	<p><b>4</b> 5103</p>  <p>HEAD LAMP RETRACTORS</p>	<p><b>5</b> 5105</p>  <p>FRONT COMBINATION LAMPS</p>	<p><b>6</b> 5110</p>  <p>REAR COMBINATION LAMPS</p>
<p><b>19</b> 6704</p>  <p>WIRING HARNESS CLAMPS</p>	<p><b>20</b> 6720</p>  <p>WINDSHIELD WASHER</p>	<p><b>21</b> 6730</p>  <p>WINDSHIELD WIPERS</p>			<p><b>7</b> 5120</p>  <p>LICENSE LAMPS</p>
<p><b>18</b> 6703</p>  <p>WIRING HARNESSES (DOOR, FLOOR/CEILING)</p>	<p><b>BODY (1/4)</b></p> 				<p><b>8</b></p>
<p><b>17</b> 6702</p>  <p>WIRING HARNESSES (DASHBOARD)</p>					<p><b>9</b></p>
<p><b>16</b> 6701</p>  <p>WIRING HARNESSES (ENGINE &amp; T/MISSION)</p>					<p><b>10</b> 6600</p>  <p>SWITCHES &amp; RELAYS (ENGINE)</p>
<p><b>15</b> 6700</p>  <p>WIRING HARNESSES (FRONT &amp; REAR)</p>					<p><b>14</b> 6640</p>  <p>AUTO CRUISE CONTROL SYSTEM</p>

















As this illustration is prepared to be applicable to all models, some parts are different in specifications from the parts listed in this parts Catalog

PICTORIAL INDEX

<p><b>1</b> 5000</p>  <p>FRONT BUMPER</p>	<p><b>2</b></p>	<p><b>3</b> 5010</p>  <p>REAR BUMPER</p>	<p><b>4</b> 5030</p>  <p>WINDOW MOULDING &amp; COWL GRILLES</p>	<p><b>5</b></p>	<p><b>6</b></p>
<p><b>20</b> 5840</p>  <p>FRONT DOOR TRIMS &amp; RELATED PARTS</p>	<p><b>21</b></p>	<p><b>22</b> 6300</p>  <p>WINDOW GLASSES</p>	<p><b>23</b> 6330</p>  <p>SUNROOF</p>	<p><b>24</b> 7900</p>  <p>ACCESSORIES</p>	<p><b>7</b></p>
<p><b>19</b> 5830</p>  <p>FRONT DOOR MECHANISMS</p>	<p><b>BODY (2/4)</b></p> 				<p><b>8</b> 5180</p>  <p>REAR FINISHER</p>
<p><b>18</b> 5800</p>  <p>FRONT DOORS</p>					<p><b>9</b> 5230</p>  <p>BONNET</p>
<p><b>17</b> 5390</p> <p>5380</p>  <p>FLOOR ATTACHMENTS</p>					<p><b>10</b> 5260</p>  <p>TRUNK LID</p>
<p><b>16</b> 5370</p>  <p>BODY PANELS (FLOOR)</p>	<p><b>15</b></p>	<p><b>14</b> 5340</p>  <p>BODY PANELS (SIDE)</p>	<p><b>13</b> 5330</p>  <p>BODY PANELS (DASH &amp; COWL PANEL)</p>	<p><b>12</b> 5320</p>  <p>BODY PANELS (FENDER &amp; WHEEL APRON)</p>	<p><b>11</b> 5310</p>  <p>BODY PANELS (FRONT)</p>




















As this illustration is prepared to be applicable to all models, some parts are different in specifications from the parts listed in this parts Catalog

PICTORIAL INDEX

<p><b>1</b> 5500</p>  <p>DASHBOARD EQUIPMENTS</p>	<p><b>2</b> 5520</p>  <p>METER HOOD</p>	<p><b>3</b> 5530</p>  <p>SPEEDOMETER CABLE</p>	<p><b>4</b> 5540</p>  <p>METER COMPONENTS</p>	<p><b>5</b> 5560</p>  <p>DASHBOARD &amp; RELATED PARTS</p>	<p><b>6</b> 5570</p>  <p>CONSOLE</p>	
<p><b>BODY (3/4)</b></p> 						<p><b>7</b></p>  <p>6120</p>  <p>6100</p>  <p>6110</p>  <p>6115</p> <p>HEATER</p>
 <p>6135</p>  <p>6140</p>  <p>6135 6150</p> <p>AIR CONDITIONER</p>						
				<p><b>10</b> 6611</p>  <p>COMBINATION SWITCH</p>	<p><b>9</b> 6610</p>  <p>DASHBOARD SWITCHES</p>	

As this illustration is prepared to be applicable to all models, some parts are different in specific areas from the parts listed in this parts Catalog.

PICTORIAL INDEX

<p><b>1</b> 5580</p>  <p>VENTILATOR</p>	<p><b>2</b> 5700</p>  <p>SEATS</p>	<p><b>3</b></p>	<p><b>4</b> 5790</p>  <p>SEAT BELTS</p>	<p><b>5</b> 6680</p>  <p>AUDIO SYSTEMS (RADIO &amp; TAPE DECK)</p>	<p><b>6</b> 6682</p>  <p>AUDIO SYSTEMS (ANTENNA &amp; SPEAKER)</p>						
<p><b>BODY (4/4)</b></p> 											
<p><b>17</b> 7250</p>  <p>REAR WINDOW GLASSES &amp; TRIMS</p>					<p><b>8</b></p>						
<table border="1"> <tr> <td data-bbox="203 1740 592 2039"> <p><b>16</b> 6930</p>  <p>CAUTION PLATES &amp; LABELS</p> </td> <td data-bbox="597 1740 977 2039"> <p><b>15</b> 6900</p>  <p>VISORS, ASSIST HANDLES &amp; MIRRORS</p> </td> <td data-bbox="983 1740 1371 2039"> <p><b>14</b> 6870</p>  <p>SERVICE TOOLS</p> </td> <td data-bbox="1377 1740 1751 2039"> <p><b>13</b></p> </td> <td data-bbox="1757 1740 2132 2039"> <p><b>12</b> 6860</p>  <p>FLOOR MATS &amp; PADS</p> </td> <td data-bbox="2137 1740 2525 2039"> <p><b>11</b></p> </td> </tr> </table>						<p><b>16</b> 6930</p>  <p>CAUTION PLATES &amp; LABELS</p>	<p><b>15</b> 6900</p>  <p>VISORS, ASSIST HANDLES &amp; MIRRORS</p>	<p><b>14</b> 6870</p>  <p>SERVICE TOOLS</p>	<p><b>13</b></p>	<p><b>12</b> 6860</p>  <p>FLOOR MATS &amp; PADS</p>	<p><b>11</b></p>
<p><b>16</b> 6930</p>  <p>CAUTION PLATES &amp; LABELS</p>	<p><b>15</b> 6900</p>  <p>VISORS, ASSIST HANDLES &amp; MIRRORS</p>	<p><b>14</b> 6870</p>  <p>SERVICE TOOLS</p>	<p><b>13</b></p>	<p><b>12</b> 6860</p>  <p>FLOOR MATS &amp; PADS</p>	<p><b>11</b></p>						

As this illustration is prepared to be applicable to all models, some parts are different in specific models from the parts listed in this parts catalog.

## SECTION NAME INDEX (ENGINE)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
1-C03	1000	SHORT ENGINE & GASKET SETS						
1-D03	1010	CYLINDER HEAD & COVER						
1-G03	1030	CYLINDER BLOCK						
1-I03	1040	OIL PAN & TIMING COVER						
1-K03	1100	PISTON, CRANKSHAFT & FLYWHEEL						
1-N03	1200	VALVE SYSTEM						
1-D04	1300	INLET MANIFOLD						
1-E04	1310	EXHAUST MANIFOLD						
1-F04	1320	FUEL SYSTEM						
1-H04	1325	FUEL DISTRIBUTOR						
1-I04	1330	AIR CLEANER						
1-K04	1364	THROTTLE BODY						
1-L04	1370	EMISSION CONTROL SYSTEM (INLET SIDE)						
1-M04	1399	CAP & HOSE CLIP (INLET & EXHAUST SIDE)						
1-N04	1400	OIL PUMP & FILTER						
1-C05	1500	COOLING SYSTEM						
1-G05	1580	BRACKET, PULLEY & BELT						
1-C06	1600	CLUTCH DISC & COVER (MANUAL)						
1-D06	1700	TRANSMISSION CASE (MANUAL)						
1-E06	1710	TRANSMISSION GEARS (MANUAL)						
1-J06	1720	CHANGE CONTROL SYSTEM (MANUAL)						
1-M06	1800	ENGINE ELECTRICAL SYSTEM						
1-C07	1830	ALTERNATOR						
1-E07	1840	STARTER						
1-G07	1850	BATTERY						
1-H07	1910	TORQUE CONVERTER, OIL PUMP & PIPINGS (AUTOMATIC)						
1-K07	1920	TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)						
1-E08	1925	CONTROL VALVE (AUTOMATIC)						
1-I08	1930	CLUTCHES & PLANETARY GEARS (AUTOMATIC)						
1-D09	1940	GOVERNOR, LOW & REVERSE PISTON (AUTOMATIC)						
1-G09	1950	MANUAL LINKAGE SYSTEM (AUTOMATIC)						
1-I09	1960	GASKET & SEAL KIT (AUTOMATIC)						

## SECTION NAME INDEX (CHASSIS)

LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
1-C11	2505	REAR PROPELLER SHAFT	1-J16	4400	PARKING BRAKE SYSTEM			
1-D11	2550	REAR DRIVE SHAFT	1-L16	4500	FUEL PIPINGS			
1-E11	2600	REAR AXLE	2-C03	4600	CHANGE CONTROL SYSTEM (AT)			
1-F11	2610	REAR BRAKE MECHANISMS						
1-H11	2710	REAR DIFFERENTIALS (NORMAL DIFF.)						
1-L11	2710 A	REAR DIFFERENTIALS (LIMITED SLIP DIFF.)						
1-D12	2800	REAR SUSPENSION MECHANISMS						
1-E12	2801	REAR SPRING & DAMPER						
1-F12	2810	REAR STABILIZER						
1-G12	2830	REAR LOWER ARMS & SUB FRAME						
1-I12	3200	STEERING WHEEL						
1-L12	3210	STEERING COLUMN & SHAFTS						
1-M12	3220	STEERING GEAR (W/O POWER STEERING)						
1-C13	3220 A	STEERING GEAR (W/ POWER STEERING)						
1-F13	3240	POWER STEERING SYSTEM						
1-H13	3300	FRONT AXLE						
1-I13	3310	FRONT BRAKE MECHANISMS						
1-K13	3400	FRONT SUSPENSION MECHANISMS						
1-M13	3401	FRONT SPRING & DAMPER						
1-N13	3410	CROSSMEMBER & STABILIZER						
1-C14	3700	TIRES & JACK						
1-C15	3900	ENGINE & T/MISSION MOUNTINGS						
1-D15	4000	EXHAUST SYSTEM						
1-F15	4140	CLUTCH RELEASE & MASTER CYLINDERS (MANUAL TRANSMISSION)						
1-G15	4145	CLUTCH PIPINGS (MANUAL TRANSMISSION)						
1-H15	4160	ACCELERATOR CONTROL SYSTEM						
1-I15	4200	FUEL TANK						
1-M15	4300	CLUTCH & BRAKE PEDALS (MANUAL TRANSMISSION)						
1-D16	4300A	BRAKE PEDALS (AUTOMATIC TRANSMISSION)						
1-F16	4340	BRAKE MASTER CYLINDER & POWER BRAKE						
1-H16	4360	BRAKE PIPINGS						

## SECTION NAME INDEX (BODY)


LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME	LO.NO	SEC.NO	SECTION NAME
2-C05	0900	KEY SETS	2-E12	6115	HEATER CONTROLS COMPONENTS	3-C03	7900	ACCESSORIES
2-E05	5000	FRONT BUMPER	2-F12	6120	HEATER BLOWER COMPONENTS			
2-H05	5010	REAR BUMPER	2-G12	6130	AIR CONDITIONER			
2-J05	5030	WINDOW MOULDING & COWL GRILLES	2-K12	6135	O RING SET, PIPING			
2-L05	5100	HEAD LAMPS	2-L12	6140	COMPRESSOR COMPONENTS (AIR CON DITIONER)			
2-M05	5103	HEAD LAMP RETRACTORS	2-N12	6150	COOLING UNIT (AIR CONDITIONER)			
2-D06	5105	FRONT COMBINATION LAMPS	2-C13	6300	WINDOW GLASSES			
2-F06	5110	REAR COMBINATION LAMPS	2-D13	6330	SUNROOF			
2-I06	5120	LICENSE LAMPS	2-M13	6600	SWITCHES & RELAYS (ENGINE)			
2-J06	5180	REAR FINISHER	2-D14	6610	DASHBOARD SWITCHES			
2-L06	5230	BONNET	2-E14	6611	COMBINATION SWITCH			
2-N06	5260	TRUNK LID	2-F14	6630	RELAYS & UNIT (BODY)			
2-D07	5310	BODY PANELS (FRONT)	2-G14	6635	DOOR SWITCH & HORNS			
2-E07	5320	BODY PANELS (FENDER & WHEEL AP RON)	2-H14	6640	AUTO CRUISE CONTROL SYSTEM			
2-H07	5330	BODY PANELS (DASH & COWL PANEL )	2-I14	6680	AUDIO SYSTEMS (RADIO & TAPE DE CK)			
2-I07	5340	BODY PANELS (SIDE)	2-K14	6682	AUDIO SYSTEMS (ANTENNA & SPEAK ER)			
2-C08	5370	BODY PANELS (FLOOR)	2-L14	6700	WIRING HARNESSSES (FRONT & REAR )			
2-F08	5380	FLOOR ATTACHMENTS (HOLE COVERS )	2-N14	6701	WIRING HARNESSSES (ENGINE & T/MI SSION)			
2-G08	5390	FLOOR ATTACHMENTS	2-D15	6702	WIRING HARNESSSES (DASHBOARD)			
2-C09	5500	DASHBOARD EQUIPMENTS	2-E15	6703	WIRING HARNESSSES (DOOR, FLOOR/CE ILING)			
2-E09	5520	METER HOOD	2-F15	6704	WIRING HARNESS CLAMPS			
2-F09	5530	SPEEDOMETER CABLE	2-I15	6720	WINDSHIELD WASHER			
2-G09	5540	METER COMPONENTS	2-K15	6730	WINDSHIELD WIPERS			
2-I09	5560	DASHBOARD & RELATED PARTS	2-M15	6740	WIPER MOTOR COMPONENTS (FRONT)			
2-L09	5570	CONSOLE	2-N15	6820	FRONT HEADER TRIM & PILLAR TRI MS			
2-C10	5580	VENTILATOR	2-C16	6840	TRIMS & SCUFF PLATES			
2-D10	5700	SEATS	2-E16	6860	FLOOR MATS & PADS			
2-K10	5790	SEAT BELTS	2-G16	6870	SERVICE TOOLS			
2-L10	5800	FRONT DOORS	2-H16	6900	VISORS, ASSIST HANDLES & MIRROR S			
2-C11	5830	FRONT DOOR MECHANISMS	2-J16	6930	CAUTION PLATES & LABELS			
2-F11	5840	FRONT DOOR TRIMS & RELATED PAR TS	2-L16	7250	QUARTER WINDOW & TRIMS			
2-C12	6100	HEATER						
2-D12	6110	HEATER UNIT COMPONENTS						




## SECTION NAME INDEX (BODY)

LD.NO	SEC.NO	SECTION NAME	LD.NO	SEC.NO	SECTION NAME	LD.NO	SEC.NO	SECTION NAME
2-C05	0900	KEY SETS	2-E12	6115	HEATER CONTROLS COMPONENTS	3-C03	7900	ACCESSORIES
2-E05	5000	FRONT BUMPER	2-F12	6120	HEATER BLOWER COMPONENTS			
2-H05	5010	REAR BUMPER	2-G12	6130	AIR CONDITIONER			
2-J05	5030	WINDOW MOULDING & COWL GRILLES	2-K12	6135	O RING SET, PIPING			
2-L05	5100	HEAD LAMPS	2-L12	6140	COMPRESSOR COMPONENTS (AIR CON DITIONER)			
2-M05	5103	HEAD LAMP RETRACTORS	2-N12	6150	COOLING UNIT (AIR CONDITIONER)			
2-D06	5105	FRONT COMBINATION LAMPS	2-C13	6300	WINDOW GLASSES			
2-F06	5110	REAR COMBINATION LAMPS	2-D13	6330	SUNROOF			
2-I06	5120	LICENSE LAMPS	2-M13	6600	SWITCHES & RELAYS (ENGINE)			
2-J06	5180	REAR FINISHER	2-D14	6610	DASHBOARD SWITCHES			
2-L06	5230	BONNET	2-E14	6611	COMBINATION SWITCH			
2-H06	5260	TRUNK LID	2-F14	6630	RELAYS & UNIT (BODY)			
2-D07	5310	BODY PANELS (FRONT)	2-G14	6635	DOOR SWITCH & HORNS			
2-EC7	5320	BODY PANELS (FENDER & WHEEL AP RON)	2-H14	6640	AUTO CRUISE CONTROL SYSTEM			
2-H07	5330	BODY PANELS (DASH & COWL PANEL )	2-I14	6680	AUDIO SYSTEMS (RADIO & TAPE DE CK)			
2-I07	5340	BODY PANELS (SIDE)	2-K14	6682	AUDIO SYSTEMS (ANTENNA & SPEAK ER)			
2-C08	5370	BODY PANELS (FLOOR)	2-L14	6700	WIRING HARNESSSES (FRONT & REAR )			
2-F08	5380	FLOOR ATTACHMENTS (HOLE COVERS )	2-N14	6701	WIRING HARNESSSES (ENGINE & T/MI SSION)			
2-G08	5390	FLOOR ATTACHMENTS	2-D15	6702	WIRING HARNESSSES (DASHBOARD)			
2-C09	5500	DASHBOARD EQUIPMENTS	2-E15	6703	WIRING HARNESSSES (DOOR, FLOOR/CE ILING)			
2-E09	5520	METER HOOD	2-F15	6704	WIRING HARNESS CLAMPS			
2-F09	5530	SPEEDOMETER CABLE	2-I15	6720	WINDSHIELD WASHER			
2-G09	5540	METER COMPONENTS	2-K15	6730	WINDSHIELD WIPERS			
2-I09	5560	DASHBOARD & RELATED PARTS	2-M15	6740	WIPER MOTOR COMPONENTS (FRONT)			
2-L09	5570	CONSOLE	2-N15	6820	FRONT HEADER TRIM & PILLAR TRI MS			
2-C10	5580	VENTILATOR	2-C16	6840	TRIMS & SCUFF PLATES			
2-D10	5700	SEATS	2-E16	6860	FLOOR MATS & PADS			
2-K10	5790	SEAT BELTS	2-G16	6870	SERVICE TOOLS			
2-L10	5800	FRONT DOORS	2-H16	6900	VISORS, ASSIST HANDLES & MIRROR S			
2-C11	5830	FRONT DOOR MECHANISMS	2-J16	6930	CAUTION PLATES & LABELS			
2-F11	5840	FRONT DOOR TRIMS & RELATED PAR TS	2-L16	7250	QUARTER WINDOW & TRIMS			
2-C12	6100	HEATER						
2-D12	6110	HEATER UNIT COMPONENTS						





PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
V1-350 0000-88-5590	1	COVER, TONNEAU			
V3-460 NA01-V3-460	1	FLAP, REAR-MUD			
V3-840 0000-88-0014	1	TRIM RING SET			
M5					
V3-841 0000-88-0014	4	TRIM RING			
01					
V4-830 0000-88-5305	1	DECK RACK			
BK		BLACK			
CM		CHROME			
V4-900A 0000-86-510A	1	AIRDAM SKIRT, FRONT			
V4-920A 0000-86-2290	1	REAR SPOILER			
V4-930A 0000-86-710A	1	REAR UNDER SKIRT			
V7-511 0000-88-1905	1	SECURITY SYSTEM			
V7-513 0000-88-1905	1	REMOTE VPGRADE KIT			
RC					
V7-514 0000-88-1905	1	REMOTE TRANSMITTER			
RR					



PART NO.	QTY	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
V9-270 NA01-V9-270	1	CHROME VALVE COVER			

### PART NUMBER INDEX

This index is listed in the following sequence.

### GENERAL PARTS

#### EXAMPLE

- ① Model/Type  
Third, in the sequence of model/types (1st-4th digits)
- ② Group  
First, in the sequence of group (5th & 6th digits)
- ③ Part  
Second, in the sequence of part (7th-9th digits)

### INDEX DES NOMBRES DE PIÈCES

Cet index a été composé selon la séquence suivante.

### PIÈCES GÉNÉRALES

#### EXEMPLE

- ① Modèle/type  
Troisièmement, séquence du modèle/type (1er à 4ème chiffres)
- ② Groupe  
Premièrement, séquence du groupe (5ème et 6ème chiffres)
- ③ Pièce  
Deuxièmement, séquence de la pièce (7ème à 9ème chiffres)

### NUMERO INDICE DE PIEZA

Este indice se ordena en la siguiente secuencia.

### PIEZAS GENERALES

#### EJEMPLO

- ① Tipo de modelo  
Tercero, en la secuencia de tipo de modelo (entre las cifras 1ro-4to lugar)
- ② Grupo  
Primero, en la secuencia de grupo (las cifras en 5to y 6to lugar)
- ③ Pieza  
Segundo, en la secuencia de pieza (entre las cifras 7mo-9no lugar)

### TEILENUMMERN

Die Teilenummern setzen sich wie folgt zusammen.

### ALLGEMEINE TEILE

#### BEISPIEL

- ① Modell/Typ  
Angabe des Modells bzw. Typs (1 bis 4. Ziffer)
- ② Baugruppe  
Angabe der Baugruppe (5. und 6. Ziffer)
- ③ Teil  
Angabe des Teils (7. bis 9. Ziffer)

①            ②            ③  
┌───┬───┬───┐  
B A 0 1    6 0    3 5 0

### STANDARD PARTS

Standard Parts are listed in numerical sequence after General Parts.  
(Note: Those parts which do not have D-Code are not listed in the index.)

### PIÈCES STANDARD

Les pièces standard sont énumérées selon une séquence numérique, après les pièces générales.  
(Remarque: Les pièces qui ne possèdent pas de code D ne sont pas mentionnées dans cet index.)

### PIEZAS NORMALES

Las piezas normales se numeran secuencialmente después de las Piezas generales.  
(Nota: Las piezas que no tienen un código D no están en el índice.)

### STANDARDTEILE

Die Standardteile sind nach den allgemeinen Teilen mit fortlaufender Numerierung aufgeführt.  
(Hinweis: Teile ohne D-Code sind nicht aufgeführt.)



PART NUMBER INDEX / INDEX DES NUMEROS DE PIECES / TEILENUMMER-INDEX / INDICE DE NUMERO DE PARTES

M502-17-261	1-F6	M502-17-476A	1-K6	B61P-18-10XB	1-M6	BU01-19-256	1-K7	BV04-19-533	1-L8	0338-19-768	1-E8	B61P-20-361	1-G4
M503-17-262	1-F6	M514-17-480	1-K6	B61P-18-10XC	1-M6	BU01-19-257	1-K7	BU03-19-534	1-L8	BU01-19-771	1-E8	B61P-20-371	1-L4
F401-17-264A	1-F6	M514-17-480A	1-K6	BP01-18-110	1-M6	0338-19-258	1-I7	0338-19-534	1-D9	0338-19-772	1-E8	B61P-20-490	1-F4
G401-17-264	1-F6	M505-17-482	1-L6	BP02-18-110	1-M6		1-K7		1-L8	0338-19-773	1-E8	B61P-20-600	1-D15
G501-17-265A	1-F6	M504-17-490A	1-L6	BP03-18-110	1-M6	BV11-19-3C4	1-K7	BV01-19-540A	1-L8	BU55-19-774	1-E8	B61P-20-660	1-K4
M502-17-265A	1-F6	0183-17-491	1-L6	BP04-18-110	1-M6	BU55-19-3C8	1-K7	BV04-19-560	1-L8	BU55-19-775	1-E8		
M504-17-265	1-F6	M501-17-501	1-L6	BP05-18-110	1-M6	BU55-19-3F3	1-L7	BV04-19-565	1-L8	0338-19-777	1-E8	*****	
M504-17-265A	1-F6	M524-17-510A	1-L6	BP06-18-110	1-M6	BU55-19-310A	1-K7	BV04-19-566	1-L8	0338-19-778	1-E8	* 21-000 *	
M516-17-271	1-F6	M515-17-520	00 1-L6	B61P-18-140B	1-M6	BU01-19-332A	1-K7	BU02-19-567	1-L8	1758-19-781	1-E8	*****	
0259-17-274A	1-F6	0884-17-530	1-D6	E356-18-141	2-G15	0338-19-336	1-D9	BV01-19-570A	1-L8	0338-19-782	1-E8		
8540-17-275A	1-G6	M509-17-540	1-D6	B61P-18-160B	1-M6	0338-19-337	1-D9	BV04-19-581	1-D9	BU55-19-785	1-E8		
0259-17-276	1-F6	M501-17-540	1-D6	B61P-18-170B	1-M6	0338-19-338	1-D9	0338-19-590	1-D9	BU55-19-786	1-E8		
0259-17-277	1-F6	M504-17-540	1-L6	B61P-18-180B	1-M6	0338-19-341	1-K7	0338-19-591	1-D9	BU55-19-787	1-F8		
0259-17-278	1-G6	M517-17-540	1-H6	B61P-18-190B	1-N6	0338-19-360B	1-J8	0338-19-593	1-D9	FT21-19-788	1-F8		
0259-17-279	1-G6	M505-17-540	1-I6	B61P-18-2FOA	2-M13	0338-19-361B	1-L7	0338-19-594	1-D9	FT13-19-789	1-F8		
M509-17-281	1-G6	M505-17-621	1-I6	B61P-18-2FOB	2-N13	BU17-19-363	1-L7	0338-19-595	1-D9	FT27-19-791A	1-F8		
M509-17-281A	1-G6	8601-17-629	1-I6	B61P-18-230	2-M13	BU20-19-368	1-L7	0338-19-596	1-E9	FT37-19-792	1-F8		
4069-17-283A	1-F6	0884-17-632B	1-I6	B61P-18-251	2-C14	BU06-19-381	1-L7	0338-19-598	1-M8	0338-19-793A	1-F8		
4069-17-284E	1-F6	0884-17-633B	1-I6	B61R-18-266	1-N6	BV03-19-381	1-L7	BT08-19-600	1-E9	0338-19-795B	1-F8		
M502-17-295C	1-E6	0884-17-634B	1-I6	B61R-18-266A	1-N6	BU10-19-384	1-L7	0338-19-603	1-E9	0338-19-797	1-F8		
M502-17-297A	1-G6	0884-17-635B	1-I6	B61P-18-300D	1-C7	BU55-19-384	1-L7	0338-19-604	1-E9	0338-19-798	1-F8		
M502-17-298A	1-G6	M506-17-640	2-M13	B64J-18-300A	1-C7	FT03-19-385	1-L7	0338-19-606	1-E9	BV01-19-8A3	1-F8		
M502-17-299A	1-H6	1391-17-640	2-M13	B61P-18-360	1-N6	0842-19-385	1-L7	0338-19-607	1-E9	BV01-19-8B1	1-F8		
M528-17-301	1-G6	8118-17-640A	2-M13	B61P-18-360A	1-N6	0338-19-386A	1-L7	0338-19-609	1-E9	0338-19-801	1-F8		
M512-17-302	1-G6	8118-17-640B	2-M13	F201-18-363	1-G5	0338-19-388A	1-L7	BU17-19-610	1-E9	0338-19-802	1-F8		
M512-17-302A	1-G6	M501-17-651	1-I6		1-N6	0338-19-389	1-L7	1758-19-613	1-E9	BU01-19-803A	1-F8		
M501-17-304B	1-G6	M501-17-652	1-I6	B6S7-18-381A	1-N6	BU06-19-391	1-L7	1758-19-614	1-E9	BU55-19-805	1-G8		
M504-17-304	1-G6	M501-17-653	1-I6	B6S7-18-381B	1-N6	1758-19-392A	1-L7	1758-19-615	1-E9	BU01-19-807	1-G8		
0839-17-305B	1-G6	M501-17-654	1-I6	B61R-18-400	1-E7	0842-19-394	1-L7	1758-19-616	1-E9	BU17-19-807	1-G8		
R502-17-306A	1-E6	M501-17-655	1-I6	B61R-18-400A	1-E7	1758-19-394A	1-M7	1758-19-617	1-E9	0338-19-808	1-G8		
M510-17-308	1-H6	W501-17-724	1-I6	B61P-18-410	1-N6	0338-19-395	1-M7	1758-19-618	1-E9	BU10-19-811	1-G8		
M501-17-309	1-H6	V501-17-725	1-I6	B660-18-411C	1-N6	0338-19-397	1-D9	0338-19-619	1-E9	0338-19-814	1-G8		
M509-17-310	1-H6	W501-17-732A	1-I6	B61P-18-501	2-M13	1758-19-397	1-M7	0338-19-621	1-M8	BU01-19-815	1-G8		
M509-17-310A	1-H6	W501-17-732B	1-I6	B541-18-51X	2-M13	0338-19-398	1-M7	FT01-19-622	1-E9	0338-19-816	1-G8		
M501-17-313	1-H6	*****		B61R-18-520A	1-G7	BU67-19-431	1-G9		1-M8	0338-19-817	1-G8		
4077-17-314A	1-H6	*****		B61R-18-520B	1-G7	0338-19-432	1-G9	0338-19-623	1-M8	0338-19-818	1-G8		
4077-17-315A	1-H6	* 18-000 *		B61P-18-524	1-G7	BU55-19-440	1-G9	0338-19-623A	1-M8	0338-19-819	1-G8		
M504-17-316	1-J6	*****		B61P-18-526	1-G7	BU55-19-444A	2-N13	0338-19-624	1-M8	BU55-19-821	2-C14		
R502-17-316	1-H6	*****		JE16-18-741	2-M13	0338-19-446	2-C14	0338-19-631	1-M8	0338-19-822	1-M7		
4077-17-316	1-H6	*****		B64J-18-780A	2-M13	0338-19-449	1-G9	0338-19-632	1-M8	BU55-19-823	1-M7		
8086-17-326	1-D6	F885-18-T41	2-M13	B64J-18-780B	2-M13	BU17-19-450	1-G9	0338-19-633	1-M8	BU55-19-825	1-M7		
0305-17-327	1-H6	B366-18-W10	1-D7	B6S8-18-811	2-N13	BU55-19-460	1-J8	0338-19-634	1-M8	0338-19-825	1-M7		
0305-17-328	1-H6	RF71-18-W20	1-D7	N236-18-821	2-N13	BU55-19-470	1-J8	0338-19-635	1-M8	0338-19-826	1-M7		
M5Y1-17-330	1-D6	B61P-18-W25	1-C7	N350-18-840	2-N13	0338-19-475	1-J8	0338-19-636	1-M8	0338-19-827	1-N7		
M507-17-335	1-D6	RF71-18-W26	1-D7	8574-18-840	2-N13	BV01-19-476	1-J8	0338-19-639	1-M8	0338-19-828	1-N7		
	1-K7	F811-18-W27	1-C7	B61R-18-861A	2-N13	0338-19-476	1-J8	0338-19-641	1-M8	0338-19-829	1-N7		
M503-17-341	1-H6	B366-18-W35	1-D7	FE30-18-867A	2-N13	BV01-19-480	1-J8	0338-19-642	1-M8	0338-19-831	1-N7		
1281-17-341	1-D9	B366-18-W35A	1-D7	B61P-18-881A	2-N13	0338-19-480	1-J8	0338-19-643	1-M8	0338-19-832	1-N7		
0114-17-351	1-J6	B61P-18-W35	1-D7	B64J-18-881	2-N13	0338-19-486	1-J8	0338-19-644	1-M8	0338-19-833	1-N7		
M503-17-402	1-J6	N336-18-W36	1-C7	B61P-18-882	2-N13	0338-19-487	1-J8	0338-19-645	1-N8	0338-19-835B	1-N7		
M501-17-404B	1-J6	B366-18-W45	1-C7	B61P-18-883	2-N13	0338-19-488	1-J8	0338-19-646	1-N8	0338-19-836A	1-N7		
M504-17-406A	1-J6	G608-18-W45	1-C7	B61P-18-884	2-N13	BU17-19-498	1-J8	0338-19-647	1-N8	0338-19-837	1-N7		
M503-17-411	1-J6	B61P-18-W50	1-C7	B61P-18-885	2-N13	0338-19-498	1-J8	0338-19-648	1-N8	BU27-19-838	1-J7		
0014-17-411	1-J6	B64J-18-W50	1-C7	B61P-18-889A	2-N13	BU55-19-499	1-J8	BU55-19-650	1-F9	1758-19-838	2-C14		
0103-17-411	1-J6	B366-18-W51	1-C7	B6S8-18-911	1-K4	FT01-19-499	1-J8	0338-19-655	1-F9	BU55-19-870	1-N7		
M507-17-412	1-J6	B675-18-W59	1-C7	B630-18-911	1-K4	BU55-19-5J0	1-J8	BU55-19-660	1-F9	BU17-19-880B	1-N7		
3648-17-415	1-J6	B366-18-W60	1-C7	*****		BV01-19-5K0	1-D9	BU55-19-661	1-F9	BU55-19-890	1-N7		
M501-17-416	1-J6	B61P-18-W60	1-C7	* 19-000 *		BU17-19-500	1-K8	0338-19-663	1-F9	0338-19-904A	1-I7		
M504-17-416	1-J6	B61P-18-W70	1-C7	*****		1758-19-503	1-K8	0338-19-664	1-F9	BU55-19-910A	1-I7		
M505-17-416	1-J6	FF2H-18-W77	1-C7	*****		3959-19-503	1-K8	BU55-19-665	1-F9	BU17-19-917	1-I7		
M503-17-421	1-J6	N337-18-W80	1-D7	*****		1758-19-504	1-K8	BU55-19-666	1-F9	BU55-19-920B	1-I7		
M507-17-422	1-J6	B61R-18-X00	1-E7	*****		3959-19-504	1-K8	0338-19-667	1-F9	BU55-19-920C	1-I7		
M506-17-431	1-K6	F210-18-X01	1-F7	BU55-19-020	1-H7	BV02-19-505	1-K8	BU55-19-670	1-F9	BU55-19-930B	1-I7		
M506-17-431A	1-K6	E356-18-X05	1-E7	FU60-19-025	1-H7	1758-19-505	1-K8	0338-19-676	1-F9	BU55-19-930C	1-I7		
M508-17-432	1-K6	E356-18-X10	1-F7	BU55-19-031	1-G9	3959-19-505	1-K8	BUY2-19-7A0	1-M7	BU55-19-933A	1-I7		
R502-17-435	1-K6	E356-18-X30	1-E7	FT31-19-063	1-H7	BV02-19-506	1-K8	0338-19-701A	1-G9	BU55-19-934A	1-I7		
BU55-17-441	1-K7	B630-18-X45	1-E7	FT31-19-064	1-H7	3959-19-506	1-K8	0338-19-702A	1-G9	BU55-19-970A	1-J7		
1472-17-441A	1-D6	B6S8-18-X60	1-E7	FU51-19-065	1-H7	BV02-19-507	1-K8	0338-19-703	1-G9	BU29-19-980	1-J7		
BU55-17-442	1-K7	F210-18-X60	1-E7	BUY2-19-090	1-H7	3759-19-507	1-K8	0338-19-704	1-G9	BU55-19-980A	1-N7		
1669-17-442B	1-D6	B61R-18-X65	1-E7	BUY2-19-090A	1-H7	BV02-19-508	1-K8	0338-19-706	1-G9	BU29-19-985	1-J7		
1011-17-443	1-D6	B630-18-X66	1-F7	BU55-19-100	1-H7	3959-19-508	1-K8	BU55-19-710	1-M7	BV01-19-986	1-N7		
	1-K7	B660-18-X66	1-F7	BU55-19-211	1-H7	BV01-19-509	1-K8	0338-19-731	1-G9	*****			
M516-17-450	1-K6	B61R-18-X70	1-F7	BU01-19-215	1-H7	0338-19-509	1-K8	BU17-19-732	1-G9	* 22-000 *			
M508-17-461	1-K6	E356-18-X80	1-E7	BU01-19-216	1-H7	3959-19-509	1-K8	0338-19-733C	1-G9	*****			
UJ98-17-462A	1-K6	E356-18-X81	1-E7	BU55-19-217	1-H7	BV01-19-510	1-L8	0338-19-734A	1-H9	* 20-000 *			
R501-17-47X	1-L6	B630-18-X90	1-E7	BU55-19-220	1-H7	1758-19-511	1-L8	0338-19-735	1-M7	*****			
M510-17-470B	1-K6	E356-18-X92	1-E7	BU55-19-223	1-I7	BV04-19-530	1-L8	0338-19-737	1-M7	*****			
M510-17-470C	1-K6	E356-18-X95	1-E7	0338-19-223A	1-I7	BV04-19-531	1-L8	0338-19-739	1-M7				
M501-17-474	1-K6</												



PART NUMBER INDEX / INDEX DES NUMEROS DE PIECES / TEILENUMMER-INDEX / INDICE DE NUMERO DE PARTES

M090-22-550	1-D11	T025-27-100J	1-L11	0259-27-408	1-J11	NA01-32-AZ2A	1-L12	NA02-32-609	1-F13	NA01-34-170	1-H12		
*****		T020-27-110B	1-H11		1-N11	G238-32-C24	1-F13	N002-32-609	1-F13	NA01-34-200	1-N13	*****	
* 24-000 *		T002-27-120A	1-L11	T020-27-409A	1-C12	NA01-32-019	1-J12	N002-32-610	1-F13	NA01-34-200A	1-K13	* 41-000 *	
*****		T002-27-120B	1-H11	0259-27-409	1-K11	B461-32-020	1-J12	N002-32-613	1-F13	8871-34-222	1-C15	*****	
8599-24-521	1-C7	T002-27-120B	1-H11		1-N11	B461-32-030	1-J12	B456-32-615	1-F13	NA01-34-300A	1-H12		
8028-24-533	1-D7	3919-27-130	1-L11	0259-27-411	1-J11	NA01-32-049	1-J12	B456-32-616	1-F13	NA01-34-350A	1-K13	0727-41-023	1-M15
0222-24-752A	1-F7	T020-27-150C	1-H11		1-N11	NA01-32-090A	1-L12	NA02-32-680	1-G13	NA01-34-460A	1-L13	NA01-41-030B	1-M15
*****		T020-27-150D	1-M11	0259-27-412	1-J11	NA01-32-090B	1-L12	NA02-32-682	1-G13	NA01-34-460A	1-L13	0727-41-061	1-M15
* 25-000 *		T020-27-150D	1-H11	0259-27-413	1-N11	NA02-32-090B	1-L12	NA02-32-684B	1-G13	NA01-34-480A	1-L13	NA01-41-070A	1-M15
*****		T020-27-158A	1-M11		1-N11	NA07-32-090A	1-L12	NA02-32-690	1-G13	NA01-34-490	1-L13	BR70-41-081	1-M15
* 25-000 *		T020-27-159A	1-I11	0259-27-414	1-J11	NA08-32-090A	1-L12	B461-32-740	1-J12	NA01-34-548	1-L13	B092-41-081	1-D16
*****		T020-27-159A	1-M11		1-N11	B455-32-099	1-L12	B461-32-750	1-J12	NA01-34-550	1-L13	B104-41-114	1-H15
M091-25-100	1-C11	T020-27-165	1-I11	0259-27-415	1-J11	NA01-32-100B	1-L12	B461-32-800A	1-J12	NA01-34-700	1-M13	NA01-41-130A	1-H15
N010-25-123	1-C11	T020-27-171	1-M11		1-N11	NA07-32-100A	1-L12	NA01-32-850	1-L12	NA01-34-800	1-N13	0824-41-131	1-M15
1368-25-124	1-D11	T020-27-171	1-I11	T001-27-431	1-C12	NA02-32-11X	1-C13	G030-32-961	1-E13	NA01-34-800A	1-N13	NA01-41-140B	1-M15
1456-25-125	1-C11	T016-27-200A	1-M11		1-K11	NA01-32-110	1-M12	B461-32-980	1-J12	*****		0750-41-308	1-J16
F001-25-421A	1-H11	T016-27-200B	1-M11	T020-27-600E	1-C12	NA02-32-110	1-C13	NA01-32-980B	1-J12	* 37-000 *		H266-41-341	1-F15
0755-27-210	1-L11	0755-27-210	1-H11	T020-27-600E	1-K11	GJ21-32-111	1-M12	NA02-32-980B	1-J12	*****		NA01-41-360A	1-G15
M090-25-500	1-D11	3919-27-220	1-H11	T020-27-600F	1-C12	NA02-32-112	1-C13	*****		*****		NA01-41-370A	1-G15
*****		T005-27-231	1-I11	G0A0-27-604A	1-C12	NA02-32-114	1-C13	* 33-000 *		B002-37-160	1-C14	NA02-41-370	1-G15
* 26-000 *		3919-27-235	1-I11	M0A1-27-609A	1-C12	G030-32-115	1-M12	*****		B455-37-190	1-C14	8871-41-370	1-G15
*****		3919-27-236	1-M11	*****		NA02-32-115	1-C13	NA01-33-000A	1-H13	B001-37-190	1-C14	GK67-41-380A	1-G15
0730-26-060	1-H11	T020-27-238	1-I11	* 28-000 *		NA01-32-118	1-M12	NA01-33-030A	1-H13	NA01-37-192	1-C14	NA01-41-390	1-G15
B455-26-071	1-H13	F035-27-251	1-I11	*****		NA01-32-119	1-M12	NA01-33-04X	1-H13	8BN1-37-600	1-D14	NA01-41-400A	1-F15
NA01-26-130	1-E11	F001-27-252	1-I11	*****		NA01-32-120	1-M12	NA01-33-042A	1-E11	8BN3-37-600	1-D14	NA01-41-443	1-D16
NA01-26-130A	1-E11	F001-27-253	1-I11	*****		NA02-32-120	1-C13	B455-33-047A	1-E11	B455-37-790	1-E14	B312-41-470	1-F15
NA01-26-140	1-E11	F001-27-254	1-I11	*****		NA02-32-121	1-C13	H260-33-048	1-E11	B455-37-790A	1-E14	NA01-41-610	1-H15
NA01-26-140A	1-E11	T020-27-255	1-I11	*****		NA01-32-122	1-M12	B455-33-061	1-E11	J21-37-810	1-E14	NA01-41-610A	1-H15
0603-26-161	1-C14	F001-27-261A	1-I11	*****		NA01-32-123	1-M12	B455-33-062	1-F11	*****		NA02-41-610	1-H15
NA01-26-251A	1-E11	C114-27-262	1-I11	NA01-28-011B	1-E12	NA02-32-123	1-C13	G304-33-065	1-E11	NA01-39-020	1-C15	NA02-41-610A	1-H15
NA01-26-261	1-E11	T005-27-270B	1-J11	NA03-28-011	1-E12	NA01-32-124	1-M12	NAY0-33-23ZA	1-I13	*****		NA01-41-619	1-H15
NA01-26-261A	1-E11	T015-27-270	1-M11	G030-28-013A	1-D12	NA02-32-124	1-C13	NA01-33-23Z	1-I13	* 39-000 *		B092-41-644	1-H15
NA10-26-28X	1-F11	T015-27-280	1-M11	B037-28-091	1-G12	NA02-32-125	1-C13	NAY1-33-23ZA	1-I13	*****		0259-41-644	1-H15
NA10-26-29X	1-F11	0180-27-301A	1-J11	LA01-28-091	1-K13	G030-32-126	1-M12	NAY1-33-24Z	1-J13	NA01-39-040	1-C15	NA01-41-660A	1-H15
NAY1-26-43Z	1-F11	0180-27-301A	1-J11	NA01-28-111	1-D12	HE01-32-126	1-D13	NA01-33-25X	1-H13	NA01-39-041	1-C15	B092-41-661	2-H14
NAY1-26-44Z	1-G11	0290-27-302	1-M11	NA01-28-113	1-K13	NA02-32-126	1-D13	NAY1-33-25Z	1-J13	NA01-39-041	1-C15	1456-41-682	1-M15
BWH-26-45Z	1-G11	0249-27-350	1-M11	NA02-32-134	1-D13	NA01-32-127	1-M12	NA01-33-261	1-H13	NA03-39-710	1-C15	*****	
BWOH-26-668	1-F11	T020-27-401A	1-J11	NA02-32-135	1-C13	NA01-32-128	1-M12	NA01-33-271	1-H13	NA01-39-721	1-C15	* 42-000 *	
BWOH-26-669	1-F11	0259-27-401	1-N11	G030-32-136	1-N12	NA02-32-128	1-C13	NA01-33-281	1-I13	NA01-39-722	1-C15	*****	
BWOH-26-68C	1-F11	T020-27-401A	1-J11	S030-32-137	1-N12	NA01-32-129	1-M12	NA01-33-291	1-I13	NA01-39-723	1-C15	BC88-42-045	1-I15
BWOH-26-683	1-F11	0259-27-401	1-N11	S083-32-137	1-M12	NA02-32-129	1-C13	NA01-33-61X	1-I13	NA01-39-724	1-C15	NA01-42-110	1-I15
BWOH-26-691	1-G11	T020-27-402A	1-K11	HA14-32-146	1-N12	NA02-32-130	1-C13	B001-33-691	1-I13	NA01-39-730	1-C15	NA01-42-110A	1-I15
BWOH-26-700	1-F11	0259-27-402	1-N11	G030-32-147	1-N12	NA02-32-131	1-C13	0259-33-691	1-F15	NA01-39-730A	1-C15	NA03-42-110	1-I15
BWOH-26-731	1-F11	T020-27-403A	1-K11	NA02-32-147	1-D13	NA02-32-132	1-C13	0259-33-693	1-F15	*****		NA01-42-210	1-I15
BWOH-26-733	1-F11	0259-27-403	1-J11	D002-32-148	1-D13	NA01-32-133	1-M12	NA01-33-699	1-I13	* 40-000 *		NA01-42-230	1-I15
BWOH-26-800	1-F11	T020-27-403A	1-K11	NA02-32-151	1-D13	NA02-32-134	1-D13	NA01-33-71X	1-I13	*****		NA01-42-233	1-I15
BWOH-26-810	1-F11	0259-27-404	1-N11	NA02-32-152	1-D13	NA02-32-135	1-C13	NA01-33-980A	1-I13	RF03-40-061	1-D15	NA01-42-241	1-I15
BWOH-26-812	1-F11	T020-27-404	1-N11	NA02-32-153	1-D13	G030-32-136	1-N12	NA01-33-990	1-I13	B690-40-080A	1-D15	NA01-42-241B	1-I15
BWOH-26-816	1-F11	0259-27-404	1-N11	NA02-32-154	1-D13	S030-32-137	1-N12	NA01-33-990A	1-I13	B684-40-100A	1-E15	NA01-42-249	1-I15
BWOH-26-851	1-G11	T020-27-405A	1-K11	NA02-32-180	1-D13	HE01-32-129	1-M12	*****		B684-40-100B	1-E15	NA01-42-249B	1-I15
BWOH-26-861	1-G11	0259-27-405	1-J11	HE01-32-201	1-N12	NA01-28-092	1-G12	* 34-000 *		B690-40-100E	1-E15	NA02-42-250	1-I15
NA01-26-980A	1-G11	T020-27-406A	1-K11	NA01-28-092	1-G12	NA01-28-111	1-D12	*****		B690-40-100F	1-E15	GB53-42-270	1-J15
NAU1-26-990A	1-G11	0259-27-406	1-N11	NA01-28-113	1-G12	NA01-28-113	1-K13	NA01-34-011A	1-M13	B322-40-305	1-D15	H260-42-270	1-J15
BWOH-26-998A	1-G11	T020-27-406A	1-N11	NA02-32-134	1-D13	NA01-28-113	1-K13	NA03-34-011	1-M13	0690-40-305	1-D15	NA01-42-291A	1-J15
*****		0259-27-407	1-N11	NA02-32-135	1-C13	NA01-28-113	1-K13	B690-40-356	1-D15	JE10-40-355	1-D15	0223-42-307	1-M4
* 27-000 *		T020-27-407A	1-K11	NA02-32-154	1-D13	NA01-28-113	1-K13	B690-40-450	1-D15	2158-40-355	1-D15	0866-42-366B	1-I15
*****		0259-27-407	1-N11	NA02-32-180	1-D13	NA01-28-113	1-K13	B690-40-500A	1-D15	B6A5-40-356	1-D15	NA01-42-410	1-J15
3919-27-012	1-H11	T020-27-408A	1-K11	HE01-32-201	1-N12	NA01-28-113	1-K13	B690-40-690	1-D15	NA01-34-019	1-K13	NA01-42-410A	1-J15
T020-27-100H	1-H11		1-N11	NA01-28-448	1-K13	NA01-28-440	1-G12	NA01-34-09XA	1-N13	NA01-34-112	1-K13	H043-42-431D	1-J15
T020-27-100J	1-H11		1-N11	NA01-28-460	1-G12	NA01-28-480	1-G12	FB01-34-091	1-H12	NA01-34-117A	1-K13	B048-42-453	2-I15
T020-27-100K	1-H11		1-N11	NA01-28-473	1-G12	NA01-28-800B	1-G12	NA01-34-156A	1-N13	NA01-34-151A	1-N13	NA01-42-561	1-J15
T025-27-100F	1-L11		1-N11	NA01-28-800	1-G12	NA01-28-880B	1-G12	NA01-34-155	1-N13	NA01-34-155A	1-N13	NA03-42-562	1-J15
T025-27-100G	1-L11		1-N11	GJ21-28-89X	2-E7	NA01-28-890	1-C12	NA01-34-155	1-N13	NA01-34-155A	1-N13	NA03-42-563	1-J15
T025-27-100H	1-L11		1-N11	NA01-28-890	1-C12	*****		NA01-34-156A	1-N13	NA01-34-156A	1-N13	NA03-42-564	1-J15
				*****		* 32-000 *						NA01-42-761	1-K15
				*****		*****							
				*****		NA01-32-AZ0A	1-L12						
				*****		NA01-32-AZ1B	1-L12						





PART NUMBER INDEX / INDEX DES NUMEROS DE PIECES / TEILENUMMER-INDEX / INDICE DE NUMERO DE PARTES

B491-55-431	2-H9	NA01-56-294	2-H8	NA01-57-630C00	2-K10	B156-59-240	2-L10	NA01-61-B15	2-F12	NA02-61-472	2-H12	NA01-64-452 00	2-M9
NA01-55-431	2-G9	NA01-56-311	2-G8	NA01-57-631B00	2-K10	NA01-59-310B	2-C11	NA01-61-B20	2-F12	NA02-61-472A	2-H12	NA01-64-481	2-M9
NA01-55-432	2-G9	NA01-56-321	2-G8	NA01-57-680 00	2-K10	G030-59-315	2-C5	NA01-61-C04	2-E12	NA01-61-474	2-H12	NA01-64-481A	2-M9
NA01-55-437	2-G9	NA01-56-34XA	2-G7	NA01-57-690A00	2-K10		2-C7	H260-61-C09	2-E12	NA02-61-474A	2-H12	H001-64-493	2-M9
NA01-55-441	2-G9	NA01-56-34XC	2-G7	NA07-57-690 00	2-K10		2-E11	NA01-61-C25	2-E12	NA02-61-476	2-I12	FB01-64-495	2-M9
NA01-55-441A	2-G9	NA01-56-34YA	2-G7			NA01-59-330A00	2-C11	NA01-61-C35	2-E12	NA01-61-480	2-I12	NA01-64-610 00	2-D9
NA01-55-441B	2-G9	NA01-56-34YC	2-G7	*****		B001-59-335	2-C11	NA01-61-C45	2-E12	UB39-61-486A	2-I12	NA01-64-612	2-D9
NA01-55-442	2-H9	NA01-56-351	2-H7	* 58-000 *		NA01-59-410A	2-D11	NA01-61-C50	2-E12	NA01-61-487	2-I12	NA01-64-613	2-D9
NA01-55-442A	2-H9	G211-56-355A	2-H7	* ***** *		NA01-59-410B	2-D11	NA01-61-C95	2-E12	NA01-61-500	2-I12	NA01-64-617 00	2-D9
NA01-55-442B	2-H9	B001-56-376	2-K13			NA01-59-410C	2-D11	NA02-61-C95	2-E12	NA01-61-52YA	2-I12	NA01-64-618	2-D9
NA03-55-442A	2-H9	NA01-56-39Y	2-I7			NA01-59-510	2-M10	NA03-61-C95	2-E12	NA01-61-522	2-I12	NA01-64-622	2-D9
NA03-55-442B	2-H9	NA01-56-411	2-H8			NA01-59-560B	2-D11	NA01-61-C22	2-E12	NA01-61-520B	2-N12	NA01-64-623 00	2-D9
NA01-55-446	2-H9	NA01-56-451	2-H8	NAY1-58-020	2-L10	NA02-59-560B	2-D11	NA01-61-J01	2-N12	NA01-61-526	2-I12	NA01-64-741	2-C10
NA01-55-446A	2-H9	0208-56-615	2-F8	NA01-58-030	2-L10	NA01-59-603A	2-M10	NA01-61-J02	2-N12	NA01-61-529	2-I12	NA01-64-81X 00	2-C10
NA01-55-461	2-H9	NA01-56-620A	2-L6	NA01-58-030A	2-L10	NA01-59-604B	2-M10	NA01-61-J04	2-N12	NA01-61-546B	2-I12	NA01-64-841	2-C10
NA01-55-461A	2-H9	LA01-56-631	2-L6	B092-58-201	2-L10	NA01-59-651A	2-M10	GJY1-61-J1X	2-K12	FB04-61-557	2-I12	NA01-64-905 00	2-K9
NA03-55-461	2-H9	NA01-56-650	2-L6	B092-58-201A	2-L10	NA01-59-661	2-M10	GJY2-61-J1X	2-K12	BF67-61-558	2-J12	NA01-64-912 00	2-K9
NA03-55-461A	2-H9	G030-56-693	2-L6	FB01-58-210	2-L10	NA01-59-760C	2-N10	GJY3-61-J1X	2-K12	BF67-61-559	2-J12	GJ21-64-996	2-K9
NA01-55-471	2-H9	NA01-56-720A	2-L6	BA54-58-225	2-L10	NA01-59-760D	2-N10	NA01-61-J10	2-N12	NA01-61-695	2-J12	W201-64-999	2-K9
NA01-55-471A	2-H9	NA01-56-720B	2-L6	B455-58-225	2-L10	NA01-59-810B	2-F11	NA01-61-J14	2-N12	NA01-61-710	2-J12	*****	
				S085-58-225	2-M10	NA01-59-810C	2-F11	NA01-61-J15	2-N12	B111-61-731	2-J12	* 66-000 *	
NA01-55-476	2-H9	NA01-56-720C	2-L6	GJ21-58-226	2-L10	NA01-59-810D	2-F11	NA01-61-J20	2-N12	*****		* ***** *	
NA01-55-481	2-H9	H260-56-724	2-H7	NA01-58-226	2-L10	NA01-59-861A	2-E11	NA02-61-K00	2-L12	* 62-000 *		* ***** *	
BR70-55-490	2-C9	NA01-56-760	2-M6	B156-58-240	2-L10	NA02-59-861A	2-E11	NA02-61-K10	2-L12				
NA01-55-491	2-H9	NA01-56-772	2-I7	H260-58-265C	2-C11			NA02-61-K11	2-L12				
B455-55-561	2-I9	NA01-56-78X	2-L6	NA01-58-270A	2-C11			NA02-61-K12	2-L12				
*****		NA01-56-784	2-N6	NA01-58-303 00	2-C11	*****		FO65-61-K19	2-L12				
* 56-000 *		B481-56-786	2-N6	NA01-58-310B	2-C11	* 60-000 *		NA02-61-K2X	2-L12				
* ***** *		FB01-56-787A	2-L6	G030-58-315	2-C5			NA02-61-K23	2-L12				
		NA01-56-787	2-L6					NA02-61-K24	2-L12				
		NA01-56-802	2-N6	NA01-58-330A00	2-C11			FO65-61-K25	2-L12				
		NA01-56-803	2-N6	FB01-58-335	2-C11			NA02-61-K28	2-L12				
		NA01-56-805	2-N6	B092-58-355	2-D11			FO65-61-K31	2-L12				
NA01-56-03XA	1-G7	NA01-56-820	2-N6	B001-58-361A	2-D11	NA01-60-070A	2-F9	NA02-61-K35	2-L12				
B095-56-032	1-G7	NA01-56-820A	2-N6	NA71-58-410A	2-D11	NA01-60-070B	2-F9	NA02-61-K39	2-M12				
NA01-56-032A	1-G7	NA01-56-840	2-C7	NA01-58-410B	2-D11	NA03-60-070	2-F9	NA02-61-L10	2-M12				
NA01-56-033A	1-G7	NA01-56-850A	1-J15	NA01-58-410C	2-D11	UB40-60-071	2-F9	FO65-61-L11	2-M12				
BOC1-56-051	2-F8	B095-56-890A	1-J15	BR75-58-492	2-C5	NA01-60-075	2-F9	NA02-61-L12	2-M12				
NA01-56-051	2-F8	NA01-56-890A	1-K15	LA02-58-493	2-C5	B092-60-076A	1-D6	FO65-61-L13	2-M12				
		NA01-56-896	1-J15	B235-58-502	2-M10	NA01-60-121	2-C10	NA02-61-L14	2-M12				
1011-56-051	2-F8	NA01-56-951	2-C7	UB39-58-502A	2-M10	NA01-60-141	2-C10						
				B092-58-505	2-M10	NA01-60-161 00	2-C10	FO65-61-L16	2-M12				
B092-56-052	2-F8	NA01-56-971	2-I7	NA01-58-510	2-M10	NA01-60-171 00	2-C10	1708-61-031	2-G12				
8545-56-052	2-F8	*****		NA01-58-560B	2-L11	NA01-60-183	2-C10	NA01-61-130	2-D12				
B092-56-053	2-F8	* 57-000 *		NA02-58-560B	2-D11	NA01-60-193	2-C10	NA01-61-130A	2-D12				
8545-56-053	2-F8			B092-58-569	2-D11	NA01-60-220 00	2-C9	NA01-61-140A	2-F12				
FB01-56-056	2-F8			B092-58-580 00	2-D11	NA01-60-223 00	2-D9	NA01-61-150	2-C12				
NA01-56-111	2-G8			B001-58-582A00	2-D11	NA01-60-230A00	2-C9	NA01-61-150A	2-C12				
NA01-56-111A	2-G8			B001-58-585	2-E11	NA01-60-35X 00	2-I9	NA01-61-161	2-C10				
NA01-56-111B	2-G8			NA01-58-603A	2-M10	NA01-60-350 00	2-I9	NA01-61-161A	2-E12				
NA01-56-111C	2-G8	NA01-57-K00A00	1-K12	NA01-58-604B	2-M10	B092-60-376	2-L9	NA01-61-191	2-E12				
NA01-56-112	2-G8	NA01-57-K10G	1-K12	NA01-58-651A	2-M10	NA01-60-401800	2-I9	NA01-61-193	2-G12				
NA01-56-131A	2-G7	NA01-57-K10H	1-K12	NA01-58-661	2-M10	NA01-60-401C00	2-I9	NA01-61-195	2-E12				
B455-56-135	2-G8	NA01-57-K2XJ	1-K12	NA01-58-760C	2-N10	NA01-60-407	2-I9	NA01-61-197	2-G12				
LA01-56-135	2-E7	NA01-57-K40D	1-K12	NA01-58-760D	2-N10	B092-60-408	2-I9	NA01-61-211	2-C12				
NA01-56-141A	2-G7	NA01-57-K45B	1-K12	G031-58-762	2-N10	NA01-60-409	2-I9	NA01-61-212	2-C12				
NA01-56-141C	2-G7	NA01-57-K46B	1-K12	1011-58-772	2-F11	NA01-60-420D	2-I9	NA01-61-212A	2-C12				
NA01-56-145	1-K12	NA01-57-K47B	1-K12			NA01-60-430A	2-J9	8871-61-219A	2-C12				
		NA01-57-K92A	1-K12			NA01-60-430B	2-J9	NA01-61-253	2-C10				
B455-56-149	2-G7	NA01-57-K92B	1-K12	NA01-58-810B	2-F11	NA01-60-430C	2-J9	NA01-61-4H1	2-G12				
		NA01-57-K91	2-J16	NA01-58-810C	2-F11	NA01-60-435	2-J9	NA01-61-4J4	2-G12				
				NA01-58-810D	2-F11								
B001-56-1 0C	1-E14	NA01-57-K92	2-J16	B156-58-815	2-F11	NA01-60-462	2-J9	NA01-61-435	2-I12	B092-64-046	2-I9	H118-66-470	1-D16
NA01-56-171A	2-G8	B455-57-05X	2-E10	B157-58-815	2-F11	NA01-60-462A	2-J9	NA02-61-450A	2-M12			BR70-66-490A	1-E16
G030-56-176	1-K15	UB40-57-05X	2-E10	NA01-58-815	2-F11	NA01-60-463	2-J9	BR71-61-46Y	2-G12				1-N15
NA01-56-181A	1-K12	NA01-57-100B00	2-E10	NA01-58-821	2-F11	NA01-60-960	1-K15	BR76-61-46Y	2-G12			B001-66-490A	1-C16
		NA01-57-100D00	2-E10	NA02-58-821	2-F11	NA01-60-962	1-G4	BR77-61-46Y	2-G12				1-E16
NA01-56-191A	1-J12	NA01-57-100E00	2-E10	NA01-58-861A	2-E11	*****		NA01-61-46YA	2-G12				1-M15
		NA01-57-100F00	2-E10	NA02-58-861A	2-E11	* 61-000 *		NA01-61-46YB	2-G12				2-G14
1219-56-211	1-E14	NA02-57-100B00	2-E10	B092-58-863A	2-E11	*****		NA01-61-461B	2-G12				2-G14
NA01-56-221A	2-D7	NA02-57-100D00	2-E10	H272-58-911	2-N10			NA01-61-462C	2-G12				2-L14
NA01-56-221B	2-D7	NA02-57-100E00	2-E10	*****				NA01-61-466	2-H12				2-L14
NA01-56-241A	2-G8	NA02-57-100F00	2-E10	* ***** *				NA02-61-466B	2-H12				2-L14
NA01-56-241B	2-G8	NA01-57-150B00	2-E10	* 59-000 *				NA02-61-466C	2-H12				2-L14
0118-56-241	2-F8	NA01-57-150D00	2-F10					NA01-61-467A	2-H12				2-L14
		NA01-57-150E00	2-F10					NA01-61-467B	2-H12				2-N14
8477-56-241	2-F8	NA01-57-150F00	2-F10	*****				NA01-61-467C	2-H12				2-N14
0118-56-242B	2-C11	NA02-57-150B00	2-E10					NA01-61-468A	2-H12				2-N14
		NA02-57-150D00	2-F10	NAY1-59-020	2-L10			NA02-61-470A	2-H12				2-G14
NA01-56-260	1-K15	NA02-57-150E00	2-F10	NA01-59-030	2-L10			NA02-61-470B	2-H12				2-F14
NA01-56-29XC	2-G8	NA02-57-150F00	2-F10	NA01-59-030A	2-L10			BF67-61-471	2-H12				1-G7
NA01-56-290C	2-H8	NA01-57-620 00	2-K10	FB01-59-210	2-L10			NA01-61-472	2-H12				2-K14



PART NUMBER INDEX / INDEX DES NUMEROS DE PIECES / TEILENUMMER-INDEX / INDICE DE NUMERO DE PARTES

99655-30025	1-C14
99655-30030	1-D14
99655-30035	1-D14
99655-30040	1-D14
99655-30045	1-D14
99655-30050	1-D14
99655-30055	1-D14
99655-30060	1-D14
99655-90005	1-D14
99655-90010	1-D14
99655-90015	1-D14
99655-90020	1-D14
99655-90025	1-D14
99655-90030	1-D14
99655-90035	1-D14
99655-90040	1-D14
99655-90045	1-D14
99655-90050	1-D14
99655-90055	1-D14
99655-90060	1-D14
99700-7180	2-F6
99701-2070	2-I6
99701-3270	2-F6
99701-4276	2-F6
99701-4278Y	2-E6
99701-5050	2-C9
99701-6030	2-G9
99701-6038	2-D6
	2-F6
99705-1130	2-L14
	2-N14
99963-6310	1-G6
99963-6315	1-G6
99963-6330	1-G6

## ALPHABETICAL INDEX \*\*\* ENGLISH \*\*\*

***** * * A * * *****	ACTUATOR, A.C.C.----- 2-H14 ACTUATOR, SHIFT LOCK----- 2-C3 ADAPTER, DRIVE PLATE----- 1-H7 ADJUSTER NO. 3----- 2-H10 ADJUSTER NO. 4----- 2-H10 ADJUSTER, HYDRAULIC LASH-- 1-N3 ADJUSTER, NO. 1----- 2-G10 ADJUSTER, NO. 2----- 2-G10 AIRDAM SKIRT, FRONT----- 3-C3 ALTERNATOR----- 1-C7 ARM NO. 1, LINK----- 2-L15 ARM NO. 2, LINK----- 2-L15 ARM(L), LOWER----- 1-L13 ARM(L), LOWER-REAR----- 1-G12 ARM(R), LOWER----- 1-K13 ARM(R), LOWER-REAR----- 1-G12 ARM, UPPER-FRT----- 1-K13 ARM, UPPER-REAR----- 1-G12 ARM, WIPER-CD DRIVER SIDE-- 2-K15 ARM, WIPER-DRIVER SIDE---- 2-K15 ARMATURE----- 1-E7 ARMATURE, MAGNET CLUTCH--- 2-M12 AUDIO SET----- 2-I14	BODY----- 1-F9 BODY & PISTON(L), CALIPER-- 1-I13 BODY & PISTON(R), CALIPER-- 1-I13 BODY(L), FRONT DOOR----- 2-L10 BODY(R), FRONT DOOR----- 2-L10 BODY, CONTROL VALVE-UP---- 1-E2 BODY, LOW-RADIO ANTENNA--- 2-K14 BODY, THROTTLE----- 1-K4 BODY, VALVE LWR----- 1-G8 BOLT----- 1-C8 BOLT----- 1-C11 BOLT----- 1-D9 BOLT----- 1-E3 BOLT----- 1-E13 BOLT----- 1-F11 BOLT----- 1-F13 BOLT----- 1-G8 BOLT----- 1-G9 BOLT----- 1-G12 BOLT----- 1-H7 BOLT----- 1-I3 BOLT----- 1-I7 BOLT----- 1-J7 BOLT----- 1-K13 BOLT----- 1-M6 BOLT----- 1-M7 BOLT----- 1-N12 BOLT----- 1-N13 BOLT----- 2-E5 BOLT----- 2-F5 BOLT----- 2-H5 BOLT----- 2-K15 BOLT----- 2-M13 BOLT SET----- 1-E7 BOLT-HEX. HD WASHER----- 2-C14 BOLT, ADJUST----- 1-G5 BOLT----- 1-G12 BOLT----- 1-K13 BOLT----- 1-M6 BOLT, AIR CLEANER----- 1-I4 BOLT, AIR CON.----- 2-J12 BOLT, ANCHOR END----- 1-K7 BOLT, BEARING CAP----- 1-G3 BOLT, BUFFLE PLATE----- 1-Y7 BOLT, CAMSHAFT CAP----- 1-D3 BOLT, CARRIER----- 1-C12 BOLT, CLAMP----- 1-J7 BOLT, COMPRESSOR----- 2-L12 BOLT, COMPRESSOR-AIR CON.- 2-L12 BOLT, CONNECTOR----- 1-F16 BOLT, CLAMP----- 1-H16 BOLT----- 1-J7 BOLT, CONTROL LINK----- 1-G12 BOLT, CONTROL VALVE----- 1-N7 BOLT, CROSS MEMBER----- 2-E7 BOLT, CYLINDER HEAD----- 1-D3 BOLT, CYLINDER HEAD COVER-- 1-E3 BOLT, FILLER PIPE----- 1-I15 BOLT, FUEL DISTRIBUTOR----- 1-H4 BOLT, GARNISH-RR----- 2-K6 BOLT, HINGE----- 2-N5 BOLT, HUB----- 1-E11 BOLT----- 1-H13 BOLT, INST. PANEL----- 2-I9 BOLT, JACK SET----- 1-E14 BOLT, LAMP LID----- 2-M5 BOLT, LINK----- 2-E10 BOLT----- 2-G10 BOLT, LOCK----- 1-H7 BOLT, LOCK-C.SHAFT PULLEY-- 1-K3 BOLT, LOCK-FLY WHEEL----- 1-L3 BOLT, MAGNET CLUTCH----- 2-M12 BOLT, MOTOR-RETRACT H/LAMP 2-C6 BOLT, OIL PAN----- 1-N7 BOLT, PLANT FRAME----- 1-C15 BOLT, PULLEY----- 1-K3 BOLT, RING GEAR----- 1-I11 BOLT----- 1-M11 BOLT, SET----- 2-C5 BOLT----- 2-E10 BOLT----- 2-L10 BOLT----- 2-M10 BOLT, SETTING-HINGE LOWER-- 2-L10	BOLT, SHAFT----- 1-L12 BOLT, STOPPER-SOFT TOP---- 2-K13 BOLT, VANE PUMP----- 1-F13 BONNET----- 2-L6 BOOT KIT, FRT CALIPER----- 1-J13 BOOT KIT, RR CALIPER----- 1-G11 BOOT SET, INNER JOINT----- 1-D11 BOOT SET, OUTER JOINT----- 1-D11 BOOT SET, ST. GEAR----- 1-M12 BOOT CHANGE----- 2-L9 BOOT, DUST-CHANGE LEVER--- 1-K6 BOOT, RACK----- 1-C13 BOOT, TOP----- 2-I13 BOOTS, MOTOR-RETRACT H/L-- 2-C6 BOSS, STEERING WHEEL----- 1-J12 BOX(L), TORQUE----- 2-F7 BOX(R), TORQUE----- 2-F7 BOX, A.C.C.----- 2-H14 BOX, COIN-CONSOLE----- 2-L9 BOX, GLOVE----- 2-J9 BOX, INSTRUMENT PANEL----- 2-I9 BRACKET----- 1-C8 BRACKET----- 1-J7 BRACKET----- 1-I4 BRACKET----- 1-N7 BRACKET----- 2-J15 BRACKET SET, DASH POT-THRO 1-K4 BRACKET(L), CABLE----- 1-G11 BRACKET(L), ENGINE----- 1-C15 BRACKET(L), F. BUMPER SIDE 2-F5 BRACKET(L), HINGE-LAMP LID 2-N5 BRACKET(L), INST.----- 2-I7 BRACKET(L), RADIATOR----- 2-D7 BRACKET(L), STABILIZER----- 2-F7 BRACKET(L), TUNER----- 2-I14 BRACKET(R), CABLE----- 1-G11 BRACKET(R), ENGINE----- 1-C15 BRACKET(R), HINGE-LAMP LID 2-N5 BRACKET(R), INST.----- 2-I7 BRACKET(R), RADIATOR----- 2-D7 BRACKET(R), STABILIZER----- 2-E7 BRACKET(R), TUNER----- 2-I14 BRACKET(RR), AUDIO----- 2-I14 BRACKET, ACCEL WIRE----- 1-D4 BRACKET, ACTUATOR----- 2-H14 BRACKET, ACTUATOR-A.C.C.-- 2-H14 BRACKET, ACTUATOR-FRONT--- 2-H14 BRACKET, AIR CLEANER----- 1-J4 BRACKET, BATTERY CLAMP---- 1-G7 BRACKET, BUMPER----- 2-D7 BRACKET, CANISTER----- 1-F4 BRACKET, CLAMP----- 2-H12 BRACKET, CLIP----- 1-K12 BRACKET----- 2-M5 BRACKET, COMPRESSOR----- 1-G5 BRACKET, CONTROL UNIT----- 2-N13 BRACKET, COUPLER----- 1-J12 BRACKET, CRUSH PAD----- 2-J9 BRACKET, EX. MANIFOLD----- 1-F4 BRACKET, FENDER----- 2-F5 BRACKET----- 2-K7 BRACKET, FRONT----- 1-E7 BRACKET, HANGER----- 1-D15 BRACKET, HARNESS----- 2-D15 BRACKET----- 2-L14 BRACKET----- 2-M14 BRACKET----- 2-N14 BRACKET, HOSE----- 2-G12 BRACKET----- 2-H12 BRACKET, IDLE PULLEY----- 1-G5 BRACKET, IGNITER----- 2-M13 BRACKET----- 2-N13 BRACKET, INST. PANEL----- 2-J9 BRACKET, LICENCE PLATE----- 2-F5 BRACKET, LOUD SPEAKER----- 2-K14 BRACKET, LOW----- 2-J14 BRACKET, MASTER CYL.----- 1-D16 BRACKET----- 1-M15 BRACKET----- 1-N15 BRACKET, MEMBER----- 2-J9 BRACKET, PARKING CABLE-FLO 2-C8 BRACKET, PIPE----- 2-H12 BRACKET, PLANT FRAME----- 1-C15 BRACKET, REAR----- 1-E7	BRACKET, REAR CONSOLE----- 2-L9 BRACKET, RELAY----- 2-F14 BRACKET, RELAY----- 2-J12 BRACKET, STARTER----- 1-N6 BRACKET, STOPPER-BATTERY-- 1-G7 BRACKET, VANE PUMP----- 1-F13 BRACKET----- 1-G13 BRACKET, WASHER TANK----- 2-J15 BRACKET, WIRING----- 2-C15 BREAKER----- 2-L14 BREATHER----- 1-H11 BREATHER----- 1-J7 BREATHER----- 1-L11 BREATHER, AIR-T/MISSION--- 1-D6 BRKT(L), BUMPER-RR SKIRT-- 2-D8 BRKT(L), SEAT-F. FLOOR PAN- 2-E8 BRKT(L), SEAT-F. FLOOR PAN- 2-D8 BRKT(L), TRK. BOARD-FENDER-- 2-N7 BRKT(R), BUMPER-RR SKIRT-- 2-D8 BRKT(R), SEAT-F. FLOOR PAN- 2-C8 BRKT, AIR CLNR-WHL APRON-- 2-E7 BRKT, AIR FLOW METER----- 1-I4 BRKT, BATT. CLAMP-QTR PANEL 2-J7 BRKT, CAP-QUARTER PANEL--- 2-M7 BRKT, DIAGNOSIS UNIT----- 2-F14 BRKT, DIAGNOSIS/POWER UNIT 2-F14 BRKT, SURGE TANK----- 1-D4 BRUSH----- 1-C7 BRUSH----- 1-F7 BRUSH, YOKE----- 1-F7 BULB----- 2-C9 BULB----- 2-D6 BULB----- 2-E6 BULB----- 2-F6 BULB----- 2-G9 BULB----- 2-H9 BULB----- 2-I6 BULB----- 2-L9 BULB & SOCKET----- 2-D3 BULB----- 2-L9 BULB, MODE CONTROL----- 2-E12 BULB, RESISTER----- 2-C9 BULB, RESISTER----- 2-G9 BULB 'B', SWITCH-RR DEFOGER 2-D14 BUMPER, FRONT----- 2-E5 BUMPER, REAR----- 2-H5 BUSH----- 1-E16 BUSH----- 1-H15 BUSH----- 1-M15 BUSH----- 1-N15 BUSH----- 2-D3 BUSH SET, CHANGE LEVE---- 1-K6 BUSH, ELBOW JOINT----- 1-F15 BUSH----- 1-G16 BUSH, HINGE----- 2-G10 BUSH, RUBBER----- 1-N7 BUSH, RUBBER-LWR ARM----- 1-L13 BUSH, STABILIZER-RR----- 1-F12 BUSHING, LOWER ARM----- 1-G12 BUSHING, RACK-ST. GEAR--- 1-N12 BUSHING, RUBBER----- 1-G12 BUSHING, RUBBER----- 1-L13 BUSHING, RUBBER-LOWER ARM- 1-G12 BUSHING----- 1-L13 BUTTON, RELEASE----- 1-J16	CAM, CHANGE LEVER----- 2-C3 CAMSHAFT----- 1-N3 CAMSHAFT, EXHAUST----- 1-C4 CANISTER----- 1-N3 CAP----- 1-F4 CAP----- 1-M4 CAP----- 2-D11 CAP----- 2-G6 CAP----- 2-C15 CAP----- 2-J5 CAP SET, RESERVE TANK----- 1-F15 CAP----- 1-F16 CAP(L), PULL HANDLE----- 2-G11 CAP(R), PULL HANDLE----- 2-G11 CAP, BLEEDER SCREW----- 1-F15 CAP----- 1-G11 CAP----- 1-I13 CAP, BLIND----- 1-E3 CAP----- 1-K4 CAP----- 1-M4 CAP, CENTER----- 1-C14 CAP, COLUMN COVER----- 2-D9 CAP, DAMPER----- 1-K13 CAP, FILLER----- 1-I15 CAP, HINGE-H.L. RETRACTABLE 2-N5 CAP, HORN----- 1-J12 CAP, HUB----- 1-H13 CAP, OIL FILLER----- 1-E3 CAP, PARK BRAKE LEVER----- 1-J16 CAP, RADIATOR----- 1-D5 CAP, SEAL-TRUNK END TRIM-- 2-C16 CAP, SEALING----- 1-E3 CAP, SPRING----- 1-K6 CAP----- 1-L6 CAP, SUB TANK----- 1-E5 CAP, TANK----- 2-J15 CARRIER, DIFFERTIAL-FRT--- 1-H11 CARRIER, FRONT----- 1-M11 CARRIER, OVER DFIVE----- 1-L8 CARRIER, REAR----- 1-N8 CARTRIDGE, OIL FILTER----- 1-N4 CASE----- 1-I11 CASE, CHANGE CONTROL----- 1-K6 CASE, LAMP----- 2-M9 CASE, METER----- 2-G9 CASE, OVER DRIVE----- 1-C8 CASE, T. MISSION----- 1-D6 CASE----- 1-K7 CASE, THERMOSTAT----- 1-D5 CASE 'A', BLOWER UNIT----- 2-F12 CASE 'A', COOLING UNIT----- 2-M12 CASE 'A', HEATER UNIT----- 2-D12 CASE 'B', BLOWER UNIT----- 2-F12 CASE 'B', COOLING UNIT----- 2-M12 CASE 'B', HEATER UNIT----- 2-D12 CASE 'OUT', ASH TRAY----- 2-D9 CASING, DIFFERTIAL----- 1-C12 CASING----- 1-K11 CASING, STOPPER----- 1-C15 CHAMBER, RESONANCE----- 1-I4 CHANNEL(L), DIVISION-DOCR-- 2-M10 CHANNEL(R), DIVISION-DOOR-- 2-M10 CHECKER, DOOR----- 2-C11 CHROME VALVE COVER----- 3-J3 CLAMP, BATTERY----- 1-G7 CLAMP, HOSE----- 1-D5 CLAMP----- 1-H3 CLAMP----- 1-M4 CLAMP----- 2-G15 CLAMP, HOSE-A. I. P. A. CLNR 1-M4 CLAMP, HOSE-F.S.----- 1-F13 CLAMP, WATER HOSE----- 1-F3 CLAMP----- 1-F5 CLAMP----- 1-M4 CLEANER, AIR----- 1-I4 CLIP----- 1-H11 CLIP----- 1-I7 CLIP----- 1-J16 CLIP----- 1-K3 CLIP----- 1-L11 CLIP----- 1-L15
***** * * B * * *****	BACK(L), FRONT SEAT----- 2-I10 BACK(R), FRONT SEAT----- 2-H10 BAG, TOOL----- 2-G16 BALL JOINT, LOWER----- 1-L13 BALL, STEEL----- 1-F15 BAND----- 1-D15 BAND----- 2-G15 BAND----- 2-I12 BAND, BRAKE----- 1-J8 BASE, INTERIOR MIRROR----- 2-I16 BATTERY----- 1-G7 BEARING----- 1-G6 BEARING----- 1-J11 BEARING----- 1-M11 BEARING, BALL----- 1-H6 BEARING, BALL-ALT. FRONT-- 1-C7 BEARING, BALL-ALT. REAR--- 1-C7 BEARING, BALL-COUNTER SHAF 1-G6 BEARING, BALL-FLY WHEEL--- 1-L3 BEARING, BALL-MAIN DRIVE G 1-E6 BEARING, BALL-MAIN SHAFT-- 1-E6 BEARING, NEEDLE----- 1-E6 BEARING----- 1-E9 BEARING----- 1-F6 BEARING----- 1-M8 BEARING, PINION----- 1-D13 BEARING----- 1-H11 BEARING----- 1-L11 BEARING----- 1-N12 BEARING, ROLLER----- 1-E6 BEARING, ST. GEAR----- 1-C13 BEARING----- 1-M12 BEARING, WHEEL----- 1-E11 BELT, TIMING----- 1-N3 BELT 'A', FRONT SEAT----- 2-K10 BELT 'B' (L), FRT SEAT----- 2-K10 BELT 'B' (R), FRT SEAT----- 2-K10 BELT 'V'----- 1-G5 BEZEL(L), HEAD LAMP----- 1-N6 BEZEL(R), HEAD LAMP----- 2-C6 BLADE(R), WIPER-FRONT----- 2-K15 BLADE, WIPER-FRONT----- 2-K15 BLOCK, CYLINDER----- 1-G3 BLOCK, FUSE----- 2-L14 BLOCK, MAIN FUSE----- 2-N14 BLOWER UNIT----- 2-F12	BOLT, INST. PANEL----- 2-I9 BOLT, JACK SET----- 1-E14 BOLT, LAMP LID----- 2-M5 BOLT, LINK----- 2-E10 BOLT----- 2-G10 BOLT, LOCK----- 1-H7 BOLT, LOCK-C.SHAFT PULLEY-- 1-K3 BOLT, LOCK-FLY WHEEL----- 1-L3 BOLT, MAGNET CLUTCH----- 2-M12 BOLT, MOTOR-RETRACT H/LAMP 2-C6 BOLT, OIL PAN----- 1-N7 BOLT, PLANT FRAME----- 1-C15 BOLT, PULLEY----- 1-K3 BOLT, RING GEAR----- 1-I11 BOLT----- 1-M11 BOLT, SET----- 2-C5 BOLT----- 2-E10 BOLT----- 2-L10 BOLT----- 2-M10 BOLT, SETTING-HINGE LOWER-- 2-L10	BRACKET, COMPRESSOR----- 1-G5 BRACKET, CONTROL UNIT----- 2-N13 BRACKET, COUPLER----- 1-J12 BRACKET, CRUSH PAD----- 2-J9 BRACKET, EX. MANIFOLD----- 1-F4 BRACKET, FENDER----- 2-F5 BRACKET----- 2-K7 BRACKET, FRONT----- 1-E7 BRACKET, HANGER----- 1-D15 BRACKET, HARNESS----- 2-D15 BRACKET----- 2-L14 BRACKET----- 2-M14 BRACKET----- 2-N14 BRACKET, HOSE----- 2-G12 BRACKET----- 2-H12 BRACKET, IDLE PULLEY----- 1-G5 BRACKET, IGNITER----- 2-M13 BRACKET----- 2-N13 BRACKET, INST. PANEL----- 2-J9 BRACKET, LICENCE PLATE----- 2-F5 BRACKET, LOUD SPEAKER----- 2-K14 BRACKET, LOW----- 2-J14 BRACKET, MASTER CYL.----- 1-D16 BRACKET----- 1-M15 BRACKET----- 1-N15 BRACKET, MEMBER----- 2-J9 BRACKET, PARKING CABLE-FLO 2-C8 BRACKET, PIPE----- 2-H12 BRACKET, PLANT FRAME----- 1-C15 BRACKET, REAR----- 1-E7	CABLE(L), R.-PARK.----- 1-K16 CABLE(R), R.-PARK.----- 1-J16 CABLE, ACCEL.----- 1-H15 CABLE, F. LID OPENER----- 1-K15 CABLE, INTER LOCK----- 2-C3 CABLE----- 2-D3 CABLE, PARKING-FRT----- 1-J16 CABLE, SPEEDOMETER----- 2-F7 CALIPER(L), FRT BRAKE----- 1-I13 CALIPER(L), RR BRAKE----- 1-G11 CALIPER(R), FRT BRAKE----- 1-I13 CALIPER(R), RR BRAKE----- 1-G11	***** * * C * * *****







## ALPHABETICAL INDEX \*\*\* ENGLISH \*\*\*

NUT, LOCK-CLUTCH HUB-----	1-I6	PANEL, REAR DECK-----	2-K7	PISTON, PRIMARY-----	1-G16	PLUG, DRAIN-----	2-C11	RAIL (L), RAIN-REAR-----	2-N7
NUT, LOCK-COUNTER SHAFT BR	1-H6	PANEL, REAR END-----	2-L7	PLATE-----	1-D16	PLUG, HOLE-----	2-G12	RAIL (R), RAIN-REAR-----	2-K7
NUT, LOCK-RACK-----	1-C13	PANEL, ROOF-----	2-H13	PLATE NO.1, SEAL-----	2-I12	PLUG, MAGNET-----	2-G12	RAIL, RAIN-SOFT TOP REAR--	2-G13
NUT, SELF LOCK-----	2-K13	PARTS KIT, INN. -BRAKE-----	2-I13	PLATE NO.2(L), SET-F. BUMPE	2-F5	PLUG, OIL CONTROL-----	2-N6	REAR SPOILER-----	3-C3
NUT, SIDE PROTECTOR-----	2-D6	PARTS KIT, INNER-----	1-G16	PLATE NO.2(R), SET-F. BUMPE	2-F5	PLUG, PINION-----	2-G12	REAR UNDER SKIRT-----	3-C3
NUT, SPRING-----	2-F6	PARTS SET-----	1-F15	PLATE NO.3, SEAL-----	2-I12	PLUG, PINION-ST. GEAR-----	1-D6	RECE, SIDE-ONE WAY CLUTCH--	1-N8
NUT, STOPPER-LAMP HINGE---	2-I9	PARTS SET, HORN CAP-----	2-M15	PLATE SET-----	2-H5	PLUG, REGULATER-----	1-H11	RECTIFIER-----	1-C7
NUT, TOP-CRUSH PAD-----	2-M5	PARTS SET, ST. WHEEL-----	1-J12	PLATE (C), SET-TOP FABRIC--	2-I5	PLUG, SCREW-----	1-L11	REGULATOR-----	1-C7
NUT, TOP-CRUSH PAD-----	2-L9	PASS, OIL-----	1-D6	PLATE (FRT), SET-ROOF PANEL	2-G13	PLUG, SQUARE HEAD-----	1-G3	REGULATOR (L), WINDOW-----	2-D11
*****		PAWL, PARKING-----	1-G9	PLATE (L), CLOSING-QTR PANE	2-E13	PLUG, TRANSFER-----	1-C13	REGULATOR (R), WINDOW-----	2-D11
* O *		PEDAL & ARM-----	1-H15	PLATE (L), FRONT SCUFF-----	2-N7	PLUG, WIPER-----	1-M12	REINF. (L), BELT LINE-C. PIL	2-K7
* *		PEDAL, BRAKE-----	1-D16	PLATE (L), HOOK-REA. DECK--	2-C16	PLUG, WIPER-----	1-E8	REINF. (L), SIDE SILL-----	2-M7
*****		PEDAL, CLUTCH-----	1-M15	PLATE (L), SEAL-----	2-F13	PLUG, WIPER-----	1-F11	REINF. (L), STRIKER-----	2-M7
		PIECE, DISTANCE-----	1-M15	PLATE (L), SET-TOP FABRIC--	2-L7	PLUG, WIPER-----	1-M6	REINF. (L), TIE DOWN HOOK--	2-F7
			1-I11	PLATE (L), SET-TOP FABRIC--	2-G13	PLUG, WIPER-----	1-K7	REINF. (L), WHEEL APRON-----	2-F7
			1-M11	PLATE (L), SIDE-RE. FLOOR--	2-D8	PLUG, 2-3 SHIFT-----	1-F8	REINF. (R), BELT LINE-C. PIL	2-K7
OIL, COMPRESSOR-----	2-M12	PILLAR (L), FRONT-OUT.-----	2-N7	PLATE (OUT), TIMING BELT--	1-K3	PLUG, 3-4 SHIFT-----	1-G8	REINF. (R), SIDE SILL-----	2-K7
OPENER, FILLER LID-----	1-J15	PILLAR (L), FRT. -INNER-----	2-M7	PLATE (R), CLOSING-QTR PANE	2-L7	PLUNGER, CONTROL-----	1-N4	REINF. (R), STRIKER-----	2-K7
ORIFICE-----	1-F3	PILLAR (L), HINGE-----	2-M7	PLATE (R), END-----	2-J7	POLE, ANTENNA-----	2-K14	REINF. (R), TIE DOWN HOOK--	2-F7
ORNAMENT, MAKER NAME-FRONT	2-G5	PILLAR (L), HINGE-OUT.-----	2-N7	PLATE (R), FRONT SCUFF-----	2-C16	PRESSURE RG., FUEL-----	1-H4	REINF. (R), WHEEL APRON-----	2-F7
ORNAMENT, MAKER NAME-REAR-	2-K6	PILLAR (R), FRONT-OUT.-----	2-N7	PLATE (R), HOOK-REAR DECK--	2-F13	PROTECTOR-----	1-F4	REINF., FUEL TANK-----	1-K15
ORNAMENT, REAR-----	2-K6	PILLAR (R), FRT. -INNER-----	2-J7	PLATE (R), SEAL-----	2-J7	PROTECTOR (C), EDGE-D. TOP--	1-F11	REINFORCEMENT-----	2-J6
ORNAMENT, STEREO-----	2-I14	PILLAR (R), HINGE-----	2-K7	PLATE (R), SET-TOP FABRIC--	2-G13	PROTECTOR (L), 'A'-----	2-D14	REINFORCEMENT (R)-----	2-F7
ORNAMENT, STEREO-LOWER---	2-I14	PILLAR (R), HINGE-OUT.-----	2-J7	PLATE (R), SIDE-REAR FLOOR--	2-C8	PROTECTOR (L), 'B'-----	2-J5	REINFORCEMENT, BUMPER-----	2-E5
OUTLET, WATER-----	1-D5	PIN-----	2-N7	PLATE, ASH TRAY-----	2-D9	PROTECTOR (L), 'A'-----	2-J13	RELAY, CIRCUIT OPEN-----	2-N13
*****		PIN, CHECKER-----	1-Y11	PLATE, BACK-BOOTS RING-----	2-L9	PROTECTOR (L), 'B'-----	2-G6	RELAY, COOLING FAN-----	2-N12
* P *		PIN, GUIDE-----	1-N15	PLATE, BACKING-----	1-H7	PROTECTOR (L), EDGE-D. TOP--	2-G6	RELAY, MAIN-----	2-N13
* *		PIN, INTER LOCK-----	2-C11	PLATE, BAFFLE-----	1-D3	PROTECTOR (L), RETRA. FRONT	2-J13	RELAY, N.O.-----	2-N13
*****		PIN, LOCK-----	1-G11	PLATE, BAFFLE-DIFF CASING--	1-C12	PROTECTOR (L), RETRA. H/L--	2-M5	RELAY, TRANSFER-----	2-F14
		PIN, PIVOT-CLUTCH REL. FORK	1-J6	PLATE, CAM-SUB FRAME-----	1-K11	PROTECTOR (L), RETRA. H/L--	2-M5	REMOTE TRANSMITTER-----	2-F14
		PIN, SLIDER-----	1-I13	PLATE, CAUTION-----	1-K13	PROTECTOR (L), SPLASH-----	2-M7	REMOTE VPGRADE KIT-----	2-J12
		PIN, SNAP-----	1-C6	PLATE, CLAMP-----	2-J16	PROTECTOR (R), 'A'-----	2-F6	RESISTOR, BLOWER UNIT-----	3-C3
		PIN, TUBULAR-----	1-I13	PLATE, CLAMP-JACK-----	1-D13	PROTECTOR (R), 'B'-----	2-G6	RESISTOR, METER-----	3-C3
			1-D16	PLATE, CONTACT-----	1-M12	PROTECTOR (R), EDGE-D. TOP--	2-J13	RESISTOR, PANEL LIGHT-----	2-F12
			1-N15	PLATE, CRANKSHAFT PULLEY--	1-N12	PROTECTOR (R), RETRA H/L--	2-M5	RESISTOR, METER-----	2-H9
			2-C3	PLATE, DISC-----	1-E14	PROTECTOR (R), RR FENDER--	2-G8	REST (L), ARM-----	2-C9
			1-G3	PLATE, DISHED-----	1-J12	PROTECTOR (R), SPLASH-----	2-J7	REST (R), ARM-----	2-G11
			1-I3	PLATE, DRIVE-----	1-K3	PROTECTOR (R), COWL GRILL--	2-I15	REST, FOOT-----	2-G11
			1-I11	PLATE, DRIVEN-----	2-I13	PROTECTOR (R), HARNESS-----	2-J5	RETAINER-----	1-D16
			1-M11	PLATE, END-----	1-E11	PROTECTOR (R), HT. CORD-S. TANK	2-G15	RETAINER (L), FRONT BUMPER--	1-N15
			1-I11	PLATE, END-HOLDER-BRUSH--	1-H13	PROTECTOR (R), MOULD-FR. WIND	1-E3	RETAINER (L), WTHSTP-D. TOP--	1-G9
			1-M12	PLATE, LOCK-----	1-J8	PROTECTOR (R), NO. PLATE-----	2-J5	RETAINER (R), FRONT BUMPER--	2-E5
			2-H12	PLATE, MANUAL-----	1-E9	PROTECTOR (R), FILLER PIPE--	2-F5	RETAINER (R), FRONT BUMPER--	2-E5
			2-H12	PLATE, NUT-TRUNK FLOOR PAN	1-J8	PROTR (L), MOULD-BELT LINE--	1-J15	RETAINER (R), WTHSTP-D. TOP--	2-J13
			2-H12	PLATE, OIL BAFFLE-----	1-K8	PROTR (L), SEAT BELT-----	2-H13	RETAINER (R), WTHSTP-D. TOP--	2-J13
			1-H16	PLATE, OIL BAFFLE-CYL. BLK	1-J3	PROTR (R), MOULD-BELT LINE--	2-F10	RETAINER, FASCIA-----	2-E5
			1-H16	PLATE, OIL BAFFLE-EX.-----	2-M15	PROTR (R), SEAT BELT-----	2-H13	RETAINER, R. BUMPER-----	2-H5
			1-I4	PLATE, OIL BAFFLE-IN. SIDE-	1-J11	PROTR (R), SEAT BELT-----	2-F10	RETAINER, SERVO-----	1-L7
			2-H14	PLATE, PRINT-----	1-M11	PROTR, BACK WINDOW-LOWER--	2-C13	RETAINER, SPRING-----	1-J8
			1-H16	PLATE, RETAINER-----	1-G9	PROTR, BACK WINDOW-SIDE---	2-C13	RETAINER 'A' (L), WTHSTP---	2-G13
			1-H16	PLATE, RETAINING-----	2-C8	PULLEY-----	1-D7	RETAINER 'A' (R), WTHSTP---	2-F13
			1-E5	PLATE, SEAL-T. BELT COVER U	1-D3	PULLEY, CAMSHAFT-----	1-N3	RETAINER 'B' (L), WTHSTP---	2-G13
			1-G15	PLATE, SET NO.1-----	1-I3	PULLEY, CRANKSHAFT-----	1-K3	RETAINER 'B' (R), WTHSTP---	2-F13
			2-N12	PLATE, SIDE 'A'-----	1-D3	PULLEY, IDLE-----	1-G5	RETAINER 'C' (L), WTHSTP---	2-G13
			2-I7	PLATE, SIDE 'B'-----	1-D3	PULLEY, MAGNET CLUTCH-----	2-M12	RETAINER 'C' (R), WTHSTP---	2-F13
			1-L16	PLATE, SIDE 'D'-----	2-H9	PULLEY, TIMING BELT-----	1-K3	RING-----	1-F9
			1-D15	PLATE, STABILIZER-----	1-F9	PULLEY, WATER PUMP-----	1-C5	RING SET, 'O'-AIR CON.-----	2-K12
			1-I15	PLATE, STABILIZER-RR-----	1-C9	PUMP, FUEL-----	1-C5	RING SET, PISTON-----	1-L3
			1-L16	PLATE, TIMING BELT GUIDE--	1-E9	PUMP, WATER-----	1-C5	RING (L) MOUNTING-----	2-L5
			2-I15	PLATE, WINDOW-----	1-G9	PUMP, WASH-----	1-H7	RING (R) MOUNTING-----	2-L5
			1-I7	PLATE, WINDOW-----	1-K8	PUMP, OIL-----	1-N4	RING, 'O'-----	1-C8
			1-G3	PLATE, WIPER-----	1-J3	PUMP, VANE-----	1-F13	RING, 'O'-AIR VALVE-----	1-D6
			1-D16	PLATE, WIPER-----	1-G8	PUMP, WASHER-----	2-J15	RING, 'O'-FUEL PUMP-----	1-D8
			1-N15	PLATE, SET NO.1-----	2-F5	*****		RING, 'O'-MASTER CYL.-----	1-G9
			1-F13	PLATE, SIDE 'A'-----	1-F8	* R *		RING, 'O'-NO.1-----	1-H4
			1-F13	PLATE, SIDE 'B'-----	1-F8	* *		RING, 'O'-NO.2-----	1-J7
			1-G16	PLATE, SIDE 'D'-----	1-E8	*****		RING, 'O'-NO.3-----	1-K7
			1-I7	PLATE, STABILIZER-----	1-N13			RING, 'O'-NO.2-----	1-M7
			1-E3	PLATE, STABILIZER-RR-----	1-F12			RING, 'O'-NO.2-----	1-N7
			1-D5	PLATE, TIMING BELT GUIDE--	1-K3			RING, 'O'-NO.2-----	2-C14
			1-C5	PLATE, WINDOW-----	2-H9			RING, 'O'-NO.2-----	2-M13
			1-E13	PLAYER, COMPACT DISC-----	2-H9	RACE, BEARING-----	1-M8	RING, 'O'-AIR VALVE-----	1-L4
			1-E13	PLUG-----	2-I14	RACE, BRG. HUB CLUTCH-----	1-C9	RING, 'O'-FUEL PUMP-----	1-F4
			1-M3	PLUG, ACCUMLATOR-----	1-C7	RACE, BRG. PUMP COVER-----	1-M8	RING, 'O'-MASTER CYL.-----	1-G16
			1-C8	PLUG, BLIND-----	1-G3	RACE, INNER-----	1-D9	RING, 'O'-NO.1-----	2-K12
			1-L7	PLUG, COMPRESSOR-----	1-H3	RACE, OUTER-----	1-F6	RING, 'O'-NO.1-----	2-K12
			1-J8	PLUG, DRAIN-----	2-F8	RACE, OUTER-ONE WAY CLUTCH	1-D9	RING, 'O'-NO.2-----	2-K12
			1-E9	*****	1-C8	RACE, SHELL BEARING-----	1-L8	RING, 'O'-NO.3-----	2-K12
			1-E9	RADIATOR-----	1-G3	RACK, STEERING GEAR-----	1-C13	RING, 'O'-WATER BY-PASS---	1-E5
			1-E9		2-L12		1-M12	RING, 'O'-WATER PUMP-----	1-C5
			1-E9		1-I15		1-D5	RING, 'O'-WATER (HERMO SW.	2-M13
			1-E9					RING, BACK UP-----	1-D13







## ALPHABETICAL INDEX \*\*\* ENGLISH \*\*\*

TRAY, REAR PACKAGE-----	2-C16	*****	*****
TRIM RING-----	3-C3	* * * * *	* * * * *
TRIM RING SET-----	3-C3	* * * * *	* * * * *
TRIM(L), 'A' PILLAR-----	2-N15	* * * * *	* * * * *
TRIM(L), DOOR-----	2-G11	* * * * *	* * * * *
TRIM(L), FRONT SIDE-----	2-C16	* * * * *	* * * * *
TRIM(L), QUARTER-----	2-L16	*****	*****
TRIM(L), SEAT BACK-----	2-J10	WASHER-----	1-D13
TRIM(L), SEAT CUSHION-----	2-I10	1-H11	YOKE-----
TRIM(R), 'A' PILLAR-----	2-N15	1-I11	YOKE SET, SUPPORT-ST. GEAR
TRIM(R), DOOR-----	2-G11	1-K13	YOKE, SUPPORT-----
TRIM(R), FRONT SIDE-----	2-C16	1-L11	1-E7
TRIM(R), QUARTER-----	2-L16	1-M8	1-C13
TRIM(R), SEAT BACK-----	2-H10	1-N8	1-M12
TRIM(R), SEAT CUSHION-----	2-G10	1-N12	
TRIM, FRONT HEADER-----	2-N15	2-M5	
TRIM, TRUNK END-----	2-D16	2-M12	
TUBE, AIR INTAKE-----	1-I4	2-M15	
TUBE, FILLER-----	1-N7	WASHER SET-----	1-E7
TUBE, GOVERNOR-----	1-J7	WASHER, COMPRESSOR-----	2-L12
TUBE, HEAD LAMP-----	2-D6	WASHER, HOOK-HOOD COVER---	2-J13
TUBE, OIL FILTER-UPPER---	1-N7	WASHER, HOOK 'A'-----	2-K13
TUBE, SILICON-----	1-J3	WASHER, HOOK 'A' & 'B'-----	2-K13
TUBE, VACUUM-----	1-G4	WASHER, LID OPENER-----	1-J15
	1-G7	WASHER, LOCK-PUMP FILTER--	1-F4
	1-L4	WASHER, PLAIN-----	1-D9
TUNER & DECK, COMB.-----	2-I14	1-H7	1-H7
		1-L7	1-L7
*****		1-M7	1-M7
* * * * *		WASHER, PLAIN CYL. HEAD---	1-D3
* * * * *		WASHER, PLAIN-FRAME-----	1-C15
* * * * *		WASHER, SEAL-----	1-J7
* * * * *		WASHER, SETTING-----	2-L10
		WASHER, STOP-----	1-G12
		WASHER, THRUST-----	1-F6
		1-G6	1-G6
		1-H6	1-H6
		1-I6	1-I6
UNIT, BACK UP POWER-A. BAG--	2-F14	WASHER, THRUST LOCK-OVER T	1-I6
UNIT, CONTROL-----	2-M13	WASHER, THRUST-REVERSE IDL	1-H6
UNIT, COOLING-----	2-N12	WASHER, TOOTHED-----	2-M15
UNIT, DIAGNOSIS-AIR BAG---	2-F14	WASHER, WAVE-CHANGE CONT.C	1-L6
UNIT, FLASHER-----	2-F14	WEATHERSTRIP NO. 1-----	2-F11
UNIT, HEAD LAMP-----	2-L5	WEATHERSTRIP NO. 2-----	2-F11
UNIT, HEAT GAUGE-----	2-M13	WEATHERSTRIP(L)-----	2-M10
		WEATHERSTRIP(L), DOOR-----	2-N10
*****		WEATHERSTRIP(L), OUT.-----	2-F11
* * * * *		WEATHERSTRIP(R)-----	2-M10
* * * * *		WEATHERSTRIP(R), DOOR-----	2-N10
* * * * *		WEATHERSTRIP(R), OUT.-----	2-F11
* * * * *		WEATHERSTRIP, BONNET-REAR--	2-M6
		WEATHERSTRIP, D. TOP-REAR--	2-J13
VACUUM POWER ASSIST-----	1-F16	WEATHERSTRIP, LID-----	2-C7
VALVE-----	1-F9	WEDGE, DOOR-FRONT-----	2-E11
VALVE, AIR-----	1-C14	WEIGHT, DISC WHEEL-ALUMI--	1-D14
	1-L4	WEIGHT, DISC WHEEL-STEEL--	1-C14
VALVE, BY-PASS AIR CONTROL	1-K4	WELT, SEAMING-----	2-N10
VALVE, CHECK-----	1-K15	WELT, SEAMING-SOFT TOP---	2-F13
	2-I15	WHEEL SET, DISC-ALUMI-----	1-D14
VALVE, CONTROL-----	1-E8	WHEEL, DISC-STEEL-----	1-C14
VALVE, DOWN SHIFT-----	1-F8	WHEEL, FLY-----	1-K3
VALVE, DUAL PROPORTIONING-	1-H16	WINDOW, BACK-D. TOP-----	2-E13
VALVE, EXHAUST-----	1-N3	WIRE, A.C.C.-----	2-H14
VALVE, EXPANSION-----	2-N12	WIRE, CONNECT-----	2-G10
VALVE, FUEL VAPOR.-----	1-K15	2-I10	2-I10
VALVE, GOVERNOR-----	1-F9	WIRE, EARTH-----	2-N14
VALVE, INLET-----	1-N3	WIRE, MODE CONTROL-----	2-E12
VALVE, MANUAL-----	1-E8	WIRE, RECYCLE & FRESH---	2-E12
VALVE, MODIFIER-----	1-F8	WIRE, RELEASE-BONNET-----	2-L6
VALVE, NON RETURN-----	1-J15	WIRE, TEMP. CONTROL-----	2-E12
VALVE, OIL JET-----	1-H3	WRENCH, HUB NUT-----	2-G16
VALVE, ONE WAY-----	1-C8	WTHSTP NO. 1(L), LINK-----	2-G13
VALVE, ORIFICE CHECK-----	1-F8	WTHSTP NO. 1(R), LINK-----	2-G13
	1-G8	WTHSTP NO. 2(L), LINK-----	2-G13
VALVE, P.C.V.-----	1-F3	WTHSTP NO. 2(R), LINK-----	2-G13
VALVE, REGULATOR-----	1-E8	WTHSTP NO. 3(L), LINK-----	2-G13
VALVE, SECOND LOCK-----	1-E8	WTHSTP NO. 3(R), LINK-----	2-G13
VALVE, SHIFT 3-4-----	1-G8	WTHSTP(L), CAB SIDE-----	2-H13
VALVE, ST. GEAR-----	1-D13	WTHSTP(L), ROOF PANEL-----	2-K13
VALVE, THREE WAY-----	2-M13	WTHSTP(R), CAB SIDE-----	2-H13
VALVE, THROTTLE-----	1-F8	WTHSTP(R), ROOF PANEL-----	2-K13
VALVE, THROTTLE BACK-UP---	1-F8	WTHSTP, FRONT HEADER-----	2-H13
VALVE, 1-2 SHIFT-----	1-E8		
VALVE, 2-3 SHIFT-----	1-F8		
VALVE 'A', CHECK-BREATH--	1-K15		

# MODEL IDENTIFICATION

This parts catalog has been compiled to cover the following models.

(1/1)

Model No.	Specifications of vehicles														VIN (Chassis No.)	Remarks				
	Basic spec		Eng ine	CC	Cy- linder	T- mission	AT cont- rol	Speed	Door	Bra- ke	Diff.	Wheel drive	Production period				Model Year			
	California	Federal	Gasoline engine	1600cc	DOHC	Manual T/mission	Automatic T/mission	Hydraulic control	4 speed	5 speed	2 door	4 disc	Normal diff	Limited slip diff.			2WD	From	To	1990
	(CL)	(FD)	(GE)	(1.6)	(DH)	(MT)	(AT)	HC AT	(4S)	(5S)	(2D)	(4DS)	(ND)	(LS)			(2W)			
NA01	CL		GE	1.6	DH	MT			5S	2D	4DS	ND		2W	Mar '89	Jul '90	→	NA35**-10001~20000		
NA02	CL		GE	1.6	DH	MT			5S	2D	4DS		LS	2W	Mar '89	Jul '90	→	NA35**-10001~20000		
NA03	CL		GE	1.6	DH		AT	HC AT	4S		2D	4DS	ND	2W	Dec '89	Jul '90	→	NA35**-10001~20000		
NA04		FD	GE	1.6	DH	MT			5S	2D	4DS	ND		2W	Mar '89	Jul '90	→	NA35**-10001~20000		
NA05		FD	GE	1.6	DH	MT			5S	2D	4DS		LS	2W	Mar '89	Jul '90	→	NA35**-10001~20000		
NA06		FD	GE	1.6	DH		AT	HC AT	4S		2D	4DS	ND	2W	Dec '89	Jul '90	→	NA35**-10001~20000		

# BODY PAINTS AND INTERIOR COLORS

THIS LIST SHOWS COMBINATION OF BODY PAINT AND INTERIOR COLOR. USING THIS LIST YOU WILL BE ABLE TO FIND OUT NECESSARY COLOR CODE OF PART YOU NEED IN THE TEXT

BODY PAINT		INTERIOR COLOR CODE
NAME	CODE	
MARINER BLUE	DU	N A O
CLASSIC RED	SU	N A O
CRYSTAL WHITE	UC	N A O
SILVER STONE METALLIC	3L	N A O

NOTE:1)

COLORS OF INTERIOR CODES  
ARE AS FOLLOWS

NAO	BLACK
-----	-------

# COMPLETE ASSEMBLY PARTS NUMBERS


(1/1)

Model No.	Specifications of vehicles												Parts number			Remarks		
	Basic spec.	Engine	CC	Cyls	T. mission	AT	Speed	Door	Brake	Diff.	Wheel drive	Engine	T/mission	Cabin				
	California	Federal	Gasoline engine	1500cc	DOHC	Manual T/mission	Automatic T/mission	Hydraulic control	4 speed	5 speed	2 door				4 disc		Normal diff.	Limited slip diff.
(CL)	(FD)	(GE)	(1.6)	(DH)	(MT)	(AT)	(HC/AT)	(4S)	(5S)	(2D)	(4DS)	(ND)	(LS)	(2W)				
NA01	CL		GE	1.6	DH	MT			5S	2D	4DS	ND		2W	B61P-02-000	M50S-03-000	NA01-07-000	
NA02	CL		GE	1.6	DH	MT			5S	2D	4DS		LS	2W	B61P-02-000	M50S-03-000	NA01-07-000	
NA03	CL		GE	1.6	DH		AT	HC/AT	4S	2D	4DS	ND		2W	B64J-02-000	BUY2-19-090A	NA01-07-000	
NA04		FD	GE	1.6	DH	MT			5S	2D	4DS	ND		2W	B61P-02-000	M50S-03-000	NA01-07-000	
NA05		FD	GE	1.6	DH	MT			5S	2D	4DS		LS	2W	B61P-02-000	M50S-03-000	NA01-07-000	
NA06		FD	GE	1.6	DH		AT	HC/AT	4S	2D	4DS	ND		2W	B64J-02-000	BUY2-19-090A	NA01-07-000	

Complete assemblies are available and manufactured in accordance with current production specifications only.

## VEHICLE IDENTIFICATION SYSTEM FOR MX-5 MIATA SERIES (1990)


VIN (= Vehicle Identification Number) for MX-5 MIATA series (1990 Year Model) consists of WMI(= World Manufacturer Identifier), VDS(= Vehicle Description Section) and VIS(= Vehicle Identification Section). VDS consisting of six alphanumeric characters denotes the "MODEL SERIES". VIS consisting of eight alphanumeric characters denotes the serial unit number of vehicle and is sequentially numbered within each VDS.



\* Check digit is included as a VIN security feature to permit law enforcement verification of the authenticity of a suspected illegal VIN plate. This single digit number is determined, based upon a complex mathematical formula which is applied to each vehicle's VIN number.

### LOCATION OF VIN PLATE

The plate is attached to the top ledge of the dash panel under the bonnet(engine hood), refer to the illustration shown right.



[Note]

If the VIN(Chassis) reference number in the PCM(Parts Catalog Microfiche) appeared as:

NA35 \* \* - 100001

...the vehicle's VIN would be e.g. JM1NA351 \* L0100001



