

CLUTCH

CONTENTS

2110900060

CLUTCH 21A

CLUTCH OVERHAUL 21B

CLUTCH

CONTENTS

21109000022


CLUTCH CONTROL	9	Bleeding	7
CLUTCH PEDAL	8	Clutch Pedal Check and Adjustment	5
GENERAL INFORMATION	3	Interlock Switch Check and Adjustment	7
LUBRICANTS	4	Interlock Switch Operating Check	6
ON-VEHICLE SERVICE	5	SERVICE SPECIFICATIONS	4
		TROUBLESHOOTING	4

GENERAL INFORMATION

The clutch is a dry single-disc, diaphragm type; hydraulic pressure is used for the clutch control.

Items	Specifications	
Clutch operating method	Hydraulic type	
Clutch disc type	Single dry disc type	
Clutch disc facing diameter O.D.×I.D. mm (in.)	1.5L Engine	200×130 (7.8×5.1)
	1.8L Engine	215×140 (8.4×5.5)
Clutch cover type	Diaphragm spring strap drive type	
Clutch cover setting load N (lbs.)	4,600 (1,014)	
Clutch release cylinder I.D. mm (in.)	20.64 (13/16)	
Clutch master cylinder I.D. mm (in.)	15.87 (10/16)	

CONSTRUCTION DIAGRAM



SERVICE SPECIFICATIONS

21100030105

Items	Standard value
Clutch pedal height mm (in.)	163.5 - 166.5 (6.43 - 6.55)
Clutch pedal clevis pin play mm (in.)	1 - 3 (.04 - .12)
Clutch pedal free play mm (in.)	6 - 13 (.24 - .51)
Distance between the clutch pedal and the firewall when the clutch is disengaged mm (in.)	70 (2.7) or more

LUBRICANTS

21100040016



Items	Specified lubricants	Quantity
Clutch fluid	Brake fluid DOT3 or DOT4	As required
Push rod assembly	Rubber grease	As required
Boot		
Release cylinder push rod	mitsubishi genuine grease Part No. 0101011	As required

TROUBLESHOOTING

21100070015

Symptom	Probable cause	Remedy
Clutch slips	Insufficient clutch pedal play	Adjust
	Excessive wear of clutch disc facing	Replace
	Hardening of clutch disc facing, or adhesion of oil	Replace
	Clutch release fork catching	Repair or replace parts
	Weak or damaged diaphragm spring	Replace
	Clogging of hydraulic system	Repair or replace parts
Gear shift malfunction	Excessive clutch pedal play	Adjust
	Distorted clutch disc, excessive oscillation	Replace
	Clutch cover assembly worn	Replace
	Clutch disc spline worn or corroded	Replace
	Clutch disc facing peeling	Replace
	Clutch release bearing worn	Replace
	Damaged pressure plate or flywheel	Replace
Leakage, air mix or clogging of hydraulic system	Repair or replace parts	

Symptom	Probable cause	Remedy
Clutch noise	Insufficient clutch pedal play	Adjust
	Improper installation of clutch cover assembly	Repair or replace parts
	Excessive wear of clutch disc facing	Replace
	Clutch release fork catching	Repair or replace parts
	Clutch release bearing worn	Replace
	Weak or damaged torsion spring	Replace
	Damaged pilot bushing	Replace
	Insufficient lubrication of bearing sleeve sliding surface	Repair
Clutch pedal feels "heavy"	Insufficient lubrication of clutch pedal	Repair
	Insufficient lubrication of clutch disc spline	Repair
	Clutch release fork catching	Repair or replace parts
	Insufficient lubrication of bearing sleeve sliding surface	Repair
Worn or damaged clutch disc facing	Worn or damaged clutch disc facing	Replace
	Oil adhered to clutch disc facing	Replace
	Uneven height of diaphragm spring	Repair or replace parts
	Weak or damaged torsion spring	Replace
	Damaged pressure plate or flywheel	Replace
	Loose or damaged mounting	Replace or tighten mounting



ON-VEHICLE SERVICE

21100090110

CLUTCH PEDAL CHECK AND ADJUSTMENT

1. Turn back the carpet, etc. under the clutch pedal.
2. Measure the clutch pedal height.

Standard value (A):


163.5 - 166.5 mm (6.43 - 6.55 in.)

3. If the height of the clutch pedal is not within the standard value, loosen the lock nut and adjust the pedal height to the standard value using the adjusting bolt (Vehicles without auto-cruise control system) or clutch pedal position switch (Vehicles with auto-cruise control system) or push rod.

Caution


Do not push in the master cylinder push rod at this time.

Clutch pedal clevis pin play




A14W0002

Clutch pedal free play



14W0002

Distance between the clutch pedal and the firewall when the clutch is disengaged


14W0003
00003373

4. Measure the clutch pedal play.
Standard value (B): 1 - 3 mm (.04 - .12 in.)
5. If the clutch pedal play is not within the standard value, loosen the setting nut and move the push rod to adjust.
Caution
Do not push in the master cylinder push rod at this time.
6. After completing the adjustments, confirm that the clutch pedal free play (measured at the face of the pedal pad) and the distance between the clutch pedal (the face of the pedal pad) and the firewall when the clutch is disengaged are within the standard value ranges.
Standard value (C; including the clevis pin play): 6-13 mm (.24 - .51 in.)
Standard value (D): 70 mm (2.7 in.) or more
7. If the clutch pedal free play and the distance between the clutch pedal and the firewall when the clutch is disengaged do not agree with the standard values, it is probably the result of either air in the hydraulic system or a faulty master cylinder, release cylinder or clutch. Bleed the air, or disassemble and inspect the master cylinder, release cylinder or clutch.
8. Put back the carpet, etc.

INTERLOCK SWITCH OPERATING CHECK

21100100011

1. Lock the front wheels, apply the parking brake and put the shift lever in the 5th gear.
2. After normally adjusting the clutch pedal, check the interlock switch operation as follows:
 - (1) The engine should not start even if the ignition switch is turned to "START" position unless the clutch pedal is depressed. If the engine should start, check the interlock switch and the harness.
 - (2) The engine should start after the clutch has completely disengaged while the clutch pedal is depressed with the ignition switch turned to "START" position. If the engine should start before the clutch is disengaged or the engine does not start even if the clutch pedal is depressed, adjust the interlock switch.




INTERLOCK SWITCH CHECK AND ADJUSTMENT

21100110052

1. Adjust the clutch pedal. (Refer to P.21A-5.)
2. Check to be sure that the interlock switch is as shown in the illustration when the clutch pedal is depressed at its full stroke [143 mm (5.6 in.)]. If necessary, loosen the lock nut and adjust.

3. Connect an ohmmeter to the interlock switch connector, and then check for continuity when the clutch pedal is fully depressed and when it is released outward.

Pedal position	Terminal No.	
	1	2
fully depressed		
released	○ — ○	○ — ○




CLUTCH PEDAL POSITION SWITCH CONTINUITY CHECK

21100310018

1. Adjust the clutch pedal. (Refer to P.21A-5.)
2. Operate the clutch pedal, and check continuity between the terminals.

Measurement conditions	Terminal No.	
	1	2
When clutch pedal depressed	○ — ○	○ — ○
When clutch pedal not depressed		




BLEEDING

21100140099

Specified fluid: Brake fluid DOT 3 or DOT 4

Caution

Use the specified brake fluid. Avoid using a mixture of the specified fluid and other fluid.




CLUTCH PEDAL


REMOVAL AND INSTALLATION

Post-installation Operation

Clutch Pedal Adjustment (Refer to P.21A-5.)



Spring installation position



Removal steps

1. Clutch master cylinder installation nut
2. Master cylinder member bracket installation nut
3. Clevis pin
4. Pedal support member and clutch pedal assembly
5. Bolt
6. Return spring
7. Bushing
8. Pipe
9. Clutch pedal
10. Pedal pad
11. Stopper
12. Adjusting bolt
13. Clutch switch <Vehicles with auto-cruise control system>
14. Interlock switch
15. Pedal support member

INSPECTION

- Check the pedal shaft and bushing for wear.
- Check the clutch pedal for bend or torsion.
- Check the return spring for damage or deterioration.
- Check the pedal pad for damage or wear.

CLUTCH CONTROL


REMOVAL AND INSTALLATION

Pre-removal Operation

- Clutch Fluid Draining
- Air Cleaner Removal

Post-installation Operation

- Air Cleaner Installation
- Clutch Fluid Supplying
- Clutch Line Bleeding (Refer to P.21A-7.)
- Clutch Pedal Adjustment (Refer to P.21A-5.)



08M0016

00004774

Clutch master cylinder removal steps


1. Clevis pin
2. Clutch pipe connection
3. Clutch master cylinder

Clutch release cylinder removal steps


4. Clutch pipe connection
5. Clutch release cylinder

Clutch line removal steps


- | | |
|---------|----------------|
| ◀A▶ ▶A◀ | 6. Clutch pipe |
| ◀A▶ ▶A◀ | 7. Hose clip |
| ◀A▶ ▶A◀ | 8. Clutch hose |

**REMOVAL SERVICE POINTS****◀A▶ CLUTCH PIPE/CLUTCH HOSE DISCONNECTION**

1. Secure the nut on the clutch hose and loosen the flare nut on the clutch pipe.
2. Remove the hose clip from the clutch hose to remove clutch hose from bracket.

**INSTALLATION SERVICE POINT****▶A◀ CLUTCH HOSE/CLUTCH PIPE INSTALLATION**


1. Temporarily tighten the clutch pipe flare nut by hand, and then tighten it to the specified torque. Being careful that the clutch hose does not become twisted.
2. After tightening the clutch pipe flare nut and eye bolt, check to be sure there is no leakage of the clutch fluid.

**INSPECTION**

21100200049




- Check the pedal shaft bushing for wear.
- Check the pedal arm for bend or torsion.
- Check the master cylinder or clutch hose for fluid leakage.
- Check the clutch hose or pipe for cracks or clogging.

**CLUTCH MASTER CYLINDER
DISASSEMBLY AND REASSEMBLY**



08M0003

00004610



Disassembly steps

- ▶◀
1. Piston stopper ring
 2. Push rod assembly
 3. Boot
 4. Piston assembly
 5. Reservoir cap
 6. Spring pin

7. Reservoir tank
8. Clutch master cylinder body


Caution

Do not disassemble the piston assembly.

INSTALLATION SERVICE POINT

▶◀ **PUSH ROD ASSEMBLY INSTALLATION**

Set the length of the push rod assembly to the shown dimension to make the adjustment of the clutch pedal easier.



INSPECTION

- Check the inside cylinder body for rust or scars.
- Check the piston cup for wear or deformation.
- Check the piston for rust or scars.
- Check the clutch pipe connection for clogging.