

# CHASSIS ELECTRICAL

## CONTENTS

54109000112

<b>AIR CONDITIONING</b> ..... Refer to GROUP 55	<b>SPECIAL TOOL</b> ..... 51
<b>ANTENNA</b> ..... 67	<b>COMBINATION METERS</b> ..... 13
<b>ANTI-LOCK BRAKING SYSTEM</b> ..... Refer to GROUP 35B	<b>COMBINATION METERS</b> ..... 21
<b>AUTO-CRUISE CONTROL SYSTEM</b> ..... Refer to GROUP 17	<b>GENERAL INFORMATION</b> ..... 13
<b>BATTERY</b> ..... 3	<b>ON-VEHICLE SERVICE</b> ..... 17
<b>ON-VEHICLE SERVICE</b> ..... 3	Engine Coolant Temperature Gauge Simple Check ..... 19
Battery Charging ..... 3	Engine Coolant Temperature Gauge Unit Check ..... 20
Battery Check ..... 3	Fuel Gauge Simple Check ..... 18
Battery Testing Procedure ..... 4	Fuel Gauge Unit Check ..... 18
<b>CIGARETTE LIGHTER</b> ..... 50	Speedometer Check ..... 17
<b>CIGARETTE LIGHTER</b> ..... 50	Tachometer Check ..... 17
<b>GENERAL INFORMATION</b> ..... 50	<b>SEALANT</b> ..... 14
<b>TROUBLESHOOTING</b> ..... 50	<b>SERVICE SPECIFICATIONS</b> ..... 13
<b>CLOCK</b> ..... 51	<b>SPECIAL TOOLS</b> ..... 14
<b>CLOCK</b> ..... 51	<b>TROUBLESHOOTING</b> ..... 15

CONTINUED ON NEXT PAGE

### WARNINGS REGARDING SERVICING OF SUPPLEMENTAL RESTRAINT SYSTEM (SRS) EQUIPPED VEHICLES

#### WARNING!

- (1) Improper service or maintenance of any component of the SRS, or any SRS-related component, can lead to personal injury or death to service personnel (from inadvertent firing of the air bag) or to the driver and passenger (from rendering the SRS inoperative).
- (2) Service or maintenance of any SRS component or SRS-related component must be performed only at an authorized MITSUBISHI dealer.
- (3) MITSUBISHI dealer personnel must thoroughly review this manual, and especially its GROUP 52B - Supplemental Restraint System (SRS) and GROUP 00 - Maintenance Service before beginning any service or maintenance of any component of the SRS or any SRS-related component.

#### NOTE

The SRS includes the following components: SRS-ECU, SRS warning light, air bag module, clock spring and interconnecting wiring. Other SRS-related components (that may have to be removed/installed in connection with SRS service or maintenance) are indicated in the table of contents by and asterisk (\*).

<b>DOOR GLASS AND REGULATOR (POWER WINDOWS)</b>		<b>GENERAL INFORMATION</b> .....	49
..... Refer to GROUP 42		<b>HORN</b> .....	49
<b>DOOR HANDLE AND LATCH (DOOR LOCKING SYSTEM)</b>		<b>TROUBLESHOOTING</b> .....	49
..... Refer to GROUP 42		<b>IGNITION SWITCH*</b> .....	5
<b>DOOR MIRROR (REMOTE CONTROLLED MIRROR)</b>		<b>GENERAL INFORMATION</b> .....	5
..... Refer to GROUP 51		<b>IGNITION SWITCH</b> .....	10
<b>FOG LIGHT</b> .....	36	<b>SPECIAL TOOLS</b> .....	5
<b>FOG LIGHT</b> .....	39	<b>TROUBLESHOOTING</b> .....	6
<b>GENERAL INFORMATION</b> .....	36	<b>INTERIOR LIGHT</b> .....	45
<b>ON-VEHICLE SERVICE</b> .....	36	<b>GENERAL INFORMATION</b> .....	45
Bulb Replacement .....	38	<b>INTERIOR LIGHT</b> .....	46
Fog Light Aiming .....	36	<b>TROUBLESHOOTING</b> .....	45
<b>SERVICE SPECIFICATIONS</b> .....	36	<b>RADIATOR (RADIATOR FAN MOTOR)</b>	
<b>SPECIAL TOOL</b> .....	36	..... Refer to GROUP 14	
<b>TROUBLESHOOTING</b> .....	36	<b>RADIO AND TAPE PLAYER</b> .....	52
<b>HAZARD WARNING LIGHT SWITCH</b>		<b>RADIO AND TAPE PLAYER</b> .....	65
.....	48	<b>SPECIAL TOOL</b> .....	52
<b>HAZARD WARNING LIGHT SWITCH</b> ....	48	<b>TROUBLESHOOTING</b> .....	52
<b>SPECIAL TOOL</b> .....	48	<b>REAR COMBINATION LIGHT</b> .....	40
<b>HEADLIGHT AND TURN-SIGNAL LIGHT</b> .....	24	<b>GENERAL INFORMATION</b> .....	40
<b>GENERAL INFORMATION</b> .....	24	<b>REAR COMBINATION LIGHT</b> .....	43
<b>HEADLIGHT AND FRONT TURN-SIGNAL LIGHT</b> .....	33	<b>SPECIAL TOOLS</b> .....	41
<b>ON-VEHICLE SERVICE</b> .....	28	<b>TROUBLESHOOTING</b> .....	41
Bulb Replacement .....	32	<b>REAR WINDOW DEFOGGER</b> .....	68
Headlight Aiming .....	28	<b>ON-VEHICLE SERVICE</b> .....	68
Luminous Intensity Measurement .....	32	Printed-heater Line Check .....	68
<b>SERVICE SPECIFICATIONS</b> .....	25	<b>REAR WINDOW DEFOGGER SWITCH</b> ..	69
<b>SPECIAL TOOLS</b> .....	25	<b>RHEOSTAT</b> .....	47
<b>TROUBLESHOOTING</b> .....	26	<b>RHEOSTAT</b> .....	47
<b>HEATER</b> .....	55	<b>SPECIAL TOOL</b> .....	47
..... Refer to GROUP 55		<b>SPEAKER</b> .....	66
<b>HIGH MOUNTED STOP LIGHT</b> .....	44	<b>SUNROOF</b> .....	Refer to GROUP 42
<b>HIGH MOUNTED STOP LIGHT</b> .....	44	<b>SUPPLEMENTAL RESTRAINT SYSTEM (SRS)</b> .....	Refer to GROUP 52B
<b>TROUBLESHOOTING</b> .....	44	<b>WINDSHIELD WIPER AND WASHER</b>	
<b>HORN</b> .....	49	..... Refer to GROUP 51	

54100100057

## BATTERY

### ON-VEHICLE SERVICE

#### BATTERY CHECK

##### BATTERY VISUAL INSPECTION (1)

The battery contains a visual test indicator which gives a blue signal when an adequate charge level exists, and a white signal when charging is required.

##### BATTERY VISUAL INSPECTION (2)

Make sure ignition switch is in OFF position and all battery fed accessories are OFF.

1. Disconnect (-) ground cable from battery before disconnecting (+) cable.
2. Remove the battery from the vehicle.

#### Caution

**Care should be taken in the event battery case is cracked or leaking to protect hands from the electrolyte. A suitable pair of rubber gloves (not the household type) should be worn when removing battery by hand.**

3. Inspect battery carrier for damage caused by loss of acid from battery. If acid damage is present, it is necessary to clean area with a solution of clean warm water and baking soda. Scrub area with a stiff bristle brush. Wipe clean with a cloth moistened with ammonia or baking soda in water.
4. Clean the battery, especially the top with same solutions as described in step 3.
5. Inspect battery case and cover for cracks. If cracks are present, battery must be replaced.
6. Clean the battery post with a suitable battery post cleaning tool.
7. Clean the inside surfaces of the terminal clamps with a suitable battery terminal cleaning tool. Replace damaged or frayed cables and broken terminal clamps.
8. Install the battery in the vehicle.
9. Connect (+) cable first, then (-) cable.
10. Tighten the hold down nut securely.

54100110074

lyte temperature above 55°C (131°F) is harmful to the battery, causing deformation of battery cell, decrease in life of battery, etc.

#### CHARGE RATE

If the test indicator is white, the battery should be charged as outlined below.

When the dot appears or when maximum charge shown below is reached, charging should be stopped.

### BATTERY CHARGING


#### Caution

**When batteries are being charged, an explosive gas forms beneath the cover of each cell. Do not smoke near batteries on charge or which have recently been charged.**

**Do not break live circuits at the terminals of the batteries on charge. A spark will occur where the live circuit is broken.**

**Keep all open flames away from the battery.**

Battery electrolyte temperature may temporarily be allowed to rise to 55°C (131°F). Increase of electro-




## Charge Rate Chart

Battery	55B24L (433 amps)
Slow charging	5 amps 10 hrs.
	10 amps 5 hrs.
Fast charging	20 amps 2.5 hrs.
	30 amps 1.5 hrs.

## BATTERY TESTING PROCEDURE

54100120091

## TEST STEP



## LOAD TEST CHART

Temperature °C (°F)	21 (70) and above	16 (60)	10 (50)	4 (40)	-1 (30)	-7 (20)	-12 (10)	-18 (0)
Minimum voltage	9.6	9.5	9.4	9.3	9.1	8.9	8.7	8.5

## LOAD TEST RATE CHART

Load test (AMPS)	210 amps
Cranking rating (0°F)	433 amps
Reserve capacity	79 minutes
Application	55B24L

# IGNITION SWITCH

54300010240

## GENERAL INFORMATION




### OPERATION


#### Ignition key reminder warning buzzer circuit

- When, with the ignition key inserted in the key cylinder (with the key reminder switch at OFF), the driver's door is opened (door switch is switched ON), the ECU detective circuit will activate.
- This system is controlled by either ETACS-ECU or BUZZER-ECU on non-ETACS equipped vehicles.
- With the detective circuit activated, buzzer output from the drive circuit makes the buzzer sound intermittently to remind the ignition key is still in the ignition switch.

## SPECIAL TOOLS

54300060214

Tool	Tool number and name	Supersession	Application
 B991502	MB991502 Scan tool (MUT-II)	MB991496-OD	ETACS-ECU input signal checking
 B991325	ROM pack		ETACS-ECU input signal checking
 B991529	MB991529 Diagnostic trouble code check harness	Tool not necessary if scan tool <MUT-II> is available	ETACS-ECU input signal checking (when using a voltmeter)



## TROUBLESHOOTING

5430070093

### DIAGNOSTIC FUNCTION

#### INPUT SIGNAL INSPECTION POINTS <VEHICLES WITH ETACS-ECU>


##### When Using the Scan Tool

1. Connect the scan tool to the data link connector.

##### Caution

The ignition switch should always be turned OFF when connecting and disconnecting the scan tool.

2. If buzzer of the scan tool sounds once when a switch is operated (ON/OFF), the ETACS-ECU input signal for that switch circuit system is normal.



##### When Using the Voltmeter

1. Use the special tool to connect a voltmeter between the ground terminal and the ETACS terminal of data link connector.
2. If the voltmeter indicator deflects once when a switch is operated (ON/OFF), the ECU input signal for that switch circuit system is normal.

## INSPECTION CHART FOR TROUBLE SYMPTOMS

54300720709

Trouble symptom	Inspection procedure No.	Reference page	
Communication with scan tool is not possible. <Vehicles with ETACS-ECU>	Communication with all systems is not possible.	1	54-7
	Communication with the one-shot pulse input signal only is not possible.	2	54-7
Ignition key reminder warning buzzer	While the ignition key reminder warning buzzer sounds, the buzzer does not stop sounding when the ignition key is turned to the ON position. (The buzzer does not sound by closing the driver's door.)	3	54-7
	The ignition key reminder warning buzzer does not stop sounding by removing the ignition key. (The buzzer does not sound by closing the driver's door.)	4	54-8
	The ignition key reminder warning buzzer does not sound when the ignition key is inserted and the driver's door is opened. (The ignition key is turned to OFF position.)	5	54-9

**INSPECTION PROCEDURE FOR TROUBLE SYMPTOMS**


**INSPECTION PROCEDURE 1**

<b>Communication with scan tool is not possible. (Communication with all systems is not possible.)</b>	<b>Probable cause</b>
The reason is probably a defect in the power supply system (including ground) for the diagnostic line.	<ul style="list-style-type: none"> <li>• Malfunction of connector</li> <li>• Malfunction of harness wire</li> </ul>

Refer to GROUP 13A - Trouble-shooting.


**INSPECTION PROCEDURE 2**

<b>Communication with scan tool is not possible. (Communication with the one-shot pulse input signal only is not possible.)</b>	<b>Probable cause</b>
The cause is probably a defective one-shot pulse input signal circuit system of the diagnostic line.	<ul style="list-style-type: none"> <li>• Malfunction of connector</li> <li>• Malfunction of harness wire</li> <li>• Malfunction of ECU</li> </ul>



**INSPECTION PROCEDURE 3**

<ul style="list-style-type: none"> <li>• While key hole illumination light is illuminated, ignition key is turned to the ON position but key hole illumination light does not switch off. (However, it switches off after 10 seconds.)</li> <li>• While the ignition key reminder warning buzzer sounds, the buzzer does not stop sounding when the ignition key is turned to the ON position. (The buzzer does not sound by closing the driver's door.)</li> </ul>	<b>Probable cause</b>
The cause is probably a defective ignition switch input circuit or a defective ECU.	<ul style="list-style-type: none"> <li>• Malfunction of connector</li> <li>• Malfunction of harness wire</li> <li>• Malfunction of ECU</li> </ul>




## INSPECTION PROCEDURE 4

**The ignition key reminder warning buzzer does not stop sounding by removing the ignition key.  
(The buzzer does not sound by closing the driver's door.)**

**Probable cause**

It is possible that there is a malfunction of the key reminder switch input circuit or the ECU.

- Malfunction of key reminder switch
- Malfunction of connector
- Malfunction of harness wire
- Malfunction of ECU





**INSPECTION PROCEDURE 5**

The ignition key reminder warning buzzer does not sound when the ignition key is inserted in the key cylinder and the driver's door is opened.  
(The ignition key is turned to OFF position.)

Probable cause

It is possible that there is a malfunction of the door switch input circuit or the key reminder switch input circuit, in case the ignition key hole illumination light is defective.

- Malfunction of driver's side door switch
- Malfunction of bulb
- Malfunction of connector
- Malfunction of harness wire
- Malfunction of ECU

<Vehicles with ETACS-ECU>  
**Scan Tool Input Signal Inspection**  
Driver's side door switch input signal  
**OK:** The scan tool buzzer sounds once when the driver's side door switch is ON.

<Vehicles with BUZZER-ECU>  
Driver's door switch input circuit system inspection (Refer to Inspection Procedure 6.)

<Vehicles with ETACS-ECU>  
**Scan Tool Input Signal Inspection**  
Driver's side door switch input signal  
**OK:** The scan tool buzzer sounds once when the switch is removed or inserted.  
For the input check, open the door. (The door switch is switched on.)

Key reminder switch continuity check (Refer to P.54-12.)  
Check the harness wire between the key reminder switch and junction block (4), and repair if necessary.

Replace the ECU.

Replace the ECU.

**NOTE**  
The broken line indicates vehicles with BUZZER-ECU.

**INSPECTION PROCEDURE 6**

**Driver's side door switch input circuit system inspection**

Door switch inspection (Refer to GROUP 42 - Door Assembly.)

Door switch ground inspection

Disconnect the door switch connector E-15 and measure at the harness side.  
● Voltage between the terminal (2) and ground  
**OK:** Battery positive voltage

Check trouble symptom.

Replace the ECU.

Replace

Repair

Check the following connectors. E-15, B-64 and B-65

Check trouble symptom.

Check the harness wire between the door switch and junction block (4), and repair if necessary.

Repair

## IGNITION SWITCH


## REMOVAL AND INSTALLATION

**CAUTION: SRS**

Before removal of air bag module and clock spring, refer to the following items:

GROUP 52B - SRS Service Precautions

GROUP 52B - Air Bag Module and Clock Spring



A16M0326

**Steering lock cylinder removal steps**

1. Steering wheel (Refer to GROUP 37A - Steering Wheel and Shaft)
2. Hood lock release handle
3. Instrument under cover
4. Column cover, lower
5. Column cover, upper
6. Clock spring and column switch assembly
7. Ring cover
8. Steering lock cylinder

**Key reminder switch removal steps**


4. Column cover, lower
5. Column cover, upper
9. Key reminder switch

**Ignition switch removal steps**

4. Column cover, lower
5. Column cover, upper
10. Ignition switch

**BUZZER-ECU or ETACS-ECU removal steps**



11. Cowl side trim (LH)
12. Junction block
13. BUZZER-ECU or ETACS-ECU

**REMOVAL SERVICE POINT****◀A▶ STEERING LOCK CYLINDER REMOVAL**

1. Insert the key in the steering lock cylinder and turn it to the "ACC" position.
2. Using a cross-tip (+) screwdriver (small) or similar tool, push the lock pin of the steering lock cylinder inward and then pull the steering lock cylinder toward you.

**INSTALLATION SERVICE POINT****▶A◀ CLOCK SPRING AND COLUMN SWITCH ASSEMBLY INSTALLATION**


1. Tighten the screws in the order shown.
2. Align the clock spring mating marks and, after turning the front wheels to the straight-ahead position, install the clock springs to the column switch.

**Mating Mark Alignment**

Turn the clock spring clockwise fully, and then turn back it approx. 3 4/5 turns counterclockwise to align the mating marks.

**Caution**

If the clock spring's mating marks are not properly aligned, the steering wheel may not rotate completely during a turn, or the flat cable within the clock spring may be severed, obstructing normal operation of the SRS and possibly leading to serious injury to the vehicle's driver.



16U0113


**INSPECTION**

54300220117

**IGNITION SWITCH CONTINUITY CHECK**

1. Remove the column cover lower and upper.
2. Disconnect the wiring connector from the ignition switch and connect an ohmmeter to the switch side connector.
3. Operate the ignition switch and check the continuity.

Ignition key position	Terminal No.				
	1	2	3	5	6
LOCK					
ACC		○	—	○	
ON	○	○	○	○	
START		○	○	—	○



16M0327

**KEY REMINDER SWITCH CONTINUITY CHECK**

54300770056

1. Remove the column cover lower and upper.
2. Disconnect the wiring connector from the key reminder switch or from the key hole illumination light and connect an ohmmeter to the switch side connector.
3. Check the continuity when the ignition key is pulled out of and inserted into the steering lock cylinder.

Ignition key	Terminal No.	
	2	5
Removed	○	○
Inserted		

# COMBINATION METERS

## GENERAL INFORMATION

### OPERATION

#### Fuel gauge

- When the ignition key is at the "ON" position, the fuel gauge is activated.
- When there is much fuel, the unit's resistance is small and the current flowing in the circuit is great, so the gauge's indicator indicates in the "F" area.
- When there is little fuel, the unit's resistance is high and the current flowing in the circuit is small, so the gauge's indicator indicates in the "E" area.

#### Engine coolant temperature gauge

- When the ignition key is at the "ON" position, the engine coolant temperature gauge is activated.
- When the engine coolant temperature is high, the unit's resistance is low and there is a great flow of current in the circuit, so the gauge's indicator indicates in the "H" area.
- When the engine coolant temperature is low, the unit's resistance is high and there is a small flow of current in the circuit, so the gauge's indicator indicates in the "C" area.

#### Electric type speedometer

- With the ignition switch turned to "ON" position, speedometer operates.

- The electric type speedometer uses an electric circuit to pulse the wave of the electric signal from the vehicle speed sensor. After calculating vehicle speed, the speedometer driver circuit drives the pointer.

#### Brake warning light

This warning light illuminates when the ignition key is in "ON" position, and goes off after the engine has started. This indicator comes on when the parking brake is applied or brake fluid level falls below the specific level.

#### Oil pressure warning light

This warning light illuminates when the ignition key is in "ON" position, and goes off after the engine has started. This indicator comes on when the engine stalls or trouble occurs in the oil circulating system while driving.

#### Low fuel warning light

With the ignition key turned to the "ON" position, the fuel level sensor resistance becomes small by its exposure from the fuel, when the fuel level comes down.

When the resistance value becomes lower than the specified value, the fuel warning light comes on to indicate that the fuel residual quantity is small.

## SERVICE SPECIFICATIONS

Items		Standard values
Speedometer indication error mph	20	19 - 22
	40	38 - 44
	60	57 - 66
	80	76 - 88
	100	94 - 110
Tachometer indication error rpm	700	±100
	3,000	±150
	5,000	±250
	6,000	±300
Fuel gauge unit resistance Ω	Float point "F"	0.9 - 5.1
	Float point "E"	102.3 - 117.7
Fuel gauge unit float height mm (in.)	A (Float point "F")	17.4 (.69)
	B (Float point "E")	130.2 (5.1)

Items	Standard values	
Fuel gauge resistance $\Omega$	Power supply and ground	192 $\pm$ 19.2
	Power supply and fuel gauge	89 $\pm$ 8.9
	Fuel gauge and ground	103 $\pm$ 10.3
Engine coolant temperature gauge resistance $\Omega$	Power supply and ground	187 $\pm$ 18.7
	Power supply and engine coolant temperature gauge	90 $\pm$ 4.5
	Engine coolant temperature gauge and ground	247 $\pm$ 24.7
Engine coolant temperature gauge unit resistance [at 70°C (158°F)] $\Omega$		104 $\pm$ 13.5






## SEALANT

54300050020

Items	Specified sealants
Engine coolant temperature gauge unit threaded portion	3M Adhesive nut locking No. 4171 or equivalent

## SPECIAL TOOLS

54300060221

Tool	Tool number and name	Supersession	Application
<p>A</p>  <p>B</p>  <p>C</p>  <p>D</p> 	MB991223 Harness set A: MB991219 Test harness B: MB991220 LED harness C: MB991221 LED adapter D: MB991222 Probe	MB991223	Fuel gauge simple check A: Connector pin contact pressure check B,C: Power circuit check D: Commercial tester connection
	MB990784 Ornament remover	General service tool	Removal of meter bezel

# TROUBLESHOOTING


## INSPECTION CHART FOR TROUBLE SYMPTOMS

Trouble symptom	Inspection procedure	Reference page
Speedometer does not work.	1	54-15
Tachometer does not work.	2	54-16


## INSPECTION PROCEDURE FOR TROUBLE SYMPTOMS

### Inspection Procedure 1

Speedometer does not work.	Probable cause
The cause may be a defective vehicle speed sensor circuit system or a defective speedometer. Vehicle speed sensor is also used by the engine-ECU and A/T-ECU.	<ul style="list-style-type: none"> <li>● Malfunction of vehicle speed sensor</li> <li>● Malfunction of speedometer</li> <li>● Malfunction of harness or connector</li> </ul>




## Inspection Procedure 2



## Inspection Procedure 3

## Vehicle speed sensor circuit system inspection





5430090084

**ON-VEHICLE SERVICE****SPEEDOMETER CHECK**

1. Adjust tire pressure to the specified level. (Refer to GROUP 31 - Service Specifications.)
2. Set the vehicle onto a speedometer tester and use wheel chocks to hold the rear wheels.
3. Make sure the parking brake has been applied.

4. To prevent the front wheel from moving from side to side, attach tension bars to the tie-down hook, and secure both ends to anchor plates.
5. To prevent the vehicle from launching, attach a chain or wire to the rear retraction hook, and make sure the end of the chain or wire is secured firmly.
6. Check if the speedometer indicator range is within the standard values.

**Caution**

**Do not operate the clutch suddenly. Do not increase/decrease speed rapidly while testing.**

**Standard values:**

Standard indication mph	Allowable range mph
20	19 - 22
40	38 - 44
60	57 - 66
80	76 - 88
100	94 - 110

7. If not to the standard value, inspect for proper tire size. If not correct, replace tires with original size tires and retest. If correct, replace the speedometer. If still not to standard value, replace vehicle speed sensor.


**TACHOMETER CHECK**

54300100084


1. Insert a paper clip in the engine speed detection connector from the harness side, and attach an external high quality tachometer.

**NOTE**


For tachometer check, use an external high quality inductive tachometer.



B16S0001



A16M0238






- Compare the readings of the vehicle tachometer and the external tachometer at every engine speed, and check if the variations are within the standard values.

**Standard values:**

700 r/min :  $\pm 100$  r/min  
 3,000 r/min :  $\pm 150$  r/min  
 5,000 r/min :  $\pm 250$  r/min  
 6,000 r/min :  $\pm 300$  r/min

54300110100

**FUEL GAUGE SIMPLE CHECK****FUEL GAUGE UNIT CHECK**

54300120141

Remove the fuel gauge unit from the fuel tank. (Refer to GROUP 13F.)

**FUEL GAUGE UNIT RESISTANCE**


- Check that the resistance value between the fuel gauge terminal and ground terminal is at standard value when fuel gauge unit float is at point F (highest) and point E (lowest).

**Standard value:**

Point F: 0.9 - 5.1  $\Omega$

Point E: 102.3 - 117.7  $\Omega$

- Check that resistance value changes smoothly when float moves slowly between point F (highest) and point E (lowest).
- If all checks are correct, proceed to fuel gauge unit float height check. If any check is not correct, replace the fuel gauge unit.




**FUEL GAUGE UNIT FLOAT HEIGHT**

1. Move float and measure the height A at point F (highest) and B at point E (lowest) with float arm touching stopper.

**Standard value:**

- A: 17.4 mm
- B: 130.2 mm

2. Adjust the float arm to the standard value, then proceed to the thermistor check.



**THERMISTOR**

1. Connect fuel gauge unit (thermistor) to battery via test lamp (12 V - 3.4 W). Immerse in water.
2. Condition is good if lamp goes off when the thermistor is immersed in water and comes on when it is taken out of water.



**Caution**


After finishing this test, wipe the unit dry and install it in the fuel tank.

3. If all checks are correct, the fuel gauge unit is OK. If any check is not correct, replace the fuel gauge unit.

**ENGINE COOLANT TEMPERATURE GAUGE SIMPLE CHECK**

54300140116






## ENGINE COOLANT TEMPERATURE GAUGE UNIT CHECK

54300150263

1. Bleed the engine coolant.  
(Refer to GROUP 00 – Maintenance Service.)
2. Remove the engine coolant temperature gauge unit.
3. Immerse the unit in 70°C water to measure the resistance.

**Standard value: 104 ± 13.5 Ω**

4. If within the standard value, the sensor is OK. Re-install it, then check the engine coolant temperature gauge.  
(Refer to P.54-21.) If not within the standard value, replace it.



5. After checking, apply the specified adhesive around the thread of engine coolant temperature gauge unit.

**Specified sealant:**


**3M Adhesive Nut Locking No. 4171 or equivalent**

6. Add engine coolant.  
(Refer to GROUP 00 – Maintenance Service.)

## COMBINATION METERS

54300290118

## REMOVAL AND INSTALLATION



## Vehicle speed sensor removal steps

- Air Cleaner, Air Intake Hose
- 1. Vehicle speed sensor

## Combination meter removal steps

2. Meter bezel
3. Combination meter


00004865

## INSPECTION





54300640067

## VEHICLE SPEED SENSOR CHECK

1. Remove the vehicle speed sensor and connect a 3 - 10 k $\Omega$  resistance as shown in the illustration.
2. Turn the shaft of the vehicle speed sensor and check that there is voltage between terminals 2 - 3. (1 turn = 4 pulses)
3. If within the standard value, the vehicle speed sensor is OK.  
If not within the standard value, replace the vehicle speed sensor.



16W0029



### FUEL GAUGE RESISTANCE CHECK

54300300088

1. Remove the power supply tightening screw.
2. Use an ohmmeter to measure the resistance value between the terminals.

#### Standard value:

Power supply - Ground:  $192 \pm 19.2$

Power supply - Fuel gauge:  $89 \pm 8.9$

Fuel gauge - Ground:  $103 \pm 10.3$

3. If within the standard value, the fuel gauge is OK.  
If not within the standard value, replace the fuel gauge.

#### Caution

When inserting the testing probe into the power supply terminal, be careful not to touch the printed board.

### ENGINE COOLANT TEMPERATURE GAUGE RESISTANCE CHECK

54300300095

1. Remove the power supply tightening screw.
2. Use an ohmmeter to measure the resistance value between the terminals.

#### Standard value:

Power supply - Ground:  $187 \pm 18.7$

Power supply - Engine coolant temperature gauge:  $90 \pm 4.5$

Engine coolant temperature gauge - Ground:  $247 \pm 24.7$

3. If within the standard value, the engine coolant temperature gauge is OK.  
If not within the standard value, replace the engine coolant temperature gauge.


#### Caution

When inserting the testing probe into the power supply terminal, be careful not to touch the printed board.


DISASSEMBLY AND REASSEMBLY

54300310074

<Vehicle without tachometer>



<Vehicle with tachometer>



16M0329

16M0330

00004794

**Disassembly steps**

- |                                     |   |
|-------------------------------------|---|
| 1. Bulb, socket                     | 9. Fuel gauge                                 |
| 2. Automatic transaxle indicator    | 10. Fuel and engine coolant temperature gauge |
| 3. Meter glass                      | 11. Speedometer                               |
| 4. Meter window plate               | 12. Tachometer                                |
| 5. Turn-signal indicator lens       | 13. Printed circuit board                     |
| 6. Indicator lens                   | 14. Meter case                                |
| 7. Indicator prism                  |   |
| 8. Engine coolant temperature gauge |   |

# HEADLIGHT AND TURN-SIGNAL LIGHT

## GENERAL INFORMATION

### OPERATION

#### Low-beam and high-beam

- Turn the lighting switch to "second position," and the contact point of the headlight relay will be closed to turn on the headlight relay.
- Pull the dimmer switch to "LO," and the low-beam will be lit. Pull the switch to "HI," and the high-beam will be lit.

#### Passing

- When the low-beam is lit, pull the passing switch to "ON," and the high-beam will be lit together with the low-beam.
- When the dimmer switch is at "LO" and the lighting switch is at "OFF" or "first position," and the passing switch is pulled "ON," the contact point of the headlight relay will be closed, turning on the headlight relay, and the low-beam and high-beam will be simultaneously lit.
- When the dimmer switch is at "HI" and the lighting switch is at "OFF" or "first position," and the passing switch is pulled "ON," the contact point of the headlight relay will be closed, turning on the headlight relay, and the high-beam will be simultaneously lit.

#### Low-beam and High-beam indicator light

- When the high-beam is lit or when the passing switch is activated, the high-beam indicator light will be lit.

#### Turn-signal lights

##### When operation is normal

- When the ignition switch is switched to the "ON" position, battery voltage is applied (via the hazard warning light switch) to the turn-signal and hazard-flasher unit.
- When the turn-signal switch is switched to the "LH" (or "RH") position, transistor (within the flasher unit) is switched ON and the relay contact (also within the flasher unit) is switched ON. As a result, the "LH" (or "RH") turn-signal lights and turn-signal indicator light illuminate.
- At the same time, charging to the capacitor (within the flasher unit) begins, and charging continues until the lower-limit potential (set by microcomputer within the flasher unit) is reached.

- When the capacitor becomes fully charged, the microprocessor (within the flasher unit) output reverses and transistor is switched OFF; the relay contact is also switched OFF, and, as a result, the "LH" (or "RH") turn-signal lights and turn-signal indicator light are switched OFF.
- At the same time that transistor (within the flasher unit) is switched OFF, the capacitor begins discharging, and, when discharging finishes, the output of the microcomputer (within the flasher unit) once again reverses and transistor (within the flasher unit) is switched ON, after which the "LH" (or "RH") turn-signal lights and turn-signal indicator light illuminate.
- As a result of the continued repetition of the steps described above, the "LH" (or "RH") turn-signal lights and turn-signal indicator light flash ON and OFF repeatedly.

##### If one light's wiring is damaged or disconnected

- If the bulb for one turn-signal light is damaged or disconnected, the resistance for the entire light circuitry increases, resulting in a decrease of the voltage at the resistor (parallel connection with capacitor) part within the flasher unit.
- As a result of this being detected, the lower-limit potential set by the microcomputer (within the flasher unit) is increased, with the result that the time required for charging of the capacitor becomes shorter.
- As a result, the ON and OFF cycles of transistor (within the flasher unit) also become shorter, and thus the number of flashes of the lights becomes greater.

##### Hazard-warning lights

- When the hazard warning light switch is switched to the "ON" position, the relay contact of the flasher unit is switched ON and OFF repeatedly, in the same manner as for the operation of the turn-signal lights, and the left and right turn-signal lights and turn-signal indicator lights simultaneously flash repeatedly.

##### NOTE

The number of flashes of the hazard-warning lights does not change if there is damaged or disconnected wiring of one light.

#### Conditions for switch-ON of headlight relay

Ignition switch	Lighting switch	Dimmer/passing switch	Headlight relay
"ACC" or "ON"	"Second position"	At rest	ON
"ACC" or "ON"	"LO" or "OFF"	"PASS"	ON







## SERVICE SPECIFICATIONS

54200030137

Items	Limit
Headlight intensity	20,000 cd or more

## SPECIAL TOOLS

54200060266

Tool	Tool number and name	Supersession	Application
 <p>B991502</p>	MB991502 Scan tool (MUT-II)	MB991496-OD	ETACS-ECU input signal checking
 <p>B991325</p>	ROM pack		ETACS-ECU input signal checking
 <p>B991529</p>	MB991529 Diagnostic trouble code check harness	Tool not necessary if scan tool <MUT-II> is available	ETACS-ECU input signal checking (when using a voltmeter)
 <p>16Z0012</p>	Headlight aimer	General service tool	Headlight aiming

# TROUBLESHOOTING

## TROUBLESHOOTING HINTS

### Headlight

1. None of the headlight comes on.
  - (1) Tail light comes on.
    - Check the headlight relay.  
(Refer to P.54-33.)
    - Check the lighting switch.  
(Refer to P.54-34.)
  - (2) The tail light neither comes on nor does the charging warning light go out.
    - Check the fusible link No. 6.
2. Low-beam does not come on on either side.
  - Check the grounding circuit.
  - Check each headlight.
3. High-beam does not come on on either side but comes on when the passing switch is ON.
  - Check the dimmer switch.  
(Refer to P.54-34.)
4. High-beam indicator light does not come on. However, high-beam is lit when the dimmer switch is at "HI" position or the passing switch is activated.
  - Check the dedicated fuse No. 7.
  - Check the bulb.
5. When passing is activated, the headlights will not come on. However, the headlights will come on when the dimmer switch is at either "LO" or "HI."
  - Check the passing switch.  
(Refer to P.54-34.)

### Turn-signal light

1. The turn-signal lights and hazard-warning lights do not operate at all.
  - Check the hazard warning light switch contact (power supply side).
  - Check the flasher unit.
2. All turn-signal lights at the left (or right) side do not function.
 

The hazard-warning lights function normally.

  - Check the hazard warning light switch contact (turn-signal side).
  - Check the turn-signal switch.  
(Refer to P.54-34.)
3. The number of flashes of the turn-signal lights is excessive.
  - Check the bulbs.
4. The hazard-warning lights do not function.
 

The turn-signal lights function normally.

  - Check the hazard warning light switch contact (hazard-warning light side).

## INSPECTION CHART FOR TROUBLE SYMPTOMS

Trouble symptoms	Inspection procedure	Reference page
Communication with Scan Tool is impossible. <Vehicles with ETACS-ECU>	Communication with all systems is impossible.	1 54-27
	Communication with one-shot pulse input signal only is impossible.	2 54-27
The lighting monitor buzzer does not sound under the following conditions while tail lights or headlights illuminate. <ul style="list-style-type: none"> <li>● When the ignition switch is turned to OFF and the driver's side door is open.</li> </ul>	3	54-27

## INSPECTION PROCEDURE FOR TROUBLE SYMPTOMS


### Inspection Procedure 1

<b>Communication with the scan tool is impossible. (Communication with all systems is impossible.)</b>	<b>Probable cause</b>
The cause is probably a defective power supply system (including ground) for the diagnosis line.	<ul style="list-style-type: none"> <li>● Malfunction of connector</li> <li>● Malfunction of harness wire</li> </ul>

Refer to GROUP 13A - Troubleshooting.


### Inspection Procedure 2

<b>Communication with the scan tool is impossible. (Communication with the one-shot pulse input signal only is impossible.)</b>	<b>Probable cause</b>
The cause is probably a defective one-shot pulse input circuit system of the diagnosis line.	<ul style="list-style-type: none"> <li>● Malfunction of connector</li> <li>● Malfunction of harness wire</li> <li>● Malfunction of ETACS-ECU</li> </ul>




### Inspection Procedure 3

<b>The ignition switch is turned to the "OFF" position and the driver's side door is opened while the tail lights or headlight are operating, but the light reminder warning buzzer does not sound.</b>	<b>Probable cause</b>
The cause is probably a defective lighting switch input circuit system or a defective driver's side door switch input circuit system.	<ul style="list-style-type: none"> <li>● Malfunction of driver's side door switch</li> <li>● Malfunction of harness or connector</li> <li>● Malfunction of BUZZER-ECU or ETACS-ECU</li> </ul>



## Inspection Procedure 4

## Driver's side door switch input circuit system inspection






## ON-VEHICLE SERVICE

54200090104

AIMING WITH GAUGES ON THE HEADLIGHT  
<4-door models>

## PRE-AIMING INSTRUCTIONS

1. Inspect for badly rusted or faulty headlight assemblies.
2. These conditions must be corrected before a satisfactory adjustment can be made.
3. Place vehicle on a lever floor.
4. Bounce front suspension through three (3) oscillations by applying body weight to hood or bumper.
5. Inspect tire inflation. Adjust inflation as necessary.
6. Rock vehicle sideways to allow vehicle to assume its normal position.
7. If fuel tank is not full, place a weight in trunk of vehicle to simulate weight of a full tank [3 kg (6.5 lbs.) per gallon.]
8. There should be no other load in the vehicle other than driver or substituted weight of approximately 70 kg (150 lbs.) placed in driver's position.
9. Thoroughly clean headlight lenses.



### VERTICAL ADJUSTING


Adjust the vertical angle by rotating the vertical adjusting screw so that the bubble in the vertical adjusting gauge locates inside the adjusting range.




### HORIZONTAL ADJUSTING

1. Check that gear (A) and gear (B) are engaged. If they are not engaged, press down the stopper until the gears engage.
2. Turn the horizontal adjusting screw to align the "O" mark of gear (B) with the stopper line and the headlight housing line.

#### NOTE

If this aiming is impossible due to the body damage, refer to "Aiming with screen."





## AIMING WITH SCREEN OR WALL HEADLIGHT AIM PREPARATION

1. Set the distance between the screen and the bulb center marks of the headlight as shown in the illustration.
2. Four lines of adhesive tape or equivalent markings are required on screen or wall:
  - (1) Position a vertical tape or mark so that it is aligned with the vehicle center line.
  - (2) Position a horizontal tape or mark with reference to center line of headlight bulb dimension A.
  - (3) Position a vertical tape with reference to the center line of each headlight bulb dimension B.

## VISUAL HEADLIGHT ADJUSTMENT

1. A properly aimed lower beam will appear on the aiming screen 3 m (9.8 ft.) in front of the vehicle. The shaded area as shown in the illustration indicates high intensity zone.

### Standard value:

(Vertical direction)

36 mm (1.42 in.) below horizontal (H)

(Horizontal direction)

Position where the 15° sloping section intersects the vertical line (V)

### NOTE

The position 3 m (9.8 feet) in front of the vehicle indicates the position from the headlight center mark.


2. When adjusting headlight, disconnect the other headlight harness.
3. Adjust low beam of the headlights to match the low beam pattern on the aiming screen.

### Caution


Do not cover a headlight for more than three minutes, or the plastic headlight lens will be deformed.

## NOTE



If the visual headlight adjustment at low beam is made, the adjustment at high beam is not necessary.

**VERTICAL ADJUSTING <4-door models>**

1. Adjust the vertical angle by rotating the vertical adjusting screw so that the bubble in the vertical adjusting gauge locates inside the adjusting range.
2. Check to see if the light distribution projected on the aiming screen is the same as the light distribution pattern described in Visual Headlight Adjustment.
3. If they differ, turn the vertical adjusting screw to adjust the vertical angle until the light distribution coincides with the correct lighting pattern.

**HORIZONTAL ADJUSTING <4-door models>**

1. Check that gear (A) and gear (B) are engaged. If they are not engaged, press down the stopper until the gears engage.
2. Check to see if the light distribution projected on the aiming screen is the same as the light distribution pattern described in Visual Headlight Adjustment.
3. If they differ, turn the vertical adjusting screw to adjust the vertical angle until the light distribution coincides with the correct lighting pattern.
4. Turn the horizontal adjusting screw to align the "O" mark of gear (B) with the stopper line and the headlight housing line.
5. Pull the stopper up to disengage gears (A) and (B).



## LUMINOUS INTENSITY MEASUREMENT

Measure the luminous intensity of headlights with a photometer in accordance with the instruction manual prepared by the manufacturer of the photometer and make sure that the luminous intensity is within the following limit.

**Limit: 20,000 cd or more**

### NOTE

- (1) When measuring the luminous intensity of headlight, keep the engine at 2,000 r/min and have the battery charged.
- (2) If there are specific regulations for luminous intensity of headlights in the region where the vehicle is operated, make sure that the intensity conforms to the requirements of such regulations.

## BULB REPLACEMENT



54200130127

1. Disconnect the connector.
2. Remove the socket cover.

3. Unhook the spring securing the bulb, and then remove the bulb.

### Caution

**Do not touch the surface of the bulb with hands or dirty gloves as the bulb may pop after a short time. If the surface does become dirty, clean it with alcohol, and let it dry thoroughly before installing.**






HEADLIGHT AND FRONT TURN-SIGNAL LIGHT

54200240097


REMOVAL AND INSTALLATION




16M0334

<2-door models>

<4-door models>



16M0321



16M0199

00004795


Lighting switch removal steps

1. Column cover, lower
2. Column cover, upper
3. Lighting switch

Headlight removal steps

4. Front turn-signal light
5. Radiator grille  
(Refer to GROUP 51.)
6. Headlight






16M0011

**REMOVAL SERVICE POINT****◀A▶ FRONT TURN-SIGNAL LIGHT REMOVAL**


Pry a screwdriver into the direction shown to move the front turn-signal light forwards.



16M0012

**◀B▶ HEADLIGHT REMOVAL <2-door models>**

1. Pull the bumper towards you.
2. Pull the inside of headlight towards you.
3. Pull the outside of headlight towards you.
4. Remove the headlight.




A16M0201

**INSTALLATION SERVICE POINTS****▶A◀ HEADLIGHT INSTALLATION**

Tighten the mounting bolts and nuts in A, B, C, D order.

NOTE

The bolt marked by "B" applies to 4-door models only.





16M0155

**INSPECTION****HEADLIGHT RELAY CHECK**


54200820093

Battery voltage	Terminal No.			
	1	3	4	5
Supplied	⊕	⊖	○	○
Not supplied	○	○		



04Z0001

00004796



## LIGHTING SWITCH, DIMMER/PASSING SWITCH AND TURN-SIGNAL LIGHT SWITCH CHECK

54200800059

	Switch position	Connector A-terminal No.					Connector B-terminal No.					
		1	2	3	4	6	3	5	6	7	8	9
LIGHTING SWITCH	OFF											
	First position								○	—	○	
	Second position	○							○	—	○	
DIMMER/PASSING SWITCH	HI			○	○							
	LOW				○	○						
	PASSING	○	○		○	○						
									○	○		
TURN-SIGNAL LIGHT SWITCH	RH										○	○
	OFF											
	LH								○	—	○	

### NOTE

- \*1 indicates continuity when the dimmer switch is at the low beam position.
- \*2 indicates continuity when the dimmer switch is at the high beam position.

### HAZARD WARNING LIGHT SWITCH CONTINUITY CHECK

54200670094

Refer to P.54-47.

# FOG LIGHT

54200010186

## GENERAL INFORMATION

### OPERATION

- If the fog light switch is set at the "ON" position when the lighting switch is at the "second position" and the dimmer switch is at the "low beam" position, current flows through the headlight relay, dedicated fuse, fog light relay, fog light switch, diode, dimmer switch and ground, causing the fog light relay contacts to close.
- Once the fog light relay contacts have closed, current flows through the dedicated fuse, fog light relay (contacts), fog light and ground, causing the fog lights to go on.


## SERVICE SPECIFICATIONS

54200030144

Items		Standard value
Fog light aiming	Vertical direction	100 mm (4 in.) below horizontal (H)
	Horizontal direction	Parallel to direction of vehicle travel

## SPECIAL TOOL

54200060273

Tool	Tool number and name	Suppression	Application
	MB990784 Ornament remover	General service tool	Fog light switch removal

## TROUBLESHOOTING

54200070245

### TROUBLESHOOTING HINTS

Fog lights do not come on.

- Check the dedicated fuse No. 5 or No. 9.
- Check the fog light relay. (Refer to P.54-38.)
- Check the fog light switch. (Refer to P.54-38.)
- Check the dimmer switch. (Refer to P.54-34.)


## ON-VEHICLE SERVICE

54200110077


### FOG LIGHT AIMING

1. Check for badly rusted or loose fog light.
2. These conditions must be corrected before a satisfactory adjustment can be made.
3. Place vehicle on a level floor.
4. Bounce front suspension through three oscillations by applying body weight to hood or bumper.
5. Check the tire inflation pressure. Adjust as necessary.
6. Rock the vehicle sideways to allow vehicle to assume its normal position.
7. If fuel tank is not full, place a weight in trunk of vehicle to simulate weight of a full tank [3 kg (6.5 lbs.) per gallon].
8. There should be no other load in the vehicle other than driver or substituted weight of approximately 70 kg (150 lbs.) placed in driver's position.
9. Thoroughly clean fog light lenses.


10. Remove the fog light bezel.



11. Measure the center of the fog lights as shown in the illustration.



12. Set the distance between the screen and the center of the fog lights as shown in the illustration.



13. Check if the beam shining onto the screen is at the standard value.


**Standard value:**

**Vertical direction**

100 mm (4 in.) below horizontal (H)

**Horizontal direction**

Parallel to direction of vehicle travel



**NOTE**



The horizontal direction is non-adjustable. If the deviation of the light beam axis exceeds the standard value, check for improper/defective mounting location.

**Caution**


When making the aiming adjustment, be sure to block the beam of those lights which are not being adjusted.

**BULB REPLACEMENT**

1. Remove the fog light bezel.
2. Remove the fog light unit fixing screw, and pull the light unit to remove it.



3. Remove the cap.




4. Unhook the spring securing the bulb and then remove the bulb.

**Caution**


**Do not touch the surface of the bulb with hands or dirty gloves. If the surface does become dirty, clean it with alcohol, and let it dry thoroughly before installing.**

# FOG LIGHT

## REMOVAL AND INSTALLATION




1. Fog light switch



00004797

### Fog light removal steps


2. Front bumper  
(Refer to GROUP 51.)
3. Fog light bezel
4. Fog light assembly



## INSPECTION

### FOG LIGHT SWITCH CONTINUITY CHECK

Switch position	Terminal No.					
	1	2	3	4	5	6
OFF	○ — (ILL) — ○					
ON	○ — (ILL) — ○		○ — ○		○ — ○	



## FOG LIGHT RELAY CONTINUITY CHECK

54200750064

Battery voltage	Terminal No.			
	1	3	4	5
Power is not supplied	○	○		
Power is supplied	⊕	⊖	○	○

## REAR COMBINATION LIGHT

54200010193

## GENERAL INFORMATION

## OPERATION

## Tail light

- When the lighting switch is set to the "first position" or "second position" position, electricity flows via dedicated fuse No. 7 to each light, and each light illuminates.

## Back-up light

- When, with the ignition switch at the "ON" position, the shift lever (or the selector lever) is moved to the "R" position, the back-up light switch (M/T) is switched ON (or the park/neutral position switch (A/T) is switched to the "R" position), and the back-up light illuminates.

## Stop light

- Battery voltage is always applied to the stop light switch through dedicated fuse No. 11.

- When the brake pedal is pressed, the stop light switch will be turned "ON" to turn on the stop lights.




## Lighting monitor buzzer

- When, with the tail light illuminated (lighting switch-first position), the ignition switch is turned off and the driver's door is opened (door switch is switched ON), the ECU detective circuit will function.
- With the detective circuit activated, buzzer output makes the buzzer sound continuously to remind that the tail light is illuminated.
- The key reminder buzzer has a function priority to the lighting monitor buzzer. With the key inserted in the key cylinder, buzzer sounds intermittently.



## SPECIAL TOOLS

54200060280

Tool	Tool number and name	Supersession	Application
 B991502	MB991502 Scan tool (MUT-II)	MB991496-OD	ETACS-ECU input signal checking
 B991325	ROM pack		ETACS-ECU input signal checking
 B991529	MB991529 Diagnostic trouble code check harness	Tool not necessary if scan tool <MUT-II> is available	ETACS-ECU input signal checking (When using a voltmeter)

## TROUBLESHOOTING

54300720716

## INSPECTION CHART FOR TROUBLE SYMPTOMS

Trouble symptom	Inspection procedure No.	Reference page	
Communication with scan tool is not possible. <Vehicles with ETACS-ECU>	Communication with all systems is not possible.	1	54-40
	Communication with one-shot pulse input signal only is not possible.	2	54-40
While the tail lights or headlight are illuminated, driver's side door is opened but the light reminder warning buzzer does not sound. (With the ignition key inserted in the key cylinder, the ignition key reminder warning buzzer sounds.)	3	54-41	

## INSPECTION PROCEDURE FOR TROUBLE SYMPTOMS


## INSPECTION PROCEDURE 1

Communication with scan tool is not possible. (Communication with all systems is not possible.)	Probable cause
The cause is probably a defect in the power supply system (including ground) for the diagnostic line.	<ul style="list-style-type: none"> <li>● Malfunction of connector</li> <li>● Malfunction harness wire</li> </ul>

Refer to GROUP 13A -  
Troubleshooting.


## INSPECTION PROCEDURE 2

<b>Communication with scan tool is not possible. (Communication with one-shot pulse input signal only is not possible.)</b>	<b>Probable cause</b>
The cause is probably a defective one-shot pulse input signal circuit system of the diagnostic line.	<ul style="list-style-type: none"> <li>● Malfunction of connector</li> <li>● Malfunction of harness wire</li> <li>● Malfunction of ECU</li> </ul>



## INSPECTION PROCEDURE 3

<b>While the tail lights or headlight are illuminated, driver's side door is opened but the light reminder warning buzzer does not sound. (With the ignition key inserted in the key cylinder, the ignition key reminder warning buzzer sounds.)</b>	<b>Probable cause</b>
The cause is probably a defective lighting switch input circuit system or a defective ECU. While the ignition key reminder warning buzzer sounds, the taillight or headlight are turned ON but the light reminder warning buzzer does not sound.	<ul style="list-style-type: none"> <li>● Malfunction of connector</li> <li>● Malfunction of harness wire</li> <li>● Malfunction of ECU</li> </ul>



## TROUBLESHOOTING HINTS

54200070252

## Tail light

All lights do not illuminate.

(1) The headlights also do not illuminate.

- Check fusible link No. 4.

(2) The headlights illuminate.

- Check dedicated fuse No. 7.

## Back-up light

Even if the shift lever (or the selector lever) is moved to "R" position, the back-up light will not come on.

- Check the back-up light switch <M/T>

- Check the park/neutral position switch <A/T> (Refer to GROUP 23A - On-vehicle Service)
- Check the back-up light bulb.

## Stop light


1. The stop lights do not come on.

- Check the stop light switch (Refer to GROUP 35A - On-vehicle Service).
- Check the dedicated fuse No. 11.


2. Some stop lights do not come on.

- Check the ground circuit.

# REAR COMBINATION LIGHT REMOVAL AND INSTALLATION



1. Column switch <Lighting switch and turn-signal light switch>  
(Refer to P.54-32.)



## Rear combination light removal steps

2. Rear end trim  
(Refer to GROUP 52A)
3. Rear combination light

## INSPECTION

### LIGHTING SWITCH AND TURN-SIGNAL LIGHT SWITCH CONTINUITY CHECK

Refer to P.54-34

# HIGH MOUNTED STOP LIGHT


## TROUBLESHOOTING

Refer to Rear Combination Light - Troubleshooting Hints.

# HIGH MOUNTED STOP LIGHT

## REMOVAL AND INSTALLATION

<On rear shelf>




1EM0343

### Removal steps for light on rear shelf

1. Socket assembly
2. Bulb
3. High mounted stop light

<On rear spoiler>



18M0128

00004800

### Removal steps for light on rear spoiler

4. Rear spoiler
5. Center stay
6. LED panel

# INTERIOR LIGHT

54200010209

## GENERAL INFORMATION

### OPERATION

#### Luggage compartment light

- Battery voltage is always applied (via fusible link No. 2 and dedicated fuse No. 2) to the luggage compartment light.
- When the trunk lid is opened, the trunk lid latch switch is switched "ON" and the luggage compartment light illuminates.

#### Dome light

- The dome light is always illuminated when the dome light switch is at the "ON" position.
- The dome light illuminates when any door is opened while the dome light switch is at the "DOOR" position.
- The dome light does not illuminate when the dome light switch is switched OFF regardless of door positions.

## TROUBLESHOOTING

54200070276

### TROUBLESHOOTING HINTS

#### Luggage compartment light

Luggage compartment light does not come on.

- Check the bulb.
- Check the trunk lid latch switch.  
(Refer to GROUP 42 - Trunk Lid.)

#### Dome light

The dome light does not illuminate.

1. The clock also stopped.
  - Check dedicated fuse No. 2.
2. The dome light does not illuminate when with the dome light switch at the "DOOR" position, any door is opened.
  - Check the bulb.
  - Check the dome light switch.


3. The dome light does not illuminate when with the dome light switch at the "DOOR" position, a certain door or doors is/are opened.
  - Check the door switch [the door switch(es) for the door(s) that does not activate the dome light when opened].

# INTERIOR LIGHT

## REMOVAL AND INSTALLATION

<Vehicles with map light>

<Vehicles with sunroof>



A16M0335

### Dome light removal steps

1. Dome light lens
2. Dome light bulb
3. Reading light bulb
4. Dome light and sunroof switch body <Vehicles with sunroof>
5. Dome light switch body <Vehicles without sunroof>
6. Dome light and reading light switch <Vehicles with sunroof>
7. Dome light bracket <Vehicles with sunroof>

### Luggage compartment light removal steps

8. Luggage compartment light assembly
9. Luggage compartment light bulb


### Map light removal steps

10. Map light lens
11. Map light bulb
12. Map light body
13. Map light switch
14. Map light bracket

## RHEOSTAT

5420060297


## SPECIAL TOOL

Tool	Tool number and name	Supersession	Use
	MB990784 Ornament remover	General service tool	Removal of switch garnish

## RHEOSTAT

54200600130


## REMOVAL AND INSTALLATION



## Removal steps

1. Switch garnish
2. Knob
3. Ring nut

4. Plate
5. Rheostat



## INSPECTION

54200610195

1. Connect the battery and the test bulb (40W) as shown in the illustration.
2. Operate the rheostat, and if the brightness changes smoothly without switching off, then the rheostat function is normal.





# HORN

54300010257

## GENERAL INFORMATION

### OPERATION

- Battery voltage is always applied to the horn relay through dedicated fuse No. 4.
- When the horn switch is turned "ON", the contact point of horn relay will be closed to turn

"ON" the horn relay. While the horn switch is "ON", the horn sounds.

## TROUBLESHOOTING

54300070279


### TROUBLESHOOTING HINTS

- Horn does not sound.
  - Check the dedicated fuse No. 4.
  - Check the horn relay.
  - Check the horn switch.
  - Check the horn.
- Only one horn sounds.
  - Check the horn.
  - Check connectors and wiring harness.

## HORN

54300790021

## REMOVAL AND INSTALLATION



A16M0348

### Removal steps

- Front bumper (Refer to GROUP 51.)
- 1. Horn


NOTE  
The horn marked by \* applies to 4-door models and 2-door 1.8L models.

## INSPECTION

54300650039

### HORN RELAY CONTINUITY CHECK

Battery voltage	Terminal No.			
	1	3	4	5
Power is not supplied				
Power is supplied				



# CIGARETTE LIGHTER

54300010202

## GENERAL INFORMATION

### OPERATION

- If the plug is pressed into the socket, the plug will remain in, and the cigarette lighter will be turned "ON".
- The element area of the plug is heated. The plug will automatically return to turn "OFF" the cigarette lighter.

## TROUBLESHOOTING

54300070613


### TROUBLESHOOTING HINTS

1. Cigarette lighter does not operate.
  - Check the cigarette lighter. (Refer to P.54-50.)
2. Cigarette lighter illumination light does not come on or is dim.
  - Check the rheostat. (Refer to P.54-46.)

## CIGARETTE LIGHTER

54300560080


### REMOVAL AND INSTALLATION



A16M0354

#### Removal steps

1. Audio panel
2. Plug
3. Fixing ring
4. Socket case
5. Socket washer
6. Socket
7. Protector

**INSPECTION**


54300570083

- Take out the plug, and check for a worn edge on the element spot connection, and for shreds of tobacco or other material on the element.
- Using an ohmmeter, check the continuity of the element.

**CLOCK**


54200060310

**SPECIAL TOOL**

Tool	Tool number and name	Supersession	Use
	MB990784 Ornament remover	General service tool	Heater control panel removal

**CLOCK**

54300590041

**REMOVAL AND INSTALLATION**

A16M0285


**Removal steps**

1. Heater control panel
2. Clock

# RADIO AND TAPE PLAYER

5440060040

## SPECIAL TOOL

Tool	Tool number and name	Supersession	Use
	MB990784 Ornament remover	General service tool	Audio panel removal

## TROUBLESHOOTING

54400070135


### QUICK-REFERENCE TROUBLESHOOTING CHART

Items	Problem symptom	Relevant chart
Noise	Noise appears at certain places when travelling (AM).	A-1
	Noise appears at certain places when travelling (FM).	A-2
	Mixed with noise, only at night (AM).	A-3
	Broadcasts can be heard but both AM and FM have a lot of noise.	A-4
	There is more noise either on AM or on FM.	A-5
	There is noise when starting the engine.	A-6
	Some noise appears when there is vibration or shocks during travelling.	A-7
	Noise sometimes appears on FM during travelling.	A-8
	Ever-present noise.	A-9
Radio	When switch is set to ON, no power is available.	B-1
	No sound from one speaker.	B-2
	There is noise but no reception for both AM and FM or no sound from AM, or no sound from FM.	B-3
	Insufficient sensitivity.	B-4
	Distortion on AM or on both AM and FM.	B-5
	Distortion on FM only.	B-6
	Too few automatic select stations.	B-7
	Insufficient memory (preset stations are erased).	B-8
Tape player	Cassette tape is not accepted.	C-1
	No sound.	C-2
	No sound from one speaker.	C-3
	Sound quality is poor, or sound is weak.	C-4
	Cassette tape will not be ejected.	C-5
	Uneven revolution. Tape speed is fast or slow.	C-6
	Faulty auto reverse.	C-7
Tape gets caught in mechanism.	C-8	

## CHART

## A. NOISE

**A-1 Noise appears at certain places when travelling (AM).**



### A-2 Noise appears at certain places when traveling (FM).

Do the following measures eliminate the noise?

- Change to a different station with a strong signal to boost resistance to interference.
- Suppress high tones to reduce noise.
- Extend antenna completely.

Yes

OK

No

If there is more noise than other radios, find out the noise conditions and the name and frequency of the radio stations from the user, and consult with the service center.

#### NOTE

About FM waves:


FM waves have the same properties as light, and can be deflected and blocked. Wave reception is not possible in the shadow of obstructions such as buildings or mountains.

1. The signal becomes weak as the distance from the station's transmission antenna increases. Although this may vary according to the signal strength of the transmitting station and intervening geographical formation or buildings, the area of good reception is approx. 20-25 km (12-16 miles) for stereo reception, and 30-40 km (19-25 miles) for monaural reception.
2. The signal becomes weak when an area of shadow from the transmitting antenna (places

where there are obstructions such as mountains or buildings between the antenna and the car), and noise will appear. <This is called first fading, and gives a steady buzzing noise.>


3. If a direct signal hits the antenna at the same time as a signal reflected by obstructions such as mountains or buildings, interference of the two signals will generate noise. During travelling, noise will appear each time the vehicle's antenna passes through this kind of obstructed area. The strength and interval of the noise varies according to the signal strength and the conditions of deflection. <This is called multipath noise, and is a repetitious buzzing.>
4. Since FM stereo transmission and reception has a weaker field than monaural, it is often accompanied by a hissing noise.

#### FM Broadcast Good Reception Areas



16A0663

#### FM Signal Characteristics and Signal Interference



16A0664

00000295

### A-3 Mixed with noise, only at night (AM).


The following factors can be considered as possible causes of noise appearing at night.

1. Factors due to signal conditions: Due to the fact that long-distance signals are more easily received at night, even stations that are received without problem during the day may experience interference in a general worsening of reception conditions. The weaker a station is the more susceptible it is to interference,

and a change to a different station or the appearance of a beating sound\* may occur.

Beat sound\*: Two signals close in frequency interfere with each other, creating a repetitious high-pitched sound. This sound is generated not only by sound signals but by electrical waves as well.

2. Factors due to vehicle noise: Generator noise may be a cause.



**A-4 Broadcasts can be heard but both AM and FM have a lot of noise.**

(1)

Noise occurs when the engine is stopped.

Yes

Do the following measures eliminate the noise?

- Tune to a station with a strong signal.
- Extend the antenna completely.
- Adjust the sound quality to suppress high tones.

Yes

OK

No

Is the radio body ground mounted securely?

No

Securely tighten the nuts for the body ground.

Yes

Is the antenna plug properly connected to the radio?

No

Correctly attach the antenna plug.

Yes

Is the antenna itself in good condition or is it properly mounted?

No

Clean the antenna plug and ground wire mounting area. Mount the antenna securely.

Yes

Is the noise eliminated?

Yes

OK

No

If there is more noise than other radios, consult a service center.

(2)

Noise occurs when the engine is running.

Inspect the vehicle's noise suppressor. (refer to A-6.)

**NOTE**

About noise encountered during FM reception only. Due to differences in FM and AM systems, FM is not as susceptible as AM to interference from engines, power lines, lightning, etc. On the other hand, there are cases due to the characteristics

of FM waves of noise or distortion generated by typical noise interference (first fading and multipath). (Refer to A-2.)

<Noise (hissing) occurs in weak signal areas such as mountainous regions, but this is not due to a problem with the radio.>



**A-5 There is more noise either on AM or on FM.**

- There is much noise only on AM  
Due to differences in AM and FM systems, AM is more susceptible to noise interference.

Were conditions such as the following present when noise was received?

- Lightning was flashing. A motorcycle was passing.
- A vehicle passed close by, but it appeared to be a vehicle generating a particularly large amount of noise radiation.
- Passed beneath a power line. Passed under a bridge
- Passed beneath a telephone line.
- Passed close by a signal generator.
- Passed close by some other source of electrical noise.

No  
Continue to check for static; when static is detected, check for the conditions listed above.

No  
If the problem is particularly worse than other radios, consult a service center.

Yes

Yes

Noise prevention on the radio side is difficult. If the problem is particularly worse than other radios, consult a service center.

- There is much noise only on FM  
Due to differences in FM and AM systems, FM is not as susceptible as AM to interference from engines, power lines, lightning, etc. On the other hand, there are cases due to the characteristics of FM waves of noise or distur-

tion generated by typical noise interference (first fading and multipath). (Refer to A-2) <Noise (hissing) occurs in weak signal areas such as mountainous regions, but this is not due to a problem with the radio.>

## A-6 There is noise when starting the engine.

Noise type Sounds are in parentheses ( ).	Conditions	Cause	Remedy
AM, FM: Ignition noise (Popping, snapping, cracking, buzzing)	<ul style="list-style-type: none"> <li>Increasing the engine speed causing the popping sound to speed up, and volume decreases.</li> <li>Disappears when the ignition switch is turned to ACC.</li> </ul>	<ul style="list-style-type: none"> <li>Mainly due to the spark plug circuit.</li> <li>Due to engine noise.</li> </ul>	<ul style="list-style-type: none"> <li>Use engine analyzer to diagnose ignition system.</li> <li>Check or replace the ground cable. (Refer to Fig. 1.)</li> <li>Check or replace the noise capacitor.</li> </ul>
Other electrical components	-	Noise may appear as electrical components become older.	Repair or replace electrical components.
Static electricity (Cracking, crinkling)	<ul style="list-style-type: none"> <li>Disappears when the vehicle is completely stopped.</li> <li>Severe when transmission is engaged and vehicle is moving.</li> </ul>	Occurs when parts or wiring move for some reason and contact metal parts of the body.	Return parts or wiring to their proper position.
	<ul style="list-style-type: none"> <li>Various noises are produced depending on the body part of the vehicle.</li> </ul>	Due to detachment from the body of the front hood, bumpers, exhaust pipe and muffler, suspension, etc.	Tighten the mounting bolts securely. Cases where the problem is not eliminated by a single response to one area are common, due to several body parts being imperfectly grounded.

**Caution**

- Connecting a high tension cable to the noise filter may destroy the noise filter and should never be done.
- Check that there is no external noise. Since failure caused by this may result in misdiagnosis due to inability to identify the noise source, this operation must be performed.
- Noise prevention should be performed by suppressing strong sources of noise step by step.

**NOTE**


- Capacitor  
The capacitor does not pass D.C. current, but as the number of waves increases when it

passes A.C. current, impedance (resistance against A.C.) decreases, and current flow is facilitated. A noise suppressing condenser which takes advantage of this property is inserted between the power line for the noise source and the ground. This suppresses noise by grounding the noise component (A.C. or pulse signal) to the body of the vehicle.


## 2. Coil

The coil passes D.C. current, but impedance rises as the number of waves increases relative to the A.C. current. A noise suppressing coil which takes advantage of this property is inserted into the power line for the noise source, and works by preventing the noise component from flowing or radiating out of the line.


(Fig. 1)



**A-7 Some noise appears when there is vibration or shocks during travelling.**



**A-8 Noise sometimes appears on FM during travelling.**



\* About multipath noise and fading noise  
 Because the frequency of FM waves is extremely high, it is highly susceptible to effects from geological formations and buildings. These effects disrupt the broadcast signal and obstruct reception in several ways.

- Multipath noise  
 This describes the echo that occurs when the broadcast signal is reflected by a large



- Fading noise  
 This is a buzzing noise that occurs when the broadcast beam is disrupted by obstructing objects and the signal strength fluctuates closely within a narrow range.

**A-9 Ever-present noise.**


Noise is often created by the following factors, and often the radio is OK when it is checked individually.

- Traveling conditions of the vehicle
- Terrain of area traveled through
- Surrounding buildings
- Signal conditions
- Time period


For this reason, if there are still problems with noise even after the measures described in steps A-1 to A-8 have been taken, get information on the factors listed above as well as determining whether the problem occurs with AM or FM, the station names, frequencies, etc., and contact a service center.

**B. RADIO****B-1 No power is supplied when the switch is set to ON.****B-2 No sound from one speaker.**




**B-3 There is noise but no reception for both AM and FM or no sound from AM, or no sound from FM.**




**B-4 Insufficient sensitivity.**



\* For multipath noise and fading noise problems, refer to P.54-53.


**B-5 Distortion on AM or on both AM and FM.****B-6 Distortion on FM only****B-7 Too few automatic select stations.**

**B-8 Insufficient memory (preset stations are erased).**




**C. TAPE PLAYER**


**C-1 Cassette tape is not accepted.**




**C-2 No sound (even after a tape has been inserted).**





**C-3 No sound from one speaker.**



**C-4 Sound quality is poor, or sound is weak.****C-5 Cassette tape will not be ejected.**


The problems covered here are all the result of the use of a bad tape (deformed or not properly tightened) or of a malfunction of the tape player itself. Malfunctions involving the tape becoming caught in the mechanism and ruining the case are

also possible, and attempting to force the tape out of the player can cause damage to the mechanism. The player should be taken to a service dealer for repair.

**C-6 Uneven revolution. Tape speed is fast or slow.**




**C-7 Faulty auto reverse.**




**C-8 Tape gets caught in mechanism\*1.**

\*1  
When the tape is caught in the mechanism, the case may not eject. When this occurs, do not try to force the tape out as this may damage the tape player mechanism. Take the cassette to a service dealer for repair.



**RADIO AND TAPE PLAYER  
REMOVAL AND INSTALLATION**

54400140065



A16M0350


**Removal steps**

1. Audio panel
2. Radio bracket
3. Radio and tape player

# SPEAKER

## REMOVAL AND INSTALLATION

### <FRONT SPEAKER>




A16M0309

#### Removal steps

- Front door trim (Refer to GROUP 42.)
- 1. Front speaker
- 2. Speaker cover


### <REAR SPEAKER>



A16M0310

#### Removal steps

1. Rear speaker garnish
2. Rear speaker

**ANTENNA****REMOVAL AND INSTALLATION**


A16M0351


**Removal steps**

1. Antenna rod
2. Audio panel
3. Radio and tape player assembly
4. Hood lock release handle
5. Driver side lower cover
6. Clip
7. Cowl side trim
8. Antenna assembly
9. Antenna base gasket

**REMOVAL SERVICE POINT****◀▶ ANTENNA ASSEMBLY REMOVAL**

1. Tie a cord to the end of the feeder cable.





2. Pull out the antenna base until the end of the drain pipe can be seen.
3. Pass the cord through the hole in the end of the drain pipe and wrap it with vinyl tape.

**Caution**

**Wrap it securely so that the cord will not come off.**

4. Slowly pull out the antenna base little by little to remove it.



## REAR WINDOW DEFOGGER

54300180033

### ON-VEHICLE SERVICE

#### PRINTED-HEATER LINE CHECK


1. Run engine at 2,000 r/min. Check heater element with battery fully charged.
2. Turn ON rear window defogger switch. Measure heater element voltage with circuit tester at rear window glass center A.  
Condition is good if it indicates about 6 V.
3. If 12 V is indicated at A, there is a break to the negative terminal side.  
Move test bar slowly to negative terminal to detect where voltage suddenly changes to 0 V.
4. If 0 V is indicated at A, there is a break in the positive terminal side. Detect where the voltage changes suddenly (12 V) in the same method described above.



## REAR WINDOW DEFOGGER SWITCH


54300620153

## REMOVAL AND INSTALLATION



## Removal steps

1. Heater control assembly  
(Refer to GROUP 55.)
2. Rear window defogger switch



## INSPECTION

54300670066

## DEFOGGER SWITCH CONTINUITY CHECK

Switch position	Terminal No.							
	1	3	4	5	2	6		
OFF	○	ILL ⏚	○			○	IND ⏚	○
ON	○	ILL ⏚	○			○	IND ⏚	○



## NOTE

\*: The switch will turn off in 13 - 17 minutes after it turns on.

## REAR WINDOW DEFOGGER RELAY CONTINUITY CHECK

54300680076

Battery voltage	Terminal No.			
	1	2	3	5
Power is not supplied	○	—	○	
Power is supplied	⊕	○	⊖	○



20Z0002

00004586