

GALANT

WORKSHOP MANUAL

FOREWORD

This Workshop manual contains procedures for service mechanics, including removal, disassembly, inspection, adjustment, reassembly and installation. Use the following manuals in combination with this manual as required.

TECHNICAL INFORMATION MANUAL

BODY REPAIR MANUAL

PARTS CATALOGUE

All information, illustrations and product descriptions contained in this manual are current as at the time of publication. We, however, reserve the right to make changes at any time without prior notice or obligation.

GROUP INDEX

General	00
Engine	11
Fuel	13
Engine and Emission Control	17
Automatic Transaxle (Transmission)	23
Front Suspension	33
Rear Suspension	34
Steering	37
Body	42
Exterior	51
Interior and Supplemental Restraint System (SRS)	52
Chassis Electrical	54
Heater, Air Conditioner and Ventilation	55
Component Locations	70
Configuration Diagrams	80
Circuit Diagrams	90

