

EXTERIOR

CONTENTS

E51AA--

SPECIFICATIONS	2	AERO PARTS	11-1
General Specifications	2	WINDSHIELD WIPER AND WASHER *	13
Service Specifications	3	REAR WIPER AND WASHER	16
SPECIAL TOOLS	3	HEADLAMP WASHER	19
FRONT BUMPER	4	DECAL	21
REAR BUMPER	5	DOOR MIRROR	22
RADIATOR GRILLE	6		
ROOF RAIL	6		
GARNISHES AND MOULDINGS			
<SPACE RUNNER>	7		
GARNISHES AND MOULDINGS			
<SPACE WAGON>	10		

WARNING REGARDING SERVICING OF SUPPLEMENTAL RESTRAINT SYSTEM (SRS) EQUIPPED VEHICLES

WARNING!

- (1) Improper service or maintenance of any component of the SRS, or any SRS-related component, can lead to personal injury or death to service personnel (from inadvertent firing of the air bag) or to the driver (from rendering the SRS inoperative).
- (2) Service or maintenance of any SRS component or SRS-related component must be performed only at an authorized MITSUBISHI dealer.
- (3) MITSUBISHI dealer personnel must thoroughly review this manual, and especially its GROUP 52B—Supplemental Restraint System (SRS), before beginning any service or maintenance of any component of the SRS or any SRS-related component.

NOTE

The SRS includes the following components: SRS diagnosis unit, SRS warning lamp, air bag module, clock spring and interconnecting wiring. Other SRS-related components (that may have to be removed/installed in connection with SRS service or maintenance) are indicated in the table of contents by and asterisk (*).

Items	Specifications
Headlamp washer motor and pump	
Motor type	Direct current ferrite magnet type
Pump type	Centrifugal type
Rated current	A 21 or less
Tank capacity	dm ³ (U.S. qts., Imp. qts.) 3.5 (3.7, 3.1) or more
Headlamp washer realy	
Timer operation time	sec. 0.52


SERVICE SPECIFICATIONS

E51CB--

Items	Specifications
Standard value	
Front wiper blade installation position	mm (in.)
<Position A>	30 ± 5 (1.18 ± 0.20)
<Position B>	40 ± 5 (1.57 ± 0.20)
Rear wiper blade installation position	25 ± 5 (0.98 ± 0.20)

SPECIAL TOOLS


E51DA--

Tool	Number	Name	Use
	MB990784	Ornament remover	Removal of decal

FRONT BUMPER

REMOVAL AND INSTALLATION

E51GABM



18C0306


Removal steps

1. Harness connector
2. Front turn signal lamp
3. Front bumper assembly
4. Slide guide bracket*

NOTE

* indicates vehicles built up to February 1992.

DISASSEMBLY AND REASSEMBLY



18C0305

Disassembly steps

1. License plate bracket
2. Slide bracket*
3. Side support bracket
4. Front bumper upper bracket
5. Front bumper face
6. Front bumper reinforcement assembly

NOTE



* indicates vehicles built up to February 1992.

REAR BUMPER

REMOVAL AND INSTALLATION

E51GABN

Pre-removal and Post-installation Operation
 ● Removal and Installation of Rear End Trim (Refer to GROUP 52A – Trims.)




Sealant:
 3M ATD Part No. 8625 or equivalent

Removal steps

1. Rear mud guard
2. Rear splash shield
3. Harness connector
4. Back up lamp
5. Rear fog lamp
6. Rear bumper assembly

NOTE
 * indicates vehicles built up to February 1992.

DISASSEMBLY AND REASSEMBLY



Disassembly steps


1. Wiring harness
2. Rear bumper reinforcement assembly
3. Rear bumper filler
4. Rear bumper upper plate
5. Slide bracket*
6. Side support bracket assembly
7. Rear bumper face

NOTE
 * indicates vehicles built up to February 1992.

RADIATOR GRILLE

REMOVAL AND INSTALLATION

E511BAH




Removal steps



1. Radiator grille
2. 4×4 mark <4WD>
3. Bracket
4. Clip

18C0495



SERVICE POINTS OF REMOVAL

1. REMOVAL OF RADIATOR GRILLE

Remove the radiator grille by pushing the tab of the radiator grille clips in the direction of the arrows with a flat-tipped screwdriver, while lightly pulling the radiator grille towards you.

ROOF RAIL


REMOVAL AND INSTALLATION

E51TAAC


Pre-removal and Post-installation Operation

- Removal and Installation of Headlining (Refer to GROUP 52A – Headlining.)

<SPACE RUNNER>



<SPACE WAGON>



GARNISHES AND MOULDINGS <SPACE RUNNER>

REMOVAL AND INSTALLATION



Pre-removal and Post-Installation Operation

- Removal and Installation of Tailgate Lower Garnish and Waterproof Film (Refer to GROUP 42 – Tailgate Trim and Waterproof Film.)

- 1. Front deck garnish
- 2. Corner garnish
- 3. Center pillar garnish
- ◆◆ 4. Drip moulding
- 5. Quarter belt line moulding
- 6. Rear door belt line moulding
- ◆◆ 7. Side protector moulding
- 8. Fender protector moulding
- 9. Front door protector moulding
- 10. Rear door protector moulding
- 11. Quarter protector moulding

Tailgate garnish removal steps

- ◆◆ 12. Rear wiper arm assembly
- ◆◆ 13. Harness connector
- ◆◆◆◆ 14. Tailgate garnish
- ◆◆◆◆ 15. Tailgate lower garnish




NOTE


- 1. ➡ : Indicates the clip positions.
- 2. Parts 3, 5, 6 and 7 are symmetrical in R.H. drive vehicles.
- 3. ➡ : indicates the stud positions.

Side protector moulding


<Vehicles built up to February 1992>








<Vehicles built from March 1992>



Tailgate lower garnish



Adhesive tape: Both-side tape 7 mm (0.28 in.) wide and 1.2 mm (0.05 in.) thick

**SERVICE POINTS OF REMOVAL****14. REMOVAL OF TAILGATE GARNISH**

(1) Apply protective tape to the moulding at the bottom of the tailgate glass to prevent it from being damaged.

(2) When using the special tool; ornament remover (MB990784) when working, be careful of the following points.

- Clamp the clip from behind to prevent it from breaking and remove the catch.

- If a stud bolt is caught in the panel, use the handle of a hammer or similar tool to push the stud bolt from behind.





(3) Use the special tool to remove the lower attachment.

(4) Remove both the left and right end attachments. Then, remove the tailgate garnish by pulling the top section out from the moulding little by little using the special tool.

NOTE

At this time, some parts of the tailgate glass may be stiff depending on the position, but keep removing the garnish carefully without damaging the moulding.

NOTES



SERVICE POINTS OF INSTALLATION

15. INSTALLATION OF TAILGATE LOWER GARNISH/7. SIDE PROTECTOR MouldING

- **Affixing the both-sided tape to the side protector moulding (when reusing)**

(1) Scrape off the both-sided adhesive tape with a resin spatula or gasket scraper.

(2) Wipe the body surface clean with a rag moistened with unleaded petrol.

(3) Remove a small portion of the residual adhesive.

Caution

Do not remove all of the residual adhesive.

(4) Affix the specified both-sided adhesive tape to the side protector moulding.


Adhesive tape: Both-side tape 7 mm (0.28 in.) wide and 1.2 mm (0.05 in.) thick

- **Installation of side protector moulding**

(1) Tear off the both-sided tape backing paper.

NOTE

If you attach the adhesive tape to the edge of the backing paper, it will be easy to tear off.




- (2) Install the side protector moulding so that the clip match the body holes.

NOTE

If the both-sided adhesive tape is difficult to affix during winter, etc., warm the bonding surfaces of the body and the side protector moulding before affixing the tape.

Body 40–60°C (104–140°F)
 Side protector moulding 20–30°C (68–86°F)

- (3) Firmly press in the side protector moulding.




14. INSTALLATION OF TAILGATE GARNISH


- (1) Correct the position of the studs if they were displaced during removal.
- (2) Push in the stud packing as far as the head of the stud.
- (3) Replace any clips that were damaged.
- (4) Place the tailgate garnish against the tailgate and align each of the studs and clips with the tailgate hole positions.

NOTE


At this time, the top edge may rest on the moulding.



- (5) Both edges of the tailgate garnish are sharp and can easily damage the moulding, so first use the special tool to push the tailgate garnish under the moulding.



- (6) Recheck that the positions of each stud and clip are aligned, and tap the garnish firmly with your hand towards the center from both sides.
- (7) Remove the protective tape that was attached to prevent the moulding from being damaged, and clean the moulding.



4. INSTALLATION OF DRIP MOULDING

Place the drip moulding clip in the position shown in the illustration, and install the drip moulding.

NOTES

GARNISHES AND MOULDINGS <SPACE WAGON>

REMOVAL AND INSTALLATION

E511CAQ


Pre-removal and Post-Installation Operation

● Removal and Installation of Tailgate Lower Garnish and Waterproof Film (Refer to GROUP 42 – Tailgate Trim and Waterproof Film.)


- 1. Front deck garnish
- 2. Corner garnish
- 3. Rear pillar garnish
- 4. Quarter garnish
- ◆◆ 5. Drip moulding
- ◆◆ 6. Side protector moulding
- ◆◆ 7. Fender protector moulding
- 8. Front door protector moulding
- 9. Rear door protector moulding
- 10. Quarter protector moulding

Tailgate garnish removal steps

- ◆◆ 11. Rear wiper arm assembly
- ◆◆ 12. Harness connector
- ◆◆ 13. Tailgate garnish
- ◆◆ 14. Tailgate lamp assembly
- ◆◆ 15. Tailgate lower garnish



18C0551




18C0309

NOTE



- 1. ⇨ : Indicates the clip positions.
- 2. ⇨ : Indicates the stud positions.

Side protector moulding <Vehicles built up to February 1992>








Tailgate lower garnish

Tailgate lower garnish <Vehicles built from March 1992>



Adhesive tape: Both-side tape 7 mm (0.28 in.) wide and 1.2 mm (0.05 in.) thick

**SERVICE POINTS OF REMOVAL****14. REMOVAL OF TAILGATE LAMP ASSEMBLY**

(1) Apply protective tape to the moulding at the bottom of the tailgate glass to prevent it from being damaged.

(2) When using the special tool; ornament remover (MB990784) when working, be careful of the following points.


- Clamp the clip from behind to prevent it from breaking and remove the catch.

- If a stud bolt is caught in the panel, use the handle of a hammer or similar tool to push the stud bolt from behind.

(3) Use the special tool to remove the lower attachment.
 (4) Remove both the left and right end attachments. Then, remove the tailgate lamp assembly by pulling the top section out from the moulding little by little using the special tool.

NOTE

At this time, some parts of the tailgate glass may be stiff depending on the position, but keep removing the garnish carefully without damaging the moulding.




SERVICE POINTS OF INSTALLATION

15. INSTALLATION OF TAILGATE LOWER GARNISH/6. SIDE PROTECTOR MouldING

Install by the same procedure as for the side protector moulding of SPACE RUNNER. (Refer to P.51-8.)

Adhesive tape: Both-side tape
7 mm (0.28 in.) wide and
1.2 mm (0.05 in.) thick




14. INSTALLATION OF TAILGATE LAMP ASSEMBLY


- (1) Correct the position of the studs if they were displaced during removal.
- (2) Push in the stud packing as far as the head of the stud.
- (3) Replace any clips that were damaged.
- (4) Place the tailgate lamp assembly against the tailgate and align each of the studs and clips with the tailgate hole positions.

NOTE

At this time, the top edge may rest on the moulding.



- (5) Both edges of the tailgate lamp assembly are sharp and can easily damage the moulding, so first use the special tool to push the tailgate lamp assembly under the moulding.



- (6) Recheck that the positions of each stud and clip are aligned, and tap the tailgate lamp assembly firmly with your hand towards the center from both sides.
- (7) Remove the protective tape that was attached to prevent the moulding from being damaged, and clean the moulding.

5. INSTALLATION OF DRIP MOULDING

Refer to P.51-9-1.

AERO PARTS

REMOVAL AND INSTALLATION


E51HBAP

Pre-removal and Post-Installation Operation

- Removal and Installation of Tailgate Lower Garnish (Refer to GROUP 42 – Tailgate Trim and Waterproof Film.)


Removal steps

1. Seal
2. Cap
3. Tailgate deflector



18C0127


DISASSEMBLY AND REASSEMBLY



18C0126


Disassembly steps

- 1. Deflector cover
- 2. Tailgate deflector
- 3. Clip



18C0109

Adhesive tape: Both-side tape
5 mm (0.20 in.) wide and
0.8 mm (0.03 in.) thick



18C0109

SERVICE POINTS OF REASSEMBLY

1. INSTALLATION OF DEFLECTOR COVER


Install by the same procedure as for the side protector moulding of SPACE RUNNER. (Refer to P.51-8.)

Adhesive tape: Both-side tape
5 mm (0.20 in.) wide and
1.2 mm (0.05 in.) thick

WINDSHIELD WIPER AND WASHER

REMOVAL AND INSTALLATION

E51KCAF



Motor and bracket assembly removal steps

- ◆◆ 1. Wiper arm assembly
- 2. Wiper blade
- 3. Wiper arm
- 4. Front deck garnish
- 5. Link assembly
- ◆◆ 6. Wiper motor

Washer tube assembly and nozzle assembly removal steps

- 7. Washer tube assembly
- 8. Nozzle


Windshield washer tank assembly removal steps

- 9. Battery
- 10. Harness clip
- 11. Battery tray
- 12. Harness connector
- 13. Windshield washer tank assembly

Washer motor removal steps

- Draining of washer fluid
- 12. Harness connector
- 14. Washer motor

CAUTION : SRS
 Before removal of air bag module and clock spring, refer to GROUP 52B – SRS Service Precautions and Air Bag Module and Clock Spring.



16C0526


Column switch removal steps

- Horn pad (Refer to GROUP 37A – Steering Wheel and Shaft.)
 - Air bag module (Refer to GROUP 52B – Air Bag Module and Clock Spring.) <Vehicles with SRS>
 - Steering wheel (Refer to GROUP 37A – Steering Wheel and Shaft.)
15. Hood lock release handle
 16. Instrument panel under cover
 17. Column cover lower
 18. Meter hood
 19. Column cover upper
 20. Column switch assembly (with built-in wiper and washer switch, and wiper relay)
 21. Clock spring* <Vehicles with SRS> (Refer to GROUP 52B – Air Bag Module and Clock Spring.)

NOTE

1. Parts marked * should not be removed from the column switch except when removal is absolutely necessary.
2. ← The mark indicates the metal clip positions.

NOTES




SERVICE POINTS OF REMOVAL

6. REMOVAL OF WIPER MOTER

Loosen the wiper motor assembly mounting bolts, and then remove the wiper motor assembly. Disconnect the linkage and the motor assembly, and then remove the linkage.

Caution

Because the installation angle of the crank arm and the motor has been set, do not remove them unless it is necessary to do so. If they must be removed, remove them only after marking their mounting positions.



INSPECTION

WIPER MOTOR


Check the wiper motor after disconnecting the wiring harness connector, and with the wiper motor remaining installed to the body.

Operation of Wiper Motor at LOW speed and HIGH speed

Connect a battery to the wiper motor as shown in the illustration and inspect motor operation at LOW speed and HIGH speed.

Operation of Wiper Motor at STOP Position

- (1) Run the wiper motor at LOW speed, disconnect the battery, and stop the motor.
- (2) Reconnect the battery as shown in the illustration, and confirm that after the motor starts turning at LOW speed, it stops at the automatic stop position.



WIPER AND WASHER SWITCH


<Vehicles without SRS>

Disconnect the column switch connector and check the continuity between the terminals for each switch.

Switch position		Terminal					
		3	4	7	8	13	22
Wiper switch	OFF	○	—	○			
	LO	○	—		○		
	HI		○	—	○		
Intermittent variable volume switch					○	—	○
Washer switch	ON				○	—	○

NOTE

○—○ indicates that there is continuity between the terminals.



<Vehicles with SRS>

Disconnect the column switch connector and check the continuity between the terminals for each switch.

Switch position		Terminal				
		6	7	8	9	10
Wiper switch	OFF		○	—	○	
	INT		○	—	○	
	LO			○	—	○
	HI				○	—
Washer switch	ON	○	—			○

NOTE


○—○ indicates that there is continuity between the terminals.

INTERMITTENT WIPER RELAY


Operate the wipers with the connector still attached to the column switch, and check the voltage at terminal ⑧.

When wipers are stopped: 0V

When wipers are operating: 12V

**WASHER MOTOR**

- (1) With the washer motor installed to the washer tank, fill the washer tank with water.
- (2) When the battery is connected as shown in the figure, check that the water squirts out strongly.

**SERVICE POINTS OF INSTALLATION****1. INSTALLATION OF WIPER ARM ASSEMBLY**

Install the wiper arm assembly so that the distance from the edge of the wiper blades to the front deck garnish is within the standard value when the wipers are stopped.

Standard value (A): 30 ± 5 mm (1.18 \pm 0.20 in.)
(B): 40 ± 5 mm (1.57 \pm 0.20 in.)

NOTES

REAR WIPER AND WASHER


REMOVAL AND INSTALLATION

E51LAAM




Pre-removal and Post-installation Operation

Removal and Installation

- Front seat <R.H.> (Refer to GROUP 52A – Front Seat.)
- Rear seat <SPACE RUNNER> (Refer to GROUP 52A – Rear Seat.)
- Second seat <SPACE WAGON> (Refer to GROUP 52A – Second Seat.)
- Third seat <SPACE WAGON> (Refer to GROUP 52A – Third Seat.)
- Scuff plate (Refer to GROUP 52A – Trims.)
- Quarter lower trim <SPACE RUNNER – R.H. drive vehicles, SPACE WAGON> (Refer to GROUP 52A – Trims.)
- Cargo side lower trim <SPACE RUNNER> (Refer to GROUP 52A – Trims.)
- Tailgate upper trim (Refer to GROUP 42 – Tailgate Trim and Waterproof Film.)
- Headlining (Refer to GROUP 52A – Headlining.)



16C0274



18C0193


1. Cluster switch assembly (Refer to GROUP 54 – Meters and Gauges.)

Rear wiper washer removal steps

2. Joint assembly
3. Plug
4. Rear washer nozzle assembly
5. Rear washer tube assembly
6. Joint

Rear wiper removal steps


7. Wiper arm assembly
8. Wiper blade
9. Wiper arm
10. Wiper motor assembly
11. Grommet



SERVICE POINTS OF REMOVAL

10. REMOVAL OF WIPER MOTOR ASSEMBLY

- (1) Remove the clips in the locations shown in the illustration, and then remove the tailgate trim.
- (2) Peel off the waterproof film and remove the wiper motor assembly.



INSPECTION

WIPER MOTOR


Check the wiper motor after disconnecting the wiring harness connector, and with the wiper motor remaining installed to the body.

Operation of Wiper Motor

Connect a battery to the wiper motor as shown in the illustration and inspect motor operation.

Operation of Wiper Motor at STOP Position

- (1) Run the wiper motor, disconnect the battery, and stop the motor.
- (2) Reconnect the battery as shown in the illustration, and confirm that after the motor starts turning, it stops at the automatic stop position.



REAR WIPER AND WASHER SWITCH

Remove the cluster switch and check the continuity between the terminals for each switch.

Switch position		Terminal				
		1	4	5	7	8
Wiper switch	OFF		○—○			
	ON			○—○		○
	INT	○	○—○			○
Washer switch					○—○	

NOTE


○—○ indicates that there is continuity between the terminals.

REAR INTERMITTENT WIPER RELAY

Operate the wiper with the connector still attached to the rear wiper switch, and check the voltage at terminal ⑧.

When wiper is stopped: 0V

When wiper is operating: 12V

**SERVICE POINT OF INSTALLATION****7. INSTALLATION OF WIPER ARM ASSEMBLY**

Install the wiper arm to the pivot shaft so that the wiper blade's stop position is the position shown in the illustration.

Standard value (A): 25 ± 5 mm (0.98 ± 0.20 in.)


HEADLAMP WASHER

REMOVAL AND INSTALLATION

E51MAAN

Pre-removal and Post-installation Operation

- Removal and installation of Front Bumper Face (Refer to P. 51-4.)
- Draining and Supplying of Washer



1. Headlamp washer switch

Headlamp washer tank assembly removal steps


2. Hose clamp
3. Harness connector
4. Washer hose
5. Headlamp washer tank assembly
6. Float assembly
7. Level sensor
8. Headlamp washer tank

Motor pump assembly removal steps

3. Harness connector
4. Washer hose
9. Motor pump assembly

Nozzle assembly removal steps


4. Washer hose
10. Hose and valve assembly
11. Bracket
12. Nozzle assembly



INSPECTION


HEADLAMP WASHER MOTOR

- (1) With the washer motor installed to the washer tank, fill the washer tank with water.
- (2) Connect battery (+) and (-) cables to terminals 2 and 1 respectively to see that the washer motor runs and water is injected.




WASHER FLUID LEVEL SENSOR

- (1) Remove the washer fluid level sensor from the washer tank.
- (2) Connect a circuit tester to the connector of washer fluid level sensor.
- (3) Move the float up and down.
- (4) Make sure that when the float is raised, there is no continuity and when it is lowered, there is continuity.




HEADLAMP WASHER RELAY


- (1) Remove the headlamp washer relay inside the engine compartment.



- (2) Connect battery and test lamp to the relay as illustrated.



- (3) The relay is normal if the lamp lights for approximately 0.5 second upon connection of terminal 2 to battery (-).



HEADLAMP WASHER SWITCH

Disconnect the column switch connector and check the continuity between the terminals for each switch.


Terminal	4	14
Switch position		
OFF		
ON	○	○

NOTE
○—○ indicates that there is continuity between the terminals.

DECAL

E51SAAB

REMOVAL AND INSTALLATION




- (1) Use unleaded gasoline or toluene to wipe off oil from decal adhesion area.
- (2) Remove protective paper from back of decal and adhere entirely to indicated area.

Caution


- Work in a dust-free workplace with temperature at 20–38°C (68–100°F).
- If workplace temperature is under 20°C (68°F), warm decal and vehicle body (adhesion area) to 20–38°C (68–100°F).
- Adhere decal securely to prevent decal from peeling off.

DOOR MIRROR REMOVAL AND INSTALLATION


E51JAAR

**Removal steps**

1. Delta cover inner
2. Harness connector
3. Door mirror assembly
4. Mirror

**SERVICE POINTS OF REMOVAL****4. REMOVAL OF MIRROR**

Turn the mirror by hand so that it faces upwards, insert the flat-tipped screwdriver wound with masking tape into the notched section, and lever out the mirror to remove it.



INSPECTION

REMOTE CONTROL MIRROR ASSEMBLY


1. Check to be sure that the mirror moves as described in the table when each terminal is connected to the battery.
2. Check if there is continuity between terminals ① and ④.

Direction of operation	Battery		Terminal				
	⊕	⊖	5	6	7	1*	4*
Up	○	○	○		○		
Down	○	○	○		○		
Left	○	○	○	○			
Right	○	○	○	○			

NOTE

○—○ indicates each terminal is connected to the battery.

*: Vehicles with heated mirror



DOOR MIRROR CONTROL SWITCH

Operate switches and check for continuity between terminals.

Direction	Terminal	Left side					Right side				
		3	4	6	7	8	2	4	6	7	9
UP			○		○	○	○	○	○		
DOWN			○		○	○	○	○	○		
LEFT		○	○		○			○	○	○	○
RIGHT		○	○		○			○	○	○	○

NOTE

○—○ indicates each terminal is connected to the battery.