
FUEL

DIESEL FUEL

CONTENTS

GENERAL	2	Engine Coolant Temperature Sensor Check	52
Outline of Change	2	Accelerator Pedal Position Sensor (1st channel) Check	52
GENERAL INFORMATION	2	Accelerator Pedal Position Sensor (2nd channel) Check	53
SERVICE SPECIFICATIONS	4	Injector Check	53
SPECIAL TOOLS	4	Fuel Temperature Sensor Check	53
TROUBLESHOOTING	5	Fuel Pressure Regulator Check	54
ON-VEHICLE SERVICE	51	Crank Angle Sensor Check	54
Component Location	51	Throttle Valve Control Solenoid Check	54
Main Relay Continuity Check	52	Throttle Actuator Check	54
Intake Air Temperature Sensor Check	52	FUEL HIGH PRESSURE PUMP AND FUEL INJECTOR	55

GENERAL

OUTLINE OF CHANGE

The following maintenance service points have been established to correspond to the adoption of the F9Q1 engine.

GENERAL INFORMATION

The common rail fuel injection system consists of sensors which detect the condition of the diesel engine, an engine-ECU which controls the system based on signals from these sensors, and actuators which operate according to control commands from the engine-ECU. The engine-ECU carries out

activities such as fuel injection control and idle speed control. In addition, the engine-ECU is equipped with several self-diagnosis functions which make troubleshooting easier in the event that a problem develops.

FUEL INJECTION CONTROL

The injector drive time and the timing are controlled so that the appropriate quantities of fuel are supplied to the engine in response to engine conditions which can change frequently. A single injector is mounted at each cylinder. The fuel is sent from the fuel tank by

the electronic fuel pump to the high pressure pump. The high pressure pump increases the fuel pressure to the pressure which is required for high-pressure injection, and then send the fuel to each injector.



SELF-DIAGNOSIS FUNCTION

- When an abnormality is detected in any of the sensors or actuators, the engine warning lamp illuminates to warn the driver.
- When an abnormality is detected in any of the sensors or actuators, a diagnosis code number corresponding to the problem which occurred is output.
- The RAM data relating to the sensors and actuators which is stored in the engine-ECU can be read using the MUT-II. In addition, the actuators can be force-driven under certain conditions.

OTHER CONTROL FUNCTIONS

1. A/C Relay Control
Turn the compressor clutch of the A/C ON and OFF.
2. Glow Control
Refer to GROUP 16.
3. Fan Control
The revolutions of the radiator fan and condenser fan are controlled in response to the engine coolant temperature and vehicle speed.
4. EGR Control
Refer to GROUP 17.
5. Throttle Valve Control
The throttle valve control solenoid controls vacuum pressure to the throttle actuator to open and close the throttle valve.
6. Boost Pressure Control
Turbocharger waste gate solenoid controls vacuum pressure to the waste gate actuator to control boost pressure.
7. Additional Heater Control
Refer to GROUP 55.




FUEL INJECTION SYSTEM DIAGRAM



SERVICE SPECIFICATIONS

Items	Specifications	
Intake air temperature sensor resistance k Ω	at -30°C	24.0 – 27.2
	at 20°C	2.35 – 2.55
	at 100°C	0.180 – 0.186
Engine coolant temperature sensor resistance k Ω	at 25°C	2.14 – 2.36
	at 80°C	0.27 – 0.29
Accelerator pedal position sensor (1st channel) Resistance between terminals (3) and (5) Ω	Approx. 1,200	
Accelerator pedal position sensor (2nd channel) Resistance between terminals (2) and (6) Ω	Approx. 1,700	
Injector coil resistance Ω (at 20°C)	Approx. 0.33	
Fuel temperature sensor resistance k Ω (at 25°C)	2.05	
Fuel pressure regulator Ω (at 20°C)	Approx. 5	
Crank angle sensor resistance Ω	720 – 880	
Throttle valve control solenoid coil resistance Ω (at 25°C)	43 – 49	


SPECIAL TOOLS

Tool	Number	Name	Use
 B991502	MB991502	MUT-II sub assembly	<ul style="list-style-type: none"> • Reading diagnosis code • Checking the fuel injection system
	MB990767	End yoke holder	Holding the fuel high pressure pump sprocket
	MD998719	Crankshaft pulley holder pin	

TROUBLESHOOTING

DIAGNOSIS TROUBLESHOOTING FLOW

Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1), GROUP 00 – How to Use Troubleshooting/Inspection Service Points.



DIAGNOSIS FUNCTION

ENGINE WARNING LAMP (CHECK ENGINE LAMP)

If an abnormality occurs in any of the items related to the electronic controlled injection system, the engine warning lamp will illuminate.

If the lamp remains illuminated or if the lamp illuminates while the engine is running, check the diagnosis code output.

NOTE

When the ignition switch is ON, the engine warning lamp illuminates as checking of the engine warning lamp circuit and the bulb, and then the warning lamp is extinguished after a few seconds.

METHOD OF READING AND ERASING DIAGNOSIS CODES

Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1), GROUP 00 – How to Use Troubleshooting/Inspection Service Points.

INSPECTION USING MUT-II DATA LIST AND ACTUATOR TESTING

1. Carry out inspection by means of the data list and the actuator test function.
If there is an abnormality, check and repair the chassis harnesses and components.
2. After repairing, re-check using the MUT-II and check that the abnormal input and output have returned to normal as a result of the repairs.
3. Erase the diagnosis code memory.
4. Remove the MUT-II.
5. Start the engine again and carry out a road test to confirm that the problem has disappeared.

FAIL-SAFE FUNCTION REFERENCE TABLE

Malfunctioning item	Control contents during malfunction
Crank angle sensor system	Engine cut-off
Camshaft position sensor system	Engine cut-off
Fuel pressure sensor system	Engine cut-off
Boost sensor system	<ul style="list-style-type: none"> ● Turbocharger waste gate control is stopped ● EGR control is stopped
Air flow sensor system	EGR control is stopped
Engine coolant temperature sensor system	<ul style="list-style-type: none"> ● The coolant temperature is regulated as specified ● The radiator fan is driven
Intake air temperature sensor system	Thermoplunger control is stopped
EGR valve position sensor system	EGR control is stopped
Immobilizer system	The engine is immobilized. However, the engine is not cut-off while the engine is running
EGR valve system	<ul style="list-style-type: none"> ● Turbocharger waste gate control is stopped ● EGR control is stopped
Turbocharger waste gate solenoid system	<ul style="list-style-type: none"> ● Turbocharger waste gate control is stopped ● EGR control is stopped
Fuel pressure regulator system	Engine cut-off
Fuel pressure system	Engine cut-off
Engine-ECU	Engine cut-off
Additional heater relay system	Thermoplunger control is stopped


INSPECTION CHART FOR DIAGNOSIS CODES**Caution**

Check that the engine-ECU earth circuit is normal before checking for the cause of the problem.

Code No.	Diagnosis item	Reference page
11	Crank angle sensor system	13D-8
12	Camshaft position sensor system	13D-9
13	Accelerator pedal position sensor (1st channel) system	13D-10
14	Accelerator pedal position sensor (2nd channel) system	13D-11
15	Fuel pressure sensor system	13D-12
16	Boost sensor system	13D-13
17	Barometric pressure sensor system	13D-14
18	Air flow sensor system	13D-15
19	Engine coolant temperature sensor system	13D-16
21	Fuel temperature sensor system	13D-17
22	Intake air temperature sensor system	13D-18
23	EGR valve position sensor system	13D-19
24	Glow relay box system	13D-20
25	Immobilizer system	13D-21
26	EGR valve system	13D-22
27	Turbocharger waste gate solenoid system	13D-23
28	Fuel pressure regulator system	13D-24
29	No. 1 injector system	13D-25
31	No. 2 injector system	13D-25
32	No. 3 injector system	13D-26
33	No. 4 injector system	13D-26
34	Glow plug system	13D-27
35	Vehicle speed sensor system	13D-27
36	Fuel pressure system	13D-28
37	Throttle valve control solenoid system	13D-29
38	Engine-ECU	13D-30
40	Additional heater relay system	13D-30
41	Fan control relay (low) system	13D-31
42	Stop lamp switch system	13D-31
43	Clutch pedal switch system	13D-32
44	Power latch system	13D-32
45	Main relay system	13D-33
46	Power supply system	13D-34
47	ECU alimentation	13D-34


INSPECTION PROCEDURE FOR DIAGNOSIS CODES

Code No. 11 Crank angle sensor system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> • During engine running <p>Set Conditions</p> <ul style="list-style-type: none"> • Sensor output voltage does not change (no pulse signal input) or • Sensor output value is 5,000 r/min or more for 1 second 	<ul style="list-style-type: none"> • Malfunction of the crank angle sensor • Improper connector contact, open circuit or short-circuited harness wire of the crank angle sensor circuit • Malfunction of the engine-ECU




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

Code No. 12 Camshaft position sensor system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> • During engine running <p>Set Conditions</p> <ul style="list-style-type: none"> • Sensor output voltage does not change for 0.5 second (no pulse signal input) <p>Range of Check</p> <ul style="list-style-type: none"> • During engine running • Pulse signal detected two or more times <p>Set Conditions</p> <ul style="list-style-type: none"> • Not synchronized with crank angle sensor output <p>or</p> <ul style="list-style-type: none"> • Crank angle sensor output voltage does not change for 0.5 second (no pulse signal input) 	<ul style="list-style-type: none"> • Malfunction of the camshaft position sensor • Improper connector contact, open circuit or short-circuited harness wire of the camshaft position sensor circuit • Malfunction of the engine-ECU




Code No. 13 Accelerator pedal position sensor (1st channel) system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON <p>Set Conditions</p> <ul style="list-style-type: none"> Sensor output voltage is 200 mV or less or Sensor output voltage is 4,750 mV or more 	<ul style="list-style-type: none"> Malfunction of the accelerator pedal position sensor (1st channel) Improper connector contact, open circuit or short-circuited harness wire of the accelerator pedal position sensor (1st channel) circuit Malfunction of the engine-ECU




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

Code No. 14 Accelerator pedal position sensor (2nd channel) system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON <p>Set Conditions</p> <ul style="list-style-type: none"> Sensor output voltage is 200 mV or less or Sensor output voltage is 2,500 mV or more <p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON <p>Set Conditions</p> <ul style="list-style-type: none"> Output difference compared to accelerator pedal position sensor (1st channel) is 6 % or more 	<ul style="list-style-type: none"> Malfunction of the accelerator pedal position sensor (2nd channel) Improper connector contact, open circuit or short-circuited harness wire of the accelerator pedal position sensor (2nd channel) circuit Malfunction of the engine-ECU




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

Code No. 15 Fuel pressure sensor system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON <p>Set Conditions</p> <ul style="list-style-type: none"> Sensor output voltage is 250 mV or less or Sensor output voltage is 4,750 mV or more <p>Range of Check</p> <ul style="list-style-type: none"> During engine running <p>Set Conditions</p> <ul style="list-style-type: none"> Fuel pressure varies greatly from command value 	<ul style="list-style-type: none"> Malfunction of the fuel pressure sensor Improper connector contact, open circuit or short-circuited harness wire of the fuel pressure sensor circuit Malfunction of the engine-ECU




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

Code No. 16 Boost sensor system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON <p>Set Conditions</p> <ul style="list-style-type: none"> Sensor output voltage is 100 mV or less for 1 second or Sensor output voltage is 4,900 mV or more for 1 second <p>Range of Check</p> <ul style="list-style-type: none"> Engine speed: 900 r/min or less <p>Set Conditions</p> <ul style="list-style-type: none"> Variation from barometric pressure sensor output signal is 15 kPa or more for 4.6 seconds 	<ul style="list-style-type: none"> Malfunction of the boost sensor Improper connector contact, open circuit or short-circuited harness wire of the boost sensor circuit Malfunction of the engine-ECU




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

Code No. 17 Barometric pressure sensor system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON <p>Set Conditions</p> <ul style="list-style-type: none"> Sensor output voltage is 200 mV or less for 1 second or Sensor output voltage is 4,950 mV or more for 1 second 	<ul style="list-style-type: none"> Malfunction of the barometric pressure sensor Malfunction of the engine-ECU




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

Code No. 18 Air flow sensor system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON <p>Set Conditions</p> <ul style="list-style-type: none"> Sensor output voltage is 100 mV or less for 1.5 seconds or Sensor output voltage is 1,200 mV or more for 1.5 seconds <p>Range of Check</p> <ul style="list-style-type: none"> Engine speed : 700 r/min or more <p>Set Conditions</p> <ul style="list-style-type: none"> Sensor output is 10 kg/h or less for 1 second 	<ul style="list-style-type: none"> Malfunction of the air flow sensor Improper connector contact, open circuit or short-circuited harness wire of the air flow sensor circuit Malfunction of the engine-ECU




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

Code No. 19 Engine coolant temperature sensor system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON <p>Set Conditions</p> <ul style="list-style-type: none"> Sensor output voltage is 100 mV or less for 1 second or Sensor output voltage is 4,900 mV or more for 1 second 	<ul style="list-style-type: none"> Malfunction of the engine coolant temperature sensor Improper connector contact, open circuit or short-circuited harness wire of the engine coolant temperature sensor circuit Malfunction of the engine-ECU




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

Code No. 21 Fuel temperature sensor system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON <p>Set Conditions</p> <ul style="list-style-type: none"> Sensor output voltage is 100 mV or less for 1 second or Sensor output voltage is 4,900 mV or more for 1 second 	<ul style="list-style-type: none"> Malfunction of the fuel temperature sensor Improper connector contact, open circuit or short-circuited harness wire of the fuel temperature sensor circuit Malfunction of the engine-ECU




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

Code No. 22 Intake air temperature sensor system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON <p>Set Conditions</p> <ul style="list-style-type: none"> Sensor output voltage is 100 mV or less for 1 second or Sensor output voltage is 4,850 mV or more for 1 second 	<ul style="list-style-type: none"> Malfunction of the intake air temperature sensor Improper connector contact, open circuit or short-circuited harness wire of the intake air temperature sensor circuit Malfunction of the engine-ECU




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

Code No. 23 EGR valve position sensor system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON <p>Set Conditions</p> <ul style="list-style-type: none"> Sensor output voltage is 250 mV or less for 1 second or Sensor output voltage is 4,700 mV or more for 1 second <p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: OFF → ON <p>Set Conditions</p> <ul style="list-style-type: none"> Sensor output voltage is 1,500 mV or more for 1 second 	<ul style="list-style-type: none"> Malfunction of the EGR valve position sensor Improper connector contact, open circuit or short-circuited harness wire of the EGR valve position sensor circuit Malfunction of the engine-ECU




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

Code No. 24 Glow relay box system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: OFF→ON <p>Set Conditions</p> <ul style="list-style-type: none"> Trouble signal input from the glow relay box 	<ul style="list-style-type: none"> Malfunction of the glow relay box Improper connector contact, open circuit or short-circuited harness wire of the glow relay box circuit Malfunction of the engine-ECU



*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)


Code No. 25 Immobilizer system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON <p>Set Conditions</p> <ul style="list-style-type: none"> Improper communication between the engine-ECU and Immobilizer-ECU 	<ul style="list-style-type: none"> Malfunction of the immobilizer-ECU Improper connector contact, open circuit or short-circuited harness wire Malfunction of the engine-ECU



NOTE


If the engine-ECU is replaced, the immobilizer-ECU and ignition key should be replaced together with it.

Code No. 26 EGR valve system	Probable cause
	<ul style="list-style-type: none"> ● Malfunction of the EGR valve ● Improper connector contact, open circuit or short-circuited harness wire of the EGR valve circuit ● Malfunction of the engine-ECU




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

Code No. 27 Turbocharger waste gate solenoid system	Probable cause
	<ul style="list-style-type: none"> ● Malfunction of the turbocharger waste gate solenoid ● Improper connector contact, open circuit or short-circuited harness wire of the turbocharger waste gate solenoid circuit ● Malfunction of the engine-ECU




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

Code No. 28 Fuel pressure regulator system	Probable cause
	<ul style="list-style-type: none"> ● Malfunction of the fuel pressure regulator ● Improper connector contact, open circuit or short-circuited harness wire of the fuel pressure regulator circuit ● Malfunction of the engine-ECU




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

Code No. 29 No.1 injector system	Probable cause
	<ul style="list-style-type: none"> • Malfunction of the No.1 injector • Improper connector contact, open circuit or short-circuited harness wire of the No.1 injector circuit • Malfunction of the engine-ECU




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

Code No. 31 No.2 injector system	Probable cause
	<ul style="list-style-type: none"> • Malfunction of the No.2 injector • Improper connector contact, open circuit or short-circuited harness wire of the No.2 injector circuit • Malfunction of the engine-ECU




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

Code No. 32 No.3 injector system	Probable cause
	<ul style="list-style-type: none"> • Malfunction of the No.3 injector • Improper connector contact, open circuit or short-circuited harness wire of the No.3 injector circuit • Malfunction of the engine-ECU




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

Code No. 33 No.4 injector system	Probable cause
	<ul style="list-style-type: none"> • Malfunction of the No.4 injector • Improper connector contact, open circuit or short-circuited harness wire of the No.4 injector circuit • Malfunction of the engine-ECU




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

Code No. 34 Glow plug system	Probable cause
	<ul style="list-style-type: none"> • Malfunction of the glow plug • Improper connector contact, open circuit or short-circuited harness wire of the glow plug circuit • Malfunction of the engine-ECU




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

Code No. 35 Vehicle speed sensor system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> • Ignition switch: ON <p>or</p> <ul style="list-style-type: none"> • During engine running <p>Set Conditions</p> <ul style="list-style-type: none"> • Sensor output voltage corresponds to a speed of 250 km/h or more for 1 second 	<ul style="list-style-type: none"> • Malfunction of the vehicle speed sensor • Improper connector contact, open circuit or short-circuited harness wire of the vehicle speed sensor circuit • Malfunction of the engine-ECU




Code No. 36 Fuel pressure system	Probable cause
	<ul style="list-style-type: none"> ● Malfunction of the high pressure pump ● Malfunction of the injector ● Seized fuel pressure regulator ● Fuel leaking from high pressure fuel system




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

Code No. 37 Throttle valve control solenoid system	Probable cause
	<ul style="list-style-type: none"> • Malfunction of the throttle valve control solenoid • Improper connector contact, open circuit or short-circuited harness wire of the throttle valve control solenoid circuit • Malfunction of the engine-ECU




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

Code No. 38 Engine-ECU	Probable cause
	<ul style="list-style-type: none"> Malfunction of the engine-ECU




Code No. 40 Additional heater relay system	Probable cause
	<ul style="list-style-type: none"> Malfunction of the additional heater relay 1, 2 Improper connector contact, open circuit or short-circuited harness wire of the additional heater relay circuit Malfunction of the engine-ECU




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

Code No. 41 Fan control relay (low) system	Probable cause
	<ul style="list-style-type: none"> Malfunction of the fan control relay Improper connector contact, open circuit or short-circuited harness wire of the fan control relay circuit Malfunction of the engine-ECU




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

Code No. 42 Stop lamp switch system	Probable cause
Range of Check <ul style="list-style-type: none"> Ignition switch: ON Set Conditions <ul style="list-style-type: none"> Outputs for stop lamp switches 1 and 2 are different 	<ul style="list-style-type: none"> Malfunction of the stop lamp switch Improper connector contact, open circuit or short-circuited harness wire of the stop lamp switch circuit Malfunction of the engine-ECU




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

Code No. 43 Clutch pedal switch system	Probable cause
Range of Check • Vehicle speed: 100 km/h or more Set Conditions • Clutch pedal switch remains off for 1 second	<ul style="list-style-type: none"> • Malfunction of the clutch pedal switch • Improper connector contact, open circuit or short-circuited harness wire of the clutch pedal switch circuit • Malfunction of the engine-ECU




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)


Code No. 44 Power latch system	Probable cause
	<ul style="list-style-type: none"> • Malfunction of the engine-ECU




Code No. 45 Main relay system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON <p>Set Conditions</p> <ul style="list-style-type: none"> Power is not supplied <p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: OFF → ON <p>Set Conditions</p> <ul style="list-style-type: none"> Power latch time is short or long 	<ul style="list-style-type: none"> Malfunction of the main relay Improper connector contact, open circuit or short-circuited harness wire of the main relay circuit Malfunction of the engine-ECU



Code No. 46 Power supply system	Probable cause
Range of Check • Ignition switch: ON Set Conditions • Power supply voltage is 6.5 V or less, or 16.5 V or more	• Malfunction of the engine-ECU



Code No. 47 ECU alimentation	Probable cause
	• Malfunction of the engine-ECU



INSPECTION CHART FOR TROUBLE SYMPTOMS**Caution**


Check that the engine-ECU earth circuit is normal before checking for the cause of the problem.

Trouble symptoms		Inspection procedure No.	Reference page
Communication with MUT-II is impossible	Communication with all systems is not possible.	1	13D-36
	Communication with engine-ECU only is not possible.	2	13D-36
Engine warning lamp and related parts	The engine warning lamp does not illuminate right after the ignition switch is turned to the ON position	3	13D-37
	The engine warning lamp remains illuminating and never goes out.	4	13D-38
Starting	No initial combustion (Starting not possible)	5	13D-38
	Poor startability when engine is cold (Poor starting)	6	13D-39
	Poor startability when engine is cold or warm (Poor starting)	7	13D-39
Idling stability (Improper idling)	Idle speed is low when engine is cold (Improper idling speed)	8	13D-40
	Idling speed is high (Improper idling speed)	9	13D-40
	Idling speed is low (Improper idling speed)	10	13D-41
	Idle speed is unstable (Rough idling, hunting)	11	13D-41
Idling stability (Engine stalls)	Engine stops soon after starting	12	13D-42
	Engine stops during idling	13	13D-42
Driving	Engine output is too low	14	13D-43
	Abnormal engine knocking occurs	15	13D-43
	Abnormally black smoke	16	13D-44
	Abnormally white smoke	17	13D-44
	Hunting occurs while driving	18	13D-45

INSPECTION PROCEDURE FOR TROUBLE SYMPTOMS


INSPECTION PROCEDURE 1

Communication with MUT-II is not possible (Communication with all systems is not possible)	Probable cause
The cause is probably a defect in the power supply system (including earth) for the diagnosis line.	<ul style="list-style-type: none"> ● Malfunction of the connector ● Malfunction of the harness wire



INSPECTION PROCEDURE 2

MUT-II communication with engine-ECU is impossible.	Probable cause
One of the following causes may be suspected. <ul style="list-style-type: none"> ● No power supply to engine-ECU ● Defective earth circuit of engine-ECU ● Defective engine-ECU ● Improper communication line between engine-ECU and MUT-II 	<ul style="list-style-type: none"> ● Malfunction of engine-ECU power supply circuit ● Malfunction of the engine-ECU ● Open circuit between engine-ECU and diagnosis connector




NOTE

On vehicles with the multi-center display, if a malfunction cannot be resolved after the procedure above, check the multi-center display and replace if necessary. (Refer to GROUP 54 – Multi-center Display.)


INSPECTION PROCEDURE 3

The engine warning lamp does not illuminate right after the ignition switch is turned to the ON position	Probable cause
Because there is a burnt-out bulb, the engine-ECU causes the engine warning lamp to illuminate immediately after the ignition switch is turned to ON. If the engine warning lamp does not illuminate immediately after the ignition switch is turned to ON, one of the malfunctions listed at right has probably occurred.	<ul style="list-style-type: none"> ● Burnt-out bulb ● Defective warning lamp circuit ● Malfunction of the engine-ECU




INSPECTION PROCEDURE 4

The engine warning lamp remains illuminating and never goes out	Probable cause
In cases such as the above, the cause is probably that the engine-ECU is detecting a problem in a sensor or actuator, or that one of the malfunctions listed at right has occurred.	<ul style="list-style-type: none"> ● Short-circuit between the engine warning lamp and engine-ECU ● Malfunction of the engine-ECU




INSPECTION PROCEDURE 5

No initial combustion (Starting not possible)	Probable cause
The cause is probably a malfunction of the control system, high pressure pump, glow system or power supply.	<ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the high pressure pump ● Malfunction of the glow system ● Malfunction of the immobilizer system ● Malfunction of the engine-ECU




INSPECTION PROCEDURE 6

Poor startability when engine is cold (Poor starting)	Probable cause
The cause is probably a malfunction of the control system, high pressure pump, fuel system or glow system.	<ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the high pressure pump ● Malfunction of the fuel system ● Malfunction of the glow system ● Malfunction of the engine-ECU




INSPECTION PROCEDURE 7

Poor startability when engine is both cold and warm (Poor starting)	Probable cause
The cause is probably a malfunction of the control system, high pressure pump or fuel system.	<ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the high pressure pump ● Malfunction of the fuel system ● Malfunction of the engine-ECU




INSPECTION PROCEDURE 8

Idle speed is low when engine is cold (Improper idling speed)	Probable cause
The cause is probably a malfunction of the control system, high pressure pump or fuel system.	<ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the high pressure pump ● Malfunction of the fuel system ● Malfunction of the engine-ECU




INSPECTION PROCEDURE 9

Idle speed is high (Improper idling speed)	Probable cause
The cause is probably a malfunction of the control system, fuel injector or high pressure pump.	<ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the fuel injector ● Malfunction of the high pressure pump ● Malfunction of the engine-ECU




INSPECTION PROCEDURE 10

Idle speed is low (Improper idling speed)	Probable cause
The cause is probably a malfunction of the control system, high pressure pump or fuel system.	<ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the high pressure pump ● Malfunction of the fuel system ● Malfunction of the engine-ECU




INSPECTION PROCEDURE 11

Idle speed is unstable (Rough idling, hunting)	Probable cause
The cause is probably a malfunction of the control system, high pressure pump, fuel system or glow system.	<ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the high pressure pump ● Malfunction of the fuel system ● Malfunction of the glow system ● Malfunction of the EGR system ● Malfunction of the engine-ECU




INSPECTION PROCEDURE 12

Engine stops soon after starting	Probable cause
The cause is probably a malfunction of the control system, high pressure pump or fuel system.	<ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the high pressure pump ● Malfunction of the fuel system ● Malfunction of the engine-ECU




INSPECTION PROCEDURE 13

Engine stops during idling	Probable cause
The cause is probably a malfunction of the control system, high pressure pump or power supply system.	<ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the high pressure pump ● Malfunction of the EGR system ● Malfunction of the engine-ECU




INSPECTION PROCEDURE 14

Engine output is too low	Probable cause
The cause is probably a malfunction of the control system, high pressure pump, fuel system or EGR system.	<ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the high pressure pump ● Malfunction of the fuel system ● Malfunction of the EGR system ● Clogged air flow sensor ● Malfunction of the engine-ECU




INSPECTION PROCEDURE 15

Abnormal engine knocking occurs	Probable cause
The cause is probably a malfunction of the control system, high pressure pump or fuel system.	<ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the high pressure pump ● Malfunction of the fuel system ● Malfunction of the engine-ECU




INSPECTION PROCEDURE 16

Abnormally black smoke	Probable cause
The cause is probably a malfunction of the control system, high pressure pump, fuel system or EGR system.	<ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the high pressure pump ● Malfunction of the fuel system ● Malfunction of the EGR system ● Malfunction of the engine-ECU




INSPECTION PROCEDURE 17

Abnormally white smoke	Probable cause
The cause is probably a malfunction of the control system, high pressure pump, fuel system, EGR system or glow system.	<ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the high pressure pump ● Malfunction of the fuel system ● Malfunction of the EGR system ● Malfunction of the glow system ● Malfunction of the engine-ECU




INSPECTION PROCEDURE 18

Hunting occurs while driving	Probable cause
The cause is probably a malfunction of the control system, high pressure pump or fuel system.	<ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the high pressure pump ● Malfunction of the fuel system ● Malfunction of the engine-ECU



INSPECTION PROCEDURE 19

Check the engine-ECU power supply and earth circuit



DATA LIST REFERENCE TABLE

Caution**Driving tests always need another personnel.**

Item No.	Inspection item	Inspection contents	Normal condition	Inspection procedure No.	Reference page	
01	Engine coolant temperature sensor	Ignition switch: ON	Engine coolant temperature is -20°C	-20°C	Code No. 19	13D-16
			Engine coolant temperature is 0°C	0°C		
			Engine coolant temperature is 20°C	20°C		
			Engine coolant temperature is 40°C	40°C		
			Engine coolant temperature is 80°C	80°C		
02	Fuel temperature sensor	<ul style="list-style-type: none"> In cooled state Ignition switch: ON 	Approx. the same as the outdoor temperature	Code No. 21	13D-17	
03	Intake air temperature sensor	Ignition switch: ON	Intake air temperature is -20°C	-20°C	Code No. 22	13D-18
			Intake air temperature is 0°C	0°C		
			Intake air temperature is 20°C	20°C		
			Intake air temperature is 40°C	40°C		
			Intake air temperature is 80°C	80°C		
04	Boost sensor	Ignition switch: ON		950 – 1040 hPa	Code No. 16	13D-13
		<ul style="list-style-type: none"> Engine coolant temperature: $80 - 95^{\circ}\text{C}$ Lamp, electric cooling fan and all accessories: OFF 	When engine is suddenly raced	Pressure increases		
05	Barometric pressure sensor	Ignition switch: ON	At altitude of 0 m	950 – 1040 hPa	Code No. 17	13D-14
06	Fuel pressure sensor	Engine: After warm-up	When engine is suddenly raced	Pressure increases	Code No. 15	13D-12
07	Fuel pressure sensor (command value)	Engine: After warm-up	When engine is suddenly raced	Pressure increases	–	–

Item No.	Inspection item	Inspection contents	Normal condition	Inspection procedure No.	Reference page	
08	Air flow sensor	<ul style="list-style-type: none"> Engine coolant temperature: 80 – 95°C Lamp, electric cooling fan and all accessories: OFF 	When engine is suddenly raced	Increases	–	–
09	Accelerator pedal position sensor (1st channel)	Ignition switch: ON	Release the accelerator pedal	700 – 800 mV	Code No. 13	13D-10
			Depress the accelerator pedal gradually	Increases in response to the pedal depression stroke		
			Depress the accelerator pedal fully	3,270 – 4,700 mV		
10	Accelerator pedal position sensor (1st channel)	Ignition switch: ON	Release the accelerator pedal	375 mV	Code No. 14	13D-11
			Depress the accelerator pedal gradually	Increases in response to the pedal depression stroke		
			Depress the accelerator pedal fully	1,635 – 2,500 mV		
11	Accelerator pedal position sensor	Ignition switch: ON	Release the accelerator pedal	0 %	–	–
			Depress the accelerator pedal gradually	Increases in response to the pedal depression stroke		
			Depress the accelerator pedal fully	100 %		
12	Crank angle sensor	<ul style="list-style-type: none"> Engine: Cranking Tachometer: Connected 	Compare the engine speed readings on the tachometer and the MUT-II	Accord	Code No. 11	13D-8
14	Fuel injection amount	<ul style="list-style-type: none"> Engine coolant temperature: 80 – 95°C Lamp, electric cooling fan and all accessories: OFF 	Engine is Idling	4 – 9 mm ³	–	–

Item No.	Inspection item	Inspection contents		Normal condition	Inspection procedure No.	Reference page
15	EGR valve position sensor	<ul style="list-style-type: none"> Engine coolant temperature: 80 – 95°C Lamp, electric cooling fan and all accessories: OFF 	When engine is suddenly raced	Increases	Code No. 23	13D-19
16	EGR valve	<ul style="list-style-type: none"> Engine coolant temperature: 80 – 95°C Lamp, electric cooling fan and all accessories: OFF 	Engine is Idling	5 – 10 %	Code No. 26	13D-22
			When engine is suddenly raced	Increases		
17	Turbocharger waste gate solenoid	Ignition switch: ON	When engine is suddenly raced	Increases	Code No. 27	13D-23
18	Fuel pressure regulator	Engine: After warm-up	When engine is suddenly raced	Voltage increases	Code No. 28	13D-24
20	Crank angle sensor (2,000 r/min or less)	<ul style="list-style-type: none"> Engine: Cranking [reading is possible at 2,000 r/min or less] Tachometer: Connected 		Engine speeds displayed on the MUT-II and tachometer are identical	–	–
21	Vehicle speed sensor	When vehicle is moving	Compare the speeds displayed on the speedometer and the MUT-II	Accord	Code No. 35	13D-27
41	Ignition switch – IG	Ignition switch: ON		ON	–	–
42	Stop lamp switch	Ignition switch: ON	Brake pedal: Depressed	ON	Code No. 42	13D-31
			Brake pedal: Released	OFF		
44	Clutch pedal switch	Ignition switch: ON	Clutch pedal: Depressed	ON	Code No. 43	13D-32
			Clutch pedal: Released	OFF		
45	Overheat indicator lamp	Ignition switch: ON	Several seconds pass after ignition switch is turned to ON	ON → OFF	–	–
46	Glow indicator lamp	Ignition switch: ON	From 0.5 – 16 seconds after ignition switch is turned to ON	ON → OFF	–	–
47	Throttle valve control solenoid	Engine: Idle		OFF	Code No. 37	13D-29
		Engine: Idle → stopped		ON		
48	Glow relay box	Ignition switch: ON	From 0.5 – 16 seconds after ignition switch is turned to ON	ON → OFF	Code No. 24	13D-20

Item No.	Inspection item	Inspection contents	Normal condition	Inspection procedure No.	Reference page	
50	A/C relay	Engine: After warm-up, idle	A/C switch: OFF	OFF (Compressor clutch is not operating)	–	–
			A/C switch: ON	ON (Compressor clutch is operating)		
51	A/C switch	Engine: After warm-up, idle	A/C switch: OFF	OFF	–	–
			A/C switch: ON	ON		
52	Additional heater relay 1	<ul style="list-style-type: none"> ● Engine coolant temperature: 75°C or lower ● Intake air temperature: 10°C or lower ● Post-heating complete ● All accessories: OFF 	ON	Code No. 40	13D-30	
		Engine: After warm-up	OFF			
53	Additional heater relay 2	<ul style="list-style-type: none"> ● Engine coolant temperature: 75°C or lower ● Intake air temperature: 10°C or lower ● Post-heating complete ● All accessories: OFF 	ON	Code No. 40	13D-30	
		Engine: After warm-up	OFF			
54	Fan control relay (high)	Engine coolant temperature: 96°C or lower	OFF	–	–	
		Engine coolant temperature: 102°C or higher	ON			
55	Fan control relay (low)	Engine coolant temperature: 99°C or lower	OFF	–	–	
		Engine coolant temperature: 99 – 102°C	ON			


ACTUATOR TEST REFERENCE TABLE


Item No.	Inspection item	Drive contents	Inspection contents	Normal condition	Inspection procedure No.	Reference page
01	Injector	Cut fuel to No. 1 injector	Engine: After warm-up, idle (Cut the fuel supply to each injector in turn and check cylinders which don't affect idling)	Idling condition becomes different (becomes unstable)	Code No. 29	13D-25
02		Cut fuel to No. 2 injector			Code No. 31	13D-25
03		Cut fuel to No. 3 injector			Code No. 32	13D-26
04		Cut fuel to No. 4 injector			Code No. 33	13D-26
05	Turbocharger waste gate solenoid	Solenoid valve turns from OFF to ON	Ignition switch: ON	Sound of operation can be heard when solenoid valve is driven	Code No. 27	13D-23
06	Throttle valve control solenoid	Solenoid valve turns from OFF to ON	Ignition switch: ON	Sound of operation can be heard when solenoid valve is driven	Code No. 37	13D-29
07	Fuel pressure regulator	Solenoid valve turns from OFF to ON	Ignition switch: ON	Sound of operation can be heard when solenoid valve is driven	Code No. 28	13D-24
08	EGR valve	Solenoid valve turns from OFF to ON	Ignition switch: ON	Sound of operation can be heard when solenoid valve is driven	Code No. 26	13D-22
09	Glow relay box	Relay turns from OFF to ON	<ul style="list-style-type: none"> ● Ignition switch: ON ● Check operating condition on data list 	OFF → ON	Code No. 24	13D-20
10	Additional heater relay 1	Relay turns from OFF to ON	Ignition switch: ON	Sound of operation can be heard when relay is driven	Code No. 40	13D-30
11	Additional heater relay 2	Relay turns from OFF to ON	Ignition switch: ON	Sound of operation can be heard when relay is driven	Code No. 40	13D-30
12	Fan control relay (high)	Relay turns from OFF to ON	Ignition switch: ON	Fan motor operates at high speed	–	–
13	Fan control relay (low)	Relay turns from OFF to ON	Ignition switch: ON	Fan motor operates at low speed	–	–
14	Engine warning lamp	Causes engine warning lamp to illuminate	Engine: Idle	Engine warning lamp illuminates	–	–
15	Glow indicator lamp	Causes glow indicator lamp to illuminate	Engine: Idle	Glow indicator lamp illuminates	–	–
16	Overheat indicator lamp	Causes overheat indicator lamp to illuminate	Engine: Idle	Glow overheat lamp illuminates	–	–

ON-VEHICLE SERVICE

COMPONENT LOCATION


Name	Symbol	Name	Symbol
A/C relay	H	Engine-ECU (with barometric pressure sensor)	A
A/C switch	Q	Fuel pressure regulator	J
Accelerator pedal position sensor (1st and 2nd channel)	P	Fuel pressure sensor	D
Air flow sensor (with intake air temperature sensor)	G	Fuel temperature sensor	D
Boost sensor	M	Glow relay box	I
Camshaft position sensor	B	Injector	C
Clutch pedal switch	N	Main relay	R
Crank angle sensor	K	Stop lamp switch	N
Diagnosis connector	R	Throttle valve control solenoid	E
EGR valve	F	Turbocharger waste gate solenoid	E
EGR valve position sensor	F	Vehicle speed sensor	K
Engine coolant temperature sensor	L		





MAIN RELAY CONTINUITY CHECK

Battery voltage	Terminal No.			
	1	2	3	4
Not supplied	○	○	○	○
Supplied	○	⊖	○	⊕



INTAKE AIR TEMPERATURE SENSOR CHECK


1. Disconnect the air flow sensor connector.
2. Measure the resistance between terminals 1 and 2.

Standard value:

24.0 – 27.2 kΩ (at -30°C)

2.35 – 2.55 kΩ (at 20°C)

0.180 – 0.186 kΩ (at 100°C)




ENGINE COOLANT TEMPERATURE SENSOR CHECK

1. Disconnect the engine coolant temperature sensor connector.
2. Measure the resistance between terminals 2 and 3.

Standard value: 2.14 – 2.36 kΩ (at 25°C)

0.27 – 0.29 kΩ (at 80°C)



ACCELERATOR PEDAL POSITION SENSOR (1st channel) CHECK


1. Disconnect the accelerator pedal position sensor connector.
2. Measure the resistance between terminals 3 and 5.


Standard value: Approx. 1200 Ω

3. Measure the resistance between terminals 4 and 5.

Normal condition:

Depress the accelerator pedal slowly	Resistance value changes in accordance with the accelerator pedal depression smoothly
--------------------------------------	---





ACCELERATOR PEDAL POSITION SENSOR (2nd channel) CHECK

1. Disconnect the accelerator pedal position sensor connector.
2. Measure the resistance between terminals 2 and 6.



Standard value: Approx. 1,700 Ω

3. Measure the resistance between terminals 1 and 6.

Normal condition:

Depress the accelerator pedal slowly


Resistance value changes in accordance with the accelerator pedal depression smoothly



INJECTOR CHECK

1. Disconnect the injector connector.
2. Measure the resistance between terminals.


Standard value: Approx. 0.33 Ω (at 20°C)



FUEL TEMPERATURE SENSOR CHECK

1. Disconnect the fuel temperature sensor connector.
2. Measure the resistance between terminals.


Standard value: 2.05 k Ω (at 25°C)



FUEL PRESSURE REGULATOR CHECK

1. Disconnect the fuel pressure regulator connector.
2. Measure the resistance between terminals.


Standard value: Approx. 5 Ω (at 20°C)



CRANK ANGLE SENSOR CHECK

1. Disconnect the crank angle sensor connector.
2. Measure the resistance between terminals.

Standard value: 720 – 880 Ω




THROTTLE VALVE CONTROL SOLENOID CHECK

NOTE

When disconnecting the vacuum hose, always make a mark so that it can be reconnected at original position.


1. Disconnect the vacuum hose from the solenoid.
2. Disconnect the solenoid connector.
3. Connect a hand vacuum pump to the nipple (B) of the solenoid (refer to the illustration at left).
4. Check the airtightness by applying a vacuum with voltage applied directly from the battery to the solenoid and without applying voltage.



Battery voltage	Nipple A condition	Normal condition
Applied	Open	Vacuum leaks
	Close	Vacuum maintained
Not applied	Open	Vacuum leaks

5. Measure the resistance between the terminals.

Standard value: 43 – 49 Ω (at 25°C)




THROTTLE ACTUATOR CHECK

1. Disconnect the vacuum hose from the throttle actuator and connect a hand vacuum pump to the throttle actuator nipple.
2. Check that the actuator rod moves smoothly when applying vacuum gradually.

FUEL HIGH PRESSURE PUMP AND FUEL INJECTOR

REMOVAL AND INSTALLATION



AY0220AJ

Fuel high pressure pump removal steps

- Timing belt (Refer to GROUP 11C.)
- 1. Fuel high pressure pump connector
- 2. Fuel supply hose connection
- 3. Fuel return hose connection
- 6. Fuel pump pipe
- 7. Fuel high pressure pump sprocket
- 8. Fuel high pressure pump




Fuel injector removal steps

- 4. Fuel return tube
- 5. Fuel pressure sensor connector
- 6. Fuel pump pipe
- 9. Fuel injector pipe
- 10. Fuel pressure sensor
- 11. Common rail
- 12. Fuel injector connector
- 13. Fuel injector holder
- 14. Fuel injector

REMOVAL SERVICE POINTS

◀B▶ FUEL HOSE CONNECTION/FUEL PIPE/FUEL RETURN TUBE/FUEL PRESSURE SENSOR REMOVAL

Disconnect the fuel hose, fuel pipe, fuel return tube and the fuel pressure sensor. Then, plug them to prevent dust from entering the fuel line, common rail and the fuel high pressure pump.



◀B▶ FUEL HIGH PRESSURE PUMP SPROCKET REMOVAL

INSTALLATION SERVICE POINT


▶A◀ FUEL HIGH PRESSURE PUMP SPROCKET INSTALLATION

Use the special tool to secure the fuel high pressure pump sprocket in the same way as during removal, and then tighten the bolt to the specified torque.



SERVICE BULLETIN

QUALITY INFORMATION ANALYSIS
OVERSEAS SERVICE DEPT. MITSUBISHI MOTORS CORPORATION

SERVICE BULLETIN		No.: ESB-01E13-502	
		Date: 2001-12-19	<Model> <M/Y>
Subject: DELETION OF NOTE ON CODE NO. 25 IMMOBILIZER SYSTEM		(EC)CARISMA (DA0A)	96-01
Group: FUEL	Draft No.: 01CH501	(EC)SPACE STAR (DDG0A)	99-01
CORRECTION	INTERNATIONAL CAR ADMINISTRATION OFFICE	 O. Kai - E.V.P. & G.M. After Sales Service Dept	


1. Description:

Deletion has been made of NOTE on Code No.25 Immobilizer System and Troubleshooting.

2. Applicable Manuals:

Manual	Pub. No.	Language	Page(s)
2001 CARISMA W/M SUPPLEMENT	PWDE9502-E	(English)	13E-21
	PWDS9503-E	(Spanish)	
	PWDF9504-E	(French)	
	PWDG9505-E	(German)	
	PWDD9506-E	(Dutch)	
	PWDW9507-E	(Swedish)	
'96 - '01 MY CARISMA W/M CD - ROM (SUPPLEMENT)	CDXX96E1CD	(English)	-
	CDXX96E1CD	(Spanish)	
	CDXZ96E1CD	(French)	
	CDXZ96E1CD	(German)	
	CDXZ96E1CD	(Dutch)	
	CDXX96E1CD	(Swedish)	
2001 SPACE STAR W/M SUPPLEMENT	CMXE99E1-A	(English)	13D-21
	CMXS99E1-A	(Spanish)	
	CMXF99E1-A	(French)	
	CMXG99E1-A	(German)	
	CMXD99E1-A	(Dutch)	
	CMXW99E1-A	(Swedish)	
	CMXI99E1-A	(Italian)	
'99 - '01 MY SPACE STAR W/M CD - ROM (SUPPLEMENT)	CMXX99E2CD	(English)	-
	CMXX99E2CD	(Spanish)	
	CMXZ99E2CD	(French)	
	CMXZ99E2CD	(German)	
	CMXZ99E2CD	(Dutch)	
	CMXX99E2CD	(Swedish)	
CMXZ99E2CD	(Italian)		


Code No. 25 Immobilizer system	Probable cause
Range of Check • Ignition switch: ON Set Conditions • Improper communication between the engine-ECU and Immobilizer	<ul style="list-style-type: none"> • Malfunction of the immobilizer-ECU • Improper connector contact, open circuit or short-circuited harness wire • Malfunction of the engine-ECU



<Deleted>

NOTE
 If the engine-ECU is replaced, the immobilizer-ECU and ignition key should be replaced together with it.

Code No. 25 Immobilizer system	Probable cause
Range of Check • Ignition switch: ON Set Conditions • Improper communication between the engine-ECU and Immobilizer	<ul style="list-style-type: none"> • Malfunction of the immobilizer-ECU • Improper connector contact, open circuit or short-circuited harness wire • Malfunction of the engine-ECU




<Deleted>

NOTE
 If the engine-ECU is replaced, the immobilizer-ECU and ignition key should be replaced together with it.



SERVICE BULLETIN

SERVICE ENGINEERING & PUBLICATION
INTERNATIONAL AFTER-SALES DEPARTMENT. MITSUBISHI MOTORS CORPORATION

SERVICE BULLETIN		NO. : MSB-01E13-504	
		DATE : 2001-11-20	<MODEL> (EC)CARISMA (DA0A)
SUBJECT : CORRECTION TO TIGHTENING TORQUES AND ILLUSTRATIONS FOR F9Q ENGINE			<M/Y> 01-10
GROUP : FUEL		DRAFTNO. : 01AL030	
CORRECTION		INTERNATIONAL AFTER-SALES DEPARTMENT	 T. Inoue - Manager SERVICE ENGINEERING & PUBLICATION
			(EC)SPACE STAR (DG0A) 01-10

1. Description:

On the F9Q engine installed on the CARISMA and SPACE STAR, corrections have been made to the following items:

- Shape and tightening torque of the fuel high pressure pump sprocket mounting nut
- Tightening torque of the fuel pressure sensor
- Shape of the fuel injector pump bracket mounting bolt

2. Applicable Manuals:


Manual	Pub. No.	Page
'01 CARISMA Workshop Manual (Supplement)	PWDE9502-E (English) PWDS9503-E (Spanish) PWDF9504-E (French) PWDG9505-E (German) PWDD9506-E (Dutch) PVDW9507-E (Swedish)	13E-55
'01 SPACE STAR Workshop Manual (Supplement)	CMXE99E1-A (English) CMXS99E1-A (Spanish) CMXF99E1-A (French) CMXD99E1-A (Dutch)	13D-55

3. Details:

'01 CARISMA Workshop Manual (Supplement)

DIESEL FUEL <F9Q> – Fuel High Pressure Pump and Fuel Injector 13E-55

**FUEL HIGH PRESSURE PUMP AND FUEL INJECTOR
REMOVAL AND INSTALLATION**



AY0220AJ

Fuel high pressure pump removal steps

- Timing belt (Refer to GROUP 11C.)
- 1. Fuel high pressure pump connector
- 2. Fuel supply hose connection
- 3. Fuel return hose connection
- 6. Fuel pump pipe
- 7. Fuel high pressure pump sprocket
- 8. Fuel high pressure pump




Fuel injector removal steps

- 4. Fuel return tube
- 5. Fuel pressure sensor connector
- 6. Fuel pump pipe
- 9. Fuel injector pipe
- 10. Fuel pressure sensor
- 11. Common rail
- 12. Fuel injector connector
- 13. Fuel injector holder
- 14. Fuel injector



FUEL HIGH PRESSURE PUMP AND FUEL INJECTOR

REMOVAL AND INSTALLATION



Fuel high pressure pump removal steps

- Timing belt (Refer to GROUP 11C.)
- 1. Fuel high pressure pump connector
- 2. Fuel supply hose connection
- 3. Fuel return hose connection
- 6. Fuel pump pipe
- 7. Fuel high pressure pump sprocket
- 8. Fuel high pressure pump



Fuel injector removal steps

- 4. Fuel return tube
- 5. Fuel pressure sensor connector
- 6. Fuel pump pipe
- 9. Fuel injector pipe
- 10. Fuel pressure sensor
- 11. Common rail
- 12. Fuel injector connector
- 13. Fuel injector holder
- 14. Fuel injector

