

---

# ENGINE ELECTRICAL

# ENGINE ELECTRICAL

## CONTENTS

16109000233

|   |           |  |           |
|---|-----------|--|-----------|
| <b>CHARGING SYSTEM</b> .....                  | <b>3</b>  | <b>IGNITION SYSTEM</b> .....                   | <b>34</b> |
| <b>GENERAL INFORMATION</b> .....              | <b>3</b>  | <b>GENERAL INFORMATION</b> .....               | <b>34</b> |
| <b>SERVICE SPECIFICATIONS</b> .....           | <b>5</b>  | <b>SERVICE SPECIFICATIONS</b> .....            | <b>36</b> |
| <b>SPECIAL TOOLS</b> .....                    | <b>5</b>  | <b>SPECIAL TOOLS</b> .....                     | <b>37</b> |
| <b>ON-VEHICLE SERVICE</b> .....               | <b>6</b>  | <b>ON-VEHICLE SERVICE</b> .....                | <b>37</b> |
| Alternator Output Line Voltage Drop Test .... | 6         | Ignition Coil Check <MPI> .....                | 37        |
| Output Current Test .....                     | 8         | Power Transistor Continuity Check <MPI> ..     | 38        |
| Regulated Voltage Test .....                  | 10        | Ignition Coil (with built-in power transistor) |           |
| Waveform Check Using An Analyzer .....        | 12        | Check <GDI> .....                              | 38        |
| Alternator Relay Continuity Check .....       | 13        | Resistive Cord Check <MPI> .....               | 39        |
| <b>ALTERNATOR</b> .....                       | <b>14</b> | Spark Plug Check and Cleaning .....            | 39        |
| <b>STARTING SYSTEM</b> .....                  | <b>23</b> | Crank Angle Sensor Check <MPI> .....           | 40        |
| <b>GENERAL INFORMATION</b> .....              | <b>23</b> | Crank Angle Sensor, Camshaft Position Sensor   |           |
| <b>SERVICE SPECIFICATIONS</b> .....           | <b>24</b> | Check <GDI> .....                              | 40        |
| <b>STARTER MOTOR</b> .....                    | <b>24</b> | Detonation Sensor Check .....                  | 40        |
|   |           | Waveform Check Using An                        |           |
|   |           | Analyzer <MPI> .....                           | 41        |
|   |           | <b>CONTINUED ON NEXT PAGE</b>                  |           |

---

|   |    |
|---|----|
| IGNITION COIL <GDI> .....               | 48 |
| CAMSHAFT POSITION<br>SENSOR <GDI> ..... | 48 |
| CRANK ANGLE SENSOR <GDI> .....          | 49 |

|                         |    |
|-------------------------|----|
| DISTRIBUTOR <MPI> ..... | 50 |
| DETONATION SENSOR ..... | 52 |




# CHARGING SYSTEM

16100010341

## GENERAL INFORMATION

The charging system uses the alternator output to keep the battery charged at a constant level under various electrical loads.



## OPERATION

Rotation of the excited field coil generates AC voltage in the stator.

This alternating current is rectified through diodes to DC voltage having a waveform shown in the illustration at left. The average output voltage fluctuates slightly with the alternator load condition.

When the ignition switch is turned on, current flows in the field coil and initial excitation of the field coil occurs.

When the stator coil begins to generate power after the engine is started, the field coil is excited by the output current of the stator coil.


The alternator output voltage rises as the field current increases and it falls as the field current decreases. When the battery voltage (alternator S terminal voltage) reaches a regulated voltage of

approx. 14.4 V, the field current is cut off. When the battery voltage drops below the regulated voltage, the voltage regulator regulates the output voltage to a constant level by controlling the field current.

In addition, when the field current is constant, the alternator output voltage rises as the engine speed increases.


SYSTEM DIAGRAM

<GDI>



W6016AJ

<MPI>



9EN0552

**ALTERNATOR SPECIFICATIONS**

|                   |                                     |                          |
|-------------------|-------------------------------------|--------------------------|
| Items             | GDI                                 | MPI                      |
| Type              | Reduction drive with planetary gear | Battery voltage sensing  |
| Rated output V/A  | 12/85, 12/100*                      | 12/90                    |
| Voltage regulator | Electronic built-in type            | Electronic built-in type |

**NOTE**

\*: Vehicles for cold climate zone



**SERVICE SPECIFICATIONS**

16100030231

| Items  |       | Standard value | Limit                        |
|--|-------|----------------|------------------------------|
| Alternator output line voltage drop (at 30 A) V              |       | –              | Max. 0.3                     |
| Regulated voltage ambient temperature at voltage regulator V | –20°C | 14.2 – 15.4    | –                            |
|  | 20°C  | 13.9 – 14.9    | –                            |
|  | 60°C  | 13.4 – 14.6    | –                            |
|  | 80°C  | 13.1 – 14.5    | –                            |
| Output current   |       | –              | 70% of normal output current |
| Rotor coil resistance $\Omega$                               | GDI   | Approx. 2 – 5  | –                            |
|  | MPI   | Approx. 2.6    | –                            |

**SPECIAL TOOLS**


16100060117

| Tool   | Number   | Name                    | Use  |
|--|----------|-------------------------|--|
| <br>B991519 | MB991519 | Alternator test harness | Checking the alternator (S terminal voltage) <GDI> |
| <br>B991450 | MB991450 | Alternator test harness | Checking the alternator (S terminal voltage) <MPI> |

## ON-VEHICLE SERVICE

16100090314

## ALTERNATOR OUTPUT LINE VOLTAGE DROP TEST



9EN0468

This test determines whether the wiring from the alternator "B" terminal to the battery (+) terminal (including the fusible line) is in a good condition or not.

1. Always be sure to check the following before the test.
  - Alternator installation
  - Alternator drive belt tension
  - Fusible link
  - Abnormal noise from the alternator while the engine is running
2. Turn the ignition switch off.
3. Disconnect the negative battery cable.
4. Disconnect the alternator output wire from the alternator "B" terminal and connect a DC test ammeter with a range of 0–100 A in series between the "B" terminal and the disconnected

output wire. (Connect the (+) lead of the ammeter to the "B" terminal, and then connect the (–) lead of the ammeter to the disconnected output wire.)

## NOTE

An inductive-type ammeter which enables measurements to be taken without disconnecting the alternator output wire should be recommended. Using this equipment will lessen the possibility of a voltage drop caused by a loose "B" terminal connection.

5. Connect a digital-type voltmeter between the alternator "B" terminal and the battery (+) terminal. (Connect the (+) lead of the voltmeter to the "B" terminal and the connect the (–) lead of the voltmeter to the battery (+) cable.)

6. Reconnect the negative battery cable.
7. Connect a tachometer or the MUT-II.
8. Leave the hood open.
9. Start the engine.
10. With the engine running at 2,500 r/min, turn the headlamps and other lamps on and off to adjust the alternator load so that the value displayed on the ammeter is slightly above 30 A.  
Adjust the engine speed by gradually decreasing it until the value displayed on the ammeter is 30 A. Take a reading of the value displayed on the voltmeter at this time.  
**Limit: max. 0.3 V**
11. If the value displayed on the voltmeter is above the limit value, there is probably a malfunction in the alternator output wire, so check the wiring between the alternator “B” terminal and the battery (+) terminal (including fusible link). If a terminal is not sufficiently tight or if the harness has become discolored due to overheating, repair and then test again.
12. After the test, run the engine at idle.
13. Turn off all lamps and the ignition switch.
14. Remove the tachometer or the MUT-II.
15. Disconnect the negative battery cable.
16. Disconnect the ammeter and voltmeter.
17. Connect the alternator output wire to the alternator “B” terminal.
18. Connect the negative battery cable.

**NOTE**


When the alternator output is high and the value displayed on the ammeter does not decrease until 30 A, set the value to 40 A. Read the value displayed on the voltmeter at this time. When the value range is 40 A, the limit is max. 0.4 V.



OUTPUT CURRENT TEST


16100100314

<GDI>



6EN1162

<MPI>



6EN1140

This test determines whether the alternator output current is normal.

1. Before the test, always be sure to check the following.

- Alternator installation
- Battery

**NOTE**

The battery should be slightly discharged. The load needed by a fully-charged battery is insufficient for an accurate test.

- Alternator drive belt tension
- Fusible link
- Abnormal noise from the alternator while the engine is running.

2. Turn the ignition switch off.
3. Disconnect the negative battery cable.
4. Disconnect the alternator output wire from the alternator "B" terminal. Connect a DC test ammeter with a range of 0–100 A in series between the "B" terminal and the disconnected output wire. (Connect the (+) lead of the ammeter to the "B" terminal. Connect the (–) lead of the ammeter to the disconnected output wire.)

**Caution**

**Never use clips but tighten bolts and nuts to connect the line. Otherwise loose connections (e.g. using clips) will lead to a serious accident because of high current.**

**NOTE**

An inductive-type ammeter which enables measurements to be taken without disconnecting the alternator output wire should be recommended.

5. Connect a voltmeter with a range of 0–20 V between the alternator "B" terminal and the earth. (Connect the (+) lead of the voltmeter to the "B" terminal, and then connect the (–) lead of the voltmeter to the earth.)
6. Connect the negative battery cable.
7. Connect a tachometer or the MUT-II.
8. Leave the hood open.
9. Check that the reading on the voltmeter is equal to the battery voltage.

**NOTE**

If the voltage is 0 V, the cause is probably an open circuit in the wire or fusible link between the alternator "B" terminal and the battery (+) terminal.

10. Turn the light switch on to turn on headlamps and then start the engine.
11. Immediately after setting the headlamps to high beam and turning the heater blower switch to the high revolution position, increase the engine speed to 2,500 r/min and read the maximum current output value displayed on the ammeter.

**Limit: 70% of normal current output**


**NOTE**

- For the nominal current output, refer to the Alternator Specifications.
  - Because the current from the battery will soon drop after the engine is started, the above step should be carried out as quickly as possible in order to obtain the maximum current output value.
  - The current output value will depend on the electrical load and the temperature of the alternator body.
  - If the electrical load is small while testing, the specified level of current may not be output even though the alternator is normal. In such cases, increase the electrical load by leaving the headlamps turned on for some time to discharge the battery or by using the lighting system in another vehicle, and then test again.
  - The specified level of current also may not be output if the temperature of the alternator body or the ambient temperature is too high. In such cases, cool the alternator and then test again.
12. The reading on the ammeter should be above the limit value. If the reading is below the limit value and the alternator output wire is normal, remove the alternator from the engine and check the alternator.
  13. Run the engine at idle after the test.
  14. Turn the ignition switch off.
  15. Remove the tachometer or the MUT-II.
  16. Disconnect the negative battery cable.
  17. Disconnect the ammeter and voltmeter.
  18. Connect the alternator output wire to the alternator "B" terminal.
  19. Connect the negative battery cable.

REGULATED VOLTAGE TEST


16100110317

<GDI>



6EN1163

<MPI>



6EN1141

This test determines whether the voltage regulator is correctly controlling the alternator output voltage.

1. Always be sure to check the following before the test.
  - Alternator installation
  - Check that the battery installed in the vehicle is fully charged.
  - Alternator drive belt tension
  - Fusible link
  - Abnormal noise from the alternator while the engine is running
2. Turn the ignition switch to the OFF position.
3. Disconnect the negative battery cable.
4. Use the special tool (Alternator test harness: MB991519, MB991450) to connect a digital voltmeter between the alternator S terminal and earth. (Connect the (+) lead of the voltmeter to the "S" terminal, and then connect the (-) lead of the voltmeter to a secure earth or to the battery (-) terminal.)
5. Disconnect the alternator output wire from the alternator "B" terminal.
6. Connect a DC test ammeter with a range of 0–100 A in series between the "B" terminal and the disconnected output wire. (Connect the (+) lead of the ammeter to the "B" terminal. Connect the (-) lead of the ammeter to the disconnected output wire.)
7. Reconnect the negative battery cable.
8. Connect a tachometer or the MUT-II.
9. Turn the ignition switch to the ON position and check that the reading on the voltmeter is equal to the battery voltage.

NOTE


If the voltage is 0 V, the cause is probably an open circuit in the wire or fusible link between the alternator "S" terminal and the battery (+) terminal.

10. Turn all lamps and accessories off.
11. Start the engine.
12. Increase the engine speed to 2,500 r/min.
13. Read the value displayed on the voltmeter when the alternator output current alternator becomes 10 A or less.
14. If the voltage reading conforms to the value in the voltage regulation, then the voltage regulator is operating normally.  
If the voltage is not within the standard value, there is a malfunction of the voltage regulator or of the alternator.
15. After the test, lower the engine speed to the idle speed.
16. Turn the ignition switch off.
17. Remove the tachometer or the MUT-II.
18. Disconnect the negative battery cable.
19. Disconnect the ammeter and voltmeter.
20. Connect the alternator output wire to the alternator "B" terminal.
21. Remove the special tool, and return the connector to the original condition.
22. Connect the negative battery cable.

**Voltage Regulation Table**

**Standard value:**

| Inspection terminal | Voltage regulator ambient temperature °C | Voltage V |
|---------------------|--|-----------|
| Terminal "S"        | -20                                      | 14.2–15.4 |
|                     | 20                                       | 13.9–14.9 |
|                     | 60                                       | 13.4–14.6 |
|                     | 80                                       | 13.1–14.5 |



**WAVEFORM CHECK USING AN ANALYZER**

16100120211


**MEASUREMENT METHOD**

Connect the analyzer special patterns pick-up to the alternator B terminal.


**STANDARD WAVEFORM**

**Observation Conditions**

| FUNCTION         | SPECIAL PATTERNS                   |
|------------------|------------------------------------|
| PATTERN HEIGHT   | VARIABLE                           |
| VARIABLE knob    | Adjust while viewing the waveform. |
| PATTERN SELECTOR | RASTER                             |
| Engine speed     | Curb idle speed                    |



7EL0115



**NOTE**






The voltage waveform of the alternator B terminal can undulate as shown at left. This waveform is produced when the regulator operates according to fluctuations in the alternator load (current), and is normal for the alternator.


In addition, when the voltage waveform reaches an excessively high value (approx. 2 V or higher at idle), it often indicates an open circuit due to a brown fuse between alternator B terminal and battery, but not a defective alternator.

EXAMPLES OF ABNORMAL WAVEFORMS

NOTE

1. The size of the waveform patterns differs largely, depending on the adjustment of the variable knob on the analyzer.
2. Identification of abnormal waveforms is easier when there is a large output current (regulator is not operating). (Waveforms can be observed when the headlamps are illuminated.)
3. Check the conditions of the charging warning lamp (illuminated/not illuminated). Also, check the charging system totally.

| Abnormal waveforms   | Problem cause  | Abnormal waveforms  | Problem cause  |
|--|--|---|--|
| <p>Example 1</p>  <p>A7EL0120</p>   | <ul style="list-style-type: none"> <li>• Open diode</li> </ul>                 | <p>Example 4</p>  <p>A7EL0123</p> | <ul style="list-style-type: none"> <li>• Short in stator coil</li> </ul>     |
| <p>Example 2</p>  <p>A7EL0121</p>   | <ul style="list-style-type: none"> <li>• Short in diode</li> </ul>             | <p>Example 5</p>  <p>A7EL0124</p> | <ul style="list-style-type: none"> <li>• Open supplementary diode</li> </ul> |
| <p>Example 3</p>  <p>A7EL0122</p> | <ul style="list-style-type: none"> <li>• Broken wire in stator coil</li> </ul> | <p>At this time, the charging warning lamp is illuminated.</p>  |  |



ALTERNATOR RELAY CONTINUITY CHECK

16100190045

1. Remove the alternator relay from the relay box inside the engine compartment.
2. Set the analogue-type circuit tester to the  $\Omega$  range and check that there is continuity when the (+) terminal of the tester is connected to terminal 2 of the alternator relay and the (-) terminal is connected to terminal 4.
3. Next, check that there is no continuity when the (+) terminal is connected to terminal 4 and the (-) terminal is connected to terminal 2.
4. If the continuity checks in steps 2 and 3 show a defect, replace the alternator relay.

## ALTERNATOR


16100140439

## REMOVAL AND INSTALLATION


**Pre-removal and Post-installation Operation**

- Engine Cover Removal and Installation <GDI>
- Under Cover Removal and Installation
- Drive Belt Tension Adjustment <after installation only> (Refer to GROUP 11 – On-vehicle Service.)

&lt;GDI&gt;




&lt;MPI&gt;

**Removal steps**

1. Drive belt (Power steering and A/C)
2. Drive belt (Alternator)
3. Water pump pulley <MPI>
4. Alternator connector
5. Alternator
6. Alternator brace

DISASSEMBLY AND REASSEMBLY <GDI>

16100160213



6EN1621

**Disassembly steps**




1. Front bracket assembly
2. Alternator pulley
3. Rotor
4. Rear bearing
5. Bearing retainer
6. Front bearing
7. Front bracket



8. Stator
9. Plate
10. Regulator assembly
11. Brush
12. Slinger
13. Rectifier
14. Rear bracket




**DISASSEMBLY SERVICE POINTS****◀A▶ FRONT BRACKET ASSEMBLY REMOVAL**

Insert a flat tip screwdriver, etc., in the clearance between the front bracket assembly and stator core, to pry open and separate the stator and front bracket.

**Caution**


The stator coil could be damaged so do not insert the screwdriver too far.

**◀B▶ ALTERNATOR PULLEY REMOVAL**

Face the pulley side upward, fix the rotor with a work bench and remove the pulley.

**Caution**


Use care so that the rotor is not damaged.

**◀C▶ STATOR/REGULATOR ASSEMBLY REMOVAL**

1. Use a soldering iron (180 to 250 W) to unsolder the stator. This work should complete within approximately four seconds to prevent heat from transferring to the diode.
2. When removing the rectifier from the regulator assembly, remove the soldered sections of the rectifier.

**Caution**


- (1) Use care to make sure that the heat of the soldering iron is not transmitted to the diodes for a long period.
- (2) Use care that no undue force is exerted to the lead wires of the diodes.

**REASSEMBLY SERVICE POINTS****►A◄ REGULATOR ASSEMBLY INSTALLATION**


After installing the regulator assembly, insert a wire into the hole provided on the rear bracket while pressing in the brush to fix the brush.

**NOTE**

The brush is fixed when a wire is inserted, making rotor installation easier.

**►B◄ ROTOR INSTALLATION**

After installing the rotor, remove the wire used to fix the brush.


**INSPECTION**

16100170216



**ROTOR CHECK**

1. Check the continuity between the rotor coil slip rings, and replace the rotor if the resistance value is not at the standard value.

**Standard value: 2 – 5 Ω**




2. Check the continuity between the slip ring and core, and if there is continuity, replace the rotor.




### STATOR CHECK

1. Check the continuity between the coil leads, and if there is continuity, replace the stator.
2. Check the continuity between the coil and core, and if there is continuity, replace the stator.




### RECTIFIER CHECK


1. Inspect the (+) heat sink by checking the continuity between the (+) heat sink and stator coil lead wire connection terminal using a tester probe.  
If there is a continuity at both, the diode is short circuited, so replace the rectifier.



2. Inspect the (-) heat sink by checking the continuity between the (-) heat sink and stator coil lead wire connection terminal using a tester probe.  
If there is a continuity at both, the diode is short circuited, so replace the rectifier.




3. Check the diode trio by connecting an ohmmeter to both ends of each diode and check the continuity of the three diodes.  
If there is a continuity at both ends, or if there is no continuity, the diode is damaged so replace the rectifier.

**BRUSH CHECK**

1. Measure the length of the brush protrusion shown in the illustration, and replace the brush if the measured value is below the limit value.


**Limit: 2 mm or less**



2. The brush can be removed if the solder of the brush lead wire is removed.
3. When installing a new brush, insert the brush into the holder as shown in the illustration, and then solder the lead wires.

DISASSEMBLY AND REASSEMBLY <MPI>

16100160084




9EN0598

**Disassembly steps**

1. Rear end cover
2. Brush holder assembly
3. Stator and rectifier assembly
4. Bearing cover
5. Alternator pulley
6. Space collar


7. Rotor assembly
8. Rear bearing
9. Bearing retainer
10. Front bearing
11. Front bracket




**DISASSEMBLY SERVICE POINT**

**◀A▶ ALTERNATOR PULLEY REMOVAL**

1. Clamp the front bracket in a vise with soft jaws.
2. Use the special tool and a box wrench to hold the nut. Then attach a double hexagonal wrench to the rotor shaft and loosen the nut.

**REASSEMBLY SERVICE POINT****▶◀ ALTERNATOR PULLEY INSTALLATION**


1. Clamp the front bracket in a vise with soft jaws.
2. Use the special tool and a box wrench to hold the nut. Then attach a double hexagonal wrench to the rotor shaft and tighten the nut.

**INSPECTION**


16100170087

**ROTOR**


1. Check field coil for continuity. Check to ensure that there is continuity between slip rings. If resistance is extremely small, it means that there is a short. If there is no continuity or if there is short circuit, replace rotor assembly.

**Resistance value: Approx. 2.6 Ω**


2. Check field coil for grounding. Check to ensure that there is no continuity between slip ring and core. If there is continuity, replace rotor assembly.

**STATOR**

1. Carry out a continuity test for the stator coil. Check that there is continuity between coil leads (A)–(B), (C)–(D) and (E)–(F). If there is no continuity, replace the stator and rectifier assembly.
2. Check the earth connection of the stator coil. Check that there is no continuity between each coil lead and the core. If there is continuity, replace the stator and rectifier assembly.

**RECTIFIERS**

1. Check the continuity between terminal (B) and coil leads (A), (C) and (E). If there is continuity in both directions, there is a short-circuit in the diode, so replace the stator and rectifier assembly.
2. Check the continuity between coil leads (B), (D) and (F) and the earth. If there is continuity in both directions, there is a short-circuit in the diode, so replace the stator and rectifier assembly.

**BRUSH**

If the brush has been worn down to the centre of the mark (3 mm from the centre of the brush holder), replace the brush holder assembly.

# STARTING SYSTEM

16200010290

## GENERAL INFORMATION

If the ignition switch is turned to the "START" position, current flows in the pull-in and holding coils provided inside magnetic switch, attracting the plunger. When the plunger is attracted, the lever connected to the plunger is actuated to engage the starter clutch.


On the other hand, attracting the plunger will turn on the magnetic switch, allowing the B terminal and

M terminal to conduct. Thus, current flows to engage the starter motor.

When the ignition switch is returned to the "ON" position after starting the engine, the starter clutch is disengaged from the ring gear.

An overrunning clutch is provided between the pinion and the armature shaft, to prevent damage to the starter.

## SYSTEM DIAGRAM



6EN0939

## STARTER MOTOR SPECIFICATIONS

| Items               | GDI                                 | MPI                                 |
|---------------------|-------------------------------------|-------------------------------------|
| Type                | Reduction drive with planetary gear | Reduction drive with planetary gear |
| Rated output kW/V   | 1.2/12                              | 0.9/12                              |
| No. of pinion teeth | 8                                   | 8                                   |



## SERVICE SPECIFICATIONS


16200030173

## GDI

| Items                        | Standard value | Limit |
|------------------------------|----------------|-------|
| Pinion gap mm                | 0.5 – 2.0      | –     |
| Commutator outer diameter mm | 29.4           | 28.4  |
| Commutator runout mm         | 0.05           | 0.1   |
| Commutator undercut mm       | 0.5            | 0.2   |

## MPI

| Items           | Standard value | Limit |
|-----------------|----------------|-------|
| Brush length mm | –              | 11    |



## STARTER MOTOR

16200110242


## INSPECTION

## PINION GAP ADJUSTMENT &lt;GDI&gt;

1. Disconnect field coil wire from M-terminal of magnetic switch.
2. Connect a 12V battery between S-terminal and M-terminal.
3. Set switch to "ON", and pinion will move out.


**Caution**

**This test must be performed quickly (in less than 10 seconds) to prevent coil from burning.**




4. Check pinion to stopper clearance (pinion gap) with a thickness gauge.

**Pinion gap: 0.5 – 2.0 mm**



5. If pinion gap is out of specification, adjust by adding or removing gaskets between magnetic switch and front bracket.





**MAGNETIC SWITCH PULL-IN TEST**

1. Disconnect field coil wire from M-terminal of magnetic switch.
2. Connect a 12V battery between S-terminal and M-terminal.

**Caution**

**This test must be performed quickly (in less than 10 seconds) to prevent coil from burning.**

3. If pinion moves out, then pull-in coil is good. If it doesn't, replace magnetic switch.




**MAGNETIC SWITCH HOLD-IN TEST**





1. Disconnect field coil wire from M-terminal of magnetic switch.
2. Connect a 12V battery between S-terminal and body.

**Caution**

**This test must be performed quickly (in less than 10 seconds) to prevent coil from burning.**

3. Manually pull out the pinion as far as the pinion stopper position.
4. If pinion remains out, everything is in order. If pinion moves in, hold-in circuit is open. Replace magnetic switch.





**FREE RUNNING TEST**

1. Place starter motor in a vise equipped with soft jaws and connect a fully-charged 12-volt battery to starter motor as follows:
2. Connect a test ammeter (100-ampere scale) and carbon pile rheostat in series with battery positive post and starter motor terminal.
3. Connect a voltmeter (15-volt scale) across starter motor.
4. Rotate carbon pile to full-resistance position.
5. Connect battery cable from battery negative post to starter motor body.
6. Adjust the rheostat until the battery voltage shown by the voltmeter is 11 V.
7. Confirm that the maximum amperage is within the specifications and that the starter motor turns smoothly and freely.

**Current:**

**max. 50 Amps <GDI>**

**max. 40 Amps <MPI>**

**MAGNETIC SWITCH RETURN TEST**

1. Disconnect field coil wire from M-terminal of magnetic switch.
2. Connect a 12V battery between M-terminal and body.

**Caution**

**This test must be performed quickly (in less than 10 seconds) to prevent coil from burning.**


3. Pull pinion out and release. If pinion quickly returns to its original position, everything is in order. If it doesn't, replace magnetic switch.

**Caution**

**Be careful not to get your fingers caught when pulling out the pinion.**

DISASSEMBLY AND REASSEMBLY <GDI>


16200120269



6EN1620

Disassembly steps

- |                                  |   |                               |  |
|----------------------------------|---|-------------------------------|--|
| <p>◀A▶</p> <p>◀B▶</p> <p>◀B▶</p> | <p>1. Screw</p> <p>2. Magnetic switch</p> <p>3. Screw</p> <p>4. Through bolt</p> <p>5. Rear bracket</p> <p>6. Brush holder</p> <p>7. Brush</p> <p>8. Rear bearing</p> <p>9. Armature</p> <p>10. Yoke assembly</p> <p>11. Ball</p> | <p>◀C▶ ▶A▶</p> <p>▶A▶ ▶C▶</p> | <p>12. Packing A</p> <p>13. Packing B</p> <p>14. Plate</p> <p>15. Planetary gear</p> <p>16. Lever</p> <p>17. Snap ring</p> <p>18. Stop ring</p> <p>19. Overrunning clutch</p> <p>20. Internal gear</p> <p>21. Planetary gear holder</p> <p>22. Front bracket</p> |
|----------------------------------|---|-------------------------------|--|




## DISASSEMBLY SERVICE POINTS

### ◀A▶ MAGNETIC SWITCH REMOVAL

Disconnect the field coil wire from terminal M of the magnetic switch.


### ◀B▶ ARMATURE AND BALL REMOVAL

When removing the armature, do not lose the ball placed at the end as a bearing.




### ◀C▶ SNAP RING/STOP RING REMOVAL

1. Using an appropriate wrench socket, push the stop ring toward the overrunning clutch.
2. Remove the snap ring with snap ring pliers and then remove the stop ring and overrunning clutch.




## STARTER MOTOR PARTS CLEANING

1. Do not immerse the parts in cleaning solvent. Immersing the yoke and field coil assembly and/or armature will damage insulation. Wipe these parts with a cloth only.
2. Do not immerse the drive unit in cleaning solvent. The overrunning clutch is pre-lubricated at the factory and solvent will wash lubrication from clutch.
3. The drive unit may be cleaned with a brush moistened with cleaning solvent and wiped dry with a cloth.

**REASSEMBLY SERVICE POINTS****▶◀ STOP RING/SNAP RING INSTALLATION**

Using an appropriate tool, pull the stop ring over the snap ring.

**INSPECTION**


16200130255

**COMMUTATOR**

1. Place the armature in a pair of "V" blocks and check the runout with a dial indicator.

**Standard value: 0.05 mm**

**Limit: 0.1 mm**



2. Measure the commutator outer diameter.

**Direct drive type and planetary gear reduction drive type (for diesel engine)**


**Standard value: 32.0 mm**

**Limit: 31.0 mm**

**Planetary gear reduction drive type (for petrol engine)**

**Standard value: 29.4 mm**


**Limit: 28.4 mm**




3. Check the undercut depth between segments.

**Standard value: 0.5 mm**

**Limit: 0.2 mm**

**OVERRUNING CLUTCH**


1. Check that the pinion locks when it is turned counterclockwise and moves smoothly when it is turned clockwise.
2. Check the pinion for wear or damage.

**BRUSH**

1. Check the brush for roughness of the surface that contacts the commutator and check the brush length.

**Limit: Wear limit line**


2. In case the contacting surface has been corrected or the brush has been replaced, correct the contacting surface by winding sandpaper around the commutator.

**ARMATURE COIL SHORT-CIRCUIT TEST**


1. Place armature in a growler.
2. Hold a thin steel blade parallel and just above while rotating armature slowly in growler. A shorted armature will cause blade to vibrate and be attracted to the core. Replace shorted armature.

**Caution**

**Clean the armature surface thoroughly before checking.**




3. Check the insulation between each commutator segment and armature coil core.  
If there is no continuity, the insulation is in order.

**ARMATURE COIL OPEN-CIRCUIT INSPECTION**

Check the continuity between segments. If there is continuity, the coil is in order.

DISASSEMBLY AND REASSEMBLY <MPI>

16200120115





9EN0593

**Disassembly steps**

- |                  |                        |
|------------------|------------------------|
| 1. Rear cover    | 11. Magnetic switch    |
| 2. Rubber        | 12. Spring             |
| 3. Cover         | 13. Pin                |
| 4. Brush spring  | 14. Plunger            |
| 5. Plate         | 15. Lever              |
| 6. Brush         | 16. Snap ring          |
| 7. Brush holder  | 17. Stop ring          |
| 8. Packing       | 18. Overrunning clutch |
| 9. Front bracket | 19. Motor assembly     |
| 10. Bushing      |                        |








## DISASSEMBLY SERVICE POINTS

### ◀A▶ SNAP RING/STOP RING REMOVAL

1. Press stop ring off snap ring with a suitable socket.
2. Remove snap ring with snap ring pliers and then remove stop ring and overrunning clutch.

## STARTER MOTOR PARTS CLEANING


1. Do not immerse parts in cleaning solvent. Immersing the motor assembly will damage insulation. Wipe motor assembly with a cloth only.
2. Do not immerse drive unit in cleaning solvent. Overrunning clutch is pre-lubricated at the factory and solvent will wash lubrication from clutch.
3. The drive unit may be cleaned with a brush moistened with cleaning solvent and wiped dry with a cloth.



## REASSEMBLY SERVICE POINTS

### ▶A◀ STOP RING/SNAP RING INSTALLATION

Using a suitable pulling tool, pull overrunning clutch stop ring over snap ring.




## INSPECTION

16200130118

### OVERRUNNING CLUTCH

1. While holding clutch housing, rotate the pinion. Drive pinion should rotate smoothly in one direction, but should not rotate in opposite direction. If clutch does not function properly, replace overrunning clutch assembly.
2. Inspect pinion for wear or burrs. If pinion is worn or burred, replace overrunning clutch assembly. If pinion is damaged, also inspect ring gear for wear or burrs.



### BRUSH

1. Check the brush length.

**Limit: 11 mm**

# IGNITION SYSTEM

16300010118

## GENERAL INFORMATION

### <GDI>


This system is equipped with four ignition coils with built-in power transistors for each of the cylinders. Interruption of the primary current flowing in the primary side of an ignition coil generates a high voltage in the secondary side of the ignition coil. The high voltage thus generated is applied to the spark plugs to generate sparks.

The engine-ECU turns the power transistors inside the ignition coils alternately on and off. This causes the primary currents in the ignition coils to be alternately interrupted and allowed to flow to fire the cylinders in the order 1 – 3 – 4 – 2.

The engine-ECU determines which ignition coil should be controlled by means of the signals from the camshaft position sensor and the crank angle sensor. It also detects the crankshaft position, in order to provide ignition at the most appropriate timing in response to the engine operation conditions.

When the engine is cold or running at high altitudes, the ignition timing is slightly advanced to provide optimum performance. Furthermore, if knocking occurs, the ignition timing is gradually retarded until knocking ceases.

## SYSTEM DIAGRAM



<MPI>

Interruption of the primary current flowing in the primary side of the ignition coil generates high voltage in the secondary side of the ignition coil. The high voltage thus generated is directed by the distributor to the applicable spark plug. The engine firing order is 1-3-4-2 cylinders.

On application of high voltage, the spark plug generates a spark to ignite the compressed air fuel mixture in the combustion chamber.

The engine-ECU makes and breaks the primary current of the ignition coil to regulate the ignition


timing.

The engine-ECU detects the crankshaft position by the crank angle sensor incorporated in the distributor to provide ignition at the most appropriate timing for the engine operating condition.

When the engine is cold or operated at a high altitude, the ignition timing is slightly advanced to provide optimum performance to the operating condition.

Furthermore, if knocking occurs, the ignition timing is gradually retarded until knocking ceases.

SYSTEM DIAGRAM



1FU1269

**DISTRIBUTOR SPECIFICATIONS <MPI>**

|                   |   |
|-------------------|---|
| Items             | Specifications                                |
| Type              | Contact pointless with built-in ignition coil |
| Advance mechanism | Electronic                                    |
| Firing order      | 1–3–4–2                                       |

**IGNITION COIL SPECIFICATIONS**

|       |               |  |
|-------|---------------|--|
| Items | GDI           | MPI  |
| Type  | Molded 4-coil | Molded single-coil with a built-in distributor |

**SPARK PLUG SPECIFICATIONS**

|          |        |           |
|----------|--------|-----------|
| Items    | GDI    | MPI       |
| NGK      | IZFR6B | BKR5E-11  |
| DENSO    | –      | K16PR-U11 |
| CHAMPION | –      | –         |

**SERVICE SPECIFICATIONS**

16300030121

**IGNITION COIL <MPI>**

|                                     |                |       |
|-------------------------------------|----------------|-------|
| Items                               | Standard value | Limit |
| Primary coil resistance $\Omega$    | 0.5 – 0.7      | –     |
| Secondary coil resistance $k\Omega$ | 15 – 22        | –     |

**SPARK PLUG**



|  |                |           |
|--|----------------|-----------|
| Items  | Standard value | Limit     |
| Spark plug gap mm                                    | GDI            | 0.5 – 0.6 |
|  | MPI            | 1.0 – 1.1 |
| Spark plug gap insulation resistance $M\Omega$ <GDI> | –              | 1         |


**RESISTIVE CORD <MPI>**

|                      |                |         |
|----------------------|----------------|---------|
| Items                | Standard value | Limit   |
| Resistance $k\Omega$ | –              | max. 22 |

## SPECIAL TOOLS

16300060070

| Tool  | Number   | Name                 | Use  |
|---|----------|----------------------|--|
|  | MB991348 | Test harness set     | Inspection of ignition primary voltage (power transistor connection) |
|  | MD998770 | Oxygen sensor wrench | Detonation sensor removal and installation                           |



## ON-VEHICLE SERVICE

16300120149


## IGNITION COIL CHECK &lt;MPI&gt;

1. Measurement of the primary coil resistance  
Measure the resistance between connector terminal 1 and 2 of the distributor.

**Standard value: 0.5 – 0.7  $\Omega$**

2. Measurement of secondary coil resistance  
Measure the resistance between the high-voltage terminals and connector terminals 1.

**Standard value: 15 – 22 k $\Omega$**



**POWER TRANSISTOR CONTINUITY CHECK**

**<MPI>**

16300130104


1. An analogue-type circuit tester should be used.
2. Connect the negative (-) probe of the circuit tester to terminal 2.

**Caution**

**This test must be performed quickly (in less than 10 seconds) to prevent coil from burning and power transistor from breakage.**

| Voltage: 1.5V               | Terminal No. |   |   |
|-----------------------------|--------------|---|---|
|                             | 2            | 3 | 4 |
| When current is flowing     | ○            | ⊕ | ⊖ |
| When current is not flowing |              |   |   |

Replace the power transistor if there is a malfunction.



**IGNITION COIL (WITH BUILT-IN POWER TRANSISTOR) CHECK <GDI>**

16300120156

**PRIMARY COIL AND POWER TRANSISTOR CONTINUITY CHECK**

1. An analogue-type circuit tester should be used.
2. Connect the negative (-) probe of the circuit tester to terminal 1.

**Caution**

**This test must be performed quickly (in less than 10 seconds) to prevent coil from burning and power transistor from breakage.**

| Voltage: 1.5V               | Terminal No. |   |   |
|-----------------------------|--------------|---|---|
|                             | 1            | 2 | 3 |
| When current is flowing     | ○            | ⊖ | ⊕ |
| When current is not flowing |              |   |   |


**SECONDARY COIL CHECK**

Resistance check, etc. can not be used to check the secondary coil of this ignition coil because a diode is built-in in the secondary coil circuit. Because of this, check the secondary coil by the following procedure.

1. Disconnect the ignition coil connector.
2. Remove the ignition coil, and then install a new spark plug to the ignition coil.
3. Connect the ignition coil connector.

4. Connect the spark plug outer electrode to earth, and then crank the engine.
5. Check if the spark plug sparks.
6. If the spark plug does not spark, replace the ignition coil with a new one and recheck.
7. If the spark plug sparks when the new ignition coil is used, the ignition coil to be checked is defective. Replace the ignition coil.

If the spark plug does not spark when the new ignition coil is used, the ignition circuit may be defective. Check the ignition circuit.



### RESISTIVE CORD CHECK <MPI>

16300140039

Measure the resistance of the all spark plug cables.

1. Check cap and coating for cracks.
2. Measure resistance.

**Limit: Max. 22 k $\Omega$**

### SPARK PLUG CHECK AND CLEANING

16300150056

<GDI>


#### Caution

1. The spark plug gap for iridium plugs should not be adjusted.
2. Cleaning iridium plugs may result in damage to the iridium tip. Therefore, if cleaning is necessary because the plug is sooty, use a plug cleaner, and do not clean the plug for more than 20 seconds in order to preserve the electrodes. A wire brush should never be used.
3. The spark plugs in GDI engines are special iridium plugs in which the electrodes can become black even when the plugs are working normally. Carbon which may become deposited on these plugs burns off more readily than with conventional plugs, and so should not cause any problems with spark plug performance. Judgement of whether a spark plug is operating normally or not should be made by checking the insulation resistance.
  1. Remove the ignition coils.
  2. Remove the spark plugs.
  3. Check the spark plug gap. Replace the spark plug if the gap exceeds the limit.

**Limit: 0.75 mm**

**Standard value: 0.5 – 0.6 mm**





4. Measure the spark plug insulation resistance. Replace the spark plug if the measured value is lower than the limit value.

**Limit: 1 MΩ**

5. Clean the spark plug holes.
6. Install the spark plugs.
7. Install the ignition coils.

#### <MPI>

1. Remove the spark plug cables.

#### Caution

**When pulling off the spark plug cable from the plug always hold the cable cap, not the cable.**

2. Remove the spark plugs.
3. Check for burned out electrode or damaged insulator. Check for even burning.
4. Remove carbon deposits with wire brush or plug cleaner. Remove sand from plug screw with compressed air.
5. Use a plug gap gauge to check that the plug gap is within the standard value range.

**Standard value: 1.0 – 1.1 mm**


If the plug gap is not within the standard value range, adjust by bending the earth electrode.

6. Clean the engine plug holes.

#### Caution

**Be careful not to allow foreign matter in cylinders.**

7. Install the spark plugs.



#### CRANK ANGLE SENSOR CHECK <MPI> 16300260223

Refer to GROUP 13B – Troubleshooting.

#### CRANK ANGLE SENSOR, CAMSHAFT POSITION SENSOR CHECK <GDI> 16300260223

Refer to GROUP 13A – Troubleshooting.

#### DETONATION SENSOR CHECK 16300180062

Check the detonation sensor circuit if self-diagnosis code, No. 31 is shown.

#### NOTE

For information concerning the self-diagnosis codes, after to GROUP 13A – Troubleshooting <GDI> or GROUP 13B – Troubleshooting <MPI>.

**WAVEFORM CHECK USING AN ANALYZER**  
**<MPI>**

16300170199


**Ignition Secondary Voltage Check**  
**MEASUREMENT METHOD**

1. Clamp the spark plug cable of the No. 1 cylinder with the secondary pickup and check the waveform.
2. Connect the secondary pickup to the other cylinders in turn and check the waveforms for each cylinder.

**STANDARD WAVEFORM**

**Observation Conditions**

|                  |                 |
|------------------|-----------------|
| FUNCTION         | SECONDARY       |
| PATTERN HEIGHT   | HIGH (or LOW)   |
| PATTERN SELECTOR | RASTER          |
| Engine Speed     | Curb idle speed |



7EL0128

**WAVEFORM OBSERVATION POINTS**

Point A: The height, length and slope of the spark line show the following trends (Refer to abnormal waveform examples, 1, 2, 3 and 4).

| Spark line |       | Plug gap | Condition of electrode | Compression force | Concentration of air mixture | Ignition timing | Spark plug cable |
|------------|-------|----------|------------------------|-------------------|------------------------------|-----------------|------------------|
| Length     | Long  | Small    | Normal                 | Low               | Rich                         | Advanced        | Leak             |
|            | Short | Large    | Large wear             | High              | Lean                         | Retarded        | High resistance  |
| Height     | High  | Large    | Large wear             | High              | Lean                         | Retarded        | High resistance  |
|            | Low   | Small    | Normal                 | Low               | Rich                         | Advanced        | Leak             |
| Slope      |       | Large    | Plug is fouled         | –                 | –                            | –               | –                |

Point B: Number of vibration in reduction vibration section (Refer to abnormal waveform example 5)

|                      |                    |
|----------------------|--------------------|
| Number of vibrations | Coil and condenser |
| Three or more        | Normal             |
| Except above         | Abnormal           |






Point C: Number of vibrations at beginning of dwell section (Refer to abnormal waveform example 5)

|                      |          |
|----------------------|----------|
| Number of vibrations | Coil     |
| 5–6 or higher        | Normal   |
| Except above         | Abnormal |

Point D: Ignition voltage height (distribution per each cylinder) shows the following trends.


| Ignition voltage | Plug gap | Condition of electrode | Compression force | Concentration of air mixture | Ignition timing | Spark plug cable |
|------------------|----------|------------------------|-------------------|------------------------------|-----------------|------------------|
| High             | Large    | Large wear             | High              | Lean                         | Retarded        | High resistance  |
| Low              | Small    | Normal                 | Low               | Rich                         | Advanced        | Leak             |

EXAMPLES OF ABNORMAL WAVEFORMS

| Abnormal waveform   | Wave characteristics  | Cause of problem   |
|---|---|--|
| <p>Example 1</p>  <p>01P0215</p>   | <p>Spark line is high and short.</p>  | <p>Spark plug gap is too large.</p>                                      |
| <p>Example 2</p>  <p>01P0216</p>   | <p>Spark line is low and long, and is sloping. Also, the second half of the spark line is distorted. This could be a result of misfiring.</p> | <p>Spark plug gap is too small.</p>                                      |
| <p>Example 3</p>  <p>01P0217</p> | <p>Spark line is low and long, and is sloping. However, there is almost no spark line distortion.</p>   | <p>Spark plug gap is fouled.</p>   |
| <p>Example 4</p>  <p>01P0218</p> | <p>Spark line is high and short. Difficult to distinguish between this and abnormal waveform example 1.</p>                                   | <p>Spark plug cable is nearly falling off. (Causing a dual ignition)</p> |
| <p>Example 5</p>  <p>01P0219</p> | <p>No waves in wave damping section.</p>  | <p>Layer short in ignition coil</p>                                      |

**Ignition Primary Voltage Waveform Check****MEASUREMENT METHOD**

1. Disconnect the distributor connector and connect the special tool (test harness: MB991348) in between. (All of the terminals should be connected.)



2. Connect the analyzer primary pickup to the distributor connector terminal 2.
3. Connect the primary pickup earth terminal.
4. Clamp the spark plug cable with the trigger pickup.


**NOTE**

The waveform of the cylinder clamped to the trigger pickup will appear at the left edge of the screen.

**STANDARD WAVEFORM**

**Observation conditions**

|                  |                 |
|------------------|-----------------|
| FUNCTION         | SECONDARY       |
| PATTERN HEIGHT   | HIGH (or LOW)   |
| PATTERN SELECTOR | RASTER          |
| Engine Speed     | Curb idle speed |




7EL0132

**Observation conditions**

(Only the pattern selector shown below changes from the previous conditions)

|                  |         |
|------------------|---------|
| PATTERN SELECTOR | DISPLAY |
|------------------|---------|



9EL0006

**WAVEFORM OBSERVATION POINTS**

Point A: The height, length and slope of the spark line (refer to abnormal waveform examples 1, 2, 3 and 4) show the following trends.

| Spark line |       | Plug gap | Condition of electrode | Compression force | Concentration of air mixture | Ignition timing | High tension cable |
|------------|-------|----------|------------------------|-------------------|------------------------------|-----------------|--------------------|
| Length     | Long  | Small    | Normal                 | Low               | Rich                         | Advanced        | Leak               |
|            | Short | Large    | Large wear             | High              | Lean                         | Retarded        | High resistance    |
| Height     | High  | Large    | Large wear             | High              | Lean                         | Retarded        | High resistance    |
|            | Low   | Small    | Normal                 | Low               | Rich                         | Advanced        | Leak               |
| Slope      |       | Large    | Plug is fouled         | –                 | –                            | –               | –                  |






Point B: Number of vibration in reduction vibration section  
(Refer to abnormal waveform example 5)

|                      |                 |
|----------------------|-----------------|
| Number of vibrations | Coil, condenser |
| 3 or higher          | Normal          |
| Except above         | Abnormal        |

Point C: Height of Zener voltage

|                         |   |
|-------------------------|---|
| Height of Zener voltage | Probable cause                              |
| High                    | Problem in Zener diode                      |
| Low                     | Abnormal resistance in primary coil circuit |

EXAMPLES OF ABNORMAL WAVEFORMS


| Abnormal waveform   | Wave characteristics  | Cause of problem   |
|---|---|--|
| <p>Example 1</p>  <p>01P0210</p>   | <p>Spark line is high and short.</p>  | <p>Spark plug gap is too large.</p>                                      |
| <p>Example 2</p>  <p>01P0211</p>   | <p>Spark line is low and long, and is sloping. Also, the second half of the spark line is distorted. This could be a result of misfiring.</p> | <p>Spark plug gap is too small.</p>                                      |
| <p>Example 3</p>  <p>01P0212</p>  | <p>Spark line is low and long, and is sloping. However, there is almost no spark line distortion.</p>   | <p>Spark plug gap is fouled.</p>   |
| <p>Example 4</p>  <p>01P0213</p> | <p>Spark line is high and short.</p>  | <p>Spark plug cable is nearly falling off. (Causing a dual ignition)</p> |
| <p>Example 5</p>  <p>01P0214</p> | <p>No waves in wave damping section</p>   | <p>Layer short in ignition coil</p>                                      |



# IGNITION COIL <GDI>

## REMOVAL AND INSTALLATION


Pre-removal and Post-installation Operation  
 Engine Cover Removal and Installation



### Removal steps

1. Ignition coil assembly
2. Spark plug

# CAMSHAFT POSITION SENSOR <GDI>




**CRANK ANGLE SENSOR <GDI>**

16300250121

**REMOVAL AND INSTALLATION****Pre-removal and Post-installation Operation**

- Timing Belt Front Lower Cover Removal and Installation (Refer to GROUP 11A – Timing Belt.)



**DISTRIBUTOR <MPI>**

16300200256


**REMOVAL AND INSTALLATION**

**Pre-removal Operation**

- Air Cleaner Removal

**Post-installation Operation**


- Air Cleaner Installation
- Ignition Timing Check and Adjustment  
(Refer to GROUP 11B – On-vehicle Service.)



A16M0206

**Removal steps**

1. Spark plug cable connection
2. Distributor connector
3. Distributor



A1EN0435


**INSTALLATION SERVICE POINT**

**▶A◀ DISTRIBUTOR INSTALLATION**

1. Remove the timing belt upper cover.
2. Turn the crankshaft clockwise to align the timing marks.

**NOTE**

The No.1 cylinder will be at compression top dead centre if the timing mark on the camshaft sprocket is aligned with the timing mark on the cylinder head.



Mating marks


16S0278

16S0276  
00004498

3. Align the mating mark on the distributor housing side with the mating mark on the coupling side.
4. Install the distributor to the engine.

## DISASSEMBLY AND REASSEMBLY

16300220078



1EN0588

1. Distributor cap
2. Rotor
3. Cover
4. O-ring
5. Distributor housing

**INSPECTION**

16300230040

Check the following points; repair or replace if a problem is found.

**CAP, ROTOR**


1. There must be no cracking in the cap.
2. There must be no damage to the cap's electrode or the rotor's electrode.
3. Clean away any dirt from the cap and rotor.

# DETONATION SENSOR

16300280229

## REMOVAL AND INSTALLATION

- Pre-removal and Post-installation Operation**
- Engine Cover Removal and Installation <GDI>
  - Air Cleaner Removal and Installation <GDI>



**Removal steps**


1. Surging resonator mounting bolt
2. Harness connector clamp (for oxygen sensor)
3. Intake manifold stay



4. Detonation sensor

**Caution**

Do not subject the detonation sensor to any shocks.



**REMOVAL SERVICE POINT**

◀A▶ DETONATION SENSOR REMOVAL

# ENGINE ELECTRICAL

## CONTENTS

|  |           |   |           |
|--|-----------|---|-----------|
| <b>CHARGING SYSTEM</b> .....                   | <b>2</b>  | Waveform Check Using an Analyzer .....      | 11        |
| <b>GENERAL</b> .....                           | <b>2</b>  | <b>IGNITION COIL &lt;4G93-GDI&gt;</b> ..... | <b>15</b> |
| Outline of Change .....                        | 2         | <b>IGNITION COIL &lt;4G13-MPI&gt;</b> ..... | <b>16</b> |
| <b>GENERAL INFORMATION</b> .....               | <b>2</b>  | <b>CAMSHAFT POSITION SENSOR</b>             |           |
| Alternator Specifications .....                | 2         | <4G13-MPI> .....                            | 17        |
| <b>SERVICE SPECIFICATIONS</b> .....            | <b>2</b>  | <b>CAMSHAFT POSITION SENSOR</b>             |           |
| <b>ON-VEHICLE SERVICE</b> .....                | <b>3</b>  | <F9Q1> .....                                | 18        |
| Alternator Output Line Voltage Drop Test ....  | 3         | <b>CRANK ANGLE SENSOR</b> .....             | <b>19</b> |
| Output Current Test .....                      | 4         | <b>DETONATION SENSOR</b> .....              | <b>20</b> |
| Regulated Voltage Test .....                   | 6         | <b>GLOW SYSTEM</b> .....                    | <b>21</b> |
| <b>ALTERNATOR &lt;F9Q1&gt;</b> .....           | <b>8</b>  | <b>GENERAL</b> .....                        | <b>21</b> |
| <b>IGNITION SYSTEM</b> .....                   | <b>9</b>  | Outline of Changes .....                    | 21        |
| <b>GENERAL</b> .....                           | <b>9</b>  | <b>GENERAL INFORMATION</b> .....            | <b>21</b> |
| Outline of Changes .....                       | 9         | <b>SERVICE SPECIFICATIONS</b> .....         | <b>22</b> |
| <b>GENERAL INFORMATION</b> .....               | <b>9</b>  | <b>ON-VEHICLE SERVICE</b> .....             | <b>22</b> |
| <b>SERVICE SPECIFICATIONS</b> .....            | <b>10</b> | Glow System Check .....                     | 22        |
| <b>ON-VEHICLE SERVICE</b> .....                | <b>10</b> | Glow Plug Check .....                       | 23        |
| Ignition Coil (with Built-in Power Transistor) |           | <b>GLOW PLUG</b> .....                      | <b>24</b> |
| Check .....                                    | 10        |   |           |
| Ignition Failure Sensor Check .....            | 11        |   |           |

# CHARGING SYSTEM

## GENERAL

### OUTLINE OF CHANGE

The service procedure for the alternator has been added to correspond to the addition of the diesel-powered vehicle.


## GENERAL INFORMATION

### ALTERNATOR SPECIFICATIONS

| Items             | Diesel engine without A/C | Diesel engine with A/C   |
|-------------------|---------------------------|--------------------------|
| Type              | Battery voltage sensing   | Battery voltage sensing  |
| Rated output V/A  | 12/80                     | 12/110                   |
| Voltage regulator | Electronic built-in type  | Electronic built-in type |

## SERVICE SPECIFICATIONS

| Items  |       | Standard value | Limit                        |
|--|-------|----------------|------------------------------|
| Alternator output line voltage drop (at 30A) V               |       | –              | Max. 0.3                     |
| Regulated voltage ambient temperature at voltage regulator V | –20°C | 14.7 – 15.3    | –                            |
|  | 20°C  | 14.4 – 14.7    | –                            |
|  | 60°C  | 13.9 – 14.4    | –                            |
|  | 80°C  | 13.7 – 14.2    | –                            |
| Output current   |       | –              | 70% of normal output current |

**ON-VEHICLE SERVICE <Diesel-powered vehicle>****ALTERNATOR OUTPUT LINE VOLTAGE DROP TEST**

5EL0015

This test determines whether the wiring from the alternator “B” terminal to the battery (+) terminal (including the fusible line) is in a good condition or not.

- (1) Always be sure to check the following before the test.
  - Alternator installation
  - Alternator drive belt tension (Refer to GROUP 11C – On-vehicle Service.)
  - Fusible link
  - Abnormal noise from the alternator while the engine is running
- (2) Turn the ignition switch off.
- (3) Disconnect the negative battery cable.
- (4) Disconnect the alternator output wire from the alternator “B” terminal and connect a DC test ammeter with a range of 0 – 100 A in series between the “B” terminal and the disconnected

output wire. (Connect the (+) lead of the ammeter to the “B” terminal, and then connect the (–) lead of the ammeter to the disconnected output wire.)

**NOTE**

An inductive-type ammeter which enables measurements to be taken without disconnecting the alternator output wire should be recommended. Using this equipment will lessen the possibility of a voltage drop caused by a loose “B” terminal connection.

- (5) Connect a digital-type voltmeter between the alternator “B” terminal and the battery (+) terminal. (Connect the (+) lead of the voltmeter to the “B” terminal and the connect the (–) lead of the voltmeter to the battery (+) cable.)



- (6) Connect a tachometer.
- (7) Reconnect the negative battery cable.
- (8) Leave the hood open.
- (9) Start the engine.
- (10) With the engine running at 2,500 r/min, turn the headlamps and other lamps on and off to adjust the alternator load so that the value displayed on the ammeter is slightly above 30 A.  
Adjust the engine speed by gradually decreasing it until the value displayed on the ammeter is 30 A. Take a reading of the value displayed on the voltmeter at this time.


**Limit: max. 0.3 V**

**NOTE**

When the alternator output is high and the value displayed on the ammeter does not decrease until 30 A, set the value to 40 A. Read the value displayed on the voltmeter at this time.

- (11) If the value displayed on the voltmeter is above the limit value, there is probably a malfunction in the alternator output wire, so check the wiring between the alternator "B" terminal and the battery (+) terminal (including fusible link). If a terminal is not sufficiently tight or if the harness has become discolored due to overheating, repair and then test again.
- (12) After the test, run the engine at idle.
- (13) Turn all lamps and the ignition at idle.
- (14) Disconnect the negative battery cable.
- (15) Disconnect the ammeter, voltmeter and tachometer.
- (16) Connect the alternator output wire to the alternator "B" terminal.
- (17) Connect the negative battery cable.

## OUTPUT CURRENT TEST



REN0141

This test determines whether the alternator output current is normal.

- (1) Before the test, always be sure to check the following.
  - Alternator installation
  - Battery (Refer to GROUP 54 – Battery.)

**NOTE**

The used battery should be slightly discharged. The load needed by a fully-charged battery is insufficient for an accurate test.

- Alternator drive belt tension (Refer to GROUP 11C – On-vehicle Service.)
- Fusible link
- Abnormal noise from the alternator while the engine is running.

- (2) Turn the ignition switch off.
- (3) Disconnect the negative battery cable.
- (4) Disconnect the alternator output wire from the alternator “B” terminal. Connect a DC test ammeter with a range of 0 – 100 A in series between the “B” terminal and the disconnected output wire. (Connect the (+) lead of the ammeter to the “B” terminal. Connect the (–) lead of the ammeter to the disconnected output wire.)

**Caution**

**Never use clips but tighten bolts and nuts to connect the line. Otherwise loose connections (e.g. using clips) will lead to a serious accident because of high current.**

**NOTE**

An inductive-type ammeter which enables measurements to be taken without disconnecting the alternator output wire should be recommended.

- (5) Connect a voltmeter with a range of 0 – 20 V between the alternator “B” terminal and the earth. (Connect the (+) lead of the voltmeter to the “B” terminal, and then connect the (–) lead of the voltmeter to the earth.)
- (6) Connect a tachometer.
- (7) Connect the negative battery cable.
- (8) Leave the hood open.
- (9) Check that the reading on the voltmeter is equal to the battery voltage.

**NOTE**

If the voltage is 0 V, the cause is probably an open circuit in the wire or fusible link between the alternator “B” terminal and the battery (+) terminal.


- (10) Turn the light switch on to turn on headlamps and then start the engine.
- (11) Immediately after setting the headlamps to high beam and turning the heater blower switch to the high revolution position, increase the engine speed to 2,500 r/min and read the maximum current output value displayed on the ammeter.

**Limit: 70 % of normal current output**

**NOTE**

- For the nominal current output, refer to the Alternator Specifications.
  - Because the current from the battery will soon drop after the engine is started, the above step should be carried out as quickly as possible in order to obtain the maximum current output value.
  - The current output value will depend on the electrical load and the temperature of the alternator body.
  - If the electrical load is small while testing, the specified level of current may not be output even though the alternator is normal. In such cases, increase the electrical load by leaving the headlamps turned on for some time to discharge the battery or by using the lighting system in another vehicle, and then test again.
  - The specified level of current also may not be output if the temperature of the alternator body or the ambient temperature is too high. In such cases, cool the alternator and then test again.
- (12) The reading on the ammeter should be above the limit value. If the reading is below the limit value and the alternator output wire is normal, remove the alternator from the engine and check the alternator.
  - (13) Run the engine at idle after the test.
  - (14) Turn the ignition switch off.
  - (15) Disconnect the negative battery cable.
  - (16) Disconnect the ammeter, voltmeter and tachometer.
  - (17) Connect the alternator output wire to the alternator “B” terminal.
  - (18) Connect the negative battery cable.

## REGULATED VOLTAGE TEST



REN0142

This test determines whether the voltage regulator is correctly controlling the alternator output voltage.

- (1) Always be sure to check the following before the test.
  - Alternator installation
  - Check that the battery installed in the vehicle is fully charged. (Refer to GROUP 54 – Battery.)
  - Alternator drive belt tension (Refer to GROUP 11C – On-vehicle Service.)
  - Fusible link
  - Abnormal noise from the alternator while the engine is running
- (2) Turn the ignition switch to the OFF position.
- (3) Disconnect the negative battery cable.
- (4) Connect a digital-type voltmeter between the alternator “L” terminal and the earth. (Connect the (+) lead of the voltmeter to the “L” terminal, and then connect the (–) lead of the voltmeter to a secure earth or to the battery (–) terminal.)
- (5) Disconnect the alternator output wire from the alternator “B” terminal.

- (6) Connect a DC test ammeter with a range of 0 – 100 A in series between the “B” terminal and the disconnected output wire. (Connect the (+) lead of the ammeter to the “B” terminal. Connect the (–) lead of the ammeter to the disconnected output wire.)
- (7) Connect a tachometer.
- (8) Reconnect the negative battery cable.
- (9) Turn the ignition switch to the ON position and check that the reading on the voltmeter is 2 – 5 V.

**NOTE**

If the voltage is 0 V, the cause is probably an open circuit in the wire or fusible link between the alternator “L” terminal and the battery (+) terminal.

- (10) Turn all lamps and accessories off.
- (11) Start the engine.
- (12) Increase the engine speed to 2,500 r/min.
- (13) Read the value displayed on the voltmeter when the alternator output current alternator becomes 10 A or less.

- (14) If the voltage reading conforms to the value in the voltage regulation, then the voltage regulator is operating normally.  
If the voltage is not within the standard value, there is a malfunction of the voltage regulator or of the alternator.
- (15) After the test, lower the engine speed to the idle speed.

- (16) Turn the ignition switch off.
- (17) Disconnect the negative battery cable.
- (18) Disconnect the ammeter, voltmeter and tachometer.
- (19) Connect the alternator output wire to the alternator "B" terminal.
- (20) Connect the negative battery cable.

**Voltage Regulation Table**

**Standard value:**


| Inspection terminal | Voltage regulator ambient temperature °C | Voltage V   |
|---------------------|--|-------------|
| Terminal "L"        | -20                                      | 14.7 – 15.3 |
|                     | 20                                       | 14.4 – 14.7 |
|                     | 60                                       | 13.9 – 14.4 |
|                     | 80                                       | 13.7 – 14.2 |

**ALTERNATOR <F9Q1>****REMOVAL AND INSTALLATION****Pre-removal Operation**

- Under Cover Removal
- Intercooler Air Hose Removal  
(Refer to GROUP 15 – Intercooler.)

**Post-installation Operation**

- Intercooler Air Hose Installation  
(Refer to GROUP 15 – Intercooler.)
- Under Cover Installation




AY0143AJ

**Removal steps**

1. Drive belt
  2. Idler pulley
- A/C Compressor mounting bolt

3. Alternator connector
4. Alternator



AY0144AJ

**REMOVAL SERVICE POINT****◀A▶ ALTERNATOR REMOVAL**

Put the A/C compressor aside so that enough space to remove the alternator can be secured.

# IGNITION SYSTEM

## GENERAL

### OUTLINE OF CHANGES

#### <4G93-GDI>

An ignition failure sensor has been added. Other service specifications are the same as before.


#### <4G13-MPI>

The following service specifications have been established. Other items are the same as before.

- A distributorless 2-coil ignition system has been adopted.
- The spark plugs have been changed.
- An ignition failure sensor has been added.

## GENERAL INFORMATION

### SYSTEM DIAGRAM <4G13-MPI>



### IGNITION COIL SPECIFICATIONS

|       |               |
|-------|---------------|
| Items | 4G13-MPI      |
| Type  | Molded 2-coil |

### SPARK PLUG SPECIFICATIONS

|       |           |
|-------|-----------|
| Items | 4G13-MPI  |
| NGK   | BKR6E-11  |
| DENSO | K20PR-U11 |



**SERVICE SPECIFICATIONS**

**IGNITION COIL**

|                              |            |
|------------------------------|------------|
| Items                        | 4G13-MPI   |
| Secondary coil resistance kΩ | 8.5 – 11.5 |

**IGNITION FAILURE SENSOR**

|              |                    |
|--------------|--------------------|
| Items        | 4G93-GDI, 4G13-MPI |
| Resistance Ω | 0.1 or less        |



**ON-VEHICLE SERVICE**

**IGNITION COIL (WITH BUILT-IN POWER TRANSISTOR) CHECK**

<4G13-MPI>

Check by the following procedure, and replace if there is a malfunction.

**SECONDARY COIL RESISTANCE CHECK**

Measure the resistance between the high-voltage terminals of the ignition coil.


**Standard value: 8.5 – 11.5 kΩ**

**PRIMARY COIL AND POWER TRANSISTOR CONTINUITY CHECK**

**NOTE**

An analog-type circuit tester should be used.

| Voltage: 1.5 V              | Terminal No. |       |   |
|-----------------------------|--------------|-------|---|
|                             | 1            | 2     | 3 |
| When current is flowing     | ○            | ⊖ — ⊕ | ⊕ |
| When current is not flowing |              |       |   |



## IGNITION FAILURE SENSOR CHECK

### NOTE

An analog-type circuit tester should be used.

Check that the resistance between terminals 3 and 4 is at the standard value.

**Standard value: 0.1  $\Omega$  or less**

## WAVEFORM CHECK USING AN ANALYZER <4G13-MPI>

### Ignition Secondary Voltage Waveform Check MEASUREMENT METHOD

1. Clamp the secondary pickup around the spark plug cable.

### NOTE

- (1) The peak ignition voltage will be reversed when the spark cables No. 2 and No. 4, or No. 1 and No. 3 cylinders are clamped.
  - (2) Because of the two-cylinder simultaneous ignition system, the waveforms for two cylinders in each group appear during waveform observation (No. 1 cylinder – No. 4 cylinder, No. 2 cylinder – No. 3 cylinder). However, waveform observation is only applicable for the cylinder with the spark plug cable clamped by the secondary pickup.
  - (3) Identifying which cylinder waveform is displayed can be difficult. For reference, remember that the waveform of the cylinder attached to the secondary pickup will be displayed as stable.
2. Clamp the spark plug cable with the trigger pickup.

### NOTE


Clamp the trigger pickup to the same spark plug cable clamped by the secondary pickup.



**STANDARD WAVEFORM**

**Observation Conditions**


|                    |                 |
|--------------------|-----------------|
| Function           | Secondary       |
| Pattern height     | High (or Low)   |
| Pattern selector   | Raster          |
| Engine revolutions | Curb idle speed |



7EL0147

**Observation Condition (The only change from above condition is the pattern selector.)**

|                  |         |
|------------------|---------|
| Pattern selector | Display |
|------------------|---------|



6EL0183

**WAVEFORM OBSERVATION POINTS**

Point A: The height, length and slope of the spark line show the following trends (Refer to abnormal waveform examples, 1, 2, 3 and 4).

| Spark line |       | Plug gap | Condition of electrode | Compression force | Concentration of air mixture | Ignition timing | Spark plug cable |
|------------|-------|----------|------------------------|-------------------|------------------------------|-----------------|------------------|
| Length     | Long  | Small    | Normal                 | Low               | Rich                         | Advanced        | Leak             |
|            | Short | Large    | Large wear             | High              | Lean                         | Retarded        | High resistance  |
| Height     | High  | Large    | Large wear             | High              | Lean                         | Retarded        | High resistance  |
|            | Low   | Small    | Normal                 | Low               | Rich                         | Advanced        | Leak             |
| Slope      |       | Large    | Plug is fouled         | –                 | –                            | –               | –                |

Point B: Number of vibration in reduction vibration section (Refer to abnormal waveform example 5).

|                      |                    |
|----------------------|--------------------|
| Number of vibrations | Coil and condenser |
| Three or more        | Normal             |
| Except above         | Abnormal           |






Point C: Number of vibrations at beginning of dwell section (Refer to abnormal waveform example 5).

|                      |          |
|----------------------|----------|
| Number of vibrations | Coil     |
| 5 – 6 or higher      | Normal   |
| Except above         | Abnormal |

Point D: Ignition voltage height (distribution per each cylinder) shows the following trends.


| Ignition voltage | Plug gap | Condition of electrode | Compression force | Concentration of air mixture | Ignition timing | Spark plug cable |
|------------------|----------|------------------------|-------------------|------------------------------|-----------------|------------------|
| High             | Large    | Large wear             | High              | Lean                         | Retarded        | High resistance  |
| Low              | Small    | Normal                 | Low               | Rich                         | Advanced        | Leak             |

EXAMPLES OF ABNORMAL WAVEFORMS

| Abnormal waveform   | Wave characteristics  | Cause of problem   |
|---|---|--|
| <p>Example 1</p>  <p>01P0215</p>   | <p>Spark line is high and short.</p>  | <p>Spark plug gap is too large.</p>                                      |
| <p>Example 2</p>  <p>01P0216</p>   | <p>Spark line is low and long, and is sloping. Also, the second half of the spark line is distorted. This could be a result of misfiring.</p> | <p>Spark plug gap is too small.</p>                                      |
| <p>Example 3</p>  <p>01P0217</p> | <p>Spark line is low and long, and is sloping. However, there is almost no spark line distortion.</p>   | <p>Spark plug gap is fouled.</p>   |
| <p>Example 4</p>  <p>01P0218</p> | <p>Spark line is high and short. Difficult to distinguish between this and abnormal waveform example 1.</p>                                   | <p>Spark plug cable is nearly falling off. (Causing a dual ignition)</p> |
| <p>Example 5</p>  <p>01P0219</p> | <p>No waves in wave damping section.</p>  | <p>Rayer short in ignition coil.</p>                                     |

**IGNITION COIL <4G93-GDI>****REMOVAL AND INSTALLATION**

**Pre-removal and Post-installation Operation**  
 Engine Cover Removal and Installation  
 (Refer to GROUP 11A – Camshaft, Camshaft Oil Seal.)




AY0099AJ

**Ignition coil removal steps**

1. Ignition coil connector
2. Ignition coil
3. Earth strap
4. Spark plug

**Ignition failure sensor removal steps**

5. Ignition failure sensor connector
6. Ignition failure sensor

**IGNITION COIL <4G13-MPI>****REMOVAL AND INSTALLATION**

AY0100AJ

**Ignition coil removal steps**

1. Ignition coil connector
2. Spark plug cable assembly
3. Ignition coil
4. Spark plug



**Ignition failure sensor removal steps**

5. Ignition failure sensor connector
6. Ignition failure sensor

**CAMSHAFT POSITION SENSOR <4G13-MPI>**

Camshaft position sensor


9.8 Nm




AY0101AJ

**CAMSHAFT POSITION SENSOR <F9Q1>****REMOVAL AND INSTALLATION**

**Pre-removal and Post-installation Operation**  
Engine hanger (Refer to GROUP 15 – Intake Manifold  
and Exhaust Manifold.)



Camshaft position sensor




AY0146AJ

## CRANK ANGLE SENSOR REMOVAL AND INSTALLATION

- Pre-removal and Post-installation Operation
- Timing Belt Cover Removal and Installation


<4G93-GDI>



### Removal steps

1. Bracket
2. Crank angle sensor

<4G13-MPI>



### Removal steps

1. Crank angle sensor
2. Connector bracket




# DETONATION SENSOR

## REMOVAL AND INSTALLATION

**Pre-removal and Post-installation Operation**


- Engine Cover Removal and Installation <4G93-GDI> (Refer to GROUP 11A – Camshaft, Camshaft Oil Seal.)
- Intake Manifold Stay Removal and Installation (Refer to GROUP 15.)

<4G93-GDI>



A16M0279


<4G13-MPI>



AV0342WE

◀A▶ ▶A◀ 1. Detonation sensor

**Caution**  
Do not subject the detonation sensor to any shocks.



**REMOVAL SERVICE POINT**

◀A▶ DETONATION SENSOR REMOVAL

**INSTALLATION SERVICE POINT**

▶A◀ DETONATION SENSOR INSTALLATION

# GLOW SYSTEM

## GENERAL

### OUTLINE OF CHANGES


The following maintenance service points have been established to correspond to the adoption of the F9Q1 engine.

### GENERAL INFORMATION

The glow system reduces the time required for starting at low temperatures to provide a degree of starting and operation that is identical to petrol-engine vehicles by pre-heating the glow plugs at super-quick speed. The engine-ECU controls both the time during which current is supplied to the glow plugs after the ignition switch is turned to the ON position and also the glow indicator lamp illumination time in accordance with the engine coolant temperature.

When the engine-ECU detects an abnormality in the glow system, it outputs diagnosis code (diesel fuel system) in response to the abnormal item.

### SYSTEM DIAGRAM



## SERVICE SPECIFICATIONS

| Items  |   | Standard value   |
|--|---|--|
| Voltage between glow plug lead and glow body V | Immediately after ignition switch is turned to ON (without starting the engine) | 9 – 11<br>(Drops to 0 V after 0.5 – 16 seconds have passed)                                |
|  | While engine is cranking  | 6 or more  |
|  | While engine is warming up  | 12 – 15<br>(Drops to 0 V when if 10 – 60 seconds have passed since the engine was started) |
| Glow plug resistance $\Omega$                  |   | 0.6  |

## ON-VEHICLE SERVICE

### GLOW SYSTEM CHECK

1. Check that battery voltage is 11 – 13 V.
2. Check that the engine coolant temperature is 40°C or less.
3. Measure the voltages at the glow plug circuits of each cylinder.
  - For the No. 1 glow plug cylinder, measure between glow relay box connector terminal (5) and earth.
  - For the No. 2 glow plug cylinder, measure between glow relay box connector terminal (7) and earth.
  - For the No. 3 glow plug cylinder, measure between glow relay box connector terminal (3) and earth.
  - For the No. 4 glow plug cylinder, measure between glow relay box connector terminal (4) and earth.
4. Measure the voltage immediately after the ignition switch is turned to ON (without starting the engine).

**Standard value:**

**9 – 11 V (Drops to 0 V after 0.5 – 16 seconds have passed)**

In addition, check to be sure that the glow indicator lamp illuminates immediately after the ignition switch is turned to ON.

**NOTE**

The voltage generated time (continuity time) varies depending on the engine coolant temperature when the ignition switch is ON.

5. Measure the voltage while the engine is cranking.


**Standard value: 6 V or more**

6. Start the engine and measure the voltage while the engine is warming up.  
The voltage always drops to 0 V when 10 – 60 seconds have passed after starting the engine.

**Standard value: 12 – 15 V**


**NOTE**

The voltage generated time (continuity time) varies depending on the engine coolant temperature when the ignition switch is ON.


**GLOW PLUG CHECK**

1. Remove the glow plug leads.
2. Measure the resistance between the glow plug terminals and the body.

**Standard value: 0.6  $\Omega$**

**GLOW PLUG****REMOVAL AND INSTALLATION****Removal steps**

1. Glow plug connector connection
2. Glow plug

**REMOVAL SERVICE POINT****◀A▶ GLOW PLUG (NO.1) REMOVAL**

After removing the common rail, remove the Glow plug (NO.1).  
(Refer to GROUP 13D – Injection Pump and Nozzle)

---

# ENGINE ELECTRICAL

## CONTENTS

|                         |          |                                     |          |
|-------------------------|----------|-------------------------------------|----------|
| <b>STARTING SYSTEM</b>  |          | <b>GENERAL INFORMATION</b> .....    | <b>2</b> |
| <b>GENERAL</b> .....    | <b>2</b> | <b>SERVICE SPECIFICATIONS</b> ..... | <b>2</b> |
| Outline of Change ..... | 2        | <b>STARTER MOTOR</b> .....          | <b>3</b> |

---

# STARTING SYSTEM

## GENERAL

### OUTLINE OF CHANGES


Due to the addition of the 4G18 engine model, some service procedures have been added.

- A direct drive type starter has been introduced. <4G18-A/T>

## GENERAL INFORMATION

### SYSTEM DIAGRAM

<4G18-A/T>





9EN0288

### STARTER MOTOR SPECIFICATIONS

|                     |              |
|---------------------|--------------|
| Items               | 4G18 <A/T>   |
| Type                | Direct drive |
| Rated output kW/V   | 0.9/12       |
| No. of pinion teeth | 8            |

### SERVICE SPECIFICATIONS

| Items                        | Standard value | Limit |
|------------------------------|----------------|-------|
| Pinion gap mm                | 0.5 – 2.0      | –     |
| Commutator outer diameter mm | 32.0           | 31.0  |
| Commutator runout mm         | 0.05           | 0.1   |
| Commutator undercut mm       | 0.5            | 0.2   |



## STARTER MOTOR

### INSPECTION

#### PINION GAP ADJUSTMENT

Pinion gap for the direct drive type starter has been added. Its inspection is the same as before.

**Pinion gap: 0.5 – 2.0 mm**


### FREE RUNNING TEST

1. Place starter motor in a vise equipped with soft jaws and connect a fully-charged 12-volt battery to starter motor as follows:
2. Connect a test ammeter (100-ampere scale) and carbon pile rheostat in series with battery positive post and starter motor terminal.
3. Connect a voltmeter (15-volt scale) across starter motor.
4. Rotate carbon pile to full-resistance position.
5. Connect battery cable from battery negative post to starter motor body.
6. Adjust the rheostat until the battery voltage shown by the voltmeter is 11.5 V.
7. Confirm that the maximum amperage is within the specifications and that the starter motor turns smoothly and freely.

**Current: max. 60 Amps**



DISASSEMBLY AND REASSEMBLY




D9EN0186

**Disassembly steps**


- 1. Screw
- 2. Magnetic switch
- 3. Packing
- 4. Plate
- 5. Screw
- 6. Through bolt
- 7. Rear bracket
- 8. Rear bearing
- 9. Brush holder assembly




- 10. Yoke assembly
- 11. Armature
- 12. Lever
- 13. Washer
- 14. Snap ring
- 15. Stop ring
- 16. Overrunning clutch
- 17. Front bracket

**DISASSEMBLY SERVICE POINTS****◀A▶ SNAP RING/STOP RING REMOVAL**

1. Press stop ring off snap ring with a suitable socket.
2. Remove snap ring with snap ring pliers and then remove stop ring and overrunning clutch.

**STARTER MOTOR PARTS CLEANING**

1. Do not immerse parts in cleaning solvent. Immersing the yoke and field coil assembly and/or armature will damage insulation. Wipe these parts with a cloth only.
2. Do not immerse drive unit in cleaning solvent. Overrunning clutch is pre-lubricated at the factory and solvent will wash lubrication from clutch.
3. The drive unit may be cleaned with a brush moistened with cleaning solvent and wiped dry with a cloth.

**REASSEMBLY SERVICE POINTS****▶A◀ STOP RING/SNAP RING INSTALLATION**

Using a suitable pulling tool, pull overrunning clutch stop ring over snap ring.

---

## NOTES