
FUEL

CONTENTS

| | |
|---------------------------------------|-----|
| GASOLINE DIRECT INJECTION (GDI) | 13A |
| MULTIPOINT FUEL INJECTION (MPI) | 13B |
| FUEL SUPPLY | 13C |
| DIESEL FUEL | 13D |

GASOLINE DIRECT INJECTION (GDI)

CONTENTS

| | | | |
|-------------------------------------|------------|--|------------|
| GENERAL | 3 | Fuel Leak Check | 125 |
| Outline of Change | 3 | Component Location | 126 |
| GENERAL INFORMATION | 3 | Accelerator Pedal Position Sensor Check | 127 |
| SERVICE SPECIFICATIONS | 5 | Accelerator Pedal Position Switch Check | 127 |
| TROUBLESHOOTING | 6 | Oxygen Sensor Check | 128 |
| ON-VEHICLE SERVICE | 121 | FUEL PUMP (HIGH PRESSURE) | 130 |
| Accelerator Pedal Position Sensor | | FUEL INJECTOR | 133 |
| Adjustment | 121 | THROTTLE BODY | 137 |
| Fuel Pressure Test | 122 | | |

GENERAL

OUTLINE OF CHANGES

Due to the changes shown below, the service procedures regarding the different description from the previous version have been established.

- On-board Diagnostics System has been adopted to expand the diagnostic items and to change diagnosis code numbering system.
- Fuel pressure regulator (high-pressure) incorporate fuel pump (high-pressure) has been adopted.
- An oxygen sensor (rear) has been added.
- A ignition failure sensor has been added.
- Lead cables of the crank angle sensor have been contained in the timing belt cover.
- An accelerator pedal position sensor attached to the accelerator pedal has been adopted.
- An engine-ECU has been changed.(Change of terminal layout) <Vehicles with M/T>
- An engine-A/T-ECU has been adopted. <Vehicles with A/T>

GENERAL INFORMATION

SELF-DIAGNOSIS FUNCTION



Following functions have been added.

- The engine-ECU records the engine operating condition when the diagnosis code is set.
This data is called “freeze frame” data.
This data can be read by using the MUT-II, are can then be used in simulation tests for troubleshooting.

GENERAL SPECIFICATIONS


| Items | | Specifications |
|----------------------|--------------------|----------------|
| Engine-ECU <M/T> | Identification No. | E2T72675 |
| Engine-A/T-ECU <A/T> | Identification No. | E2T77572 |

GASOLINE DIRECT INJECTION SYSTEM DIAGRAM



SERVICE SPECIFICATIONS

| Items | | Standard value |
|--|------------------------|-------------------|
| Adjustment voltage of accelerator pedal position sensor (1st and 2nd channel) V | | 0.985 – 1.085 |
| Resistance of accelerator pedal position sensor (1st and 2nd channel) k Ω | | 3.5 – 6.5 |
| Fuel pressure | High-pressure side MPa | 4 – 6.9 |
| | Low-pressure side kPa | Approximately 329 |
| Oxygen sensor output voltage (during revving) V | | 0.6 – 1.0 |
| Oxygen sensor heater resistance (at 20°C) Ω | Front | 4.5 – 8.0 |
| | Rear | 11 – 18 |



TROUBLESHOOTING

DIAGNOSIS FUNCTION

ENGINE WARNING LAMP (CHECK ENGINE LAMP)

If an abnormality occurs in any of the following items related to the GDI system, the engine warning lamp will illuminate or flash. If the lamp remains illuminated or if the lamp illuminates while the engine is running, check the diagnosis code output. However, the warning lamp will illuminate as bulb check for five seconds whenever the ignition switch is turned to the ON position.

Engine warning lamp inspection items

| Code No. | Diagnosis item |
|----------|--|
| – | Engine-ECU <M/T> or engine-A/T-ECU <A/T> |
| P0100 | Air flow sensor system |
| P0105 | Barometric pressure sensor system |
| P0110 | Intake air temperature sensor system |
| P0115 | Engine coolant temperature sensor system |
| P0120★ | Throttle position sensor (1st channel) system |
| P0125 | Feedback system |
| P0130 | Oxygen sensor (front) system <sensor 1> |
| P0135 | Oxygen sensor heater (front) system <sensor 1> |
| P0136 | Oxygen sensor (rear) system <sensor 2> |
| P0141 | Oxygen sensor heater (rear) system <sensor 2> |
| P0170 | Abnormal fuel system |
| P0190★ | Abnormal fuel pressure |
| P0201 | No. 1 injector system |
| P0202 | No. 2 injector system |
| P0203 | No. 3 injector system |
| P0204 | No. 4 injector system |
| P0220★ | Accelerator pedal position sensor (1st channel) system |
| P0225★ | Throttle position sensor (2nd channel) system |
| P0300★ | Ignition coil (power transistor) system |
| P0301 | No. 1 cylinder misfire detected |
| P0302 | No. 2 cylinder misfire detected |
| P0303 | No. 3 cylinder misfire detected |
| P0304 | No. 4 cylinder misfire detected |

| Code No. | Diagnosis item |
|----------|---|
| P0335 | Crank angle sensor system |
| P0340 | Camshaft position sensor system |
| P0403 | EGR valve system |
| P0420 | Catalyst malfunction |
| P0443 | Purge control solenoid valve system |
| P1200 | Injector driver system |
| P1220★ | Electronic-controlled throttle valve system |
| P1221★ | Throttle valve position feedback system |
| P1223★ | Communication line with throttle valve controller |
| P1224★ | Throttle valve control servo motor (motor 1st phase malfunction) system |
| P1225★ | Accelerator pedal position sensor (2nd channel) system |
| P1228★ | Throttle valve control servo motor (motor 2nd phase malfunction) system |
| P1515 | Brake vacuum sensor system |

NOTE

- If the engine warning lamp illuminates because of a malfunction of the engine-ECU (engine-A/T-ECU), communication between MUT-II and the engine-ECU (engine-A/T-ECU) is impossible. In this case, the diagnosis code cannot be read.
- After the engine-ECU (engine-A/T-ECU) has detected a malfunction, the engine warning lamp illuminates when the engine is next turned on and the same malfunction is re-detected. However, for items marked with a “★” in the diagnosis code number column, the engine warning lamp illuminates only on the first detection of the malfunction.
As for P1220, P1221, P1223, P1224, and P1228, the engine warning lamp flashes. If malfunctions are detected at the throttle position sensor (1st channel) and the throttle position sensor (2nd channel) at the same time, or malfunctions are detected at the accelerator pedal position sensor (1st channel) and the accelerator pedal position sensor (2nd channel) at the same time, the engine warning lamp will flash.
- After the engine warning lamp illuminates, it will be switched off under the following conditions.
 - When the engine-ECU (engine-A/T-ECU) monitored the power train malfunction three times* and met set condition requirements, it detected no malfunction.
*: In this case, “one time” indicates from engine start to stop.
 - For misfiring malfunction, when driving conditions (engine speed, engine coolant temperature, etc.) are similar to those when the malfunction was first recorded.
- Sensor 1 indicates the sensor mounted at a position closest to the engine, and sensor 2 indicates the sensor mounted at the position second closest to the engine.

METHOD OF READING AND ERASING DIAGNOSIS CODES

Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points.

DIAGNOSIS USING DIAGNOSIS 2 MODE

1. Switch the diagnosis mode of the engine control unit to DIAGNOSIS 2 mode using the MUT-II.
2. Carry out a road test.
3. Take a reading of the diagnosis code and repair the problem location.
4. Turn the ignition switch to OFF and then back to ON again.

NOTE

By turning the ignition switch to OFF, the engine-ECU <M/T> or engine-A/T-ECU <A/T> will switch the diagnosis mode from DIAGNOSIS 2 mode to DIAGNOSIS 1 mode.

5. Erase the diagnosis codes.

INSPECTION USING MUT-II DATA LIST AND ACTUATOR TESTING

1. Carry out inspection by means of the data list and the actuator test function. If there is an abnormality, check and repair the chassis harnesses and components.
2. After repairing, re-check using the MUT-II and check that the abnormal input and output have returned to normal as a result of the repairs.
3. Erase the diagnosis code memory.
4. Remove the MUT-II, and then start the engine again and carry out a road test to confirm that the problem has disappeared.

FREEZE FRAME DATA

When the engine-ECU <M/T> or engine-A/T-ECU <A/T> detects a malfunction and stores a diagnosis code, it also stores a current status of the engine. This function is called “Freeze frame data.” By analyzing this “freeze frame” data with the MUT-II, an effective troubleshooting can be performed.

The display items of freeze frame data are shown below.

Display item list

| Data item | Unit | |
|---|--|---------|
| Engine coolant temperature sensor | °C | |
| Engine speed | r/min | |
| Vehicle speed | km/h | |
| Long-term fuel compensation (long-term fuel trim) | % | |
| Short-term fuel compensation (short-term fuel trim) | % | |
| Fuel control condition | Open loop | OL |
| | Closed loop | CL |
| | Open loop owing to drive condition | OL-DRV. |
| | Open loop owing to system malfunction | OL-SYS. |
| | Closed loop based on one oxygen sensor | CL-H02S |
| Calculation load value | % | |
| Diagnosis code during data recording | – | |

NOTE

If malfunctions have been detected in multiple systems, store one malfunction only, which has been detected first.

READINESS TEST STATUS

The engine-ECU <M/T> or engine-A/T-ECU <A/T> monitors the following main diagnosis items, judges if these items are in good condition or not, and the stores its history. This history can be read out by using MUT-II. (If the ECU has judged a item before, the MUT-II displays “Complete.”)

In addition, if diagnosis codes are erased or the battery cable is disconnected, this history will also be erased (the memory will be reset).

- Catalyst: P0420
- Oxygen sensor: P0130
- Oxygen sensor heater: P0135, P0141

FAIL-SAFE FUNCTION REFERENCE TABLE

When the main sensor malfunctions are detected by the diagnosis function, the vehicle is controlled by means of the pre-set control logic to maintain safe conditions for driving.

| Malfunctioning item | Control contents during malfunction |
|---|---|
| Air flow sensor | <ol style="list-style-type: none"> 1. Suspends lean burn operation. 2. Uses the throttle position sensor signal and engine speed signal (crank angle sensor signal) to take reading of the basic injector drive time and basic ignition timing from the pre-set mapping. |
| Intake air temperature sensor | Controls as if the intake air temperature is 25°C. |
| Throttle position sensor (2nd channel) | <ol style="list-style-type: none"> 1. Suspends lean burn operation. 2. Controls the throttle opening angle feedback (half as much as the opening rate in the normal condition) by using signals from the throttle position sensor (1st channel). However, this controlling system is not applied if the throttle position sensor (1st channel) and throttle position sensor (2nd channel) combination output voltage is outside 4 – 6 V. 3. Refrains from controlling the throttle opening angle feedback if the throttle position sensor (1st channel) is also defective. |
| Engine coolant temperature sensor | Controls as if the engine coolant temperature is 80°C. (Moreover, the control system is working until the ignition switch is turned OFF if the sensor signal returns to normal.) |
| Camshaft position sensor | Controls maintaining the condition before determined as failure. Fuel will be cut-off 4 seconds after a malfunction is detected. (However, only if No. 1 cylinder TDC has never been detected after the ignition switch is turned to the ON position) |
| Vehicle speed sensor | <ol style="list-style-type: none"> 1. Suspends lean burn operation. However, the control is cancelled as a certain time passes by with the engine speed of 1,500 r/min or more. 2. Suspends lean burn operation during the engine idling. |
| Barometric pressure sensor | Controls as if the barometric pressure is 101 kPa. |
| Detonation sensor | Fixes the ignition timing as that for standard petrol. |
| Injector | <ol style="list-style-type: none"> 1. Suspends lean burn operation. 2. Suspends the exhaust gas recirculation. |
| Ignition coil (incorporating power transistor) | <ol style="list-style-type: none"> 1. Suspends lean burn operation. 2. Cuts off the fuel supply to cylinders with an abnormal ignition signal. |
| Fuel pressure sensor | <ol style="list-style-type: none"> 1. Controls as if the fuel pressure is 5 MPa. (In case of open/short circuit) 2. Turns the fuel pump relay off. (In case of abnormality in high pressure) 3. Suspends fuel injection. (when the low pressure is detected and the engine speed is more than 3,000 r/min) |
| Alternator FR terminal | Refrains from controlling to suppress the alternator output to electrical load. (Operated as a normal alternator) |
| Accelerator pedal position sensor (2nd channel) | <ol style="list-style-type: none"> 1. Suspends lean burn operation. 2. Controls the throttle valve position by using signals from the accelerator pedal position sensor (1st channel). (However, the control system is not applicable if the difference from the accelerator pedal position sensor (1st channel) output voltage is 1.0 V or higher.) 3. Suspends the electronic controlled throttle valve system if accelerator pedal position sensor (1st channel) is also defective. |

| Malfunctioning item | Control contents during malfunction |
|---|--|
| Accelerator pedal position sensor (1st channel) | <ol style="list-style-type: none"> 1. Suspends lean burn operation. 2. Controls the throttle valve position by using signals from the accelerator pedal position sensor (2nd channel). (However, this control is not applicable if the voltage difference between the accelerator pedal position sensor (1st channel) and accelerator pedal position sensor (2nd channel) is 1.0 V or higher.) 3. Also suspends the electronic-controlled throttle valve system when the accelerator pedal position sensor (2nd channel) is defective. |
| Throttle position sensor (1st channel) | <ol style="list-style-type: none"> 1. Suspends lean burn operation. 2. Controls throttle opening angle feedback by using signals from throttle position sensor (2nd channel). (However, the controlling system is not applied when the throttle position sensor (1st channel) and throttle position sensor (2nd channel) combination output voltage is outside 4 – 6 V.) 3. Refrains from controlling the throttle opening angle feedback when throttle position sensor (2nd channel) is also defective. |
| Electronic-controlled throttle valve system | <ol style="list-style-type: none"> 1. Suspends the electronic controlled throttle valve system. 2. Suspends lean burn operation. 3. Suspends the idle speed feedback control. |
| Throttle valve position feedback | <ol style="list-style-type: none"> 1. Suspends the electronic controlled throttle valve system. 2. Suspends lean burn operation. 3. Suspends the engine speed feedback control. |
| Communication line between the throttle valve controller and the engine-ECU <M/T> or engine-A/T-ECU <A/T> | <ol style="list-style-type: none"> 1. Communication error between the throttle valve controller and the engine-ECU <M/T> or engine-A/T-ECU <A/T>: <ul style="list-style-type: none"> ● Suspends lean burn operation. ● Cuts the fuel supply when the engine speed reaches 3,000 r/min or more. ● Suspends the cruise-control. 2. Communication error between the throttle valve controller and the engine-ECU <M/T> or engine-A/T-ECU <A/T>: <ul style="list-style-type: none"> ● Suspends lean burn operation. ● Cuts the fuel supply when the engine speed reaches 3,000 r/min or more. ● Suspends the cruise-control. ● The throttle valve controller controls the throttle valve opening angle by using signals from accelerator pedal position sensor (2nd channel). |
| Throttle control servo motor 1st phase malfunction | Bans lean burn operation. |
| Throttle control servo motor 2nd phase malfunction | <ol style="list-style-type: none"> 1. Suspends electronic control throttle valve system. 2. Bans lean burn operation. 3. Bans engine speed feed back control. |
| Misfiring | If the detected misfiring causes damage to the catalyst, the misfiring cylinder will be shut down. |

NOTE

If the electronic-controlled throttle valve system is suspended, the engine warning lamp will illuminate.

INSPECTION CHART FOR DIAGNOSIS CODES

| Code No. | Diagnosis item | Reference page |
|----------|--|----------------|
| P0100 | Air flow sensor system | 13A-14 |
| P0105 | Barometric pressure sensor system | 13A-16 |
| P0110 | Intake air temperature sensor system | 13A-18 |
| P0115 | Engine coolant temperature sensor system | 13A-19 |
| P0120★ | Throttle position sensor 1 (1st channel) system | 13A-22 |
| P0125 | Feedback system | 13A-24 |
| P0130 | Oxygen sensor (front) system <sensor 1> | 13A-26 |
| P0135 | Oxygen sensor heater (front) system <sensor 1> | 13A-28 |
| P0136 | Oxygen sensor (rear) system <sensor 2> | 13A-29 |
| P0141 | Oxygen sensor heater (rear) system <sensor 2> | 13A-31 |
| P0170 | Abnormal fuel system | 13A-32 |
| P0190★ | Abnormal fuel pressure | 13A-34 |
| P0201 | No. 1 injector system | 13A-35 |
| P0202 | No. 2 injector system | 13A-37 |
| P0203 | No. 3 injector system | 13A-38 |
| P0204 | No. 4 injector system | 13A-39 |
| P0220★ | Accelerator pedal position sensor (1st channel) system | 13A-41 |
| P0225★ | Throttle position sensor (2nd channel) system | 13A-44 |
| P0300★ | Ignition coil (power transistor) system | 13A-45 |
| P0301 | No. 1 cylinder misfire detected | 13A-47 |
| P0302 | No. 2 cylinder misfire detected | 13A-47 |
| P0303 | No. 3 cylinder misfire detected | 13A-47 |
| P0304 | No. 4 cylinder misfire detected | 13A-47 |
| P0325 | Detonation sensor system | 13A-48 |
| P0335 | Crank angle sensor system | 13A-48 |
| P0340 | Camshaft position sensor system | 13A-50 |
| P0403 | EGR valve system | 13A-52 |
| P0420 | Catalyst malfunction | 13A-54 |
| P0443 | Purge control solenoid valve system | 13A-55 |
| P0500 | Vehicle speed sensor system | 13A-56 |
| P1200 | Injector driver system | 13A-56 |
| P1220★ | Electronic-controlled throttle valve system | 13A-57 |


| Code No. | Diagnosis item | Reference page |
|----------|---|----------------|
| P1221★ | Throttle valve position feedback system | 13A-58 |
| P1223★ | Communication line with throttle valve controller | 13A-59 |
| P1224★ | Throttle valve control servo motor (motor 1st phase malfunction) system | 13A-60 |
| P1225★ | Accelerator pedal position sensor (2nd channel) system | 13A-61 |
| P1228★ | Throttle valve control servo motor (motor 2nd phase malfunction) system | 13A-63 |
| P1500 | Alternator FR terminal system | 13A-64 |
| P1515 | Brake vacuum sensor system | 13A-65 |
| P1610 | Immobilizer system | 13A-67 |


NOTE

1. Do not replace the engine-ECU <M/T> or engine-A/T-ECU <A/T> until a through terminal check reveals there are no short/open circuit.
2. Check that the engine-ECU <M/T> or engine-A/T-ECU <A/T> earth circuit is normal before checking for the cause of the problem.
3. After the engine-ECU <M/T> or engine-A/T-ECU <A/T> has detected a malfunction, a diagnosis code is recorded the next time the engine is started and the same malfunction is re-detected. However, for items marked with a “★”, the diagnosis code is recorded on the first detection of the malfunction.
4. Sensor 1 indicates the sensor mounted at a position closest to the engine, and sensor 2 indicates the sensor mounted at the position second closest to the engine.


INSPECTION PROCEDURE CLASSIFIED BY DIAGNOSIS CODE


| Code No. P0100 Air flow sensor system | Probable cause |
|--|---|
| Range of Check • Engine speed: 500 r/min or more Set Conditions • The sensor output frequency is 3.3 Hz or less for four seconds. | • Malfunction of air flow sensor • Open or short circuit in air flow sensor circuit or loose connector contact • Malfunction of engine-ECU <M/T> • Malfunction of engine-A/T-ECU <A/T> |






| Code No. P0105 Barometric pressure sensor system | Probable cause |
|---|---|
| <p>Range of Check</p> <ul style="list-style-type: none"> Two seconds have passed since the ignition switch is turned ON or the engine starting process is completed. Battery voltage: 8 V or more <p>Set Conditions</p> <ul style="list-style-type: none"> The sensor output voltage is 4.5 V or more for four seconds (equivalent to 114 kPa of barometric pressure) <p>or</p> <ul style="list-style-type: none"> The sensor output voltage is 0.2 V or less (equivalent to 53 kPa of barometric pressure) | <ul style="list-style-type: none"> Malfunction of barometric pressure sensor Open or short circuit in barometric pressure sensor circuit or loose connector contact Malfunction of engine-ECU <M/T> Malfunction of engine-A/T-ECU <A/T> |






| Code No. P0110 Intake air temperature sensor system | Probable cause |
|---|---|
| <p>Range of Check</p> <ul style="list-style-type: none"> Two seconds have passed since the ignition switch is turned ON or the engine starting process is completed. <p>Set Conditions</p> <ul style="list-style-type: none"> The sensor output voltage is 4.6 V or more for four seconds (equivalent to -45°C of intake air temperature) <p>or</p> <ul style="list-style-type: none"> The sensor output voltage is 0.2 V or more for four seconds (equivalent to 125°C of intake air temperature) | <ul style="list-style-type: none"> Malfunction of intake air temperature sensor Open or short circuit in intake air temperature sensor or loose connector contact Malfunction of engine-ECU <M/T> Malfunction of engine-A/T-ECU <A/T> |





NOTE

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1).



| Code No. P0115 Engine coolant temperature sensor system | Probable cause |
|--|---|
| Range of Check <ul style="list-style-type: none"> Engine: Two seconds after the engine has been started Set Conditions <ul style="list-style-type: none"> The sensor output voltage is 4.6 V or more for four seconds (equivalent to -45°C of engine coolant temperature) or <ul style="list-style-type: none"> The sensor output voltage is 0.1 V or less for four seconds (equivalent to 140°C of engine coolant temperature) | <ul style="list-style-type: none"> Malfunction of engine coolant temperature sensor Open or short circuit in the engine coolant temperature sensor circuit or loose connector contact Malfunction of engine-ECU <M/T> Malfunction of engine-A/T-ECU <A/T> |
| Range of Check <ul style="list-style-type: none"> Engine: After starting Set Conditions <ul style="list-style-type: none"> The engine coolant temperature has reduced from over 40°C to less than 40°C, and that condition has lasted for five minutes or more. | |






NOTE


*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1).

| Code No. P0120 Throttle position sensor (1st channel) system | Probable cause |
|---|---|
| <p>The throttle valve controller judges a malfunction, and then transmit the result to the engine-ECU <M/T> or engine-A/T-ECU <A/T>.</p> <p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON <p>Set Conditions</p> <ul style="list-style-type: none"> The sensor output voltage is 0.2 V or less. <p>or</p> <ul style="list-style-type: none"> The sensor output voltage is 4.9 V or more. <p>or</p> <ul style="list-style-type: none"> The throttle position sensor (1st channel) and throttle position sensor (2nd channel) combination output voltage is outside 4 – 6 V. <p>or</p> <ul style="list-style-type: none"> The output voltage of the throttle position sensor (1st channel) is significantly different (approx. 1V) from the throttle valve opening angle (voltage), which the engine-ECU <M/T> or engine-A/T-ECU <A/T> request the throttle valve controller. | <ul style="list-style-type: none"> Malfunction of throttle position sensor Open or short circuit in the throttle position sensor (1st channel) circuit or loose connector contact Malfunction of throttle valve controller Malfunction of engine-ECU <M/T> Malfunction of engine-A/T-ECU <A/T> |



NOTE


*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)




NOTE

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)


| Code No. P0125 Feedback system | Probable cause |
|--|--|
| <p>Range of Check</p> <ul style="list-style-type: none">• The engine coolant temperature is approx. 80°C or more.• During stoichiometric feedback control• The vehicle is not being decelerated. <p>Set Conditions</p> <ul style="list-style-type: none">• Oxygen sensor (front) output voltage has been higher or lower than 0.5 V for at least thirty seconds. | <ul style="list-style-type: none">• Malfunction of oxygen sensor (front)• Open or short circuit in the oxygen sensor (front) circuit or loose connector contact• Malfunction of engine-ECU <M/T>• Malfunction of engine-A/T-ECU <A/T> |




| Code No. P0130 Oxygen sensor (front) system <sensor 1> | Probable cause |
|---|---|
| <p>Range of Check</p> <ul style="list-style-type: none"> ● Three minutes have been passed since the engine has been started. ● The engine coolant temperature is approx. 80°C or more. ● Intake air temperature is 20 – 50°C ● Engine speed is 1,200 r/min or more ● Driving on a level surface at constant speed. <p>Set Conditions</p> <ul style="list-style-type: none"> ● The oxygen sensor (front) output voltage is 4.5 V or more when the sensor output voltage is 0.2 V or less and a voltage of 5 V is applied to the oxygen sensor (front) inside the engine-ECU. | <ul style="list-style-type: none"> ● Malfunction of oxygen sensor (front) ● Open or short circuit in the oxygen sensor (front) circuit or loose connector contact ● Malfunction of engine-ECU <M/T> ● Malfunction of engine-A/T-ECU <A/T> |
| <p>Range of Check</p> <ul style="list-style-type: none"> ● Engine speed is 3,000 r/min or less ● During driving ● During air/fuel ratio feedback control <p>Set Conditions</p> <ul style="list-style-type: none"> ● The oxygen sensor (front) output frequency is five or less per 12 seconds on average. | |




| Code No. P0135 Oxygen sensor heater (front) system <sensor 1> | Probable cause |
|---|---|
| <p>Range of Check</p> <ul style="list-style-type: none"> The engine coolant temperature is approx. 20°C or more. The oxygen sensor heater (front) remains on. The engine speed is 50 r/min or more. Battery voltage is 11 – 16 V. <p>Set Conditions</p> <ul style="list-style-type: none"> The current, which flows through the oxygen sensor heater (front), is 0.2 A or less or 3.5 A or more for six seconds. | <ul style="list-style-type: none"> Malfunction of oxygen sensor heater (front) Open or short circuit in the oxygen sensor heater (front) circuit or loose connector contact Malfunction of engine-ECU <M/T> Malfunction of engine-A/T-ECU <A/T> |




| Code No. P0136 Oxygen sensor (rear) system <sensor 2> | Probable cause |
|---|---|
| <p>Range of Check</p> <ul style="list-style-type: none"> ● Three minutes have been passed since the engine has been started. ● The engine coolant temperature is approx. 80°C or more. ● Intake air temperature is 20 – 50°C ● Engine speed is 1,200 r/min or more ● Driving on a level surface at constant speed. <p>Set Conditions</p> <ul style="list-style-type: none"> ● The oxygen sensor (rear) output voltage is 4.5 V or more when the sensor output voltage is 0.2 V or less and a voltage of 5 V is applied to the oxygen sensor (rear) inside the engine-ECU <M/T> or engine-A/T-ECU <A/T>. | <ul style="list-style-type: none"> ● Malfunction of oxygen sensor (rear) ● Open or short circuit in the oxygen sensor (rear) circuit or loose connector contact ● Malfunction of engine-ECU <M/T> ● Malfunction of engine-A/T-ECU <A/T> |
| <p>Range of Check</p> <ul style="list-style-type: none"> ● Two seconds have passed after the engine-ECU <M/T> or engine-A/T-ECU <A/T> detected an open circuit. ● When the oxygen sensor (front) is in good condition. <p>Set Conditions</p> <ul style="list-style-type: none"> ● When the air/fuel ratio is rich, the oxygen sensor (front) output voltage is 0.5 V or more, the oxygen sensor (rear) output voltage is less than 0.1 V, and the oxygen sensor (rear) output voltage fluctuates within 0.078 V. | |



| Code No. P0141 Oxygen sensor heater (rear) system <sensor 2> | Probable cause |
|---|---|
| <p>Range of Check</p> <ul style="list-style-type: none"> • The engine coolant temperature is approx. 20°C or more. • The oxygen sensor heater (rear) remains on. • The engine speed is 50 r/min or more. • Battery voltage is 11 – 16 V. <p>Set Conditions</p> <ul style="list-style-type: none"> • The current, which flows through the oxygen sensor heater (rear), is 0.2 A or less or 3.5 A or more for six seconds. | <ul style="list-style-type: none"> • Malfunction of oxygen sensor heater (rear) • Open or short circuit in the oxygen sensor heater (rear) circuit or loose connector contact • Malfunction of engine-ECU <M/T> • Malfunction of engine-A/T-ECU <A/T> |




| Code No. P0170 Abnormal fuel system | Probable cause |
|--|--|
| Range of Check ● Engine: Being learning the air-fuel ratio Set Conditions ● Ten seconds or more have been passed while the fuel injection amount compensation value is too low. or ● Ten seconds or more have been passed while the fuel injection amount compensation value is too high. | <ul style="list-style-type: none"> ● Malfunction of fuel supply system ● Malfunction of oxygen sensor (front) ● Malfunction of intake air temperature sensor ● Malfunction of barometric pressure sensor ● Malfunction of air flow sensor ● Malfunction of engine-ECU <M/T> ● Malfunction of engine-A/T-ECU <A/T> |





NOTE

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)




| Code No. P0190 Abnormal fuel pressure | Probable cause |
|---|---|
| Range of Check ● Ignition switch: ON Set Conditions ● The sensor output voltage is 4.8 V or more, or 0.2 V or less for four seconds. | ● Malfunction of fuel pressure sensor ● Open or short circuit in the fuel pressure sensor circuit or loose connector contact ● Malfunction of engine-ECU <M/T> ● Malfunction of engine-A/T-ECU <A/T> |
| Range of Check ● The following conditions are detected temporarily after the engine has been started. (1) Engine speed: 1,000 r/min or more (2) Fuel pressure: 2 MPa or more ● Engine running Set Conditions ● The fuel pressure is 6.9 MPa or more, or 2 MPa or less for four seconds. | ● Malfunction of high-pressure fuel pump ● Clogging of high-pressure fuel lines |
| This diagnosis code will also be output when air is trapped into the high-pressure fuel lines (such as poor fuel level). In that case, the air can be evacuated by operating the engine for at least 15 seconds at 2,000 r/min. After the repair, use the MUT-II to erase the diagnosis code. | ● Air trapped due to poor fuel level |







| Code No. P0201 No. 1 injector system | Probable cause |
|---|---|
| <p>Range of Check</p> <ul style="list-style-type: none"> The engine speed is 4,000 r/min or less. The battery voltage is 10 V or more. The fuel cut operation or the injector operation (by carrying out the Actuator Test) is not in progress. <p>Set Conditions</p> <ul style="list-style-type: none"> The injector driver is not transmitting a injector open circuit check signal for four seconds. | <ul style="list-style-type: none"> Malfunction of No. 1 injector Open or short circuit in the No. 1 injector circuit or loose connector contact Malfunction of engine-ECU <M/T> Malfunction of engine-A/T-ECU <A/T> |





| Code No. P0202 No. 2 injector system | Probable cause |
|---|---|
| <p>Range of Check</p> <ul style="list-style-type: none"> The engine speed is 4,000 r/min or less. The battery voltage is 10 V or more. The fuel cut operation or the injector operation (by carrying out the Actuator Test) is not in progress. <p>Set Conditions</p> <ul style="list-style-type: none"> The injector driver is not transmitting a injector open circuit check signal for four seconds. | <ul style="list-style-type: none"> Malfunction of No. 2 injector Open or short circuit in the No. 2 injector circuit or loose connector contact Malfunction of engine-ECU <M/T> Malfunction of engine-A/T-ECU <A/T> |






| Code No. P0203 No. 3 injector system | Probable cause |
|---|---|
| Range of Check <ul style="list-style-type: none"> • The engine speed is 4,000 r/min or less. • The battery voltage is 10 V or more. • The fuel cut operation or the injector operation (by carrying out the Actuator Test) is not in progress. Set Conditions <ul style="list-style-type: none"> • The injector driver is not transmitting a injector open circuit check signal for four seconds. | <ul style="list-style-type: none"> • Malfunction of No. 3 injector • Open or short circuit in the No. 3 injector circuit or loose connector contact • Malfunction of engine-ECU <M/T> • Malfunction of engine-A/T-ECU <A/T> |







| Code No. P0204 No. 4 injector system | Probable cause |
|---|---|
| <p>Range of Check</p> <ul style="list-style-type: none"> • The engine speed is 4,000 r/min or less. • The battery voltage is 10 V or more. • The fuel cut operation or the injector operation (by carrying out the Actuator Test) is not in progress. <p>Set Conditions</p> <ul style="list-style-type: none"> • The injector driver is not transmitting a injector open circuit check signal for four seconds. | <ul style="list-style-type: none"> • Malfunction of No. 4 injector • Open or short circuit in the No. 4 injector circuit or loose connector contact • Malfunction of engine-ECU <M/T> • Malfunction of engine-A/T-ECU <A/T> |




| Code No. P0220 Accelerator pedal position sensor (1st channel) system | Probable cause |
|---|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> ● Accelerator pedal position sensor (2nd channel) is normal. ● Communication between the engine-ECU <M/T> or engine-A/T-ECU <A/T> and the throttle valve controller is normal. <p>Set Conditions</p> <ul style="list-style-type: none"> ● The output voltage of accelerator pedal position sensor (1st channel) is 0.2 V or less for one second. <p>or</p> <ul style="list-style-type: none"> ● The output voltage of accelerator pedal position sensor (2nd channel) is 2.5 V or less, and that of accelerator pedal position sensor (1st channel) is 4.5 V or more for one second <p>or</p> <ul style="list-style-type: none"> ● The difference between accelerator pedal position sensor (1st channel) and accelerator pedal position sensor (2nd channel) output voltages is 1.0 V or more (i.e. the throttle opening angle changes slightly). <p>or</p> <ul style="list-style-type: none"> ● The output voltage of accelerator pedal position sensor (1st channel) is 1.875 V or more for one second when the accelerator pedal position switch is turned on. | <ul style="list-style-type: none"> ● Malfunction of accelerator pedal position sensor (1st channel) ● Open or short circuit in the accelerator pedal position sensor (1st channel) circuit or loose connector contact ● Accelerator pedal position switch seized ON ● Malfunction of throttle valve controller ● Malfunction of engine-ECU <M/T> ● Malfunction of engine-A/T-ECU <A/T> |






| Code No. 0225 Throttle position sensor (2nd channel) system | Probable cause |
|--|---|
| <p>The throttle valve controller judges a malfunction, and then transmit the result to the engine-ECU <M/T> or engine-A/T-ECU <A/T>.</p> <p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON The throttle position sensor (1st channel) is normal. <p>Set Conditions</p> <ul style="list-style-type: none"> The sensor output voltage is 0.2 V or less for four seconds. <p>or</p> <ul style="list-style-type: none"> The sensor output voltage is 4.85 V or more for four seconds, and the output voltage of the throttle position sensor (1st channel) is 1.2 V or more. <p>or</p> <ul style="list-style-type: none"> The throttle position sensor (1st channel) and throttle position sensor (2nd channel) combination output voltage is outside 4 – 6 V. | <ul style="list-style-type: none"> Malfunction of throttle position sensor (2nd channel) Open or short circuit in the throttle position sensor (2nd channel) circuit or loose connector contact Malfunction of the throttle valve controller Malfunction of the engine-ECU <M/T> Malfunction of the engine-A/T-ECU <A/T> |



NOTE


*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)




NOTE

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)


| Code No. P0300 Ignition coil (power transistor) system | Probable cause |
|--|---|
| Range of Check <ul style="list-style-type: none"> • Engine speed is approx. 50 – 4,000 r/min. • Engine is not cranking. Set Conditions <ul style="list-style-type: none"> • The ignition failure sensor does not send a signal about a certain cylinder for four seconds. | <ul style="list-style-type: none"> • Malfunction of the ignition coil • Malfunction of the ignition failure sensor • Malfunction of spark plug • Open or short circuit in the primary ignition circuit or loose connector contact • Malfunction of engine-ECU <M/T> • Malfunction of engine-A/T-ECU <A/T> |




| Code No. P0301 No. 1 cylinder misfire detected Code No. P0302 No. 2 cylinder misfire detected Code No. P0303 No. 3 cylinder misfire detected Code No. P0304 No. 4 cylinder misfire detected | Probable cause |
|--|---|
| <p>Range of Check</p> <ul style="list-style-type: none"> • The engine speed is 500 – 4,500 r/min. • While the engine is running except deceleration and sudden acceleration. <p>Set Conditions</p> <ul style="list-style-type: none"> • The number of misfires exceeds a predetermined number per 200 engine revolutions (Misfire has occurred in only one cylinder). <p>or</p> <ul style="list-style-type: none"> • The number of misfires exceeds a predetermined number per 100 engine revolutions (Misfire has occurred in only one cylinder). | <ul style="list-style-type: none"> • Malfunction of the ignition system • Abnormal compression • Malfunction of injector • Malfunction of engine-ECU <M/T> • Malfunction of engine-A/T-ECU <A/T> |




| Code No. P0325 Detonation sensor system | Probable cause |
|--|---|
| Range of Check ● Engine: Two seconds after the engine has been started Set Conditions ● Changes in sensor output voltage (detonation sensor peak voltage per 1/3 crankshaft rotation) in 200 consecutive cycles are 0.08 V or less. | <ul style="list-style-type: none"> ● Malfunction of the detonation sensor ● Open or short circuit in the detonation sensor circuit or loose connector contact ● Malfunction of engine-ECU <M/T> ● Malfunction of engine-A/T-ECU <A/T> |




| Code No. P0335 Crank angle sensor system | Probable cause |
|--|---|
| Range of Check ● Engine is cranking Set Conditions ● Sensor output voltage does not change for 4 seconds (no pulse signal input). | <ul style="list-style-type: none"> ● Malfunction of the crank angle sensor. ● Open or short circuit in the crank angle sensor circuit or loose connector contact. ● Malfunction of engine-ECU <M/T> ● Malfunction of engine-A/T-ECU <A/T> |




| Code No. P0340 Camshaft position sensor system | Probable cause |
|--|--|
| Range of Check ● After the engine was started Set Conditions ● The sensor output voltage does not change for 4 seconds (no pulse signal input). | ● Malfunction of the camshaft position sensor ● Open or short circuit in the camshaft position sensor circuit or loose connector contact. ● Malfunction of engine-ECU <M/T> ● Malfunction of engine-A/T-ECU <A/T> |




| Code No. P0403 EGR valve system | Probable cause |
|--|--|
| <p>Range of Check</p> <ul style="list-style-type: none">● Ignition switch: OFF to ON● EGR valve is in operation after the engine starting process is complete. <p>Set Conditions</p> <ul style="list-style-type: none">● Off-surge voltage is not generated from the motor coil while the EGR valve control motor is running. | <ul style="list-style-type: none">● Malfunction of the EGR valve● Open or short circuit in the EGR valve circuit or loose connector contact● Malfunction of engine-ECU <M/T>● Malfunction of engine-A/T-ECU <A/T> |




| Code No. P0420 Catalyst malfunction | Probable cause |
|---|--|
| Range of Check <ul style="list-style-type: none"> • The engine speed is 3,000 r/min or less. • During driving • During air/fuel ratio feedback control Set Conditions <ul style="list-style-type: none"> • The ratio between the oxygen sensor (rear) and the oxygen sensor (front) output frequencies reaches 0.8 per 12 seconds on average. | <ul style="list-style-type: none"> • Malfunction of catalyst • Malfunction of the oxygen sensor (front) • Malfunction of the oxygen sensor (rear) • Malfunction of engine-ECU <M/T> • Malfunction of engine-A/T-ECU <A/T> |




| Code No. P0443 Purge control solenoid valve system | Probable cause |
|---|---|
| <p>Range of Check</p> <ul style="list-style-type: none"> ● Ignition switch: ON ● Battery voltage is 10 V or more. <p>Set Conditions</p> <ul style="list-style-type: none"> ● The solenoid coil surge voltage (battery voltage + 2 V) is not detected when the purge control solenoid valve is turned from on to off. | <ul style="list-style-type: none"> ● Malfunction of the purge control solenoid valve ● Open or short circuit in the purge control solenoid valve circuit or loose connector contact ● Malfunction of engine-ECU <M/T> ● Malfunction of engine-A/T-ECU <A/T> |




| Code No. P0500 Vehicle speed sensor system | Probable cause |
|---|---|
| <p>Range of Check</p> <ul style="list-style-type: none"> ● Engine: Two seconds after the engine was started ● Idle switch: OFF ● Engine speed: 2,500 r/min or more ● During high engine load <p>Set Conditions</p> <ul style="list-style-type: none"> ● The sensor output voltage does not change for 4 seconds (no pulse signal input). | <ul style="list-style-type: none"> ● Malfunction of the vehicle speed sensor ● Open or short circuit in the vehicle speed sensor circuit or loose connector contact ● Malfunction of engine-ECU <M/T> ● Malfunction of engine-A/T-ECU <A/T> |




| Code No. P1200 Injector driver system | Probable cause |
|--|---|
| <p>Range of Check</p> <ul style="list-style-type: none"> ● Engine speed: 4,000 r/m or less ● Battery voltage: 10 V or more ● The fuel cut operation and the injector operation (by carrying out the Actuator test) are not in progress. ● During high engine load <p>Set Conditions</p> <ul style="list-style-type: none"> ● Injector open circuit check signal is not output from the injector driver. | <ul style="list-style-type: none"> ● Malfunction of the injector driver ● Open or short circuit, or loose connector contact ● Malfunction of engine-ECU <M/T> ● Malfunction of engine-A/T-ECU <A/T> |



| Code No. P1220 Electronic-controlled throttle valve system | Probable cause |
|--|---|
| <p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON Error in communication between the engine-ECU <M/T> or engine-A/T-ECU <A/T> and the throttle valve controller <p>Set Conditions</p> <ul style="list-style-type: none"> Output voltage of throttle position sensor (2nd channel) fluctuates significantly (approx. 1 V or more) from an expected value, based on that of the accelerator pedal position sensor (2nd channel). <p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON Error in communication between the throttle valve controller and the engine-ECU <M/T> or engine-A/T-ECU <A/T> <p>Set Conditions</p> <ul style="list-style-type: none"> The output voltage of the throttle position sensor (2nd channel) is significantly different (approx. 1 V) from the throttle valve opening angle (voltage), which the engine-ECU <M/T> or engine-A/T-ECU <A/T> request the throttle valve controller. | <ul style="list-style-type: none"> Short in communication line Malfunction of the engine-ECU <M/T> Malfunction of the engine-A/T-ECU <A/T> Malfunction of the throttle valve controller |




| Code No. P1221 Throttle valve position feedback system | Probable cause |
|--|---|
| <p>The throttle valve controller judges a malfunction, and then transmit the result to the engine-ECU <M/T> or engine-A/T-ECU <A/T>.</p> <p>Range of Check</p> <ul style="list-style-type: none"> • Ignition switch: ON • Battery voltage: 10 V or more <p>Set Conditions</p> <ul style="list-style-type: none"> • Failure in the motor position feedback (The engine-ECU <M/T> or engine-A/T-ECU <A/T> detects that the current in the motor is excessive and the opening angle difference between the target value of throttle position sensor (1st channel) and the actual value of throttle position sensor (1st channel) is 1.0 V or more) | <ul style="list-style-type: none"> • Malfunction of throttle position sensor (1st channel) • Open or short circuit in the throttle position sensor (1st channel) circuit or loose connector contact • Malfunction of the throttle valve controller |




NOTE

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. P1223 Communication line system with the throttle valve controller | Probable cause |
|--|---|
| <p>Range of Check</p> <ul style="list-style-type: none"> ● Ignition switch: ON ● Battery voltage: 8 V or more. ● Engine: Not cranking <p>Set Conditions</p> <ul style="list-style-type: none"> ● System detects an error in communication line between the engine-ECU <M/T> or engine-A/T-ECU <A/T> and the throttle valve controller, and between the throttle valve controller and the engine-ECU <M/T> or engine-A/T-ECU <A/T>. | <ul style="list-style-type: none"> ● Short in communication line ● Malfunction of engine-ECU <M/T> ● Malfunction of engine-A/T-ECU <A/T> ● Malfunction of throttle valve controller |




| Code No. P1224 Throttle valve control servo motor (Motor 1st phase malfunction) system | Probable cause |
|--|---|
| <p>Range of Check</p> <ul style="list-style-type: none"> • Throttle valve control servo relay: ON • System voltage: 8 V or more. <p>Set Conditions</p> <ul style="list-style-type: none"> • Throttle valve control servo drive circuit is shorted to earth. • Other power source interferences with throttle valve control servo drive circuit. • Throttle valve control servo drive circuit is open circuit. | <ul style="list-style-type: none"> • Malfunction of the throttle valve control servo • Open circuit or short-circuited harness wire in throttle valve control servo system, or poor connector contact • Malfunction of the throttle valve controller |




NOTE


*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. P1225 Accelerator pedal position sensor (2nd channel) system | Probable cause |
|---|---|
| <p>Range of Check</p> <ul style="list-style-type: none"> Accelerator pedal position sensor (2nd channel) is normal. Communication between the engine-ECU <M/T> or engine-A/T-ECU <A/T> and the throttle valve controller is normal. <p>Set Conditions</p> <ul style="list-style-type: none"> Output voltage of the accelerator pedal position sensor (2nd channel) is 0.2 V or less for one second <p>or</p> <ul style="list-style-type: none"> Output voltage of the accelerator pedal position sensor (1st channel) is 2.5 V or less, and output voltage of the accelerator pedal position sensor (2nd channel) is 4.5 V or more for one second. <p>or</p> <ul style="list-style-type: none"> Difference between the accelerator pedal position sensor (1st and 2nd channels) output voltages exceeds 1.0 V (i.e. when the throttle valve opening angle changes slightly). | <ul style="list-style-type: none"> Malfunction of accelerator pedal position sensor (2nd channel) Open or short circuit in accelerator pedal position sensor (2nd channel) circuit or loose connector contact Malfunction of the throttle valve controller Malfunction of engine-ECU <M/T> Malfunction of engine-A/T-ECU <A/T> |






| Code No. P1228 Throttle valve control servo motor (Motor 2nd phase malfunction) system | Probable cause |
|--|---|
| <p>Range of Check</p> <ul style="list-style-type: none"> • Throttle valve control servo relay: ON • System voltage: 8 V or more <p>Set Conditions</p> <ul style="list-style-type: none"> • Throttle valve control servo drive circuit is shorted to earth. • Other power source interferes with throttle valve control servo drive circuit. • Throttle valve control servo drive circuit is open-circuit. | <ul style="list-style-type: none"> • Malfunction of the throttle valve control servo • Open circuit or short-circuited harness wire in throttle valve control servo system, or poor connector contact • Malfunction of the throttle valve controller |




NOTE


*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. P1500 Alternator FR terminal system | Probable cause |
|---|--|
| Range of Check ● Engine speed: 50 r/min or more Set Conditions ● Input voltage from the alternator FR terminal is system voltage for 20 seconds. | ● Open circuit in alternator FR terminal circuit ● Malfunction of engine-ECU <M/T> ● Malfunction of engine-A/T-ECU <A/T> |



| Code No. P1515 Brake vacuum sensor system | Probable cause |
|---|---|
| Range of Check ● Ignition switch: ON Set Conditions ● Sensor output voltage is 4.8 V or more. or ● Sensor output voltage is 0.2 V or less. | ● Malfunction of the brake vacuum sensor ● Improper connector contact, open circuit or short-circuited harness wire of the brake vacuum sensor ● Malfunction of the engine-ECU <M/T> ● Malfunction of the engine-A/T-ECU <A/T> |






| Cord No. P1610 Immobilizer system | Probable cause |
|--|---|
| Range of Check ● Ignition switch: ON Set Conditions ● Improper communication between the engine-ECU <M/T> or engine-A/T-ECU <A/T> and the immobilizer-ECU | ● Open or short circuit, or loose connector contact ● Malfunction of the immobilizer-ECU ● Malfunction of the engine-ECU <M/T> ● Malfunction of the engine-A/T-ECU <A/T> |

NOTE

- (1) If the registered ignition keys are close each other when starting the engine, radio interference may cause this code to be displayed.
- (2) This code may be displayed when registering the key ID code.




INSPECTION CHART FOR TROUBLE SYMPTOMS

| Trouble symptom | | Inspection procedure No. | Reference page |
|--|---|--------------------------|----------------|
| Communication with MUT-II is impossible. | Communication with all systems is not possible. | 1 | 13A-69 |
| | Communication with engine-ECU only is not possible. | 2 | 13A-71 |
| Engine warning lamp and related parts | The engine warning lamp does not illuminate right after the ignition switch is turned to the ON position. | 3 | 13A-70 |
| | The engine warning lamp remains illuminating and never goes out. | 4 | 13A-70 |
| Starting | No initial combustion (starting impossible) | 5 | 13A-71 |
| | Initial combustion but no complete combustion (starting impossible) | 6 | 13A-73 |
| | Long time to start (improper starting) | | |
| Idling stability (Improper idling) | Unstable idling (Rough idling, hunting) | 7 | 13A-74 |
| | Idling speed is high. (Improper idling speed) | 8 | 13A-76 |
| | Idling speed is low. (Improper idling speed) | | |
| Idling stability (Engine stalls) | When the engine is cold, it stalls at idling. (Die out) | 9 | 13A-77 |
| | When the engine is hot, it stalls at idling. (Die out) | 10 | 13A-78 |
| | The engine stalls when starting the car. (Pass out) | 11 | 13A-80 |
| | The engine stalls when decelerating. | 12 | 13A-81 |
| Driving | Hesitation, sag or stumble | 13 | 13A-82 |
| | Poor acceleration | | |
| | Surge | | |
| | The feeling of impact or vibration when accelerating | 14 | 13A-83 |
| | The feeling of impact or vibration when decelerating | 15 | 13A-84 |
| | Knocking | 16 | 13A-84 |
| Dieseling | | 17 | 13A-84 |
| Too high CO and HC concentration when idling | | 18 | 13A-85 |
| Low alternator output voltage (approx. 12.3 V) | | 19 | 13A-86 |
| Engine idle speed is incorrect while the A/C is on. | | 20 | 13A-87 |
| Fans (radiator fan, A/C condenser fan) are inoperative | | 21 | 13A-87 |
| Clutch switch system malfunction <M/T> | | 22 | 13A-88 |
| GDI ECO indicator lamp system | GDI ECO indicator lamp does not illuminate. | 23 | 13A-88 |
| | GDI ECO indicator lamp remains illuminated and does not go off. | 24 | 13A-89 |

INSPECTION PROCEDURE FOR TROUBLE SYMPTOMS


INSPECTION PROCEDURE 1

| Communication with MUT-II is not possible. (Communication with all systems is not possible.) | Probable cause |
|---|--|
| The cause is probably a defect in the power supply system (including earth) for the diagnosis line. | <ul style="list-style-type: none"> ● Malfunction of the connector ● Malfunction of the harness wire ● Malfunction of MUT-II |



INSPECTION PROCEDURE 2

| MUT-II communication with engine-ECU (engine-A/T-ECU) is impossible. | Probable cause |
|--|--|
| One of the following causes may be suspected. <ul style="list-style-type: none"> ● No power supply to engine-ECU <M/T> or engine-A/T-ECU <A/T>. ● Defective earth circuit of engine-ECU <M/T> or engine-A/T-ECU <A/T>. ● Defective engine-ECU <M/T> or engine-A/T-ECU <A/T>. ● Improper communication line between engine-ECU <M/T> or engine-A/T-ECU <A/T> and MUT-II | <ul style="list-style-type: none"> ● Malfunction of engine-ECU <M/T> or engine-A/T-ECU <A/T> power supply circuit ● Malfunction of engine-ECU <M/T> or engine-A/T-ECU <A/T> ● Open circuit between the engine-ECU <M/T> or engine-A/T-ECU <A/T> and diagnosis connector |




NOTE

On vehicles with multi center display, if a malfunction cannot be resolved after the procedure above, check the multi center display and replace if necessary. (Refer to GROUP 54 – Multi Center display.)


INSPECTION PROCEDURE 3

| The engine warning lamp does not illuminate right after the ignition switch is turned to the ON position. | Probable cause |
|---|--|
| Because there is a burnt-out bulb, the engine-ECU <M/T> or engine-A/T-ECU <A/T> causes the engine warning lamp to illuminate for five seconds immediately after the ignition switch is turned to ON. If the engine warning lamp does not illuminate immediately after the ignition switch is turned to ON, one of the malfunctions listed at right has probably occurred. | <ul style="list-style-type: none"> ● Burnt-out bulb ● Defective warning lamp circuit ● Malfunction of the engine-ECU <M/T> ● Malfunction of the engine-A/T-ECU <A/T> |




INSPECTION PROCEDURE 4

| The engine warning lamp remains illuminating and never goes out. | Probable cause |
|---|--|
| In cases such as the above, the cause is probably that the engine-ECU <M/T> or engine-A/T-ECU <A/T> is detecting a problem in a sensor or actuator, or that one of the malfunctions listed at right has occurred. | <ul style="list-style-type: none"> ● Short-circuit between the engine warning lamp and engine-ECU ● Malfunction of the engine-ECU <M/T> ● Malfunction of the engine-A/T-ECU <A/T> |




INSPECTION PROCEDURE 5

| No initial combustion (starting impossible) | Probable cause |
|---|---|
| This is caused by incorrect fuel supply into the combustion chamber, and improper ignition circuit. Besides that, foreign material may be contaminated in fuel. | <ul style="list-style-type: none"> ● Malfunction of the fuel supply system ● Malfunction of the ignition system ● Malfunction of the engine-ECU <M/T> ● Malfunction of the engine-A/T-ECU <A/T> |




NOTE

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)



INSPECTION PROCEDURE 6

| Initial combustion takes place, but does not complete (start impossible), too long time to start (poor start) | Probable cause |
|---|--|
| This may be caused by improper spark plug ignition (poor spark), improper mixture during engine cranking, improper fuel pressure. | <ul style="list-style-type: none"> ● Malfunction of the fuel supply system ● Malfunction of the fuel pressure sensor ● Malfunction of the ignition system ● Malfunction of the electronic-controlled throttle valve system ● Malfunction of the engine-ECU <M/T> ● Malfunction of the engine-A/T-ECU <A/T> |




NOTE

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)


INSPECTION PROCEDURE 7

| Unstable idling (rough idle, hunting) | Probable cause |
|--|--|
| This malfunction is probably caused by a faulty ignition system, improper air/fuel ratio, a faulty electronic-controlled throttle valve system, improper compression pressure, etc. As many causes can be suspected, diagnose from easier items. | <ul style="list-style-type: none"> ● Malfunction of the ignition system ● Malfunction of the air/fuel ratio control system ● Malfunction of the electronic-control throttle valve system ● Improper compression pressure ● Air sucking into the air intake system |



NOTE

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)




NOTE

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

INSPECTION PROCEDURE 8

| Idle speed is high or low (Improper idling) | Probable cause |
|---|--|
| The cause is probably that the intake air amount during idling is too great or too small. | <ul style="list-style-type: none"> • Malfunction of the electronic-controlled throttle valve system • Malfunction of the throttle body |




NOTE

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

INSPECTION PROCEDURE 9

| When the engine is cold, it stalls at idling. (Die out) | Probable cause |
|--|---|
| The cause is probably an incorrect air/fuel ratio or poor intake air amount when the engine is cold. | <ul style="list-style-type: none"> Malfunction of the electronic-control throttle valve system Malfunction of the throttle body |





NOTE

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

INSPECTION PROCEDURE 10

| When the engine is hot, it stalls at idling. (Die out) | Probable cause |
|--|---|
| <p>The cause is probably an improper air/fuel ratio, faulty electronic-controlled throttle valve system, compression pressure. In addition, if the engine stalls suddenly, another possible cause might be a poor connector contact.</p> | <ul style="list-style-type: none"> ● Malfunction of the ignition system ● Malfunction of air/fuel ratio control system ● Malfunction of electronic-controlled throttle valve system ● Malfunction of the throttle body ● Poor connector contact ● Improper compression pressure ● Air stuck in the air intake system |






NOTE

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)


INSPECTION PROCEDURE 11

| The engine stalls when starting the car. (Pass out) | Probable cause |
|--|--|
| The cause is probably poor ignition due to a malfunctioning spark plug (weak spark), or an incorrect air/fuel ratio when the accelerator is depressed. | <ul style="list-style-type: none"> ● Malfunction of the ignition system ● Malfunction of the EGR valve ● Air stuck in the air intake system |



INSPECTION PROCEDURE 12

| The engine stalls when decelerating. | Probable cause |
|---|--|
| The cause is probably an improper air/fuel ratio due to a faulty EGR system, or poor intake air volume due to a faulty electronic-controlled throttle valve system. | <ul style="list-style-type: none"> ● Malfunction of the electronic-controlled throttle valve system ● Malfunction of the EGR valve |





NOTE

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

INSPECTION PROCEDURE 13


| Hesitation, sag, stumble, poor acceleration or surge | Probable cause |
|---|---|
| The cause is probably a malfunction of the ignition system, electronic-controlled throttle valve system, compression pressure, etc. | <ul style="list-style-type: none"> Malfunction of the ignition system Malfunction of the air/fuel ratio control system Malfunction of the electronic-controlled throttle valve system Improper compression pressure Air stuck in the air intake system |






INSPECTION PROCEDURE 14

| The feeling of impact when accelerating | Probable cause |
|--|--|
| The cause is probably an ignition leak being generated in line with an increase in the spark plug request voltage during acceleration. | <ul style="list-style-type: none"> Malfunction of the ignition system |



INSPECTION PROCEDURE 15

| The feeling of impact when decelerating | Probable cause |
|--|--|
| The cause is probably insufficient intake air due to a faulty electronic-controlled throttle valve system. | <ul style="list-style-type: none"> Malfunction of the electronic-controlled throttle valve system |




NOTE

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

INSPECTION PROCEDURE 16

| Knocking | Probable cause |
|---|--|
| The cause is probably incorrect detonation control or improper heat range of the spark plugs. | <ul style="list-style-type: none"> Malfunction of the detonation sensor Improper heat range of the spark plugs |




INSPECTION PROCEDURE 17


| Run-on (dieseling) | Probable cause |
|--|---|
| The cause is probably fuel leak from injector(s) | <ul style="list-style-type: none"> Malfunction of the injector |

Replace the injector.

INSPECTION PROCEDURE 18


| Too high CO and HC concentration when idling | Probable cause |
|---|---|
| The cause is probably an incorrect air/fuel ratio | <ul style="list-style-type: none"> Malfunction of air/fuel ratio control system Deterioration of the catalyst |






INSPECTION PROCEDURE 19

| Low alternator output voltage (approx. 12.3 V) | Probable cause |
|---|---|
| The cause is probably a malfunction of the alternator or one of the problems listed at right. | <ul style="list-style-type: none"> ● Malfunction of the charging system ● Open circuit between the alternator G terminal and the engine-ECU <M/T> or engine-A/T-ECU <A/T> ● Malfunction of the engine-ECU <M/T> ● Malfunction of the engine-A/T-ECU <A/T> |




INSPECTION PROCEDURE 20

| Idling speed is improper when A/C is operating | Probable cause |
|--|---|
| <p>If the engine-ECU <M/T> or engine-A/T-ECU <A/T> detects that the air conditioner is on, it activates the throttle control servo to control idle-up operation. The A/C-ECU judges if the load caused by air conditioner operation is high or low, and converts it to voltage signal (high or low voltage) and inputs the signal to the engine-ECU <M/T> or engine-A/T-ECU <A/T>. Based on this voltage signal, the engine-ECU <M/T> or engine-A/T-ECU <A/T> controls the idle-up speed (for high or low load).</p> | <ul style="list-style-type: none"> • Malfunction of the A/C control system • Improper connector contact, open circuit or short-circuited harness wire • Malfunction of the engine-ECU <M/T> • Malfunction of the engine-A/T-ECU <A/T> |




INSPECTION PROCEDURE 21

| Fans (radiator fan, A/C condenser fan) are inoperative. | Probable cause |
|--|---|
| <p>The engine-ECU <M/T> or engine-A/T-ECU <A/T> sends a duty signal to the fan controller according to engine coolant temperature, vehicle speed, or A/C switch load. The fan controller controls radiator fan and condenser fan speeds, based on this signal. (The closer the terminal voltage comes to 5 V, the higher the fan speed becomes.)</p> | <ul style="list-style-type: none"> • Malfunction of the fan motor relay • Malfunction of the fan motor • Malfunction of the fan controller • Open or short circuit, or poor connector contact • Malfunction of the engine-ECU <M/T> • Malfunction of the engine-A/T-ECU <A/T> |



INSPECTION PROCEDURE 22

| Clutch switch system malfunction <M/T> | Probable cause |
|---|--|
| The clutch pedal switch sends a signal indicating clutch pedal depression to the engine-ECU. The engine-ECU controls the fuel injection properly according to this signal, thus prevents the fluctuation of the engine speed during shift change. | <ul style="list-style-type: none"> • Malfunction of the clutch switch • Open circuit or short-circuited harness wire in the clutch switch circuit • Malfunction of the engine-ECU |




NOTE

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)


INSPECTION PROCEDURE 23

| GDI ECO indicator lamp does not illuminate. | Probable cause |
|--|--|
| If the GDI ECO indicator lamp does not illuminate after turning switch, the causes listed in the right column are suspected. | <ul style="list-style-type: none"> • Burned-out GDI ECO indicator lamp bulb • Open circuit or short-circuited harness wire in the GDI ECO indicator lamp circuit • Malfunction of the engine-ECU <M/T> • Malfunction of the engine-A/T-ECU <A/T> |



INSPECTION PROCEDURE 24


| GDI ECO indicator lamp remains illuminated and does not go off. | Probable cause |
|--|---|
| If the GDI ECO indicator lamp does not go off during high load operation, the causes listed in the right column are suspected. | <ul style="list-style-type: none"> ● Short circuit between the GDI ECO indicator lamp and engine-ECU ● Malfunction of the engine-ECU <M/T> ● Malfunction of the engine-A/T-ECU <A/T> |




INSPECTION PROCEDURE 25

| Engine-ECU (engine-A/T-ECU) power supply and earth circuit system | Probable cause |
|---|---|
| The cause is probably a malfunction of the engine-ECU <M/T> or engine-A/T-ECU <A/T> or one of the problems listed at right. | <ul style="list-style-type: none"> • Open circuit or short-circuited harness wire in the engine-ECU <M/T> or engine-A/T-ECU <A/T> power supply circuit • Open circuit or short-circuited harness wire in the engine-ECU <M/T> or engine-A/T-ECU <A/T> earth circuit • Malfunction of the engine-ECU <M/T> • Malfunction of the engine-A/T-ECU <A/T> |

<M/T>




<A/T>



INSPECTION PROCEDURE 26

| Engine control relay and ignition switch-IG system | Probable cause |
|--|---|
| When the ignition switch ON signal is input to the engine-ECU <M/T> or engine-A/T-ECU <A/T>, the engine-ECU <M/T> or engine-A/T-ECU <A/T> turns on the engine control relay. This causes system voltage to be supplied to the engine-ECU <M/T> or engine-A/T-ECU <A/T> and to the sensors and actuators. | <ul style="list-style-type: none"> Malfunction of the ignition switch Malfunction of the engine control relay Open circuit or short-circuited harness wire of the engine control relay circuit Malfunction of the engine-ECU <M/T> Malfunction of the engine-A/T-ECU <A/T> |




NOTE

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

INSPECTION PROCEDURE 27

| Injector driver relay system | Probable cause |
|--|---|
| When the ignition switch ON signal is input to the engine-ECU <M/T> or the engine -A/T-ECU <A/T>, engine-ECU <M/T> or the engine -A/T-ECU <A/T> turns on the injector driver relay. This causes system voltage to be supplied to the injector driver. | <ul style="list-style-type: none"> ● Malfunction of the injector driver relay ● Improper connector contact, open circuit or short-circuited harness wire ● Malfunction of the engine-ECU <M/T> or engine-A/T-ECU <A/T> |




NOTE

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)


INSPECTION PROCEDURE 28

| Ignition switch-ST system | Probable cause |
|--|--|
| The ignition switch-ST outputs a HIGH signal to the engine-ECU <M/T> or engine-A/T-ECU <A/T> while the engine is cranking. The engine-ECU <M/T> or engine-A/T-ECU <A/T> uses this signal to carry out functions such as fuel injection control during starting. | <ul style="list-style-type: none"> ● Malfunction of the ignition switch ● Malfunction of the inhibitor switch <A/T> ● Open circuit or short-circuited harness wire of the ignition switch circuit ● Malfunction of the engine-ECU <M/T> ● Malfunction of the engine-A/T-ECU <A/T> |

<M/T>




<A/T>




INSPECTION PROCEDURE 29

| Accelerator pedal position switch system | Probable cause |
|--|---|
| <p>The accelerator pedal position switch detects that the accelerator pedal is fully closed, and sends a signal to the engine-ECU <M/T> or engine-A/T-ECU <A/T>. The engine-ECU <M/T> or engine-A/T-ECU <A/T> controls idle speed, based on this signal.</p> | <ul style="list-style-type: none"> ● Maladjustment of the accelerator cable ● Maladjustment of the accelerator pedal position switch ● Open circuit or short-circuited harness wire in the accelerator pedal position switch system, or poor connector contact ● Malfunction of the engine-ECU <M/T> ● Malfunction of the engine-A/T-ECU <A/T> |



INSPECTION PROCEDURE 30

| Fuel pump (low pressure) system | Probable cause |
|---|--|
| The engine-ECU <M/T> or engine-A/T-ECU <A/T> turns on the fuel pump relay while the engine is cranking or running, and supplies power source to the fuel pump (low pressure). | <ul style="list-style-type: none"> • Malfunction of the fuel pump relay • Malfunction of the fuel pump (low pressure) • Open circuit or short-circuited harness wire in the fuel pump (low pressure) circuit, or poor connector contact • Malfunction of the engine-ECU <M/T> • Malfunction of the engine-A/T-ECU <A/T> |




NOTE

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)


INSPECTION PROCEDURE 31

| Power steering fluid pressure switch system | Probable cause |
|---|--|
| <p>The power steering fluid pressure switch sends a signal to the engine-ECU <M/T> or engine-A/T-ECU <A/T> according to power steering load. Based on this signal, the engine-ECU <M/T> or engine-A/T-ECU <A/T> controls the throttle control servo so that idle speed increases when the power steering is in operation.</p> | <ul style="list-style-type: none"> ● Malfunction of the power steering fluid pressure switch ● Open circuit or short-circuited harness wire in the power steering fluid pressure switch circuit, or poor connector contact ● Malfunction of the engine-ECU <M/T> ● Malfunction of the engine-A/T-ECU <A/T> |




INSPECTION PROCEDURE 32

| A/C switch and A/C relay system | Probable cause |
|--|---|
| <p>If the engine-ECU receives a 'A/C on' signal, it operates the throttle control servo and A/C compressor magnetic clutch so that idle speed increases.</p> | <ul style="list-style-type: none"> ● Malfunction of the A/C control system ● Malfunction of the A/C switch ● Open circuit or short-circuited harness wire in the A/C switch circuit, or poor connector contact ● Malfunction of the engine-ECU <M/T> ● Malfunction of the engine-A/T-ECU <A/T> |




INSPECTION PROCEDURE 33

| M/T oil temperature sensor system | Probable cause |
|--|--|
| This sensor inputs the manual transmission oil temperature to the engine-ECU. The engine-ECU uses this input to control the idle speed control servo so that the idle speed is increased when the manual transmission oil temperature becomes low. | <ul style="list-style-type: none"> ● Malfunction of the M/T oil temperature sensor ● Open circuit or short-circuited harness wire in the M/T oil temperature sensor circuit ● Malfunction of the engine-ECU |




INSPECTION PROCEDURE 34

| Stop lamp switch system | Probable cause |
|---|---|
| The engine-ECU <M/T> or engine-A/T-ECU <A/T> determines whether the brake pedal is depressed or not, by means of the stop lamp switch input signal. | <ul style="list-style-type: none"> • Malfunction of the stop lamp switch • Open circuit or short-circuited harness wire in the stop lamp circuit, or poor connector contact • Malfunction of the engine-ECU <M/T> • Malfunction of the engine-A/T-ECU <A/T> |



INSPECTION PROCEDURE 35

| Small lamp switch system | Probable cause |
|---|--|
| The engine-ECU <M/T> or engine-A/T-ECU <A/T> determines whether the small lamp switch is on or off. According to that information, the engine-ECU <M/T> or engine-A/T-ECU <A/T> controls alternator output current when the vehicle is started. | <ul style="list-style-type: none"> • Improper connector contact, open circuit or short-circuited harness wire in the taillamp circuit • Malfunction of the engine-ECU <M/T> • Malfunction of the engine-A/T-ECU <A/T> |



DATA LIST REFERENCE TABLE

Caution

When shifting the select lever to D range, the brakes should be applied so that the vehicle does not move forward.

NOTE

*1: Within four minutes after starting the engine

*2: In a new vehicle [driven approximately 500 km or less], the injector drive time is sometimes 10 % longer than the standard time.

*3: The accelerator pedal position switch normally turns off when the voltage of the accelerator pedal position sensor (1st channel) is 200 – 600 mV higher than the voltage at the idle position. If the accelerator pedal position switch turns back on after the accelerator pedal position sensor voltage has risen by 100 mV and the throttle valve has opened, the accelerator pedal position switch and the accelerator pedal position sensor (1st channel) need to be adjusted.

| Item No. | Check items | Requirements | Normal condition | Inspection procedure No. | Reference page | |
|----------|-------------------------------|---|-------------------------------|---|----------------|--------|
| 11 | Oxygen sensor (front) | Engine: warm-up After | Idling | 200 mV or less*1 | Code No. P0130 | 13A-26 |
| | | | Sudden racing | 600 – 1,000 mV | | |
| | | | 2,500 r/min | 400 mV or less and 600 – 1,000 mV alternates. | | |
| 12 | Air flow sensor | <ul style="list-style-type: none"> • Engine coolant temperature: 80 – 95°C • Lamps, electric cooling fan and all accessories: OFF • Transmission: Neutral (A/T: P range) | Idling | 27 – 53 Hz | Code No. P0100 | 13A-14 |
| | | | 2,500 r/min | 55 – 95 Hz | | |
| | | | Racing | Frequency increases in response to racing. | | |
| 13 | Intake air temperature sensor | Ignition switch: ON | Intake air temperature: –20°C | –20°C | Code No. P0110 | 13A-18 |
| | | | Intake air temperature: 0°C | 0°C | | |
| | | | Intake air temperature: 20°C | 20°C | | |
| | | | Intake air temperature: 40°C | 40°C | | |
| | | | Intake air temperature: 80°C | 80°C | | |

| Item No. | Check items | Requirements | Normal condition | Inspection procedure No. | Reference page | |
|----------|--|---|---|--|------------------|--------|
| 14 | Throttle position sensor (2nd channel) | <ul style="list-style-type: none"> Engine coolant temperature: 80 – 95°C Ignition switch: ON (Engine stopped) | Release the accelerator pedal. | 4,500 – 5,500 | Code No. P0225 | 13A-44 |
| | | | Depress the accelerator pedal gradually. | Voltage decreases in response to the pedal depression. | | |
| | | | Depress the accelerator pedal fully. | 400 – 600 mV | | |
| 16 | Power supply voltage | Ignition switch: ON | System voltage | Procedure No. 25 | 13A-90 | |
| 18 | Cranking signal (Ignition switch – ST) | Transmission: Neutral (A/T: P range) | Engine: Stopped | OFF | Procedure No. 28 | 13A-93 |
| | | | Engine: Cranking | ON | | |
| 21 | Engine coolant temperature sensor | Ignition switch: ON | Engine coolant temperature: –20°C | –20°C | Code No. P0115 | 13A-19 |
| | | | Engine coolant temperature: 0°C | 0°C | | |
| | | | Engine coolant temperature: 20°C | 20°C | | |
| | | | Engine coolant temperature: 40°C | 40°C | | |
| | | | Engine coolant temperature: 80°C | 80°C | | |
| 22 | Crank angle sensor | <ul style="list-style-type: none"> Engine: Cranking Tachometer: Connected | Compare the engine speed readings on the tachometer and the MUT-II. | Accord | Code No. P0335 | 13A-48 |
| | | | <ul style="list-style-type: none"> Engine: Idling Accelerator pedal position switch: ON | Engine coolant temperature: –20°C | | |
| | | Engine coolant temperature: 0°C | | 1,100 – 1,300 r/min | | |
| | | Engine coolant temperature: 20°C | | 1,000 – 1,200 r/min | | |
| | | Engine coolant temperature: 40°C | | 800 – 1,000 r/min | | |
| | | Engine coolant temperature: 80°C | 550 – 650 <M/T> r/min*1 600 – 700 <A/T> r/min*1 | | | |
| 24 | Vehicle speed sensor | Drive at 40 km/h | Approximately 40 km/h | Code No. P0500 | 13A-56 | |

| Item No. | Check items | Requirements | Normal condition | Inspection procedure No. | Reference page | |
|----------|--------------------------------------|---|---|---|------------------|--------|
| 25 | Barometric pressure sensor | Ignition switch: ON | Altitude: 0 m | 101 kPa | Code No. P0105 | 13A-16 |
| | | | Altitude: 600 m | 95 kPa | | |
| | | | Altitude: 1,200 m | 88 kPa | | |
| | | | Altitude: 1,800 m | 81 kPa | | |
| 26 | Accelerator pedal position switch | Ignition switch: ON (Depress and release the accelerator pedal several times) | Release the accelerator pedal. | ON | Procedure No. 29 | 13A-94 |
| | | | Depress the accelerator pedal slightly. | OFF | | |
| 27 | Power steering fluid pressure switch | Engine: Idling | Steering wheel stationary | OFF | Procedure No. 31 | 13A-96 |
| | | | Steering wheel turning | ON | | |
| 28 | A/C switch | Engine: Idling (The A/C compressor is running when the A/C switch is on.) | A/C switch: OFF | OFF | Procedure No. 32 | 13A-96 |
| | | | A/C switch: ON | ON | | |
| 31 | Small lamp switch | Engine: Idling | Lighting switch: OFF | OFF | Procedure No. 35 | 13A-98 |
| | | | Lighting switch: ON | ON | | |
| 34 | Air flow sensor reset signal | Engine: After having warmed up | Engine is idling | ON | Code No. P0100 | 13A-14 |
| | | | 3,000 r/min | OFF | | |
| 37 | Volumetric efficiency | <ul style="list-style-type: none"> Engine coolant temperature: 80 – 95°C Lamps, electric cooling fan and all accessories: OFF Transmission: Neutral (A/T: P range) | Engine is idling | 15 – 35 % | – | – |
| | | | 2,500 r/min | 15 – 35 % | | |
| | | | Engine is suddenly raced | Volumetric efficiency increases in response to racing | | |
| 38 | Crank angle sensor | <ul style="list-style-type: none"> Engine: Cranking [reading is possible at 2,000 r/min or less] Tachometer: Connected | Engine speeds displayed on the MUT-II and tachometer are identical. | – | – | |

| Item No. | Check items | Requirements | Normal condition | Inspection procedure No. | Reference page | |
|----------|----------------------------|---|--|--|------------------|--------|
| 41 | Injector drive time*2 | <ul style="list-style-type: none"> Engine coolant temperature: 80 – 95°C Lamps, electric cooling fan and all accessories: OFF Transmission: Neutral (A/T: P range) | Idling | 0.5 – 0.7 ms*1 | – | – |
| | | | 2,500 r/min | 0.6 – 0.8 ms | | |
| | | | Sudden racing | Increases | | |
| 44 | Ignition advance | <ul style="list-style-type: none"> Engine: After warm-up Set a timing light. | Idling | 12 – 20° BTDC*1 | Code No. P0300 | 13A-45 |
| | | | 2,500 r/min | 20 – 40° BTDC | | |
| 48 | M/T oil temperature sensor | Drive after the engine has warmed up. | Drive for 15 minutes or more | Gradually increases to 50 – 90°C | Procedure No. 33 | 13A-97 |
| 49 | A/C relay | Engine: After warm-up, idling | A/C switch: OFF | OFF (compressor clutch is not operating) | Procedure No. 32 | 13A-96 |
| | | | A/C switch: ON | ON (compressor clutch is operating) | | |
| 59 | Oxygen sensor (rear) | <ul style="list-style-type: none"> Transmission: 2nd gear (A/T: L range) Drive with throttle widely open | 3,500 r/min | 600 – 1,000 mV | Code No. P0136 | 13A-29 |
| 66 | Brake vacuum sensor | <ul style="list-style-type: none"> Engine coolant temperature: 80 – 95°C Lamps, electric cooling fan and all accessories: OFF Transmission: Neutral (A/T: P range) | Stop the engine from idling speed, and then depress the brake pedal several times with the ignition switch on. | Displayed pressure increases. | Code No. P1515 | 13A-65 |
| 67 | Stop lamp switch | Ignition switch: ON | Brake pedal: Depressed | OFF | Procedure No. 34 | 13A-98 |
| | | | Brake pedal: Released | ON | | |
| 68 | EGR valve | <ul style="list-style-type: none"> Engine coolant temperature: 80 – 95°C Lamps, electric cooling fan and all accessories: OFF Transmission: Neutral (A/T: P range) | Idling | 2 – 20 STEP | Code No. P0403 | 13A-52 |
| | | | 2,500 r/min | 0 – 10 STEP | | |

| Item No. | Check items | Requirements | Normal condition | Inspection procedure No. | Reference page | |
|----------|---|---|--|---|----------------|--------|
| 74 | Fuel pressure sensor | <ul style="list-style-type: none"> Engine coolant temperature: 80 – 95°C Lamps, electric cooling fan and all accessories: OFF Transmission: Neutral (A/T: P range) | Engine: Idling | 4 – 6.9 MPa | Code No. P0190 | 13A-34 |
| 77 | Accelerator pedal position sensor (2nd channel)* ³ | Ignition switch: ON | Release the accelerator pedal. | 985 – 1,085 mV | Code No. P1225 | 13A-61 |
| | | | Depress the accelerator pedal gradually. | Increases in response to the pedal depression stroke. | | |
| | | | Depress the accelerator pedal fully. | 4,000 mV or more | | |
| 78 | Accelerator pedal position sensor (1st channel)* ³ | Ignition switch: ON | Release the accelerator pedal. | 985 – 1,085 mV | Code No. P0220 | 13A-41 |
| | | | Depress the accelerator pedal gradually. | Increases in response to pedal depression stroke. | | |
| | | | Depress the accelerator pedal fully. | 4,000 mV or more | | |
| 79 | Throttle position sensor (1st channel) | <ul style="list-style-type: none"> Engine coolant temperature: 80 – 95°C Ignition switch: ON (Engine stopped) | Release the accelerator pedal. | 450 – 800 mV | Code No. P0120 | 13A-22 |
| | | | Depress the accelerator pedal gradually. | Increases in response to pedal depression stroke. | | |
| | | | Depress the accelerator pedal fully. | 4,200 – 4,900 mV | | |
| | | Engine: After warm-up, idling | No load | 450 – 1,000 mV | | |
| | | A/C switch: OFF → ON | Increases by 100 – 600 mV. | | | |
| 81 | Long-term fuel compensation | Engine: Warm, 2,500 r/min without any load (during closed loop) | | -12.5 – 12.5 % | Code No. P0170 | 13A-32 |
| 82 | Short-term fuel compensation | Engine: Warm, 2,500 r/min without any load (during closed loop) | | -30 – 25 % | Code No. P0170 | 13A-32 |

| Item No. | Check items | Requirements | | Normal condition | Inspection procedure No. | Reference page |
|----------|---|---|--|--|--------------------------|----------------|
| 85 | Fuel pressure sensor | <ul style="list-style-type: none"> Engine coolant temperature: 80 – 95°C Lamps, electric cooling fan and all accessories: OFF Transmission: Neutral (A/T: P range) | Engine: Idling | 4,000 – 6,900 kPa | – | – |
| 87 | Calculation load value | Engine: Warm | Engine: Idling | 15 – 35 % | – | – |
| | | | 2,500 r/min | 15 – 35 % | | |
| 88 | Fuel control condition | Engine: Warm | 2,500 r/min | Closed loop | Code No. P0125 | 13A-24 |
| | | | When engine is suddenly raced | Open loop – drive condition | | |
| 99 | Fuel injection mode | Engine: After warm up | Idling (after four minutes or more have passed since engine start) | Lean compression | – | – |
| | | | 2,500 r/min | Stoichiometric metric feedback | | |
| | | | Sudden racing after idle position | Open loop | | |
| A1 | Oxygen sensor (front) | Engine: After warm-up | Idling | 0 V | Code No. P0130 | 13A-26 |
| | | | Sudden racing | 0.6 – 1.0 V | | |
| | | | 2,500 r/min | 0.4 V or less and 0.6 – 1.0 V alternates | | |
| A2 | Oxygen sensor (rear) | <ul style="list-style-type: none"> Transmission: 2nd gear <M/T>, L range <A/T> Drive with throttle widely open | 3,500 r/min | 0.6 – 1.0 V | Code No. P0136 | 13A-29 |
| 8A | Throttle position sensor (1st channel) (Throttle valve opening angle) | <ul style="list-style-type: none"> Engine coolant temperature: 80 – 95°C Ignition switch: ON (Engine: stopped) | Release the accelerator pedal. | 8 – 16 % | Code No. P0120 | 13A-22 |
| | | | Depress the accelerator pedal gradually. | Increase in response to pedal depression stroke. | | |
| | | | Depress the accelerator pedal fully. | 80 – 100 % | | |
| | | Engine: After warm-up, idling | No load | 8 – 18 % | | |
| | | A/C switch: OFF → ON | Rises by 2 – 10 % | | | |


ACTUATOR TEST REFERENCE TABLE

| Item No. | Inspection item | Drive contents | Inspection contents | Normal condition | Inspection procedure No. | Reference page |
|----------|---|---|---|--|--------------------------|----------------|
| 01 | Injectors | Cut fuel to No. 1 injector | Engine: After having warmed up/Engine is idling (Cut the fuel supply to each injector in turn and check cylinders which don't affect idling.) | Idling condition becomes different (becomes unstable). | Code No. P0201 | 13A-35 |
| 02 | | Cut fuel to No. 2 injector | | | Code No. P0202 | 13A-37 |
| 03 | | Cut fuel to No. 3 injector | | | Code No. P0203 | 13A-38 |
| 04 | | Cut fuel to No. 4 injector | | | Code No. P0204 | 13A-39 |
| 07 | Fuel pump (low pressure) | Fuel pump operates and fuel is recirculated. | Ignition switch: ON | Sound of operation is heard. | Procedure No. 30 | 13A-95 |
| 08 | Purge control solenoid valve | Solenoid valve turns from OFF to ON. | Ignition switch: ON | Sound of operation can be heard when solenoid valve is driven. | Code No. P0443 | 13A-55 |
| 17 | Basic ignition timing | Set the engine-ECU <M/T> or engine-A/T-ECU <A/T> to ignition timing adjustment mode | Idling after engine warm up | 5° BTDC | – | – |
| 21 | Fan controller | Drive the fan motor | Ignition switch: ON | The fan motor operates | Procedure No. 21 | 13A-87 |
| 34 | Electronic-controlled throttle valve system | Stop the throttle control servo. | Ignition switch: ON | Throttle valve is opened slightly. | Code No. P1220 | 13A-57 |

CHECK AT THE ENGINE-ECU TERMINALS <M/T>

TERMINAL VOLTAGE CHECK CHART

Engine-ECU Connector Terminal Arrangement



7FU2119

| Terminal No. | Check item | Check requirements (engine condition) | Normal condition | |
|--------------|------------------------------|--|---|-------------------|
| 1 | No. 1 injector | Engine: Warm up, and then depress the accelerator pedal suddenly from the idle speed. | Decreases slightly for short time from 9 – 13 V | |
| 9 | No. 2 injector | | | |
| 24 | No. 3 injector | | | |
| 2 | No. 4 injector | | | |
| 3 | No. 1 ignition coil | Engine: 3,000 r/min | 0.3 – 3.0 V | |
| 13 | No. 2 ignition coil | | | |
| 12 | No. 3 ignition coil | | | |
| 4 | No. 4 ignition coil | | | |
| 5 | EGR valve (D) | Ignition switch: Immediately after turning ON | 5 – 8 V (fluctuates for approx. three seconds) | |
| 6 | EGR valve (C) | | | |
| 32 | EGR valve (B) | | | |
| 34 | EGR valve (A) | | | |
| 8 | Alternator G terminal | <ul style="list-style-type: none"> Engine: Warm up, and then idling Radiator fan: Not operating Headlamp: OFF → ON Stop lamp: OFF → ON Rear defogger switch: OFF → ON | Voltage increases by 0.2 – 3.5 V | |
| 14 | GDI ECO indication lamp | Ignition switch: OFF → ON | 0 – 3 V (System voltage after five seconds) | |
| | | Engine: When the accelerator pedal is suddenly depressed while the engine is idling | System voltage | |
| 16 | Purge control solenoid valve | <ul style="list-style-type: none"> Engine coolant temperature: 80 – 95°C Ignition switch: ON | Engine: Stopped | System voltage |
| | | | Engine: Start the engine, and then increase engine speed up to 3,500 r/min. | Voltage decreases |

| Terminal No. | Check item | Check requirements (engine condition) | | Normal condition |
|--------------|---|---|----------------------------------|--|
| 18 | Fan controller | Radiator and condenser fans are not operating. | | 0 – 0.3 V |
| | | Radiator and condenser fans are operating. | | 0.7 V or more |
| 20 | A/C relay | <ul style="list-style-type: none"> ● Engine: Idling ● A/C switch: OFF → ON (Compressor is operating) | | System voltage, or changes from momentarily 6 V or more to 0 → 3 V |
| 21 | Fuel pump relay | Ignition switch: ON | Engine: Stopped | System voltage |
| | | | Engine: Idling | 0 – 3 V |
| 31 | Engine warning lamp | Ignition switch: OFF → ON | | 0 – 3 V → System voltage (after several seconds) |
| 41 | Sensor power supply | Ignition switch: ON | | 4.5 – 5.5 V |
| 42 | Power supply to accelerator pedal position sensor (1st channel) | Ignition switch: ON | | 4.5 – 5.5 V |
| 43 | Crank angle sensor | Engine: Cranking | | 0.4 – 4.0 V |
| | | Engine: Idling | | 1.5 – 2.5 V |
| 44 | Engine coolant temperature sensor | Ignition switch: ON | Engine coolant temperature: 0°C | 3.2 – 3.5 V |
| | | | Engine coolant temperature: 20°C | 2.3 – 2.9 V |
| | | | Engine coolant temperature: 40°C | 1.5 – 2.1 V |
| | | | Engine coolant temperature: 80°C | 0.4 – 1.0 V |
| 45 | Engine ignition signal | Engine: 3,000 r/min | | 0.3 – 3.0 V |
| 47 | Power supply | Ignition switch: ON | | System voltage |
| 59 | | | | |
| 50 | Camshaft position sensor | Engine: Cranking | | 0.4 – 3.0 V |
| | | Engine: Idling | | 0.5 – 2.0 V |
| 51 | Barometric pressure sensor | Ignition switch: ON | Altitude: 0 m | 3.7 – 4.3 V |
| | | | Altitude: 1,200 m | 3.2 – 3.8 V |
| 52 | Alternator FR terminal | <ul style="list-style-type: none"> ● Engine: Warm up, and then idling ● Radiator fan: Not operating ● Headlamp: OFF → ON ● Stop lamp: OFF → ON ● Rear defogger: OFF → ON | | Voltage decreases |

| Terminal No. | Check item | Check requirements (engine condition) | Normal condition | |
|--------------|--------------------------------------|--|---|-------------|
| 53 | Oxygen sensor (rear) | <ul style="list-style-type: none"> • Transmission: 2nd gear • Engine speed: 3,500 r/min or more • Driving with the throttle valve widely open | 0.6 – 1.0 V | |
| 54 | Power steering fluid pressure switch | Engine: Warm up, and then idling | Steering wheel stationary System voltage | |
| | | | Steering wheel turning 0 – 3 V | |
| 55 | Injector driver relay | Ignition switch: OFF | 0 – 0.1 V | |
| | | Ignition switch: ON | 0.5 – 1.0 V | |
| 56 | Throttle valve control servo relay | Ignition switch: OFF | 0 – 0.3 V | |
| | | Ignition switch: ON | 0.5 – 1.0 V | |
| 57 | Engine control relay | Ignition switch: OFF | 0 – 3 V | |
| | | Ignition switch: ON | System voltage | |
| 60 | Back-up power source | Ignition switch: OFF | System voltage | |
| 61 | Air flow sensor | Engine: Idling | 2.2 – 3.2 V | |
| | | Engine: 2,500 r/min | | |
| 62 | Intake air temperature sensor | Ignition switch: ON | Intake air temperature: 0°C | 3.2 – 3.8 V |
| | | | Intake air temperature: 20°C | 2.3 – 2.9 V |
| | | | Intake air temperature: 40°C | 1.5 – 2.1 V |
| | | | Intake air temperature: 80°C | 0.4 – 1.0 V |
| 63 | Stop lamp switch | Depress the brake pedal. | System voltage | |
| | | Release the brake pedal. | 0 – 3 V | |
| 65 | A/C switch (2nd channel) | Refer to GROUP 55 – Troubleshooting “Check at the A/C-ECU terminal, engine-ECU output terminals.” | | |
| 66 | Clutch switch | Depress the clutch pedal. | 0 – 3 V | |
| | | Release the clutch pedal. | System voltage | |
| 68 | Ignition switch-ST | Engine: Cranking | 8 V or more | |
| 71 | Oxygen sensor (front) | Engine: Warm up, and then hold the engine speed at 2,500 r/min (Use a digital voltmeter). | 0 ↔ 0.8 V alternates. | |
| 73 | M/T oil temperature sensor | M/T oil temperature: 25°C | 2.4 – 2.7 V | |
| | | M/T oil temperature: 80°C | 0.5 – 0.8 V | |

| Terminal No. | Check item | Check requirements (engine condition) | | Normal condition |
|--------------|---|---|--|--|
| 74 | Brake vacuum sensor | Engine: Stop the engine from idle speed, turn the ignition switch ON, and then depress the brake pedal several times. | | Voltage increases |
| 76 | Air flow sensor reset signal | Engine: Idling | | 0 – 1 V |
| | | Engine: 3,000 r/min | | 6 – 9 V |
| 78 | Throttle position sensor (2nd channel) | Ignition switch: ON | Release the accelerator pedal. | 4.5 – 5.5 V |
| | | | Depress the accelerator pedal fully. | 0.4 – 0.6 V |
| 79 | Accelerator pedal position switch | Ignition switch: ON | Release the accelerator pedal. | 0 – 1 V |
| | | | Depress the accelerator pedal fully. | 4 V or more |
| 80 | Vehicle speed sensor | <ul style="list-style-type: none"> ● Ignition switch: ON ● Move the vehicle forward. | | 0 ↔ system voltage alternates. |
| 83 | A/C switch (1st channel) | Engine: Idling | A/C switch: OFF | 0 – 3 V |
| | | | A/C switch: ON (Compressor is operating) | System voltage |
| 88 | Small lamp switch | Lighting switch: OFF | | 0 – 3 V |
| | | Lighting switch: ON (Taillamp: ON) | | System voltage |
| 89 | Oxygen sensor heater (front) | Engine: Idling | | 0 – 3 V |
| | | Engine: 3,500 r/min | | System voltage |
| 90 | Oxygen sensor heater (rear) | Engine: Idling | | 0 – 3 V |
| | | Engine: 3,500 r/min | | System voltage |
| 92 | Fuel pressure sensor | Engine: Idling | | 0.3 – 4.7 V |
| 94 | Accelerator pedal position sensor (1st channel) | Ignition switch: ON | Release the accelerator pedal. | 0.985 – 1.085 V* ¹ |
| | | | Depress the accelerator pedal fully. | 4 V or more* ² |
| 96 | Injector open circuit check signal | Engine: Increase engine speed from idle speed to 4,000 r/min. | | Decreases slightly (approx. 0.7 V) from 4.5 V – 5.0 V. |
| 99 | Ignition switch-IG | Ignition switch: ON | | System voltage |

NOTE

Check if the difference in output between *1 and *2 is 4 V or more.

**CHECK CHART FOR RESISTANCE AND CONTINUITY
BETWEEN TERMINALS**

1. Turn the ignition switch to OFF.
2. Disconnect the engine-ECU connector.
3. Measure the resistance and check for continuity between the terminals of the engine-ECU harness-side connector while referring to the check chart.

NOTE


- (1) When measuring resistance and checking continuity, a harness for checking contact pin pressure should be used instead of inserting a test probe.
- (2) Checking need not be carried out in the order given in the chart.

Caution

**If the terminals that should be checked are mistaken, or if connector terminals are not correctly shorted to earth, damage may be caused to the vehicle wiring, sensors, engine-ECU and/or ohmmeter.
Be careful to prevent this!**

4. If the ohmmeter shows any deviation from the standard value, check the corresponding sensor, actuator and related electrical wiring, and then repair or replace.
5. After repair or replacement, recheck with the ohmmeter to confirm that the repair or replacement has corrected the problem.

Engine-ECU Harness Side Connector Terminal Arrangement



| Terminal No. | Check item | Standard value, normal condition (check requirements) |
|-----------------|--------------------------------------|--|
| 5 – 47 | EGR valve (D) | 15 – 20 Ω (at 20°C) |
| 6 – 47 | EGR valve (C) | |
| 32 – 47 | EGR valve (B) | |
| 34 – 47 | EGR valve (A) | |
| 16 – 47 | Purge control solenoid valve | 36 – 44 Ω (at 20°C) |
| 44 – 72 | Engine coolant temperature sensor | 5.1 – 6.5 kΩ (when engine coolant temperature is 0°C) |
| | | 2.1 – 2.7 kΩ (when engine coolant temperature is 20°C) |
| | | 0.9 – 1.3 kΩ (when engine coolant temperature is 40°C) |
| | | 0.26 – 0.36 kΩ (when engine coolant temperature is 80°C) |
| 46 – Body earth | Earth | Continuity (0 Ω) |
| 58 – Body earth | | |
| 62 – 72 | Intake air temperature sensor | 5.3 – 6.7 kΩ (when intake air temperature is 0°C) |
| | | 2.3 – 3.0 kΩ (when intake air temperature is 20°C) |
| | | 1.0 – 1.5 kΩ (when intake air temperature is 40°C) |
| | | 0.30 – 0.42 kΩ (when intake air temperature is 80°C) |
| 79 – 49 | Accelerator pedal position switch | Continuity (when the accelerator pedal is released) |
| | | No continuity (when the accelerator pedal is slightly depressed) |
| 89 – 47 | Oxygen sensor heater control (front) | 4.5 – 8.0 Ω (at 20°C) |
| 90 – 47 | Oxygen sensor heater (rear) | 11 – 18 Ω (at 20°C) |

CHECK AT THE ENGINE-A/T-ECU TERMINALS <A/T>**TERMINAL VOLTAGE CHECK CHART**

Engine-A/T-ECU Connector Terminal Arrangement

| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 | 56 | 57 | 58 | 59 | 60 | 61 | 62 | 63 | 64 | 65 | 66 | 67 | 68 | 69 | 70 | 71 | 72 | 73 | 74 | 75 | 76 | 77 | 78 | 79 | 80 | 81 | 82 | 83 | 84 | 85 | 86 | 87 | 88 | 89 | 90 | 91 | 92 | 93 | 94 | 95 | 96 | 97 | 98 | 99 | 100 | 101 | 102 | 103 | 104 | 105 | 106 | 107 | 108 | 109 | 110 | 111 | 112 | 113 | 114 | 115 | 116 | 117 | 118 | 119 | 120 | 121 | 122 | 123 | 124 | 125 | 126 | 127 | 128 | 129 | 130 |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|

7FU1763

| Terminal No. | Check item | Check condition (Engine condition) | Normal condition |
|--------------|------------------------------|---|---|
| 1 | No. 1 injector | While engine is idling after having warmed up, suddenly depress the accelerator pedal. | From 9 – 13 V, momentarily drops slightly |
| 9 | No. 2 injector | | |
| 24 | No. 3 injector | | |
| 2 | No. 4 injector | | |
| 3 | Oxygen sensor heater (front) | Engine: Idling | 0 – 3 V |
| | | Engine: 3,500 r/min | System voltage |
| 6 | Injector driver relay | Ignition switch: OFF | 0 – 0.1 V |
| | | Ignition switch: ON | 0.5 – 1.0 V |
| 8 | Alternator G terminal | <ul style="list-style-type: none"> ● Engine: Idling after warming-up ● Radiator fan: Not operating ● Headlamp: OFF to ON ● Stop lamp: OFF to ON ● Defogger switch: OFF to ON | The voltage increases by 0.2 – 3.5 V |
| 54 | Alternator FR terminal | <ul style="list-style-type: none"> ● Engine: Idling after warming-up ● Radiator fan: Not operating ● Headlamp: OFF to ON ● Stop lamp: OFF to ON ● Defogger switch: OFF to ON | The voltage drops |
| 11 | No. 1 ignition coil | Engine speed: 3,000 r/min | 0.3 – 3.0 V |
| 12 | No. 2 ignition coil | | |
| 31 | No. 3 ignition coil | | |
| 30 | No. 4 ignition coil | | |
| 14 | Throttle control servo relay | Ignition switch: OFF | 0 – 0.1 V |
| | | Ignition switch: ON | 0.5 – 1.0 V |
| 18 | Fan controller | Condenser fan not operating | System voltage |
| | | Condenser fan operating | 0 – 3 V or more |
| 19 | Air flow sensor reset signal | Engine: Idling | 0 – 1 V |
| | | Engine speed: 3,000 r/min | 6 – 9 V |

| Terminal No. | Check item | Check condition (Engine condition) | Normal condition | |
|--------------|---|--|---|-------------------|
| 20 | A/C relay | <ul style="list-style-type: none"> Engine: Idling A/C switch: OFF to ON (Compressor operating) | System voltage or changes momentarily 6 V or more to 0 – 3 V | |
| 21 | Fuel pump relay | Ignition switch: ON | System voltage | |
| | | Engine: Idling | 0 – 3 V | |
| 22 | Engine warning lamp | Ignition switch: OFF to ON | System voltage | |
| 23 | GDI ECO indication lamp | Ignition switch: OFF → ON | 0 – 3 V (System voltage after five seconds) | |
| | | Rev the engine suddenly. | System voltage | |
| 26 | Oxygen sensor heater (rear) | Engine: Idling | 0 – 3 V | |
| | | Engine: 3,500 r/min | System voltage | |
| 34 | Purge control solenoid valve | <ul style="list-style-type: none"> Engine coolant temperature: 80 – 95°C Ignition switch: ON | Engine: Stopped | System voltage |
| | | | Engine: After starting, increase the engine speed up to 3,500 r/min | The voltage drops |
| 41 | Power supply | Ignition switch: ON | System voltage | |
| 47 | | | | |
| 43 | Engine ignition signal | Engine speed: 3,000 r/min | 0.3 – 3.0 V | |
| 44 | Engine coolant temperature sensor | Ignition switch: ON | When engine coolant temperature is 0°C | 3.2 – 3.8 V |
| | | | When engine coolant temperature is 20°C | 2.3 – 2.9 V |
| | | | When engine coolant temperature is 40°C | 1.3 – 1.9 V |
| | | | When engine coolant temperature is 80°C | 0.3 – 0.9 V |
| 45 | Crank angle sensor | Engine: Cranking | 0.4 – 4.0 V | |
| | | Engine: Idling | 1.5 – 2.5 V | |
| 46 | Power supply voltage applied to accelerator pedal position sensor (1st channel) | Ignition switch: ON | 4.5 – 5.5 V | |
| 49 | Engine control relay | Ignition switch: OFF | 0 – 3 V | |
| | | Ignition switch: ON | System voltage | |
| 51 | EGR valve (A) | Ignition switch: OFF to ON | 5 – 8 V (Repeatedly changes for approx. 3 seconds) | |
| 53 | EGR valve (C) | | | |
| 60 | EGR valve (B) | | | |
| 62 | EGR valve (D) | | | |

| Terminal No. | Check item | Check condition (Engine condition) | | Normal condition |
|--------------|--|---|---|--|
| 52 | Power steering fluid pressure switch | Engine: Idling after warming-up | When steering wheel is stationary | System voltage |
| | | | When steering wheel is turned | 0 – 3 V |
| 55 | Barometric pressure sensor | Ignition switch: ON | At an altitude of 0 m | 3.7 – 4.3 V |
| | | | At an altitude of 1,200 m | 3.2 – 3.8 V |
| 56 | Camshaft position sensor | Engine: Cranking | | 0.4 – 3.0 V |
| | | Engine: Idling | | 0.5 – 2.0 V |
| 58 | Ignition switch-ST | Engine: Cranking | | 8 V or more |
| 61 | A/C switch 2 | Refer to GROUP 55 – Troubleshooting (Check at A/C-ECU or Engine-ECU Terminal). | | |
| 63 | Injector open circuit check signal | Engine: Increases from idling up to 4,000 r/min | | The voltage decreases slightly (approx. 0.7 V) from 4.5 – 5.0 V. |
| 64 | Intake air temperature sensor | Ignition switch: ON | When intake air temperature is 0°C | 3.2 – 3.8 V |
| | | | When intake air temperature is 20°C | 2.3 – 2.9 V |
| | | | When intake air temperature is 40°C | 1.5 – 2.1 V |
| | | | When intake air temperature is 80°C | 0.4 – 1.0 V |
| 65 | Air flow sensor | Engine: Idling | | 2.2 – 3.2 V |
| | | Engine speed: 2,500 r/min | | |
| 66 | Backup power supply | Ignition switch: OFF | | System voltage |
| 71 | Oxygen sensor (front) | Engine: Running at 2,500 r/min after warming-up (Check by using a digital voltmeter.) | | Voltages of 0 V and 0.8 V alternate |
| 73 | Oxygen sensor (rear) | <ul style="list-style-type: none"> ● Transmission: L range ● Engine speed: 3,500 r/min or more ● Driving with the throttle valve widely open | | 0.6 – 1.0 V |
| 78 | Throttle position sensor (2nd channel) | Ignition switch: ON | Release the accelerator pedal. | 4.5 – 5.5 V |
| | | | Depress the accelerator pedal fully. | 0.4 – 0.6 V |
| 79 | Accelerator pedal position switch | Ignition switch: ON | Release the accelerator pedal. | 0 – 1 V |
| | | | Depress the accelerator pedal slightly. | 4 V or more |
| 80 | Vehicle speed sensor | <ul style="list-style-type: none"> ● Ignition switch: ON ● Move the vehicle slowly forward | | Voltages of 0 and 8 – 12 V alternate (changes repeatedly) |

| Terminal No. | Check item | Check condition (Engine condition) | | Normal condition |
|--------------|---|---|--|-------------------|
| 83 | A/C switch 1 | Engine: Idling | A/C switch: OFF | 0 – 3 V |
| | | | A/C switch: ON (Compressor is operating) | System voltage |
| 86 | Small lamp switch | Lighting switch: OFF | | 0 – 3 V |
| | | Lighting switch: Tail light position | | System voltage |
| 87 | Sensor applied voltage | Ignition switch: ON | | 4.5 – 5.5 V |
| 93 | Fuel pressure sensor | Engine: Idling | | 0.3 – 4.7 V |
| 95 | Accelerator pedal position sensor (1st channel) | Ignition switch: ON | Release the accelerator pedal. | 0.985 – 1.085 V |
| | | | Depress the accelerator pedal fully. | 4.0 V or higher |
| 96 | Brake vacuum sensor | Engine: Stop the engine from idle speed, turn the ignition switch ON, and then depress the brake pedal several times. | | Voltage increases |
| 98 | Ignition switch-IG | Ignition switch: ON | | System voltage |
| 123 | Stop lamp switch | Depress the brake pedal. | | System voltage |
| | | Release the brake pedal. | | 0 – 3 V |

CHECK CHART FOR RESISTANCE AND CONTINUITY BETWEEN TERMINALS

1. Turn the ignition switch to OFF.
2. Disconnect the engine-A/T-ECU connector.
3. Measure the resistance and check for continuity between the terminals of the engine-A/T-ECU harness-side connector while referring to the check chart.

NOTE


- (1) When measuring resistance and checking continuity, a harness for checking contact pin pressure should be used instead of inserting a test probe.
- (2) Checking need not be carried out in the order given in the chart.

Caution

If the terminals that should be checked are mistaken, or if connector terminals are not correctly shorted to earth, damage may be caused to the vehicle wiring, sensors, engine-A/T-ECU and/or ohmmeter. Be careful to prevent this!


4. If the ohmmeter shows any deviation from the standard value, check the corresponding sensor, actuator and related electrical wiring, and then repair or replace.
5. After repair or replacement, recheck with the ohmmeter to confirm that the repair or replacement has corrected the problem.

Engine-A/T-ECU Harness Side Connector Terminal Arrangement



7FU1764

| Terminal No. | Check item | Standard value, normal condition (check conditions) |
|------------------------------------|-----------------------------------|--|
| 3 – 41 | Oxygen sensor heater (front) | 4.5 – 8.0 Ω (at 20°C) |
| 26 – 41 | Oxygen sensor heater (rear) | 11 – 18 Ω (at 20°C) |
| 34 – 41 | Purge control solenoid valve | 28 – 36 Ω (at 20°C) |
| Between terminal 42 and body earth | Earth | Continuity (0 Ω) |
| Between terminal 48 and body earth | | |
| 51 – 41 | EGR valve (A) | 15 – 20 Ω (at 20°C) |
| 53 – 41 | EGR valve (C) | |
| 60 – 41 | EGR valve (B) | |
| 62 – 41 | EGR valve (D) | |
| 44 – 81 | Engine coolant temperature sensor | 5.1 – 6.5 kΩ (When coolant temperature is 0°C) |
| | | 2.1 – 2.7 kΩ (When coolant temperature is 20°C) |
| | | 0.9 – 1.3 kΩ (When coolant temperature is 40°C) |
| | | 0.26 – 0.36 kΩ (When coolant temperature is 80°C) |
| 64 – 81 | Intake air temperature sensor | 5.3 – 6.7 kΩ (When intake air temperature is 0°C) |
| | | 2.3 – 3.0 kΩ (When intake air temperature is 20°C) |
| | | 1.0 – 1.5 kΩ (When intake air temperature is 40°C) |
| | | 0.30 – 0.42 kΩ (When intake air temperature is 80°C) |
| 79 – 81 | Accelerator pedal position switch | Continuity (when the accelerator pedal is released) |
| | | No continuity (when the accelerator pedal is depressed slightly) |

CHECK AT THE THROTTLE VALVE CONTROLLER TERMINALS**TERMINAL VOLTAGE CHECK CHART****Throttle Valve Controller Terminal Arrangement**

7FU2121

| Terminal No. | Check items | Requirements | Normal value | |
|--------------|---|---|---|-------------------------------|
| 1 | Throttle valve control servo (A+) | <ul style="list-style-type: none"> Ignition switch: ON Accelerator pedal: Fully opened → fully closed | Decreases slightly from system voltage. | |
| 9 | Throttle valve control servo (B+) | | | |
| 14 | Throttle valve control servo (A-) | <ul style="list-style-type: none"> Ignition switch: ON Accelerator pedal: Fully closed → fully opened | Decreases slightly (approx. 2 V) from system voltage. | |
| 15 | Throttle valve control servo (B-) | | | |
| 2 | Power supply to throttle valve control servo | Ignition switch: ON | System voltage | |
| 19 | | | | |
| 5 | Power supply | Ignition switch: ON | System voltage | |
| 6 | Sensor voltage | Ignition switch: ON | 4.5 – 5.5 V | |
| 7 | Throttle position sensor (1st channel) | Ignition switch: ON | Release the accelerator pedal. | 0.45 – 0.8 V |
| | | | Depress the accelerator pedal fully. | 4.2 – 4.9 V |
| 20 | Accelerator pedal position sensor (2nd channel) | Ignition switch: ON | Release the accelerator pedal. | 0.985 – 1.085 V* ¹ |
| | | | Depress the accelerator pedal fully. | 4 V or more* ¹ |

NOTE:Check that the voltage difference between *¹ and *² is 4 V or more.

INSPECTION PROCEDURE USING AN ANALYZER**AIR FLOW SENSOR (AFS)**


The followings have been changed from the previous description.

Alternate Method (Test harness not available)**<Vehicles with M/T>**

Connect the analyzer special patterns pickup to engine-ECU terminal 61.

<Vehicles with A/T>

Connect the analyzer special patterns pickup to engine-A/T-ECU terminal 65.

**CAMSHAFT POSITION SENSOR AND CRANK ANGLE SENSOR**

The measurement method has been changed from the previous description.

Measurement Method



1. Disconnect the camshaft position sensor connector and connect the special tool (test harness: MB991709) in between. (All terminals should be connected.)
2. Connect the analyzer special patterns pickup to camshaft position sensor terminal 2.
3. Disconnect the crank angle sensor connector and connect the special tool (test harness: MD998478) in between.
4. Connect the analyzer special patterns pickup to crank angle sensor terminal 2.

Alternate Method (Test harness not available)**<Vehicles with M/T>**

1. Connect the analyzer special patterns pickup to engine-ECU terminal 50. (When checking the camshaft position sensor signal wave pattern.)
2. Connect the analyzer special patterns pickup to engine-ECU terminal 43. (When checking the crank angle sensor signal wave pattern.)

<Vehicles with A/T>

1. Connect the analyzer special patterns pickup to engine-A/T-ECU terminal 56. (When checking the camshaft position sensor signal wave pattern.)
2. Connect the analyzer special patterns pickup to engine-A/T-ECU terminal 45. (When checking the crank angle sensor signal wave pattern.)



INJECTORS AND INJECTOR OPEN CIRCUIT CHECK SIGNAL

The measurement method has been changed from the previous description.

Measurement Method

<Vehicles with M/T>

1. Connect the analyzer special patterns pickup to terminal 1 (No. 1 injector) of the engine-ECU connector.
2. Connect the analyzer special patterns pickup to terminal 96 (injector open circuit check signal) of the engine-ECU connector.
3. After checking terminal 1, check terminal 9 (No. 2 injector), terminal 24 (No. 3 injector) and terminal 2 (No. 4 injector).

<Vehicles with A/T>

1. Connect the analyzer special patterns pickup to terminal 1 (No. 1 injector) of the engine-A/T-ECU connector.
2. Connect the analyzer special patterns pickup to terminal 63 (injector open circuit check signal) of the engine-A/T-ECU connector.
3. After checking terminal 1, check terminal 9 (No. 2 injector), terminal 24 (No. 3 injector) and terminal 2 (No. 4 injector).

IGNITION COIL AND POWER TRANSISTOR (Power transistor control signal)

The followings have been changed from the previous description.

Alternate Method (Test harness not available)

<Vehicles with M/T>

Connect the analyzer special patterns pickup to engine-ECU terminal 3 (No. 1 ignition coil), terminal 13 (No. 2 ignition coil), terminal 12 (No. 3 ignition coil) and terminal 4 (No. 4 ignition coil) respectively.

<Vehicles with A/T>

Connect the analyzer special patterns pickup to engine-A/T-ECU terminal 11 (No. 1 ignition coil), terminal 12 (No. 2 ignition coil), terminal 31 (No. 3 ignition coil) and terminal 30 (No. 4 ignition coil) respectively.

EGR VALVE (STEPPER MOTOR)


The followings have been changed from the previous description.

Alternate Method (Test harness not available)**<Vehicles with M/T>**

Connect the analyzer special patterns pickup to engine-ECU terminal 34, connection terminal 32, connection terminal 6, and connection terminal 5 respectively.

<Vehicles with A/T>


Connect the analyzer special patterns pickup to engine-A/T-ECU terminal 51, connection terminal 60, connection terminal 53, and connection terminal 62 respectively.



ON-VEHICLE SERVICE

Caution


- (1) Never attempt to tamper the fixed SAS. The fixed SAS is precisely adjusted at factory.
- (2) Should it be tampered, the full closed position of the throttle valve will be changed. This causes the engine-ECU <M/T> or engine-A/T-ECU <A/T> to learn a wrong position of the throttle valve.




ACCELERATOR PEDAL POSITION SENSOR ADJUSTMENT

Caution

- (1) Never attempt to tamper the accelerator pedal position sensor. The sensor position is precisely adjusted at factory.
 - (2) Should it be tampered, follow the procedure below:
 1. Remove the accelerator pedal complete.
 2. Connect the MUT-II to the diagnosis connector.
 3. Loosen the accelerator pedal position sensor attaching bolts to allow it to be loosely fitted.
 4. Ensure that the accelerator pedal arm contacts the full-stop position stopper.
 5. Turn the ignition switch to the ON position (but do not start the engine).
 6. Rotate the accelerator pedal position sensor to adjust sensor output voltage to the standard value.
- Standard value: 0.985 – 1.085 V**
7. Tighten the sensor mounting bolts securely.
 8. Install the accelerator pedal complete.





FUEL PRESSURE TEST

MEASUREMENT OF FUEL LOW PRESSURE BETWEEN FUEL PUMP (LOW PRESSURE) AND FUEL PUMP (HIGH PRESSURE)

1. Release residual pressure from the fuel pipe line to prevent fuel gush out.


NOTE

Refer to SPACE STAR '99 Workshop Manual (Pub. No. CMXE99E1) GROUP 13A – On-vehicle Service.

2. Disconnect the high-pressure fuel hose at the fuel pump (high pressure) side.

Caution


Cover the hose connection with rags to prevent splash of fuel that could be caused by some residual pressure in the fuel pipe line.



3. Remove the union joint and bolt from the special tool (adapter hose) and instead attach the special tool (hose adapter) to the adapter hose.
4. Install the special tool (for measuring the fuel pressure) that was set up in step 3.

<When using the fuel pressure gauge set (special tool)>

- (1) Install the special tool (for measuring the fuel pressure) between the high-pressure fuel hose and the fuel pump (high pressure).
- (2) Install the fuel pressure gauge set (special tool) on the special tool (for measuring the fuel pressure) putting the gasket between them.
- (3) Connect the lead wire of the fuel pressure gauge set (special tool) to the power supply (cigarette lighter socket) and to the MUT-II.



<When using the fuel pressure gauge>

- (1) Install the fuel pressure gauge on the special tool (for measuring the fuel pressure) putting a suitable O-ring or gasket between them.
- (2) Install the special tool which was set up in step (1) between the high-pressure fuel hose and the fuel pump (high pressure).

5. Connect the MUT-II to the diagnosis connector.

Caution

Turn off the ignition switch before disconnecting or connecting the MUT-II.

6. Turn the ignition switch to ON. (But do not start the engine.)
7. Select "Item No. 07" from the MUT-II Actuator test to drive the fuel pump (low pressure) at the fuel tank side. Check that there are no fuel leaks from any parts.
8. Finish the actuator test or turn the ignition switch to OFF.
9. Start the engine and run at idle.
10. Measure fuel pressure while the engine is running at idle.

Standard value: approximately 324 kPa

11. Check to see that fuel pressure at idle does not drop even after the engine has been raced several times.
12. If fuel pressure is out of the standard value, troubleshoot and repair according to the table below.

| Symptom | Probable cause | Remedy |
|---|--|--|
| <ul style="list-style-type: none"> ● Fuel pressure too low ● Fuel pressure drops after racing | Clogged fuel filter | Replace fuel filter |
| | Fuel leaking to return side due to poor fuel pressure regulator (low pressure) valve seating or settled spring | Replace fuel pressure regulator (low pressure) |
| | Low fuel pump (low pressure) delivery pressure | Replace the fuel pump (low pressure) |
| Fuel pressure too high | Binding valve in fuel pressure regulator (low pressure) | Replace fuel pressure regulator (low pressure) |
| | Clogged fuel return hose or pipe | Clean or replace hose or pipe |

13. Stop the engine and check change of fuel pressure gauge reading. Normal if the reading does not drop within 2 minutes. If it does, observe the rate of drop and troubleshoot and repair according to the table below.

| Symptom | Probable cause | Remedy |
|---|---|--|
| Fuel pressure drops gradually after engine is stopped | Leaky fuel pressure regulator (low pressure) valve seat | Replace fuel pressure regulator (low pressure) |
| Fuel pressure drops sharply immediately after engine is stopped | Check valve in fuel pump (low pressure) is held open | Replace the fuel pump (low pressure) |

14. Release residual pressure from the fuel pipe line.

NOTE


Refer to SPACE STAR '99 Workshop Manual (Pub. No. CMXE99E1) GROUP 13A – On-vehicle Service.

15. Remove the fuel pressure gauge and special tools from the fuel pump (high pressure).

Caution

Cover the hose connection with rags to prevent splash of fuel that could be caused by some residual pressure in the fuel pipe line.

16. Replace the O-ring at the end of the high-pressure fuel hose with a new one. Furthermore, apply engine oil to the new O-ring before replacement.
17. Fit the high-pressure fuel hose to the fuel pump (high pressure) and tighten the mounting bolt to specified torque.
18. Check for any fuel leaks by following the procedure in step 7.
19. Disconnect the MUT-II.



MEASUREMENT OF FUEL HIGH PRESSURE BETWEEN FUEL PUMP (HIGH PRESSURE) AND INJECTORS

NOTE

Measurement of the fuel pressure between the fuel pump (high pressure) and the injectors should be carried out after checking that the fuel pressure between the fuel pump (low pressure) and the fuel pump (high pressure) is normal.

1. Connect the MUT-II to the diagnosis connector.
2. Disconnect the injector intermediate harness connector.
3. Turn the ignition switch to ON.
4. Select "Item No. 74" from the MUT-II Data list.
5. Crank the engine continuously for 2 seconds or more, and visually check that there are no fuel leaks from any parts.

Caution

If any fuel leaks appear, stop cranking immediately and repair the source of the leak.


6. Check if the fuel pressure is more than 1 MPa immediately after 20 seconds have passed since cranking was finished.
7. If the fuel pressure is lower than 1 MPa, it means that there is likely to be a leak in the high-pressure fuel system, so this system should be checked.
8. Turn the ignition switch to OFF.
9. Connect the injector intermediate harness connector.
10. Start the engine and run at idle.
11. Measure fuel pressure while the engine is running at idle.

Standard value: 4 – 6.9 MPa

12. Check to see that fuel pressure at idle does not drop even after the engine has been raced several times.
13. If fuel pressure is out of the standard value, troubleshoot and repair according to the table below.

| Symptom | Probable cause | Remedy |
|---|---|---------------------------------------|
| <ul style="list-style-type: none"> ● Fuel pressure too low ● Fuel pressure drops after racing | Fuel leaking to return side due to poor fuel pressure regulator valve seating or settled spring in the fuel pump (high pressure). | Replace fuel pump (high pressure) |
| | Low fuel pump (high pressure) delivery pressure | Replace the fuel pump (high pressure) |
| Fuel pressure too high | Clogged fuel pressure regulator valve in the fuel pump (high pressure) | Replace fuel pump (high pressure) |
| | Clogged fuel return hose or pipe | Clean or replace hose or pipe |

14. Stop the engine and turn the ignition switch to OFF.
15. Disconnect the MUT-II.



FUEL LEAK CHECK

1. Connect the MUT-II to the diagnosis connector.
2. Disconnect the injector intermediate harness connector.
3. Turn the ignition switch to ON.
4. Select "Item No. 74" from the MUT-II Data list.
5. Crank the engine continuously for two seconds or more, and visually check that there are no fuel leaks from any parts.

Caution

If any fuel leaks appear, stop cranking immediately and repair the source of the leak.

6. Crank the engine, and then measure fuel pressure immediately after 20 seconds.

Limit: Minimum 1 MPa


Caution

If the fuel pressure is less than 1 MPa, there may be a partial fuel leak in the high-pressure fuel system.


7. Turn off the ignition switch.
8. Reconnect the injector intermediate connector.
9. Remove the MUT-II.

COMPONENT LOCATION

| Name | Symbol | Name | Symbol |
|-------------------------|--------|-----------------------|--------|
| Engine-A/T-ECU <A/T> | B | Oxygen sensor (front) | C |
| Ignition failure sensor | A | Oxygen sensor (rear) | D |



Y6065AJ



ACCELERATOR PEDAL POSITION SENSOR (1ST AND 2ND CHANNELS) CHECK

1. Disconnect the accelerator pedal position sensor connector.
2. Measure resistance between terminal Nos. 2 (1st channel power supply) and 1 (1st channel earth) as well as between terminal Nos. 8 (2nd channel power supply) and terminal No. 7 (2nd channel earth) of the sensor connector.

Standard value: 3.5 – 6.5 kΩ

3. Measure resistance between terminal Nos. 2 (1st channel power supply) and 3 (1st channel output) as well as between terminal Nos. 8 (2nd channel power supply) and terminal No. 6 (2nd channel output) of the sensor connector.


Normal condition:

| | |
|---------------------------------------|--|
| Depress the accelerator pedal slowly. | Resistance value changes in accordance with the accelerator pedal depression smoothly. |
|---------------------------------------|--|

4. If not within the standard value, or resistance value does not change smoothly, replace the accelerator pedal position sensor.

NOTE

After replacement, adjust the accelerator pedal position sensor. (Refer to P.13A-121.)



ACCELERATOR PEDAL POSITION SWITCH CHECK

1. Disconnect the accelerator pedal position sensor connector.
2. Check continuity between terminal Nos. 4 (accelerator pedal position switch) and 5 (earth) of the connector.




Normal condition:

| | |
|-------------------|------------------|
| Accelerator pedal | Continuity |
| Depressed | No continuity |
| Released | Continuity (0 Ω) |

3. If defective, replace the accelerator pedal position sensor.

NOTE

After replacement, adjust the accelerator pedal position sensor. (Refer to P.13A-121.)



OXYGEN SENSOR CHECK

<Oxygen sensor (front)>

1. Disconnect the oxygen sensor connector and connect the special tool (test harness) to the connector on the oxygen sensor side.
2. Make sure that there is continuity (4.5 – 8.0 Ω at 20°C) between terminal 1 (red clip of special tool) and terminal 3 (blue clip of special tool) on the oxygen sensor connector.

3. If there is no continuity, replace the oxygen sensor.
4. Warm up the engine until engine coolant is 80°C or higher.

5. Use a jumper wire to connect terminal 1 (red clip) of the oxygen sensor connector to the battery (+) terminal and terminal 3 (blue clip) to the battery (-) terminal.

Caution

Be very careful when connecting the jumper wire; incorrect connection can damage the oxygen sensor.

6. Connect a digital voltage meter between terminal 2 (black clip) and terminal 4 (white clip).
7. While repeatedly racing the engine, measure the oxygen sensor output voltage.



Standard value:

| Engine | Oxygen sensor output voltage | Remarks |
|------------------------|------------------------------|---|
| When racing the engine | 0.6 – 1.0 V | If you make the air/fuel ratio rich by racing the engine repeatedly, a normal oxygen sensor will output a voltage of 0.6 – 1.0 V. |

8. If the sensor is defective, replace the oxygen sensor.

NOTE

For removal and installation of the oxygen sensor, refer to GROUP 15 – Exhaust Pipe and Main Muffler.



<Oxygen sensor (rear)>

1. Disconnect the oxygen sensor connector and connect the special tool (test harness set) to the connector on the oxygen sensor side.
2. Make sure that there is continuity ($11 - 18 \Omega$ at 20°C) between terminal 3 and terminal 4 on the oxygen sensor connector.
3. If there is no continuity, replace the oxygen sensor.

NOTE


- (1) If the MUT-II does not display the standard value although no abnormality is found by the above mentioned continuity test and harness check, replace the oxygen sensor (rear).
- (2) For removal and installation of the oxygen sensor, refer to GROUP 15 – Exhaust Pipe and Main Muffler.

FUEL PUMP (HIGH PRESSURE)

REMOVAL AND INSTALLATION

Pre-removal and Post-installation Operation


- Engine Cover Removal and Installation (Refer to GROUP 11A – Camshaft, Camshaft Oil Seal.)
- Prevention of Fuel Discharge <before removal only>
- Fuel Leak Check <after installation only>
- Air Cleaner Assembly Removal and Installation
- Throttle Body Remove and Installation (Refer to P.13A-137.)
- Intake Manifold Removal and Installation (Refer to GROUP 15.)



Apply engine oil to all O-rings during installation.

Removal steps


- ▶D◀ ● Air bleeding the high-pressure fuel path
- ▶C◀ 1. Fuel return hoses connection
- ▶B◀ 2. Fuel pipe
- ▶B◀ 3. Back-up ring A
- ▶B◀ 4. O-ring
- ▶B◀ 5. Back-up ring B
- ▶A◀ 6. Fuel pump (high pressure)
- 7. O-ring
- 8. Insulator



INSTALLATION SERVICE POINTS

►A◄ FUEL PUMP (HIGH PRESSURE) INSTALLATION

1. Apply a small amount of fresh engine oil to the fuel pump (high pressure) roller and O-ring.
2. Insert the fuel pump (high pressure) to the cylinder head ports squarely, and then tighten the mounting bolts temporarily (a little more tightly than finger-tightening). Tightening them to the specified torque should be carried out in later step ►B◄.



►B◄ BACK-UP RING B/O-RING/BACK-UP RING A/FUEL PIPE INSTALLATION

1. Install the back-up rings and the O-ring as shown in the illustration.

Caution

(1) Install the back-up ring B facing its cutaway surface toward the opposite side of the O-ring as shown in the illustration.

(2) Confirm the outer diameter of the back-up ring A. Take care not to install the back-up ring for the fuel pressure sensor by mistake. (Outer diameter of the back-up ring A: 14.8 mm)


2. Apply a small amount of fresh engine oil to the O-ring.

Caution


Take care not to let any of the engine oil get inside the fuel pump (high-pressure) or the delivery pipe assembly.

3. Install the fuel pipe into the fuel pump (high pressure) and the delivery pipe ports squarely. Insert the pipe securely, being careful not to twisting it, and then tighten the mounting bolts to the specified torque.

Tightening torque: 11 – 13 Nm



4. Tighten the temporarily tightened mounting bolts of the fuel pump (high pressure) in shown order to 5.0 Nm.
5. Tighten the bolts to 17 Nm in the order shown in the illustration. The overall difference in tightening torque between the four bolts should be within 2 Nm.



►C◄ FUEL RETURN HOSES INSTALLATION

Install the fuel return hoses so that the identification mark of fuel return hoses comes to the illustrated position.

▶D◀ AIR BLEEDING THE HIGH-PRESSURE FUEL PATH

1. Air-bleed the high-pressure fuel path with the engine running at 2000 r/min for 15 seconds or more.

NOTE

When the air is trapped into the high-pressure fuel path due to the fuel pipe removal, an abnormality in the fuel pressure causes the output of diagnosis code No. 56.

2. If diagnosis code No. 56 at the fuel pressure sensor system is output after the diagnosis code is confirmed by MUT-II, the code will be erased.


FUEL INJECTOR

REMOVAL AND INSTALLATION

Pre-removal and Post-installation Operation

- Engine Cover Removal and Installation (Refer to GROUP 11A – Camshaft, Camshaft Oil Seal.)
- Prevention of Fuel Discharge <before removal only>
- Fuel Leak Check <after installation only>
- Air bleeding the high-pressure fuel path <after installation only>

Apply engine oil to all O-rings during installation.



AY0069AU

Fuel pressure sensor removal steps

◀A▶

▶E▶
▶E▶
▶D▶
▶D▶

1. Fuel pressure sensor connector
2. Flange
3. Fuel pressure sensor
4. O-ring
5. Back-up ring


Fuel injector removal steps

▶C▶

- Air cleaner
- Throttle body (Refer to P.13A-137.)
- Intake manifold (Refer to GROUP 15.)
- 6. Injector harness
- 7. Injector harness support bracket
- 8. Fuel pipe

▶B▶

- ▶C▶ 9. Back-up ring A
- ▶C▶ 10. O-ring
- ▶C▶ 11. Back-up ring B
- ▶B▶ 12. Injector washer
- ▶B▶ 13. Injector holder
- ▶B▶ 14. Delivery pipe and fuel injector assembly
- ▶B▶ 15. Insulator
- ▶B▶ 16. Injector gasket
- ▶B▶ 17. Fuel injector
- ▶A▶ 18. Corrugated washer
- ▶A▶ 19. Back-up ring A
- ▶A▶ 20. O-ring
- ▶A▶ 21. Back-up ring B
- ▶A▶ 22. Delivery pipe



REMOVAL SERVICE POINTS

◀A▶ FLANGE REMOVAL

If the fuel pressure sensor is reused, make mating marks on the sensor and the flange.

NOTE



The flange secures sealing performance of fuel pressure sensor and installation rigidity by bending to deform the shape at installation. Therefore, make mating marks to install the flange with the right phase and side. In addition, If the fuel pressure sensor is replaced with a new one, replace it together with the flange as a set.

◀B▶ DELIVERY PIPE AND FUEL INJECTOR ASSEMBLY REMOVAL

Remove the delivery pipe with the fuel injector assembly still attached.

Caution

Be careful not to drop the fuel injector assembly when removing the delivery pipe.



INSTALLATION SERVICE POINTS

▶A◀ BACK-UP RING B/O-RING/BACK-UP RING A/CORRUGATED WASHER INSTALLATION

1. Install the back-up rings and the O-ring as shown in the illustration.

Caution

(1) Install the back-up ring B facing its cutaway surface toward the opposite side of the O-ring as shown in the illustration.

(2) Confirm the outer diameter of the back-up ring A. Take care not to install the back-up ring for the fuel pressure sensor by mistake. (Outer diameter of the back-up ring A: 14.8 mm)

2. Apply petroleum jelly to the corrugated washer to prevent it from dropping, and then install it to the direction shown.

Caution


The corrugated washer should always be replaced with a new part.

▶B◀ FUEL INJECTOR/INJECTOR GASKET/INSULATOR/DELIVERY PIPE AND FUEL INJECTOR ASSEMBLY/INJECTOR HOLDER/INJECTOR WASHER INSTALLATION

1. Apply a small amount of fresh engine oil to the O-ring.


Caution

Take care not to let any of the engine oil get inside the delivery pipe.




2. While being careful not to damage the O-ring, turn the fuel injector to the left and right and connect it to the delivery pipe. After connecting, check that the fuel injector turns smoothly.
3. If the fuel injector does not turn smoothly, the cause may be that the O-ring is getting caught. Remove the fuel injector, check the O-ring for damage and re-connect the fuel injector to the delivery pipe assembly and then re-check.
4. Align the Fuel injector mating mark with the delivery pipe mating mark.
5. Install the injector gasket and insulator to the cylinder head.
6. Install the delivery pipe and fuel injector assembly to the cylinder head, and then temporarily tighten mounting bolts.
7. Install the injector holder and the injector washer then tighten mounting bolts to the specified torque.

Tightening torque: 21 – 25 Nm



8. Tighten the mounting bolts to temporarily tighten the delivery pipe and the fuel injector assembly according to the illustrated sequence to the specified torque.

Tightening torque: 11 – 13 Nm



▶◀ BACK-UP RING B/O-RING/BACK-UP RING A/FUEL PIPE INSTALLATION

1. Install the back-up rings and the O-ring as shown in the illustration.

Caution

- (1) Install the back-up ring B facing its cutaway surface toward the opposite side of the O-ring as shown in the illustration.
- (2) Confirm the outer diameter of the back-up ring A. Take care not to install the back-up ring for the fuel pressure sensor by mistake. (Outer diameter of the back-up ring A: 14.8 mm)


2. Apply a small amount of fresh engine oil to the O-ring.

Caution

Take care not to let any of the engine oil get inside the fuel pump (high pressure) or the delivery pipe.

3. Insert the fuel pipe into the fuel pump (high pressure) and the delivery pipe ports squarely. Insert the pipe securely, being careful not to twisting it, and then tighten the mounting bolts to the specified torque.

Tightening torque: 11 – 13 Nm



►D◄ BACK-UP RING/O-RING INSTALLATION

Install the back-up ring and the O-ring as shown in the illustration.

Caution


Be careful not to confuse this back-up ring with the back-up ring A for the fuel injector or back-up ring A for the fuel pipe. (External diameter of the back-up ring: 15.1 mm)

►E◄ FUEL PRESSURE SENSOR/FLANGE INSTALLATION

1. Apply a small amount of fresh engine oil to the O-ring.

Caution

Take care not to let any of the engine oil get inside the delivery pipe.



2. Install the fuel pressure sensor so that the part number label comes to the same direction shown in the illustration. If the old fuel pressure sensor is reused, Install the sensor to the delivery pipe using the mating mark made during its removal.

Caution


If the fuel pressure sensor is replaced with a new one, replace it together with the flange as a set.

THROTTLE BODY

REMOVAL AND INSTALLATION


Pre-removal and Post-installation Operation

- Engine Cover Removal and Installation (Refer to GROUP 11A – Camshaft, Camshaft Oil Seal.)
- Prevention of Fuel Discharge <before removal only>
- Fuel Leak Check <after installation only>
- Engine Coolant Draining and Supplying
- Air Cleaner Removal and Installation



Removal steps

1. Throttle position sensor connector
2. Idle speed control servo connector
3. Ignition failure sensor
4. Water hose
5. Water hose connection
- ▶B◀ 6. High-pressure fuel hose connection
- ▶B◀ 7. O-ring
8. Throttle body stay
9. Throttle body
10. Water hose
- ▶A◀ 11. Throttle body gasket



INSTALLATION SERVICE POINTS

▶A◀ THROTTLE BODY GASKET INSTALLATION

Install the throttle body gasket so that the projection comes to the illustrated position.

**►B◄ O-RING/HIGH-PRESSURE FUEL HOSE
INSTALLATION**

1. Apply a small amount of new engine oil to the O-ring.


Caution

Do not let any engine oil get into the delivery pipe.

2. While turning the high-pressure fuel hose to the right and left, install the delivery pipe, while being careful not to damage the O-ring. After installing, check that the hose turns smoothly.
3. If the hose does not turn smoothly, the O-ring is probably being clamped. Disconnect the high-pressure fuel hose and check the O-ring for damage. After this, re-insert the delivery pipe and check that the hose turns smoothly.
4. Tighten to the specified torque.

Tightening torque: 5.0 Nm


DISASSEMBLY AND REASSEMBLY




Y6085AJ

Disassembly steps

- ▶◀ 1. Throttle position sensor
2. Throttle body



Y6086AJ



7FU0535

REASSEMBLY SERVICE POINTS

▶◀ **THROTTLE POSITION SENSOR**

1. Position the throttle position sensor on the throttle body along the dotted line as shown in the illustration.
2. Rotate the throttle position sensor anticlockwise as shown in the illustration, and then tighten the screws.

3. Measure resistance value between terminal Nos. 1 (sensor power supply) and 2 (throttle position sensor 1st-channel output) as well as 1 (sensor power supply) and 4 (throttle position sensor 2nd-channel output).

Normal condition

| | |
|--|--|
| Open the throttle valve slowly from the idle position to full-open position. | Resistance value changes smoothly in response to throttle valve opening angle. |
|--|--|

4. If the resistance value does not change smoothly, replace the throttle position sensor.

NOTES

MULTIPOINT FUEL INJECTION (MPI)



CONTENTS

| | | | |
|-------------------------------------|----------|---|-----------|
| GENERAL | 2 | ON-VEHICLE SERVICE | 78 |
| Outline of Changes | 2 | Basic Idle Speed Adjustment | 78 |
| GENERAL INFORMATION | 2 | Component Location | 79 |
| SERVICE SPECIFICATIONS | 4 | Intake Air Temperature Sensor Check | 80 |
| SPECIAL TOOLS | 4 | Oxygen Sensor Check | 80 |
| TROUBLESHOOTING | 5 | FUEL INJECTOR | 82 |
| | | THROTTLE BODY | 84 |



GENERAL

OUTLINE OF CHANGES

The service procedures have been established to describe revised sections due to the changed items shown below.

- On-board Diagnostics System has been adopted, diagnostic items have been expanded, and diagnostic code numbering system has been changed.
- Non-distributor two-coiled ignition system has been adopted.
- Crank angle sensor attached to the crank shaft has been adopted.
- Camshaft position sensor has been added.
- Ignition failure sensor has been added.
- Intake air temperature sensor built in the vacuum sensor (manifold absolute pressure sensor) has been adopted.
- Oxygen sensor (front, rear) has been changed.
- Ignition timing adjustment terminal has been abolished.

GENERAL INFORMATION

SELF-DIAGNOSIS FUNCTION



The following functions have been added.

- The engine-ECU records the engine operating condition when the diagnosis code is set.
This data is called “freeze frame” data.
This data can be read by using the MUT-II, are can then be used in simulation tests for troubleshooting.

GENERAL SPECIFICATIONS

| Item | | Specifications |
|------------|--------------------|----------------|
| Engine-ECU | Identification No. | E2T71279 |

MULTI-POINT FUEL INJECTION SYSTEM DIAGRAM








Y6062AJ

SERVICE SPECIFICATIONS

| Items | | Standard value |
|---|-------|----------------|
| Intake air temperature sensor resistance k Ω | 20°C | 2.3 – 3.0 |
| | 80°C | 0.30 – 0.42 |
| Oxygen sensor output voltage (during revving) V | | 0.6 – 1.0 |
| Oxygen sensor heater resistance (at 20°C) Ω | Front | 4.5 – 8.0 |
| | Rear | 11 – 18 |

SPECIAL TOOLS

| Tool | Number | Name | Use |
|--|----------|---|--|
|  B991536 | MB991536 | Throttle position sensor adjustment harness | <ul style="list-style-type: none"> Measurement of voltage during troubleshooting |
|  | MB991658 | Test harness set | <ul style="list-style-type: none"> Measurement of voltage during troubleshooting |
|  | MD998464 | Test harness (4-pin, square) | <ul style="list-style-type: none"> Measurement of voltage during troubleshooting Inspection of oxygen sensor (front) |
|  | MD998478 | Test harness (3-pin, triangle) | <ul style="list-style-type: none"> Measurement of voltage during troubleshooting Inspection using an analyzer |



TROUBLESHOOTING

DIAGNOSIS FUNCTION

ENGINE WARNING LAMP (CHECK ENGINE LAMP)

If an abnormality occurs in any of the following items related to the Multipoint Fuel Injection (MPI) system, the engine warning lamp will illuminate. If the lamp remains illuminated or if the lamp illuminates while the engine is running, check the diagnosis code output.

However, the warning lamp will illuminate as bulb check for five seconds whenever the ignition switch is turned to the ON position.

Engine warning lamp inspection items

| Code No. | Diagnosis item |
|----------|--|
| – | Engine-ECU |
| P0105 | Vacuum sensor system |
| P0110 | Intake air temperature sensor system |
| P0115 | Engine coolant temperature sensor system |
| P0120 | Throttle position sensor system |
| P0125 | Feedback system |
| P0130 | Oxygen sensor (front) system <sensor 1> |
| P0135 | Oxygen sensor heater (front) system <sensor 1> |
| P0136 | Oxygen sensor (rear) system <sensor 2> |
| P0141 | Oxygen sensor heater (rear) system <sensor 2> |
| P0170 | Abnormal fuel system |
| P0201 | No. 1 injector system |
| P0202 | No. 2 injector system |
| P0203 | No. 3 injector system |
| P0204 | No. 4 injector system |
| P0300★ | Random cylinder misfire detected |
| P0301 | No. 1 cylinder misfire detected |
| P0302 | No. 2 cylinder misfire detected |
| P0303 | No. 3 cylinder misfire detected |
| P0304 | No. 4 cylinder misfire detected |
| P0335 | Crank angle sensor system |
| P0340 | Camshaft position sensor system |
| P0403 | EGR control solenoid valve system |
| P0420 | Catalyst malfunction |
| P0443 | Purge control solenoid valve system |
| P0505 | Idle speed control system |

NOTE

1. If the engine warning lamp illuminates because of a malfunction of the engine-ECU, communication between MUT-II and the engine-ECU is impossible. In this case, the diagnosis code cannot be read.
2. After the engine-ECU has detected a malfunction, the engine warning lamp illuminates when the engine is next turned on and the same malfunction is re-detected. However, for items marked with a “★” in the diagnosis code number column, the engine warning lamp illuminates only on the first detection of the malfunction.
3. After the engine warning lamp illuminates, it will be switched off under the following conditions.
 - (1) When the engine-ECU monitored the power train malfunction three times* and met set condition requirements, it detected no malfunction.
*: In this case, “one time” indicates from engine start to stop.
 - (2) For misfiring malfunction, when driving conditions (engine speed, engine coolant temperature, etc.) are similar to those when the malfunction was first recorded.
4. Sensor 1 indicates the sensor mounted at a position closest to the engine, and sensor 2 indicates the sensor mounted at the position second closest to the engine.

METHOD OF READING AND ERASING DIAGNOSIS CODES

Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points.

DIAGNOSIS USING DIAGNOSIS 2 MODE

1. Switch the diagnosis mode of the engine control unit to DIAGNOSIS 2 mode using the MUT-II.
2. Carry out a road test.
3. Take a reading of the diagnosis code and repair the problem location.
4. Turn the ignition switch to OFF and then back to ON again.

NOTE

By turning the ignition switch to OFF, the engine-ECU will switch the diagnosis mode from DIAGNOSIS 2 mode to DIAGNOSIS 1 mode.

5. Erase the diagnosis codes.

INSPECTION USING MUT-II DATA LIST AND ACTUATOR TESTING

1. Carry out inspection by means of the data list and the actuator test function. If there is an abnormality, check and repair the chassis harnesses and components.
2. After repairing, re-check using the MUT-II and check that the abnormal input and output have returned to normal as a result of the repairs.
3. Erase the diagnosis code memory.
4. Remove the MUT-II, and then start the engine again and carry out a road test to confirm that the problem has disappeared.

FREEZE FRAME DATA

When the engine-ECU detects a malfunction and stores a diagnosis code, it also stores a current status of the engine. This function is called “freeze frame data.” By analyzing this “freeze frame” data with the MUT-II, an effective troubleshooting can be performed.

Displayed items of freeze frame data are shown in the following:

DISPLAYED ITEM LIST

| Data item | Unit | |
|---|--|---------|
| Engine coolant temperature sensor | °C | |
| Engine speed | r/min | |
| Vehicle speed | km/h | |
| Long-term fuel compensation (long-term fuel trim) | % | |
| Short-term fuel compensation (short-term fuel trim) | % | |
| Fuel control condition | Open loop | OL |
| | Closed loop | CL |
| | Open loop owing to drive condition | OL-DRV. |
| | Open loop owing to system malfunction | OL-SYS. |
| | Closed loop based on one oxygen sensor | CL-H02S |
| Calculation load value | % | |
| Diagnosis code during data recording | – | |

NOTE

If malfunctions have been detected in multiple systems, store one malfunction only, which has been detected first.

READINESS TEST STATUS

The engine-ECU monitors the following main diagnosis items, judges if these items are in good condition or not, and the stores its history. This history can be read out by using MUT-II. (If the ECU has judged a item before, the MUT-II displays “Complete.”)

In addition, if diagnosis codes are erased or the battery cable is disconnected, this history will also be erased (the memory will be reset).

- Catalyst: P0421
- Oxygen sensor: P0130
- Oxygen sensor heater: P0135, P0141

FAIL-SAFE FUNCTION REFERENCE TABLE

When the main sensor malfunctions are detected by the diagnosis function, the vehicle is controlled by means of the pre-set control logic to maintain safe conditions for driving.

| Malfunctioning item | Control contents during malfunction |
|-----------------------------------|--|
| Vacuum sensor | <ol style="list-style-type: none"> 1. Uses the throttle position sensor signal and engine speed signal (crank angle sensor signal) to take reading of the basic injector drive time and basic ignition timing from the pre-set mapping. 2. Fixes the ISC servo in the appointed position so idle control is not performed. |
| Intake air temperature sensor | Controls as if the intake air temperature is 45°C. |
| Throttle position sensor (TPS) | No increase in fuel injection amount during acceleration due to the throttle position sensor signal. |
| Engine coolant temperature sensor | Controls as if the engine coolant temperature is 80°C. |
| Camshaft position sensor | Injects fuel into the cylinders in the order 1-3-4-2 with irregular timing. (After the ignition switch is turned to ON, the No. 1 cylinder top dead centre is not detected at all.) |
| Detonation sensor | Switches the ignition timing from ignition timing for super petrol to ignition timing for standard petrol. |
| Oxygen sensor (front) | Air/fuel ratio feedback control (closed loop control) is not performed. |
| Oxygen sensor (rear) | Performs the feedback control (closed loop control) of the air/fuel ratio by using only the signal of the oxygen sensor (front) installed on the front of the catalytic converter. |
| Misfire detection | The engine-ECU stops supplying fuel to the cylinder with the highest misfiring rate if a misfiring that could damage the catalytic converter is detected. |

INSPECTION CHART FOR DIAGNOSIS CODES


| Code No. | Diagnosis item | Reference page |
|----------|--|----------------|
| P0105 | Vacuum sensor system | 13B-10 |
| P0110 | Intake air temperature sensor system | 13B-12 |
| P0115 | Engine coolant temperature sensor system | 13B-13 |
| P0120 | Throttle position sensor system | 13B-16 |
| P0125 | Feedback system | 13B-18 |
| P0130 | Oxygen sensor (front) system <sensor 1> | 13B-19 |
| P0135 | Oxygen sensor heater (front) system <sensor 1> | 13B-21 |
| P0136 | Oxygen sensor (rear) system <sensor 2> | 13B-22 |
| P0141 | Oxygen sensor heater (rear) system <sensor 2> | 13B-24 |
| P0170 | Abnormal fuel system | 13B-25 |
| P0201 | No. 1 injector system | 13B-26 |
| P0202 | No. 2 injector system | 13B-26 |
| P0203 | No. 3 injector system | 13B-26 |
| P0204 | No. 4 injector system | 13B-26 |
| P0300★ | Random cylinder misfire detected | 13B-27 |
| P0301 | No. 1 cylinder misfire detected | 13B-28 |
| P0302 | No. 2 cylinder misfire detected | 13B-28 |
| P0303 | No. 3 cylinder misfire detected | 13B-28 |
| P0304 | No. 4 cylinder misfire detected | 13B-28 |
| P0325 | Detonation sensor system | 13B-29 |
| P0335 | Crank angle sensor system | 13B-25 |
| P0340 | Camshaft position sensor system | 13B-31 |
| P0403 | EGR control solenoid valve system | 13B-32 |
| P0421 | Catalyst malfunction | 13B-33 |
| P0443 | Purge control solenoid valve system | 13B-34 |
| P0500 | Vehicle speed sensor system | 13B-35 |
| P0505 | Idle speed control system | 13B-36 |
| P1610 | Immobilizer system | 13B-38 |


NOTE

1. Do not replace the engine-ECU until a through terminal check reveals there are no short/open circuit.
2. Check that the engine-ECU earth circuit is normal before checking for the cause of the problem.
3. After the engine-ECU has detected a malfunction, a diagnosis code is recorded the next time the engine is started and the same malfunction is re-detected. However, for items marked with a “★”, the diagnosis code is recorded on the first detection of the malfunction.
4. Sensor 1 indicates the sensor mounted at a position closest to the engine, and sensor 2 indicates the sensor mounted at the position second closest to the engine.


INSPECTION PROCEDURE CLASSIFIED BY DIAGNOSIS CODE


| Code No. P0105 Vacuum sensor system | Range of Check |
|--|--|
| Range of Check ● Ignition switch: ON Set Conditions ● The output voltage of the vacuum sensor is 4.5 V or more for 2 seconds. (This corresponds to the absolute manifold pressure of 115 kPa or more.) | <ul style="list-style-type: none"> ● Malfunction of the vacuum sensor ● Improper connector contact, open circuit or short-circuited harness ● Malfunction of the engine-ECU |
| Range of Check ● The output voltage of the throttle position sensor is 1.25 V or more. or ● The vehicle is stationary. Set Conditions ● The output voltage of the vacuum sensor is 0.2 V or less for 2 seconds. (This corresponds to the absolute manifold pressure of 4.9 kPa or less.) | |







| Code No. P0110 Intake air temperature sensor system | Probable cause |
|---|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> Two seconds have passed since the ignition switch is turned ON or the engine starting process is completed. <p>Set Conditions</p> <ul style="list-style-type: none"> The sensor output voltage is 4.6 V or more for two seconds (equivalent to -45°C of intake air temperature) <p>or</p> <ul style="list-style-type: none"> The sensor output voltage is 0.2 V or more for two seconds (equivalent to 125°C of intake air temperature) | <ul style="list-style-type: none"> Malfunction of intake air temperature sensor Open or short circuit in intake air temperature sensor or loose connector contact Malfunction of engine-ECU |





| Code No. P0115 Engine coolant temperature sensor system | Probable cause |
|---|--|
| Range of Check • Engine: Two seconds after the engine has been started Set Conditions • The sensor output voltage is 4.6 V or more for two seconds (equivalent to -45°C of engine coolant temperature) or • The sensor output voltage is 0.1 V or less for two seconds (equivalent to 140°C of engine coolant temperature) | <ul style="list-style-type: none"> • Malfunction of engine coolant temperature sensor • Open or short circuit in the engine coolant temperature sensor circuit or loose connector contact • Malfunction of engine-ECU |
| Range of Check • Engine: After starting Set Conditions • The engine coolant temperature has reduced from over 40°C to less than 40°C, and that condition has lasted for five minutes or more. | |






NOTE:


*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. 0120 Throttle position sensor system | Probable cause |
|--|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON Excluding 2 seconds after the ignition switch is turned to ON or immediately after the engine starts. <p>Set Conditions</p> <ul style="list-style-type: none"> Engine speed is 1,000 r/min or less, and intake air pressure is 48kPa or less, TPS output voltage is 4.6 V or more for 2 seconds. <p>or</p> <ul style="list-style-type: none"> The sensor output voltage is 0.2 V or less for 2 seconds. | <ul style="list-style-type: none"> Malfunction of throttle position sensor Open or short circuit in the throttle position sensor circuit or loose connector contact Malfunction of the engine-ECU |



NOTE:


*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)




NOTE:

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)


| Code No. P0125 Feedback system | Probable cause |
|--|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> The engine coolant temperature is approx. 80°C or more. During stoichiometric feedback control The vehicle is not being decelerated. <p>Set Conditions</p> <ul style="list-style-type: none"> Oxygen sensor (front) output voltage has been higher or lower than 0.5 V for at least thirty seconds. | <ul style="list-style-type: none"> Malfunction of oxygen sensor (front) Open or short circuit in the oxygen sensor (front) circuit or loose connector contact Malfunction of engine-ECU |




| Code No. P0130 Oxygen sensor (front) system <sensor 1> | Probable cause |
|---|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> ● Three minutes have been passed since the engine has been started. ● The engine coolant temperature is approx. 80°C or more. ● Intake air temperature is 20 – 50°C ● Engine speed is 1,200 r/min or more ● Driving on a level surface at constant speed. <p>Set Conditions</p> <ul style="list-style-type: none"> ● The oxygen sensor (front) output voltage is 4.5 V or more when the sensor output voltage is 0.2 V or less and a voltage of 5 V is applied to the oxygen sensor (front) inside the engine-ECU. | <ul style="list-style-type: none"> ● Malfunction of oxygen sensor (front) ● Open or short circuit in the oxygen sensor (front) circuit or loose connector contact ● Malfunction of engine-ECU |
| <p>Range of Check</p> <ul style="list-style-type: none"> ● Engine speed is 2,800 r/min or less ● During driving ● During air/fuel ratio feedback control <p>Set Conditions</p> <ul style="list-style-type: none"> ● The oxygen sensor (front) output frequency is six or less per 10 seconds on average. | |




| Code No. P0135 Oxygen sensor heater (front) system <sensor 1> | Probable cause |
|---|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> • The engine coolant temperature is approx. 20°C or more. • The oxygen sensor heater (front) remains on. • The engine speed is 50 r/min or more. • Battery voltage is 11 – 16 V. <p>Set Conditions</p> <ul style="list-style-type: none"> • The current, which flows through the oxygen sensor heater (front), is 0.2 A or less or 3.5 A or more for six seconds. | <ul style="list-style-type: none"> • Malfunction of oxygen sensor heater (front) • Open or short circuit in the oxygen sensor heater (front) circuit or loose connector contact • Malfunction of engine-ECU |




| Code No. P0136 Oxygen sensor (rear) system <sensor 2> | Probable cause |
|---|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> ● Three minutes have been passed since the engine has been started. ● The engine coolant temperature is approx. 80°C or more. ● Intake air temperature is 20 – 50°C ● Engine speed is 1,200 r/min or more ● Driving on a level surface at constant speed. <p>Set Conditions</p> <ul style="list-style-type: none"> ● The oxygen sensor (rear) output voltage is 4.5 V or more when the sensor output voltage is 0.2 V or less and a voltage of 5 V is applied to the oxygen sensor (rear) inside the engine-ECU. | <ul style="list-style-type: none"> ● Malfunction of oxygen sensor (rear) ● Open or short circuit in the oxygen sensor (rear) circuit or loose connector contact ● Malfunction of engine-ECU |
| <p>Range of Check</p> <ul style="list-style-type: none"> ● Two seconds have passed after the ECU detected an open circuit. ● When the oxygen sensor (front) is in good condition. <p>Set Conditions</p> <ul style="list-style-type: none"> ● When the air/fuel ratio is rich, the oxygen sensor (front) output voltage is 0.5 V or more, the oxygen sensor (rear) output voltage is less than 0.1 V, and the oxygen sensor (rear) output voltage fluctuates within 0.078 V. | |



| Code No. P0141 Oxygen sensor heater (rear) system <sensor 2> | Probable cause |
|---|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> • The engine coolant temperature is approx. 20°C or more. • The oxygen sensor heater (rear) remains on. • The engine speed is 50 r/min or more. • Battery voltage is 11 – 16 V. <p>Set Conditions</p> <ul style="list-style-type: none"> • The current, which flows through the oxygen sensor heater (rear), is 0.2 A or less or 3.5 A or more for six seconds. | <ul style="list-style-type: none"> • Malfunction of oxygen sensor heater (rear) • Open or short circuit in the oxygen sensor heater (rear) circuit or loose connector contact • Malfunction of engine-ECU |




| Code No. P0170 Abnormal fuel system | Probable cause |
|--|---|
| Range of Check ● Engine: Being learning the air-fuel ratio Set Conditions ● Two seconds or more have been passed while the fuel injection amount compensation value is too low. or ● Two seconds or more have been passed while the fuel injection amount compensation value is too high. | <ul style="list-style-type: none"> ● Incorrect fuel pressure ● Malfunction of injector ● Malfunction of oxygen sensor (front) ● Malfunction of intake air temperature sensor ● Malfunction of vacuum sensor ● Malfunction of engine-ECU |



NOTE:

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)


| Code No. P0201 No. 1 injector system Code No. P0202 No. 2 injector system Code No. P0203 No. 3 injector system Code No. P0204 No. 4 injector system | Probable cause |
|--|--|
| Range of Check ● Engine speed is approx. 50 – 1,000 r/min ● The throttle position sensor output voltage is 1.15 V or less. ● Actuator test by MUT-II is not carried out. Set Conditions ● Surge voltage of injector coil is not detected for 2 seconds. | ● Malfunction of the injector ● Improper connector contact, open circuit or short-circuited harness wire of the injector circuit ● Malfunction of the engine-ECU |



NOTE:

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)


| Code No. P0300 Random cylinder misfire detected | Probable cause |
|--|--|
| Range of Check <ul style="list-style-type: none"> ● Engine speed is approx. 50 – 4,500 r/min. ● When the engine is running except deceleration and sudden acceleration Set Conditions <ul style="list-style-type: none"> ● The number of misfire exceeds a predetermined number per 200 engine revolutions. ● The number of misfire exceeds a predetermined number per 1,000 engine revolutions. | <ul style="list-style-type: none"> ● Malfunction of the ignition system ● Abnormal compression ● Malfunction of injector ● Abnormal signal from the crank angle sensor ● Malfunction of the lambda control system ● Malfunction of the engine coolant temperature sensor ● Missing timing belt teeth ● Malfunction of the EGR valve ● Malfunction of engine-ECU |



NOTE:

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)


| Code No. P0301 No. 1 cylinder misfire detected Code No. P0302 No. 2 cylinder misfire detected Code No. P0303 No. 3 cylinder misfire detected Code No. P0304 No. 4 cylinder misfire detected | Probable cause |
|--|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> • The engine speed is 500 – 4,500 r/min. • While the engine is running except deceleration and sudden acceleration. <p>Set Conditions</p> <ul style="list-style-type: none"> • The number of misfires exceeds a predetermined number per 200 engine revolutions (Misfire has occurred in only one cylinder). <p>or</p> <ul style="list-style-type: none"> • The number of misfires exceeds a predetermined number per 1,000 engine revolutions (Misfire has occurred in only one cylinder). | <ul style="list-style-type: none"> • Malfunction of the ignition system • Abnormal compression • Malfunction of injector • Malfunction of engine-ECU |




NOTE:

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)


| Code No. P0325 Detonation sensor system | Probable cause |
|--|--|
| Range of Check ● Engine: Two seconds after the engine has been started Set Conditions ● Changes in sensor output voltage (detonation sensor peak voltage per 1/2 crankshaft rotation) in 200 consecutive cycles are 0.06 V or less. | ● Malfunction of the detonation sensor ● Open or short circuit in the detonation sensor circuit or loose connector contact ● Malfunction of engine-ECU |




| Code No. P0335 Crank angle sensor system | Probable cause |
|--|--|
| Range of Check ● Engine is cranking Set Conditions ● Sensor output voltage does not change for 2 seconds (no pulse signal input). | ● Malfunction of the crank angle sensor. ● Open or short circuit in the crank angle sensor circuit or loose connector contact. ● Malfunction of engine-ECU |




| Code No. P0340 Camshaft position sensor system | Probable cause |
|--|---|
| Range of Check ● After the engine was started Set Conditions ● The sensor output voltage does not change for 2 seconds (no pulse signal input). | ● Malfunction of the camshaft position sensor ● Open or short circuit in the camshaft position sensor circuit or loose connector contact. ● Malfunction of engine-ECU |




| Code No. P0403 EGR control solenoid valve system | Probable cause |
|---|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> ● Ignition switch: ON ● Battery voltage is 10 V or more. <p>Set Conditions</p> <ul style="list-style-type: none"> ● The solenoid coil surge voltage (battery voltage + 2 V) is not detected when the EGR control solenoid valve is turned from on to off. | <ul style="list-style-type: none"> ● Malfunction of the EGR control solenoid valve ● Open or short circuit in the EGR control solenoid valve circuit or loose connector contact ● Malfunction of engine-ECU |




| Code No. P0421 Catalyst malfunction | Probable cause |
|---|---|
| <p>Range of Check</p> <ul style="list-style-type: none"> • The engine speed is 4,000 r/min or less. • During driving • During air/fuel ratio feedback control <p>Set Conditions</p> <ul style="list-style-type: none"> • The ratio between the oxygen sensor (rear) and the oxygen sensor (front) output frequencies reaches 0.8 per 10 seconds on average. | <ul style="list-style-type: none"> • Malfunction of catalyst • Malfunction of the oxygen sensor (front) • Malfunction of the oxygen sensor (rear) • Malfunction of engine-ECU |




| Code No. P0443 Purge control solenoid valve system | Probable cause |
|---|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> ● Ignition switch: ON ● Battery voltage is 10 V or more. <p>Set Conditions</p> <ul style="list-style-type: none"> ● The solenoid coil surge voltage (battery voltage + 2 V) is not detected when the purge control solenoid valve is turned from on to off. | <ul style="list-style-type: none"> ● Malfunction of the purge control solenoid valve ● Open or short circuit in the purge control solenoid valve circuit or loose connector contact ● Malfunction of engine-ECU |



| Code No. P0500 Vehicle speed sensor system | Probable cause |
|---|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> ● Engine: Two seconds after the engine was started ● Idle switch: OFF ● Engine speed: 2,500 r/min or more ● During high engine load <p>Set Conditions</p> <ul style="list-style-type: none"> ● The sensor output voltage does not change for 2 seconds (no pulse signal input). | <ul style="list-style-type: none"> ● Malfunction of the vehicle speed sensor ● Open or short circuit in the vehicle speed sensor circuit or loose connector contact ● Malfunction of engine-ECU |



| Code No. P0505 Idle speed control (ISC) system | Probable cause |
|--|--|
| <p>Check Area</p> <ul style="list-style-type: none"> ● Vehicle speed has reached 1.5 km/h at least once. ● Under the closed loop idle speed control. <p>Judgment Criteria</p> <ul style="list-style-type: none"> ● Actual idle speed has continued to be higher than the target idle speed by 300 r/min or more for 10 sec. <p>Check Area</p> <ul style="list-style-type: none"> ● Vehicle speed has reached 1.5 km/h at least once. ● During idle speed closed loop control. ● The highest temperature at the last drive is 45°C or less. ● Engine coolant temperature is approx. 80°C or more. ● Battery voltage is 10 V or more. ● Intake air temperature is -10°C (14°F) or more. <p>Judgment Criteria</p> <ul style="list-style-type: none"> ● Actual idle speed has been minimum 200 r/min higher than the target idle speed for ten seconds. <p>Check Area</p> <ul style="list-style-type: none"> ● During idle speed closed loop control. ● Engine coolant temperature is about 80°C or higher. ● Battery voltage is 10 V or higher. ● Power steering switch is off. ● Intake air pipe pressure is 53 kPa or less. ● Intake air temperature is -10°C or more. <p>Judgment Criteria</p> <ul style="list-style-type: none"> ● Actual idle speed has been minimum 100 r/min higher than the target idle speed for ten seconds. | <ul style="list-style-type: none"> ● Malfunction of idle speed control (ISC) servo ● Improper connector contact, open circuit or short-circuited harness wire ● Malfunction of the engine-ECU |




NOTE:

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Cord No. P1610 Immobilizer system | Probable cause |
|--|--|
| Range of Check ● Ignition switch: ON Set Conditions ● Improper communication between the engine-ECU and the immobilizer-ECU | ● Open or short circuit, or loose connector contact ● Malfunction of the immobilizer-ECU ● Malfunction of the engine-ECU |

NOTE

- (1) If the registered ignition keys are close each other when starting the engine, radio interference may cause this code to be displayed.
- (2) This code may be displayed when registering the key ID code.




INSPECTION CHART FOR TROUBLE SYMPTOMS

| Trouble symptom | | Inspection procedure No. | Reference page |
|--|---|--------------------------|----------------|
| Communication with MUT-II is impossible. | Communication with all systems is not possible. | 1 | 13B-40 |
| | Communication with engine-ECU only is not possible. | 2 | 13B-40 |
| Engine warning lamp and related parts | The engine warning lamp does not illuminate right after the ignition switch is turned to the ON position. | 3 | 13B-41 |
| | The engine warning lamp remains illuminating and never goes out. | 4 | 13B-41 |
| Starting | No initial combustion (starting impossible) | 5 | 13B-42 |
| | Initial combustion but no complete combustion (starting impossible) | 6 | 13B-43 |
| | Long time to start (improper starting) | 7 | 13B-44 |
| Idling stability (Improper idling) | Unstable idling (Rough idling, hunting) | 8 | 13B-45 |
| | Idling speed is high. (Improper idling speed) | 9 | 13B-47 |
| | Idling speed is low. (Improper idling speed) | 10 | 13B-47 |
| Idling stability (Engine stalls) | When the engine is cold, it stalls at idling. (Die out) | 11 | 13B-48 |
| | When the engine becomes hot, it stalls at idling. (Die out) | 12 | 13B-49 |
| | The engine stalls when starting the car. (Pass out) | 13 | 13B-51 |
| | The engine stalls when decelerating. | 14 | 13B-51 |
| Driving | Hesitation, sag or stumble | 15 | 13B-52 |
| | The feeling of impact or vibration when accelerating | 16 | 13B-53 |
| | The feeling of impact or vibration when decelerating | 17 | 13B-53 |
| | Poor acceleration | 18 | 13B-54 |
| | Surge | 19 | 13B-55 |
| | Knocking | 20 | 13B-56 |
| Dieseling | | 21 | 13B-56 |
| Too high CO and HC concentration when idling | | 22 | 13B-57 |
| Fans (radiator fan, A/C condenser fan) are inoperative | | 23 | 13B-58 |

INSPECTION PROCEDURE FOR TROUBLE SYMPTOMS


INSPECTION PROCEDURE 1

| | |
|--|---|
| <p>Communication with MUT-II is not possible. (Communication with all systems is not possible.)</p> | <p>Probable cause</p> |
| <p>The cause is probably a defect in the power supply system (including earth) for the diagnosis line.</p> | <ul style="list-style-type: none"> ● Malfunction of the connector ● Malfunction of the harness wire |



INSPECTION PROCEDURE 2

| | |
|---|--|
| <p>MUT-II communication with engine-ECU is impossible.</p> | <p>Probable cause</p> |
| <p>One of the following causes may be suspected:</p> <ul style="list-style-type: none"> ● No power supply to engine-ECU. ● Defective earth circuit of engine-ECU. ● Defective engine-ECU. ● Improper communication line between engine-ECU and MUT-II | <ul style="list-style-type: none"> ● Malfunction of engine-ECU power supply circuit ● Malfunction of engine-ECU ● Open circuit between engine-ECU and diagnosis connector |




NOTE

Though the above inspection has been performed, if trouble symptom does not disappear, check the multi center display, and replace it if necessary.


INSPECTION PROCEDURE 3

| The engine warning lamp does not illuminate right after the ignition switch is turned to the ON position. | Probable cause |
|---|---|
| Because there is a burnt-out bulb, the engine-ECU causes the engine warning lamp to illuminate for five seconds immediately after the ignition switch is turned to ON. If the engine warning lamp does not illuminate immediately after the ignition switch is turned to ON, one of the malfunctions listed at right has probably occurred. | <ul style="list-style-type: none"> • Burnt-out bulb • Defective warning lamp circuit • Malfunction of the engine-ECU |




INSPECTION PROCEDURE 4

| The engine warning lamp remains illuminating and never goes out. | Probable cause |
|---|---|
| In cases such as the above, the cause is probably that the engine-ECU is detecting a problem in a sensor or actuator, or that one of the malfunctions listed at right has occurred. | <ul style="list-style-type: none"> • Short-circuit between the engine warning lamp and engine-ECU • Malfunction of the engine-ECU |




INSPECTION PROCEDURE 5

| No initial combustion (starting impossible) | Probable cause |
|--|--|
| In cases such as the above, the cause is probably that a spark plug is defective, or that the supply of fuel to the combustion chamber is defective. In addition, foreign materials (water, kerosene, etc.) may be mixed with the fuel. | <ul style="list-style-type: none"> ● Malfunction of the ignition system ● Malfunction of the fuel pump system ● Malfunction of the injectors ● Malfunction of the engine-ECU ● Malfunction of the immobilizer system ● Foreign materials in fuel |



INSPECTION PROCEDURE 6

| Initial combustion but no complete combustion (starting impossible) | Probable cause |
|---|--|
| In such cases as the above, the cause is probably that the spark plugs are generating sparks but the sparks are weak, or the initial mixture for starting is not appropriate. | <ul style="list-style-type: none"> ● Malfunction of the ignition system ● Malfunction of the injector system ● Foreign materials in fuel ● Poor compression ● Malfunction of the engine-ECU |




NOTE:

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)


INSPECTION PROCEDURE 7

| In takes too long time to start. (Incorrect starting) | Probable cause |
|--|--|
| In cases such as the above, the cause is probably that the spark is weak and ignition is difficult, the initial mixture for starting is not appropriate, or sufficient compression pressure is not being obtained. | <ul style="list-style-type: none"> ● Malfunction of the ignition system ● Malfunction of the injector system ● Inappropriate gasoline use ● Poor compression |




INSPECTION PROCEDURE 8

| Unstable idling (Rough idling, hunting) | Probable cause |
|--|--|
| <p>In cases as the above, the cause is probably that the ignition system, air/fuel mixture, idle speed control (ISC) or compression pressure is defective. Because the range of possible causes is broad, inspection is narrowed down to simple items.</p> | <ul style="list-style-type: none"> ● Malfunction of the ignition system ● Malfunction of air-fuel ratio control system ● Malfunction of the ISC system ● Malfunction of the purge control solenoid valve system ● Malfunction of the EGR solenoid valve system ● Poor compression ● Drawing air into exhaust system |



NOTE:

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)




NOTE:

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

INSPECTION PROCEDURE 9

| Idling speed is high. (Improper idling speed) | Probable cause |
|--|---|
| In such cases as the above, the cause is probably that the intake air volume during idling is too great. | <ul style="list-style-type: none"> ● Malfunction of the ISC system ● Malfunction of the throttle body |




NOTE:

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

INSPECTION PROCEDURE 10

| Idling speed is low. (Improper idling speed) | Probable cause |
|--|---|
| In cases such as the above, the cause is probably that the intake air volume during idling is too small. | <ul style="list-style-type: none"> ● Malfunction of the ISC system ● Malfunction of the throttle body |




NOTE:

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

INSPECTION PROCEDURE 11

| When the engine is cold, it stalls at idling. (Die out) | Probable cause |
|--|---|
| In such cases as the above, the cause is probably that the air/fuel mixture is inappropriate when the engine is cold, or that the intake air volume is insufficient. | <ul style="list-style-type: none"> ● Malfunction of the ISC system ● Malfunction of the throttle body ● Malfunction of the injector system ● Malfunction of the ignition system |





NOTE:

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

INSPECTION PROCEDURE 12

| When the engine is hot, it stalls at idling. (Die out) | Probable cause |
|--|---|
| In such cases as the above, the cause is probably that ignition system, air/fuel mixture, idle speed control (ISC) or compression pressure is defective. In addition, if the engine suddenly stalls, the cause may also be a defective connector contact. | <ul style="list-style-type: none"> ● Malfunction of the ignition system ● Malfunction of air-fuel ratio control system ● Malfunction of the ISC system ● Drawing air into intake system ● Improper connector contact |






NOTE:

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)


INSPECTION PROCEDURE 13

| The engine stalls when starting the car. (Pass out) | Probable cause |
|--|--|
| In cases such as the above, the cause is probably misfiring due to a weak spark, or an inappropriate air/fuel mixture when the accelerator pedal is depressed. | <ul style="list-style-type: none"> • Drawing air into intake system • Malfunction of the ignition system |




INSPECTION PROCEDURE 14

| The engine stalls when decelerating. | Probable cause |
|--|---|
| In cases such as the above, the cause is probably that the intake air volume is insufficient due to a defective idle speed control (ISC) servo system. | <ul style="list-style-type: none"> • Malfunction of the ISC system |



INSPECTION PROCEDURE 15

| Hesitation, sag or stumble | Probable cause |
|--|---|
| In cases such as the above, the cause is probably that ignition system, air/fuel mixture or compression pressure is defective. | <ul style="list-style-type: none"> ● Malfunction of the ignition system ● Malfunction of air-fuel ratio control system ● Malfunction of the fuel supply system ● Malfunction of the EGR control solenoid valve system ● Poor compression |




NOTE:

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)


INSPECTION PROCEDURE 16

| The feeling of impact or vibration when accelerating | Probable cause |
|--|--|
| In cases such as the above, the cause is probably that there is an ignition leak accompanying the increase in the spark plug demand voltage during acceleration. | <ul style="list-style-type: none"> • Malfunction of the ignition system |



INSPECTION PROCEDURE 17

| The feeling of impact or vibration when decelerating. | Probable cause |
|---|---|
| Malfunction of the ISC system is suspected. | <ul style="list-style-type: none"> • Malfunction of the ISC system |




NOTE:

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

INSPECTION PROCEDURE 18

| Poor acceleration | Probable cause |
|--|--|
| Defective ignition system, abnormal air-fuel ratio, poor compression pressure, etc. are suspected. | <ul style="list-style-type: none"> ● Malfunction of the ignition system ● Malfunction of air-fuel ratio control system ● Malfunction of the fuel supply system ● Poor compression pressure ● Clogged exhaust system |




NOTE:

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

INSPECTION PROCEDURE 19

| Surge | Probable cause |
|---|--|
| Defective ignition system, abnormal air-fuel ratio, etc. are suspected. | <ul style="list-style-type: none"> ● Malfunction of the ignition system ● Malfunction of air-fuel ratio control system ● Malfunction of the EGR control solenoid valve system |




NOTE:

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

INSPECTION PROCEDURE 20

| Knocking | Probable cause |
|---|---|
| In cases as the above, the cause is probably that the detonation control is defective or the heat value of the spark plug is inappropriate. | <ul style="list-style-type: none"> ● Defective detonation sensor ● Inappropriate heat value of the spark plug |




INSPECTION PROCEDURE 21

| Dieseling | Probable cause |
|---|---|
| Fuel leakage from injectors is suspected. | <ul style="list-style-type: none"> ● Fuel leakage from injectors |

Check the injectors for fuel leakage.

INSPECTION PROCEDURE 22

| Too high CO and HC concentration when idling | Probable cause |
|--|---|
| Abnormal air-fuel ratio is suspected. | <ul style="list-style-type: none"> ● Malfunction of the air-fuel ratio control system ● Deteriorated catalyst |




NOTE:

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)


INSPECTION PROCEDURE 23

| Fans (radiator fan, A/C condenser fan) are inoperative. | Probable cause |
|---|--|
| The fan motor relay is controlled by the power transistor inside the engine-ECU turning ON and OFF. | <ul style="list-style-type: none"> ● Malfunction of the fan motor relay ● Malfunction of the fan motor ● Malfunction of the thermostat ● Improper connector contact, open circuit or short-circuited harness wire ● Malfunction of the engine-ECU |




INSPECTION PROCEDURE 24

Check the engine-ECU power supply and earth circuit.



INSPECTION PROCEDURE 25

| Power supply system and ignition switch-IG system | Probable cause |
|---|---|
| When an ignition switch ON signal is input to the engine-ECU, the engine-ECU turns the control relay ON. This causes battery voltage to be supplied to the engine-ECU, injectors and air flow sensor. | <ul style="list-style-type: none"> Malfunction of the ignition switch Malfunction of the control relay Improper connector contact, open circuit or short-circuited harness wire Disconnected engine-ECU earth wire Malfunction of the engine-ECU |




NOTE:

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

INSPECTION PROCEDURE 26

| Fuel pump system | Probable cause |
|---|---|
| The engine-ECU turns the fuel pump relay ON when the engine is cranking or running, and this supplies power to drive the fuel pump. | <ul style="list-style-type: none"> • Malfunction of the fuel pump relay • Malfunction of the fuel pump • Improper connector contact, open circuit or short-circuited harness wire • Malfunction of the engine-ECU |




NOTE:

*: Refer to the '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)


INSPECTION PROCEDURE 27

| Ignition switch-ST system | Probable cause |
|--|---|
| The ignition switch-ST inputs a HIGH signal to the engine-ECU while the engine is cranking. The engine-ECU controls fuel injection, etc. during starting based on this input. | <ul style="list-style-type: none"> ● Malfunction of ignition switch ● Improper connector contact, open circuit or short-circuited harness wire ● Malfunction of the engine-ECU |




INSPECTION PROCEDURE 28

| Power steering fluid pressure switch system | Probable cause |
|---|--|
| The presence or absence of power steering load is input to the engine-ECU. The engine-ECU controls the idle speed control (ISC) servo based on this input. | <ul style="list-style-type: none"> ● Malfunction of power steering fluid pressure switch ● Improper connector contact, open circuit or short-circuited harness wire ● Malfunction of the engine-ECU |




INSPECTION PROCEDURE 29

| A/C switch and A/C relay system | Probable cause |
|---|---|
| When an A/C ON signal is input to the engine-ECU, the engine-ECU carries out control of the idle speed control (ISC) servo, and also operates the A/C compressor magnetic clutch. | <ul style="list-style-type: none"> ● Malfunction of A/C control system ● Malfunction of A/C switch ● Improper connector contact, open circuit or short-circuited harness wire ● Malfunction of the engine-ECU |




INSPECTION PROCEDURE 30


| Electrical load switch | Probable cause |
|---|--|
| During idling, the ON/OFF condition of switches is equipment which have a large electrical load is input to the engine-ECU. The engine-ECU controls the idle speed control servo on this input. | <ul style="list-style-type: none"> ● Improper connector contact, open circuit or short-circuited harness wire in the headlamp relay circuit ● Improper connector contact, open circuit or short-circuited harness wire in the defogger relay circuit. ● Malfunction of the engine-ECU |



INSPECTION PROCEDURE 31

| Ignition circuit system | Probable cause |
|---|---|
| The engine-ECU interrupts the ignition coil primary current by turning the power transistor inside the engine-ECU ON and OFF. | <ul style="list-style-type: none"> • Malfunction of ignition coil • Malfunction of ignition failure sensor • Improper connector contact, open circuit or short-circuited harness wire • Malfunction of the engine-ECU |





DATA LIST REFERENCE TABLE

NOTE

- *1: In a new vehicle [driven approximately 500 km or less], the air intake plenum pressure is sometimes 10 % higher than the standard pressure.
- *2: The injector drive time represents the time when the cranking speed is at 250 r/min or below when the power supply voltage is 11 V.
- *3: In a new vehicle [driven approximately 500 km or less], the injector drive time is sometimes 10 % longer than the standard time.
- *4: In a new vehicle [driven approximately 500 km or less], the step of the stepper motor is sometimes 30 steps greater than the standard value.

| Item No. | Inspection item | Inspection contents | Normal condition | Inspection procedure No. | Reference page | |
|----------|-------------------------------|---|---|---|----------------|--------|
| 11 | Oxygen sensor (front) | Engine: After having warmed up Air/fuel mixture is made leaner when decelerating, and is made richer when racing. | When at 4,000 r/min, engine is suddenly decelerated | 200 mV or less | Code No. P0130 | 13B-19 |
| | | | When engine is suddenly raced | 600 – 1,000 mV | | |
| | | Engine: After having warmed up The oxygen sensor signal is used to check the air/fuel mixture ratio, and control condition is also checked by the ECU. | Engine is idling | 400 mV or less (Changes) 600 – 1,000 mV | | |
| | | | 2,500 r/min | | | |
| 13 | Intake air temperature sensor | Ignition switch: ON or with engine running | When intake air temperature is –20°C | –20°C | Code No. P0110 | 13B-12 |
| | | | When intake air temperature is 0°C | 0°C | | |
| | | | When intake air temperature is 20°C | 20°C | | |
| | | | When intake air temperature is 40°C | 40°C | | |
| | | | When intake air temperature is 80°C | 80°C | | |
| 14 | Throttle position sensor | Ignition switch: ON | Set to idle position | 300 – 1,000 mV | Code No. P0120 | 13B-16 |
| | | | Gradually open | Increases in proportion to throttle opening angle | | |
| | | | Open fully | 4,500 – 5,500 mV | | |

| Item No. | Inspection item | Inspection contents | Normal condition | Inspection procedure No. | Reference page | |
|----------|--------------------------------------|---|--|--|------------------|--------|
| 16 | Power supply voltage | Ignition switch: ON | System voltage | Procedure No. 25 | 13B-59 | |
| 18 | Cranking signal (ignition switch-ST) | Ignition switch: ON | Engine: Stopped | OFF | Procedure No. 27 | 13B-61 |
| | | | Engine: Cranking | ON | | |
| 21 | Engine coolant temperature sensor | Ignition switch: ON or with engine running | When engine coolant temperature is -20°C | -20°C | Code No. P0115 | 13B-13 |
| | | | When engine coolant temperature is 0°C | 0°C | | |
| | | | When engine coolant temperature is 20°C | 20°C | | |
| | | | When engine coolant temperature is 40°C | 40°C | | |
| | | | When engine coolant temperature is 80°C | 80°C | | |
| 22 | Crank angle sensor | <ul style="list-style-type: none"> ● Engine: Cranking ● Tachometer: Connected | Compare the engine speed readings on the tachometer and the MUT-II. | Accord | Code No. P0335 | 13B-25 |
| | | | <ul style="list-style-type: none"> ● Engine: Idling ● Idle position switch: ON | When engine coolant temperature is -20°C | | |
| | | When engine coolant temperature is 0°C | | 1,345 – 1,545 r/min | | |
| | | When engine coolant temperature is 20°C | | 1,200 – 1,400 r/min | | |
| | | When engine coolant temperature is 40°C | | 1,160 – 1,225 r/min | | |
| | | When engine coolant temperature is 80°C | 650 – 850 r/min | | | |
| 24 | Vehicle speed sensor | Drive at 40 km/h | Approximately 40 km/h | Code No. P0500 | 13B-35 | |

| Item No. | Inspection item | Inspection contents | Normal condition | Inspection procedure No. | Reference page | |
|----------|--------------------------------------|---|--|--------------------------|------------------|--------|
| 27 | Power steering fluid pressure switch | Engine: Idling | Steering wheel stationary | OFF | Procedure No. 28 | 13B-61 |
| | | | Steering wheel turning | ON | | |
| 28 | A/C switch | Engine: Idling (when A/C switch is ON, A/C compressor should be operating.) | A/C switch: OFF | OFF | Procedure No. 29 | 13B-62 |
| | | | A/C switch: ON | ON | | |
| 32 | Vacuum sensor*1 | <ul style="list-style-type: none"> ● Engine coolant temperature: 80 – 95°C ● Lamps, electric cooling fan and all accessories: OFF ● Transmission: Neutral ● Ignition switch: ON | Engine: Stopped (At altitude of 0 m) | 101 kPa | Code No. P0105 | 13B-10 |
| | | | Engine: Stopped (At altitude of 600 m) | 95 kPa | | |
| | | | Engine: Stopped (At altitude of 1,200 m) | 88 kPa | | |
| | | | Engine: Stopped (At altitude of 1,800 m) | 81 kPa | | |
| | | | Engine: Idling | 24.3 – 37.7 kPa | | |
| | | | When engine is suddenly raced | Increases | | |
| 33 | Electrical load switch | All accessories: OFF | Lighting switch only: OFF → ON | OFF → ON | Procedure No. 30 | 13B-62 |
| 41 | Injectors*2 | Engine: Cranking | When engine coolant temperature is 0°C (injection is carried out for all cylinders simultaneously) | 13 – 23 ms | – | – |
| | | | When engine coolant temperature is 20°C | 26 – 46 ms | | |
| | | | When engine coolant temperature is 80°C | 8 – 12 ms | | |

| Item No. | Inspection item | Inspection contents | Normal condition | Inspection procedure No. | Reference page | |
|----------|--|---|-------------------------------|--|------------------|--------|
| 41 | Injectors* ³ | <ul style="list-style-type: none"> • Engine coolant temperature: 80 – 95°C • Lamps, electric cooling fan and all accessories: OFF • Transmission: Neutral | Engine is idling | 1.7 – 2.9 ms | – | – |
| | | | 2,500 r/min | 1.4 – 2.6 ms | | |
| | | | When engine is suddenly raced | Increases | | |
| 44 | Ignition coils and power transistors | <ul style="list-style-type: none"> • Engine: After having warmed up • Timing lamp is set. (The timing lamp is set in order to check actual ignition timing.) | Engine is idling | 0 – 20 °BTDC | – | – |
| | | | 2,500 r/min | 19 – 39 °BTDC | | |
| 45 | ISC (stepper) motor position* ⁴ | <ul style="list-style-type: none"> • Engine coolant temperature: 80 – 95°C • Lamps, electric cooling fan and all accessories: OFF • Transmission: Neutral • Engine: Idling • When A/C switch is ON, A/C compressor should be operating | A/C switch: OFF | 2 – 25 STEP | – | – |
| | | | A/C switch: OFF → ON | Increases by 10 – 70 steps | | |
| 49 | A/C relay | Engine: After having warmed up/Engine is idling | A/C switch: OFF | OFF (Compressor clutch is not operating) | Procedure No. 29 | 13B-62 |
| | | | A/C switch: ON | ON (Compressor clutch is operating) | | |
| 59 | Oxygen sensor (rear) | <ul style="list-style-type: none"> • Transmission: 2nd gear • Drive with throttle widely open | 3,500 r/min | 600 – 1,000 mV | Code No. P0136 | 13B-22 |

| Item No. | Inspection item | Inspection contents | | Normal condition | Inspection procedure No. | Reference page |
|----------|---|--|---|--|--------------------------|----------------|
| 81 | Long-term fuel compensation | Engine: Warm, 2,500 r/min without any load (during closed loop) | | -12.5 – 12.5 % | Code No. P0170 | 13B-25 |
| 82 | Short-term fuel compensation | Engine: Warm, 2,500 r/min without any load (during closed loop) | | -17 – 17 % | Code No. P0170 | 13B-25 |
| 87 | Calculation load value | Engine: Warm | Engine: Idling | 20 – 33 % | – | – |
| | | | 2,500 r/min | 20 – 33 % | | |
| 88 | Fuel control condition | Engine: Warm | 2,500 r/min | Closed loop | Code No. P0125 | 13B-18 |
| | | | When engine is suddenly raced | Open loop – drive condition | | |
| A1 | Oxygen sensor (front) | Engine: After having warmed up Air/fuel mixture is made leaner when decelerating, and is made richer when racing. | When at 4,000 r/min, engine is suddenly decelerated | 0.2 V or less | Code No. P0130 | 13B-19 |
| | | | When engine is sudden racing | 0.6 – 1.0 V | | |
| | | Engine: After having warmed up The oxygen sensor signal is used to check the air/fuel mixture ratio, and control condition is also checked by the engine-ECU. | Engine is idling | 0.4 V or less (Changes) 0.6 – 1.0 V | | |
| | | | 2,500 r/min | | | |
| A2 | Oxygen sensor (rear) | <ul style="list-style-type: none"> Transmission: 2nd gear Drive with throttle widely open | 3,500 r/min | 0.6 – 1.0 V | Code No. P0136 | 13B-22 |
| 8A | Throttle position sensor (Throttle opening angle) | <ul style="list-style-type: none"> Ignition switch: ON | Set to idle position | 6 – 20 % | Code No. P0120 | 13B-16 |
| | | | Gradually open | Increase in proportion to throttle opening angle | | |
| | | | Open fully | 80 – 100 % | | |

ACTUATOR TEST REFERENCE TABLE

| Item No. | Inspection item | Drive contents | Inspection contents | Normal condition | Inspection procedure No. | Reference page | |
|----------|------------------------------|--|---|--|--|------------------|--------|
| 01 | Injectors | Cut fuel to No. 1 injector | Engine: After having warmed up/Engine is idling (Cut the fuel supply to each injector in turn and check cylinders which don't affect idling.) | Idling condition becomes different (becomes unstable). | Code No. P0201 | 13B-26 | |
| 02 | | Cut fuel to No. 2 injector | | | Code No. P0202 | | |
| 03 | | Cut fuel to No. 3 injector | | | Code No. P0203 | | |
| 04 | | Cut fuel to No. 4 injector | | | Code No. P0204 | | |
| 07 | Fuel pump | Fuel pump operates and fuel is recirculated. | <ul style="list-style-type: none"> ● Engine: Cranking ● Fuel pump: Forced driving Inspect according to both the above conditions. | Pinch the return hose with fingers to feel the pulse of the fuel being recirculated. | Pulse is felt. | Procedure No. 26 | 13B-60 |
| | | | Listen near the fuel tank for the sound of fuel pump operation. | Sound of operation is heard. | | | |
| 08 | Purge control solenoid valve | Solenoid valve turns from OFF to ON. | Ignition switch: ON | | Sound of operation can be heard when solenoid valve is driven. | Code No. P0443 | 13B-34 |
| 10 | EGR control solenoid valve | Solenoid valve turns from OFF to ON. | Ignition switch: ON | | Sound of operation can be heard when solenoid valve is driven. | Code No. P0403 | 13B-32 |
| 20 | Condenser fan | Drive the fan motors (condenser) | <ul style="list-style-type: none"> ● Ignition switch: ON ● A/C switch: ON | | Fan motor runs | Procedure No. 23 | 13B-23 |
| 21 | Radiator fan | Drive the fan motors (radiator) | <ul style="list-style-type: none"> ● Ignition switch: ON | | Fan motor runs | Procedure No. 23 | 13B-23 |


CHECK AT THE ENGINE-ECU TERMINALS**TERMINAL VOLTAGE CHECK CHART**

The following items have been added. The ignition timing adjustment terminal (terminal No. 52) has been discontinued.

| Terminal No. | Check item | Check condition | Normal condition |
|--------------|---|---------------------------|------------------|
| 10 | Ignition coil – No. 1, No. 4 (Ignition power transistor) | Engine r/min: 3,000 r/min | 0.3 – 3.0 V |
| 23 | Ignition coil – No. 2, No. 3 (Ignition power transistor) | Engine r/min: 3,000 r/min | 0.3 – 3.0 V |
| 58 | Engine ignition signal | Engine r/min: 3,000 r/min | 0.3 – 3.0 V |
| 88 | Camshaft position sensor | Engine: Cranking | 0.4 – 3.0 V |
| | | Engine: Idling | 0.5 – 2.0 V |

CHECK CHART FOR RESISTANCE AND CONTINUITY BETWEEN TERMINALS

| Terminal No. | Check item | Normal condition (check condition) |
|--------------|------------------------------|------------------------------------|
| 54 – 12 | Oxygen sensor heater (rear) | 4.5 – 8.0 Ω (at 20°C) |
| 60 – 12 | Oxygen sensor heater (front) | 11 – 18 Ω (at 20°C) |



INSPECTION PROCEDURE USING AN ANALYZER

CAMSHAFT POSITION SENSOR AND CRANK ANGLE SENSOR

Measurement Method

1. Disconnect the camshaft position sensor connector and connect the special tool (test harness: MB991709) in between. (All terminals should be connected.)
2. Connect the analyzer special patterns pickup to camshaft position sensor terminal 2.
3. Disconnect the crank angle sensor connector and connect the special tool (test harness: MD998478) in between.
4. Connect the analyzer special patterns pickup to crank angle sensor terminal 2.

Alternate Method (Test harness not available)


1. Connect the analyzer special patterns pickup to engine-ECU terminal 88. (When checking the camshaft position sensor signal wave pattern.)
2. Connect the analyzer special patterns pickup to engine-ECU terminal 89. (When checking the crank angle sensor signal wave pattern.)

Standard Wave Pattern

Observation conditions


| Function | Special patterns |
|------------------|------------------|
| Pattern height | Low |
| Pattern selector | Display |
| Engine r/min | Idle speed |

Standard wave pattern



Wave Pattern Observation Points

Check that cycle time T becomes shorter when the engine speed increases.



Examples of Abnormal Wave Patterns


- Example 1

Cause of problem

Sensor interface malfunction

Wave pattern characteristics

Rectangular wave pattern is output even when the engine is not started.




- Example 2

Cause of problem

Loose timing belt
Abnormality in sensor disk

Wave pattern characteristics

Wave pattern is displaced to the left or right.



IDLE SPEED CONTROL (ISC) SERVO (STEPPER MOTOR)

Measurement Method

1. Disconnect the ISC servo connector, and connect the special tool (test harness: MB991709) in between. (All terminals should be connected.)
2. Connect the analyzer special patterns pickup to the ISC servo-side connector terminal 1, terminal 3, terminal 4 and terminal 6 respectively.

Alternate Method (Test harness not available)


1. Connect the analyzer special patterns pickup to engine-ECU terminal 4, connection terminal 5, connection terminal 17, and connection terminal 18 respectively.

Standard Wave Pattern

Observation conditions

| | |
|------------------|--|
| Function | Special patterns |
| Pattern height | High |
| Pattern selector | Display |
| Engine condition | When the engine coolant temperature is 20°C or below, turn the ignition switch from OFF to ON (without starting the engine). |
| | While the engine is idling, turn the A/C switch to ON. |
| | Immediately after starting the warm engine |

Standard wave pattern



Wave Pattern Observation Points



Check that the standard wave pattern appears when the ISC servo is operating.

Point A: Presence or absence of induced electromotive force from the motor turning. (Refer to the abnormal wave pattern.)

| Contrast with standard wave pattern | Probable cause |
|--|-------------------------|
| Induced electromotive force does not appear or is extremely small. | Motor is malfunctioning |

Point B: Height of coil electromotive force

| Contrast with standard wave pattern | Probable cause |
|---|-------------------|
| Coil reverse electromotive force does not appear or is extremely small. | Short in the coil |



Examples of Abnormal Wave Pattern

- Example 1

Cause of problem

Motor is malfunctioning. (Motor is not operating.)

Wave pattern characteristics

Induced electromotive force from the motor turning does not appear.


- Example 2

Cause of problem

Open circuit in the line between the ISC servo and the engine-ECU.

Wave pattern characteristics

Current is not supplied to the motor coil on the open circuit side. (Voltage does not drop to 0 V.) Furthermore, the induced electromotive force waveform at the normal side is slightly different from the normal waveform.



IGNITION COIL AND POWER TRANSISTOR

Power transistor control signal

Measurement Method

1. Disconnect the ignition coil connector, and connect the special tool (test harness: MB991348) in between. (All terminals should be connected.)
2. Connect the analyzer special patterns pickup to terminal 3 of each ignition coil connector in turn.

Alternate Method (Test harness not available)


1. Connect the analyzer special patterns pickup to engine-ECU terminal 10 (No. 1 – No. 4), terminal 23 (No. 2 – No. 3) respectively.

Standard Wave Pattern

Observation condition

| | |
|------------------|---------------------|
| Function | Special patterns |
| Pattern height | Low |
| Pattern selector | Display |
| Engine r/min | Approx. 1,200 r/min |


Standard wave pattern



Wave Pattern Observation Points

Point: Condition of wave pattern build-up section and maximum voltage (Refer to abnormal wave pattern examples 1 and 2.)

| Condition wave pattern build-up section and maximum voltage | Probable cause |
|---|--|
| Rises from approx. 2 V to approx. 4.5 V at the top-right | Normal |
| 2V rectangular wave | Open-circuit in ignition primary circuit |
| Rectangular wave at power voltage | Power transistor malfunction |



Examples of Abnormal Wave Pattern

- Example 1


Wave pattern during engine cranking

Cause of problem

Open-circuit in ignition primary circuit

Wave pattern characteristics

Top-right part of the build-up section cannot be seen, and voltage value is approximately 2 V too low.



- Example 2

Wave pattern during engine cranking

Cause of problem

Malfunction in power transistor

Wave pattern characteristics

Power voltage results when the power transistor is ON.

ON-VEHICLE SERVICE

BASIC IDLE SPEED ADJUSTMENT

NOTE

- (1) The standard idling speed has been adjusted by the speed adjusting screw (SAS) by the manufacturer, and there should usually be no need for readjustment.
 - (2) If the adjustment has been changed by mistake, the idle speed may become too high or the idle speed may drop too low when loads from components such as the A/C are placed on the engine. If this occurs, adjust by the following procedure.
 - (3) The adjustment, if made, should be made after first confirming that the spark plugs, the injectors, the idle speed control servo, the compression pressure, etc., are all normal.
1. Before inspection and adjustment, set the vehicle to the pre-inspection condition.
 2. Connect the MUT-II to the diagnosis connector (16-pin).

NOTE

When the MUT-II is connected, the diagnosis control terminal should be earthed.

3. Start the engine and run at idle.
4. Select the item No. 30 of the MUT-II Actuator test.

NOTE


This holds the ISC servo at the basic step to adjust the basic idle speed.

5. Check the idle speed.

Standard value: 750 ± 50 r/min

NOTE

- (1) The engine speed may be 20 to 100 r/min lower than indicated above for a new vehicle [driven approximately 500 km or less], but no adjustment is necessary.
 - (2) If the engine stalls or the engine speed is low even though the vehicle has been driven approximately 500 km or more, it is probable that deposits are adhered to the throttle valve, so clean it.
6. If not within the standard value range, turn the speed adjusting screw (SAS) to make the necessary adjustment.
 7. Press the MUT-II clear key, and release the ISC servo from the Actuator test mode.



1FU1265


NOTE

Unless the ISC servo is released, the Actuator test mode will continue 27 minutes.



8. Switch OFF the ignition switch.
9. Disconnect the MUT-II.
10. Start the engine again and let it run at idle speed for about 10 minutes; check that the idling condition is normal.

COMPONENT LOCATION

| Name | Symbol | Name | Symbol |
|--------------------------|--------|-------------------------|--------|
| Camshaft position sensor | B | Ignition failure sensor | B |
| Crank angle sensor | C | Oxygen sensor (front) | D |
| Ignition coil | A | Oxygen sensor (rear) | E |



Y6068AJ



INTAKE AIR TEMPERATURE SENSOR CHECK

1. Disconnect the vacuum sensor connector.
2. Measure resistance between terminals 1 and 3.

Standard value:

2.3 – 3.0 kΩ (at 20°C)
 0.30 – 0.42 kΩ (at 80°C)

3. Remove the vacuum sensor.



4. Measure resistance while heating the sensor using a hair drier.

Normal condition:

| Temperature (°C) | Resistance (kΩ) |
|------------------|-----------------|
| Higher | Smaller |

5. If the value deviates from the standard value or the resistance remains unchanged, replace the vacuum sensor.
6. Install the vacuum sensor and tighten it to the specified torque.

Tightening torque: 13 – 15 Nm




OXYGEN SENSOR CHECK

<Oxygen sensor (front)>

1. Disconnect the oxygen sensor connector and connect the special tool (test harness) to the connector on the oxygen sensor side.

2. Make sure that there is continuity (4.5 – 8.0 Ω at 20°C) between terminal 1 (red clip of special tool) and terminal 3 (blue clip of special tool) on the oxygen sensor connector.
3. If there is no continuity, replace the oxygen sensor.
4. Warm up the engine until engine coolant is 80°C or higher.



- Use a jumper wire to connect terminal 1 (red clip) of the oxygen sensor connector to the battery (+) terminal and terminal 3 (blue clip) to the battery (-) terminal.

Caution

Be very careful when connecting the jumper wire; incorrect connection can damage the oxygen sensor.

- Connect a digital voltage meter between terminal 2 (black clip) and terminal 4 (white clip).
- While repeatedly racing the engine, measure the oxygen sensor output voltage.


Standard value:

| Engine | Oxygen sensor output voltage | Remarks |
|------------------------|------------------------------|---|
| When racing the engine | 0.6 – 1.0 V | If you make the air/fuel ratio rich by racing the engine repeatedly, a normal oxygen sensor will output a voltage of 0.6 – 1.0 V. |

- If the sensor is defective, replace the oxygen sensor.

NOTE

For removal and installation of the oxygen sensor, refer to GROUP 15 – Exhaust Pipe and Main Muffler.




<Oxygen sensor (rear)>

- Disconnect the oxygen sensor connector and connect the special tool (test harness set) to the connector on the oxygen sensor side.
- Make sure that there is continuity (11 – 18 Ω at 20°C) between terminal 3 and terminal 4 on the oxygen sensor connector.
- If there is no continuity, replace the oxygen sensor.

NOTE

- If the MUT-II does not display the standard value although no abnormality is found by the above mentioned continuity test and harness check, replace the oxygen sensor (rear).
- For removal and installation of the oxygen sensor, refer to GROUP 15 – Exhaust Pipe and Main Muffler.




FUEL INJECTOR

REMOVAL AND INSTALLATION

Pre-removal and Post-installation Operation


- Prevention of Fuel Discharge <before removal only>
- Fuel Leak Check <after installation only>
- Accelerator Cable Adjustment



Removal steps

1. Accelerator cable connection
2. Fuel injector connector
3. Vacuum hose connection
4. Fuel return hose connection
5. Fuel pressure regulator
6. O-ring
7. High-pressure fuel hose connection
8. O-ring
9. Delivery pipe and fuel injector assembly

- ▶A◀ 10. Insulator
- ▶A◀ 11. Insulator
- ▶A◀ 12. Fuel injector assembly
- ▶A◀ 13. O-ring
- ▶A◀ 14. Grommet
- ▶A◀ 15. Fuel injector
- ▶A◀ 16. Harness bracket
- ▶A◀ 17. Delivery pipe



REMOVAL SERVICE POINT**◀A▶ DELIVERY PIPE AND FUEL INJECTOR
ASSEMBLY REMOVAL**

Remove the delivery pipe (with the injectors attached to it).

Caution

Care must be taken, when removing the delivery pipe, not to drop the injector.

INSTALLATION SERVICE POINT**▶A◀ O-RING/FUEL INJECTOR ASSEMBLY/
HIGH-PRESSURE FUEL HOSE/FUEL PRESSURE
REGULATOR INSTALLATION**

1. Apply a drop of new engine oil to the O-ring.

Caution

Be sure not to let engine oil enter the delivery pipe.

2. While turning the injector, high-pressure fuel hose and fuel pressure regulator to the right and left, install the delivery pipe, while being careful not to damage the O-ring. After installing, check that the hose turns smoothly.
3. If it does not turn smoothly, the O-ring may be trapped, remove the injector, high-pressure fuel hose or fuel pressure regulator and then re-insert it into the delivery pipe and check once again.
4. Tighten the high-pressure fuel hose and fuel pressure regulator to the specified torque.

Tightening torque:

5.0 Nm (High-pressure fuel hose)


8.8 Nm (Fuel pressure regulator)

THROTTLE BODY

REMOVAL AND INSTALLATION


Pre-removal and Post-installation Operation

- Engine Coolant Draining
- Air Intake Hose Removal and Installation
- Accelerator Cable Adjustment <after installation>



Removal steps

- | | |
|---|--|
| <ul style="list-style-type: none"> 1. Accelerator cable connection 2. Throttle position sensor connector 3. Idle speed control servo connector 4. Water hose connection | <ul style="list-style-type: none"> 5. Vacuum hose connection 6. Vacuum pipe and hose assembly 7. Throttle body 8. Throttle body gasket |
|---|--|



INSTALLATION SERVICE POINT

▶A◀ THROTTLE BODY GASKET INSTALLATION

Install the throttle body gasket with its projection facing as shown in the illustration.

FUEL SUPPLY

CONTENTS


| | | | |
|-------------------------|----------|-------------------------------------|----------|
| GENERAL | 2 | SPECIAL TOOL | 2 |
| Outline of Change | 2 | FUEL TANK <F9QT> | 3 |



GENERAL**OUTLINE OF CHANGE**

The following service procedures have been established to correspond to the addition of the F9QT diesel engine. Other service procedures are the same as before.

SPECIAL TOOL

| Tool | Number | Name | Use |
|---|----------|-----------------|--------------------------|
|  | MB996009 | Tank cap wrench | Installation of tank cap |

FUEL TANK <F9QT>


REMOVAL AND INSTALLATION

Pre-removal Operation

- Draining the Fuel

Post-installation Operation


- Refilling the Fuel
- Checking for Fuel Leaks



AY0093AJ


Removal steps




1. Fuel hoses connection
2. Harness clamp
3. Toe control link support bar
4. Band (RH)
5. Fuel pump module connector
6. Fuel tank assembly
7. Heat protector
8. Band (LH)
9. Fuel hoses
10. Cap
11. Fuel pump module
12. Fuel filler cap
13. Fuel rubber drain
14. Filler neck assembly
15. Leveling hose
16. Filler hose



REMOVAL SERVICE POINT

◀A▶ CAP REMOVAL





INSTALLATION SERVICE POINTS

▶A◀ FUEL PUMP MODULE INSTALLATION

1. Check to be sure that the fuel tank packing is not damaged or deformed, and then securely install the packing to the fuel tank.

Caution

If the packing is installed to the fuel pump module, packing lip will be damaged when installing the fuel pump module to the fuel tank and the fuel leak will result.

NOTE

If the packing is damaged or deformed, replace the defective packing with a new packing.

2. Apply soapy water to the inside of the packing. Align the mating marks on the fuel tank and fuel pump module as shown in the illustration, and then install the fuel pump module to the fuel tank.

Caution

- (1) Do not tilt the fuel pump module when installing.
- (2) The packing should not be folded over as shown by (A) in the illustration.

▶B◀ CAP INSTALLATION

Apply soapy water to the cap thread, and then use the special tool as the same manner as for removal to tighten the cap to the specified torque.

Tightening torque: 49 Nm

Caution

Prevent the fuel pump module from turning with the cap when tightening the cap.

DIESEL FUEL

CONTENTS

| | | | |
|---|-----------|--|-----------|
| GENERAL | 2 | Engine Coolant Temperature Sensor Check | 52 |
| Outline of Change | 2 | Accelerator Pedal Position Sensor (1st channel) Check | 52 |
| GENERAL INFORMATION | 2 | Accelerator Pedal Position Sensor (2nd channel) Check | 53 |
| SERVICE SPECIFICATIONS | 4 | Injector Check | 53 |
| SPECIAL TOOLS | 4 | Fuel Temperature Sensor Check | 53 |
| TROUBLESHOOTING | 5 | Fuel Pressure Regulator Check | 54 |
| ON-VEHICLE SERVICE | 51 | Crank Angle Sensor Check | 54 |
| Component Location | 51 | Throttle Valve Control Solenoid Check | 54 |
| Main Relay Continuity Check | 52 | Throttle Actuator Check | 54 |
| Intake Air Temperature Sensor Check | 52 | FUEL HIGH PRESSURE PUMP AND FUEL INJECTOR | 55 |

GENERAL

OUTLINE OF CHANGE

The following maintenance service points have been established to correspond to the adoption of the F9Q1 engine.

GENERAL INFORMATION

The common rail fuel injection system consists of sensors which detect the condition of the diesel engine, an engine-ECU which controls the system based on signals from these sensors, and actuators which operate according to control commands from the engine-ECU. The engine-ECU carries out

activities such as fuel injection control and idle speed control. In addition, the engine-ECU is equipped with several self-diagnosis functions which make troubleshooting easier in the event that a problem develops.

FUEL INJECTION CONTROL

The injector drive time and the timing are controlled so that the appropriate quantities of fuel are supplied to the engine in response to engine conditions which can change frequently. A single injector is mounted at each cylinder. The fuel is sent from the fuel tank by

the electronic fuel pump to the high pressure pump. The high pressure pump increases the fuel pressure to the pressure which is required for high-pressure injection, and then send the fuel to each injector.



SELF-DIAGNOSIS FUNCTION

- When an abnormality is detected in any of the sensors or actuators, the engine warning lamp illuminates to warn the driver.
- When an abnormality is detected in any of the sensors or actuators, a diagnosis code number corresponding to the problem which occurred is output.
- The RAM data relating to the sensors and actuators which is stored in the engine-ECU can be read using the MUT-II. In addition, the actuators can be force-driven under certain conditions.

OTHER CONTROL FUNCTIONS

1. A/C Relay Control
Turn the compressor clutch of the A/C ON and OFF.
2. Glow Control
Refer to GROUP 16.
3. Fan Control
The revolutions of the radiator fan and condenser fan are controlled in response to the engine coolant temperature and vehicle speed.
4. EGR Control
Refer to GROUP 17.
5. Throttle Valve Control
The throttle valve control solenoid controls vacuum pressure to the throttle actuator to open and close the throttle valve.
6. Boost Pressure Control
Turbocharger waste gate solenoid controls vacuum pressure to the waste gate actuator to control boost pressure.
7. Additional Heater Control
Refer to GROUP 55.




FUEL INJECTION SYSTEM DIAGRAM



SERVICE SPECIFICATIONS

| Items | Specifications | |
|--|----------------|---------------|
| Intake air temperature sensor resistance k Ω | at -30°C | 24.0 – 27.2 |
| | at 20°C | 2.35 – 2.55 |
| | at 100°C | 0.180 – 0.186 |
| Engine coolant temperature sensor resistance k Ω | at 25°C | 2.14 – 2.36 |
| | at 80°C | 0.27 – 0.29 |
| Accelerator pedal position sensor (1st channel) Resistance between terminals (3) and (5) Ω | Approx. 1,200 | |
| Accelerator pedal position sensor (2nd channel) Resistance between terminals (2) and (6) Ω | Approx. 1,700 | |
| Injector coil resistance Ω (at 20°C) | Approx. 0.33 | |
| Fuel temperature sensor resistance k Ω (at 25°C) | 2.05 | |
| Fuel pressure regulator Ω (at 20°C) | Approx. 5 | |
| Crank angle sensor resistance Ω | 720 – 880 | |
| Throttle valve control solenoid coil resistance Ω (at 25°C) | 43 – 49 | |


SPECIAL TOOLS

| Tool | Number | Name | Use |
|--|----------|------------------------------|--|
|  B991502 | MB991502 | MUT-II sub assembly | <ul style="list-style-type: none"> • Reading diagnosis code • Checking the fuel injection system |
|  | MB990767 | End yoke holder | Holding the fuel high pressure pump sprocket |
|  | MD998719 | Crankshaft pulley holder pin | |

TROUBLESHOOTING

DIAGNOSIS TROUBLESHOOTING FLOW

Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1), GROUP 00 – How to Use Troubleshooting/Inspection Service Points.



DIAGNOSIS FUNCTION

ENGINE WARNING LAMP (CHECK ENGINE LAMP)

If an abnormality occurs in any of the items related to the electronic controlled injection system, the engine warning lamp will illuminate.

If the lamp remains illuminated or if the lamp illuminates while the engine is running, check the diagnosis code output.

NOTE

When the ignition switch is ON, the engine warning lamp illuminates as checking of the engine warning lamp circuit and the bulb, and then the warning lamp is extinguished after a few seconds.

METHOD OF READING AND ERASING DIAGNOSIS CODES

Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1), GROUP 00 – How to Use Troubleshooting/Inspection Service Points.

INSPECTION USING MUT-II DATA LIST AND ACTUATOR TESTING

1. Carry out inspection by means of the data list and the actuator test function.
If there is an abnormality, check and repair the chassis harnesses and components.
2. After repairing, re-check using the MUT-II and check that the abnormal input and output have returned to normal as a result of the repairs.
3. Erase the diagnosis code memory.
4. Remove the MUT-II.
5. Start the engine again and carry out a road test to confirm that the problem has disappeared.

FAIL-SAFE FUNCTION REFERENCE TABLE

| Malfunctioning item | Control contents during malfunction |
|--|---|
| Crank angle sensor system | Engine cut-off |
| Camshaft position sensor system | Engine cut-off |
| Fuel pressure sensor system | Engine cut-off |
| Boost sensor system | <ul style="list-style-type: none"> ● Turbocharger waste gate control is stopped ● EGR control is stopped |
| Air flow sensor system | EGR control is stopped |
| Engine coolant temperature sensor system | <ul style="list-style-type: none"> ● The coolant temperature is regulated as specified ● The radiator fan is driven |
| Intake air temperature sensor system | Thermoplunger control is stopped |
| EGR valve position sensor system | EGR control is stopped |
| Immobilizer system | The engine is immobilized. However, the engine is not cut-off while the engine is running |
| EGR valve system | <ul style="list-style-type: none"> ● Turbocharger waste gate control is stopped ● EGR control is stopped |
| Turbocharger waste gate solenoid system | <ul style="list-style-type: none"> ● Turbocharger waste gate control is stopped ● EGR control is stopped |
| Fuel pressure regulator system | Engine cut-off |
| Fuel pressure system | Engine cut-off |
| Engine-ECU | Engine cut-off |
| Additional heater relay system | Thermoplunger control is stopped |

INSPECTION CHART FOR DIAGNOSIS CODES


Caution

Check that the engine-ECU earth circuit is normal before checking for the cause of the problem.

| Code No. | Diagnosis item | Reference page |
|----------|--|----------------|
| 11 | Crank angle sensor system | 13D-8 |
| 12 | Camshaft position sensor system | 13D-9 |
| 13 | Accelerator pedal position sensor (1st channel) system | 13D-10 |
| 14 | Accelerator pedal position sensor (2nd channel) system | 13D-11 |
| 15 | Fuel pressure sensor system | 13D-12 |
| 16 | Boost sensor system | 13D-13 |
| 17 | Barometric pressure sensor system | 13D-14 |
| 18 | Air flow sensor system | 13D-15 |
| 19 | Engine coolant temperature sensor system | 13D-16 |
| 21 | Fuel temperature sensor system | 13D-17 |
| 22 | Intake air temperature sensor system | 13D-18 |
| 23 | EGR valve position sensor system | 13D-19 |
| 24 | Glow relay box system | 13D-20 |
| 25 | Immobilizer system | 13D-21 |
| 26 | EGR valve system | 13D-22 |
| 27 | Turbocharger waste gate solenoid system | 13D-23 |
| 28 | Fuel pressure regulator system | 13D-24 |
| 29 | No. 1 injector system | 13D-25 |
| 31 | No. 2 injector system | 13D-25 |
| 32 | No. 3 injector system | 13D-26 |
| 33 | No. 4 injector system | 13D-26 |
| 34 | Glow plug system | 13D-27 |
| 35 | Vehicle speed sensor system | 13D-27 |
| 36 | Fuel pressure system | 13D-28 |
| 37 | Throttle valve control solenoid system | 13D-29 |
| 38 | Engine-ECU | 13D-30 |
| 40 | Additional heater relay system | 13D-30 |
| 41 | Fan control relay (low) system | 13D-31 |
| 42 | Stop lamp switch system | 13D-31 |
| 43 | Clutch pedal switch system | 13D-32 |
| 44 | Power latch system | 13D-32 |
| 45 | Main relay system | 13D-33 |
| 46 | Power supply system | 13D-34 |
| 47 | ECU alimentation | 13D-34 |


INSPECTION PROCEDURE FOR DIAGNOSIS CODES

| Code No. 11 Crank angle sensor system | Probable cause |
|---|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> • During engine running <p>Set Conditions</p> <ul style="list-style-type: none"> • Sensor output voltage does not change (no pulse signal input) or • Sensor output value is 5,000 r/min or more for 1 second | <ul style="list-style-type: none"> • Malfunction of the crank angle sensor • Improper connector contact, open circuit or short-circuited harness wire of the crank angle sensor circuit • Malfunction of the engine-ECU |




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. 12 Camshaft position sensor system | Probable cause |
|--|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> • During engine running <p>Set Conditions</p> <ul style="list-style-type: none"> • Sensor output voltage does not change for 0.5 second (no pulse signal input) <p>Range of Check</p> <ul style="list-style-type: none"> • During engine running • Pulse signal detected two or more times <p>Set Conditions</p> <ul style="list-style-type: none"> • Not synchronized with crank angle sensor output <p>or</p> <ul style="list-style-type: none"> • Crank angle sensor output voltage does not change for 0.5 second (no pulse signal input) | <ul style="list-style-type: none"> • Malfunction of the camshaft position sensor • Improper connector contact, open circuit or short-circuited harness wire of the camshaft position sensor circuit • Malfunction of the engine-ECU |




| Code No. 13 Accelerator pedal position sensor (1st channel) system | Probable cause |
|--|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON <p>Set Conditions</p> <ul style="list-style-type: none"> Sensor output voltage is 200 mV or less or Sensor output voltage is 4,750 mV or more | <ul style="list-style-type: none"> Malfunction of the accelerator pedal position sensor (1st channel) Improper connector contact, open circuit or short-circuited harness wire of the accelerator pedal position sensor (1st channel) circuit Malfunction of the engine-ECU |




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. 14 Accelerator pedal position sensor (2nd channel) system | Probable cause |
|---|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON <p>Set Conditions</p> <ul style="list-style-type: none"> Sensor output voltage is 200 mV or less or Sensor output voltage is 2,500 mV or more <p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON <p>Set Conditions</p> <ul style="list-style-type: none"> Output difference compared to accelerator pedal position sensor (1st channel) is 6 % or more | <ul style="list-style-type: none"> Malfunction of the accelerator pedal position sensor (2nd channel) Improper connector contact, open circuit or short-circuited harness wire of the accelerator pedal position sensor (2nd channel) circuit Malfunction of the engine-ECU |




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. 15 Fuel pressure sensor system | Probable cause |
|--|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON <p>Set Conditions</p> <ul style="list-style-type: none"> Sensor output voltage is 250 mV or less or Sensor output voltage is 4,750 mV or more <p>Range of Check</p> <ul style="list-style-type: none"> During engine running <p>Set Conditions</p> <ul style="list-style-type: none"> Fuel pressure varies greatly from command value | <ul style="list-style-type: none"> Malfunction of the fuel pressure sensor Improper connector contact, open circuit or short-circuited harness wire of the fuel pressure sensor circuit Malfunction of the engine-ECU |




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. 16 Boost sensor system | Probable cause |
|---|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON <p>Set Conditions</p> <ul style="list-style-type: none"> Sensor output voltage is 100 mV or less for 1 second or Sensor output voltage is 4,900 mV or more for 1 second <p>Range of Check</p> <ul style="list-style-type: none"> Engine speed: 900 r/min or less <p>Set Conditions</p> <ul style="list-style-type: none"> Variation from barometric pressure sensor output signal is 15 kPa or more for 4.6 seconds | <ul style="list-style-type: none"> Malfunction of the boost sensor Improper connector contact, open circuit or short-circuited harness wire of the boost sensor circuit Malfunction of the engine-ECU |




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. 17 Barometric pressure sensor system | Probable cause |
|---|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON <p>Set Conditions</p> <ul style="list-style-type: none"> Sensor output voltage is 200 mV or less for 1 second or Sensor output voltage is 4,950 mV or more for 1 second | <ul style="list-style-type: none"> Malfunction of the barometric pressure sensor Malfunction of the engine-ECU |




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. 18 Air flow sensor system | Probable cause |
|--|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON <p>Set Conditions</p> <ul style="list-style-type: none"> Sensor output voltage is 100 mV or less for 1.5 seconds or Sensor output voltage is 1,200 mV or more for 1.5 seconds <p>Range of Check</p> <ul style="list-style-type: none"> Engine speed : 700 r/min or more <p>Set Conditions</p> <ul style="list-style-type: none"> Sensor output is 10 kg/h or less for 1 second | <ul style="list-style-type: none"> Malfunction of the air flow sensor Improper connector contact, open circuit or short-circuited harness wire of the air flow sensor circuit Malfunction of the engine-ECU |




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. 19 Engine coolant temperature sensor system | Probable cause |
|---|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON <p>Set Conditions</p> <ul style="list-style-type: none"> Sensor output voltage is 100 mV or less for 1 second or Sensor output voltage is 4,900 mV or more for 1 second | <ul style="list-style-type: none"> Malfunction of the engine coolant temperature sensor Improper connector contact, open circuit or short-circuited harness wire of the engine coolant temperature sensor circuit Malfunction of the engine-ECU |




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. 21 Fuel temperature sensor system | Probable cause |
|---|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON <p>Set Conditions</p> <ul style="list-style-type: none"> Sensor output voltage is 100 mV or less for 1 second or Sensor output voltage is 4,900 mV or more for 1 second | <ul style="list-style-type: none"> Malfunction of the fuel temperature sensor Improper connector contact, open circuit or short-circuited harness wire of the fuel temperature sensor circuit Malfunction of the engine-ECU |




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. 22 Intake air temperature sensor system | Probable cause |
|---|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON <p>Set Conditions</p> <ul style="list-style-type: none"> Sensor output voltage is 100 mV or less for 1 second or Sensor output voltage is 4,850 mV or more for 1 second | <ul style="list-style-type: none"> Malfunction of the intake air temperature sensor Improper connector contact, open circuit or short-circuited harness wire of the intake air temperature sensor circuit Malfunction of the engine-ECU |




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. 23 EGR valve position sensor system | Probable cause |
|--|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON <p>Set Conditions</p> <ul style="list-style-type: none"> Sensor output voltage is 250 mV or less for 1 second or Sensor output voltage is 4,700 mV or more for 1 second <p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: OFF → ON <p>Set Conditions</p> <ul style="list-style-type: none"> Sensor output voltage is 1,500 mV or more for 1 second | <ul style="list-style-type: none"> Malfunction of the EGR valve position sensor Improper connector contact, open circuit or short-circuited harness wire of the EGR valve position sensor circuit Malfunction of the engine-ECU |




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. 24 Glow relay box system | Probable cause |
|--|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: OFF→ON <p>Set Conditions</p> <ul style="list-style-type: none"> Trouble signal input from the glow relay box | <ul style="list-style-type: none"> Malfunction of the glow relay box Improper connector contact, open circuit or short-circuited harness wire of the glow relay box circuit Malfunction of the engine-ECU |



*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)


| Code No. 25 Immobilizer system | Probable cause |
|--|---|
| Range of Check ● Ignition switch: ON Set Conditions ● Improper communication between the engine-ECU and Immobilizer-ECU | <ul style="list-style-type: none"> ● Malfunction of the immobilizer-ECU ● Improper connector contact, open circuit or short-circuited harness wire ● Malfunction of the engine-ECU |



NOTE


If the engine-ECU is replaced, the immobilizer-ECU and ignition key should be replaced together with it.

| Code No. 26 EGR valve system | Probable cause |
|------------------------------|--|
| | <ul style="list-style-type: none"> • Malfunction of the EGR valve • Improper connector contact, open circuit or short-circuited harness wire of the EGR valve circuit • Malfunction of the engine-ECU |




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. 27 Turbocharger waste gate solenoid system | Probable cause |
|---|--|
| | <ul style="list-style-type: none"> ● Malfunction of the turbocharger waste gate solenoid ● Improper connector contact, open circuit or short-circuited harness wire of the turbocharger waste gate solenoid circuit ● Malfunction of the engine-ECU |




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. 28 Fuel pressure regulator system | Probable cause |
|--|--|
| | <ul style="list-style-type: none"> ● Malfunction of the fuel pressure regulator ● Improper connector contact, open circuit or short-circuited harness wire of the fuel pressure regulator circuit ● Malfunction of the engine-ECU |




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. 29 No.1 injector system | Probable cause |
|----------------------------------|--|
| | <ul style="list-style-type: none"> • Malfunction of the No.1 injector • Improper connector contact, open circuit or short-circuited harness wire of the No.1 injector circuit • Malfunction of the engine-ECU |




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. 31 No.2 injector system | Probable cause |
|----------------------------------|--|
| | <ul style="list-style-type: none"> • Malfunction of the No.2 injector • Improper connector contact, open circuit or short-circuited harness wire of the No.2 injector circuit • Malfunction of the engine-ECU |




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. 32 No.3 injector system | Probable cause |
|----------------------------------|--|
| | <ul style="list-style-type: none"> ● Malfunction of the No.3 injector ● Improper connector contact, open circuit or short-circuited harness wire of the No.3 injector circuit ● Malfunction of the engine-ECU |




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. 33 No.4 injector system | Probable cause |
|----------------------------------|--|
| | <ul style="list-style-type: none"> ● Malfunction of the No.4 injector ● Improper connector contact, open circuit or short-circuited harness wire of the No.4 injector circuit ● Malfunction of the engine-ECU |




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. 34 Glow plug system | Probable cause |
|------------------------------|--|
| | <ul style="list-style-type: none"> • Malfunction of the glow plug • Improper connector contact, open circuit or short-circuited harness wire of the glow plug circuit • Malfunction of the engine-ECU |




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. 35 Vehicle speed sensor system | Probable cause |
|---|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> • Ignition switch: ON <p>or</p> <ul style="list-style-type: none"> • During engine running <p>Set Conditions</p> <ul style="list-style-type: none"> • Sensor output voltage corresponds to a speed of 250 km/h or more for 1 second | <ul style="list-style-type: none"> • Malfunction of the vehicle speed sensor • Improper connector contact, open circuit or short-circuited harness wire of the vehicle speed sensor circuit • Malfunction of the engine-ECU |




| Code No. 36 Fuel pressure system | Probable cause |
|----------------------------------|---|
| | <ul style="list-style-type: none"> ● Malfunction of the high pressure pump ● Malfunction of the injector ● Seized fuel pressure regulator ● Fuel leaking from high pressure fuel system |




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. 37 Throttle valve control solenoid system | Probable cause |
|--|--|
| | <ul style="list-style-type: none"> • Malfunction of the throttle valve control solenoid • Improper connector contact, open circuit or short-circuited harness wire of the throttle valve control solenoid circuit • Malfunction of the engine-ECU |




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. 38 Engine-ECU | Probable cause |
|------------------------|---|
| | <ul style="list-style-type: none"> Malfunction of the engine-ECU |




| Code No. 40 Additional heater relay system | Probable cause |
|--|---|
| | <ul style="list-style-type: none"> Malfunction of the additional heater relay 1, 2 Improper connector contact, open circuit or short-circuited harness wire of the additional heater relay circuit Malfunction of the engine-ECU |




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. 41 Fan control relay (low) system | Probable cause |
|--|--|
| | <ul style="list-style-type: none"> Malfunction of the fan control relay Improper connector contact, open circuit or short-circuited harness wire of the fan control relay circuit Malfunction of the engine-ECU |




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. 42 Stop lamp switch system | Probable cause |
|--|--|
| Range of Check <ul style="list-style-type: none"> Ignition switch: ON Set Conditions <ul style="list-style-type: none"> Outputs for stop lamp switches 1 and 2 are different | <ul style="list-style-type: none"> Malfunction of the stop lamp switch Improper connector contact, open circuit or short-circuited harness wire of the stop lamp switch circuit Malfunction of the engine-ECU |




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)

| Code No. 43 Clutch pedal switch system | Probable cause |
|---|--|
| Range of Check • Vehicle speed: 100 km/h or more Set Conditions • Clutch pedal switch remains off for 1 second | <ul style="list-style-type: none"> • Malfunction of the clutch pedal switch • Improper connector contact, open circuit or short-circuited harness wire of the clutch pedal switch circuit • Malfunction of the engine-ECU |




*: Refer to '99 SPACE STAR Workshop Manual (Pub. No. CMXE99E1)


| Code No. 44 Power latch system | Probable cause |
|--------------------------------|---|
| | <ul style="list-style-type: none"> • Malfunction of the engine-ECU |




| Code No. 45 Main relay system | Probable cause |
|---|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON <p>Set Conditions</p> <ul style="list-style-type: none"> Power is not supplied <p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: OFF → ON <p>Set Conditions</p> <ul style="list-style-type: none"> Power latch time is short or long | <ul style="list-style-type: none"> Malfunction of the main relay Improper connector contact, open circuit or short-circuited harness wire of the main relay circuit Malfunction of the engine-ECU |



| Code No. 46 Power supply system | Probable cause |
|---|---------------------------------|
| Range of Check • Ignition switch: ON Set Conditions • Power supply voltage is 6.5 V or less, or 16.5 V or more | • Malfunction of the engine-ECU |



| Code No. 47 ECU alimentation | Probable cause |
|------------------------------|---------------------------------|
| | • Malfunction of the engine-ECU |



INSPECTION CHART FOR TROUBLE SYMPTOMS**Caution**


Check that the engine-ECU earth circuit is normal before checking for the cause of the problem.

| Trouble symptoms | | Inspection procedure No. | Reference page |
|---|--|--------------------------|----------------|
| Communication with MUT-II is impossible | Communication with all systems is not possible. | 1 | 13D-36 |
| | Communication with engine-ECU only is not possible. | 2 | 13D-36 |
| Engine warning lamp and related parts | The engine warning lamp does not illuminate right after the ignition switch is turned to the ON position | 3 | 13D-37 |
| | The engine warning lamp remains illuminating and never goes out. | 4 | 13D-38 |
| Starting | No initial combustion (Starting not possible) | 5 | 13D-38 |
| | Poor startability when engine is cold (Poor starting) | 6 | 13D-39 |
| | Poor startability when engine is cold or warm (Poor starting) | 7 | 13D-39 |
| Idling stability (Improper idling) | Idle speed is low when engine is cold (Improper idling speed) | 8 | 13D-40 |
| | Idling speed is high (Improper idling speed) | 9 | 13D-40 |
| | Idling speed is low (Improper idling speed) | 10 | 13D-41 |
| | Idle speed is unstable (Rough idling, hunting) | 11 | 13D-41 |
| Idling stability (Engine stalls) | Engine stops soon after starting | 12 | 13D-42 |
| | Engine stops during idling | 13 | 13D-42 |
| Driving | Engine output is too low | 14 | 13D-43 |
| | Abnormal engine knocking occurs | 15 | 13D-43 |
| | Abnormally black smoke | 16 | 13D-44 |
| | Abnormally white smoke | 17 | 13D-44 |
| | Hunting occurs while driving | 18 | 13D-45 |

INSPECTION PROCEDURE FOR TROUBLE SYMPTOMS


INSPECTION PROCEDURE 1

| Communication with MUT-II is not possible (Communication with all systems is not possible) | Probable cause |
|---|---|
| The cause is probably a defect in the power supply system (including earth) for the diagnosis line. | <ul style="list-style-type: none"> ● Malfunction of the connector ● Malfunction of the harness wire |



INSPECTION PROCEDURE 2

| MUT-II communication with engine-ECU is impossible. | Probable cause |
|---|--|
| One of the following causes may be suspected. <ul style="list-style-type: none"> ● No power supply to engine-ECU ● Defective earth circuit of engine-ECU ● Defective engine-ECU ● Improper communication line between engine-ECU and MUT-II | <ul style="list-style-type: none"> ● Malfunction of engine-ECU power supply circuit ● Malfunction of the engine-ECU ● Open circuit between engine-ECU and diagnosis connector |




NOTE

On vehicles with the multi-center display, if a malfunction cannot be resolved after the procedure above, check the multi-center display and replace if necessary. (Refer to GROUP 54 – Multi-center Display.)


INSPECTION PROCEDURE 3

| The engine warning lamp does not illuminate right after the ignition switch is turned to the ON position | Probable cause |
|---|---|
| Because there is a burnt-out bulb, the engine-ECU causes the engine warning lamp to illuminate immediately after the ignition switch is turned to ON. If the engine warning lamp does not illuminate immediately after the ignition switch is turned to ON, one of the malfunctions listed at right has probably occurred. | <ul style="list-style-type: none"> ● Burnt-out bulb ● Defective warning lamp circuit ● Malfunction of the engine-ECU |




INSPECTION PROCEDURE 4

| The engine warning lamp remains illuminating and never goes out | Probable cause |
|---|---|
| In cases such as the above, the cause is probably that the engine-ECU is detecting a problem in a sensor or actuator, or that one of the malfunctions listed at right has occurred. | <ul style="list-style-type: none"> ● Short-circuit between the engine warning lamp and engine-ECU ● Malfunction of the engine-ECU |




INSPECTION PROCEDURE 5

| No initial combustion (Starting not possible) | Probable cause |
|---|--|
| The cause is probably a malfunction of the control system, high pressure pump, glow system or power supply. | <ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the high pressure pump ● Malfunction of the glow system ● Malfunction of the immobilizer system ● Malfunction of the engine-ECU |




INSPECTION PROCEDURE 6

| Poor startability when engine is cold (Poor starting) | Probable cause |
|--|---|
| The cause is probably a malfunction of the control system, high pressure pump, fuel system or glow system. | <ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the high pressure pump ● Malfunction of the fuel system ● Malfunction of the glow system ● Malfunction of the engine-ECU |




INSPECTION PROCEDURE 7

| Poor startability when engine is both cold and warm (Poor starting) | Probable cause |
|---|---|
| The cause is probably a malfunction of the control system, high pressure pump or fuel system. | <ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the high pressure pump ● Malfunction of the fuel system ● Malfunction of the engine-ECU |




INSPECTION PROCEDURE 8

| | |
|---|---|
| Idle speed is low when engine is cold (Improper idling speed) | Probable cause |
| The cause is probably a malfunction of the control system, high pressure pump or fuel system. | <ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the high pressure pump ● Malfunction of the fuel system ● Malfunction of the engine-ECU |




INSPECTION PROCEDURE 9

| | |
|---|---|
| Idle speed is high (Improper idling speed) | Probable cause |
| The cause is probably a malfunction of the control system, fuel injector or high pressure pump. | <ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the fuel injector ● Malfunction of the high pressure pump ● Malfunction of the engine-ECU |




INSPECTION PROCEDURE 10

| Idle speed is low (Improper idling speed) | Probable cause |
|---|---|
| The cause is probably a malfunction of the control system, high pressure pump or fuel system. | <ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the high pressure pump ● Malfunction of the fuel system ● Malfunction of the engine-ECU |




INSPECTION PROCEDURE 11

| Idle speed is unstable (Rough idling, hunting) | Probable cause |
|--|--|
| The cause is probably a malfunction of the control system, high pressure pump, fuel system or glow system. | <ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the high pressure pump ● Malfunction of the fuel system ● Malfunction of the glow system ● Malfunction of the EGR system ● Malfunction of the engine-ECU |




INSPECTION PROCEDURE 12

| Engine stops soon after starting | Probable cause |
|---|---|
| The cause is probably a malfunction of the control system, high pressure pump or fuel system. | <ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the high pressure pump ● Malfunction of the fuel system ● Malfunction of the engine-ECU |




INSPECTION PROCEDURE 13

| Engine stops during idling | Probable cause |
|---|--|
| The cause is probably a malfunction of the control system, high pressure pump or power supply system. | <ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the high pressure pump ● Malfunction of the EGR system ● Malfunction of the engine-ECU |




INSPECTION PROCEDURE 14

| Engine output is too low | Probable cause |
|---|---|
| The cause is probably a malfunction of the control system, high pressure pump, fuel system or EGR system. | <ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the high pressure pump ● Malfunction of the fuel system ● Malfunction of the EGR system ● Clogged air flow sensor ● Malfunction of the engine-ECU |




INSPECTION PROCEDURE 15

| Abnormal engine knocking occurs | Probable cause |
|---|---|
| The cause is probably a malfunction of the control system, high pressure pump or fuel system. | <ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the high pressure pump ● Malfunction of the fuel system ● Malfunction of the engine-ECU |




INSPECTION PROCEDURE 16

| Abnormally black smoke | Probable cause |
|---|--|
| The cause is probably a malfunction of the control system, high pressure pump, fuel system or EGR system. | <ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the high pressure pump ● Malfunction of the fuel system ● Malfunction of the EGR system ● Malfunction of the engine-ECU |




INSPECTION PROCEDURE 17

| Abnormally white smoke | Probable cause |
|--|--|
| The cause is probably a malfunction of the control system, high pressure pump, fuel system, EGR system or glow system. | <ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the high pressure pump ● Malfunction of the fuel system ● Malfunction of the EGR system ● Malfunction of the glow system ● Malfunction of the engine-ECU |




INSPECTION PROCEDURE 18

| Hunting occurs while driving | Probable cause |
|---|---|
| The cause is probably a malfunction of the control system, high pressure pump or fuel system. | <ul style="list-style-type: none"> ● Malfunction of the control system ● Malfunction of the high pressure pump ● Malfunction of the fuel system ● Malfunction of the engine-ECU |



INSPECTION PROCEDURE 19

Check the engine-ECU power supply and earth circuit



DATA LIST REFERENCE TABLE

Caution**Driving tests always need another personnel.**

| Item No. | Inspection item | Inspection contents | Normal condition | Inspection procedure No. | Reference page | |
|----------|--------------------------------------|---|---|--------------------------|----------------|--------|
| 01 | Engine coolant temperature sensor | Ignition switch: ON | Engine coolant temperature is -20°C | -20°C | Code No. 19 | 13D-16 |
| | | | Engine coolant temperature is 0°C | 0°C | | |
| | | | Engine coolant temperature is 20°C | 20°C | | |
| | | | Engine coolant temperature is 40°C | 40°C | | |
| | | | Engine coolant temperature is 80°C | 80°C | | |
| 02 | Fuel temperature sensor | <ul style="list-style-type: none"> In cooled state Ignition switch: ON | Approx. the same as the outdoor temperature | Code No. 21 | 13D-17 | |
| 03 | Intake air temperature sensor | Ignition switch: ON | Intake air temperature is -20°C | -20°C | Code No. 22 | 13D-18 |
| | | | Intake air temperature is 0°C | 0°C | | |
| | | | Intake air temperature is 20°C | 20°C | | |
| | | | Intake air temperature is 40°C | 40°C | | |
| | | | Intake air temperature is 80°C | 80°C | | |
| 04 | Boost sensor | Ignition switch: ON | | 950 – 1040 hPa | Code No. 16 | 13D-13 |
| | | <ul style="list-style-type: none"> Engine coolant temperature: $80 - 95^{\circ}\text{C}$ Lamp, electric cooling fan and all accessories: OFF | When engine is suddenly raced | Pressure increases | | |
| 05 | Barometric pressure sensor | Ignition switch: ON | At altitude of 0 m | 950 – 1040 hPa | Code No. 17 | 13D-14 |
| 06 | Fuel pressure sensor | Engine: After warm-up | When engine is suddenly raced | Pressure increases | Code No. 15 | 13D-12 |
| 07 | Fuel pressure sensor (command value) | Engine: After warm-up | When engine is suddenly raced | Pressure increases | – | – |

| Item No. | Inspection item | Inspection contents | Normal condition | Inspection procedure No. | Reference page | |
|----------|---|--|--|--|----------------|--------|
| 08 | Air flow sensor | <ul style="list-style-type: none"> Engine coolant temperature: 80 – 95°C Lamp, electric cooling fan and all accessories: OFF | When engine is suddenly raced | Increases | – | – |
| 09 | Accelerator pedal position sensor (1st channel) | Ignition switch: ON | Release the accelerator pedal | 700 – 800 mV | Code No. 13 | 13D-10 |
| | | | Depress the accelerator pedal gradually | Increases in response to the pedal depression stroke | | |
| | | | Depress the accelerator pedal fully | 3,270 – 4,700 mV | | |
| 10 | Accelerator pedal position sensor (1st channel) | Ignition switch: ON | Release the accelerator pedal | 375 mV | Code No. 14 | 13D-11 |
| | | | Depress the accelerator pedal gradually | Increases in response to the pedal depression stroke | | |
| | | | Depress the accelerator pedal fully | 1,635 – 2,500 mV | | |
| 11 | Accelerator pedal position sensor | Ignition switch: ON | Release the accelerator pedal | 0 % | – | – |
| | | | Depress the accelerator pedal gradually | Increases in response to the pedal depression stroke | | |
| | | | Depress the accelerator pedal fully | 100 % | | |
| 12 | Crank angle sensor | <ul style="list-style-type: none"> Engine: Cranking Tachometer: Connected | Compare the engine speed readings on the tachometer and the MUT-II | Accord | Code No. 11 | 13D-8 |
| 14 | Fuel injection amount | <ul style="list-style-type: none"> Engine coolant temperature: 80 – 95°C Lamp, electric cooling fan and all accessories: OFF | Engine is Idling | 4 – 9 mm ³ | – | – |

| Item No. | Inspection item | Inspection contents | | Normal condition | Inspection procedure No. | Reference page |
|----------|--|--|--|--|--------------------------|----------------|
| 15 | EGR valve position sensor | <ul style="list-style-type: none"> Engine coolant temperature: 80 – 95°C Lamp, electric cooling fan and all accessories: OFF | When engine is suddenly raced | Increases | Code No. 23 | 13D-19 |
| 16 | EGR valve | <ul style="list-style-type: none"> Engine coolant temperature: 80 – 95°C Lamp, electric cooling fan and all accessories: OFF | Engine is Idling | 5 – 10 % | Code No. 26 | 13D-22 |
| | | | When engine is suddenly raced | Increases | | |
| 17 | Turbocharger waste gate solenoid | Ignition switch: ON | When engine is suddenly raced | Increases | Code No. 27 | 13D-23 |
| 18 | Fuel pressure regulator | Engine: After warm-up | When engine is suddenly raced | Voltage increases | Code No. 28 | 13D-24 |
| 20 | Crank angle sensor (2,000 r/min or less) | <ul style="list-style-type: none"> Engine: Cranking [reading is possible at 2,000 r/min or less] Tachometer: Connected | | Engine speeds displayed on the MUT-II and tachometer are identical | – | – |
| 21 | Vehicle speed sensor | When vehicle is moving | Compare the speeds displayed on the speedometer and the MUT-II | Accord | Code No. 35 | 13D-27 |
| 41 | Ignition switch – IG | Ignition switch: ON | | ON | – | – |
| 42 | Stop lamp switch | Ignition switch: ON | Brake pedal: Depressed | ON | Code No. 42 | 13D-31 |
| | | | Brake pedal: Released | OFF | | |
| 44 | Clutch pedal switch | Ignition switch: ON | Clutch pedal: Depressed | ON | Code No. 43 | 13D-32 |
| | | | Clutch pedal: Released | OFF | | |
| 45 | Overheat indicator lamp | Ignition switch: ON | Several seconds pass after ignition switch is turned to ON | ON → OFF | – | – |
| 46 | Glow indicator lamp | Ignition switch: ON | From 0.5 – 16 seconds after ignition switch is turned to ON | ON → OFF | – | – |
| 47 | Throttle valve control solenoid | Engine: Idle | | OFF | Code No. 37 | 13D-29 |
| | | Engine: Idle → stopped | | ON | | |
| 48 | Glow relay box | Ignition switch: ON | From 0.5 – 16 seconds after ignition switch is turned to ON | ON → OFF | Code No. 24 | 13D-20 |

| Item No. | Inspection item | Inspection contents | Normal condition | Inspection procedure No. | Reference page | |
|----------|---------------------------|---|------------------|--|----------------|---|
| 50 | A/C relay | Engine: After warm-up, idle | A/C switch: OFF | OFF (Compressor clutch is not operating) | – | – |
| | | | A/C switch: ON | ON (Compressor clutch is operating) | | |
| 51 | A/C switch | Engine: After warm-up, idle | A/C switch: OFF | OFF | – | – |
| | | | A/C switch: ON | ON | | |
| 52 | Additional heater relay 1 | <ul style="list-style-type: none"> ● Engine coolant temperature: 75°C or lower ● Intake air temperature: 10°C or lower ● Post-heating complete ● All accessories: OFF | ON | Code No. 40 | 13D-30 | |
| | | Engine: After warm-up | OFF | | | |
| 53 | Additional heater relay 2 | <ul style="list-style-type: none"> ● Engine coolant temperature: 75°C or lower ● Intake air temperature: 10°C or lower ● Post-heating complete ● All accessories: OFF | ON | Code No. 40 | 13D-30 | |
| | | Engine: After warm-up | OFF | | | |
| 54 | Fan control relay (high) | Engine coolant temperature: 96°C or lower | OFF | – | – | |
| | | Engine coolant temperature: 102°C or higher | ON | | | |
| 55 | Fan control relay (low) | Engine coolant temperature: 99°C or lower | OFF | – | – | |
| | | Engine coolant temperature: 99 – 102°C | ON | | | |


ACTUATOR TEST REFERENCE TABLE


| Item No. | Inspection item | Drive contents | Inspection contents | Normal condition | Inspection procedure No. | Reference page |
|----------|----------------------------------|--|---|---|--------------------------|----------------|
| 01 | Injector | Cut fuel to No. 1 injector | Engine: After warm-up, idle (Cut the fuel supply to each injector in turn and check cylinders which don't affect idling) | Idling condition becomes different (becomes unstable) | Code No. 29 | 13D-25 |
| 02 | | Cut fuel to No. 2 injector | | | Code No. 31 | 13D-25 |
| 03 | | Cut fuel to No. 3 injector | | | Code No. 32 | 13D-26 |
| 04 | | Cut fuel to No. 4 injector | | | Code No. 33 | 13D-26 |
| 05 | Turbocharger waste gate solenoid | Solenoid valve turns from OFF to ON | Ignition switch: ON | Sound of operation can be heard when solenoid valve is driven | Code No. 27 | 13D-23 |
| 06 | Throttle valve control solenoid | Solenoid valve turns from OFF to ON | Ignition switch: ON | Sound of operation can be heard when solenoid valve is driven | Code No. 37 | 13D-29 |
| 07 | Fuel pressure regulator | Solenoid valve turns from OFF to ON | Ignition switch: ON | Sound of operation can be heard when solenoid valve is driven | Code No. 28 | 13D-24 |
| 08 | EGR valve | Solenoid valve turns from OFF to ON | Ignition switch: ON | Sound of operation can be heard when solenoid valve is driven | Code No. 26 | 13D-22 |
| 09 | Glow relay box | Relay turns from OFF to ON | <ul style="list-style-type: none"> ● Ignition switch: ON ● Check operating condition on data list | OFF → ON | Code No. 24 | 13D-20 |
| 10 | Additional heater relay 1 | Relay turns from OFF to ON | Ignition switch: ON | Sound of operation can be heard when relay is driven | Code No. 40 | 13D-30 |
| 11 | Additional heater relay 2 | Relay turns from OFF to ON | Ignition switch: ON | Sound of operation can be heard when relay is driven | Code No. 40 | 13D-30 |
| 12 | Fan control relay (high) | Relay turns from OFF to ON | Ignition switch: ON | Fan motor operates at high speed | – | – |
| 13 | Fan control relay (low) | Relay turns from OFF to ON | Ignition switch: ON | Fan motor operates at low speed | – | – |
| 14 | Engine warning lamp | Causes engine warning lamp to illuminate | Engine: Idle | Engine warning lamp illuminates | – | – |
| 15 | Glow indicator lamp | Causes glow indicator lamp to illuminate | Engine: Idle | Glow indicator lamp illuminates | – | – |
| 16 | Overheat indicator lamp | Causes overheat indicator lamp to illuminate | Engine: Idle | Glow overheat lamp illuminates | – | – |

ON-VEHICLE SERVICE

COMPONENT LOCATION


| Name | Symbol | Name | Symbol |
|---|--------|--|--------|
| A/C relay | H | Engine-ECU (with barometric pressure sensor) | A |
| A/C switch | Q | Fuel pressure regulator | J |
| Accelerator pedal position sensor (1st and 2nd channel) | P | Fuel pressure sensor | D |
| Air flow sensor (with intake air temperature sensor) | G | Fuel temperature sensor | D |
| Boost sensor | M | Glow relay box | I |
| Camshaft position sensor | B | Injector | C |
| Clutch pedal switch | N | Main relay | R |
| Crank angle sensor | K | Stop lamp switch | N |
| Diagnosis connector | R | Throttle valve control solenoid | E |
| EGR valve | F | Turbocharger waste gate solenoid | E |
| EGR valve position sensor | F | Vehicle speed sensor | K |
| Engine coolant temperature sensor | L | | |





MAIN RELAY CONTINUITY CHECK

| Battery voltage | Terminal No. | | | |
|-----------------|--------------|---|---|---|
| | 1 | 2 | 3 | 4 |
| Not supplied | ○ | ○ | ○ | ○ |
| Supplied | ○ | ⊖ | ○ | ⊕ |



INTAKE AIR TEMPERATURE SENSOR CHECK


1. Disconnect the air flow sensor connector.
2. Measure the resistance between terminals 1 and 2.

Standard value:

24.0 – 27.2 kΩ (at -30°C)

2.35 – 2.55 kΩ (at 20°C)

0.180 – 0.186 kΩ (at 100°C)




ENGINE COOLANT TEMPERATURE SENSOR CHECK

1. Disconnect the engine coolant temperature sensor connector.
2. Measure the resistance between terminals 2 and 3.

Standard value: 2.14 – 2.36 kΩ (at 25°C)

0.27 – 0.29 kΩ (at 80°C)



ACCELERATOR PEDAL POSITION SENSOR (1st channel) CHECK


1. Disconnect the accelerator pedal position sensor connector.
2. Measure the resistance between terminals 3 and 5.


Standard value: Approx. 1200 Ω

3. Measure the resistance between terminals 4 and 5.

Normal condition:

| | |
|--------------------------------------|---|
| Depress the accelerator pedal slowly | Resistance value changes in accordance with the accelerator pedal depression smoothly |
|--------------------------------------|---|





ACCELERATOR PEDAL POSITION SENSOR (2nd channel) CHECK

1. Disconnect the accelerator pedal position sensor connector.
2. Measure the resistance between terminals 2 and 6.



Standard value: Approx. 1,700 Ω

3. Measure the resistance between terminals 1 and 6.

Normal condition:

Depress the accelerator pedal slowly


Resistance value changes in accordance with the accelerator pedal depression smoothly



INJECTOR CHECK

1. Disconnect the injector connector.
2. Measure the resistance between terminals.


Standard value: Approx. 0.33 Ω (at 20°C)



FUEL TEMPERATURE SENSOR CHECK

1. Disconnect the fuel temperature sensor connector.
2. Measure the resistance between terminals.


Standard value: 2.05 k Ω (at 25°C)



FUEL PRESSURE REGULATOR CHECK

1. Disconnect the fuel pressure regulator connector.
2. Measure the resistance between terminals.


Standard value: Approx. 5 Ω (at 20°C)



CRANK ANGLE SENSOR CHECK

1. Disconnect the crank angle sensor connector.
2. Measure the resistance between terminals.

Standard value: 720 – 880 Ω




THROTTLE VALVE CONTROL SOLENOID CHECK

NOTE

When disconnecting the vacuum hose, always make a mark so that it can be reconnected at original position.


1. Disconnect the vacuum hose from the solenoid.
2. Disconnect the solenoid connector.
3. Connect a hand vacuum pump to the nipple (B) of the solenoid (refer to the illustration at left).
4. Check the airtightness by applying a vacuum with voltage applied directly from the battery to the solenoid and without applying voltage.



| Battery voltage | Nipple A condition | Normal condition |
|-----------------|--------------------|-------------------|
| Applied | Open | Vacuum leaks |
| | Close | Vacuum maintained |
| Not applied | Open | Vacuum leaks |

5. Measure the resistance between the terminals.

Standard value: 43 – 49 Ω (at 25°C)




THROTTLE ACTUATOR CHECK

1. Disconnect the vacuum hose from the throttle actuator and connect a hand vacuum pump to the throttle actuator nipple.
2. Check that the actuator rod moves smoothly when applying vacuum gradually.

FUEL HIGH PRESSURE PUMP AND FUEL INJECTOR

REMOVAL AND INSTALLATION



AY0220AJ

Fuel high pressure pump removal steps

- Timing belt (Refer to GROUP 11C.)
- 1. Fuel high pressure pump connector
- 2. Fuel supply hose connection
- 3. Fuel return hose connection
- 6. Fuel pump pipe
- 7. Fuel high pressure pump sprocket
- 8. Fuel high pressure pump



Fuel injector removal steps


- 4. Fuel return tube
- 5. Fuel pressure sensor connector
- 6. Fuel pump pipe
- 9. Fuel injector pipe
- 10. Fuel pressure sensor
- 11. Common rail
- 12. Fuel injector connector
- 13. Fuel injector holder
- 14. Fuel injector



REMOVAL SERVICE POINTS

◀B▶ FUEL HOSE CONNECTION/FUEL PIPE/FUEL RETURN TUBE/FUEL PRESSURE SENSOR REMOVAL

Disconnect the fuel hose, fuel pipe, fuel return tube and the fuel pressure sensor. Then, plug them to prevent dust from entering the fuel line, common rail and the fuel high pressure pump.



◀B▶ FUEL HIGH PRESSURE PUMP SPROCKET REMOVAL

INSTALLATION SERVICE POINT

▶A◀ FUEL HIGH PRESSURE PUMP SPROCKET INSTALLATION

Use the special tool to secure the fuel high pressure pump sprocket in the same way as during removal, and then tighten the bolt to the specified torque.