

# ENGINE FUEL & EMISSION CONTROL SYSTEM

## SECTION **EF & EC**

### CONTENTS

<b>PREPARATION / PRECAUTION</b> .....	3
Special Service Tools .....	3
Supplemental Restraint System "AIR BAG" .....	3

 
**VG30E**
 

<b>ENGINE AND EMISSION CONTROL OVERALL SYSTEM</b> .....	5
ECCS Component Parts Location .....	5
System Diagram .....	7
System Chart .....	8
Vacuum Hose Drawing .....	9
Circuit Diagram .....	10

**ENGINE AND EMISSION CONTROL PARTS DESCRIPTION** .....

Engine Control Module (ECM)-ECCS Control Module .....	11
Camshaft Position Sensor (CMPS) .....	11
Mass Air Flow Sensor (MAFS) .....	11
Engine Coolant Temperature Sensor (ECTS) .....	12
Throttle Position Sensor (TPS) & Soft/Hard Closed Throttle Position (CTP) Switch .....	12
Fuel Injector .....	13
Pressure Regulator .....	13
Heated Oxygen Sensor (HO2S) .....	13
Fuel Pump .....	13
Power Transistor & Ignition Coil .....	14
Idle Air Control Valve (IACV)-Auxiliary Air Control (AAC) Valve .....	14
Air Cut Valve .....	14
Power Steering Oil Pressure Switch .....	15
Safety Relay .....	15
Vehicle Speed Sensor (VSS) .....	15
Knock Sensor (KS) .....	15
Exhaust Gas Recirculation (EGR) Valve .....	16
EGR Control (EGRC)-BPT Valve .....	16
EGR Control (EGRC)-Solenoid Valve .....	16
Power Valve Control Solenoid Valve .....	16
Power Valve .....	16

Fuel Filter .....	17
Check Connector for ECCS Checker Box .....	17
EGR Temperature Sensor .....	17

**ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION** .....

Multiport Fuel Injection (MFI) System .....	18
Electronic Ignition (EI) System .....	20
Idle Air Control (IAC) System .....	21
Fuel Pump Control .....	22
Exhaust Gas Recirculation (EGR) System .....	23
Power Valve Control .....	24
Acceleration Cut Control .....	25
Cooling Fan Control .....	25
Fail-safe System .....	26

**IDLE SPEED/IGNITION TIMING/** .....

<b>TROUBLE DIAGNOSES</b> .....	34
Contents .....	34

**MULTIPOINT FUEL INJECTION SYSTEM INSPECTION** .....

Releasing Fuel Pressure .....	150
Fuel Pressure Check .....	150
Injector Removal .....	151

**EVAPORATIVE EMISSION SYSTEM** .....

Description .....	152
Inspection .....	152

**CRANKCASE EMISSION CONTROL SYSTEM** .....

Description .....	154
Inspection .....	154

 
**VE30DE**
 

**ENGINE AND EMISSION CONTROL OVERALL SYSTEM** .....

ECCS Component Parts Location .....	155
System Diagram .....	157
System Chart .....	158
Vacuum Hose Drawing .....	159
Circuit Diagram .....	160

GI

MA

EM

LC

**EF & EC**

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

DX

# CONTENTS (Cont'd)

## ENGINE AND EMISSION CONTROL PARTS

<b>DESCRIPTION</b> .....	161	Idle Air Control (IAC) System.....	171
Engine Control Module (ECM)-ECCS Control		Fuel Pump Control .....	172
Module.....	161	Exhaust Gas Recirculation (EGR) System.....	172
Camshaft Position Sensor (CMPS).....	161	Power Valve Control .....	173
Mass Air Flow Sensor (MAFS).....	161	Acceleration Cut Control .....	174
Engine Coolant Temperature Sensor (ECTS).....	161	Valve Timing Control (VTC).....	174
Throttle Position Sensor (TPS) & Soft/Hard		Cooling Fan Control.....	177
Closed Throttle Position (CTP) Switch.....	162	Fail-safe System.....	177
Fuel Injector .....	162	Direct Ignition System .....	179
Pressure Regulator.....	163	<b>IDLE SPEED/IGNITION TIMING/IDLE MIXTURE</b>	
Heated Oxygen Sensor (HO2S) .....	163	<b>RATIO INSPECTION</b> .....	182
Fuel Pump .....	163	Preparation.....	182
Power Transistor Unit & Ignition Coil.....	163	Inspection and Adjustment.....	182
Idle Air Control Valve (IACV)-Air Regulator.....	164	<b>TROUBLE DIAGNOSES</b> .....	190
Idle Air Adjusting (IAA) Unit.....	164	Contents.....	190
Idle Air Control Valve (IACV)-Fast Idle Control		<b>MULTIPORT FUEL INJECTION SYSTEM</b>	
Device (FICD) Solenoid Valve .....	164	<b>INSPECTION</b> .....	333
Idle Air Control Valve (IACV)-Auxiliary Air		Releasing Fuel Pressure .....	333
Control (AAC) Valve.....	164	Fuel Pressure Check .....	333
Vehicle Speed Sensor (VSS).....	165	Injector Removal and Installation .....	334
Power Steering Oil Pressure Switch .....	165	<b>EVAPORATIVE EMISSION SYSTEM</b> .....	335
Knock Sensor (KS).....	165	Description .....	335
Valve Timing Control Solenoid Valve.....	165	Inspection .....	335
Exhaust Gas Recirculation (EGR) Valve.....	165	<b>CRANKCASE EMISSION CONTROL SYSTEM</b> .....	337
EGR Control (EGRC)-BPT Valve.....	166	Description .....	337
EGR Control (EGRC)-Solenoid Valve.....	166	Inspection .....	337
EGR Temperature Sensor .....	166		
Power Valve .....	166		
Power Valve Control Solenoid Valve.....	166		
Fuel Filter .....	167		
Data Link Connector for CONSULT.....	167		
Activated Carbon Canister .....	167		
<b>ENGINE AND EMISSION CONTROL SYSTEM</b>			
<b>DESCRIPTION</b> .....	168		
Multiport Fuel Injection (MFI) System.....	168		
Electronic Ignition (EI) System.....	170		

**VG30E**

<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> .....	338
General Specifications.....	338
Inspection and Adjustment.....	338

**VE30DE**

<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> .....	339
General Specifications.....	339
Inspection and Adjustment.....	339

**When you read wiring diagrams:**



- Read GI section, "HOW TO READ WIRING DIAGRAMS".
- See EL section, "POWER SUPPLY ROUTING" for power distribution circuit.

**When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES".**

**Note:** Refer to Foldout page for "ECCS WIRING DIAGRAM".

# PREPARATION / PRECAUTION

## Special Service Tools

Tool number (Kent-Moore No.) Tool name	Description
EG11160000 ( — ) Adapter harness	 <p style="text-align: right;">Measuring engine speed</p> <p style="text-align: left;">NT056</p>
<p>① KV109D0010 (J-36777-1) Ignition timing adapter coil</p> <p>② (J39387) Adapter harness</p>	 <p style="text-align: right;">Measuring ignition timing</p> <p style="text-align: left;">NT345</p>

### Supplemental Restraint System "AIR BAG"

The Supplemental Restraint System "Air Bag" helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of an air bag (located in the center of the steering wheel), sensors, a diagnostic unit, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **BF** section of this Service Manual.

**WARNING:**

- a. To avoid rendering the SRS inoperative, which could lead to personal injury or death in the event of a severe frontal collision, all maintenance must be performed by an authorized NISSAN dealer.
- b. Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- c. All SRS electrical wiring harnesses and connectors are covered with yellow outer insulation. Do not use electrical test equipment on any circuit related to the SRS "Air Bag".

GI  
 MA  
 EW  
 LC  
**EF & EC**  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX

# PREPARATION / PRECAUTION

## BATTERY

- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.

## INJECTOR

- Do not disconnect injector harness connectors with engine running.
- Do not apply battery power directly to injectors.

## ECCS PARTS HANDLING




- Handle mass air flow sensor carefully to avoid damage.
- Do not disassemble mass air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Do not disassemble IACV-AAC valve.
- Even a slight leak in the air intake system can cause serious problems.
- Do not shock or jar the crankshaft position sensor.

## ECM

- Do not disassemble ECM (ECCS control module).
- Do not turn diagnosis test mode selector forcibly.
- If a battery terminal is disconnected, the memory will return to ECM value. The ECM will now start to self-control at its initial value. Engine operation can vary slightly when the terminal is disconnected. However, this is not an indication of a problem. Do not replace parts because of a slight variation.

## WIRELESS EQUIPMENT

- When installing C.B. ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on its installation location.
  - 1) Keep the antenna as far as possible away from the ECM.
  - 2) Keep the antenna feeder line more than 20 cm (7.9 in) away from the harness of electronic controls. Do not let them run parallel for a long distance.
  - 3) Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller.
  - 4) Be sure to ground the radio to vehicle body.



## WHEN STARTING

- Do not depress accelerator pedal when starting.
- Immediately after starting, do not rev up engine unnecessarily.
- Do not rev up engine just prior to shutdown.



## FUEL PUMP

- Do not operate fuel pump when there is no fuel in lines.
- Tighten fuel hose clamps to the specified torque.

## ECM HARNESS HANDLING


- Securely connect ECM harness connectors. A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep ECM harness at least 10 cm (3.9 in) away from adjacent harnesses, to prevent an ECM system malfunction due to external noise, degraded operation of ICs, etc.
- Keep ECCS parts and harnesses dry.
- Before removing parts, turn off ignition switch and then disconnect battery ground cable.

ECCS Component Parts Location




GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
WT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX


ECCS Component Parts Location (Cont'd)



Luggage compartment




Engine compartment




SEC215BA

System Diagram




GF  
 MA  
 EM  
 LC  
**EF & EC**  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX

System Chart






Vacuum Hose Drawing




- |        |                              |        |                              |
|--------|------------------------------|--------|------------------------------|
| Port ① | Power valve actuator         | Port ⑧ | Water hose for throttle body |
| Port ② | Heater hose                  | Port ⑨ | EGRC-BPT valve               |
| Port ③ | One-way valve                | Port ⑩ | Throttle body vacuum port    |
| Port ④ | Surge tank                   | Port ⑪ | Intake manifold vacuum port  |
| Port ⑤ | Air cut valve                | Port ⑫ | Throttle body vacuum port    |
| Port ⑥ | Canister purge port          | Port ⑬ | Air cut valve                |
| Port ⑦ | Canister control vacuum port |        |                              |

GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Circuit Diagram



- (U) : For U.S.A.
- (BR) : For Brazil
- (EB) : Except for Brazil
- (AA) : Auto air conditioner
- (MA) : Manual air conditioner
- (DM) : Digital type combination meter
- (NM) : Needle type combination meter



SEC220B


**Engine Control Module (ECM)-ECCS Control Module**

The ECM consists of a microcomputer, inspection lamps, a diagnostic test mode selector, and connectors for signal input and output and for power supply. The ECM controls the engine.

CI

VA

EM



SEF613B

**Camshaft Position Sensor (CMPS)**


The camshaft position sensor is a basic component of the entire ECCS. It monitors engine speed and piston position, and sends signals to the ECM to control fuel injection, ignition timing and other functions.

LC

EF & EC

The camshaft position sensor has a rotor plate and a wave-forming circuit. The rotor plate has 360 slits for 1° signal and 6 slits for 120° signal. Light Emitting Diodes (LED) and photo diodes are built in the wave-forming circuit.

FE



SEF614B

When the rotor plate passes between the LED and the photo diode, the slits in the rotor plate continually cut the light being transmitted to the photo diode from the LED. This generates rough-shaped pulses which are converted into on-off pulses by the wave-forming circuit, which are sent to the ECM.


CL

MT

AT

FA

RA



SEC221B

**Mass Air Flow Sensor (MAFS)**

The mass air flow sensor measures the intake air flow rate by taking a part of the entire flow. Measurements are made in such a manner that the ECM receives electrical output signals varied by the amount of heat emitting from the hot film placed in the stream of the intake air.

BR

ST

When intake air flows into the intake manifold through a route around the hot film, the heat generated from the hot film is taken away by the air. The amount of heat depends on the air flow. On the other hand, the temperature of the hot film is automatically controlled to a certain number of degrees.


BF

HA

Therefore, it is necessary to supply the hot film with more electric current in order to maintain the temperature of the hot film. The ECM knows the air flow by means of the electric change.

EL


IDX



### Engine Coolant Temperature Sensor (ECTS)

The engine coolant temperature sensor, located on the top of water inlet housing, detects engine coolant temperature and transmits a signal to the ECM.


The temperature sensing unit employs a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.




### Throttle Position Sensor (TPS) & Soft/Hard Closed Throttle Position (CTP) Switch

The throttle position sensor responds to the accelerator pedal movement. This sensor is a kind of potentiometer which transforms the throttle position into output voltage, and emits the voltage signal to the ECM. In addition, the sensor detects the opening and closing speed of the throttle valve and feeds the voltage signal to the ECM.

Idle position of the throttle valve is determined by the ECM receiving the signal from the throttle position sensor. This system is called "soft closed throttle position switch". This one controls engine operation such as fuel cut. On the other hand, "hard closed throttle position switch", which is built in the throttle position sensor unit, is used not for engine control but for on-board diagnostic system.






**Fuel Injector**

The fuel injector is a small, elaborate solenoid valve. As the ECM sends injection signals to the injector, the coil in the injector pulls the needle valve back and fuel is released into the intake manifold through the nozzle. The injected fuel is controlled by the ECM in terms of injection pulse duration. This type allows fuel to be supplied from top of injector.


GI  
MA  
EM



**Pressure Regulator**

The pressure regulator maintains the fuel pressure at 299.1 kPa (3.05 kg/cm<sup>2</sup>, 43.4 psi). Since the injected fuel amount depends on injection pulse duration, it is necessary to maintain the pressure at the above value.


LC  
EF & EC




**Heated Oxygen Sensor (HO2S)**

The heated oxygen sensor, located in the exhaust manifold, monitors the oxygen level in the exhaust gas. This sensor is made of ceramic titania, the electric resistance of which drastically changes at the ideal air-fuel ratio. The ECM supplies the sensor with approximately 1V and then measures the output voltage depending on its resistance.

FE  
CL  
MT  
AT  
FA  
RA




BR  
ST  
BF  
HA



**Fuel Pump**


The fuel pump with a fuel damper is an in-tank type, that is the pump and damper are located in the fuel tank.

EL  
IDX




**Power Transistor & Ignition Coil**

The ignition signal from the ECM is amplified by the power transistor, which turns the ignition coil primary circuit on and off, inducing the proper high voltage in the secondary circuit. The ignition coil is a small, molded type.




SEC225B




**Idle Air Control Valve (IACV)-Auxiliary Air Control (AAC) Valve**

The IACV-AAC valve is operated by a step motor for centralized control of auxiliary air supply. This motor has four winding phases and is actuated by the output pulse signal of ECM which turns ON and OFF two windings each in sequence. Each time the IACV-AAC valve opens or closes to change the auxiliary air quantity, an ON pulse is issued. When no change in the auxiliary air quantity is needed, the valve remains at a certain opening, hence no pulse signal output is issued.



MEF232D




**Air Cut Valve**

The air cut valve closes gradually as the cooling water temperature rises. This valve restricts the auxiliary air flow after the engine has warmed up and limits the maximum air flow even when there is trouble in the IACV-AAC valve, so that engine overrunning can be avoided.

**CAUTION:**  
Do not forcibly push valve as this may cause damage.

SEC228B





**Power Steering Oil Pressure Switch**

The power steering oil pressure switch is attached to the power steering high-pressure oil tube and detects the power steering load, sending the load signal to the ECM. The ECM then sends the idle-up signal to the IACV-AAC valve.

**Safety Relay**


The safety relay prevents electrical damage to the ECM and injectors when battery terminals are connected in reverse. The safety relay is built into the fuel pump control circuit.



**Vehicle Speed Sensor (VSS)**

The vehicle speed sensor provides a vehicle speed signal to the ECM.

The speed sensor consists of a reed switch, which is installed in the speedometer unit and transforms vehicle speed into a pulse signal.




**Knock Sensor (KS)**

The knock sensor is attached to the cylinder block and senses engine knocking conditions.

A knocking vibration from the cylinder block is applied as pressure to the piezoelectric element. This vibrational pressure is then converted into a voltage signal which is delivered as output.


GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX



SEF632B

**Exhaust Gas Recirculation (EGR) Valve**


The EGR valve controls the quantity of exhaust gas to be led to the intake manifold through vertical movement of the taper valve connected to the diaphragm, to which vacuum is applied in response to the opening of the throttle valve.



MEF867C

**EGR Control (EGRC)-BPT Valve**


The EGRC-BPT valve monitors exhaust pressure to activate the diaphragm, controlling throttle body vacuum applied to the EGR valve. In other words, recirculated exhaust gas is controlled in response to positioning of the EGR valve or to engine operation.



SEC231B

**EGR Control (EGRC)-Solenoid Valve**


The EGR system is controlled only by the ECM. At both low- and high-speed revolutions of engine, the solenoid valve turns on and accordingly the EGR valve cuts the exhaust gas leading to the intake manifold.



SEC230B

**Power Valve Control Solenoid Valve**

The power valve control solenoid valve cuts the intake manifold vacuum signal for power valve control. It responds to the ON/OFF signal from the ECM. When the solenoid is off, the vacuum signal from the intake manifold is cut. When the ECM sends an ON signal the coil pulls the plunger downward and feeds the vacuum signal to the power valve actuator.




SEC244B

**Power Valve**

The power valve is used to change over the suction passage of the power valve control system. It is set in the fully closed or fully opened position by the power valve actuator operated by the vacuum stored in the surge tank. The vacuum in the surge tank is controlled by the power valve control solenoid valve.






**Fuel Filter**

The specially designed fuel filter has a metal case in order to withstand high fuel pressure.

GI

MA

EW




**Check Connector for ECCS Checker Box**

The check connector for ECCS checker box is located in the instrument panel to the rear of the hood opener.

LC

**EF & EC**

FE



**EGR Temperature Sensor**

The EGR temperature sensor monitors in exhaust gas temperature and transmits a signal to the ECM. The temperature sensing unit employs a thermistor which is sensitive to the change in temperature. Electric resistance of the thermistor decreases in response to the temperature rise.

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

IDX

**Multiport Fuel Injection (MFI) System**

**INPUT/OUTPUT SIGNAL LINE**




**BASIC MULTIPOINT FUEL INJECTION SYSTEM**

The amount of fuel injected from the fuel injector, or the length of time the valve remains open, is determined by the ECM. The basic amount of fuel injected is a program value mapped in the ECM memory. In other words, the program value is preset by engine operating conditions determined by input signals (for engine speed and air intake) from both the camshaft position sensor and the mass air flow sensor.

**VARIOUS FUEL INJECTION INCREASE/DECREASE COMPENSATION**

In addition, the amount of fuel injection is compensated for to improve engine performance under various operating conditions as listed below.

- < Fuel increase >
  - 1) During warm-up
  - 2) When starting the engine
  - 3) During acceleration
  - 4) Hot-engine operation
- < Fuel decrease >
  - 1) During deceleration



**Multiport Fuel Injection (MFI) System (Cont'd)**


**MIXTURE RATIO FEEDBACK CONTROL**

Mixture ratio feedback system is designed to precisely control the mixture ratio to the stoichiometric point so that the three way catalyst can reduce CO, HC and NOx emissions. This system uses an heated oxygen sensor in the exhaust manifold to check the air-fuel ratio. The ECM adjusts the injection pulse width according to the sensor voltage so the mixture ratio will be within the range of the stoichiometric air-fuel ratio. This stage refers to the closed loop control condition. The open loop control condition refers to that under which the ECM detects any of the following conditions and feedback control stops in order to maintain stabilized fuel combustion.

- 1) Deceleration
- 2) High-load, high-speed operation
- 3) Engine idling
- 4) Malfunction of heated oxygen sensor or its circuit
- 5) Insufficient activation of heated oxygen sensor at low engine coolant temperature
- 6) Engine starting

**MIXTURE RATIO SELF-LEARNING CONTROL**

The mixture ratio feedback control system monitors the mixture ratio signal transmitted from the heated oxygen sensor. This feedback signal is then sent to the ECM to control the amount of fuel injection to provide a basic mixture ratio as close to the theoretical mixture ratio as possible. However, the basic mixture ratio is not necessarily controlled as originally designed. This is due to manufacturing errors (e.g., mass air flow sensor hot wire) and changes during operation (injector clogging, etc.) of ECCS parts which directly affect the mixture ratio. Accordingly, a difference between the basic and theoretical mixture ratios is quantitatively monitored in this system. It is then computed in terms of "fuel injection duration" to automatically compensate for the difference between the two ratios.



**FUEL INJECTION TIMING**

Two types of fuel injection systems are used — simultaneous multipoint fuel injection system and sequential multipoint fuel injection system. In the former, fuel is injected into all six cylinders simultaneously twice each engine cycle.

In other words, pulse signals of the same width are simultaneously transmitted from the ECM to the six injectors two times for each engine cycle.

In the sequential multipoint fuel injection system, fuel is injected into each cylinder during each engine cycle according to the firing order.

When engine is starting, fuel is injected into all six cylinders simultaneously twice a cycle.



**FUEL SHUT-OFF**

Fuel to each cylinder is cut off during deceleration or high-speed operation.

GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Electronic Ignition (EI) System

INPUT/OUTPUT SIGNAL LINE



SYSTEM DESCRIPTION

The ignition timing is controlled by the ECM in order to maintain the best air-fuel ratio in response to every running condition of the engine.

The ignition timing data is stored in the ECM, in the form of the map as shown.

The ECM detects information such as the injection pulse width and camshaft position sensor signal which varies every moment. Then responding to this information, ignition signals are transmitted to the power transistor.

e.g. N: 1,800 rpm, Tp: 1.50 msec  
A °BTDC

In addition to this,

- 1) At starting
- 2) During warm-up
- 3) At idle
- 4) At low battery voltage

the ignition timing is revised according to the other data stored in the ECM.



Electronic Ignition (EI) System (Cont'd)

The retard system by knock sensor is designed only for emergencies. The basic ignition timing is pre-programmed within the anti-knocking zone, even if recommended fuel is used under dry conditions. Consequently, the retard system does not operate under normal driving conditions.

However, if engine knocking occurs, the knock sensor monitors the condition and the signal is transmitted to the ECM. After receiving it, the ECM retards the ignition timing to avoid the knocking condition.

Idle Air Control (IAC) System


INPUT/OUTPUT SIGNAL LINE



SYSTEM DESCRIPTION


This system automatically controls engine idle speed to a specified level. Idle speed is controlled through fine adjustment of the amount of air which by-passes the throttle valve via IACV-AAC valve. The IACV-AAC valve changes the opening of the air by-pass passage to control the amount of auxiliary air. This valve is actuated by a step motor built into the valve, which moves the valve in the axial direction in steps corresponding to the ECM output pulses, the opening of the valve is varied to allow for optimum control of the engine idling speed. The camshaft position sensor detects the actual engine speed and sends a signal to the ECM. The ECM then controls the ON/OFF time of the IACV-AAC valve so that engine speed coincides with the target value memorized in ECM. The target engine speed is the lowest speed at which the engine can operate steadily. The optimum value stored in the ECM is determined by taking into consideration various engine conditions, such as warming up and during deceleration, fuel consumption, and engine load (air conditioner, electrical load).

Idle Air Control (IAC) System (Cont'd)



Fuel Pump Control

INPUT/OUTPUT SIGNAL LINE



Fuel Pump Control (Cont'd)

SYSTEM DESCRIPTION


When the fuel pump terminal voltage drops, pump speed, current consumption and fuel discharge decrease. This terminal voltage therefore is finely controlled corresponding to engine operating conditions in order to reduce power consumption and compartment noise level. The ECM receives various signals from sensors and switches and determines operating conditions of the engine. It then transmits a 20 Hz pulse signal to turn ON/OFF the grounding circuit of the fuel

pump. The voltage is controlled by changing the mean voltage applied to the pump terminal by varying this on/off time ratio. That is, the longer the on-time in a cycle, the higher the mean voltage becomes, and vice versa. If the on-time reaches 100%, battery voltage is applied directly to the pump. The pump is driven directly by this battery voltage for several seconds after turning on the ignition switch when the engine is cold, when starting, and when the engine is hot.

GI  
MA  
EM

Exhaust Gas Recirculation (EGR) System

INPUT/OUTPUT SIGNAL LINE



LC  
EF & EC

FE  
CL  
MT  
AT  
FA  
RA

SYSTEM DESCRIPTION

In addition, a system is provided which precisely cuts and controls port vacuum applied to the EGR valve to suit engine operating conditions. This cut-and-control operation is accomplished through the ECM. When the ECM detects any of the following conditions, current flows through the solenoid valve in the EGR control vacuum


line. This causes the port vacuum to be discharged into the atmosphere so that the EGR valve remains closed.

- 1) Low engine coolant temperature
- 2) Engine starting
- 3) High-speed engine operation
- 4) Engine idling

BR  
ST  
BF  
HA  
EL  
IDX


**Power Valve Control**

**INPUT/OUTPUT SIGNAL LINE**



**When power valve is "ON"**

**When power valve is "OFF"**



MEF238D

**SYSTEM DESCRIPTION**

When the engine is running at low or medium speed under a heavy load, the power valve control solenoid valve is energized by a signal from the ECM. This signal introduces the intake manifold vacuum into the power valve actuator to close the power valve. Under this condition, the effective suction port length is equivalent to the total length of the intake manifold collector's suction port including the intake valve. This long suction port provides increased air intake which results in improved suction efficiency and higher torque generation.


The surge tank and one-way valve are provided so that the power valve can be maintained in the fully closed position under heavy loads when the manifold vacuum is insufficient. In other conditions, the power valve control solenoid valve is de-energized, and the power valve actuator is vented to the atmosphere. This opens the power valve to two suction passages together in the collector.

Under this condition, the effective port length is equivalent to the length of the suction port provided independently for each cylinder. This shortened port length results in enhanced engine output with reduced suction resistance under high speeds.



**Acceleration Cut Control**

**INPUT/OUTPUT SIGNAL LINE**




**SYSTEM DESCRIPTION**

Air conditioner is turned off for a few seconds during accelerating condition.

This system improves acceleration when air conditioner is used.

**Cooling Fan Control**

**INPUT/OUTPUT SIGNAL LINE**



The ECM performs ON/OFF control and LOW/HIGH speed control of the cooling fan corresponding to the vehicle speed, engine coolant temperature, and air conditioner ON signal.

**OPERATION**

**Air conditioner switch is "OFF".**

Engine coolant temperature °C (°F)	Cooling fan	Cooling fan control relay		Remarks
Below 96 (205)	OFF	Relay-1	OFF	—
		Relay-2 & -3	OFF	
Between 97 (207) and 106 (223)	*LOW	Relay-1	ON	* OFF if vehicle speed is below 20 km/h (12 MPH).
		Relay-2 & -3	OFF	
Above 107 (225)	HIGH	Relay-1	ON	—
		Relay-2 & -3	ON	

Cooling Fan Control (Cont'd)

Air conditioner switch is "ON".


Engine coolant temperature °C (°F)	Cooling fan	Cooling fan control relay		Remarks
Below 94 (201)	*LOW	Relay-1	ON	* OFF if vehicle speed is above 80 km/h (50 MPH).
		Relay-2 & -3	OFF	
Between 95 (203) and 104 (219)	*HIGH	Relay-1	ON	* LOW if vehicle speed is below 20 km/h (12 MPH).
		Relay-2 & -3	ON	
Above 105 (221)	HIGH	Relay-1	ON	—
		Relay-2 & -3	ON	

The cooling fan operates at HIGH if the self-diagnosing engine coolant temperature sensor system results in "NG".

Fail-safe System

CPU MALFUNCTION OF ECM AND CAMSHAFT POSITION SENSOR MALFUNCTION

Input/output signal line



**Fail-safe System (Cont'd)**

**Outline**

The fail-safe system makes engine starting possible if there is something malfunctioning in the ECM's CPU circuit, or if there is a disconnection or short/open circuit in the camshaft position sensor circuit. In former models, engine starting was difficult under the conditions mentioned above. But with the provisions provided in this fail-safe system, it is possible to start the engine.

**Fail-safe system activating condition when ECM is malfunctioning**

The fail-safe mode operates when the computing function of the ECM is judged to be malfunctioning. When the fail-safe system activates, i.e. if a malfunction condition is detected in the CPU of the ECM, the MALFUNCTION INDICATOR LAMP on the instrument panel lights to warn the driver.

**Engine control with fail-safe system, operates when ECM is malfunctioning**

When the fail-safe system is operating, fuel injection, ignition timing, fuel pump operation, and so on are controlled under certain limitations.

**Cancellation of fail-safe system when ECM is malfunctioning**

Activation of the fail-safe system is canceled each time the ignition switch is turned OFF. The system is reactivated if all of the activating conditions are satisfied after turning the ignition switch from OFF to ON.

**Fail-safe system activating condition when camshaft position sensor is malfunctioning**

The fail-safe mode operation starts immediately after all of the following conditions have been satisfied for several seconds.

- (1) No pulse of 120° signal (reference signal) detected for several seconds, or 1° signal (position signal) is equivalent to 0 rpm.
- (2) Ignition switch in START
- (3) Battery voltage is greater than 10 volts with ignition switch ON.
- (4) The neutral position switch is ON, or the inhibitor switch is in the "P" or "N" position.
- (5) When ignition switch is in START, battery voltage is at least 1 volt lower than when ignition switch is ON.

When the camshaft position sensor fail-safe system activates, the MALFUNCTION INDICATOR LAMP on the instrument panel lights to warn the driver.

**Engine control with fail-safe system when camshaft position sensor is malfunctioning**

When the fail-safe system is operating, fuel injection, ignition timing, fuel pump operation, engine idle speed, EGR operation, cooling fan operation, and power valve operation are controlled under certain limitations.

**Cancellation of fail-safe system when camshaft position sensor is malfunctioning**

Activation of the fail-safe system is canceled each time the ignition switch is turned OFF. The system is reactivated if all of the above-mentioned activating conditions are satisfied after turning the ignition switch from OFF to ON.

GI

MA

EM

LC

**EF & EC**

FE

CI

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX

**Fail-safe System (Cont'd)**

**MASS AIR FLOW SENSOR MALFUNCTION**

If the mass air flow sensor output voltage is above or below the specified value, the ECM senses a mass air flow sensor malfunction. In case of a malfunction, the throttle position sensor substitutes for the mass air flow sensor.

Though mass air flow sensor is malfunctioning, it is possible to drive the vehicle and start the engine. But engine speed will not rise more than 2,000 rpm in order to inform the driver of fail-safe system operation while driving.

**Operation**

Engine condition	Starter switch	Fail-safe system	Fail-safe functioning
Stopped	ANY	Does not operate	—
Cranking	ON	Operates	Engine will be started by a pre-determined injection pulse on ECM.
Running	OFF		Engine speed will not rise above 2,000 rpm

**ENGINE COOLANT TEMPERATURE SENSOR MALFUNCTION**

When engine coolant temperature sensor output voltage is below or above the specified value, engine coolant temperature is fixed at the preset value as follows:

**Operation**

Condition	Engine coolant temperature decided
Just as ignition switch is turned ON or Start	20°C (68°F)
More than 6 minutes after ignition ON or Start	80°C (176°F)
Except as shown above	20 - 80°C (68 - 176°F) (Depends on the time)

**FUEL PUMP MALFUNCTION**

When the ECM detects a malfunction (discontinuity, short-circuit, etc.) in the fuel pump voltage control circuit, the fuel pump relay turns ON and 12 volts are applied to the fuel pump.

**KNOCK SENSOR MALFUNCTION**

When the output signal of the knock sensor is abnormal, the ECM judges it to be malfunctioning. When knock sensor is malfunctioning, ignition timing will retard according to operating conditions.

## PREPARATION

1. Make sure that the following parts are in good order.
  - Battery
  - Ignition system
  - Engine oil and coolant levels
  - Fuses
  - ECM SMJ harness connector
  - Vacuum hoses
  - Air intake system  
(Oil filler cap, oil level gauge, etc.)
  - Fuel pressure
  - Engine compression
  - EGR valve operation
  - Throttle valve
2. On air conditioner equipped models, checks


should be carried out while the air conditioner is "OFF".

3. On automatic transaxle equipped models, when checking idle rpm, ignition timing and mixture ratio, checks should be carried out while shift lever is in "N" position.
4. When measuring "CO" percentage, insert probe more than 40 cm (15.7 in) into tail pipe.
5. Turn off headlamps, heater blower, rear defogger.
6. Keep front wheels pointed straight ahead.
7. Make the check after the cooling fan has stopped.

### WARNING:

Apply parking brake and block both front and rear wheels with chocks.

## Overall inspection sequence




GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

# IDLE SPEED/IGNITION TIMING/ IDLE MIXTURE RATIO INSPECTION


VG30E

## Idle check and set procedure



# IDLE SPEED/IGNITION TIMING/ IDLE MIXTURE RATIO INSPECTION


VG30E



GI  
 MA  
 EM  
 LC  
**EF & EC**  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX

# IDLE SPEED/IGNITION TIMING/ IDLE MIXTURE RATIO INSPECTION


VG30E





# IDLE SPEED/IGNITION TIMING/ IDLE MIXTURE RATIO INSPECTION

VG30E






GI  
MA  
EM  
LC  
**EF & EC**  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

## Contents

How to Perform Trouble Diagnoses for Quick and Accurate Repair .....	EF & EC- 36
On-board Diagnostic System .....	EF & EC- 39
On-board Diagnostic System — Diagnostic Test Mode I (Heated oxygen sensor monitor) .....	EF & EC- 41
On-board Diagnostic System — Diagnostic Test Mode II (Mixture ratio feedback control monitor) .....	EF & EC- 41
On-board Diagnostic System — Diagnostic Test Mode III (Self-diagnostic results) .....	EF & EC- 42
On-board Diagnostic System — Diagnostic Test Mode IV (Switches ON/OFF diagnostic test mode) .....	EF & EC- 45
On-board Diagnostic System — Diagnostic Test Mode V (Real-time diagnostic test mode) .....	EF & EC- 47
Diagnostic Procedure .....	EF & EC- 53
Basic Inspection .....	EF & EC- 55
Diagnostic Procedure 1 — High Idling after Warm-up .....	EF & EC- 57
Diagnostic Procedure 2 — Hunting .....	EF & EC- 58
Diagnostic Procedure 3 — Unstable Idle .....	EF & EC- 59
Diagnostic Procedure 4 — Hard to Start or Impossible to Start when the Engine is Cold ..	EF & EC- 61
Diagnostic Procedure 5 — Hard to Start or Impossible to Start when the Engine is Hot ....	EF & EC- 62
Diagnostic Procedure 6 — Hard to Start or Impossible to Start under Normal Conditions .....	EF & EC- 63
Diagnostic Procedure 7 — Hesitation when the Engine is Hot .....	EF & EC- 65
Diagnostic Procedure 8 — Hesitation when the Engine is Cold .....	EF & EC- 65
Diagnostic Procedure 9 — Hesitation under Normal Conditions .....	EF & EC- 67
Diagnostic Procedure 10 — Engine Stalls when Turning .....	EF & EC- 68
Diagnostic Procedure 11 — Engine Stalls when the Engine is Hot .....	EF & EC- 69
Diagnostic Procedure 12 — Engine Stalls when the Engine is Cold .....	EF & EC- 71
Diagnostic Procedure 13 — Engine Stalls when Stepping on the Accelerator Momentarily .....	EF & EC- 72
Diagnostic Procedure 14 — Engine Stalls after Decelerating .....	EF & EC- 74
Diagnostic Procedure 15 — Engine Stalls when Accelerating or Cruising .....	EF & EC- 76
Diagnostic Procedure 16 — Engine Stalls when the Electrical Load is Heavy .....	EF & EC- 77
Diagnostic Procedure 17 — Lack of Power and Stumble .....	EF & EC- 79
Diagnostic Procedure 18 — Knock .....	EF & EC- 79
Diagnostic Procedure 19 — Surge .....	EF & EC- 81
Diagnostic Procedure 20 — Backfire through the Intake .....	EF & EC- 82
Diagnostic Procedure 21 — Backfire through the Exhaust .....	EF & EC- 82
Diagnostic Procedure 22 MAIN POWER SUPPLY AND GROUND CIRCUIT .....	EF & EC- 83
Diagnostic Procedure 23 CAMSHAFT POSITION SENSOR .....	EF & EC- 85
Diagnostic Procedure 24 MASS AIR FLOW SENSOR .....	EF & EC- 88
Diagnostic Procedure 25 ENGINE COOLANT TEMPERATURE SENSOR .....	EF & EC- 91
Diagnostic Procedure 26 VEHICLE SPEED SENSOR .....	EF & EC- 94
Diagnostic Procedure 27 IGNITION SIGNAL .....	EF & EC- 96
Diagnostic Procedure 28 FUEL PUMP .....	EF & EC- 99
Diagnostic Procedure 29 ENGINE CONTROL MODULE (ECM) .....	EF & EC-101
Diagnostic Procedure 30 EGR FUNCTION .....	EF & EC-102

**Contents (Cont'd)**

<b>Diagnostic Procedure 31</b>		
HEATED OXYGEN SENSOR .....	EF & EC-105	
<b>Diagnostic Procedure 32</b>		
KNOCK SENSOR .....	EF & EC-108	
<b>Diagnostic Procedure 33</b>		GI
EGR TEMPERATURE SENSOR .....	EF & EC-110	
<b>Diagnostic Procedure 34</b>		MA
THROTTLE POSITION SENSOR .....	EF & EC-112	
<b>Diagnostic Procedure 35</b>		EM
INJECTOR LEAK .....	EF & EC-115	
<b>Diagnostic Procedure 36</b>		IC
INJECTOR CIRCUIT .....	EF & EC-117	
<b>Diagnostic Procedure 37</b>		<b>EF &amp; EC</b>
A/T CONTROL .....	EF & EC-120	
<b>Diagnostic Procedure 38</b>		
CLOSED THROTTLE POSITION SWITCH .....	EF & EC-122	
<b>Diagnostic Procedure 39</b>		FE
START SIGNAL .....	EF & EC-124	
<b>Diagnostic Procedure 40</b>		CL
IACV-AAC VALVE .....	EF & EC-126	
<b>Diagnostic Procedure 41</b>		MT
POWER VALVE CONTROL .....	EF & EC-129	
<b>Diagnostic Procedure 42</b>		AT
COOLING FAN CONTROL .....	EF & EC-131	
<b>Diagnostic Procedure 43</b>		
FAIL-SAFE SYSTEM FOR CAMSHAFT POSITION SENSOR AND CPU OF ECM .....	EF & EC-134	
<b>Diagnostic Procedure 44</b>		FA
INHIBITOR SWITCH CIRCUIT .....	EF & EC-136	
<b>Electrical Components Inspection</b> .....	EF & EC-138	RA
		BR
		ST
		BF
		HA
		EL
		DX



## How to Perform Trouble Diagnoses for Quick and Accurate Repair

### INTRODUCTION

The engine has an ECM to control major systems such as fuel control, ignition control, idle air control system, etc. The ECM accepts input signals from sensors and instantly drives actuators. It is essential that both kinds of signals are proper and stable. At the same time, it is important that there are no conventional problems such as vacuum leaks, fouled spark plugs, or other problems with the engine.


It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.

A visual check only may not find the cause of the problems, so a road test with a circuit tester connected to a suspected circuit should be performed.

Before undertaking actual checks, take just a few minutes to talk with a customer who approaches with a driveability complaint. The customer is a very good supplier of information on such problems, especially intermittent ones. Through interaction with the customer, find out what symptoms are present and under what conditions they occur.

Start your diagnosis by looking for "conventional" problems first. This is one of the best ways to troubleshoot driveability problems on an electronically controlled engine vehicle.

### WORK FLOW






## How to Perform Trouble Diagnoses for Quick and Accurate Repair (Cont'd)

### INTERMITTENT PROBLEM SIMULATION


In order to duplicate an intermittent problem, it is effective to create similar conditions for component parts, under which the problem might occur.

Perform the activity listed under Service procedure and note the result.



SEF235G

	Variable factor	Influential part	Target condition	Service procedure
1	Mixture ratio	Pressure regulator	Made lean	Remove vacuum hose and apply vacuum.
			Made rich	Remove vacuum hose and apply pressure.
2	Ignition timing	Distributor	Advanced	Rotate distributor clockwise.
			Retarded	Rotate distributor counterclockwise.
3	Mixture ratio feed-back control	Heated oxygen sensor	Suspended	Disconnect heated oxygen sensor harness connector.
		ECM	Operation check	Perform on-board diagnostic system (Diagnostic Test Mode I/II) at 2,000 rpm.
4	Idle speed	IACV-AAC valve	Raised	Turn idle adjusting screw counterclockwise.
			Lowered	Turn idle adjusting screw clockwise.
5	Electric connection (Electric continuity)	Harness connectors and wires	Poor electric connection or faulty wiring	Tap or wiggle. Race engine rapidly. See if the torque reaction of the engine unit causes electric breaks.
			Cooled	Cool with an icing spray or similar device.
6	Temperature	ECM	Warmed	Heat with a hair drier. [WARNING: Do not overheat the unit.]
				Wet. [WARNING: Do not directly pour water on components. Use a mist sprayer.]
7	Moisture	Electric parts	Damp	Wet. [WARNING: Do not directly pour water on components. Use a mist sprayer.]
8	Electric loads	Load switches	Loaded	Turn on head lights, air conditioner, rear defogger, etc.
9	Closed throttle position switch condition	ECM	ON-OFF switching	Perform on-board diagnostic system (Diagnostic Test Mode IV).
10	Ignition spark	Timing light	Spark power check	Try to flash timing light for each cylinder.



## On-board Diagnostic System

### MALFUNCTION INDICATOR LAMP

A malfunction indicator lamp has been adopted. This light blinks under the following conditions:

	California model	Non-California model
Condition	Light illuminates when any one of conditions 1), 2), 3) and 4) is satisfied.	Light illuminates when any one of conditions 1), 2) and 4) is satisfied.


- 1) When ignition switch is turned "ON" (for bulb check).
- 2) When systems related to emission performance malfunction in Diagnostic Test Mode I (with engine running).

● **This malfunction indicator lamp always illuminates and is synchronous with red LED.**

- 3) When a malfunction is detected regarding the following self-diagnostic items.

Malfunction	On-board diagnostic system diagnostic trouble code No.
Mass air flow sensor circuit	12
Engine coolant temperature sensor circuit	13
Vehicle speed sensor circuit	14
ECM (ECGS control module)	31
EGR function	32

Malfunction	On-board diagnostic system diagnostic trouble code No.
Heated oxygen sensor circuit	33
EGR temperature sensor circuit	35
Throttle position sensor circuit	43
injector leak	45
Injector circuit	51



- The malfunction indicator lamp will turn off when normal operation is resumed. Diagnostic Test Mode III memory must be cleared as the contents remain stored.

- 4) When camshaft position sensor or CPU of ECM malfunctions and fail-safe system operates during engine rotation.


### ECM LED

In the ECM, Green and Red LED's have been adopted to monitor the self-diagnostic functions.

### ON-BOARD DIAGNOSTIC SYSTEM FUNCTION

Diagnostic Test Mode	Function
Diagnostic Test Mode I	HEATED OXYGEN SENSOR MONITOR
Diagnostic Test Mode II	MIXTURE RATIO FEEDBACK CONTROL MONITOR
Diagnostic Test Mode III	SELF-DIAGNOSTIC RESULTS
Diagnostic Test Mode IV	SWITCHES ON/OFF DIAGNOSTIC TEST MODE
Diagnostic Test Mode V	REAL-TIME DIAGNOSTIC TEST MODE

**On-board Diagnostic System (Cont'd)**  
**HOW TO SWITCH DIAGNOSTIC TEST MODES**



\*1 While the diagnostic test mode selector is kept turned fully clockwise, it will continue to change in the order of Diagnostic Test Mode I → II → III → IV → V → I ...

\*2 The diagnostic trouble code is erased from the backup memory of the ECM.

- Return the diagnostic test mode selector to the original position so as not to disturb the idle speed.
- Refer to EF & EC-42.



**On-board Diagnostic System — Diagnostic Test Mode I**

**Heated oxygen sensor monitor**

This mode checks the heated oxygen sensor for proper functioning. The operation of the ECM LED in this mode differs with mixture ratio control conditions as follows:

Diagnostic Test Mode	LED	Engine stopped (Ignition switch "ON")	Engine running	
			Open loop condition	Closed loop condition
Diagnostic Test Mode I	Green	ON	*Remains ON or OFF	Blinks
	Red	ON	Except for California model ● ON: When fail-safe system is operating	For California model ● ON: a. when the MALFUNCTION INDICATOR LAMP ITEMS are stored in the ECM b. when fail-safe system is operating ● OFF: except for the above conditions

\*: Maintains conditions just before switching to open loop

**HEATED OXYGEN SENSOR FUNCTION CHECK**

If the number of LED blinks is less than that specified, replace the heated oxygen sensor.

If the LED does not blink, check heated oxygen sensor circuit.

**HEATED OXYGEN SENSOR CIRCUIT CHECK**

See page EF & EC-104.

**On-board Diagnostic System — Diagnostic Test Mode II**

**Mixture ratio feedback control monitor**

This mode checks, through the ECM LED, optimum control of the mixture ratio. The operation of the LED, as shown below, differs with the control conditions of the mixture ratio (for example, richer or leaner mixture ratios, etc., which are controlled by the ECM).


Diagnostic Test Mode	LED	Engine stopped (Ignition switch "ON")	Engine running		
			Open loop condition	Closed loop condition	
Diagnostic Test Mode II	Green	ON	*Remains ON or OFF	Blinks	
	Red	OFF	*Remains ON or OFF	Compensating mixture ratio	
				More than 5% rich	Between 5% lean and 5% rich
			OFF	Synchronized with green LED	Remains ON

\*: Maintains conditions just before switching to open loop

If the red LED remains on or off during the closed loop operation, the mixture ratio may not be controlled properly. Using the following procedures, check the related components or adjust the mixture ratio.

**COMPONENT CHECK OR MIXTURE RATIO**

**ADJUSTMENT** — See page EF & EC-29.



## On-board Diagnostic System — Diagnostic Test Mode III

### Self-diagnostic results

The ECM constantly monitors the function of these sensors and actuators, regardless of ignition key position. If a malfunction occurs, the information is stored in the ECM and can be retrieved from the memory by turning on the diagnostic test mode selector, located on the side of the ECM. When activated, the malfunction is indicated by flashing a red and a green LED (Light Emitting Diode), also located on the ECM. Since all the self-diagnostic results are stored in the ECM's memory even intermittent malfunctions can be diagnosed.

A malfunction is indicated by the number of both red and green flashing LEDs. First, the red LED flashes and the green flashes follow. The red LED corresponds to units of ten and the green LED corresponds to units of one. For example, when the red LED flashes once and the green LED flashes twice, this signifies the number "12", showing that the mass air flow sensor signal is malfunctioning. All problems are classified by diagnostic trouble code numbers in this way.

- When the engine fails to start, crank it two or more seconds before beginning on-board diagnostic system.
- Read out self-diagnostic results first and then erase the malfunction records which are stored in the ECM memory. If it is erased, the on-board diagnostic system function for intermittent malfunctions will be lost.

### DISPLAY DIAGNOSTIC TROUBLE CODE TABLE

Diagnostic trouble code No.	Detected items	
11	Camshaft position sensor circuit	X
12	Mass air flow sensor circuit	X
13	Engine coolant temperature sensor circuit	X
14	Vehicle speed sensor circuit	X
21	Ignition signal missing in primary coil	X
22	Fuel pump circuit	X
31	ECM (ECCS control module)	X

Diagnostic trouble code No.	Detected items	
32	EGR function	X
33	Heated oxygen sensor circuit	X
34	Knock sensor circuit	X
35	EGR temperature sensor circuit	X
43	Throttle position sensor circuit	X
45	Injector leak	X
51	Injector circuit	X
54	A/T control circuit	X
55	No malfunction in the above circuit	X

X: Available

### HOW TO ERASE DIAGNOSTIC TEST MODE III (SELF-DIAGNOSTIC RESULTS)

The diagnostic trouble code is erased from the backup memory of the ECM by the following;

- when the battery terminal is disconnected, the diagnostic trouble code will be lost from the backup memory within 24 hours.
- when mode IV is selected after selecting mode III.

**On-board Diagnostic System — Diagnostic Test  
Mode III  
Self-diagnostic results (Cont'd)**


Diagnostic trouble code No.	Detected items	Malfunction is detected when ...	Check item (remedy)	
*11	Camshaft position sensor circuit	<ul style="list-style-type: none"> <li>● Either 1° or 120° signal is not entered for the first few seconds during engine cranking.</li> <li>● Either 1° or 120° signal is not input often enough while the engine speed is higher than the specified rpm.</li> </ul>	<ul style="list-style-type: none"> <li>● Harness and connector (If harness and connector are normal, replace camshaft position sensor.)</li> </ul>	GI MA EM
12	Mass air flow sensor circuit	<ul style="list-style-type: none"> <li>● The mass air flow sensor circuit is open or shorted. (An abnormally high or low voltage is entered.)</li> </ul>	<ul style="list-style-type: none"> <li>● Harness and connector (If harness and connector are normal, replace mass air flow sensor.)</li> </ul>	LC EF & EC
13	Engine coolant temperature sensor circuit	<ul style="list-style-type: none"> <li>● The engine coolant temperature sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.)</li> </ul>	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Engine coolant temperature sensor</li> </ul>	FE
14	Vehicle speed sensor circuit	<ul style="list-style-type: none"> <li>● The vehicle speed sensor circuit is open or shorted.</li> </ul>	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Vehicle speed sensor (reed switch)</li> </ul>	CL
*21	Ignition signal circuit	<ul style="list-style-type: none"> <li>● The ignition signal in the primary circuit is not entered during engine cranking or running.</li> </ul>	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Power transistor unit</li> </ul>	MT
31	ECM	<ul style="list-style-type: none"> <li>● ECM calculation function is malfunctioning.</li> </ul>	(Replace ECM (ECOS control module).)	AT
32	EGR function	<ul style="list-style-type: none"> <li>● EGR valve does not operate. (EGR valve spring does not lift.)</li> </ul>	<ul style="list-style-type: none"> <li>● EGR valve</li> <li>● EGRC-solenoid valve</li> </ul>	FA
33	Heated oxygen sensor circuit	<ul style="list-style-type: none"> <li>● The heated oxygen sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.)</li> </ul>	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Heated oxygen sensor</li> <li>● Fuel pressure</li> <li>● Injectors</li> <li>● Intake air leaks</li> </ul>	RA BR
34	Knock sensor circuit	<ul style="list-style-type: none"> <li>● The knock sensor circuit is open or shorted. (An abnormally high or low voltage is entered.)</li> </ul>	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Knock sensor</li> </ul>	ST
35	EGR temperature sensor circuit	<ul style="list-style-type: none"> <li>● The EGR temperature sensor circuit is open or shorted. (An abnormally high or low voltage is entered.)</li> </ul>	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● EGR temperature sensor</li> </ul>	BF
43	Throttle position sensor circuit	<ul style="list-style-type: none"> <li>● The throttle position sensor circuit is open or shorted. (An abnormally high or low voltage is entered.)</li> </ul>	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Throttle position sensor</li> </ul>	HA
45	Injector leak	<ul style="list-style-type: none"> <li>● Fuel leaks from injector.</li> </ul>	<ul style="list-style-type: none"> <li>● Injector</li> </ul>	EL
51	Injector circuit	<ul style="list-style-type: none"> <li>● The injector circuit is open.</li> </ul>	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Injector</li> </ul>	EL

\*: Check items causing a malfunction of camshaft position sensor circuit first, if both diagnostic trouble code No. 11 and 21 are displayed at the same time.

## On-board Diagnostic System — Diagnostic Test Mode III

### Self-diagnostic results (Cont'd)

#### PROCEDURE



#### CAUTION:

- During display of a Diagnostic trouble code No. in on-board diagnostic system mode (Diagnostic Test Mode III), if another diagnostic test mode is to be performed, be sure to note the malfunction Diagnostic trouble code No. before turning diagnostic test mode selector on ECM fully clockwise. When selecting an alternative, select the diagnosis mode after turning switch "OFF". Otherwise, on-board diagnostic system information in the ECM memory will be lost.

## On-board Diagnostic System — Diagnostic Test Mode IV

### Switches ON/OFF diagnostic test mode

In switches ON/OFF diagnostic system, ON/OFF operation of the following switches can be detected continuously.

- Closed throttle position switch
- Starter switch
- Vehicle speed sensor

(1) Closed throttle position switch & Starter switch

The switches ON/OFF status in Diagnostic Test Mode IV is stored in ECM memory. When either switch is turned from "ON" to "OFF" or "OFF" to "ON", the red LED on ECM alternately comes on and goes off each time switching is performed.

(2) Vehicle Speed Sensor

The switches ON/OFF status in Diagnostic Test Mode IV is stored in ECM memory. The green LED on ECM remains off when vehicle speed is 20 km/h (12 MPH) or below, and comes ON at higher speeds.

GI

MA

EM

LC

EF &  
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

DX

**On-board Diagnostic System — Diagnostic Test Mode IV**  
**Switches ON/OFF diagnostic test mode (Cont'd)**  
**PROCEDURE**



**CAUTION:**

- For safety, do not drive rear wheels at higher speed than required.

**On-board Diagnostic System — Diagnostic Test Mode V**


**Real-time diagnostic test mode**

In real-time diagnosis, if the following items are judged to be working incorrectly, a malfunction will be indicated immediately.

- Camshaft position sensor (120° signal & 1° signal) output signal
- Ignition signal
- Mass air flow sensor output signal
- Fuel pump

Consequently, this diagnosis very effectively determines whether the above systems cause the malfunction, during driving test. Compared with on-board diagnostic system, real-time diagnosis is very sensitive and can detect malfunctions instantly. However, items regarded as malfunctions in this diagnosis are not stored in ECM memory.

**PROCEDURE**



**CAUTION:**

In real-time diagnosis, pay attention to inspection lamp flashing. ECM displays the diagnostic trouble code only once and does not memorize the inspection.

**On-board Diagnostic System — Diagnostic Test Mode V**  
**Real-time diagnostic test mode (Cont'd)**



**DECODING CHART**

Display presentation

Malfunction circuit or parts

ECM shows a malfunction signal when the following conditions are detected.  
 (Compare with On-board diagnostic system —Diagnostic Test Mode III.)



**CAMSHAFT POSITION SENSOR**



The 1° or 120° signal is momentarily missing, or, multiple, momentary noise signals enter.

**REAL TIME DIAGNOSTIC INSPECTION**  
 See page EF & EC-49.



**MASS AIR FLOW SENSOR**



Abnormal, momentary increase in mass air flow sensor output signal.

**REAL TIME DIAGNOSTIC INSPECTION**  
 See page EF & EC-50.



**IGNITION SIGNAL**



Signal from the primary ignition coil momentarily drops off.

**REAL TIME DIAGNOSTIC INSPECTION**  
 See page EF & EC-51.

**FUEL PUMP**



Fuel pump circuit is momentarily open or shorted.

**REAL TIME DIAGNOSTIC INSPECTION**  
 See page EF & EC-52.



On-board Diagnostic System — Diagnostic Test Mode V


Real-time diagnostic test mode (Cont'd)

REAL-TIME DIAGNOSTIC INSPECTION

Camshaft Position Sensor

X: Available  
—: Not available

Check sequence	Check items	Check conditions	Check parts			If malfunction, perform the following items.
			Camshaft position sensor harness connector	Sensor & actuator	ECM SMJ harness connector	
1	Tap and wiggle harness connector or component during real-time diagnosis.	During real-time diagnosis	X	X	X	Go to check item 2.
2	Check harness continuity at connector.	Engine stopped	X	—	—	Go to check item 3.
3	Disconnect harness connector, and then check dust adhesion to harness connector.	Engine stopped	X	—	X	Clean terminal surface.
4	Check pin terminal bend.	Engine stopped	—	—	X	Take out bend.
5	Reconnect harness connector and then recheck harness continuity at connector.	Engine stopped	X	—	—	Replace terminal.
6	Tap and wiggle harness connector or component during real-time diagnosis.	During real-time diagnosis	X	X	X	If diagnostic trouble codes are displayed during real-time diagnosis, replace terminal.




MEF253DA

**On-board Diagnostic System — Diagnostic Test Mode V  
Real-time diagnostic test mode (Cont'd)**

**Mass Air Flow Sensor**

X: Available  
—: Not available

Check sequence	Check items	Check conditions	Check parts			If malfunction, perform the following items.
			Mass air flow sensor harness connector	Sensor & actuator	ECM SMJ harness connector	
1	Tap and wiggle harness connector or component during real-time diagnosis.	During real-time diagnosis	X	X	X	Go to check item 2.
2	Check harness continuity at connector.	Engine stopped	X	—	—	Go to check item 3.
3	Disconnect harness connector, and then check dust adhesion to harness connector.	Engine stopped	X	—	X	Clean terminal surface.
4	Check pin terminal bend.	Engine stopped	—	—	X	Take out bend.
5	Reconnect harness connector and then recheck harness continuity at connector.	Engine stopped	X	—	—	Replace terminal.
6	Tap and wiggle harness connector or component during real-time diagnosis.	During real-time diagnosis	X	X	X	If diagnostic trouble codes are displayed during real-time diagnosis, replace terminal.



SEF453N


On-board Diagnostic System — Diagnostic Test Mode V  
Real-time diagnostic test mode (Cont'd)

Ignition Signal

X: Available  
—: Not available

Check sequence	Check items	Check conditions	Check parts			If malfunction, perform the following items.
			Ignition signal harness connector	Sensor & actuator	ECM SMJ harness connector	
1	Tap and wiggle harness connector or component during real-time diagnosis.	During real-time diagnosis	X	X	X	Go to check item 2.
2	Check harness continuity at connector.	Engine stopped	X	—	—	Go to check item 3.
3	Disconnect harness connector, and then check dust adhesion to harness connector.	Engine stopped	X	—	X	Clean terminal surface.
4	Check pin terminal bend.	Engine stopped	—	—	X	Take out bend.
5	Reconnect harness connector and then recheck harness continuity at connector.	Engine stopped	X	—	—	Replace terminal.
6	Tap and wiggle harness connector or component during real-time diagnosis.	During real-time diagnosis	X	X	X	If diagnostic trouble codes are displayed during real-time diagnosis, replace terminal.

GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX



MEF255DA


On-board Diagnostic System — Diagnostic Test Mode V

Real-time diagnostic test mode (Cont'd)






Fuel pump

X: Available  
—: Not available

Check sequence	Check items	Check conditions	Check parts			If malfunction, perform the following items.
			Fuel pump harness connector	Sensor & actuator	ECM SMJ harness connector	
1	Tap and wiggle harness connector or component during real-time diagnosis.	During real-time diagnosis	X	X	X	Go to check item 2.
2	Check harness continuity at connector.	Engine stopped	X	—	—	Go to check item 3.
3	Disconnect harness connector, and then check dust adhesion to harness connector.	Engine stopped	X	—	X	Clean terminal surface.
4	Check pin terminal bend.	Engine stopped	—	—	X	Take out bend.
5	Reconnect harness connector and then recheck harness continuity at connector.	Engine stopped	X	—	—	Replace terminal.
6	Tap and wiggle harness connector or component during real-time diagnosis.	During real-time diagnosis	X	X	X	If diagnostic trouble codes are displayed during real-time diagnosis, replace terminal.



MEF256DA



## Diagnostic Procedure

### CAUTION:

1. Before connecting or disconnecting the ECM harness connector to or from any ECM, be sure to turn the ignition switch to the "OFF" position and disconnect the negative battery terminal in order not to damage ECM as battery voltage is applied to ECM even if ignition switch is turned off. Failure to do so may damage the ECM.
2. When connecting ECM harness connector, tighten securing bolt until red projection is in line with connector face.
3. When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break).
4. Make sure that there are not any bends or breaks on ECM pin terminal, when connecting pin connectors.
5. Before replacing ECM, perform ECM input/output signal inspection and make sure whether ECM functions properly or not. (See page EF & EC-138.)
6. After performing this "Diagnostic Procedure", perform diagnostic test mode III (Self-diagnostic results) and driving test.

GI

MA

EM

LC

EF &  
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL






IDX

## Diagnostic Procedure (Cont'd)



7. When measuring ECM controlled components supply voltage with a circuit tester, separate one tester probe from the other.

If the two tester probes accidentally make contact with each other during measurement, the circuit will be shorted, resulting in damage to the ECM power transistor.



**Basic Inspection**

**1 BEFORE STARTING**

1. Check service records for any recent repairs that may indicate a related problem, or the current need for scheduled maintenance.
2. Open engine hood and check the following:
  - Harness connectors for proper connections
  - Vacuum hoses for splits, kinks, and proper connections
  - Wiring for proper connections, pinches, and cuts

**2 DOES ENGINE START?** No → Go to **5**.

**3 CHECK IGNITION TIMING.** Warm up engine sufficiently and check ignition timing at idle using timing light. (Refer to page EF & EC-xx.)  
Ignition timing:  $15^\circ \pm 2^\circ$  BTDC

NG → Adjust ignition timing by turning camshaft position sensor.

**4 CHECK IDLE ADJ. SCREW INITIAL SET RPM.**

1. Close IACV-AAC valve completely by turning diagnostic test mode selector on ECM fully clockwise.
2. Does engine speed fall to;  $700 \pm 50$  rpm [in "N" position]?

No → Adjust engine speed by turning idle adjusting screw.

**5 CHECK THROTTLE POSITION SENSOR IDLE POSITION.** Measure output voltage of throttle position sensor using voltmeter, and check that it is 0.4 to 0.5V. (Throttle valve fully closed.)



NG →

1. Adjust output voltage by rotating throttle position sensor body.
2. Disconnect throttle position sensor harness connector for a few seconds and then reconnect it.
3. Confirm that "IDLE POSITION" stays "ON".

(Go to (A) on next page.)

GI  
 MA  
 EM  
 LC  
 EF & EC  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX

Basic Inspection (Cont'd)



**6**

**CHECK SWITCH INPUT SIGNAL.**  
Remove ECM from front floor panel and check the above switches' ON-OFF operation using voltmeter at each ECM terminal.

NG → Repair or replace the malfunctioning switch or its circuit.

Switch	Condition	Voltage (V)
Start signal	IGN ON → IGN START	0 → Battery voltage
Closed throttle position switch signal	Idle position → Half throttle	Battery voltage → 0
A/C signal	A/C OFF → A/C ON (Engine running)	Battery voltage → 0.5 - 0.7
Neutral position (Parking) switch	Shift lever is "N" or "P" position → Except "N" and "P"	0 → 8.0 - 9.0

OK

**7**




**READ SELF-DIAGNOSTIC RESULTS.**

1. Set "Self-diagnostic function" in Diagnostic Test Mode III. (Refer to page EF & EC-44.)
2. Count the number of RED LED flashes and read out the diagnostic trouble codes.
3. Are the diagnostic trouble codes being output?


Yes → Go to the relevant inspection procedure.

No → INSPECTION END






**Diagnostic Procedure 1 — High Idling after Warm-up**




GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX


Diagnostic Procedure 2 — Hunting




**1**  
**CHECK HEATED OXYGEN SENSORS.**  
 When disconnecting heated oxygen sensor harness connector, is the hunting fixed?  
 Yes → Check heated oxygen sensor. (See page EF & EC-105.)  
 No →




**2**  
**PERFORM POWER BALANCE TEST.**  
 When disconnecting each spark plug cord one at a time, is there any cylinder which does not produce a momentary engine speed drop?  
 No → Go to **4**.  
 Yes →



**3**  
**CHECK SPARK PLUGS.**  
 Remove the spark plugs and check for fouling, etc.  
 NG → Repair or replace spark plug(s).  
 OK →








**4**  
**CHECK FOR INTAKE AIR LEAK.**  
 When pinching blow-by hose (lowering the blow-by air supply), does the engine speed rise?  
 Yes → Discover air leak location and repair.  
 No →




**5**  
**CHECK EGR VALVE.**  
 Check EGR valve for sticking.  
 NG → Repair or replace.  
 OK →

INSPECTION END














**Diagnostic Procedure 3 — Unstable Idle**




CI  
 MA  
 EM  
 IC  
**EF & EC**  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX

Diagnostic Procedure 3 — Unstable Idle (Cont'd)







**Diagnostic Procedure 4 — Hard to Start or Impossible to Start when the Engine is Cold**









GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX



**Diagnostic Procedure 4 — Hard to Start or Impossible to Start when the Engine is Cold (Cont'd)**



**Diagnostic Procedure 5 — Hard to Start or Impossible to Start when the Engine is Hot**






**Diagnostic Procedure 5 — Hard to Start or Impossible to Start when the Engine is Hot (Cont'd)**




GI  
 MA  
 EM  
 LC  
 EF & EC  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA

**Diagnostic Procedure 6 — Hard to Start or Impossible to Start under Normal Conditions**




BR  
 ST  
 BF  
 HA  
 EL  
 IX

**Diagnostic Procedure 8 — Hesitation when the Engine is Cold (Cont'd)**







**Diagnostic Procedure 9 — Hesitation under Normal Conditions**

**1**

**CHECK SPARK PLUGS.**

Remove spark plugs and check for fouling, etc.

NG

Repair or replace spark plug(s).

OK

**2**


**CHECK HEATED OXYGEN SENSOR.**

1. Set "Self-diagnostic function" in Diagnostic Test Mode I. (See page EF & EC-41.)
2. Maintaining engine at 2,000 rpm under no-load, check that GREEN LED on the ECM goes ON and OFF more than 5 times during 10 seconds.

Yes

Replace heated oxygen sensor.

No



**3**

**CHECK CANISTER PURGE.**

1. Disconnect canister purge line hose and plug hose.
2. Perform cruise test.
3. Does the hesitation disappear?

Yes

Check purge and vacuum lines.

No

**4**

**CHECK FOR INTAKE AIR LEAK.**




When pinching blow-by hose (lowering the blow-by air supply), does the engine speed rise?

Yes

Discover air leak location and repair.

No

INSPECTION END



GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST







BF

HA


EL

IDX


**Diagnostic Procedure 10 — Engine Stalls when Turning**




**Diagnostic Procedure 10 — Engine Stalls when Turning (Cont'd)**





GI  
MA  
EM  
LC  
EF & EC  
FE  
CL






**Diagnostic Procedure 11 — Engine Stalls when the Engine is Hot**








AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX



**Diagnostic Procedure 11 — Engine Stalls when the Engine is Hot (Cont'd)**



**Diagnostic Procedure 12 — Engine Stalls when the Engine is Cold**



**1**  
**CHECK IACV-AAC VALVE.**  
 When the engine is cold, can you start the engine when pressing accelerator pedal fully?

NG → Check IACV-AAC valve, and circuits. (See page EF & EC-126.)

OK →

**2**  
**PERFORM POWER BALANCE TEST.**  
 When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

NG → Go to **6**.

OK →

**3**  
**CHECK INJECTOR.**  
 1. Remove camshaft position sensor from engine. (Harness connector should remain connected.)  
 2. Turn ignition switch ON. (Do not start engine.)  
 3. When rotating camshaft position sensor shaft, does each injector make an operating sound?

NG → Check injector(s) and circuit(s).

OK →

**4**  
**CHECK IGNITION SPARK.**  
 1. Disconnect spark plug cord.  
 2. Connect a known good spark plug to the spark plug cord.  
 3. Place end of spark plug against a suitable ground and crank engine.  
 4. Check for spark.

NG → Check ignition coil, ignition wire, power transistor unit and circuits. (See page EF & EC-96.)

OK →

**5**  
**CHECK SPARK PLUGS.**  
 Remove the spark plugs and check for fouling, etc.


NG → Repair or replace spark plug(s).

OK →

(Go to (A) on next page.)

GI  
 MA  
 EW  
 LC  
**EF & EC**  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX

**Diagnostic Procedure 12 — Engine Stalls when the Engine is Cold (Cont'd)**



**6**

**CHECK FUEL PRESSURE.**  
 1. Release fuel pressure to zero. (Refer to page EF & EC-xxx.)  
 2. Install fuel pressure gauge and check fuel pressure.  
**At idle:**  
 Approx. 250.1 kPa (2.55 kg/cm<sup>2</sup>, 36.3 psi)  
**The moment throttle valve is fully open:**  
 Approx. 299.1 kPa (3.05 kg/cm<sup>2</sup>, 43.4 psi)

NG → Check fuel pressure regulator diaphragm.

OK

**CHECK ECM HARNESS CONNECTOR.**  
 Check the ECM pin terminals for damage or poor connection of ECM harness connector.

NG → Repair or replace.

OK

Reconnect ECM harness connector and retest.

Trouble is not fixed.

**CHECK ECM POWER SUPPLY AND GROUND CIRCUIT.**  
 Refer to page EF & EC-xx.


NG → Repair or replace.

OK

**TRY A KNOWN GOOD ECM.**

OK

INSPECTION END



**Diagnostic Procedure 13 — Engine Stalls when Stepping on the Accelerator Momentarily**

**1**

**CHECK IACV-AAC VALVE.**  
 1. Close IACV-AAC valve completely by turning diagnostic test mode selector on ECM fully clockwise.  
 2. Does the engine speed drop?


No → Check IACV-AAC valve and circuit. (See page EF & EC-xxx.)

Yes

**2**


**PERFORM POWER BALANCE TEST.**  
 When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

No → Go to 5




(Go to (A) on next page.)

**Diagnostic Procedure 13 — Engine Stalls when Stepping on the Accelerator Momentarily (Cont'd)**




**3**  
**CHECK INJECTOR.**  
 1. Remove camshaft position sensor from engine. (Harness connector should remain connected.)  
 2. Turn ignition switch ON. (Do not start engine.)  
 3. When rotating camshaft position sensor shaft, does each injector make an operating sound?

No → Check injector(s) and their circuit(s).



**4**  
**CHECK IGNITION SPARK.**  
 1. Disconnect spark plug cord.  
 2. Connect a known good spark plug to the spark plug cord.  
 3. Place end of spark plug against a suitable ground and crank engine.  
 4. Check for spark.

NG → Check ignition coil, ignition wire, power transistor unit and their circuits. (See page EF & EC-96.)



**5**  
**CHECK FUEL PRESSURE.**  
 1. Release fuel pressure to zero. (Refer to page EF & EC-150.)  
 2. Install fuel pressure gauge and check fuel pressure.  
**At idle:**  
 Approx. 250.1 kPa (2.55 kg/cm<sup>2</sup>, 36.3 psi)  
**The moment throttle valve is fully open:**  
 Approx. 299.1 kPa (3.05 kg/cm<sup>2</sup>, 43.4 psi)

NG → Check fuel pressure regulator diaphragm.

**CHECK ECM HARNESS CONNECTOR.**  
 Check the ECM pin terminals for damage or poor connection of ECM harness connector.

NG → Repair or replace.

Reconnect ECM harness connector and retest.

**CHECK ECM POWER SUPPLY AND GROUND CIRCUIT.**  
 Refer to page EF & EC-83.







NG → Repair or replace.

**TRY A KNOWN GOOD ECM.**

INSPECTION END





GF  
 MA  
 FM  
 LC  
**EF & EC**  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX

**Diagnostic Procedure 14 — Engine Stalls after Decelerating**










Diagnostic Procedure 14 — Engine Stalls after Decelerating (Cont'd)



GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

### Diagnostic Procedure 15 — Engine Stalls when Accelerating or Cruising



**1**

**PERFORM POWER BALANCE TEST.**

When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

No → Go to **4**.

Yes →

**2**

**CHECK INJECTOR.**

1. Remove camshaft position sensor from engine. (Harness connector should remain connected.)
2. Turn ignition switch ON. (Do not start engine.)
3. When rotating camshaft position sensor shaft, does each injector make an operating sound?

No → Check injector(s) and circuit(s).

Yes →

**3**

**CHECK IGNITION SPARK.**

1. Disconnect spark plug cord.
2. Connect a known good spark plug to the spark plug cord.
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.

NG → Check ignition coil, power transistor unit and circuits. (See page EF & EC-96.)

OK →

**4**

**CHECK FUEL PRESSURE.**

1. Release fuel pressure to zero. (Refer to page EF & EC-150.)
2. Install fuel pressure gauge and check fuel pressure.

**At idle:**  
 Approx. 250.1 kPa  
 (2.55 kg/cm<sup>2</sup>, 36.3 psi)

**The moment throttle valve is fully open:**  
 Approx. 299.1 kPa  
 (3.05 kg/cm<sup>2</sup>, 43.4 psi)

NG → Check fuel pump, circuit and fuel pressure regulator.

OK →

**5**



**CHECK FOR INTAKE AIR LEAK.**

When pinching blow-by hose (lowering the blow-by air supply), does the engine speed rise?




Yes → Discover air leak location and repair.

No → (Go to **A** on next page.)




**Diagnostic Procedure 15 — Engine Stalls when Accelerating or Cruising (Cont'd)**





**Diagnostic Procedure 16 — Engine Stalls when the Electrical Load is Heavy**




**Diagnostic Procedure 16 — Engine Stalls when the Electrical Load is Heavy (Cont'd)**








### Diagnostic Procedure 17 — Lack of Power and Stumble




GI  
 MA  
 EM  
 LC  
**EF & EC**  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX



### Diagnostic Procedure 18 — Knock



Diagnostic Procedure 18 — Knock (Cont'd)




**3**

**CHECK EGRC-SOLENOID VALVE.**

1. Disconnect EGRC-solenoid valve harness connector.
2. Supply EGRC-solenoid valve terminals with battery current and check operating sound.

NG → Check solenoid valve and circuit.

OK →



**4**

**CHECK VACUUM HOSES.**

Check the following vacuum hoses for clogging, cracks and poor connection.

- a) Vacuum hose between EGR valve and EGRC-solenoid valve.
- b) Vacuum hose between EGRC-solenoid valve and throttle body port.
- c) Vacuum hose between EGRC-solenoid valve and air duct.

NG → Repair or replace.

OK →



**CHECK FOR OIL LEAK TO COMBUSTION CHAMBER.**

Remove spark plugs and check for fouling with oil.


Yes → Check pistons, piston rings, valves, valve seats, valve oil seal, engine oil level, etc.

No →


INSPECTION END





**Diagnostic Procedure 19 — Surge**




GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX



**Diagnostic Procedure 20 — Backfire through the Intake**




**Diagnostic Procedure 21 — Backfire through the Exhaust**








Diagnostic Procedure 22

MAIN POWER SUPPLY AND GROUND CIRCUIT







GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA

Harness layout



RA  
BR  
ST  
BF  
HA  
EL  
IDX

## Diagnostic Procedure 22 (Cont'd)



INSPECTION START

## CHECK POWER SUPPLY.

1) Turn ignition switch "ON".

**A** 2) Check voltage between ECM pin terminal ⑩ and ground.

**Voltage:**

**Approximately 1V**

**B** 3) Check voltage between ECM pin terminals ④⑨, ⑤⑨ and ground.

**Voltage: Battery voltage**

NG

**C** CHECK HARNESS CONTINUITY BETWEEN ECM AND BATTERY.

1) Turn ignition switch "OFF".

2) Disconnect ECM SMJ harness connector.

3) Connect a suitable jumper wire between ECM terminal ⑩ and ground.

4) Turn ignition switch "ON".

5) Check harness continuity between battery ⊕ terminal harness connector ②④ and ECM pin terminals ④⑨ and ⑤⑨.

**Continuity should exist.**

NG

Check the following items.

1) ECCS relay  
Refer to "Electrical Components Inspection".  
(See page EF & EC-148.)

2) "BR" fusible link  
3) Joint connector ⑤⑩  
4) Joint connector ⑤②  
If OK, check harness connectors/harness.

**D** CHECK GROUND CIRCUIT.

1) Turn ignition switch "OFF".

2) Disconnect ECM SMJ harness connector.

3) Check harness continuity between ECM pin terminals ⑩, ②①, ⑤①, ⑥①, ⑩⑦, ⑩⑧, ⑩⑩ and ground.

**Continuity should exist.**

NG


1) Check if engine ground terminal connectors ②⑧ and ③① contact with engine body properly.  
2) Repair harness or connectors.

OK

INSPECTION END



Diagnostic Procedure 23

CAMSHAFT POSITION SENSOR (Diagnostic trouble code No. 11)




GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA

Harness layout




RA  
BR  
ST  
BF  
HA



EL  
IDX


Diagnostic Procedure 23 (Cont'd)




INSPECTION START

**A**  
 CHECK POWER SUPPLY.  
 1) Turn ignition switch "ON".  
 2) Check voltage between terminal (a) and ground.  
**Voltage: Battery voltage**

**B**  
 CHECK HARNESS CONTINUITY BETWEEN ECM AND CAMSHAFT POSITION SENSOR.  
 1) Turn ignition switch "OFF".  
 2) Disconnect camshaft position sensor harness connector.  
 3) Disconnect ECM SMJ harness connector.  
 4) Check harness continuity between ECM terminals (49), (59) and terminal (a).  
**Continuity should exist.**  
 If NG, repair harness or connectors.




OK




**C**  
 CHECK INPUT SIGNAL.  
 1) Start engine.  
 2) Check that pulse signals exist in ECM terminals (41), (51) and (42), (52) with logic probe.  
**Pulse signal should exist.**  
 (41), (51): 120° signal  
 (42), (52): 1° signal

**D**  
 CHECK HARNESS CONTINUITY BETWEEN ECM AND CAMSHAFT POSITION SENSOR.  
 1) Stop engine.  
 2) Disconnect camshaft position sensor harness connector.  
 3) Disconnect ECM SMJ harness connector.  
 4) Check harness continuity between ECM terminals (41), (51) and terminal (b), ECM terminals (42), (52) and terminal (c).  
**Continuity should exist.**  
 If NG, repair harness or connectors.




OK




OK


**A**  
 CHECK COMPONENT (Camshaft position sensor).  
 Refer to "Electrical Components Inspection".  
 (See page EF & EC-143.)

Diagnostic Procedure 23 (Cont'd)






Diagnostic Procedure 24


MASS AIR FLOW SENSOR (Diagnostic trouble code No. 12)  (MALFUNCTION INDICATOR LAMP ITEM)



Harness layout




Diagnostic Procedure 24 (Cont'd)



INSPECTION START

**A**  
 CHECK POWER SOURCE.  
 1) Turn ignition switch "ON".  
 2) Check voltage between terminal **e** and ground.  
**Voltage: Battery voltage**


**B**  
 CHECK HARNESS CONTINUITY BETWEEN MASS AIR FLOW SENSOR AND ECM.  
 1) Turn ignition switch "OFF".  
 2) Disconnect mass air flow sensor harness connector.  
 3) Disconnect ECM SMJ harness connector.  
 4) Check harness continuity between ECM terminals **49**, **59** and terminal **e**.  
**Continuity should exist.**  
 If NG, repair harness or connectors.




OK

**C**  
 CHECK INPUT SIGNAL.  
 1) Start engine and warm it up sufficiently.  
 2) Check voltage between terminal **d** and ground at idle under no-load.  
**Voltage: 1.0 - 1.3V**

**D**  
 CHECK HARNESS CONTINUITY BETWEEN MASS AIR FLOW SENSOR AND ECM.  
 1) Stop engine.  
 2) Disconnect mass air flow sensor harness connector.  
 3) Disconnect ECM SMJ harness connector.  
 4) Check harness continuity between ECM terminal **27** and terminal **d**.  
**Continuity should exist.**  
 If NG, repair harness or connectors.



OK





OK

**A**  
 CHECK COMPONENT (Mass air flow sensor). Refer to "Electrical Components Inspection". (See page EF & EC-143.)

GI  
 MA  
 EM  
 LC  
**EF & EC**  
 FE  
 CL  
 WT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 DX


Diagnostic Procedure 24 (Cont'd)







Diagnostic Procedure 25

ENGINE COOLANT TEMPERATURE SENSOR (Diagnostic trouble code No. 13)  
 (MALFUNCTION INDICATOR LAMP ITEM)






Harness layout



GI  
 MA  
 EM  
 LC  
**EF & EC**  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX


Diagnostic Procedure 25 (Cont'd)



```

    graph TD
        Start[INSPECTION START] --> A[A]
        A["A  
CHECK INPUT SIGNAL.  
1) Start engine.  
2) Make sure that voltage between ECM terminal 28 and ground changes during engine warm-up.  
Cold → Hot:  
Approximately 5 - 0V"] -- NG --> B["B  
CHECK HARNESS CONTINUITY BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM.  
1) Stop engine.  
2) Disconnect engine coolant temperature sensor harness connector.  
3) Disconnect ECM SMJ harness connector.  
4) Check harness continuity between ECM terminal 28 and terminal a.  
Continuity should exist.  
If NG, repair harness or connectors."]
        B -- OK --> C["CHECK COMPONENT (Engine coolant temperature sensor).  
Refer to 'Electrical Components Inspection'.  
(See page EF & EC-143.)"]
        A -- OK --> D["C  
CHECK GROUND CIRCUIT.  
1) Stop engine.  
2) Disconnect engine coolant temperature sensor harness connector.  
3) Disconnect ECM SMJ harness connector.  
4) Check harness continuity between ECM terminal 30 and terminal b.  
Continuity should exist."]
        D -- NG --> E[Repair harness or connectors.]
        D -- OK --> F[Reinstall any part removed.]
        F --> G((A))
    
```

Diagnostic Procedure 25 (Cont'd)



GI

MA

EM

LC

**EF &  
EC**

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL




IDX

Diagnostic Procedure 26




VEHICLE SPEED SENSOR (Diagnostic trouble code No. 14)(Switch ON/OFF diagnosis)   
(MALFUNCTION INDICATOR LAMP ITEM)



Harness layout




Diagnostic Procedure 26 (Cont'd)





GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 27







IGNITION SIGNAL (Diagnostic trouble code No. 21)



Harness layout






Diagnostic Procedure 27 (Cont'd)



GI  
MA  
EV  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX


Diagnostic Procedure 27 (Cont'd)







Diagnostic Procedure 28

FUEL PUMP (Diagnostic trouble code No. 22)




GI  
MA  
EM  
LC  
EF & EC  
FE  
CI  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IOX


Harness layout



Luggage compartment



Diagnostic Procedure 28 (Cont'd)




INSPECTION START

**A**

CHECK POWER SUPPLY.

- 1) Turn ignition switch "ON".
- 2) Check voltage between terminal ⑥ and ground.

**Battery voltage indication should appear 5 seconds after ignition switch is turned "ON".**



OK

**B**


CHECK HARNESS CONTINUITY BETWEEN FUSE AND FUEL PUMP.

- 1) Turn ignition switch "OFF".
- 2) Disconnect fuel pump harness connector.
- 3) Disconnect "FUEL PUMP" fuse.
- 4) Check harness continuity between terminal ⑥ and fuel pump fuse.

**Continuity should exist.**

NG

CHECK COMPONENT (Safety relay). Refer to "Electrical Components Inspection". (See page EF & EC-149.) If OK, repair harness or connectors.



**C**


CHECK OUTPUT SIGNAL.

- 1) Turn ignition switch "OFF" and then "ON".
- 2) Check voltage between ECM terminal ⑩④ and ground.

**Voltage:**  
A voltage indication of approx. 4.0 to 4.5 appears for 5 seconds after ignition switch is turned "ON".

NG

CHECK COMPONENT (Fuel pump). Refer to "Electrical Components Inspection". (See page EF & EC-144.)



OK

**D**


CHECK HARNESS CONTINUITY BETWEEN FUEL PUMP AND ECM.

- 1) Turn ignition switch "OFF".
- 2) Disconnect ECM SMJ harness connector.
- 3) Disconnect fuel pump harness connector.
- 4) Check harness continuity between ECM terminal ⑩④ and terminal ③.

**Continuity should exist.**  
If NG, repair harness or connectors.

NG

CHECK COMPONENT (Fuel pump). Refer to "Electrical Components Inspection". (See page EF & EC-144.)



**E**

CHECK GROUND CIRCUIT.


- 1) Turn ignition switch "OFF".
- 2) Disconnect safety relay.
- 3) Check resistance between terminal ③ and ground.

**Continuity should exist.**

OK

Repair or replace harness.

Diagnostic Procedure 28 (Cont'd)



GI

MA

EM


LC

EF & EC

FE

Diagnostic Procedure 29

ENGINE CONTROL MODULE (ECM) (Diagnostic trouble code No. 31)  (MALFUNCTION INDICATOR LAMP ITEM)



CL

MT

AT

FA

RA

BR

ST


BF


HA

EL



IDX

Diagnostic Procedure 30


EGR FUNCTION (Diagnostic trouble code No. 32)  (MALFUNCTION INDICATOR LAMP ITEM)



Harness layout



Diagnostic Procedure 30 (Cont'd)




INSPECTION START

**A** CHECK EGR VALVE OPERATION.

- 1) Start engine.
- 2) Make sure engine is warmed up sufficiently.
- 3) Make sure EGR valve spring responds to your touch (use your fingers) and also when engine is raced.

Responds → INSPECTION END




Does not respond

**B** CHECK VACUUM SOURCE TO EGR VALVE.

- 1) Disconnect vacuum hose connected to EGR valve.
- 2) Make sure vacuum exists when racing engine.


OK → CHECK COMPONENT (EGR valve and EGRC-BPT valve). Refer to "Electrical Components Inspection". (See page EF & EC-145.)



NG

**C** CHECK VACUUM HOSE. Check vacuum hose for clogging, cracks and proper connections.

NG → If necessary, replace vacuum hose or reconnect vacuum hose firmly.



OK

**D** CHECK ECM OUTPUT SIGNAL.


- 1) Check voltage between ECM terminal 102 and ground under the following conditions:

Engine condition	Voltage
Racing	Battery voltage
Idle	Temporarily drops to Approximately 1V

NG → **E** CHECK POWER SOURCE TO EGRC-SOLENOID VALVE.

- 1) Stop engine.
- 2) Turn ignition switch "ON".
- 3) Check voltage between terminal ① and ground.

**Voltage: Battery voltage**



OK

→ **F** CHECK GROUND CIRCUIT.

- 1) Turn ignition switch "OFF".
- 2) Disconnect ECM SMJ harness connector.
- 3) Disconnect EGRC-solenoid valve harness connector.
- 4) Check resistance between ECM terminal 102 and terminal ②.


**Resistance: Approximately 0Ω**

If NG, repair or replace harness.

→ A

GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
DX

Diagnostic Procedure 30 (Cont'd)



**G ROAD TEST**

**Test condition**  
 Drive vehicle under the following conditions with a suitable shift position.



(1) Engine speed:  
 2,100±300 rpm

(2) Intake manifold vacuum:  
 For California:  
 -14.7±2.7 kPa  
 (-110±20 mmHg, -4.33±0.79 inHg)  
 Except for California:  
 -29.3±0.7 kPa  
 (-220±5 mmHg, -8.66±0.20 inHg)

**Driving mode**


① Start engine and warm it up sufficiently.  
 ② Turn off ignition switch and keep it off until green and red LED go off.  
 ③ Start engine and make sure that air conditioner switch and rear defogger are turned "OFF" during driving test.  
 ④ Keep engine running for at least 3 minutes.  
 ⑤ Shift to suitable gear position and drive in "Test condition" for at least 11 seconds.  
 ⑥ Decrease engine speed to less than 2,000 rpm.  
 ⑦ Repeat steps ⑤ through ⑥ at least 1 time.

MEF441DA






Diagnostic Procedure 31

HEATED OXYGEN SENSOR (Diagnostic trouble code No. 33)  (MALFUNCTION INDICATOR LAMP ITEM)








Harness layout



GI  
VA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 31 (Cont'd)




```

    graph TD
      Start[INSPECTION START] --> A[CHECK HEATED OXYGEN SENSOR CIRCUIT.  
1) Start engine and warm it up sufficiently.  
2) Run engine at about 2,000 rpm for about 2 minutes under no-load.  
3) Keep engine speed at 2,000 rpm and make sure that green LED on ECM goes ON and OFF.]
      A -- OK --> End[INSPECTION END]
      A -- NG --> B[CHECK POWER SUPPLY.  
1) Stop engine.  
2) Disconnect heated oxygen sensor harness connector.  
3) Turn ignition switch "ON".  
4) Check voltage between terminal a and ground.  
Voltage: Battery voltage]
      B -- OK --> D[CHECK GROUND CIRCUIT.  
1) Turn ignition switch "OFF".  
2) Loosen and retighten ground screws.  
3) Check harness continuity between terminal c and ground.  
Continuity should exist.]
      B -- NG --> C[CHECK HARNESS CONTINUITY BETWEEN HEATED OXYGEN SENSOR AND FUSE.  
1) Turn ignition switch "OFF".  
2) Disconnect "ENG CONT" fuse.  
3) Check harness continuity between terminal a and the fuse.  
Continuity should exist.  
If NG, repair harness or connectors.]
      D -- OK --> E[CHECK INPUT SIGNAL CIRCUIT.  
1) Disconnect ECM harness connector.  
2) Check harness continuity between ECM terminal 29 and terminal b.  
Continuity should exist.]
      D -- NG --> Repair1[Repair harness or connectors.]
      E -- OK --> Replace[Replace heated oxygen sensor.]
      E -- NG --> Repair2[Repair harness or connectors.]
      Replace --> A1((A))
  
```



Diagnostic Procedure 31 (Cont'd)



GI

MA

EM

LC

**EF & EC**

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL





IDX

Diagnostic Procedure 32



KNOCK SENSOR (Diagnostic trouble code No. 34)



Harness layout



Diagnostic Procedure 32 (Cont'd)




```

    graph TD
        Start[INSPECTION START] --> A[CHECK INPUT SIGNAL CIRCUIT.  
1) Make sure that ignition switch is in "OFF" position.  
2) Disconnect knock sensor sub-harness connector.  
3) Disconnect ECM SMJ harness connector.  
4) Check harness continuity between ECM terminal 23 and terminal a.  
Continuity should exist.]
        A -- NG --> NG1[Repair harness or connectors.]
        A -- OK --> B[CHECK GROUND CIRCUIT.  
1) Loosen and retighten ground screws.  
2) Check harness continuity between terminal b and ground.  
Continuity should exist.]
        B -- NG --> NG2[Repair harness or connectors.]
        B -- OK --> C[CHECK COMPONENT  
(Knock sensor).  
Refer to "Electrical Components Inspection".  
(See page EF & EC-147.)]
        C -- OK --> D[Reinstall any part removed.]
        D --> E[Erase the diagnostic test mode III (Self-diagnostic results) memory.  
(Refer to EF & EC-42.)]
        E --> F[Perform driving test and then perform diagnostic test mode III (Self-diagnostic results) again.  
(Refer to EF & EC-42.)]
        F -- NG --> NG3[1) Perform ECM input/output signal inspection test.  
2) If NG, recheck the ECM pin terminals for damage or the connection of ECM harness connector.]
        F -- OK --> End[INSPECTION END]
    
```



CI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 33




EGR TEMPERATURE SENSOR (Diagnostic trouble code No. 35)  (MALFUNCTION INDICATOR LAMP ITEM)



Harness layout



Diagnostic Procedure 33 (Cont'd)



INSPECTION START

**A**  
CHECK INPUT SIGNAL.  
1) Start engine and warm it up sufficiently.  
2) Keep engine speed at approximately 2,000 rpm.  
3) Check voltage between ECM terminal 39 and ground under the following conditions:

Condition	Voltage
When vacuum is not applied to EGR valve	1.0V or more
When vacuum is applied to EGR valve	0 - 1.0V

**A sufficient vacuum applied with a hand vacuum pump may cause the engine to stall.**

**B**  
CHECK HARNESS CONTINUITY BETWEEN ECM AND EGR TEMPERATURE SENSOR.  
1) Stop engine.  
2) Disconnect ECM SMJ harness connector.  
3) Disconnect EGR temperature sensor harness connector.  
4) Check continuity between ECM terminal 39 and terminal a. **Continuity should exist.**  
If NG, repair harness or connector.

OK  
CHECK COMPONENT (EGR temperature sensor). Refer to "Electrical Components Inspection". (See page EF & EC-145.)

NG

**C**  
CHECK GROUND CIRCUIT.  
1) Stop engine.  
2) Disconnect ECM SMJ harness connector.  
3) Disconnect EGR temperature sensor harness connector.  
4) Check harness continuity between ECM terminal 30 and terminal b. **Continuity should exist.**

NG  
Repair harness or connectors.

OK  
Reinstall any part removed.

Erase the diagnostic test mode III (Self-diagnostic results) memory. (Refer to EF & EC-42.)

1) Start engine and warm it up sufficiently.  
2) Perform test drive for more than 15 minutes.  
3) Perform diagnostic test mode III (Self-diagnostic results) again. (Refer to EF & EC-42.)


NG  
1) Perform ECM input/output signal inspection test.  
2) If NG, recheck the ECM pin terminals for damage or the connection of ECM harness connector.

OK  
INSPECTION END




GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 34


THROTTLE POSITION SENSOR (Diagnostic trouble code No. 43)  (MALFUNCTION INDICATOR LAMP ITEM)



Harness layout




Diagnostic Procedure 34 (Cont'd)



INSPECTION START

**A**  
**CHECK POWER SOURCE.**  
 1) Turn ignition switch "ON".  
 2) Check voltage between terminal ① and ground.  
**Voltage:**  
**Approximately 5.0V**


**B**  
**CHECK HARNESS CONTINUITY BETWEEN THROTTLE POSITION SENSOR AND ECM.**  
 1) Turn ignition switch "OFF".  
 2) Disconnect throttle position sensor harness connector.  
 3) Disconnect ECM SMJ harness connector.  
 4) Check harness continuity between ECM terminal ④⑧ and terminal ①.  
**Continuity should exist.**  
 If NG, repair harness or connectors.



OK


**C**  
**CHECK INPUT SIGNAL.**  
 Make sure that voltage between ECM terminal ③⑧ and ground changes when accelerator pedal is depressed.  
**Voltage:**  
**Approximately 0.5 - 4.2V**

**D**  
**CHECK HARNESS CONTINUITY BETWEEN THROTTLE POSITION SENSOR AND ECM.**  
 1) Turn ignition switch "OFF".  
 2) Disconnect throttle position sensor harness connector.  
 3) Disconnect ECM SMJ harness connector.  
 4) Check harness continuity between ECM terminal ③⑧ and terminal ②.  
**Continuity should exist.**  
 If NG, repair harness or connectors.




OK

OK  
**CHECK COMPONENT (Throttle position sensor).**  
 Refer to "Electrical Components Inspection".  
 (See page EF & EC-145.)



**E**  
**CHECK GROUND CIRCUIT.**  
 1) Turn ignition switch "OFF".  
 2) Disconnect ECM SMJ harness connector.  
 3) Disconnect throttle position sensor harness connector.  
 4) Loosen and retighten ground screws.  
 5) Check resistance between ECM terminal ③⑩ and terminal ④.  
**Continuity should exist.**


NG  
 1) Check harness continuity between throttle position sensor and ground.  
 2) ECM ground circuit.




OK  
 (A)

GI  
 MA  
 EM  
 LC  
 EF & EC  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX

Diagnostic Procedure 34 (Cont'd)








**Diagnostic Procedure 35**

**INJECTOR LEAK (Diagnostic trouble code No. 45)  
(MALFUNCTION INDICATOR LAMP ITEM)**



GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 35 (Cont'd)

**B ROAD TEST**


**Test conditions**

Drive vehicle under the following conditions with suitable gear position.

- (1) Engine speed:  
2,500 ± 700 rpm
- (2) Intake manifold vacuum:  
-44.7 ± 8.7 kPa  
(-335 ± 65 mmHg, -13.19 ± 2.56 inHg)

**Driving mode**


- (A): 13 minutes
- (B): 15 minutes at idle speed
- (C): 5 minutes at test condition
- (D): 2 minutes at idle speed



- ① Start engine and warm it up sufficiently.
- ② Turn off ignition switch and keep it off until red LED goes off.
- ③ Start engine and keep it running for 13 minutes.
- ④ Turn off ignition switch and keep it off until red LED goes off.
- ⑤ Repeat steps ③ through ④: total 3 times.
- ⑥ Start engine and keep it at idle speed for at least 15 minutes.  
If engine stalls or ignition is turned off under 13 minutes after starting engine, return to step ②. If over 13 minutes, restart step ⑥.
- ⑦ Shift to suitable gear position and drive in "Test condition" for at least 5 minutes.  
If the following conditions occur during step ⑦, return to step ⑥.
  - Engine is raced over 4,000 rpm or hardly accelerated for more than 10 seconds.
  - Engine stalls or ignition is turned off.
- ⑧ Keep engine at idle speed for more than 2 minutes.

SEF608N

**C**



MALFUNCTION INDICATOR LAMP

MEF307D

(A)

Erase the diagnostic test mode III (Self-diagnostic results) memory.  
Make sure Diagnostic trouble code No. 55 is displayed in Diagnostic Test Mode III.  
(Refer to EF & EC-42.)

- 1) Start engine and warm it up sufficiently.
- 2) Disconnect heated oxygen sensor harness connector for at least 30 seconds at 2,000 rpm.
- 3) Stop engine and reconnect heated oxygen sensor connector.

**B**

Perform test drive under the following conditions:  
1) Warm up engine sufficiently.  
2) Use test driving modes indicated in figure B.

**C**

Make sure malfunction indicator lamp does not come "ON" during engine racing.


Comes "ON"


- 1) Perform diagnostic test mode III (Self-diagnostic results) and find diagnostic trouble code.
- 2) According to displayed Diagnostic trouble code No., perform "Diagnostic Procedure".
- 3) If Diagnostic trouble code No. 45 is displayed again, replace all injectors, then perform "Diagnostic Procedure".

Does not come "ON"




INSPECTION END

Diagnostic Procedure 36

INJECTOR CIRCUIT (Diagnostic trouble code No. 51)  (MALFUNCTION INDICATOR LAMP ITEM)




Harness layout



GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 36 (Cont'd)



INSPECTION START

**A**

CHECK POWER SUPPLY.

- 1) Disconnect harness connectors for No. 1, No. 3 and No. 5 injectors.
- 2) Disconnect sub-harness connector (F16) for No. 2, No. 4 and No. 6 injectors.
- 3) Turn ignition switch "ON" (Only models for Brazil).
- 4) Make sure that battery voltage exist in the terminals shown in figure **A**.

**B**


**(Except for Brazil)**

CHECK HARNESS CONTINUITY BETWEEN INJECTORS AND BATTERY.

- 1) Disconnect battery ⊕ terminal.
- 2) Check harness continuity between terminal (a) and battery ⊕ terminal. **Continuity should exist.**
- 3) Check "BR" fusible link.
- 4) Check joint connector-3.

If NG, replace harness, connector or fusible link.

— OR —



**(For Brazil)**



CHECK HARNESS CONTINUITY BETWEEN INJECTORS AND IGNITION SWITCH.

- 1) Turn ignition switch "OFF".
- 2) Disconnect ignition switch harness connector.
- 3) Check harness continuity between terminal (a) and terminal (i). **Continuity should exist.**
- 4) Check joint connector-5.

If NG, replace harness, or connector.

Ⓐ

Diagnostic Procedure 36 (Cont'd)



**C**

↓ A

**CHECK HARNESS CONTINUITY BETWEEN INJECTORS AND ECM.**  
 1) Turn ignition switch "OFF".  
 2) Disconnect ECM SMJ harness connector.  
 3) Check harness continuity, following the figure **C**.  
**Continuity should exist.**

NG → Repair harness or connectors.

OK ↓

**CHECK COMPONENT (Injector).**  
 Refer to "Electrical Components Inspection".  
 (See page EF & EC-147.)

NG → Repair or replace injector.

OK ↓

Reinstall any part removed.

↓

Erase the diagnostic test mode III (Self-diagnostic results) memory.  
 (Refer to EF & EC-42.)

↓

Perform driving test and then perform diagnostic test mode III (Self-diagnostic results) again.  
 (Refer to EF & EC-42.)

NG → 1) Perform ECM input/output signal inspection test.  
 2) If NG, recheck the ECM pin terminals for damage or the connection of ECM harness connector.


OK ↓

INSPECTION END


GI  
 MA  
 EM  
 LC  
**EF & EC**  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX

Diagnostic Procedure 37


A/T CONTROL (Diagnostic trouble code No. 54)



Harness layout



Diagnostic Procedure 37 (Cont'd)




```

    graph TD
      Start[INSPECTION START] --> Step1[CHECK HARNESS CONTINUITY BETWEEN ECM AND A/T CONTROL UNIT.  
1) Disconnect ECM SMJ harness connector.  
2) Disconnect A/T control unit harness connector.  
3) Check harness continuity between ECM terminal 36 and A/T control unit terminal 10.  
Continuity should exist.]
      Step1 -- NG --> Repair[Repair harness or connectors.]
      Step1 -- OK --> Step2[Reinstall any part removed.]
      Step2 --> Step3[Erase the diagnostic test mode III (Self-diagnostic results) memory.  
(Refer to EF & EC-42.)]
      Step3 --> Step4[Perform driving test and then perform diagnostic test mode III (Self-diagnostic results) again.  
(Refer to EF & EC-42.)]
      Step4 -- NG --> Step5[1) Perform ECM input/output signal inspection test.  
2) If NG, recheck the ECM pin terminals for damage.  
Check the connection at the ECM harness connector.]
      Step4 -- OK --> End[INSPECTION END]
  
```



GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
WT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 38

CLOSED THROTTLE POSITION SWITCH (Switch ON/OFF diagnostic item)





Harness layout





Diagnostic Procedure 38 (Cont'd)



INSPECTION START

**A**

CHECK INPUT SIGNAL.

- 1) Turn ignition switch "ON".
- 2) Perform on-board diagnostic system Diagnostic Test Mode IV (Switch ON/OFF diagnosis).
- 3) Make sure that red LED on ECM comes "ON" or goes "OFF" when accelerator pedal is depressed or released.

OK

INSPECTION END

**B**

CHECK HARNESS CONTINUITY BETWEEN ECM AND CLOSED THROTTLE POSITION SWITCH.

- 1) Turn ignition switch "OFF".
- 2) Disconnect closed throttle position switch harness connector.
- 3) Disconnect ECM SMJ harness connector.
- 4) Check harness continuity between ECM terminals 54, 57 and terminal a, b.

**Continuity should exist.**

If NG, repair harness or connectors.

OK

Check if throttle position sensor is installed in proper position. (See page EF & EC-145.)


OK

CHECK COMPONENT (Closed throttle position switch). Refer to "Electrical Components Inspection". (See page EF & EC-149.)


GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 39



START SIGNAL (Switch ON/OFF diagnostic item)



Harness layout



Diagnostic Procedure 39 (Cont'd)



INSPECTION START

**A**

CHECK INPUT SIGNAL.

- 1) Turn ignition switch "ON".
- 2) Perform on-board diagnostic system Diagnostic Test Mode IV (Switch ON/OFF diagnosis).
- 3) Make sure that red LED on ECM comes "ON" or goes "OFF" when ignition switch is turned to "START".

INSPECTION END

**B**

CHECK HARNESS CONTINUITY BETWEEN ECM AND BATTERY.

- 1) Turn ignition switch "OFF".
- 2) Disconnect ECM SMJ harness connector.
- 3) Turn ignition switch to "START".
- 4) Check harness continuity between ECM terminal ④ and battery harness terminal ①.

**Continuity should exist.**

Check the following items.


- 1) "G" fusible link
- 2) Ignition switch
- 3) SMJ
- 4) "STARTER" fuse
- 5) Joint connector (E51)
- 6) Joint connector (M60)

If all items are OK, repair harness or connectors.



GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 40






IACV-AAC VALVE (Not self-diagnostic item)



Harness layout




Diagnostic Procedure 40 (Cont'd)



GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
WT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 40 (Cont'd)



Ⓐ

Ⓑ

Check the following items.

- 1) "BR" fusible link
- 2) ECCS relay
- 3) Joint connector

If all items are OK, repair harness or connectors.

Ⓔ

**CHECK HARNESS CONTINUITY BETWEEN IACV-AAC VALVE AND ECM.**

- 1) Turn ignition switch "OFF".
- 2) Check harness continuity between ECM terminals ④, ⑤, ⑭, ⑮ and terminals ③, ①, ②, ⑥.

**Continuity should exist.**

NG →


Repair harness or connectors.

OK ↓

**CHECK COMPONENT (IACV-AAC valve).**


Refer to "Electrical Components Inspection".

(See page EF & EC-146.)



Alternative method for providing IACV-AAC valve fully close signal:


- 1) Pull out check connector for ECCS checker box.



- 2) Connect check connector terminals No. 2 and 3 with a suitable jumper wire.
- 3) To open IACV-AAC valve again, simply disconnect jumper wire.



Diagnostic Procedure 41

POWER VALVE CONTROL (Not self-diagnostic item)




GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IOX

Harness layout




Diagnostic Procedure 41 (Cont'd)



INSPECTION START


**A**  
CHECK POWER VALVE ACTUATOR FUNCTION.  
1) Start engine.  
2) Race engine a few times under no-load condition.  
3) Make sure that power valve actuator rod moves.

OK → INSPECTION END




**B**  
CHECK INPUT SIGNAL.  
Check voltage between ECM terminal **B** and ground.  
**Voltage should drop to approximately 1V when accelerator pedal is depressed.**

OK → Check the following items.  
1) Vacuum hose for improper connection  
2) Surge tank for cracks or holes  
3) One-way valve for air leakage



**C**  
CHECK POWER SUPPLY.  
1) Stop engine.  
2) Disconnect power valve control solenoid valve harness connector.  
3) Turn ignition switch "ON".  
4) Check voltage between terminal **b** and ground.  
**Voltage: Battery voltage**


NG → **D**  
CHECK HARNESS CONTINUITY BETWEEN BATTERY AND POWER VALVE CONTROL SOLENOID VALVE.  
1) Turn ignition switch "OFF".  
2) Disconnect battery ⊕ terminal harness connector **E24**.  
3) Check harness continuity between terminals **b** and **c**.  
**Continuity should exist.**



OK → **E**  
CHECK HARNESS CONTINUITY BETWEEN ECM AND POWER VALVE CONTROL SOLENOID VALVE.  
1) Disconnect ECM SMJ harness connector.  
2) Check harness continuity between ECM terminal **B** and terminal **a**.  
**Continuity should exist.**

NG → Check the following items.  
1) "BR" fusible link  
2) Joint connector **E52**

OK → Repair harness or connectors.



**E**  
CHECK HARNESS CONTINUITY BETWEEN ECM AND POWER VALVE CONTROL SOLENOID VALVE.  
1) Disconnect ECM SMJ harness connector.  
2) Check harness continuity between ECM terminal **B** and terminal **a**.  
**Continuity should exist.**


NG → Repair harness or connectors.

OK → **E**  
CHECK COMPONENT (Power valve control solenoid valve). Refer to "Electrical Components Inspection". (See page EF & EC-147.)






Diagnostic Procedure 42






COOLING FAN CONTROL (Not self-diagnostic item)



Harness layout



Diagnostic Procedure 42 (Cont'd)



INSPECTION START

**A**  
CHECK COOLING FAN LOW SPEED CIRCUIT.  
1) Start engine.  
2) Turn air conditioner switch "ON".  
3) Make sure that both cooling fan motors operate at low speed.

**B**  
CHECK POWER SUPPLY.  
1) Stop engine.  
2) Disconnect cooling fan relay-1.  
3) Disconnect both cooling fan motor harness connectors.  
4) Connect jumper wire between terminals ③ and ⑤.  
5) Check voltage between terminal ① and ground.  
**Voltage: Battery voltage**

CHECK COMPONENT (Cooling fan relay-1). Refer to "Electrical Components Inspection". (See page EF & EC-148.)

**C**  
CHECK HARNESS CONTINUITY BETWEEN ECM AND COOLING FAN RELAY-1.  
1) Turn ignition switch "OFF".  
2) Disconnect jumper wire.  
3) Disconnect ECM SMJ harness connector.  
4) Check harness continuity between ECM terminal ⑱ and terminal ①.  
**Continuity should exist.**

OK → **B**

NG

Check the following items:  
1) "GY" fusible link  
2) "R" fusible link  
3) Joint connector (E51)

OK

Repair harness or connectors.

OK

Replace cooling fan relay-1.




OK

Repair harness or connectors.

OK



→ **A**

Diagnostic Procedure 42 (Cont'd)




GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 42 (Cont'd)



Diagnostic Procedure 43




FAIL-SAFE SYSTEM FOR CAMSHAFT POSITION SENSOR AND CPU OF ECM



Diagnostic Procedure 43 (Cont'd)

TROUBLE DIAGNOSES FOR FAIL-SAFE SYSTEM


When fail-safe system activates, warning lamp (MALFUNCTION INDICATOR LAMP) in instrument panel blinks. When vehicle with such a problem is brought to dealer for checkup, conduct diagnostic procedures using the following chart as a guide.





GF  
WA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 44





INHIBITOR SWITCH CIRCUIT (Not self-diagnostic item)






Harness layout



Diagnostic Procedure 44 (Cont'd)



GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX



## Electrical Components Inspection

### ECM INPUT/OUTPUT SIGNAL INSPECTION

1. ECM is located behind center console panel. For this inspection, remove left side of center console under cover.
2. Remove ECM harness protector.
3. Perform all voltage measurements with the connectors connected.  
Improve tester probe as shown to perform tests easily.



Electrical Components Inspection (Cont'd)

ECM inspection table

\*Data are reference values.

TERMI- NAL NO.	ITEM	CONDITION	*DATA	
1	Ignition signal	Engine is running. └ Idle speed	0.4 - 0.6V	GE MA
		Engine is running. └ Engine speed is 4,000 rpm.	1.9 - 2.1V	FM
2	Ignition check	Engine is running. └ Idle speed	BATTERY VOLTAGE (11 - 14V)	LC
4, 5, 14, 15	IACV-AAC valve	Engine is running. └ Racing condition	Voltage briefly decreases from bat- tery voltage (11 - 14V).	EF & EC
6	Cooling fan (High speed)	Engine is running. └ Cooling fan is not operating.	BATTERY VOLTAGE (11 - 14V)	FE
		Engine is running. └ Cooling fan is operating.	0.7 - 0.8V	CL
8	Power valve control solenoid valve	Engine is running. └ Idle speed	BATTERY VOLTAGE (11 - 14V)	MT
		Engine is running. └ Racing (up to 4,000 rpm) quickly	0.7 - 0.8V	AT
9	Air conditioner relay	Engine is running. └ Air conditioner switch "OFF"	BATTERY VOLTAGE (11 - 14V)	FA
		Engine is running. └ Air conditioner switch "ON"	0.7 - 0.8V	RA
16	ECM power source (Self-shutoff)	Engine is running. └ Idle speed	0.8 - 1.0V	BR
		Engine is running. └ For a few seconds after turn- ing ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)	ST
18	Fuel pump relay	Engine is running. └ Normal condition	BATTERY VOLTAGE (11 - 14V)	BF HA
		Engine is running. └ Abnormal condition [ Fuel pump voltage control circuit (ECM terminal No. 104 ) is inoperative. ]	0.7 - 0.8V	EL DX

## Electrical Components Inspection (Cont'd)

\*Data are reference values.

TERMI- NAL NO.	ITEM	CONDITION	*DATA
19	Cooling fan (Low speed)	Engine is running. └ Cooling fan is not operating.	BATTERY VOLTAGE (11 - 14V)
		Engine is running. └ Cooling fan is operating.	0.7 - 0.8V
23	Knock sensor	Engine is running.	3.0 - 4.0V
25	Electric load signal	Engine is running. └ Electric load signal is "OFF".	BATTERY VOLTAGE (11 - 14V)
		Engine is running. └ Electric load signal (Rear defogger switch) is "ON".	0.1 - 0.3V
27	Mass air flow sensor	Engine is running. (Warm-up condition) └ Idle speed	1.0 - 1.3V
		Engine is running. (Warm-up condition) └ Engine speed is 3,000 rpm.	1.8 - 2.0V
28	Engine coolant temperature sensor	Engine is running.	0 - 5.0V Output voltage varies with engine coolant temperature.
34	Power steering oil pressure switch	Engine is running. └ Steering wheel stays straight.	8.0 - 9.0V
		Engine is running. └ Steering wheel is turned.	0 - 0.2V
38	Throttle position sensor	Ignition switch "ON"	0.5 - 4.2V Output voltage varies with throttle valve opening angle.
39	EGR temperature sensor	Engine is running. (Warm-up condition) └ Idle speed	1.0V or more
		Engine is running. (Warm-up condition) └ EGR system is operating.	0 - 1.0V

**Electrical Components Inspection (Cont'd)**

\*Data are reference values.

TERMI- NAL NO.	ITEM	CONDITION	*DATA
41 51	Camshaft position sensor (Reference signal)	Engine is running. Do not run engine at high speed under no-load.	0.2 - 0.4V Output voltage slightly varies with engine speed.
42 52	Camshaft position sensor (Position signal)	Engine is running. Do not run engine at high speed under no-load.	2.5 - 2.7V Output voltage slightly varies with engine speed.
43	Start signal	Ignition switch "ON"	0V
		Ignition switch "START"	BATTERY VOLTAGE (11 - 14V)
44	Inhibitor switch	Ignition switch "ON" └ Gear position is "N" or "P"(A/T model).	BATTERY VOLTAGE (11 - 14V)
		Ignition switch "ON" └ Except the above conditions	0V
45	Ignition switch	Ignition switch "ON" └ Engine stopped	BATTERY VOLTAGE (11 - 14V)
46	Air conditioner switch	Engine is running. └ Air conditioner switch "OFF"	8.0 - 9.0V
		Engine is running. └ Air conditioner switch "ON"	0.5 - 0.7V
48	Power source for sensors	Ignition switch "ON" └ Engine stopped	Approximately 5.0V
49	Battery source	Ignition switch "ON" └ Engine stopped	BATTERY VOLTAGE (11 - 14V)
53	Vehicle speed sensor	Ignition switch "ON" └ Engine stopped └ While rotating front wheel by hand	0 or 7.0 - 9.0V
54	Closed throttle position switch	Ignition switch "ON" └ Accelerator pedal is fully released (engine stopped).	9.0 - 10.0V
		Ignition switch "ON" └ Accelerator pedal is depressed (engine stopped).	0V

GI

MA

EM

LC

EF &  
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL


IDX

Electrical Components Inspection (Cont'd)

\*Data are reference values.

TERMI- NAL NO.	ITEM	CONDITION	*DATA
57	Power source for closed throttle position switch	Ignition switch "ON" └ Engine stopped	8.0 - 9.0V
59	Power supply	Ignition switch "ON" └ Idle speed	BATTERY VOLTAGE (11 - 14V)
101, 103, 105, 110, 112, 114	Injectors	Engine is running.	BATTERY VOLTAGE (11 - 14V)
102	EGRC-solenoid valve	Engine is running. (Warm-up condition) └ Idle speed └ Engine speed is approximately 3,400 rpm or more.	0.7 - 0.8V
		Engine is running. (Warm-up condition) └ Engine speed is about 2,000 rpm.	BATTERY VOLTAGE (11 - 14V)
104	Fuel pump voltage control	Ignition switch "ON" └ 5 seconds after turning ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
		Engine is running. └ 30 seconds after engine begins to run.	4.0 - 4.5V
		Engine is running. └ Racing (up to 4,000 rpm)	2.0 - 4.5V


ECM SMJ HARNESS CONNECTOR TERMINAL LAYOUT



SEC250B

Electrical Components Inspection (Cont'd)

CAMSHAFT POSITION SENSOR




1. Remove distributor from engine. (Camshaft position sensor harness connector should remain connected.)
2. Turn ignition switch "ON".
3. Rotate distributor shaft slowly by hand and check voltage between terminals ③, ④ and ground.


Terminal	Voltage
③ (120° signal)	Tester's pointer fluctuates between 5V and 0V.
④ (1° signal)	

If NG, replace distributor assembly with camshaft position sensor.

4. Visually check signal plate for damage or dust.




MASS AIR FLOW SENSOR




1. Peel mass air flow sensor harness connector rubber as shown in the figure if the harness connector is connected.
2. Turn ignition switch "ON".
3. Start engine and warm it up sufficiently.
4. Check voltage between terminal (b) and ground.

Conditions	Voltage V
Ignition switch "ON" (Engine stopped.)	Less than 0.5
Idle (Engine is warm-up sufficiently.)	Approximately 1.0 - 1.3

5. If NG, remove mass air flow sensor from air duct. Check hot wire for damage or dust.



ENGINE COOLANT TEMPERATURE SENSOR




1. Disconnect engine coolant temperature sensor harness connector.
2. Check resistance as shown in the figure.

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.0
80 (176)	0.30 - 0.33

If NG, replace engine coolant temperature sensor.

**Electrical Components Inspection (Cont'd)**


**IGNITION COIL**



1. Disconnect ignition coil harness connector.
2. Check resistance as shown in the figure.

Terminal	Resistance
① - ②	Approximately 1.0Ω

If NG, replace ignition coil.




**POWER TRANSISTOR**

1. Disconnect power transistor harness connector.
2. Check power transistor continuity between terminals as shown in the figure.

**Set tester in lower range.**

Terminal No.	Tester polarity	Continuity
Ⓐ	⊕	Yes
Ⓑ	⊖	
Ⓐ	⊖	No
Ⓑ	⊕	
Ⓐ	⊕	Yes
Ⓒ	⊖	
Ⓐ	⊖	No
Ⓒ	⊕	

If NG, replace power transistor.




**FUEL PUMP**

1. Disconnect fuel pump harness connector.
2. Check resistance between terminals (a) and (c).

**Resistance: Approximately 1.0Ω**

If NG, replace fuel pump.



**VEHICLE SPEED SENSOR**

1. Jack up front wheel.
2. Disconnect vehicle speed sensor harness connector.
3. Check continuity, as shown in the figure, rotating the wheel by hand.

**Continuity should come and go.**

If NG, replace vehicle speed sensor.


Electrical Components Inspection (Cont'd)

EGRC-SOLENOID VALVE

1. Disconnect EGRC-solenoid valve harness connector.
2. Check solenoid valve, following the table as shown below:

Conditions	Continuity between port (A) and (B)
Supply 12V direct current between terminals ① and ②	Yes
No current supply	No

If NG, replace EGRC-solenoid valve.



EGR VALVE

Apply vacuum to EGR vacuum port with a hand vacuum pump.


**EGR valve spring should lift.**

If NG, replace EGR valve.

HEATED OXYGEN SENSOR

Refer to "Diagnostic Procedure 31".


(See page EF & EC-104.)



EGRC-BPT VALVE

Plug one of two ports of EGRC-BPT valve.

Apply a pressure above 0.490 kPa (50 mmH<sub>2</sub>O, 1.97 inH<sub>2</sub>O) to check for leakage. If a leak is noted, replace valve.



EGR TEMPERATURE SENSOR


Check resistance change and resistance value at 100°C (212°F).

- Resistance should decrease in response to temperature increase.

**Resistance: 100°C (212°F)**

**85.3 ± 8.53 kΩ**

If NG, replace EGR temperature sensor.




THROTTLE POSITION SENSOR

1. Disconnect throttle position sensor harness connector.
2. Make sure that resistance between terminals (e) and (f) changes when opening throttle valve manually.

Accelerator pedal conditions	Resistance kΩ
Completely released	Approximately 1
Partially released	1 - 9
Completely depressed	Approximately 9




If NG, replace throttle position sensor.



## Electrical Components Inspection (Cont'd)

## Adjustment

If throttle position sensor, closed throttle position switch or wide open throttle position switch is replaced or removed, it is necessary to install it in proper position, by following the procedure as shown below:



1. Install throttle position sensor body in throttle body. Do not tighten bolts. Leave bolts loose.
2. Connect throttle position sensor and closed throttle position switch harness connector.
3. Start engine and warm it up sufficiently.
4. Turn diagnostic test mode selector on ECM fully clockwise.
5. Disconnect closed throttle position switch harness connector.
6. Check closed throttle position switch OFF → ON speed with circuit tester, closing throttle valve manually.

**Closed throttle position switch OFF → ON speed:**

**Engine speed (Idle speed in "N" position) +  
250 ± 150 rpm**

7. If NG, set closed throttle position switch OFF → ON speed to the specified value by turning throttle position sensor body. Connect circuit tester with terminals **c** and **b** on closed throttle position switch side and find out OFF → ON point.
8. Tighten throttle position sensor installing bolts carefully after setting so that throttle position sensor does not move.

## IACV-AAC VALVE


## Resistance check

1. Disconnect IACV-AAC valve harness connector.
2. Check resistance between terminals, following the table as shown below:

Terminal No.	Resistance
① - ②	Approximately 27 - 40Ω
② - ③	
④ - ⑤	
⑤ - ⑥	
① - ⑥	



Electrical Components Inspection (Cont'd)



MEF349E

Operation check

1. Remove IACV-AAC valve assembly from intake manifold.
2. Apply battery voltage between terminals one by one in order indicated in the table below:


Terminal No.	⊕ ⊖	Order	
		② - ①	↓
	⑤ - ④		
	② - ③		
	⑤ - ⑥		
Moving direction		a	b

3. Check IACV-AAC valve shaft moves forward and backward. If results of both checks are NG, replace IACV-AAC valve.

WARNING:

- IACV-AAC valve shaft movement is hard to see visually, but vibration is felt if IACV-AAC valve can be reached with hand.
- When IACV-AAC valve is removed or replaced, IACV-AAC valve should be closed by turning diagnostic test mode selector fully clockwise.


There is a possibility that IACV-AAC valve opening angle memorized in ECM does not match the actual IACV-AAC valve opening angle.



MEF330D

KNOCK SENSOR

1. Disconnect knock sensor sub-harness connector.
2. Check continuity between terminals (a) and (b).  
**Continuity should exist.**




MEF331D

POWER VALVE CONTROL SOLENOID VALVE

1. Disconnect power valve control solenoid valve harness connector.
2. Check solenoid valve, following the table as shown below:

Conditions	Continuity between port (A) and (B)
Supply 12V between terminals ① and ②	Yes
No current supply	No

If NG, replace power valve control solenoid valve.




SEC196B

Electrical Components Inspection (Cont'd)

INJECTOR

No. 1, No. 3 and No. 5 cylinders

1. Disconnect injector harness connector.
2. Check resistance between terminals as shown in the figure.  
**Resistance: 10 - 14Ω**  
If NG, replace injector.




No. 2, No. 4 and No. 6 cylinders

1. Disconnect middle harness connector for injectors.
2. Check resistance between terminals, following the table as shown below:

Cylinder	Terminal No.	Resistance
No. 2	② - ⑧	10 - 14Ω
No. 4	④ - ⑧	
No. 6	⑥ - ⑧	

If NG, replace injector.




CLOSED THROTTLE POSITION SWITCH

1. Disconnect closed throttle position switch harness connector.
2. Check continuity between terminals (b) and (c).

Accelerator pedal condition	Continuity
Released	Yes
Depressed	No

If NG, replace closed throttle position switch.




INHIBITOR SWITCH

Check continuity between terminals (a) and (b).

Conditions	Continuity
Shift to "P" position	Yes
Shift to "N" position	Yes
Shift to positions other than "P" and "N"	No

If NG, replace inhibitor switch.




ECCS RELAY, FUEL PUMP RELAY AND COOLING FAN RELAY-1

Check continuity between terminals (3) and (5).

Conditions	Continuity
12V supply between terminals ① and ②	Yes
No current supply	No


If NG, replace relay.



Electrical Components Inspection (Cont'd)

COOLING FAN RELAY-2 AND COOLING FAN RELAY-3

Check continuity between terminals ③ and ⑤, ⑥ and ⑦.




SEC202B

Conditions	Continuity
12V supply between terminals ① and ②	Yes
No current supply	No

If NG, replace relay.

SAFETY RELAY

Check continuity between terminals ② and ③.



SEF648E

Conditions		Continuity between terminals ② and ③
12V supply between terminals ① and ②		
①	②	
-	+	Yes
+	-	No


If NG, replace relay.

RESISTOR

1. Disconnect resistor harness connector.
2. Check resistance between terminal (a) and (b).

Resistance: Approximately 2.2Ω


If NG, replace resistor.



SEF334H

WIDE OPEN THROTTLE POSITION SWITCH

1. Disconnect throttle position switch harness connector.
2. Check continuity between terminals (b) and (a).




SEF895M

Accelerator pedal condition	Continuity
Released	No
Depressed	Yes

If NG, replace throttle position switch.

GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX



**Releasing Fuel Pressure**


Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger.

1. Remove fuse for fuel pump.
2. Start engine.
3. After engine stalls, crank it two or three times to release all fuel pressure.
4. Turn ignition switch off and reconnect fuel pump fuse.

Erase the diagnostic test mode III (self-diagnostic results) memory (Diagnostic trouble code No. 22).

**Fuel Pressure Check**

- a. When reconnecting fuel line, always use new clamps.
- b. Make sure that clamp screw does not contact adjacent parts.
- c. Use a torque driver to tighten clamps.
- d. Use Pressure Gauge to check fuel pressure.
- e. Do not perform fuel pressure check while fuel pressure regulator control system is operating; otherwise, fuel pressure gauge might indicate incorrect readings.



1. Release fuel pressure to zero.
2. Disconnect fuel hose between fuel filter and fuel tube (engine side).
3. Install pressure gauge between fuel filter and fuel tube.
4. Start engine and check for fuel leakage.
5. Read the indication of fuel pressure gauge.

**At idling:**


**When fuel pressure regulator valve vacuum hose is connected.**

Approximately 250.1 kPa  
(2.55 kg/cm<sup>2</sup>, 36.3 psi)

**When fuel pressure regulator valve vacuum hose is disconnected.**


Approximately 299.1 kPa  
(3.05 kg/cm<sup>2</sup>, 43.4 psi)

6. Stop engine and disconnect fuel pressure regulator vacuum hose from intake manifold.
7. Plug intake manifold with a rubber cap.
8. Connect variable vacuum source to fuel pressure regulator.



9. Start engine and read indication of fuel pressure gauge as vacuum is changed.

**Fuel pressure should decrease as vacuum increases. If results are unsatisfactory, replace fuel pressure regulator.**




**Injector Removal**


1. Release fuel pressure to zero.
2. Separate ASCD and accelerator control wire from intake manifold collector.
3. Remove intake upper manifold collector from engine.

- The following parts should be disconnected or removed.
- (1) Harness connectors for
    - IACV-AAC valve
    - Throttle position sensor
    - Closed throttle position switch
    - Water hose for air cut valve


- (2) PCV hoses
- (3) Vacuum hoses from
  - Vacuum gallery
  - Power valve actuator
  - Master brake cylinder
  - EGR valve
- (4) EGR flare tube



4. Remove intake lower manifold collector from engine.
  - Remove engine earth harness.



5. Remove injector fuel tube assembly. The following parts should be disconnected or removed.
  - Vacuum hose for fuel pressure regulator
  - Fuel feed and return hose
  - All injectors harness connectors



6. Remove any malfunctioning injector from injector fuel tube.
7. Replace or clean injector as necessary.

**Always replace O-ring with a new one.**

8. Connect injector to injector fuel tube.
9. Reinstall any part removed in reverse order of removal.

**CAUTION:**

**After properly connecting fuel hose to injector and fuel tube, check connection for fuel leakage.**

GF

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

DX

Description




The evaporative emission system is used to reduce hydrocarbons emitted to the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the carbon canister.

The fuel vapor from the sealed fuel tank is led into the canister which contains activated carbon and the vapor is stored there when the engine is not running.

The canister retains the fuel vapor until the canister is purged by the air drawn through the bottom of the canister to the intake manifold when the engine is running. When the engine runs at idle, the purge control valve is closed.

Only a small amount of stored vapor flows into the intake manifold through the constant purge orifice. As the engine speed increases, and the throttle vacuum rises higher, the purge control valve opens and the vapor is sucked into the intake manifold through both the main purge orifice and the constant purge orifice.




Inspection

ACTIVATED CARBON CANISTER

Check carbon canister as follows:

1. Blow air port **A** and ensure that there is no leakage.
2.
  - Apply vacuum to port **A**.
  - Cover port **D** with hand.
  - Blow air in port **C** and ensure free flow out of port **B**.



**Inspection (Cont'd)**

**FUEL CHECK VALVE (With rollover valve)**

**Check valve operation**

1. Blow air through connector on fuel tank side.  
A considerable resistance should be felt and a portion of air flow should be directed toward the canister side.
2. Blow air through connector on canister side.  
Air flow should be smoothly directed toward fuel tank side.
3. If fuel check valve is suspected of not properly functioning in steps 1 and 2 above, replace it.

**Rollover valve operation**

Ensure that continuity of air passage does not exist when the installed rollover valve is tilted to 90° or 180°.

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA


EL

IDX



**FUEL TANK VACUUM RELIEF VALVE**

1. Wipe clean valve housing.
2. Suck air through the cap. A slight resistance accompanied by valve clicks indicates that valve A is in good mechanical condition. Note also that, by further sucking air, the resistance should disappear with valve clicks.
3. Blow air on fuel tank side and ensure that continuity of air passage exist through valve B.
4. If valve is clogged or if no resistance is felt, replace cap as an assembly.



**Description**

This system returns blow-by gas to both the intake manifold and air cleaner.

The positive crankcase ventilation (PCV) valve is provided to conduct crankcase blow-by gas to the intake manifold.


During partial throttle operation of the engine, the intake manifold sucks the blow-by gas through the PCV valve.

Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air.

The ventilating air is then drawn from the air cleaner, through the hose connecting air cleaner to rocker cover, into the crankcase.

Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the valve, and its flow goes through the hose connection in the reverse direction.


On vehicles with an excessively high blow-by some of the flow will go through the hose connection to the air cleaner under all conditions.



**Inspection**


**PCV (Positive Crankcase Ventilation)**

With engine running at idle, remove ventilation hose from PCV valve; if valve is working properly, a hissing noise will be heard as air passes through it and a strong vacuum should be felt immediately when a finger is placed over valve inlet.




**VENTILATION HOSE**

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.











ECCS Component Parts Location




GI  
MA  
EM  
LC  
**EF & EC**  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IOX



ECCS Component Parts Location (Cont'd)




System Diagram



- GI
- MA
- EM
- LC
- EF & EC**
- FE
- CL
- MT
- AT
- FA
- RA
- BR
- ST
- BF
- HA
- EL
- IDX


System Chart




\*: When throttle position sensor is malfunctioning, idle position is determined by closed throttle position switch instead.

Vacuum Hose Drawing


M/T models



A/T models



M/T and A/T



SEF449N

- ① Power valve actuator to vacuum tube
- ② Pressure regulator to vacuum gallery
- ③ Throttle body to vacuum gallery
- ④ Intake manifold collector to vacuum gallery

- ⑤ Intake manifold collector to vacuum gallery
- ⑥ EGR valve to EGRC-solenoid valve
- ⑦ Surge tank to vacuum gallery
- ⑧ Surge tank to power valve control solenoid valve

- ⑨ Power valve control solenoid valve to vacuum tube
- ⑩ EGRC-solenoid valve to vacuum gallery
- ⑪ Activated carbon canister (purge line) to sub-fuel tube assembly
- ⑫ Activated carbon canister (vacuum line) to throttle body

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST


BF


HA

EL

IDX

Circuit Diagram





SEC220B


### Engine Control Module (ECM)-ECCS Control Module

The ECM consists of a microcomputer, inspection lamp, a diagnostic test mode selector, and connectors for signal input and output and for power supply. The ECM controls the engine.

GI

MA

EM



SEF971E

### Camshaft Position Sensor (CMPS)

The camshaft position sensor is the basic component of the ECCS. It monitors engine speed and piston position, and sends signals to the ECM to control fuel injection, ignition timing and other functions.


LC

EF & EC

The camshaft position sensor has a rotor plate and a wave-forming circuit. The rotor plate has 360 slits for 1° signal and 6 slits for 120° signal. Light Emitting Diodes (LED) and photo diodes are built in the wave-forming circuit.

FE

CL



SEF326I


When the rotor plate passes between the LED and the photo diode, the slits in the rotor plate allow light to be transmitted to the photo diode from the LED. This generates rough-shaped pulses which are converted into on-off pulses by the wave-forming circuit, which are sent to the ECM.

MT

AT

FA

RA



SEC221B

### Mass Air Flow Sensor (MAFS)

The mass air flow sensor measures the intake air flow by maintaining the temperature of a hot film placed in the air stream. The amount of heat dissipated from the film, and hence the film temperature, depends on the volume of the air flow around the film. The higher the air flow, the more heat is dissipated and thus a higher current is required to maintain the film temperature.


BR

ST

BF

The ECM monitors the amount of current from the output of the mass air flow sensor, and calculates the air flow rate.

HA



MEF338D


### Engine Coolant Temperature Sensor (ECTS)

The engine coolant temperature sensor detects engine coolant temperature and transmits a signal to the ECM.

EL

The temperature sensing unit employs a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.

IDX





### Throttle Position Sensor (TPS) & Soft/Hard Closed Throttle Position (CTP) Switch

The throttle position sensor responds to accelerator pedal movement. This sensor is a kind of potentiometer which transforms the throttle position into an output voltage, and transmits the voltage signal to the ECM. In addition, the sensor detects the opening and closing speed of the throttle valve and transmits the voltage signal to the ECM.

The ECM sets the throttle valve idle position from the throttle position sensor signal.


This system is called "soft closed throttle position switch". It controls engine operations such as fuel cut. On the other hand, the "hard closed throttle position switch", which is built into the throttle position sensor unit, is used for engine control when the soft closed throttle position switch is malfunctioning.



### Fuel Injector

The fuel injector is a small, elaborate solenoid valve. As the ECM sends injection signals to the injector, the coil in the injector pulls the needle valve back and fuel is released into the intake manifold through the nozzle. The ECM controls the injection pulse duration which is burn controls the amount of injected fuel.






**Pressure Regulator**

The pressure regulator maintains the fuel pressure at 299.1 kPa (3.05 kg/cm<sup>2</sup>, 43.4 psi). Since the injected fuel amount depends on injection pulse duration, it is necessary to maintain the pressure at the above value.

GI

WA

FW



**Heated Oxygen Sensor (HO2S)**


The heated oxygen sensor, located in the exhaust tube, monitors the oxygen level in the exhaust gas. This sensor is made of ceramic titania, the electric resistance of which drastically changes at the ideal air-fuel ratio. The ECM supplies the sensor with approximately 1V and then measures the output voltage depending on its resistance. In order to activate the sensor element, it is equipped with a heater.

LC

EF & EC

FE

CL




WT

AT

FA

RA



**Fuel Pump**


A turbine type design fuel pump is used and is situated in the fuel tank.

BR

ST

BF

HA





**Power Transistor Unit & Ignition Coil**

The ignition signal from the ECM is amplified by the power transistor, which turns the ignition coil primary circuit on and off, inducing the proper high voltage in the secondary circuit. The ignition coil is a small, molded type.

EL

DX


**Power Transistor Unit & Ignition Coil (Cont'd)**



**Idle Air Control Valve (IACV)-Air Regulator**

The IACV-air regulator provides an air by-pass when the engine is cold for a fast idle during warm-up.

Wax, piston and spring are built into the IACV-air regulator. When the coolant temperature is low, the air by-pass port opens. When the coolant temperature is high, the wax expands, moving the piston up and closing the air by-pass port, which decreases the idle speed.




**Idle Air Adjusting (IAA) Unit**

The IAA unit is made up of the IACV-AAC valve, IACV-FICD solenoid valve, IACV-air regulator and idle adjusting screw. It receives the signal from the ECM and controls the idle speed at the preset value.


**Idle Air Control Valve (IACV)-Fast Idle Control Device (FICD) Solenoid Valve**

When the air conditioner switch is on, additional air is supplied by the IACV-FICD solenoid valve.



**Idle Air Control Valve (IACV)-Auxiliary Air Control (AAC) Valve**


The ECM actuates the IACV-AAC valve by an ON/OFF pulse. The longer that an ON pulse is received, the larger the amount of air that will flow through the IACV-AAC valve.



**Vehicle Speed Sensor (VSS)**

The vehicle speed sensor provides a vehicle speed signal to the ECM. The speed sensor consists of a reed switch, which is installed in the speedometer unit and transforms vehicle speed into a pulse signal.


GI  
MA  
EM



**Power Steering Oil Pressure Switch**

The power steering oil pressure switch is attached to the power steering high-pressure tube and detects the power steering load, sending a load signal to the ECM. The ECM then sends an idle-up signal to the IACV-AAC valve.


LC  
EF & EC



**Knock Sensor (KS)**

The knock sensor is attached to the cylinder block and senses engine knocking. A knocking vibration from the cylinder block is transmitted as pressure to the piezoelectric element. This vibrational pressure is then converted into a voltage signal which is delivered as output.


FE  
CL  
MT  
AT  
FA  
RA



**Valve Timing Control Solenoid Valve**

The valve timing control solenoids are installed on the cylinder heads, and control oil pressure which regulates the position of the intake camshafts.


BR  
ST  
BF  
HA



**Exhaust Gas Recirculation (EGR) Valve**


The EGR valve controls the quantity of exhaust gas to be fed into the intake manifold through vertical movement of the taper valve connected to the diaphragm, to which vacuum is applied in response to the opening of the throttle valve.

EL  
IDX




**EGR Control (EGRC)-BPT Valve**

The EGRC-BPT valve monitors exhaust pressure to activate the diaphragm, controlling throttle body vacuum applied to the EGR valve. In other words, recirculated exhaust gas is controlled in response to positioning of the EGR valve or to engine operation.




**EGR Control (EGRC)-Solenoid Valve**

The solenoid valve responds to ON/OFF signals from the ECM. When it is off, a vacuum signal from the throttle body is fed into the EGR valve. When the ECM sends an ON signal, the coil pulls the plunger downward and cuts the vacuum signal.




**EGR Temperature Sensor**

The EGR temperature sensor monitors exhaust gas temperature and transmits a signal to the ECM. The temperature sensing unit employs a thermistor which is sensitive to changes in temperature. Electric resistance of the thermistor decreases in response to a rise in temperature.




**Power Valve**

The power valve is used to control the suction passage of the power valve control system. It is set in the fully closed or fully opened position by the power valve actuator operated by the vacuum stored in the surge tank. The vacuum in the surge tank is controlled by the power valve control solenoid valve.



**Power Valve Control Solenoid Valve**

The power valve control solenoid valve cuts the intake manifold vacuum signal for power valve control. It responds to ON/OFF signals from the ECM. When the solenoid is off, the vacuum signal from the intake manifold is cut. When the ECM sends an ON signal the coil pulls the plunger downward and feeds the vacuum signal to the power valve actuator.




**Fuel Filter**

The specially designed fuel filter has a metal case in order to withstand high fuel pressure.

GI

MA

EM




**Data Link Connector for CONSULT**

The data link connector for CONSULT is located behind the fuse box cover.

LC

EF & EC

FE



**Activated Carbon Canister**

The carbon canister is filled with active charcoal to absorb evaporative gases produced in the fuel tank. These absorbed gases are then sucked into the intake manifold by manifold vacuum for combustion.

MT

AT

FA

RA

BR

ST

BF


HA

EL

IDX

**Multiport Fuel Injection (MFI) System**

**INPUT/OUTPUT SIGNAL LINE**



\*: When throttle position sensor is malfunctioning, idle position is determined by closed throttle position switch instead.


**BASIC MULTI-PORT FUEL INJECTION SYSTEM**

The amount of fuel injected from the fuel injector, or the length of time the valve remains open, is determined by the ECM. The amount of fuel injected is a program value mapped in the ECM memory. In other words, the program value is preset by engine operating conditions determined by input signals (for engine speed and air intake) from both the camshaft position sensor and the mass air flow sensor.

**FUEL INJECTION INCREASE/DECREASE**

In addition, the amount of fuel injection is compensated for to improve engine performance under various operating conditions as listed below.

- < Fuel increase >
- 1) During warm-up
- 2) When starting the engine
- 3) During acceleration
- 4) Hot-engine operation
- < Fuel decrease >
- 1) During deceleration



**MIXTURE RATIO FEEDBACK CONTROL**

The mixture ratio feedback system is designed to precisely control the mixture ratio to the stoichiometric point so that the three way catalyst can reduce CO, HC and NOx emissions. This system uses an heated oxygen sensor in the exhaust manifold to check the air-fuel ratio. The ECM adjusts the injection pulse width according to the sensor voltage so the mixture ratio will be within the range of the stoichiometric air-fuel ratio.

**Multiport Fuel Injection (MFI) System (Cont'd)**

This stage refers to closed loop control. Open loop control refers to that under which the ECM detects any of the following conditions and feedback control stops in order to maintain stabilized fuel combustion.


- 1) Deceleration
- 2) High-load operation
- 3) Engine idling
- 4) Malfunction of heated oxygen sensor or its circuit
- 5) Insufficient activation of heated oxygen sensor at low engine coolant temperature.
- 6) Engine starting

**MIXTURE RATIO SELF-LEARNING CONTROL**

The mixture ratio feedback control system monitors the mixture ratio signal transmitted from the heated oxygen sensor. This feedback signal is then sent to the ECM to control the amount of fuel injection to provide a basic mixture ratio as close to the theoretical mixture ratio as possible. However, the basic mixture ratio is not necessarily controlled as originally designed. This is due to manufacturing errors (e.g., mass air flow sensor hot wire) and changes during operation (injector clogging, etc.) of ECCS parts which directly affect the mixture ratio.

Accordingly, a difference between the basic and theoretical mixture ratios is quantitatively monitored in this system. It is then computed in terms of "fuel injection duration" to automatically compensate for the difference between the two ratios.

GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
DX



**FUEL INJECTION TIMING**

Two types of fuel injection systems are used — simultaneous multiport fuel injection system and sequential multiport fuel injection system. In the former, fuel is injected into all cylinders simultaneously twice each engine cycle.

In other words, pulse signals of the same width are simultaneously transmitted from the ECM to the all injectors two times for each engine cycle.

In the sequential multiport fuel injection system, fuel is injected into each cylinder during each engine cycle according to the firing order.

When the engine is being started and/or if the fail-safe system (CPU of ECM) is operating, simultaneous multiport fuel injection system is used.


When the engine is running sequential multiport fuel injection system is used.

**FUEL SHUT-OFF**


Fuel to each cylinder is cut off during deceleration or operation of the engine at excessively high speeds.

### Electronic Ignition (EI) System

#### INPUT/OUTPUT SIGNAL LINE



\*: When throttle position sensor is malfunctioning, idle position is determined by closed throttle position switch instead.



#### SYSTEM DESCRIPTION

The ignition timing is controlled by the ECM in order to maintain the best air-fuel ratio in response to every running condition of the engine.

The ignition timing data is stored in the ECM, in the form of the map as shown.

The ECM detects information such as the injection pulse width and camshaft position sensor signal which varies every moment. Then responding to this information, ignition signals are transmitted to the power transistor

e.g. N: 1,800 rpm, Tp: 1.50 msec  
A °BTDC

In addition to this, the ignition timing is revised by the ECM according to the other data stored in the ECM at the following times:

- 1) At starting
- 2) During warm-up
- 3) At idle
- 4) At acceleration
- 5) During fuel shut-off




Electronic Ignition (EI) System (Cont'd)

The knock sensor retard system is designed only for emergencies. The basic ignition timing is pre-programmed within the anti-knocking zone, even if recommended fuel is used under dry conditions. Consequently, the retard system does not operate under normal driving conditions.

However, if engine knocking occurs, the knock sensor monitors this and a signal is transmitted to the ECM. After receiving it, the ECM retards the ignition timing to avoid engine knocking.

Idle Air Control (IAC) System

INPUT/OUTPUT SIGNAL LINE



\*: When throttle position sensor is malfunctioning, idle position is determined by closed throttle position switch instead.

SYSTEM DESCRIPTION

This system automatically controls engine idle speed to a specified level. Idle speed is controlled through fine adjustment of the amount of air which by-passes the throttle valve via the IACV-AAC valve.

The IACV-AAC valve repeats ON/OFF operation according to signals sent from the ECM.

The camshaft position sensor detects the actual engine speed and sends a signal to the ECM.

The ECM then controls the ON/OFF time of the IACV-AAC valve so that engine speed coincides


with the target value memorized in the ECM. The target engine speed is the lowest speed at which the engine can operate steadily. The optimum value stored in the ECM is determined by taking into consideration various engine conditions, such as warm-up, during deceleration and engine load.

GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF

HA  
EL  
IDX

### Fuel Pump Control

#### INPUT/OUTPUT SIGNAL LINE



#### SYSTEM DESCRIPTION

##### Fuel pump ON-OFF control


The ECM activates the fuel pump for several seconds after the ignition switch is turned on to improve engine start-up. If the ECM receives a 120° signal from the camshaft position sensor, it knows that the engine is rotating, and causes the pump to activate. If the 120° signal is not received when the ignition switch is on, the engine stalls. The ECM stops pump operation and prevents the battery from discharging, thereby improving safety. The ECM does not directly drive the fuel

pump. It controls the ON/OFF fuel pump relay, which in turn controls the fuel pump.

Condition	Fuel pump operation
Ignition switch is turned to ON.	Operates for 5 seconds
Engine running and cranking	Operates
When engine is stopped	Stops in 1.5 seconds
Except as shown above	Stops

### Exhaust Gas Recirculation (EGR) System

#### INPUT/OUTPUT SIGNAL LINE



\*: When throttle position sensor is malfunctioning, idle position is determined by closed throttle position switch instead.

#### SYSTEM DESCRIPTION

A system is provided which precisely cuts and controls the port vacuum applied to the EGR valve to suit engine operating conditions.


This cut-and-control operation is accomplished through the ECM. When the ECM detects any of the conditions listed below, current flows through the solenoid valve in the EGR control vacuum line.

This causes the port vacuum to be discharged into the atmosphere so that the EGR valve remains closed.

- 1) Low engine coolant temperature
- 2) Engine starting
- 3) High-speed engine operation
- 4) Engine idling
- 5) Excessively high engine coolant temperature
- 6) Mass air flow sensor malfunction

Power Valve Control

INPUT/OUTPUT SIGNAL LINE



GI  
MA  
EM  
LC  
EF & EC

FE

CL

INT

AT

FA

RA

BR

ST


BF

HA

EL

IDX

\*: When throttle position sensor is malfunctioning, idle position is determined by closed throttle position switch instead.



MEF348D

SYSTEM DESCRIPTION

When the engine is running at low or medium speed under a heavy load, the power valve control solenoid valve is energized by a signal from the ECM. This signal introduces the intake manifold vacuum into the power valve actuator to close the power valve. Under this condition, the effective suction port length is equivalent to the total length of the intake manifold collector's suction port including the intake valve. This long suction port provides increased air intake which results in improved suction efficiency and higher torque generation.


The surge tank and one-way valve are provided so that the power valve can be maintained in the

fully closed position under heavy loads when the manifold vacuum is insufficient. In other conditions, the power valve control solenoid valve is de-energized, and the power valve actuator is vented to the atmosphere. This opens the power valve to two suction passages together in the collector.

Under this condition, the effective port length is equivalent to the length of the suction port provided independently for each cylinder. This shortened port length results in enhanced engine output with reduced suction resistance under high speeds.

### Acceleration Cut Control

#### INPUT/OUTPUT SIGNAL LINE



\*: When throttle position sensor is malfunctioning, idle position is determined by closed throttle position switch instead.


#### SYSTEM DESCRIPTION

When the accelerator pedal is fully depressed, the air conditioner is turned off for a few seconds.

This system improves acceleration when the air conditioner is used.

### Valve Timing Control (VTC)

#### INPUT/OUTPUT SIGNAL LINE



\*: When throttle position sensor is malfunctioning, idle position is determined by closed throttle position switch instead.


#### SYSTEM DESCRIPTION

The valve timing control system is utilized to increase engine performance. Intake valve opening and closing time is controlled, according to the engine operating conditions, by the ECM.

Engine coolant temperature signals, engine speed, amount of intake air, throttle position, vehicle speed and gear position are used to determine intake valve timing.

The intake camshaft pulley position is regulated by oil pressure, which is controlled by the valve timing control solenoid valve.

Valve Timing Control (VTC) (Cont'd)



GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX






Valve Timing Control (VTC) (Cont'd)

OPERATION

Engine operating condition	Valve timing control solenoid valve	Intake valve opening and closing time	Valve overlap	Engine torque curve
<ul style="list-style-type: none"> <li>● Except at idle</li> <li>● Engine coolant temperature is below 110°C (230°F).</li> <li>● Engine speed is below 4,600 rpm.</li> <li>● Engine load is high.</li> <li>● Selector lever other than "N" or "P" position.</li> </ul>	ON	Advance	Increased	II
Those other than above	OFF	Retard	Decreased	I

Ⓘ Valve timing control (VTC) valve is OFF.


Ⓜ Valve timing control (VTC) valve is ON.



SEF617LA

### Cooling Fan Control

#### INPUT/OUTPUT SIGNAL LINE




#### SYSTEM DESCRIPTION

The ECM controls the cooling fan corresponding to the vehicle speed, engine coolant temperature,

and air conditioner ON signal.

The control system has 3-step control [HIGH/LOW/OFF].

#### OPERATION



### Fail-safe System

#### CPU MALFUNCTION

##### Outline

The fail-safe system makes engine starting possible if there is something malfunctioning in the ECM's CPU circuit.

In former models, engine starting was difficult under the previously mentioned conditions. But with the provisions in this fail-safe system, it is possible to start the engine.

#### Fail-safe system activating condition when ECM is malfunctioning

The fail-safe mode operates when the computing function of the ECM is judged to be malfunctioning.

When the fail-safe system activates, i.e. if a malfunction condition is detected in the CPU of the ECM, the MALFUNCTION INDICATOR LAMP on the instrument panel lights to warn the driver.

#### Engine control with fail-safe system, operates when ECM is malfunctioning

When the fail-safe system is operating, fuel injection, ignition timing, fuel pump operation, IACV-AAC valve operation, and so on are controlled under certain limitations.

##### Operation

	Operation
Fuel injection	Simultaneous multiport fuel injection system
Ignition timing	Ignition timing preset value is fixed at the factory.
Fuel pump	Fuel pump relay is "ON" when engine is running and "OFF" when engine stalls.
IACV-AAC valve	Full open
Cooling fans	Cooling fan relays "ON"

#### Cancellation of fail-safe system when ECM is malfunctioning

Activation of the fail-safe system is canceled each time the ignition switch is turned OFF. The system is reactivated if all of the activating conditions are satisfied after turning the ignition switch from OFF to ON.

**Fail-safe System (Cont'd)**

**MASS AIR FLOW SENSOR MALFUNCTION**

If the mass air flow sensor output voltage is below the specified value, the ECM senses an mass air flow sensor malfunction. In the case of a malfunction, the throttle position sensor substitutes for the mass air flow sensor.

Although the mass air flow sensor is malfunctioning, it is possible to start the engine and drive the vehicle. But engine speed will not rise more than 2,400 rpm in order to inform the driver of fail-safe system operation while driving.

**Operation**

Engine condition	Starter switch	Fail-safe system	Fail-safe functioning
Stopped	ANY	Does not operate	—
Cranking	ON	Operates	Engine will be started by a pre-determined injection pulse on ECM.
Running	OFF		Engine speed will not rise above 2,400 rpm

**ENGINE COOLANT TEMPERATURE SENSOR MALFUNCTION**

When engine coolant temperature sensor output voltage is below or above the specified value, water temperature is fixed at the preset value as follows:

**Operation**

Condition	Engine coolant temperature determined by ECM
Just as ignition switch is turned ON or Start	40°C (104°F)
More than 6 minutes after ignition ON or Start	80°C (176°F)
Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)

**THROTTLE POSITION SENSOR MALFUNCTION**

**Description**

When the output signal of throttle position sensor is abnormal the ECM judges it as a closed throttle position sensor malfunction.

With throttle position switch

The ECM does not use the throttle position sensor signal, but determines the idle position by the closed throttle position switch.


**Operation**

	Driving condition
When engine is idling	Normal
When accelerating	Poor acceleration

**KNOCK SENSOR MALFUNCTION**



When the output signal of the knock sensor is abnormal, the ECM judges it to be malfunctioning. When the knock sensor is malfunctioning, ignition timing will retard according to operating conditions.





For check connector location, see "Harness Layout" in EL section.

SEF809M



**Direct Ignition System**

**CHECKING IDLE SPEED AND IGNITION TIMING**

**Idle speed**

- Check idle speed in "DATA MONITOR" mode with CONSULT.

- 1. Disconnect check connector for voltage type tachometer.
- 2. Connect tachometer using a suitable tool.

**Ignition timing**

Any of the following three methods may be used, however, methods "A" and "B" give more reliable results and are preferable.



● **Method A (With SST)**

- 1. Disconnect No. 1 ignition coil harness connector.
- 2. Connect SST and clamp wire with timing light as shown.
- 3. Check ignition timing.

GI  
 MA  
 EM  
 LC  
 EF & EC  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX


## Direct Ignition System (Cont'd)

Align direction marks on SST and timing light clamp if aligning mark is punched.






- **Method B (Without SST)**

1. Remove No. 1 ignition coil.
2. Connect No. 1 ignition coil and No. 1 spark plug with suitable high-tension wire as shown, and attach timing light clamp to this wire.
3. Check ignition timing.



Direct Ignition System (Cont'd)

- For above procedures, enlarge suitable high-tension wire end with insulating tape as shown.



- Method C (Without SST)  
Clamp wire as shown.


GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

**Preparation**

1. Make sure that the following parts are in good order:
  - Battery
  - Ignition system
  - Engine oil and coolant levels
  - Fuses
  - ECM harness connector
  - Vacuum hoses
  - Air intake system  
(Oil filler cap, oil level gauge, etc.)
  - Fuel pressure
  - Engine compression
  - Throttle valve
  - EGR valve operation
2. On air conditioner equipped models, checks should be carried out while the air conditioner is "OFF".
3. On automatic transaxle equipped models, when checking idle rpm, ignition timing and mixture ratio, checks should be carried out while shift lever is in "N" position.
4. When measuring "CO" percentage, insert probe more than 40 cm (15.7 in) into tail pipe.
5. Turn off headlamps, heater blower, rear defogger.
6. Keep front wheels pointed straight ahead.
7. Make the check after the cooling fan has stopped.


**Inspection and Adjustment**

**OVERALL INSPECTION SEQUENCE**




**Inspection and Adjustment (Cont'd)**


**CHECKING AND ADJUSTING IDLE SPEED, IGNITION TIMING AND MIXTURE RATIO**



**Inspection and Adjustment (Cont'd)**



**Inspection and Adjustment (Cont'd)**



↓

**Check idle speed.**

📱 • Read idle speed in "DATA MONITOR" mode with CONSULT.



OR

🕒 • Check idle speed.

---

**M/T: 750 ± 50 rpm**


**A/T: 790 ± 50 rpm (in "N" position)**



\* ECM may be the cause of problem, but this is rarely the case.

GI  
 VA  
 EW  
 LC  
**EF & EC**  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX

**Inspection and Adjustment (Cont'd)**





B

1. See "M/R F/C MNT" in "Data monitor" mode.
2. Run engine at about 2,000 rpm for about 2 minutes under no-load.
3. Maintaining engine at 2,000 rpm under no-load (engine is warmed up sufficiently.), check that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds.  
RICH → LEAN → RICH →  
 1 time                      2 times  
LEAN → RICH .....  
 OR

NG → C

---

1. Set "Heated oxygen sensor monitor" in the self-diagnostic test mode II. (See page EF & EC-201.)
2. Run engine at about 2,000 rpm for about 2 minutes under no-load.
3. Maintaining engine at 2,000 rpm under no-load, check to make sure that the RED LED on the ECM or the malfunction indicator lamp on the instrument panel goes ON and OFF more than 5 times during 10 seconds.




OK

END




**Inspection and Adjustment (Cont'd)**



Check heated oxygen sensor harness:


- 1) Turn off engine and disconnect battery ground cable.
- 2) Disconnect ECM SMJ harness connector from ECM.
- 3) Disconnect heated oxygen sensor harness connector and connect main harness side terminal for heated oxygen sensor to ground with a jumper wire. (For the location, refer to EF & EC-272.)
- 4) Check for continuity between terminal No. 29 of ECM SMJ harness connector and body ground.

Continuity exists .....OK  
Continuity does not exist .....NG



Repair or replace harness.

Connect ECM SMJ harness connector to ECM.



1) Connect battery ground cable.

2) Select "ENG COOLANT TEMP" in "ACTIVE TEST" mode.


3) Set "COOLANT TEMP" to 20°C (68°F) by touching "Qu" and "Qd" and "UP", "DOWN".

OR


1) Disconnect engine coolant temperature sensor harness connector.

2) Connect a resistor (2.5 kΩ) between terminals of engine coolant temperature sensor harness connector.

3) Connect battery ground cable.



Start engine and warm it up until water temperature indicator points to middle of gauge.




GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

**Inspection and Adjustment (Cont'd)**

①


Race engine two or three times under no-load, then run engine at idle speed.



Check "CO"%.  
**Idle CO: Less than 8%**  
 After checking CO%,  
 1) Touch "BACK".


---

1) Disconnect the resistor from terminals of engine coolant temperature sensor harness connector.  
 2) Connect engine coolant temperature sensor harness connector to engine coolant temperature sensor.




NG OK


Replace heated oxygen sensor.



1. See "M/R F/C MNT" in "Data monitor" mode.  
 2. Maintaining engine at 2,000 rpm under no-load (engine is warmed up sufficiently.), check that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds.  
**RICH → LEAN → RICH →**  
           1 time          2 times  
**LEAN → RICH .....**  
**OR**




1. Set "Heated oxygen sensor monitor" in the self-diagnostic test mode II.  
 (See page EF & EC-201.)  
 2. Maintaining engine at 2,000 rpm under no-load, check to make sure that the RED LED on the ECM or the malfunction indicator lamp on the instrument panel goes ON and OFF more than 5 times during 10 seconds.



NG OK  
 ② ③

**Inspection and Adjustment (Cont'd)**



\*: ECM may be the cause of a problem, but this is rarely the case.

GI

MA

EM

LC

**EF & EC**

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL


IDX

## Contents

How to Perform Trouble Diagnoses for Quick and Accurate Repair .....	EF & EC-192
On-board Diagnostic System .....	EF & EC-195
On-board Diagnostic System — Diagnostic Test Mode I .....	EF & EC-198
On-board Diagnostic System — Diagnostic Test Mode II (Self-diagnostic results) .....	EF & EC-199
On-board Diagnostic System — Diagnostic Test Mode II (Heated oxygen sensor monitor) .....	EF & EC-201
Consult .....	EF & EC-201
Diagnostic Procedure .....	EF & EC-213
Basic Inspection .....	EF & EC-215
Diagnostic Procedure 1 — High Idling after Warm-up .....	EF & EC-218
Diagnostic Procedure 2 — Hunting .....	EF & EC-219
Diagnostic Procedure 3 — Unstable Idle .....	EF & EC-221
Diagnostic Procedure 4 — Hard to Start or Impossible to Start when the Engine is Cold ..	EF & EC-224
Diagnostic Procedure 5 — Hard to Start or Impossible to Start when the Engine is Hot ....	EF & EC-225
Diagnostic Procedure 6 — Hard to Start or Impossible to Start under Normal Conditions .....	EF & EC-227
Diagnostic Procedure 7 — Hesitation when the Engine is Hot .....	EF & EC-228
Diagnostic Procedure 8 — Hesitation when the Engine is Cold .....	EF & EC-229
Diagnostic Procedure 9 — Hesitation under Normal Conditions .....	EF & EC-230
Diagnostic Procedure 10 — Engine Stalls when Turning .....	EF & EC-231
Diagnostic Procedure 11 — Engine Stalls when the Engine is Hot .....	EF & EC-233
Diagnostic Procedure 12 — Engine Stalls when the Engine is Cold .....	EF & EC-235
Diagnostic Procedure 13 — Engine Stalls when Stepping on the Accelerator Momentarily .....	EF & EC-237
Diagnostic Procedure 14 — Engine Stalls after Decelerating .....	EF & EC-239
Diagnostic Procedure 15 — Engine Stalls when Accelerating or Cruising .....	EF & EC-242
Diagnostic Procedure 16 — Engine Stalls when the Electrical Load is Heavy .....	EF & EC-244
Diagnostic Procedure 17 — Lack of Power and Stumble .....	EF & EC-246
Diagnostic Procedure 18 — Knock .....	EF & EC-247
Diagnostic Procedure 19 — Surge .....	EF & EC-248
Diagnostic Procedure 20 — Backfire through the Intake .....	EF & EC-249
Diagnostic Procedure 21 — Backfire through the Exhaust .....	EF & EC-249
Diagnostic Procedure 22 MAIN POWER SUPPLY AND GROUND CIRCUIT .....	EF & EC-250
Diagnostic Procedure 23 CAMSHAFT POSITION SENSOR .....	EF & EC-253
Diagnostic Procedure 24 MASS AIR FLOW SENSOR .....	EF & EC-256
Diagnostic Procedure 25 ENGINE COOLANT TEMPERATURE SENSOR .....	EF & EC-259
Diagnostic Procedure 26 VEHICLE SPEED SENSOR .....	EF & EC-262
Diagnostic Procedure 27 IGNITION SIGNAL .....	EF & EC-264
Diagnostic Procedure 28 ENGINE CONTROL MODULE (ECM) .....	EF & EC-267
Diagnostic Procedure 29 EGR FUNCTION & EGR CONTROL .....	EF & EC-268
Diagnostic Procedure 30 HEATED OXYGEN SENSOR .....	EF & EC-272
Diagnostic Procedure 31 KNOCK SENSOR .....	EF & EC-276
Diagnostic Procedure 32 EGR TEMPERATURE SENSOR .....	EF & EC-278

**Contents (Cont'd)**

<b>Diagnostic Procedure 33</b>			
THROTTLE POSITION SENSOR .....	EF & EC-281		
<b>Diagnostic Procedure 34</b>			
INJECTOR LEAK .....	EF & EC-284		
<b>Diagnostic Procedure 35</b>			GI
INJECTOR CIRCUIT .....	EF & EC-287		
<b>Diagnostic Procedure 36</b>			MA
A/T CONTROL .....	EF & EC-290		
<b>Diagnostic Procedure 37</b>			EW
CLOSED THROTTLE POSITION SWITCH .....	EF & EC-292		
<b>Diagnostic Procedure 38</b>			
START SIGNAL .....	EF & EC-294		
<b>Diagnostic Procedure 39</b>			LC
POWER STEERING OIL PRESSURE SWITCH .....	EF & EC-296		
<b>Diagnostic Procedure 40</b>			<b>EF &amp; EC</b>
NEUTRAL POSITION SWITCH & A/T CONTROL UNIT (NEUTRAL POSITION SIGNAL) CIRCUIT .....	EF & EC-298		
<b>Diagnostic Procedure 41</b>			PE
FUEL PUMP .....	EF & EC-302		
<b>Diagnostic Procedure 42</b>			CL
IACV-AAC VALVE .....	EF & EC-305		
<b>Diagnostic Procedure 43</b>			MT
POWER VALVE CONTROL .....	EF & EC-307		
<b>Diagnostic Procedure 44</b>			
VTC SOLENOID VALVE .....	EF & EC-310		
<b>Diagnostic Procedure 45</b>			AT
COOLING FAN CONTROL .....	EF & EC-194		
<b>Electrical Components Inspection</b> .....	EF & EC-319		FA
			RA
			BR
			ST
			BF
			HA
			EL
			IDX



## How to Perform Trouble Diagnoses for Quick and Accurate Repair

### INTRODUCTION



The engine has an ECM to control major systems such as fuel control, ignition control, idle air control system, etc. The ECM accepts input signals from sensors and instantly drives actuators. It is essential that both kinds of signals are proper and stable. At the same time, it is important that there are no conventional problems such as vacuum leaks, fouled spark plugs, or other problems with the engine.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.

A visual check only may not find the cause of the problems, so a road test with a circuit tester connected to a suspected circuit should be performed.


Before undertaking actual checks, take just a few minutes to talk with a customer who approaches with a driveability complaint. The customer is a very good supplier of information on such problems, especially intermittent ones. Through interaction with the customer, find out what symptoms are present and under what conditions they occur.

Start your diagnosis by looking for "conventional" problems first. This is one of the best ways to troubleshoot driveability problems on an electronically controlled engine vehicle.



How to Perform Trouble Diagnoses for Quick and Accurate Repair (Cont'd)

WORK FLOW



\*1: If the on-board diagnostic system cannot be performed, check main power supply and ground circuit. (See Diagnostic Procedure 22.)

\*2: If the trouble is not duplicated, see INTERMITTENT PROBLEM SIMULATION (EF & EC-195).






**How to Perform Trouble Diagnoses for Quick and Accurate Repair (Cont'd)**

**INTERMITTENT PROBLEM SIMULATION**

In order to duplicate an intermittent problem, it is effective to create similar conditions for component parts, under which the problem might occur. Perform the activity listed under Service procedure and note the result.



GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
WT  
AT  
FA  
RA  
BR  
ST  
BF


	Variable factor	Influential part	Target condition	Service procedure
1	Mixture ratio	Pressure regulator	Made lean	Remove vacuum hose and apply vacuum.
			Made rich	Remove vacuum hose and apply pressure.
2	Ignition timing	Camshaft position sensor	Advanced	Rotate distributor clockwise.
			Retarded	Rotate distributor counterclockwise.
3	Mixture ratio feedback control	Heated oxygen sensor	Suspended	Disconnect heated oxygen sensor harness connector.
		ECM	Operation check	Perform diagnostic test mode II (Self-diagnostic results) at 2,000 rpm.
4	Idle speed	IACV-AAC valve	Raised	Turn idle adjusting screw counterclockwise.
			Lowered	Turn idle adjusting screw clockwise.
5	Electric connection (Electric continuity)	Harness connectors and wires	Poor electric connection or improper wiring	Tap or wiggle. Race engine rapidly. See if the torque reaction of the engine unit causes electric breaks.
			Cooled	Cool with an icing spray or similar device.
6	Temperature	ECM	Warmed	Heat with a hair drier. [WARNING: Do not overheat the unit.]
			Damp	Wet. [WARNING: Do not directly pour water on components. Use a mist sprayer.]
7	Moisture	Electric parts		
8	Electric loads	Load switches	Loaded	Turn on headlamps, air conditioner, rear defogger, etc.
9	Closed throttle position switch condition	ECM	ON-OFF switching	Rotate throttle position sensor body.
10	Ignition spark	Timing light	Spark power check	Try to flash timing light for each cylinder using ignition adapter (SST).

HA  
EL  
IDX

**On-board Diagnostic System**

**MALFUNCTION INDICATOR LAMP**


A malfunction indicator lamp has been adopted on all models. This light blinks simultaneously with the RED LED on the ECM.






**On-board Diagnostic System (Cont'd)**

**ECM LED**


The ECM has only one RED LED.



**ON-BOARD DIAGNOSTIC SYSTEM FUNCTION**

Condition		Diagnostic Test Mode	
		Diagnostic Test Mode I	Diagnostic Test Mode II
Ignition switch in "ON" position 	Engine stopped 	BULB CHECK	SELF-DIAGNOSTIC RESULTS
	Engine running 	MALFUNCTION WARNING	HEATED OXYGEN SENSOR MONITOR

On-board Diagnostic System (Cont'd)



GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

HOW TO SWITCH DIAGNOSTIC TEST MODES

- Switching the modes is not possible when the engine is running.
- When the ignition switch is turned off during diagnosis in each mode, and then turned back on again after power to the ECM has dropped off completely, the diagnosis will automatically return to Diagnostic Test Mode I.
- Turn back diagnostic test mode selector to the fully counterclockwise position whenever vehicle is in use.

## On-board Diagnostic System — Diagnostic Test Mode I

### DIAGNOSTIC TEST MODE I — BULB CHECK

In this mode, the RED LED in the ECM and the MALFUNCTION INDICATOR LAMP in the instrument panel stay "ON".

If either remain "OFF", check the bulb in the MALFUNCTION INDICATOR LAMP or the RED LED.

### DIAGNOSTIC TEST MODE I — MALFUNCTION WARNING

MALFUNCTION INDICATOR LAMP and RED LED	Condition
ON	When the following malfunction (malfunction indicator lamp item) is detected or the ECM's CPU is malfunctioning.
OFF	OK


Diagnostic trouble code No.	Malfunction
12	Mass air flow sensor circuit
13	Engine coolant temperature sensor circuit
14	Vehicle speed sensor circuit
31	ECM (ECCS control module)
32	EGR function
33	Heated oxygen sensor circuit
35	EGR temperature sensor circuit
43	Throttle position sensor circuit
45	Injector leak
51	Injector circuit

- These Diagnostic Trouble Code Numbers are clarified in Diagnostic Test Mode II — SELF-DIAGNOSTIC RESULTS.
- The RED LED and the MALFUNCTION INDICATOR LAMP will turn off when normal condition is detected. At this time, the Diagnostic Test Mode II — SELF-DIAGNOSTIC RESULTS memory must be cleared as the contents remain stored.

### On-board Diagnostic System — Diagnostic test mode II (Self-diagnostic results)

#### DESCRIPTION

In this mode, a diagnostic trouble code is indicated by the number of flashes from the RED LED or the MALFUNCTION INDICATOR LAMP as shown below:



Long (0.6 second) blinking indicates the number of ten digits and short (0.3 second) blinking indicates the number of single digits.

For example, the red LED flashes once for 0.6 seconds and then it flashes twice for 0.3 seconds. This indicates the number "12" and refers to a malfunction in the mass air flow sensor. In this way, all the problems are classified by their diagnostic trouble code numbers.

The diagnostic results will remain in ECM memory.

#### Display diagnostic trouble code table

Diagnostic trouble code No.	Detected items	
11*	Camshaft position sensor circuit	X
12	Mass air flow sensor circuit	X
13	Engine coolant temperature sensor circuit	X
14	Vehicle speed sensor circuit	X
21*	Ignition signal circuit	X
31	ECM	X
32	EGR function	X
33	Heated oxygen sensor circuit	X
34	Knock sensor circuit	X
35	EGR temperature sensor circuit	X
43	Throttle position sensor circuit	X
45	Injector leak	X
51	Injector circuit	X
54	Signal circuit from A/T control unit to ECM (A/T only)	X
55	No malfunction in the above circuits	X

X: Available

: Malfunction indicator lamp item

\*: Check items causing a malfunction of camshaft position sensor circuit first, if both diagnostic trouble code No. 11 and 21 are displayed at the same time.

### On-board Diagnostic System — Diagnostic test mode II (Self-diagnostic results) (Cont'd)

Diagnostic trouble code No.	Detected items	Malfunction is detected when ...	Check item (remedy)
*11	Camshaft position sensor circuit	<ul style="list-style-type: none"> <li>● Either 1° or 120° signal is not entered for the first few seconds during engine cranking.</li> <li>● Either 1° or 120° signal is not input often enough while the engine speed is higher than the specified rpm.</li> </ul>	<ul style="list-style-type: none"> <li>● Harness and connector (If harness and connector are normal, replace camshaft position sensor.)</li> </ul>
12	Mass air flow sensor circuit	<ul style="list-style-type: none"> <li>● The mass air flow sensor circuit is open or shorted. (An abnormally high or low voltage is entered.)</li> </ul>	<ul style="list-style-type: none"> <li>● Harness and connector (If harness and connector are normal, replace mass air flow sensor.)</li> </ul>
13	Engine coolant temperature sensor circuit	<ul style="list-style-type: none"> <li>● The engine coolant temperature sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.)</li> </ul>	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Engine coolant temperature sensor</li> </ul>
14	Vehicle speed sensor circuit	<ul style="list-style-type: none"> <li>● The vehicle speed sensor circuit is open or shorted.</li> </ul>	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Vehicle speed sensor (reed switch)</li> </ul>
*21	Ignition signal circuit	<ul style="list-style-type: none"> <li>● The ignition signal in the primary circuit is not entered during engine cranking or running.</li> </ul>	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Power transistor unit</li> </ul>
31	ECM	<ul style="list-style-type: none"> <li>● ECM calculation function is malfunctioning.</li> </ul>	(Replace ECM (ECCS control module).)
32	EGR function	<ul style="list-style-type: none"> <li>● EGR valve does not operate. (EGR valve spring does not lift.)</li> </ul>	<ul style="list-style-type: none"> <li>● EGR valve</li> <li>● EGRC-solenoid valve</li> </ul>
33	Heated oxygen sensor circuit	<ul style="list-style-type: none"> <li>● The heated oxygen sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.)</li> </ul>	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Heated oxygen sensor</li> <li>● Fuel pressure</li> <li>● Injectors</li> <li>● Intake air leaks</li> </ul>
34	Knock sensor circuit	<ul style="list-style-type: none"> <li>● The knock sensor circuit is open or shorted. (An abnormally high or low voltage is entered.)</li> </ul>	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Knock sensor</li> </ul>
35	EGR temperature sensor circuit	<ul style="list-style-type: none"> <li>● The EGR temperature sensor circuit is open or shorted. (An abnormally high or low voltage is entered.)</li> </ul>	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● EGR temperature sensor</li> </ul>
43	Throttle position sensor circuit	<ul style="list-style-type: none"> <li>● The throttle position sensor circuit is open or shorted. (An abnormally high or low voltage is entered.)</li> </ul>	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Throttle position sensor</li> </ul>
45	Injector leak	<ul style="list-style-type: none"> <li>● Fuel leaks from injector.</li> </ul>	<ul style="list-style-type: none"> <li>● Injector</li> </ul>
51	Injector circuit	<ul style="list-style-type: none"> <li>● The injector circuit is open.</li> </ul>	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Injector</li> </ul>
54	Signal circuit from A/T control unit to ECM (A/T only)	<ul style="list-style-type: none"> <li>● The A/T communication line is open or shorted.</li> </ul>	<ul style="list-style-type: none"> <li>● Harness and connector</li> </ul>

\*: Check items causing a malfunction of camshaft position sensor circuit first, if both diagnostic trouble code No. 11 and 21 are displayed at the same time.

## On-board Diagnostic System — Diagnostic test mode II (Self-diagnostic results) (Cont'd)

### HOW TO ERASE DIAGNOSTIC TEST MODE II (SELF-DIAGNOSTIC RESULTS)

The diagnostic trouble code is erased from the backup memory on the ECM when the diagnostic test mode is changed from Diagnostic Test Mode II to Diagnostic Test Mode I. (Refer to "HOW TO SWITCH DIAGNOSTIC TEST MODES".)

- When the battery terminal is disconnected, the diagnostic trouble code will be lost from the backup memory within 24 hours.
- Do not erase the stored memory before beginning on-board diagnostic system.

## On-board Diagnostic System — Diagnostic Test Mode II (Heated oxygen sensor monitor)

### DESCRIPTION


In this mode, the MALFUNCTION INDICATOR LAMP and RED LED display the condition of the fuel mixture (lean or rich) which is monitored by the heated oxygen sensor.

MALFUNCTION INDICATOR LAMP and RED LED	Fuel mixture condition in the exhaust gas	Air fuel ratio feedback control condition
ON	Lean	Closed loop system
OFF	Rich	
*Remains ON or OFF	Any condition	Open loop system

\*: Maintains conditions just before switching to open loop.

### HOW TO CHECK HEATED OXYGEN SENSOR

1. Set Diagnostic Test Mode II. (Refer to "HOW TO SWITCH DIAGNOSTIC TEST MODES".)
2. Start engine and warm it up until engine coolant temperature indicator points to the middle of the gauge.
3. Run engine at about 2,000 rpm for about 2 minutes under no-load conditions.
4. Make sure RED LED or MALFUNCTION INDICATOR LAMP goes ON and OFF more than 5 times every 10 seconds; measured at 2,000 rpm under no-load.





## Consult


### CONSULT INSPECTION PROCEDURE

1. Turn off ignition switch.
2. Connect "CONSULT" to data link connector for CONSULT. (Data link connector for CONSULT is located in left dash side panel.)


Consult (Cont'd)



3. Turn on ignition switch.
4. Touch "START".



5. Touch "ENGINE".



6. Perform each diagnostic test mode according to the inspection sheet as follows:

**For further information, see the CONSULT Operation Manual.**



Consult (Cont'd)

ECCS COMPONENT PARTS APPLICATION

ECCS COMPONENT PARTS		DIAGNOSTIC TEST MODE				
		WORK SUPPORT	SELF-DIAG-NOSTIC RESULTS	DATA MONITOR	ACTIVE TEST	FUNCTION TEST
IN-PUT	Camshaft position sensor		X	X		
	Mass air flow sensor		X	X		
	Engine coolant temperature sensor		X	X	X	
	Heated oxygen sensor		X	X		
	Vehicle speed sensor		X	X		X
	Throttle position sensor	X	X	X		X
	EGR temperature sensor		X	X		
	Knock sensor		X			
	Ignition switch (start signal)			X		X
	Air conditioner switch			X		
	Neutral position switch			X		X
	Power steering oil pressure switch			X		X
	Battery			X		
	A/T signal		X			
OUT-PUT	Injectors		X	X	X	X
	Power transistors (ignition timing)		X (Ignition signal)	X	X	X
	IACV-AAC valve	X		X	X	X
	Valve timing control solenoid valve			X	X	X
	EGRC-solenoid valve			X	X	X
	Power valve control solenoid valve*			X		X
	Air conditioner relay			X		
	Fuel pump relay	X		X	X	X
Cooling fan			X	X	X	

\*: M/T models only

X: Applicable

GF

MA

EM

LC

EF & EC

FE

CL

MT

AT

EA

RA

BR

ST

BF

HA

EL

IDX

## Consult (Cont'd)

## FUNCTION

Diagnostic test mode	Function
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT unit.
Self-diagnostic results	Self-diagnostic results can be read and erased quickly.
Date monitor	Input/Output data in the ECM can be read.
Active test	Diagnostic Test Mode in which CONSULT drives some actuators apart from the ECM and also shifts some parameters in a specified range.
ECM part number	ECM part number can be read.
Function test	Conducted by CONSULT instead of a technician to determine whether each system is "OK" or "NG".

## WORK SUPPORT MODE

WORK ITEM	CONDITION	USAGE
THRTL POS SEN ADJ	CHECK THE THROTTLE POSITION SENSOR SIGNAL. ADJUST IT TO THE SPECIFIED VALUE BY ROTATING THE SENSOR BODY UNDER THE FOLLOWING CONDITIONS. <ul style="list-style-type: none"> <li>● IGN SW "ON"</li> <li>● ENG NOT RUNNING</li> <li>● ACC PEDAL NOT PRESSED</li> </ul>	When adjusting throttle position sensor initial position,
IACV-AAC/V ADJ	SET ENGINE SPEED AT THE SPECIFIED VALUE UNDER THE FOLLOWING CONDITIONS. <ul style="list-style-type: none"> <li>● ENGINE WARMED UP</li> <li>● NO-LOAD</li> </ul>	When adjusting idle speed,
FUEL PRESSURE RELEASE	<ul style="list-style-type: none"> <li>● FUEL PUMP WILL STOP BY TOUCHING "START" DURING IDLING.</li> </ul> CRANK A FEW TIMES AFTER ENGINE STALLS.	When releasing fuel pressure from fuel line,

## Consult (Cont'd)

## SELF-DIAGNOSTIC RESULTS MODE

DIAGNOSTIC ITEM	DIAGNOSTIC ITEM IS DETECTED WHEN ...	CHECK ITEM (REMEDY)
CRANK POSITION SEN*	<ul style="list-style-type: none"> <li>Either 1° or 120° signal is not entered for the first few seconds during engine cranking.</li> <li>Either 1° or 120° signal is not input often enough while the engine speed is higher than the specified rpm.</li> </ul>	<ul style="list-style-type: none"> <li>Harness and connector (If harness and connector are normal, replace camshaft position sensor.)</li> </ul>
MASS AIR FLOW SEN	<ul style="list-style-type: none"> <li>The mass air flow sensor circuit is open or shorted. (An abnormally high or low voltage is entered.)</li> </ul>	<ul style="list-style-type: none"> <li>Harness and connector (If harness and connector are normal, replace mass air flow sensor.)</li> </ul>
COOLANT TEMP SEN	<ul style="list-style-type: none"> <li>The engine coolant temperature sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.)</li> </ul>	<ul style="list-style-type: none"> <li>Harness and connector</li> <li>Engine coolant temperature sensor</li> </ul>
VEHICLE SPEED SEN	<ul style="list-style-type: none"> <li>The vehicle speed sensor circuit is open or shorted.</li> </ul>	<ul style="list-style-type: none"> <li>Harness and connector</li> <li>Vehicle speed sensor (reed switch)</li> </ul>
IGN SIGNAL—PRIMARY*	<ul style="list-style-type: none"> <li>The ignition signal in primary circuit is not entered during engine cranking or running.</li> </ul>	<ul style="list-style-type: none"> <li>Harness and connector</li> <li>Power transistor unit</li> </ul>
ECM	<ul style="list-style-type: none"> <li>ECM calculation function is malfunctioning.</li> </ul>	(Replace ECM.)
EGRC SOLENOID/V	<ul style="list-style-type: none"> <li>EGR valve does not operate. (EGR valve spring does not lift.)</li> </ul>	<ul style="list-style-type: none"> <li>EGR valve</li> <li>EGRC-solenoid valve</li> </ul>
OXYGEN SEN	<ul style="list-style-type: none"> <li>The heated oxygen sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.)</li> </ul>	<ul style="list-style-type: none"> <li>Harness and connector</li> <li>Heated oxygen sensor</li> <li>Fuel pressure</li> <li>Injectors</li> <li>Intake air leaks</li> </ul>
KNOCK SENSOR	<ul style="list-style-type: none"> <li>The knock sensor circuit is open or shorted. (An abnormally high or low voltage is entered.)</li> </ul>	<ul style="list-style-type: none"> <li>Harness and connector</li> <li>Knock sensor</li> </ul>
EGR TEMP SENSOR	<ul style="list-style-type: none"> <li>The EGR temperature sensor circuit is open or shorted. (An abnormally high or low voltage is entered.)</li> </ul>	<ul style="list-style-type: none"> <li>Harness and connector</li> <li>EGR temperature sensor</li> </ul>
THROTTLE POSI SEN	<ul style="list-style-type: none"> <li>The throttle position sensor circuit is open or shorted. (An abnormally high or low voltage is entered.)</li> </ul>	<ul style="list-style-type: none"> <li>Harness and connector</li> <li>Throttle position sensor</li> </ul>
INJECTOR-LEAK	<ul style="list-style-type: none"> <li>Fuel leaks from injector.</li> </ul>	<ul style="list-style-type: none"> <li>Injector</li> </ul>
INJECTOR-OPEN	<ul style="list-style-type: none"> <li>The injector circuit is open.</li> </ul>	<ul style="list-style-type: none"> <li>Injector</li> </ul>
A/T COMM LINE	<ul style="list-style-type: none"> <li>The A/T communication line is open or shorted.</li> </ul>	<ul style="list-style-type: none"> <li>Harness and connector</li> </ul>

GI

MA

EM

LC

EF &  
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX

\*: Check items causing a malfunction of camshaft position sensor circuit first, if both "CRANK POSITION SEN" and "IGN SIGNAL—PRIMARY" are displayed at the same time.

**Consult (Cont'd)**

**DATA MONITOR MODE**

Remarks: ● The monitor item marked "\*" is applicable to M/T models only.

● Specification data are reference values.

● Specification data are out-put/in-put values which are detected or supplied by ECM at the connector.

\* Specification data may not be directly related to their components signals/values/operations.

ie. Adjust ignition timing with a timing light before monitoring IGN TIMING, because the monitor may show the specification data in spite of the ignition timing being not adjusted to the specification data. This IGN TIMING monitors the calculated data by ECM according to the input signals from camshaft position sensor and other ignition timing related sensors.

MONITOR ITEM	CONDITION		SPECIFICATION	CHECK ITEM WHEN OUTSIDE SPEC.
CMPS RPM (POS)	● Tachometer: Connect ● Run engine and compare tachometer indication with the CONSULT value.		Almost the same speed as the CONSULT value.	● Harness and connector ● Camshaft position sensor
CMPS RPM (REF)				
MAS AIR/FL SE	● Engine: After warming up, idle the engine ● A/C switch "OFF" ● Shift lever "N" ● No-load	Idle	0.8 - 1.5V	● Harness and connector ● Mass air flow sensor
		2,000 rpm	1.4 - 1.8V	
COOLANT TEMP/S	● Engine: After warming up		More than 70°C (158°F)	● Harness and connector ● Engine coolant temperature sensor
OXYGEN SEN	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ 0.6 - 1.0V	● Harness and connector ● Heated oxygen sensor ● Intake air leaks ● Injectors
M/R F/C MNT			LEAN ↔ RICH Changes more than 5 times during 10 seconds.	
VHCL SPEED SE	● Turn drive wheels and compare speedometer indication with the CONSULT value		Almost the same speed as the CONSULT value	● Harness and connector ● Vehicle speed sensor
BATTERY VOLT	● Ignition switch: ON (Engine stopped)		11 - 14V	● Battery ● ECM power supply circuit
THRTL POS SEN	● Ignition switch: ON (Engine stopped)	Throttle valve fully closed	0.4 - 0.5V	● Harness and connector ● Throttle position sensor ● Throttle position sensor adjustment
		Throttle valve fully opened	Approx. 4.0V	
EGR TEMP SEN	● Engine: After warming up		Less than 4.5V	● Harness and connector ● EGR temperature sensor
START SIGNAL	● Ignition switch: ON → START		OFF → ON	● Harness and connector ● Starter switch
CLOSED TH/POS	● Ignition switch: ON (Engine stopped)	Throttle valve: Idle position	ON	● Harness and connector ● Throttle position sensor ● Throttle position sensor adjustment
		Throttle valve: Slightly open	OFF	
AIR COND SIG	● Engine: After warming up, idle the engine	A/C switch "OFF"	OFF	● Harness and connector ● Air conditioner switch
		A/C switch "ON"	ON	

# TROUBLE DIAGNOSES

VE30DE

## Consult (Cont'd)

MONITOR ITEM	CONDITION	SPECIFICATION	CHECK ITEM WHEN OUTSIDE SPEC.	
NEUT POSI SW	● Ignition switch: ON	Shift lever "P" or "N"	ON	● Harness and connector ● Neutral position switch
		Except above	OFF	
PW/ST SIGNAL	● Engine: After warming up, idle the engine	Steering wheel in neutral position (forward direction)	OFF	● Harness and connector ● Power steering oil pressure switch
		The steering wheel is turned	ON	
INJ PULSE	● Engine: After warming up ● A/C switch "OFF" ● Shift lever "N" ● No-load	Idle	2.0 - 3.0 msec.	● Harness and connector ● Injector ● Mass air flow sensor ● Intake air system
		2,000 rpm	1.8 - 2.8 msec.	
IGN TIMING	ditto	Idle	15° BTDC	● Harness and connector ● Camshaft position sensor
		2,000 rpm	More than 25° BTDC	
IACV-AAC/V	ditto	Idle	15 - 40%	● Harness and connector ● IACV-AAC valve
		2,000 rpm	—	
FUEL PUMP RLY	● Ignition switch is turned to ON (Operates for 5 seconds) ● Engine running and cranking ● When engine is stopped (stops in 1.5 seconds)		ON	● Harness and connector ● Fuel pump relay
		Except as shown above	OFF	
COOLING FAN	● After warming up engine, idle the engine. ● A/C switch "OFF"	Engine coolant temperature is 94°C (201°F) or less	OFF	● Harness and connector ● Cooling fan relay ● Cooling fan
		Engine coolant temperature is between 95°C (203°F) and 104°C (219°F)	LOW	
		Engine coolant temperature is 105°C (221°F) or more	HIGH	
A/F ALPHA	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	75 - 125%	● Harness and connector ● Injectors ● Mass air flow sensor ● Heated oxygen sensor ● Canister purge line ● Intake air system
AIR COND RLY	● Air conditioner switch OFF → ON		OFF → ON	● Harness and connector ● Air conditioner switch ● Air conditioner relay
EGRC SOL/V	● Engine: After warming up ● A/C switch: "OFF" ● Shift lever "N" ● No-load	Idle	ON	● Harness and connector ● EGRC-solenoid valve
		2,000 rpm	OFF	

# TROUBLE DIAGNOSES

VE30DE

## Consult (Cont'd)

MONITOR ITEM	CONDITION	SPECIFICATION	CHECK ITEM WHEN OUTSIDE SPEC.
VALVE TIM SOL	<ul style="list-style-type: none"> <li>● Jack up front wheel</li> <li>● Engine: After warming up</li> </ul>	<ul style="list-style-type: none"> <li>● Idle</li> </ul>	OFF
		<ul style="list-style-type: none"> <li>● Shift select lever to any range except "N" or "P" range</li> <li>● Quickly depress accelerator pedal, then quickly release it.</li> </ul>	OFF → ON → OFF
VIAS S/V*	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> </ul>	<ul style="list-style-type: none"> <li>● Idle</li> </ul>	OFF
		<ul style="list-style-type: none"> <li>● Quickly depress accelerator pedal, then quickly release it</li> </ul>	OFF → ON → OFF

**Consult (Cont'd)**

**FUNCTION TEST MODE**

FUNCTION TEST ITEM	CONDITION	JUDGEMENT		CHECK ITEM (REMEDY)	
SELF-DIAG RESULTS	<ul style="list-style-type: none"> <li>● Ignition switch: ON (Engine stopped)</li> <li>● Displays the results of self-diagnosis.</li> </ul>	—		Objective system	GI
CLOSED THROTTLE POSI	<ul style="list-style-type: none"> <li>● Ignition switch: ON (Engine stopped)</li> <li>● Closed throttle position switch circuit is tested when throttle is opened and closed fully. ("IDLE POSITION" is the test item name for the vehicles in which idle is selected by throttle position sensor.)</li> </ul>	Throttle valve: opened	OFF	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Throttle position sensor (Closed throttle position switch)</li> <li>● Throttle position sensor (Closed throttle position switch) adjustment</li> <li>● Throttle linkage</li> <li>● Verify operation in DATA MONITOR mode.</li> </ul>	MA
		Throttle valve: closed	ON		EM
THROTTLE POSI SEN CKT	<ul style="list-style-type: none"> <li>● Ignition switch: ON (Engine stopped)</li> <li>● Throttle position sensor circuit is tested when throttle is opened and closed fully.</li> </ul>	Range (Throttle valve fully opened — Throttle valve fully closed)	More than 3.0V	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Throttle position sensor</li> <li>● Throttle position sensor adjustment</li> <li>● Throttle linkage</li> <li>● Verify operation in DATA MONITOR mode.</li> </ul>	LC
NEUTRAL POSI SW CKT	<ul style="list-style-type: none"> <li>● Ignition switch: ON (Engine stopped)</li> <li>● Neutral position switch circuit is tested when shift lever is manipulated.</li> </ul>	OUT OF N/P-RANGE	OFF	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Neutral position switch/ inhibitor switch</li> <li>● Linkage + Inhibitor switch adjustment</li> </ul>	FE
		IN N-RANGE	ON		CL
FUEL PUMP CIRCUIT	<ul style="list-style-type: none"> <li>● Ignition switch: ON (Engine stopped)</li> <li>● Fuel pump circuit is tested by checking the pulsation in fuel pressure when fuel tube is pinched.</li> </ul>	There is pressure pulsation on the fuel feed hose.		<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Fuel pump</li> <li>● Fuel pump relay</li> <li>● Fuel filter clogging</li> <li>● Fuel level</li> </ul>	MT
EGRC SOL/V CIRCUIT	<ul style="list-style-type: none"> <li>● Ignition switch: ON (Engine stopped)</li> <li>● EGR control S/V circuit is tested by checking solenoid valve operating noise.</li> </ul>	The solenoid valve makes an operating sound every 3 seconds.		<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● EGRC-solenoid valve</li> </ul>	AT
VALVE TIMING S/V CKT	<ul style="list-style-type: none"> <li>● Ignition switch: ON (Engine stopped)</li> <li>● Valve timing S/V circuit is tested by checking solenoid valve operating noise.</li> </ul>	The solenoid valve makes an operating sound every 3 seconds.		<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Valve timing solenoid valve</li> </ul>	FA
COOLING FAN CIRCUIT	<ul style="list-style-type: none"> <li>● Ignition switch: ON (Engine stopped)</li> <li>● Cooling fan circuit is tested by rotating and stopping cooling fan.</li> </ul>	The cooling fans rotate and stop every 3 seconds.		<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Cooling fan relays</li> <li>● Cooling fan motors</li> </ul>	RA

GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

**Consult (Cont'd)**

FUNCTION TEST ITEM	CONDITION	JUDGEMENT		CHECK ITEM (REMEDY)
START SIGNAL CIRCUIT	<ul style="list-style-type: none"> <li>● Ignition switch: ON → START</li> <li>● Start signal circuit is tested when engine is started by operating the starter. Battery voltage and coolant temperature before cranking, and average battery voltage, mass air flow sensor output voltage and cranking speed during cranking are displayed.</li> </ul>	Start signal: OFF → ON		<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Ignition switch</li> </ul>
PW/ST SIGNAL CIRCUIT	<ul style="list-style-type: none"> <li>● Ignition switch: ON (Engine running)</li> <li>● Power steering circuit is tested when steering wheel is rotated fully and then set to a straight line running position.</li> </ul>	Locked position	ON	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Power steering oil pressure switch</li> <li>● Power steering oil pump</li> </ul>
		Neutral position	OFF	
VIAS S/V CIRCUIT	<ul style="list-style-type: none"> <li>● Ignition switch: ON (Engine stopped)</li> <li>● Power valve control solenoid valve circuit is tested by checking solenoid valve operating noise.</li> </ul>	The solenoid valve makes an operating sound every 3 seconds.		<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Power valve control solenoid valve</li> </ul>
VEHICLE SPEED SEN CKT	<ul style="list-style-type: none"> <li>● Vehicle speed sensor circuit is tested when vehicle is running at a speed of 10 km/h (6 mph) or higher.</li> </ul>	Vehicle speed sensor input signal is greater than 4 km/h (2 MPH)		<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Vehicle speed sensor</li> <li>● Electric speedometer</li> </ul>
IGN TIMING ADJ	<ul style="list-style-type: none"> <li>● After warming up, idle the engine.</li> <li>● Ignition timing adjustment is checked by reading ignition timing with a timing light and checking whether it agrees with specifications.</li> </ul>	The timing light indicates the same value on the screen.		<ul style="list-style-type: none"> <li>● Adjust ignition timing (by moving camshaft position sensor or distributor)</li> <li>● Camshaft position sensor drive mechanism</li> </ul>
MIXTURE RATIO TEST	<ul style="list-style-type: none"> <li>● Air-fuel ratio feedback circuit (injection system, ignition system, vacuum system, etc.) is tested by examining the heated oxygen sensor output at 2,000 rpm under non-loaded state.</li> </ul>	<ul style="list-style-type: none"> <li>● O<sub>2</sub> SEN COUNT: More than 5 times during 10 seconds (O<sub>2</sub> SEN-R COUNT: More than 5 times during 10 seconds)</li> </ul>		<ul style="list-style-type: none"> <li>● INJECTION SYS (Injector, fuel pressure regulator, harness or connector)</li> <li>● IGNITION SYS (Spark plug, power transistor, ignition coil, harness or connector)</li> <li>● VACUUM SYS (Intake air leaks)</li> <li>● Heated oxygen sensor circuit</li> <li>● Heated oxygen sensor operation</li> <li>● Fuel pressure high or low</li> <li>● Mass air flow sensor</li> </ul>



Consult (Cont'd)

FUNCTION TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
POWER BALANCE	<ul style="list-style-type: none"> <li>● After warming up, idle the engine.</li> <li>● Injector operation of each cylinder is stopped one after another, and resultant change in engine rotation is examined to evaluate combustion of each cylinder. (This is only displayed for models where a sequential multipoint fuel injection system is used.)</li> </ul>	Difference in engine speed is greater than 25 rpm before and after cutting off the injector of each cylinder.	<ul style="list-style-type: none"> <li>● Injector circuit (Injector, harness or connector)</li> <li>● Ignition circuit (Spark plug, power transistor, ignition coil, harness or connector)</li> <li>● Compression</li> <li>● Valve timing</li> </ul>
IACV-AAC/V SYSTEM	<ul style="list-style-type: none"> <li>● After warming up, idle the engine.</li> <li>● IACV-AAC valve system is tested by detecting change in engine speed when IACV-AAC valve opening is changed to 0%, 20% and 80%.</li> </ul>	Difference in engine speed is greater than 150 rpm between when valve opening is at 80% (102 steps) and at 20% (25 steps).	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● IACV-AAC valve</li> <li>● Air passage restriction between air inlet and IACV-AAC valve</li> <li>● IAS (Idle adjusting screw) adjustment</li> </ul>

GI

MA

EV

LC

**EF & EC**

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL


IDX

## Consult (Cont'd)

## ACTIVE TEST MODE

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
FUEL INJECTION	<ul style="list-style-type: none"> <li>● Engine: Return to the original trouble condition</li> <li>● Change the amount of fuel injection with the CONSULT.</li> </ul>	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Fuel injectors</li> <li>● Heated oxygen sensors</li> </ul>
IACV-AAC/V OPENING	<ul style="list-style-type: none"> <li>● Engine: After warming up, idle the engine.</li> <li>● Change the IACV-AAC valve opening percent with the CONSULT.</li> </ul>	Engine speed changes according to the opening percent.	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● IACV-AAC valve</li> </ul>
ENG COOLANT TEMP	<ul style="list-style-type: none"> <li>● Engine: Return to the original trouble condition</li> <li>● Change the engine coolant temperature with the CONSULT.</li> </ul>	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Engine coolant temperature sensor</li> <li>● Fuel injectors</li> </ul>
IGN TIMING	<ul style="list-style-type: none"> <li>● Engine: Return to the original trouble condition</li> <li>● Timing light: Set</li> <li>● Retard the ignition timing with the CONSULT.</li> </ul>	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> <li>● Adjust initial ignition timing</li> </ul>
POWER BALANCE	<ul style="list-style-type: none"> <li>● Engine: After warming up, idle the engine.</li> <li>● A/C switch "OFF"</li> <li>● Shift lever "N"</li> <li>● Cut off each injector signal one at a time with the CONSULT.</li> </ul>	Engine runs rough or dies.	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Compression</li> <li>● Injectors</li> <li>● Power transistor</li> <li>● Spark plugs</li> <li>● Ignition coils</li> </ul>
COOLING FAN	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> <li>● Turn the cooling fan "ON" and "OFF" with the CONSULT.</li> </ul>	Cooling fan moves and stops.	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Cooling fan motor</li> </ul>
FUEL PUMP RELAY	<ul style="list-style-type: none"> <li>● Ignition switch: ON (Engine stopped)</li> <li>● Turn the fuel pump relay "ON" and "OFF" with the CONSULT and listen to operating sound.</li> </ul>	Fuel pump relay makes the operating sound.	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Fuel pump relay</li> </ul>
EGRC SOLENOID VALVE	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> <li>● Turn solenoid valve "ON" and "OFF" with the CONSULT and listen to operating sound.</li> </ul>	Each solenoid valve makes an operating sound.	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Solenoid valve</li> </ul>
VIAS SOL VALVE (Power valve)*			
VALVE TIMING SOL			
SELF-LEARNING CONT	<ul style="list-style-type: none"> <li>● In this test, the coefficient of self-learning control mixture ratio returns to the original coefficient by touching "CLEAR" on the screen.</li> </ul>		

\*: M/T models only



**Diagnostic Procedure**

**CAUTION:**

1. Before connecting or disconnecting the ECM harness connector to or from any ECM, be sure to turn the ignition switch to the "OFF" position and disconnect the negative battery terminal in order not to damage ECM as battery voltage is applied to ECM even if ignition switch is turned off. Failure to do so may damage the ECM.

GI

MA

EM

LC

EF & EC

FE

CL

WT

AT

FA

RA

BR


ST

BF


HA

EL


IDX




2. When connecting ECM harness connector, tighten securing bolt until red projection is in line with connector face.



3. When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break).
4. Make sure that there are not any bends or breaks on ECM pin terminal, when connecting pin connectors.




5. Before replacing ECM, perform ECM input/output signal inspection and make sure whether ECM functions properly or not. (See page EF & EC-319.)







6. After performing this "Diagnostic Procedure", perform on-board diagnostic system and driving test.

## Diagnostic Procedure (Cont'd)



7. When measuring ECM controlled components supply voltage with a circuit tester, separate one tester probe from the other.

If the two tester probes accidentally make contact with each other during measurement, the circuit will be shorted, resulting in damage to the ECM power transistor.



**Basic Inspection**

**1**

**BEFORE STARTING**

1. Check service records for any recent repairs that may indicate a related problem, or the current need for scheduled maintenance.
2. Open engine hood and check the following:
  - Harness connectors for proper connections
  - Vacuum hoses for splits, kinks, and proper connections
  - Wiring for proper connections, pinches, and cuts

**2**

**CONNECT CONSULT TO THE VEHICLE**  
 Connect "CONSULT" to the data link connector for CONSULT and select "ENGINE" from the menu. (Refer to page EF & EC-201.)

**3**

**DOES ENGINE START?**

No → Go to **6**.

Yes →

**4**

**CHECK IGNITION TIMING.**  
 Warm up engine sufficiently and check ignition timing at idle using timing light. (Refer to page EF & EC-182.)  
**Ignition timing: 15° ± 2° BTDC**

NG → Adjust ignition timing by turning camshaft position sensor.

OK →

(Go to **A** on next page.)

GI  
 MA  
 EM  
 LC  
**EF & EC**  
 FE  
 CL  
 IMT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX

Basic Inspection (Cont'd)


**5** ■ IACV-AAC/V ADJ ■ □

SET ENGINE RPM AT THE SPECIFIED VALUE UNDER THE FOLLOWING CONDITION

- ENG WARMED UP
- NO LOAD

START

MEF379D



**6** ■ THRTL POS SEN ADJ ■

\*\*\* ADJ MONITOR \*\*\*


THRTL POS SEN 0.50V

=== MONITOR ===

CMPS-RPM (REF) 0rpm

CLOSED TH/POS ON

SEF484N



**5**

Ⓐ

**CHECK IDLE ADJ. SCREW INITIAL SET RPM.**

1. Select "IACV-AAC/V ADJ" in "WORK SUPPORT" mode.

2. When touching "START", does engine speed fall to  $700 \pm 50$  rpm (in "N" position)?

OR

When disconnecting IACV-AAC valve harness connector, does engine speed fall to  $700 \pm 50$  rpm (in "N" position)?

No → Adjust engine speed by turning idle speed adjusting screw.

**6**

**CHECK THROTTLE POSITION SENSOR IDLE POSITION.**

1. Perform "THRTL POS SEN ADJ" in "WORK SUPPORT" mode.

2. Check that output voltage of throttle position sensor is 0.4 to 0.5V. (Throttle valve fully closes.) and "CLOSED TH/POS" stays "ON".

OR

Measure output voltage of throttle position sensor using voltmeter, and check that it is 0.4 to 0.5V. (Throttle valve fully closed.)

NG → 1. Adjust output voltage by rotating throttle position sensor body.  
2. Disconnect throttle position sensor harness connector for a few seconds and then reconnect it.  
3. Confirm that "CLOSED TH/POS" stays "ON".

OK

(Go to Ⓑ on next page.)

Basic Inspection (Cont'd)


**7**

☆ MONITOR ☆ NO FAIL

START SIGNAL	OFF
CLOSED TH/POS	ON
AIR COND SIG	OFF
NEUT POSI SW	ON

RECORD

MEF382D



**8**

■ SELF-DIAG RESULTS ■


FAILURE DETECTED TIME

\* NO SELF DIAGNOSTIC FAILURE INDICATED.

FURTHER TESTING MAY BE REQUIRED. \*\*

ERASE PRINT

SEF227L



**7**

**CHECK SWITCH INPUT SIGNAL.**

Select the following items in "DATA MONITOR" mode,

- START SIGNAL,
- CLOSED TH/POS,
- AIR COND SIG,
- NEUT POSI SW,

and check the switches' ON-OFF operation.

NG → Repair or replace the malfunctioning switch or its circuit.

OR

Remove ECM from front floor panel and check the above switches' ON-OFF operation using voltmeter at each ECM terminal.

Switch	Condition	Voltage (V)
Start signal	IGN ON → IGN START	0 → Battery voltage
Idle position	Engine warmed up sufficiently Idle position → Depress the accelerator pedal.	0.4 - 0.5 → Approx. 4.0
A/C signal	A/C OFF → A/C ON (Engine running)	Battery voltage → Approx. 0.2
Neutral position (Parking) switch	Shift lever is "N" or "P" position → Except "N" and "P"	0 → 4.0 - 5.0

**8**

**READ SELF-DIAGNOSTIC RESULTS.**

- Perform "SELF-DIAG RESULTS" mode.
- Read out self-diagnostic results.
- Is a failure detected?

Yes → Go to the relevant inspection procedure.


OR

- Set "Self-diagnostic results mode" in Diagnostic Test Mode II. (Refer to page EF & EC-199.)
- Count the number of RED LED or malfunction indicator lamp flashes and read out the diagnostic trouble codes.
- Are the diagnostic trouble codes being output?

No

INSPECTION END

GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX



### Diagnostic Procedure 1 — High Idling after Warm-up

**1**

**CHECK IAA UNIT.**

When pinching the IAA unit hose, does the engine speed drop?

Yes

Check IACV-air regulator, IACV-AAC valve and circuit.

No

**2**

**CHECK INTAKE AIR LEAK.**

1. Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode.
2. Clear the self-learning control coefficient by touching "CLEAR".
3. Does the engine speed drop?

Yes

Discover air leak location and repair.

OR

1. Disconnect heated oxygen sensor harness connector.
2. After racing engine at 1,500 rpm under no load for about 30 seconds, does the engine speed drop?

No

**3**

**CHECK THROTTLE LINKAGE.**




1. Check that throttle linkage moves smoothly.
2. Confirm that throttle valve both fully opens and fully closes.

NG

Repair throttle linkage or sticking of throttle valve.


OK

INSPECTION END






Diagnostic Procedure 2 — Hunting



**1**  
**CHECK HEATED OXYGEN SENSOR.**  
 When disconnecting heated oxygen sensor harness connector, is the hunting fixed?

Yes → Check heated oxygen sensor. (See page EF & EC-272.)

No




**2**  
**PERFORM POWER BALANCE TEST.**  
 1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.  
 2. Is there any cylinder which does not produce a momentary engine speed drop?

No → Go to **4**.



OR  
 When disconnecting each ignition coil harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

Yes




**3**  
**CHECK SPARK PLUGS.**  
 Remove the spark plugs and check for fouling, etc.

NG → Repair or replace spark plug(s).


OK

(Go to **A** on next page.)



GI  
 MA  
 EM  
 LC  
**EF & EC**  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX


Diagnostic Procedure 2 — Hunting (Cont'd)



**4**

**CHECK FOR INTAKE AIR LEAK.**  
When pinching blow-by hose (lowering the blow-by air supply), does the engine speed rise?

Yes → Discover air leak location and repair.




**5**

**CHECK EGR VALVE**  
Check EGR valve for sticking.


NG → Repair or replace.

OK → INSPECTION END


Diagnostic Procedure 3 — Unstable Idle




SEC547A




SEF607N




SEF649L



SEF650L




SEF651L



GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX


Diagnostic Procedure 3 — Unstable Idle (Cont'd)



**5**

**CHECK SPARK PLUGS.**  
Remove the spark plugs and check for fouling, etc.


NG → Repair or replace spark plug(s).



**6**

**CHECK FUEL PRESSURE.**  
1. Release fuel pressure to zero. (Refer to page EF & EC-333.)  
2. Install fuel pressure gauge and check fuel pressure.  
**At idle:**  
**Approx. 245 kPa (2.5 kg/cm<sup>2</sup>, 36 psi)**

NG → Check fuel pump and circuit.




**7**

**CHECK HEATED OXYGEN SENSOR.**

- See "M/R F/C MNT" in "DATA MONITOR" mode.
- Maintaining engine at 2,000 rpm under no-load (engine is warmed up sufficiently.), check that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds.  
**RICH → LEAN → RICH →**  
**1 time            2 times**  
**LEAN → RICH.....**  
**OR**

NG → Replace heated oxygen sensor.




- Set "Heated oxygen sensor monitor" in the Self-diagnostic Test Mode II. (See page EF & EC-201.)
- Maintaining engine at 2,000 rpm under no-load, check to make sure that the RED LED on the ECM or the malfunction indicator lamp on the instrument panel goes ON and OFF more than 5 times during 10 seconds.

OK →

**8**





**CHECK FOR INTAKE AIR LEAK.**  
When pinching blow-by hose (lowering the blow-by air supply), does the engine speed rise?

Yes → Discover air leak location and repair.




No → (Go to ⑥ on next page.)

Diagnostic Procedure 3 — Unstable Idle (Cont'd)



GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
VT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

\*: ECM may be the cause of a problem, but this is rarely the case.



**Diagnostic Procedure 4 — Hard to Start or Impossible to Start when the Engine is Cold**

**1**

**CHECK BATTERY AND STARTER.**  
Check battery and starter condition.  
(Refer to EL section.)

NG → Repair or replace.

OK

**2**

**CHECK FUEL PRESSURE.**  
1. Pinch fuel feed hose with fingers.  
2. When cranking the engine, is there any pressure on the fuel feed hose?

No → Check fuel pump and circuit. (See page EF & EC-302.)

Yes

**3**

**CHECK IACV-AIR REGULATOR AND IACV-AAC VALVE.**  
When pressing accelerator pedal fully, can you start the engine.

Yes → Check IACV-AAC valve, IACV-air regulator and circuit. (See pages EF & EC-305.)

No

**4**

**CHECK INJECTOR.**  
1. Remove camshaft position sensor from engine. (Harness connector should remain connected.)  
2. Disconnect power transistor harness connector.  
3. Turn ignition switch ON. (Do not start engine.)  
4. When rotating camshaft position sensor shaft, does each injector make an operating sound?

No → Check injector(s) and circuit(s).

Yes





**5**

**CHECK IGNITION SPARK.**  
1. Disconnect ignition coil assembly from collector.  
2. Connect a known good spark plug to the ignition coil assembly.  
3. Place end of spark plug against a suitable ground and crank engine.  
4. Check for spark.


NG → Check ignition coil, power transistor unit and their circuits. (See page EF & EC-264.)

OK


(Go to Ⓐ on next page.)



**Diagnostic Procedure 4 — Hard to Start or Impossible to Start when the Engine is Cold (Cont'd)**




SEF156I




\*: ECM may be the cause of a problem, but this is rarely the case.


**Diagnostic Procedure 5 — Hard to Start or Impossible to Start when the Engine is Hot**






SEF654L



SEF655L




**Diagnostic Procedure 5 — Hard to Start or Impossible to Start when the Engine is Hot (Cont'd)**



\*: ECM may be the cause of a problem, but this is rarely the case.




**Diagnostic Procedure 6 — Hard to Start or Impossible to Start under Normal Conditions**



**1**  
**CHECK BATTERY AND STARTER.**  
 Check battery and starter operation. (Refer to EL section.)

NG → Repair or replace.


OK



**2**  
**CHECK FUEL PRESSURE.**  
 1. Pinch fuel feed hose with fingers.  
 2. When cranking the engine, is there any pressure on the fuel feed hose?

No → Check fuel pump and circuit. (See page EF & EC-302.)


Yes



**3**  
**CHECK INJECTOR FOR LEAKAGE.**  
 When pressing accelerator pedal fully, can you start the engine.

Yes → Check injector(s) for leakage.


No



**4**  
**CHECK INJECTOR.**  
 1. Remove camshaft position sensor from engine. (Harness connector should remain connected.)  
 2. Disconnect power transistor harness connector.  
 3. Turn ignition switch ON. (Do not start engine.)  
 4. When rotating camshaft position sensor shaft, does each injector make an operating sound?

No → Check injectors and circuits.

Yes



**5**  
**CHECK IGNITION SPARK.**  
 1. Disconnect ignition coil assembly from collector.  
 2. Connect a known good spark plug to the ignition coil assembly.  
 3. Place end of spark plug against a suitable ground and crank engine.  
 4. Check for spark.




NG → Check ignition coil, power transistor unit and circuits. (See page EF & EC-264.)

OK



(Go to ① on next page.)

GI  
 MA  
 EM  
 LC  
**EF & EC**  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX


**Diagnostic Procedure 6 — Hard to Start or Impossible to Start under Normal Conditions (Cont'd)**





\*: ECM may be the cause of a problem, but this is rarely the case.



**Diagnostic Procedure 7 — Hesitation when the Engine is Hot**






**Diagnostic Procedure 7 — Hesitation when the Engine is Hot (Cont'd)**




GI  
MA  
EM  
LC  
EF & EC


**Diagnostic Procedure 8 — Hesitation when the Engine is Cold**




FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX




SEF156I




MEF225F



MEF377DA




SMA486C




SEF648L

**Diagnostic Procedure 9 — Hesitation under Normal Conditions**



**Diagnostic Procedure 10 — Engine Stalls when Turning**




**1**

**CHECK FUEL LEVEL.**  
Check to see that there is enough fuel in tank.

NG → Fill fuel tank with fuel.

OK

**2**




**PERFORM POWER BALANCE TEST.**  
1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.  
2. Is there any cylinder which does not produce a momentary engine speed drop?

No → Go to 5.

OR  
When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

Yes




**3**

**CHECK INJECTOR.**  
1. Remove camshaft position sensor from engine. (Harness connector should remain connected.)  
2. Disconnect power transistor harness connector.  
3. Turn ignition switch ON. (Do not start engine.)  
4. When rotating camshaft position sensor shaft, does each injector make an operating sound?

No → Check injector(s) and circuit(s).

Yes




**4**

**CHECK IGNITION SPARK.**  
1. Disconnect ignition coil assembly from collector.  
2. Connect a known good spark plug to the ignition coil assembly.  
3. Place end of spark plug against a suitable ground and crank engine.  
4. Check for spark.

NG → Check ignition coil, power transistor unit and circuits. (See page EF & EC-264.)



OK

(Go to A on next page.)




GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
WTF  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

## Diagnostic Procedure 10 — Engine Stalls when Turning (Cont'd)



\*: ECM may be the cause of a problem, but this is rarely the case.

**Diagnostic Procedure 11 — Engine Stalls when the Engine is Hot**




**1**

**CHECK FUEL VAPOR.**

1. Disconnect fuel pressure regulator vacuum hose and plug hose.
2. Perform cruise test.
3. Does the engine stall disappear?

Yes → Check fuel properties.

No



**2**

**PERFORM POWER BALANCE TEST.**

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Is there any cylinder which does not produce a momentary engine speed drop?




OR

When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

No → Go to 5.

Yes



**3**


**CHECK INJECTOR.**

1. Remove camshaft position sensor from engine. (Harness connector should remain connected.)
2. Disconnect power transistor harness connector.
3. Turn ignition switch ON. (Do not start engine.)
4. When rotating camshaft position sensor shaft, does each injector make an operating sound?

No → Check injector(s) and circuit(s).




Yes

(Go to A on next page.)



GI  
MA  
EW  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX


Diagnostic Procedure 11 — Engine Stalls when the Engine is Hot (Cont'd)



\*: ECM may be the cause of a problem, but this is rarely the case.



**Diagnostic Procedure 12 — Engine Stalls when the Engine is Cold**




**1**

**CHECK IACV-AIR REGULATOR AND IACV-AAC VALVE.**

When the engine is cold, can you start the engine when pressing accelerator pedal fully?

NG → Check IACV-AAC valve, IACV-air regulator and circuit. (See page EF & EC-305.)

OK



**2**

**PERFORM POWER BALANCE TEST.**


1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Is there any cylinder which does not produce a momentary engine speed drop?

OR

When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

NG → Go to **6**.

OK




**3**

**CHECK INJECTOR.**

1. Remove camshaft position sensor from engine. (Harness connector should remain connected.)
2. Disconnect power transistor harness connector.
3. Turn ignition switch ON. (Do not start engine.)
4. When rotating camshaft position sensor shaft, does each injector make an operating sound?

NG → Check injector(s) and circuit(s).

OK



**4**


**CHECK IGNITION SPARK.**

1. Disconnect ignition coil assembly from collector.
2. Connect a known good spark plug to the ignition coil assembly.
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.

NG → Check ignition coil, power transistor unit and circuits. (See page EF & EC-264.)




OK

(Go to **A** on next page.)









GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 12 — Engine Stalls when the Engine is Cold (Cont'd)






\*: ECM may be the cause of a problem, but this is rarely the case.

**Diagnostic Procedure 13 — Engine Stalls when Stepping on the Accelerator Momentarily**








GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

**Diagnostic Procedure 13 — Engine Stalls when Stepping on the Accelerator Momentarily (Cont'd)**




\*: ECM may be the cause of a problem, but this is rarely the case.

### Diagnostic Procedure 14 — Engine Stalls after Decelerating



GI  
MA  
EM  
LC  
EF & EC  
EF  
CL  
MIT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 14 — Engine Stalls after Decelerating (Cont'd)



**3**


**PERFORM POWER BALANCE TEST.**

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Is there any cylinder which does not produce a momentary engine speed drop?

OR

When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

No → Go to **6**




**4**

**CHECK INJECTOR.**

1. Remove camshaft position sensor from engine. (Harness connector should remain connected.)
2. Disconnect power transistor harness connector.
3. Turn ignition switch ON. (Do not start engine.)
4. When rotating camshaft position sensor shaft, does each injector make an operating sound?

No → Check injector(s) and circuit(s).




**5**

**CHECK IGNITION SPARK.**

1. Disconnect ignition coil assembly from collector.
2. Connect a known good spark plug to the ignition coil assembly.
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.

NG → Check ignition coil, power transistor unit and circuits. (See page EF & EC-264.)



**6**


**CHECK FUEL PRESSURE.**

1. Release fuel pressure to zero. (Refer to page EF & EC-333.)
2. Install fuel pressure gauge and check fuel pressure.

**At idle:**  
 Approx. 245 kPa (2.5 kg/cm<sup>2</sup>, 36 psi)

**A few seconds after ignition switch is turned OFF to ON:**  
 Approx. 294 kPa (3.0 kg/cm<sup>2</sup>, 43 psi)

NG → Check fuel pressure regulator diaphragm.



OK → **B**

Diagnostic Procedure 14 — Engine Stalls after Decelerating (Cont'd)

**7**

☆ MONITOR ☆ NO FAIL

CMPS•RPM(POS) 2000rpm  
M/R F/C MNT LEAN

RECORD

MEF225F


**7**

RED LED

CHECK

Malfunction indicator lamp


MEF377DA



GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
DX

\*: ECM may be the cause of a problem, but this is rarely the case.

**Diagnostic Procedure 15 — Engine Stalls when Accelerating or Cruising**




**1**

**PERFORM POWER BALANCE TEST.**

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.

2. Is there any cylinder which does not produce a momentary engine speed drop?


No → Go to **4**.



OR

When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

Yes →



**2**

**CHECK INJECTOR.**

1. Remove camshaft position sensor from engine. (Harness connector should remain connected.)


2. Disconnect power transistor harness connector.

3. Turn ignition switch ON. (Do not start engine.)

4. When rotating camshaft position sensor shaft, does each injector make an operating sound?

No → Check injector(s) and circuit(s).

Yes →



**3**

**CHECK IGNITION SPARK.**

1. Disconnect ignition coil assembly from collector.

2. Connect a known good spark plug to the ignition coil assembly.

3. Place end of spark plug against a suitable ground and crank engine.

4. Check for spark.




NG → Check ignition coil, power transistor unit and circuits. (See page EF & EC-264.)

OK →

(Go to **A** on next page.)




Diagnostic Procedure 15 — Engine Stalls when Accelerating or Cruising (Cont'd)



GI  
 MA  
 EM  
 LC  
**EF & EC**  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX

\*: ECM may be the cause of a problem, but this is rarely the case.


**Diagnostic Procedure 16 — Engine Stalls when the Electrical Load is Heavy**



**1**  
**CHECK BATTERY AND ALTERNATOR.**  
 Check battery and alternator condition. (Refer to EL section.)

NG → Repair or replace.

OK



**2**  
**PERFORM POWER BALANCE TEST.**




1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Is there any cylinder which does not produce a momentary engine speed drop?

No → Go to **5**.



OR  
 When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

Yes




**3**  
**CHECK INJECTOR.**

1. Remove camshaft position sensor from engine. (Harness connector should remain connected.)
2. Disconnect power transistor harness connector.
3. Turn ignition switch ON. (Do not start engine.)
4. When rotating camshaft position sensor shaft, does each injector make an operating sound?

No → Check injector(s) and circuit(s).

Yes




**4**  
**CHECK IGNITION SPARK.**

1. Disconnect ignition coil assembly from collector.
2. Connect a known good spark plug to the ignition coil assembly.
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.



NG → Check ignition coil, power transistor unit and circuits. (See page EF & EC-264.)

OK

(Go to **A** on next page.)



Diagnostic Procedure 16 — Engine Stalls when the Electrical Load is Heavy (Cont'd)



GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST



BF

HA

EL

IDX

\*: ECM may be the cause of a problem, but this is rarely the case.



### Diagnostic Procedure 17 — Lack of Power and Stumble

**1**

**CHECK FUEL PRESSURE.**

1. Release fuel pressure to zero. (Refer to page EF & EC-333.)
2. Install fuel pressure gauge and check fuel pressure.

**At idle:**

**Approx. 245 kPa  
(2.5 kg/cm<sup>2</sup>, 36 psi)**

**A few seconds after ignition switch is turned OFF to ON:**

**Approx. 294 kPa  
(3.0 kg/cm<sup>2</sup>, 43 psi)**

NG

Check fuel pressure regulator diaphragm.

OK

**2**

**CHECK FOR INTAKE AIR LEAK.**

When pinching blow-by hose (lowering the blow-by air supply), does the engine speed rise?







Yes

Discover air leak location and repair.

No

INSPECTION END

Diagnostic Procedure 18 — Knock



G1

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX

Diagnostic Procedure 19 — Surge

**1**

☆ MONITOR ☆ NO FAIL

CMPS•RPM(POS) 2000rpm  
M/R F/C MNT LEAN

RECORD

MEF225F

**1**


RED LED

Malfunction indicator lamp


MEF377DA

**2**

SEC547A



\*: ECM may be the cause of a problem, but this is rarely the case.



**Diagnostic Procedure 20 — Backfire through the Intake**

**1**

**CHECK SPARK PLUGS.**

Remove the spark plugs and check for fouling, etc.

NG

Repair or replace spark plug(s).

OK

**2**

**CHECK INTAKE AIR LEAK.**

When pinching blow-by hose (lowering the blow-by air supply), does the engine speed rise?

Yes


Discover air leak location and repair.

No

**CHECK FOR INTAKE VALVE DEPOSITS.**

If there are deposits on intake valves, remove them.

INSPECTION END



**Diagnostic Procedure 21 — Backfire through the Exhaust**

**CHECK ENGINE COOLANT TEMPERATURE SENSOR.**

Check engine coolant temperature sensor and its circuit. (See page EF & EC-259.)

NG

Replace or repair.


OK

INSPECTION END

CI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX




Diagnostic Procedure 22

MAIN POWER SUPPLY AND GROUND CIRCUIT (Not self-diagnostic item)








MEF244F

Harness layout





Diagnostic Procedure 22 (Cont'd)




```

    graph TD
        Start[INSPECTION START] --> A[CHECK POWER SUPPLY.  
1) Turn ignition switch "ON".  
2) Check voltage between ECM terminals 49, 59, 109 and ground.  
Voltage: Battery voltage]
        A -- OK --> B[CHECK GROUND CIRCUIT.  
1) Turn ignition switch "OFF".  
2) Disconnect ECM harness connector.  
3) Check harness continuity between ECM terminals 10, 20, 107, 108, 116 and engine ground.  
Continuity should exist.  
If NG, repair harness or connectors.]
        A -- NG --> C[CHECK HARNESS CONTINUITY BETWEEN ECCS RELAY AND ECM.  
1) Turn ignition switch "OFF".  
2) Disconnect ECM harness connector.  
3) Disconnect ECCS relay.  
4) Check harness continuity between ECM terminals 49, 59, 109 and terminal 5.  
Continuity should exist.]
        B -- OK --> D[Check ECM pin terminals for damage or the connection of ECM harness connector.]
        C -- NG --> E[Check the following.  
• Harness connectors F2, E3  
• Harness continuity between ECM and ECCS relay  
If NG, repair harness or connectors.]
        D -- OK --> F[Check the following.  
• "BR" fusible link  
• Joint connector-3  
• Harness continuity between ECCS relay and battery  
If NG, repair harness or connectors.]
        E -- NG --> G[Check the following.  
• Harness connectors F2, E3  
• Joint connector-3  
• Harness continuity between ECM and joint connector-3  
If NG, repair harness or connectors.]
        F -- OK --> H[A]
        G -- OK --> H
    
```

GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 22 (Cont'd)



**F**


**Ⓐ**

**F**

CHECK GROUND CIRCUIT.  
 1) Check harness continuity between ECM terminals 50, 60 and engine ground.  
**Continuity should exist.**

NG → Repair harness or connectors.

OK




**G**

**G**

CHECK OUTPUT SIGNAL CIRCUIT.  
 1) Check harness continuity between ECM terminal 16 and terminal 1.  
**Continuity should exist.**

NG → Check the following.  
 ● Harness connectors (F1), (E2)  
 ● Joint connector-4  
 ● Harness continuity between ECM and ECCS relay  
 If NG, repair harness or connectors.

OK



**H**

**H**

CHECK INPUT SIGNAL CIRCUIT.  
 1) Turn ignition switch "ON".  
 2) Check voltage between ECM terminal 45 and ground.  
**Voltage: Battery voltage**

NG → Check the following.  
 ● Harness connectors (F2), (E3)  
 ● Joint connector-3  
 ● Joint connector-5  
 ● Harness connector (E110)  
 ● Harness continuity between ECM and ignition switch  
 If NG, repair harness or connectors.

OK

CHECK COMPONENT (ECCS relay).  
 Refer to "Electrical Components Inspection".  
 (See page EF & EC-331.)

NG → Replace ECCS relay.

OK


Disconnect and reconnect harness connectors in the circuit, and retest.

Trouble is not fixed.




Check ECM pin terminals for damage or the connection of ECM harness connector. Reconnect ECM harness connector and retest.

Diagnostic Procedure 23

CAMSHAFT POSITION SENSOR (Diagnostic trouble code No. 11)




Harness layout



GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 23 (Cont'd)



INSPECTION START

**A**

**CHECK POWER SUPPLY.**

- 1) Disconnect camshaft position sensor harness connector.
- 2) Turn ignition switch "ON".
- 3) Check voltage between terminal (b) and ground.


**Voltage: Battery voltage**

NG

Check the following.

- Harness connectors (F2), (E3)
- Harness continuity between camshaft position sensor and ECCS relay

If NG, repair harness or connectors.



**B**


**CHECK GROUND CIRCUIT.**

- 1) Turn ignition switch "OFF".
- 2) Loosen and retighten ground screws.
- 3) Check harness continuity between terminal (a) and engine ground.

**Continuity should exist.**

NG

Repair harness or connectors.



**C**

**CHECK INPUT SIGNAL CIRCUIT.**

- 1) Reconnect camshaft position sensor harness connector.
- 2) Start engine.
- 3) Read "CMPS-RPM" signals in "DATA MONITOR" mode with CONSULT.

**rpm: M/T 750 ± 50**  
**A/T 790 ± 50**


OR

- 1) Disconnect ECM harness connector.
- 2) Check harness continuity between terminal (c) and ECM terminals (42), (52) (1° signal), terminal (d) and ECM terminals (41), (51) (120° signal).

**Continuity should exist.**

NG

Repair harness or connectors.



**CHECK COMPONENT** (Camshaft position sensor). Refer to "Electrical Components Inspection". (See page EF & EC-324.)

NG

Replace camshaft position sensor.

OK


Disconnect and reconnect harness connectors in the circuit, and retest.

Trouble is not fixed.

Check ECM pin terminals for damage or the connection of ECM harness connector. Reconnect ECM harness connector and retest.

**Diagnostic Procedure 23 (Cont'd)**

Perform **FINAL CHECK** by the following procedure after repair is completed.



GI

MA

EM

LC

**EF & EC**

FE

CL

MT

AT

FA

RA

BR

ST


BF


HA

EL

IDX




Diagnostic Procedure 24

MASS AIR FLOW SENSOR (Diagnostic trouble code No. 12)  (MALFUNCTION INDICATOR LAMP ITEM)




MEF246F

Harness layout




Diagnostic Procedure 24 (Cont'd)



INSPECTION START


**A**  
**CHECK POWER SUPPLY.**  
 1) Disconnect mass air flow sensor harness connector.  
 2) Turn ignition switch "ON".  
 3) Check voltage between terminal **d** and ground.  
**Voltage: Battery voltage**

NG → Check the following.  
 ● Harness connectors  
 ● **F2**, **E3**  
 ● Harness continuity between mass air flow sensor and ECCS relay  
 If NG, repair harness or connectors.



**B**  
**CHECK GROUND CIRCUIT.**  
 1) Turn ignition switch "OFF".  
 2) Disconnect ECM harness connector.  
 3) Loosen and retighten ground screws.  
 4) Check harness continuity between terminal **c** and ECM terminal **26**, terminal **b** and engine ground.  
**Continuity should exist.**

NG → Repair harness or connectors.




**C**  
**CHECK INPUT SIGNAL CIRCUIT.**  
 1) Reconnect mass air flow sensor harness connector and ECM harness connector.  
 2) Start engine and warm it up sufficiently.  
 3) Read "MAS AIR/FL SE" signal in "DATA MONITOR" mode with CONSULT.  
**Voltage: 0.8 - 1.5V (At idle)**  
 OR  
 1) Check harness continuity between terminal **a** and ECM terminal **27**.  
**Continuity should exist.**

NG → Repair harness or connectors.

**CHECK COMPONENT**  
 (Mass air flow sensor). Refer to "Electrical Components Inspection". (See page EF & EC-324.)

NG → Replace mass air flow sensor.




Disconnect and reconnect harness connectors in the circuit, and retest.

Trouble is not fixed.  
 Check ECM pin terminals for damage or the connection of ECM harness connector. Reconnect ECM harness connector and retest.

GI  
 MA  
 EM  
 LC  
 EF & EC  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX

**Diagnostic Procedure 24 (Cont'd)**


Perform **FINAL CHECK** by the following procedure after repair is completed.







Diagnostic Procedure 25

ENGINE COOLANT TEMPERATURE SENSOR (Diagnostic trouble code No. 13)  
 (MALFUNCTION INDICATOR LAMP ITEM)






Harness layout



GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 25 (Cont'd)



INSPECTION START

**A**

**CHECK POWER SUPPLY.**

- 1) Start engine and warm it up sufficiently.
- 2) Select "COOLAN TEMP/S" signal in "DATA MONITOR" mode with CONSULT.
- 3) Stop engine.
- 4) When restarting engine make sure that CONSULT indicates "COOLAN TEMP/S" is 50°C (122°F) or more.

OR

- 1) Disconnect engine coolant temperature sensor harness connector.
- 2) Turn ignition switch "ON".
- 3) Check voltage between terminal **(b)** and ground.

**Voltage: Approximately 5V**

NG

Check the following.

- Harness continuity between ECM and engine coolant temperature sensor.

If NG, repair harness or connectors.

**B**

**CHECK GROUND CIRCUIT.**

- 1) Turn ignition switch "OFF".
- 2) Check harness continuity between terminal **(a)** and engine ground.

**Continuity should exist.**

NG

Check the following.

- Harness continuity between ECM and engine coolant temperature sensor.

If NG, repair harness or connectors.

**CHECK COMPONENT**  
(Engine coolant temperature sensor).  
Refer to "Electrical Components Inspection".  
(See page EF & EC-325.)

NG

Replace engine coolant temperature sensor.


Disconnect and reconnect harness connectors in the circuit, and retest.

Trouble is not fixed.

Check ECM pin terminals for damage or the connection of ECM harness connector. Reconnect ECM harness connector and retest.

**Diagnostic Procedure 25 (Cont'd)**

**Perform FINAL CHECK by the following procedure after repair is completed.**



GI

MA

EM

LC

**EF & EC**

FE

CL

MT

AT

FA

RA

BR

ST

BF


KA

EL




IDX

Diagnostic Procedure 26

VEHICLE SPEED SENSOR (Diagnostic trouble code No. 14)  (MALFUNCTION INDICATOR LAMP ITEM)



Harness layout



Diagnostic Procedure 26 (Cont'd)

**A** ■ VEHICLE SPEED SEN CKT ■

AFTER TOUCH START,  
DRIVE VEHICLE  
AT 10 km/h (6 mph) OR  
MORE WITHIN 15 sec.

NEXT      START


MEF430D

**A** ☆ MONITOR ☆ NO FAIL

VHCL SPEED SE      0mph

RECORD

MEF431D



INSPECTION START

CHECK SPEEDOMETER FUNCTION.  
Make sure that speedometer functions properly.

NG → Check vehicle speed sensor and its circuit. (Refer to EL section.)

OK

**A**

CHECK INPUT SIGNAL CIRCUIT.

1) Perform "VEHICLE SPEED SEN CKT" in "FUNCTION TEST" mode with CONSULT.      OR

1) Read "VHCL SPEED SE" signal in "DATA MONITOR" mode with CONSULT.  
**CONSULT value should be the same as the speedometer indication.**

NG → Check the following.  
● Harness connectors (F53, M37)  
● Harness connectors (M22, I1)  
● Harness continuity between ECM and combination meter  
If NG, repair harness or connectors.

OR

1) Turn ignition switch "OFF".  
2) Disconnect ECM harness connector and combination meter harness connector.  
3) Check harness continuity between ECM terminal (53) and terminal (h).  
**Continuity should exist.**

OK

Disconnect and reconnect harness connectors in the circuit, and retest.

Trouble is not fixed.

Check ECM pin terminals for damage or the connection of ECM harness connector. Reconnect ECM harness connector and retest.

**Perform FINAL CHECK by the following procedure after repair is completed.**

FINAL CHECK

Start engine.

Perform diagnostic test mode II (Self-diagnostic results). (Refer to EF & EC-199.)

NG → Recheck ECM pin terminals for damage or the connection of ECM harness connector.


OK

INSPECTION END





GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 27





IGNITION SIGNAL (Diagnostic trouble code No. 21)



Harness layout



Diagnostic Procedure 27 (Cont'd)




```

    graph TD
        Start[INSPECTION START] --> A[A]
        A["CHECK POWER SUPPLY-I.  
1) Disconnect ignition coil harness connectors.  
2) Turn ignition switch 'ON'.  
3) Check voltage between terminal (b) and ground.  
Voltage: Battery voltage"] -- OK --> A_OK[Go to "CHECK GROUND CIRCUIT" on next page.]
        A -- NG --> B[B]
        B["CHECK POWER SUPPLY-II.  
1) Turn ignition switch 'OFF'.  
2) Disconnect ignition coil relay.  
3) Check harness continuity between terminal (b) and terminal (5).  
Continuity should exist."] -- NG --> B_NG["Check the following.  
• Harness connectors (F2), (E3)  
• Harness continuity between ignition coil and ignition coil relay  
If NG, repair harness or connectors."]
        B -- OK --> C[C]
        C["CHECK POWER SUPPLY-III.  
1) Turn ignition switch 'ON'.  
2) Check voltage between terminals (2), (3) and ground.  
Voltage: Battery voltage"] -- NG --> C_NG["Check the following.  
• Joint connector-3  
• Joint connector-5  
• 'BR' fusible link  
• Harness continuity between ignition coil relay and ignition switch  
• Harness continuity between ignition coil relay and battery  
If NG, repair harness or connectors."]
        C -- OK --> D[D]
        D["CHECK OUTPUT SIGNAL CIRCUIT-I.  
1) Turn ignition switch 'OFF'.  
2) Disconnect ECM harness connector.  
3) Check harness continuity between ECM terminal (16) and terminal (1).  
Continuity should exist."] -- NG --> D_NG["Check the following.  
• Harness connectors (F1), (E2)  
• Joint connector-4  
• Harness continuity between ECM and ignition coil relay  
If NG, repair harness or connectors."]
        D -- OK --> End((A))
    
```

GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
WT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 27 (Cont'd)



Ⓐ


CHECK COMPONENT  
(Ignition coil relay).  
Refer to "Electrical Components  
Inspection".  
(See page EF & EC-331.)

NG → Replace ignition coil  
relay.

OK

Disconnect and reconnect harness con-  
nectors in the circuit, and retest.

Trouble is not fixed.



Check ECM pin terminals for damage  
or the connection of ECM harness con-  
nector. Reconnect ECM harness con-  
nector and retest.

CHECK GROUND CIRCUIT.

1) Turn ignition switch "OFF".


Ⓔ 2) Check harness continuity  
between terminal Ⓐ and  
engine ground.  
**Continuity should exist.**

3) Disconnect power transistor unit har-  
ness connector.

Ⓕ 4) Check harness continuity  
between terminal Ⓔ and  
engine ground.  
**Continuity should exist.**

NG → Repair harness or con-  
nectors.

OK



CHECK OUTPUT SIGNAL CIRCUIT-II.

Ⓖ 1) Check harness continuity  
between terminals (k), (l), (m),  
(n), (o), (p) and terminal Ⓒ.  
**Continuity should exist.**

2) Disconnect ECM harness connector.


Ⓗ 3) Check harness continuity  
between following terminals.

① - ①	⑪ - ①
② - ①	⑫ - ②
③ - ②	⑬ - ③

**Continuity should exist.**

NG → Repair harness or con-  
nectors.

OK



CHECK COMPONENTS  
(Ignition coil and power transistor).  
Refer to "Electrical Components  
Inspection".  
(See pages EF & EC-325 and 326.)

NG → Replace malfunctioning  
component(s).

OK

Disconnect and reconnect harness con-  
nectors in the circuit, and retest.


Trouble is not fixed.

Check ECM pin terminals for damage  
or the connection of ECM harness con-  
nector. Reconnect ECM harness con-  
nector and retest.



**Diagnostic Procedure 27 (Cont'd)**

Perform **FINAL CHECK** by the following procedure after repair is completed.



G1


MA


EM

LC

EF & EC

**Diagnostic Procedure 28**

**ECM (ECCS CONTROL MODULE) (Diagnostic trouble code No. 31)**  **(MALFUNCTION INDICATOR LAMP ITEM)**



FE

CL

WT

AT

FA

RA

BR

ST


BF


HA

EL




IDX

Diagnostic Procedure 29





EGR FUNCTION (Diagnostic trouble code No. 32)  (MALFUNCTION INDICATOR LAMP ITEM)



Harness layout



Diagnostic Procedure 29 (Cont'd)



INSPECTION START

**A**  
**CHECK VACUUM SOURCE TO EGR VALVE.**  
 1) Start engine and warm it up sufficiently.  
 2) Perform diagnostic test mode II (Self-diagnostic results). Make sure that diagnostic trouble code No. 12 is not displayed.  
 3) Disconnect vacuum hose to EGR valve.  
 4) Make sure that vacuum exists under the following conditions.  
**At idle:**  
 Vacuum should not exist.  
**Engine is racing:**  
 Vacuum should exist.

**OK**  
**CHECK COMPONENTS**  
 (EGR valve, EGRC-BPT valve and EGR temperature sensor). Refer to "Electrical Components Inspection". (See page EF & EC-326.)

**NG**  
 Replace malfunctioning component(s).

**B**  
**CHECK CONTROL FUNCTION.**  
 1) Check voltage between ECM terminal (102) and ground under the following conditions.  
**Voltage:**  
**At idle**  
 Approximately 0V  
**Engine speed is 2,000 rpm**  
 Battery voltage

**OK**  
**C**  
**CHECK VACUUM HOSE.**  
 1) Check vacuum hose for clogging, cracks and proper connection.


**D**  
**CHECK POWER SUPPLY.**  
 1) Stop engine.  
 2) Disconnect EGRC-solenoid valve harness connector.  
 3) Turn ignition switch "ON".  
 4) Check voltage between terminal (b) and ground.  
**Voltage: Battery voltage**

**NG**  
 Check the following.  
 ● Harness connectors (F53, M37)  
 ● 10A fuse  
 ● Harness continuity between EGRC-solenoid valve and fuse  
 If NG, repair harness or connectors.

**OK**  
**A**

GI  
 MA  
 EM  
 LC  
**EF & EC**  
 FE  
 CL  
 WT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX

Diagnostic Procedure 29 (Cont'd)



**E**

Ⓐ

**E**

CHECK OUTPUT SIGNAL CIRCUIT.

- 1) Turn ignition switch "OFF".
- 2) Disconnect ECM harness connector.
- 3) Check harness continuity between ECM terminal (102) and terminal Ⓐ.

**Continuity should exist.**

NG → Repair harness or connectors.

OK

**F**

■ EGRC SOL/V CIRCUIT ■

DOES THE SOLENOID VALVE MAKE AN OPERATING SOUND EVERY 3 SECONDS ?

NEXT NO YES

MEF437D

**F**

CHECK COMPONENT (EGRC-solenoid valve).

- 1) Reconnect EGRC-solenoid valve harness connector and ECM harness connector.
- 2) Turn ignition switch "ON".
- 3) Perform "EGRC SOL/V CIRCUIT" in "FUNCTION TEST" mode with CONSULT.

OR

- 3) Turn EGRC-solenoid valve "ON" and "OFF" in "ACTIVE TEST" mode with CONSULT and check operating sound.

OR

Refer to "Electrical Components Inspection". (See page EF & EC-326.)

NG → Replace EGRC-solenoid valve.

OK

**F**

■ ACTIVE TEST ■

EGRC SOL/V ON

==== MONITOR ====

CMPS•RPM (POS) 0rpm

ON ON/OFF OFF

MEF224F

Check resistance of EGR temperature sensor. (See page EF & EC-327.)

OK

Disconnect and reconnect harness connectors in the circuit, and retest.

Trouble is not fixed.

Check ECM pin terminals for damage or the connection of ECM harness connector. Reconnect ECM harness connector and retest.

Diagnostic Procedure 29 (Cont'd)


**G ROAD TEST**

**Test condition**

Drive vehicle under the following conditions with a suitable shift position.

- (1) Engine speed:  
2,100±300 rpm
- (2) Intake manifold vacuum:  
M/T: -23.3±4.7 kPa  
(-175±35 mmHg, -6.89±1.38 inHg)  
A/T: -26.0±7.3 kPa  
(-195±55 mmHg, -7.68±2.17 inHg)


**Driving mode**




- ① Start engine and warm it up sufficiently.
- ② Turn off ignition switch and keep it off until green and red LEDs go off.
- ③ Start engine and make sure that air conditioner switch and rear defogger are turned "OFF" during driving test.
- ④ Keep engine running for at least 3 minutes.
- ⑤ Shift to suitable gear position and drive in "Test condition" for at least 11 seconds.
- ⑥ Decrease engine speed to less than 1,800 rpm.
- ⑦ Repeat steps ⑤ through ⑥ at least 1 time.

MEF440DA

Perform FINAL CHECK by the following procedure after repair is completed.



**H**



MALFUNCTION INDICATOR LAMP

MEF439D

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

IDX




Diagnostic Procedure 30

HEATED OXYGEN SENSOR (Diagnostic trouble code No. 33)  (MALFUNCTION INDICATOR LAMP ITEM)







MEF251F

Harness layout







Diagnostic Procedure 30 (Cont'd)



GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
WT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 30 (Cont'd)





Diagnostic Procedure 30 (Cont'd)

Perform FINAL CHECK by the following procedure after repair is completed.

**E**

MIXTURE RATIO TEST

ACCELERATE TO 2000 RPM AND HOLD THEN TOUCH START

1800 2000 2200

NEXT START

SEF115L

FINAL CHECK

Erase the diagnostic test mode II (Self-diagnostic results) memory.  
(Refer to EF & EC-201.)

**E**

☆ MONITOR ☆ NO FAIL

CMPS•RPM(POS) 2000rpm  
M/R F/C MNT LEAN

RECORD

MEF225F

**E**

Perform test drive under the following conditions.

1) Start engine and warm it up sufficiently.

2) Perform "MIXTURE RATIO TEST" in "FUNCTION TEST" mode with CONSULT.

OR

2) Make sure that "M/R F/C MNT" in "DATA MONITOR" mode indicates "RICH" and "LEAN" periodically more than 5 times during 10 seconds at 2,000 rpm.

OR

2) Make sure that the red LED on the ECM or the malfunction indicator lamp on the instrument panel goes on and off periodically more than 5 times during 10 seconds at 2,000 rpm in Diagnostic Test Mode II (Heated oxygen sensor monitor).

**E**

RED LED

Malfunction indicator lamp

MEF377DA

Perform diagnostic test mode II (Self-diagnostic results) again.  
(Refer to EF & EC-199.)

OK

INSPECTION END


NG

Recheck ECM pin terminals for damage or the connection of ECM harness connector.




GI  
VA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 31


KNOCK SENSOR (Diagnostic trouble code No. 34)



Harness layout



Diagnostic Procedure 31 (Cont'd)



INSPECTION START

**A** CHECK INPUT SIGNAL CIRCUIT.  
 1) Disconnect ECM harness connector and knock sensor sub-harness connector.  
 2) Check harness continuity between terminal ① and ECM terminal ②3. **Continuity should exist.**

NG → Repair harness or connectors.

OK

Loosen and retighten ground screws.

CHECK COMPONENT (Knock sensor).  
 Refer to "Electrical Components Inspection"  
 (See page EF & EC-330.)

NG → Replace knock sensor.

OK

Disconnect and reconnect harness connectors in the circuit, and retest.

Trouble is fixed.

Check ECM pin terminals for damage or the connection of ECM harness connector. Reconnect ECM harness connector and retest.

**Perform FINAL CHECK by the following procedure after repair is completed.**

FINAL CHECK

1) Erase the diagnostic test mode II (Self-diagnostic results) memory. (Refer to EF & EC-201.)  
 2) Perform test drive.  
 3) Perform diagnostic test mode II (Self-diagnostic results) again. (Refer to EF & EC-199.)

NG → Recheck ECM pin terminals for damage or the connection of ECM harness connector.


OK

INSPECTION END

GI  
 MA  
 EM  
 LC  
 EF & EC  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX




Diagnostic Procedure 32

EGR TEMPERATURE SENSOR (Diagnostic trouble code No. 35)  (MALFUNCTION INDICATOR LAMP ITEM)







SEF465N

Harness layout




Diagnostic Procedure 32 (Cont'd)



GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
WT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX


**Diagnostic Procedure 32 (Cont'd)**

Perform **FINAL CHECK** by the following procedure after repair is completed.







Diagnostic Procedure 33

THROTTLE POSITION SENSOR (Diagnostic trouble code No. 43)  (MALFUNCTION INDICATOR LAMP ITEM)




Harness layout



G1  
WA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX


Diagnostic Procedure 33 (Cont'd)



INSPECTION START


**A**  
**CHECK POWER SUPPLY.**  
 1) Disconnect throttle position sensor harness connector.  
 2) Turn ignition switch "ON".  
 3) Check voltage between terminal **c** and ground.  
**Voltage: Approximately 5V**

NG → Repair harness or connectors.



**B**  
**CHECK GROUND CIRCUIT.**  
 1) Turn ignition switch "OFF".  
 2) Loosen and retighten ground screws.  
 3) Check harness continuity between terminal **a** and engine ground.  
**Continuity should exist.**

NG → Repair harness or connectors.




**C**  
**CHECK INPUT SIGNAL CIRCUIT.**  
 1) Reconnect throttle position sensor harness connector.  
 2) Turn ignition switch "ON".  
 3) Perform "THROTTLE POSI SEN CKT" in "FUNCTION TEST" mode with CONSULT.

NG → Repair harness or connectors.

OR  
 3) Read "THRTL POS SEN" signal in "WORK SUPPORT" mode with CONSULT.  
**Throttle valve fully closed: 0.4 - 0.5V**  
**Throttle valve fully open: Approx. 4.0V**


OR  
 1) Disconnect ECM harness connector.  
 2) Check harness continuity between ECM terminal **38** and terminal **b**.  
**Continuity should exist.**



OK  
**CHECK COMPONENT** (Throttle position sensor). Refer to "Electrical Components Inspection". (See page EF & EC-327.)

NG → Replace throttle position sensor.

OK  
 Disconnect and reconnect harness connectors in the circuit, and retest.




↓ Trouble is not fixed.  
 Check ECM pin terminals for damage or the connection of ECM harness connector. Reconnect ECM harness connector and retest.



Diagnostic Procedure 33 (Cont'd)

Perform FINAL CHECK by the following procedure after repair is completed.



GI

MA

EM

LC

**EF & EC**

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA


EL

DX



**Diagnostic Procedure 34**

**INJECTOR LEAK (Diagnostic trouble code No. 45)  
(MALFUNCTION INDICATOR LAMP ITEM)**



## Diagnostic Procedure 34 (Cont'd)

**B**

■ ACTIVE TEST ■ □	
SELF-LEARN CONTROL	100%
== MONITOR ==	
CMPS-RPM (POS)	787rpm
COOLAN TEMP/S	95°C
O <sub>2</sub> SEN	0.02V
A/F ALPHA	98%
CLEAR	

MEF628F

Perform FINAL CHECK by the following procedure after repair is completed.

FINAL CHECK

↓

Erase the diagnostic test mode II (Self-diagnostic results) memory. Make sure Diagnostic trouble code No. 55 is displayed in Diagnostic Test Mode II. Refer to EF & EC-201.

**C**

### ROAD TEST

**Test conditions**  
Drive vehicle under the following conditions with suitable gear position.

- Engine speed:  
M/T : 2,600 ± 600 rpm  
A/T : 2,500 ± 700 rpm
- Intake manifold vacuum:  
M/T : -30.0 ± 23.3 kPa  
(-225 ± 175 mmHg, -8.86 ± 6.89 inHg)  
A/T : -45.3 ± 8.0 kPa  
(-340 ± 60 mmHg, -13.39 ± 2.36 inHg)

**Driving mode**

(A) : 13 minutes  
 (B) : 15 minutes at idle speed  
 (C) : 5 minutes at test condition  
 (D) : 2 minutes at idle speed

Until red LED goes off.

- Start engine and warm it up sufficiently.
- Turn off ignition switch and keep it off until red LED goes off.
- Start engine and keep it running for 13 minutes.
- Turn off ignition switch and keep it off until red LED goes off.
- Repeat steps ③ through ④: total 3 times.
- Start engine and keep it at idle for at least 15 minutes.  
If engine stalls or ignition is turned off under 13 minutes after starting engine, return to step ②. If over 13 minutes, restart step ⑥.
- Shift to suitable gear position and drive in "Test condition" for at least 5 minutes.  
If following conditions occur during step ⑦, return to step ⑥.
  - Engine is raced over 4,000 rpm or hardly accelerated for more than 10 seconds.
  - Engine stalls or ignition is turned off.
- Keep engine at idle speed for more than 2 minutes.

SEF598N

**B**

Clear the self-learning data using the following procedure:

- Start engine and warm it up sufficiently.
- Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode.
- Clear the self-learning control coefficient by touching "CLEAR".

OR

- Disconnect mass air flow sensor connector, and restart and run engine for at least 30 seconds at 2,000 rpm.
- Stop engine and reconnect mass air flow sensor connector.
- Make sure Diagnostic trouble code No. 12 is displayed in Diagnostic Test Mode II.
- Erase the diagnostic test mode II (Self-diagnostic results) memory. Make sure Diagnostic trouble code No. 55 is displayed in Diagnostic Test Mode II.

**C**

Perform test drive under the following conditions:

- Warm up engine sufficiently.
- Use test driving modes indicated in figure **C**.

(A)

GI

MA

EM

LC

EF &amp; EC

FE

CL

MT

AT

FA

RA

BR

ST



BF

HA


EL


IDX

Diagnostic Procedure 34 (Cont'd)






Diagnostic Procedure 35



INJECTOR CIRCUIT (Diagnostic trouble code No. 51)  (MALFUNCTION INDICATOR LAMP ITEM)



Harness layout



Diagnostic Procedure 35 (Cont'd)



- (101): No.1 cylinder
- (112): No.4 cylinder
- (110): No.2 cylinder
- (105): No.5 cylinder
- (103): No.3 cylinder
- (114): No.6 cylinder

INSPECTION START

**A**  
**CHECK POWER SUPPLY.**  
 1) Disconnect injector sub-harness connector and injector harness connectors.  
 2) Check voltage between terminals (a), (d) and ground.  
**Voltage: Battery voltage**

NG → Check the following.  
 ● Harness connectors  
 ● (F2), (E3)  
 ● Joint connector-3  
 ● "BR" fusible link  
 ● Harness continuity between battery and injector  
 ● Harness continuity between battery and injector sub-harness connector  
 If NG, repair harness or connectors.

OK →

**B**  
**CHECK OUTPUT SIGNAL CIRCUIT.**  
 1) Disconnect ECM harness connector.  
 2) Check harness continuity between ECM terminal (101) and terminal (c), ECM terminal (103) and terminal (d), ECM terminal (105) and terminal (b), ECM terminals (110), (112), (114) and terminal (e).  
**Continuity should exist.**

NG → Repair harness or connectors.

OK →  
**CHECK COMPONENT (Injector).**  
 Refer to "Electrical Components Inspection". (See page EF & EC-329.)


NG → Replace injector.

OK →  
 Disconnect and reconnect harness connectors in the circuit, and retest.

Trouble is not fixed.  
 Check ECM pin terminals for damage or the connection of ECM harness connector. Reconnect ECM harness connector and retest.

**Diagnostic Procedure 35 (Cont'd)**

**Perform FINAL CHECK by the following procedure after repair is completed.**



GI

MA

EM

LC

**EF & EC**

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL



DX

Diagnostic Procedure 36

A/T CONTROL (Diagnostic trouble code No. 54)





Harness layout






Diagnostic Procedure 36 (Cont'd)




Perform FINAL CHECK by the following procedure after repair is completed.






GI  
MA  
EW  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 37

CLOSED THROTTLE POSITION SWITCH (Not self-diagnostic item)



Harness layout



Diagnostic Procedure 37 (Cont'd)

**A**

■ CLOSED THROTTLE POSI ■

DEPRESS  
THROTTLE FULLY  
THEN  
TOUCH START

NEXT      START

MEF469D




**A**

☆ MONITOR ☆ NO FAIL

CMPS-RPM(POS)	0rpm
CMPS-RPM(REF)	0rpm
COOLAN TEMP/S	80°C
THRTL POS SEN	0.50V
CLOSED TH/POS	ON

RECORD

MEF229F



INSPECTION START

**A**

CHECK OVERALL FUNCTION.

- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF".
- 3) Disconnect throttle position sensor harness connector.
- 4) Turn ignition switch "ON".
- 5) Perform "CLOSED THROTTLE POSI" in "FUNCTION TEST" mode with CONSULT.

OK → INSPECTION END

OR

5) Check "CLOSED TH/POS" signal in "DATA MONITOR" mode with CONSULT.

**Accelerator pedal is released ... ON**  
**Accelerator pedal is depressed ... OFF**

OR

- 3) Turn ignition switch "ON".
- 4) Check voltage between ECM terminal 54 and ground under the following conditions.

**Voltage:**  
**Accelerator pedal is released**  
**Approximately 8 - 10V**  
**Accelerator pedal is depressed**  
**Approximately 0V**

**B**

CHECK POWER SUPPLY.

- 1) Turn ignition switch "OFF".
- 2) Disconnect closed throttle position switch harness connector.
- 3) Turn ignition switch "ON".
- 4) Check voltage between terminal b and ground.

**Voltage: Approximately 8 - 10V**

NG → Repair harness or connectors.

**C**

CHECK GROUND CIRCUIT.

- 1) Turn ignition switch "OFF".
- 2) Check harness continuity between terminal a and engine ground.

**Continuity should exist.**

NG → Repair harness or connectors.

CHECK COMPONENT (Closed throttle position switch). Refer to "Electrical Components Inspection". (See page EF & EC-327.)

NG → Replace closed throttle position switch.

Disconnect and reconnect harness connectors in the circuit, and retest.


Trouble is not fixed.

Check ECM pin terminals for damage or the connection of ECM harness connector. Reconnect ECM harness connector and retest.


GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 38

START SIGNAL (Not self-diagnostic item)



Harness layout



Diagnostic Procedure 38 (Cont'd)

**A**

■ START SIGNAL CKT ■

1. CLOSE THROTTLE, SHIFT TO P OR N RANGE.
2. TOUCH START AND START ENGINE IMMEDIATELY.

NEXT      START

MEF481B




**A**

☆ MONITOR ☆ NO FAIL

START SIGNAL	OFF
CLOSED TH/POS	ON
AIR COND SIG	OFF
NEUT POSI SW	ON

RECORD

MEF472D



GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL



IDX

Diagnostic Procedure 39

POWER STEERING OIL PRESSURE SWITCH (Not self-diagnostic item)



Harness layout



Diagnostic Procedure 39 (Cont'd)

**A**

■ PW/ST SIGNAL CIRCUIT ■

HOLD STEERING WHEEL  
IN A FULL  
LOCKED POSITION  
THEN  
TOUCH START

NEXT    START

SEF200L




**A**

☆ MONITOR    ☆ NO FAIL    □

PW/ST SIGNAL    OFF

RECORD

SEF831K



INSPECTION START

**A**

CHECK CONTROL FUNCTION.

1) Start engine and warm it up sufficiently.

2) Perform "PW/ST SIGNAL CIRCUIT" in "FUNCTION TEST" mode with CONSULT.

OR

2) Check "PW/ST SIGNAL" in "DATA MONITOR" mode with CONSULT.

**Steering is neutral position: OFF**  
**Steering is turned: ON**

OR

2) Check voltage between ECM terminal 34 and ground.

**Voltage:**  
**When steering wheel is turned quickly**  
**Approximately 0V**  
**Except above 4 - 5V**

OK → INSPECTION END

NG →

**B**

CHECK GROUND CIRCUIT.

1) Stop engine.

2) Disconnect power steering oil pressure switch harness connector.

3) Check harness continuity between terminal ① and body ground.

**Continuity should exist.**

OK →

NG → Repair harness or connectors.

**C**

CHECK INPUT SIGNAL CIRCUIT.

1) Disconnect ECM harness connector.

2) Check harness continuity between ECM terminal 34 and terminal ②.

**Continuity should exist.**

OK →

NG → Repair harness or connectors.

CHECK COMPONENT (Power steering oil pressure switch). Refer to "Electrical Components Inspection". (See page EF & EC-331.)

OK →

NG → Replace power steering oil pressure switch.

Disconnect and reconnect harness connectors in the circuit, and retest.


Trouble is not fixed.

Check ECM pin terminals for damage or the connection of ECM harness connector. Reconnect ECM harness connector and retest.


GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 40

NEUTRAL POSITION SWITCH & A/T CONTROL UNIT (NEUTRAL POSITION SIGNAL) CIRCUIT  
(Not self-diagnostic item)








Harness layout







Diagnostic Procedure 40 (Cont'd)



GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 40 (Cont'd)



Diagnostic Procedure 40 (Cont'd)

**D** ■ NEUTRAL POSI SW CKT ■

SHIFT  
OUT OF N/P-RANGE  
THEN  
TOUCH START

START



MEF481D

**D** ☆ MONITOR ☆ NO FAIL

START SIGNAL	OFF
CLOSED TH/POS	ON
AIR COND SIG	OFF
NEUT POSI SW	ON

RECORD

MEF482D



A/T CONTROL UNIT (NEUTRAL POSITION SIGNAL) CIRCUIT

INSPECTION START

**D**

CHECK OVERALL FUNCTION.

- 1) Turn ignition switch "ON".
- 2) Perform "NEUTRAL POSI SW CKT" in "FUNCTION TEST" mode with CONSULT.

OR

OK → INSPECTION END

**D**

- 2) Check "NEUT POSI SW" signal in "DATA MONITOR" mode with CONSULT.

"N" or "P": ON  
Except above: OFF

OR

**D**

- 1) Shift selector lever to "P" position.
- 2) Disconnect ECM harness connector.
- 3) Check harness continuity between ECM terminal ④④ and body ground.  
**Continuity should exist.**
- 4) Shift selector lever to "N" position.
- 5) Check harness continuity between ECM terminal ④④ and body ground.  
**Continuity should exist.**

NG

**D**

- 1) Turn ignition switch "OFF".
- 2) Disconnect ECM harness connector.

**E**

CHECK INPUT SIGNAL CIRCUIT.

- 1) Disconnect A/T control unit harness connector.
- 2) Check harness continuity between ECM terminal ④④ and terminal ⑬⑬.  
**Continuity should exist.**

NG → Repair harness or connectors.

OK

CHECK INHIBITOR SWITCH FUNCTION.  
Make sure that inhibitor switch functions properly. (Refer to AT section).

NG → Check inhibitor switch and circuit (Refer to AT section.)

OK

Disconnect and reconnect harness connectors in the circuit, and retest.


Trouble is not fixed.

Check ECM pin terminals for damage or the connection of ECM harness connector. Reconnect ECM harness connector and retest.




GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 41


FUEL PUMP (Not self-diagnostic item)



Harness layout



Diagnostic Procedure 41 (Cont'd)




INSPECTION START

**A**  
 CHECK OVERALL FUNCTION.  
 1) Turn ignition switch "ON".  
 2) Listen to fuel pump operating sound.  
**Fuel pump should operate for 5 seconds after ignition switch is turned "ON".**

OK → INSPECTION END


GI  
 MA  
 EM



**B**  
 CHECK POWER SUPPLY.  
 1) Turn ignition switch "OFF".  
 2) Disconnect fuel pump relay.  
 3) Turn ignition switch "ON".  
 4) Check voltage between terminals ②, ③ and ground.  
**Voltage: Battery voltage**

NG → Check the following.  
 ● Harness connectors  
 ● Joint connector-5  
 ● 10A fuse  
 ● Harness continuity between fuel pump relay and ignition switch  
 If NG, repair harness or connectors.


LC  
 EF & EC



**C**  
 CHECK GROUND CIRCUIT.  
 1) Turn ignition switch "OFF".  
 2) Disconnect fuel pump harness connector.  
 3) Check harness continuity between terminal ② and body ground, terminal ④ and terminal ⑤.  
**Continuity should exist.**

NG → Repair harness or connectors.

FE  
 CL  
 MT  
 AT



**D**  
 CHECK OUTPUT SIGNAL CIRCUIT.  
 1) Disconnect ECM harness connector.  
 2) Check harness continuity between ECM terminal ⑱ and terminal ①.  
**Continuity should exist.**

NG → Check the following:  
 ● Harness connectors  
 ● Harness continuity between ECM and fuel pump relay  
 If NG, repair harness or connectors.

FA  
 RA  
 BR  
 ST

OK → A

BF  
 HA  
 EL  
 IDX

Diagnostic Procedure 41 (Cont'd)

**E**

■ FUEL PUMP CIRCUIT ■  
 PINCH FUEL FEED HOSE WITH FINGERS. IS THERE ANY PRESSURE PULSATION ON THE FUEL FEED HOSE?  
 OR  
 DOES THE FUEL PUMP RELAY MAKE AN OPERATING SOUND EVERY 3 SECONDS?

NEXT NO YES

SEF194L

**E**


■ ACTIVE TEST ■

FUEL PUMP RELAY ON

=== MONITOR ===  
 CMPS•RPM (POS) 0rpm


ON ON/OFF OFF

MEF230F






Diagnostic Procedure 42

IACV-AAC VALVE (Not self-diagnostic item)




GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Harness layout




Diagnostic Procedure 42 (Cont'd)



INSPECTION START


**A**  
**CHECK OVERALL FUNCTION.**  
 1) Start engine and warm it up sufficiently.  
 2) Check idle speed.  
     **M/T 750 ± 50 rpm**  
     **A/T 790 ± 50 rpm**  
 If NG, adjust idle speed.  
 3) Disconnect IACV-AAC valve harness connector.  
 4) Make sure that idle speed drops.

Drops → INSPECTION END




**B**  
**CHECK POWER SUPPLY.**  
 1) Stop engine.  
 2) Turn ignition switch "ON".  
 3) Check voltage between terminal (a) and ground.  
**Voltage: Battery voltage**

NG → Check the following.  
 • Harness connectors (F53, M37)  
 • 10A fuse  
 • Harness continuity between IACV-AAC valve and fuse  
 If NG, repair harness or connectors.



**C**  
**CHECK OUTPUT SIGNAL CIRCUIT.**  
 1) Turn ignition switch "OFF".  
 2) Reconnect IACV-AAC valve harness connector.  
 3) Perform "IACV-AAC/V SYSTEM" in "FUNCTION TEST" mode with CONSULT.  
 OR  
 2) Perform "IACV-AAC/V OPENING" in "ACTIVE TEST" mode with CONSULT.  
 OR  
 2) Disconnect ECM harness connector.  
 3) Check harness continuity between ECM terminal (4) and terminal (b).  
**Continuity should exist.**


NG → Repair harness or connectors.



OK → **CHECK COMPONENT (IACV-AAC valve).**  
 Refer to "Electrical Components Inspection". (See page EF & EC-328.)

NG → Replace IACV-AAC valve.

OK → Disconnect and reconnect harness connectors in the circuit, and retest.




Trouble is not fixed.

Check ECM pin terminals for damage or the connection of ECM harness connector. Reconnect ECM harness connector and retest.





Diagnostic Procedure 43

POWER VALVE CONTROL (Not self-diagnostic item)



Harness layout



GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 43 (Cont'd)

**A**

■ VIAS S/V CIRCUIT ■

DOES THE VIAS ACTUATOR MOVE EVERY 3 SECONDS?

NEXT NO YES

SEF712L

**A**

■ ACTIVE TEST ■

VIAS SOLENOID/V OFF





=== MONITOR ===

CMPS•RPM (POS) 787rpm





IACV-AAC/V 20%

ON ON/OFF OFF

MEF233F




Diagnostic Procedure 43 (Cont'd)





GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Diagnostic Procedure 44






VTC SOLENOID VALVE (Not self-diagnostic item)



Harness layout



Diagnostic Procedure 44 (Cont'd)



GI  
 MA  
 EM  
 LC  
 EF & EC  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX

Diagnostic Procedure 44 (Cont'd)

**E**

■ VALVE TIMING S/V CKT ■

DOES THE SOLENOID VALVE MAKE AN OPERATING SOUND EVERY 3 SECONDS?

NEXT NO YES

SEF711L

**E**

■ ACTIVE TEST ■

VALVE TIMING SOL OFF


==== MONITOR ====

CMPS•RPM (POS) 0rpm

IACV-AAC/V 16%


ON ON/OFF OFF

MEF237F






Diagnostic Procedure 45




COOLING FAN CONTROL (Not self-diagnostic item)



Harness layout





## Diagnostic Procedure 45 (Cont'd)





Diagnostic Procedure 45 (Cont'd)



PROCEDURE A

INSPECTION START

**C**

**CHECK POWER SUPPLY.**

- 1) Stop engine.
- 2) Disconnect cooling fan relay-1.
- 3) Turn ignition switch "ON".
- 4) Check voltage between terminals ②, ③ and ground.

**Voltage: Battery voltage**

NG → Check the following.

- Harness connectors
- 10A fuse
- "L" fusible link
- "R" fusible link
- Joint connector-1
- Joint connector-2
- Harness continuity between cooling fan relay-1 and fuse
- Harness continuity between cooling fan relay-1 and battery

If NG, repair harness or connectors.

OK ↓

**D**

**CHECK GROUND CIRCUIT.**

- 1) Turn ignition switch "OFF".
- 2) Disconnect cooling fan motor-1 harness connector and cooling fan motor-2 harness connector.
- 3) Check harness continuity between terminals ①, ② and terminal ⑤, terminals ④, ⑥ and body ground.

**Continuity should exist.**

NG → Repair harness or connectors.


OK ↓

Ⓐ

GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX



Diagnostic Procedure 45 (Cont'd)




**PROCEDURE B**

INSPECTION START


**G**  
**CHECK POWER SUPPLY.**  
 1) Stop engine.  
 2) Disconnect cooling fan relays-2, -3.  
 3) Turn ignition switch "ON".  
 4) Check voltage between terminals ①, ⑥ and ground.  
**Voltage: Battery voltage**

NG → Check the following.  
 ● Joint connector-1  
 ● Joint connector-2  
 ● Harness continuity between cooling fan relays-2, -3 and joint connector-1  
 ● Harness continuity between cooling fan relays-2, -3 and joint connector-2  
 If NG, repair harness or connectors.



OK →  
**CHECK GROUND CIRCUIT.**  
 1) Turn ignition switch "OFF".  
 2) Disconnect cooling fan motor-1 harness connector and cooling fan motor-2 harness connector.  
**H** 3) Check harness continuity between terminal ⑦ and terminals ⑩, ⑪.  
**Continuity should exist.**  
**I** 4) Check harness continuity between terminal ③ and terminals ③, ⑨, terminal ⑤ and body ground.  
**Continuity should exist.**



NG → Repair harness or connectors.



OK →  
 (A)

GE  
 MA  
 EM  
 LC  
**EF & EC**  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX

Diagnostic Procedure 45 (Cont'd)



**J**

Ⓐ

**J**

CHECK OUTPUT SIGNAL CIRCUIT.  
 1) Disconnect ECM harness connector.  
 2) Check harness continuity between ECM terminal ⑥ and terminal ②.  
**Continuity should exist.**

NG → Check the following.  
 ● Harness connectors  
 ● F1, E2  
 ● Harness continuity between ECM and cooling fan relays-2, -3  
 If NG, repair harness or connectors.

OK

**K**

CHECK COMPONENT  
 (Cooling fan relays-2 and 3).  
 Refer to "Electrical Components Inspection".  
 (See page EF & EC-331.)

NG → Replace cooling fan relays.

OK

**K**

CHECK COMPONENTS  
 (Cooling fan motors-1 and -2).  
 ① 1) Reconnect cooling fan relays-2, -3, cooling fan motor harness connectors, engine coolant temperature sensor harness connector and ECM harness connector.  
 2) Start engine.  
 3) Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT.  
 OR  
 ② Refer to "Electrical Components Inspection".  
 (See page EF & EC-332).


NG → Replace cooling fan motors.

OK

Disconnect and reconnect harness connectors in the circuit, and retest.

Trouble is not fixed.

Check ECM pin terminals for damage or the connection of ECM harness connector. Reconnect ECM harness connector and retest.



**Electrical Components Inspection**


**ECM INPUT/OUTPUT SIGNAL INSPECTION**

1. ECM is located behind front passenger side floor board. For this inspection, remove the front passenger side floor board.

GI

MA

EM



2. Remove ECM harness protector.

LC

**EF & EC**

FE


CL

3. Perform all voltage measurements with the connectors connected.

MT

Extend tester probe as shown to perform tests easily.

AT



FA

RA


BR

ST

BF

**ECM HARNESS CONNECTOR TERMINAL LAYOUT**

HA



EL

IDX

## Electrical Components Inspection (Cont'd)

## ECM inspection table

\*Data are reference values.

TER-MINAL NO.	ITEM	CONDITION	*DATA
1 2 3 11	Ignition signal	Engine is running. └ Idle speed	Approximately 0.1V
12 13		Engine is running. └ Engine speed is 2,000 rpm.	Approximately 0.1V
4	IACV-AAC valve	Engine is running. └ Racing condition	Voltage briefly decreases from battery voltage (11 - 14V).
6	Cooling fan (High speed)	Engine is running. └ Cooling fan is not operating.	BATTERY VOLTAGE (11 - 14V)
		Engine is running. └ Cooling fan is operating.	Approximately 0V
7	Tachometer	Engine is running. └ Idle speed	BATTERY VOLTAGE (11 - 14V)
		Engine is running. └ Engine speed is 2,000 rpm.	Approximately 2.5V
8	Power valve control solenoid valve	Engine is running. └ Idle speed	BATTERY VOLTAGE (11 - 14V)
		Engine is running. └ Racing (up to 4,000 rpm) quickly	Approximately 0V
9	Air conditioner relay	Engine is running. └ Air conditioner switch "OFF"	BATTERY VOLTAGE (11 - 14V)
		Engine is running. └ Air conditioner switch "ON"	Approximately 0V
16	ECM power source (Self-shutoff)	Engine is running. └ Idle speed	0.8 - 1.0V
		Engine is running. └ For a few seconds after turning ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)

Electrical Components Inspection (Cont'd)

\*Data are reference values.

TERMINAL NO.	ITEM	CONDITION	*DATA
18	Fuel pump relay	Ignition switch "ON" └ For 5 seconds after turning ignition switch "ON"	0.7 - 0.9V
		Engine is running. Ignition switch "ON" └ 5 seconds after turning ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
19	Cooling fan (Low speed)	Engine is running. └ Cooling fan is not operating.	BATTERY VOLTAGE (11 - 14V)
		Engine is running. └ Cooling fan is operating.	Approximately 0V
23	Knock sensor	Engine is running.	2.0 - 3.0V
27	Mass air flow sensor	Engine is running. (Warm-up condition) └ Idle speed	0.8 - 1.5V
		Engine is running. (Warm-up condition) └ Engine speed is 3,000 rpm.	1.4 - 2.0V
28	Engine coolant temperature sensor	Engine is running.	0 - 5.0V Output voltage varies with engine coolant temperature.
29	Heated oxygen sensor	Engine is running. └ After warming up sufficiently and engine speed is 2,000 rpm.	0 ↔ Approximately 0V
34	Power steering oil pressure switch	Engine is running. └ Steering wheel stays straight.	4.0 - 5.0V
		Engine is running. └ Steering wheel is turned.	Approximately 0V
38	Throttle position sensor	Ignition switch "ON"	0.4 - 4.0V Output voltage varies with throttle valve opening angle.

GI  
WA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA

EL  
IDX

Electrical Components Inspection (Cont'd)

\*Data are reference values.

TER-MINAL NO.	ITEM	CONDITION	*DATA
39	EGR temperature sensor	Engine is running. (Warm-up condition) └ Idle speed.	1.0V or more
		Engine is running. (Warm-up condition) └ EGR system is operating.	0 - 1.0V
41 51	Camshaft position sensor (Reference signal)	Engine is running. └ Do not run engine at high speed under no-load.	1.0 - 1.5V Output voltage slightly varies with engine speed.
42 52	Camshaft position sensor (Position signal)	Engine is running. └ Do not run engine at high speed under no-load.	2.3 - 2.6V Output voltage slightly varies with engine speed.
43	Start signal	Ignition switch "ON"	0V
		Ignition switch "START"	BATTERY VOLTAGE (11 - 14V)
44	Neutral position switch (M/T models) Inhibitor switch (A/T models)	Ignition switch "ON" └ Gear position is "Neutral position" (M/T models) └ Gear position is "N" or "P" (A/T models)	0V
		Ignition switch "ON" └ Except the above conditions	4.0 - 5.0V
45	Ignition switch	Ignition switch "ON" └ Engine stopped	BATTERY VOLTAGE (11 - 14V)
46	Air conditioner switch	Engine is running. └ Air conditioner switch "OFF"	BATTERY VOLTAGE (11 - 14V)
		Engine is running. └ Air conditioner switch "ON"	Approximately 0.2V
48	Power source for sensors	Ignition switch "ON" └ Engine stopped	Approximately 5.0V
49	Battery source	Ignition switch "ON" └ Engine stopped	BATTERY VOLTAGE (11 - 14V)



Electrical Components Inspection (Cont'd)

\*Data are reference values.


TERMINAL NO.	ITEM	CONDITION	*DATA
53	Vehicle speed sensor	Ignition switch "ON" └ Engine stopped └ While rotating front wheel by hand	0 or 7.0 - 9.0V
54	Closed throttle position switch (Idle position)	Ignition switch "ON" └ Accelerator pedal is fully released (engine stopped).	8.0 - 10.0V
		Ignition switch "ON" └ Accelerator pedal is depressed (engine stopped).	0V
57	Power source for closed throttle position switch	Ignition switch "ON" └ Engine stopped	8.0 - 10.0V
58	Battery	Ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
59	Power supply	Ignition switch "ON" └ Idle speed	BATTERY VOLTAGE (11 - 14V)
101 103 105 110 112 114	Injectors	Ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
102	EGRC-solenoid valve	Engine is running. (Warm-up condition) └ Idle speed └ Engine speed is approximately 2,700 rpm or more (M/T models) └ 3,200 rpm or more (A/T models)	Approximately 0V
		Engine is running. (Warm-up condition) └ Engine speed is between idle and approximately 2,700 rpm or more (M/T models) └ 3,200 rpm or more (A/T models)	BATTERY VOLTAGE (11 - 14V)

GI  
WA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

Electrical Components Inspection (Cont'd)

\*Data are reference values.


TER-MINAL NO.	ITEM	CONDITION	*DATA
113	Valve timing control solenoid valve	Engine is running. └ Idle speed	BATTERY VOLTAGE (11 - 14V)
		Engine is running. └ Quickly depress accelerator pedal, then quickly release it.	0.2 - 0.5V



CAMSHAFT POSITION SENSOR

1. Remove camshaft position sensor from engine. (Camshaft position sensor harness connector should remain connected.)
2. Disconnect power transistor harness connector.
3. Turn ignition switch "ON".
4. Rotate camshaft position sensor shaft slowly by hand and check voltage between terminals **a**, **b** and ground.


Terminal	Voltage
<b>a</b> (120° signal)	Voltage fluctuates between 5V and 0V.
<b>b</b> (1° signal)	



If NG, replace camshaft position sensor.

After this inspection, diagnostic trouble code Nos. 11 and 21 might be displayed though the camshaft position sensor is functioning properly. In this case erase the stored memory.

5. Visually check signal plate for damage or dust.




MASS AIR FLOW SENSOR

1. Fold back mass air flow sensor harness connector rubber as shown in the figure if the harness connector is connected.
2. Turn ignition switch "ON".
3. Start engine and warm it up sufficiently.
4. Check voltage between terminal **b** and ground.


Conditions	Voltage V
Ignition switch "ON" (Engine stopped.)	Less than 1.0V
Idle (Engine is warm-up sufficiently.)	Approximately 0.8 - 1.5

Electrical Components Inspection (Cont'd)



- If NG, remove mass air flow sensor from air duct. Check hot film for damage or dust.

GI  
MA  
EM



ENGINE COOLANT TEMPERATURE SENSOR


- Disconnect engine coolant temperature sensor harness connector.
- Check resistance as shown in the figure.

LC  
EF & EC

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
80 (176)	0.30 - 0.33

If NG, replace engine coolant temperature sensor.

CL



IGNITION COIL


- Disconnect ignition coil harness connector.
- Check resistance as shown in the figure.

WT  
AT

Terminal	Resistance
① - ②	Approximately 0.8Ω

If NG, replace ignition coil.

FA  
RA



FUEL PUMP

- Disconnect fuel pump harness connector.
- Check resistance between terminals ① and ③.


**Resistance: Approximately 0.5Ω**

If NG, replace fuel pump.

BR  
ST  
BF  
HA  
EL  
IDX

Electrical Components Inspection (Cont'd)


POWER TRANSISTOR



1. Disconnect power transistor harness connector.
2. Check power transistor resistance between terminals with a digital tester as shown in the figure.

Terminal combination						Tester polarity	Resistance	Tester polarity	Resistance
d	d	d	d	d	d	⊕	Not ∞ or 0	⊖	Not ∞ or 0
a	b	c	e	f	g	⊖	Not ∞ or 0	⊕	Not ∞ or 0
d	d	d	d	d	d	⊕	Not ∞ or 0	⊖	∞
1	2	3	4	5	6	⊖	Not ∞ or 0	⊕	∞
a	b	c	e	f	g	⊕	Not ∞ or 0	⊖	∞
1	2	3	4	5	6	⊖	Not ∞ or 0	⊕	∞

If NG, replace power transistor.




EGRC-SOLENOID VALVE

Check air passage continuity.

Condition	Air passage continuity between (A) and (B)
12V direct current supply between terminals ① and ②	Yes
No supply	No

If NG, replace solenoid valve.




EGR VALVE

Apply vacuum to EGR vacuum port with a hand vacuum pump.

**EGR valve spring should lift.**

If NG, replace EGR valve.




EGRC-BPT VALVE

Plug one of two ports of EGRC-BPT valve.

Apply a pressure above 0.490 kPa (50 mmH<sub>2</sub>O, 1.97 inH<sub>2</sub>O) to check for leakage. If a leak is noted, replace valve.

Electrical Components Inspection (Cont'd)



**HEATED OXYGEN SENSOR**

Refer to "Diagnostic Procedure 30".  
(See page EF & EC-272.)

**HEATED OXYGEN SENSOR HEATER**

Check resistance between terminals (a) and (c).


**Resistance: 3 - 1,000Ω**

If NG, replace heated oxygen sensor.

GI

MA

EM



**EGR TEMPERATURE SENSOR**

Check resistance change and resistance value at 100°C (212°F).

- Resistance should decrease in response to temperature increase.

**Resistance: 100°C (212°F)**

**85.3 ± 8.53 kΩ**


If NG, replace EGR temperature sensor.

LC

EF & EC

FE

CL



**THROTTLE POSITION SENSOR**

1. Disconnect throttle position sensor harness connector.
2. Make sure that resistance between terminals (b) and (c) changes when opening throttle valve manually.

Accelerator pedal condition	Resistance kΩ
Completely released	Approximately 1
Partially released	1 - 9
Completely depressed	Approximately 9


If NG, replace throttle position sensor.

MT

AT

FA

RA



**CLOSED THROTTLE POSITION SWITCH (Idle position)**

1. Warm up engine sufficiently.
2. Disconnect closed throttle position switch harness connector.
3. Check continuity between terminals (b) and (c).

Accelerator pedal condition	Continuity
Released	Yes
Depressed	No

If NG, replace throttle position switch.

**Adjustment for throttle position sensor and throttle position switch**

If throttle position sensor, closed throttle position switch or wide open throttle position switch is replaced or removed, it is necessary to install it in the proper position, by following the procedure as shown below:

1. Install throttle position sensor body in throttle body. Do not tighten bolts.
2. Connect throttle position sensor and closed throttle position switch harness connector.

BR

ST

BF

HA

EL


IDX

**Electrical Components Inspection (Cont'd)**

3. Start engine and warm it up sufficiently.
4. Disconnect closed throttle position switch harness connector.
5. Check closed throttle position switch OFF → ON speed with circuit tester, closing throttle valve manually.

**Closed throttle position switch OFF → ON speed:**


**A/T: Engine speed in "N" position**  
**950 ± 150 rpm**

**IACV-AAC VALVE**


- Check IACV-AAC valve resistance.

**Resistance:**


**Approximately 10Ω**



- Check plunger for seizing or sticking.
- Check for broken spring.

**IACV-FICD SOLENOID VALVE**


- Check for clicking sound when applying 12V direct current to terminals.



- Check plunger for seizing or sticking.
- Check for broken spring.

Electrical Components Inspection (Cont'd)

POWER VALVE ACTUATOR



1. Disconnect power valve actuator vacuum hose.
2. Connect handy vacuum pump with power valve actuator.
3. Apply vacuum. Make sure that power valve begins to open between -13.3 and -26.7 kPa (-100 and -200 mmHg, -3.94 and -7.87 inHg) vacuum and there is no vacuum leak in the actuator.
4. If there is vacuum leakage, replace power valve actuator.


IACV-AIR REGULATOR

Water temperature	Air inlet
Approx. 20°C (68°F)	
80°C (176°F) or more	


1. Remove IAA unit from engine.
2. Immerse IAA unit in cold or hot water as shown, and check air flow.

Water temperature	When blowing from air inlet hole
20°C (68°F)	Air flows
80°C (176°F) or more	Almost no air flows

If NG, replace air cut valve.



POWER VALVE CONTROL SOLENOID VALVE




1. Disconnect power valve control solenoid valve harness connector.
2. Check solenoid valve, following the table as shown below:

Conditions	Continuity between port (A) and (B)
Supply 12V direct current between terminals ① and ②	Yes
No current supply	No

If NG, replace power valve control solenoid valve.

INJECTOR

No. 2, No. 4 and No. 6 cylinders



1. Disconnect injector harness connector.
2. Check resistance between terminals as shown in the figure.  
**Resistance: 10 - 14Ω**  
 If NG, replace injector.


Electrical Components Inspection (Cont'd)

No. 1, No. 3 and No. 5 cylinders

1. Disconnect sub-harness connector for injectors.
2. Check resistance between terminals, following the table as shown below:

Cylinder	Terminal No.	Resistance
No. 1	Ⓑ - Ⓓ	10 - 14Ω
No. 3	Ⓑ - Ⓒ	
No. 5	Ⓑ - Ⓐ	

If NG, replace injector.



KNOCK SENSOR


1. Disconnect knock sensor sub-harness connector.
2. Check continuity between terminal Ⓐ and ground.

Continuity should exist.

- It is necessary to use an ohmmeter which can measure more than 10 MΩ.

CAUTION:


Discard any knock sensor which has been dropped or undergone shocks; use a new one.



VALVE TIMING CONTROL (VTC) SOLENOID VALVE

Check valve timing control solenoid valve for normal operation by supplying it with battery voltage between terminals Ⓐ and Ⓑ.

If NG, replace solenoid valve.




NEUTRAL POSITION SWITCH

Check continuity between terminals Ⓐ and Ⓒ.

Conditions	Continuity
Shift to Neutral position	Yes
Shift to other position	No


If NG, replace neutral position switch.



INHIBITOR SWITCH

Check continuity between terminals Ⓐ and Ⓑ, Ⓕ.


Conditions	Continuity between terminals Ⓐ and Ⓑ	Continuity between terminals Ⓐ and Ⓕ
Shift to "P" position	Yes	No
Shift to "N" position	No	Yes
Shift to positions other than "P" and "N"	No	No





**Electrical Components Inspection (Cont'd)**  
**ECCS RELAY, FUEL PUMP RELAY, COOLING FAN RELAY-1 AND IGNITION COIL RELAY**

Check continuity between terminals ③ and ⑤.




SEF054F

Conditions	Continuity
12V direct current supply between terminals ① and ②	Yes
No current supply	No

If NG, replace relay.

**COOLING FAN RELAYS-2 AND -3**

Check continuity between terminals ③ and ⑤, ⑥ and ⑦.




SEC202B

Conditions	Continuity
12V direct current supply between terminals ① and ②	Yes
No current supply	No

If NG, replace relay.

**POWER STEERING OIL PRESSURE SWITCH**

1. Disconnect power steering oil pressure switch harness connector.
2. Check continuity between terminals ① and ②.




SEF677L

Conditions (Engine running)	Continuity
Steering wheel is being turned	Yes
Steering wheel is not being turned	No

If NG, replace power steering oil pressure switch.

**WIDE OPEN THROTTLE POSITION SWITCH**

1. Warm up engine sufficiently.
2. Check continuity between terminals ① and ②.



SEF896M


Accelerator pedal condition	Continuity
Released	No
Depressed	Yes

If NG, replace throttle position switch.

Electrical Components Inspection (Cont'd)

COOLING FAN MOTORS-1 AND -2



1. Disconnect cooling fan motor harness connectors.
2. Supply cooling fan motor terminals with battery voltage and check operation.



	Speed	Terminals	
		(⊕)	(⊖)
Cooling fan motor-1	Low	b	c
	High	a, b	c, d
Cooling fan motor-2	Low	b	c
	High	a, b	c, d

Cooling fan motor should operate.

If NG, replace cooling fan motor.



### Releasing Fuel Pressure

Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger.


1. Turn ignition switch "ON".
  2. Perform "FUEL PRES RELEASE" in "WORK SUPPORT" mode with CONSULT.
  3. Start engine.
  4. After engine stalls crank it two or three times to release all fuel pressure.
  5. Turn ignition switch off.
1. Remove fuel pump fuse.
  2. Start engine.
  3. After engine stalls, crank it two or three times to release all fuel pressure.
  4. Turn ignition switch off and reconnect fuel pump fuse.

GI  
MA  
EM  
LC  
EF & EC

### Fuel Pressure Check

- a. When reconnecting fuel line, always use new clamps.
  - b. Make sure that clamp screw does not contact adjacent parts.
  - c. Use a torque driver to tighten clamps.
  - d. Use Pressure Gauge to check fuel pressure.
  - e. Do not perform fuel pressure check while fuel pressure regulator control system is operating; otherwise, fuel pressure gauge might indicate incorrect readings.
1. Release fuel pressure to zero.
  2. Disconnect fuel hose between fuel filter and fuel tube (engine side).
  3. Install pressure gauge between fuel filter and fuel tube.
  4. Start engine and check for fuel leakage.

MT  
AT  
FA  
RA  
BR  
ST  
BF




5. Read the indication of fuel pressure gauge.
  - At idling:  
Approximately 245 kPa (2.5 kg/cm<sup>2</sup>, 36 psi)
  - A few seconds after ignition switch is turned OFF to ON:  
Approximately 294 kPa (3.0 kg/cm<sup>2</sup>, 43 psi)
6. Stop engine and disconnect fuel pressure regulator vacuum hose from intake manifold.
7. Plug intake manifold with a rubber cap.
8. Connect variable vacuum source to fuel pressure regulator.

EL  
IDX

**Fuel Pressure Check (Cont'd)**

9. Start engine and read indication of fuel pressure gauge as vacuum is changed.

**Fuel pressure should decrease as vacuum increases. If results are unsatisfactory, replace fuel pressure regulator.**



**Injector Removal and Installation**



1. Release fuel pressure to zero.
2. Drain coolant from radiator drain cock.
3. Remove or disconnect the following:
  - Related harnesses, wires and tubes
  - Intake manifold collector
 For details, refer to EM section.
4. Remove injectors with fuel tube assembly.
5. Push out any malfunctioning injector from fuel tube assembly.

**Do not extract injector by pinching connector.**

6. Replace or clean injector as necessary.
7. Install injector to fuel tube assembly.


**Always replace O-rings and insulators with new ones. Lubricate O-rings with a smear of engine oil.**

8. Install fuel tube assembly onto intake manifold.



9. Install front sub-fuel tube as follows:

- 1) Connect fuel hoses to fuel tubes.
- 2) Tighten clamps ①.
- 3) Install front sub-fuel tube.
- 4) Tighten clamps ②.




10. Install rear sub-fuel tube as follows:

- 1) Connect fuel hoses to fuel tubes.
- 2) Tighten clamps ①.
- 3) Install rear sub-fuel tube.
- 4) Tighten clamps ②.


**CAUTION:**

**After properly connecting fuel hose to injectors and fuel tube assembly, check connections for fuel leakage.**

11. Install any parts removed in reverse order of removal.



Description




The evaporative emission system is used to reduce hydrocarbons emitted into the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the carbon canister.

The fuel vapor from the sealed fuel tank is led into the canister which contains activated carbon and the vapor is stored there when the engine is not running.

The canister retains the fuel vapor until the canister is purged by the air drawn through the bottom of the canister to the intake manifold when the engine is running. When the engine runs at idle, the purge control valve is closed.

Only a small amount of stored vapor flows into the intake manifold through the constant purge orifice. As the engine speed increases, and the throttle vacuum rises higher, the purge control valve opens and the vapor is sucked into the intake manifold through both the main purge orifice and the constant purge orifice.




Inspection

ACTIVATED CARBON CANISTER

Check carbon canister as follows:

1. Blow air port (A) and ensure that there is no leakage.
2.
  - Apply vacuum to port (A).
  - Cover port (D) with hand.
  - Blow air in port (C) and ensure free flow out of port (B).

GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX



**Inspection (Cont'd)**


**FUEL CHECK VALVE (With rollover valve)**

**Check valve operation**

1. Blow air through connector on fuel tank side.  
A considerable resistance should be felt and a portion of air flow should be directed toward the canister side.
2. Blow air through connector on canister side.  
Air flow should be smoothly directed toward fuel tank side.
3. If fuel check valve is suspected of not properly functioning in steps 1 and 2 above, replace it.

**Rollover valve operation**

Ensure that continuity of air passage does not exist when the installed rollover valve is tilted to 90° or 180°.



**FUEL TANK VACUUM RELIEF VALVE**

1. Wipe clean valve housing.
2. Suck air through the cap. A slight resistance accompanied by valve clicks indicates that valve A is in good mechanical condition. Note also that, by further sucking air, the resistance should disappear with valve clicks.
3. Blow air on fuel tank side and ensure that continuity of air passage exists through valve B.
4. If valve is clogged or if no resistance is felt, replace cap as an assembly.

**Description**

This system returns blow-by gas to both the intake manifold and air inlet tubes.

The positive crankcase ventilation (PCV) valve is provided to conduct crankcase blow-by gas to the intake manifold.



During partial throttle operation of the engine, the intake manifold sucks the blow-by gas through the PCV valve.

Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air.

The ventilating air is then drawn from the air inlet tubes, through the hose connecting air inlet tubes to rocker cover, into the crankcase.

Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the valve, and its flow goes through the hose connection in the reverse direction.


On vehicles with an excessively high blow-by some of the flow will go through the hose connection to the air inlet tubes under all conditions.



**Inspection**

**PCV (Positive Crankcase Ventilation)**

With engine running at idle, remove PCV valve from cylinder head; if the valve is working properly, a hissing noise will be heard as air passes through it and a strong vacuum should be felt immediately when a finger is placed over valve inlet.



**VENTILATION HOSE**

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.

GI  
MA  
EM  
LC  
EF & EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

**General Specifications**

<b>PRESSURE REGULATOR</b>	
Regulated pressure kPa (kg/cm <sup>2</sup> , psi)	
Vacuum hose is connected	250.1 (2.55, 36.3)
Vacuum hose is disconnected	299.1 (3.05, 43.4)

**Inspection and Adjustment**

Idle speed*1	rpm	
No-load*2		
A/T (in "N" position)		750 ± 50
Air conditioner: ON		
A/T (in "N" position)		800 ± 50
Ignition timing	degree	15° ± 2° BTDC
Closed closed throttle position switch touch speed	rpm	
A/T (in "N" position)		Idle speed + 250 ± 150*3

\*1: Feedback controlled and needs no adjustments

\*2: Under the following conditions:

- Air conditioner switch: OFF
- Steering wheel: Kept straight
- Electric load: OFF (Lights, heater, fan & rear defogger)
- Cooling fan: OFF

\*3: Diagnostic test mode selector turned fully clockwise

**IGNITION COIL**

Primary voltage	V	12
Primary resistance [at 20°C (68°F)]	Ω	Approximately 1.0
Secondary resistance [at 20°C (68°F)]	Ω	8.2 - 12.4

**MASS AIR FLOW SENSOR**

Supply voltage	V	Battery voltage (11 - 14)
Output voltage	V	Approximately 1.0 - 1.3*

\*: Engine is warmed up sufficiently and idling under no-load.

**ENGINE COOLANT TEMPERATURE SENSOR**

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
80 (176)	0.30 - 0.33

**FUEL PUMP**

Resistance	Ω	Approximately 0
------------	---	-----------------

**EGR TEMPERATURE SENSOR**

Resistance [at 100°C (212°F)]	kΩ	85.3 ± 8.53
----------------------------------	----	-------------

**IACV-AAC VALVE (Step motor type)**

Resistance	Ω	Approximately 0.5
------------	---	-------------------

**INJECTOR**

Resistance	Ω	10 - 14
------------	---	---------

**RESISTOR**

Resistance	KΩ	Approximately 2.2
------------	----	-------------------

**THROTTLE POSITION SENSOR**

Accelerator pedal conditions	Resistance kΩ
Completely released	Approximately 1
Partially released	1 - 9
Completely depressed	Approximately 9

**IGNITION WIRE**

Resistance	kΩ/m (kΩ/ft)	Less than 30 (9.1)
------------	--------------	--------------------



**General Specifications**

<b>PRESSURE REGULATOR</b>	
Fuel pressure at idling kPa (kg/cm <sup>2</sup> , psi)	
Vacuum hose is connected	Approximately 245 (2.5, 36)
Vacuum hose is disconnected	Approximately 294 (3.0, 43)

GI

MA

**Inspection and Adjustment**

Idle speed*1	rpm	
No-load*2 M/T		750 ± 50
A/T (in "N" position)		790 ± 50
Air conditioner: ON (in "N" position)		800 ± 50
Ignition timing	degree	15 ± 2 BTDC
Throttle position sensor idle position	V	0.4 - 0.5

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX

**EGR TEMPERATURE SENSOR**

Resistance [at 100°C (212°F)]	kΩ	85.3 ± 8.53
----------------------------------	----	-------------

**HEATED OXYGEN SENSOR HEATER**

Resistance	Ω	3 - 1,000
------------	---	-----------

**IACV-AAC VALVE**

Resistance	Ω	Approximately 10
------------	---	------------------

**INJECTOR**

Resistance	Ω	10 - 14
------------	---	---------

**THROTTLE POSITION SENSOR**

Accelerator pedal conditions	Resistance kΩ
Completely released	Approximately 1
Partially released	1 - 9
Completely depressed	Approximately 9

\*1: Feedback controlled and needs no adjustments

\*2: Under the following conditions:

- Air conditioner switch: OFF
- Steering wheel: Kept straight
- Electric load: OFF (Lights, heater, fan & rear defogger)
- Cooling fan: OFF

**IGNITION COIL**

Primary voltage	V	12
Primary resistance [at 20°C (68°F)]	Ω	Approximately 0.8
Secondary resistance [at 20°C (68°F)]	Ω	∞

**MASS AIR FLOW SENSOR**

Supply voltage	V	Battery voltage (11 - 14)
Output voltage	V	0.8 - 1.5*

\*: Engine is warmed up sufficiently and idling under no-load.

**ENGINE COOLANT TEMPERATURE SENSOR**

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
80 (176)	0.30 - 0.33

**FUEL PUMP**

Resistance	Ω	Approximately 0.5
------------	---	-------------------