

A
EM
C
D
E
F
G
H
I
J
K
L
M

SECTION **EM**

ENGINE MECHANICAL

CONTENTS

MR20DE	
PRECAUTIONS	5
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	5
Precautions for Procedures without Cowl Top Cover....	5
Precautions Necessary for Steering Wheel Rotation After Battery Disconnect	5
OPERATION PROCEDURE	5
Precautions for Drain Coolant	6
Precautions for Disconnecting Fuel Piping	6
Precautions for Removal and Disassembly	6
Precautions for Inspection, Repair and Replacement	6
Precautions for Assembly and Installation	6
Parts Requiring Angular Tightening	6
Precautions for Liquid Gasket	7
REMOVAL OF LIQUID GASKET SEALING	7
LIQUID GASKET APPLICATION PROCEDURE....	7
PREPARATION	9
Special Service Tools	9
Commercial Service Tools	11
NOISE, VIBRATION AND HARSHNESS (NVH)	
TROUBLESHOOTING	13
NVH Troubleshooting — Engine Noise	13
Use the Chart Below to Help You Find the Cause of the Symptom.	14
DRIVE BELTS	15
Components	15
Checking Drive Belts	15
Tension Adjustment	15
Removal and Installation	15
REMOVAL	15
INSTALLATION	16
Components	16
Removal and Installation of Drive Belt Auto-Tensioner	16
REMOVAL	16
INSTALLATION	17
AIR CLEANER AND AIR DUCT	18
Components	18
Removal and Installation	18
REMOVAL	18
INSTALLATION	18
Changing Air Cleaner Filter	19
REMOVAL	19
INSPECTION AFTER REMOVAL	19
INSTALLATION	19
INTAKE MANIFOLD	20
Components	20
Removal and Installation	20
REMOVAL	20
INSTALLATION	21
INSPECTION AFTER INSTALLATION	22
EXHAUST MANIFOLD	23
Components	23
Removal and Installation	23
REMOVAL	23
INSPECTION AFTER REMOVAL	24
INSTALLATION	24
OIL PAN	26
Components	26
Removal and Installation	26
REMOVAL	26
INSPECTION AFTER REMOVAL	28
INSTALLATION	28
IGNITION COIL, SPARK PLUG AND ROCKER COVER	32
Components	32
Removal and Installation	32
REMOVAL	32
INSPECTION AFTER REMOVAL	33
INSTALLATION	33
FUEL INJECTOR AND FUEL TUBE	35
Components	35
Removal and Installation	35
REMOVAL	35
INSTALLATION	37

TIMING CHAIN	39	HOW TO SELECT MAIN BEARING	88
Components	39	Inspection After Disassembly	92
Removal and Installation	40	CRANKSHAFT END PLAY	92
REMOVAL	40	CONNECTING ROD SIDE CLEARANCE	92
INSPECTION AFTER REMOVAL	43	PISTON TO PISTON PIN OIL CLEARANCE	92
INSTALLATION	43	PISTON RING SIDE CLEARANCE	93
CAMSHAFT	48	PISTON RING END GAP	93
Components	48	CONNECTING ROD BEND AND TORSION	94
Removal and Installation	48	CONNECTING ROD BIG END DIAMETER	94
REMOVAL	48	CONNECTING ROD BUSHING OIL CLEAR- ANCE	94
INSPECTION AFTER REMOVAL	50	CYLINDER BLOCK TOP SURFACE DISTOR- TION	95
INSTALLATION	52	MAIN BEARING HOUSING INNER DIAMETER...	95
INSPECTION AFTER INSTALLATION	55	PISTON TO CYLINDER BORE CLEARANCE ...	96
Valve Clearance	56	CRANKSHAFT MAIN JOURNAL DIAMETER	97
INSPECTION	56	CRANKSHAFT PIN JOURNAL DIAMETER	97
ADJUSTMENT	58	OUT-OF-ROUND AND TAPER OF CRANK- SHAFT	97
OIL SEAL	60	CRANKSHAFT RUNOUT	97
Removal and Installation of Valve Oil Seal	60	CONNECTING ROD BEARING OIL CLEAR- ANCE	98
REMOVAL	60	MAIN BEARING OIL CLEARANCE	98
INSTALLATION	60	MAIN BEARING CRUSH HEIGHT	99
Removal and Installation of Front Oil Seal	61	CONNECTING ROD BEARING CRUSH HEIGHT	99
REMOVAL	61	MAIN BEARING CAP BOLT OUTER DIAMETER	100
INSTALLATION	61	CONNECTING ROD BOLT OUTER DIAMETER	100
Removal and Installation of Rear Oil Seal	62	CLOGGED OR DAMAGED OIL FILTER (FOR INTAKE VALVE TIMING CONTROL)	100
REMOVAL	62	FLYWHEEL DEFLECTION (M/T MODELS)	100
INSTALLATION	62	MOVEMENT AMOUNT OF FLYWHEEL (M/T MODELS)	100
CYLINDER HEAD	63	ENGINE ASSEMBLY	102
On-Vehicle Service	63	Components	102
CHECKING COMPRESSION PRESSURE	63	Removal and Installation	102
Components	64	REMOVAL	103
Removal and Installation	64	INSTALLATION	104
REMOVAL	64	INSPECTION AFTER INSTALLATION	105
INSPECTION AFTER REMOVAL	65	SERVICE DATA AND SPECIFICATIONS (SDS) ...	106
INSTALLATION	66	Standard and Limit	106
Components	67	GENERAL SPECIFICATIONS	106
Disassembly and Assembly	67	DRIVE BELT	106
DISASSEMBLY	67	WATER CONTROL VALVE	106
ASSEMBLY	68	EXHAUST MANIFOLD	106
Inspection After Disassembly	69	THERMOSTAT	106
VALVE DIMENSIONS	69	SPARK PLUG	106
VALVE GUIDE CLEARANCE	69	CYLINDER HEAD	106
VALVE GUIDE REPLACEMENT	70	VALVE	107
VALVE SEAT CONTACT	71	CAMSHAFT AND CAMSHAFT BEARING	110
VALVE SEAT REPLACEMENT	71	CYLINDER BLOCK	111
VALVE SPRING SQUARENESS	72	PISTON, PISTON RING AND PISTON PIN	112
VALVE SPRING DIMENSIONS AND VALVE SPRING PRESSURE LOAD	73	CONNECTING ROD	113
CYLINDER BLOCK	74	CRANKSHAFT	113
Components	74	MAIN BEARING	115
Disassembly and Assembly	75	CONNECTING ROD BEARING	115
DISASSEMBLY	75		
ASSEMBLY	78		
How to Select Piston and Bearing	84		
DESCRIPTION	84		
HOW TO SELECT PISTON	84		
HOW TO SELECT CONNECTING ROD BEAR- ING	85		

QR25DE

PRECAUTIONS	117	
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	117	
Precautions for Draining Coolant	117	
Precautions for Disconnecting Fuel Piping	117	
Precautions for Removal and Disassembly	117	
Precautions for Inspection, Repair and Replacement	117	
Precautions for Assembly and Installation	117	
Parts Requiring Angular Tightening	118	
Precautions for Liquid Gasket	118	
REMOVAL OF LIQUID GASKET SEALING	118	
LIQUID GASKET APPLICATION PROCEDURE	118	
PREPARATION	120	
Special Service Tools	120	
Commercial Service Tools	123	
NOISE, VIBRATION, AND HARSHNESS (NVH)		
TROUBLESHOOTING	125	
NVH Troubleshooting —Engine Noise	125	
Use the Chart Below to Help You Find the Cause of the Symptom.	126	
DRIVE BELTS	127	
Checking Drive Belts	127	
Tension Adjustment	127	
Removal and Installation	127	
REMOVAL	127	
INSTALLATION	128	
Removal and Installation of Drive Belt Auto-tensioner	128	
REMOVAL	128	
INSTALLATION	128	
AIR CLEANER AND AIR DUCT	130	
Removal and Installation	130	
REMOVAL	130	
INSTALLATION	130	
CHANGING THE AIR CLEANER ELEMENT ...	131	
INTAKE MANIFOLD	132	
Removal and Installation	132	
REMOVAL	132	
INSPECTION AFTER REMOVAL	134	
INSTALLATION	134	
INSPECTION AFTER INSTALLATION	135	
EXHAUST MANIFOLD AND THREE WAY CATALYST	136	
Removal and Installation	136	
REMOVAL	136	
INSPECTION AFTER REMOVAL	137	
INSTALLATION	137	
OIL PAN AND OIL STRAINER	138	
Removal and Installation	138	
REMOVAL	138	
INSPECTION AFTER REMOVAL	139	
INSTALLATION	139	
INSPECTION AFTER INSTALLATION	140	
IGNITION COIL	141	
Removal and Installation	141	A
REMOVAL	141	
INSTALLATION	141	
SPARK PLUG	142	EM
Removal and Installation	142	
REMOVAL	142	
INSPECTION AFTER REMOVAL	142	
INSTALLATION	143	C
FUEL INJECTOR AND FUEL TUBE	144	
Removal and Installation	144	
REMOVAL	144	D
INSTALLATION	145	
INSPECTION AFTER INSTALLATION	146	
ROCKER COVER	147	E
Removal and Installation	147	
REMOVAL	147	
INSTALLATION	147	
CAMSHAFT	149	F
Removal and Installation	149	
REMOVAL	149	
INSPECTION AFTER REMOVAL	151	G
INSTALLATION	154	
INSPECTION AFTER INSTALLATION	156	
INSPECTION OF CAMSHAFT SPROCKET (INT) OIL GROOVE	156	H
Valve Clearance	157	
INSPECTION	157	
ADJUSTMENT	158	I
TIMING CHAIN	160	
Removal and Installation	160	
REMOVAL	161	J
INSPECTION AFTER REMOVAL	164	
INSTALLATION	164	
OIL SEAL	168	K
Removal and installation of Valve Oil Seal	168	
REMOVAL	168	
INSTALLATION	168	L
Removal and Installation of Front Oil Seal	169	
REMOVAL	169	
INSTALLATION	169	
Removal and Installation of Rear Oil Seal	170	M
REMOVAL	170	
INSTALLATION	170	
CYLINDER HEAD	171	
On-Vehicle Service	171	
CHECKING COMPRESSION PRESSURE	171	
Removal and Installation	172	
REMOVAL	172	
INSPECTION AFTER REMOVAL	172	
INSTALLATION	173	
Disassembly and Assembly	174	
DISASSEMBLY	174	

ASSEMBLY	175	ANCE (SMALL END)	201
Inspection After Disassembly	176	CYLINDER BLOCK DISTORTION	202
CYLINDER HEAD DISTORTION	176	INNER DIAMETER OF MAIN BEARING HOUSING	202
VALVE DIMENSIONS	176	PISTON TO CYLINDER BORE CLEARANCE	203
VALVE GUIDE CLEARANCE	176	OUTER DIAMETER OF CRANKSHAFT JOURNAL	204
VALVE GUIDE REPLACEMENT	177	OUTER DIAMETER OF CRANKSHAFT PIN	204
VALVE SEAT CONTACT	178	OUT-OF-ROUND AND TAPER OF CRANKSHAFT	204
VALVE SEAT REPLACEMENT	178	CRANKSHAFT RUNOUT	204
VALVE SPRING SQUARENESS	179	OIL CLEARANCE OF CONNECTING ROD BEARING	205
VALVE SPRING DIMENSIONS AND VALVE SPRING PRESSURE LOAD	179	OIL CLEARANCE OF MAIN BEARING	205
ENGINE ASSEMBLY	181	CRUSH HEIGHT OF MAIN BEARING	206
Removal and Installation	181	OUTER DIAMETER OF LOWER CYLINDER BLOCK BOLT	206
REMOVAL	182	OUTER DIAMETER OF CONNECTING ROD BOLT	206
INSTALLATION	183	MOVEMENT AMOUNT OF FLYWHEEL (M/T MODEL)	206
INSPECTION AFTER INSTALLATION	183	SERVICE DATA AND SPECIFICATIONS (SDS) ...	208
CYLINDER BLOCK	184	Standard and Limit	208
Disassembly and Assembly	184	GENERAL SPECIFICATIONS	208
DISASSEMBLY	185	DRIVE BELTS	208
ASSEMBLY	187	INTAKE MANIFOLD AND EXHAUST MANIFOLD	208
How to Select Piston and Bearing	192	SPARK PLUG	208
DESCRIPTION	192	CYLINDER HEAD	209
HOW TO SELECT A PISTON	192	VALVE	209
HOW TO SELECT A CONNECTING ROD BEARING	193	CAMSHAFT AND CAMSHAFT BEARING	212
HOW TO SELECT A MAIN BEARING	195	CYLINDER BLOCK	213
Inspection After Disassembly	198	PISTON, PISTON RING, AND PISTON PIN	214
CRANKSHAFT SIDE CLEARANCE	198	CONNECTING ROD	215
CONNECTING ROD SIDE CLEARANCE	199	CRANKSHAFT	216
PISTON AND PISTON PIN CLEARANCE	199	MAIN BEARING	217
PISTON RING SIDE CLEARANCE	200	CONNECTING ROD BEARING	218
PISTON RING END GAP	200		
CONNECTING ROD BEND AND TORSION	200		
CONNECTING ROD BEARING (BIG END)	201		
CONNECTING ROD BUSHING OIL CLEARANCE (SMALL END)	201		

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

EBS00Z94

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.


WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions for Procedures without Cowl Top Cover

EBS00Z95

When performing the procedure after removing cowl top cover, cover the lower end of windshield.



Precautions Necessary for Steering Wheel Rotation After Battery Disconnect

EBS00Z96

NOTE:

- This Procedure is applied only to models with Intelligent Key system and NATS (NISSAN ANTI-THEFT SYSTEM).
- Remove and install all control units after disconnecting both battery cables with the ignition knob in the “LOCK” position.
- Always use CONSULT-II to perform self-diagnosis as a part of each function inspection after finishing work. If DTC is detected, perform trouble diagnosis according to self-diagnostic results.

For models equipped with the Intelligent Key system and NATS, an electrically controlled steering lock mechanism is adopted on the key cylinder.

For this reason, if the battery is disconnected or if the battery is discharged, the steering wheel will lock and steering wheel rotation will become impossible.

If steering wheel rotation is required when battery power is interrupted, follow the procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

2. Use the Intelligent Key or mechanical key to turn the ignition switch to the “ACC” position. At this time, the steering lock will be released.

PRECAUTIONS

[MR20DE]

3. Disconnect both battery cables. The steering lock will remain released and the steering wheel can be rotated.
4. Perform the necessary repair operation.
5. When the repair work is completed, return the ignition switch to the "LOCK" position before connecting the battery cables. (At this time, the steering lock mechanism will engage.)
6. Perform a self-diagnosis check of all control units using CONSULT-II.

Precautions for Drain Coolant

EBS00Z97

- Drain coolant when engine is cooled.

Precautions for Disconnecting Fuel Piping

EBS00Z98

- Before starting work, make sure no fire or spark producing items are in the work area.
- Release fuel pressure before disassembly.
- After disconnecting pipes, plug openings to stop fuel leakage.

Precautions for Removal and Disassembly

EBS00Z99

- When instructed to use special service tools, use the specified tools. Always be careful to work safely, avoid forceful or uninstructed operations.
- Exercise maximum care to avoid damage to mating or sliding surfaces.
- Cover openings of engine system with tape or the equivalent, if necessary, to seal out foreign materials.
- Mark and arrange disassembly parts in an organized way for easy troubleshooting and assembly.
- When loosening nuts and bolts, as a basic rule, start with the one furthest outside, then the one diagonally opposite, and so on. If the order of loosening is specified, do exactly as specified. Power tools may be used where noted in the step.

Precautions for Inspection, Repair and Replacement

EBS00Z9A

- Before repairing or replacing, thoroughly inspect parts. Inspect new replacement parts in the same way, and replace if necessary.

Precautions for Assembly and Installation

EBS00Z9B

- Use torque wrench to tighten bolts or nuts to specification.
- When tightening nuts and bolts, as a basic rule, equally tighten in several different steps starting with the ones in center, then ones on inside and outside diagonally in this order. If the order of tightening is specified, do exactly as specified.
- Replace with new gasket, packing, oil seal or O-ring.
- Thoroughly wash, clean, and air-blow each part. Carefully check oil or coolant passages for any restriction and blockage.
- Avoid damaging sliding or mating surfaces. Completely remove foreign materials such as cloth lint or dust. Before assembly, oil sliding surfaces well.
- Release air within route after draining coolant.
- Before starting engine, apply fuel pressure to fuel lines with turning ignition switch ON (with engine stopped). Then make sure that there are no leaks at fuel line connections.
- After repairing, start engine and increase engine speed to check coolant, fuel, oil, and exhaust systems for leakage.

Parts Requiring Angular Tightening

EBS00Z9C

- Use an angle wrench for the final tightening of the following engine parts:
 - Cylinder head bolts
 - Camshaft sprocket (INT)
 - Main bearing cap bolts
 - Connecting rod cap nuts
 - Crankshaft pulley bolt (No angle wrench is required as the bolt flange is provided with notches for angular tightening)

Tool number : KV10112100 (BT-8653-A)

PRECAUTIONS

[MR20DE]

- Do not use a torque value for final tightening.
- The torque value for these parts are for a preliminary step.
- Ensure thread and seat surfaces are clean and coated with engine oil.

Precautions for Liquid Gasket REMOVAL OF LIQUID GASKET SEALING

EBS00Z9D

EM

- After removing the bolts and nuts, separate the mating surface and remove the sealant using Tool.

Tool number : KV10111100 (J-37228)


CAUTION:

Be careful not to damage the mating surfaces.

- In areas where the cutter is difficult to use, use a plastic hammer to lightly tap (1) the cutter where the RTV Silicone Sealant is applied. Use a plastic hammer to slide the cutter (2) by tapping on the side.


CAUTION:

If for some unavoidable reason a tool such as a flat-bladed screwdriver is used, be careful not to damage the mating surfaces.





LIQUID GASKET APPLICATION PROCEDURE

1. Using a scraper, remove the old Silicone RTV Sealant adhering to the gasket application surface and the mating surface.
 - Remove the sealant completely from the groove of the gasket application surface, bolts, and bolt holes.
2. Thoroughly clean the gasket application surface and the mating surface and remove adhering moisture, grease and foreign materials.
3. Attach the sealant tube to the tube presser.
Use Genuine Silicone RTV Sealant or equivalent. Refer to [GI-44, "Recommended Chemical Products and Sealants"](#).
4. Apply the sealant without breaks to the specified location using Tool.



Tool number WS39930000 (-)

- If there is a groove for the sealant application, apply the sealant to the groove.
- As for the bolt holes, normally apply the sealant inside the holes. If specified, it should be applied outside the holes. Make sure to read the text of this manual.
- Within five minutes of the sealant application, install the mating component.
- If the sealant protrudes, wipe it off immediately.
- Do not retighten after the installation.
- After 30 minutes or more have passed from the installation, fill the engine with the specified oil and coolant. Refer to [MA-14, "MR20DE"](#).



PRECAUTIONS

[MR20DE]

CAUTION:

Follow all specific instructions in this manual.

PREPARATION

[MR20DE]







PF0:00002

EBS00Z9E

PREPARATION

Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
KV10111100 (J-37228) Seal cutter	Removing steel oil pan and rear timing chain case  NT046
KV10112100 (BT-8653-A) Angle wrench	Tightening bolts for bearing cap, cylinder head, etc.  NT014
KV10107902 (J-38959) Valve oil seal puller	Removing valve oil seal  S-NT011
EM03470000 (J-8037) Piston ring compressor	Installing piston assembly into cylinder bore  NT044
KV101092S0 (J-26336-B) Valve spring compressor 1 KV10109210 (J-26336-20) Attachment 2 KV10109220 (—) 3. KV10109230 Adapter (M8)	Disassembling and assembling valve mechanism  NT718
WS39930000 (—) Tube presser	Pressing the tube of liquid gasket  NT052

A

EM

C

D

E

F

G

H

I

J

K


L

M


PREPARATION

[MR20DE]


Tool number (Kent-Moore No.) Tool name	Description
ST16610001 (J-23907) Pilot bushing puller	Removing crankshaft pilot bushing
KV11103000 (—) Pulley puller	Removing crankshaft pulley
KV991J0050 (J-44626) Air fuel sensor Socket	Loosening or tightening air fuel ratio A/F sensor a: 22 mm (0.87 in)
KV10114400 (J-38365) Heated oxygen sensor wrench	Loosening or tightening rear heated oxygen sensor a: 22 mm (0.87 in)
KV11105210 (J-44716) Stopper plate	Securing diveplate and flywheel
KV10115600 (J-38958) Valve oil seal drift	Installing valve oil seal Use side A. a: 20 (0.79) dia b: 13 (0.51) dia. c: 10.3 (0.406) dia d: 8 (0.31) dia. e: 10.7 (0.421) f: 5 (0.20)
KV10115801 (—) Oil filter wrench	Removing and installing oil filter a: 64.3 mm (2.531 in)




NT045




NT676




LBA0444E




NT636



ZZA0009D



S-NT603










S-NT375

PREPARATION

[MR20DE]


EBS00Z9F


Commercial Service Tools

(Kent-Moore No.) Tool name	Description	A
(BT-3373-F) Belt tension gauge  AMA126	Checking drive belt tension	EM
Power tool  PBIC0190E	Loosening bolts and nuts	C D E
Spark plug wrench  14 mm (0.55 in) PBIC2982E	Removing and installing spark plug	F G H
Valve seat cutter set  NT048	Finishing valve seat dimensions	I J
Piston ring expander  NT030	Removing and installing piston ring	K L
KV10109300 (—) Pulley holder  NT628	Removing and installing crankshaft pulley	M
KV10111800 Valve guide drift  PBIC4012E	Removing and installing valve guide	

PREPARATION

[MR20DE]

(Kent-Moore No.) Tool name	Description
Valve guide reamer  <p style="text-align: right;">PBIC4013E</p>	(1): Reaming valve guide inner hole (2): Reaming hole for oversize valve guide
(J-43897-18) (J-43897-12) Oxygen sensor thread cleaner	Reconditioning the exhaust system threads before installing a new oxygen sensor and Air Fuel ratio sensor (Use with anti-seize lubricant shown below.) a: J-43897-18 (18 mm dia.) Air Fuel ratio sensors b: J-43897-12 (12 mm dia.) Air Fuel ratio sensors
Anti-seize lubricant (Permatex 133AR or equivalent meeting MIL specification MIL-A-907)	Lubricating oxygen sensor thread cleaning tool when reconditioning exhaust system threads
E20 Torx® Socket (J-45816)	Removing and installing drive plate and fly-wheel bolts



NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

[MR20DE]

- | | | |
|-------------------------|-------------------------------------|--------------------------------------|
| 1. Piston pin noise | 2. Piston slap noise | 3. Main bearing noise |
| 4. Water pump noise | 5. Timing chain and tensioner noise | 6. Drive belt noise (stick/slipping) |
| 7. Tappet noise | 8. Camshaft bearing noise | 9. Connecting rod noise |
| A. Rotational mechanism | B. Water pump | C. Timing chain |
| D. Drive belt | E. Crankshaft pulley | F. A/C compressor |
| G. Water pump | H. Alternator | I. Tension pulley |
| J. Valve mechanism | K. Valves | |

Use the Chart Below to Help You Find the Cause of the Symptom.

EBS00Z9H

1. Locate the area where noise occurs.
2. Confirm the type of noise.
3. Specify the operating condition of engine.
4. Check specified noise source.


If necessary, repair or replace these parts.

Location of noise	Type of noise	Operating condition of engine						Source of noise	Check item	Reference page
		Before warm-up	After warm-up	When starting	When idling	When racing	While driving			
Top of engine Rocker cover Cylinder head	Ticking or clicking	C	A	—	A	B	—	Tappet noise	Valve clearance	EM-56
	Rattle	C	A	—	A	B	C	Camshaft bearing noise	Camshaft journal oil clearance Camshaft runout	EM-50 EM-51
Crankshaft pulley Cylinder block (Side of engine) Oil pan	Slap or knock	—	A	—	B	B	—	Piston pin noise	Piston to piston pin oil clearance Connecting rod bushing oil clearance	EM-92 EM-95
	Slap or rap	A	—	—	B	B	A	Piston slap noise	Piston to cylinder bore clearance Piston ring side clearance Piston ring end gap Connecting rod bend and torsion	EM-96 EM-93 EM-93 EM-94
	Knock	A	B	C	B	B	B	Connecting rod bearing noise	Connecting rod bushing oil clearance Connecting rod bearing oil clearance	EM-94 EM-98
	Knock	A	B	—	A	B	C	Main bearing noise	Main bearing oil clearance Crankshaft runout	EM-98 EM-97
Front of engine Front cover	Tapping or ticking	A	A	—	B	B	B	Timing chain and chain tensioner noise	Timing chain cracks and wear Timing chain tensioner operation	EM-43
Front of engine	Squeaking or fizzing	A	B	—	B	—	C	Drive belt (Sticking or slipping)	Drive belt deflection	EM-15
	Creaking	A	B	A	B	A	B	Drive belt (Slipping)	Idler pulley bearing operation	
	Squall Creak	A	B	—	B	A	B	Water pump noise	Water pump operation	CO-16

A: Closely related B: Related C: Sometimes related —: Not related

DRIVE BELTS

Components



- | | | |
|--|---|----------------------|
| 1. Alternator | 2. Drive belt auto-tensioner | 3. Crankshaft pulley |
| 4. A/C compressor (models with A/C)
Idler pulley (models without A/C) | 5. Water pump | 6. Drive belt |
| A. Possible use range | B. Range when new drive belt is installed | C. Indicator |

Checking Drive Belts

WARNING:

Be sure to perform this step when the engine is stopped.

- Make sure that the indicator (notch on fixed side) of drive belt auto-tensioner is within the possible use range (A).

NOTE:

- Check the drive belt auto-tensioner indication when the engine is cold.
- When new drive belt is installed, the indicator (notch on fixed side) should be within the range (B).
- Visually check entire drive belt for wear, damage or cracks.
- If the indicator (notch on fixed side) is out of the possible use range or belt is damaged, replace drive belt.

Tension Adjustment

Belt tension is not necessary, as it is automatically adjusted by drive belt auto-tensioner.

Removal and Installation


REMOVAL

1. Hold the hexagonal part (A) of drive belt auto-tensioner (1) with a wrench securely. Then move the wrench handle in the direction of arrow (loosening direction of tensioner).

CAUTION:

Never place hand in a location where pinching may occur if the holding tool accidentally comes off.

2. Insert a rod such as short-length screwdriver approximately 6 mm (0.24 in) in diameter into the hole (B) of the retaining boss to fix drive belt auto-tensioner.
3. Remove drive belt.




INSTALLATION

1. Hold the hexagonal part (A) of drive belt auto-tensioner (1) with a box wrench securely. Then move the wrench handle in the direction of arrow (loosening direction of tensioner).

CAUTION:

Never place hand in a location where pinching may occur if the holding tool accidentally comes off.

2. Insert a rod such as short-length screwdriver approximately 6 mm (0.24 in) in diameter into the hole (B) of retaining boss to fix drive belt auto-tensioner.
3. Install drive belt.




CAUTION:

- Confirm drive belt is completely set to pulleys.
- Check for engine oil, working fluid and engine coolant are not adhered to drive belt and each pulley groove.

4. Release drive belt auto-tensioner, and apply tension to drive belt.
5. Turn crankshaft pulley clockwise several times to equalize tension between each pulley.
6. Confirm tension of drive belt at indicator (notch on fixed side) is within the possible use range. Refer to [EM-15, "Checking Drive Belts"](#).

Components

EBS0029M



: N•m (kg-m, ft-lb)

- | | | |
|---------------------------------|-------------------------------|--------------------------------------|
| 1. Front cover | 2. Drive belt auto-tensioner | 3. Idler pulley (models without A/C) |
| 4. Bracket (models without A/C) | 5. Shaft (models without A/C) | |

Removal and Installation of Drive Belt Auto-Tensioner

EBS0029N

REMOVAL

1. Remove drive belt. Refer to [EM-15, "Removal and Installation"](#).
2. Release the fixed drive belt auto-tensioner pulley.
3. Loosen bolt and remove drive belt auto-tensioner.

NOTE:

Use TORX socket (size T50).

4. Remove idler pulley and bracket (models without A/C).

INSTALLATION

Installation is the reverse order of removal.

CAUTION:

- When installing drive belt auto-tensioner, be careful not to interfere with water pump pulley.
- If there is damage greater than peeled paint, replace drive belt auto-tensioner and/or idler pulley.

A

EM

C

D

E

F

G

H

I

J

K

L


M

AIR CLEANER AND AIR DUCT

PFP:16500

Components

EBS00Z90



- | | | |
|-----------------------|--|---------------------|
| 1. Air cleaner filter | 2. Mass air flow sensor | 3. O-ring |
| 4. Holder | 5. Air cleaner cover | 6. Air duct |
| 7. PCV hose | 8. Clip | 9. Air duct (Inlet) |
| 10. Resonator | 11. Air duct | 12. Grommet |
| 13. Air cleaner case | A. To electric throttle control actuator | B. To rocker cover |

Removal and Installation

REMOVAL

EBS00Z9P

1. Remove the air duct (inlet).
2. Remove the air cleaner filter from the air cleaner case. Refer to [EM-19, "Changing Air Cleaner Filter"](#) .
3. Remove the air duct [between air duct (inlet) and air cleaner case] from the air cleaner case.
4. Remove the PCV hose.
5. Remove the air duct (between air cleaner case and electric throttle control actuator).
 - Add marks as necessary for easier installation.
6. Remove air cleaner case with the following procedure.
 - a. Remove battery. Refer to [SC-4, "BATTERY"](#) .
 - b. Disconnect harness connector from mass air flow sensor.
 - c. Remove the air cleaner case.
7. Remove the mass air flow sensor from the air cleaner case, if necessary.

CAUTION:

- Handle it carefully and avoid impacts.
- Do not touch sensor part.

INSTALLATION

Installation is in the reverse order of removal.


- Align marks.
- Attach each joint securely.
- Screw clamps firmly.

Changing Air Cleaner Filter REMOVAL

EBS00Z9Q

EM

1. Unclip the tabs (A) of both ends of the air cleaner cover (1).



2. Remove the air cleaner filter and holder assembly from the air cleaner case.
3. Remove the air cleaner filter from the holder.

INSPECTION AFTER REMOVAL

It is necessary to replace it at the recommended intervals, more often under dusty driving conditions. Refer to [MA-8, "PERIODIC MAINTENANCE"](#) .

INSTALLATION

Installation is in the reverse order of removal.

A
C
D
E
F
G
H
I
J
K
L
M


INTAKE MANIFOLD

PFP:14003

Components

EBS00Z9R

SEC. 118•140•163•211•223



- | | | |
|--|---------------------------------------|-------------|
| 1. Hose clamp | 2. Bracket | 3. PCV hose |
| 4. Gasket | 5. Intake manifold | 6. O-ring |
| 7. EVAP canister purge volume control solenoid valve | 8. Electric throttle control actuator | 9. Gasket |

Removal and Installation

EBS00Z9S

REMOVAL

1. Remove engine cover (1).
2. Drain engine coolant. Refer to [CO-10, "DRAINING ENGINE COOLANT"](#).

CAUTION:

Perform this step when engine is cold.

NOTE:

This step is unnecessary when putting plugs to water hoses (to electronic throttle control actuator)

- a. Disconnect water hoses from electronic throttle control actuator.
- b. Remove electronic throttle control actuator.


CAUTION:

- Handle carefully to avoid any shock to electric throttle control actuator.
- Never disassemble.

3. Remove oil level gauge.

CAUTION:

Cover the oil level gauge guide openings to avoid entry of foreign materials.




INTAKE MANIFOLD

[MR20DE]

- Loosen and remove intake manifold (1) bolts (A) (B).

← : Engine front



- Loosen bolts in reverse order as shown.

← : Engine front

CAUTION:


Cover engine openings to avoid entry of foreign materials.

- Remove EVAP canister purge volume control solenoid valve from intake manifold, if necessary.

CAUTION:

Handle it carefully and avoid impacts.

- Remove intake manifold.



INSTALLATION


- Install intake manifold.

NOTE:

Be sure the intake manifold gasket is seated correctly in groove of intake manifold.

- Tighten bolts in numerical order as shown.

← : Engine front




INTAKE MANIFOLD

[MR20DE]


3. Tighten intake manifold bolt (A). Then tighten intake manifold bolt (B).

- 1 : Intake manifold
⇐ : Engine front



4. Install electronic throttle control actuator
5. Install water hoses (3), (5) to electronic throttle control actuator as shown.

- 1 : Electric throttle control actuator
2 : Clamp
4 : Water outlet
A : Paint Mark
B : The clamp shall not interfere with the bulged section.



6. Installation of the remaining components is in the reverse order of removal.


INSPECTION AFTER INSTALLATION

- Check for leaks of engine coolant. Refer to [CO-10. "CHECKING COOLING SYSTEM FOR LEAKS"](#) .
- Start and warm up the engine. Visually check for engine coolant leaks.

EXHAUST MANIFOLD

Components

SEC. 140•226



- | | | |
|---------------------------|---------------------|-----------------------|
| 1. Exhaust manifold cover | 2. Exhaust manifold | 3. Gasket |
| 4. Stud bolt | 5. Bracket | 6. A/F ratio sensor 1 |
| 7. Exhaust manifold stay | ↔ Engine front | |

Removal and Installation


REMOVAL

1. Remove exhaust front tube. Refer to [EX-2, "Removal and Installation"](#).
2. Remove exhaust manifold cover.
3. Remove the A/F sensor 1, using Tool (A).

Tool number :KV991J0050 (J-44626)

CAUTION:

Handle it carefully and avoid impacts.



4. Remove exhaust manifold side bolt of exhaust manifold stay.


EXHAUST MANIFOLD

[MR20DE]

- Loosen nuts in reverse order as shown and remove exhaust manifold.

⇐ : Engine front

CAUTION:
Cover engine openings to avoid entry of foreign materials.



INSPECTION AFTER REMOVAL

Surface Distortion


- Using straightedge (B) and feeler gauge (A), check the surface distortion of exhaust manifold mating surface in each exhaust port and entire part.

Limit:

Each exhaust port : 0.3 mm (0.012 in)

Entire part : 0.7 mm (0.028 in)


- If it exceeds the limit, replace exhaust manifold.



INSTALLATION


- Install exhaust manifold gasket to cylinder head as shown.

⇐ : Engine front



- Tighten exhaust manifold nuts to specification in two stages in the numerical order as shown.

⇐ : Engine front




EXHAUST MANIFOLD

[MR20DE]

3. Install exhaust manifold stay (2) in the direction as shown.

- 1 : Exhaust manifold
- A : Upper mark
- ← : Engine front



4. Install the A/F ratio sensor 1, using Tool


Tool number : KV991J0050 (J-44626)

CAUTION:

- Handle it carefully and avoid impacts.
- Before installing a new A/F ratio sensor, clean the exhaust tube threads using suitable tool and approved anti-seize lubricant.
- Do not over-tighten the A/F ratio sensor. Doing so may damage the A/F ratio sensor, resulting in the MIL coming on.

Tool number : — (J-43897-12)

Tool number : — (J-43897-18)



5. Installation of the remaining parts is in the reverse order of removal.

A
EM
C
D
E
F
G
H
I
J
K
L
M

OIL PAN

[MR20DE]

- Prolonged and repeated contact with used engine oil may cause skin cancer; try to avoid direct skin contact with used oil. If skin contact is made, wash thoroughly with soap or hand cleaner as soon as possible.

1. Drain engine oil. Refer to [LU-6, "Changing Engine Oil"](#) .
2. Remove engine and transaxle assembly. Refer to [EM-102, "Removal and Installation"](#) .
3. Remove oil filter using Tool.


Tool number : KV10115801 (—)

CAUTION:

When removing, prepare a shop cloth to absorb any engine oil leakage or spillage.

4. Remove oil pan (lower) bolts in reverse order as shown.

← : Engine front




5. After removing the bolts and nuts, separate the mating surface and remove the sealant using Tool.

Tool number : KV10111100 (J-37228)


CAUTION:

Be careful not to damage the mating surfaces.



6. Remove the following parts:
 - Flywheel (M/T models) or drive plate (CVT models); Refer to [EM-74, "CYLINDER BLOCK"](#) .
 - Front cover, timing chain, oil pump drive chain; Refer to [EM-39, "TIMING CHAIN"](#) .
7. Remove oil pan (lower) bolts in reverse order as shown.

← : Engine front



OIL PAN


[MR20DE]

8. Insert a screwdriver shown by the arrow (←) and open up a crack between oil pan (upper) and cylinder block.

← : Engine front

CAUTION:

A more adhesive liquid gasket is applied compared to previous types when shipped, so it should not be forced off the position not specified.




9. After removing the bolts, separate the mating surface and remove the sealant using Tool.

Tool number : KV10111100 (J-37228)

- Slide (1) the Tool by tapping (2) its side with a hammer to remove the lower oil pan from the upper oil pan.

CAUTION:

Be careful not to damage the mating surfaces.



10. Remove O-ring between cylinder block and oil pan (upper).

INSPECTION AFTER REMOVAL

Oil Filter

Clean oil strainer portion (part of the oil pump) if any object attached.


INSTALLATION

1. Use a scraper (A) to remove old liquid gasket from mating surfaces.

- Remove the old liquid gasket from mating surface of cylinder block.
- Remove old liquid gasket from the bolt holes and threads.

CAUTION:

Never scratch or damage the mating surfaces when cleaning off old liquid gasket.



OIL PAN

[MR20DE]

2. Apply the sealant without breaks to the specified location using Tool.


Use Genuine Silicone RTV Sealant or equivalent. Refer to GI-44, "Recommended Chemical Products and Sealants" .

Tool number WS39930000 (-)

- 1 : Oil pan (upper)
- A : 2 mm protruded to outside
- B : 2 mm protruded to rear oil seal mounting side
- ⇐ : Engine front
- ➡ : Engine outside

CAUTION:

Apply liquid gasket to outside of bolt hole for the positions shown by ▲ marks.




3. Install new O-ring at cylinder block side.

CAUTION:

Install avoiding misalignment of O-ring.

4. Tighten bolts in numerical order as shown.

- ⇐ : Engine front



5. Install rear oil seal with the following procedure.

CAUTION:

- **The installation of rear oil seal should be completed within 5 minutes after installing oil pan (upper).**

- **Always replace rear oil seal with new one.**


- **Never touch oil seal lip.**

- a. Wipe off liquid gasket protruding to the rear oil seal mating part of oil pan (upper) and cylinder block using a scraper.
- b. Apply engine oil to entire outside area of rear oil seal.

OIL PAN

[MR20DE]

- c. Press-fit the rear oil seal using a drift with outer diameter 115 mm (4.53 in) and inner diameter 90 mm (3.54 in) (A) (commercial service tool).



- Press-fit to the specified dimensions as shown.

1 : Rear oil seal


A : Cylinder block rear end surface

CAUTION:

- Never touch the grease applied to the oil seal lip.
- Be careful not to damage the rear oil seal mounting part of oil pan (upper) and cylinder block or the crankshaft.
- Press-fit straight, making sure that rear oil seal does not curl or tilt.

NOTE:

The standard surface of the dimension is the rear end surface of cylinder block.



6. Install oil pump.


- Tighten bolts in numerical order as shown.

1 : Oil pump

2 : Oil pan (upper)


← : Engine front

7. Install oil pump sprocket, oil pump drive chain and other related parts if removed.



8. Use a scraper (A) to remove old liquid gasket from mating surfaces.

- Also remove old liquid gasket from mating surface of oil pan (upper).
- Remove old liquid gasket from the bolt holes and threads.



OIL PAN

[MR20DE]


9. Apply the sealant without breaks to the specified location using Tool.

Use Genuine Silicone RTV Sealant or equivalent. Refer to GI-44, "Recommended Chemical Products and Sealants"

Tool number WS39930000 (-)

1 : Oil pan (lower)

← : Engine outside




10. Tighten bolts in numerical order as shown.

↔ : Engine front


11. Install oil filter with the following procedure:

- Remove foreign materials adhering to the oil filter installation surface.
- Apply new engine oil to the oil seal contact surface of new oil filter.



- Screw oil filter manually until it touches the installation surface, then tighten it by 2/3 turn. Or tighten to specification.

Oil filter: : 17.7 N·m (1.8 kg·m, 13 ft·lb)




12. Installation of the remaining components is in the reverse order of removal.

IGNITION COIL, SPARK PLUG AND ROCKER COVER

PF202448

Components

EBS00Z9X



- | | | |
|------------------|-------------------------------------|-----------------------|
| 1. PCV hose | 2. Rocker cover | 3. Spark plug |
| 4. Ignition coil | 5. PCV hose | 6. PCV valve |
| 7. O-ring | 8. Gasket | |
| A. To air duct | B. Refer to EM-33 . | C. To intake manifold |

Removal and Installation

REMOVAL

EBS00Z9Y

- Remove intake manifold. Refer to [EM-20, "INTAKE MANIFOLD"](#).
- Remove ignition coil.


CAUTION:

- Handle it carefully and avoid impacts.
- Never disassemble.

- Remove spark plug using suitable tool.

CAUTION:


Never drop or shock it.



IGNITION COIL, SPARK PLUG AND ROCKER COVER

[MR20DE]


- Remove rocker cover.
 - Loosen bolts in reverse order as shown.
 - ⇐ Engine front




INSPECTION AFTER REMOVAL

CAUTION:

- Never drop or shock spark plug.
- Checking and adjusting spark plug gap is not required between change intervals.



- If spark plug tip is covered with carbon, a spark plug cleaner may be used.
 - Cleaner air pressure : Less than 588 kPa (5.88 bar, 6 kg/cm², 85 psi)
 - Cleaning time : Less than 20 seconds
- Never use wire brush for cleaning spark plug.




INSTALLATION

- Install rocker cover gasket to rocker cover.
- Install rocker cover.
 - Tighten bolts in two steps separately in numerical order as shown.
 - 1st step : 1.96 N-m (0.20 kg-m, 17 in-lb)
 - 2nd step : 8.33 N-m (0.85 kg-m, 73 in-lb)
 - ⇐ Engine front

CAUTION:

Check if rocker cover gasket is not dropped from the installation groove of rocker cover.




IGNITION COIL, SPARK PLUG AND ROCKER COVER

[MR20DE]

3. Install spark plug using suitable tool.

Plug type : Platinum tipped
Make : NGK
Part number : PLZKAR6A-11
Gap (nominal) : 1.1 mm (0.043 in)

CAUTION:
Never drop or shock it.



4. Install ignition coil.

CAUTION:

- Handle it carefully and avoid impacts.
- Never disassemble.

5. Install intake manifold. Refer to [EM-20, "INTAKE MANIFOLD"](#).


FUEL INJECTOR AND FUEL TUBE

PFP:16600

Components

EBS00Z9Z

SEC. 164



WBIA0779E

- | | | |
|-------------------|------------------|-------------------|
| 1. Bracket | 2. Bracket | 3. Fuel tube |
| 4. Clip | 5. Fuel injector | 6. O-ring (green) |
| 7. O-ring (black) | | |

Removal and Installation


REMOVAL

EBS00ZA0

WARNING:

- Put a "CAUTION: FLAMMABLE" sign in the workshop.
- Be sure to work in a well ventilated area and furnish workshop with a CO₂ fire extinguisher.
- Do not smoke while servicing fuel system. Keep open flames and sparks away from the work area.

1. Release the fuel pressure. Refer to [EC-81, "FUEL PRESSURE RELEASE"](#).
2. Remove quick connector cap (1) from quick connector connection.



PBIC3664E

FUEL INJECTOR AND FUEL TUBE


[MR20DE]

3. Disconnect fuel feed hose from hose clamp.

1 : Quick connector cap

NOTE:

There is no fuel return path.




4. With the sleeve side of quick connector release facing quick connector, install quick connector release onto fuel tube.

5. Insert quick connector release into quick connector until sleeve contacts and goes no further. Hold quick connector release on that position.

CAUTION:


Inserting quick connector release hard will not disconnect quick connector. Hold quick connector release where it contacts and goes no further.



6. Draw and pull out quick connector straight from fuel tube.

CAUTION:

- Pull quick connector holding "A" position.
- Do not pull with lateral force applied. O-ring inside quick connector may be damaged.
- Prepare container and cloth beforehand as fuel will leak out.
- Avoid fire and sparks.
- Keep parts away from heat source. Especially, be careful when welding is performed around them.
- Do not expose parts to battery electrolyte or other acids.
- Do not bend or twist connection between quick connector and fuel feed hose during installation/removal.
- To keep clean the connecting portion and to avoid damage and foreign materials, cover them completely with plastic bags or something similar.




7. Remove intake manifold. Refer to [EM-20, "INTAKE MANIFOLD"](#).

FUEL INJECTOR AND FUEL TUBE

[MR20DE]

8. Remove fuel tube.
 - Loosen bolts in reverse order as shown.

← : Engine front



9. Remove the fuel tube and fuel injector assembly.

CAUTION:

- When removing, be careful to avoid any interference with fuel injector.
- Use a shop cloth to absorb any fuel leaks from fuel tube.

10. Remove fuel injector from fuel tube with the following procedure:

- a. Open and remove clip.
- b. Remove fuel injector from fuel tube by pulling straight.

CAUTION:

- Be careful with remaining fuel that may go out from fuel tube.
- Be careful not to damage fuel injector nozzle during removal.
- Never bump or drop fuel injector.
- Never disassemble fuel injector.

INSTALLATION

1. Note the following, and install O-rings to fuel injector.

CAUTION:

- Upper and lower O-rings are different. Be careful not to confuse them.

Fuel tube side : Black
Nozzle side : Green

- Handle O-ring with bare hands. Never wear gloves.
- Lubricate O-ring with new engine oil.
- Never clean O-ring with solvent.
- Make sure that O-ring and its mating part are free of foreign material.
- When installing O-ring, be careful not to scratch it with tool or fingernails. Also be careful not to twist or stretch O-ring. If O-ring was stretched while it was being attached, never insert it quickly into fuel tube.
- Insert O-ring straight into fuel tube. Never twist it.

FUEL INJECTOR AND FUEL TUBE

[MR20DE]

2. Install fuel injector (4) to fuel tube (1) with the following procedure:

- 3 : O-ring (black)
- 5 : O-ring (green)

- a. Insert clip (2) into clip groove (F) on fuel injector.

- Insert clip so that protrusion (G) of fuel injector matches cut-out (D) of clip.


CAUTION:

- **Never reuse clip. Replace it with a new one.**
- **Be careful to keep clip from interfering with O-ring. If interference occurs, replace O-ring.**

- b. Insert fuel injector into fuel tube with clip attached.

- Insert it while matching it to the axial center.
- Insert fuel injector so that protrusion (B) of fuel tube matches cut-out (C) of clip.
- Make sure that fuel tube flange (A) is securely fixed in flange fixing groove (E) on clip.

- c. Make sure that installation is complete by making sure that fuel injector does not rotate or come off.




3. Set fuel tube and fuel injector assembly at its position for installation on cylinder head.

CAUTION:

For installation, be careful not to interfere with fuel injector nozzle.

4. Tighten bolts in numerical order as shown.

← : Engine front



5. Installation of the remaining components is in the reverse order of removal.

TIMING CHAIN

[MR20DE]


PFP:13028

EBS00ZA1

TIMING CHAIN

Components

SEC. 112•120•130•135



- | | | |
|-----------------------------|---|-------------------------------|
| 1. Timing chain slack guide | 2. Timing chain tensioner | 3. Camshaft sprocket (EXH) |
| 4. Timing chain | 5. Oil filler cap | 6. Front cover |
| 7. O-ring | 8. Intake valve timing control solenoid valve | 9. Crankshaft pulley bolt |
| 10. Crankshaft pulley | 11. Front oil seal | 12. Drive belt auto-tensioner |

A
C
D
E
F
G
H
I
J
K
L
M

EM

PBIC3538J

- | | | |
|---|------------------------------------|--------------------------------|
| 13. Timing chain tension guide (front cover side) | 14. Crankshaft sprocket | 15. Oil pump sprocket |
| 16. Oil pump drive chain | 17. Camshaft sprocket (INT) | 18. Timing chain tension guide |
| 19. O-ring | 20. Chain tensioner (for oil pump) | |
| A. Refer to EM-43 | B. Refer to EM-52 | |

Removal and Installation

EBS00ZA2

CAUTION:

The rotating direction indicated in the text indicates all directions seen from the engine front.

REMOVAL


1. Remove front RH wheel. Refer to [WT-6, "ROAD WHEEL TIRE ASSEMBLY"](#) .
2. Remove front fender protector (RH). Refer to [EI-21, "FENDER PROTECTOR"](#) .
3. Drain engine oil. Refer to [LU-6, "Changing Engine Oil"](#) .

NOTE:

Perform this step when engine is cold.

4. Remove the following parts.
 - Rocker cover: Refer to [EM-32, "Components"](#) .
 - Drive belt: Refer to [EM-15, "Components"](#) .
 - Water pump pulley: Refer to [CO-16, "Components"](#) .
 - Ground cable (between engine bracket (RH) and radiator core support)
5. Support the bottom surface of engine using a transmission jack, and then remove the engine bracket and insulator (RH). Refer to [EM-102, "ENGINE ASSEMBLY"](#) .
6. Set No. 1 cylinder at TDC on its compression stroke with the following procedure:
 - a. Rotate crankshaft pulley (1) clockwise and align TDC mark (no paint) (B) to timing indicator (A) on front cover.

C : White paint mark (Not use for service)




- b. At the same time, make sure that the cam noses of the No.1 cylinder are located (←) as shown.

1 : Camshaft (INT)

2 : Camshaft (EXH)

↔ : Engine front

- If not, rotate crankshaft pulley one revolution (360 degrees) and align as shown.




TIMING CHAIN

[MR20DE]

7. Hold crankshaft pulley (1) using suitable tool (A) loosen crankshaft pulley bolt, and locate bolt seating surface at 10 mm (0.39 in) from its original position.


CAUTION:

Never remove the crankshaft pulley bolt as it will be used as a supporting point for the pulley puller.



8. Attach a pulley puller (A) in the M6 thread hole on crankshaft pulley (1), and remove crankshaft pulley.

Tool number : KV11103000 (—)




9. Remove oil pan (lower). Refer to [EM-26. "OIL PAN"](#).

NOTE:

When crankshaft sprocket, oil pump sprocket and other related parts are not removed, this step is unnecessary.

10. Remove intake valve timing control solenoid valve.
11. Remove drive belt auto-tensioner.
12. Loosen bolts in reverse order as shown.




TIMING CHAIN

[MR20DE]

13. Cut liquid gasket by prying the position (←) shown, and then remove the front cover.

CAUTION:

- Be careful not to damage the mating surface.
- A more adhesive liquid gasket is applied compared to previous types when shipped, so it should not be forced off the position not specified.



14. Remove front oil seal from front cover.
- Lift up front oil seal using a suitable tool.

CAUTION:


Be careful not to damage front cover.

15. Push in timing chain tensioner plunger.
16. Insert a stopper pin (A) into the body hole to retain the plunger in collapsed position.

NOTE:

Use approximately 1.5 mm (0.059 in) diameter, hard metal pin as a stopper pin.


17. Remove timing chain tensioner (1).



18. Remove timing chain slack guide (2), timing chain tension guide (3) and timing chain (1).

CAUTION:

Never rotate each crankshaft and camshaft individually while timing chain is removed. It causes interference between valve and piston.




TIMING CHAIN

[MR20DE]

19. Fully lift up lever (A), and push the slack guide (B) into the inside of chain tensioner (for oil pump) (1).
 - The slack guide is released by fully lifting the lever up. As the result, the slack guide can be moved.
20. Matching the hole on lever with the hole on tensioner body, insert a stopper pin (C) to secure slack guide.

NOTE:

Use approximately 1.0 mm (0.04 in) diameter, hard metal pin as a stopper pin.




21. Remove chain tensioner (for oil pump).
 - When the holes on lever and tensioner body cannot be aligned, align these holes by slightly moving the slack guide.
22. Remove crankshaft sprocket, oil pump sprocket and oil pump drive chain as a set.
23. Remove timing chain tension guide (front cover side) from front cover if necessary.

INSPECTION AFTER REMOVAL

Timing Chain

- Check timing chain and oil pump drive chain for cracks (A) and any excessive wear (B) at the roller links of timing chain.
- Replace timing chain and/or oil pump drive chain if necessary.




INSTALLATION

NOTE:

The figure shows the relationship between the matching mark on each timing chain and that on the corresponding sprocket, with the components installed.

1. Make sure that crankshaft key points straight up.

- 1 : Timing chain
- 2 : Camshaft sprocket (EXH)
- 3 : Timing chain slack guide
- 4 : Timing chain tensioner
- 5 : Oil pump sprocket
- 6 : Oil pump drive chain
- 7 : Chain tensioner (for oil pump)
- 8 : Crankshaft sprocket
- 9 : Timing chain tension guide
- 10 : Camshaft sprocket (INT)
- A : Matching mark (dark blue link)
- B : Matching mark (stamping)
- C : Crankshaft key position (straight up)
- D : Matching mark (gold link)
- E : Matching mark (orange link)
- F : Matching mark (outer groove*)



NOTE:

*: There are two outer grooves in camshaft sprocket (INT). The wider one is a matching mark.

- If the timing chain tension guide (front cover side) is removed, install it to the front cover.


CAUTION:

Check the joint condition by sound or feeling.

- Install crankshaft sprocket (2), oil pump sprocket (3) and oil pump drive chain (1).

- A : Matching mark (stamping)
- B : Matching mark (orange link)
- C : Matching mark (dark blue link)


- Install it by aligning matching marks on each sprocket and oil pump drive chain.
- If these matching marks are not aligned, rotate the oil pump shaft slightly to correct the position.



CAUTION:

Check matching mark position of each sprocket after installing the oil pump drive chain.

- Install chain tensioner (for oil pump) (1).
 - Fix the plunger at the most compressed position using a stopper pin (A), and then install it.
 - Securely pull out (←) the stopper pin after installing the chain tensioner (for oil pump).
 - Check matching mark position of oil pump drive chain and each sprocket again.



- Align the matching marks of each sprocket with the matching marks of timing chain.

- 1 : Camshaft sprocket (EXH)
- 2 : Camshaft sprocket (INT)
- 3 : Timing chain
- A : Matching mark (dark blue link)
- B : Matching mark (stamping)
- C : Matching mark (outer groove*)
- D : Matching mark (gold link)
- E : Matching mark (stamping)


NOTE:

*: There are 2 outer grooves in camshaft sprocket (INT). The wider one is a matching mark.

- If these matching marks are not aligned, rotate the camshaft slightly by holding the hexagonal portion to correct the position.

CAUTION:

Check matching mark position of each sprocket and timing chain again after installing the timing chain.




TIMING CHAIN

[MR20DE]


6. Install the timing chain tension guide (3) and the timing chain slack guide (2).

1 : Timing chain



7. Install timing chain tensioner (1).

- Fix the plunger at the most compressed position using a stopper pin (A), and then install it.
- Securely pull out the stopper pin after installing the timing chain tensioner.



8. Check matching mark position of timing chain and each sprocket again.

9. Apply new engine oil to new front oil seal joint surface.

10. Using a suitable tool install front oil seal so that each seal lip is oriented as shown.

A : Dust seal lip

B : Oil seal lip

⇐ : Engine front

⇨ : Engine rear


- Press-fit front oil seal until it is flush with front end surface of front cover as shown below with a suitable tool.

Within 0.3 mm (0.012 in) toward engine front

Within 0.5 mm (0.020 in) toward engine rear

CAUTION:

- Be careful not to damage front cover and crankshaft.
- Press-fit oil seal straight to avoid causing burrs or tilting.
- Never touch grease applied onto oil seal lip.



11. Install new O-ring to cylinder block.

CAUTION:
Be sure O-rings are aligned properly.


12. Apply the sealant without breaks to the specified location using Tool.

Use Genuine Silicone RTV Sealant or equivalent. Refer to [GI-44, "Recommended Chemical Products and Sealants"](#).

Tool number WS39930000 (-)

A : Liquid gasket application area

↶ : Engine outside



13. Make sure that matching marks of timing chain and each sprocket are still aligned.

CAUTION:

- Make sure O-ring on cylinder block is correctly installed.
- Be careful not to damage front oil seal by interference with front end of crankshaft.

14. Install front cover, and tighten bolts in numerical order as shown.

CAUTION:

Attaching should be done within 5 minutes after liquid gasket application.

NOTE:


Refer to the following for the installation position of bolts.

M6 bolts	:	No. 1
M10 bolts	:	No. 6, 7, 10, 11, 14
M12 bolts	:	No. 2, 4, 8, 12
M8 bolts	:	Except the above

15. Tighten all bolts in two stages to specified torque in numerical order as shown.

CAUTION:

Be sure to wipe off any excessive liquid gasket leaking.



16. Install crankshaft pulley.

CAUTION:


- Never damage front oil seal lip section.

TIMING CHAIN

[MR20DE]


- If needed use a plastic hammer, tap on its center portion (not circumference) to seat crankshaft pulley.

17. Secure crankshaft pulley (1) using tool (A).
18. Apply new engine oil to thread and seat surfaces of crankshaft pulley bolt.
19. Tighten crankshaft pulley bolt in three steps.
 - Step 1 : 68.6 N·m (7.0 kg-m, 51 ft-lb)**
 - Step 2 : 0 N·m (0 kg-m, 0 ft-lb)**
 - Step 3 : 29.4 N·m (3.0 kg-m, 22 ft-lb)**



20. Put a paint mark (B) on crankshaft pulley (2), matching with any one of six easy to recognize angle marks (A) on crankshaft pulley bolt (1) flange.
21. Turn another 60 degrees clockwise (angle tightening) using Tool.
 - Check the tightening angle with movement of one angle mark.


Tool number : KV10112100 (BT-8653-A)



22. Make sure that crankshaft rotates clockwise smoothly.
23. Installation of the remaining components is in the reverse order of removal.

A
EM
C
D
E
F
G
H
I
J
K
L
M

CAMSHAFT Components



PBIC4589E

- | | | |
|----------------------------|-------------------------------------|-----------------------|
| 1. O-ring | 2. Camshaft position sensor (PHASE) | 3. Camshaft bracket |
| 4. Camshaft sprocket (EXH) | 5. Camshaft sprocket (INT) | 6. Camshaft (EXH) |
| 7. Camshaft (INT) | 8. Valve lifter (EXH) | 9. Valve lifter (INT) |
| 10. Cylinder head | | |
- A. Refer to [EM-52](#).

Removal and Installation REMOVAL

EBS00ZA4

WARNING:

- Put a "CAUTION: FLAMMABLE" sign in the workshop.
 - Be sure to work in a well ventilated area and furnish workshop with a CO₂ fire extinguisher.
 - Do not smoke while servicing fuel system. Keep open flames and sparks away from the work area.
1. Release the fuel pressure. Refer to [EC-81, "FUEL PRESSURE RELEASE"](#).
 2. Disconnect negative battery cable. Refer to [SC-7, "Removal and Installation MR20DE"](#).
 3. Remove front RH wheel. Refer to [WT-6, "ROAD WHEEL TIRE ASSEMBLY"](#).
 4. Remove front fender protector (RH). Refer to [EI-21, "FENDER PROTECTOR"](#).
 5. Drain engine coolant. Refer to [CO-10, "ENGINE COOLANT"](#).

NOTE:

Perform this step when engine is cold.

6. Remove the following parts.
 - Intake manifold; Refer to [EM-20, "INTAKE MANIFOLD"](#).

CAMSHAFT

[MR20DE]

- Rocker cover; Refer to [EM-32, "IGNITION COIL, SPARK PLUG AND ROCKER COVER"](#).
- Fuel tube and fuel injector assembly; Refer to [EM-35, "FUEL INJECTOR AND FUEL TUBE"](#).
- Front cover, timing chain and related parts; Refer to [EM-39, "TIMING CHAIN"](#).

7. Remove camshaft position sensor (PHASE) from camshaft bracket.

CAUTION:


- Handle carefully to avoid dropping and shocks.
- Never disassemble.
- Never allow metal powder to adhere to magnetic part at sensor tip.
- Never place sensor in a location where it is exposed to magnetism.

8. Put the matching mark (A) on the camshaft sprocket (INT) (2) and the camshaft bracket (1) as shown.

← : Engine front

NOTE:

It prevents the knock pin of the camshaft (INT) from engaging with the incorrect pin hole when installing the camshaft sprocket (INT).




9. Remove camshaft sprockets (INT) (1) and (EXH) (2).

- Secure hexagonal part (A) of camshaft with a wrench. Loosen camshaft sprocket bolts and remove camshaft sprocket.


CAUTION:

- Never rotate crankshaft or camshaft while timing chain is removed. It causes interference between valve and piston.
- Never loosen the bolts with securing anything other than the camshaft hexagonal part or with tensioning the timing chain.



10. Loosen bolts in reverse order as shown.

← : Engine front




11. Cut liquid gasket by prying the position (←) shown, and then remove the camshaft bracket.

← : Engine front

CAUTION:

- Be careful not to damage the mating surface.
- A more adhesive liquid gasket is applied compared to previous types when shipped, so it should not be forced off the position not specified.



A
EM
C
D
E
F
G
H
I
J
K
L
M

12. Remove camshafts.
13. Remove valve lifters.

NOTE:

Identify installed positions, and store them without mixing them up.

INSPECTION AFTER REMOVAL

Camshaft Runout

1. Put V-block on a precise flat table, and support No. 2 and 5 journal of camshaft.

CAUTION:


Never support No. 1 journal (on the side of camshaft sprocket) because it has a different diameter from the other four locations.

2. Set dial indicator (A) vertically to No. 3 journal.
3. Turn camshaft to one direction with hands, and measure the camshaft runout on dial indicator. (Total indicator reading)

Standard : Less than 0.02 mm (0.0008 in).

Limit : 0.05 mm (0.0020 in)

4. If it exceeds the limit, replace camshaft.



Camshaft Cam Height

1. Measure the camshaft cam height with a micrometer (A).

Standard:


Intake : 44.605 - 44.795 mm (1.7560 - 1.7635 in)

Exhaust : 43.175 - 43.365 mm (1.6997 - 1.7072 in)

Limit:

Intake : 44.405 mm (1.7482 in)

Exhaust : 42.975 mm (1.6919 in)



2. If it exceeds the limit, replace camshaft.

Camshaft Journal Oil Clearance


CAMSHAFT JOURNAL OUTER DIAMETER

Measure the outer diameter of camshaft journal with a micrometer (A).

Standard:

No. 1 : 27.935 - 27.955 mm (1.0998 - 1.1006 in)

No. 2, 3, 4, 5 : 24.950 - 24.970 mm (0.9823 - 0.9831 in)



CAMSHAFT BRACKET INNER DIAMETER

- Tighten camshaft bracket bolts with specified torque. Refer to [EM-52, "INSTALLATION"](#) for the tightening procedure.

CAMSHAFT

[MR20DE]


- Measure the inner diameter of camshaft bracket with a bore gauge (A).

B : Measuring direction of inner diameter

Standard:

No. 1 : 28.000 - 28.021 mm (1.1024 - 1.1032 in)

No. 2, 3, 4, 5 : 25.000 - 25.021 mm (0.9843 - 0.9851 in)



CAMSHAFT JOURNAL OIL CLEARANCE

- (Oil clearance) = (Camshaft bracket inner diameter) – (Camshaft journal diameter)

Standard:

No. 1 : 0.045 - 0.086 mm (0.0018 - 0.0034 in)

No. 2, 3, 4, 5 : 0.030 - 0.071 mm (0.0012 - 0.0028 in)

Limit:

: 0.15 mm (0.0059 in)

- If it exceeds the limit, replace camshaft or cylinder head, or both.

NOTE:


Camshaft bracket cannot be replaced as a single part, because it is machined together with cylinder head. Replace whole cylinder head assembly.

Camshaft End Play

1. Install camshaft in cylinder head. Refer to [EM-52, "INSTALLATION"](#) for tightening procedure.
2. Install dial indicator in thrust direction on front end of camshaft. Read the end play of dial indicator (A) when camshaft is moved forward/backward (in direction to axis).

Standard : 0.075 - 0.153 mm (0.0030 - 0.0060 in)

Limit : 0.24 mm (0.0094 in)



- Measure the following parts if out of the standard.


- Dimension "A" for groove of cylinder head No. 1 journal

Standard : 4.000 - 4.030 mm (0.1575 - 0.1587 in)

- Dimension "B" for camshaft flange

Standard : 3.877 - 3.925 mm (0.1526 - 0.1545 in)

- Refer to the standards above, and then replace camshaft and/or cylinder head.



Camshaft Sprocket Runout

1. Put V-block on precise flat table, and support No. 2 and 5 journals of camshaft.

CAUTION:

Never support No. 1 journal (on the side of camshaft sprocket) because it has a different diameter from the other four locations.


CAMSHAFT

[MR20DE]

2. Measure the camshaft sprocket runout with a dial indicator (A).
(Total indicator reading)

Limit : 0.15 mm (0.0059 in)

- If it exceeds the limit, replace camshaft sprocket.




PBIC3182J

Valve Lifter

Check if surface of valve lifter has any wear or cracks.

- If anything above is found, replace valve lifter. Refer to [EM-56](#), "[Valve Clearance](#)".



KBIA0182E

Valve Lifter Clearance


VALVE LIFTER OUTER DIAMETER

- Measure the outer diameter of valve lifter with a micrometer (A).

Standard:

Intake : 33.977 - 33.987 mm (1.3377 - 1.3381 in)

Exhaust : 29.977 - 29.987 mm (1.1802 - 1.1806 in)



PBIC3185J

VALVE LIFTER HOLE DIAMETER

Measure the diameter of valve lifter hole of cylinder head with an inside micrometer (A).

Standard:

Intake : 34.000 - 34.021 mm (1.3386 - 1.3394 in)


Exhaust : 30.000 - 30.021 mm (1.1811 - 1.1819 in)

VALVE LIFTER CLEARANCE

- (Valve lifter clearance) = (Valve lifter hole diameter) – (Valve lifter outer diameter)

Standard: 0.013 - 0.044 mm (0.0005 - 0.0017 in)

- If out of the standard, referring to the each standard of valve lifter outer diameter and valve lifter hole diameter, replace either or both valve lifter and cylinder head.



PBIC3184J

INSTALLATION

1. Install valve lifters.
 - Install them in the original positions.
2. Install camshafts.


CAMSHAFT

[MR20DE]

- Clean camshaft journal to remove any foreign material.
- Distinguish between the intake and the exhaust by looking at the different shapes of the front and rear ends of the camshaft or using the identification colors (A) and (B).

- 1 : Camshaft (EXH)
- 2 : Camshaft (INT)

Identification color	A	B
Camshaft (EXH)	—	Yellow
Camshaft (INT)	Yellow	—




- Install camshafts so that camshaft dowel pins (A) on the front side are positioned as shown.

- 1 : Camshaft (EXH)
- 2 : Camshaft (INT)

NOTE:

Though camshaft does not stop at the positions as shown, for the placement of cam nose, it is generally accepted camshaft is placed for the same direction as shown.




- Remove foreign material completely from camshaft bracket backside and from cylinder head installation face.
- Apply liquid gasket (A) to camshaft bracket as shown.

Use Genuine Silicone RTV Sealant or equivalent. Refer to [GI-44, "Recommended Chemical Products and Sealants"](#) .

Tool number WS39930000 (-)

- B : Plug hole inner wall
- ⇐ : Engine front
- ⇨ : Engine outside



CAMSHAFT

[MR20DE]

5. Install camshaft bracket bolts in three stage in numerical order as shown in numerical order as shown.

⇐ : Engine front


- There are two types of bolts. Refer to the following for locating bolts.

M6 bolts [thread length: 57.5 mm (2.264 in)]

: 13, 14 and 15 in the figure

M6 bolts [thread length: 35.00 mm (1.378 in)]

: Except the above



PBIC3176J

6. Tighten all bolts in numerical order in three steps.

Step 1 : 1.96 N·m (0.20 kg-m, 17 in-lb)

Step 2 : 5.88 N·m (0.60 kg-m, 52 in-lb)

Step 3 : 9.5 N·m (0.97 kg-m, 84 in-lb)


7. Install the camshaft sprocket (INT) to the camshaft (INT).

NOTE:

When the camshaft sprocket (INT) (2) is removed, refer to the paint mark (A) put according to step "3". Securely align the knock pin and the pin hole, and then install them.

1 : Camshaft bracket

⇐ : Engine front



PBIC3992J

8. Tighten camshaft (INT) sprocket bolt.

Camshaft sprocket bolt (INT) : 35.0 N·m (3.6 kg-m, 26 ft-lb)

NOTE:

Secure the hexagonal part of camshaft (INT) using wrench to tighten bolt.

9. Turn 67 degrees clockwise (angle tightening) using Tool.


1 : Camshaft sprocket (INT)

A : Camshaft (INT) hexagonal part

CAUTION:

Never judge by visual inspection without an angle wrench.

Tool number : KV10112100 (BT-8653-A)



PBIC3455J

CAMSHAFT

[MR20DE]


10. Install camshaft sprocket (EXH) (2).

1 : Camshaft sprocket (INT)

Camshaft sprocket bolt (EXH) : 88.2 N·m (9.0 kg-m, 65 ft-lb)

NOTE:

Secure the hexagonal part (A) of camshaft (EXH) using wrench to tighten bolt.



11. Install timing chain and related parts. Refer to [EM-39, "TIMING CHAIN"](#) .

12. Inspect and adjust valve clearance. Refer to [EM-56, "Valve Clearance"](#) .

13. Installation of the remaining components is in the reverse order of removal.

INSPECTION AFTER INSTALLATION

The following are procedures for checking fluids leak, lubricates leak.

- Before starting engine, check oil/fluid levels including engine coolant and engine oil. If less than required quantity, fill to the specified level. Refer to [GI-44, "Recommended Chemical Products and Sealants"](#) .
- Use procedure below to check for fuel leakage.
 - Turn ignition switch "ON" (with engine stopped). With fuel pressure applied to fuel piping, check for fuel leakage at connection points.
 - Start engine. With engine speed increased, check again for fuel leakage at connection points.
- Run engine to check for unusual noise and vibration.

NOTE:

If hydraulic pressure inside timing chain tensioner drops after removal/installation, slack in the guide may generate a pounding noise during and just after engine start. However, this is normal. Noise will stop after hydraulic pressure rises.

- Warm up engine thoroughly to make sure there is no leakage of fuel, or any oil/fluids including engine oil and engine coolant.
- Bleed air from lines and hoses of applicable lines, such as in cooling system.
- After cooling down engine, again check oil/fluid levels including engine oil and engine coolant. Refill to the specified level, if necessary.

Summary of the inspection items:

Item	Before starting engine	Engine running	After engine stopped
Engine coolant	Level	Leakage	Level
Engine oil	Level	Leakage	Level
Other oils and fluid*	Level	Leakage	Level
Fuel	Leakage	Leakage	Leakage
Exhaust gases	—	Leakage	—

* Transmission/transaxle/CVT fluid, power steering fluid, brake fluid, etc.


Inspection of Camshaft Sprocket (INT) Oil Groove

CAUTION:

- Perform this inspection only when DTC P0011 is detected in self-diagnostic results of CONSULT-II and it is directed according to inspection procedure of EC section. Refer to [EC-50, "ON BOARD DIAGNOSTIC \(OBD\) SYSTEM"](#) .
- Check when engine is cold so as to prevent burns from the splashing engine oil.
 1. Check engine oil level. Refer to [LU-5, "ENGINE OIL LEVEL"](#) .
 2. Perform the following procedure so as to prevent the engine from being unintentionally started while checking.
 - a. Remove intake manifold. Refer to [EM-20, "Components"](#) .

- b. Disconnect ignition coil and injector harness connectors.
3. Remove intake valve timing control solenoid valve. Refer to [EM-39, "Components"](#) .
4. Clean the mating area of intake valve timing control solenoid valve. Insert a clean shop cloth (with no oil adhesion) into the oil hole (A) of the cylinder head.

1 : Front cover
 ⇐ : Vehicle front



5. Install engine mounting bracket (RH), engine mounting insulator, and torque rod (RH) under the Step 4 condition. (With intake valve timing control solenoid valve removed, and a shop cloth inserted into the oil hole.) Refer to [EM-102, "Components"](#) .
6. Crank engine, and then make sure that engine oil comes out from intake valve timing control solenoid valve hole (A). End crank after checking.

- Check engine oil leakage by oil amount adhered to the waste inserted into the oil hole.

WARNING:

Be careful not to touch rotating parts (drive belts, idler pulley, and crankshaft pulley, etc.).

CAUTION:

- Do not perform cranking without installing right engine mount bracket, right engine mount insulator, and right torque rod.
 - Prevent splashing by using a shop cloth so as to prevent the worker from injury from engine oil and so as to prevent engine oil contamination.
 - Prevent splashing by using a shop cloth so as to prevent engine oil from being splashed to engine and vehicle. Especially, be careful not to apply engine oil to rubber parts of drive belts, engine mounting insulator, etc. Wipe engine oil off immediately if it is splashed.
7. Perform the following inspection if engine oil does not come out from intake valve timing control solenoid valve oil hole of the cylinder head.
 - Remove oil filter (for intake valve timing control), and then clean it. Refer to [LU-8, "OIL FILTER"](#) .
 - Clean oil groove between oil strainer and intake valve timing control solenoid valve. Refer to [LU-4, "Lubrication Circuit"](#) .
 8. Remove components between intake valve timing control solenoid valve and camshaft sprocket (INT), and then check each oil groove for clogging.
 - Clean oil groove if necessary. Refer to [LU-4, "Lubrication Circuit"](#) .
 9. Installation of the remaining components is in the reverse order of removal


Valve Clearance INSPECTION

EBS00ZA5

Perform inspection as follows after removal, installation or replacement of camshaft or valve-related parts, or if there is unusual engine conditions regarding valve clearance.

1. Remove rocker cover. Refer to [EM-32, "IGNITION COIL, SPARK PLUG AND ROCKER COVER"](#) .
2. Measure the valve clearance with the following procedure:
 - a. Set No. 1 cylinder at TDC of its compression stroke.
 - Rotate crankshaft pulley (1) clockwise and align TDC mark (no paint) (B) to timing indicator (A) on front cover.

C : White paint mark (Not use for service)




CAMSHAFT

[MR20DE]


- At the same time, make sure that both intake and exhaust cam noses of No. 1 cylinder face inside (←) as shown.

- 1 : Camshaft (INT)
- 2 : Camshaft (EXH)
- ← : Engine front

- If they do not face inside, rotate crankshaft pulley once more (360 degrees) and align as shown.



- b. Use a feeler gauge, measure the clearance between valve lifter and camshaft.



Valve clearance:

Unit: mm (in)


	Cold	Hot * (reference data)
Intake	0.26 - 0.34 (0.010 - 0.013)	0.304 - 0.416 (0.012 - 0.016)
Exhaust	0.29 - 0.37 (0.011 - 0.015)	0.308 - 0.432 (0.012 - 0.017)

*: Approximately 80°C (176°F)

- By referring to the figure, measure the valve clearances at locations marked "x" as shown in the table below [locations indicated with black arrow (←)] with a feeler gauge.

- No. 1 cylinder compression TDC

Measuring position		No. 1 CYL.	No. 2 CYL.	No. 3 CYL.	No. 4 CYL.
No. 1 cylinder at compression TDC	EXH	x		x	
	INT	x	x		



- A : Exhaust side
- B : No.1 cylinder
- C : No.2 cylinder
- D : No.3 cylinder
- E : No.4 cylinder
- F : Intake side
- ← : Engine front


- c. Set No.4 cylinder at TDC of its compression stroke.

CAMSHAFT

[MR20DE]

- Rotate crankshaft pulley (1) one revolution (360 degrees) and align TDC mark (no paint) (B) to timing indicator (A) on front cover.


C : White paint mark (Not use for service)



- By referring to the figure, measure the valve clearance at locations marked "x" as shown in the table below [locations indicated with black arrow (←)] with a feeler gauge.
- No. 4 cylinder compression TDC

Measuring position		No. 1 CYL.	No. 2 CYL.	No. 3 CYL.	No. 4 CYL.
No. 4 cylinder at compression TDC	EXH		x		x
	INT			x	x


- A : Exhaust side
 B : No.1 cylinder
 C : No.2 cylinder
 D : No.3 cylinder
 E : No.4 cylinder
 F : Intake side
 ← : Engine front



3. If out of standard, perform adjustment. Refer to [EM-58, "ADJUSTMENT"](#).

ADJUSTMENT

- Perform adjustment depending on selected head thickness of valve lifter.
1. Remove camshaft. Refer to [EM-48, "REMOVAL"](#).
 2. Remove valve lifters at the locations that are out of the standard.
 3. Measure the center thickness of the removed valve lifters with a micrometer (A).



4. Use the equation below to calculate valve lifter thickness for replacement.


Valve lifter thickness calculation: $t = t_1 + (C_1 - C_2)$

- t** = Valve lifter thickness to be replaced
t₁ = Removed valve lifter thickness
C₁ = Measured valve clearance
C₂ = Standard valve clearance:
 Intake : 0.30 mm (0.012 in)
 Exhaust : 0.33 mm (0.013 in)

CAMSHAFT

[MR20DE]

- Thickness of new valve lifter (B) can be identified by stamp mark (A) on the reverse side (inside the cylinder). Stamp mark "302" indicates 3.02 mm (0.1189 in) in thickness.



NOTE:

Available thickness of valve lifter: 26 sizes range 3.00 to 3.50 mm (0.1181 to 0.1378 in) in steps of 0.02 mm (0.0008 in) (when manufactured at factory). Refer to [EM-108, "Available Valve Lifter"](#) .

5. Install the selected valve lifter.
6. Install camshaft. Refer to [EM-52, "INSTALLATION"](#) .
7. Install timing chain and related parts. Refer to [EM-39, "TIMING CHAIN"](#) .
8. Manually rotate crankshaft pulley a few rotations.
9. Make sure that the valve clearances is within the standard. Refer to [EM-56, "INSPECTION"](#) .
10. Installation of the remaining components is in the reverse order of removal.

OIL SEAL

Removal and Installation of Valve Oil Seal
REMOVAL

1. Remove camshafts. Refer to [EM-48, "Components"](#) .
2. Remove valve lifters. Refer to [EM-48, "CAMSHAFT"](#) .
3. Rotate crankshaft, and set piston whose valve oil seal is to be removed to TDC. This will prevent valve from dropping into cylinder.

CAUTION:


When rotating crankshaft, be careful to avoid scarring front cover with timing chain.

4. Remove valve collet.
 - Compress valve spring using Tool, the attachment and the adapter (A). Remove valve collet with a suitable magnet hand (B).

CAUTION:


When working, be careful not to damage valve lifter holes.

Tool number : KV101092S0 (J-26336-B)



5. Remove valve spring retainer, valve spring and valve spring seat.
6. Remove valve oil seal using Tool (A).

Tool number : KV10107902 (J-38959)




INSTALLATION

1. Apply new engine oil to valve oil seal joint surface and seal lip.
2. Press in valve oil seal to the height "H" shown using Tool (A).

Height "H" : 15.1 - 15.7 mm (0.594 - 0.618 in)

Tool number : KV10115600 (—)



3. Installation of the remaining components is in the reverse order of removal.

Removal and Installation of Front Oil Seal

REMOVAL

1. Remove the following parts.
 - Front fender protector (RH); Refer to [EI-21, "FENDER PROTECTOR"](#) .
 - Drive belt; Refer to [EM-15, "Components"](#) .
 - Crankshaft pulley; Refer to [EM-39, "Components"](#) .
2. Remove front oil seal using a suitable tool.


CAUTION:

Be careful not to damage front cover and crankshaft.

INSTALLATION

1. Apply new engine oil to new front oil seal joint surface and seal lip.
2. Install front oil seal so that each seal lip is oriented as shown in the figure.

- A : Dust seal lip
- B : Oil seal lip
- ⇐ : Engine outside
- ➡ : Engine inside




- Install front oil seal (2) using a suitable tool with outer diameter 57 mm (2.24 in) and inner diameter 45 mm (1.77 in) (A) to the dimension as shown.

Within 0.3 mm (0.012 in) toward engine front

Within 0.5 mm (0.020 in) toward engine rear

CAUTION:

- **Be careful not to damage front cover and crankshaft.**
- **Press-fit oil seal straight to avoid causing burrs or tilting.**
- **Do not touch grease applied on oil seal lip.**



3. Installation of the remaining components is in the reverse order of removal.

Removal and Installation of Rear Oil Seal

REMOVAL

1. Remove transaxle assembly. Refer to [MT-17, "REMOVAL"](#) (M/T models), [CVT-204, "REMOVAL"](#) (CVT models).
2. Remove clutch cover and clutch disk (M/T models). Refer to [CL-13, "CLUTCH DISC, CLUTCH COVER AND FLYWHEEL"](#).
3. Remove drive plate (A/T or CVT models) or flywheel (M/T models). Refer to [EM-74, "Components"](#).
4. Remove rear oil seal with a suitable tool.


CAUTION:

Be careful not to damage crankshaft and cylinder block.

INSTALLATION

1. Apply the liquid gasket lightly to entire outside area of new rear oil seal.
Use Genuine Silicone RTV Sealant or equivalent. Refer to [GI-44, "Recommended Chemical Products and Sealants"](#).
2. Install rear oil seal so that each seal lip is oriented as shown.


- A : Dust seal lip
- B : Oil seal lip
- ⇐ : Engine outside
- ⇨ : Engine inside



- Install rear oil seal with a suitable tool with an outer diameter 115 mm (4.53 in) and inner diameter 90 mm (3.54 in) (A).

CAUTION:

- **Be careful not to damage crankshaft and cylinder block.**
- **Press-fit oil seal straight to avoid causing burrs or tilting.**
- **Do not touch grease applied onto oil seal lip.**




- Install rear oil seal (1) to the position as shown.

- A : Rear end surface of cylinder block

NOTE:

The standard surface of the dimension is the rear end surface of cylinder block.




3. Installation of the remaining components is in the reverse order of removal.

CYLINDER HEAD


On-Vehicle Service CHECKING COMPRESSION PRESSURE

1. Warm up engine thoroughly. Then, stop it.
2. Release fuel pressure. Refer to [EC-81, "FUEL PRESSURE RELEASE"](#).
3. Disconnect fuel pump fuse (1) to avoid fuel injection during measurement.


← : Vehicle front



4. Remove engine cover.
5. Remove ignition coil and spark plug from each cylinder. Refer to [EM-32, "IGNITION COIL, SPARK PLUG AND ROCKER COVER"](#).
6. Connect an engine tachometer (not required in use of CONSULT-II).
7. Install a suitable compression tester with an adapter onto spark plug hole.



- Use the adapter whose picking up end inserted to spark plug hole is smaller than 20 mm (0.79 in) in diameter. Otherwise, it may be caught by cylinder head during removal.



8. With accelerator pedal fully depressed, turn ignition switch to "START" for cranking. When the gauge pointer stabilizes, read the compression pressure and the engine rpm. Perform these steps to check each cylinder.

Compression pressure:

Unit: kPa (bar, kg/cm² psi) /rpm

Standard	Minimum	Differential limit between cylinders
1,500 (15.0, 15.3, 217.6) / 200	1,200 (12.0, 12.2, 174) / 200	100 (1, 1, 15) / 200

CAUTION:

Always use fully a charged battery to obtain the specified engine speed.


CYLINDER HEAD

[MR20DE]

- If the engine speed is out of the specified range, check battery liquid for proper gravity. Check engine speed again with normal battery gravity.
 - If compression pressure is below minimum value, check valve clearances and parts associated with combustion chamber (Valve, valve seat, piston, piston ring, cylinder bore, cylinder head, cylinder head gasket). After the checking, measure the compression pressure again.
 - If some cylinder has low compression pressure, pour small amount of engine oil into the spark plug hole of the cylinder to re-check it for compression.
 - If the added engine oil improves the compression, piston rings may be worn out or damaged. Check piston rings and replace if necessary.
 - If the compression pressure remains at low level despite the addition of engine oil, valves may be malfunctioning. Check valves for damage. Replace valve or valve seat accordingly.
 - If two adjacent cylinders have respectively low compression pressure and their compression remains low even after the addition of engine oil, cylinder head gasket is leaking. In such a case, replace cylinder head gasket.
9. After inspection is completed, install removed parts.
10. Start the engine, and confirm that the engine runs smoothly.
11. Perform trouble diagnosis. If DTC appears, erase it. Refer to [EC-83, "TROUBLE DIAGNOSIS"](#) .

Components

EBS00ZAA



1. Cylinder head assembly

2. Cylinder head bolt

3. Cylinder head gasket

A. Refer to [EM-66](#)

Removal and Installation

EBS00ZAB

REMOVAL


WARNING:

- Put a “CAUTION: FLAMMABLE” sign in the workshop.
 - Be sure to work in a well ventilated area and furnish workshop with a CO₂ fire extinguisher.
 - Do not smoke while servicing fuel system. Keep open flames and sparks away from the work area.
1. Release the fuel pressure. Refer to [EC-81, "FUEL PRESSURE RELEASE"](#) .
 2. Drain engine coolant and engine oil. Refer to [CO-10, "ENGINE COOLANT"](#) and [LU-6, "Changing Engine Oil"](#) .
 3. Remove front fender protector (RH). Refer to [EI-21, "FENDER PROTECTOR"](#) .
 4. Remove drive belt. Refer to [EM-15, "Removal and Installation"](#) .
 5. Remove the following components and related parts.
 - Exhaust manifold; Refer to [EM-23, "EXHAUST MANIFOLD"](#) .
 - Intake manifold; Refer to [EM-20, "INTAKE MANIFOLD"](#) .

CYLINDER HEAD

[MR20DE]


- Fuel tube and fuel injector assembly; Refer to [EM-35, "FUEL INJECTOR AND FUEL TUBE"](#) .
 - Water outlet; Refer to [CO-21, "WATER OUTLET AND WATER CONTROL VALVE"](#) .
 - Rocker cover; Refer to [EM-32, "IGNITION COIL, SPARK PLUG AND ROCKER COVER"](#) .
 - Front cover, timing chain; Refer to [EM-39, "TIMING CHAIN"](#) .
 - Camshaft; Refer to [EM-48, "CAMSHAFT"](#) .
6. Remove cylinder head.
 - Loosen bolts in reverse order as shown.
⇐ : Engine front
 - Using TORX socket (size E18), loosen cylinder head bolts.
 7. Remove cylinder head gasket.



INSPECTION AFTER REMOVAL

Cylinder Head Bolts Outer Diameter

- Cylinder head bolts are tightened by plastic zone tightening method. Whenever the size difference between "d1" and "d2" exceeds the limit, replace them with a new one.
Limit ("d1" – "d2"): 0.15 mm (0.0059 in)
- If reduction of outer diameter appears in a position other than "d2", use it as "d2" point.



Cylinder Head Distortion

NOTE:

When performing this inspection, cylinder block distortion should be also checked. Refer to [EM-95, "CYLINDER BLOCK TOP SURFACE DISTORTION"](#) .

1. Wipe off engine oil and remove water scale (like deposit), gasket, sealant, carbon, etc. with a scraper.


CAUTION:

Use utmost care not to allow gasket debris to enter passages for engine oil or water.

2. At each of several locations on bottom surface of cylinder head, measure the distortion in six directions using straightedge (A) and feeler gauge (B).

Limit: 0.1 mm (0.004 in)

- If it exceeds the limit, replace cylinder head.



INSTALLATION

1. Install cylinder head gasket.
2. Apply new engine oil to threads and seating surface of bolts.

CAUTION:

If cylinder head bolts re-used, check their outer diameters before installation. Refer to [EM-65. "Cylinder Head Bolts Outer Diameter"](#).

3. Install cylinder head, follow the steps below to tighten cylinder head bolts in numerical order as shown.



- Step a : 40 N·m (4.1 kg-m, 30 ft-lb)
- Step b : 100° clockwise
- Step c : Loosen to 0 N·m in the reverse order of tightening.
- Step d : 40 N·m (4.1 kg-m, 30 ft-lb)
- Step e : 100° clockwise
- Step f : 100° clockwise

⇐: Engine front

CAUTION:


Check and confirm the tightening angle by using Tool (A) or protractor. Never judge by visual inspection without the tool.

Tool number : KV10112100 (BT-8653-A)



4. Installation of the remaining components is in the reverse order of removal.

Components



- | | | |
|--|-----------------------------------|---|
| 1. Valve collet | 2. Valve spring retainer | 3. Valve spring (EXH)
(with valve spring seat) |
| 4. Valve oil seal | 5. Valve guide (EXH) | 6. Valve seat (EXH) |
| 7. Valve (EXH) | 8. Valve (INT) | 9. Valve seat (INT) |
| 10. Cylinder head | 11. Valve guide (INT) | 12. Spark plug |
| 13. Valve spring (INT)
(with valve spring seat) | | |
| A. Refer to EM-70 | B. Refer to EM-71 | |

Disassembly and Assembly

DISASSEMBLY

- Remove spark plug using suitable tool.
- Remove valve lifter.
 - Identify installation positions, and store them without mixing them up.
- Remove valve collet.

CYLINDER HEAD


[MR20DE]

- Compress valve spring using Tool, attachment and adapter (A). Remove valve collet using a suitable magnet hand.

CAUTION:

When working, be careful not to damage valve lifter holes.

Tool number : KV101092S0 (J-26336-B)



4. Remove valve spring retainer and valve spring (with valve spring seat).

CAUTION:

Never remove valve spring seat from valve spring.


5. Push valve stem to combustion chamber side, and remove valve.

NOTE:

Identify installed positions, and store them without mixing them up.

6. Remove valve oil seal using Tool (A).

Tool number : KV10107902 (J-38959)



7. When valve seat must be replaced, refer to [EM-71, "VALVE SEAT REPLACEMENT"](#) to removal.
8. When valve guide must be replaced, refer to [EM-70, "VALVE GUIDE REPLACEMENT"](#) to removal.

ASSEMBLY

1. Install valve guide if removed. Refer to [EM-70, "VALVE GUIDE REPLACEMENT"](#).
2. Install valve seat if removed. Refer to [EM-71, "VALVE SEAT REPLACEMENT"](#).
3. Install valve oil seal.


- Install with a valve oil seal using Tool (A) to match dimension as shown.

Tool number : KV10115600 (J-38958)

NOTE:

Dimension "H" is height that measured before installing valve spring (with valve spring seat).

Height "H" : 15.1 - 15.7 mm (0.594 - 0.618 in)




4. Install valve.
 - Install larger diameter to intake side.

CYLINDER HEAD

[MR20DE]

5. Install valve spring (with valve spring seat).
 - Install smaller pitch (valve spring seat side) to cylinder head side (B).
 - Confirm identification color (A) of valve spring.
 - 1 : Valve spring seat (Do not remove from valve spring.)

Intake : White
Exhaust : Orange




6. Install valve spring retainer.
7. Install valve collet.
 - Compress valve spring using Tool (A). Install valve collet with a magnet hand.

Tool number : KV101092S0 (J-26336 B)

CAUTION:
When working, be careful not to damage valve lifter holes.

- Tap valve stem edge lightly with a plastic hammer after installation to check its installed condition.



8. Install valve lifter.
 - Install it in the original position.
9. Install spark plug using suitable tool.

Inspection After Disassembly VALVE DIMENSIONS

EBS00ZAE

- Check dimensions of each valve. For dimensions, refer to [EM-107, "Valve Dimensions"](#).
- If dimensions are out of the standard, replace valve.

VALVE GUIDE CLEARANCE


Valve Stem Diameter

Measure the diameter of valve stem with a micrometer (A).

Standard

Intake : 5.465 - 5.480 mm (0.2152 - 0.2157 in)

Exhaust : 5.455 - 5.470 mm (0.2148 - 0.2154 in)



Valve Guide Inner Diameter

Measure the inner diameter of valve guide with a bore gauge.

Standard

: 5.500 - 5.518 mm (0.2165 - 0.2172 in)

Valve Guide Clearance

(Valve guide clearance) = (Valve guide inner diameter) – (Valve stem diameter).

Valve guide clearance:

Standard

Intake : 0.020 - 0.053 mm (0.0008 - 0.0021 in)

Exhaust : 0.030 - 0.063 mm (0.0012 - 0.0025 in)

Limit


: 0.1 mm (0.004 in)

- If it exceeds the limit, replace valve guide and/or valve.

VALVE GUIDE REPLACEMENT

When valve guide is removed, replace with oversized [0.2 mm (0.008 in)] valve guide.


1. To remove valve guide, heat cylinder head to 110° to 130°C (230° to 266°F) by soaking in heated oil (A).



2. Drive out valve guide using suitable tools.

CAUTION:


Cylinder head contains heat, when working, wear protective equipment to avoid getting burned.



3. Ream cylinder head valve guide hole using suitable tool (A).

Valve guide hole diameter (for service parts):


: 9.675 - 9.696 mm (0.3809 - 0.3817 in)



CYLINDER HEAD

[MR20DE]

4. Heat cylinder head to 110° to 130°C (230° to 266°F) by soaking in heated oil (A).




5. Press valve guide (1) from camshaft side to dimensions as shown.

2 : Cylinder head

Projection "H" : 13.35 - 13.65 mm (0.526 - 0.537 in)

CAUTION:


Cylinder head contains heat, when working, wear protective equipment to avoid getting burned.



6. Apply reamer finish to valve guide using suitable tool (A).


Standard

: 5.500 - 5.518 mm (0.2165 - 0.2172 in)



VALVE SEAT CONTACT

- After confirming that the dimensions of valve guides and valves are within specifications, perform this procedure.
- Apply prussian blue (or white lead) onto contacting surface of valve seat to check the condition of the valve contact on the surface.
- Check if the contact area band is continuous all around the circumference.
- If not, grind to adjust valve fitting and check again. If the contacting surface still has NG conditions even after the re-check, replace valve seat.



VALVE SEAT REPLACEMENT

When valve seat is removed, replace with oversized [0.5 mm (0.020 in)] valve seat.

1. Bore out old seat until it collapses. Boring should not continue beyond the bottom face of the seat recess in cylinder head. Set the machine depth stop to ensure this. Refer to [EM-110, "Valve Seat"](#).

CYLINDER HEAD

[MR20DE]

2. Ream cylinder head (1) recess diameter for service valve seat.


2 : Valve seat

Oversize [0.5 mm (0.020 in)]


Intake : 35.200 - 35.227 mm (1.3858 - 1.3869 in)

Exhaust : 29.200 - 29.227 mm (1.1496 - 1.1507 in)

- Be sure to ream in circles concentric to the valve guide center. This will enable valve seat to fit correctly.



3. Heat cylinder head to 110° to 130°C (230° to 266°F) by soaking in heated oil (A).



4. Provide valve seats cooled well with dry ice. Press-fit valve seat into cylinder head.


CAUTION:

- Never touch cold valve seats directly.
- Cylinder head contains heat, when working, wear protective equipment to avoid getting burned.

5. Using valve seat cutter set or valve seat grinder, finish valve seat to the specified dimensions. For dimensions, refer to [EM-110, "Valve Seat"](#).

CAUTION:

When using valve seat cutter, firmly grip the cutter handle with both hands. Then, press on the contacting surface all around the circumference to cut in a single drive. Improper pressure on with the cutter or cutting many different times may result in stage valve seat.



6. Using compound, grind to adjust valve fitting.

7. Check again for normal contact. Refer to [EM-71, "VALVE SEAT CONTACT"](#).

VALVE SPRING SQUARENESS


- Set try square along the side of valve spring and rotate the spring. Measure the maximum clearance between the top of valve spring and try square.

CAUTION:

Never remove valve spring seat from valve spring.

Limit: 1.9 mm (0.075 in)

- If it exceeds the limit, replace valve spring (with valve spring seat).



CYLINDER HEAD


[MR20DE]

VALVE SPRING DIMENSIONS AND VALVE SPRING PRESSURE LOAD

- Check valve spring pressure with valve spring seat installed at the specified spring height.

CAUTION:

Never remove valve spring seat from valve spring.



Standard:

Items	Intake	Exhaust
Free height	44.90 - 45.10 mm (1.7677 - 1.7755 in)	45.74 - 45.94 mm (1.8007 - 1.8086 in)
Installation height	35.30 mm (1.390 in)	35.30 mm (1.390 in)
Installation load	153 - 173 N (15.6 - 17.6 kg, 34 - 39 lb)	139 - 157 N (14.2 - 16 kg, 10 - 35 lb)
Height during valve open	26.36 mm (1.0377 in)	27.80 mm (1.0944 in)
Load with valve open	335 - 377 N (34.2 - 38.5 kg, 75 - 85 lb)	266 - 297 N (27.1 - 3.03 kg, 60 - 67 lb)
Identification color	White	Orange

- If the installation load or load with valve open is out of the standard, replace valve spring (with valve spring seat).

CYLINDER BLOCK

[MR20DE]


CYLINDER BLOCK

PF1:11010

Components

EBS00ZAH

SEC. 110•120•150•221•226•253



WBIA0773E

- | | | |
|---|---|--------------------------------------|
| 1. Cylinder block | 2. O-ring | 3. Crankshaft position sensor (POS) |
| 4. Crankshaft position sensor (POS) cover | 5. Oil filter (for intake valve timing control) | 6. Knock sensor |
| 7. Oil pressure switch | 8. Top ring | 9. Second ring |
| 10. Oil ring | 11. Snap ring | 12. Piston |
| 13. Piston pin | 14. Connecting rod | 15. Thrust bearing |
| 16. Connecting rod bearing upper | 17. Main bearing upper | 18. Crankshaft key |
| 19. Main bearing lower | 20. Connecting rod bearing lower | 21. Connecting rod bearing cap |
| 22. Connecting rod bolt | 23. Main bearing cap | 24. Main bearing cap bolt |
| 25. Crankshaft | 26. Pilot converter (CVT models) | 27. Signal plate |
| 28. Rear oil seal | 29. Drive plate (CVT models) | 30. Reinforcement plate (CVT models) |
| 31. Flywheel (M/T models) | 32. Block heater (Canada only) | A. Refer to EM-78 |

A
EM
C
D
E
F
G
H
I
J
K
L
M

Disassembly and Assembly

DISASSEMBLY

EBS00ZAI

- Remove engine and transaxle assembly from vehicle, separate transaxle from engine. Refer to [EM-102, "ENGINE ASSEMBLY"](#).
- Install engine to engine stand as follows;
 - Remove flywheel (M/T models) or drive plate (1) (CVT models).
 - Secure flywheel (M/T models) or drive plate (CVT models) using Tool (A), and remove bolts.


Tool number : KV 11105210 (J-44716)

CAUTION:

Be careful not to damage or scratch drive plate (CVT models) and contact surface for clutch disc of flywheel (M/T models).

NOTE:

Figure shows drive plate (CVT models)



- Lift the engine with a hoist to install it onto widely use engine stand.

CAUTION:


- Use the engine stand that has a load capacity [approximately 135 kg (298 lb) or more] large enough for supporting the engine weight.
- If the load capacity of stand is not adequate, remove the following parts beforehand to reduce the potential risk of overturning stand.
 - Exhaust manifold; Refer to [EM-23, "EXHAUST MANIFOLD"](#).
 - Rocker cover; Refer to [EM-32, "IGNITION COIL, SPARK PLUG AND ROCKER COVER"](#).

NOTE:

The figure shows an example of widely used engine stand (A) that can support mating surface of transaxle with flywheel (M/T models) or drive plate (CVT models) removed.

CAUTION:

Before removing the hanging chains, make sure the engine stand is stable and there is no risk of overturning.



- Remove oil pan (upper and lower). Refer to [EM-26, "OIL PAN"](#).
- Remove cylinder head. Refer to [EM-63, "CYLINDER HEAD"](#).
- Remove thermostat housing. Refer to [CO-18, "THERMOSTAT"](#).
- Remove knock sensor.

CAUTION:

Carefully handle knock sensor avoiding shocks.

- Remove crankshaft position sensor (POS) cover and crankshaft position sensor (POS).

CAUTION:


- Avoid impacts such as a dropping.
- Never disassemble.
- Keep it away from metal particles.
- Never place sensor in a location where it is exposed to magnetism.

- Remove oil filter (for intake valve timing control).
- Remove pilot converter (1) using Tool (A). (CVT models)

Tool number :ST16610001 (J-23907)

NOTE:

M/T models have no pilot converter.



- Position crankshaft pin corresponding to connecting rod to be removed onto the bottom dead center.


NOTE:

Before removing piston and connecting rod assembly, check the connecting rod side clearance. Refer to [EM-92, "CONNECTING ROD SIDE CLEARANCE"](#).

- Remove connecting rod cap.
- Using a suitable tool, push piston and connecting rod assembly out to the cylinder head side.

CAUTION:

- Be careful not to damage matching surface with connecting rod cap.
- Be careful not to damage the cylinder wall and crankshaft pin, resulting from an interference of the connecting rod big end.



- Remove connecting rod bearings.


CAUTION:

When removing them, note the installation position. Keep them in the correct order.

- Remove piston rings from piston.
 - Before removing piston rings, check the piston ring side clearance. Refer to [EM-93, "PISTON RING SIDE CLEARANCE"](#).
- Using a suitable tool (A) remove piston rings.

CAUTION:


- When removing piston rings, be careful not to damage the piston.
- Be careful not to damage piston rings by expanding them excessively.




CYLINDER BLOCK

[MR20DE]


16. Using snap ring pliers (A), remove snap rings.



17. Heat piston to 60° to 70°C (140° to 158°F) using a suitable tool (A).



18. Push out piston pin using a suitable tool of an outer diameter approximately 18 mm (0.71 in).



19. Loosen main bearing cap bolts in reverse order as shown, and remove them.

NOTE:

Before loosening main bearing cap bolts, measure crankshaft end play. Refer to [EM-92. "CRANKSHAFT END PLAY"](#).

⇐ : Engine front


20. Remove main bearing caps.

- Tap main bearing caps lightly using a suitable tool for removal.

CAUTION:

Be careful not to damage the mounting surface.

21. Remove crankshaft.



A
EM
C
D
E
F
G
H
I
J
K
L
M

CYLINDER BLOCK

[MR20DE]


CAUTION:

- Be careful not to damage or deform signal plate (1) mounted on rear end of crankshaft (A).
- When setting crankshaft on a flat floor surface, use a block of wood to avoid interference between signal plate and the floor surface.
- Never remove signal plate unless it is necessary to do so.

22. Pull rear oil seal out from rear end of crankshaft.
23. Remove main bearings and thrust bearings from cylinder block and main bearing caps.

CAUTION:

Identify installation positions, and store them without mixing them up.



ASSEMBLY

1. Fully air-blow engine coolant and engine oil passages in cylinder block, cylinder bore and crankcase to remove any foreign material.

CAUTION:

Use a goggles to protect your eye.

2. Install water drain plug (1) to cylinder block.


⇐ : Engine front

- Apply liquid gasket to the drain plug thread.

Use Genuine Silicone RTV Sealant or equivalent. Refer to [GI-44, "Recommended Chemical Products and Sealants"](#).

9.8 N·m (1.0 kg·m, 87 in·lb)


3. Remove dust, dirt, and engine oil on the bearing mating surfaces of cylinder block and main bearing cap.



4. Install thrust bearings to the both sides of the No. 3 journal housing (B) on cylinder block.

⇐ : Engine front

- Install thrust bearings with the oil groove (A) facing crankshaft arm (outside).



5. Install the main bearings paying attention to the direction.

CAUTION:


- Before installing main bearings, apply new engine oil to the bearing surface (inside). Do not apply new engine oil to the back surface, but thoroughly clean it.
- When installing, align main bearing to the center position of cylinder block and main bearing cap.

CYLINDER BLOCK


[MR20DE]

- The difference (A) between main bearing upper (1) and main bearing lower (3) should be 0.85 mm (0.033 in) or less when installing.

- 2 : Cylinder block
- 4 : Main bearing cap



- Ensure the oil holes on cylinder block and oil holes (A) on the main bearings (1) are aligned.



6. Install signal plate to crankshaft if removed.
7. Set the signal plate with the flange facing toward the counter weight side (engine front side) to the crankshaft rear surface.
8. Apply new engine oil to threads and seat surfaces of bolts.
9. Position crankshaft (2) and signal plate (1) using a dowel pin (service part), and tighten bolts in numerical order as shown.

A : Dowel pin hole

NOTE:


Dowel pin of crankshaft and signal plate is provided as a set for each.

10. Tighten bolts in numerical order as shown.
11. Remove dowel pin. (service parts)

CAUTION:

Be sure to remove dowel pin.

12. Install crankshaft to cylinder block.
 - While turning crankshaft by hand, make sure that it turns smoothly.




13. Install main bearing caps referring to the journal No. stamp (A) and front mark (B) as shown.

↩ : Engine front

NOTE:

Main bearing cap cannot be replaced as a single part, because it is machined together with cylinder block.



14. Apply new engine oil to threads and seat surfaces of bolts.

CYLINDER BLOCK

[MR20DE]

15. Tighten main bearing cap bolts in two steps.

NOTE:



Tighten main bearing cap bolts in numerical order as shown:

← : Engine front

Step 1 : 34.3 N-m (3.5 kg-m, 25 ft-lb)

Step2 60° clockwise

Tool number : KV10112100 (BT-8653-A)



- After installing bolts, make sure that crankshaft can be rotated smoothly by hand.
- Check crankshaft end play. Refer to [EM-92, "CRANKSHAFT END PLAY"](#).

16. Using snap ring pliers, install new snap ring to the groove of the piston rear side.

- Insert it fully into groove to install.

17. Assemble piston to connecting rod.

- Using a suitable tool, heat the piston until the piston pin can be pushed in by hand without excess force [approximately 60° to 70 °C (140° to 158 °F)]. From the front to the rear, insert piston pin into piston and connecting rod.
- Assemble so that the front mark (A) on the piston head and the oil hole (B) and the cylinder number (C) on connecting rod are positioned as shown.

D : Big end diameter grade

E : Small end diameter grade

F : Front mark (connecting rod bearing cap)


18. Install new snap ring to the groove of the piston front side.

- Insert it fully into groove to install.
- After installing, make sure that connecting rod moves smoothly.

19. Using a suitable tool, install piston rings.

CAUTION:

- Be careful not to damage piston.
- Be careful not to damage piston rings by expanding them excessively.



CYLINDER BLOCK

[MR20DE]


- Position each ring with the gap as shown referring to the piston front mark.

- A : Oil ring upper or lower rail gap
- B : Front mark
- C : Second ring and oil ring spacer gap
- D : Top ring gap
- E : Stamped mark

CAUTION:

Never contact the rail end gap under the oil ring with the oil drain cast groove of piston.

- Install second ring with the stamped surface facing upward.



PBIC3588J



20. Install connecting rod bearing upper (2) and lower (3) to connecting rod (1) and connecting rod cap (4).

- C : Oil hole (connecting rod)
- D : Arrow view
- ⇐ : Engine front

- Install the connecting rod in the dimension shown.
- Make sure that connecting rod bearing oil hole (A) is completely in the inside of connecting rod oil hole chamfered area (B).
- When installing connecting rod bearings, apply new engine oil to the bearing surface (inside). Do not apply new engine oil to the back surface, but thoroughly clean it.

NOTE:

- There is no positioning tab.
- Install the connecting rod bearings in the center of connecting rod and connecting rod bearing cap as shown. For service operation, the center position can be checked, visually.




PBIC4541E

21. Install piston and connecting rod assembly to crankshaft.

- Position crankshaft pin corresponding to connecting rod to be installed onto the bottom dead center.
- Apply new engine oil sufficiently to the cylinder bore, piston and crankshaft pin.
- Match the cylinder position with the cylinder number (C) on connecting rod to install.

- B : Oil hole
- D : Big end diameter grade
- E : Small end diameter grade
- F : Front mark (connecting rod bearing cap)

- Install so that front mark (A) on the piston head faces the front of engine.



PBIC3587J


CYLINDER BLOCK

[MR20DE]

- Using a piston ring compressor [SST: EM03470000 (J-8037)] (A) or suitable tool, install piston with the front mark on the piston head facing the front of the engine.

CAUTION:

Be careful not to damage the cylinder wall and crankshaft pin, resulting from an interference of the connecting rod big end.




PBIC3244J

22. Install connecting rod cap.

- Match the stamped cylinder number marks (C) on connecting rod with those on connecting rod cap to install.

- A : Front mark (piston)
- B : Oil hole
- D : Big end diameter grade
- E : Small end diameter grade
- F : Front mark (connecting rod bearing cap)



PBIC3587J

23. Tighten connecting rod bolt with the following procedure:

CAUTION:

- **Make sure that there is no gap in the thrust surface (A) of the joint between connecting rod (1) and connecting rod bearing cap (2) and that these parts are in the correct position. And then, tighten the connecting rod bolts.**
- **If the connecting rod bolts are reused, measure the outer diameter. Refer to [EM-100, "CONNECTING ROD BOLT OUTER DIAMETER"](#) .**

24. Apply new engine oil to the threads and seats of connecting rod bolts.

25. Tighten bolts in three steps

Step 1 : 27.4 N·m (2.8 kg-m, 20 ft-lb)

Step 2 : 0 N·m (0 kg-m, 0 ft-lb)

Step 3 : 19.6 N·m (2.0 kg-m, 14 ft-lb)


- After tightening connecting rod bolt, make sure that crankshaft rotates smoothly.
- Check the connecting rod side clearance. Refer to [EM-92, "CONNECTING ROD SIDE CLEARANCE"](#) .

26. Install oil pan (upper). Refer to [EM-26, "OIL PAN"](#) .

NOTE:

Install the rear oil seal after installing the oil pan (upper).

27. Install rear oil seal. Refer to [EM-26, "OIL PAN"](#) .



PBIC3510J


CYLINDER BLOCK

[MR20DE]

28. Install flywheel (M/T models) or drive plate (1) (CVT models).

- Secure crankshaft using Tool. (A), and tighten bolts crosswise over several times.

Tool number : KV11105210 (J-44716)



- Install pilot converter (1), drive plate (2) and reinforcement plate (3) as shown (CVT models).


A : Crankshaft rear end

B : R

- Using a suitable tool of 33 mm. (1.30 in) in diameter, press-fit pilot converter into the end of crankshaft until it stops (CVT models).

NOTE:

M/T models have no pilot converter and reinforcement plate.



29. Install knock sensor (1) with connector facing toward the rear of engine.

A : Cylinder block left side

⇐ : Engine front

CAUTION:

- Never tighten bolts while holding the connector.
- If any impact by dropping is applied to knock sensor, replace it with a new one.


NOTE:

- Make sure that there is no foreign material on the cylinder block mating surface and the back surface of knock sensor.
- Make sure that knock sensor does not interfere with other parts.

30. Install crankshaft position sensor (POS) and crankshaft position sensor (POS) cover.


CAUTION:

- Avoid impacts such as a dropping.
- Keep it away from metal particles.
- Never place sensor in a location where it is exposed to magnetism.



31. Install oil filter (for intake valve timing control) (1) in the direction shown.

- Make sure that the oil filter does not protrude from the upper surface of cylinder block (2) after installation.



32. Assemble in the reverse order of disassembly.

How to Select Piston and Bearing DESCRIPTION

Selection points	Selection parts	Selection items	Selection methods
Between cylinder block and crankshaft	Main bearing	Main bearing grade (bearing thickness)	Determined by match of cylinder block bearing housing grade (inner diameter of housing) and crankshaft journal grade (outer diameter of journal)
Between crankshaft and connecting rod	Connecting rod bearing	Connecting rod bearing grade (bearing thickness)	Combining service grades for connecting rod big end diameter and crankshaft pin outer diameter determine connecting rod bearing selection.
Between cylinder block and piston	Piston and piston pin assembly (piston is available together with piston pin as an assembly.)	Piston grade (piston outer diameter)	Piston grade = cylinder bore grade (inner diameter of bore)

- The identification grade stamped on each part is the grade for the dimension measured in new condition. This grade cannot apply to reused parts.
- For reused or repaired parts, measure the dimension accurately. Determine the grade by comparing the measurement with the values of each selection table.
- For details of the measurement method of each part, the reuse standards and the selection method of the selective fitting parts, refer to the text.


HOW TO SELECT PISTON

When New Cylinder Block is Used

- Check the cylinder bore grade on rear left side of cylinder block (L), and select piston of the same grade.

- A : Correction stamp
- B : Standard stamp
- C : Cylinder No. 1 bore grade
- D : Cylinder No. 2 bore grade
- E : Cylinder No. 3 bore grade
- F : Cylinder No. 4 bore grade
- G : No. 1 main bearing housing grade
- H : No. 2 main bearing housing grade
- I : No. 3 main bearing housing grade
- J : No. 4 main bearing housing grade
- K : No. 5 main bearing housing grade
- ⇐ : Engine front

- If there is a correction stamp mark on the cylinder block, use it as a correct reference.



When Cylinder Block is Reused


1. Measure the cylinder bore inner diameter. Refer to [EM-96, "Cylinder Bore Inner Diameter"](#).
2. Determine the bore grade by comparing the measurement with the values under the cylinder bore inner diameter of the "Piston Selection Table".

CYLINDER BLOCK

[MR20DE]

3. Select piston of the same grade.

- A : Identification code
- B : Front mark
- C : Piston grade number



Piston Selection Table

Unit: mm (in)

Grade number (Mark)	1	2 [or no mark (piston only)]
Cylinder bore Inner diameter	84.000 - 84.010 (3.3071 - 3.3075)	84.010 - 84.020 (3.3075 - 3.3079)
Piston skirt diameter	83.970 - 83.980 (3.3059 - 3.3063)	83.980 - 83.990 (3.3063 - 3.3067)

NOTE:


- Piston is available together with piston pin as an assembly.
- There is no piston pin (piston pin hole) grade.

HOW TO SELECT CONNECTING ROD BEARING

When New Connecting Rod and Crankshaft are Used


1. Apply connecting rod big end diameter grade stamped (C) on connecting rod side face to the row in the "Connecting Rod Bearing Selection Table".

- A : Oil hole
- B : Cylinder number
- D : Small end diameter grade
- E : Front mark



2. Apply crankshaft pin journal diameter grade stamped on crankshaft front side to the column in the "Connecting Rod Bearing Selection Table".

- A : No. 1 pin journal diameter grade
- B : No. 2 pin journal diameter grade
- C : No. 3 pin journal diameter grade
- D : No. 4 pin journal diameter grade
- E : No. 1 main journal diameter grade
- F : No. 2 main journal diameter grade
- G : No. 3 main journal diameter grade
- H : No. 4 main journal diameter grade
- I : No. 5 main journal diameter grade



3. Read the symbol at the cross point of selected row and column in the "Connecting Rod Bearing Selection Table".
4. Apply the symbol obtained to the "Connecting Rod Bearing Grade Table" to select connecting rod bearing.

When Crankshaft and Connecting Rod are Reused

1. Measure the dimensions of the connecting rod big end diameter and crankshaft pin journal diameter individually. Refer to [EM-94, "CONNECTING ROD BIG END DIAMETER"](#) and [EM-97, "CRANKSHAFT PIN JOURNAL DIAMETER"](#).

CYLINDER BLOCK

[MR20DE]

2. Apply the measured dimension to the “Connecting Rod Bearing Selection Table”.
3. Read the symbol at the cross point of selected row and column in the “Connecting Rod Bearing Selection Table”.
4. Apply the symbol obtained to the “Connecting Rod Bearing Grade Table” to select connecting rod bearing.

Connecting Rod Bearing Selection Table

Crankshaft pin journal diameter Unit: mm (in)		Connecting rod big end diameter Unit: mm (in)		Mark													
				Hole diameter													
Mark	Axle diameter	47.000 - 47.001 (1.8504 - 1.8504)	47.001 - 47.002 (1.8504 - 1.8505)	47.002 - 47.003 (1.8505 - 1.8505)	47.003 - 47.004 (1.8505 - 1.8505)	47.004 - 47.005 (1.8505 - 1.8506)	47.005 - 47.006 (1.8506 - 1.8506)	47.006 - 47.007 (1.8506 - 1.8507)	47.007 - 47.008 (1.8507 - 1.8507)	47.008 - 47.009 (1.8507 - 1.8507)	47.009 - 47.010 (1.8507 - 1.8508)	47.010 - 47.011 (1.8508 - 1.8508)	47.011 - 47.012 (1.8508 - 1.8509)	47.012 - 47.013 (1.8509 - 1.8509)			
A	43.970 - 43.971 (1.7311 - 1.7311)	0	0	0	0	0	01	01	01	1	1	1	12	12			
B	43.969 - 43.970 (1.7311 - 1.7311)	0	0	0	0	01	01	01	1	1	1	1	12	12			
C	43.968 - 43.969 (1.7310 - 1.7311)	0	0	0	01	01	01	1	1	1	12	12	12	2			
D	43.967 - 43.968 (1.7310 - 1.7310)	0	0	01	01	01	1	1	1	12	12	12	2	2			
E	43.966 - 43.967 (1.7309 - 1.7310)	0	01	01	01	1	1	1	12	12	12	2	2	2			
F	43.965 - 43.966 (1.7309 - 1.7309)	01	01	01	1	1	1	12	12	12	2	2	2	23			
G	43.964 - 43.965 (1.7309 - 1.7309)	01	01	1	1	1	12	12	12	2	2	2	23	23			
H	43.963 - 43.964 (1.7308 - 1.7309)	01	1	1	1	12	12	12	2	2	2	23	23	23			
J	43.962 - 43.963 (1.7308 - 1.7308)	1	1	1	12	12	12	2	2	2	23	23	23	3			
K	43.961 - 43.962 (1.7307 - 1.7308)	1	1	12	12	12	2	2	2	23	23	23	3	3			
L	43.960 - 43.961 (1.7307 - 1.7307)	1	12	12	12	2	2	2	23	23	23	3	3	3			
M	43.959 - 43.960 (1.7307 - 1.7307)	12	12	12	2	2	2	23	23	23	3	3	3	34			
N	43.958 - 43.959 (1.7306 - 1.7307)	12	12	2	2	2	23	23	23	3	3	3	34	34			
P	43.957 - 43.958 (1.7306 - 1.7306)	12	2	2	2	23	23	23	3	3	3	34	34	34			
R	43.956 - 43.957 (1.7305 - 1.7306)	2	2	2	23	23	23	3	3	3	34	34	34	4			
S	43.955 - 43.956 (1.7305 - 1.7305)	2	2	23	23	23	3	3	3	34	34	34	4	4			
T	43.954 - 43.955 (1.7305 - 1.7305)	2	23	23	23	3	3	3	34	34	34	4	4	4			
U	43.953 - 43.954 (1.7304 - 1.7305)	23	23	23	3	3	3	34	34	34	4	4	4	4			

PBIC4077E

CYLINDER BLOCK

[MR20DE]

Connecting Rod Bearing Grade Table

Unit: mm (in)


Grade number		Thickness	Identification color	Remarks
0		1.494 - 1.497 (0.0588 - 0.0589)	Black	Grade and color are the same for upper and lower bearings.
1		1.497 - 1.500 (0.0589 - 0.0591)	Brown	
2		1.500 - 1.503 (0.0591 - 0.0592)	Green	
3		1.503 - 1.506 (0.0592 - 0.0593)	Yellow	
4		1.506 - 1.509 (0.0593 - 0.0594)	Blue	
01	UPR	1.494 - 1.497 (0.0588 - 0.0589)	Black	Grade and color are different between upper and lower bearings.
	LWR	1.497 - 1.500 (0.0589 - 0.0591)	Brown	
12	UPR	1.497 - 1.500 (0.0589 - 0.0591)	Brown	
	LWR	1.500 - 1.503 (0.0591 - 0.0592)	Green	
23	UPR	1.500 - 1.503 (0.0591 - 0.0592)	Green	
	LWR	1.503 - 1.506 (0.0592 - 0.0593)	Yellow	
34	UPR	1.503 - 1.506 (0.0592 - 0.0593)	Yellow	
	LWR	1.506 - 1.509 (0.0593 - 0.0594)	Blue	

Undersize Bearings Usage Guide

- When the specified connecting rod bearing oil clearance is not obtained with standard size connecting rod bearings, use undersize (US) bearings.
- When using undersize (US) bearing, measure the connecting rod bearing inner diameter with bearing installed, and grind the crankshaft pin so that the connecting rod bearing oil clearance satisfies the standard.

CAUTION:

In grinding crankshaft pin to use undersize bearings, keep the fillet R [1.5 - 1.7 mm (0.059 - 0.067 in)] (A).



Bearing undersize table

Unit: mm (in)

Size	Thickness
US 0.25 (0.0098)	1.623 - 1.631 (0.0639 - 0.0642)


HOW TO SELECT MAIN BEARING

When New Cylinder Block and Crankshaft are Used

1. "Main Bearing Selection Table" rows correspond to main bearing housing grade on rear left side of cylinder block (L).


- A : Correction stamp
- B : Standard stamp
- C : Cylinder No. 1 bore grade
- D : Cylinder No. 2 bore grade
- E : Cylinder No. 3 bore grade
- F : Cylinder No. 4 bore grade
- G : No. 1 main bearing housing grade
- H : No. 2 main bearing housing grade
- I : No. 3 main bearing housing grade
- J : No. 4 main bearing housing grade
- K : No. 5 main bearing housing grade
- ↔ : Engine front

- If there is a correction stamp mark on cylinder block, use it as a correct reference.



2. Apply main journal diameter grade stamped on crankshaft front side to column in the "Main Bearing Selection Table".

- A : No. 1 pin journal diameter grade
- B : No. 2 pin journal diameter grade
- C : No. 3 pin journal diameter grade
- D : No. 4 pin journal diameter grade
- E : No. 1 main journal diameter grade
- F : No. 2 main journal diameter grade
- G : No. 3 main journal diameter grade
- H : No. 4 main journal diameter grade
- I : No. 5 main journal diameter grade



3. Read the symbol at the cross point of selected row and column in the "Main Bearing Selection Table".

CAUTION:

There are two main bearing selection tables. One is for No. 1, 4 and 5 journals and the other is for No. 2 and 3 journals. Make certain to use the appropriate table. This is due to differences in the specified clearances.

4. Apply the symbol obtained to the "Main Bearing Grade Table" to select main bearing.

NOTE:

Service part is available as a set of both upper and lower.

When Cylinder Block and Crankshaft are Reused

1. Measure the dimensions of the cylinder block main bearing housing inner diameter and crankshaft main journal diameter individually. Refer to [EM-95, "MAIN BEARING HOUSING INNER DIAMETER"](#) and [EM-97, "CRANKSHAFT MAIN JOURNAL DIAMETER"](#).
2. Apply the measured dimension to the "Main Bearing Selection Table".
3. Read the symbol at the cross point of selected row and column in the "Main Bearing Selection Table".

CYLINDER BLOCK

[MR20DE]

CAUTION:

There are two main bearing selection tables. One is for No. 1, 4 and 5 journals and the other is for No. 2 and 3 journals. Make certain to use the appropriate table. This is due to differences in the specified clearances.

- Apply the symbol obtained to the "Main Bearing Grade Table" to select main bearing.

NOTE:

Service part is available as a set of both upper and lower.

Main Bearing Selection Table (No. 1, 4 and 5 journals)

Cylinder block main bearing housing inner diameter Unit: mm (in)	Mark	Hole diameter																								
		A	B	C	D	E	F	G	H	J	K	L	M	N	P	R	S	T	U	V	W					
Crankshaft main journal diameter Unit: mm (in)	Mark	Axle diameter																								
			55.997 - 55.998 (2.2046 - 2.2046)	55.998 - 55.999 (2.2046 - 2.2047)	55.999 - 56.000 (2.2047 - 2.2047)	56.000 - 56.001 (2.2047 - 2.2048)	56.001 - 56.002 (2.2048 - 2.2048)	56.002 - 56.003 (2.2048 - 2.2048)	56.003 - 56.004 (2.2048 - 2.2049)	56.004 - 56.005 (2.2049 - 2.2049)	56.005 - 56.006 (2.2049 - 2.2050)	56.006 - 56.007 (2.2050 - 2.2050)	56.007 - 56.008 (2.2050 - 2.2050)	56.008 - 56.009 (2.2050 - 2.2051)	56.009 - 56.010 (2.2051 - 2.2051)	56.010 - 56.011 (2.2051 - 2.2052)	56.011 - 56.012 (2.2052 - 2.2052)	56.012 - 56.013 (2.2052 - 2.2052)	56.013 - 56.014 (2.2052 - 2.2053)	56.014 - 56.015 (2.2053 - 2.2053)	56.015 - 56.016 (2.2053 - 2.2053)	56.016 - 56.017 (2.2053 - 2.2054)				
A		51.978 - 51.979 (2.0464 - 2.0464)	0	0	0	0	0	0	0	01	01	01	1	1	1	12	12	12	2	2	2	23	23			
B		51.977 - 51.978 (2.0463 - 2.0464)	0	0	0	0	0	0	01	01	01	1	1	1	12	12	12	2	2	2	23	23	23			
C		51.976 - 51.977 (2.0463 - 2.0463)	0	0	0	0	0	01	01	01	1	1	1	12	12	12	2	2	2	23	23	23	23			
D		51.975 - 51.976 (2.0463 - 2.0463)	0	0	0	0	01	01	01	1	1	1	12	12	12	2	2	2	23	23	23	23	3			
E		51.974 - 51.975 (2.0462 - 2.0463)	0	0	0	01	01	01	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3			
F		51.973 - 51.974 (2.0462 - 2.0462)	0	0	01	01	01	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	3			
G		51.972 - 51.973 (2.0461 - 2.0462)	0	01	01	01	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	3	34			
H		51.971 - 51.972 (2.0461 - 2.0461)	01	01	01	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34			
J		51.970 - 51.971 (2.0461 - 2.0461)	01	01	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	34			
K		51.969 - 51.970 (2.0460 - 2.0461)	01	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	34	4			
L		51.968 - 51.969 (2.0460 - 2.0460)	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4			
M		51.967 - 51.968 (2.0459 - 2.0460)	1	1	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	4			
N		51.966 - 51.967 (2.0459 - 2.0459)	1	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	4	45			
P		51.965 - 51.966 (2.0459 - 2.0459)	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	45	45	45			
R		51.964 - 51.965 (2.0458 - 2.0459)	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	45	45	45	45			
S		51.963 - 51.964 (2.0458 - 2.0458)	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	45	45	45	45	5			
T		51.962 - 51.963 (2.0457 - 2.0458)	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	45	45	45	5	5	5			
U		51.961 - 51.962 (2.0457 - 2.0457)	2	2	23	23	23	3	3	3	34	34	34	4	4	4	45	45	45	5	5	5	5			
V		51.960 - 51.961 (2.0457 - 2.0457)	2	23	23	23	3	3	3	34	34	34	4	4	4	45	45	45	5	5	5	5	5			
W		51.959 - 51.960 (2.0456 - 2.0457)	23	23	23	3	3	3	34	34	34	4	4	4	45	45	45	5	5	5	5	5	5			

PBIC4078E

CYLINDER BLOCK

[MR20DE]

Main Bearing Selection Table (No. 2 and 3 journals)

Crankshaft main journal diameter Unit: mm (in)	Cylinder block main bearing housing inner diameter Unit: mm (in)	Mark		Hole diameter																						
		A	B	C	D	E	F	G	H	J	K	L	M	N	P	R	S	T	U	V	W					
Mark	Axle diameter	55.997 - 55.998 (2.2046 - 2.2046)	55.998 - 55.999 (2.2046 - 2.2047)	55.999 - 56.000 (2.2047 - 2.2047)	56.000 - 56.001 (2.2047 - 2.2048)	56.001 - 56.002 (2.2048 - 2.2048)	56.002 - 56.003 (2.2048 - 2.2048)	56.003 - 56.004 (2.2048 - 2.2049)	56.004 - 56.005 (2.2049 - 2.2049)	56.005 - 56.006 (2.2049 - 2.2050)	56.006 - 56.007 (2.2050 - 2.2050)	56.007 - 56.008 (2.2050 - 2.2050)	56.008 - 56.009 (2.2050 - 2.2051)	56.009 - 56.010 (2.2051 - 2.2051)	56.010 - 56.011 (2.2051 - 2.2052)	56.011 - 56.012 (2.2052 - 2.2052)	56.012 - 56.013 (2.2052 - 2.2052)	56.013 - 56.014 (2.2052 - 2.2053)	56.014 - 56.015 (2.2053 - 2.2053)	56.015 - 56.016 (2.2053 - 2.2053)	56.016 - 56.017 (2.2053 - 2.2054)					
A	51.978 - 51.979 (2.0464 - 2.0464)	1	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	45	45				
B	51.977 - 51.978 (2.0463 - 2.0464)	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	45	45					
C	51.976 - 51.977 (2.0463 - 2.0463)	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	45	45	45					
D	51.975 - 51.976 (2.0463 - 2.0463)	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	45	45	45	5	5				
E	51.974 - 51.975 (2.0462 - 2.0463)	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	45	45	45	5	5					
F	51.973 - 51.974 (2.0462 - 2.0462)	2	2	23	23	23	3	3	3	34	34	34	4	4	4	45	45	45	5	5	5					
G	51.972 - 51.973 (2.0461 - 2.0462)	2	23	23	23	3	3	3	34	34	34	4	4	4	45	45	45	5	5	5	56	56				
H	51.971 - 51.972 (2.0461 - 2.0461)	23	23	23	3	3	3	34	34	34	4	4	4	45	45	45	5	5	5	56	56					
J	51.970 - 51.971 (2.0461 - 2.0461)	23	23	3	3	3	34	34	34	4	4	4	45	45	45	5	5	5	56	56	56	56				
K	51.969 - 51.970 (2.0460 - 2.0461)	23	3	3	3	34	34	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6				
L	51.968 - 51.969 (2.0460 - 2.0460)	3	3	3	34	34	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6					
M	51.967 - 51.968 (2.0459 - 2.0460)	3	3	34	34	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6	6	6				
N	51.966 - 51.967 (2.0459 - 2.0459)	3	34	34	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6	6	6	67				
P	51.965 - 51.966 (2.0459 - 2.0459)	34	34	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6	6	67	67	67				
R	51.964 - 51.965 (2.0458 - 2.0459)	34	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6	6	67	67	67	67				
S	51.963 - 51.964 (2.0458 - 2.0458)	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6	6	67	67	67	7	7				
T	51.962 - 51.963 (2.0457 - 2.0458)	4	4	4	45	45	45	5	5	5	56	56	56	6	6	6	67	67	67	7	7	7				
U	51.961 - 51.962 (2.0457 - 2.0457)	4	4	45	45	45	5	5	5	56	56	56	6	6	6	67	67	67	7	7	7	7				
V	51.960 - 51.961 (2.0457 - 2.0457)	4	45	45	45	5	5	5	56	56	56	6	6	6	67	67	67	7	7	7	7	7				
W	51.959 - 51.960 (2.0456 - 2.0457)	45	45	45	5	5	5	56	56	56	6	6	6	67	67	67	7	7	7	7	7	7				

PBIC4079E

CYLINDER BLOCK

[MR20DE]

Main Bearing Grade Table (All Journals)

Unit: mm (in)


Grade number	Thickness	Identification color	Remarks	
0	1.996 - 1.999 (0.0786 - 0.0787)	Black	Grade and color are the same for upper and lower bearings.	
1	1.999 - 2.002 (0.0787 - 0.0788)	Brown		
2	2.002 - 2.005 (0.0788 - 0.0789)	Green		
3	2.005 - 2.008 (0.0789 - 0.0791)	Yellow		
4	2.008 - 2.011 (0.0791 - 0.0792)	Blue		
5	2.011 - 2.014 (0.0792 - 0.0793)	Pink		
6	2.014 - 2.017 (0.0793 - 0.0794)	Purple		
7	2.017 - 2.020 (0.0794 - 0.0795)	White		
01	UPR	1.996 - 1.999 (0.0786 - 0.0787)	Black	Grade and color are different between upper and lower bearings.
	LWR	1.999 - 2.002 (0.0787 - 0.0788)	Brown	
12	UPR	1.999 - 2.002 (0.0787 - 0.0788)	Brown	
	LWR	2.002 - 2.005 (0.0788 - 0.0789)	Green	
23	UPR	2.002 - 2.005 (0.0788 - 0.0789)	Green	
	LWR	2.005 - 2.008 (0.0789 - 0.0791)	Yellow	
34	UPR	2.005 - 2.008 (0.0789 - 0.0791)	Yellow	
	LWR	2.008 - 2.011 (0.0791 - 0.0792)	Blue	
45	UPR	2.008 - 2.011 (0.0791 - 0.0792)	Blue	
	LWR	2.011 - 2.014 (0.0792 - 0.0793)	Pink	
56	UPR	2.011 - 2.014 (0.0792 - 0.0793)	Pink	
	LWR	2.014 - 2.017 (0.0793 - 0.0794)	Purple	
67	UPR	2.014 - 2.017 (0.0793 - 0.0794)	Purple	
	LWR	2.017 - 2.020 (0.0794 - 0.0795)	White	

Use Undersize Bearing Usage Guide

- When the specified main bearing oil clearance is not obtained with standard size main bearings, use undersize (US) bearing.
- When using undersize (US) bearing, measure the main bearing inner diameter with bearing installed, and grind main journal so that the main bearing oil clearance satisfies the standard.

CAUTION:

In grinding crankshaft main journal to use undersize bearings, keep the fillet R [1.5 - 1.7 mm (0.059 - 0.067 in)] (A).



Bearing undersize table

Unit: mm (in)

Size	Thickness
US 0.25 (0.0098)	2.126 - 2.134 (0.0837 - 0.0840)

Inspection After Disassembly


CRANKSHAFT END PLAY

- Measure the clearance between thrust bearings and crankshaft arm when crankshaft is moved fully forward or backward with a dial indicator (A).

Standard : 0.10 - 0.26 mm (0.0039 - 0.0102 in)

Limit : 0.30 mm (0.012 in)

- If the measured value exceeds the limit, replace thrust bearings, and measure again. If it still exceeds the limit, replace crankshaft also.




CONNECTING ROD SIDE CLEARANCE

- Measure the side clearance between connecting rod and crankshaft arm with a feeler gauge (A).

Standard : 0.20 - 0.35 mm (0.0079 - 0.0138 in)

Limit : 0.40 mm (0.0157 in)

- If the measured value exceeds the limit, replace connecting rod, and measure again. If it still exceeds the limit, replace crankshaft also.




PISTON TO PISTON PIN OIL CLEARANCE

Piston Pin Hole Diameter

Measure the inner diameter of piston pin hole with an inside micrometer (A).


Standard: 19.993 - 19.999 mm (0.7871 - 0.7874 in)



Piston Pin Outer Diameter

Measure the outer diameter of piston pin with a micrometer (A).

Standard: 19.989 - 19.995 mm (0.7870 - 0.7872 in)



Piston to Piston Pin Oil Clearance

(Piston to piston pin oil clearance) = (Piston pin hole diameter) – (Piston pin outer diameter)

Standard: 0.002 - 0.006 mm (0.0001 - 0.0002 in)

- If oil clearance is out of the standard, replace piston and piston pin assembly.

- When replacing piston and piston pin assembly, refer to [EM-96, "Piston to Cylinder Bore Clearance"](#) .

NOTE:

- Piston is available together with piston pin as assembly.
- Piston pin (piston pin hole) grade is provided only for the parts installed at the plant. For service parts, no grades can be selected. (Only grade "0" is available.)

PISTON RING SIDE CLEARANCE


- Measure the side clearance of piston ring and piston ring groove with a feeler gauge (A).

Standard:

- Top ring** : 0.04 - 0.08 mm (0.002 - 0.003 in)
- 2nd ring** : 0.03 - 0.07 mm (0.001 - 0.003 in)
- Oil ring** : 0.015 - 0.185 mm (0.001 - 0.007 in)

Limit:

- Top ring** : 0.11 mm (0.0043 in)
- 2nd ring** : 0.10 mm (0.0039 in)



- If the measured value exceeds the limit, replace piston ring, and measure again. If it still exceeds the limit, replace piston also.

PISTON RING END GAP


- Make sure that cylinder bore inner diameter is within specification. Refer to [EM-96, "Cylinder Bore Inner Diameter"](#) .
- Lubricate with new engine oil to piston (1) and piston ring (2), and then insert (A) piston ring until middle of cylinder (B) with piston, and measure piston ring end gap with a feeler gauge (C).

Standard:

- Top ring** : 0.20 - 0.30 mm (0.008 - 0.012 in)
- 2nd ring** : 0.50 - 0.65 mm (0.020 - 0.026 in)
- Oil ring (rail ring)** : 0.15 - 0.45 mm (0.006 - 0.018 in)

Limit:

- Top ring** : 0.51 mm (0.020 in)
- 2nd ring** : 0.83 mm (0.033 in)
- Oil ring (rail ring)** : 0.78 mm (0.031 in)



- If the measured value exceeds the limit, replace piston ring, and measure again. If it still exceeds the limit, re-bore cylinder and use oversized piston and piston rings.

CONNECTING ROD BEND AND TORSION

- Check with a connecting rod aligner.

C : Feeler gauge


Bend (A):

Limit: 0.15 mm (0.0059 in) per 100 mm (3.94 in) length

Torsion (B):

Limit: 0.30 mm (0.0118 in) per 100 mm (3.94 in) length

- If it exceeds the limit, replace connecting rod assembly.



CONNECTING ROD BIG END DIAMETER

- Install connecting rod cap (1) without connecting rod bearing installed, and tightening connecting rod bolts to the specified torque. Refer to [EM-78, "ASSEMBLY"](#) for the tightening procedure.

2 : Connecting rod


A : Example

B : Measuring direction of inner diameter

- Measure the inner diameter of connecting rod big end with an inside micrometer.

Standard: 47.000 - 47.013 mm (1.8504 - 1.8509 in)

- If out of the standard, replace connecting rod assembly.




CONNECTING ROD BUSHING OIL CLEARANCE

Connecting Rod Bushing Inner Diameter

Measure the inner diameter of connecting rod bushing with an inside micrometer (A).


Standard: 20.000 - 20.012 mm (0.7874 - 0.7879 in)



Piston Pin Outer Diameter

Measure the outer diameter of piston pin with a micrometer (A).

Standard: 19.989 - 19.995 mm (0.7870 - 0.7872 in)



Connecting Rod Bushing Oil Clearance

(Connecting rod bushing oil clearance) = (Connecting rod bushing inner diameter) – (Piston pin outer diameter)

Standard : 0.005 - 0.023 mm (0.0002 - 0.0009 in)

Limit : 0.03 mm (0.0012 in)

- If the measured value is out of the standard, replace connecting rod assembly and/or piston and piston pin assembly.
- If replacing piston and piston pin assembly, refer to [EM-92, "PISTON TO PISTON PIN OIL CLEARANCE"](#)
- If replacing connecting rod assembly, refer to [EM-95, "Connecting Rod Bushing Oil Clearance"](#) to select connecting rod bearing.

CYLINDER BLOCK TOP SURFACE DISTORTION

- Using a scraper, remove gasket on the cylinder block surface, and also remove engine oil, scale, carbon, or other contamination.


CAUTION:

Be careful not to allow gasket flakes to enter engine oil or engine coolant passages.

- Measure the distortion on the cylinder block upper face at some different points in six directions with a straight edge (A) and feeler gauge (B).

Limit: 0.1 mm (0.004 in)

- If it exceeds the limit, replace cylinder block.



MAIN BEARING HOUSING INNER DIAMETER

- Install main bearing cap without main bearings installed, and tighten main bearing cap bolts to the specified torque. Refer to [EM-78, "ASSEMBLY"](#) for the tightening procedure.
- Measure the inner diameter of main bearing housing with a bore gauge.

CYLINDER BLOCK

[MR20DE]

- Measure the position shown [5 mm (0.20 in)] backward from main bearing housing front side in the 2 directions as shown. The smaller one is the measured value.


- 1 : Cylinder block
- 2 : Main bearing cap
- ⇐ : Engine front

Standard: 55.997 - 56.017 mm (2.2046 - 2.2054 in)

- If out of the standard, replace cylinder block and main bearing caps assembly.

NOTE:

Main bearing caps cannot be replaced as a single, because it is machined together with cylinder block.



PISTON TO CYLINDER BORE CLEARANCE

Cylinder Bore Inner Diameter

- Using a bore gauge (A), measure the cylinder bore for wear, out-of-round and taper at six different points on each cylinder. ("X" and "Y" directions at "A", "B" and "C") ("Y" is in longitudinal direction of engine)

NOTE:

When determining cylinder bore grade, measure the cylinder bore "X" direction at "B" position.

Standard inner diameter:

84.000 - 84.020 mm (3.3071 - 3.3079 in)

Out-of-round (Difference between "X" and "Y"):

0.015 mm (0.0006 in)


Taper limit (Difference between "A" and "C"):

0.01 mm (0.0004 in)

- If the measured value exceeds the limit, or if there are scratches and/or seizure on the cylinder inner wall, replace cylinder block.

NOTE:

Oversize piston is not provided.



Piston Skirt Diameter


Measure the outer diameter of piston skirt with a micrometer (A).

Measure point

: Distance from the top 39.9 mm (1.571 in)

Standard

: 83.970 - 83.990 mm (3.3059 - 3.3067 in)



Piston to Cylinder Bore Clearance

Calculate by piston skirt diameter and cylinder bore inner diameter (direction "X", position "B").
 (Clearance) = (Cylinder bore inner diameter) – (Piston skirt diameter)

Standard : 0.020 - 0.040 mm (0.0008 - 0.0016 in)

Limit : 0.08 mm (0.0031 in)

CYLINDER BLOCK

[MR20DE]


- If it exceeds the limit, replace piston and piston pin assembly and/or cylinder block. Refer to [EM-84, "HOW TO SELECT PISTON"](#).

CRANKSHAFT MAIN JOURNAL DIAMETER

- Measure the outer diameter of crankshaft main journals with a micrometer (A).

Standard: 51.959 - 51.979 mm (2.0456 - 2.0464 in) dia.

- If out of the standard, measure the main bearing oil clearance. Then use undersize bearing. Refer to [EM-98, "MAIN BEARING OIL CLEARANCE"](#).



CRANKSHAFT PIN JOURNAL DIAMETER

- Measure the outer diameter of crankshaft pin journal with a micrometer.

Standard: 43.953 - 43.971 mm (1.7304-1.7311 in) dia.

- If out of the standard, measure the connecting rod bearing oil clearance. Then use undersize bearing. Refer to [EM-98, "CONNECTING ROD BEARING OIL CLEARANCE"](#).

OUT-OF-ROUND AND TAPER OF CRANKSHAFT

- Measure the dimensions at four different points as shown on each main journal and pin journal with a micrometer.
- Out-of-round is indicated by the difference in dimensions between "X" and "Y" at "A" and "B".
- Taper is indicated by the difference in dimension between "A" and "B" at "X" and "Y".


Limit:

Out-of-round (Difference between "X" and "Y")

: 0.0035 mm (0.0001 in)

Taper (Difference between "A" and "B")

: 0.0035 mm (0.0001 in)



- If the measured value exceeds the limit, correct or replace crankshaft.
- If corrected, measure the bearing oil clearance of the corrected main journal and/or pin journal. Then select main bearing and/or connecting rod bearing. Refer to [EM-98, "MAIN BEARING OIL CLEARANCE"](#) and/or [EM-98, "CONNECTING ROD BEARING OIL CLEARANCE"](#).


CRANKSHAFT RUNOUT

- Place a V-block on a precise flat table to support the journals on the both end of the crankshaft.
- Place a dial indicator (A) straight up on the No. 3 journal.
- While rotating crankshaft, read the movement of the pointer on the dial indicator. (Total indicator reading)

Standard : 0.05 mm (0.0020 in)

Limit : 0.10 mm (0.0040 in)

- If it exceeds the limit, replace crankshaft.



CONNECTING ROD BEARING OIL CLEARANCE

Method by Calculation

- Install connecting rod bearings (2) to connecting rod (3) and connecting rod bearing cap (1), and tighten connecting rod bolts to the specified torque. Refer to [EM-78, "ASSEMBLY"](#) for tightening procedure.

A : Example


B : Inner diameter measuring direction

- Measure the inner diameter of connecting rod bearing with an inside micrometer.
(Bearing oil clearance) = (Connecting rod bearing inner diameter) – (Crankshaft pin journal diameter)

Standard : 0.037 - 0.047 mm (0.0015 - 0.0019 in)

Limit : 0.07 mm (0.0028 in)

- If clearance exceeds the limit, select proper connecting rod bearing according to connecting rod big end diameter and crankshaft pin journal diameter to obtain specified bearing oil clearance. Refer to [EM-85, "HOW TO SELECT CONNECTING ROD BEARING"](#).



Method of Using Plastigage

- Remove engine oil and dust on crankshaft pin and the surfaces of each bearing completely.
- Cut a plastigage slightly shorter than the bearing width, and place it in crankshaft axial direction, avoiding oil holes.
- Install connecting rod bearings to connecting rod and cap, and tighten connecting rod bolts to the specified torque. Refer to [EM-78, "ASSEMBLY"](#) for the tightening procedure.


CAUTION:

Never rotate crankshaft.

- Remove connecting rod cap and bearing, and using the scale (A) on the plastigage bag, measure the plastigage width.

NOTE:

The procedure when the measured value exceeds the limit is same as that described in the "Method by Calculation".



MAIN BEARING OIL CLEARANCE

Method by Calculation

- Install main bearings (3) to cylinder block (1) and main bearing cap (2), and tighten main bearing cap bolts to the specified torque. Refer to [EM-78, "ASSEMBLY"](#) for the tightening procedure.

A : Example

B : Inner diameter measuring direction


- Measure the inner diameter of main bearing with a bore gauge.
(Bearing oil clearance) = (Main bearing inner diameter) – (Crankshaft main journal diameter)

Standard:

No. 1, 4 and 5 journals

: 0.024 - 0.034 mm (0.0009 - 0.0013 in)

No. 2 and 3 journals



: 0.012 - 0.022 mm (0.0005 - 0.0009 in)

Limit : 0.065 mm (0.0026 in)

- If clearance exceeds the limit, select proper main bearing according to main bearing inner diameter and crankshaft main journal diameter to obtain specified bearing oil clearance. Refer to [EM-88, "HOW TO SELECT MAIN BEARING"](#).

Method of Using Plastigage

- Remove engine oil and dust on crankshaft main journal and the surfaces of each bearing completely.
- Cut a plastigage slightly shorter than the bearing width, and place it in crankshaft axial direction, avoiding oil holes.
- Install main bearings to cylinder block and main bearing cap, and tighten main bearing cap bolts to the specified torque. Refer to [EM-78, "ASSEMBLY"](#) for the tightening procedure.


CAUTION:

Never rotate crankshaft.

- Remove main bearing cap and bearings, and using the scale (A) on the plastigage bag, measure the plastigage width.

NOTE:

The procedure when the measured value exceeds the limit is same as that described in the "Method by Calculation".




MAIN BEARING CRUSH HEIGHT

- When main bearing cap is removed after being tightened to the specified torque with main bearings (1) installed, the tip end of bearing must protrude (B). Refer to [EM-78, "ASSEMBLY"](#) for the tightening procedure.

A : Example

Standard : There must be crush height.

- If the standard is not met, replace main bearings.




CONNECTING ROD BEARING CRUSH HEIGHT

- When connecting rod bearing cap is removed after being tightened to the specified torque with connecting rod bearings (1) installed, the tip end of bearing must protrude. Refer to [EM-78, "ASSEMBLY"](#) for the tightening procedure (B).

A : Example

Standard : There must be crush height.

- If the standard is not met, replace connecting rod bearings.



CYLINDER BLOCK

[MR20DE]

MAIN BEARING CAP BOLT OUTER DIAMETER

- Measure the outer diameters (“d1”, “d2”) at two positions as shown.


A : “d1” measuring position

B : “d2” measuring position

- If reduction appears in places other than “B” range, regard it as “d2”.

Limit (“d1” – “d2”): 0.15 mm (0.0059 in)

- If it exceeds the limit (a large difference in dimensions), replace main bearing cap bolt with a new one.




CONNECTING ROD BOLT OUTER DIAMETER

- Measure the outer diameter “d” at position as shown.
- If reduction appears in a position other than “d”, regard it as “d”.


Limit: 7.75 mm (0.3051 in)

- When “d” exceeds the limit (when it becomes thinner), replace connecting rod bolt with a new one.



CLOGGED OR DAMAGED OIL FILTER (FOR INTAKE VALVE TIMING CONTROL)

- Make sure that there is no foreign material on the oil filter and check it for clogging.
 - Clean it if necessary.
- Check the oil filter for damage.
 - Replace it if necessary.



FLYWHEEL DEFLECTION (M/T MODELS)

- Measure the deflection of flywheel contact surface to clutch with a dial indicator (A).
- Measure the deflection at 210 mm (8.27 in) diameter.

Limit : 0.45 mm (0.0177 in) or less.

- If measured value is out of the standard, replace flywheel.
- If a trace of burn or discoloration is found on the surface, repair it with sandpaper.

CAUTION:

When measuring, keep magnetic fields (such as dial indicator stand) away from signal plate of the rear end of crankshaft.


MOVEMENT AMOUNT OF FLYWHEEL (M/T MODELS)

CAUTION:

Never disassemble double mass flywheel.

Movement Amount of Thrust (Fore-and-Aft) Direction

- Measure the movement amount of thrust (fore-and-aft) direction when 100 N (10.2 kg, 22 lb) force is added at the portion of 125 mm (4.92 in) radius from the center of flywheel.




Standard : 1.8 mm (0.071 in) or less

- If measured value is out of the standard, replace flywheel.

Movement Amount in Radial (Rotation) Direction

Check the movement amount of radial (rotation) direction with the following procedure:

1. Install clutch cover bolt (1) to clutch cover mating hole, and place a torque wrench (A) on the extended line of the flywheel (2) center line.
 - Tighten bolt at a force of 9.8 N·m (1.0 kg-m, 87 in-lb) to keep it from loosening.
2. Put a mating mark on circumferences of the two flywheel masses without applying any load (Measurement standard points).
3. Apply a force of 9.8 N·m (1.0 kg-m, 87 in-lb) in each direction, and mark the movement amount on the mass on the transaxle side.
4. Measure the dimensions of movement amounts "A" and "B" on circumference of the flywheel on the transaxle side.



Limit: 33.2 mm (1.307 in) or less.

- If measured value is out of the standard, replace flywheel.


A
EM
C
D
E
F
G
H
I
J
K
L
M

ENGINE ASSEMBLY

PF1:10001

Components

EBS00ZAF



WBIA0826E

- | | | |
|---------------------------------|-----------------------------------|---------------------------------|
| 1. Torque rod (RH) | 2. Engine mounting Insulator (RH) | 3. Engine mounting bracket (RH) |
| 4. Bracket | 5. Rear torque rod | 6. Engine through bolt |
| 7. Engine mounting bracket (LH) | 8. Engine mounting insulator (LH) | |

Removal and Installation

EBS00ZAG

WARNING:

- Situate the vehicle on a flat and solid surface.
- Place chocks at front and back of rear wheels.
- Attach proper slingers and bolts described in PARTS CATALOG if engine slingers are not equipped.

CAUTION:

- Always be careful to work safely, avoid forceful or uninstructed operations.
- Do not start working until exhaust system and coolant are cool enough.
- If items or work required are not covered by the engine section, refer to the applicable sections.
- Always use the support point specified for lifting.

- Use either 2-pole lift type or separate type lift as best you can. If board-on type is used for unavoidable reasons, support at the rear axle jacking point with a transmission jack or similar tool before starting work, in preparation for the backward shift of center of gravity.
- For supporting points for lifting and jacking point at rear axle, refer to [GI-40, "Garage Jack and Safety Stand and 2-Pole Lift"](#).

REMOVAL

Outline

Remove the engine and the transaxle assembly from the vehicle downward. Separate the engine and the transaxle.


1. Remove engine undercover
2. Drain engine coolant from radiator. Refer to [CO-10, "Changing Engine Coolant"](#).
 - CAUTION:**
 - Perform this step when the engine is cold.
 - Do not spill engine coolant on drive belt.
3. Remove front fender protector (RH and LH); Refer to [EI-21, "FENDER PROTECTOR"](#).
4. Remove exhaust front tube; Refer to [EX-2, "EXHAUST SYSTEM"](#).
5. Remove drive shafts (LH and RH) from steering knuckle. Refer to [FAX-8, "FRONT DRIVE SHAFT"](#).
6. Remove transaxle joint bolts which pierce at oil pan (upper) lower rear side. Refer to [CVT-204, "TRAN-SAXLE ASSEMBLY"](#) (CVT) or [MT-17, "REMOVAL"](#) (M/T models).
7. Remove rear torque rod.
8. Remove hood assembly. Refer to [BL-14, "HOOD"](#).
9. Remove cowl top cover and cowl top extension assembly. Refer to [EI-19, "COWL TOP"](#).
10. Release fuel pressure. Refer to [EC-81, "FUEL PRESSURE RELEASE"](#).
11. Remove battery and battery tray; Refer to [SC-4, "BATTERY"](#).
12. Remove drive belt; Refer to [EM-15, "Components"](#).
13. Remove air duct and air cleaner case assembly; Refer to [EM-18, "AIR CLEANER AND AIR DUCT"](#).
14. Remove cooling fan assembly.
15. Remove radiator hose (upper and lower). Refer to [CO-13, "RADIATOR"](#).
16. Disconnect CVT fluid cooler hoses. Refer to [CO-13, "RADIATOR"](#).
17. Disconnect all connections of engine harness around the engine mounting insulator (LH), and then temporarily secure the engine harness into the engine side.
 - CAUTION:**
 - Protect connectors using a resin bag to protect against foreign materials during the operation.
18. Disconnect fuel feed hose at engine side. Refer to [EM-35, "Components"](#).
19. Disconnect heater hoses, and install plugs them to prevent engine coolant from draining. Refer to [CO-21, "Components"](#).
20. Disconnect control cable from transaxle. Refer to [CVT-186, "SHIFT CONTROL SYSTEM"](#) (CVT), [MT-14, "REMOVAL"](#) (MT).
21. Remove ground cable at transaxle side.
22. Remove ground cable between front cover and vehicle.
23. Remove alternator. Refer to [SC-25, "CHARGING SYSTEM"](#).
24. Remove A/C compressor with piping connected from the engine. Temporarily secure it on the vehicle side with a rope to avoid putting load on it. Refer to [MTC-97, "Removal and Installation for Compressor - MR20DE"](#).
25. Remove the intake manifold to prevent the hanging chain from interfering. Refer to [EM-20, "Components"](#).

26. Install engine slinger to cylinder head front left side (A) and rear right side (B) and support the engine position with a hoist.

↶ : Engine front

Slinger bolts (front) : 32.9 N-m (3.3 kg-m, 24.2 ft-lb)

Slinger bolts (rear) : 25.0 N-m (2.5 kg-m, 18.4 ft-lb)




LBIA0461E

27. Support engine and transaxle assembly with a hoist and secure the engine in appropriate position.

28. Use a manual lift table caddy (A) or equivalently rigid tool such as a transmission jack. Securely support bottom of the engine and the transaxle, and simultaneously adjust hoist tension.

CAUTION:

Put a piece of wood or something similar as the supporting surface, secure a completely stable condition.



PBIC3223J


29. Remove torque rod (RH) (1), engine insulator (RH) (2) and engine bracket (RH) (3).

4 : Engine insulator (LH)

A : Engine front side

B : Transaxle side

30. Remove engine through bolt-securing nut (C).



WBIA0827E

31. Remove the engine and the transaxle assembly from the vehicle downward by carefully operating supporting tools.

CAUTION:

- During the operation, make sure that no part interferes with the vehicle side.
- Before and during this lifting, always check if any harnesses are left connected.
- During the removal operation, always be careful to prevent the vehicle from falling off the lift due to changes in the center of gravity.
- If necessary, support the vehicle by setting jack or suitable tool at the rear.
- During operation, securely support the engine by placing a piece of wood under the engine oil pan and transaxle oil pan. Securely support the engine slingers with a hoist.

32. When the engine hoisting is not performed simultaneously, install engine slinger to cylinder head front left side and rear right side.

33. Remove starter motor. Refer to [SC-8, "STARTING SYSTEM"](#).

34. Lift with a hoist and position above engine.

35. Separate the engine and the transaxle. Refer to [CVT-204, "REMOVAL"](#) (CVT models) or [CVT-204, "REMOVAL"](#) (M/T models).


INSTALLATION

Note the following, and install in the reverse order of removal.

- Do not allow engine oil to get on engine mounting insulator. Be careful not to damage engine mounting insulator.

- When installation directions are specified, install parts according to the directions. Refer to [EM-102, "Components"](#) .
- Make sure that each mounting insulator is seated properly, and tighten nuts and bolts.
- Tighten engine mounting insulator (RH) bolts in the numerical order shown.

← : Vehicle front



INSPECTION AFTER INSTALLATION

Inspection for Leaks

The following are procedures for checking fluids leak, lubricates leak and exhaust gases leak.

- Before starting engine, check oil/fluid levels including engine coolant and engine oil. If less than required quantity, fill to the specified level. Refer to [MA-14, "RECOMMENDED FLUIDS AND LUBRICANTS"](#) .
- Use procedure below to check for fuel leakage.
 - Turn ignition switch "ON" (with engine stopped). With fuel pressure applied to fuel piping, check for fuel leakage at connection points.
 - Start engine. With engine speed increased, check again for fuel leakage at connection points.
- Run engine to check for unusual noise and vibration.
- Warm up engine thoroughly to make sure there is no leakage of fuel, exhaust gases, or any oil/fluids including engine oil and engine coolant.
- Bleed air from lines and hoses of applicable lines, such as in cooling system.
- After cooling down engine, again check oil/fluid levels including engine oil and engine coolant. Refill to the specified level, if necessary.

Summary of the inspection items:

Item	Before starting engine	Engine running	After engine stopped
Engine coolant	Level	Leakage	Level
Engine oil	Level	Leakage	Level
Other oils and fluid*	Level	Leakage	Level
Fuel	Leakage	Leakage	Leakage
Exhaust gases	—	Leakage	—

* Transmission/transaxle/CVT fluid, power steering fluid, brake fluid, etc.

SERVICE DATA AND SPECIFICATIONS (SDS)

[MR20DE]

SERVICE DATA AND SPECIFICATIONS (SDS)

PF0:00030

Standard and Limit GENERAL SPECIFICATIONS

EBS00ZAL

Engine type		MR20DE
Cylinder arrangement		In-line 4
Displacement	cm ³ (cu in)	1,997 (121.86)
Bore and stroke	mm (in)	84.0 x 90.1 (3.307 x 3.547)
Valve arrangement		DOHC
Firing order		1-3-4-2
Number of piston rings	Compression	2
	Oil	1
Compression ratio		10.2
Compression pressure kPa (bar, kg/cm ² , psi) / 250 rpm	Standard	1,390 (13.9, 14.2, 202)
	Minimum	1,140 (11.4, 11.6, 165)
	Differential limit between cylinders	100 (1.0, 1.0, 15)

DRIVE BELT

Tension of drive belt	Auto adjustment by auto-tensioner
-----------------------	-----------------------------------

WATER CONTROL VALVE

Valve opening temperature	93.5 - 96.5°C (200 - 206°F)
Maximum valve lift	8 mm/ 108°C (0.315 in/ 226°F)
Valve closing temperature	More than 90°C (194°F)

EXHAUST MANIFOLD

Unit: mm (in)

Items	Limit	
Surface distortion	Each exhaust port	0.3 (0.012)
	Entire part	0.7 (0.028)

THERMOSTAT

Valve opening temperature	80.5 - 83.5°C (177 - 182°F)
Maximum valve lift	8 mm/ 95°C (0.315 in/ 203°F)
Valve closing temperature	More than 77°C (171°F)

SPARK PLUG

Unit: mm (in)

Plug type	Platinum-tipped TYPE
Make	NGK
Standard type	PLZKAR6A-11
Spark plug gap	Nominal: 1.1 (0.043)

CYLINDER HEAD


Unit: mm (in)

Items	Standard	Limit
Head surface distortion	—	0.1 (0.004)

SERVICE DATA AND SPECIFICATIONS (SDS)

[MR20DE]

Items	Standard	Limit
Normal cylinder head height "H"	130.9 (5.15)	—



PBIC0924E

VALVE Valve Timing

Unit: degree


Valve timing						
	a	b	c	d	e	f
	220	232	-13 (27)	65 (25)	7	33

PBIC4542E

() : Valve timing control "ON"

Valve Dimensions

Unit: mm (in)



SEM188A

Valve head diameter "D"	Intake	33.8 - 34.1 (1.331 - 1.343)
	Exhaust	27.6 - 27.9 (1.087 - 1.098)
Valve length "L"	Intake	106.21 (4.181)
	Exhaust	105.26 (4.144)
Valve stem diameter "d"	Intake	5.465 - 5.480 (0.2152 - 0.2157)
	Exhaust	5.455 - 5.470 (0.2148 - 0.2154)
Valve seat angle "α"		45°15' - 45°45'
Valve margin "T"	Intake	1.1 (0.043)
	Exhaust	1.2 (0.047)

SERVICE DATA AND SPECIFICATIONS (SDS)

[MR20DE]

Valve Clearance


Unit: mm (in)

Items	Cold	Hot* (reference data)
Intake	0.26 - 0.34 (0.010 - 0.013)	0.304 - 0.416 (0.012 - 0.016)
Exhaust	0.29 - 0.37 (0.011 - 0.015)	0.308 - 0.432 (0.012 - 0.017)

*: Approximately 80°C (176°F)

Available Valve Lifter

Thickness mm (in)	Identification mark
-------------------	---------------------



KBIA0119E

3.00 (0.1181)	300
3.02 (0.1189)	302
3.04 (0.1197)	304
3.06 (0.1205)	306
3.08 (0.1213)	308
3.10 (0.1220)	310
3.12 (0.1228)	312
3.14 (0.1236)	314
3.16 (0.1244)	316
3.18 (0.1252)	318
3.20 (0.1260)	320
3.22 (0.1268)	322
3.24 (0.1276)	324
3.26 (0.1283)	326
3.28 (0.1291)	328
3.30 (0.1299)	330
3.32 (0.1307)	332
3.34 (0.1315)	334
3.36 (0.1323)	336
3.38 (0.1331)	338
3.40 (0.1339)	340
3.42 (0.1346)	342
3.44 (0.1354)	344
3.46 (0.1362)	346
3.48 (0.1370)	348
3.50 (0.1378)	350

SERVICE DATA AND SPECIFICATIONS (SDS)

[MR20DE]

Valve Spring

Items	Intake	Exhaust
Free height	44.90 - 45.10 mm (1.7677 - 1.7755 in)	45.74 - 45.94 mm (1.8007 - 1.8086 in)
Installation height	35.30 mm (1.390 in)	35.30 mm (1.390 in)
Installation load	153 - 173 N (15.6 - 17.6 kg, 34 - 39 lb)	139 - 157 N (14.2 - 16.0 kg, 31 - 35 lb)
Height during valve open	26.36 mm (1.0377 in)	27.80 mm (1.0944 in)
Load with valve open	335 - 377 N (34.2 - 38.5 kg, 75 - 85 lb)	266 - 297 N (27.1 - 30.3 kg, 60 - 67 lb)
Identification color	White	Orange


Valve Lifter

Unit: mm (in)

Items		Standard
Valve lifter outer diameter	Intake	33.977 - 33.987 (1.3377 - 1.3381)
	Exhaust	29.977 - 29.987 (1.1802 - 1.1806)
Valve lifter hole diameter	Intake	34.000 - 34.021 (1.3386 - 1.3394)
	Exhaust	30.000 - 30.021 (1.1811 - 1.1819)
Valve lifter clearance		0.013 - 0.044 (0.0005 - 0.0017)

Valve Guide

Unit: mm (in)



PBIC0184E


Items		Standard part	Service part
Valve guide	Outer diameter	9.523 - 9.534 (0.3749 - 0.3754)	9.723 - 9.734 (0.3828 - 0.3832)
	Inner diameter (Finished size)	5.500 - 5.518 (0.2165 - 0.2172)	
Cylinder head valve guide hole diameter		9.475 - 9.496 (0.3730 - 0.3739)	9.675 - 9.696 (0.3809 - 0.3817)
Interference fit of valve guide		0.027 - 0.059 (0.0011 - 0.0023)	
Items		Standard	Limit
Valve guide clearance	Intake	0.020 - 0.053 (0.0008 - 0.0021)	0.1 (0.004)
	Exhaust	0.030 - 0.063 (0.0012 - 0.0025)	
Projection length "L"		13.35 - 13.65 (0.526 - 0.537)	

SERVICE DATA AND SPECIFICATIONS (SDS)

[MR20DE]

Valve Seat

Unit: mm (in)



Items		Standard	Oversize [0.5 (0.02)] (Service)
Cylinder head seat recess diameter "D"	Intake	34.700 - 34.727 (1.3661 - 1.3672)	35.200 - 35.227 (1.3858 - 1.3869)
	Exhaust	28.700 - 28.727 (1.1299 - 1.1310)	29.200 - 29.227 (1.1496 - 1.1507)
Valve seat outer diameter "d"	Intake	34.808 - 34.824 (1.3704 - 1.3710)	35.308 - 35.324 (1.3901 - 1.3907)
	Exhaust	28.808 - 28.824 (1.1342 - 1.1348)	29.308 - 29.324 (1.1539 - 1.1545)
Valve seat interference fit		0.081 - 0.124 (0.0032 - 0.0049)	
Diameter "d1"*1	Intake	31.8 (1.252)	
	Exhaust	25.3 (0.996)	
Diameter "d2"*2	Intake	33.1 - 33.6 (1.303 - 1.323)	
	Exhaust	26.9 - 27.4 (1.059 - 1.079)	
Angle "α1"	Intake	60°	
	Exhaust	45°	
Angle "α2"		88°45' - 90°15'	
Angle "α3"		120°	
Contacting width "W"*3	Intake	1.0 - 1.4 (0.039 - 0.055)	
	Exhaust	1.2 - 1.6 (0.047 - 0.063)	
Height "h"	Intake	5.9 - 6.0 (0.232 - 0.236)	5.03 - 5.13 (0.1980 - 0.2020)
	Exhaust	5.9 - 6.0 (0.232 - 0.236)	4.95 - 5.05 (0.1949 - 0.1988)
Depth "H"	Intake	6.04 (0.2378)	
	Exhaust	6.05 (0.2382)	

*: Diameter made by intersection point of conic angles "α1" and "α2"

*2: Diameter made by intersection point of conic angles "α2" and "α3"

*3: Machining data

CAMSHAFT AND CAMSHAFT BEARING


Unit: mm (in)

Items		Standard	Limit
Camshaft journal oil clearance	No. 1	0.045 - 0.086 (0.0018 - 0.0034)	0.15 (0.0059)
	No. 2, 3, 4, 5	0.030 - 0.071 (0.0012 - 0.0028)	
Camshaft bracket inner diameter	No. 1	28.000 - 28.021 (1.1024 - 1.1032)	—
	No. 2, 3, 4, 5	25.000 - 25.021 (0.9843 - 0.9851)	—
Camshaft journal diameter	No. 1	27.935 - 27.955 (1.0998 - 1.1006)	—
	No. 2, 3, 4, 5	24.950 - 24.970 (0.9823 - 0.9381)	—
Camshaft end play		0.075 - 0.153 (0.0030 - 0.0060)	0.24 (0.0094)
Camshaft cam height "A"	Intake	44.605 - 44.795 (1.7560 - 1.7635)	44.405 (1.7482)
	Exhaust	43.175 - 43.365 (1.6997 - 1.7072)	42.975 (1.6919)

SERVICE DATA AND SPECIFICATIONS (SDS)

[MR20DE]

Camshaft runout [TIR*]	Less than 0.02 mm (0.0008)	0.05 (0.0020)
Camshaft sprocket runout [TIR*]	—	0.15 (0.0059)




SEM671

*: Total indicator reading

CYLINDER BLOCK

Unit: mm (in)



PBIC4017E

Top surface distortion		Limit	0.1 (0.004)
Cylinder bore	Inner diameter	Standard	Grade No. 1
			Grade No. 2
Out-of-round (Difference between "X" and "Y")		Limit	0.015 (0.0006)
Taper (Difference between "A" and "C")		Limit	0.01 (0.0004)
Main bearing housing inner diameter grade		Grade No. A	55.997 - 55.998 (2.2046 - 2.2046)
		Grade No. B	55.998 - 55.999 (2.2046 - 2.2047)
		Grade No. C	55.999 - 56.000 (2.2047 - 2.2047)
		Grade No. D	56.000 - 56.001 (2.2047 - 2.2048)
		Grade No. E	56.001 - 56.002 (2.2048 - 2.2048)
		Grade No. F	56.002 - 56.003 (2.2048 - 2.2048)
		Grade No. G	56.003 - 56.004 (2.2048 - 2.2049)
		Grade No. H	56.004 - 56.005 (2.2049 - 2.2049)
		Grade No. J	56.005 - 56.006 (2.2049 - 2.2050)
		Grade No. K	56.006 - 56.007 (2.2050 - 2.2050)
		Grade No. L	56.007 - 56.008 (2.2050 - 2.2050)
		Grade No. M	56.008 - 56.009 (2.2050 - 2.2051)
		Grade No. N	56.009 - 56.010 (2.2051 - 2.2051)
		Grade No. P	56.010 - 56.011 (2.2051 - 2.2052)
Grade No. R	56.011 - 56.012 (2.2052 - 2.2052)		
Grade No. S	56.012 - 56.013 (2.2052 - 2.2052)		
Grade No. T	56.013 - 56.014 (2.2052 - 2.2053)		
Grade No. U	56.014 - 56.015 (2.2053 - 2.2053)		
Grade No. V	56.015 - 56.016 (2.2053 - 2.2053)		
Grade No. W	56.016 - 56.017 (2.2053 - 2.2054)		


SERVICE DATA AND SPECIFICATIONS (SDS)

[MR20DE]

PISTON, PISTON RING AND PISTON PIN

Available Piston

Unit: mm (in)



PBIC0188E

Piston skirt diameter "A"	Standard	Grade No. 1	83.970 - 83.980 (3.3059 - 3.3063)
		Grade No. 2	83.980 - 83.990 (3.3063 - 3.3067)
Piston height "H" dimension			39.9 (1.571)
Piston pin hole diameter			19.993 - 19.999 (0.7871 - 0.7874)
Piston to cylinder bore clearance	Standard		0.020 - 0.040 (0.0008 - 0.0016)
	Limit		0.08 (0.0031)

Piston Ring

Unit: mm (in)

Items		Standard	Limit
Side clearance	Top	0.04 - 0.08 (0.002 - 0.003)	0.11 (0.0043)
	2nd	0.03 - 0.07 (0.001 - 0.003)	0.10 (0.0039)
	Oil ring	0.015 - 0.185 (0.001 - 0.007)	—
End gap	Top	0.20 - 0.30 (0.008 - 0.012)	0.51 (0.020)
	2nd	0.50 - 0.65 (0.020 - 0.026)	0.83 (0.033)
	Oil (rail ring)	0.15 - 0.45 (0.006 - 0.018)	0.78 (0.031)

Piston Pin

Unit: mm (in)

Items	Standard	Limit
Piston pin outer diameter	19.989 - 19.995 (0.7870 - 0.7872)	—
Piston to piston pin oil clearance	0.002 - 0.006 (0.0001 - 0.0002)	—
Connecting rod bushing oil clearance	0.005 - 0.023 (0.0002 - 0.0009)	0.03 (0.0012)

SERVICE DATA AND SPECIFICATIONS (SDS)

[MR20DE]

CONNECTING ROD


Unit: mm (in)

Center distance		143.44 - 143.54 (5.647 - 5.650)
Bend [per 100 (3.94)]	Limit	0.15 (0.0059)
Torsion [per 100 (3.94)]	Limit	0.30 (0.0118)
Connecting rod bushing inner diameter*		20.000 - 20.012 (0.7874 - 0.7879)
Side clearance	Standard	0.20 - 0.35 (0.0079 - 0.0138)
	Limit	0.40 (0.0157)
Connecting rod big end diameter	Grade No. A	47.000 - 47.001 (1.8504 - 1.8504)
	Grade No. B	47.001 - 47.002 (1.8504 - 1.8505)
	Grade No. C	47.002 - 47.003 (1.8505 - 1.8505)
	Grade No. D	47.003 - 47.004 (1.8505 - 1.8505)
	Grade No. E	47.004 - 47.005 (1.8505 - 1.8506)
	Grade No. F	47.005 - 47.006 (1.8506 - 1.8506)
	Grade No. G	47.006 - 47.007 (1.8506 - 1.8507)
	Grade No. H	47.007 - 47.008 (1.8507 - 1.8507)
	Grade No. J	47.008 - 47.009 (1.8507 - 1.8507)
	Grade No. K	47.009 - 47.010 (1.8507 - 1.8508)
	Grade No. L	47.010 - 47.011 (1.8508 - 1.8508)
	Grade No. M	47.011 - 47.012 (1.8508 - 1.8509)
	Grade No. N	47.012 - 47.013 (1.8509 - 1.8509)


*: After installing in connecting rod

CRANKSHAFT

Unit: mm (in)



SEM645



PBIC3459J

Center distance "r"		40.41 - 40.49 (1.5909 - 1.5940)
Out-of-round (Difference between "X" and "Y")	Limit	0.0035 (0.0001)
Taper (Difference between "A" and "B")	Limit	0.0035 (0.0001)
Runout [TIR*]	Standard	0.05 (0.0020)
	Limit	0.10 (0.0040)
Crankshaft end play	Standard	0.10 - 0.26 (0.0039 - 0.0102)
	Limit	0.30 (0.012)

SERVICE DATA AND SPECIFICATIONS (SDS)

[MR20DE]

Pin journal diameter grade. "Dp"	Grade No. A	43.970 - 43.971 (1.7311 - 1.7311)
	Grade No. B	43.969 - 43.970 (1.7311 - 1.7311)
	Grade No. C	43.968 - 43.969 (1.7310 - 1.7311)
	Grade No. D	43.967 - 43.968 (1.7310 - 1.7310)
	Grade No. E	43.966 - 43.967 (1.7309 - 1.7310)
	Grade No. F	43.965 - 43.966 (1.7309 - 1.7309)
	Grade No. G	43.964 - 43.965 (1.7309 - 1.7309)
	Grade No. H	43.963 - 43.964 (1.7308 - 1.7309)
	Grade No. J	43.962 - 43.963 (1.7308 - 1.7308)
	Grade No. K	43.961 - 43.962 (1.7307 - 1.7308)
	Grade No. L	43.960 - 43.961 (1.7307 - 1.7307)
	Grade No. M	43.959 - 43.960 (1.7307 - 1.7307)
	Grade No. N	43.958 - 43.959 (1.7306 - 1.7307)
	Grade No. P	43.957 - 43.958 (1.7306 - 1.7306)
	Grade No. R	43.956 - 43.957 (1.7305 - 1.7306)
	Grade No. S	43.955 - 43.956 (1.7305 - 1.7305)
Grade No. T	43.954 - 43.955 (1.7305 - 1.7305)	
Grade No. U	43.953 - 43.954 (1.7304 - 1.7305)	
Main journal diameter grade. "Dm"	Grade No. A	51.978 - 51.979 (2.0464 - 2.0464)
	Grade No. B	51.977 - 51.978 (2.0463 - 2.0464)
	Grade No. C	51.976 - 51.977 (2.0463 - 2.0463)
	Grade No. D	51.975 - 51.976 (2.0463 - 2.0463)
	Grade No. E	51.974 - 51.975 (2.0462 - 2.0463)
	Grade No. F	51.973 - 51.974 (2.0462 - 2.0462)
	Grade No. G	51.972 - 51.973 (2.0461 - 2.0462)
	Grade No. H	51.971 - 51.972 (2.0461 - 2.0461)
	Grade No. J	51.970 - 51.971 (2.0461 - 2.0461)
	Grade No. K	51.969 - 51.970 (2.0460 - 2.0461)
	Grade No. L	51.968 - 51.969 (2.0460 - 2.0460)
	Grade No. M	51.967 - 51.968 (2.0459 - 2.0460)
	Grade No. N	51.966 - 51.967 (2.0459 - 2.0459)
	Grade No. P	51.965 - 51.966 (2.0459 - 2.0459)
	Grade No. R	51.964 - 51.965 (2.0458 - 2.0459)
	Grade No. S	51.963 - 51.964 (2.0458 - 2.0458)
Grade No. T	51.962 - 51.963 (2.0457 - 2.0458)	
Grade No. U	51.961 - 51.962 (2.0457 - 2.0457)	
Grade No. V	51.960 - 51.961 (2.0457 - 2.0457)	
Grade No. W	51.959 - 51.960 (2.0456 - 2.0457)	

*: Total indicator reading

SERVICE DATA AND SPECIFICATIONS (SDS)

[MR20DE]

MAIN BEARING

Unit: mm (in)

Grade number	Thickness	Identification color	Remarks
0	1.996 - 1.999 (0.0786 - 0.0787)	Black	Grade and color are the same for upper and lower bearings.
1	1.999 - 2.002 (0.0787 - 0.0788)	Brown	
2	2.002 - 2.005 (0.0788 - 0.0789)	Green	
3	2.005 - 2.008 (0.0789 - 0.0791)	Yellow	
4	2.008 - 2.011 (0.0791 - 0.0792)	Blue	
5	2.011 - 2.014 (0.0792 - 0.0793)	Pink	
6	2.014 - 2.017 (0.0793 - 0.0794)	Purple	
7	2.017 - 2.020 (0.0794 - 0.0795)	White	
01	UPR	1.996 - 1.999 (0.0786 - 0.0787)	Grade and color are different between upper and lower bearings.
	LWR	1.999 - 2.002 (0.0787 - 0.0788)	
12	UPR	1.999 - 2.002 (0.0787 - 0.0788)	
	LWR	2.002 - 2.005 (0.0788 - 0.0789)	
23	UPR	2.002 - 2.005 (0.0788 - 0.0789)	
	LWR	2.005 - 2.008 (0.0789 - 0.0791)	
34	UPR	2.005 - 2.008 (0.0789 - 0.0791)	
	LWR	2.008 - 2.011 (0.0791 - 0.0792)	
45	UPR	2.008 - 2.011 (0.0791 - 0.0792)	
	LWR	2.011 - 2.014 (0.0792 - 0.0793)	
56	UPR	2.011 - 2.014 (0.0792 - 0.0793)	
	LWR	2.014 - 2.017 (0.0793 - 0.0794)	
67	UPR	2.014 - 2.017 (0.0793 - 0.0794)	
	LWR	2.017 - 2.020 (0.0794 - 0.0795)	

Undersize

Unit: mm (in)

Item	Thickness	Main journal diameter
US 0.25 (0.0098)	2.126 - 2.134 (0.0837 - 0.0840)	Grind so that bearing clearance is the specified value.

Bearing Oil Clearance

Unit: mm (in)

Main bearing oil clearance	Standard	No. 1, 4 and 5	0.024 - 0.034 (0.0009 - 0.0013)
		No. 2 and 3	0.012 - 0.022 (0.0005 - 0.0009)
	Limit	0.065 (0.0026)	

CONNECTING ROD BEARING

Grade number	Thickness mm (in)	Identification color	Remarks
0	1.494 - 1.497 (0.0588 - 0.0589)	Black	Grade and color are the same for upper and lower bearings.
1	1.497 - 1.500 (0.0589 - 0.0591)	Brown	
2	1.500 - 1.503 (0.0591 - 0.0592)	Green	
3	1.503 - 1.506 (0.0592 - 0.0593)	Yellow	
4	1.506 - 1.509 (0.0593 - 0.0594)	Blue	

SERVICE DATA AND SPECIFICATIONS (SDS)

[MR20DE]

01	UPR	1.494 - 1.497 (0.0588 - 0.0589)	Black	Grade and color are different between upper and lower bearings.
	LWR	1.497 - 1.500 (0.0589 - 0.0591)	Brown	
12	UPR	1.497 - 1.500 (0.0589 - 0.0591)	Brown	
	LWR	1.500 - 1.503 (0.0591 - 0.0592)	Green	
23	UPR	1.500 - 1.503 (0.0591 - 0.0592)	Green	
	LWR	1.503 - 1.506 (0.0592 - 0.0593)	Yellow	
34	UPR	1.503 - 1.506 (0.0592 - 0.0593)	Yellow	
	LWR	1.506 - 1.509 (0.0593 - 0.0594)	Blue	

Undersize

Unit: mm (in)

Item	Thickness	Crank pin journal diameter
US 0.25 (0.0098)	1.623 - 1.631 (0.0639 - 0.0642)	Grind so that bearing clearance is the specified value.

Bearing Oil Clearance

Unit: mm (in)

Connecting rod bearing oil clearance	Standard	0.037 - 0.047 (0.0015 - 0.0019)
	Limit	0.07 (0.0028)

PRECAUTIONS**Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”**

EBS00Z80

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions for Draining Coolant

EBS00Z81

- Drain coolant when engine is cooled.

Precautions for Disconnecting Fuel Piping

EBS00Z82

- Before starting work, make sure no fire or spark producing items are in the work area.
- Release fuel pressure before any removal or disassembly.
- After disconnecting pipes, plug openings to stop fuel leakage.

Precautions for Removal and Disassembly

EBS00Z83

- When instructed to use special service tools, use the specified tools. Always be careful to work safely, avoid forceful operations.
- Use maximum care to avoid damage to mating or sliding surfaces.
- Cover openings of engine system with tape or equivalent, if necessary, to seal out foreign materials.
- Mark and arrange disassembly parts in an organized way for easy troubleshooting and assembly.
- When loosening nuts and bolts, as a basic rule, start with the one furthest outside, then the one diagonally opposite, and so on. If the order of loosening is specified, follow the specifications.

Precautions for Inspection, Repair and Replacement

EBS00Z84

- Before repairing or replacing, thoroughly inspect parts. Inspect new replacement parts in the same way, and replace if necessary.

Precautions for Assembly and Installation

EBS00Z85

- Use torque wrench to tighten bolts or nuts.
- When tightening nuts and bolts, as a basic rule, equally tighten in several different steps starting with the ones in center, then ones on inside and outside diagonally in this order. If the order of tightening is specified, follow the specifications.
- Always replace the old with a new gasket, packing, oil seal or O-ring.
- Thoroughly wash, clean, and air-blow each part. Carefully check oil or coolant passages for any restriction and blockage.
- Avoid damaging sliding or mating surfaces. Completely remove foreign materials such as cloth lint or dust. Before assembly, oil sliding surfaces well.
- Bleed the air trapped within the system after draining the coolant.
- Before starting engine, apply fuel pressure to fuel lines with turning ignition switch ON (with engine stopped). Then make sure that there are no leaks at fuel line connections.

PRECAUTIONS

[QR25DE]

- After repairing, start engine and increase engine speed to check coolant, fuel, oil, and exhaust systems for leakage or rattles.

Parts Requiring Angular Tightening

EBS00ZB6

- Use an angle wrench for the final tightening of the following engine parts.
 - Cylinder head bolts
 - Lower cylinder block bolts
 - Connecting rod cap bolts
 - Crankshaft pulley bolt (No angle wrench is required as the bolt flange is provided with notches for angular tightening)
- Do not use a torque value for final tightening.
- The torque value for these parts are for a preliminary step.
- Ensure thread and seat surfaces are clean and coated with engine oil.

Precautions for Liquid Gasket

EBS00ZB7

REMOVAL OF LIQUID GASKET SEALING


- After removing the bolts and nuts, separate the mating surface and remove the sealant using Tool.

Tool number : KV10111100 (J-37228)

CAUTION:

Be careful not to damage the mating surfaces.

- In areas where the cutter is difficult to use, use a plastic hammer to lightly tap (1) the cutter where the RTV Silicone Sealant is applied. Use a plastic hammer to slide the cutter (2) by tapping on the side.




PBIC0002E

CAUTION:

If for some unavoidable reason a tool such as a flat-bladed screwdriver is used, be careful not to damage the mating surfaces.

LIQUID GASKET APPLICATION PROCEDURE

1. Using a scraper, remove the old Silicone RTV Sealant adhering to the gasket application surface and the mating surface.
 - Remove the sealant completely from the groove of the gasket application surface, mounting bolts, and bolt holes.
2. Thoroughly clean the gasket application surface and the mating surface and remove adhering moisture, grease and foreign materials.
3. Attach the sealant tube to the tube presser.
Use Genuine Silicone RTV Sealant or equivalent. Refer to [GI-44, "Recommended Chemical Products and Sealants"](#).




PBIC0003E

4. Apply the sealant using Tool without breaks to the specified location.

Tube presser WS39930000 (-)

- If there is a groove for the sealant application, apply the sealant to the groove.
- As for the bolt holes, normally apply the sealant inside the holes. If specified, it should be applied outside the holes. Make sure to read the text of this manual.
- Within five minutes of the sealant application, install the mating component.
- If the sealant protrudes, wipe it off immediately.
- Do not retighten after the installation.




EMA0622D

PRECAUTIONS

[QR25DE]

- After 30 minutes or more have passed from the installation, fill the engine with the specified oil and coolant. Refer to [MA-14](#), "[RECOMMENDED FLUIDS AND LUBRICANTS](#)".



CAUTION:
Follow all specific instructions in this manual.

A
EM
C
D
E
F
G
H
I
J
K
L
M

PREPARATION

[QR25DE]








PFP:00002

EBS00Z88

PREPARATION

Special Service Tools

The actual shapes of the Kent-Moore tools may differ from those of the special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
KV10111100 (J-37228) Seal cutter	Removing steel oil pan and rear timing chain case  <p style="text-align: center;">S-NT046</p>
ST0501S000 Engine stand assembly 1. ST05011000 (—) Engine stand 2. ST05012000 (—) Base	Disassembling and assembling  <p style="text-align: center;">NT042</p>
KV10106500 (—) Engine stand shaft	 <p style="text-align: center;">NT028</p>
KV10115300 (—) Engine sub-attachment	 <p style="text-align: center;">ZZA1078D</p>
KV10116200 (J-26336-B) Valve spring compressor 1. KV10115900 (J-26336-20) Attachment	Disassembling valve mechanism  <p style="text-align: center;">NT022</p>
KV10112100 (BT-8653-A) Angle wrench	Tightening bolts for bearing cap, cylinder head, etc.  <p style="text-align: center;">S-NT014</p>
KV10107902 (J-38959) Valve oil seal puller	Removing valve oil seal  <p style="text-align: center;">S-NT011</p>

PREPARATION


[QR25DE]

Tool number (Kent-Moore No.) Tool name	Description	
KV10115600 (J-38958) Valve oil seal drift <div data-bbox="609 310 950 430" style="text-align: center;"> </div> <div data-bbox="852 451 917 472" style="text-align: center;">S-NT603</div>	Installing valve oil seal Use side A. a: 20 (0.79) dia. d: 8 (0.31) dia. b: 13 (0.51) dia. e: 10.7 (0.421) dia. c: 10.3 (0.406) dia. f: 5 (0.20) dia. Unit: mm (in)	A EM C
EM03470000 (J-8037) Piston ring compressor <div data-bbox="690 535 868 672" style="text-align: center;"> </div> <div data-bbox="852 682 917 703" style="text-align: center;">S-NT044</div>	Installing piston assembly into cylinder bore	D E
ST16610001 (J-23907) Pilot bushing puller <div data-bbox="625 766 917 913" style="text-align: center;"> </div> <div data-bbox="852 924 917 945" style="text-align: center;">S-NT045</div>	Removing crankshaft pilot bushing	F G H
WS39930000 (—) Tube presser <div data-bbox="657 997 901 1144" style="text-align: center;"> </div> <div data-bbox="852 1155 917 1176" style="text-align: center;">S-NT052</div>	Pressing the tube of liquid gasket	I J
16441 6N210 (J-45488) Quick connector release <div data-bbox="755 1228 836 1375" style="text-align: center;"> </div> <div data-bbox="852 1386 917 1407" style="text-align: center;">PBIC0198E</div>	Removing fuel tube quick connectors in engine room (Available in SEC. 164 of PARTS CATALOG: Part No. 16441 6N210)	K L
KV10114400 (J-38365) Heated oxygen sensor wrench <div data-bbox="625 1459 933 1617" style="text-align: center;"> </div> <div data-bbox="852 1627 917 1648" style="text-align: center;">NT636</div>	Loosening or tightening rear heated oxygen sensor a: 22 mm (0.87 in)	M
KV10117100 (J-36471-A) Heated oxygen sensor wrench <div data-bbox="641 1669 917 1879" style="text-align: center;"> </div> <div data-bbox="852 1858 917 1879" style="text-align: center;">NT379</div>	Loosening or tightening heated oxygen sensor For 22 mm (0.87 in) hexagon nut	


PREPARATION

[QR25DE]

Tool number (Kent-Moore No.) Tool name	Description
— (J-44626) Air fuel ratio (A/F) sensor wrench	Loosening or tightening air fuel ratio (A/F) sensor 1
— (J-46535) Drive belt tension releaser	Releasing drive belt tension



LEM054










WBIA0536E

PREPARATION

[QR25DE]

EBS00Z89






Commercial Service Tools


Tool number (Kent-Moore No.) Tool name	Description
Pulley holder  <p style="text-align: right;">NT628</p>	Crankshaft pulley removing and installing a: 68 mm (2.68 in) dia. b: 8 mm (0.31 in) dia.
Crank puller  <p style="text-align: right;">ZZA0010D</p>	Crankshaft pulley removing
Spark plug wrench  <p style="text-align: right;">PBIC2982E</p>	Removing and installing spark plug
Valve seat cutter set  <p style="text-align: right;">S-NT048</p>	Finishing valve seat dimensions
Piston ring expander  <p style="text-align: right;">S-NT030</p>	Removing and installing piston ring
Valve guide drift  <p style="text-align: right;">S-NT015</p>	Removing and installing valve guide Intake & Exhaust: a: 9.5 mm (0.374 in) dia. b: 5.5 mm (0.217 in) dia.
Valve guide reamer  <p style="text-align: right;">S-NT016</p>	1: Reaming valve guide inner hole 2: Reaming hole for oversize valve guide Intake & Exhaust: d1 : 6.0 mm (0.236 in) dia. d2 : 10.2 mm (0.402 in) dia.

A
EM
C
D
E
F
G
H
I
J
K
L
M

PREPARATION

[QR25DE]

Tool number (Kent-Moore No.) Tool name	Description
(J-43897-18) (J-43897-12) Oxygen sensor thread cleaner	 <p>Reconditioning the exhaust system threads before installing a new heated oxygen sensor (Use with anti-seize lubricant shown below.) a: J-43897-18 [18 mm (0.71 in) dia.] for zirconia heated oxygen sensor b: J-43897-12 [12 mm (0.47 in) dia.] for titania heated oxygen sensor</p>
Anti-seize lubricant (Permatex 133AR or equivalent meeting MIL specification MIL-A-907)	 <p>Lubricating oxygen sensor thread cleaning tool when reconditioning exhaust system threads</p>
Power tool	 <p>Loosening bolts and nuts</p>
TP55 Torx® plus Bit	 <p>Removing and installing M/T flywheel bolts</p>
E20 Torx® Socket (J-45816)	 <p>Removing and installing CVT drive plate bolts</p>



A

EM

C

D

E

F

G

H

I

J

K

L

M

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

[QR25DE]

EBS00Z6B

Use the Chart Below to Help You Find the Cause of the Symptom.

1. Locate the area where noise occurs.
2. Confirm the type of noise.
3. Specify the operating condition of engine.
4. Check specified noise source.


If necessary, repair or replace these parts.

Location of noise	Type of noise	Operating condition of engine						Source of noise	Check item	Reference page
		Before warm-up	After warm-up	When starting	When idling	When racing	While driving			
Top of engine Rocker cover Cylinder head	Ticking or clicking	C	A	—	A	B	—	Tappet noise	Valve clearance	EM-157
	Rattle	C	A	—	A	B	C	Camshaft bearing noise	Camshaft journal clearance Camshaft runout	EM-152 EM-151
Crankshaft pulley Cylinder block (Side of engine) Oil pan	Slap or knock	—	A	—	B	B	—	Piston pin noise	Piston and piston pin clearance Connecting rod bushing clearance	EM-201 EM-201
	Slap or rap	A	—	—	B	B	A	Piston slap noise	Piston-to-bore clearance Piston ring side clearance Piston ring end gap Connecting rod bend and torsion	EM-200 EM-200 EM-200 EM-200
	Knock	A	B	C	B	B	B	Connecting rod bearing noise	Connecting rod bushing clearance (Small end) Connecting rod bearing clearance (Big end)	EM-201 EM-201
	Knock	A	B	—	A	B	C	Main bearing noise	Main bearing oil clearance Crankshaft runout	EM-205 EM-204
Front of engine Timing chain cover	Tapping or ticking	A	A	—	B	B	B	Timing chain and chain tensioner noise	Timing chain cracks and wear Timing chain tensioner operation	EM-160
Front of engine	Squeaking or fizzing	A	B	—	B	—	B	Drive belts (Sticking or slipping)	Drive belts deflection	EM-127
	Creaking	A	B	A	B	A	B	Drive belts (Slipping)	Idler pulley bearing operation	
	Squall Creak	A	B	—	B	A	B	Water pump noise	Water pump operation	CO-31

A: Closely related B: Related C: Sometimes related —: Not related

DRIVE BELTS

Checking Drive Belts



WARNING:

Inspect the drive belt only when the engine is stopped.

NOTE:

On vehicles not equipped with A/C, there is an idler pulley in the position for the drive belt routing.

- Make sure that the stamp mark of drive belt auto-tensioner is within the usable range.

NOTE:

- Check the drive belt auto-tensioner indicator (notch) when the engine is cold.
- When the new drive belt is installed, the range of possible use should be as shown.
- Visually check entire belt for wear, damage or cracks.
- If the indicator is out of allowable use range or belt is damaged, replace the belt.

Tension Adjustment

- Belt tension is not manually adjustable, it is automatically adjusted by the drive belt auto-tensioner.

Removal and Installation


REMOVAL

1. While securely holding the hexagonal part in pulley center of drive belt auto-tensioner, move in the direction of arrow (loosening direction of tensioner) using Tool.

Tool number : — (J-46535)

CAUTION:

- Avoid placing hand in a location where pinching may occur if the holding tool accidentally comes off.
- Do not loosen the auto-tensioner pulley bolt. (Do not turn it counterclockwise.) If turned counterclockwise, the complete auto-tensioner must be replaced as a unit, including pulley.



2. Insert a rod approximately 6 mm (0.24 in) in diameter through the rear of tensioner into retaining boss to lock tensioner pulley.
 - Leave tensioner pulley arm locked until belt is installed again.
3. Loosen auxiliary drive belt from water pump pulley in sequence, and remove it.

INSTALLATION

1. Hook the auxiliary drive belt onto all of the pulleys except for the water pump pulley. Hook the drive belt onto water pump pulley last.

CAUTION:

Confirm belts are completely set on the pulleys.

2. Release tensioner, and apply tensions to belt.


CAUTION:

- Avoid placing hand in a location where pinching may occur if the holding tool accidentally comes off.
- Do not loosen the auto-tensioner pulley bolt. (Don't turn it counterclockwise. If turned counterclockwise, the complete auto-tensioner must be replaced as a unit, including pulley.)

3. Turn crankshaft pulley clockwise several times to equalize tension between each pulley.
4. Confirm tensions of belt at indicator is within the allowable use range. Refer to [EM-127, "Checking Drive Belts"](#) .

Removal and Installation of Drive Belt Auto-tensioner

EBS00Z8F



1. Drive Belt auto-tensioner
2. Water pump pulley

REMOVAL

CAUTION:

The complete auto-tensioner must be replaced as a unit, including the pulley.

1. Remove the front RH engine cover.
2. Remove the drive belt [EM-127, "Removal and Installation"](#) .
 - Insert a rod approximately 6 mm (0.24 in) in diameter through the rear of tensioner into the retaining boss to lock tensioner pulley.
3. Remove the generator. Refer to [SC-33, "REMOVAL"](#) .
4. Remove the drive belt auto-tensioner, with power tool.

CAUTION:

Do not loosen the auto-tensioner pulley bolt. (Do not turn it counterclockwise). If turned counterclockwise, the complete auto-tensioner must be replaced as a unit, including pulley.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- If there is damage greater than peeled paint, replace drive belt auto-tensioner units
- Install the drive belt auto-tensioner carefully so not to damage the water pump pulley.

DRIVE BELTS

[QR25DE]

- Do not swap the pulley between the new and old auto-tensioner units

A

EM

C

D

E

F

G

H

I

J

K

L


M

AIR CLEANER AND AIR DUCT

PF1:16500

Removal and Installation

EBS0028G



- | | | |
|--|-------------------------|-------------------|
| 1. Electronic throttle control actuator tube | 2. Air duct | 3. Front air duct |
| 4. Air cleaner case | 5. Mass air flow sensor | 6. Resonator tube |
| 7. Resonator in fender | | |

REMOVAL

1. Disconnect the mass air flow sensor electrical connector.
2. Disconnect the tube clamp at the electronic throttle control actuator and the fresh air intake tube.
3. Remove air cleaner to electronic throttle control actuator tube, air cleaner case, with mass air flow sensor attached.
4. Remove mass air flow sensor from air cleaner case, as necessary.

CAUTION:

Handle the mass air flow sensor with care:

- Do not shock it.
- Do not disassemble it.
- Do not touch the internal sensor.

5. Remove ECM bracket and CVT controller if necessary.
6. Remove the resonator in the fender, as necessary.

INSTALLATION

Installation is in the reverse order of removal.

CHANGING THE AIR CLEANER ELEMENT

1. Depress the air cleaner case lid side clips and remove.
2. Remove the air cleaner element.
3. Install a new air cleaner element.
4. Installation is in the reverse order of removal.

A

EM

C

D

E

F

G

H

I

J


K

L

M

INTAKE MANIFOLD

Removal and Installation



- | | | |
|--------------------|--|----------------------------|
| 1. Intake manifold | 2. Rubber seal | 3. Intake manifold adapter |
| 4. Gasket | 5. Electric throttle control actuator | 6. Rubber seal |
| 7. PCV hose | 8. EVAP canister purge volume control solenoid | 9. EVAP hose |

REMOVAL

WARNING:

To avoid the danger of being scalded, never drain the coolant when the engine is hot.


1. Remove the engine cover.
2. Release the fuel pressure. Refer to [EC-633, "FUEL PRESSURE RELEASE"](#).
3. Drain coolant when engine is cooled. Refer to [CO-34, "DRAINING ENGINE COOLANT"](#).
4. Disconnect the MAF sensor electrical connector.
5. Remove air cleaner case and air duct assembly. Refer to [EM-130, "Removal and Installation"](#).
6. Remove cowl top. Refer to [EI-19, "REMOVAL"](#).
7. Disconnect the following components at the intake side:
 - PCV hose
 - EVAP canister purge volume control solenoid
 - Electric throttle control actuator
 - Brake booster vacuum hose

INTAKE MANIFOLD


[QR25DE]

8. Disconnect the fuel quick connector on the engine side.
- Using Tool perform the following steps to disconnect the quick connector.

Tool number : — (J-45488)



- a. Remove quick connector cap.



- b. With the sleeve side of Tool facing quick connector, install Tool onto fuel tube.
c. Insert Tool into quick connector until sleeve contacts and goes no further. Hold the Tool on that position.


CAUTION:

Inserting the Tool hard will not disconnect quick connector. Hold Tool where it contacts and goes no further.

- d. Pull the quick connector straight out from the fuel tube.

CAUTION:

- Pull quick connector holding it at the "A" position, as shown.
- Do not pull with lateral force applied. O-ring inside quick connector may be damaged.
- Prepare container and cloth beforehand as fuel will leak out.
- Avoid fire and sparks.
- Be sure to cover openings of disconnected pipes with plug or plastic bag to avoid fuel leakage and entry of foreign materials.




9. When removing fuel hose quick connector at vehicle piping side, perform as follows.


- a. Remove quick connector cap.
b. Hold the sides of the connector, push in tabs and pull out the tube. (The figure is shown for reference only.)
- If the connector and the tube are stuck together, push and pull several times until they start to move. Then disconnect them by pulling.

CAUTION:

- The tube can be removed when the tabs are completely depressed. Do not twist it more than necessary.
- Do not use any tools to remove the quick connector.
- Keep the resin tube away from heat. Be especially careful when welding near the tube.
- Prevent acid liquid such as battery electrolyte etc. from getting on the resin tube.
- Do not bend or twist the tube during installation and removal.



- Do not remove the remaining retainer on tube.
 - When the tube is replaced, also replace the retainer with a new one.
Retainer color: Green.
 - To keep clean the connecting portion and to avoid damage and foreign materials, cover them completely with plastic bags or something similar.
10. Loosen mounting bolts diagonally, and remove the electric throttle control actuator.
- CAUTION:**
Handle carefully to avoid any damage.
11. Disconnect intake manifold collector harness, and vacuum hose.
- CAUTION:**
Cover engine openings to avoid entry of foreign materials.
12. Loosen the bolts in the order shown to remove the intake manifold assembly, using power tools.



INSPECTION AFTER REMOVAL

Surface Distortion

- Using straightedge and feeler gauge, inspect surface distortion of intake manifold surface.

Limit : 0.1 mm (0.004 in)

INSTALLATION


- Install the intake manifold bolts and nuts in the reverse order of removal, following the tightening sequences below.

Tightening Intake Manifold Bolts and Nuts

- Tighten in numerical order as shown.

CAUTION:

After tightening No.5, retighten the No.1 bolt to specification.



Installation of Electric Throttle Control Actuator:

- Tighten the mounting bolts of electric throttle control actuator equally and diagonally in several steps.
- After installation perform procedure in [EM-135, "INSPECTION AFTER INSTALLATION"](#) .

CONNECTING QUICK CONNECTOR ON THE FUEL HOSE (ENGINE SIDE)

1. Make sure no foreign substances are deposited in and around the fuel tube and quick connector, and there is no damage to them.
2. Thinly apply new engine oil around the fuel tube tip end.

INTAKE MANIFOLD


[QR25DE]

3. Align center to insert quick connector straight into fuel tube.

- Insert fuel tube into quick connector until the top spool on fuel tubes is inserted completely and the second level spool is positioned slightly below the quick connector bottom end.

CAUTION:

- Hold at position "A" as shown, when inserting the fuel tube into the quick connector.
- Carefully align to center to avoid inclined insertion to prevent damage to the O-ring inside the quick connector.
- Insert the fuel tube until you hear a "click" sound and actually feel the engagement.
- To avoid misidentification of engagement with a similar sound, be sure to perform the next step.



4. Before clamping the fuel hose with the hose clamp, pull the quick connector hard by hand, holding at the "A" position, as shown. Make sure it is completely engaged (connected) so that it does not come off of the fuel tube.


NOTE:

Recommended pulling force is 50 N (5.1 kg-f, 11.2 lb-f).

5. Install quick connector cap on quick connector joint.

- Direct arrow mark on quick connector cap to upper side (fuel hose side).

6. Install fuel hose to hose clamp.




CONNECTING QUICK CONNECTOR ON THE FUEL HOSE (VEHICLE PIPING SIDE)

1. Make sure no foreign substances are deposited in and around the fuel tube and quick connector, and there is no damage to them.

2. Align center to insert quick connector straight into fuel tube.

- Insert fuel tube until a click is heard.
- Install quick connector cap on quick connector joint. Direct arrow mark on quick connector cap upper side.
- Install fuel hose to hose clamp.



INSPECTION AFTER INSTALLATION

Make sure there is no fuel leakage at connections as follows:

1. Apply fuel pressure to fuel lines by turning ignition switch ON (with engine stopped). Then check for fuel leaks at connections.
2. Start the engine and rev it up and check for fuel leaks at connections.

NOTE:

Use mirrors for checking on connections out of the direct line of sight.


CAUTION:

Do not touch engine immediately after stopping as engine is extremely hot.

- Perform procedures for "Throttle Valve Closed Position Learning" after finishing repairs. Refer to [EC-630, "Throttle Valve Closed Position Learning"](#).
- If electric throttle control actuator is replaced, perform procedures for "Idle Air Volume Learning" after finishing repairs. Refer to [EC-630, "Idle Air Volume Learning"](#).

EXHAUST MANIFOLD AND THREE WAY CATALYST

Removal and Installation



WBIA0865E

- | | | |
|----------------------------------|--------------------------------------|---|
| 1. Exhaust manifold gasket | 2. Heated oxygen sensor 1 | 3. Exhaust manifold cover (upper and lower) |
| 4. Air fuel ratio (A/F) sensor 1 | 5. Exhaust manifold cover lower bolt | 6. Air fuel ratio (A/F) sensor 2 |
| 7. Heated oxygen sensor 2 | 8. Exhaust manifold assembly | |


REMOVAL

1. Remove the engine undercover and engine side covers..
2. Remove generator and generator bracket. Refer to [SC-33, "REMOVAL"](#) .
3. Remove the exhaust front tube. Refer to [EX-5, "REMOVAL"](#) .
4. Remove oil level indicator tube.
5. Disconnect the electrical connector of heated oxygen sensor 1 or air fuel ratio (A/F) sensor 1, and unhook the harness from the bracket and middle clamp on the cover.
6. Remove the heated oxygen sensor 1 or air fuel ratio (A/F) sensor 1 using Tool.

Tool numbers : — (J-44626)
 : KV10117100 (J-36471-A)

CAUTION:

- Be careful not to damage heated oxygen sensor or air fuel ratio (A/F) sensor.
- Discard any heated oxygen sensor or air fuel ratio (A/F) sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.




WBIA0474E

7. Remove the lower exhaust manifold covers.
8. Remove the upper exhaust manifold cover.

EXHAUST MANIFOLD AND THREE WAY CATALYST

[QR25DE]

- Loosen the nuts in the sequence as shown, on the exhaust manifold and three way catalyst.
- Remove the exhaust manifold and three way catalyst assembly and gasket. Discard the gasket.




INSPECTION AFTER REMOVAL

Surface Distortion

- Use a reliable straightedge and feeler gauge to check the flatness of exhaust manifold fitting surface.

Limit : 0.7 mm (0.0276 in)




INSTALLATION

Installation is in the reverse order of removal. Pay attention to the following.

Tightening Exhaust Manifold Nuts

- Tighten the nuts in the numerical order shown, to specification. After tightening No.5, retighten No.1 and then No.3 to specification.



Installation of A/F Sensors and Heated Oxygen Sensors

Clean the A/F sensor and heated oxygen sensor threads with the Tool, then apply the anti-seize lubricant to the threads before installing the A/F sensor and heated oxygen sensors.


Tool number : J-43897 - 18
: J-43897 - 12

CAUTION:

Do not over-tighten the A/F sensors and heated oxygen sensors. Doing so may cause damage to the A/F sensors and heated oxygen sensors, resulting in a malfunction and the MIL coming on.

OIL PAN AND OIL STRAINER

Removal and Installation



WBIA0867E

- | | | |
|----------------------|----------------------|-------------------|
| 1. Oil dipstick tube | 2. Oil pan, upper | 3. Cylinder block |
| 4. Oil filter | 5. Oil pickup screen | 6. Drain plug |
| 7. Oil pan, lower | 8. Rear plate cover | |

REMOVAL

WARNING:


To avoid the danger of being scalded, never drain the engine oil when the engine is hot.

1. Remove the engine under covers on both sides, using power tool.
2. Drain engine oil. Refer to [LU-16, "Changing Engine Oil"](#) .
3. Remove oil level guage and indicator.
4. Remove the front exhaust tube. Refer to [EX-5, "REMOVAL"](#) .
5. Remove lower steering joint bolt.
6. Remove power steering hose bracket from rear of collector.
7. Remove LH and RH drive shafts.
8. Remove A/C compressor. Refer to .
9. Support the engine from above and underneath with suitable hoist and floor jack.
10. Remove the front suspension member for clearance to remove the oil pan. Refer to [FSU-10, "REMOVAL"](#)

OIL PAN AND OIL STRAINER

[QR25DE]

11. Remove the lower oil pan bolts. Loosen the bolts in the order shown, using power tool.




12. Remove the lower oil pan using Tool.

NOTE:

Tap gently to cut sealant around the pan; do not damage the mating surface using Tool.


Tool number : KV10111100 (J-37228)



13. Remove the oil pickup screen.

14. Remove rear plate cover, and four engine-to transaxle bolts, using power tool.

15. Loosen the upper oil pan bolts in the order shown to remove upper oil pan, using power tool.




16. Remove upper oil pan using Tool.

NOTE:

Tap gently to cut sealant around the pan; do not damage the mating surface using Tool.

Tool number : KV10111100 (J-37228)



INSPECTION AFTER REMOVAL

- Clean the oil pickup screen to remove any foreign material.


INSTALLATION

1. Installation is in the reverse order of removal. Paying attention to the following.

OIL PAN AND OIL STRAINER

[QR25DE]

- a. Apply Genuine Silicone RTV Sealant, or equivalent, to the upper oil pan. Refer to [GI-44, "Recommended Chemical Products and Sealants"](#) , and [EM-118, "Precautions for Liquid Gasket"](#) .
- Install the two new O-rings in the upper oil pan.



- b. Tighten the upper oil pan bolts in the order as shown.
- Bolt No.10,11,18 indicate a double tightening in the sequence of bolt No.s 1, 2, 3.

NOTE:


Refer below for specified bolt sizes:

M6 × 20 mm (0.79 in): No.19, 20


M8 × 25 mm (0.98 in): No.1, 3, 4, 9

M8 x 45 mm (1.77 in): No.2, 5, 6, 7, 8, 17


M8 x100 mm (3.97 in): No.12, 13, 14, 15, 16



- c. Apply Genuine Silicone RTV Sealant, or equivalent to the lower oil pan. Refer to [GI-44, "Recommended Chemical Products and Sealants"](#) , and [EM-118, "Precautions for Liquid Gasket"](#)



- d. Tighten the lower oil pan bolts in the numerical order shown.
- Wait at least 30 minutes after the oil pans are installed before filling the engine with oil.




INSPECTION AFTER INSTALLATION

- Check for any engine oil leaks with the engine at operating temperature and running at idle.

IGNITION COIL

Removal and Installation



1. Ignition coil

2. Spark plug

3. Rocker cover

REMOVAL

1. Remove the engine cover.
2. Remove air duct. Refer to [EM-130, "REMOVAL"](#).
3. Disconnect the harness connector from the ignition coil.
4. Remove the ignition coil.

CAUTION:


Do not drop or shock it.

INSTALLATION

Installation is in the reverse order of removal.

SPARK PLUG

Removal and Installation



1. Ignition coil


2. Spark plug

3. Rocker cover

WBIA0859E

REMOVAL


1. Remove the ignition coil. Refer to [EM-141, "Removal and Installation"](#).
2. Remove the spark plug with a suitable spark plug wrench.



PBIC2982E

INSPECTION AFTER REMOVAL

- Do not use a wire brush for cleaning the spark plugs. Replace as necessary.



SMA773C

- If plug is covered with carbon, a spark plug cleaner may be used.

Cleaner air pressure : less than 588 kPa (6 kg/cm², 85 psi)


Cleaning time : less than 20 seconds

SPARK PLUG

[QR25DE]

- Checking and adjusting plug gap is not required between change intervals. If the gap is out of specification, replace the spark plug.

Gap (nominal) : 1.1 mm (0.043 in)



INSTALLATION

Installation is in the reverse order of removal.

Spark Plug Types

Temperature range	NGK
Standard type	DILKAR6A-11
Gap (nominal)	1.1 mm (0.043 in)

A

EM

C

D

E

F

G

H

I

J

K

L


M

FUEL INJECTOR AND FUEL TUBE

PF1:16600

Removal and Installation

EBS0028M



1. Fuel tube protector

2. Fuel tube

3. O-ring (upper)

4. Fuel tube

5. Clip

6. Intake manifold adapter

A. Refer to installation

CAUTION:

- Apply new engine oil to parts before installing the parts, as shown above.
- Do not remove or disassemble parts unless instructed as shown in the figure.

REMOVAL

1. Release the fuel pressure. Refer to [EC-633, "FUEL PRESSURE RELEASE"](#).
2. Remove the intake air duct. Refer to [EM-130, "Removal and Installation"](#).
3. Disconnect the fuel hose quick connector at the fuel tube side. Refer to [EM-132, "INTAKE MANIFOLD"](#).


CAUTION:

- Prepare a container and cloth for catching any spilled fuel.
- This operation should be performed in a place that is free from any open flames.

FUEL INJECTOR AND FUEL TUBE


[QR25DE]

- While hoses are disconnected seal their openings with vinyl bag or similar material to prevent foreign material from entering them.
4. Remove the intake collector. Refer to [EM-132, "INTAKE MANIFOLD"](#) .
 5. Disconnect sub-harness for injector at engine front side, and remove it from bracket.
 6. Loosen the bolts in the order as shown, then remove fuel tube and fuel injectors as an assembly.
 7. Remove the fuel injectors from the fuel tube.
 - Release the clip and remove the fuel injector.
 - Pull fuel injector straight out of the fuel tube.
 - Be careful not to damage the nozzle.
 - Avoid any impact, such as dropping the fuel injector.
 - Do not disassemble or adjust the fuel injector.



INSTALLATION

1. Install new O-rings on the fuel injector.
 - Lubricate the O-rings lightly with new engine oil.
 - Be careful not to scratch O-rings during installation. Also be careful not to twist or stretch the O-ring. If the O-ring was stretched while it is attached, do not insert it into the fuel tube immediately.
2. Install the fuel injector into the fuel tube with the following procedure:
 - Do not reuse the clip, replace it with a new one.
 - Insert the new clip into the clip attachment groove on fuel injector.
 - Insert the clip so that lug "A" of fuel injector matches notch "A" of the clip.
3. Insert fuel injector into fuel tube with clip attached.
 - Insert it while matching it to the axial center.
 - Insert fuel injector so that lug "B" of fuel injector matches notch "B" of the clip.
 - Make sure that fuel tube flange is securely fixed in flange fixing groove on the clip.
 - Make sure that installation is complete by checking that fuel injector does not rotate or come off.
4. Install fuel tube assembly.
 - a. Insert the tip of each fuel injector into intake manifold.




- b. Tighten the bolts in two steps in the numerical order as shown.

Fuel tube assembly bolts

Step 1 : 10.0 N·m (1.0 kg·m, 7 ft·lb.)

Step 2 : 22.0 N·m (2.2 kg·m, 16 ft·lb.)



CAUTION:

- After properly connecting fuel tube assembly to injector and fuel hose, check connection for fuel leakage.
- 5. Install the intake collector. Refer to [EM-132, "INTAKE MANIFOLD"](#) .
- 6. Connect the fuel hose quick connector. Refer to [EM-132, "INTAKE MANIFOLD"](#) .
- 7. Installation of the remaining components is in the reverse order of removal.

INSPECTION AFTER INSTALLATION

Make sure there is no fuel leakage at connections as follows:

1. Apply fuel pressure to fuel lines by turning ignition switch ON (with engine stopped). Then check for fuel leaks at connections.
2. Start the engine and rev it up and check for fuel leaks at connections.

NOTE:

Use mirrors for checking on connections out of the direct line of sight.


CAUTION:

Do not touch engine immediately after stopping as engine is extremely hot.

- Perform procedures for "Throttle Valve Closed Position Learning" after finishing repairs. Refer to [EC-630, "Throttle Valve Closed Position Learning"](#) .
- If electric throttle control actuator is replaced, perform procedures for "Idle Air Volume Learning" after finishing repairs. Refer to [EC-630, "Idle Air Volume Learning"](#) .

ROCKER COVER

Removal and Installation




1. PCV valve

2. Oil filler cap

3. Rocker cover

REMOVAL

1. Remove the ignition coils. Refer to [EM-141, "Removal and Installation"](#).
2. Install a suitable jack under engine.
3. Remove RH engine mount. Refer to [EM-181, "ENGINE ASSEMBLY"](#).
4. Loosen the bolts in the numerical order as shown using power tool.
5. Remove the rocker cover. Remove the oil filler cap and PCV valve if necessary, to transfer to the new rocker cover.



INSTALLATION


1. Apply RTV Silicone Sealant to the joint part of the cylinder head and camshaft bracket using the following the steps.

ROCKER COVER

[QR25DE]

- Use Genuine Silicone RTV Sealant, or equivalent. Refer to .


- Refer to illustration "a" to apply sealant to joint part of No.1 camshaft bracket and cylinder head.
 - Refer to illustration "b" to apply sealant in a 90° degree angle to the illustration "a".
- Install the rocker cover.
 - The rocker cover gasket must be securely installed in the groove in the rocker cover.



- Tighten the rocker cover bolts in two steps, in the numerical order as shown.

Step 1 : 1.96 N-m (0.20 kg-m, 17 in-lb)

Step 2 : 8.33 N-m (0.85 kg-m, 74 in-lb)




- Connect the PCV hose and breather hose to the rocker cover. If necessary, install the oil filler cap and PCV valve and lubricate the PCV valve O-ring with new engine oil.
- Install the ignition coils. Refer to [EM-141, "Removal and Installation"](#) .

CAMSHAFT

Removal and Installation

SEC.111•130•135



- | | | |
|---------------------------|-----------------------------|-------------------------------|
| 1. Camshaft bracket (1) | 2. Washer | 3. Front cover (partial view) |
| 4. Chain guide | 5. Chain tensioner | 6. O-ring(s) |
| 7. Chain tensioner spring | 8. Chain tensioner plunger | 9. IVT control solenoid valve |
| 10. IVT control cover | 11. Camshaft sprocket (EXH) | 12. Camshaft sprocket (INT) |
| 13. Valve lifter | 14. Camshaft (EXH) | 15. Camshaft (INT) |
| 16. Camshaft brackets (2) | 17. Camshaft brackets (5) | 18. Camshaft sensor bracket |
| A. Refer to INSTALLATION | | |


REMOVAL

1. Remove the rocker cover. Refer to [EM-147, "Removal and Installation"](#).
2. Remove the front right side tire and wheel using power tool.
3. Remove the RH splash shield using power tool.
4. Remove the drive belt. Refer to [EM-127, "REMOVAL"](#).
5. Remove the coolant overflow reservoir tank.
6. Disconnect variable timing control solenoid harness connector.

CAMSHAFT


[QR25DE]

7. Loosen the bolts in the order as shown.




- Remove the IVT control cover by cutting the sealant using Tool.

Tool number : KV10111100 (J-37228)




8. Set the No.1 cylinder at TDC on its compression stroke with the following procedure:

- Open the splash cover on RH under cover.
- Rotate crankshaft pulley clockwise, and align mating marks for TDC with timing indicator on front cover, as shown.



c. At the same time, make sure that the mating marks on camshaft sprockets are lined up with the yellow links in the timing chain, as shown.

- If not, rotate crankshaft pulley one more turn to line up the mating marks to the yellow links, as shown.



9. Pull the timing chain guide out between the camshaft sprockets through front cover.

CAMSHAFT

[QR25DE]



10. Remove camshaft sprockets with the following procedure.

CAUTION:

- Do not rotate the crankshaft or camshaft while the timing chain is removed. It causes interference between valve and piston.

NOTE:

- Chain tension holding work is not necessary. Crankshaft sprocket and timing chain do not disconnect structurally while front cover is attached.
- a. Line up the mating marks on camshaft sprockets with the yellow links in the timing chain, and paint an indelible mating mark on the sprocket and timing chain link plate.
 - b. Push in the tensioner plunger and hold. Insert a stopper pin into the hole on tensioner body to hold the chain tensioner. Remove the timing chain tensioner.
 - Use a wire with 0.5 mm (0.02 in) diameter for a stopper pin.
 - c. Secure the hexagonal part of camshaft with a suitable tool. Loosen the camshaft sprocket mounting bolts and remove the camshaft sprockets.




11. Loosen the camshaft bracket bolts in the order as shown, and remove the camshaft brackets and camshafts.

- Remove No.1 camshaft bracket by slightly tapping it with a rubber mallet.

12. Remove the valve lifters.

- Check mounting positions, and set them aside in the order removed.




INSPECTION AFTER REMOVAL

Camshaft Runout

1. Put the camshaft on a V-block supporting the No.2 and No.5 journals.
2. Set the dial gauge vertically on the No.3 journal.
3. Turn camshaft in one direction by hand, and measure the camshaft runout on the dial gauge total indicator reading.

Standard : Less than 0.04 mm (0.0016 in)




Camshaft Cam Height

1. Measure the camshaft cam height.

Standard intake cam height : 44.815 - 45.005mm
(1.7644 - 1.7718 in)

Standard exhaust cam height : 43.975 - 44.165 mm
(1.7313 - 1.7388 in)

2. If wear is beyond the limit, replace the camshaft.




Camshaft Journal Clearance

Outer Diameter of Camshaft Journal

- Measure the outer diameter of the camshaft journal.


Standard No.1 outer diameter : 27.935 - 27.955 mm
(1.0998 - 1.1006 in)

Standard No.2, 3, 4, 5, outer diameter : 23.435 - 23.455 mm
(0.9226 - 0.9234 in)



Inner Diameter of Camshaft Bracket


- Tighten the camshaft bracket bolts to the specified torque following the tightening pattern as shown. Refer to Step 4 of [EM-154, "INSTALLATION"](#), of "CAMSHAFT" for the specified torque sequence.



- Using inside micrometer, measure inner diameter of camshaft bracket.

Standard No.1 : 28.000 - 28.021 mm (1.1024 - 1.1032 in)

Standard No.2, 3, 4, 5 : 23.500 - 23.521 mm (0.9252 - 0.9260 in)



Calculation of Camshaft Journal Clearance

- (Journal clearance) = (inner diameter of camshaft bracket) – (outer diameter of camshaft journal)

Standard : 0.045 - 0.086 mm (0.0018 - 0.0034 in)

- When out of the specified range above, replace either or both the camshaft and the cylinder head assembly.

NOTE:


Inner diameter of the camshaft bracket is manufactured together with the cylinder head. If the camshaft bracket is out of specification, replace the whole cylinder head assembly.

Camshaft End Play

1. Install a dial gauge in the thrust direction on the front end of the camshaft. Measure the end play with the dial gauge while moving the camshaft forward and backward (in direction to axis).

Standard end play : 0.115 - 0.188 mm (0.0045 - 0.0074 in)

2. If out of the specified range, replace with new camshaft and measure again.
3. If out of the specified range again, replace with new cylinder head assembly.




Camshaft Sprocket Runout

1. Install the camshaft in the cylinder head.
2. Install the camshaft sprocket on the camshaft.
3. Measure camshaft sprocket runout while turning the camshaft by hand.


Runout : Less than 0.15 mm (0.0059 in)

4. If it exceeds the specification, replace camshaft sprocket.



Valve Lifter

- Check if the surface of the valve lifter has any excessive wear or cracks, replace as necessary.




Valve Lifter Clearance

Outer Diameter of Valve Lifter

- Measure the outer diameter of the valve lifter.

Valve lifter outer diameter : 33.977 - 33.987 mm (1.3377 - 1.3381 in)

- If out of the specified range, replace the valve lifter.



A
EM
C
D
E
F
G
H
I
J
K
L
M

CAMSHAFT


[QR25DE]

Valve Lifter Bore Inner Diameter

- Using inside micrometer, measure diameter of valve lifter bore of cylinder head.

Standard : 34.000 - 34.021 mm (1.3386 - 1.3394 in)

- If out of the specified range, replace the cylinder head assembly.



Calculation of Valve Lifter Clearance

- (Valve lifter clearance) = (hole diameter for valve lifter) – (outer diameter of valve lifter)

Standard : 0.020 - 0.056 mm (0.0008 - 0.0022 in)


- If out of specified range, replace either or both valve lifter and cylinder head assembly.

INSTALLATION


- Install the valve lifter.
 - Install them in the same position from which they were removed.
- Install the camshafts.
 - The distinction between the intake and exhaust camshafts is in a difference of shapes of the back end:

Intake: Signal plate for the camshaft position sensor (PHASE)


Exhaust: Cone end shape



- Install camshafts so that the dowel pins on the front side are positioned as shown.



- Install camshaft brackets.
 - Install by referring to identification mark on upper surface mark.
 - Install so that identification mark can be correctly read when viewed from the exhaust side.




CAMSHAFT

[QR25DE]


- Install No. 1 camshaft bracket as follows.
- Apply sealant to No.1 camshaft bracket as shown.
- Use **Genuine Silicone RTV Sealant, or equivalent. Refer to GI-44, "Recommended Chemical Products and Sealants"**.

CAUTION:


- After installation, be sure to wipe off any excessive sealant leaking from part "A" (both on right and left sides).



- Apply sealant to camshaft bracket contact surface on the front cover backside.
- Apply sealant to the outside of bolt hole on front cover.



- Position the No.1 camshaft bracket near the mounting position, and install it without disturbing the sealant applied to the surfaces.




4. Tighten camshaft bracket bolts in four steps in the order as shown.

- Step 1 (bolts 9 - 11) : 1.96 N·m (0.2 kg·m, 17 in-lb)**
- Step 2 (bolts 1 - 8) : 1.96 N·m (0.2 kg·m, 17 in-lb)**
- Step 3 (bolts 1 - 11) : 5.88 N·m (0.6 kg·m, 52 in-lb)**
- Step 4 (bolts 1 - 11) : 10.4 N·m (1.02 kg·m, 92 in-lb)**

CAUTION:

After tightening camshaft bracket bolts, be sure to wipe off excessive sealant from the parts listed below.

- Mating surface of rocker cover.
- Mating surface of front cover, when installed without the front cover.



CAMSHAFT


[QR25DE]

5. Install camshaft sprockets.

- Install them by lining up the mating marks on each camshaft sprocket with the ones painted on the timing chain during removal.
- Before installation of chain tensioner, it is possible to re-match the marks on timing chain with the ones on each sprocket.

CAUTION:

- **Aligned mating marks could slip. Therefore, after matching them, hold the timing chain in place by hand.**
- **Before and after installing chain tensioner, check again to make sure that mating marks have not slipped.**



6. Install chain tensioner.


CAUTION:

- **After installation, pull the stopper pin off completely, and make sure that the tensioner is fully released.**

7. Install chain guide.

8. Install IVT control cover with the following procedure.

- Install IVT control solenoid valve to intake valve timing control cover.
- Install O-ring to front cover side.
- Apply Genuine Silicone RTV Sealant to the positions as shown in the figure. Refer to [GI-44, "Recommended Chemical Products and Sealants"](#).




d. Install IVT control cover.

- Tighten the bolts in the numerical order as shown.

9. Check and adjust valve clearances. Refer to [EM-157, "Valve Clearance"](#).

10. Installation of the remaining components is in the reverse order of removal.



INSPECTION AFTER INSTALLATION

INSPECTION OF CAMSHAFT SPROCKET (INT) OIL GROOVE

EBS00Z8P

CAUTION:

- **Perform this inspection only when DTC P0011 is detected in self-diagnostic results of CONSULT III and it is directed according to inspection procedure of EC section. Refer to [EC-702, "DTC P0011 IVT CONTROL"](#).**
 - **Check when engine is cold so as to prevent burns from any splashing engine oil.**
- Check engine oil level. Refer to [LU-15, "OIL LEVEL"](#).
 - Perform the following procedure so as to prevent the engine from being unintentionally started while checking.
 - Release fuel pressure. Refer to [EC-633, "FUEL PRESSURE RELEASE"](#).
 - Disconnect ignition coil and injector harness connectors if practical.
 - Remove IVT control solenoid valve. Refer to [EM-149, "CAMSHAFT"](#).


4. Crank engine, and then make sure that engine oil comes out from IVT control cover oil hole. End cranking after checking.

WARNING:

Be careful not to touch rotating parts (drive belts, idler pulley, and crankshaft pulley, etc.).

CAUTION:

- Engine oil may squirt from IVT control solenoid valve installation hole during cranking. Use a shop cloth to prevent engine oil from splashing on worker, engine components and vehicle.
- Do not allow engine oil to get on rubber components such as drive belts or engine mount insulators. Immediately wipe off any splashed engine oil.




5. Clean oil groove between oil strainer and IVT control solenoid valve if engine oil does not come out from IVT control cover oil hole. Refer to [LU-13, "Lubrication Circuit"](#).
6. Remove components between IVT control solenoid valve and camshaft sprocket (INT), and then check each oil groove for clogging.
 - Clean oil groove if necessary. Refer to [LU-13, "Lubrication Circuit"](#).
7. After inspection, installation of the remaining components is in the reverse order of removal.


Valve Clearance INSPECTION

EBS00Z8Q

- Perform this inspection as follows after removal, installation, or replacement of the camshaft or any valve-related parts, or if there are any unusual engine conditions due to changes in valve clearance over time (starting, idling, and/or noise).
1. Warm up the engine, then stop it.
 2. Remove front RH engine under cover using power tool.
 3. Remove the rocker cover using power tool. Refer to [EM-147, "Removal and Installation"](#).
 4. Turn crankshaft pulley in normal direction (clockwise when viewed from front) to align TDC identification mark (without paint mark) with timing indicator.



5. At this time, check that the both intake and exhaust cam lobes of No. 1 cylinder face outside.
 - If they do not face outside, turn crankshaft pulley once more.




CAMSHAFT

[QR25DE]

6. By referring to the figure (locations indicated with black arrow), measure valve clearances with a feeler gauge at locations marked X as shown in the table below.

- No.1 cylinder compression TDC.

Cylinder	No.1		No.2		No.3		No.4	
	INT	EXH	INT	EXH	INT	EXH	INT	EXH
Measurable	x	x	x			x		



- Use a feeler gauge to measure the clearance between valve and camshaft.

Valve clearance standard:

Cold Intake : 0.24 - 0.32 mm (0.009 - 0.013 in)

Exhaust : 0.26 - 0.34 mm (0.010 - 0.013 in)


Hot* Intake : 0.304 - 0.416 mm (0.012 - 0.016 in)

Exhaust : 0.308 - 0.432 mm (0.013 - 0.017 in)

*Reference data at approximately 80°C (176°F)

CAUTION:

If inspection was carried out with cold engine, check that values with fully warmed up engine are still within specifications.




7. Turn crankshaft one complete revolution (360°) and align mark on crankshaft pulley with pointer.

8. By referring to the figure (locations indicated with black arrow), measure valve clearances with a feeler gauge at locations marked X as shown in the table below.

- No.4 cylinder compression TDC.

Cylinder	No.1		No.2		No.3		No.4	
	INT	EXH	INT	EXH	INT	EXH	INT	EXH
Measurable			x	x			x	x




9. If out of specifications, adjust as follows.

ADJUSTMENT

- Perform adjustment depending on selected head thickness of valve lifter.
- The specified valve lifter thickness is the dimension at normal temperatures. Ignore dimensional differences caused by temperature. Use the specifications for hot engine condition to adjust.

1. Remove camshaft. Refer to [EM-149, "Removal and Installation"](#).
2. Remove the valve lifters at the locations that are outside the standard.
3. Measure the center thickness of the removed valve lifters with a micrometer.



4. Use the equation below to calculate valve lifter thickness for replacement.

- Valve lifter thickness calculation.

$$t = t1 + (C1 - C2)$$


t = Thickness of replacement valve lifter.

t1 = Thickness of removed valve lifter.

C1 = Measured valve clearance.

C2 = Standard valve clearance.

- Thickness of a new valve lifter can be identified by stamp marks on the reverse side (inside the cylinder).
Stamp mark 696 indicates a thickness of 6.96 mm (0.2740 in)
Available thickness of valve lifter: 26 sizes with a range of 6.96 to 7.46 mm (0.2740 to 0.2937 in), in steps of 0.02 mm (0.0008 in), when assembled at the factory.



5. Install the selected valve lifter.

6. Install camshaft.

7. Manually turn crankshaft pulley a few turns.

8. Check that valve clearances for cold engine are within specifications, by referring to the specified values.

9. After completing the repair, check valve clearances again with the specifications for warmed engine. Use a feeler gauge to measure the clearance between the valve and camshaft. Make sure the values are within specifications.

Valve clearance standard:

Cold Intake : 0.24 - 0.32 mm (0.009 - 0.013 in)

Exhaust : 0.26 - 0.34 mm (0.010 - 0.013 in)

Hot* Intake : 0.304 - 0.416 mm (0.012 - 0.016 in)

Exhaust : 0.308 - 0.432 mm (0.013 - 0.017 in)

*: Reference data at approximately 80°C (176°F)

TIMING CHAIN


[QR25DE]

PF1:13028

EBS00Z8R

TIMING CHAIN

Removal and Installation



WBIA0884E


- | | | |
|--|--------------------------------|----------------------------|
| 1. Oil rings | 2. Camshaft sprocket (INT) | 3. Camshaft sprocket (EXH) |
| 4. Chain tensioner | 5. Spring | 6. Chain tensioner plunger |
| 7. Timing chain slack guide | 8. Timing chain | 9. Front cover |
| 10. Chain guide | 11. IVT solenoid valve | 12. IVT cover |
| 13. Crankshaft pulley bolt | 14. Crankshaft pulley | 15. Front oil seal |
| 16. Balancer unit timing chain tensioner | 17. Oil pump drive spacer | 18. Crankshaft sprocket |
| 19. Timing chain tension guide | 20. Balancer unit timing chain | 21. Balancer unit |

CAUTION:

Apply new engine oil to parts marked in illustration before installation.


REMOVAL

1. Support the engine and transaxle assembly with suitable tools.
2. Remove RH splash shield.
3. Remove the upper and lower oil pan, and oil strainer. Refer to [EM-138, "Removal and Installation"](#) .
4. Remove generator. Refer to [SC-33, "REMOVAL"](#) .
5. Remove engine cover.
6. Disconnect variable timing control solenoid harness connector.
7. Remove engine ground.
8. Remove the coolant overflow reservoir tank.
9. Position the RH engine compartment fuse and relay box aside.
10. Remove the RH engine mount and bracket. Refer to [EM-181, "Removal and Installation"](#) .
11. Loosen bolts in the numerical order as shown.




Remove the IVT (intake valve timing) control cover using Tool.

Tool number : KV10111100 (J-37228)




12. Pull chain guide between camshaft sprockets out through front cover.
13. Set the No.1 cylinder at TDC on the compression stroke with the following procedure:
 - a. Rotate the crankshaft pulley clockwise and align the mating marks to the timing indicator on the front cover.




TIMING CHAIN

[QR25DE]


- b. At the same time, make sure that the mating marks on the camshaft sprockets are lined up as shown.
- If not lined up, rotate the crankshaft pulley one more turn to line up the mating marks to the positions as shown.



14. Remove crankshaft pulley with the following procedure:
- a. Hold the crankshaft pulley using suitable tool, then loosen the crankshaft pulley bolt, and pull the pulley out about 10 mm (0.39 in).



- b. Attach suitable pulley puller in the M 6 (0.24 in diameter) thread hole on crankshaft pulley, and remove crankshaft pulley using a suitable puller.




15. Remove the front cover with the following procedure:
- a. Loosen the bolts in the reverse order as shown, and remove them.
- b. Remove the front cover.

CAUTION:

- Be careful not to damage the mounting surface.

16. If the front oil seal needs to be replaced, lift it out with a screwdriver to remove it.




TIMING CHAIN

[QR25DE]

17. Remove timing chain with the following procedure:


- a. Push in the tensioner plunger. Insert a stopper pin into the hole on the tensioner body to hold the chain tensioner.
 - Use a wire of 0.5 mm (0.02 in) diameter as a stopper pin.
- b. Remove the chain tensioner.



- c. Secure hexagonal part of the camshaft with a wrench and loosen the camshaft sprocket bolt and remove the camshaft sprocket for both camshafts.

CAUTION:


- Do not rotate the crankshaft or camshafts while the timing chain is removed. It can cause damage to the valve and piston.



18. Remove the chain slack guide, tension guide, timing chain, and oil pump drive spacer.

19. Remove the timing chain tensioner for the balancer unit with the following procedure:

- a. Lift the tensioner lever up, and release the ratchet claw for installation.
 - b. Push tensioner sleeve in, and hold it.
 - c. Matching the hole on lever with the one on body, insert a stopper pin to secure tensioner sleeve.
 - d. Remove the timing chain tensioner for the balancer unit.
20. Remove timing chain for balancer unit and crankshaft sprocket.




21. Loosen bolts in reverse order as shown, and remove balancer unit.

- Use Torx socket (size E14)

CAUTION:

- Do not disassemble balancer unit.




A
EM
C
D
E
F
G
H
I
J
K
L
M

INSPECTION AFTER REMOVAL

Timing Chain

Check the timing chain for cracks or serious wear. If a defect is detected, replace it.




PBIC0282E

Balancer Unit Bolt Outer Diameter

- Measure outer diameters (d1, d2) at the two positions as shown.
- Measure d2 within the range A.
- If the value difference (d1 - d2) exceeds the limit (a dimension difference is large), replace it with a new one.

Limit : 0.15 mm (0.0059 in) or more



KBIA0126E

INSTALLATION

NOTE:

- There may be two color variations of the link marks (link colors) on the timing chain.
 - There are 26 links between the gold/yellow mating marks on the timing chain; and 64 links between the camshaft sprocket gold/yellow link and the crankshaft sprocket orange/blue link, on the timing chain side without the tensioner.
1. Make sure the crankshaft key points straight up.
 2. Install the balancer unit and tighten the bolts in the numerical order as shown:

CAUTION:

- **When reusing a bolt, check its outer diameter before installation. Refer to [EM-164, "Balancer Unit Bolt Outer Diameter"](#).**


Tool number : KV10112100 (BT-8653-A)

CAUTION:


- **Check tightening angle with an angle wrench or a protractor. Do not make judgment by visual check alone.**
- Apply new engine oil to threads and seating surfaces of bolts.

Balancer unit bolts

- | | |
|---|---|
| Step 1 | : 42 N-m (4.3 kg-m, 31 ft-lb) |
| Step 2 | : 90° - 95° degrees rotation
(Target: 90° degrees) |
| Step 3 (Loosen in reverse order or tightening) | : 0 N-m (0 kg-m, 0 ft-lb) |
| Step 4 | : 45.2 - 51.0 N-m (4.6 - 5.2 kg-m, 34 - 37 ft-lb) |
| Step 5 | : 90° - 95° degrees rotation
(Target: 90° degrees) |



WBIA0887E




WBIA0888E

TIMING CHAIN

[QR25DE]

- Install the crankshaft sprocket and timing chain for the balancer unit.

- Make sure that the crankshaft sprocket is positioned with mating marks on the block and sprocket meeting at the top.
- Install it by lining up mating marks on each sprocket and timing chain.




- Install timing chain tensioner for balancer unit.

NOTE:

Chain guide and tensioner move freely with the staking pin as the axle. Therefore, bolt hole position of the three points could be changed during removal. If points change, temporarily tighten the two bolts on the chain guide and move the tensioner to match the bolt holes.

- Be careful not to let mating marks of each sprocket and timing chain slip.
- After installation, make sure the mating marks have not slipped, then remove stopper pin and release tensioner.



- Install timing chain and related parts.

- Install by lining up mating marks on each sprocket and timing chain as shown.


NOTE:

Before installing chain tensioner, it is possible to change the position of mating mark on timing chain for that of each sprocket for alignment.

CAUTION:

For the above reason, after the mating marks are aligned, keep them aligned by holding them with a hand.

- Before and after installing chain tensioner, check again to make sure that mating marks have not slipped.
- After installing chain tensioner, remove stopper pin, and make sure the tensioner moves freely.
- To avoid skipped teeth, do not move crankshaft and camshaft until front cover is installed.




- Install new front oil seal to front cover, using suitable tool

- Install new oil seal in until it is flush with front end surface of front cover.

CAUTION:

- Be careful not to cause damage to circumference of oil seal.



TIMING CHAIN

[QR25DE]


7. Install front cover with the following procedure:
 - a. Install O-rings to cylinder head and cylinder block.
 - b. Apply Genuine Silicone RTV Sealant or equivalent, to positions specified in the figure. Refer to [GI-44, "Recommended Chemical Products and Sealants"](#) .

C (Sealant dimension) : 3.9 mm (0.154 in) dia

- c. Make sure the mating marks on the timing chain and each sprocket are still aligned. Then install the front cover.

CAUTION:

- Be careful not to damage the front oil seal during installation with the front end of the crankshaft.



- d. Tighten front cover bolts in the numerical order as shown.
 - e. After all bolts are tightened, retighten them to the specified torque.

Front cover bolt torque

Bolts A : 49 N·m (5.0 kg·m, 36 ft·lb)

Bolts B : 12.7 N·m (1.3 kg·m, 9 ft·lb)


Bolts C : 12.7 N·m (1.3 kg·m, 9 ft·lb)

Bolts D : 49 N·m (5.0 kg·m, 36 ft·lb)

E Dowel pins

CAUTION:

Wipe off any excess sealant leaking at the surface for installing the oil pan.




8. Install the chain guide between the camshaft sprockets.
9. Install IVT cover with the following procedure:
 - a. Install IVT solenoid valves to IVT cover.
 - b. Install new oil rings to the intake camshaft sprocket insertion points on IVT control cover backside.
 - c. Install new O-ring to front cover.


TIMING CHAIN

[QR25DE]

- d. Apply Silicone RTV Sealant to the IVT cover as shown.
- Apply Genuine Silicone RTV Sealant or equivalent, to positions specified in the figure. Refer to [GI-44, "Recommended Chemical Products and Sealants"](#).



- e. Tighten the IVT cover bolts in the numerical order as shown.



10. Insert crankshaft pulley by aligning with crankshaft key.
- Tap its center with a plastic hammer to insert.
 - Do not tap the belt hook.
11. Tighten crankshaft pulley bolts.
- Secure crankshaft pulley with a pulley holder to tighten the bolt.
 - Perform angle tightening using Tool with the following procedure:


Tool number : KV10112100 (BT-8653-A)

- a. Apply new engine oil to threads and seat surfaces of bolts.
- b. Tighten to initial specifications:-

Crankshaft pulley bolt initial tightening : 37.3 - 47.1 N-m (3.8 - 4.8 kg-m, 28 - 34 ft-lb)

- c. Apply a paint mark on the front cover, mating with any one of six easy to recognize stamp marks on bolt flange.
- d. Turn crankshaft pulley bolt another 60° to 66° degrees [Target: 60° degrees].
- Check vertical mounting angle with movement of one stamp mark.

12. Installation of the remaining components is in reverse order of removal.



OIL SEAL

Removal and installation of Valve Oil Seal
REMOVAL

1. Remove camshaft. Refer to [EM-149, "REMOVAL"](#) .
2. Remove valve lifter. Refer to [EM-149, "REMOVAL"](#) .
3. Rotate crankshaft, and set piston whose oil seal is to be removed to top dead center. This prevents valve from dropping inside cylinder.

CAUTION:


When rotating crankshaft, be careful to avoid scarring the front cover with the timing chain.

4. Remove valve collet, valve spring retainer and valve spring using Tool.

Tool number


: KV10116200 (J-26336-B)

: KV10115900 (J-26336-20)



5. Remove valve oil seal using Tool.

Tool number : KV10107902 (J-38959)




INSTALLATION

1. Apply new engine oil to new valve oil seal joint surface and seal lip.
2. Press in valve oil seal to the position shown using Tool.

Oil seal installed height : 12.1 mm (0.476 in)

Tool number : KV10115600 (J-38958)



3. Installation of the remaining components in the reverse order of removal.


Removal and Installation of Front Oil Seal

REMOVAL

- Remove the following parts:
 - Engine under cover using power tools.
 - Drive belts. Refer to [EM-127, "DRIVE BELTS"](#).
 - Crankshaft pulley. Refer to [EM-160, "TIMING CHAIN"](#).
- Remove front oil seal from front cover.


CAUTION:

Be careful not to scratch front cover.




INSTALLATION

- Apply new engine oil to new oil seal and install it using a suitable tool.



- Install new oil seal in the direction shown.



- Installation of the remaining components is in reverse order of removal.


Removal and Installation of Rear Oil Seal

REMOVAL

1. Remove the transaxle. Refer to [MT-66, "REMOVAL"](#) or [MT-142, "REMOVAL"](#) (M/T), [CVT-204, "REMOVAL"](#) (CVT).
2. Remove flywheel (MT) or drive plate (CVT).
3. Remove rear oil seal using suitable tool.


CAUTION:

Be careful not to scratch rear oil seal retainer.




INSTALLATION


1. Apply new engine oil to new oil seal and install it using a suitable drift.
 - Install new oil seal in the direction shown.



- Press fit new oil seal straight using a suitable drift, to avoid causing burrs or tilting.



- Press in the new oil seal to the specified depth as shown.




2. Installation of the remaining components in reverse order of removal.

CYLINDER HEAD


On-Vehicle Service

CHECKING COMPRESSION PRESSURE

1. Warm up the engine to full operating temperature.
2. Release the fuel pressure. Refer to [EC-633, "FUEL PRESSURE RELEASE"](#).
3. Remove the ignition coil and spark plug from each cylinder. Refer to [EM-142, "Removal and Installation"](#).
4. Connect engine tachometer (not required in use of CONSULT-III).
5. Disconnect the fuel injector harness connector to avoid any residual fuel injection during the measurement.
6. Install the compression tester with the adapter into the spark plug hole.



- Use compression gauge whose picking up end inserted to spark plug hole is smaller than 20 mm (0.79 in) in diameter. Otherwise, it may be caught by cylinder head during removal.



7. With the accelerator pedal fully depressed, turn the ignition switch to the "START" position to crank over the engine. When the gauge pointer stabilizes, read the compression pressure and engine rpm. Perform these steps to check each cylinder.

Unit: kPa (kg/cm², psi) / rpm

Standard	Minimum	Difference limit between cylinders
1,250 (12.8, 181.3) / 250	1,060 (10.8, 153.7) / 250	100 (1.0, 14) / 250

CAUTION:

Always use a fully charged battery to obtain specified engine cranking speed.

- If the engine speed is out of specified rpm range, check the battery. Check engine speed again with a fully charged battery.
- If compression pressure is below minimum value, check valve clearances and parts associated with combustion chamber (valve, valve seat, piston, piston ring, cylinder bore, cylinder head, cylinder head gasket). After the checking, measure compression pressure again.
- If some cylinders have low compression pressure, pour small amount of engine oil into the spark plug hole of the cylinder to re-check it for compression.
- If the added engine oil improves the compression, the piston rings may be worn or damaged. Check the piston rings and replace if necessary.
- If the compression pressure remains at low level despite the addition of engine oil, the valves may be malfunctioning. Check the valves for damage. Replace the valve or valve seat accordingly.


CYLINDER HEAD

[QR25DE]

- If two adjacent cylinders have respectively low compression pressure and their compression remains low even after the addition of engine oil, the head gasket is leaking. In such a case, replace the cylinder head gasket.
8. Install spark plug, ignition coil and harness connectors.


Removal and Installation

EBS00Z8W



REMOVAL

1. Remove the timing chain. Refer to [EM-160, "Removal and Installation"](#) .
2. Remove the camshafts. Refer to [EM-149, "CAMSHAFT"](#) .
3. Remove spark plugs. Refer to [EM-142, "Removal and Installation"](#) .
4. Remove exhaust manifold. Refer to [EM-136, "REMOVAL"](#) .
5. Remove cylinder head loosening bolts in the order as shown, using power tool.
6. If necessary to transfer to new cylinder head or remove for reconditioning, remove the intake manifold collector, intake manifold, and fuel tube assembly. Refer to [EM-174, "Disassembly and Assembly"](#) .



INSPECTION AFTER REMOVAL

Outer Diameter of Cylinder Head Bolts


- Cylinder head bolts are tightened by plastic zone tightening method. Whenever the size difference between d1 and d2 exceeds the limit, replace the bolts with new ones.

CYLINDER HEAD

[QR25DE]

Limit (d1 - d2) : 0.23 mm (0.0091 in) or less

- If reduction of outer diameter appears in a position other than d2, use it as d2 point.



INSTALLATION

1. Install a new cylinder head gasket.
2. Follow the steps below to tighten the cylinder head bolts using Tool, in the numerical order as shown.

- Apply new engine oil to the threads and the seating surfaces of bolts.

CAUTION:

- If cylinder head bolts are re-used, check their outer diameters before installation. Refer to [EM-172. "Outer Diameter of Cylinder Head Bolts"](#).
- Check and confirm the tightening angle by using angle wrench or protractor. Avoid judgment by visual inspection without the tool.

Step a : 98.1 N·m (10 kg·m, 37 ft·lb)




Step c : Loosen to 0 N·m in the reverse order of tightening.

Step d : 39.2 N·m (4.0 kg·m, 29 ft·lb)

Step e : 75° clockwise


Step f : 75° clockwise

Tool number : KV10112100 (BT-8653-A)



3. Installation of the remaining components is in reverse order of removal.

Disassembly and Assembly



- | | | |
|----------------------|--------------------------|--|
| 1. Valve collet | 2. Valve spring retainer | 3. Valve spring (with valve spring seat) |
| 4. Valve oil seal | 5. Valve guide | 6. Cylinder head |
| 7. Valve seat (INT) | 8. valve (INT) | 9. Valve (EXH) |
| 10. Valve seat (EXH) | 11. Spark plug | 12. Spark plug tube |

CAUTION:

- When installing camshafts, chain tensioners, oil seals or other sliding parts, lubricate contacting surfaces with new engine oil.
- Apply new engine oil to threads and seat surfaces when installing the cylinder head, camshaft sprocket, crankshaft pulley and camshaft bracket.
- Attach tags to valve lifters so all parts are assembled in their original position.

DISASSEMBLY


1. Remove the valve lifter.
 - Confirm installation point.
2. Remove the valve collet, valve spring retainer and valve spring using Tool.

Tool number : KV10116200 (J-26336-B)
 : KV10115900 (J-26336-20)

CAUTION:

Do not remove valve spring seat from valve spring.

3. Push valve stem to combustion chamber side, and remove valve.
 - Inspect valve guide clearance before removal. Refer to [EM-176, "VALVE GUIDE CLEARANCE"](#).
 - Confirm installation point.
4. Remove valve oil seal using Tool.



CYLINDER HEAD


[QR25DE]

Tool number : KV10107902 (J-38959)

- When valve seat must be replaced, refer to [EM-178, "VALVE SEAT REPLACEMENT"](#) .
- When valve guide must be replaced, refer to [EM-177, "VALVE GUIDE REPLACEMENT"](#) .
- Remove spark plug using suitable tool.
- Remove spark plug tubes, if necessary using suitable tool.

CAUTION:

- Be careful not to damage cylinder head.
- Do not remove spark plug tube if not necessary. Once removed, the spark plug tube cannot be reused because of deformation.




WBIA0478E

ASSEMBLY

- Install valve guide. Refer to [EM-177, "VALVE GUIDE REPLACEMENT"](#) .
- Install valve seat. Refer to [EM-178, "VALVE SEAT REPLACEMENT"](#) .
- Install new valve oil seal to the specified height as shown, using Tool.

Oil seal installed height : 12.1 mm (0.476 in)

Tool number : KV10115600 (J-38958)




WBIA0892E

- Install valve.
 - Install larger diameter to intake side.
- Install valve spring (with valve spring seat).
 - Install smaller pitch spring end (valve spring seat side) to cylinder head side.
 - Confirm the identification color of the valve spring.

Intake spring identification color : Pink

Exhaust spring identification color : Blue



PBIC0525E

- Install valve spring retainer.
- Install valve collet using Tool.

Tool numbers : KV10116200 (J-26336-B)


: KV10115900 (J-26336-20)

- Install valve collet with a magnet hand.

CAUTION:

When working, be careful not to damage valve lifter holes.

- Tap valve stem edge lightly with a plastic hammer after installation to check its installed condition.




WBIA0578E

- Install valve lifter.

CYLINDER HEAD

[QR25DE]

9. Install the spark plug tube, if removed. Press-fit the spark plug tube into the cylinder head using the following procedure:
 - a. Remove old sealant from cylinder head side installation hole.
 - b. Apply sealant all round on spark plug tube within approximately 12 mm (0.47 in) width from edge of spark plug tube on the press-fit side.
Use Genuine High Strength Locking Sealant or equivalent. Refer to [GI-44, "Recommended Chemical Products and Sealants"](#)
 - c. Press-fit the spark plug tube to specified height "H" as shown, using suitable tool.



Standard press-fit height "H" : 41.2 - 42.2 mm (1.622 - 1.661 in)

CAUTION:

- When press-fitting, be careful not to deform spark plug tube.
- After press-fitting, wipe off any protruding sealant on top surface of cylinder head.

10. Install spark plug. Refer to [EM-142, "SPARK PLUG"](#) .

Inspection After Disassembly CYLINDER HEAD DISTORTION

EBS00Z8Y


1. Wipe off oil and remove water scale deposits, old gasket, old sealer, and carbon with a scraper.

CAUTION:

Use care not to allow gasket debris to enter passages for oil or water.


2. At each of several locations on bottom surface of cylinder head, measure distortion in six directions.

Limit : 0.1 mm (0.004 in) or less



VALVE DIMENSIONS

Check dimensions of each valve. Refer to [EM-209, "VALVE"](#) .



VALVE GUIDE CLEARANCE


Perform this inspection before removing the valve guide.

1. Make sure that the valve stem diameter is within the specification.
2. Push the valve out by approximately 15 mm (0.59 in) toward the combustion chamber side to measure the valve's run-out volume (in the direction of dial gauge) with dial gauge.
3. Half of the run-out volume accounts for the valve guide clearance.

CYLINDER HEAD

[QR25DE]


- Intake valve guide clearance** : 0.020 - 0.053 mm (0.0008 - 0.0021 in) or less
- Exhaust valve guide clearance** : 0.030 - 0.063 mm (0.0012 - 0.0025 in) or less




VALVE GUIDE REPLACEMENT

When valve guide is removed, replace with oversized (0.2 mm, 0.008 in) valve guide.

1. To remove valve guide, heat cylinder head to 110° to 130°C (230° to 266°F) by soaking in heated oil.




2. Drive out valve guide with a press [under a 20 kN (2.2 ton-force) pressure] or hammer and suitable tool.



3. Ream cylinder head valve guide hole using suitable reamer.

Intake and exhaust valve guide hole diameter (Service) : 9.975 - 9.996 mm (0.3927 - 0.3935 in)


4. Heat cylinder head to 110° to 130°C (230° to 266°F) by soaking in heated oil.



CYLINDER HEAD


[QR25DE]

5. Press valve guide from camshaft side to dimensions as shown.



6. Apply finish to valve guide using suitable reamer.

Intake and exhaust : 6.000 - 6.018 mm (0.2362 - 0.2369 in)




VALVE SEAT CONTACT

NOTE:

After confirming that the dimensions of valve guides and valves are within specifications, perform this procedure:

- Apply prussian blue (or white lead) onto contacting surface of valve seat to check the condition of the valve contact on the seat surface.
- Check if the contact area band is continuous all around the circumference.
- If not, grind to adjust valve fitting and check again. If the contacting surface still has NG conditions even after the re-check, replace the valve seat.



VALVE SEAT REPLACEMENT

NOTE:


When valve seat is removed, replace with an oversized [0.5 mm (0.020 in)] valve seat.

1. Bore out old seat until it collapses. Boring should not continue beyond the bottom face of the seat recess in the cylinder head. Set the machine depth stop to ensure this.
2. Ream cylinder head recess diameter for service valve seat.

Intake : 37.000 - 37.016 mm (1.4567 - 1.4573 in)

Exhaust : 32.000 - 32.016 mm (1.2598 - 1.2605 in)


- Be sure to ream in circles concentric to the valve guide center. This will enable the valve seat to fit correctly.



CYLINDER HEAD

[QR25DE]

- Heat cylinder head to 110° to 130°C (230° to 266°F) by soaking in heated oil.




- Use valve seats cooled well with dry ice. Force fit valve seat into cylinder head.

CAUTION:
Avoid directly touching the cold valve seats.

- Finish the seat to the specified dimensions using suitable tool.

CAUTION:
When using valve seat cutter, firmly grip the cutter handle with both hands. Then, press on the contacting surface all around the circumference to cut in a single drive. Improper pressure on the cutter or cutting many different times may result in a defective valve seat.




- Using compound, grind to adjust valve fitting.
- Check again for normal contact.

VALVE SPRING SQUARENESS

Set try square along the side of the valve spring and rotate the spring. Measure the maximum clearance between the top face of the spring and the try square.


Limit : 1.9 mm (0.0748 in)



VALVE SPRING DIMENSIONS AND VALVE SPRING PRESSURE LOAD

Check valve spring pressure with valve spring seat installed at specified spring height. Replace if not within specifications.

CAUTION:
Do not remove the valve spring seat.



CYLINDER HEAD


[QR25DE]

Valve Spring Specifications

Specifications	Intake	Exhaust
Identification color	Pink	Green
Free height	43.72 - 43.92 mm (1.7213 - 1.7291 in)	45.29 - 45.49 mm (1.7831 - 1.7909 in)
Installation height	35.30 mm (1.390 in)	35.30 mm (1.390 in)
Installation load	151 - 175 N (15.4 - 17.8 kg-f, 34 - 39 lb-f)	151 - 175 N (15.4 - 17.8 kg-f, 34 - 39 lb-f)
Height during valve open	25.3 mm (0.996 in)	26.76 mm (1.0535 in)
Load with valve open	351 - 394 N (35.8 - 40.2 kg-f, 79 - 89 lb-f)	318 - 362 N (32.4 - 36.9 kg-f, 71 - 81 lb-f)

ENGINE ASSEMBLY Removal and Installation

SEC. 112



WBIA0894E

- | | | |
|---|--|---------------------------------------|
| 1. LH transaxle mounting insulator (CVT) | 2. LH transaxle mounting bracket | 3. Transaxle mounting insulator (M/T) |
| 4. RH engine mounting insulator | 5. Rear engine mounting insulator (orient by direction mark) | 6. Front suspension member |
| 7. Front engine mounting insulator (orient by direction mark) | | |

WARNING:

- Place chocks at the front and back of the rear wheels.
- For engines not equipped with slingers, attach proper slingers and bolts as described in the parts catalog.

CAUTION:

- Do not start working until the exhaust system and coolant are cool.

A
EM
C
D
E
F
G
H
I
J
K
L
M

- If items or work required are not covered by the engine main body section, refer to the applicable sections.
- Use the correct supporting points for lifting and jacking. Refer to [GI-40, "LIFTING POINT"](#) .
- In removing the drive shaft, be careful not to damage the grease seals on the transaxle.
- Before separating the engine and transaxle, remove the crankshaft position sensor (POS) from the assembly.
- Be sure not to damage the edge of the crankshaft position sensor (POS) or the ring gear teeth.


REMOVAL

1. Release fuel pressure. Refer to [EC-633, "FUEL PRESSURE RELEASE"](#) .
2. Disconnect the fuel rail at the fuel hose quick connector (engine side). Refer to [EM-132, "INTAKE MANIFOLD"](#) .
3. Drain the engine oil. Refer to [LU-16, "Changing Engine Oil"](#) .
4. Drain the engine coolant. Refer to [CO-34, "DRAINING ENGINE COOLANT"](#) .
5. Remove the engine hood assembly. Refer to [BL-15, "Removal"](#) .
6. Remove cowl extension. Refer to [EI-19, "REMOVAL"](#) .
7. Remove the battery, battery hold downs, and battery tray.
8. Disconnect the MAF sensor electrical connector.
9. Remove the air duct and air cleaner case assembly. Refer to [EM-130, "REMOVAL"](#) .
10. Disconnect the heater hoses.
11. Remove engine cover using power tool.
12. Remove the engine coolant reservoir tank, radiator and radiator fan assembly. Refer to [CO-37, "Removal and Installation"](#) .
13. Disconnect and set aside the IPDM/ER and remove the IPDM/ER bracket. Refer to [PG-30, "REMOVAL"](#) .
14. Remove the generator. Refer to [SC-33, "REMOVAL"](#) .
15. Remove the engine under covers and splash shield using power tool.
16. Dismount the A/C compressor with piping connected and secure with wire to the radiator support.
17. Disconnect the engine wiring harness retainers and ground strap.
18. Remove clutch operating cylinder from transaxle, and move it aside (M/T models).
19. Disconnect the transaxle shift controls.
20. Remove front exhaust tube. Refer to [EX-5, "REMOVAL"](#) .
21. Remove the left and right drive shafts. Refer to [FAX-8, "REMOVAL"](#) and [FAX-10, "REMOVAL"](#) .
22. Remove the front suspension member. Refer to [FSU-10, "REMOVAL"](#) .
23. Install engine slingers into front left cylinder head and rear right cylinder head.

- Use alternator bracket bolt holes for the front slinger.
- Use the proper slingers and bolts as described in the Parts Catalog.

Slinger bolts - front (B) : 48 N·m (4.9 kg·m, 35 ft·lb)

Slinger bolts - rear (A) : 28 N·m (2.8 kg·m, 21 ft·lb)



24. Support engine and transaxle assembly with engine lifting equipment from the top with the vehicle raised on a hoist.
25. Remove RH engine mounting insulator and bracket.
26. Remove LH transaxle mounting insulator through-bolts.
27. Lower the engine and transaxle assembly from the engine compartment using Tool.

CAUTION:

- Before and during this procedure, always check if any harnesses are left connected.
- Avoid any damage to, or any oil/grease smearing or spills onto the engine mounting insulators.

Tool number : — (J-47242)

- 28. Remove the starter motor. Refer to [SC-24, "REMOVAL"](#) .
- 29. Separate engine and transaxle.

INSTALLATION

Combine enging and transaxle assembly. Refer to [CVT-208, "INSTALLATION"](#) CVT, [MT-66, "INSTALLATION"](#) or [MT-142, "INSTALLATION"](#) M/T.

Installation is in the reverse order of removal.

- Do not allow oil to get on mounting insulators. Be careful not to damage mounting insulators.
- If parts have a direction mark (arrow) this indicates front of the vehicle, and the parts must be installed according to the identification mark.

INSPECTION AFTER INSTALLATION

- Before starting engine, check oil/fluid levels including engine coolant and engine oil. If less than required quantity, fill to the specified level. Refer to [MA-14, "RECOMMENDED FLUIDS AND LUBRICANTS"](#) .
- Use procedure below to check for fuel leakage.
- Turn ignition switch ON (with engine stopped). With fuel pressure applied to fuel piping, check for fuel leakage at connection points.
- Start engine. With engine speed increased, check again for fuel leakage at connection points.
- Run engine to check for unusual noise and vibration.
- Warm up engine thoroughly to make sure there is no leakage of fuel, exhaust gas, or any oils/fluids including engine oil and engine coolant.
- Bleed air from passages in lines and hoses, such as in cooling system.
- After cooling down engine, again check oils/fluids including engine oil and engine coolant. Refill to specified level, if necessary.
- Summary of the inspection items:

Item	Before starting engine	Engine running	After engine stopped
Engine coolant	Level	Leakage	Level
Engine oil	Level	Leakage	Level
Other oils and fluids*	Level	Leakage	Level
Fuel	Leakage	Leakage	Leakage
Exhaust gas	—	Leakage	—

*Transmission/transaxle/CVT fluid, power steering fluid, brake fluid, etc.

CYLINDER BLOCK

[QR25DE]


PF9:11010

EBS00Z90

CYLINDER BLOCK

Disassembly and Assembly

SEC.110 • 120 • 221 • 226



WBIA0897E

- | | | |
|---|--------------------------------|-------------------------------------|
| 1. Cylinder block | 2. O-ring | 3. Crankshaft position sensor (POS) |
| 4. Knock sensor | 5. Oil pressure switch | 6. Lower cylinder block |
| 7. Lower cylinder block bolt | 8. Snap ring | 9. Connecting rod |
| 10. Connecting rod bearing | 11. Connecting rod bearing cap | 12. Connecting rod bearing cap bolt |
| 13. Piston | 14. Oil ring | 15. Second ring |
| 16. Top ring | 17. Piston pin | 18. Main thrust bearing |
| 19. Main bearing upper | 20. Crankshaft | 21. Main bearing lower |
| 22. Crankshaft rear oil seal | 23. Pilot converter (CVT only) | 24. Crankshaft signal plate |
| 25. Drive plate (CVT) | 26. Reinforcement plate (CVT) | 27. Flywheel (M/T) |
| 28. Cylinder block heater (if equipped) | A. Refer to text. | |

CAUTION:

Apply new engine oil to parts marked in illustration before installation.

DISASSEMBLY

1. Remove the engine and transaxle as an assembly from the vehicle, and separate the transaxle from the engine. Refer to [EM-181, "Removal and Installation"](#).
2. Mount the engine on a suitable engine stand.
3. Drain any remaining engine oil and coolant from the engine.
4. Remove the following components and associated parts.
 - Exhaust manifold and three way catalyst assembly. Refer to [EM-136, "Removal and Installation"](#).
 - Intake manifold collector. Refer to [EM-132, "Removal and Installation"](#).
 - Intake manifold and fuel tube assembly. Refer to [EM-132, "Removal and Installation"](#).
 - Ignition coils. Refer to [EM-141, "Removal and Installation"](#).
 - Rocker cover. Refer to [EM-147, "Removal and Installation"](#).
 - Front cover, timing chain, and balancer unit. Refer to [EM-160, "Removal and Installation"](#).
 - Cylinder head. Refer to [EM-172, "Removal and Installation"](#).
5. Remove the knock sensor.


CAUTION:

Carefully handle the sensor and do not drop the sensor.

6. Remove crankshaft position sensor (POS).

CAUTION:

- Avoid impacts such as a dropping.
- Do not disassemble.
- Keep it away from metal particles.
- Do not place sensor close to magnetic materials.




7. Remove the flywheel (M/T models) or drive plate (CVT models). Hold the crankshaft with a stopper plate and use a suitable tool to remove the bolts.

CAUTION:


- Be careful not to damage the flywheel contact surface for the clutch disc.

NOTE:

- The flywheel two-block construction allows movement in response to transmission side pressure, or when twisted in its rotational direction, therefore, some amount of noise is normal.



8. Remove pilot converter using Tool (CVT models).




CYLINDER BLOCK

[QR25DE]

9. Remove the piston and connecting rod assemblies.
 - a. Position the crankshaft and corresponding connecting rod, to be removed, to the bottom dead center stroke.
 - b. Remove the connecting rod cap. Number the cap so it can be assembled in the same position.
 - c. Using a hammer handle or similar tool, push the piston and connecting rod assembly out of the top of the cylinder block. Number the piston and rod so it can be assembled in the same position.

- Before removing the piston and connecting rod assembly, check the connecting rod side clearance. Refer to [EM-199, "CONNECTING ROD SIDE CLEARANCE"](#).



10. Remove the connecting rod bearings. If reusing, number them so they can be assembled in the same position and direction.

CAUTION:


- When removing them, note the installation position. Keep them in the correct order.

11. Remove the piston rings from the piston.

- Use a piston ring expander.


CAUTION:

- When removing the piston rings, be careful not to damage the piston.
- Be careful not to damage piston rings by expanding them excessively, if reusing them.
- Before removing the piston rings, check the piston ring side clearance. Refer to [EM-200, "PISTON RING SIDE CLEARANCE"](#).




12. Remove the piston from the connecting rod as follows.

- a. Using a snap ring pliers, remove the two snap rings.




- b. Heat the piston to 60° - 70°C (140° - 158°F) with a heat gun, or equivalent.



CYLINDER BLOCK


[QR25DE]

- c. Push out piston pin with a punch of an outer diameter of approximately 19 mm (0.75 in).



13. Remove the lower cylinder block bolts.

- Before loosening the lower cylinder block bolts, measure the crankshaft side clearance. Refer to [EM-198, "CRANKSHAFT SIDE CLEARANCE"](#).
- Loosen them in the order as shown to remove them.



14. Remove the lower cylinder block.

- Cut the Silicone RTV Sealant and remove the lower cylinder block from the cylinder block, using Tool.
Seal cutter [KV10111100 \(J-37228\)](#)

CAUTION:

Be careful not to damage the mounting surface.

15. Remove the crankshaft.

CAUTION:

- Do not damage or deform the signal plate while mounted on the crankshaft.
- When setting the crankshaft on a flat surface, use a block of wood to avoid interference between the signal plate and the surface.
- Do not remove signal plate unless it is necessary.

16. Pull the rear oil seal out of the rear end of the crankshaft.

CAUTION:

Do not to damage the crankshaft or cylinder block when removing the rear oil seal.


NOTE:

When replacing the rear oil seal without removing the cylinder block, use a screwdriver to pull it out from between crankshaft and block.

17. Remove the main bearings and thrust bearings from the cylinder block and lower cylinder block.

CAUTION:

Identify and number the bearings, if reusing them, so that they are assembled in the same position and direction.



ASSEMBLY

1. Using compressed air, clean out the coolant and oil passages in the cylinder block, the cylinder bore and the crankcase to remove any foreign material.

CAUTION:


Use approved safety glasses to protect your eyes.

CYLINDER BLOCK

[QR25DE]


2. Install the drain plugs on the cylinder block.

- Apply Silicone RTV Sealant.
Use Genuine Silicone RTV Sealant, or equivalent. Refer to GI-44, "Recommended Chemical Products and Sealants".
- Replace the copper washers with new ones.




3. Install the main bearings and the thrust bearings.

- Remove dust, dirt, and oil from the bearing mating surfaces of the cylinder block and lower cylinder block.
- Install the thrust bearings to both sides of the No. 3 main bearing journal on the cylinder block.
 - Install the thrust bearings with the oil groove facing the crankshaft arm (outside).



- Install the main bearings paying attention to their position and direction.

- The main bearing with an oil hole and groove goes on the cylinder block. The one without them goes on the lower cylinder block.
- Only the main bearing (on the cylinder block) for No. 3 journal has different specifications.
- Before installing the bearings, apply engine oil to the bearing friction surface (inside). Do not apply oil to the back surface, but thoroughly clean it.
- When installing, align the bearing stopper to the notch.
- Make sure that the oil holes on the cylinder block and those on the corresponding bearing are aligned.



4. Install the signal plate to the crankshaft.

- Position the crankshaft and signal plate using a positioning dowel pin, and tighten the bolts to specification.
- Remove the dowel pin.

CAUTION:


Be sure to remove dowel pin before installing the crankshaft.

NOTE:

Dowel pins for the crankshaft and signal plate are supplied as a set for each.

5. Install the crankshaft onto the cylinder block.

- While turning the crankshaft by hand, check that it turns smoothly.



CYLINDER BLOCK

[QR25DE]

6. Install the lower cylinder block.


- Apply Silicone RTV Sealant to positions as shown.
- Use Genuine Silicone RTV Sealant, or equivalent. Refer to [GI-44, "Recommended Chemical Products and Sealants"](#).

NOTE:

Cylinder block and lower cylinder block are machined together. Neither of them can be replaced separately.

CAUTION:


After the Silicone RTV Sealant is applied, the lower cylinder block installation must be finished within 5 minutes.



7. Tighten lower cylinder block bolts in the numerical order as shown and according to the following steps:

- Apply new engine oil to threads and seat surfaces of the bolts.
- Tighten bolts No. 11 - 22 only in the order as shown, to specification below.

Step 1, bolts 11 - 22 only : 25.1 N·m (2.6 kg·m, 19 ft·lb)



c. Tighten bolts No. 1 - 10 only in the order as shown, to specification below.

Step 2, bolts 1 - 10 only : 39.2 N·m (4.0 kg·m, 29 ft·lb)

d. Tighten bolts No. 1 - 10 only in the order as shown, to specification below.


CAUTION:

Check tightening angle. Do not make judgment by visual inspection.

Tool number : KV 10112100 (BT-8653-A)


Step 3, bolts 1 - 10 only : 60° degrees rotation

- Wipe off completely any protruding Silicone RTV Sealant on the exterior of engine.
- Check crankshaft side clearance. Refer to [EM-198, "CRANK-SHAFT SIDE CLEARANCE"](#).
- After installing the bolts, make sure that the crankshaft can be rotated smoothly by hand.



8. Install the rear oil seal.


- Press the oil seal between cylinder block and crankshaft with a suitable drift.
- Be careful not to touch the grease on the oil seal lip.
- Be careful not to cause scratches or burrs when pressing in the rear oil seal.




CYLINDER BLOCK

[QR25DE]

- Press in rear oil seal to the position as shown.



9. Install the piston to the connecting rod. Assemble the components in their original positions.
- a. Using a snap ring pliers, install the snap ring to the grooves of the piston's rear side.
- Insert the piston pin snap ring fully into groove.
- b. Install the piston to the connecting rod.
- Using a heat gun, heat the piston [approximately 60° - 70 C° (140° - 158 °F)] until the piston pin can be pushed in by hand without excessive force. From the front to the rear, insert the piston pin into the piston and the connecting rod.
 - Assemble so that the front mark on the piston crown and the oil holes and the cylinder No. on the connecting rod are positioned as shown.
- c. Install the piston pin snap ring into the front of the piston.
- Check that the connecting rod moves smoothly.




10. Using a piston ring expander, install the piston rings. Assemble the components in their original positions.

CAUTION:

Be careful not to damage the piston.


- Position each ring with the gap as shown, referencing the piston front mark as the starting point.
- Install the top ring and the second ring with the stamped surface facing upward.

Stamped mark : 1K (top ring)
: 2K (second ring)



11. Install the connecting rod bearings to the connecting rod and the connecting rod cap. Assemble the components in their original positions.


- When installing the connecting rod bearings, apply engine oil to the bearing friction surface (inside). Do not apply oil to the back surface, but thoroughly clean the back.
- When installing, align the connecting rod bearing stopper protrusion with the notch of the connecting rod to install.
- Check the oil holes on the connecting rod and those on the corresponding bearing are aligned.



12. Install the piston and connecting rod assembly to the crankshaft. Assemble the components in their original positions.

Tool number : EM03470000

- Rotate the crankshaft so the pin corresponding to the connecting rod to be installed is at the bottom dead center position.
- Apply engine oil sufficiently to the cylinder bore, piston, and crankshaft pin.
- Match the cylinder position number with the cylinder No. on the connecting rod for installation.
- Using tool as shown, install the piston with the front mark on the piston crown facing the front of the engine.




CAUTION:

Be careful not to damage the crankshaft pin, resulting from an interference of the connecting rod big end.

13. Install the connecting rod caps. Assemble the components in their original positions.

- Match the stamped cylinder number marks on the connecting rod with those on the cap to install.



14. Tighten the connecting rod bolt as follows:


Apply engine oil to the threads and seats of the connecting rod bolts.

CAUTION:

Check tightening angle. Do not make judgment by visual inspection.

Tool number : KV10112100 (BT-8653-A)


- Step 1 : 27.4 N·m (2.8 kg-m, 20 ft-lb)**
- Step 2 : 0 N·m**
- Step 3 : 19.6 N·m (2.0 kg-m, 14 ft-lb)**
- Stage 2 : Rotate bolts 90° degrees**



- Check the connecting rod side clearance. Refer to [EM-199, "CONNECTING ROD SIDE CLEARANCE"](#)
- After tightening the bolts, make sure that the crankshaft rotates smoothly.

15. Install flywheel (M/T Models), or drive plate (CVT Models).

- Install drive plate, reinforcement plate and pilot converter as shown.
- Using a drift with 33 mm (1.30 in) diameter, push pilot converter into the end of the crankshaft.



CYLINDER BLOCK


[QR25DE]

16. Install the knock sensor.

- Make sure that there is no foreign material on the cylinder block mating surface and the back surface of the knock sensor.
- Install the knock sensor with the connector facing lower left by 45° as shown.
- Do not tighten the bolts while holding the connector.
- Make sure that the knock sensor does not interfere with other parts.

CAUTION:

If the knock sensor is dropped, replace it with new one.



17. Install the crankshaft position sensor (POS).

18. Installation of remaining components is in the reverse order of removal.

How to Select Piston and Bearing DESCRIPTION

EBS00Z91

Selection points	Selection parts	Selection items	Selection methods
Between cylinder block to crankshaft	Main bearing	Main bearing grade (bearing thickness)	Determined by match of cylinder block bearing housing grade (inner diameter of housing) and crankshaft journal grade (outer diameter of journal)
Between crankshaft to connecting rod	Connecting rod bearing	Connecting rod bearing grade (bearing thickness)	Combining service grades for connecting rod big end inner diameter and crankshaft pin outer diameter determine connecting rod bearing selection
Between cylinder block to piston	Piston and piston pin assembly (The piston is available together with piston pin as an assembly)	Piston grade (piston outer diameter)	Piston grade = cylinder bore grade (inner diameter of bore)
*Between piston to connecting rod	—	—	—


*For the service parts, the grade for fitting cannot be selected between a piston pin and a connecting rod. (Only 0 grade is available.) The information at the shipment from the plant is described as a reference.

- The identification grade stamped on each part is the grade for the dimension measured in new condition. This grade cannot apply to reused parts.
- For reused or repaired parts, measure the dimension accurately. Determine the grade by comparing the measurement with the values of each selection table.
- For details of the measurement method of each part, the reuse standards, and the selection method of the selective fitting parts, refer to the text.

HOW TO SELECT A PISTON


When New Cylinder Block is Used:

- Check the cylinder bore grade on rear left side of cylinder block, and select a piston of the same grade.
- If there is a corrected stamp mark on the cylinder block, use it as a correct reference.



CYLINDER BLOCK

[QR25DE]



When a Cylinder Block is Reused:

1. Measure the cylinder block bore inner diameter.
2. Determine the bore grade by comparing the measurement with the values under the cylinder bore inner diameter of the "Piston Selection Table". Select the piston of the same grade.

Piston Selection Table

Unit: mm (in)

Grade number (Mark)	2 (or no mark)	3
Inner diameter of cylinder bore	89.010-89.020 (3.5043-3.5047)	89.020-89.030 (3.5047-3.5051)
Outer diameter of piston skirt	88.990-89.000 (3.5035-3.5039)	89.000-89.010 (3.5039-3.5043)


NOTE:

- The piston is available together with piston pin as an assembly.
- The piston pin (piston pin bore) grade is provided only for the parts installed at the plant. For service parts, no grades can be selected. Only 0 grade is available.


HOW TO SELECT A CONNECTING ROD BEARING

When New Connecting Rod and Crankshaft are Used:

1. Apply big end inside diameter grade stamped on connecting rod side face to the row in the "Connecting Rod Bearing Selection Table".



2. Apply pin diameter grade stamped on crankshaft front side to the column in the "Connecting Rod Bearing Selection Table".
3. Read the symbol at the cross point of selected row and column in the "Connecting Rod Bearing Selection Table".
4. Apply the symbol obtained to connecting rod bearing grade table to select.
 - A: Journal diameter
 - B: Pin diameter



When Crankshaft and Connecting Rod are Reused:

1. Measure dimensions of the big end inner diameter of connecting rod and outer diameter of crankshaft pin individually.
2. Apply the dimension measured to the "Connecting Rod Bearing Selection Table" below.

CYLINDER BLOCK

[QR25DE]

Connecting Rod Bearing Selection Table

Connecting rod big end diameter		Mark												
		0	1	2	3	4	5	6	7	8	9	A	B	C
Crankshaft pin journal diameter		Inner diameter Unit: mm (in)												
		48.000 - 48.001 (1.8898 - 1.8898)	48.001 - 48.002 (1.8898 - 1.8898)	48.002 - 48.003 (1.8898 - 1.8899)	48.003 - 48.004 (1.8899 - 1.8899)	48.004 - 48.005 (1.8899 - 1.8900)	48.005 - 48.006 (1.8900 - 1.8900)	48.006 - 48.007 (1.8900 - 1.8900)	48.007 - 48.008 (1.8900 - 1.8901)	48.008 - 48.009 (1.8901 - 1.8901)	48.009 - 48.010 (1.8901 - 1.8902)	48.010 - 48.011 (1.8902 - 1.8902)	48.011 - 48.012 (1.8902 - 1.8902)	48.012 - 48.013 (1.8902 - 1.8903)
Mark	Outer diameter Unit: mm (in)													
A	44.974 - 44.973 (1.7706 - 1.7706)	0	0	0	0	01	01	01	1	1	1	12	12	12
B	44.973 - 44.972 (1.7706 - 1.7705)	0	0	0	01	01	01	1	1	1	12	12	12	2
C	44.972 - 44.971 (1.7705 - 1.7705)	0	0	01	01	01	1	1	1	12	12	12	2	2
D	44.971 - 44.970 (1.7705 - 1.7705)	0	01	01	01	1	1	1	12	12	12	2	2	2
E	44.970 - 44.969 (1.7705 - 1.7704)	01	01	01	1	1	1	12	12	12	2	2	2	23
F	44.969 - 44.968 (1.7704 - 1.7704)	01	01	1	1	1	12	12	12	2	2	2	23	23
G	44.968 - 44.967 (1.7704 - 1.7704)	01	1	1	1	12	12	12	2	2	2	23	23	23
H	44.967 - 44.966 (1.7704 - 1.7703)	1	1	1	12	12	12	2	2	2	23	23	23	3
J	44.966 - 44.965 (1.7703 - 1.7703)	1	1	12	12	12	2	2	2	23	23	23	3	3
K	44.965 - 44.964 (1.7703 - 1.7702)	1	12	12	12	2	2	2	23	23	23	3	3	3
L	44.964 - 44.963 (1.7702 - 1.7702)	12	12	12	2	2	2	23	23	23	3	3	3	34
M	44.963 - 44.962 (1.7702 - 1.7701)	12	12	2	2	2	23	23	23	3	3	3	34	34
N	44.962 - 44.961 (1.7702 - 1.7701)	12	2	2	2	23	23	23	3	3	3	34	34	34
P	44.961 - 44.960 (1.7701 - 1.7701)	2	2	2	23	23	23	3	3	3	34	34	34	4
R	44.960 - 44.959 (1.7701 - 1.7700)	2	2	23	23	23	3	3	3	34	34	34	4	4
S	44.959 - 44.958 (1.7700 - 1.7700)	2	23	23	23	3	3	3	34	34	34	4	4	4
T	44.958 - 44.957 (1.7700 - 1.7700)	23	23	23	3	3	3	34	34	34	4	4	4	4
U	44.957 - 44.956 (1.7700 - 1.7699)	23	23	3	3	3	34	34	34	4	4	4	4	4

WBIA0838E

Connecting Rod Bearing Grade Table

Unit: mm (in)

Grade number	0	1	2	3	4
Thickness	1.496 - 1.493 (0.0589 - 0.0588)	1.499 - 1.496 (0.0590 - 0.0589)	1.502 - 1.499 (0.0591 - 0.0590)	1.505 - 1.502 (0.0593 - 0.0591)	1.508 - 1.505 (0.0594 - 0.0593)
Identification color	Black	Brown	Green	Yellow	Blue

Undersize Bearing Usage Guide

- When the specified oil clearance is not obtained with standard size connecting rod bearing, use undersize (US) bearing.
- When using undersize bearing, measure the bearing inner diameter with bearing installed, and grind the crankshaft pin so that the oil clearance satisfies the standard.

CYLINDER BLOCK

[QR25DE]


Bearing Undersize Table

Unit: mm (in)

Size U.S.	Thickness
0.25 (0.0098)	1.622 - 1.630 (0.0639 - 0.0642)

CAUTION:


In grinding the crankshaft pin to use undersize bearings, do not damage the fillet R (All crankshaft pins).




HOW TO SELECT A MAIN BEARING

When New Cylinder Block and Crankshaft are Used:

- "Main Bearing Selection Table" rows correspond to bearing housing grade on rear left side of cylinder block.
 - If there is a corrected stamp mark on the cylinder block, use it as a correct reference.



- Apply journal diameter grade stamped on crankshaft front side to column in "Main Bearing Selection Table".



- Find value at crossing of row and column in "Main Bearing Selection Table".

CAUTION:

- There are two main bearing selection tables. One is for odd-numbered journals (1, 3, and 5) and the other is for even-numbered journals (2 and 4). Make certain to use the appropriate table. This is due to differences in the specified clearances.

- Apply the symbol obtained to "Main Bearing Grade Table" to select.

NOTE:

- Service parts are available as a set of both upper and lower.

When Cylinder Block and Crankshaft are Reused:

- Measure inner diameter of cylinder block main bearing housing and outer diameter of crankshaft journal.
- Apply measurement in above step 1 to the "Main Bearing Selection Table".
- Follow steps 3 and 4 in "When New Cylinder Block and Crankshaft are Used".

CYLINDER BLOCK

[QR25DE]

Main Bearing Selection Table (No.1, 3, and No.5 journals)

Crankshaft journal outer diameter / Cylinder block main bearing housing inner diameter		Mark																													
		A	B	C	D	E	F	G	H	J	K	L	M	N	P	R	S	T	U	V	W	X	Y	4	7	Inner diameter Unit: mm (in)					
Mark	Outer diameter Unit: mm (in)																														
		58.944 - 58.945 (2.3206 - 2.3207)	58.945 - 58.946 (2.3207 - 2.3207)	58.946 - 58.947 (2.3207 - 2.3207)	58.947 - 58.948 (2.3207 - 2.3208)	58.948 - 58.949 (2.3208 - 2.3208)	58.949 - 58.950 (2.3208 - 2.3209)	58.950 - 58.951 (2.3209 - 2.3209)	58.951 - 58.952 (2.3209 - 2.3209)	58.952 - 58.953 (2.3209 - 2.3210)	58.953 - 58.954 (2.3210 - 2.3210)	58.954 - 58.955 (2.3210 - 2.3211)	58.955 - 58.956 (2.3211 - 2.3211)	58.956 - 58.957 (2.3211 - 2.3211)	58.957 - 58.958 (2.3211 - 2.3212)	58.958 - 58.959 (2.3212 - 2.3212)	58.959 - 58.960 (2.3212 - 2.3213)	58.960 - 58.961 (2.3213 - 2.3213)	58.961 - 58.962 (2.3213 - 2.3213)	58.962 - 58.963 (2.3213 - 2.3214)	58.963 - 58.964 (2.3214 - 2.3214)	58.964 - 58.965 (2.3214 - 2.3215)	58.965 - 58.966 (2.3215 - 2.3215)	58.966 - 58.967 (2.3215 - 2.3215)	58.967 - 58.968 (2.3215 - 2.3216)						
A	54.979 - 54.978 (2.1645 - 2.1645)	0	0	01	01	01	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	4			
B	54.978 - 54.977 (2.1645 - 2.1644)	0	01	01	01	1	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	4			
C	54.977 - 54.976 (2.1644 - 2.1644)	01	01	01	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	3	34	34	34	4	4	4	4				
D	54.976 - 54.975 (2.1644 - 2.1644)	01	01	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	3	34	34	34	4	4	4	4	45				
E	54.975 - 54.974 (2.1644 - 2.1643)	01	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	3	34	34	34	4	4	4	4	45	45				
F	54.974 - 54.973 (2.1643 - 2.1643)	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	4	4	45	45	45				
G	54.973 - 54.972 (2.1643 - 2.1642)	1	1	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	4	4	45	45	45	5				
H	54.972 - 54.971 (2.1642 - 2.1642)	1	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	4	45	45	45	5	5	5				
J	54.971 - 54.970 (2.1642 - 2.1642)	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	4	45	45	45	5	5	5					
K	54.970 - 54.969 (2.1642 - 2.1641)	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	4	45	45	45	5	5	5	56					
L	54.969 - 54.968 (2.1641 - 2.1641)	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	4	45	45	45	5	5	5	56	56					
M	54.968 - 54.967 (2.1641 - 2.1641)	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	45	45	45	5	5	5	56	56	56	6					
N	54.967 - 54.966 (2.1641 - 2.1640)	2	2	23	23	23	3	3	3	34	34	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6					
P	54.966 - 54.965 (2.1640 - 2.1640)	2	23	23	23	3	3	3	34	34	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6	6					
R	54.965 - 54.964 (2.1640 - 2.1639)	23	23	23	3	3	3	34	34	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6	6	6					
S	54.964 - 54.963 (2.1639 - 2.1639)	23	23	3	3	3	34	34	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6	6	6	6	67				
T	54.963 - 54.962 (2.1639 - 2.1639)	23	3	3	3	34	34	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6	6	6	6	67	67				
U	54.962 - 54.961 (2.1639 - 2.1638)	3	3	3	34	34	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6	6	6	6	67	67	67				
V	54.961 - 54.960 (2.1638 - 2.1638)	3	3	34	34	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6	6	6	6	6	67	67	67	7			
W	54.960 - 54.959 (2.1638 - 2.1637)	3	34	34	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6	6	6	6	6	67	67	67	7	7			
X	54.959 - 54.958 (2.1637 - 2.1637)	34	34	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6	6	6	67	67	67	7	7	7	7				
Y	54.958 - 54.957 (2.1637 - 2.1637)	34	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6	6	6	67	67	67	7	7	7	7	7				
4	54.957 - 54.956 (2.1637 - 2.1636)	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6	6	6	67	67	67	7	7	7	7	7	7				
7	54.956 - 54.955 (2.1636 - 2.1636)	4	4	4	45	45	45	5	5	5	56	56	56	6	6	6	6	67	67	67	7	7	7	7	7	7	7				

KBIA0149E

CYLINDER BLOCK

[QR25DE]

Main Bearing Selection Table (No.2,and 4 journals)

Cylinder block main bearing housing inner diameter	Crankshaft journal outer diameter	Mark	Mark		A	B	C	D	E	F	G	H	J	K	L	M	N	P	R	S	T	U	V	W	X	Y	4	7
			Outer diameter Unit: mm (in)	Inner diameter Unit: mm (in)	58.944 - 58.945 (2.3206 - 2.3207)	58.945 - 58.946 (2.3207 - 2.3207)	58.946 - 58.947 (2.3207 - 2.3207)	58.947 - 58.948 (2.3207 - 2.3208)	58.948 - 58.949 (2.3208 - 2.3208)	58.949 - 58.950 (2.3208 - 2.3209)	58.950 - 58.951 (2.3209 - 2.3209)	58.951 - 58.952 (2.3209 - 2.3209)	58.952 - 58.953 (2.3209 - 2.3210)	58.953 - 58.954 (2.3210 - 2.3210)	58.954 - 58.955 (2.3210 - 2.3211)	58.955 - 58.956 (2.3211 - 2.3211)	58.956 - 58.957 (2.3211 - 2.3211)	58.957 - 58.958 (2.3211 - 2.3212)	58.958 - 58.959 (2.3212 - 2.3212)	58.959 - 58.960 (2.3212 - 2.3213)	58.960 - 58.961 (2.3213 - 2.3213)	58.961 - 58.962 (2.3213 - 2.3213)	58.962 - 58.963 (2.3213 - 2.3214)	58.963 - 58.964 (2.3214 - 2.3214)	58.964 - 58.965 (2.3214 - 2.3215)	58.965 - 58.966 (2.3215 - 2.3215)	58.966 - 58.967 (2.3215 - 2.3215)	58.967 - 58.968 (2.3215 - 2.3216)
A	54.979 - 54.978 (2.1645 - 2.1645)	0	0	0	0	0	0	0	0	0	0	0	01	01	01	1	1	1	12	12	12	2	2	2	23	23	23	3
B	54.978 - 54.977 (2.1645 - 2.1644)	0	0	0	0	0	0	0	0	0	0	01	01	01	1	1	1	12	12	12	2	2	2	23	23	23	3	3
C	54.977 - 54.976 (2.1644 - 2.1644)	0	0	0	0	0	0	0	0	01	01	01	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	3
D	54.976 - 54.975 (2.1644 - 2.1644)	0	0	0	0	0	0	01	01	01	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	3	3	34
E	54.975 - 54.974 (2.1644 - 2.1643)	0	0	0	0	01	01	01	1	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	3	3	34	34
F	54.974 - 54.973 (2.1643 - 2.1643)	0	0	0	01	01	01	1	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	3	3	34	34	34
G	54.973 - 54.972 (2.1643 - 2.1642)	0	0	01	01	01	1	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	3	34	34	34	4	4
H	54.972 - 54.971 (2.1642 - 2.1642)	0	01	01	01	1	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	3	34	34	34	4	4	4
J	54.971 - 54.970 (2.1642 - 2.1642)	01	01	01	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	4	4	4
K	54.970 - 54.969 (2.1642 - 2.1641)	01	01	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	4	4	4	45
L	54.969 - 54.968 (2.1641 - 2.1641)	01	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	4	4	4	4	45
M	54.968 - 54.967 (2.1641 - 2.1641)	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	4	4	4	4	45	45
N	54.967 - 54.966 (2.1641 - 2.1640)	1	1	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	4	4	4	4	45	45	5
P	54.966 - 54.965 (2.1640 - 2.1640)	1	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	4	4	4	45	45	45	5	5
R	54.965 - 54.964 (2.1640 - 2.1639)	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	4	4	45	45	45	5	5	5	5
S	54.964 - 54.963 (2.1639 - 2.1639)	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	4	45	45	45	5	5	5	5	5	56
T	54.963 - 54.962 (2.1639 - 2.1639)	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	4	45	45	45	5	5	5	5	5	5	56
U	54.962 - 54.961 (2.1639 - 2.1638)	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	4	45	45	45	5	5	5	5	5	5	5	56
V	54.961 - 54.960 (2.1638 - 2.1638)	2	2	23	23	23	3	3	3	34	34	34	4	4	4	4	45	45	45	5	5	5	5	5	5	5	5	56
W	54.960 - 54.959 (2.1638 - 2.1637)	2	23	23	23	3	3	3	34	34	34	4	4	4	4	45	45	45	5	5	5	5	5	5	5	5	5	56
X	54.959 - 54.958 (2.1637 - 2.1637)	23	23	23	3	3	3	34	34	34	4	4	4	4	45	45	45	5	5	5	5	5	5	5	5	5	5	56
Y	54.958 - 54.957 (2.1637 - 2.1637)	23	23	3	3	3	34	34	34	4	4	4	4	45	45	45	5	5	5	5	5	5	5	5	5	5	5	56
4	54.957 - 54.956 (2.1637 - 2.1636)	23	3	3	3	34	34	34	4	4	4	4	4	45	45	45	5	5	5	5	5	5	5	5	5	5	5	56
7	54.956 - 54.955 (2.1636 - 2.1636)	3	3	3	34	34	34	4	4	4	4	4	4	45	45	45	5	5	5	5	5	5	5	5	5	5	5	56

KBIA0150E

Main Bearing Grade Table (All Journals)

Unit: mm (in)

Grade number	Thickness	Identification color (UPR / LWR)	Remarks
0	1.973 - 1.976 (0.0777 - 0.0778)	Black	Grade and color are the same for upper and lower bearings.
1	1.976 - 1.979 (0.0778 - 0.0779)	Brown	
2	1.979 - 1.982 (0.0779 - 0.0780)	Green	
3	1.982 - 1.985 (0.0780 - 0.0781)	Yellow	
4	1.985 - 1.988 (0.0781 - 0.0783)	Blue	
5	1.988 - 1.991 (0.0783 - 0.0784)	Pink	
6	1.991 - 1.994 (0.0784 - 0.0785)	Purple	
7	1.994 - 1.997 (0.0785 - 0.0786)	White	

CYLINDER BLOCK

[QR25DE]

01	UPR	1.973 - 1.976 (0.0777 - 0.0778)	Black / Brown	Grade and color are different for upper and lower bearings.
	LWR	1.976 - 1.979 (0.0778 - 0.0779)		
12	UPR	1.976 - 1.979 (0.0778 - 0.0779)	Brown / Green	
	LWR	1.979 - 1.982 (0.0779 - 0.0780)		
23	UPR	1.979 - 1.982 (0.0779 - 0.0780)	Green / Yellow	
	LWR	1.982 - 1.985 (0.0780 - 0.0781)		
34	UPR	1.982 - 1.985 (0.0780 - 0.0781)	Yellow / Blue	
	LWR	1.985 - 1.988 (0.0781 - 0.0783)		
45	UPR	1.985 - 1.988 (0.0781 - 0.0783)	Blue / Pink	
	LWR	1.988 - 1.991 (0.0783 - 0.0784)		
56	UPR	1.988 - 1.991 (0.0783 - 0.0784)	Pink / Purple	
	LWR	1.991 - 1.994 (0.0784 - 0.0785)		
67	UPR	1.991 - 1.994 (0.0784 - 0.0785)	Purple / White	
	LWR	1.994 - 1.997 (0.0785 - 0.0786)		

Use Undersize Bearing Usage Guide

- Use undersize (U.S.) bearing when oil clearance with standard size main bearing is not within specification.
- When using undersize (U.S.) bearing, measure the bearing inner diameter with the bearing installed and grind journal until oil clearance falls within specification.


Bearing Undersize Table

Unit: mm (in)

Size U.S.	Thickness
0.25 (0.0098)	2.106 - 2.114 (0.0829 - 0.0832)

CAUTION:

Do not damage fillet R when grinding crankshaft journal in order to use an undersize bearing (all journals).



EBS00Z92


Inspection After Disassembly CRANKSHAFT SIDE CLEARANCE

- Using a dial gauge, measure the clearance between the thrust bearings and the crankshaft arm when the crankshaft is moved fully forward or backward.

Standard : 0.10 - 0.26 mm (0.0039 - 0.0102 in)

Limit : 0.30 mm (0.0118 in)

- If the measured value exceeds the limit, replace the thrust bearings, and measure again. If it still exceeds the limit, replace the crankshaft.




CONNECTING ROD SIDE CLEARANCE

- Measure side clearance between connecting rod and crankshaft arm using a feeler gauge.

Standard : 0.20 - 0.35 mm (0.0079 - 0.0138 in)

Limit : 0.50 mm (0.0197 in)


- If the measured value exceeds the limit, replace the connecting rod bearings, and measure again. If it still exceeds the limit, replace the crankshaft also.



PISTON AND PISTON PIN CLEARANCE


Diameter of Piston Pin Bore

- Measure the diameter of piston pin bore using an inside micrometer. Refer to [EM-214, "Available Piston"](#).



Outer Diameter of Piston Pin

- Measure outer diameter of piston pin using a micrometer. Refer to [EM-215, "Piston Pin"](#).




Piston to Piston Pin Clearance

(Piston pin clearance) = (Piston pin bore diameter) – (Outer diameter of piston pin)

Standard : 0.002 - 0.006 mm (0.0001 - 0.0002 in)


- If clearance exceeds specification, replace either or both of piston/piston pin assembly and connecting rod assembly with reference to specification of each parts.
- Refer to piston selection table to replace piston/piston pin assembly. Refer to [EM-192, "HOW TO SELECT A PISTON"](#).
- Refer to connecting rod bearing selection table to replace connecting rod. Refer to [EM-193, "HOW TO SELECT A CONNECTING ROD BEARING"](#).



A
EM
C
D
E
F
G
H
I
J
K
L
M


NOTE:

- The connecting rod small end grade and piston pin hole (piston pin) grade are provided only for the parts installed at the plant. For service parts, no grades can be selected. Only 0 grade is available.
- Refer to [EM-201, "CONNECTING ROD BUSHING OIL CLEARANCE \(SMALL END\)"](#) for the values for each grade at the plant.
- Regarding marks on piston head, Refer to [EM-192, "HOW TO SELECT A PISTON"](#) .




PISTON RING SIDE CLEARANCE

- Measure side clearance of piston ring and piston ring groove using a feeler gauge. Refer to [EM-214, "Available Piston"](#) .
- If out of specification, replace piston and/or piston ring assembly.




PISTON RING END GAP

- Check if inner diameter of cylinder bore is within specification. Refer to [EM-203, "PISTON TO CYLINDER BORE CLEARANCE"](#) .
- Insert piston ring until middle of cylinder with piston, and measure gap using a feeler gauge. Refer to [EM-214, "Available Piston"](#) .
- If out of specification, replace piston ring. If gap still exceeds the limit even with a new ring, re-bore cylinder and use oversized piston and piston ring.



CONNECTING ROD BEND AND TORSION


- Check with connecting rod aligner. Refer to [EM-215, "CONNECTING ROD"](#) .



CYLINDER BLOCK


[QR25DE]

- If it exceeds the limit, replace connecting rod assembly.



CONNECTING ROD BEARING (BIG END)


- Install the connecting rod cap without the connecting rod bearing installed. After tightening the connecting rod bolt to the specified torque, measure the connecting rod big end inner diameter using an inside micrometer. Refer to [EM-215, "CONNECTING ROD"](#).



CONNECTING ROD BUSHING OIL CLEARANCE (SMALL END)


Inner Diameter of Connecting Rod (Small End)

- Measure inner diameter of bushing. Refer to [EM-215, "CONNECTING ROD"](#)



Outer Diameter of Piston Pin

- Measure outer diameter of piston pin. Refer to [EM-215, "Piston Pin"](#).



CYLINDER BLOCK


[QR25DE]

Connecting Rod Bushing Oil Clearance (Small End)

(Connecting rod small end oil clearance) = (Inner diameter of connecting rod small end) – (Outer diameter of piston pin)

Standard : 0.005 - 0.017 mm (0.0002 - 0.0007 in)


- If the measured value exceeds the standard, replace the connecting rod assembly and/or piston and piston pin assembly.
- If replacing the piston and piston pin assembly, refer to the "Piston Selection Table" to select the piston corresponding to the applicable bore grade of the cylinder block to be used. Refer to [EM-192, "HOW TO SELECT A PISTON"](#) .



Factory Installed Parts Grading:

- Service parts apply only to grade 0.

Grade	Unit: mm (in)	
	0	1
Connecting rod small end inner diameter	20.000 - 20.006 (0.7874 - 0.7876)	20.006 - 20.012 (0.7876 - 0.7879)
Piston pin outer diameter	19.989 - 19.995 (0.7870 - 0.7872)	19.995 - 20.001 (0.7872 - 0.7874)
Piston pin bore diameter	19.993 - 19.999 (0.7871 - 0.7874)	19.999 - 20.005 (0.7874 - 0.7876)




CYLINDER BLOCK DISTORTION

- Using a scraper, remove gasket on the cylinder block surface, and also remove oil, scale, carbon, or other contamination.
- CAUTION:**
Be careful not to allow gasket debris to enter the oil or coolant passages.
- Measure the distortion on the block upper face at some different points in 6 directions.

Limit : 0.1 mm (0.004 in)

- If out of the distortion limit, replace the cylinder block.



INNER DIAMETER OF MAIN BEARING HOUSING


- Install the main bearing caps with the main bearings removed and tighten the bolts to the specified torque. Refer to [EM-187, "ASSEMBLY"](#) .
- Using a bore gauge, measure the inner diameter of the main bearing housing.

Standard : 58.944 - 58.968 mm (2.3206 - 2.3216 in)

- If out of the standard, replace the cylinder block and lower cylinder block assembly.

NOTE:

These components cannot be replaced as a single unit because they were processed together.



PISTON TO CYLINDER BORE CLEARANCE

Inner Diameter of Cylinder Bore


- Using a bore gauge, measure cylinder bore for wear, out-of-round and taper at 6 different points on each cylinder. (X and Y directions at A, B and C). The Y axis is in the longitudinal direction of the engine.

NOTE:

When determining cylinder bore grade, measure cylinder bore at B position. Refer to [EM-213, "CYLINDER BLOCK"](#).


- If the measured value rebore exceeds the limit, or if there are scratches and/or seizure on the cylinder inner wall, hone the inner wall.
- An oversize piston is provided. When using an oversize piston, rebore the cylinder so that the clearance of the piston cylinder satisfies the standard.

Over size (OS) : 0.2 mm (0.008 in)



Outer Diameter of Piston

- Measure piston skirt diameter using a micrometer. Refer to [EM-214, "Available Piston"](#).



- Measure point (distance from the top): 42 mm (1.65 in)

Piston to Cylinder Bore Clearance

- Calculate by outer diameter of piston skirt and inner diameter of cylinder (direction X, position B).
(Clearance) = (Inner diameter of cylinder) – (Outer diameter of piston skirt).

Standard : 0.010 - 0.030 mm (0.0004 - 0.0012 in)

Limit : 0.08 mm (0.0031 in)

- If it exceeds the limit, replace piston/piston pin assembly.

Reboring Cylinder Bore

- Cylinder bore size is determined by adding piston-to-bore clearance to piston diameter "A".

Rebored size calculation: $D = A + B - C$

D: Bored diameter

A: Piston diameter as measured

B: Piston-to-bore clearance (standard value)

C: Honing allowance 0.02 mm (0.0008 in)

- Install main bearing caps, and tighten to the specified torque. Otherwise, cylinder bores may be distorted in final assembly.
- Cut cylinder bores.
 - When any cylinder needs boring, all other cylinders must also be bored.**
 - Do not cut too much out of cylinder bore at a time. Cut only 0.05 mm (0.0020 in) or so in diameter at a time.**

4. Hone cylinders to obtain specified piston-to-bore clearance.
5. Measure finished cylinder bore for out-of-round and taper.
 - **Measurement should be done after cylinder bore cools down.**

OUTER DIAMETER OF CRANKSHAFT JOURNAL


- Measure outer diameter of crankshaft journals.

Standard : 54.955 - 54.979 mm (2.1636 - 2.1645 in)

OUTER DIAMETER OF CRANKSHAFT PIN

- Measure outer diameter of crankshaft pin.

Standard : 44.956 - 44.974 mm (1.7699 - 1.7706 in)




OUT-OF-ROUND AND TAPER OF CRANKSHAFT

- Measure the dimensions at four different points as shown on each journal and pin using a micrometer.
- Out-of-round is indicated by the difference in dimensions between "X" and "Y" at "A" and "B".
- Taper is indicated by the difference in dimension between "A" and "B" at "X" and "Y".

Limit

Out-of-round (X - Y) : 0.005 mm (0.0002 in)


Taper (A - B) : 0.005 mm (0.0002 in)



CRANKSHAFT RUNOUT

- Place a V-block on a precise flat table to support the journals on both ends of the crankshaft.
- Place a dial gauge straight up on the No. 3 journal.
- While rotating the crankshaft, read the movement of the pointer on the dial gauge, the total indicator reading.

Limit : Less than 0.05 mm (0.002 in)




OIL CLEARANCE OF CONNECTING ROD BEARING**Method of Measurement**

- Install the connecting rod bearings to the connecting rod and the cap, and tighten the connecting rod bolts to the specified torque. Using an inside micrometer measure the inner diameter of connecting rod bearing.
(Oil clearance) = (Inner diameter of connecting rod bearing) – (Outer diameter of crankshaft pin)

Standard : 0.035 - 0.045 mm (0.0014 - 0.0018 in)

Limit : 0.10 mm (0.0039 in)

- If clearance cannot be adjusted within the standard, grind crankshaft pin and use undersized bearing. Refer to [EM-193, "HOW TO SELECT A CONNECTING ROD BEARING"](#).

**Method of Using Plastigage**

- Remove oil and dust on the crankshaft pin and the surfaces of each bearing completely.
- Cut the Plastigage slightly shorter than the bearing width, and place it in crankshaft axial direction, avoiding oil holes.
- Install the connecting rod bearings to the connecting rod cap, and tighten the connecting rod bolts to the specified torque.


CAUTION:

Never rotate the crankshaft.

- Remove the connecting rod cap and bearings, and using the scale on the Plastigage bag, measure the Plastigage width.

NOTE:

The procedure when the measured value exceeds the limit is same as that described in the method by calculation.

**OIL CLEARANCE OF MAIN BEARING****Method of Measurement**

- Install the main bearings to the cylinder block and bearing cap. Measure the main bearing inner diameter with the bearing cap bolt tightened to the specified torque.
(Oil clearance) = (Inner diameter of main bearing) – (Outer diameter of crankshaft journal)

Standard:

No. 1, 3, and 5 journals : 0.012 - 0.022 mm (0.0005 - 0.0009 in)

No. 2 and 4 journals : 0.018 - 0.028 mm (0.0007 - 0.0011 in)

Limit : 0.1 mm (0.004 in)

- If the measured value exceeds the limit, select main bearings referring to the main bearing inner diameter and crankshaft journal outer diameter, so that the oil clearance satisfies the standard. Refer to [EM-195, "HOW TO SELECT A MAIN BEARING"](#).


Method of Using Plastigage

- Remove oil and dust on the crankshaft journal and the surfaces of each bearing completely.
- Cut the Plastigage slightly shorter than the bearing width, and place it in crankshaft axial direction, avoiding oil holes.
- Tighten the main bearing bolts to the specified torque.

CAUTION:

Never rotate the crankshaft.

- Remove the bearing cap and bearings, and using the scale on the plastigage bag, measure the plastigage width.



NOTE:


The procedure when the measured value exceeds the limit is same as that described in the "Method by Calculation".

CRUSH HEIGHT OF MAIN BEARING

- When the bearing cap is removed after being tightened to the specified torque with main bearings installed, the tip end of bearing must protrude.

Standard : There must be crush height.


- If the standard is not met, replace main bearings.



OUTER DIAMETER OF LOWER CYLINDER BLOCK BOLT

- Perform only with M10 (0.39 in) bolts.
- Measure outer diameters (d1, d2) at two positions as shown.
- Measure d2 at a point within area A as shown.
- When the value of d1- d2 exceeds the limit (a large difference in dimensions), replace the bolt with a new one.


Limit : 0.13 mm (0.0051 in)



OUTER DIAMETER OF CONNECTING ROD BOLT

- Measure outer diameter (d) at position as shown.
- When "d" exceeds the limit (when it becomes thinner), replace the bolt with a new one.

Limit : 7.75 mm (0.3051 in) or less



MOVEMENT AMOUNT OF FLYWHEEL (M/T MODEL)

NOTE:

- Inspection for double mass flywheel only.
- Do not disassemble double mass flywheel.


Flywheel Deflection

- Measure deflection of flywheel contact surface to the clutch with a dial gauge.

CYLINDER BLOCK

[QR25DE]

- Measure runout at 210 mm (8.27 in) dia.
Limit : 0.45 mm (0.0177 in) or less under no load
- Measure axial displacement at 250 mm (9.84 in) dia.
Limit : 1.3 mm (0.051 in) or less under 100N (22.48 lb) force
- When measured value exceeds the limit, replace the flywheel with a new one.




Movement Amount in Rotation Direction

- Check the movement amount in the following procedure.
 1. Install a bolt to clutch cover mounting hole, and place a torque wrench on the extended line of the flywheel center line.
 2. Tighten bolt to keep it from loosening at a force of 9.8 N·m (1 kg·m, 87 in-lb).
 3. Put a mating mark on circumferences of the two flywheel masses without applying any load (measurement standard points).
 4. Apply a force of 9.8 N·m (1 kg·m, 87 in-lb) in each direction, and mark the movement amount on the mass on the transmission side.
 5. Measure dimensions of movement amounts A and B on circumference of the flywheel on the transmission side.

Standard : 35 mm (1.38 in) or less

- When measured value is outside the standard, replace flywheel.



SERVICE DATA AND SPECIFICATIONS (SDS)

[QR25DE]


SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

Standard and Limit GENERAL SPECIFICATIONS

EBS00Z93

Cylinder arrangement		In-line 4
Displacement cm ³ (in ³)		2,488 (151.82)
Bore and stroke mm (in)		89.0 x 100 (3.50 x 3.94)
Valve arrangement		DOHC
Firing order		1-3-4-2
Number of piston rings	Compression	2
	Oil	1
Compression ratio		9.5:1
Compression pressure kPa (kg/cm ² , psi) / 250 rpm	Standard	1,250 (12.8, 181.3)
	Minimum	1,060 (10.8, 153.7)
	Differential limit between cylinders	100 (1.0, 14)



Unit: degree					
a	b	c	d	e	f
224°	244°	0°	64°	3°	41°

DRIVE BELTS

Tension of drive belts	Auto adjustment by auto tensioner
------------------------	-----------------------------------

INTAKE MANIFOLD AND EXHAUST MANIFOLD

Unit: mm (in)		
Surface distortion	Description	Limit
	Intake manifold collector	0.1 (0.004)
	Intake manifold	0.1 (0.004)
	Exhaust manifold	0.3 (0.012)

SPARK PLUG


Unit: mm (in)		
Make	NGK	
Type	Standard	DILKAR6A-11
Gap (nominal)	1.1 (0.043)	

SERVICE DATA AND SPECIFICATIONS (SDS)

[QR25DE]

CYLINDER HEAD

Unit: mm (in)



Nominal cylinder head height:
H = 129.4 mm (5.09 in)


PBIC0283E

Description	Limit
Head surface distortion	0.1 (0.004)

VALVE

Valve Dimensions

Unit: mm (in)



Valve head diameter "D"	Intake	35.5 - 35.8 (1.398 - 1.409)
	Exhaust	30.5 - 30.8 (1.201 - 1.213)
Valve length "L"	Intake	97.16 (3.8252)
	Exhaust	98.82 (3.8905)
Valve stem diameter "d"	Intake	5.965 - 5.980 (0.2348 - 0.2354)
	Exhaust	5.955 - 5.970 (0.2344 - 0.2350)
Valve seat angle "α"	Intake	45°15' - 45°45'
	Exhaust	
Valve margin "T"	Intake	1.1 (0.043)
	Exhaust	1.3 (0.051)

Valve Clearance

Unit: mm (in)


	Cold* (reference data)	Hot
Intake	0.24 - 0.32 (0.009 - 0.013)	0.304 - 0.416 (0.012 - 0.016)
Exhaust	0.26 - 0.34 (0.010 - 0.013)	0.308 - 0.432 (0.013 - 0.017)

*: Approximately 20°C (68 °F)

SERVICE DATA AND SPECIFICATIONS (SDS)

[QR25DE]

Available Valve Lifter



KBIA0119E

Thickness mm (in)	Identification mark (Stamp)
7.88 (0.3102)	788U
7.90 (0.3110)	790U
7.92 (0.3118)	792U
7.94 (0.3126)	794U
7.96 (0.3134)	796U
7.98 (0.3142)	798U
8.00 (0.3150)	800U
8.02 (0.3157)	802U
8.04 (0.3165)	804U
8.06 (0.3173)	806U
8.08 (0.3181)	808U
8.10 (0.3189)	810U
8.12 (0.3197)	812U
8.14 (0.3205)	814U
8.16 (0.3213)	816U
8.18 (0.3220)	818U
8.20 (0.3228)	820U
8.22 (0.3236)	822U
8.24 (0.3244)	824U
8.26 (0.3252)	826U
8.28 (0.3260)	828U
8.30 (0.3268)	830U
8.32 (0.3276)	832U
8.34 (0.3283)	834U
8.36 (0.3291)	836U
8.38 (0.3299)	838U

Valve Spring

Specifications	Intake	Exhaust
Identification color	Pink	Blue
Free height	43.72 - 43.92 mm (1.7213 - 1.7291 in)	45.29 - 45.49 mm (1.7831 - 1.7909 in)
Pressure standard at height 35.30 mm (1.390 in)	151 - 175 N (15.4 - 17.8 kg-f, 34 - 39 lb-f)	151 - 175 N (15.4 - 17.8 kg-f, 34 - 39 lb-f)
Squareness	1.9 mm (0.0748 in)	1.9 mm (0.0748 in)
Installation height	35.30 mm (1.390 in)	35.30 mm (1.390 in)

SERVICE DATA AND SPECIFICATIONS (SDS)

[QR25DE]

Specifications	Intake	Exhaust
Installation load	151 - 175 N (15.4 - 17.8 kg-f, 34 - 39 lb-f)	151 - 175 N (15.4 - 17.8 kg-f, 34 - 39 lb-f)
Height during valve open	25.30 mm (0.996 in)	26.76 mm (1.0535 in)
Load with valve open	351 - 394 N (35.8 - 40.2 kg-f, 79 - 89 lb-f)	318 - 362 N (32.4 - 36.9 kg-f, 71 - 81 lb-f)


Valve Lifter

Unit: mm (in)

Description	Standard
Valve lifter outer diameter	33.977 - 33.987 (1.3377 - 1.3381)
Lifter lifter bore inner diameter	34.000 - 34.021 (1.3386 - 1.3394)
Clearance between lifter and lifter guide	0.013 - 0.0544 (0.0005 - 0.0018)

Valve Guide

Unit: mm (in)



PBIC0184E


Description		Standard	Service
Valve guide	Outer diameter	10.023 - 10.034 (0.3946 - 0.3950)	10.223 - 10.234 (0.4025 - 0.4029)
	Inner diameter (Finished size)	6.000 - 6.018 (0.2362 - 0.2369)	
Intake and exhaust valve guide hole diameter		9.975 - 9.996 (0.3927 - 0.3935)	10.175 - 10.196 (0.4006 - 0.4014)
Interference fit of valve guide		0.027 - 0.059 (0.0011 - 0.0023)	
Standard			
Valve guide clearance	Intake	0.020 - 0.053 (0.0008 - 0.0021) or less	
	Exhaust	0.030 - 0.063 (0.0012 - 0.0025) or less	
Projection length "L"	Intake	10.1 - 10.3 (0.398 - 0.406)	
	Exhaust	10.0 - 10.4 (0.394 - 0.409)	

SERVICE DATA AND SPECIFICATIONS (SDS)

[QR25DE]

Valve Seat

Unit: mm (in)




Description		Standard	Service
Cylinder head seat recess diameter (D)	Intake	36.500 - 36.516 (1.4370 - 1.4376)	37.000 - 37.016 (1.4567 - 1.4573)
	Exhaust	31.500 - 31.516 (1.2402 - 1.2408)	32.000 - 32.016 (1.2598 - 1.2605)
Valve seat interference fit	Intake	0.081 - 0.113 (0.0032 - 0.0044)	
	Exhaust	0.084 - 0.116 (0.0033 - 0.0046)	
Valve seat outer diameter (d)	Intake	36.597 - 36.613 (1.4408 - 1.4415)	37.097 - 37.113 (1.4605 - 1.4611)
	Exhaust	31.600 - 31.616 (1.2441 - 1.2447)	32.100 - 32.116 (1.2638 - 1.2644)
Diameter "d1"	Intake	33.5 (1.319)	
	Exhaust	28.0 (1.102)	
Diameter "d2"	Intake	34.8 - 35.3 (1.3701 - 1.3898)	
	Exhaust	29.6 - 30.1 (1.1654 - 1.1850)	
Angle $\alpha 1$	Intake	60°	
	Exhaust	60°	
Angle $\alpha 2$	Intake	88° 46' - 90° 14'	
	Exhaust	88° 46' - 90° 14'	
Angle $\alpha 3$	Intake	120°	
	Exhaust	120°	
Contacting width "W"	Intake	0.99 - 1.35 (0.0390 - 0.0531)	
	Exhaust	1.19 - 1.55 (0.0469 - 0.0610)	

*1 Machining data

CAMSHAFT AND CAMSHAFT BEARING

Unit: mm (in)

	Standard
Camshaft runout [TIR*]	Less than 0.04 (0.0016)



SEM671

Cam height "A"	Intake	44.815 - 45.005 (1.7644 - 1.7718)
	Exhaust	43.975 - 44.165 (1.7313 - 1.7388)

SERVICE DATA AND SPECIFICATIONS (SDS)


[QR25DE]

	Standard
Outer diameter of camshaft journal	No. 1 27.935 - 27.955 (1.0998 - 1.1006)
	No. 2, 3, 4, 5 23.435 - 23.455 (0.9226 - 0.9234)
Inner diameter of camshaft bracket	No.1 28.000 - 28.021 (1.1024 - 1.1032)
	No.2, 3, 4, 5 23.500 - 23.521 (0.9252 - 0.9260)
Camshaft journal clearance	0.045 - 0.086 (0.0018 - 0.0034)
Camshaft end play	0.115 - 0.188 (0.0045 - 0.0074)
Camshaft sprocket runout [TIR*]	Less than 0.15 (0.0059)

*: Total indicator reading

CYLINDER BLOCK

Unit: mm (in)



PBIC0281E

Surface distortion	Limit		0.1 (0.004)
Cylinder bore	Inner diameter	Standard	Grade No. 2 89.010 - 89.020 (3.5043 - 3.5047)
			Grade No. 3 89.020 - 89.030 (3.5047 - 3.5051)
		Wear limit	0.2 (0.008)
Out-of-round (X - Y)			Less than 0.015 (0.0006)
Taper (C - A)			Less than 0.01 (0.0004)

SERVICE DATA AND SPECIFICATIONS (SDS)


[QR25DE]

Main journal inner diameter grade (Without bearing)	Grade No. A	58.944 - 58.945 (2.3206 - 2.3207)
	Grade No. B	58.945 - 58.946 (2.3207 - 2.3207)
	Grade No. C	58.946 - 58.947 (2.3207 - 2.3207)
	Grade No. D	58.947 - 58.948 (2.3207 - 2.3208)
	Grade No. E	58.948 - 58.949 (2.3208 - 2.3208)
	Grade No. F	58.949 - 58.950 (2.3208 - 2.3209)
	Grade No. G	58.950 - 58.951 (2.3209 - 2.3209)
	Grade No. H	58.951 - 58.952 (2.3209 - 2.3209)
	Grade No. J	58.952 - 58.953 (2.3209 - 2.3210)
	Grade No. K	58.953 - 58.954 (2.3210 - 2.3210)
	Grade No. L	58.954 - 58.955 (2.3210 - 2.3211)
	Grade No. M	58.955 - 58.956 (2.3211 - 2.3211)
	Grade No. N	58.956 - 58.957 (2.3211 - 2.3211)
	Grade No. P	58.957 - 58.958 (2.3211 - 2.3212)
	Grade No. R	58.958 - 58.959 (2.3212 - 2.3212)
	Grade No. S	58.959 - 58.960 (2.3212 - 2.3213)
	Grade No. T	58.960 - 58.961 (2.3213 - 2.3213)
	Grade No. U	58.961 - 58.962 (2.3213 - 2.3213)
	Grade No. V	58.962 - 58.963 (2.3213 - 2.3214)
Grade No. W	58.963 - 58.964 (2.3214 - 2.3214)	
Grade No. X	58.964 - 58.965 (2.3214 - 2.3215)	
Grade No. Y	58.965 - 58.966 (2.3215 - 2.3215)	
Grade No. 4	58.966 - 58.967 (2.3215 - 2.3215)	
Grade No. 7	58.967 - 58.968 (2.3215 - 2.3216)	
Difference in inner diameter between cylinders	Standard	Less than 0.03 (0.0012)

PISTON, PISTON RING, AND PISTON PIN

Available Piston

Unit: mm (in)



PBIC0188E

Piston skirt diameter "A"	Standard	Grade No. 1	88.980 - 88.990 (3.5031 - 3.5035)
		Grade No. 2	88.990 - 89.000 (3.5035 - 3.5039)
		Grade No. 3	89.000 - 89.010 (3.5039 - 3.5043)
		0.20 (0.0079) oversize (service)	89.180 - 89.210 (3.5110 - 3.5122)
"H" dimension			42 (1.65)
Piston pin bore diameter	Grade No. 0		19.993 - 19.999 (0.7871 - 0.7874)
	Grade No. 1		19.999 - 20.005 (0.7874 - 0.7876)
Piston clearance to cylinder bore	Standard		0.010 - 0.030 (0.0004 - 0.0012)
	Limit		0.08 (0.0031)

SERVICE DATA AND SPECIFICATIONS (SDS)

[QR25DE]

Piston Ring

Unit: mm (in)

		Standard	Limit
Side clearance	Top	0.040 - 0.080 (0.0018 - 0.0031)	0.11 (0.0043)
	2nd	0.030 - 0.070 (0.0012 - 0.0028)	0.10 (0.0039)
	Oil ring	0.045 - 0.125 (0.0018 - 0.0049)	—
End gap	Top	0.21 - 0.31 (0.0083 - 0.0122)	0.54 (0.0213)
	2nd	0.37 - 0.52 (0.0146 - 0.0205)	0.67 (0.0264)
	Oil (rail ring)	0.20 - 0.45 (0.0079 - 0.0177)	0.95 (0.0374)

Piston Pin

Unit: mm (in)

Piston pin outer diameter	Grade No.0	19.989 - 19.995 (0.7870 - 0.7872)
	Grade No.1	19.995 - 20.001 (0.7872 - 0.7874)
Piston to piston pin clearance (Standard)		0.002 - 0.006 (0.0001 - 0.0002)
Piston pin to connecting rod bushing clearance	Standard	0.005 - 0.017 (0.0002 - 0.0007)

CONNECTING ROD

Unit: mm (in)

Center distance		143.00 - 143.10 (5.63 - 5.63)
Bend [per 100 (3.94)]	Limit	0.15 (0.0059)
Torsion [per 100 (3.94)]	Limit	0.30 (0.0118)
Connecting rod small end inner diameter		22.000 - 22.012 (0.7874 - 0.7879)
Connecting rod small end inner diameter*	Grade No. 0	20.000 - 20.006 (0.7874 - 0.7876)
	Grade No. 1	20.006 - 20.012 (0.7876 - 0.7879)
Connecting rod big end inner diameter		48.000 - 48.013 (1.8898 - 1.8903)
Side clearance	Standard	0.20 - 0.35 (0.0079 - 0.0138)
	Limit	0.50 (0.0197)
Connecting rod bearing housing	Grade No. 0	48.000 - 48.001 (1.8898 - 1.8898)
	Grade No. 1	48.001 - 48.002 (1.8898 - 1.8898)
	Grade No. 2	48.002 - 48.003 (1.8898 - 1.8899)
	Grade No. 3	48.003 - 48.004 (1.8899 - 1.8899)
	Grade No. 4	48.004 - 48.005 (1.8899 - 1.8899)
	Grade No. 5	48.005 - 48.006 (1.8899 - 1.8900)
	Grade No. 6	48.006 - 48.007 (1.8900 - 1.8900)
	Grade No. 7	48.007 - 48.008 (1.8900 - 1.8901)
	Grade No. 8	48.008 - 48.009 (1.8901 - 1.8901)
	Grade No. 9	48.009 - 48.010 (1.8901 - 1.8902)
	Grade No. A	48.010 - 48.011 (1.8902 - 1.8902)
	Grade No. B	48.011 - 48.012 (1.8902 - 1.8902)
Grade No. C	48.012 - 48.013 (1.8902 - 1.8903)	


*: After installing in connecting rod

SERVICE DATA AND SPECIFICATIONS (SDS)

[QR25DE]


CRANKSHAFT

Unit: mm (in)



SEM645

Out-of-round (X - Y)
Taper (A - B)



SEM715

Pin journal dia. "DP"	Grade No. A Grade No. B Grade No. C Grade No. D Grade No. E Grade No. F Grade No. G Grade No. H Grade No. J Grade No. K Grade No. L Grade No. M Grade No. N Grade No. P Grade No. R Grade No. S Grade No. T Grade No. U	44.974 - 44.973 (1.7706 - 1.7706) 44.973 - 44.972 (1.7706 - 1.7705) 44.972 - 44.971 (1.7705 - 1.7705) 44.971 - 44.970 (1.7705 - 1.7705) 44.970 - 44.969 (1.7705 - 1.7704) 44.969 - 44.968 (1.7704 - 1.7704) 44.968 - 44.967 (1.7704 - 1.7704) 44.967 - 44.966 (1.7704 - 1.7703) 44.966 - 44.965 (1.7703 - 1.7703) 44.965 - 44.964 (1.7703 - 1.7702) 44.964 - 44.963 (1.7702 - 1.7702) 44.963 - 44.962 (1.7702 - 1.7702) 44.962 - 44.961 (1.7702 - 1.7701) 44.961 - 44.960 (1.7701 - 1.7701) 44.960 - 44.959 (1.7701 - 1.7700) 44.959 - 44.958 (1.7700 - 1.7700) 44.958 - 44.957 (1.7700 - 1.7700) 44.957 - 44.956 (1.7700 - 1.7699)
Main journal dia. "Dm" grade	Grade No. A Grade No. B Grade No. C Grade No. D Grade No. E Grade No. F Grade No. G Grade No. H Grade No. J Grade No. K Grade No. L Grade No. M Grade No. N Grade No. P Grade No. R Grade No. S Grade No. T Grade No. U Grade No. V Grade No. W Grade No. X Grade No. Y Grade No. 4 Grade No. 7	54.979 - 54.978 (2.1645 - 2.1645) 54.978 - 54.977 (2.1645 - 2.1644) 54.977 - 54.976 (2.1644 - 2.1644) 54.976 - 54.975 (2.1644 - 2.1644) 54.975 - 54.974 (2.1644 - 2.1643) 54.974 - 54.973 (2.1643 - 2.1643) 54.973 - 54.972 (2.1643 - 2.1642) 54.972 - 54.971 (2.1642 - 2.1642) 54.971 - 54.970 (2.1642 - 2.1642) 54.970 - 54.969 (2.1642 - 2.1641) 54.969 - 54.968 (2.1641 - 2.1641) 54.968 - 54.967 (2.1641 - 2.1641) 54.967 - 54.966 (2.1641 - 2.1640) 54.966 - 54.965 (2.1640 - 2.1640) 54.965 - 54.964 (2.1640 - 2.1639) 54.964 - 54.963 (2.1639 - 2.1639) 54.963 - 54.962 (2.1639 - 2.1639) 54.962 - 54.961 (2.1639 - 2.1638) 54.961 - 54.960 (2.1638 - 2.1638) 54.960 - 54.959 (2.1638 - 2.1637) 54.959 - 54.958 (2.1637 - 2.1637) 54.958 - 54.957 (2.1637 - 2.1637) 54.957 - 54.956 (2.1637 - 2.1636) 54.956 - 54.955 (2.1636 - 2.1636)
Center distance "r"		49.60 - 50.04 (1.9528 - 1.9701)
Out-of-round (X - Y)	Standard	Less than 0.005 (0.0002)
Taper (A - B)	Standard	Less than 0.005 (0.0002)
Runout [TIR*]	Limit	Less than 0.05 (0.002)
Free end play	Standard	0.10 - 0.26 (0.0039 - 0.0102)
	Limit	0.30 (0.0118)


SERVICE DATA AND SPECIFICATIONS (SDS)

[QR25DE]

*: Total indicator reading

MAIN BEARING

Unit: mm (in)



SEM685D

Grade number		Thickness	Identification color (UPR / LWR)	Remarks
0		1.973 - 1.976 (0.0777 - 0.0778)	Black	Grade and color are the same for upper and lower bearings.
1		1.976 - 1.979 (0.0778 - 0.0779)	Brown	
2		1.979 - 1.982 (0.0779 - 0.0780)	Green	
3		1.982 - 1.985 (0.0780 - 0.0781)	Yellow	
4		1.985 - 1.988 (0.0781 - 0.0783)	Blue	
5		1.988 - 1.991 (0.0783 - 0.0784)	Pink	
6		1.991 - 1.994 (0.0784 - 0.0785)	Purple	
7		1.994 - 1.997 (0.0785 - 0.0786)	Orange	
01	UPR	1.973 - 1.976 (0.0777 - 0.0778)	Black / Brown	Grade and color are different for upper and lower bearings.
	LWR	1.976 - 1.979 (0.0778 - 0.0779)		
12	UPR	1.976 - 1.979 (0.0778 - 0.0779)	Brown / Green	
	LWR	1.979 - 1.982 (0.0779 - 0.0780)		
23	UPR	1.979 - 1.982 (0.0779 - 0.0780)	Green / Yellow	
	LWR	1.982 - 1.985 (0.0780 - 0.0781)		
34	UPR	1.982 - 1.985 (0.0780 - 0.0781)	Yellow / Blue	
	LWR	1.985 - 1.988 (0.0781 - 0.0783)		
45	UPR	1.985 - 1.988 (0.0781 - 0.0783)	Blue / Pink	
	LWR	1.988 - 1.991 (0.0783 - 0.0784)		
56	UPR	1.988 - 1.991 (0.0783 - 0.0784)	Pink / Purple	
	LWR	1.991 - 1.994 (0.0784 - 0.0785)		
67	UPR	1.991 - 1.994 (0.0784 - 0.0785)	Purple / White	
	LWR	1.994 - 1.997 (0.0785 - 0.0786)		

Undersize

Unit: mm (in)

Size U.S.	Thickness	Main journal diameter
0.25 (0.0098)	2.106 - 2.114 (0.0829 - 0.0832)	Grind so that bearing clearance is the specified value.

Bearing Clearance

Unit: mm (in)

Main bearing oil clearance	Standard	No.1, 3, and 5	0.012 - 0.022 (0.0005 - 0.0009)
		No.2 and 4	0.018 - 0.028 (0.0007 - 0.0011)
	Limit		0.1 (0.004)

SERVICE DATA AND SPECIFICATIONS (SDS)

[QR25DE]

CONNECTING ROD BEARING

Grade number	Thickness mm (in)	Identification color
0	1.493 - 1.496 (0.0588 - 0.0589)	Black
1	1.496 - 1.499 (0.0589 - 0.0590)	Brown
2	1.499 - 1.502 (0.0590 - 0.0591)	Green
3	1.502 - 1.505 (0.0591 - 0.0593)	Yellow
4	1.505 - 1.508 (0.0593 - 0.0594)	Blue

Undersize

Unit: mm (in)

Size U.S.	Thickness	Crank pin journal diameter
0.25 (0.0098)	1.622 - 1.630 (0.0639 - 0.0642)	Grind so that bearing clearance is the specified value.

Bearing Clearance

Unit: mm (in)

Connecting rod bearing oil clearance	Standard	0.035 - 0.045 (0.0014 - 0.0018)
	Limit	0.10 (0.0039)