

# SECTION PG

## POWER SUPPLY, GROUND & CIRCUIT ELEMENTS

### CONTENTS

<b>SERVICE INFORMATION</b> .....	2	<b>GROUND CIRCUIT</b> .....	28	A
<b>PRECAUTIONS</b> .....	2	Ground Distribution .....	28	B
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	2	<b>HARNES</b> .....	37	C
<b>POWER SUPPLY ROUTING CIRCUIT</b> .....	3	Harness Layout .....	37	D
Schematic .....	3	Wiring Diagram Codes (Cell Codes) .....	58	E
Wiring Diagram - POWER - .....	5	<b>ELECTRICAL UNITS LOCATION</b> .....	61	F
Fuse .....	15	Electrical Units Location .....	61	G
Fusible Link .....	15	<b>HARNES CONNECTOR</b> .....	65	H
Circuit Breaker (Built Into BCM) .....	15	Description .....	65	I
Circuit Breaker .....	15	<b>ELECTRICAL UNITS</b> .....	68	J
<b>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)</b> .....	16	Terminal Arrangement .....	68	PG
System Description .....	16	<b>STANDARDIZED RELAY</b> .....	69	L
CAN Communication System Description .....	17	Description .....	69	M
Function of Detecting Ignition Relay Malfunction ....	17	<b>SUPER MULTIPLE JUNCTION (SMJ)</b> .....	71	N
CONSULT-III Function (IPDM E/R) .....	17	Terminal Arrangement .....	71	O
Auto Active Test .....	19	<b>FUSE BLOCK-JUNCTION BOX (J/B)</b> .....	72	P
IPDM E/R Terminal Arrangement .....	22	Terminal Arrangement .....	72	
Terminal and Reference Value for IPDM E/R .....	23	<b>FUSE AND FUSIBLE LINK BOX</b> .....	73	
IPDM E/R Power/Ground Circuit Inspection .....	25	Terminal Arrangement .....	73	
Inspection with CONSULT-III (Self-Diagnosis) .....	26			
Removal and Installation of IPDM E/R .....	26			

# PRECAUTIONS

< SERVICE INFORMATION >

## SERVICE INFORMATION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000001704690

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.


#### **WARNING:**

- **To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.**
- **Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.**
- **Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.**



# POWER SUPPLY ROUTING CIRCUIT

< SERVICE INFORMATION >



AWMWA0064G

# POWER SUPPLY ROUTING CIRCUIT




< SERVICE INFORMATION >

## Wiring Diagram - POWER -

INFOID:000000001704692

### BATTERY POWER SUPPLY — IGNITION SWITCH IN ANY POSITION

PG-POWER-01





\* : (F39) IS AN INTEGRAL PART OF FUSIBLE LINK BOX (BATTERY) ASSEMBLY.

AWMWA0065G


# POWER SUPPLY ROUTING CIRCUIT

< SERVICE INFORMATION >

PG-POWER-02



REFER TO THE FOLLOWING.





WKWA5822E

# POWER SUPPLY ROUTING CIRCUIT

< SERVICE INFORMATION >

PG-POWER-03





LKWA0374E

# POWER SUPPLY ROUTING CIRCUIT

< SERVICE INFORMATION >

PG-POWER-04

AC : WITH A/C





AWMWA0066G

# POWER SUPPLY ROUTING CIRCUIT

< SERVICE INFORMATION >

PG-POWER-05

— : DATA LINE



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
PG  
L  
M  
N  
O  
P

LKWA0376E




# POWER SUPPLY ROUTING CIRCUIT

< SERVICE INFORMATION >

IGNITION POWER SUPPLY — IGNITION SWITCH IN ON

PG-POWER-07


 : WITH A/C



IG1	ST	B	(M26)
IG2	ACC	R	

W

REFER TO THE FOLLOWING.



AWMWA0067G

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P



PG

# POWER SUPPLY ROUTING CIRCUIT


< SERVICE INFORMATION >

IGNITION POWER SUPPLY — IGNITION SWITCH IN ON AND/OR START.

PG-POWER-08



REFER TO THE FOLLOWING.





LKWA0379E

# POWER SUPPLY ROUTING CIRCUIT

< SERVICE INFORMATION >

## PG-POWER-09



REFER TO THE FOLLOWING.  
 (M69) - SUPER MULTIPLE JUNCTION (SMJ)

AWMWA0068G



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
PG  
L  
M  
N  
O  
P

# POWER SUPPLY ROUTING CIRCUIT

< SERVICE INFORMATION >

IGNITION POWER SUPPLY — IGNITION SWITCH IN START

PG-POWER-10



REFER TO THE FOLLOWING.

(M69) - SUPER MULTIPLE JUNCTION (SMJ)

LKWA0380E


# POWER SUPPLY ROUTING CIRCUIT

## < SERVICE INFORMATION >

### Fuse

INFOID:000000001704693

- If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.




### Fusible Link

INFOID:000000001704694

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

#### CAUTION:

- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of malfunction.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.




### Circuit Breaker (Built Into BCM)

INFOID:000000001704695

For example, when current is 30A, the circuit is broken within 8 to 20 seconds.

A circuit breaker is used for the following systems:


- Power windows
- Power sunroof



### Circuit Breaker

INFOID:000000001704696

The PTC thermistor generates heat in response to current flow. The temperature (and resistance) of the thermistor element varies with current flow. Excessive current flow will cause the element's temperature to rise. When the temperature reaches a specified level, the electrical resistance will rise sharply to control the circuit current. Reduced current flow will cause the element to cool. Resistance falls accordingly and normal circuit current flow is allowed to resume.



# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< SERVICE INFORMATION >

## IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

### System Description

INFOID:000000001704697

- IPDM E/R (Intelligent Power Distribution Module Engine Room) integrates the relay box and fuse block which were originally placed in engine compartment. It controls integrated relays via IPDM E/R control circuits.
- IPDM E/R-integrated control circuits perform ON-OFF operation of relays, CAN communication control, oil pressure switch signal reception, etc.
- It controls operation of each electrical component via ECM, BCM and CAN communication lines.

#### **CAUTION:**

**None of the IPDM E/R integrated relays can be removed.**

### SYSTEMS CONTROLLED BY IPDM E/R

1. Lamp control  
Using CAN communication lines, it receives signals from the BCM and controls the following lamps:
  - Headlamps (High, Low)
  - Parking lamps
  - Tail and license plate lamps
  - Front fog lamps
2. Wiper control  
Using CAN communication lines, it receives signals from the BCM and controls the front wipers.
3. Rear window defogger relay control  
Using CAN communication lines, it receives signals from the BCM and controls the rear window defogger relay.
4. A/C compressor control  
Using CAN communication lines, it receives signals from the ECM and controls the A/C compressor (magnet clutch).
5. Starter control  
Using CAN communication lines, it receives signals from the BCM and controls the starter relay.
6. Cooling fan control  
Using CAN communication lines, it receives signals from the ECM and controls the cooling fan relays.
7. Horn control  
Using CAN communication lines, it receives signals from the BCM and controls the horn relay.
8. Daytime light system control (Canada only)  
Using CAN communication lines, it receives signals from the BCM and controls the daytime light relay.

### CAN COMMUNICATION LINE CONTROL

With CAN communication, by connecting each control unit using two communication lines (CAN L-line, CAN H-line), it is possible to transmit a maximum amount of information with minimum wiring. Each control unit can transmit and receive data, and reads necessary information only.

1. Fail-safe control
  - When CAN communication with other control units is impossible, IPDM E/R performs fail-safe control. After CAN communication returns to normal operation, it also returns to normal control.
  - Operation of control parts by IPDM E/R during fail-safe mode is as follows:

Controlled system	Fail-safe mode
Headlamp	<ul style="list-style-type: none"><li>• With the ignition switch ON, headlamp low relay is ON, headlamp high relays are OFF, and daytime light system (Canada only) is OFF.</li><li>• With the ignition switch OFF, the headlamp relays are OFF.</li></ul>
Tail, license plate and parking lamps	<ul style="list-style-type: none"><li>• With the ignition switch ON, the tail lamp relay is ON.</li><li>• With the ignition switch OFF, the tail lamp relay is OFF.</li></ul>
Cooling fan	<ul style="list-style-type: none"><li>• With the ignition switch ON, cooling fan relay-1, relay-2, and relay-3 are ON.</li><li>• With the ignition switch OFF, all cooling fan relays are OFF.</li></ul>
Front wiper	Until the ignition switch is turned off, the front wiper relays remain in the same status they were in just before fail-safe control was initiated.

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < SERVICE INFORMATION >

Controlled system	Fail-safe mode
Rear window defogger	Rear window defogger relay OFF
A/C compressor	A/C relay is OFF
Front fog lamps	Front fog lamp relay OFF

### IPDM E/R STATUS CONTROL

In order to save power, IPDM E/R switches status by itself based on each operating condition.

1. CAN communication status
  - CAN communication is normally performed with other control units.
  - Individual unit control by IPDM E/R is normally performed.
  - When sleep request signal is received from BCM, mode is switched to sleep waiting status.
2. Sleep waiting status
  - Process to stop CAN communication is activated.
  - All systems controlled by IPDM E/R are stopped. When 1 second has elapsed after CAN communication with other control units is stopped, mode switches to sleep status.
3. Sleep status
  - IPDM E/R operates in low current-consumption mode.
  - CAN communication is stopped.
  - When a change in CAN communication signal is detected, mode switches to CAN communication status.
  - When a change in ignition switch signal is detected, mode switches to CAN communication status.

### CAN Communication System Description

INFOID:000000001704698

Refer to [LAN-6. "System Description"](#).

### Function of Detecting Ignition Relay Malfunction

INFOID:000000001704699

- When the integrated ignition relay is stuck in a "closed contact" position and cannot be turned OFF, IPDM E/R turns ON tail and parking lamps for 10 minutes to indicate IPDM E/R malfunction.
- When the state of the integrated ignition relay does not agree with the state of the ignition switch signal received via CAN communication, the IPDM E/R activates the tail lamp relay.

Ignition switch signal	Ignition relay status	Tail lamp relay
ON	ON	—
OFF	OFF	—
ON	OFF	—
OFF	ON	ON (10 minutes)

#### NOTE:

When the ignition switch is turned ON, the tail lamps are OFF.

### CONSULT-III Function (IPDM E/R)

INFOID:000000001704700

CONSULT-III can display each diagnostic item using the diagnostic test modes shown following.

IPDM E/R diagnostic Mode	Description
SELF-DIAG RESULTS	Displays IPDM E/R self-diagnosis results.
DATA MONITOR	Displays IPDM E/R input/output data in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.

### SELF-DIAGNOSTIC RESULTS

Display Item List

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < SERVICE INFORMATION >

Display items	CONSULT-III display code	Malfunction detection	TIME		Possible causes
			CRNT	PAST	
NODTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	—	—	—	—	—
CAN COMM CIRC	U1000	<ul style="list-style-type: none"> <li>If CAN communication reception/transmission data has a malfunction, or if any of the control units fail, data reception/transmission cannot be confirmed.</li> <li>When the data in CAN communication is not received before the specified time.</li> </ul>	X	X	Any of items listed below have errors: <ul style="list-style-type: none"> <li>TRANSMIT DIAG</li> <li>ECM</li> <li>BCM/SEC</li> </ul>
IGN RELAY ON	—	When the ignition switch is not in the ON position, the ignition relay in the IPDM E/R is ON.	X	X	
IGN RELAY OFF	—	When the ignition switch is not in the ON position, the ignition relay in the IPDM E/R is OFF.	X	X	
EEPROM	—	Malfunction is detected with the integrated EEPROM memory diagnosis.	X	X	

x: Applicable

### NOTE:

The details for display of the period are as follows:

- CRNT: Error currently detected with IPDM E/R.
- PAST: Error detected in the past and placed in IPDM E/R memory.

## DATA MONITOR

All Signals, Main Signals, Selection From Menu

Item name	CONSULT-III screen display	Display or unit	Monitor item selection			Description
			ALL SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	
Motor fan request	MOTOR FAN REQ	1/2/3/4	X	X	X	Signal status input from ECM
Compressor request	AC COMP REQ	ON/OFF	X	X	X	Signal status input from ECM
Parking, license, and tail lamp request	TAIL & CLR REQ	ON/OFF	X	X	X	Signal status input from BCM
Headlamp low beam request	HL LO REQ	ON/OFF	X	X	X	Signal status input from BCM
Headlamp high beam request	HL HI REQ	ON/OFF	X	X	X	Signal status input from BCM
Front fog request	FR FOG REQ	ON/OFF	X	X	X	Signal status input from BCM
FR wiper request	FR WIP REQ	STOP/1LO/LO/HI	X	X	X	Signal status input from BCM
Wiper auto stop	WIP AUTO STOP	ACT P/STOP P	X	X	X	Output status of IPDM E/R
Wiper protection	WIP PROT	OFF/LS/HS/Block	X	X	X	Control status of IPDM E/R
Starter request	ST RLY REQ	ON/OFF	X		X	Status of input signal (*1)
Ignition relay status	IGN RLY	ON/OFF	X	X	X	Ignition relay status monitored with IPDM E/R
Rear defogger request	RR DEF REQ	ON/OFF	X	X	X	Signal status input from BCM
Oil pressure switch	OIL P SW	OPEN/CLOSE	X		X	Signal status input from IPDM E/R
Hood switch	HOOD SW (*2)	OFF	X		X	Signal status input from IPDM E/R

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < SERVICE INFORMATION >

Item name	CONSULT-III screen display	Display or unit	Monitor item selection			Description
			ALL SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	
Theft warning horn request	THFT HRN REQ	ON/OFF	X		X	Signal status input from BCM
Horn chirp	HORN CHIRP	ON/OFF	X		X	Output status of IPDM E/R
Daytime light request	DTRL REQ	ON/OFF	X		X	Signal status input from BCM

\*1 Perform monitoring of IPDM E/R data with the ignition switch ON. When the ignition switch is in ACC position, display may not be correct.

\*2 This item is displayed, but does not function.

### CAN DIAG SUPPORT MNTR

Refer to [LAN-8](#).

### ACTIVE TEST

#### Display Item List

Test name	CONSULT-III screen display	Description
Head, tail, fog lamp output	EXTERNAL LAMPS	With a certain ON-OFF operation (OFF, TAIL, LO, HI, FOG), the front fog lamp, headlamp low, headlamp high RH, headlamp high LH, and tail lamp relays can be operated.
Rear defogger output	REAR DEFOGGER	With a certain ON-OFF operation, the rear defogger relay can be operated.
Front wiper (HI, LO) output	FRONT WIPER	With a certain operation (OFF, HI ON, LO ON), the front wiper relays (Lo, Hi) can be operated.
Cooling fan output	MOTOR FAN	With a certain operation (1, 2, 3, 4), the cooling fan relays can be operated.
Horn output	HORN	With a certain ON-OFF operation, the horn relay can be operated.

### Auto Active Test

INFOID:000000001704701

#### DESCRIPTION

- In auto active test mode, operation inspection can be performed when IPDM E/R sends a drive signal to the following systems:
  - Rear window defogger
  - Front wipers
  - Tail, license and parking lamps
  - Daytime lamp system (Canada only)
  - Front fog lamps
  - Headlamps (High, Low)
  - A/C compressor (magnet clutch)
  - Cooling fan

#### OPERATION PROCEDURE

1. Close hood and front door RH, and lift wiper arms away from windshield (to prevent glass damage by wiper operation).
 

**NOTE:**  
When auto active test is performed with hood opened, sprinkle water on windshield beforehand.
2. Turn ignition switch OFF.
3. Turn ignition switch ON and, within 20 seconds, press front door switch LH 20 times. Then turn ignition switch OFF.
4. Turn ignition switch ON within 10 seconds after ignition switch OFF.
5. When auto active test mode is actuated, horn chirps once.
6. After a series of operations is repeated three times, auto active test is completed.

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < SERVICE INFORMATION >

**NOTE:**


When auto active test mode has to be cancelled halfway, turn ignition switch OFF.

**CAUTION:**

Be sure to perform [BL-37, "Door Switch Check \(Hatchback\)"](#) when the auto active test cannot be performed.

### INSPECTION IN AUTO ACTIVE TEST MODE

When auto active test mode is actuated, the following six steps are repeated three times.




(A): Oil pressure warning lamp is blinking when the auto active test is operating.

Item Number	Test Item	Operation Time/Frequency
1	Rear window defogger	10 seconds
2	Front wipers	LOW 5 seconds then HIGH 5 seconds
3	Daytime light system (Canada only)	10 seconds
3	Tail, license, and parking lamps	10 seconds
3	Front fog lamps	10 seconds
4	Headlamps (low)	20 seconds
4	Headlamps (high)	ON-OFF 5 times
5	A/C compressor (magnet clutch)	ON-OFF 5 times
6	Cooling fan	LOW 5 seconds then HIGH 5 seconds

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < SERVICE INFORMATION >

### Concept of Auto Active Test



- IPDM E/R actuates auto active test mode when it receives door switch signal from BCM via CAN communication line. Therefore, when auto active test mode is activated successfully, CAN communication between IPDM E/R and BCM is normal.
- If any of the systems controlled by IPDM E/R cannot be operated, possible cause can be easily diagnosed using auto active test.

Diagnosis chart in auto active test mode


Symptom	Inspection contents	Possible cause
Rear window defogger does not operate.	Perform auto active test. Does rear window defogger operate?	YES <ul style="list-style-type: none"> <li>• BCM signal input circuit</li> </ul>
		NO <ul style="list-style-type: none"> <li>• Rear window defogger relay</li> <li>• Open circuit of rear window defogger</li> <li>• IPDM E/R malfunction</li> <li>• Harness or connector malfunction between IPDM E/R and rear window defogger</li> </ul>
Any of front wipers, tail and parking lamps, front fog lamps, daytime light system (Canada only), and headlamps (High, Low) do not operate.	Perform auto active test. Does system in question operate?	YES <ul style="list-style-type: none"> <li>• BCM signal input system</li> </ul>
		NO <ul style="list-style-type: none"> <li>• Lamp/wiper motor malfunction</li> <li>• Lamp/wiper motor ground circuit malfunction</li> <li>• Harness/connector malfunction between IPDM E/R and system in question</li> <li>• IPDM E/R (integrated relay) malfunction</li> </ul>
A/C compressor does not operate.	Perform auto active test. Does magnet clutch operate?	YES <ul style="list-style-type: none"> <li>• BCM signal input circuit</li> <li>• CAN communication signal between BCM and ECM</li> <li>• CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO <ul style="list-style-type: none"> <li>• Magnet clutch malfunction</li> <li>• Harness/connector malfunction between IPDM E/R and magnet clutch</li> <li>• IPDM E/R (integrated relay) malfunction</li> </ul>
Cooling fan does not operate.	Perform auto active test. Does cooling fan operate?	YES <ul style="list-style-type: none"> <li>• ECM signal input circuit</li> <li>• CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO <ul style="list-style-type: none"> <li>• Cooling fan motor malfunction</li> <li>• Harness/connector malfunction between IPDM E/R and cooling fan motor</li> <li>• IPDM E/R (integrated relay) malfunction</li> </ul>
Oil pressure warning lamp does not operate.	Perform auto active test. Does oil pressure warning lamp blink?	YES <ul style="list-style-type: none"> <li>• Harness/connector malfunction between IPDM E/R and oil pressure switch</li> <li>• Oil pressure switch malfunction</li> <li>• IPDM E/R</li> </ul>
		NO <ul style="list-style-type: none"> <li>• CAN communication signal between BCM and combination meter</li> <li>• Combination meter</li> </ul>

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< SERVICE INFORMATION >

## IPDM E/R Terminal Arrangement

INFOID:000000001704702



WKIA5666E

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< SERVICE INFORMATION >

## Terminal and Reference Value for IPDM E/R

INFOID:000000001704703

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value (Approx.)
				Ignition switch	Operation or condition	
1	R	Battery power supply	Input	OFF	—	Battery voltage
2	G	Battery power supply	Input	OFF	—	Battery voltage
3	Y	ECM Relay	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
4	G	ECM relay	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
6	R	Daytime light relay control	Input	ON	Daytime light system active.	Less than battery voltage
					Daytime light system inactive.	Battery voltage
7	G	ECM relay control	Input	—	Ignition switch ON or START	0V
					Ignition switch OFF or ACC	Battery voltage
8	G	Throttle control motor relay	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
11	W	A/C compressor	Output	ON or START	A/C switch ON or defrost A/C switch	Battery voltage
					A/C switch OFF or defrost A/C switch	0V
12	O	Ignition switch supplied power	Input	—	OFF or ACC	0V
					ON or START	Battery voltage
14	LG (M/T) R (A/T or CVT)	Fuse 49	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
15	V	Fuse 50	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
16	BR	Fuse 51	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
17	Y	Battery power supply	Output	—	—	Battery voltage
19	R	Starter motor	Output	START	—	Battery voltage
20	L (with A/C) LG (without A/C)	Cooling fan relay-1	Output	—	Conditions correct for cooling fan low operation.	Battery voltage
					Conditions not correct for cooling fan low operation.	0V
22	G	Battery power supply	Input	—	—	Battery voltage
23	L	Cooling fan relay-2	Input	—	Conditions correct for cooling fan high operation	Battery voltage
					Conditions not correct for cooling fan high operation	0V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PG

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < SERVICE INFORMATION >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value (Approx.)
				Ignition switch	Operation or condition	
24	Y	Cooling fan relay-3	Output	—	Conditions correct for cooling fan high operation	Battery voltage
					Conditions not correct for cooling fan high operation	0V
26	O	Tail lamp relay (parking lamps)	Output	—	Lighting switch in 2nd position	Battery voltage
27	BR	Tail lamp relay (parking lamps)	Output	—	Lighting switch in 2nd position	Battery voltage
28	GR	Tail lamp relay (parking lamps)	Output	—	Lighting switch in 2nd position	Battery voltage
29	P	Tail lamp relay (parking lamps)	Output	—	Lighting switch in 2nd position	Battery voltage
30 (A/T only)	R	Fuse 54	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
31	O	Fuse 55	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
32	L	Wiper high speed signal	Output	ON or START	Wiper switch OFF, LO, INT	0V
					Wiper switch HI	Battery voltage
33	Y	Wiper low speed signal	Output	ON or START	Wiper switch OFF	0V
					Wiper switch LO or INT	Battery voltage
35	BR	Starter relay (inhibit switch)	Input	ON or START	Selector lever in "P" or "N" (CVT or A/T) or clutch pedal depressed (M/T)	Battery voltage
					Selector lever any other position (CVT or A/T) or clutch pedal released (M/T)	0V
36	BR	Fuel pump relay	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
37	G	Oil pressure switch	Input	ON or START	Engine running and oil pressure within specification	Battery voltage
					Engine not running or oil pressure below specification	0V
38	R	Wiper auto stop signal	Input	ON or START	Wipers not in park position	Battery voltage
					Wipers in park position	0V
39	B	Ground	Input	—	—	0V
40	P	CAN-L	—	ON	—	—
41	L	CAN-H	—	ON	—	—
45	R	Horn relay control	Input	—	Horn switch PUSHED, alarm switch activated or door lock/unlock is confirmed when operating lock system via the keyfob	0V
					Horn switch released, alarm not active, keyfob not active	Battery voltage
46	Y	Throttle control motor relay control	Input	—	Ignition switch ON or START	0V
					Ignition switch OFF or ACC	Battery voltage
47	GR	Fuel pump relay control	Input	—	Ignition switch ON or START	0V
					Ignition switch OFF or ACC	Battery voltage

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < SERVICE INFORMATION >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value (Approx.)	
				Ignition switch	Operation or condition		
50	V	Front fog lamp (LH)	Output	ON or START	Lighting switch must be in the 2ND position (LOW beam is ON) and the front fog lamp switch	OFF	0V
						ON	Battery voltage
51	W	Front fog lamp (RH)	Output	ON or START	Lighting switch must be in the 2ND position (LOW beam is ON) and the front fog lamp switch	OFF	0V
						ON	Battery voltage
52	L	LH Low beam head-lamp	Output	—	Lighting switch in 2nd position		Battery voltage
54	P	RH Low beam head-lamp	Output	—	Lighting switch in 2nd position		Battery voltage
55	G	LH High beam head-lamp	Output	—	Lighting switch in 2nd position and placed in HIGH or PASS position		Battery voltage
56	Y	RH High beam head-lamp	Output	—	Lighting switch in 2nd position and placed in HIGH or PASS position		Battery voltage
59	B	Ground	Input	—	—		0V
60	R	Rear window defogger relay	Output	ON or START	Rear defogger Switch ON		Battery voltage
					Rear defogger Switch OFF		0V

## IPDM E/R Power/Ground Circuit Inspection

INFOID:000000001704704

### 1. FUSE AND FUSIBLE LINK INSPECTION

Check that the following fusible links or IPDM E/R fuses are not blown.

Terminal No.	Signal name	Fuse, fusible link No.
1, 2	Battery power	a, b, d

#### OK or NG

OK >> GO TO 2.

NG >> Replace fuse or fusible link.

### 2. POWER CIRCUIT INSPECTION

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R harness connector E42.
3. Check voltage between IPDM E/R harness connector E42 terminals 1, 2 and ground.


# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < SERVICE INFORMATION >

**Battery voltage should exist.**

### OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace IPDM E/R power circuit harness.




## 3. GROUND CIRCUIT INSPECTION

1. Disconnect IPDM E/R harness connectors E46 and E48.
2. Check continuity between IPDM E/R harness connector E46 (A) terminal 39, E48 (B) terminal 59 and ground.

**Continuity should exist.**

### OK or NG

- OK >> Inspection End.
- NG >> Repair or replace IPDM E/R ground circuit harness.



## Inspection with CONSULT-III (Self-Diagnosis)

INFOID:000000001704705

### 1. SELF-DIAGNOSIS RESULT CHECK

1. Connect CONSULT-III and select "IPDM E/R" on the "SELECT SYSTEM" screen.
2. Select "SELF-DIAG RESULTS" on the "SELECT DIAG MODE" screen.
3. Check display content in self-diagnosis results.

CONSULT-III Display	CONSULT-III display code	TIME		Details of diagnosis result
		CRNT	PAST	
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	—	—	—	No malfunction
CAN COMM CIRC	U1000	X	X	Any of items listed below have errors: • TRANSMIT DIAG • ECM • BCM/SEC

### NOTE:

The Details for Display for the Period are as follows:

- CRNT: Error currently detected by IPDM E/R.
- PAST: Error detected in the past and stored in IPDM E/R memory.

### Contents displayed

NO DTC DETECTED. FURTHER TESTING MAY BE REQUIRED.>>Inspection End.

CAN COMM CIRC>>Print out the self-diagnosis result and refer to [LAN-15. "Trouble Diagnosis Flow Chart"](#).

## Removal and Installation of IPDM E/R

INFOID:000000001704706


↶: Vehicle front

### REMOVAL

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < SERVICE INFORMATION >

1. Lift up the IPDM E/R while pushing and opening pawls (A) or (B), and remove the IPDM E/R while pushing and opening the other side pawls.
2. Disconnect harness connector.



## INSTALLATION

Installation is the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PG

# GROUND CIRCUIT


< SERVICE INFORMATION >

## GROUND CIRCUIT

### Ground Distribution

INFOID:000000001704707

### MAIN HARNESS



# GROUND CIRCUIT

< SERVICE INFORMATION >

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

Preceding page



Next page





CONNECTOR NUMBER	CONNECT TO
(M10)	Instrument panel antenna (shield) (with hatchback early production)
(M36)	Front passenger airbag OFF indicator
(M36)	A/T device (Terminal No. 2)
(M38)	A/T device (Terminal No. 6)
(M38)	CVT device (Park position switch)
(M36)	CVT device (Overdrive control switch) (Terminal No. 2)
(M38)	CVT device (Terminal No. 6)
(M52)	Intelligent key unit
(M55)	Hazard switch
(M73)	Key switch and ignition knob switch

PG



AWMIA0119GB

# GROUND CIRCUIT

< SERVICE INFORMATION >



Preceding page







AWMIA0141GB

# GROUND CIRCUIT

< SERVICE INFORMATION >

## ENGINE ROOM HARNESS





A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

PG


WKIA5992E

# GROUND CIRCUIT


< SERVICE INFORMATION >



Preceding page



CONNECTOR NUMBER	CONNECT TO
(E3)	Cooling fan motor (Terminal No. 2) with A/C
(E3)	Cooling fan motor (Terminal No. 4) without A/C
(E25)	Front combination lamp LH
(E27)	Front fog lamp LH
(E30)	Front combination lamp RH
(E38)	Daytime light relay 2
(E40)	Brake fluid level switch
(E46)	IPDM E/R (Intelligent power distribution module engine room) (Terminal No. 39)
(E48)	IPDM E/R (Intelligent power distribution module engine room) (Terminal No. 59)
(E53)	Front combination lamp LH






CONNECTOR NUMBER	CONNECT TO
(E33)	ABS actuator and electric unit (Control unit) (Terminal No. 1) (with ABS)
(E33)	ABS actuator and electric unit (Control unit) (Terminal No. 4) (with ABS)

AWMIA0142GB

# GROUND CIRCUIT

< SERVICE INFORMATION >

## ENGINE CONTROL HARNESS






WKIA5648E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
PG  
L  
M  
N  
O  
P

# GROUND CIRCUIT

< SERVICE INFORMATION >

## BODY HARNESS




AWMIA0120GB




# GROUND CIRCUIT

< SERVICE INFORMATION >


## BACK DOOR HARNESS (HATCHBACK)



Preceding page



CONNECTOR NUMBER	CONNECT TO
D404	Rear wiper motor
D405	Back door lock assembly (Terminal No. 2)
D405	Back door lock assembly (Terminal No. 4)
D406	Back door request switch
D407	High-mounted stop lamp
D408	Back door opener switch



CONNECTOR NUMBER	CONNECT TO
D413	Rear window defogger (hatchback)

WKIA5995E

# HARNESS

< SERVICE INFORMATION >

## HARNESS

### Harness Layout

INFOID:000000001704708


#### HOW TO READ HARNESS LAYOUT

The following Harness Layouts use a map style grid to help locate connectors on the drawings:


- Main Harness
- Engine Room Harness (LH View)
- Engine Room Harness (RH View)
- Engine Control Harness
- Body Harness (Hatchback)
- Body Harness (Sedan)
- Body No. 2 Harness (Hatchback)
- Body No. 2 Harness (Sedan)
- Room Lamp Harness
- Back Door Harness (Hatchback Only)

#### To use the grid reference

1. Find the desired connector number on the connector list.
2. Find the grid reference.
3. On the drawing, find the crossing of the grid reference letter column and number row.
4. Find the connector number in the crossing zone.
5. Follow the line to the connector.



#### OUTLINE




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
PG  
L  
M  
N  
O  
P

# HARNESS

< SERVICE INFORMATION >

## MAIN HARNESS



G1	M1	W/16	: To R1	D2	M44	W/16	: Audio unit
B3	M2	B/5	: Passenger select unlock relay	D2	M45	W/12	: Audio unit
B2	M3	W/1	: Fuse block (J/B)	A1	M46	BR/2	: Front tweeter LH
B3	M4	W/1	: Fuse block (J/B)	G1	M47	BR/2	: Front tweeter RH
B3	M5	W/3	: Illumination control switch	B2	M48	L/4	: Heated mirror relay

# HARNESS


## < SERVICE INFORMATION >

C2	M6	W/4	: Steering lock solenoid	E2	M52	W/40	: Intelligent key unit	A
B3	M7	W/16	: Door mirror remote control switch	B2	M53	W/16	: EPS control unit	
A3	M8	W/16	: To D2	B3	M54	B/2	: EPS control unit	
A3	M9	W/16	: To D1	C3	M55†	W/4	: Hazard switch (hatchback early production)	B
E2	M10	GR/2	: Instrument panel antenna	D2	M55††	W/4	: Hazard switch (hatchback late production or sedan)	C
G3	M11	W/4	: To B106	B2	M57	—	: Body ground	
G4	M12	W/16	: To B101	F2	M59	W/2	: Glove box lamp	
G3	M13	W/24	: To B102	C1	M60	L/2	: EPS control unit	D
G3	M14	W/24	: To B120	F1	M61	—	: Body ground	
B4	M15	W/16	: To B23	E2	M62	W/2	: Front blower motor	E
B4	M16	W/24	: To B24	C1	M63	W/4	: Torque sensor	
D5	M17	B/1	: Parking brake switch	A2	M69	SMJ	: To E7	
F2	M18	W/40	: BCM (body control module)	B2	M73	GR/6	: Key switch and ignition knob switch (With intelligent key)	F
F2	M19	W/15	: BCM (body control module)	G3	M74	W/12	: To D102	
F3	M20	B/15	: BCM (body control module)	G3	M75	W/12	: To D101	G
C2	M21	W/4	: NATS antenna amp.	F2	M77	Y/4	: Front passenger air bag module	
B3	M22	W/16	: Data link connector	A2	M78	B/2	: To E11	H
E3	M23	W/4	: Remote keyless entry receiver	B1	M79	—	: Body ground	
C1	M24	W/40	: Combination meter	D3	M150	W/4	: To M32	I
C3	M25	/2	: Diode-1	C3	M151	W/4	: Front blower motor resistor	
B2	M26	W/6	: Ignition switch					
C2	M27	GR/6	: Key switch and key lock solenoid					J
C2	M28	W/16	: Combination switch					
C3	M29	Y/6	: Combination switch (spiral cable)					
C3	M30	GR/8	: Combination switch (spiral cable)					PG
E3	M32	W/4	: To M150					
D2	M33	B/15	: Front air control					
D4	M35	Y/28	: Air bag diagnosis sensor unit					L
D2	M36†	W/3	: Front passenger air bag OFF indicator (hatchback early production)					
C3	M36††	W/3	: Front passenger air bag OFF indicator (hatchback late production or sedan)					M
D4	M38	W/6	: A/T device					
D4	M38	W/6	: CVT device (without intelligent key)					N
D4	M38	W/8	: CVT device (with intelligent key)					
B3	M39	W/2	: Tire pressure warning check connector					O
D2	M41	W/2	: Defrost A/C switch					
D3	M42	W/3	: Thermo control amp. (without CVT)					P
D2	M43	W/20	: Audio unit					

# HARNESS

< SERVICE INFORMATION >

## ENGINE ROOM HARNESS (LH VIEW)



Refer to "ENGINE ROOM HARNESS (RH VIEW)" for continuation of engine room harness.

LKIA0815E

C4	E3	GR/4	: Cooling fan motor (without A/C)	C3	E47	BR/8	: IPDM E/R (Intelligent Power Distribution Module Engine Room)
C4	E3	B/2	: Cooling fan motor (with A/C)	D3	E48	B/6	: IPDM E/R (Intelligent Power Distribution Module Engine Room)
C4	E5	GR/3	: Resistor	D1	E51	B/2	: Front wheel sensor LH

# HARNESS


## < SERVICE INFORMATION >

C3	E6	—	: Fuse and fusible link box	D3	E53	B/2	: Front combination lamp LH (parking)	A
B1	E7	SMJ	: To M69					
D3	E8	SMJ	: To F8					B
B4	E9	BR/2	: Fusible link box (battery)					
B3	E10	GR/2	: Fusible link box (battery)					
B1	E11	B/2	: To M78					C
A3	E12	B/6	: Accelerator pedal position sensor					
A2	E13	B/2	: Stop lamp switch (with M/T)					D
A2	E13	W/4	: Stop lamp switch (without M/T)					
D3	E14	—	: Engine ground (crash zone sensor)					
C2	E15	—	: Engine ground					E
B2	E16	B/32	: ECM					
C5	E18	B/1	: Horn (low)					
C4	E19	GR/6	: To F33					F
D5	E20	B/1	: Horn (low)					
D3	E25	B/3	: Front combination lamp LH (headlamp)					G
E4	E27	B/2	: Front fog lamp LH					
D4	E29	B/2	: Front combination lamp LH (turn signal)					H
B1	E31	W/24	: TCM					
B1	E32	GR/24	: TCM					I
A2	E34	BR/2	: Clutch interlock switch (with M/T)					
A2	E35	BR/2	: ASCD clutch switch					J
A2	E36	BR/2	: ASCD brake switch					
B4	E40	GR/2	: Brake fluid level switch					
D3	E42	B/2	: IPDM E/R (Intelligent Power Distribution Module Engine Room)					PG
C3	E43	W/16	: IPDM E/R (Intelligent Power Distribution Module Engine Room)					L
C3	E44	W/6	: IPDM E/R (Intelligent Power Distribution Module Engine Room)					
D3	E45	BR/12	: IPDM E/R (Intelligent Power Distribution Module Engine Room)					M
D3	E46	W/12	: IPDM E/R (Intelligent Power Distribution Module Engine Room)					N

# HARNESS

< SERVICE INFORMATION >

## ENGINE ROOM HARNESS (RH VIEW)



Refer to "ENGINE ROOM HARNESS (LH VIEW)" for continuation of engine room harness.

G2	E1	GR/5	: Front wiper motor	D3	E30	B/2	: Front combination lamp RH (turn signal)
C3	E2	B/2	: Front and rear washer motor	F2	E33	B/26	: ABS actuator and electric unit (control unit)
F5	E4	Y/2	: Crash zone sensor	E2	E37	B/5	: Daytime light relay 1

# HARNESS

## < SERVICE INFORMATION >

E4	E17	B/3	: Refrigerant pressure sensor	D2	E38	L/5	: Daytime light relay 2
E5	E21	B/1	: Horn (high)	E2	E41	—	: Ground (ABS)
E5	E22	B/1	: Horn (high)	C3	E50	W/2	: Washer fluid level switch
D2	E24	—	: Engine ground	D1	E52	B/2	: Front wheel sensor RH
C3	E26	B/3	: Front combination lamp RH (headlamp)	D2	E54	B/2	: Front combination lamp RH (parking)
C4	E28	B/2	: Front fog lamp RH				

A  
B  
C

D

E

F

G

H

I

J

**PG**

L

M

N


O

P

# HARNESS

< SERVICE INFORMATION >

## ENGINE CONTROL HARNESS




B4	F1	B/3	: Generator	E4	F39	—	: Fusible link box (battery)
B5	F2	—	: Generator	E4	F40	—	: Fusible link box (battery)
B5	F3	B/1	: A/C compressor	E2	F41	GR/2	: Vehicle speed sensor
B4	F4	—	: Generator	F5	F45	GR/3	: Turbine revolution sensor
A4	F5	—	: Generator ground	E5	F46	GR/22	: CVT unit

# HARNESS

## < SERVICE INFORMATION >

E3	F6	GR/2	: Engine coolant temperature sensor	E5	F47	B/3	: Powertrain revolution sensor (with A/T)	A
D2	F7	B/6	: Electric throttle control actuator	E3	F48	B/3	: Secondary speed sensor (with M/T)	B
G4	F8	SMJ	: To E8					C
B4	F9	—	: Engine ground					D
G2	F10	GR/32	: ECM					E
G2	F11	BR/48	: ECM					F
D3	F12	GR/4	: Air fuel ratio (A/F) sensor 1					G
E2	F13	B/4	: Heated oxygen sensor 2					H
C4	F14	B/2	: Knock sensor					I
D3	F15	B/3	: Crankshaft position sensor (POS)					J
C4	F16	—	: Engine ground					PG
B4	F17	GR/2	: Fuel injector No. 1					L
C4	F18	GR/2	: Fuel injector No. 2					M
C4	F19	GR/2	: Fuel injector No. 3					N
D4	F20	GR/2	: Fuel injector No. 4					O
D4	F21	B/3	: Camshaft position sensor (PHASE)					P
C3	F22	GR/2	: EVAP canister purge volume control solenoid valve					
B3	F23	GR/2	: Intake valve timing control solenoid valve					
E5	F24	G/3	: Park/neutral position (PNP) switch (with M/T)					
F5	F25	B/10	: Park/neutral position (PNP) switch (with A/T)					
C3	F26	W/2	: Condenser-2					
C5	F27	—	: Starter motor					
C5	F28	—	: Starter motor					
F5	F30	B/8	: Terminal cord assembly					
F2	F31	B/6	: Mass air flow sensor					
C5	F32	GR/1	: Oil pressure switch					
F5	F33	GR/6	: To E19					
C3	F34	GR/3	: Ignition coil No. 1 (with power transistor)					
C3	F35	GR/3	: Ignition coil No. 2 (with power transistor)					
C3	F36	GR/3	: Ignition coil No. 3 (with power transistor)					
C3	F37	GR/3	: Ignition coil No. 4 (with power transistor)					
E5	F38	BR/3	: Revolution sensor					

## BODY HARNESS (HATCHBACK)



# HARNESS


## < SERVICE INFORMATION >

G4	B2	GR/2	: Rear bumper antenna				
C4	B4	W/8	: To D201				
C4	B5	—	: Body ground				
E4	B6	W/1	: Rear door switch LH				
C4	B7	—	: Body ground				
C4	B8	W/3	: Front door switch LH				
C4	B9	Y/12	: Air bag diagnosis sensor unit				
C4	B10	Y/2	: Front LH side air bag module				
F3	B13	W/3	: Seat belt buckle switch LH				
C4	B14	Y/2	: Front LH seat belt pre-tensioner				
C5	B15	Y/2	: LH side air bag (satellite) sensor				
G4	B16	BR/2	: License plate lamp LH				
G4	B17	BR/2	: License plate lamp RH				
F3	B19	—	: Body ground				
F3	B21	W/2	: Luggage room lamp				
A4	B23	W/16	: To M15				
A4	B24	W/24	: To M16				
F3	B25	BR/6	: Rear combination lamp LH				
F3	B26	Y/2	: LH side curtain air bag module				
F4	B29	W/6	: Subwoofer				
F4	B30	W/16	: Satellite radio tuner				

# HARNESS

< SERVICE INFORMATION >

## BODY HARNESS (SEDAN)



G4	B2	GR/2	: Rear bumper antenna				
C4	B4	W/8	: To D201				
C4	B5	—	: Body ground				
D3	B6	W/1	: Rear door switch LH				
C3	B7	—	: Body ground				

# HARNESS


## < SERVICE INFORMATION >

C4	B8	W/3	: Front door switch LH				
B3	B9	Y/12	: Air bag diagnosis sensor unit				
B3	B10	Y/2	: Front LH side air bag module				
B4	B13	W/3	: Seat belt buckle switch LH				
C4	B14	Y/2	: Front LH seat belt pre-tensioner				
C5	B15	Y/2	: LH side air bag (satellite) sensor				
E3	B19	—	: Body ground				
F2	B21	W/2	: Luggage room lamp				
A4	B23	W/16	: To M15				
A4	B24	W/24	: To M16				
G4	B25	BR/6	: Rear combination lamp LH				
E3	B26	Y/2	: LH side curtain air bag module				
E4	B30	W/16	: Satellite radio tuner				
F2	B31	W/2	: High mounted stop lamp				
F3	B32	BR/2	: Intelligent key warning buzzer (trunk)				

# HARNESS

< SERVICE INFORMATION >

## BODY NO. 2 HARNESS (HATCHBACK)



D3	B100	GR/5	: Fuel level sensor unit and fuel pump			
G5	B101	W/16	: To M12			
G5	B102	W/24	: To M13			
F3	B103	B/2	: Console power socket			
A4	B104	GR/3	: EVAP control system pressure sensor			

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P


PG

# HARNESS

## < SERVICE INFORMATION >

A3	B105	B/2	: EVAP canister vent control valve				
G5	B106	W/4	: To M11				
A2	B107	BR/6	: Rear combination lamp RH				
E4	B108	W/3	: Front door switch RH				
F4	B109	Y/2	: Front RH side air bag module				
F4	B110	W/10	: To B300				
E5	B111	Y/2	: RH side air bag (satellite) sensor				
F4	B112	W/3	: Seat belt buckle switch RH				
F3	B113	Y/12	: Air bag diagnosis sensor unit				
E4	B114	—	: Body ground				
E4	B115	Y/2	: Front RH seat belt pre-tensioner				
C3	B116	W/1	: Rear door switch RH				
E3	B117	—	: Body ground				
B2	B118	Y/2	: RH side curtain air bag module				
D3	B119	W/8	: To D301				
G5	B120	W/24	: To M14				
A3	B121	W/32	: Bluetooth control unit				
A3	B122	GR/1	: Bluetooth control unit				
D2	B123	B/2	: Rear wheel sensor LH				
C3	B124	B/2	: Rear wheel sensor RH				
F3	B125	GR/2	: Front console antenna				
C3	B126	GR/2	: Rear floor antenna				
A2	B132	—	: Body ground				
B2	B133	W/2	: To D400				
A2	B134	W/12	: To D401				
E5	B138	B/3	: Belt tension sensor				

## BODY NO. 2 HARNESS (SEDAN)



# HARNESS


## < SERVICE INFORMATION >

E3	B100	GR/5	: Fuel level sensor unit and fuel pump					A
G5	B101	W/16	: To M12					
G5	B102	W/24	: To M13					
F4	B103	B/2	: Console power socket					B
B4	B104	GR/3	: EVAP control system pressure sensor					C
B3	B105	B/2	: EVAP canister vent control valve					
G5	B106	W/4	: To M11					
A2	B107	BR/6	: Rear combination lamp RH					D
F4	B108	W/3	: Front door switch RH					
F4	B109	Y/2	: Front RH side air bag module					
F4	B110	W/10	: To B300					E
E5	B111	Y/2	: RH side air bag (satellite) sensor					
F4	B112	W/3	: Seat belt buckle switch RH					F
G3	B113	Y/12	: Air bag diagnosis sensor unit					
E4	B114	—	: Body ground					
E4	B115	Y/2	: Front RH seat belt pre-tensioner					G
C3	B116	W/1	: Rear door switch RH					
E3	B117	—	: Body ground					H
C2	B118	Y/2	: RH side curtain air bag module					
E4	B119	W/8	: To D301					
G5	B120	W/24	: To M14					I
C3	B121	W/32	: Bluetooth control unit					
B3	B122	GR/1	: Bluetooth control unit					J
E3	B123	B/2	: Rear wheel sensor LH					
D4	B124	B/2	: Rear wheel sensor RH					
F4	B125	GR/2	: Front console antenna					PG
D3	B126	GR/2	: Rear floor antenna					
B2	B127	W/3	: Trunk lamp switch and trunk release solenoid					L
B1	B128	BR/2	: Trunk lid opener switch					
B1	B129	GR/2	: Trunk opener request switch					M
C2	B130	B/1	: Condenser-1					
C2	B131	B/1	: Condenser-1					
C3	B132	—	: Body ground					N
E5	B138	B/3	: Belt tension sensor					
D1	B139	—	: Body ground					
C2	B140	B/1	: Rear window defogger (+)					O
D1	B141	B/1	: Rear window defogger (-)					
B2	B142	W/3	: Trunk key cylinder switch					P
B1	B143	BR/2	: License plate lamp RH					
B2	B144	BR/2	: License plate lamp LH					

# HARNESS

< SERVICE INFORMATION >

## ROOM LAMP HARNESS



LKIA0820E


D5	R1	W/16	: To M1				
F2	R2	GR/6	: Map lamp				
F2	R3	W/3	: Map lamp				
F2	R4	GR/10	: Sunroof motor assembly				
F2	R6	W/3	: Sunroof switch				

# HARNESS

## < SERVICE INFORMATION >

D1	R7	W/3	: Interior room lamp				
E2	R8	W/3	: To R50 (without map lamps)				
G2	R9	W/2	: Vanity mirror lamp LH				
D3	R10	W/2	: Vanity mirror lamp RH				
D1	R15	W/8	: Microphone				


## FRONT DOOR LH HARNESS



D1	W/16	: To M9	D8	W/3	: Main power window and door lock/ unlock switch
D2	W/16	: To M8	D9	B/6	: Front power window motor LH
D3	B/6	: Front door lock actuator LH	D10	GR/2	: Front outside antenna LH
D4	BR/8	: Door mirror LH	D12	W/2	: Front door speaker LH
D5	GR/2	: Front door request switch LH	D14	BR/3	: Front door key cylinder switch LH
D6	BR/2	: Intelligent key warning buzzer (front door LH)			
D7	W/16	: Main power window and door lock/ unlock switch			

# HARNESS

## < SERVICE INFORMATION > FRONT DOOR RH HARNESS




LKIA0822E

D101	W/12	: To M75	D106	GR/2	: Front outside antenna RH
D102	W/12	: To M74	D107	BR/8	: Door mirror RH
D103	GR/2	: Front door request switch RH	D112	W/2	: Front door speaker RH
D104	BR/2	: Front power window motor RH	D114	B/6	: Front door lock actuator RH
D105	W/12	: Power window and door lock/unlock switch RH			

# HARNESS

< SERVICE INFORMATION >

## REAR DOOR LH HARNESS




LKIA0824E

D201	W/8	: To B4	D205	B/6	: Rear door lock actuator LH
D203	W/8	: Rear power window switch LH	D207	W/2	: Rear door speaker LH
D204	BR/2	: Rear power window motor LH			

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
PG  
L  
M  
N  
O  
P

# HARNESS

< SERVICE INFORMATION >  
**REAR DOOR RH HARNESS**




LKIA0823E

D301	W/8	: To B119	D305	B/6	: Rear door lock actuator RH
D303	W/8	: Rear power window switch RH	D307	W/2	: Rear door speaker RH
D304	BR/2	: Rear power window motor RH			

# HARNESS

< SERVICE INFORMATION >

## BACK DOOR HARNESS (HATCHBACK ONLY)



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

PG

LKIA0825E

G3	D400	W/12	: To B133			
G3	D401	W/12	: To B134			
G3	D401	W/24	: To B48 (without power back door)			
E4	D402	—	: Body ground			
F3	D403	—	: Body ground			

# HARNESS

## < SERVICE INFORMATION >

D3	D404	W/3	: Rear wiper motor				
D4	D405	W/4	: Back door lock assembly				
D4	D406	W/2	: Back door request switch				
E2	D407	W/2	: High mounted stop lamp				
D4	D408	BR/2	: Back door opener switch				
E4	D409	B/1	: Condenser-1				
C2	D410	—	: Body ground				
E3	D411	B/1	: Condenser-1				
E1	D412	B/1	: Rear window defogger (+)				
C2	D413	B/1	: Rear window defogger (-)				
F3	D414	—	: Body ground				

## Wiring Diagram Codes (Cell Codes)

INFOID:000000001704709

Use the chart below to find out what each wiring diagram code stands for.  
Refer to the wiring diagram code in the alphabetical index to find the location (page number) of each wiring diagram.

Code	Section	Wiring Diagram Name
ABS	BRC	Anti-lock Brake System
A/C,M	MTC	Manual Air Conditioner
APPS1	EC	Accelerator Pedal Position Sensor
A/F	EC	Air Fuel Ratio Sensor 1
A/FH	EC	Air Fuel Ratio Sensor 1 Heater
APPS2	EC	Accelerator Pedal Position Sensor
APPS3	EC	Accelerator Pedal Position Sensor
ASC/BS	EC	ASCD Brake Switch
ASC/SW	EC	ASCD Steering Switch
ASCBOF	EC	ASCD Brake Switch
ASCIND	EC	ASCD Indicator
AT/IND	DI	A/T Indicator Lamp
AUDIO	AV	Audio
BACK/L	LT	Back-up Lamp
BA/FTS	AT	A/T Fluid Temperature Sensor and TCM Power Supply
B/DOOR	BL	Back Door Opener
BRK/SW	EC	Brake Switch
CAN	AT	CAN Communication Line
CAN	CVT	CAN Communication Line
CAN	EC	CAN Communication Line
CAN	LAN	CAN System
CHARGE	SC	Charging System
CHIME	DI	Warning Chime
COOL/F	EC	Cooling Fan Control
COMBSW	LT	Combination Switch
CVTIND	DI	CVT Indicator Lamp
D/LOCK	BL	Power Door Lock
DEF	GW	Rear Window Defogger
DTRL	LT	Headlamp - With Daytime Light System
ECTS	EC	Engine Coolant Temperature Sensor
ENGSS	AT	Engine Speed Signal
EPS	STC	Electronic Controlled Power Steering
ETC1	EC	Electric Throttle Control Function

# HARNESS

## < SERVICE INFORMATION >

ETC2	EC	Throttle Control Motor Relay	A
ETC3	EC	Throttle Control Motor	
F/FOG	LT	Front Fog Lamp	
F/PUMP	EC	Fuel Pump	B
FTS	AT	A/T Fluid Temperature Sensor	
FTS	CVT	CVT Fluid Temperature Sensor Circuit	
FTTS	EC	Fuel Tank Temperature Sensor	C
FUEL	EC	Fuel Ignition System Function	
HEATER	MTC	Heater System	
H/LAMP	LT	Headlamp	D
H/PHON	AV	Hands Free Telephone	
HORN	WW	Horn	
HO2S2	EC	Heated Oxygen Sensor 2	E
HO2S2H	EC	Heated Oxygen Sensor 2 Heater	
IATS	EC	Intake Air Temperature Sensor	
IGNSYS	EC	Ignition System	F
I/KEY	BL	Intelligent Key System	
ILL	LT	Illumination	
INJECT	EC	Injector	G
INT/L	LT	Room/Map, Vanity and Luggage Lamps	
IVC	EC	Intake Valve Timing Control Solenoid Valve	H
KEYLES	BL	Remote Keyless Entry System	
KS	EC	Knock Sensor	I
LPSV	AT	Line Pressure Solenoid Valve	
LPSV	CVT	Line Pressure Solenoid Valve	
L/USSV	CVT	Lock-up Select Solenoid Valve	J
MAFS	EC	Mass Air Flow Sensor	
MAIN	AT	Main Power Supply and Ground Circuit	
MAIN	EC	Main Power Supply and Ground Circuit	
METER	DI	Speedometer, Tachometer, Temp. and Fuel Gauges	PG
MIL/DL	EC	Malfunction Indicator Lamp	
MIRROR	GW	Door Mirror	
NATS	BL	Nissan Anti-Theft System	L
NONDTC	AT	Non-detectable Item	
NONDTC	CVT	Non-detectable Item	
ODSW	CVT	Overdrive Control Switch	M
OVRCSV	AT	Over Run Clutch Solenoid Valve	
P/SCKT	WW	Power Socket	
PGC/V	EC	EVAP Canister Purge Volume Control Solenoid Valve	N
PHASE	EC	Camshaft Position Sensor (PHASE)	
PNP/SW	AT	Park/Neutral Position Switch	O
PNP/SW	CVT	Park/Neutral Position Switch	
PNP/SW	EC	Park/Neutral Position Switch	
POS	EC	Crankshaft Position Sensor (POS)	P
POWER	CVT	Transmission Control Module (Power Supply)	
PRE/SE	EC	EVAP Control System Pressure Sensor	
PRIPS	CVT	Primary Pressure Sensor	
PRSCVT	CVT	Primary Speed Sensor CVT (Revolution Sensor)	
PT/SEN	AT	Powertrain Revolution Sensor	
RP/SEN	EC	Refrigerant Pressure Sensor	
SECPS	CVT	Secondary Pressure Sensor	
SECPSV	CVT	Secondary Speed Sensor CVT (Revolution Sensor)	

# HARNESSES

## < SERVICE INFORMATION >

SEN/PW	EC	Sensor Power Supply
SESCVT	CVT	Secondary Pressure Sensor Solenoid Valve
SHIFT	AT	A/T Shift Lock System
SHIFT	CVT	CVT Shift Lock System
SROOF	RF	Sunroof
SRS	SRS	Supplemental Restraint System
SSV/A	AT	Shift Solenoid Valve A
SSV/B	AT	Shift Solenoid Valve B
START	SC	Starting System
STM	CVT	Step Motor
STSIG	CVT	Start Signal Circuit
STOP/L	LT	Stop Lamp
TCV	AT	Torque Converter Clutch Solenoid Valve
TCV	CVT	Torque Converter Clutch Solenoid Valve
T/LID	BL	Trunk Lid Opener
T/WARN	WT	Low Tire Pressure Warning System
TAIL/L	LT	Parking, License and Tail Lamps
TPS1	EC	Throttle Position Sensor
TPS2	EC	Throttle Position Sensor
TPS3	EC	Throttle Position Sensor
TURN	LT	Turn Signal and Hazard Warning Lamps
VEHSEC	BL	Vehicle Security (Theft Warning) System
VENT/V	EC	EVAP Canister Vent Control Valve
VSSA/T	AT	Vehicle Speed Sensor A/T (Revolution Sensor)
VSSMTR	AT	Vehicle Speed Sensor MTR
WARN	DI	Warning Lamps
WINDOW	GW	Power Window
WIP/R	WW	Rear Wiper and Washer
WIPER	WW	Front Wiper and Washer

# ELECTRICAL UNITS LOCATION



< SERVICE INFORMATION >

## ELECTRICAL UNITS LOCATION

### Electrical Units Location

INFOID:000000001704710

### ENGINE COMPARTMENT



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

PG




L  
M  
N  
O  
P

WKIA6006E

# ELECTRICAL UNITS LOCATION

< SERVICE INFORMATION >


## PASSENGER COMPARTMENT



LKIA0827E

# ELECTRICAL UNITS LOCATION

< SERVICE INFORMATION >






A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PG

LKIA0828E

# ELECTRICAL UNITS LOCATION

< SERVICE INFORMATION >  
LUGGAGE COMPARTMENT



WKIA5998E

# HARNESS CONNECTOR

< SERVICE INFORMATION >

## HARNESS CONNECTOR

### Description

INFOID:000000001704711

#### HARNESS CONNECTOR (TAB-LOCKING TYPE)


- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the illustration below.

Refer to the next page for description of the slide-locking type connector.

**CAUTION:**

**Do not pull the harness or wires when disconnecting the connector.**

[Example]



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PG

SEL769DA

#### HARNESS CONNECTOR (SLIDE-LOCKING TYPE)

- A new style slide-locking type connector is used on certain systems and components, especially those related to OBD.
- The slide-locking type connectors help prevent incomplete locking and accidental looseness or disconnection.
- The slide-locking type connectors are disconnected by pushing or pulling the slider. Refer to the figure below.


# HARNESS CONNECTOR

## < SERVICE INFORMATION >

### CAUTION:

- Do not pull the harness or wires when disconnecting the connector.
- Be careful not to damage the connector support bracket when disconnecting the connector.

[Example]



## HARNESS CONNECTOR (LEVER LOCKING TYPE)


- Lever locking type harness connectors are used on certain control units and control modules such as ECM, ABS actuator and electric unit (control unit), etc.
- Lever locking type harness connectors are also used on super multiple junction (SMJ) connectors.
- Always confirm the lever is fully locked in place by moving the lever as far as it will go to ensure full connection.

### CAUTION:

# HARNES CONNECTOR

## < SERVICE INFORMATION >

Always confirm the lever is fully released (loosened) before attempting to disconnect or connect these connectors to avoid damage to the connector housing or terminals.



LKIA0670E


- |                                                                                            |                                                                                            |                                                                           |
|--------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------|---------------------------------------------------------------------------|
| <p>1. Control unit with single lever</p> <p>A. Fasten</p> <p>B. Loosen</p> <p>C. Lever</p> | <p>2. Control unit with dual levers</p> <p>A. Levers</p> <p>B. Fasten</p> <p>C. Loosen</p> | <p>3. SMJ connector</p> <p>A. Lever</p> <p>B. Fasten</p> <p>C. Loosen</p> |
|--------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------|---------------------------------------------------------------------------|

## HARNES CONNECTOR (DIRECT-CONNECT SRS COMPONENT TYPE)

- SRS direct-connect type harness connectors are used on certain SRS components such as air bag modules and seat belt pre-tensioners.
- Always pull up to release black locking tab prior to removing connector from SRS component.
- Always push down to lock black locking tab after installing connector to SRS component. When locked, the black locking tab is level with the connector housing.

### CAUTION:

- Do not pull the harness or wires when removing connectors from SRS components.



WHIA0103E

# ELECTRICAL UNITS


< SERVICE INFORMATION >

## ELECTRICAL UNITS


### Terminal Arrangement

INFOID:000000001704712


#### BCM (BODY CONTROL MODULE)




#### ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)



#### ECM



#### TCM (TRANSMISSION CONTROL MODULE)



LKIA0810E

# STANDARDIZED RELAY

< SERVICE INFORMATION >


## STANDARDIZED RELAY

### Description


INFOID:000000001704713

### NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS

Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.


















### TYPE OF STANDARDIZED RELAYS



1M	1 Make	2M	2 Make
1T	1 Transfer	1M·1B	1 Make 1 Break

# STANDARDIZED RELAY

< SERVICE INFORMATION >

Type	Outer view	Circuit	Connector Symbol and connection	Case color
1T				BLACK
2M				BROWN
1M · 1B				GRAY
1M				BLACK
				BLUE

The arrangement of terminal numbers on the actual relays may differ from those shown above.

WKIA0253E


# SUPER MULTIPLE JUNCTION (SMJ)

< SERVICE INFORMATION >

## SUPER MULTIPLE JUNCTION (SMJ)

### Terminal Arrangement

INFOID:000000001704714



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
PG  
L  
M  
N  
O  
P

LKIA0811E


# FUSE BLOCK-JUNCTION BOX (J/B)

< SERVICE INFORMATION >


## FUSE BLOCK-JUNCTION BOX (J/B)

### Terminal Arrangement

INFOID:000000001704715



1 10 A	2 10 A	3 10 A	4 15 A	5 10 A	6 10 A														
7 10 A	8 10 A	9 X	10 X	11 X	12 X	13 10 A	14 10 A												
15 15 A	16 10 A	17 15 A				18 X	19 15 A	20 10 A											



LKIA0812E


# FUSE AND FUSIBLE LINK BOX

< SERVICE INFORMATION >


## FUSE AND FUSIBLE LINK BOX

### Terminal Arrangement

INFOID:000000001704716



### FUSIBLE LINK BOX (BATTERY)



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
PG  
L  
M  
N  
O  
P

WKIA5604E