

**SECTION CL**

MA

EM

LC

EC

FE

**CL**

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

# CONTENTS

<p><b>PRECAUTIONS AND PREPARATION</b>.....2</p> <p style="padding-left: 20px;">Precautions .....2</p> <p style="padding-left: 20px;">Special Service Tools .....2</p> <p style="padding-left: 20px;">Commercial Service Tools .....2</p> <p><b>NOISE, VIBRATION AND HARSHNESS (NVH)</b></p> <p><b>TROUBLESHOOTING</b> .....3</p> <p style="padding-left: 20px;">NVH Troubleshooting Chart.....3</p> <p><b>CLUTCH SYSTEM</b>.....4</p> <p style="padding-left: 20px;">Clutch Pedal .....5</p> <p><b>INSPECTION AND ADJUSTMENT</b> .....6</p> <p style="padding-left: 20px;">Adjusting Clutch Pedal .....6</p> <p style="padding-left: 20px;">Air Bleeding Procedure.....7</p>	<p><b>HYDRAULIC CLUTCH CONTROL</b> .....8</p> <p style="padding-left: 20px;">Clutch Master Cylinder (With clutch damper) .....8</p> <p style="padding-left: 20px;">Operating Cylinder.....9</p> <p><b>CLUTCH RELEASE MECHANISM</b> .....10</p> <p><b>CLUTCH DISC AND CLUTCH COVER</b> .....12</p> <p style="padding-left: 20px;">Clutch Disc.....12</p> <p style="padding-left: 20px;">Clutch Cover and Flywheel .....13</p> <p><b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> .....14</p> <p style="padding-left: 20px;">General Specifications.....14</p> <p style="padding-left: 20px;">Clutch Control System .....14</p> <p style="padding-left: 20px;">Inspection and Adjustment .....14</p>
--	---

## PRECAUTIONS AND PREPARATION



### Precautions



- Recommended fluid is brake fluid DOT 3.
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas.
- When removing and installing clutch piping, use a suitable tool.
- Use new brake fluid to clean or wash all parts of master cylinder, operating cylinder and clutch damper.
- Never use mineral oils such as gasoline or kerosene. They will ruin the rubber parts of the hydraulic system.

### WARNING:




After cleaning the clutch disc, wipe it with a dust collector. Do not use compressed air.

### Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
ST20630000 (J26366) Clutch aligning bar	 <p>NT405</p> <p>Installing clutch cover and clutch disc</p> <p>a: 15.9 mm (0.626 in) dia. b: 22.8 mm (0.898 in) dia. c: 55 mm (2.17 in)</p>
ST20050240 ( — ) Diaphragm spring adjusting wrench	 <p>NT404</p> <p>Adjusting unevenness of clutch cover diaphragm spring</p> <p>a: 150 mm (5.91 in) b: 25 mm (0.98 in)</p>

### Commercial Service Tools

Tool name	Description
① Flare nut crowfoot ② Torque wrench	 <p>NT360</p> <p>Removing and installing clutch piping</p> <p>a: 10 mm (0.39 in)</p>
Bearing puller	 <p>NT077</p> <p>Removing release bearing</p>
Bearing drift	 <p>NT474</p> <p>Installing release bearing</p> <p>a: 52 mm (2.05 in) dia. b: 45 mm (1.77 in) dia.</p>

# NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

## NVH Troubleshooting Chart


Use the chart below to help you find the cause of the symptom. The numbers indicate the order of the inspection. If necessary, repair or replace these parts.

	Reference page	CL-6	CL-7	CL-8	CL-9	Refer to EM section	CL-10	CL-12	CL-13	CL-13	CL-13	CL-13						
SUSPECTED PARTS (Possible cause)	CLUTCH PEDAL (Free play out of adjustment)																	
	CLUTCH LINE (Air in line)																	
	MASTER CYLINDER PISTON CUP (Damaged)																	
	OPERATING CYLINDER PISTON CUP (Damaged)																	
	ENGINE MOUNTING (Loose)																	
	RELEASE BEARING (Worn, dirty or damaged)																	
	CLUTCH DISC (Out of true)																	
	CLUTCH DISC (Runout is excessive)																	
	CLUTCH DISC (Lining broken)																	
	CLUTCH DISC (Dirty or burned)																	
	CLUTCH DISC (Oily)																	
	CLUTCH DISC (Worn out)																	
	CLUTCH DISC (Hardened)																	
	CLUTCH DISC (Lack of spline grease)																	
	DIAPHRAGM SPRING (Damaged)																	
	DIAPHRAGM SPRING (Out of tip alignment)																	
	CLUTCH COVER (Distortion)																	
	FLYWHEEL (Distortion)																	
Symptom	Clutch grabs/chatters					1												
	Clutch pedal spongy		1	2	2													
	Clutch noisy						1											
	Clutch slips	1										2	2					
	Clutch does not disengage	1	2	3	4			5	5	5	5	5		5	6	6	7	5

GI  
 MA  
 EM  
 LC  
 EC  
 FE  
**CL**  
 MT  
 AT  
 TF  
 PD  
 FA  
 RA  
 BR  
 ST  
 RS  
 BT  
 HA  
 EL  
 IDX

# CLUTCH SYSTEM

SEC. 300 • 305 • 306 • 465



Ⓜ : N·m (kg-m, in-lb)

Ⓟ : N·m (kg-m, ft-lb)

Ⓡ : Apply genuine anaerobic liquid gasket, Three Bond TB 1212, Loctite Part No. 51813 or equivalent.

L : Apply lithium-based grease including molybdenum disulphide.

Ⓡ : Apply rubber lubricant.


ACL096

CL-4

# CLUTCH SYSTEM

## Clutch Pedal

SEC. 465




: N·m (kg·m, ft·lb)

ACL093

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# INSPECTION AND ADJUSTMENT




## Adjusting Clutch Pedal

1. Adjust pedal height with pedal stopper bolt or ASCD clutch switch.

**Pedal height "H":**

**227 - 237 mm (8.94 - 9.33 in)**



2. Adjust pedal free play by turning master cylinder push rod. Then tighten lock nut.

**Pedal free play "A":**

**9 - 16 mm (0.35 - 0.63 in)**


Pedal free play, measured at pedal pad includes the following:

- Free play due to clevis pin and clevis pin hole, push rod and master cylinder.

3. Make sure that clevis pin can rotate smoothly. If not, readjust pedal free play with master cylinder push rod.

## INSPECTION AND ADJUSTMENT


### Adjusting Clutch Pedal (Cont'd)



4. Adjust clearance "C" shown in the figure while fully depressing clutch pedal.

Clearance "C":

0.1 - 1.0 mm (0.004 - 0.039 in)



### Air Bleeding Procedure

Bleed air according to the following procedure.


Bleed air from operating cylinder.

1. Fill the master cylinder reservoir tank with new brake fluid.
2. Connect a transparent vinyl hose to the air bleeder.
3. Slowly depress the clutch pedal to its full stroke length and release it completely. Repeat this operation several times at 2 to 3 second intervals.
4. Open the air bleeder with the clutch pedal fully depressed.
5. Close the air bleeder.
6. Release the clutch pedal and wait at least 5 seconds.
7. Repeat steps 3 through 6 above until air bubbles no longer appear in the brake fluid.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# HYDRAULIC CLUTCH CONTROL

## Clutch Master Cylinder (With clutch damper)



### DISASSEMBLY AND ASSEMBLY

- Use a screwdriver to remove stopper ring while pushing push rod into cylinder.
- When installing stopper ring, tap in lightly while pushing push rod into cylinder.


### INSPECTION

Check the following items, and replace as necessary.

- Rubbing surface of cylinder and piston, for uneven wear, rust and damage
- Piston with piston cup, for wear and damage
- Return spring, for wear and damage
- Dust cover, for cracks, deformation and damage
- Reservoir, for deformation and damage

# HYDRAULIC CLUTCH CONTROL

## Operating Cylinder



### INSPECTION


Check the following items, and replace as necessary.

- Rubbing surface of cylinder and piston, for uneven wear, rust and damage.
- Piston with piston cup, for wear and damage.
- Piston spring, for wear and damage.
- Dust cover, for cracks, deformation and damage.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# CLUTCH RELEASE MECHANISM




SEC. 321



ACL095

## REMOVAL AND INSTALLATION

- Remove release bearing.
- Install release bearing with suitable drift.
- Install retainer spring and holder spring.



CL-10

# CLUTCH RELEASE MECHANISM



## INSPECTION

Check the following items, and replace as necessary.

- Release bearing, to see that it rolls freely and is free from noise, cracks, pitting and wear
- Release sleeve and withdrawal lever rubbing surface for wear, rust and damage

## LUBRICATION

- Apply recommended grease to contact surface and rubbing surface.
- Too much lubricant might damage clutch disc facing.




## WATERPROOF

- Apply recommended sealant to contact surface of transmission case dust cover and withdrawal lever, then install dust cover clip.

**Recommended sealant: Nissan genuine part KP115-00100, Three Bond TB1212, Loctite Part No. 51813 or equivalent.**


# CLUTCH DISC AND CLUTCH COVER

SEC. 300



- Do not clean clutch disc surface with solvent.
  - When installing, be careful that grease from main drive shaft does not adhere to clutch disc.
- : Apply lithium-based grease including molybdenum disulphide.
- : N·m (kg-m, ft-lb)

ACL092




## Clutch Disc

### INSPECTION

Check the following items, and replace as necessary.

- Clutch disc, for burns, discoloration and oil or grease leakage.
- Clutch disc, for wear of facing.

**Wear limit of facing surface to rivet head:**  
0.3 mm (0.012 in)



- Clutch disc, for backlash of spline and runout of facing.  
**Maximum backlash of spline (at outer edge of disc):**  
1.0 mm (0.039 in)  
**Runout limit:**  
1.0 mm (0.039 in)  
**Distance of runout check point (from hub center):**  
120 mm (4.72 in)


CL-12

# CLUTCH DISC AND CLUTCH COVER

## Clutch Disc (Cont'd)

### INSTALLATION


- Apply recommended grease to contact surface of splines.
- Too much lubricant may damage clutch disc facing.



### Clutch Cover and Flywheel

#### INSPECTION AND ADJUSTMENT

- Check clutch cover installed on vehicle for uneven diaphragm spring toe height.  
**Uneven limit:**  
**0.5 mm (0.020 in)**
- If out of limit, adjust the height using Tool.



#### FLYWHEEL INSPECTION


##### CAUTION:

Do not allow any magnetic materials to contact the ring gear teeth.

- Inspect contact surface of flywheel for slight burns or discoloration. Clean flywheel using emery paper.
- Check flywheel runout.

##### Maximum allowable runout:

Refer to EM section ("Inspection", "CYLINDER BLOCK").



#### INSTALLATION

- Insert Tool into clutch disc hub while installing clutch cover and disc.
- Be careful not to allow grease to contaminate clutch facing.
- Tighten bolts in numerical order, in two steps.

##### First step:

☑: 10 - 20 N·m (1.0 - 2.0 kg-m, 7 - 14 ft-lb)

##### Final step:

☑: 22 - 29 N·m (2.2 - 3.0 kg-m, 16 - 22 ft-lb)

# SERVICE DATA AND SPECIFICATIONS (SDS)

## General Specifications

### CLUTCH CONTROL SYSTEM

Type of clutch control	Hydraulic
------------------------	-----------

### CLUTCH MASTER CYLINDER (with clutch damper)

Unit: mm (in)

Inner diameter	15.87 (5/8)
----------------	-------------

### CLUTCH OPERATING CYLINDER

Unit: mm (in)

Inner diameter	19.05 (3/4)
----------------	-------------

### CLUTCH DISC

Unit: mm (in)

Model	250
Engine	VG33E
Facing size (Outer dia. x inner dia. x thickness)	250 x 160 x 3.5 (9.84 x 6.30 x 0.138)
Thickness of disc assembly With load	8.1 - 8.5 (0.3189 - 0.3346) with 6473 N (660 kg - 1455 lb)

### CLUTCH COVER

Model	250
Engine	VG33E
Set-load N (kg, lb)	4658 (475, 1047)

## Inspection and Adjustment

### CLUTCH PEDAL

Unit: mm (in)

Pedal height "H"	227 - 237 (8.94 - 9.33)
Pedal free play "A" (at pedal pad)	9 - 16 (0.35 - 0.63)
Clearance "C" between pedal stopper bracket and clutch pedal position switch (with clutch pedal fully depressed)	0.1 - 1.0 (0.004 - 0.039)

\*: Measured from surface of dash lower panel to pedal pad.

### CLUTCH DISC

Unit: mm (in)

Model	250
Wear limit of facing surface to rivet head	0.3 (0.012)
Runout limit of facing Distance of runout check point (from hub center)	1.0 (0.039) 120 (4.72)
Maximum backlash of spline (at outer edge of disc)	1.0 (0.039)

### CLUTCH COVER

Unit: mm (in)

Model	250
Diaphragm spring height	36.5 - 38.5 (1.437 - 1.516)
Uneven limit of diaphragm spring toe height	0.5 (0.020)