

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# SECTION EC

## ENGINE CONTROL SYSTEM

### CONTENTS

<p><b>APPLICATION NOTICE</b> ..... 15</p> <p style="padding-left: 20px;">How to Check Vehicle Type ..... 15</p> <p style="text-align: center;"><b>VQ TYPE 1</b></p> <hr style="border: 0.5px solid black;"/> <p><b>INDEX FOR DTC</b> ..... 16</p> <p style="padding-left: 20px;">DTC No. Index ..... 16</p> <p style="padding-left: 20px;">Alphabetical Index ..... 19</p> <p><b>PRECAUTIONS</b> ..... 22</p> <p style="padding-left: 20px;">Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" ..... 22</p> <p style="padding-left: 20px;">On Board Diagnostic (OBD) System of Engine ..... 22</p> <p style="padding-left: 20px;">Precaution ..... 22</p> <p><b>PREPARATION</b> ..... 26</p> <p style="padding-left: 20px;">Special Service Tools ..... 26</p> <p style="padding-left: 20px;">Commercial Service Tools ..... 27</p> <p><b>ENGINE CONTROL SYSTEM</b> ..... 28</p> <p style="padding-left: 20px;">System Diagram ..... 28</p> <p style="padding-left: 20px;">Multiport Fuel Injection (MFI) System ..... 29</p> <p style="padding-left: 20px;">Electronic Ignition (EI) System ..... 31</p> <p style="padding-left: 20px;">Fuel Cut Control (at No Load and High Engine Speed) ..... 32</p> <p><b>AIR CONDITIONING CUT CONTROL</b> ..... 33</p> <p style="padding-left: 20px;">Input/Output Signal Chart ..... 33</p> <p style="padding-left: 20px;">System Description ..... 33</p> <p><b>AUTOMATIC SPEED CONTROL DEVICE (ASCD)</b>.. 34</p> <p style="padding-left: 20px;">System Description ..... 34</p> <p style="padding-left: 20px;">Component Description ..... 35</p> <p><b>CAN COMMUNICATION</b> ..... 36</p> <p style="padding-left: 20px;">System Description ..... 36</p> <p><b>EVAPORATIVE EMISSION SYSTEM</b> ..... 37</p> <p style="padding-left: 20px;">Description ..... 37</p> <p style="padding-left: 20px;">Component Inspection ..... 40</p> <p><b>POSITIVE CRANKCASE VENTILATION</b> ..... 41</p> <p style="padding-left: 20px;">Description ..... 41</p> <p style="padding-left: 20px;">Component Inspection ..... 41</p> <p><b>NATS (NISSAN ANTI-THEFT SYSTEM)</b> ..... 43</p> <p style="padding-left: 20px;">Description ..... 43</p>	<p><b>ON BOARD DIAGNOSTIC (OBD) SYSTEM</b> ..... 44</p> <p style="padding-left: 20px;">Introduction ..... 44</p> <p style="padding-left: 20px;">Two Trip Detection Logic ..... 44</p> <p style="padding-left: 20px;">Emission-related Diagnostic Information ..... 45</p> <p style="padding-left: 20px;">Malfunction Indicator Lamp (MIL) ..... 57</p> <p style="padding-left: 20px;">OBD System Operation Chart ..... 59</p> <p><b>BASIC SERVICE PROCEDURE</b> ..... 65</p> <p style="padding-left: 20px;">Basic Inspection ..... 65</p> <p style="padding-left: 20px;">Idle Speed and Ignition Timing Check ..... 69</p> <p style="padding-left: 20px;">Accelerator Pedal Released Position Learning ..... 71</p> <p style="padding-left: 20px;">Throttle Valve Closed Position Learning ..... 71</p> <p style="padding-left: 20px;">Idle Air Volume Learning ..... 71</p> <p style="padding-left: 20px;">Fuel Pressure Check ..... 74</p> <p><b>TROUBLE DIAGNOSIS</b> ..... 77</p> <p style="padding-left: 20px;">Trouble Diagnosis Introduction ..... 77</p> <p style="padding-left: 20px;">DTC Inspection Priority Chart ..... 83</p> <p style="padding-left: 20px;">Fail-safe Chart ..... 84</p> <p style="padding-left: 20px;">Symptom Matrix Chart ..... 85</p> <p style="padding-left: 20px;">Engine Control Component Parts Location ..... 89</p> <p style="padding-left: 20px;">Vacuum Hose Drawing ..... 96</p> <p style="padding-left: 20px;">Circuit Diagram ..... 97</p> <p style="padding-left: 20px;">ECM Harness Connector Terminal Layout ..... 99</p> <p style="padding-left: 20px;">ECM Terminals and Reference Value ..... 99</p> <p style="padding-left: 20px;">CONSULT-II Function (ENGINE) ..... 108</p> <p style="padding-left: 20px;">Generic Scan Tool (GST) Function ..... 119</p> <p style="padding-left: 20px;">CONSULT-II Reference Value in Data Monitor .... 122</p> <p style="padding-left: 20px;">Major Sensor Reference Graph in Data Monitor Mode ..... 125</p> <p><b>TROUBLE DIAGNOSIS - SPECIFICATION VALUE</b> 127</p> <p style="padding-left: 20px;">Description ..... 127</p> <p style="padding-left: 20px;">Testing Condition ..... 127</p> <p style="padding-left: 20px;">Inspection Procedure ..... 127</p> <p style="padding-left: 20px;">Diagnostic Procedure ..... 128</p> <p><b>TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT</b> ..... 137</p> <p style="padding-left: 20px;">Description ..... 137</p> <p style="padding-left: 20px;">Diagnostic Procedure ..... 137</p> <p><b>POWER SUPPLY AND GROUND CIRCUIT</b> ..... 138</p> <p style="padding-left: 20px;">Wiring Diagram ..... 138</p>
--	--

Diagnostic Procedure .....	141	Wiring Diagram .....	182
Ground Inspection .....	145	Diagnostic Procedure .....	184
<b>DTC U1000, U1001 CAN COMMUNICATION LINE 146</b>		Component Inspection .....	186
Description .....	146	Removal and Installation .....	186
On Board Diagnosis Logic .....	146	<b>DTC P0138, P0158 HO2S2 187</b>	
DTC Confirmation Procedure .....	146	Component Description .....	187
Wiring Diagram .....	147	CONSULT-II Reference Value in Data Monitor Mode	
Diagnostic Procedure .....	148		187
<b>DTC P0011, P0021 IVT CONTROL 149</b>		On Board Diagnosis Logic .....	187
Description .....	149	DTC Confirmation Procedure .....	188
CONSULT-II Reference Value in Data Monitor Mode		Wiring Diagram .....	189
	149	Diagnostic Procedure .....	192
On Board Diagnosis Logic .....	150	Component Inspection .....	194
DTC Confirmation Procedure .....	150	Removal and Installation .....	195
Diagnostic Procedure .....	151	<b>DTC P0139, P0159 HO2S2 196</b>	
Component Inspection .....	152	Component Description .....	196
Removal and Installation .....	153	CONSULT-II Reference Value in Data Monitor Mode	
<b>DTC P0037, P0038, P0057, P0058 HO2S2 HEATER 154</b>			196
Description .....	154	On Board Diagnosis Logic .....	196
CONSULT-II Reference Value in Data Monitor Mode		DTC Confirmation Procedure .....	197
	154	Overall Function Check .....	198
On Board Diagnosis Logic .....	154	Wiring Diagram .....	199
DTC Confirmation Procedure .....	155	Diagnostic Procedure .....	202
Wiring Diagram .....	156	Component Inspection .....	205
Diagnostic Procedure .....	159	Removal and Installation .....	206
Component Inspection .....	161	<b>DTC P0171, P0174 FUEL INJECTION SYSTEM</b>	
Removal and Installation .....	162	<b>FUNCTION 207</b>	
<b>DTC P0102, P0103 MAF SENSOR 163</b>		On Board Diagnosis Logic .....	207
Component Description .....	163	DTC Confirmation Procedure .....	207
CONSULT-II Reference Value in Data Monitor Mode		Wiring Diagram .....	209
	163	Diagnostic Procedure .....	213
On Board Diagnosis Logic .....	163	<b>DTC P0172, P0175 FUEL INJECTION SYSTEM</b>	
DTC Confirmation Procedure .....	164	<b>FUNCTION 219</b>	
Wiring Diagram .....	165	On Board Diagnosis Logic .....	219
Diagnostic Procedure .....	166	DTC Confirmation Procedure .....	219
Component Inspection .....	168	Wiring Diagram .....	221
Removal and Installation .....	169	Diagnostic Procedure .....	225
<b>DTC P0112, P0113 IAT SENSOR 170</b>		<b>DTC P0222, P0223 TP SENSOR 231</b>	
Component Description .....	170	Component Description .....	231
On Board Diagnosis Logic .....	170	CONSULT-II Reference Value in Data Monitor Mode	
DTC Confirmation Procedure .....	170		231
Wiring Diagram .....	172	On Board Diagnosis Logic .....	231
Diagnostic Procedure .....	173	DTC Confirmation Procedure .....	232
Component Inspection .....	174	Wiring Diagram .....	233
Removal and Installation .....	174	Diagnostic Procedure .....	235
<b>DTC P0117, P0118 ECT SENSOR 175</b>		Component Inspection .....	237
Component Description .....	175	Removal and Installation .....	237
On Board Diagnosis Logic .....	175	<b>DTC P0300 - P0306 MULTIPLE CYLINDER MIS-</b>	
DTC Confirmation Procedure .....	176	<b>FIRE, NO. 1 - 6 CYLINDER MISFIRE 238</b>	
Wiring Diagram .....	177	On Board Diagnosis Logic .....	238
Diagnostic Procedure .....	178	DTC Confirmation Procedure .....	238
Component Inspection .....	179	Diagnostic Procedure .....	239
Removal and Installation .....	179	<b>DTC P0327, P0328, P0332, P0333 KS 247</b>	
<b>DTC P0122, P0123 TP SENSOR 180</b>		Component Description .....	247
Component Description .....	180	On Board Diagnosis Logic .....	247
CONSULT-II Reference Value in Data Monitor Mode		DTC Confirmation Procedure .....	247
	180	Wiring Diagram .....	248
On Board Diagnosis Logic .....	180	Diagnostic Procedure .....	249
DTC Confirmation Procedure .....	181		



Component Inspection .....	251	DTC Confirmation Procedure .....	288
Removal and Installation .....	251	Diagnostic Procedure .....	289
<b>DTC P0335 CKP SENSOR (POS) .....</b>	<b>252</b>	<b>DTC P1031, P1032, P1051, P1052 A/F SENSOR 1</b>	
Component Description .....	252	<b>HEATER .....</b>	<b>291</b>
CONSULT-II Reference Value in Data Monitor Mode		Description .....	291
	252	CONSULT-II Reference Value in Data Monitor Mode	291
On Board Diagnosis Logic .....	252	On Board Diagnosis Logic .....	291
DTC Confirmation Procedure .....	253	DTC Confirmation Procedure .....	291
Wiring Diagram .....	254	Wiring Diagram .....	293
Diagnostic Procedure .....	256	Diagnostic Procedure .....	296
Component Inspection .....	258	Component Inspection .....	298
Removal and Installation .....	258	Removal and Installation .....	298
<b>DTC P0340, P0345 CMP SENSOR (PHASE) .....</b>	<b>259</b>	<b>DTC P1065 ECM POWER SUPPLY .....</b>	<b>299</b>
Component Description .....	259	Component Description .....	299
CONSULT-II Reference Value in Data Monitor Mode		On Board Diagnosis Logic .....	299
	259	DTC Confirmation Procedure .....	299
On Board Diagnosis Logic .....	259	Wiring Diagram .....	300
DTC Confirmation Procedure .....	260	Diagnostic Procedure .....	301
Wiring Diagram .....	261	<b>DTC P1111, P1136 IVT CONTROL SOLENOID</b>	
Diagnostic Procedure .....	264	<b>VALVE .....</b>	<b>303</b>
Component Inspection .....	267	Component Description .....	303
Removal and Installation .....	267	CONSULT-II Reference Value in Data Monitor Mode	303
<b>DTC P0420, P0430 THREE WAY CATALYST FUNCTION .....</b>	<b>268</b>		303
On Board Diagnosis Logic .....	268	On Board Diagnosis Logic .....	303
DTC Confirmation Procedure .....	268	DTC Confirmation Procedure .....	303
Overall Function Check .....	269	Wiring Diagram .....	304
Diagnostic Procedure .....	270	Diagnostic Procedure .....	308
<b>DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE .....</b>	<b>274</b>	Component Inspection .....	309
Description .....	274	Removal and Installation .....	309
CONSULT-II Reference Value in Data Monitor Mode		<b>DTC P1121 ELECTRIC THROTTLE CONTROL ACTUATOR .....</b>	<b>310</b>
	274	Component Description .....	310
On Board Diagnosis Logic .....	275	On Board Diagnosis Logic .....	310
DTC Confirmation Procedure .....	275	DTC Confirmation Procedure .....	310
Wiring Diagram .....	276	Diagnostic Procedure .....	311
Diagnostic Procedure .....	278	<b>DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION .....</b>	<b>312</b>
Component Inspection .....	279	Description .....	312
Removal and Installation .....	280	On Board Diagnosis Logic .....	312
<b>DTC P0500 VSS .....</b>	<b>281</b>	DTC Confirmation Procedure .....	312
Description .....	281	Wiring Diagram .....	313
On Board Diagnosis Logic .....	281	Diagnostic Procedure .....	314
DTC Confirmation Procedure .....	281	Component Inspection .....	317
Overall Function Check .....	281	Removal and Installation .....	317
Diagnostic Procedure .....	282	<b>DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY .....</b>	<b>318</b>
<b>DTC P0550 PSP SENSOR .....</b>	<b>283</b>	Component Description .....	318
Component Description .....	283	CONSULT-II Reference Value in Data Monitor Mode	318
CONSULT-II Reference Value in Data Monitor Mode			318
	283	On Board Diagnosis Logic .....	318
On Board Diagnosis Logic .....	283	DTC Confirmation Procedure .....	318
DTC Confirmation Procedure .....	283	Wiring Diagram .....	320
Wiring Diagram .....	284	Diagnostic Procedure .....	321
Diagnostic Procedure .....	285	<b>DTC P1128 THROTTLE CONTROL MOTOR .....</b>	<b>324</b>
Component Inspection .....	287	Component Description .....	324
Removal and Installation .....	287	On Board Diagnosis Logic .....	324
<b>DTC P0605 ECM .....</b>	<b>288</b>	DTC Confirmation Procedure .....	324
Component Description .....	288	Wiring Diagram .....	325
On Board Diagnosis Logic .....	288		

Diagnostic Procedure .....	326	Diagnostic Procedure .....	377
Component Inspection .....	327	Removal and Installation .....	380
Removal and Installation .....	328	<b>DTC P1272, P1282 A/F SENSOR 1 .....</b>	<b>381</b>
<b>DTC P1146, P1166 HO2S2 .....</b>	<b>329</b>	Component Description .....	381
Component Description .....	329	CONSULT-II Reference Value in Data Monitor Mode .....	381
CONSULT-II Reference Value in Data Monitor Mode .....	329	On Board Diagnosis Logic .....	381
On Board Diagnosis Logic .....	329	DTC Confirmation Procedure .....	381
DTC Confirmation Procedure .....	330	Wiring Diagram .....	383
Overall Function Check .....	331	Diagnostic Procedure .....	386
Wiring Diagram .....	332	Removal and Installation .....	389
Diagnostic Procedure .....	335	<b>DTC P1273, P1283 A/F SENSOR 1 .....</b>	<b>390</b>
Component Inspection .....	338	Component Description .....	390
Removal and Installation .....	339	CONSULT-II Reference Value in Data Monitor Mode .....	390
<b>DTC P1147, P1167 HO2S2 .....</b>	<b>340</b>	On Board Diagnosis Logic .....	390
Component Description .....	340	DTC Confirmation Procedure .....	390
CONSULT-II Reference Value in Data Monitor Mode .....	340	Wiring Diagram .....	392
On Board Diagnosis Logic .....	340	Diagnostic Procedure .....	395
DTC Confirmation Procedure .....	341	Removal and Installation .....	399
Overall Function Check .....	342	<b>DTC P1274, P1284 A/F SENSOR 1 .....</b>	<b>400</b>
Wiring Diagram .....	343	Component Description .....	400
Diagnostic Procedure .....	346	CONSULT-II Reference Value in Data Monitor Mode .....	400
Component Inspection .....	349	On Board Diagnosis Logic .....	400
Removal and Installation .....	350	DTC Confirmation Procedure .....	400
<b>DTC P1217 ENGINE OVER TEMPERATURE .....</b>	<b>351</b>	Wiring Diagram .....	402
Description .....	351	Diagnostic Procedure .....	405
CONSULT-II Reference Value in Data Monitor Mode .....	352	Removal and Installation .....	409
On Board Diagnosis Logic .....	353	<b>DTC P1276, P1286 A/F SENSOR 1 .....</b>	<b>410</b>
Overall Function Check .....	353	Component Description .....	410
Wiring Diagram .....	355	CONSULT-II Reference Value in Data Monitor Mode .....	410
Diagnostic Procedure .....	357	On Board Diagnosis Logic .....	410
Main 12 Causes of Overheating .....	359	DTC Confirmation Procedure .....	410
Component Inspection .....	360	Overall Function Check .....	411
<b>DTC P1225 TP SENSOR .....</b>	<b>361</b>	Wiring Diagram .....	413
Component Description .....	361	Diagnostic Procedure .....	416
On Board Diagnosis Logic .....	361	Removal and Installation .....	419
DTC Confirmation Procedure .....	361	<b>DTC P1278, P1288 A/F SENSOR 1 .....</b>	<b>420</b>
Diagnostic Procedure .....	362	Component Description .....	420
Removal and Installation .....	362	CONSULT-II Reference Value in Data Monitor Mode .....	420
<b>DTC P1226 TP SENSOR .....</b>	<b>363</b>	On Board Diagnosis Logic .....	420
Component Description .....	363	DTC Confirmation Procedure .....	421
On Board Diagnosis Logic .....	363	Wiring Diagram .....	423
DTC Confirmation Procedure .....	363	Diagnostic Procedure .....	426
Diagnostic Procedure .....	364	Removal and Installation .....	431
Removal and Installation .....	364	<b>DTC P1279, P1289 A/F SENSOR 1 .....</b>	<b>432</b>
<b>DTC P1229 SENSOR POWER SUPPLY .....</b>	<b>365</b>	Component Description .....	432
On Board Diagnosis Logic .....	365	CONSULT-II Reference Value in Data Monitor Mode .....	432
DTC Confirmation Procedure .....	365	On Board Diagnosis Logic .....	432
Wiring Diagram .....	366	DTC Confirmation Procedure .....	433
Diagnostic Procedure .....	369	Wiring Diagram .....	435
<b>DTC P1271, P1281 A/F SENSOR 1 .....</b>	<b>372</b>	Diagnostic Procedure .....	438
Component Description .....	372	Removal and Installation .....	443
CONSULT-II Reference Value in Data Monitor Mode .....	372	<b>DTC P1564 ASCD STEERING SWITCH .....</b>	<b>444</b>
On Board Diagnosis Logic .....	372	Component Description .....	444
DTC Confirmation Procedure .....	372		
Wiring Diagram .....	374		

CONSULT-II Reference Value in Data Monitor Mode	484	On Board Diagnosis Logic	484	A
On Board Diagnosis Logic	444	DTC Confirmation Procedure	485	
DTC Confirmation Procedure	445	Wiring Diagram	486	EC
Wiring Diagram	446	Diagnostic Procedure	488	
Diagnostic Procedure	447	Component Inspection	490	
Component Inspection	450	Removal and Installation	490	
<b>DTC P1572 ASCD BRAKE SWITCH</b>	<b>451</b>	<b>DTC P2135 TP SENSOR</b>	<b>491</b>	C
Component Description	451	Component Description	491	
CONSULT-II Reference Value in Data Monitor Mode	451	CONSULT-II Reference Value in Data Monitor Mode	491	
On Board Diagnosis Logic	451	On Board Diagnosis Logic	491	D
DTC Confirmation Procedure	452	DTC Confirmation Procedure	492	
Wiring Diagram	453	Wiring Diagram	493	E
Diagnostic Procedure	454	Diagnostic Procedure	495	
Component Inspection	462	Component Inspection	497	
<b>DTC P1574 ASCD VEHICLE SPEED SENSOR</b>	<b>464</b>	Removal and Installation	498	
Component Description	464	<b>DTC P2138 APP SENSOR</b>	<b>499</b>	F
On Board Diagnosis Logic	464	Component Description	499	
DTC Confirmation Procedure	464	CONSULT-II Reference Value in Data Monitor Mode	499	
Diagnostic Procedure	465	On Board Diagnosis Logic	499	G
<b>DTC P1706 PNP SWITCH</b>	<b>466</b>	DTC Confirmation Procedure	500	
Component Description	466	Wiring Diagram	501	H
CONSULT-II Reference Value in Data Monitor Mode	466	Diagnostic Procedure	503	
On Board Diagnosis Logic	466	Component Inspection	505	
DTC Confirmation Procedure	466	Removal and Installation	506	
Overall Function Check	467	<b>ASCD BRAKE SWITCH</b>	<b>507</b>	I
Wiring Diagram	468	Component Description	507	
Diagnostic Procedure	469	CONSULT-II Reference Value in Data Monitor Mode	507	J
<b>DTC P1715 INPUT SPEED SENSOR (TURBINE REVOLUTION SENSOR)</b>	<b>472</b>	Wiring Diagram	508	
Description	472	Diagnostic Procedure	509	
CONSULT-II Reference Value in Data Monitor Mode	472	Component Inspection	518	K
On Board Diagnosis Logic	472	<b>ASCD INDICATOR</b>	<b>520</b>	
Diagnostic Procedure	472	Component Description	520	
<b>DTC P1805 BRAKE SWITCH</b>	<b>473</b>	CONSULT-II Reference Value in Data Monitor Mode	520	L
Description	473	Wiring Diagram	521	
CONSULT-II Reference Value in Data Monitor Mode	473	Diagnostic Procedure	522	
On Board Diagnosis Logic	473	<b>ELECTRICAL LOAD SIGNAL</b>	<b>523</b>	M
DTC Confirmation Procedure	473	Description	523	
Wiring Diagram	474	CONSULT-II Reference Value in Data Monitor Mode	523	
Diagnostic Procedure	475	Diagnostic Procedure	523	
Component Inspection	477	<b>EVAP CANISTER VENT CONTROL VALVE</b>	<b>525</b>	
<b>DTC P2122, P2123 APP SENSOR</b>	<b>478</b>	Component Description	525	
Component Description	478	Wiring Diagram	526	
CONSULT-II Reference Value in Data Monitor Mode	478	Diagnostic Procedure	527	
On Board Diagnosis Logic	478	Component Inspection	529	
DTC Confirmation Procedure	479	<b>FUEL INJECTOR</b>	<b>530</b>	
Wiring Diagram	480	Component Description	530	
Diagnostic Procedure	481	CONSULT-II Reference Value in Data Monitor Mode	530	
Component Inspection	483	Wiring Diagram	531	
Removal and Installation	483	Diagnostic Procedure	532	
<b>DTC P2127, P2128 APP SENSOR</b>	<b>484</b>	Component Inspection	536	
Component Description	484	Removal and Installation	536	
CONSULT-II Reference Value in Data Monitor Mode	484			

<b>FUEL PUMP</b> .....	<b>537</b>	<b>ENGINE CONTROL SYSTEM</b> .....	<b>585</b>
Description .....	537	System Diagram .....	585
CONSULT-II Reference Value in Data Monitor Mode .....	537	Multiport Fuel Injection (MFI) System .....	586
Wiring Diagram .....	538	Electronic Ignition (EI) System .....	588
Diagnostic Procedure .....	539	Fuel Cut Control (at No Load and High Engine Speed) .....	589
Component Inspection .....	542	<b>AIR CONDITIONING CUT CONTROL</b> .....	<b>590</b>
Removal and Installation .....	542	Input/Output Signal Chart .....	590
<b>IGNITION SIGNAL</b> .....	<b>543</b>	System Description .....	590
Component Description .....	543	<b>AUTOMATIC SPEED CONTROL DEVICE (ASCD)</b> .....	<b>591</b>
Wiring Diagram .....	544	System Description .....	591
Diagnostic Procedure .....	549	Component Description .....	592
Component Inspection .....	554	<b>CAN COMMUNICATION</b> .....	<b>593</b>
Removal and Installation .....	555	System Description .....	593
<b>REFRIGERANT PRESSURE SENSOR</b> .....	<b>556</b>	<b>EVAPORATIVE EMISSION SYSTEM</b> .....	<b>594</b>
Component Description .....	556	Description .....	594
Wiring Diagram .....	557	Component Inspection .....	597
Diagnostic Procedure .....	558	<b>POSITIVE CRANKCASE VENTILATION</b> .....	<b>598</b>
Removal and Installation .....	561	Description .....	598
<b>VIAS</b> .....	<b>562</b>	Component Inspection .....	598
Description .....	562	<b>NATS (NISSAN ANTI-THEFT SYSTEM)</b> .....	<b>600</b>
CONSULT-II Reference Value in Data Monitor Mode .....	563	Description .....	600
Wiring Diagram .....	564	<b>ON BOARD DIAGNOSTIC (OBD) SYSTEM</b> .....	<b>601</b>
Diagnostic Procedure .....	566	Introduction .....	601
Component Inspection .....	569	Two Trip Detection Logic .....	601
Removal and Installation .....	570	Emission-Related Diagnostic Information .....	601
<b>MIL AND DATA LINK CONNECTOR</b> .....	<b>571</b>	Malfunction Indicator Lamp (MIL) .....	605
Wiring Diagram .....	571	<b>BASIC SERVICE PROCEDURE</b> .....	<b>608</b>
<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> ...	<b>573</b>	Basic Inspection .....	608
Fuel Pressure .....	573	Idle Speed and Ignition Timing Check .....	612
Idle Speed and Ignition Timing .....	573	Accelerator Pedal Released Position Learning .....	614
Calculated Load Value .....	573	Throttle Valve Closed Position Learning .....	614
Mass Air Flow Sensor .....	573	Idle Air Volume Learning .....	614
Intake Air Temperature Sensor .....	573	Fuel Pressure Check .....	617
Engine Coolant Temperature Sensor .....	573	<b>TROUBLE DIAGNOSIS</b> .....	<b>620</b>
Air Fuel Ratio (A/F) Sensor 1 Heater .....	573	Trouble Diagnosis Introduction .....	620
Heated Oxygen sensor 2 Heater .....	573	DTC Inspection Priority Chart .....	626
Crankshaft Position Sensor (POS) .....	573	Fail-Safe Chart .....	627
Camshaft Position Sensor (PHASE) .....	573	Symptom Matrix Chart .....	628
Throttle Control Motor .....	573	Engine Control Component Parts Location .....	632
Fuel Injector .....	574	Vacuum Hose Drawing .....	639
Fuel Pump .....	574	Circuit Diagram .....	640
		ECM Harness Connector Terminal Layout .....	642
		ECM Terminals and Reference Value .....	642
		CONSULT-II Function (ENGINE) .....	651
		CONSULT-II Reference Value in Data Monitor .....	662
		Major Sensor Reference Graph in Data Monitor Mode .....	665
		<b>TROUBLE DIAGNOSIS - SPECIFICATION VALUE</b> .....	<b>667</b>
		Description .....	667
		Testing Condition .....	667
		Inspection Procedure .....	667
		Diagnostic Procedure .....	668
		<b>TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT</b> .....	<b>677</b>
		Description .....	677
		Diagnostic Procedure .....	677
		<b>POWER SUPPLY AND GROUND CIRCUIT</b> .....	<b>678</b>
		Wiring Diagram .....	678

## VQ TYPE 2

<b>INDEX FOR DTC</b> .....	<b>575</b>
DTC No. Index .....	575
Alphabetical Index .....	577
<b>PRECAUTIONS</b> .....	<b>579</b>
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	579
On Board Diagnostic (OBD) System of Engine .....	579
Precaution .....	579
<b>PREPARATION</b> .....	<b>583</b>
Special Service Tools .....	583
Commercial Service Tools .....	584

Diagnostic Procedure .....	681	DTC Confirmation Procedure .....	720
Ground Inspection .....	685	Wiring Diagram .....	721
<b>DTC U1000, U1001 CAN COMMUNICATION LINE 686</b>		Diagnostic Procedure .....	722
Description .....	686	Component Inspection .....	724
On Board Diagnosis Logic .....	686	Removal and Installation .....	724
DTC Confirmation Procedure .....	686	<b>DTC P0335 CKP SENSOR (POS) ..... 725</b>	
Wiring Diagram .....	687	Component Description .....	725
Diagnostic Procedure .....	688	CONSULT-II Reference Value in Data Monitor Mode	
<b>DTC P0011, P0021 IVT CONTROL ..... 689</b>			725
Description .....	689	On Board Diagnosis Logic .....	725
CONSULT-II Reference Value in Data Monitor Mode		DTC Confirmation Procedure .....	726
	689	Wiring Diagram .....	727
On Board Diagnosis Logic .....	690	Diagnostic Procedure .....	729
DTC Confirmation Procedure .....	690	Component Inspection .....	731
Overall Function Check .....	691	Removal and Installation .....	731
Diagnostic Procedure .....	691	<b>DTC P0340, P0345 CMP SENSOR (PHASE) ..... 732</b>	
Component Inspection .....	692	Component Description .....	732
Removal and Installation .....	693	CONSULT-II Reference Value in Data Monitor Mode	
<b>DTC P0102, P0103 MAF SENSOR ..... 694</b>			732
Component Description .....	694	On Board Diagnosis Logic .....	732
CONSULT-II Reference Value in Data Monitor Mode		DTC Confirmation Procedure .....	733
	694	Wiring Diagram .....	734
On Board Diagnosis Logic .....	694	Diagnostic Procedure .....	737
DTC Confirmation Procedure .....	695	Component Inspection .....	740
Wiring Diagram .....	696	Removal and Installation .....	740
Diagnostic Procedure .....	697	<b>DTC P0550 PSP SENSOR ..... 741</b>	
Component Inspection .....	699	Component Description .....	741
Removal and Installation .....	700	CONSULT-II Reference Value in Data Monitor Mode	
<b>DTC P0117, P0118 ECT SENSOR ..... 701</b>			741
Component Description .....	701	On Board Diagnosis Logic .....	741
On Board Diagnosis Logic .....	701	DTC Confirmation Procedure .....	741
DTC Confirmation Procedure .....	702	Wiring Diagram .....	742
Wiring Diagram .....	703	Diagnostic Procedure .....	743
Diagnostic Procedure .....	704	Component Inspection .....	745
Component Inspection .....	705	Removal and Installation .....	745
Removal and Installation .....	705	<b>DTC P0605 ECM ..... 746</b>	
<b>DTC P0122, P0123 TP SENSOR ..... 706</b>		Component Description .....	746
Component Description .....	706	On Board Diagnosis Logic .....	746
CONSULT-II Reference Value in Data Monitor Mode		DTC Confirmation Procedure .....	746
	706	Diagnostic Procedure .....	748
On Board Diagnosis Logic .....	706	<b>DTC P1031, P1032, P1051, P1052 A/F SENSOR 1 HEATER ..... 749</b>	
DTC Confirmation Procedure .....	707	Description .....	749
Wiring Diagram .....	708	CONSULT-II Reference Value in Data Monitor Mode	
Diagnostic Procedure .....	710		749
Component Inspection .....	712	On Board Diagnosis Logic .....	749
Removal and Installation .....	712	DTC Confirmation Procedure .....	749
<b>DTC P0222, P0223 TP SENSOR ..... 713</b>		Wiring Diagram .....	751
Component Description .....	713	Diagnostic Procedure .....	754
CONSULT-II Reference Value in Data Monitor Mode		Component Inspection .....	756
	713	Removal and Installation .....	756
On Board Diagnosis Logic .....	713	<b>DTC P1065 ECM POWER SUPPLY ..... 757</b>	
DTC Confirmation Procedure .....	714	Component Description .....	757
Wiring Diagram .....	715	On Board Diagnosis Logic .....	757
Diagnostic Procedure .....	717	DTC Confirmation Procedure .....	757
Component Inspection .....	719	Wiring Diagram .....	758
Removal and Installation .....	719	Diagnostic Procedure .....	759
<b>DTC P0327, P0328, P0332, P0333 KS ..... 720</b>		<b>DTC P1111, P1136 IVT CONTROL SOLENOID</b>	
Component Description .....	720		
On Board Diagnosis Logic .....	720		

<b>VALVE</b> .....	<b>761</b>	<b>DTC P1226 TP SENSOR</b> .....	<b>801</b>
Component Description .....	761	Component Description .....	801
CONSULT-II Reference Value in Data Monitor Mode .....	761	On Board Diagnosis Logic .....	801
On Board Diagnosis Logic .....	761	DTC Confirmation Procedure .....	801
DTC Confirmation Procedure .....	761	Diagnostic Procedure .....	802
Wiring Diagram .....	763	Removal and Installation .....	802
Diagnostic Procedure .....	767	<b>DTC P1229 SENSOR POWER SUPPLY</b> .....	<b>803</b>
Component Inspection .....	768	On Board Diagnosis Logic .....	803
Removal and Installation .....	768	DTC Confirmation Procedure .....	803
<b>DTC P1121 ELECTRIC THROTTLE CONTROL</b>		Wiring Diagram .....	804
<b>ACTUATOR</b> .....	<b>769</b>	Diagnostic Procedure .....	807
Component Description .....	769	<b>DTC P1271, P1281 A/F SENSOR 1</b> .....	<b>810</b>
On Board Diagnosis Logic .....	769	Component Description .....	810
DTC Confirmation Procedure .....	769	CONSULT-II Reference Value in Data Monitor Mode .....	810
Diagnostic Procedure .....	770	On Board Diagnosis Logic .....	810
<b>DTC P1122 ELECTRIC THROTTLE CONTROL</b>		DTC Confirmation Procedure .....	810
<b>FUNCTION</b> .....	<b>772</b>	Overall Function Check .....	811
Description .....	772	Wiring Diagram .....	812
On Board Diagnosis Logic .....	772	Diagnostic Procedure .....	815
DTC Confirmation Procedure .....	772	Removal and Installation .....	818
Wiring Diagram .....	773	<b>DTC P1272, P1282 A/F SENSOR 1</b> .....	<b>819</b>
Diagnostic Procedure .....	774	Component Description .....	819
Component Inspection .....	777	CONSULT-II Reference Value in Data Monitor Mode .....	819
Removal and Installation .....	777	On Board Diagnosis Logic .....	819
<b>DTC P1124, P1126 THROTTLE CONTROL MOTOR</b>		DTC Confirmation Procedure .....	819
<b>RELAY</b> .....	<b>778</b>	Overall Function Check .....	820
Component Description .....	778	Wiring Diagram .....	821
CONSULT-II Reference Value in Data Monitor Mode .....	778	Diagnostic Procedure .....	824
On Board Diagnosis Logic .....	778	Removal and Installation .....	827
DTC Confirmation Procedure .....	778	<b>DTC P1276, P1286 A/F SENSOR 1</b> .....	<b>828</b>
Wiring Diagram .....	780	Component Description .....	828
Diagnostic Procedure .....	781	CONSULT-II Reference Value in Data Monitor Mode .....	828
<b>DTC P1128 THROTTLE CONTROL MOTOR</b> .....	<b>784</b>	On Board Diagnosis Logic .....	828
Component Description .....	784	Overall Function Check .....	828
On Board Diagnosis Logic .....	784	Wiring Diagram .....	830
DTC Confirmation Procedure .....	784	Diagnostic Procedure .....	833
Wiring Diagram .....	785	Removal and Installation .....	836
Diagnostic Procedure .....	786	<b>DTC P1564 ASCD STEERING SWITCH</b> .....	<b>837</b>
Component Inspection .....	787	Component Description .....	837
Removal and Installation .....	788	CONSULT-II Reference Value in Data Monitor Mode .....	837
<b>DTC P1217 ENGINE OVER TEMPERATURE</b> .....	<b>789</b>	On Board Diagnosis Logic .....	837
Description .....	789	DTC Confirmation Procedure .....	838
CONSULT-II Reference Value in Data Monitor Mode .....	790	Wiring Diagram .....	839
On Board Diagnosis Logic .....	791	Diagnostic Procedure .....	840
Overall Function Check .....	791	Component Inspection .....	843
Wiring Diagram .....	793	<b>DTC P1572 ASCD BRAKE SWITCH</b> .....	<b>844</b>
Diagnostic Procedure .....	795	Component Description .....	844
Main 12 Causes of Overheating .....	797	CONSULT-II Reference Value in Data Monitor Mode .....	844
Component Inspection .....	798	On Board Diagnosis Logic .....	844
<b>DTC P1225 TP SENSOR</b> .....	<b>799</b>	DTC Confirmation Procedure .....	845
Component Description .....	799	Overall Function Check .....	845
On Board Diagnosis Logic .....	799	Wiring Diagram .....	847
DTC Confirmation Procedure .....	799	Diagnostic Procedure .....	848
Diagnostic Procedure .....	800	Component Inspection .....	856
Removal and Installation .....	800		

<b>DTC P1706 PNP SWITCH</b> .....	<b>858</b>	DTC Confirmation Procedure .....	892	
Component Description .....	858	Wiring Diagram .....	893	A
CONSULT-II Reference Value in Data Monitor Mode		Diagnostic Procedure .....	895	
. 858		Component Inspection .....	897	
On Board Diagnosis Logic .....	858	Removal and Installation .....	898	EC
Overall Function Check .....	858	<b>ASC D BRAKE SWITCH</b> .....	<b>899</b>	
Wiring Diagram .....	859	Component Description .....	899	
Diagnostic Procedure .....	860	CONSULT-II Reference Value in Data Monitor Mode		
<b>DTC P1715 INPUT SPEED SENSOR (TURBINE</b>		. 899		C
<b>REVOLUTION SENSOR)</b> .....	<b>863</b>	Wiring Diagram .....	900	
Description .....	863	Diagnostic Procedure .....	901	
CONSULT-II Reference Value in Data Monitor Mode		Component Inspection .....	910	D
. 863		<b>ASC D INDICATOR</b> .....	<b>912</b>	
On Board Diagnosis Logic .....	863	Component Description .....	912	
Diagnostic Procedure .....	863	CONSULT-II Reference Value in Data Monitor Mode		E
<b>DTC P1805 BRAKE SWITCH</b> .....	<b>864</b>	. 912		
Description .....	864	Wiring Diagram .....	913	
CONSULT-II Reference Value in Data Monitor Mode		Diagnostic Procedure .....	914	F
. 864		<b>ELECTRICAL LOAD SIGNAL</b> .....	<b>915</b>	
On Board Diagnosis Logic .....	864	Description .....	915	G
DTC Confirmation Procedure .....	864	CONSULT-II Reference Value in Data Monitor Mode		
Wiring Diagram .....	866	. 915		
Diagnostic Procedure .....	867	Diagnostic Procedure .....	915	
Component Inspection .....	869	<b>EVAP CANISTER PURGE VOLUME CONTROL</b>		
<b>DTC P2122, P2123 APP SENSOR</b> .....	<b>870</b>	<b>SOLENOID VALVE</b> .....	<b>917</b>	H
Component Description .....	870	Description .....	917	
CONSULT-II Reference Value in Data Monitor Mode		CONSULT-II Reference Value in Data Monitor Mode		
. 870		. 917		I
On Board Diagnosis Logic .....	870	Wiring Diagram .....	918	
DTC Confirmation Procedure .....	871	Diagnostic Procedure .....	920	
Wiring Diagram .....	872	Component Inspection .....	923	
Diagnostic Procedure .....	873	Removal and Installation .....	923	J
Component Inspection .....	875	<b>EVAP CANISTER VENT CONTROL VALVE</b> .....	<b>924</b>	
Removal and Installation .....	875	Component Description .....	924	
<b>DTC P2127, P2128 APP SENSOR</b> .....	<b>876</b>	Wiring Diagram .....	925	K
Component Description .....	876	Diagnostic Procedure .....	926	
CONSULT-II Reference Value in Data Monitor Mode		Component Inspection .....	928	
. 876		<b>FUEL INJECTOR</b> .....	<b>929</b>	L
On Board Diagnosis Logic .....	876	Component Description .....	929	
DTC Confirmation Procedure .....	877	CONSULT-II Reference Value in Data Monitor Mode		
Wiring Diagram .....	878	. 929		
Diagnostic Procedure .....	880	Wiring Diagram .....	930	M
Component Inspection .....	882	Diagnostic Procedure .....	931	
Removal and Installation .....	882	Component Inspection .....	935	
<b>DTC P2135 TP SENSOR</b> .....	<b>883</b>	Removal and Installation .....	935	
Component Description .....	883	<b>FUEL PUMP</b> .....	<b>936</b>	
CONSULT-II Reference Value in Data Monitor Mode		Description .....	936	
. 883		CONSULT-II Reference Value in Data Monitor Mode		
On Board Diagnosis Logic .....	883	. 936		
DTC Confirmation Procedure .....	884	Wiring Diagram .....	937	
Wiring Diagram .....	885	Diagnostic Procedure .....	938	
Diagnostic Procedure .....	887	Component Inspection .....	941	
Component Inspection .....	889	Removal and Installation .....	941	
Removal and Installation .....	890	<b>HO2S2</b> .....	<b>942</b>	
<b>DTC P2138 APP SENSOR</b> .....	<b>891</b>	Component Description .....	942	
Component Description .....	891	CONSULT-II Reference Value in Data Monitor Mode		
CONSULT-II Reference Value in Data Monitor Mode		. 942		
. 891		Wiring Diagram .....	943	
On Board Diagnosis Logic .....	891	Diagnostic Procedure .....	946	

Component Inspection .....	949
Removal and Installation .....	950
<b>HO2S2 HEATER .....</b>	<b>951</b>
Description .....	951
CONSULT-II Reference Value in Data Monitor Mode .....	951
Wiring Diagram .....	952
Diagnostic Procedure .....	955
Component Inspection .....	958
Removal and Installation .....	958
<b>IAT SENSOR .....</b>	<b>959</b>
Component Description .....	959
Wiring Diagram .....	960
Diagnostic Procedure .....	961
Component Inspection .....	963
Removal and Installation .....	963
<b>IGNITION SIGNAL .....</b>	<b>964</b>
Component Description .....	964
Wiring Diagram .....	965
Diagnostic Procedure .....	970
Component Inspection .....	975
Removal and Installation .....	976
<b>REFRIGERANT PRESSURE SENSOR .....</b>	<b>977</b>
Component Description .....	977
Wiring Diagram .....	978
Diagnostic Procedure .....	979
Removal and Installation .....	982
<b>VIAS .....</b>	<b>983</b>
Description .....	983
CONSULT-II Reference Value in Data Monitor Mode .....	984
Wiring Diagram .....	985
Diagnostic Procedure .....	987
Component Inspection .....	990
Removal and Installation .....	991
<b>VSS .....</b>	<b>992</b>
Description .....	992
Diagnostic Procedure .....	992
<b>MIL AND DATA LINK CONNECTOR .....</b>	<b>993</b>
Wiring Diagram .....	993
<b>SERVICE DATA AND SPECIFICATIONS (SDS) ...</b>	<b>995</b>
Fuel Pressure .....	995
Idle Speed and Ignition Timing .....	995
Mass Air Flow Sensor .....	995
Intake Air Temperature Sensor .....	995
Engine Coolant Temperature Sensor .....	995
Air Fuel Ratio (A/F) Sensor 1 Heater .....	995
Heated Oxygen sensor 2 Heater .....	995
Crankshaft Position Sensor (POS) .....	995
Camshaft Position Sensor (PHASE) .....	995
Throttle Control Motor .....	995
Fuel Injector .....	995
Fuel Pump .....	995

**YD**

<b>INDEX FOR DTC .....</b>	<b>996</b>
DTC No. Index .....	996
Alphabetical Index .....	998

<b>PRECAUTIONS .....</b>	<b>1000</b>
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	1000
On Board Diagnostic (OBD) System of Engine .....	1000
Precautions .....	1000
<b>PREPARATION .....</b>	<b>1003</b>
Special Service Tools .....	1003
Commercial Service Tools .....	1003
<b>ENGINE CONTROL SYSTEM .....</b>	<b>1004</b>
System Diagram .....	1004
Vacuum Hose Drawing .....	1005
System Chart .....	1007
Fuel Injection Control System .....	1007
Fuel Injection Timing Control System .....	1009
Air Conditioning Cut Control .....	1009
Fuel Cut Control (At No Load & High Engine Speed) .....	1009
Crankcase Ventilation System .....	1010
CAN Communication .....	1011
<b>BASIC SERVICE PROCEDURE .....</b>	<b>1012</b>
Fuel Filter .....	1012
Fuel Pump Learning Value Clearing .....	1013
Injector Adjustment Value Registration .....	1014
<b>ON BOARD DIAGNOSTIC (OBD) SYSTEM .....</b>	<b>1016</b>
DTC Detection Logic .....	1016
Diagnostic Trouble Code (DTC) .....	1016
Freeze Frame Data .....	1017
NATS (Nissan Anti-theft System) .....	1017
Malfunction Indicator Lamp (MIL) .....	1017
Relationship Between MIL, DTC, CONSULT-II and Driving Patterns .....	1020
<b>TROUBLE DIAGNOSIS .....</b>	<b>1022</b>
Trouble Diagnosis Introduction .....	1022
DTC Inspection Priority Chart .....	1026
Basic Inspection .....	1027
Symptom Matrix Chart .....	1031
Engine Control Component Parts Location .....	1035
Circuit Diagram .....	1039
ECM Harness Connector Terminal Layout .....	1041
ECM Terminals And Reference Value .....	1041
CONSULT-II Function (ENGINE) .....	1047
CONSULT-II Reference Value in Data Monitor Mode .....	1054
Major Sensor Reference Graph in Data Monitor Mode .....	1057
<b>TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT .....</b>	<b>1058</b>
Description .....	1058
Diagnostic Procedure .....	1058
<b>POWER SUPPLY AND GROUND CIRCUIT .....</b>	<b>1059</b>
ECM Terminals and Reference Value .....	1059
Wiring Diagram .....	1060
Diagnostic Procedure .....	1061
Ground Inspection .....	1066
<b>DTC U1000 CAN COMMUNICATION LINE .....</b>	<b>1067</b>
Description .....	1067
On Board Diagnosis Logic .....	1067
DTC Confirmation Procedure .....	1067



Wiring Diagram .....	1068	Component Inspection .....	1100
Diagnostic Procedure .....	1069	Removal and Installation .....	1100
<b>DTC P0016 CKP - CMP CORRELATION .....</b>	<b>1070</b>	<b>DTC P0182, P0183 FUEL PUMP TEMPERATURE</b>	
On Board Diagnosis Logic .....	1070	<b>SENSOR .....</b>	<b>1101</b>
DTC Confirmation Procedure .....	1070	Description .....	1101
Diagnostic Procedure .....	1070	CONSULT-II Reference Value in Data Monitor Mode	1101
<b>DTC P0088 FUEL SYSTEM .....</b>	<b>1072</b>	ECM Terminals and Reference Value .....	1101
On Board Diagnosis Logic .....	1072	On Board Diagnosis Logic .....	1101
DTC Confirmation Procedure .....	1072	DTC Confirmation Procedure .....	1102
Diagnostic Procedure .....	1072	Wiring Diagram .....	1103
Removal and Installation .....	1073	Diagnostic Procedure .....	1104
<b>DTC P0089 FUEL PUMP .....</b>	<b>1074</b>	Removal and Installation .....	1105
On Board Diagnosis Logic .....	1074	<b>DTC P0192, P0193 FRP SENSOR .....</b>	<b>1106</b>
DTC Confirmation Procedure .....	1074	Description .....	1106
Diagnostic Procedure .....	1075	CONSULT-II Reference Value in Data Monitor Mode	1106
Removal and Installation .....	1075	ECM Terminals and Reference Value .....	1106
<b>DTC P0093 FUEL SYSTEM .....</b>	<b>1076</b>	On Board Diagnosis Logic .....	1106
On Board Diagnosis Logic .....	1076	DTC Confirmation Procedure .....	1107
DTC Confirmation Procedure .....	1076	Wiring Diagram .....	1108
Diagnostic Procedure .....	1077	Diagnostic Procedure .....	1109
Component Inspection .....	1078	Component Inspection .....	1110
Removal and Installation .....	1079	Removal and Installation .....	1110
<b>DTC P0102, P0103 MAF SENSOR .....</b>	<b>1080</b>	<b>DTC P0200 FUEL INJECTOR .....</b>	<b>1111</b>
Component Description .....	1080	On Board Diagnosis Logic .....	1111
CONSULT-II Reference Value in Data Monitor Mode	1080	DTC Confirmation Procedure .....	1111
ECM Terminals and Reference Value .....	1080	Diagnostic Procedure .....	1111
On Board Diagnosis Logic .....	1081	<b>DTC P0201 - P0204 FUEL INJECTOR .....</b>	<b>1113</b>
DTC Confirmation Procedure .....	1081	Component Description .....	1113
Wiring Diagram .....	1082	CONSULT-II Reference Value in Data Monitor Mode	1113
Diagnostic Procedure .....	1083	ECM Terminals and Reference Value .....	1113
Component Inspection .....	1084	On Board Diagnosis Logic .....	1114
Removal and Installation .....	1085	DTC Confirmation Procedure .....	1115
<b>DTC P0112, P0113 IAT SENSOR .....</b>	<b>1086</b>	Wiring Diagram .....	1116
Component Description .....	1086	Diagnostic Procedure .....	1117
On Board Diagnosis Logic .....	1086	Component Inspection .....	1118
DTC Confirmation Procedure .....	1086	Removal and Installation .....	1119
Wiring Diagram .....	1088	<b>DTC P0217 ENGINE OVER TEMPERATURE .....</b>	<b>1120</b>
Diagnostic Procedure .....	1089	Description .....	1120
Component Inspection .....	1090	CONSULT-II Reference Value in Data Monitor Mode	1121
Removal and Installation .....	1090	On Board Diagnosis Logic .....	1121
<b>DTC P0117, P0118 ECT SENSOR .....</b>	<b>1091</b>	Overall Function Check .....	1121
Description .....	1091	Wiring Diagram .....	1123
On Board Diagnosis Logic .....	1091	Diagnostic Procedure .....	1125
DTC Confirmation Procedure .....	1091	Main 12 Causes of Overheating .....	1128
Wiring Diagram .....	1093	Component Inspection .....	1129
Diagnostic Procedure .....	1094	<b>DTC P0222, P0223 APP SENSOR .....</b>	<b>1130</b>
Component Inspection .....	1095	Description .....	1130
Removal and Installation .....	1095	CONSULT-II Reference Value in Data Monitor Mode	1130
<b>DTC P0122, P0123 APP SENSOR .....</b>	<b>1096</b>	ECM Terminals and Reference Value .....	1130
Description .....	1096	On Board Diagnosis Logic .....	1131
CONSULT-II Reference Value in Data Monitor Mode	1096	DTC Confirmation Procedure .....	1131
ECM Terminals and Reference Value .....	1096	Wiring Diagram .....	1132
On Board Diagnosis Logic .....	1097	Diagnostic Procedure .....	1133
DTC Confirmation Procedure .....	1097		
Wiring Diagram .....	1098		
Diagnostic Procedure .....	1099		

Component Inspection .....	1134	Diagnostic Procedure .....	1168
Removal and Installation .....	1134	Component Inspection .....	1170
<b>DTC P0234 TC SYSTEM .....</b>	<b>1135</b>	Removal and Installation .....	1170
Description .....	1135	<b>DTC P0501 ASCD VEHICLE SPEED SENSOR .....</b>	<b>1171</b>
ECM Terminals and Reference Value .....	1135	Component Description .....	1171
On Board Diagnosis Logic .....	1136	On Board Diagnosis Logic .....	1171
Overall Function Check .....	1136	DTC Confirmation Procedure .....	1171
Wiring Diagram .....	1137	Diagnostic Procedure .....	1172
Diagnostic Procedure .....	1138	<b>DTC P0502 ASCD VEHICLE SPEED SENSOR .....</b>	<b>1173</b>
Component Inspection .....	1140	Component Description .....	1173
Removal and Installation .....	1140	On Board Diagnosis Logic .....	1173
<b>DTC P0237, P0238 TC BOOST SENSOR .....</b>	<b>1141</b>	DTC Confirmation Procedure .....	1173
Component Description .....	1141	Diagnostic Procedure .....	1174
CONSULT-II Reference Value in Data Monitor Mode .....	1141	<b>DTC P0503 ASCD VEHICLE SPEED SENSOR .....</b>	<b>1175</b>
ECM Terminals and Reference Value .....	1141	Component Description .....	1175
On Board Diagnosis Logic .....	1142	On Board Diagnosis Logic .....	1175
DTC Confirmation Procedure .....	1142	DTC Confirmation Procedure .....	1175
Wiring Diagram .....	1143	Diagnostic Procedure .....	1176
Diagnostic Procedure .....	1144	<b>DTC P0504 ASCD BRAKE SWITCH .....</b>	<b>1177</b>
Component Inspection .....	1146	Component Description .....	1177
Removal and Installation .....	1146	CONSULT-II Reference Value in Data Monitor Mode .....	1177
<b>DTC P0335 CKP SENSOR .....</b>	<b>1147</b>	ECM Terminals and Reference Value .....	1177
Description .....	1147	On Board Diagnosis Logic .....	1178
CONSULT-II Reference Value in Data Monitor Mode .....	1147	DTC confirmation Procedure .....	1178
ECM Terminals and Reference Value .....	1147	Wiring Diagram .....	1180
On Board Diagnosis Logic .....	1148	Diagnostic Procedure .....	1181
DTC Confirmation Procedure .....	1148	Component Inspection .....	1190
Wiring Diagram .....	1149	<b>DTC P0563 BATTERY VOLTAGE .....</b>	<b>1191</b>
Diagnostic Procedure .....	1150	On Board Diagnosis Logic .....	1191
Component Inspection .....	1152	DTC Confirmation Procedure .....	1191
Removal and Installation .....	1152	Diagnostic Procedure .....	1191
<b>DTC P0336 CKP SENSOR .....</b>	<b>1153</b>	<b>DTC P0580, P0581 ASCD STEERING SWITCH .....</b>	<b>1194</b>
Description .....	1153	Component Description .....	1194
CONSULT-II Reference Value in Data Monitor Mode .....	1153	CONSULT-II Reference Value in Data Monitor Mode .....	1194
ECM Terminals and Reference Value .....	1153	ECM Terminals and Reference Value .....	1194
On Board Diagnosis Logic .....	1154	On Board Diagnosis Logic .....	1195
DTC Confirmation Procedure .....	1154	DTC Confirmation Procedure .....	1195
Wiring Diagram .....	1155	Wiring Diagram .....	1196
Diagnostic Procedure .....	1156	Diagnostic Procedure .....	1197
Component Inspection .....	1158	Component Inspection .....	1200
Removal and Installation .....	1158	<b>DTC P0605 ECM .....</b>	<b>1201</b>
<b>DTC P0340 CMP SENSOR .....</b>	<b>1159</b>	Description .....	1201
Description .....	1159	On Board Diagnosis Logic .....	1201
ECM Terminals and Reference Value .....	1159	DTC Confirmation Procedure .....	1201
On Board Diagnosis Logic .....	1160	Diagnostic Procedure .....	1202
DTC Confirmation Procedure .....	1160	<b>DTC P0606 ECM .....</b>	<b>1203</b>
Wiring Diagram .....	1161	Description .....	1203
Diagnostic Procedure .....	1162	On Board Diagnosis Logic .....	1203
Component Inspection .....	1163	DTC Confirmation Procedure .....	1203
Removal and Installation .....	1164	Diagnostic Procedure .....	1204
<b>DTC P0341 CMP SENSOR .....</b>	<b>1165</b>	<b>DTC P0628, P0629 FUEL PUMP .....</b>	<b>1205</b>
Description .....	1165	Description .....	1205
ECM Terminals and Reference Value .....	1165	CONSULT-II Reference Value in Data Monitor Mode .....	1205
On Board Diagnosis Logic .....	1166	ECM Terminals and Reference Value .....	1205
DTC Confirmation Procedure .....	1166	On Board Diagnosis Logic .....	1206
Wiring Diagram .....	1167	DTC Confirmation Procedure .....	1206

Wiring Diagram .....	1207	ECM Terminals and Reference Value .....	1246
Diagnostic Procedure .....	1208	On Board Diagnosis Logic .....	1247
Component Inspection .....	1209	DTC Confirmation Procedure .....	1247
Removal and Installation .....	1209	Wiring Diagram .....	1248
<b>DTC P0642, P0643 SENSOR POWER SUPPLY ..1210</b>		Diagnostic Procedure .....	1249
ECM Terminals and Reference Value .....	1210	Component Inspection .....	1250
On Board Diagnosis Logic .....	1210	Removal and Installation .....	1250
DTC Confirmation Procedure .....	1211	<b>DTC P1275 FUEL PUMP .....</b>	<b>1251</b>
Wiring Diagram .....	1212	Description .....	1251
Diagnostic Procedure .....	1213	CONSULT-II Reference Value in Data Monitor Mode .....	1251
<b>DTC P0652, P0653 SENSOR POWER SUPPLY ..1215</b>		ECM Terminals and Reference Value .....	1251
ECM Terminals and Reference Value .....	1215	On Board Diagnosis Logic .....	1252
On Board Diagnosis Logic .....	1216	DTC Confirmation Procedure .....	1252
DTC Confirmation Procedure .....	1216	Wiring Diagram .....	1254
Wiring Diagram .....	1217	Diagnostic Procedure .....	1255
Diagnostic Procedure .....	1218	Component Inspection .....	1256
<b>DTC P0686 ECM RELAY .....</b>	<b>1220</b>	Removal and Installation .....	1256
ECM Terminals and Reference valve .....	1220	<b>DTC P1616 ECM .....</b>	<b>1257</b>
On Board Diagnosis Logic .....	1220	Description .....	1257
DTC Confirmation Procedure .....	1220	On Board Diagnosis Logic .....	1257
Wiring Diagram .....	1222	DTC Confirmation Procedure .....	1257
Diagnostic Procedure .....	1223	Diagnostic Procedure .....	1258
<b>DTC P1268 - P1271 FUEL INJECTOR .....</b>	<b>1225</b>	<b>DTC P1622 INJECTOR ADJUSTMENT VALUE ..1259</b>	
Component Description .....	1225	Description .....	1259
CONSULT-II Reference Value in Data Monitor Mode .....	1225	On Board Diagnosis Logic .....	1259
ECM Terminals and Reference Value .....	1225	DTC Confirmation Procedure .....	1259
On Board Diagnosis Logic .....	1226	Diagnostic Procedure .....	1260
DTC Confirmation Procedure .....	1227	<b>DTC P1623 INJECTOR ADJUSTMENT VALUE ..1261</b>	
Wiring Diagram .....	1228	Description .....	1261
Diagnostic Procedure .....	1229	On Board Diagnosis Logic .....	1261
Component Inspection .....	1231	DTC Confirmation Procedure .....	1261
Removal and Installation .....	1232	Diagnostic Procedure .....	1262
<b>DTC P1272 FUEL PUMP .....</b>	<b>1233</b>	<b>DTC P2135 APP SENSOR .....</b>	<b>1263</b>
Description .....	1233	Description .....	1263
CONSULT-II Reference Value in Data Monitor Mode .....	1233	CONSULT-II Reference Value in Data Monitor Mode .....	1263
ECM Terminals and Reference Value .....	1233	ECM Terminals and Reference Value .....	1263
On Board Diagnosis Logic .....	1234	On Board Diagnosis Logic .....	1264
DTC Confirmation Procedure .....	1234	DTC Confirmation Procedure .....	1264
Wiring Diagram .....	1236	Wiring Diagram .....	1265
Diagnostic Procedure .....	1237	Diagnostic Procedure .....	1266
Component Inspection .....	1238	Component Inspection .....	1267
Removal and Installation .....	1238	Removal and Installation .....	1268
<b>DTC P1273 FUEL PUMP .....</b>	<b>1239</b>	<b>DTC P2146, P2149 FUEL INJECTOR POWER SUPPLY .....</b>	<b>1269</b>
Description .....	1239	Component Description .....	1269
CONSULT-II Reference Value in Data Monitor Mode .....	1239	CONSULT-II Reference Value in Data Monitor Mode .....	1269
ECM Terminals and Reference Value .....	1239	ECM Terminals and Reference Value .....	1269
On Board Diagnosis Logic .....	1240	On Board Diagnosis Logic .....	1270
DTC Confirmation Procedure .....	1240	DTC Confirmation Procedure .....	1271
Wiring Diagram .....	1242	Wiring Diagram .....	1272
Diagnostic Procedure .....	1243	Diagnostic Procedure .....	1273
Component Inspection .....	1245	<b>DTC P2147, P2148 FUEL INJECTOR CIRCUIT ..1274</b>	
Removal and Installation .....	1245	Component Description .....	1274
<b>DTC P1274 FUEL PUMP .....</b>	<b>1246</b>	CONSULT-II Reference Value in Data Monitor Mode .....	1274
Description .....	1246	ECM Terminals and Reference Value .....	1274
CONSULT-II Reference Value in Data Monitor Mode .....	1246		

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

On Board Diagnosis Logic .....	1275	Wiring Diagram .....	1308
DTC Confirmation Procedure .....	1276	Diagnostic Procedure .....	1309
Wiring Diagram .....	1277	Removal and Installation .....	1311
Diagnostic Procedure .....	1278	<b>BRAKE SWITCH .....</b>	<b>1312</b>
Component Inspection .....	1280	Description .....	1312
Removal and Installation .....	1280	CONSULT-II Reference Value in Data Monitor Mode .....	1312
<b>DTC P2228, P2229 BARO SENSOR .....</b>	<b>1281</b>	ECM Terminals and Reference Value .....	1312
Description .....	1281	Wiring Diagram .....	1313
On Board Diagnosis Logic .....	1281	Diagnostic Procedure .....	1314
DTC Confirmation Procedure .....	1281	Component Inspection .....	1323
Diagnostic Procedure .....	1282	<b>PNP SWITCH .....</b>	<b>1324</b>
<b>GLOW CONTROL SYSTEM .....</b>	<b>1283</b>	Description .....	1324
Description .....	1283	CONSULT-II Reference Value in Data Monitor Mode .....	1324
Wiring Diagram .....	1284	ECM Terminals and Reference Value .....	1324
Diagnostic Procedure .....	1285	Wiring Diagram .....	1325
Component Inspection .....	1289	Diagnostic Procedure .....	1326
Removal and Installation .....	1289	<b>START SIGNAL .....</b>	<b>1330</b>
<b>EGR VOLUME CONTROL SYSTEM .....</b>	<b>1290</b>	Wiring Diagram .....	1330
Description .....	1290	Diagnostic Procedure .....	1331
CONSULT-II Reference Value in Data Monitor Mode .....	1291	<b>ASCD INDICATOR .....</b>	<b>1333</b>
ECM Terminals and Reference Value .....	1291	Component Description .....	1333
Wiring Diagram .....	1292	Wiring Diagram .....	1334
Diagnostic Procedure .....	1293	Diagnostic Procedure .....	1335
Component Inspection .....	1295	<b>MIL AND DATA LINK CONNECTOR .....</b>	<b>1336</b>
Removal and Installation .....	1296	Wiring Diagram .....	1336
<b>TC BOOST CONTROL SOLENOID VALVE .....</b>	<b>1297</b>	<b>AUTOMATIC SPEED CONTROL DEVICE (ASCD) .....</b>	<b>1337</b>
Description .....	1297	System Description .....	1337
ECM Terminals and Reference Value .....	1298	Component Description .....	1338
Wiring Diagram .....	1299	<b>SERVICE DATA AND SPECIFICATIONS (SDS) .....</b>	<b>1339</b>
Diagnostic Procedure .....	1300	General Specifications .....	1339
Component Inspection .....	1301	Mass Air Flow Sensor .....	1339
Removal and Installation .....	1301	Intake Air Temperature Sensor .....	1339
<b>INTAKE AIR CONTROL VALVE CONTROL SOLENOID VALVE .....</b>	<b>1302</b>	Engine Coolant Temperature Sensor .....	1339
Description .....	1302	Fuel Rail Pressure Sensor .....	1339
ECM Terminals and Reference Value .....	1302	Fuel Injector .....	1339
Wiring Diagram .....	1303	Glow Plug .....	1339
Diagnostic Procedure .....	1304	EGR Volume Control Valve .....	1339
Component Inspection .....	1306	Crankshaft Position Sensor .....	1339
<b>REFRIGERANT PRESSURE SENSOR .....</b>	<b>1307</b>	Camshaft Position Sensor .....	1339
Component Description .....	1307	Fuel Pump .....	1340
ECM Terminals and Reference Value .....	1307		

# APPLICATION NOTICE

## APPLICATION NOTICE

PPF:00000

### How to Check Vehicle Type

GBS000H9

Check the vehicle type (refer to [GI-54, "IDENTIFICATION INFORMATION"](#) ) to confirm the service information in EC section.

Service information	Remarks
VQ TYPE 1	Models for Australia
VQ TYPE 2	Models except for Australia

A

EC

C

D

E

F

G

H

I

J

K

L

M

# INDEX FOR DTC

[VQ TYPE 1]

## INDEX FOR DTC

PFP:00024

### DTC No. Index

GBS000HA

**NOTE:**

If DTC U1000 or U1001 is displayed with other DTC, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-146, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#).

DTC*1		Items (CONSULT-II screen terms)	Reference page
CONSULT-II GST*2	ECM*3		
U1000	1000*4	CAN COMM CIRCUIT	<a href="#">EC-146</a>
U1001	1001*4	CAN COMM CIRCUIT	<a href="#">EC-146</a>
<b>P0000</b>	<b>0000</b>	<b>NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.</b>	—
P0011	0011	INT/V TIM CONT-B1	<a href="#">EC-149</a>
P0021	0021	INT/V TIM CONT-B2	<a href="#">EC-149</a>
P0037	0037	HO2S2 HTR (B1)	<a href="#">EC-154</a>
P0038	0038	HO2S2 HTR (B1)	<a href="#">EC-154</a>
P0057	0057	HO2S2 HTR (B2)	<a href="#">EC-154</a>
P0058	0058	HO2S2 HTR (B2)	<a href="#">EC-154</a>
P0102	0102	MAF SEN/CIRCUIT	<a href="#">EC-163</a>
P0103	0103	MAF SEN/CIRCUIT	<a href="#">EC-163</a>
P0112	0112	IAT SEN/CIRCUIT	<a href="#">EC-170</a>
P0113	0113	IAT SEN/CIRCUIT	<a href="#">EC-170</a>
P0117	0117	ECT SEN/CIRC	<a href="#">EC-175</a>
P0118	0118	ECT SEN/CIRC	<a href="#">EC-175</a>
P0122	0122	TP SEN 2/CIRC	<a href="#">EC-180</a>
P0123	0123	TP SEN 2/CIRC	<a href="#">EC-180</a>
P0138	0138	HO2S2 (B1)	<a href="#">EC-187</a>
P0139	0139	HO2S2 (B1)	<a href="#">EC-196</a>
P0158	0158	HO2S2 (B2)	<a href="#">EC-187</a>
P0159	0159	HO2S2 (B2)	<a href="#">EC-196</a>
P0171	0171	FUEL SYS-LEAN-B1	<a href="#">EC-207</a>
P0172	0172	FUEL SYS-RICH-B1	<a href="#">EC-219</a>
P0174	0174	FUEL SYS-LEAN-B2	<a href="#">EC-207</a>
P0175	0175	FUEL SYS-RICH-B2	<a href="#">EC-219</a>
P0222	0222	TP SEN 1/CIRC	<a href="#">EC-231</a>
P0223	0223	TP SEN 1/CIRC	<a href="#">EC-231</a>
P0300	0300	MULTI CYL MISFIRE	<a href="#">EC-238</a>
P0301	0301	CYL 1 MISFIRE	<a href="#">EC-238</a>
P0302	0302	CYL 2 MISFIRE	<a href="#">EC-238</a>
P0303	0303	CYL 3 MISFIRE	<a href="#">EC-238</a>
P0304	0304	CYL 4 MISFIRE	<a href="#">EC-238</a>
P0305	0305	CYL 5 MISFIRE	<a href="#">EC-238</a>
P0306	0306	CYL 6 MISFIRE	<a href="#">EC-238</a>
P0327	0327	KNOCK SEN/CIRC-B1	<a href="#">EC-247</a>
P0328	0328	KNOCK SEN/CIRC-B1	<a href="#">EC-247</a>

# INDEX FOR DTC

[VQ TYPE 1]

DTC*1		Items (CONSULT-II screen terms)	Reference page
CONSULT-II GST*2	ECM*3		
P0332	0332	KNOCK SEN/CIRC-B2	<a href="#">EC-247</a>
P0333	0333	KNOCK SEN/CIRC-B2	<a href="#">EC-247</a>
P0335	0335	CKP SEN/CIRCUIT	<a href="#">EC-252</a>
P0340	0340	CMP SEN/CIRC-B1	<a href="#">EC-259</a>
P0345	0345	CMP SEN/CIRC-B2	<a href="#">EC-259</a>
P0420	0420	TW CATALYST SYS-B1	<a href="#">EC-268</a>
P0430	0430	TW CATALYST SYS-B2	<a href="#">EC-268</a>
P0444	0444	PURG VOLUME CONT/V	<a href="#">EC-274</a>
P0445	0445	PURG VOLUME CONT/V	<a href="#">EC-274</a>
P0500	0500	VEH SPEED SEN/CIRC	<a href="#">EC-281</a>
P0550	0550	PW ST P SEN/CIRC	<a href="#">EC-283</a>
P0605	0605	ECM	<a href="#">EC-288</a>
P1031	1031	A/F SEN1 HTR (B1)	<a href="#">EC-291</a>
P1032	1032	A/F SEN1 HTR (B1)	<a href="#">EC-291</a>
P1051	1051	A/F SEN1 HTR (B2)	<a href="#">EC-291</a>
P1052	1052	A/F SEN1 HTR (B2)	<a href="#">EC-291</a>
P1065	1065	ECM BACK UP/CIRCUIT	<a href="#">EC-299</a>
P1111	1111	INT/V TIM V/CIR-B1	<a href="#">EC-303</a>
P1121	1121	ETC ACTR	<a href="#">EC-310</a>
P1122	1122	ETC FUNCTION/CIRC	<a href="#">EC-312</a>
P1124	1124	ETC MOT PWR	<a href="#">EC-318</a>
P1126	1126	ETC MOT PWR	<a href="#">EC-318</a>
P1128	1128	ETC MOT	<a href="#">EC-324</a>
P1136	1136	INT/V TIM V/CIR-B2	<a href="#">EC-303</a>
P1146	1146	HO2S2 (B1)	<a href="#">EC-329</a>
P1147	1147	HO2S2 (B1)	<a href="#">EC-340</a>
P1166	1166	HO2S2 (B2)	<a href="#">EC-329</a>
P1167	1167	HO2S2 (B2)	<a href="#">EC-340</a>
P1217	1217	ENG OVER TEMP	<a href="#">EC-351</a>
P1225	1225	CTP LEARNING	<a href="#">EC-361</a>
P1226	1226	CTP LEARNING	<a href="#">EC-363</a>
P1229	1229	SENSOR POWER/CIRC	<a href="#">EC-365</a>
P1271	1271	A/F SENSOR1 (B1)	<a href="#">EC-372</a>
P1272	1272	A/F SENSOR1 (B1)	<a href="#">EC-381</a>
P1273	1273	A/F SENSOR1 (B1)	<a href="#">EC-390</a>
P1274	1274	A/F SENSOR1 (B1)	<a href="#">EC-400</a>
P1276	1276	A/F SENSOR1 (B1)	<a href="#">EC-410</a>
P1278	1278	A/F SENSOR1 (B1)	<a href="#">EC-420</a>
P1279	1279	A/F SENSOR1 (B1)	<a href="#">EC-432</a>
P1281	1281	A/F SENSOR1 (B2)	<a href="#">EC-372</a>
P1282	1282	A/F SENSOR1 (B2)	<a href="#">EC-381</a>
P1283	1283	A/F SENSOR1 (B2)	<a href="#">EC-390</a>

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# INDEX FOR DTC

**[VQ TYPE 1]**

DTC*1		Items (CONSULT-II screen terms)	Reference page
CONSULT-II GST*2	ECM*3		
P1284	1284	A/F SENSOR1 (B2)	<a href="#">EC-400</a>
P1286	1286	A/F SENSOR1 (B2)	<a href="#">EC-410</a>
P1288	1288	A/F SENSOR1 (B2)	<a href="#">EC-420</a>
P1289	1289	A/F SENSOR1 (B2)	<a href="#">EC-432</a>
P1564	1564	ASCD SW	<a href="#">EC-444</a>
P1572	1572	ASCD BRAKE SW	<a href="#">EC-451</a>
P1574	1574	ASCD VHL SPD SEN	<a href="#">EC-464</a>
P1610 - P1615	1610 - 1615	NATS MALFUNCTION	<a href="#">EC-43</a>
P1706	1706	P-N POS SW/CIRCUIT	<a href="#">EC-466</a>
P1715	1715	IN PLUY SPEED	<a href="#">EC-472</a>
P1805	1805	BRAKE SW/CIRCUIT	<a href="#">EC-473</a>
P2122	2122	APP SEN 1/CIRC	<a href="#">EC-478</a>
P2123	2123	APP SEN 1/CIRC	<a href="#">EC-478</a>
P2127	2127	APP SEN 2/CIRC	<a href="#">EC-484</a>
P2128	2128	APP SEN 2/CIRC	<a href="#">EC-484</a>
P2135	2135	TP SENSOR	<a href="#">EC-491</a>
P2138	2138	APP SENSOR	<a href="#">EC-499</a>

\*1: 1st trip DTC No. is the same as DTC No.

\*2: This number is prescribed by ISO 15031-5.

\*3: In Diagnostic Test Mode II (Self-diagnostic results), this number is controlled by NISSAN.

\*4: The troubleshooting for this DTC needs CONSULT-II.



## Alphabetical Index

**NOTE:**

If DTC U1000 or U1001 is displayed with other DTC, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-146, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#).

Items (CONSULT-II screen terms)	DTC*1		Reference page
	CONSULT-II GST*2	ECM*3	
A/F SENSOR1 (B1)	P1271	1271	<a href="#">EC-372</a>
A/F SENSOR1 (B1)	P1272	1272	<a href="#">EC-381</a>
A/F SENSOR1 (B1)	P1273	1273	<a href="#">EC-390</a>
A/F SENSOR1 (B1)	P1274	1274	<a href="#">EC-400</a>
A/F SENSOR1 (B1)	P1276	1276	<a href="#">EC-410</a>
A/F SENSOR1 (B1)	P1278	1278	<a href="#">EC-420</a>
A/F SENSOR1 (B1)	P1279	1279	<a href="#">EC-432</a>
A/F SENSOR1 (B2)	P1281	1281	<a href="#">EC-372</a>
A/F SENSOR1 (B2)	P1282	1282	<a href="#">EC-381</a>
A/F SENSOR1 (B2)	P1283	1283	<a href="#">EC-390</a>
A/F SENSOR1 (B2)	P1284	1284	<a href="#">EC-400</a>
A/F SENSOR1 (B2)	P1286	1286	<a href="#">EC-410</a>
A/F SENSOR1 (B2)	P1288	1288	<a href="#">EC-420</a>
A/F SENSOR1 (B2)	P1289	1289	<a href="#">EC-432</a>
A/F SEN1 HTR (B1)	P1031	1031	<a href="#">EC-291</a>
A/F SEN1 HTR (B1)	P1032	1032	<a href="#">EC-291</a>
A/F SEN1 HTR (B2)	P1051	1051	<a href="#">EC-291</a>
A/F SEN1 HTR (B2)	P1052	1052	<a href="#">EC-291</a>
APP SEN 1/CIRC	P2122	2122	<a href="#">EC-478</a>
APP SEN 1/CIRC	P2123	2123	<a href="#">EC-478</a>
APP SEN 2/CIRC	P2127	2127	<a href="#">EC-484</a>
APP SEN 2/CIRC	P2128	2128	<a href="#">EC-484</a>
APP SENSOR	P2138	2138	<a href="#">EC-499</a>
ASCD BRAKE SW	P1572	1572	<a href="#">EC-451</a>
ASCD SW	P1564	1564	<a href="#">EC-444</a>
ASCD VHL SPD SEN	P1574	1574	<a href="#">EC-464</a>
BRAKE SW/CIRCUIT	P1805	1805	<a href="#">EC-473</a>
CAN COMM CIRCUIT	U1000	1000*4	<a href="#">EC-146</a>
CAN COMM CIRCUIT	U1001	1001*4	<a href="#">EC-146</a>
CKP SEN/CIRCUIT	P0335	0335	<a href="#">EC-252</a>
CMP SEN/CIRC-B1	P0340	0340	<a href="#">EC-259</a>
CMP SEN/CIRC-B2	P0345	0345	<a href="#">EC-259</a>
CTP LEARNING	P1225	1225	<a href="#">EC-361</a>
CTP LEARNING	P1226	1226	<a href="#">EC-363</a>
CYL 1 MISFIRE	P0301	0301	<a href="#">EC-238</a>
CYL 2 MISFIRE	P0302	0302	<a href="#">EC-238</a>
CYL 3 MISFIRE	P0303	0303	<a href="#">EC-238</a>
CYL 4 MISFIRE	P0304	0304	<a href="#">EC-238</a>

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# INDEX FOR DTC

[VQ TYPE 1]

Items (CONSULT-II screen terms)	DTC*1		Reference page
	CONSULT-II GST*2	ECM*3	
CYL 5 MISFIRE	P0305	0305	<a href="#">EC-238</a>
CYL 6 MISFIRE	P0306	0306	<a href="#">EC-238</a>
ECM	P0605	0605	<a href="#">EC-288</a>
ECM BACK UP/CIRCUIT	P1065	1065	<a href="#">EC-299</a>
ECT SEN/CIRC	P0117	0117	<a href="#">EC-175</a>
ECT SEN/CIRC	P0118	0118	<a href="#">EC-175</a>
ENG OVER TEMP	P1217	1217	<a href="#">EC-351</a>
ETC ACTR	P1121	1121	<a href="#">EC-310</a>
ETC FUNCTION/CIRC	P1122	1122	<a href="#">EC-312</a>
ETC MOT	P1128	1128	<a href="#">EC-324</a>
ETC MOT PWR	P1124	1124	<a href="#">EC-318</a>
ETC MOT PWR	P1126	1126	<a href="#">EC-318</a>
FUEL SYS-LEAN-B1	P0171	0171	<a href="#">EC-207</a>
FUEL SYS-LEAN-B2	P0174	0174	<a href="#">EC-207</a>
FUEL SYS-RICH-B1	P0172	0172	<a href="#">EC-219</a>
FUEL SYS-RICH-B2	P0175	0175	<a href="#">EC-219</a>
HO2S2 (B1)	P0138	0138	<a href="#">EC-187</a>
HO2S2 (B1)	P0139	0139	<a href="#">EC-196</a>
HO2S2 (B1)	P1146	1146	<a href="#">EC-329</a>
HO2S2 (B1)	P1147	1147	<a href="#">EC-340</a>
HO2S2 (B2)	P0158	0158	<a href="#">EC-187</a>
HO2S2 (B2)	P0159	0159	<a href="#">EC-196</a>
HO2S2 (B2)	P1166	1166	<a href="#">EC-329</a>
HO2S2 (B2)	P1167	1167	<a href="#">EC-340</a>
HO2S2 HTR (B1)	P0037	0037	<a href="#">EC-154</a>
HO2S2 HTR (B1)	P0038	0038	<a href="#">EC-154</a>
HO2S2 HTR (B2)	P0057	0057	<a href="#">EC-154</a>
HO2S2 HTR (B2)	P0058	0058	<a href="#">EC-154</a>
IAT SEN/CIRCUIT	P0112	0112	<a href="#">EC-170</a>
IAT SEN/CIRCUIT	P0113	0113	<a href="#">EC-170</a>
IN PULY SPEED	P1715	1715	<a href="#">EC-472</a>
INT/V TIM CONT-B1	P0011	0011	<a href="#">EC-149</a>
INT/V TIM CONT-B2	P0021	0021	<a href="#">EC-149</a>
INT/V TIM V/CIR-B1	P1111	1111	<a href="#">EC-303</a>
INT/V TIM V/CIR-B2	P1136	1136	<a href="#">EC-303</a>
KNOCK SEN/CIRC-B1	P0327	0327	<a href="#">EC-247</a>
KNOCK SEN/CIRC-B1	P0328	0328	<a href="#">EC-247</a>
KNOCK SEN/CIRC-B2	P0332	0332	<a href="#">EC-247</a>
KNOCK SEN/CIRC-B2	P0333	0333	<a href="#">EC-247</a>
MAF SEN/CIRCUIT	P0102	0102	<a href="#">EC-163</a>
MAF SEN/CIRCUIT	P0103	0103	<a href="#">EC-163</a>
MULTI CYL MISFIRE	P0300	0300	<a href="#">EC-238</a>

# INDEX FOR DTC

[VQ TYPE 1]

Items (CONSULT-II screen terms)	DTC*1		Reference page
	CONSULT-II GST*2	ECM*3	
NATS MALFUNCTION	P1610 - P1615	1610 - 1615	<a href="#">EC-43</a>
<b>NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.</b>	<b>P0000</b>	<b>0000</b>	—
P-N POS SW/CIRCUIT	P1706	1706	<a href="#">EC-466</a>
PURG VOLUME CONT/V	P0444	0444	<a href="#">EC-274</a>
PURG VOLUME CONT/V	P0445	0445	<a href="#">EC-274</a>
PW ST P SEN/CIRC	P0550	0550	<a href="#">EC-283</a>
SENSOR POWER/CIRC	P1229	1229	<a href="#">EC-365</a>
TP SEN 1/CIRC	P0222	0222	<a href="#">EC-231</a>
TP SEN 1/CIRC	P0223	0223	<a href="#">EC-231</a>
TP SEN 2/CIRC	P0122	0122	<a href="#">EC-180</a>
TP SEN 2/CIRC	P0123	0123	<a href="#">EC-180</a>
TP SENSOR	P2135	2135	<a href="#">EC-491</a>
TW CATALYST SYS-B1	P0420	0420	<a href="#">EC-268</a>
TW CATALYST SYS-B2	P0430	0430	<a href="#">EC-268</a>
VEH SPEED SEN/CIRC	P0500	0500	<a href="#">EC-281</a>

\*1: 1st trip DTC No. is the same as DTC No.

\*2: This number is prescribed by ISO 15031-5.

\*3: In Diagnostic Test Mode II (Self-diagnostic results), this number is controlled by NISSAN.

\*4: The troubleshooting for this DTC needs CONSULT-II.

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

## PRECAUTIONS

PFP:00001

### Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

GBS000HC

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### On Board Diagnostic (OBD) System of Engine

GBS000HD

The ECM has an on board diagnostic system. It will light up the malfunction indicator lamp (MIL) to warn the driver of a malfunction causing emission deterioration.


**CAUTION:**

- Be sure to turn the ignition switch OFF and disconnect the negative battery cable before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MIL to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MIL to light up due to the open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Certain systems and components, especially those related to OBD, may use a new style slide-locking type harness connector. For description and how to disconnect, refer to [PG-65, "HARNESS CONNECTOR"](#) .
- Be sure to route and secure the harnesses properly after work. The interference of the harness with a bracket, etc. may cause the MIL to light up due to the short circuit.
- Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MIL to light up due to the malfunction of the fuel injection system, etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the ECM before returning the vehicle to the customer.

### Precaution

GBS000HE



- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.
- Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect negative battery cable. Failure to do so may damage the ECM because battery voltage is applied to ECM even if ignition switch is turned OFF.
- Before removing parts, turn ignition switch OFF and then disconnect negative battery cable.





# PRECAUTIONS

[VQ TYPE 1]

- Do not disassemble ECM.
- If a battery cable is disconnected, the memory will return to the ECM value.  
The ECM will now start to self-control at its initial value. Engine operation can vary slightly when the terminal is disconnected. However, this is not an indication of a malfunction. Do not replace parts because of a slight variation.
- If the battery is disconnected, the following emission-related diagnostic information will be lost within 24 hours.
  - Diagnostic trouble codes
  - 1st trip diagnostic trouble codes
  - Freeze frame data
  - 1st trip freeze frame data
  - System readiness test (SRT) codes
  - Test values
- When connecting ECM harness connector, fasten it securely with levers as far as they will go as shown in the figure.




- When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break).  
Make sure that there are not any bends or breaks on ECM pin terminal, when connecting pin connectors.
- Securely connect ECM harness connectors.  
A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep engine control system harness at least 10 cm (4 in) away from adjacent harness, to prevent engine control system malfunctions due to receiving external noise, degraded operation of ICs, etc.
- Keep engine control system parts and harness dry.
- Before replacing ECM, perform "ECM Terminals and Reference Value" inspection and make sure ECM functions properly. Refer to [EC-99, "ECM Terminals and Reference Value"](#).
- Handle mass air flow sensor carefully to avoid damage.
- Do not disassemble mass air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Do not disassemble electric throttle control actuator.
- Even a slight leak in the air intake system can cause serious incidents.
- Do not shock or jar the camshaft position sensor (PHASE), crankshaft position sensor (POS).




# PRECAUTIONS

[VQ TYPE 1]


- After performing each TROUBLE DIAGNOSIS, perform DTC Confirmation Procedure or Overall Function Check. The DTC should not be displayed in the DTC Confirmation Procedure if the repair is completed. The Overall Function Check should be a good result if the repair is completed.



- When measuring ECM signals with a circuit tester, never allow the two tester probes to contact. Accidental contact of probes will cause a short circuit and damage the ECM power transistor.
- Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.




- B1 indicates the bank 1, B2 indicates the bank 2 as shown in the figure.




# PRECAUTIONS

[VQ TYPE 1]


- **Do not operate fuel pump when there is no fuel in lines.**
  - Fuel level sensor unit and fuel pump (1)
  - Fuel pressure regulator (2)
- **Tighten fuel hose clamps to the specified torque.**



- **Do not depress accelerator pedal when starting.**
- **Immediately after starting, do not rev up engine unnecessarily.**
- **Do not rev up engine just prior to shutdown.**



- **When installing C.B. ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on installation location.**
  - **Keep the antenna as far as possible from the electronic control units.**
  - **Keep the antenna feeder line more than 20 cm (8 in) away from the harness of electronic controls. Do not let them run parallel for a long distance.**
  - **Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller.**
  - **Be sure to ground the radio to vehicle body.**









A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

PREPARATION

PFP:00002

Special Service Tools






GBS000HG

Tool number Tool name	Description
EG17650301 Radiator cap tester adapter  <p style="text-align: center;">S-NT564</p>	Adapting radiator cap tester to radiator cap and radiator filler neck <b>a: 28 (1.10) dia.</b> <b>b: 31.4 (1.236) dia.</b> <b>c: 41.3 (1.626) dia.</b> Unit: mm (in)
KV10117100 Heated oxygen sensor wrench  <p style="text-align: center;">S-NT379</p>	Loosening or tightening heated oxygen sensor with 22 mm (0.87 in) hexagon nut
KV10114400 Heated oxygen sensor wrench  <p style="text-align: center;">S-NT636</p>	Loosening or tightening air fuel ratio (A/F) sensor <b>a: 22 mm (0.87 in)</b>
KV109E0010 Break-out box  <p style="text-align: center;">S-NT825</p>	Measuring the ECM signals with a circuit tester
KV109E0080 Y-cable adapter  <p style="text-align: center;">S-NT826</p>	Measuring the ECM signals with a circuit tester
KV101118400 Fuel tube adapter  <p style="text-align: center;">PBIB3043E</p>	Measuring fuel pressure



## Commercial Service Tools

GBS000HH

Tool name	Description
<p>Quick connector release</p> <div style="text-align: center;">  <p>PBIC0198E</p> </div>	<p>Remove fuel tube quick connectors in engine room</p>
<p>Fuel filler cap adapter</p> <div style="text-align: center;">  <p>S-NT653</p> </div>	<p>Checking fuel tank vacuum relief valve opening pressure</p>
<p>Socket wrench</p> <div style="text-align: center;">  <p>S-NT705</p> </div>	<p>Removing and installing engine coolant temperature sensor</p>
<p>Oxygen sensor thread cleaner</p> <div style="text-align: center;">  <p>AEM488</p> </div>	<p>Reconditioning the exhaust system threads before installing a new oxygen sensor. Use with anti-seize lubricant shown below.  <b>a: 18 mm diameter with pitch 1.5 mm for Zirconia Oxygen Sensor</b>  <b>b: 12 mm diameter with pitch 1.25 mm for Titania Oxygen Sensor</b></p>
<p>Anti-seize lubricant                      i.e.: (Permatex™ 133AR or equivalent meeting MIL specification MIL-A-907)</p> <div style="text-align: center;">  <p>S-NT779</p> </div>	<p>Lubricating oxygen sensor thread cleaning tool when reconditioning exhaust system threads.</p>


A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

### ENGINE CONTROL SYSTEM

PF2:23710

### System Diagram

GBS000HI



\*: This sensor/actuator is not for controlling the engine system, nor for the on board diagnosis.

## Multipoint Fuel Injection (MFI) System INPUT/OUTPUT SIGNAL CHART

Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS)	Engine speed* <sup>3</sup>	Fuel injection & mixture ratio control	Fuel injector
Camshaft position sensor (PHASE)	Piston position		
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Air fuel ratio (A/F) sensor 1	Density of oxygen in exhaust gas		
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Accelerator pedal position		
Park/neutral position (PNP) switch	Gear position		
Knock sensor	Engine knocking condition		
Battery	Battery voltage* <sup>3</sup>		
Power steering pressure sensor	Power steering operation		
Heated oxygen sensor 2* <sup>1</sup>	Density of oxygen in exhaust gas		
Air conditioner switch	Air conditioner operation* <sup>2</sup>		
Wheel sensor	Vehicle speed* <sup>2</sup>		

\*1: This sensor is not used to control the engine system under normal conditions.

\*2: This signal is sent to the ECM through CAN communication line.

\*3: ECM determines the start signal status by the signals of engine speed and battery voltage.

### SYSTEM DESCRIPTION

The amount of fuel injected from the fuel injector is determined by the ECM. The ECM controls the length of time the valve remains open (injection pulse duration). The amount of fuel injected is a program value in the ECM memory. The program value is preset by engine operating conditions. These conditions are determined by input signals (for engine speed and intake air) from both the crankshaft position sensor and the mass air flow sensor.

### VARIOUS FUEL INJECTION INCREASE/DECREASE COMPENSATION

In addition, the amount of fuel injected is compensated to improve engine performance under various operating conditions as listed below.


<Fuel increase>

- During warm-up
- When starting the engine
- During acceleration
- Hot-engine operation
- When selector lever is changed from N to D (A/T models)
- High-load, high-speed operation

<Fuel decrease>

- During deceleration
- During high engine speed operation

## MIXTURE RATIO FEEDBACK CONTROL (CLOSED LOOP CONTROL)



The mixture ratio feedback system provides the best air-fuel mixture ratio for driveability and emission control. The three way catalyst (manifold) can then better reduce CO, HC and NOx emissions. This system uses air fuel ratio (A/F) sensor 1 in the exhaust manifold to monitor whether the engine operation is rich or lean. The ECM adjusts the injection pulse width according to the sensor voltage signal. For more information about air fuel ratio (A/F) sensor 1, refer to [EC-372](#) . This maintains the mixture ratio within the range of stoichiometric (ideal air-fuel mixture).

This stage is referred to as the closed loop control condition.

Heated oxygen sensor 2 is located downstream of the three way catalyst (manifold). Even if the switching characteristics of air fuel ratio (A/F) sensor 1 shift, the air-fuel ratio is controlled to stoichiometric by the signal from heated oxygen sensor 2.

### Open Loop Control

The open loop system condition refers to when the ECM detects any of the following conditions. Feedback control stops in order to maintain stabilized fuel combustion.

- Deceleration and acceleration
- High-load, high-speed operation
- Malfunction of air fuel ratio (A/F) sensor 1 or its circuit
- Insufficient activation of air fuel ratio (A/F) sensor 1 at low engine coolant temperature
- High engine coolant temperature
- During warm-up
- After shifting from N to D (A/T models)
- When starting the engine

### MIXTURE RATIO SELF-LEARNING CONTROL

The mixture ratio feedback control system monitors the mixture ratio signal transmitted from air fuel ratio (A/F) sensor 1. This feedback signal is then sent to the ECM. The ECM controls the basic mixture ratio as close to the theoretical mixture ratio as possible. However, the basic mixture ratio is not necessarily controlled as originally designed. Both manufacturing differences (i.e., mass air flow sensor hot wire) and characteristic changes during operation (i.e., fuel injector clogging) directly affect mixture ratio.


Accordingly, the difference between the basic and theoretical mixture ratios is monitored in this system. This is then computed in terms of "injection pulse duration" to automatically compensate for the difference between the two ratios.

"Fuel trim" refers to the feedback compensation value compared against the basic injection duration. Fuel trim includes short term fuel trim and long term fuel trim.

"Short term fuel trim" is the short-term fuel compensation used to maintain the mixture ratio at its theoretical value. The signal from air fuel ratio (A/F) sensor 1 indicates whether the mixture ratio is RICH or LEAN compared to the theoretical value. The signal then triggers a reduction in fuel volume if the mixture ratio is rich, and an increase in fuel volume if it is lean.

"Long term fuel trim" is overall fuel compensation carried out long-term to compensate for continual deviation of the short term fuel trim from the central value. Such deviation will occur due to individual engine differences, wear over time and changes in the usage environment.

## FUEL INJECTION TIMING



Two types of systems are used.

### Sequential Multiport Fuel Injection System

Fuel is injected into each cylinder during each engine cycle according to the firing order. This system is used when the engine is running.

### Simultaneous Multiport Fuel Injection System

Fuel is injected simultaneously into all six cylinders twice each engine cycle. In other words, pulse signals of the same width are simultaneously transmitted from the ECM.

The six fuel injectors will then receive the signals two times for each engine cycle.

This system is used when the engine is being started and/or if the fail-safe system (CPU) is operating.

## FUEL SHUT-OFF

Fuel to each cylinder is cut off during deceleration, operation of the engine at excessively high speeds or operation of the vehicle at excessively high speeds.

## Electronic Ignition (EI) System

GBS000HK

### INPUT/OUTPUT SIGNAL CHART

Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS)	Engine speed*2 Piston position	Ignition timing control	Power transistor
Camshaft position sensor (PHASE)			
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Accelerator pedal position		
Knock sensor	Engine knocking		
Park/neutral position (PNP) switch	Gear position		
Battery	Battery voltage*2		
Wheel sensor	Vehicle speed*1		

\*1: This signal is sent to the ECM through CAN communication line.

\*2: ECM determines the start signal status by the signals of engine speed and battery voltage.

## SYSTEM DESCRIPTION

Firing order: 1-2-3-4-5-6

The ignition timing is controlled by the ECM to maintain the best air-fuel ratio for every running condition of the engine. The ignition timing data is stored in the ECM.

The ECM receives information such as the injection pulse width and camshaft position sensor signal. Computing this information, ignition signals are transmitted to the power transistor.

During the following conditions, the ignition timing is revised by the ECM according to the other data stored in the ECM.

- At starting
- During warm-up
- At idle
- At low battery voltage

- During acceleration

The knock sensor retard system is designed only for emergencies. The basic ignition timing is programmed within the anti-knocking zone, if recommended fuel is used under dry conditions. The retard system does not operate under normal driving conditions. If engine knocking occurs, the knock sensor monitors the condition. The signal is transmitted to the ECM. The ECM retards the ignition timing to eliminate the knocking condition.

## Fuel Cut Control (at No Load and High Engine Speed) INPUT/OUTPUT SIGNAL CHART

GBS000HL

Sensor	Input Signal to ECM	ECM function	Actuator
Park/neutral position (PNP) switch	Neutral position	Fuel cut control	Fuel injector
Accelerator pedal position sensor	Accelerator pedal position		
Engine coolant temperature sensor	Engine coolant temperature		
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed		
Wheel sensor	Vehicle speed*		

\*: This signal is sent to the ECM through CAN communication line.

### SYSTEM DESCRIPTION

If the engine speed is above 1,800 rpm under no load (for example, the shift position is neutral and engine speed is over 1,800 rpm) fuel will be cut off after some time. The exact time when the fuel is cut off varies based on engine speed.

Fuel cut will be operated until the engine speed reaches 1,500 rpm, then fuel cut will be cancelled.

#### NOTE:

This function is different from deceleration control listed under [EC-29, "Multiport Fuel Injection \(MFI\) System"](#) .

**AIR CONDITIONING CUT CONTROL**

PFP:23710

**Input/Output Signal Chart**

GBS000HM

Sensor	Input Signal to ECM	ECM function	Actuator
Air conditioner switch	Air conditioner ON signal* <sup>1</sup>	Air conditioner cut control	Air conditioner relay
Accelerator pedal position sensor	Accelerator pedal position		
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed* <sup>2</sup>		
Engine coolant temperature sensor	Engine coolant temperature		
Battery	Battery voltage* <sup>2</sup>		
Refrigerant pressure sensor	Refrigerant pressure		
Power steering pressure sensor	Power steering operation		
Wheel sensor	Vehicle speed* <sup>1</sup>		

\*1: This signal is sent to the ECM through CAN communication line.

\*2: ECM determines the start signal status by the signals of engine speed and battery voltage.

**System Description**

GBS000HN

This system improves engine operation when the air conditioner is used. Under the following conditions, the air conditioner is turned OFF.

- When the accelerator pedal is fully depressed.
- When cranking the engine.
- At high engine speeds.
- When the engine coolant temperature becomes excessively high.
- When operating power steering during low engine speed or low vehicle speed.
- When engine speed is excessively low.
- When refrigerant pressure is excessively low or high.

## AUTOMATIC SPEED CONTROL DEVICE (ASCD)

PFP:18930

### System Description INPUT/OUTPUT SIGNAL CHART

GBS000HO

Sensor	Input signal to ECM	ECM function	Actuator
ASCD brake switch	Brake pedal operation	ASCD vehicle speed control	Electric throttle control actuator
Stop lamp switch	Brake pedal operation		
ASCD steering switch	ASCD steering switch operation		
Park/Neutral position (PNP) switch	Gear position		
Combination meter	Vehicle speed*		
TCM	Powertrain revolution*		

\*: This signal is sent to the ECM through CAN communication line.

### BASIC ASCD SYSTEM

Refer to Owner's Manual for ASCD operating instructions.

Automatic Speed Control Device (ASCD) allows a driver to keep vehicle at predetermined constant speed without depressing accelerator pedal. Driver can set vehicle speed in advance between approximately 40 km/h (25 MPH) and 175 km/h (109 MPH).

ECM controls throttle angle of electric throttle control actuator to regulate engine speed.

Operation status of ASCD is indicated by CRUISE indicator and SET indicator in combination meter. If any malfunction occurs in ASCD system, it automatically deactivates control.

#### NOTE:

Always drive vehicle in safe manner according to traffic conditions and obey all traffic laws.

### SET OPERATION

Press MAIN switch. (The CRUISE indicator in combination meter illuminates.)

When vehicle speed reaches a desired speed between approximately 40 km/h (25 MPH) and 175 km/h (109 MPH), press SET/COAST switch. (Then SET indicator in combination meter illuminates.)

### ACCELERATE OPERATION

If the RESUME/ACCELERATE switch is pressed during cruise control driving, increase the vehicle speed until the switch is released or vehicle speed reaches maximum speed controlled by the system.

And then ASCD will keep the new set speed.

### CANCEL OPERATION

When any of following conditions exist, cruise operation will be canceled.

- CANCEL switch is pressed
- More than 2 switches at ASCD steering switch are pressed at the same time (Set speed will be cleared)
- Brake pedal is depressed
- Clutch pedal is depressed or gear position is changed to the neutral position (M/T models)
- Selector lever is changed to N, P, R position (A/T models)
- Vehicle speed decreased to 13 km/h (8 MPH) lower than the set speed

When the ECM detects any of the following conditions, the ECM will cancel the cruise operation and inform the driver by blinking indicator lamp.

- Engine coolant temperature is slightly higher than the normal operating temperature, CRUISE lamp may blink slowly.  
When the engine coolant temperature decreases to the normal operating temperature, CRUISE lamp will stop blinking and the cruise operation will be able to work by depressing SET/COAST switch or RESUME/ACCELERATE switch.
- Malfunction for some self-diagnoses regarding ASCD control: SET lamp will blink quickly.

If MAIN switch is turned to OFF during ASCD is activated, all of ASCD operations will be canceled and vehicle speed memory will be erased.



## COAST OPERATION

When the SET/COAST switch is pressed during cruise control driving, decrease vehicle set speed until the switch is released. And then ASCD will keep the new set speed.

A

## RESUME OPERATION

When the RESUME/ACCELERATE switch is pressed after cancel operation other than depressing MAIN switch is performed, vehicle speed will return to last set speed. To resume vehicle set speed, vehicle condition must meet following conditions.

EC

- Brake pedal is released
- Clutch pedal is released (M/T models)
- Selector lever is in other than P and N positions (A/T models)
- Vehicle speed is greater than 40 km/h (25 MPH) and less than 175 km/h (109 MPH)

C

D

## Component Description

GBS000HP

### ASCD STEERING SWITCH

Refer to [EC-444](#) .

E

### ASCD BRAKE SWITCH

Refer to [EC-451](#) and [EC-507](#) .

F

### STOP LAMP SWITCH

Refer to [EC-451](#) , [EC-473](#) and [EC-507](#) .

G

### ELECTRIC THROTTLE CONTROL ACTUATOR

Refer to [EC-310](#) , [EC-312](#) , [EC-318](#) and [EC-324](#) .

H

### ASCD INDICATOR

Refer to [EC-520](#) .

I

J

K

L

M

---

## CAN COMMUNICATION

PFP:23710

### System Description

GBS000HQ

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.


Refer to [LAN-21, "CAN COMMUNICATION"](#) , about CAN communication for detail.

## EVAPORATIVE EMISSION SYSTEM

PFP:14950


### Description SYSTEM DESCRIPTION

GBS000HR




The evaporative emission system is used to reduce hydrocarbons emitted into the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the EVAP canister. The fuel vapor in the sealed fuel tank is led into the EVAP canister which contains activated carbon and the vapor is stored there when the engine is not operating or when refueling to the fuel tank. The vapor in the EVAP canister is purged by the air through the purge line to the intake manifold when the engine is operating. EVAP canister purge volume control solenoid valve is controlled by ECM. When the engine operates, the flow rate of vapor controlled by EVAP canister purge volume control solenoid valve is proportionally regulated as the air flow increases. EVAP canister purge volume control solenoid valve also shuts off the vapor purge line during decelerating and idling.


## EVAPORATIVE EMISSION LINE DRAWING



**NOTE:** Do not use soapy water or any type of solvent while installing vacuum hose or purge hoses.



View from under the vehicle




BBIA0594E

## Component Inspection EVAP CANISTER


Check EVAP canister as follows:

1. Block port **B** .
2. Blow air into port **A** and check that it flows freely out of port **C** .
3. Release blocked port **B** .
4. Apply vacuum pressure to port **B** and check that vacuum pressure exists at the ports **A** and **C** .
5. Block port **A** and **B** .
6. Apply pressure to port **C** and check that there is no leakage.



## FUEL TANK VACUUM RELIEF VALVE (BUILT INTO FUEL FULLER CAP)

1. Wipe clean valve housing.




2. Check valve opening pressure and vacuum.

**Pressure:** 15.3 - 20.0 kPa (0.153 - 0.200 bar, 0.156 - 0.204 kg/cm<sup>2</sup>, 2.22 - 2.90 psi)

**Vacuum:** -6.0 to -3.3 kPa (-0.060 to -0.033 bar, -0.061 to -0.034 kg/cm<sup>2</sup>, -0.87 to -0.48 psi)

3. If out of specification, replace fuel filler cap as an assembly.



## EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Refer to [EC-279, "Component Inspection"](#) .

## EVAP CANISTER VENT CONTROL VALVE


Refer to [EC-529, "Component Inspection"](#) .

POSITIVE CRANKCASE VENTILATION

PFP:11810

Description  
SYSTEM DESCRIPTION


GBS000HT



This system returns blow-by gas to the intake manifold.

The positive crankcase ventilation (PCV) valve is provided to conduct crankcase blow-by gas to the intake manifold. During partial throttle operation of the engine, the intake manifold sucks the blow-by gas through the PCV valve. Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air. The ventilating air is then drawn from the air inlet tubes into the crankcase. In this process the air passes through the hose connecting air inlet tubes to rocker cover. Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the valve. The flow goes through the hose connection in the reverse direction.


On vehicles with an excessively high blow-by, the valve does not meet the requirement. This is because some of the flow will go through the hose connection to the air inlet tubes under all conditions.



Component Inspection  
PCV (POSITIVE CRANKCASE VENTILATION) VALVE


GBS000HU

With engine running at idle, remove PCV valve from rocker cover. A properly working valve makes a hissing noise as air passes through it. A strong vacuum should be felt immediately when a finger is placed over valve inlet.



## PCV VALVE VENTILATION HOSE

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.





**NATS (NISSAN ANTI-THEFT SYSTEM)**

PF2:25386

**Description**

GBS000HV

- If the security indicator lights up with the ignition switch in the ON position or “NATS MALFUNCTION” is displayed on “SELF-DIAG RESULTS” screen, perform self-diagnostic results mode with CONSULT-II using NATS program card. Refer to [BL-81, "NATS\(Nissan Anti-Theft System\)"](#) .
- Confirm no self-diagnostic results of NATS is displayed before touching “ERASE” in “SELF-DIAG RESULTS” mode with CONSULT-II.
- When replacing ECM, initialization of NATS system and registration of all NATS ignition key IDs must be carried out with CONSULT-II using NATS program card.  
Therefore, be sure to receive all keys from vehicle owner. Regarding the procedures of NATS initialization and all NATS ignition key ID registration, refer to CONSULT-II Operation Manual, NATS.

SELF DIAG RESULTS	
DTC RESULTS	TIME
NATS MALFUNCTION [P1610]	0

SEF543X

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

## ON BOARD DIAGNOSTIC (OBD) SYSTEM

PFP:00028

### Introduction

GBS000HW

The ECM has an on board diagnostic system, which detects malfunctions related to engine sensors or actuators. The ECM also records various emission-related diagnostic information including:

Emission-related diagnostic information	SAE Mode
Diagnostic Trouble Code (DTC)	Service \$03 of ISO 15031-5
Freeze Frame data	Service \$02 of ISO 15031-5
System Readiness Test (SRT) code	Service \$01 of ISO 15031-5
1st Trip Diagnostic Trouble Code (1st Trip DTC)	Service \$07 of ISO 15031-5
1st Trip Freeze Frame data	
Test values and Test limits	Service \$06 of ISO 15031-5
Calibration ID	Service \$09 of ISO 15031-5

The above information can be checked using procedures listed in the table below.

x: Applicable —: Not applicable

	DTC	1st trip DTC	Freeze Frame data	1st trip Freeze Frame data	SRT code	Test value
CONSULT-II	x	x	x	x	x	—
GST	x	x	x	—	x	x
ECM	x	x*	—	—	—	—

\*: When DTC and 1st trip DTC simultaneously appear on the display, they cannot be clearly distinguished from each other.

The malfunction indicator lamp (MIL) on the instrument panel lights up when the same malfunction is detected in two consecutive trips (Two trip detection logic), or when the ECM enters fail-safe mode. (Refer to [EC-84](#).)

### Two Trip Detection Logic

GBS000HX

When a malfunction is detected for the first time, 1st trip DTC and 1st trip Freeze Frame data are stored in the ECM memory. The MIL will not light up at this stage. <1st trip>

If the same malfunction is detected again during the next drive, the DTC and Freeze Frame data are stored in the ECM memory, and the MIL lights up. The MIL lights up at the same time when the DTC is stored. <2nd trip> The “trip” in the “Two Trip Detection Logic” means a driving mode in which self-diagnosis is performed during vehicle operation. Specific on board diagnostic items will cause the ECM to light up or blink the MIL, and store DTC and Freeze Frame data, even in the 1st trip, as shown below.

x: Applicable —: Not applicable

Items	MIL				DTC		1st trip DTC	
	1st trip		2nd trip		1st trip displaying	2nd trip displaying	1st trip displaying	2nd trip displaying
	Blinking	Lighting up	Blinking	Lighting up				
Misfire (Possible three way catalyst damage) — DTC: P0300 - P0306 is being detected	x	—	—	—	—	—	x	—
Misfire (Possible three way catalyst damage) — DTC: P0300 - P0306 is being detected	—	—	x	—	—	x	—	—
One trip detection diagnoses (Refer to <a href="#">EC-45</a> .)	—	x	—	—	x	—	—	—
Except above	—	—	—	x	—	x	x	—

When there is an open circuit on MIL circuit, the ECM cannot warn the driver by lighting up MIL when there is malfunction on engine control system.

Therefore, when electrical controlled throttle and part of ECM related diagnoses are continuously detected as NG for 5 trips, ECM warns the driver that engine control system malfunctions and MIL circuit is open by means of operating fail-safe function.

# ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VQ TYPE 1]

The fail-safe function also operates when above diagnoses except MIL circuit are detected and demands the driver to repair the malfunction.

Engine operating condition in fail-safe mode

Engine speed will not rise more than 2,500 rpm due to the fuel cut

## Emission-related Diagnostic Information EMISSION-RELATED DIAGNOSTIC INFORMATION ITEMS

GBS000HY

x: Applicable —: Not applicable

Items (CONSULT-II screen terms)	DTC*1		SRT code	Test value/ Test limit (GST only)	Trip	MIL	Reference page
	CONSULT-II GST*2	ECM*3					
CAN COMM CIRCUIT	U1000	1000*4	—	—	1	×	<a href="#">EC-146</a>
CAN COMM CIRCUIT	U1001	1001*4	—	—	2	—	<a href="#">EC-146</a>
<b>NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.</b>	<b>P0000</b>	<b>0000</b>	—	—	—	—	—
INT/V TIM CONT-B1	P0011	0011	—	—	2	—	<a href="#">EC-149</a>
INT/V TIM CONT-B2	P0021	0021	—	—	2	—	<a href="#">EC-149</a>
HO2S2 HTR (B1)	P0037	0037	×	×	2	×	<a href="#">EC-154</a>
HO2S2 HTR (B1)	P0038	0038	×	×	2	×	<a href="#">EC-154</a>
HO2S2 HTR (B2)	P0057	0057	×	×	2	×	<a href="#">EC-154</a>
HO2S2 HTR (B2)	P0058	0058	×	×	2	×	<a href="#">EC-154</a>
MAF SEN/CIRCUIT	P0102	0102	—	—	1	×	<a href="#">EC-163</a>
MAF SEN/CIRCUIT	P0103	0103	—	—	1	×	<a href="#">EC-163</a>
IAT SEN/CIRCUIT	P0112	0112	—	—	2	×	<a href="#">EC-170</a>
IAT SEN/CIRCUIT	P0113	0113	—	—	2	×	<a href="#">EC-170</a>
ECT SEN/CIRC	P0117	0117	—	—	1	×	<a href="#">EC-175</a>
ECT SEN/CIRC	P0118	0118	—	—	1	×	<a href="#">EC-175</a>
TP SEN 2/CIRC	P0122	0122	—	—	1	×	<a href="#">EC-180</a>
TP SEN 2/CIRC	P0123	0123	—	—	1	×	<a href="#">EC-180</a>
HO2S2 (B1)	P0138	0138	—	×	2	×	<a href="#">EC-187</a>
HO2S2 (B1)	P0139	0139	×	×	2	×	<a href="#">EC-196</a>
HO2S2 (B2)	P0158	0158	—	×	2	×	<a href="#">EC-187</a>
HO2S2 (B2)	P0159	0159	×	×	2	×	<a href="#">EC-196</a>
FUEL SYS-LEAN-B1	P0171	0171	—	—	2	×	<a href="#">EC-207</a>
FUEL SYS-RICH-B1	P0172	0172	—	—	2	×	<a href="#">EC-219</a>
FUEL SYS-LEAN-B2	P0174	0174	—	—	2	×	<a href="#">EC-207</a>
FUEL SYS-RICH-B2	P0175	0175	—	—	2	×	<a href="#">EC-219</a>
TP SEN 1/CIRC	P0222	0222	—	—	1	×	<a href="#">EC-231</a>
TP SEN 1/CIRC	P0223	0223	—	—	1	×	<a href="#">EC-231</a>
MULTI CYL MISFIRE	P0300	0300	—	—	2	×	<a href="#">EC-238</a>
CYL 1 MISFIRE	P0301	0301	—	—	2	×	<a href="#">EC-238</a>
CYL 2 MISFIRE	P0302	0302	—	—	2	×	<a href="#">EC-238</a>
CYL 3 MISFIRE	P0303	0303	—	—	2	×	<a href="#">EC-238</a>
CYL 4 MISFIRE	P0304	0304	—	—	2	×	<a href="#">EC-238</a>
CYL 5 MISFIRE	P0305	0305	—	—	2	×	<a href="#">EC-238</a>
CYL 6 MISFIRE	P0306	0306	—	—	2	×	<a href="#">EC-238</a>
KNOCK SEN/CIRC-B1	P0327	0327	—	—	2	—	<a href="#">EC-247</a>

# ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VQ TYPE 1]

Items (CONSULT-II screen terms)	DTC*1		SRT code	Test value/ Test limit (GST only)	Trip	MIL	Reference page
	CONSULT-II GST*2	ECM*3					
KNOCK SEN/CIRC-B1	P0328	0328	—	—	2	—	<a href="#">EC-247</a>
KNOCK SEN/CIRC-B2	P0332	0332	—	—	2	—	<a href="#">EC-247</a>
KNOCK SEN/CIRC-B2	P0333	0333	—	—	2	—	<a href="#">EC-247</a>
CKP SEN/CIRCUIT	P0335	0335	—	—	2	×	<a href="#">EC-252</a>
CMP SEN/CIRC-B1	P0340	0340	—	—	2	×	<a href="#">EC-259</a>
CMP SEN/CIRC-B2	P0345	0345	—	—	2	×	<a href="#">EC-259</a>
TW CATALYST SYS-B1	P0420	0420	×	×	2	×	<a href="#">EC-268</a>
TW CATALYST SYS-B2	P0430	0430	×	×	2	×	<a href="#">EC-268</a>
PURG VOLUME CONT/V	P0444	0444	—	—	2	×	<a href="#">EC-274</a>
PURG VOLUME CONT/V	P0445	0445	—	—	2	×	<a href="#">EC-274</a>
VEH SPEED SEN/CIRC	P0500	0500	—	—	2	×	<a href="#">EC-281</a>
PW ST P SEN/CIRC	P0550	0550	—	—	2	—	<a href="#">EC-283</a>
ECM	P0605	0605	—	—	1 or 2	× or —	<a href="#">EC-288</a>
A/F SEN1 HTR (B1)	P1031	1031	×	×	2	×	<a href="#">EC-291</a>
A/F SEN1 HTR (B1)	P1032	1032	×	×	2	×	<a href="#">EC-291</a>
A/F SEN1 HTR (B2)	P1051	1051	×	×	2	×	<a href="#">EC-291</a>
A/F SEN1 HTR (B2)	P1052	1052	×	×	2	×	<a href="#">EC-291</a>
ECM BACK UP/CIRC	P1065	1065	—	—	2	×	<a href="#">EC-299</a>
INT/V TIM V/CIR-B1	P1111	1111	—	—	2	×	<a href="#">EC-303</a>
ETC ACTR	P1121	1121	—	—	1	×	<a href="#">EC-310</a>
ETC FUNCTION/CIRC	P1122	1122	—	—	1	×	<a href="#">EC-312</a>
ETC MOT PWR	P1124	1124	—	—	1	×	<a href="#">EC-318</a>
ETC MOT PWR	P1126	1126	—	—	1	×	<a href="#">EC-318</a>
ETC MOT	P1128	1128	—	—	1	×	<a href="#">EC-324</a>
INT/V TIM V/CIR-B2	P1136	1136	—	—	2	×	<a href="#">EC-303</a>
HO2S2 (B1)	P1146	1146	×	×	2	×	<a href="#">EC-329</a>
HO2S2 (B1)	P1147	1147	×	×	2	×	<a href="#">EC-340</a>
HO2S2 (B2)	P1166	1166	×	×	2	×	<a href="#">EC-329</a>
HO2S2 (B2)	P1167	1167	×	×	2	×	<a href="#">EC-340</a>
ENG OVER TEMP	P1217	1217	—	—	1	×	<a href="#">EC-351</a>
CTP LEARNING	P1225	1225	—	—	2	—	<a href="#">EC-361</a>
CTP LEARNING	P1226	1226	—	—	2	—	<a href="#">EC-363</a>
SENSOR POWER/CIRC	P1229	1229	—	—	1	×	<a href="#">EC-365</a>
A/F SENSOR1 (B1)	P1271	1271	—	×	2	×	<a href="#">EC-372</a>
A/F SENSOR1 (B1)	P1272	1272	—	×	2	×	<a href="#">EC-381</a>
A/F SENSOR1 (B1)	P1273	1273	—	×	2	×	<a href="#">EC-390</a>
A/F SENSOR1 (B1)	P1274	1274	—	×	2	×	<a href="#">EC-400</a>
A/F SENSOR1 (B1)	P1276	1276	—	×	2	×	<a href="#">EC-410</a>
A/F SENSOR1 (B1)	P1278	1278	×	×	2	×	<a href="#">EC-420</a>
A/F SENSOR1 (B1)	P1279	1279	×	×	2	×	<a href="#">EC-432</a>
A/F SENSOR1 (B2)	P1281	1281	—	×	2	×	<a href="#">EC-372</a>
A/F SENSOR1 (B2)	P1282	1282	—	×	2	×	<a href="#">EC-381</a>

# ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VQ TYPE 1]

Items (CONSULT-II screen terms)	DTC*1		SRT code	Test value/ Test limit (GST only)	Trip	MIL	Reference page
	CONSULT-II GST*2	ECM*3					
A/F SENSOR1 (B2)	P1283	1283	—	×	2	×	<a href="#">EC-390</a>
A/F SENSOR1 (B2)	P1284	1284	—	×	2	×	<a href="#">EC-400</a>
A/F SENSOR1 (B2)	P1286	1286	—	×	2	×	<a href="#">EC-410</a>
A/F SENSOR1 (B2)	P1288	1288	×	×	2	×	<a href="#">EC-420</a>
A/F SENSOR1 (B2)	P1289	1289	×	×	2	×	<a href="#">EC-432</a>
ASCD SW	P1564	1564	—	—	1	—	<a href="#">EC-444</a>
ASCD BRAKE SW	P1572	1572	—	—	1	—	<a href="#">EC-451</a>
ASCD VHL SPD SEN	P1574	1574	—	—	1	—	<a href="#">EC-464</a>
NATS MALFUNCTION	P1610 - P1615	1610 - 1615	—	—	2	—	<a href="#">EC-43</a>
P-N POS SW/CIRCUIT	P1706	1706	—	—	2	×	<a href="#">EC-466</a>
IN PULY SPEED	P1715	1715	—	—	2	—	<a href="#">EC-472</a>
BRAKE SW/CIRCUIT	P1805	1805	—	—	2	—	<a href="#">EC-473</a>
APP SEN 1/CIRC	P2122	2122	—	—	1	×	<a href="#">EC-478</a>
APP SEN 1/CIRC	P2123	2123	—	—	1	×	<a href="#">EC-478</a>
APP SEN 2/CIRC	P2127	2127	—	—	1	×	<a href="#">EC-484</a>
APP SEN 2/CIRC	P2128	2128	—	—	1	×	<a href="#">EC-484</a>
TP SENSOR	P2135	2135	—	—	1	×	<a href="#">EC-491</a>
APP SENSOR	P2138	2138	—	—	1	×	<a href="#">EC-499</a>

\*1: 1st trip DTC No. is the same as DTC No.

\*2: This number is prescribed by ISO 15031-5.

\*3: In Diagnostic Test Mode II (Self-diagnostic results), this number is controlled by NISSAN.

\*4: The troubleshooting for this DTC need CONSULT-II.

## DTC AND 1ST TRIP DTC

The 1st trip DTC (whose number is the same as the DTC number) is displayed for the latest self-diagnostic result obtained. If the ECM memory was cleared previously, and the 1st trip DTC did not reoccur, the 1st trip DTC will not be displayed.

If a malfunction is detected during the 1st trip, the 1st trip DTC is stored in the ECM memory. The MIL will not light up (two trip detection logic). If the same malfunction is not detected in the 2nd trip (meeting the required driving pattern), the 1st trip DTC is cleared from the ECM memory. If the same malfunction is detected in the 2nd trip, both the 1st trip DTC and DTC are stored in the ECM memory and the MIL lights up. In other words, the DTC is stored in the ECM memory and the MIL lights up when the same malfunction occurs in two consecutive trips. If a 1st trip DTC is stored and a non-diagnostic operation is performed between the 1st and 2nd trips, only the 1st trip DTC will continue to be stored. For malfunctions that blink or light up the MIL during the 1st trip, the DTC and 1st trip DTC are stored in the ECM memory.

Procedures for clearing the DTC and the 1st trip DTC from the ECM memory are described in [EC-56, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).

For malfunctions in which 1st trip DTCs are displayed, refer to [EC-45, "EMISSION-RELATED DIAGNOSTIC INFORMATION ITEMS"](#). These items are required by legal regulations to continuously monitor the system/component. In addition, the items monitored non-continuously are also displayed on CONSULT-II.

1st trip DTC is specified in Service \$07 of ISO 15031-5. 1st trip DTC detection occurs without lighting up the MIL and therefore does not warn the driver of a malfunction. However, 1st trip DTC detection will not prevent the vehicle from being tested, for example during Inspection/Maintenance (I/M) tests.

When a 1st trip DTC is detected, check, print out or write down and erase (1st trip) DTC and Freeze Frame data as specified in Work Flow procedure Step 2, refer to [EC-78, "WORK FLOW"](#). Then perform DTC Confirmation Procedure or Overall Function Check to try to duplicate the malfunction. If the malfunction is duplicated, the item requires repair.

## How to Read DTC and 1st Trip DTC

DTC and 1st trip DTC can be read by the following methods.

**With CONSULT-II**

**With GST**

CONSULT-II or GST (Generic Scan Tool) Examples: P0340, P1148, P1706, etc.

These DTCs are prescribed by ISO 15031-5.

(CONSULT-II also displays the malfunctioning component or system.)

**No Tools**

The number of blinks of the MIL in the Diagnostic Test Mode II (Self-Diagnostic Results) indicates the DTC.

Example: 0340, 1148, 1706, etc.

These DTCs are controlled by NISSAN.

- **1st trip DTC No. is the same as DTC No.**
- **Output of a DTC indicates a malfunction. However, GST or the Diagnostic Test Mode II do not indicate whether the malfunction is still occurring or has occurred in the past and has returned to normal. CONSULT-II can identify malfunction status as shown below. Therefore, using CONSULT-II (if available) is recommended.**

A sample of CONSULT-II display for DTC and 1st trip DTC is shown below. DTC or 1st trip DTC of a malfunction is displayed in SELF-DIAGNOSTIC RESULTS mode of CONSULT-II. Time data indicates how many times the vehicle was driven after the last detection of a DTC.

If the DTC is being detected currently, the time data will be [0].

If a 1st trip DTC is stored in the ECM, the time data will be [1t].

DTC display	<b>SELF DIAG RESULTS</b>		1st trip DTC display	<b>SELF DIAG RESULTS</b>	
	DTC RESULTS			TIME	
	CKP SEN/CIRCUIT [P0335]	0		CKP SEN/CIRCUIT [P0335]	1t

PBIB0911E

## FREEZE FRAME DATA AND 1ST TRIP FREEZE FRAME DATA

The ECM records the driving conditions such as fuel system status, calculated load value, engine coolant temperature, short term fuel trim, long term fuel trim, engine speed, vehicle speed, base fuel schedule and intake air temperature at the moment a malfunction is detected.

Data which are stored in the ECM memory, along with the 1st trip DTC, are called 1st trip freeze frame data. The data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT-II or GST. The 1st trip freeze frame data can only be displayed on the CONSULT-II screen, not on the GST. For details, see [EC-111, "Freeze Frame Data and 1st Trip Freeze Frame Data"](#).

Only one set of freeze frame data (either 1st trip freeze frame data or freeze frame data) can be stored in the ECM. 1st trip freeze frame data is stored in the ECM memory along with the 1st trip DTC. There is no priority for 1st trip freeze frame data and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data (2nd trip detection/MIL on) is stored in the ECM memory, 1st trip freeze frame data is no longer stored. Remember, only one set of freeze frame data can be stored in the ECM. The ECM has the following priorities to update the data.

Priority	Items	
1	Freeze frame data	Misfire — DTC: P0300 - P0306 Fuel Injection System Function — DTC: P0171, P0172, P0174, P0175
2		Except the above items
3	1st trip freeze frame data	

For example, the EGR malfunction (Priority: 2) was detected and the freeze frame data was stored in the 2nd trip. After that when the misfire (Priority: 1) is detected in another trip, the freeze frame data will be updated from the EGR malfunction to the misfire. The 1st trip freeze frame data is updated each time a different malfunction is detected. There is no priority for 1st trip freeze frame data. However, once freeze frame data is stored in the ECM memory, 1st trip freeze data is no longer stored (because only one freeze frame data or 1st trip freeze frame data can be stored in the ECM). If freeze frame data is stored in the ECM memory and freeze frame data with the same priority occurs later, the first (original) freeze frame data remains unchanged in the ECM memory.

Both 1st trip freeze frame data and freeze frame data (along with the DTCs) are cleared when the ECM memory is erased. Procedures for clearing the ECM memory are described in [EC-56, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).

## SYSTEM READINESS TEST (SRT) CODE

System Readiness Test (SRT) code is specified in Service \$01 of ISO 15031-5.

As part of an enhanced emissions test for Inspection & Maintenance (I/M), certain states require the status of SRT be used to indicate whether the ECM has completed self-diagnosis of major emission systems and components. Completion must be verified in order for the emissions inspection to proceed.

If a vehicle is rejected for a State emissions inspection due to one or more SRT items indicating "INCMP", use the information in this Service Manual to set the SRT to "CMPLT".

In most cases the ECM will automatically complete its self-diagnosis cycle during normal usage, and the SRT status will indicate "CMPLT" for each application system. Once set as "CMPLT", the SRT status remains "CMPLT" until the self-diagnosis memory is erased.

Occasionally, certain portions of the self-diagnostic test may not be completed as a result of the customer's normal driving pattern; the SRT will indicate "INCMP" for these items.

### NOTE:

The SRT will also indicate "INCMP" if the self-diagnosis memory is erased for any reason or if the ECM memory power supply is interrupted for several hours.

If, during the state emissions inspection, the SRT indicates "CMPLT" for all test items, the inspector will continue with the emissions test. However, if the SRT indicates "INCMP" for one or more of the SRT items the vehicle is returned to the customer untested.

### NOTE:

If MIL is ON during the state emissions inspection, the vehicle is also returned to the customer untested even though the SRT indicates "CMPLT" for all test items. Therefore, it is important to check SRT ("CMPLT") and DTC (No DTCs) before the inspection.

## SRT Item

The table below shows required self-diagnostic items to set the SRT to "CMPLT".

SRT item (CONSULT-II indication)	Performance Priority*	Required self-diagnostic items to set the SRT to "CMPLT"	Corresponding DTC No.
CATALYST	2	Three way catalyst function	P0420, P0430
HO2S	1	Air fuel ratio (A/F) sensor 1	P1278, P1288
		Air fuel ratio (A/F) sensor 1	P1279, P1289
		Heated oxygen sensor 2	P0139, P0159
		Heated oxygen sensor 2	P1146, P1166
HO2S HTR	1	Air fuel ratio (A/F) sensor 1 heater	P1031, P1032, P1051, P1052
		Heated oxygen sensor 2 heater	P0037, P0038, P0057, P0058

\*: If completion of several SRTs is required, perform driving patterns (DTC confirmation procedure), one by one based on the priority for models with CONSULT-II.

## SRT Set Timing

SRT is set as "CMPLT" after self-diagnosis has been performed one or more times. Completion of SRT is done regardless of whether the result is OK or NG. The set timing is different between OK and NG results and is shown in the table below.

Self-diagnosis result	Example			
	Diagnosis	Ignition cycle		
	← ON →	OFF	← ON →	OFF ← ON →

# ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VQ TYPE 1]

All OK	Case 1	P0400	OK (1)	— (1)	OK (2)	— (2)
		P0402	OK (1)	— (1)	— (1)	OK (2)
		P1402	OK (1)	OK (2)	— (2)	— (2)
		SRT of EGR	“CMPLT”	“CMPLT”	“CMPLT”	“CMPLT”
	Case 2	P0400	OK (1)	— (1)	— (1)	— (1)
		P0402	— (0)	— (0)	OK (1)	— (1)
		P1402	OK (1)	OK (2)	— (2)	— (2)
		SRT of EGR	“INCMP”	“INCMP”	“CMPLT”	“CMPLT”
NG exists	Case 3	P0400	OK	OK	—	—
		P0402	—	—	—	—
		P1402	NG	—	NG	NG (Consecutive NG)
		(1st trip) DTC	1st trip DTC	—	1st trip DTC	DTC (= MIL ON)
		SRT of EGR	“INCMP”	“INCMP”	“INCMP”	“CMPLT”

OK: Self-diagnosis is carried out and the result is OK.

NG: Self-diagnosis is carried out and the result is NG.

—: Self-diagnosis is not carried out.

When all SRT related self-diagnoses showed OK results in a single cycle (Ignition OFF-ON-OFF), the SRT will indicate “CMPLT”. → Case 1 above

When all SRT related self-diagnoses showed OK results through several different cycles, the SRT will indicate “CMPLT” at the time the respective self-diagnoses have at least one OK result. → Case 2 above

If one or more SRT related self-diagnoses showed NG results in 2 consecutive cycles, the SRT will also indicate “CMPLT”. → Case 3 above

The table above shows that the minimum number of cycles for setting SRT as “INCMP” is one (1) for each self-diagnosis (Case 1 & 2) or two (2) for one of self-diagnoses (Case 3). However, in preparation for the state emissions inspection, it is unnecessary for each self-diagnosis to be executed twice (Case 3) for the following reasons:

- The SRT will indicate “CMPLT” at the time the respective self-diagnoses have one (1) OK result.
- The emissions inspection requires “CMPLT” of the SRT only with OK self-diagnosis results.
- When, during SRT driving pattern, 1st trip DTC (NG) is detected prior to “CMPLT” of SRT, the self-diagnosis memory must be erased from ECM after repair.
- If the 1st trip DTC is erased, all the SRT will indicate “INCMP”.

**NOTE:**


SRT can be set as “CMPLT” together with the DTC(s). Therefore, DTC check must always be carried out prior to the state emission inspection even though the SRT indicates “CMPLT”.

## SRT Service Procedure

If a vehicle has failed the state emissions inspection due to one or more SRT items indicating “INCMP”, review the flowchart diagnostic sequence on the next page.



A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



SEF573XB

\*1 [EC-47](#)

\*2 [EC-51](#)

\*3 [EC-52](#)

## How to Display SRT Code

### WITH CONSULT-II

Selecting "SRT STATUS" in "DTC CONFIRMATION" mode with CONSULT-II.

For items whose SRT codes are set, a "CMPLT" is displayed on the CONSULT-II screen; for items whose SRT codes are not set, "INCMP" is displayed.

A sample of CONSULT-II display for SRT code is shown at right.

"INCMP" means the self-diagnosis is incomplete and SRT is not set.

"CMPLT" means the self-diagnosis is complete and SRT is set.

### WITH GST

Selecting Service \$01 with GST (Generic Scan Tool)

SRT STATUS	
CATALYST	CMPLT
HO2S HTR	CMPLT
HO2S	CMPLT

PBIB0666E

---

## How to Set SRT Code

To set all SRT codes, self-diagnosis for the items indicated above must be performed one or more times. Each diagnosis may require a long period of actual driving under various conditions.

### **WITH CONSULT-II**

Perform corresponding DTC Confirmation Procedure one by one based on Performance Priority in the table on [EC-49. "SRT Item"](#).


### **WITHOUT CONSULT-II**

The most efficient driving pattern in which SRT codes can be properly set is explained on the next page. The driving pattern should be performed one or more times to set all SRT codes.

## Driving Pattern

**Note: Always drive vehicle in safe manner according to traffic conditions and obey all traffic laws. Refer to next page for more information and explanation of chart.**

### Driving pattern



A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VQ TYPE 1]

- The time required for each diagnosis varies with road surface conditions, weather, altitude, individual driving habits, etc.  
Zone A refers to the range where the time, required for the diagnosis under normal conditions\*, is the shortest.  
Zone B refers to the range where the diagnosis can still be performed if the diagnosis is not completed within zone A.

\*: Normal conditions refer to the following:

- Sea level
- Flat road
- Ambient air temperature: 20 - 30°C (68 - 86°F)
- Diagnosis is performed as quickly as possible under normal conditions.  
Under different conditions [For example: ambient air temperature other than 20 - 30°C (68 - 86°F)], diagnosis may also be performed.

Pattern 1:

- **The engine is started at the engine coolant temperature of -10 to 35°C (14 to 95°F) (where the voltage between the ECM terminal 73 and ground is 3.0 - 4.3V).**
- **The engine must be operated at idle speed until the engine coolant temperature is greater than 70°C (158°F) (where the voltage between the ECM terminal 73 and ground is lower than 1.4V).**

Pattern 2:

- When steady-state driving is performed again even after it is interrupted, each diagnosis can be conducted. In this case, the time required for diagnosis may be extended.

\*1: Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH), then release the accelerator pedal and keep it released for more than 10 seconds. Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH) again.

\*2: Checking the vehicle speed with GST is advised.

### Suggested Transmission Gear Position for A/T models

Set the selector lever in the D position with the overdrive switch turned ON.

### TEST VALUE AND TEST LIMIT (GST ONLY — NOT APPLICABLE TO CONSULT-II)

The following is the information specified in Service \$06 of ISO 15031-5.

The test value is a parameter used to determine whether a system/circuit diagnostic test is OK or NG while being monitored by the ECM during self-diagnosis. The test limit is a reference value which is specified as the maximum or minimum value and is compared with the test value being monitored.

These data (test value and test limit) are specified by Test ID (TID) and Component ID (CID) and can be displayed on the GST screen.

Item	Self-diagnostic test item	DTC	Test value (GST display)		Test limit
			TID	CID	
CATALYST	Three way catalyst function (Bank 1)	P0420	01H	01H	Max.
		P0420	02H	81H	Min.
	Three way catalyst function (Bank 2)	P0430	03H	02H	Max.
		P0430	04H	82H	Min.

# ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VQ TYPE 1]

Item	Self-diagnostic test item	DTC	Test value (GST display)		Test limit	
			TID	CID		
HO2S	Air fuel ratio (A/F) sensor 1 (Bank 1)	P1271	41H	8EH	Min.	A
		P1272	42H	0EH	Max.	EC
		P1273	43H	0EH	Max.	
		P1274	44H	8EH	Min.	C
		P1278	45H	8EH	Min.	
		P1276	46H	0EH	Max.	D
		P1276	47H	8EH	Min.	
	Air fuel ratio (A/F) sensor 1 (Bank 2)	P1281	4CH	8FH	Min.	E
		P1282	4DH	0FH	Max.	
		P1283	4EH	0FH	Max.	F
		P1284	4FH	8FH	Min.	
		P1288	50H	8FH	Min.	G
		P1286	51H	0FH	Max.	
		P1286	52H	8FH	Min.	H
	Heated oxygen sensor 2 (Bank 1)	P0139	19H	86H	Min.	I
		P1147	1AH	86H	Min.	
		P1146	1BH	06H	Max.	J
		P0138	1CH	06H	Max.	
	Heated oxygen sensor 2 (Bank 2)	P0159	21H	87H	Min.	K
		P1167	22H	87H	Min.	
		P1166	23H	07H	Max.	L
P0158		24H	07H	Max.		
HO2S HEATER	Air fuel ratio (A/F) sensor 1 heater (Bank 1)	P1032	57H	10H	Max.	
		P1031	58H	90H	Min.	M
	Air fuel ratio (A/F) sensor 1 heater (Bank 2)	P1052	59H	11H	Max.	
		P1051	5AH	91H	Min.	
	Heated oxygen sensor 2 heater (Bank 1)	P0038	2DH	0AH	Max.	
		P0037	2EH	8AH	Min.	
Heated oxygen sensor 2 heater (Bank 2)	P0058	2FH	0BH	Max.		
	P0057	30H	8BH	Min.		


## HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION

### How to Erase DTC

#### With CONSULT-II

The emission related diagnostic information in the ECM can be erased by selecting “ERASE” in the “SELF-DIAG RESULTS” mode with CONSULT-II.

1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 10 seconds and then turn it ON (engine stopped) again.
2. Touch “ENGINE”.
3. Touch “SELF-DIAG RESULTS”.
4. Touch “ERASE”. (The DTC in the ECM will be erased.)



#### With GST

The emission related diagnostic information in the ECM can be erased by selecting Service \$04 with GST.

1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 10 seconds and then turn it ON (engine stopped) again.
2. Select Service \$04 with GST (Generic Scan Tool).

#### No Tools

1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 10 seconds and then turn it ON (engine stopped) again.
2. Change the diagnostic test mode from Mode II to Mode I by depressing the accelerator pedal. Refer to [EC-58. "HOW TO SWITCH DIAGNOSTIC TEST MODE"](#) .

● **If the battery is disconnected, the emission-related diagnostic information will be lost within 24 hours.**

● **The following data are cleared when the ECM memory is erased.**


- Diagnostic trouble codes
- 1st trip diagnostic trouble codes
- Freeze frame data
- 1st trip freeze frame data
- System readiness test (SRT) codes
- Test values

Actual work procedures are explained using a DTC as an example. Be careful so that not only the DTC, but all of the data listed above, are cleared from the ECM memory during work procedures.

## Malfunction Indicator Lamp (MIL) DESCRIPTION






The MIL is located on the instrument panel.

1. The MIL will light up when the ignition switch is turned ON without the engine running. This is a bulb check.  
If the MIL does not light up, refer to [DI-32. "WARNING LAMPS"](#), or see [EC-571](#).
2. When the engine is started, the MIL should go off.  
If the MIL remains on, the on board diagnostic system has detected an engine system malfunction.



## ON BOARD DIAGNOSTIC SYSTEM FUNCTION

The on board diagnostic system has the following three functions.

Diagnostic Test Mode	KEY and ENG. Status	Function	Explanation of Function
Mode I	Ignition switch in ON position  Engine stopped 	BULB CHECK	This function checks the MIL bulb for damage (blown, open circuit, etc.). If the MIL does not come on, check MIL circuit.
	Engine running 	MALFUNCTION WARNING	This is a usual driving condition. When a malfunction is detected twice in two consecutive driving cycles (two trip detection logic), the MIL will light up to inform the driver that a malfunction has been detected. The following malfunctions will light up or blink the MIL in the 1st trip. <ul style="list-style-type: none"> <li>● Misfire (Possible three way catalyst damage)</li> <li>● One trip detection diagnoses</li> </ul>
Mode II	Ignition switch in ON position  Engine stopped 	SELF-DIAGNOSTIC RESULTS	This function allows DTCs and 1st trip DTCs to be read.

When there is an open circuit on MIL circuit, the ECM cannot warn the driver by lighting up MIL when there is malfunction on engine control system.

Therefore, when electrical controlled throttle and part of ECM related diagnoses are continuously detected as NG for 5 trips, ECM warns the driver that engine control system malfunctions and MIL circuit is open by means of operating fail-safe function.

The fail-safe function also operates when above diagnoses except MIL circuit are detected and demands the driver to repair the malfunction.

Engine operating condition in fail-safe mode	Engine speed will not rise more than 2,500 rpm due to the fuel cut
--	--


## HOW TO SWITCH DIAGNOSTIC TEST MODE

### NOTE:

- It is better to count the time accurately with a clock.
- It is impossible to switch the diagnostic mode when an accelerator pedal position sensor circuit has a malfunction.
- Always ECM returns to Diagnostic Test Mode I after ignition switch is turned OFF.

### How to Set Diagnostic Test Mode II (Self-diagnostic Results)

1. Confirm that accelerator pedal is fully released, turn ignition switch ON and wait 3 seconds.
2. Repeat the following procedure quickly five times within 5 seconds.
  - a. Fully depress the accelerator pedal.
  - b. Fully release the accelerator pedal.
3. Wait 7 seconds, fully depress the accelerator pedal and keep it for approx. 10 seconds until the MIL starts blinking.
4. Fully release the accelerator pedal.  
ECM has entered to Diagnostic Test Mode II (Self-diagnostic results).



### How to Erase Diagnostic Test Mode II (Self-diagnostic Results)

1. Set ECM in Diagnostic Test Mode II (Self-diagnostic results). Refer to [EC-58, "How to Set Diagnostic Test Mode II \(Self-diagnostic Results\)"](#) .
2. Fully depress the accelerator pedal and keep it for more than 10 seconds.  
The emission-related diagnostic information has been erased from the backup memory in the ECM.
3. Fully release the accelerator pedal, and confirm the DTC 0000 is displayed.

## DIAGNOSTIC TEST MODE I — BULB CHECK

In this mode, the MIL on the instrument panel should stay ON. If it remains OFF, check the bulb. Refer to [DI-32, "WARNING LAMPS"](#) or see [EC-571](#) .

## DIAGNOSTIC TEST MODE I — MALFUNCTION WARNING

MIL	Condition
ON	When the malfunction is detected.
OFF	No malfunction.


This DTC number is clarified in Diagnostic Test Mode II (SELF-DIAGNOSTIC RESULTS)

## DIAGNOSTIC TEST MODE II — SELF-DIAGNOSTIC RESULTS

In this mode, the DTC and 1st trip DTC are indicated by the number of blinks of the MIL as shown below. The DTC and 1st trip DTC are displayed at the same time. If the MIL does not illuminate in diagnostic test mode I (Malfunction warning), all displayed items are 1st trip DTCs. If only one code is displayed when the MIL illuminates in diagnostic test mode II (SELF-DIAGNOSTIC RESULTS), it is a DTC; if two or more codes are displayed, they may be either DTCs or 1st trip DTCs. DTC No. is same as that of 1st trip DTC. These uniden-



tified codes can be identified by using the CONSULT-II or GST. A DTC will be used as an example for how to read a code.



A particular trouble code can be identified by the number of four-digit numeral flashes. The “zero” is indicated by the number of ten flashes. The length of time the 1,000th-digit numeral flashes on and off is 1.2 seconds consisting of an ON (0.6-second) - OFF (0.6-second) cycle.

The 100th-digit numeral and lower digit numerals consist of a 0.3-second ON and 0.3-second OFF cycle.

A change from one digit numeral to another occurs at an interval of 1.0-second OFF. In other words, the later numeral appears on the display 1.3 seconds after the former numeral has disappeared.

A change from one trouble code to another occurs at an interval of 1.8-second OFF.

In this way, all the detected malfunctions are classified by their DTC numbers. The DTC 0000 refers to no malfunction. (See [EC-16, "INDEX FOR DTC"](#) )

## How to Erase Diagnostic Test Mode II (Self-diagnostic Results)

The DTC can be erased from the back up memory in the ECM by depressing accelerator pedal. Refer to [EC-58, "How to Set Diagnostic Test Mode II \(Self-diagnostic Results\)"](#) .

- If the battery is disconnected, the DTC will be lost from the backup memory within 24 hours.
- Be careful not to erase the stored memory before starting trouble diagnoses.

## OBD System Operation Chart

GBS00010

### RELATIONSHIP BETWEEN MIL, 1ST TRIP DTC, DTC, AND DETECTABLE ITEMS

- When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data are stored in the ECM memory.
- When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data are stored in the ECM memory, and the MIL will come on. For details, refer to [EC-44, "Two Trip Detection Logic"](#) .
- The MIL will go off after the vehicle is driven 3 times with no malfunction. The drive is counted only when the recorded driving pattern is met (as stored in the ECM). If another malfunction occurs while counting, the counter will reset.
- The DTC and the freeze frame data will be stored until the vehicle is driven 40 times (driving pattern A) without the same malfunction recurring (except for Misfire and Fuel Injection System). For Misfire and Fuel Injection System, the DTC and freeze frame data will be stored until the vehicle is driven 80 times (driving pattern C) without the same malfunction recurring. The “TIME” in “SELF-DIAGNOSTIC RESULTS” mode of CONSULT-II will count the number of times the vehicle is driven.
- The 1st trip DTC is not displayed when the self-diagnosis results in OK for the 2nd trip.

# ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VQ TYPE 1]

## SUMMARY CHART

Items	Fuel Injection System	Misfire	Other
MIL (goes off)	3 (pattern B)	3 (pattern B)	3 (pattern B)
DTC, Freeze Frame Data (no display)	80 (pattern C)	80 (pattern C)	40 (pattern A)
1st Trip DTC (clear)	1 (pattern C), *1	1 (pattern C), *1	1 (pattern B)
1st Trip Freeze Frame Data (clear)	*1, *2	*1, *2	1 (pattern B)


For details about patterns B and C under “Fuel Injection System” and “Misfire”, see [EC-62](#) .

For details about patterns A and B under Other, see [EC-64](#) .

\*1: Clear timing is at the moment OK is detected.

\*2: Clear timing is when the same malfunction is detected in the 2nd trip.

## RELATIONSHIP BETWEEN MIL, DTC, 1ST TRIP DTC AND DRIVING PATTERNS FOR "MISFIRE" "EXHAUST QUALITY DETERIORATION", "FUEL INJECTION SYSTEM"



- \*1: When the same malfunction is detected in two consecutive trips, MIL will light up.
- \*2: MIL will go off after vehicle is driven 3 times (pattern B) without any malfunctions.
- \*3: When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data will be stored in ECM.
- \*4: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 80 times (pattern C) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)
- \*5: When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data will be stored in ECM.
- \*6: The 1st trip DTC and the 1st trip freeze frame data will be cleared at the moment OK is detected.
- \*7: When the same malfunction is detected in the 2nd trip, the 1st trip freeze frame data will be cleared.
- \*8: 1st trip DTC will be cleared when vehicle is driven once (pattern C) without the same malfunction after DTC is stored in ECM.

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

## EXPLANATION FOR DRIVING PATTERNS FOR “MISFIRE <EXHAUST QUALITY DETERIORATION>”, “FUEL INJECTION SYSTEM”

### <Driving Pattern B>

Driving pattern B means the vehicle operation as follows:

All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected once regardless of the driving pattern.
- The B counter will be counted up when driving pattern B is satisfied without any malfunction.
- The MIL will go off when the B counter reaches 3. (\*2 in “OBD SYSTEM OPERATION CHART”)

### <Driving Pattern C>

Driving pattern C means the vehicle operation as follows:

The following conditions should be satisfied at the same time:

Engine speed: (Engine speed in the freeze frame data)  $\pm 375$  rpm

Calculated load value: (Calculated load value in the freeze frame data)  $\times (1 \pm 0.1)$  [%]

Engine coolant temperature (T) condition:

- When the freeze frame data shows lower than 70°C (158°F), T should be lower than 70°C (158°F).
- When the freeze frame data shows higher than or equal to 70°C (158°F), T should be higher than or equal to 70°C (158°F).

Example:

If the stored freeze frame data is as follows:


Engine speed: 850 rpm, Calculated load value: 30%, Engine coolant temperature: 80°C (176°F)

To be satisfied with driving pattern C, the vehicle should run under the following conditions:

Engine speed: 475 - 1,225 rpm, Calculated load value: 27 - 33%, Engine coolant temperature: more than 70°C (158°F)

- The C counter will be cleared when the malfunction is detected regardless of vehicle conditions above.
- The C counter will be counted up when vehicle conditions above is satisfied without the same malfunction.
- The DTC will not be displayed after C counter reaches 80.
- The 1st trip DTC will be cleared when C counter is counted once without the same malfunction after DTC is stored in ECM.

## RELATIONSHIP BETWEEN MIL, DTC, 1ST TRIP DTC AND DRIVING PATTERNS EXCEPT FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"



\*1: When the same malfunction is detected in two consecutive trips, MIL will light up.

\*2: MIL will go off after vehicle is driven 3 times (pattern B) without any malfunctions.

\*3: When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data will be stored in ECM.

\*4: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 40 times (pattern A) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)


\*5: When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data will be stored in ECM.

\*6: 1st trip DTC will be cleared after vehicle is driven once (pattern B) without the same malfunction.

\*7: When the same malfunction is detected in the 2nd trip, the 1st trip freeze frame data will be cleared.

## EXPLANATION FOR DRIVING PATTERNS EXCEPT FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"

### <Driving Pattern A>



- The A counter will be cleared when the malfunction is detected regardless of (1) - (4).
- The A counter will be counted up when (1) - (4) are satisfied without the same malfunction.
- The DTC will not be displayed after the A counter reaches 40.

### <Driving Pattern B>

Driving pattern B means the vehicle operation as follows:

All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected once regardless of the driving pattern.
- The B counter will be counted up when driving pattern B is satisfied without any malfunctions.
- The MIL will go off when the B counter reaches 3 (\*2 in OBD SYSTEM OPERATION CHART).

## BASIC SERVICE PROCEDURE



PFP:00018

### Basic Inspection

GBS00011

#### 1. INSPECTION START


1. Check service records for any recent repairs that may indicate a related malfunction, or a current need for scheduled maintenance.
2. Open engine hood and check the following:
  - Harness connectors for improper connections
  - Wiring harness for improper connections, pinches and cut
  - Vacuum hoses for splits, kinks and improper connections
  - Hoses and ducts for leaks
  - Air cleaner clogging
  - Gasket
3. Confirm that electrical or mechanical loads are not applied.
  - Headlamp switch is OFF.
  - Air conditioner switch is OFF.
  - Rear window defogger switch is OFF.
  - Steering wheel is in the straight-ahead position, etc.
4. Start engine and warm it up until engine coolant temperature indicator points the middle of gauge. Ensure engine stays below 1,000 rpm.



5. Run engine at about 2,000 rpm for about 2 minutes under no load.
6. Make sure that no DTC is displayed with CONSULT-II or GST.

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



#### 2. REPAIR OR REPLACE


Repair or replace components as necessary according to corresponding Diagnostic Procedure.

>> GO TO 3.

## 3. CHECK TARGET IDLE SPEED

### ④ With CONSULT-II


1. Run engine at about 2,000 rpm for about 2 minutes under no load.
2. Rev engine (2,000 to 3,000 rpm) two or three times under no load, then run engine at idle speed for about 1 minute.



3. Read idle speed in "DATA MONITOR" mode with CONSULT-II. Refer to [EC-69, "IDLE SPEED"](#).

**A/T: 625 ± 50 rpm (in P or N position)**

**M/T: 625 ± 50 rpm (in Neutral position)**



### ⊗ Without CONSULT-II

1. Run engine at about 2,000 rpm for about 2 minutes under no load.
2. Rev engine (2,000 to 3,000 rpm) two or three times under no load, then run engine at idle speed for about 1 minute.
3. Check idle speed. Refer to [EC-69, "IDLE SPEED"](#).

**A/T: 625 ± 50 rpm (in P or N position)**

**M/T: 625 ± 50 rpm (in Neutral position)**

### OK or NG

OK >> GO TO 10.

NG >> GO TO 4.

## 4. PERFORM ACCELERATOR PEDAL RELEASED POSITION LEARNING

1. Stop engine.
2. Perform [EC-71, "Accelerator Pedal Released Position Learning"](#).

>> GO TO 5.

## 5. PERFORM THROTTLE VALVE CLOSED POSITION LEARNING

Perform [EC-71, "Throttle Valve Closed Position Learning"](#).

>> GO TO 6.



**6. PERFORM IDLE AIR VOLUME LEARNING**

Refer to [EC-71, "Idle Air Volume Learning"](#) .

Is Idle Air Volume Learning carried out successfully?

Yes or No

- Yes >> GO TO 7.
- No >> 1. Follow the instruction of Idle Air Volume Learning.  
2. GO TO 4.

**7. CHECK TARGET IDLE SPEED AGAIN**

**Ⓟ With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Read idle speed in "DATA MONITOR" mode with CONSULT-II.  
Refer to [EC-69, "IDLE SPEED"](#) .

**A/T: 625 ± 50 rpm (in P or N position)**

**M/T: 625 ± 50 rpm (in Neutral position)**

**ⓧ Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Check idle speed.  
Refer to [EC-69, "IDLE SPEED"](#) .

**A/T: 625 ± 50 rpm (in P or N position)**

**M/T: 625 ± 50 rpm (in Neutral position)**

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEP174Y

OK or NG

- OK >> GO TO 10.
- NG >> GO TO 8.

**8. DETECT MALFUNCTIONING PART**

Check the following.

- Check camshaft position sensor (PHASE) and circuit. Refer to [EC-259](#) .
- Check crankshaft position sensor (POS) and circuit. Refer to [EC-252](#) .

OK or NG

- OK >> GO TO 9.
- NG >> 1. Repair or replace.  
2. GO TO 4.

**9. CHECK ECM FUNCTION**

1. Substitute another known-good ECM to check ECM function. (ECM may be the cause of an incident, but this is a rare case.)
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [BL-83, "ECM Re-communicating Function"](#) .

>> GO TO 4.

## 10. CHECK IGNITION TIMING


1. Run engine at idle.
2. Check ignition timing with a timing light.  
Refer to [EC-70, "IGNITION TIMING"](#) .

**A/T:  $15 \pm 5^\circ$  BTDC (in P or N position)**

**M/T:  $15 \pm 5^\circ$  BTDC (in Neutral position)**

OK or NG

- OK >> **INSPECTION END**  
 NG >> GO TO 11.



## 11. PERFORM ACCELERATOR PEDAL RELEASED POSITION LEARNING

1. Stop engine.
2. Perform [EC-71, "Accelerator Pedal Released Position Learning"](#) .

>> GO TO 12.

## 12. PERFORM THROTTLE VALVE CLOSED POSITION LEARNING

Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .

>> GO TO 13.

## 13. PERFORM IDLE AIR VOLUME LEARNING

Refer to [EC-71, "Idle Air Volume Learning"](#) .

**Is Idle Air Volume Learning carried out successfully?**

Yes or No

- Yes >> GO TO 14.  
 No >> 1. Follow the instruction of Idle Air Volume Learning.  
 2. GO TO 4.

## 14. CHECK TARGET IDLE SPEED AGAIN

**With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Read idle speed in "DATA MONITOR" mode with CONSULT-II.  
Refer to [EC-69, "IDLE SPEED"](#) .

**A/T:  $625 \pm 50$  rpm (in P or N position)**

**M/T:  $625 \pm 50$  rpm (in Neutral position)**

**Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Check idle speed.  
Refer to [EC-69, "IDLE SPEED"](#) .

**A/T:  $625 \pm 50$  rpm (in P or N position)**

**M/T:  $625 \pm 50$  rpm (in Neutral position)**

OK or NG

- OK >> GO TO 15.  
 NG >> GO TO 17.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y

## 15. CHECK IGNITION TIMING AGAIN


1. Run engine at idle.
2. Check ignition timing with a timing light.  
Refer to [EC-70, "IGNITION TIMING"](#) .

**A/T: 15 ± 5° BTDC (in P or N position)**

**M/T: 15 ± 5° BTDC (in Neutral position)**

OK or NG

- OK >> **INSPECTION END**  
 NG >> GO TO 16.



## 16. CHECK TIMING CHAIN INSTALLATION

Check timing chain installation. Refer to [EM-53, "TIMING CHAIN"](#) .

OK or NG

- OK >> GO TO 17.  
 NG >> 1. Repair the timing chain installation.  
 2. GO TO 4.

## 17. DETECT MALFUNCTIONING PART

Check the following.

- Check camshaft position sensor (PHASE) and circuit. Refer to [EC-259](#) .
- Check crankshaft position sensor (POS) and circuit. Refer to [EC-252](#) .

OK or NG

- OK >> GO TO 18.  
 NG >> 1. Repair or replace.  
 2. GO TO 4.

## 18. CHECK ECM FUNCTION

1. Substitute another known-good ECM to check ECM function. (ECM may be the cause of an incident, but this is a rare case.)
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [BL-83, "ECM Re-communicating Function"](#) .

>> GO TO 4.

## Idle Speed and Ignition Timing Check

### IDLE SPEED

GBS00012

**With CONSULT-II**

Check idle speed in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

 **With GST**


Check idle speed with GST.

## IGNITION TIMING


Any of following two methods may be used.

### Method A

1. Attach timing light to loop wire as shown.




2. Check ignition timing.





### Method B

1. Remove No. 4 ignition coil.




2. Connect No. 4 ignition coil and No. 4 spark plug with suitable high-tension wire as shown, and attach timing light clamp to this wire.





3. Check ignition timing.



### Accelerator Pedal Released Position Learning DESCRIPTION

GBS00013

Accelerator Pedal Released Position Learning is an operation to learn the fully released position of the accelerator pedal by monitoring the accelerator pedal position sensor output signal. It must be performed each time harness connector of accelerator pedal position sensor or ECM is disconnected.

#### OPERATION PROCEDURE

1. Make sure that accelerator pedal is fully released.
2. Turn ignition switch ON and wait at least 2 seconds.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Turn ignition switch ON and wait at least 2 seconds.
5. Turn ignition switch OFF and wait at least 10 seconds.

### Throttle Valve Closed Position Learning DESCRIPTION

GBS00014

Throttle Valve Closed Position Learning is an operation to learn the fully closed position of the throttle valve by monitoring the throttle position sensor output signal. It must be performed each time harness connector of electric throttle control actuator or ECM is disconnected.

#### OPERATION PROCEDURE

1. Make sure that accelerator pedal is fully released.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.  
Make sure that throttle valve moves during above 10 seconds by confirming the operating sound.

### Idle Air Volume Learning DESCRIPTION

GBS00015

Idle Air Volume Learning is an operation to learn the idle air volume that keeps each engine within the specific range. It must be performed under any of the following conditions:

- Each time electric throttle control actuator or ECM is replaced.
- Idle speed or ignition timing is out of specification.

#### PREPARATION

Before performing Idle Air Volume Learning, make sure that all of the following conditions are satisfied. Learning will be cancelled if any of the following conditions are missed for even a moment.


A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

- Battery voltage: More than 12.9V (At idle)
- Engine coolant temperature: 70 - 100°C (158 - 212°F)
- PNP switch: ON
- Electric load switch: OFF  
(Air conditioner, headlamp, rear window defogger)
- Steering wheel: Neutral (Straight-ahead position)
- Vehicle speed: Stopped
- Transmission: Warmed-up
  - A/T models
- With CONSULT-II: Drive vehicle until "ATF TEMP SE 1" in "DATA MONITOR" mode of "A/T" system indicates less than 0.9V.
- Without CONSULT-II: Drive vehicle for 10 minutes.
  - M/T models
- Drive vehicle for 10 minutes.


## OPERATION PROCEDURE

### ① With CONSULT-II

1. Perform [EC-71, "Accelerator Pedal Released Position Learning"](#) .
2. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
3. Start engine and warm it up to normal operating temperature.
4. Check that all items listed under the topic PREPARATION (previously mentioned) are in good order.
5. Select "IDLE AIR VOL LEARN" in "WORK SUPPORT" mode.



6. Touch "START" and wait 20 seconds.



7. Make sure that "CMPLT" is displayed on CONSULT-II screen. If "CMPLT" is not displayed, Idle Air Volume Learning will not be carried out successfully. In this case, find the cause of the incident by referring to the DIAGNOSTIC PROCEDURE below.
8. Rev up the engine two or three times and make sure that idle speed and ignition timing are within the specifications.

WORK SUPPORT	
IDLE AIR VOL LEARN	CMPLT
MONITOR	
ENG SPEED	XXX rpm
START	

MBIB0238E


ITEM	SPECIFICATION
Idle speed	A/T: 625 ± 50 rpm (in P or N position) M/T: 625 ± 50 rpm (in Neutral position)
Ignition timing	A/T: 15 ± 5° BTDC (in P or N position) M/T: 15 ± 5° BTDC (in Neutral position)

**⊗ Without CONSULT-II**

**NOTE:**

- It is better to count the time accurately with a clock.
- It is impossible to switch the diagnostic mode when an accelerator pedal position sensor circuit has a malfunction.

1. Perform [EC-71, "Accelerator Pedal Released Position Learning"](#) .
2. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
3. Start engine and warm it up to normal operating temperature.
4. Check that all items listed under the topic PREPARATION (previously mentioned) are in good order.
5. Turn ignition switch OFF and wait at least 10 seconds.
6. Confirm that accelerator pedal is fully released, then turn ignition switch ON and wait 3 seconds.
7. Repeat the following procedure quickly five times within 5 seconds.
  - a. Fully depress the accelerator pedal.
  - b. Fully release the accelerator pedal.
8. Wait 7 seconds, fully depress the accelerator pedal and keep it for approx. 20 seconds until the MIL stops blinking and turned ON.
9. Fully release the accelerator pedal within 3 seconds after the MIL turned ON.
10. Start engine and let it idle.
11. Wait 20 seconds.



12. Rev up the engine two or three times and make sure that idle speed and ignition timing are within the specifications.

ITEM	SPECIFICATION
Idle speed	A/T: 625 ± 50 rpm (in P or N position) M/T: 625 ± 50 rpm (in Neutral position)
Ignition timing	A/T: 15 ± 5° BTDC (in P or N position) M/T: 15 ± 5° BTDC (in Neutral position)

13. If idle speed and ignition timing are not within the specification, Idle Air Volume Learning will not be carried out successfully. In this case, find the cause of the incident by referring to the DIAGNOSTIC PROCEDURE below.

## DIAGNOSTIC PROCEDURE

If idle air volume learning cannot be performed successfully, proceed as follows:


1. Check that throttle valve is fully closed.
2. Check PCV valve operation.
3. Check that downstream of throttle valve is free from air leakage.
4. When the above three items check out OK, engine component parts and their installation condition are questionable. Check and eliminate the cause of the incident.  
It is useful to perform [EC-127, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE"](#) .
5. If any of the following conditions occur after the engine has started, eliminate the cause of the incident and perform Idle air volume learning all over again:
  - Engine stalls.
  - Erroneous idle.

## Fuel Pressure Check FUEL PRESSURE RELEASE

GBS00016


### With CONSULT-II

1. Turn ignition switch ON.
2. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode with CONSULT-II.
3. Start engine.
4. After engine stalls, crank it two or three times to release all fuel pressure.
5. Turn ignition switch OFF.



### Without CONSULT-II

1. Remove fuel pump fuse located in IPDM E/R.
2. Start engine.
3. After engine stalls, crank it two or three times to release all fuel pressure.
4. Turn ignition switch OFF.
5. Reinstall fuel pump fuse after servicing fuel system.



## FUEL PRESSURE CHECK

### CAUTION:

- Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger.
- The fuel hose connection method used when taking fuel pressure check must not be used for other purposes.
- Be careful not to scratch or put debris around connection area when servicing, so that the quick connector maintains sealability with O-rings inside.
- Do not perform fuel pressure check with electrical systems operating (i.e. lights, rear defogger, A/C, etc.) Fuel pressure gauge may indicate false readings due to varying engine load and changes in manifold vacuum.

### NOTE:

Prepare pans or saucers under the disconnected fuel line because the fuel may spill out. The fuel pressure cannot be completely released because D40 models do not have fuel return system.

1. Release fuel pressure to zero. Refer to [EC-74, "FUEL PRESSURE RELEASE"](#) .




# BASIC SERVICE PROCEDURE

[VQ TYPE 1]

2. Prepare fuel hose for fuel pressure check B and fuel tube adapter (KV10118400) D, then connect fuel pressure gauge A.

- : To quick connector
- : To fuel tube (engine side)
- C: Clamp
- Use suitable fuel hose for fuel pressure check (genuine NISSAN fuel hose without quick connector).
- To avoid unnecessary force or tension to hose, use moderately long fuel hose for fuel pressure check.
- Do not use the fuel hose for checking fuel pressure with damage or cracks on it.
- Use Pressure Gauge to check fuel pressure.




3. Remove fuel hose. Refer to [EM-36, "FUEL INJECTOR AND FUEL TUBE"](#) .

- Do not twist or kink fuel hose because it is plastic hose.

4. Connect fuel hose for fuel pressure check (1) to fuel tube (engine side) with clamp (2) as shown in the figure.

- No.2 spool (5)
- Wipe off oil or dirt from hose insertion part using cloth moistened with gasoline.
- Apply proper amount of gasoline between top of the fuel tube (3) and No.1 spool (4).
- Insert fuel hose for fuel pressure check until it touches the No.1 spool on fuel tube.
- Use NISSAN genuine hose clamp (part number: 16439 N4710 or 16439 40U00).
- When reconnecting fuel line, always use new clamps.
- Use a torque driver to tighten clamps.
- Install hose clamp to the position within 1 - 2 mm (0.04 - 0.08 in).



**Tightening torque: 1 - 1.5 N·m (0.1 - 0.15 kg·m, 9 - 13 in-lb)**

- Make sure that clamp screw does not contact adjacent parts.

5. Connect fuel tube adapter to quick connector.

- A: Fuel pressure gauge
- B: Fuel hose for fuel pressure check

6. After connecting fuel hose for fuel pressure check, pull the hose with a force of approximately 98 N (10 kg, 22 lb) to confirm fuel tube does not come off.

7. Turn ignition switch ON and check for fuel leakage.

8. Start engine and check for fuel leakage.

9. Read the indication of fuel pressure gauge.


- Do not perform fuel pressure check with system operating. Fuel pressure gauge may indicate false readings.
- During fuel pressure check, confirm for fuel leakage from fuel connection every 3 minutes.

**At idling: Approximately 350 kPa (3.5 bar, 3.57 kg/cm<sup>2</sup> , 51 psi)**

10. If result is unsatisfactory, go to next step.

11. Check the following.

- Fuel hoses and fuel tubes for clogging
- Fuel filter for clogging
- Fuel pump
- Fuel pressure regulator for clogging



## BASIC SERVICE PROCEDURE

[VQ TYPE 1]

---

If OK, replace fuel pressure regulator.  
If NG, repair or replace.


## TROUBLE DIAGNOSIS

PFP:00004


GBS00017

Trouble Diagnosis Introduction  
INTRODUCTION

The engine has an ECM to control major systems such as fuel control, ignition control, idle air control system, etc. The ECM accepts input signals from sensors and instantly drives actuators. It is essential that both input and output signals are proper and stable. At the same time, it is important that there are no malfunctions such as vacuum leaks, fouled spark plugs, or other malfunctions with the engine.




It is much more difficult to diagnose an incident that occurs intermittently rather than continuously. Most intermittent incidents are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.




A visual check only may not find the cause of the incidents. A road test with CONSULT-II (or GST) or a circuit tester connected should be performed. Follow the Work Flow on [EC-78](#).

Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such incidents, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A Diagnostic Worksheet like the example on [EC-82](#) should be used.

Start your diagnosis by looking for conventional malfunctions first. This will help troubleshoot driveability malfunctions on an electronically controlled engine vehicle.



**WORK FLOW**  
**Overall Sequence**



\*1: Include 1st trip DTC.

\*2: Include 1st trip freeze frame data.

**Detailed Flow****1. GET INFORMATION FOR SYMPTOM**

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred) using the [EC-81, "DIAGNOSTIC WORKSHEET"](#) .

>> GO TO 2.

**2. CHECK DTC\*1**

1. Check DTC\*1 .
2. Perform the following procedure if DTC\*1 is displayed.
  - Record DTC\*1 and freeze frame data\*2 . (Print them out with CONSULT-II or GST.)
  - Erase DTC\*1 . (Refer to [EC-56, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#) .)
  - Study the relationship between the cause detected by DTC\*1 and the symptom described by the customer. (Symptom Matrix Chart is useful. Refer to [EC-85](#) .)
3. Check related service bulletins for information.

Is any symptom described and any DTC detected?

Symptom is described, DTC\*1 is displayed>>GO TO 3.

Symptom is described, DTC\*1 is not displayed>>GO TO 4.

Symptom is not described, DTC\*1 is displayed>>GO TO 5.

**3. CONFIRM THE SYMPTOM**

Try to confirm the symptom described by the customer (except MIL ON).

DIAGNOSIS WORK SHEET is useful to verify the incident.

Connect CONSULT-II to the vehicle in "DATA MONITOR (AUTO TRIG)" mode and check real time diagnosis results.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

**4. CONFIRM THE SYMPTOM**

Try to confirm the symptom described by the customer.

DIAGNOSIS WORK SHEET is useful to verify the incident.

Connect CONSULT-II to the vehicle in "DATA MONITOR (AUTO TRIG)" mode and check real time diagnosis results.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

## 5. PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC Confirmation Procedure for the displayed DTC\*<sup>1</sup>, and then make sure that DTC\*<sup>1</sup> is detected again.

At this time, always connect CONSULT-II to the vehicle, and check diagnostic results in real time on "DATA MONITOR (AUTO TRIG)".

If two or more DTCs\*<sup>1</sup> are detected, refer to [EC-83, "DTC Inspection Priority Chart"](#) and determine trouble diagnosis order.

### NOTE:

- Freeze frame data\*<sup>2</sup> is useful if the DTC\*<sup>1</sup> is not detected.
- Perform Overall Function Check if DTC Confirmation Procedure is not included on Service Manual. This simplified check procedure is an effective alternative though DTC\*<sup>1</sup> cannot be detected during this check. If the result of Overall Function Check is NG, it is the same as the detection of DTC\*<sup>1</sup> by DTC Confirmation Procedure.

Is DTC\*<sup>1</sup> detected?

Yes >> GO TO 10.

No >> Check according to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

## 6. PERFORM BASIC INSPECTION

Perform [EC-65, "Basic Inspection"](#).

With CONSULT-II>>GO TO 7.

Without CONSULT-II>>GO TO 9.

## 7. PERFORM DATA MONITOR (SPEC) MODE


### With CONSULT-II

Make sure that "MAS A/F SE-B1", "B/FUEL SCHDL", and "A/F ALPHA-B1", "A/F ALPHA-B2" are within the SP value using CONSULT-II "DATA MONITOR (SPEC)" mode. Refer to [EC-128, "Diagnostic Procedure"](#).

Are they within the SP value?

Yes >> GO TO 9.

No >> GO TO 8.



## 8. DETECT MALFUNCTIONING PART BY TROUBLE DIAGNOSIS - SPECIFICATION VALUE

Detect malfunctioning part according to [EC-127, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE"](#).

Is malfunctioning part detected?

Yes >> GO TO 11.

No >> GO TO 9.

## 9. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM MATRIX CHART

Detect malfunctioning system according to [EC-85, "Symptom Matrix Chart"](#) based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

>> GO TO 10.

## 10. DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

### NOTE:

The Diagnostic Procedure in EC section described based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure. For details, refer to Circuit Inspection in [GL-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#).

Is malfunctioning part detected?

Yes >> GO TO 11.

No >> Monitor input data from related sensors or check voltage of related ECM terminals using CONSULT-II. Refer to [EC-122, "CONSULT-II Reference Value in Data Monitor"](#), [EC-99, "ECM Terminals and Reference Value"](#).

## 11. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure again after repair and replacement.
3. Check DTC. If DTC is displayed, erase it, refer to [EC-56, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).

>> GO TO 12.

## 12. FINAL CHECK

When DTC was detected in step 2, perform DTC Confirmation Procedure or Overall Function Check again, and then make sure that the malfunction have been repaired securely.

When symptom was described from the customer, refer to confirmed symptom in step 3 or 4, and make sure that the symptom is not detected.

OK or NG

NG (DTC\*<sup>1</sup> is detected)>>GO TO 10.

NG (Symptom remains)>>GO TO 6.

OK >> 1. Before returning the vehicle to the customer, make sure to erase unnecessary DTC\*<sup>1</sup> in ECM. (Refer to [EC-56, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).)

2. If the completion of SRT is needed, drive vehicle under the specific driving pattern. Refer to [EC-53, "Driving Pattern"](#).

### 3. INSPECTION END

\*1: Include 1st trip DTC.

\*2: Include 1st trip freeze frame data.

## DIAGNOSTIC WORKSHEET

### Description

There are many operating conditions that lead to the malfunction of engine components. A good grasp of such conditions can make troubleshooting faster and more accurate.

In general, each customer feels differently about a incident. It is important to fully understand the symptoms or conditions for a customer complaint.

Utilize a diagnostic worksheet like the one on the next page in order to organize all the information for troubleshooting.

Some conditions may cause the MIL to come on steady or blink and DTC to be detected. Examples:

- Vehicle ran out of fuel, which caused the engine to misfire.

### KEY POINTS


**WHAT** ..... Vehicle & engine model  
**WHEN** ..... Date, Frequencies  
**WHERE**..... Road conditions  
**HOW** ..... Operating conditions,  
 Weather conditions,  
 Symptoms

SEF907L

# TROUBLE DIAGNOSIS

[VQ TYPE 1]

## Worksheet Sample

Customer name MR/MS		Model & Year	VIN
Engine #		Trans.	Mileage
Incident Date		Manuf. Date	In Service Date
Fuel and fuel filler cap		<input type="checkbox"/> Vehicle ran out of fuel causing misfire <input type="checkbox"/> Fuel filler cap was left off or incorrectly screwed on.	
Symptoms	<input type="checkbox"/> Startability	<input type="checkbox"/> Impossible to start <input type="checkbox"/> No combustion <input type="checkbox"/> Partial combustion <input type="checkbox"/> Partial combustion affected by throttle position <input type="checkbox"/> Partial combustion NOT affected by throttle position <input type="checkbox"/> Possible but hard to start <input type="checkbox"/> Others [        ]	
	<input type="checkbox"/> Idling	<input type="checkbox"/> No fast idle <input type="checkbox"/> Unstable <input type="checkbox"/> High idle <input type="checkbox"/> Low idle <input type="checkbox"/> Others [        ]	
	<input type="checkbox"/> Driveability	<input type="checkbox"/> Stumble <input type="checkbox"/> Surge <input type="checkbox"/> Knock <input type="checkbox"/> Lack of power <input type="checkbox"/> Intake backfire <input type="checkbox"/> Exhaust backfire <input type="checkbox"/> Others [        ]	
	<input type="checkbox"/> Engine stall	<input type="checkbox"/> At the time of start <input type="checkbox"/> While idling <input type="checkbox"/> While accelerating <input type="checkbox"/> While decelerating <input type="checkbox"/> Just after stopping <input type="checkbox"/> While loading	
Incident occurrence		<input type="checkbox"/> Just after delivery <input type="checkbox"/> Recently <input type="checkbox"/> In the morning <input type="checkbox"/> At night <input type="checkbox"/> In the daytime	
Frequency		<input type="checkbox"/> All the time <input type="checkbox"/> Under certain conditions <input type="checkbox"/> Sometimes	
Weather conditions		<input type="checkbox"/> Not affected	
	Weather	<input type="checkbox"/> Fine <input type="checkbox"/> Raining <input type="checkbox"/> Snowing <input type="checkbox"/> Others [        ]	
	Temperature	<input type="checkbox"/> Hot <input type="checkbox"/> Warm <input type="checkbox"/> Cool <input type="checkbox"/> Cold <input type="checkbox"/> Humid    °F	
Engine conditions		<input type="checkbox"/> Cold <input type="checkbox"/> During warm-up <input type="checkbox"/> After warm-up  Engine speed 	
Road conditions		<input type="checkbox"/> In town <input type="checkbox"/> In suburbs <input type="checkbox"/> Highway <input type="checkbox"/> Off road (up/down)	
Driving conditions		<input type="checkbox"/> Not affected <input type="checkbox"/> At starting <input type="checkbox"/> While idling <input type="checkbox"/> At racing <input type="checkbox"/> While accelerating <input type="checkbox"/> While cruising <input type="checkbox"/> While decelerating <input type="checkbox"/> While turning (RH/LH)	
Malfunction indicator lamp		<input type="checkbox"/> Turned on <input type="checkbox"/> Not turned on	

LEC031A



## DTC Inspection Priority Chart

GBS00018

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

**NOTE:**

**If DTC U1000 and/or U1001 is displayed with other DTC, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-146. "DTC U1000, U1001 CAN COMMUNICATION LINE"](#) .**

Priority	Detected items (DTC)
1	<ul style="list-style-type: none"> <li>● U1000 U1001 CAN communication line</li> <li>● P0102 P0103 Mass air flow sensor</li> <li>● P0112 P0113 Intake air temperature sensor</li> <li>● P0117 P0118 Engine coolant temperature sensor</li> <li>● P0122 P0123 P0222 P0223 P1225 P1226 P2135 Throttle position sensor</li> <li>● P0327 P0328 P0332 P0333 Knock sensor</li> <li>● P0335 Crankshaft position sensor (POS)</li> <li>● P0340 P0345 Camshaft position sensor (PHASE)</li> <li>● P0500 Vehicle speed sensor</li> <li>● P0605 ECM</li> <li>● P1229 Sensor power supply</li> <li>● P1610 - P1615 NATS</li> <li>● P1706 Park/Neutral position (PNP) switch</li> <li>● P2122 P2123 P2127 P2128 P2138 Accelerator pedal position sensor</li> </ul>
2	<ul style="list-style-type: none"> <li>● P0037 P0038 P0057 P0058 Heated oxygen sensor 2 heater</li> <li>● P0138 P0139 P0158 P0159 P1146 P1147 P1166 P1167 Heated oxygen sensor 2</li> <li>● P0444 P0445 EVAP canister purge volume control solenoid valve</li> <li>● P0550 Power steering pressure sensor</li> <li>● P1031 P1032 P1051 P1052 Air fuel ratio (A/F) sensor 1 heater</li> <li>● P1065 ECM power supply</li> <li>● P1111 P1136 Intake valve timing control solenoid valve</li> <li>● P1122 Electric throttle control function</li> <li>● P1124 P1126 P1128 Electric throttle control actuator</li> <li>● P1217 Engine over temperature (OVERHEAT)</li> <li>● P1271 P1272 P1273 P1274 P1276 P1278 P1279 P1281 P1282 P1283 P1284 P1286 P1288 P1289 Air fuel ratio (A/F) sensor 1</li> <li>● P1805 Brake switch</li> </ul>
3	<ul style="list-style-type: none"> <li>● P0011 P0021 Intake valve timing control</li> <li>● P0171 P0172 P0174 P0175 Fuel injection system function</li> <li>● P0300 - P0306 Misfire</li> <li>● P0420 P0430 Three way catalyst function</li> <li>● P1121 Electric throttle control actuator</li> <li>● P1564 ASCD steering switch</li> <li>● P1572 ASCD brake switch</li> <li>● P1574 ASCD vehicle speed sensor</li> <li>● P1715 Turbine revolution sensor</li> </ul>

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# TROUBLE DIAGNOSIS

[VQ TYPE 1]

## Fail-safe Chart

GBS00019

When the DTC listed below is detected, the ECM enters fail-safe mode and the MIL lights up.

DTC No.	Detected items	Engine operating condition in fail-safe mode								
P0102 P0103	Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.								
P0117 P0118	Engine coolant temperature sensor circuit	<p>Engine coolant temperature will be determined by ECM based on the time after turning ignition switch ON or START. CONSULT-II displays the engine coolant temperature decided by ECM.</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Condition</th> <th style="text-align: center;">Engine coolant temperature decided (CONSULT-II display)</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Just as ignition switch is turned ON or START</td> <td style="text-align: center;">40°C (104°F)</td> </tr> <tr> <td style="text-align: center;">More than approx. 4 minutes after ignition ON or START</td> <td style="text-align: center;">80°C (176°F)</td> </tr> <tr> <td style="text-align: center;">Except as shown above</td> <td style="text-align: center;">40 - 80°C (104 - 176°F) (Depends on the time)</td> </tr> </tbody> </table> <p>When the fail-safe system for engine coolant temperature sensor is activated, the cooling fan operates while engine is running.</p>	Condition	Engine coolant temperature decided (CONSULT-II display)	Just as ignition switch is turned ON or START	40°C (104°F)	More than approx. 4 minutes after ignition ON or START	80°C (176°F)	Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)
Condition	Engine coolant temperature decided (CONSULT-II display)									
Just as ignition switch is turned ON or START	40°C (104°F)									
More than approx. 4 minutes after ignition ON or START	80°C (176°F)									
Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)									
P0122 P0123 P0222 P0223 P2135	Throttle position sensor	<p>The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees. The ECM regulates the opening speed of the throttle valve to be slower than the normal condition. So, the acceleration will be poor.</p>								
P1121	Electric throttle control actuator	<p>(When electric throttle control actuator does not function properly due to the return spring malfunction:) ECM controls the electric throttle actuator by regulating the throttle opening around the idle position. The engine speed will not rise more than 2,000 rpm.</p> <p>(When throttle valve opening angle in fail-safe mode is not in specified range:) ECM controls the electric throttle control actuator by regulating the throttle opening to 20 degrees or less.</p> <p>(When ECM detects the throttle valve is stuck open:) While the vehicle is driving, it slows down gradually by fuel cut. After the vehicle stops, the engine stalls. The engine can restart in N or P position (A/T), Neutral position (M/T) and engine speed will not exceed 1,000 rpm or more.</p>								
P1122	Electric throttle control function	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.								
P1124 P1126	Throttle control motor relay	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.								
P1128	Throttle control motor	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.								
P1229	Sensor power supply	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.								
P2122 P2123 P2127 P2128 P2138	Accelerator pedal position sensor	<p>The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees. The ECM regulates the opening speed of the throttle valve to be slower than the normal condition. So, the acceleration will be poor.</p>								

When there is an open circuit on MIL circuit, the ECM cannot warn the driver by lighting up MIL when there is malfunction on engine control system.

Therefore, when electrical controlled throttle and part of ECM related diagnoses are continuously detected as NG for 5 trips, ECM warns the driver that engine control system malfunctions and MIL circuit is open by means of operating fail-safe function.

The fail-safe function also operates when above diagnoses except MIL circuit are detected and demands the driver to repair the malfunction.

Engine operating condition in fail-safe mode	Engine speed will not rise more than 2,500 rpm due to the fuel cut
--	--

# TROUBLE DIAGNOSIS

[VQ TYPE 1]

GBS0001A

## Symptom Matrix Chart SYSTEM — BASIC ENGINE CONTROL SYSTEM

		SYMPTOM												Reference page	
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION		BATTERY DEAD (UNDER CHARGE)
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Fuel	Fuel pump circuit	1	1	2	3	2		2	2			3		2	<a href="#">EC-537</a>
	Fuel pressure regulator system	3	3	4	4	4	4	4	4	4		4			<a href="#">EC-74</a>
	Fuel injector circuit	1	1	2	3	2		2	2			2			<a href="#">EC-530</a>
	Evaporative emission system	3	3	4	4	4	4	4	4	4	4	4			<a href="#">EC-37</a>
Air	Positive crankcase ventilation system	3	3	4	4	4	4	4	4	4		4	1		<a href="#">EC-41</a>
	Incorrect idle speed adjustment						1	1	1	1		1			<a href="#">EC-65</a>
	Electric throttle control actuator	1	1	2	3	3	2	2	2	2		2		2	<a href="#">EC-310</a> , <a href="#">EC-312</a>
Ignition	Incorrect ignition timing adjustment	3	3	1	1	1		1	1			1			<a href="#">EC-65</a>
	Ignition circuit	1	1	2	2	2		2	2			2			<a href="#">EC-543</a>
Power supply and ground circuit		2	2	3	3	3		3	3		2	3			<a href="#">EC-138</a>
Mass air flow sensor circuit		1			2										<a href="#">EC-163</a>
Engine coolant temperature sensor circuit					3										
Air fuel ratio (A/F) sensor			1	2	3	2		2	2			2			<a href="#">EC-372</a> , <a href="#">EC-381</a> , <a href="#">EC-390</a> , <a href="#">EC-400</a> , <a href="#">EC-410</a> , <a href="#">EC-420</a> , <a href="#">EC-432</a>
Throttle position sensor circuit							2			2					<a href="#">EC-180</a> , <a href="#">EC-231</a> , <a href="#">EC-361</a> , <a href="#">EC-363</a> , <a href="#">EC-491</a>
Accelerator pedal position sensor circuit				3	2	1									<a href="#">EC-365</a> , <a href="#">EC-478</a> , <a href="#">EC-484</a> , <a href="#">EC-499</a>
Knock sensor circuit				2								3			<a href="#">EC-247</a>
Crankshaft position sensor (POS) circuit		2	2												<a href="#">EC-252</a>
Camshaft position sensor (PHASE) circuit		3	2												<a href="#">EC-259</a>
Vehicle speed signal circuit			2	3		3						3			<a href="#">EC-281</a>
Power steering pressure sensor circuit			2					3	3						<a href="#">EC-283</a>

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# TROUBLE DIAGNOSIS

[VQ TYPE 1]

	SYMPTOM													Reference page
	HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
ECM	2	2	3	3	3	3	3	3	3	3	3			<a href="#">EC-288</a> , <a href="#">EC-299</a>
Intake valve timing control solenoid valve circuit		3	2		1	3	2	2	3		3			<a href="#">EC-303</a>
PNP switch circuit			3		3		3	3			3			<a href="#">EC-466</a>
VIAS control solenoid valve circuit					1									<a href="#">EC-562</a>
Refrigerant pressure sensor circuit		2				3			3		4			<a href="#">EC-556</a>
Electrical load signal circuit							3							<a href="#">EC-523</a>
Air conditioner circuit	2	2	3	3	3	3	3	3	3		3		2	<a href="#">MTC-32</a>
ABS actuator and electric unit (control unit)			4											<a href="#">BRC-8</a>

1 - 6: The numbers refer to the order of inspection.  
(continued on next page)

## SYSTEM — ENGINE MECHANICAL & OTHER

	SYMPTOM													Reference page
	HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Fuel	Fuel tank	5												<a href="#">FL-5</a>
	Fuel piping		5	5	5		5	5			5			<a href="#">FL-3</a>
	Vapor lock	5												—
	Valve deposit		5	5	5		5	5			5			—
	Poor fuel (Heavy weight gasoline, Low octane)	5		5	5	5		5	5			5		

# TROUBLE DIAGNOSIS

[VQ TYPE 1]

		SYMPTOM												Reference page	
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION		BATTERY DEAD (UNDER CHARGE)
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Air	Air duct														<a href="#">EM-17</a>
	Air cleaner														<a href="#">EM-17</a>
	Air leakage from air duct (Mass air flow sensor — electric throttle control actuator)	5	5	5		5		5	5			5			<a href="#">EM-17</a>
	Electric throttle control actuator	5			5		5			5					<a href="#">EM-18</a>
	Air leakage from intake manifold/ Collector/Gasket														<a href="#">EM-18</a> , <a href="#">EM-21</a>
Cranking	Battery	1	1	1		1		1	1					1	<a href="#">SC-5</a>
	Generator circuit														<a href="#">SC-14</a>
	Starter circuit	3										1			<a href="#">SC-30</a>
	Signal plate	6													<a href="#">EM-107</a>
	PNP switch	4													<a href="#">MT-12</a> , <a href="#">AT-104</a>
Engine	Cylinder head	5	5	5	5	5		5	5			5			<a href="#">EM-91</a>
	Cylinder head gasket										4		3		
	Cylinder block													4	
	Piston														
	Piston ring														
	Connecting rod	6	6	6	6	6		6	6			6			<a href="#">EM-107</a>
	Bearing														
	Crankshaft														
Valve mechanism	Timing chain														<a href="#">EM-53</a>
	Camshaft														<a href="#">EM-73</a>
	Intake valve timing control	5	5	5	5	5		5	5			5		<a href="#">EM-53</a>	
	Intake valve													3	<a href="#">EM-91</a>
	Exhaust valve														
Exhaust	Exhaust manifold/Tube/Muffler/ Gasket	5	5	5	5	5		5	5			5			<a href="#">EM-23</a> , <a href="#">EX-2</a>
	Three way catalyst														
Lubrication	Oil pan/Oil strainer/Oil pump/Oil filter/Oil gallery/Oil cooler	5	5	5	5	5		5	5			5			<a href="#">EM-28</a> , <a href="#">LU-13</a> , <a href="#">LU-10</a> , <a href="#">LU-11</a>
	Oil level (Low)/Filthy oil														<a href="#">LU-7</a>

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# TROUBLE DIAGNOSIS

[VQ TYPE 1]

		SYMPTOM												Reference page		
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION		BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA		
Cooling	Radiator/Hose/Radiator filler cap														<a href="#">CO-13</a>	
	Thermostat									5					<a href="#">CO-27</a>	
	Water pump														<a href="#">CO-23</a>	
	Water gallery	5	5	5	5	5		5	5		4	5			<a href="#">CO-29</a>	
	Cooling fan														5	<a href="#">CO-21</a>
	Coolant level (Low)/Contaminated coolant														5	<a href="#">CO-10</a>
NATS (Nissan Anti-theft system)		1	1												<a href="#">BL-81</a> or <a href="#">EC-43</a>	

1 - 6: The numbers refer to the order of inspection.

### Engine Control Component Parts Location

GBS0001B

A

EC

C

D

E

F

G

H


I

J

K







L

M



MB1B1270E

- |   |   |   |
|---|---|---|
| 1. ECM  | 2. Refrigerant pressure sensor                                    | 3. Electric throttle control actuator                             |
| 4. Power steering pressure sensor                             | 5. Power valve actuator   | 6. Cooling fan motor  |
| 7. VIAS control solenoid valve                                | 8. EVAP canister purge volume control solenoid valve              | 9. Intake valve timing control solenoid valve (bank 2)            |
| 10. Mass air flow sensor (with intake air temperature sensor) | 11. Ignition coil (with power transistor) and spark plug (bank 2) | 12. Camshaft position sensor (PHASE) (bank 2)                     |
| 13. Fuel injector (bank 2)                                    | 14. Knock sensor  | 15. Camshaft position sensor (PHASE) (bank 1)                     |
| 16. Engine coolant temperature sensor                         | 17. Fuel injector (bank 1)  | 18. Ignition coil (with power transistor) and spark plug (bank 1) |
| 19. Intake valve timing control solenoid valve (bank 1)       | 20. IPDM E/R  |   |









↶ : Vehicle front

- |   |   |   |
|---|---|---|
| 1. Mass air flow sensor                                   | 2. Engine coolant temperature sensor                        | 3. Electric throttle control actuator                       |
| 4. Fuel level sensor unit and fuel pump harness connector | 5. Air fuel ratio (A/F) sensor 1 (bank 1) harness connector | 6. Air fuel ratio (A/F) sensor 1 (bank 2) harness connector |

MBIB1271E





A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M




↔ : Vehicle front

- |  |  |  |
|--|--|--|
| 1. EVAP canister purge volume control solenoid valve | 2. EVAP control system pressure sensor                 | 3. EVAP canister                                       |
| 4. EVAP canister vent control valve                  | 5. Power steering pressure sensor                      | 6. Throttle valve                                      |
| 7. Electric throttle control actuator                | 8. Intake valve timing control solenoid valve (bank 1) | 9. Intake valve timing control solenoid valve (bank 2) |

MBIB1409E

# TROUBLE DIAGNOSIS

[VQ TYPE 1]








MBIB1273E

↩ : Vehicle front

- |  |   |  |
|--|---|--|
| 1. Air fuel ratio (A/F) sensor 1 (bank 1)            | 2. Air fuel ratio (A/F) sensor 1 (bank 2) | 3. Heated oxygen sensor 2 (bank 2)                   |
| 4. Heated oxygen sensor 2 (bank 2) harness connector | 5. Heated oxygen sensor 2 (bank 1)        | 6. Heated oxygen sensor 2 (bank 1) harness connector |







A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



← : Vehicle front

- |  |   |   |
|--|---|---|
| 1. Accelerator pedal position sensor harness connector | 2. IPDM E/R                                 | 3. Fuel pump fuse (15A)                     |
| 4. ECM harness connectors                              | 5. Fuel injector (bank 1) harness connector | 6. Fuel injector (bank 2) harness connector |
| 7. Knock sensor (bank 2)                               | 8. Knock sensor (bank 1)                    |   |

MBIB1274E








↖ : Vehicle front

- |   |   |  |
|---|---|--|
| 1. ASCD brake switch                              | 2. Stop lamp switch                               | 3. Condenser-1                                   |
| 4. Ignition coil (with power transistor) (bank 1) | 5. Ignition coil (with power transistor) (bank 2) | 6. Refrigerant pressure sensor harness connector |
| 7. Power valve actuator                           | 8. VIAS control solenoid valve                    |  |

MBIB1275E

A  
**EC**  
 C  
 D  
 E  
 F  
 G  
 H  
 I  
 J  
 K  
 L  
 M




- |  |  |  |
|--|--|--|
| 1. Crankshaft position sensor (POS)      | 2. Camshaft position sensor (PHASE) (bank 2) | 3. Camshaft position sensor (PHASE) (bank 1)   |
| 4. ASCD steering switch                  | 5. RESUME/ACCELERATE switch                  | 6. SET/COAST switch                            |
| 7. MAIN switch                           | 8. CANCEL switch                             | 9. Cooling fan control motor harness connector |
| 10. Fuel level sensor unit and fuel pump | 11. Fuel pressure regulator                  |  |

MBIB1276E

### Vacuum Hose Drawing

GBS0001C




**NOTE:** Do not use soapy water or any type of solvent while installing vacuum hose or purge hoses.

Refer to [EC-28, "System Diagram"](#) for Vacuum Control System.

PBIB2529E

## Circuit Diagram


GBS000ID



\* : This relay is built into the IPDM E/R (Intelligent power distribution module engine room)

# TROUBLE DIAGNOSIS

[VQ TYPE 1]




MBWA1418E



## ECM Harness Connector Terminal Layout

GBS0001E




MBIB0045E

## ECM Terminals and Reference Value


GBS0001F

1. ECM located in the engine room passenger side behind reservoir tank.
2. Remove ECM harness connector.



BBIA0537E

3. When disconnecting ECM harness connector, loosen it with levers as far as they will go as shown in the figure.
4. Connect a break-out box (SST) and Y-cable adapter (SST) between the ECM and ECM harness connector.
  - Use extreme care not to touch 2 pins at one time.
  - Data is for comparison and may not be exact.




PBIB1512E

## ECM INSPECTION TABLE

Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-II.

**CAUTION:**





**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECMs transistor. Use a ground other than ECM terminals, such as the ground.**

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
1	B	ECM ground	<b>[Engine is running]</b> ● Idle speed	Body ground
2	L	A/F sensor 1 heater (Bank 1)	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed	Approximately 5V★ 

PBIB1584E





# TROUBLE DIAGNOSIS

[VQ TYPE 1]

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
3	BR	Throttle control motor relay power supply	<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)
4	L/W	Throttle control motor (Close)	<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully released</li> </ul>	0 - 14V★  <small>PBIB1104E</small>
5	L/B	Throttle control motor (Open)	<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully depressed</li> </ul>	0 - 14V★  <small>PBIB1105E</small>
6	R	Heated oxygen sensor 2 heater (Bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed is below 3,600 rpm after the following conditions are met               <ul style="list-style-type: none"> <li>- Engine: after warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - 1.0V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> </ul> <b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed: Above 3,600 rpm</li> </ul>	BATTERY VOLTAGE (11 - 14V)
10	W	Intake valve timing control solenoid valve (Bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	BATTERY VOLTAGE (11 - 14V)
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,500 rpm</li> </ul>	7 - 12V★  <small>PBIB1790E</small>
11	V	Intake valve timing control solenoid valve (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	BATTERY VOLTAGE (11 - 14V)
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,500 rpm</li> </ul>	7 - 12V★  <small>PBIB1790E</small>

# TROUBLE DIAGNOSIS




[VQ TYPE 1]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
12	P	Power steering pressure sensor	<b>[Engine is running]</b> ● Steering wheel: Being turned	0.5 - 4.5V
			<b>[Engine is running]</b> ● Steering wheel: Not being turned	0.4 - 0.8V
13	G	Crankshaft position sensor (POS)	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed <b>NOTE:</b> The pulse cycle changes depending on rpm at idle	Approximately 10V★ 
			<b>[Engine is running]</b> ● Engine speed: 2,000 rpm	Approximately 10V★ 
14	Y	Camshaft position sensor (PHASE) (Bank 2)	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed <b>NOTE:</b> The pulse cycle changes depending on rpm at idle	1.0 - 4.0V★ 
			<b>[Engine is running]</b> ● Engine speed: 2,000 rpm	1.0 - 4.0V★ 
15	W	Knock sensor (Bank 1)	<b>[Engine is running]</b> ● Idle speed	Approximately 2.5V
16	SB	A/F sensor 1 (Bank 1)	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed	Approximately 3.1V
35	O			Approximately 2.6V
56	LG			Approximately 2.3V
75	P			Approximately 2.3V

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M





# TROUBLE DIAGNOSIS

[VQ TYPE 1]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
21 22 23	W LG SB	Fuel injector No. 5 Fuel injector No. 3 Fuel injector No. 1	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p style="text-align: right; font-size: small;">SEC984C</p>
			<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p style="text-align: right; font-size: small;">SEC985C</p>
24	G	A/F sensor 1 heater (Bank 2)	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	<p>Approximately 5V★</p>  <p style="text-align: right; font-size: small;">PBIB1584E</p>
25	SB	Heated oxygen sensor 2 heater (Bank 1)	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Engine speed is below 3,600 rpm after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: after warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - 1.0V
			<p><b>[Ignition switch: ON]</b></p> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> </ul> <p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Engine speed: Above 3,600 rpm</li> </ul>	BATTERY VOLTAGE (11 - 14V)
29	GR	VIAS control solenoid valve	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Idle speed</li> </ul>	BATTERY VOLTAGE (11 - 14V)
			<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Engine speed: Between 2,200 and 3,300 rpm</li> </ul>	0 - 1.0V
32	W	EVAP control system pressure sensor	<b>[Ignition switch: ON]</b>	Approximately 1.8 - 4.8V

# TROUBLE DIAGNOSIS



[VQ TYPE 1]

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
33	L	Camshaft position sensor (PHASE) (Bank 1)	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	<p>1.0 - 4.0V★</p>  <p style="text-align: right; font-size: small;">PBIB1039E</p>
			<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>1.0 - 4.0V★</p>  <p style="text-align: right; font-size: small;">PBIB1040E</p>
34	BR	Intake air temperature sensor	<p><b>[Engine is running]</b></p>	<p>Approximately 0 - 4.8V</p> <p>Output voltage varies with intake air temperature.</p>
36	W	Knock sensor (Bank 2)	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Idle speed</li> </ul>	<p>Approximately 2.5V</p>
40 41 42	V R O	Fuel injector No. 6 Fuel injector No. 4 Fuel injector No. 2	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p style="text-align: right; font-size: small;">SEC984C</p>
			<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p style="text-align: right; font-size: small;">SEC985C</p>

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



# TROUBLE DIAGNOSIS

[VQ TYPE 1]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
45	P	EVAP canister purge volume control solenoid valve	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Idle speed</li> <li>● Accelerator pedal is not depressed even slightly, after engine starting</li> </ul>	BATTERY VOLTAGE (11 - 14V)★  <small>SEC990C</small>
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed: About 2,000 rpm (More than 100 seconds after starting engine)</li> </ul>	BATTERY VOLTAGE (11 - 14V)★  <small>SEC991C</small>
47	W	Sensor power supply (Throttle position sensor)	<b>[Ignition switch: ON]</b>	Approximately 5V
48	SB	Sensor power supply (EVAP control system pressure sensor)	<b>[Ignition switch: ON]</b>	Approximately 5V
49	P	Sensor power supply (Refrigerant pressure sensor)	<b>[Ignition switch: ON]</b>	Approximately 5V
50	W	Throttle position sensor 1	<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully released</li> </ul>	More than 0.36V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully depressed</li> </ul>	Less than 4.75V
51	P	Mass air flow sensor	<b>[Ignition switch: ON]</b>	Approximately 0.4V
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	0.9 - 1.2V
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine is revving from idle to about 4,000 rpm</li> </ul>	0.9 - 1.2 to Approximately 2.4V (Check for linear voltage rise in response to engine being increased to about 4,000 rpm)
55	G	Heated oxygen sensor 2 (Bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Revving engine from idle to 3,000 rpm quickly after the following conditions are met               <ul style="list-style-type: none"> <li>- Engine: after warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - Approximately 1.0V

# TROUBLE DIAGNOSIS



[VQ TYPE 1]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
57	GR	A/F sensor 1 (Bank 2)	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed	Approximately 2.6V
58	O			Approximately 2.3V
76	V			Approximately 3.1V
77	Y			Approximately 2.3V
60 61 62	V L Y	Ignition signal No. 5 Ignition signal No. 3 Ignition signal No. 1	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed  <b>NOTE:</b> The pulse cycle changes depending on rpm at idle	0 - 0.2V★ 
			<b>[Engine is running]</b> ● Warm-up condition ● Engine speed: 2,500 rpm	0.1 - 0.4V★ 
66	B	Sensor ground (Throttle position sensor)	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed	Approximately 0V
67	GR	Sensor ground	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed	Approximately 0V
68	V	Sensor power supply (Power steering pressure sensor)	<b>[Ignition switch: ON]</b>	Approximately 5V
69	R	Throttle position sensor 2	<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Shift lever: D (A/T), 1st (M/T) ● Accelerator pedal: Fully released	Less than 4.75V
			<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Shift lever: D (A/T), 1st (M/T) ● Accelerator pedal: Fully depressed	More than 0.36V
70	BR	Refrigerant pressure sensor	<b>[Engine is running]</b> ● Warm-up condition ● Both A/C switch and blower switch: ON (Compressor operates)	1.0 - 4.0V
73	Y	Engine coolant temperature sensor	<b>[Engine is running]</b>	Approximately 0 - 4.8V Output voltage varies with engine coolant temperature.

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# TROUBLE DIAGNOSIS

[VQ TYPE 1]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
74	O	Heated oxygen sensor 2 (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Revving engine from idle to 3,000 rpm quickly after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: after warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - Approximately 1.0V
78	B	Sensor ground (Heated oxygen sensor 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● <b>Warm-up condition</b></li> <li>● Idle speed</li> </ul>	Approximately 0V
79 80 81	P GR G	Ignition signal No. 6 Ignition signal No. 4 Ignition signal No. 2	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● <b>Warm-up condition</b></li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	0 - 0.2V★ 
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● <b>Warm-up condition</b></li> <li>● Engine speed: 2,500 rpm</li> </ul>	0.1 - 0.4V★ 
82	B	Sensor ground (APP sensor 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● <b>Warm-up condition</b></li> <li>● Idle speed</li> </ul>	Approximately 0V
83	O	Sensor ground (APP sensor 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● <b>Warm-up condition</b></li> <li>● Idle speed</li> </ul>	Approximately 0V
85	SB	Data link connector	<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● CONSULT-II or GST: Disconnected</li> </ul>	Approximately 5V - Battery voltage (11 - 14V)
86	P	CAN communication line	<b>[Ignition switch: ON]</b>	Approximately 1.1 - 2.3V Output voltage varies with the communication status.
90	L	Sensor power supply (APP sensor 1)	<b>[Ignition switch: ON]</b>	Approximately 5V
91	G	Sensor power supply (APP sensor 2)	<b>[Ignition switch: ON]</b>	Approximately 5V
94	L	CAN communication line	<b>[Ignition switch: ON]</b>	Approximately 2.6 - 3.2V Output voltage varies with the communication status.
98	GR	Accelerator pedal position sensor 2	<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Accelerator pedal: Fully released</li> </ul>	0.3 - 0.45V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Accelerator pedal: Fully depressed</li> </ul>	Less than 2.4V



# TROUBLE DIAGNOSIS

[VQ TYPE 1]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	A
99	SB	ASCD steering switch	<b>[Ignition switch: ON]</b> ● ASCD steering switch: OFF	Approximately 4.0V	EC
			<b>[Ignition switch: ON]</b> ● MAIN switch: Pressed	Approximately 0V	C
			<b>[Ignition switch: ON]</b> ● CANCEL switch: Pressed	Approximately 1V	D
			<b>[Ignition switch: ON]</b> ● RESUME/ACCELERATE switch: Pressed	Approximately 3V	E
			<b>[Ignition switch: ON]</b> ● SET/COAST switch: Pressed	Approximately 2V	F
101	V	Stop lamp switch	<b>[Ignition switch: OFF]</b> ● Brake pedal: Fully released	Approximately 0V	G
			<b>[Ignition switch: OFF]</b> ● Brake pedal: Slightly depressed	BATTERY VOLTAGE (11 - 14V)	H
102	G	PNP switch	<b>[Ignition switch: ON]</b> ● Shift lever: P or N (A/T), Neutral (M/T)	Approximately 0V	I
			<b>[Ignition switch: ON]</b> ● Except above position	BATTERY VOLTAGE (11 - 14V)	J
104	O	Throttle control motor relay	<b>[Ignition switch: OFF]</b>	BATTERY VOLTAGE (11 - 14V)	K
			<b>[Ignition switch: ON]</b>	0 - 1.0V	L
106	R	Accelerator pedal position sensor 1	<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully released	0.6 - 0.95V	M
			<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully depressed	Less than 4.75V	
108	LG	ASCD brake switch	<b>[Ignition switch: ON]</b> ● Brake pedal: Slightly depressed (A/T) ● Clutch pedal and/or brake pedal: Slightly depressed (M/T)	Approximately 0V	
			<b>[Ignition switch: ON]</b> ● Brake pedal: Fully released (A/T) ● Clutch pedal and brake pedal: Fully released (M/T)	BATTERY VOLTAGE (11 - 14V)	
109	R	Ignition switch	<b>[Ignition switch: OFF]</b>	0V	
			<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)	
111	BR	ECM relay (Self shut-off)	<b>[Engine is running]</b> <b>[Ignition switch: OFF]</b> ● For a few seconds after turning ignition switch OFF	0 - 1.5V	
			<b>[Ignition switch: OFF]</b> ● More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14V)	

# TROUBLE DIAGNOSIS

**[VQ TYPE 1]**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
113	V	Fuel pump relay	<b>[Ignition switch: ON]</b> ● For 1 second after turning ignition switch ON	0 - 1.5V
			<b>[Engine is running]</b> ● More than 1 second after turning ignition switch ON	BATTERY VOLTAGE (11 - 14V)
115 116	B B	ECM ground	<b>[Engine is running]</b> ● Idle speed	Body ground
117	G	EVAP canister vent control valve	<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)
119 120	R P	Power supply for ECM	<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)
121	V	Power supply for ECM (Back-up)	<b>[Ignition switch: OFF]</b>	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## CONSULT-II Function (ENGINE) FUNCTION

GBS000IG

Diagnostic test mode	Function
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT-II unit.
Self-diagnostic results	Self-diagnostic results such as 1st trip DTC, DTCs and 1st trip freeze frame data or freeze frame data can be read and erased quickly.*
Data monitor	Input/Output data in the ECM can be read.
Data monitor (SPEC)	Input/Output of the specification for Basic fuel schedule, AFM, A/F feedback control value and the other data monitor items can be read.
CAN diagnostic support monitor	The results of transmit/receive diagnosis of CAN communication can be read.
Active test	Diagnostic Test Mode in which CONSULT-II drives some actuators apart from the ECMs and also shifts some parameters in a specified range.
Function test	This mode is used to inform customers when their vehicle condition requires periodic maintenance.
DTC & SRT confirmation	The status of system monitoring tests and the self-diagnosis status/result can be confirmed.
ECM part number	ECM part number can be read.

\*: The following emission-related diagnostic information is cleared when the ECM memory is erased.

- Diagnostic trouble codes
- 1st trip diagnostic trouble codes
- Freeze frame data
- 1st trip freeze frame data
- System readiness test (SRT) codes
- Test values

# TROUBLE DIAGNOSIS

[VQ TYPE 1]

## ENGINE CONTROL COMPONENT PARTS/CONTROL SYSTEMS APPLICATION

		DIAGNOSTIC TEST MODE							A	
		WORK SUP- PORT	SELF-DIAGNOSTIC RESULTS		DATA MONI- TOR	DATA MONI- TOR (SPEC)	ACTIVE TEST	DTC & SRT CONFIRMATION		EC
			DTC*1	FREEZE FRAME DATA*2				SRT STATUS	DTC WORK SUP- PORT	C
ENGINE CONTROL COMPONENT PARTS	INPUT	Crankshaft position sensor (POS)	×	×	×	×				D
	Camshaft position sensor (PHASE)	×	×	×	×				E	
	Mass air flow sensor	×		×	×				F	
	Engine coolant temperature sensor	×	×	×	×	×			G	
	Air fuel ratio (A/F) sensor 1	×		×	×		×	×	H	
	Heated oxygen sensor 2	×		×	×		×	×	I	
	Wheel sensor	×	×	×	×				J	
	Accelerator pedal position sensor	×		×	×				K	
	Throttle position sensor	×		×	×				L	
	Intake air temperature sensor	×	×	×	×				M	
	Knock sensor	×								
	Refrigerant pressure sensor				×	×				
	Closed throttle position switch (accelerator pedal position sensor signal)				×	×				
	Air conditioner switch				×	×				
	Park/neutral position (PNP) switch	×			×	×				
	Stop lamp switch	×			×	×				
	Power steering pressure sensor	×			×	×				
	Battery voltage				×	×				
	Load signal				×	×				
	ASCD steering switch	×			×	×				
ASCD brake switch	×			×	×					
ASCD clutch switch	×			×	×					
ENGINE CONTROL COMPONENT PARTS	OUTPUT	Fuel injector			×	×	×			
	Power transistor (Ignition timing)				×	×	×			
	Throttle control motor relay	×			×	×				
	Throttle control motor	×								
	Air conditioner relay				×	×				
	Fuel pump relay	×			×	×	×			
	Cooling fan relay	×			×	×	×			
	Air fuel ratio (A/F) sensor 1 heater	×			×	×		×		
	Heated oxygen sensor 2 heater	×			×	×		×		
	Intake valve timing control solenoid valve	×			×	×	×			
	VIAS control solenoid valve				×	×	×			
Calculated load value			×	×	×					

X: Applicable

\*1: This item includes 1st trip DTCs.


\*2: This mode includes 1st trip freeze frame data or freeze frame data. The items appear on CONSULT-II screen in freeze frame data mode only if a 1st trip DTC or DTC is detected. For details, refer to [EC-111](#).

## INSPECTION PROCEDURE


### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. Turn ignition switch OFF.
2. Connect CONSULT-II and CONSULT-II CONVERTER to data link connector (1), which is located under LH dash panel near the hood opener handle.
3. Turn ignition switch ON.




4. Touch "START (NISSAN BASED VHCL)".



5. Touch "ENGINE".  
If "ENGINE" is not indicated, go to [GI-47, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



6. Perform each diagnostic test mode according to each service procedure.  
**For further information, see the CONSULT-II Operation Manual.**



## WORK SUPPORT MODE

### Work Item

WORK ITEM	CONDITION	USAGE
FUEL PRESSURE RELEASE	<ul style="list-style-type: none"> <li>FUEL PUMP WILL STOP BY TOUCHING "START" DURING IDLING. CRANK A FEW TIMES AFTER ENGINE STALLS.</li> </ul>	When releasing fuel pressure from fuel line
IDLE AIR VOL LEARN	<ul style="list-style-type: none"> <li>THE IDLE AIR VOLUME THAT KEEPS THE ENGINE WITHIN THE SPECIFIED RANGE IS MEMORIZED IN ECM.</li> </ul>	When learning the idle air volume
SELF-LEARNING CONT	<ul style="list-style-type: none"> <li>THE COEFFICIENT OF SELF-LEARNING CONTROL MIXTURE RATIO RETURNS TO THE ORIGINAL COEFFICIENT.</li> </ul>	When clearing the coefficient of self-learning control value
TARGET IDLE RPM ADJ*	<ul style="list-style-type: none"> <li>IDLE CONDITION</li> </ul>	When setting target idle speed
TARGET IGN TIM ADJ*	<ul style="list-style-type: none"> <li>IDLE CONDITION</li> </ul>	When adjusting target ignition timing

\*: This function is not necessary in the usual service procedure.

## SELF-DIAG RESULTS MODE

### Self Diagnostic Item

Regarding items of DTC and 1st trip DTC, refer to [EC-45, "EMISSION-RELATED DIAGNOSTIC INFORMATION ITEMS"](#).

### Freeze Frame Data and 1st Trip Freeze Frame Data

Freeze frame data item*	Description
DIAG TROUBLE CODE [PXXXX]	<ul style="list-style-type: none"> <li>The engine control component part/control system has a trouble code, it is displayed as "PXXXX". (Refer to <a href="#">EC-16, "INDEX FOR DTC"</a>.)</li> </ul>
FUEL SYS-B1	<ul style="list-style-type: none"> <li>"Fuel injection system status" at the moment a malfunction is detected is displayed.</li> </ul>
FUEL SYS-B2	<ul style="list-style-type: none"> <li>One mode in the following is displayed.                             <ul style="list-style-type: none"> <li>"Mode2": Open loop due to detected system malfunction</li> <li>"Mode3": Open loop due to driving conditions (power enrichment, deceleration enrichment)</li> <li>"Mode4": Closed loop - using oxygen sensor(s) as feedback for fuel control</li> <li>"Mode5": Open loop - has not yet satisfied condition to go to closed loop</li> </ul> </li> </ul>
CAL/LD VALUE [%]	<ul style="list-style-type: none"> <li>The calculated load value at the moment a malfunction is detected is displayed.</li> </ul>
COOLANT TEMP [°C] or [°F]	<ul style="list-style-type: none"> <li>The engine coolant temperature at the moment a malfunction is detected is displayed.</li> </ul>
L-FUEL TRM-B1 [%]	<ul style="list-style-type: none"> <li>"Long-term fuel trim" at the moment a malfunction is detected is displayed.</li> </ul>
L-FUEL TRM-B2 [%]	<ul style="list-style-type: none"> <li>The long-term fuel trim indicates much more gradual feedback compensation to the base fuel schedule than short-term fuel trim.</li> </ul>
S-FUEL TRM-B1 [%]	<ul style="list-style-type: none"> <li>"Short-term fuel trim" at the moment a malfunction is detected is displayed.</li> </ul>
S-FUEL TRM-B2 [%]	<ul style="list-style-type: none"> <li>The short-term fuel trim indicates dynamic or instantaneous feedback compensation to the base fuel schedule.</li> </ul>
ENGINE SPEED [rpm]	<ul style="list-style-type: none"> <li>The engine speed at the moment a malfunction is detected is displayed.</li> </ul>
VEHICL SPEED [km/h] or [mph]	<ul style="list-style-type: none"> <li>The vehicle speed at the moment a malfunction is detected is displayed.</li> </ul>
B/FUEL SCHDL [msec]	<ul style="list-style-type: none"> <li>The base fuel schedule at the moment a malfunction is detected is displayed.</li> </ul>
INT/A TEMP SE [°C] or [°F]	<ul style="list-style-type: none"> <li>The intake air temperature at the moment a malfunction is detected is displayed.</li> </ul>

\*: The items are the same as those of 1st trip freeze frame data.

# TROUBLE DIAGNOSIS

[VQ TYPE 1]

## DATA MONITOR MODE

### Monitored Item

×: Applicable

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	Description	Remarks
ENG SPEED [rpm]	×	×	<ul style="list-style-type: none"> <li>Indicates the engine speed computed from the signal of the crankshaft position sensor (POS) and camshaft position sensor (PHASE).</li> </ul>	<ul style="list-style-type: none"> <li>Accuracy becomes poor if engine speed drops below the idle rpm.</li> <li>If the signal is interrupted while the engine is running, an abnormal value may be indicated.</li> </ul>
MAS A/F SE-B1 [V]	×	×	<ul style="list-style-type: none"> <li>The signal voltage of the mass air flow sensor is displayed.</li> </ul>	<ul style="list-style-type: none"> <li>When the engine is stopped, a certain value is indicated.</li> </ul>
B/FUEL SCHDL [msec]		×	<ul style="list-style-type: none"> <li>"Base fuel schedule" indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction.</li> </ul>	
A/F ALPHA-B1 [%]		×	<ul style="list-style-type: none"> <li>The mean value of the air-fuel ratio feedback correction factor per cycle is indicated.</li> </ul>	<ul style="list-style-type: none"> <li>When the engine is stopped, a certain value is indicated.</li> <li>This data also includes the data for the air-fuel ratio learning control.</li> </ul>
A/F ALPHA-B2 [%]		×		
COOLAN TEMP/S [°C] or [°F]	×	×	<ul style="list-style-type: none"> <li>The engine coolant temperature (determined by the signal voltage of the engine coolant temperature sensor) is displayed.</li> </ul>	<ul style="list-style-type: none"> <li>When the engine coolant temperature sensor is open or short-circuited, ECM enters fail-safe mode. The engine coolant temperature determined by the ECM is displayed.</li> </ul>
A/F SEN1 (B1) [V]	×	×	<ul style="list-style-type: none"> <li>The A/F signal computed from the input signal of the air fuel ratio (A/F) sensor 1 is displayed.</li> </ul>	
A/F SEN1 (B2) [V]	×			
HO2S2 (B1) [V]	×		<ul style="list-style-type: none"> <li>The signal voltage of the heated oxygen sensor 2 is displayed.</li> </ul>	
HO2S2 (B2) [V]	×			
HO2S2 MNTR (B1) [RICH/LEAN]	×		<ul style="list-style-type: none"> <li>Display of heated oxygen sensor 2 signal: RICH: Means the amount of oxygen after three way catalyst is relatively small. LEAN: Means the amount of oxygen after three way catalyst is relatively large.</li> </ul>	<ul style="list-style-type: none"> <li>When the engine is stopped, a certain value is indicated.</li> </ul>
HO2S2 MNTR (B2) [RICH/LEAN]	×			
VHCL SPEED SE [km/h] or [mph]	×	×	<ul style="list-style-type: none"> <li>The vehicle speed computed from the vehicle speed signal sent from combination meter is displayed.</li> </ul>	
BATTERY VOLT [V]	×	×	<ul style="list-style-type: none"> <li>The power supply voltage of ECM is displayed.</li> </ul>	
ACCEL SEN 1 [V]	×	×	<ul style="list-style-type: none"> <li>The accelerator pedal position sensor signal voltage is displayed.</li> </ul>	<ul style="list-style-type: none"> <li>ACCEL SEN 2 signal is converted by ECM internally. Thus, it differs from ECM terminal voltage signal.</li> </ul>
ACCEL SEN 2 [V]	×			
THRTL SEN 1 [V]	×	×	<ul style="list-style-type: none"> <li>The throttle position sensor signal voltage is displayed.</li> </ul>	<ul style="list-style-type: none"> <li>THRTL SEN 2 signal is converted by ECM internally. Thus, it differs from ECM terminal voltage signal.</li> </ul>
THRTL SEN 2 [V]	×			
INT/A TEMP SE [°C] or [°F]	×	×	<ul style="list-style-type: none"> <li>The intake air temperature (determined by the signal voltage of the intake air temperature sensor) is indicated.</li> </ul>	
START SIGNAL [ON/OFF]	×	×	<ul style="list-style-type: none"> <li>Indicates start signal status [ON/OFF] computed by the ECM according to the signals of engine speed and battery voltage.</li> </ul>	<ul style="list-style-type: none"> <li>After starting the engine, [OFF] is displayed regardless of the starter signal.</li> </ul>
CLSD THL POS [ON/OFF]	×	×	<ul style="list-style-type: none"> <li>Indicates idle position [ON/OFF] computed by ECM according to the accelerator pedal position sensor signal.</li> </ul>	

# TROUBLE DIAGNOSIS

[VQ TYPE 1]

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	Description	Remarks
AIR COND SIG [ON/OFF]	×	×	<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition of the air conditioner switch as determined by the air conditioner signal.</li> </ul>	
P/N POSI SW [ON/OFF]	×	×	<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from the park/neutral position (PNP) switch signal.</li> </ul>	
PW/ST SIGNAL [ON/OFF]	×	×	<ul style="list-style-type: none"> <li>[ON/OFF] condition of the power steering system (determined by the signal voltage of the power steering pressure sensor signal) is indicated.</li> </ul>	
LOAD SIGNAL [ON/OFF]	×	×	<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from the electrical load signal.</li> <li>ON: Rear window defogger switch is ON and/or lighting switch is in 2nd position.</li> <li>OFF: Both rear window defogger switch and lighting switch are OFF.</li> </ul>	
IGNITION SW [ON/OFF]	×		<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from ignition switch signal.</li> </ul>	
HEATER FAN SW [ON/OFF]	×		<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from the heater fan switch signal.</li> </ul>	
BRAKE SW [ON/OFF]	×		<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from the stop lamp switch signal.</li> </ul>	
INJ PULSE-B1 [msec]		×	<ul style="list-style-type: none"> <li>Indicates the actual fuel injection pulse width compensated by ECM according to the input signals.</li> </ul>	<ul style="list-style-type: none"> <li>When the engine is stopped, a certain computed value is indicated.</li> </ul>
INJ PULSE-B2 [msec]				
IGN TIMING [BTDC]		×	<ul style="list-style-type: none"> <li>Indicates the ignition timing computed by ECM according to the input signals.</li> </ul>	<ul style="list-style-type: none"> <li>When the engine is stopped, a certain value is indicated.</li> </ul>
CAL/LD VALUE [%]			<ul style="list-style-type: none"> <li>Calculated load value indicates the value of the current air flow divided by peak air flow.</li> </ul>	
MASS AIRFLOW [g·m/s]			<ul style="list-style-type: none"> <li>Indicates the mass air flow computed by ECM according to the signal voltage of the mass air flow sensor.</li> </ul>	
PURG VOL C/V [%]			<ul style="list-style-type: none"> <li>Indicates the EVAP canister purge volume control solenoid valve control value computed by the ECM according to the input signals.</li> <li>The opening becomes larger as the value increases.</li> </ul>	
INT/V TIM (B1) [°CA]			<ul style="list-style-type: none"> <li>Indicates [°CA] of intake camshaft advanced angle.</li> </ul>	
INT/V TIM (B2) [°CA]				
INT/V SOL (B1) [%]			<ul style="list-style-type: none"> <li>The control condition of the intake valve timing control solenoid valve (determined by ECM according to the input signals) is indicated.</li> <li>The advance angle becomes larger as the value increases.</li> </ul>	
INT/V SOL (B2) [%]				
VIAS S/V [ON/OFF]			<ul style="list-style-type: none"> <li>The control condition of the VIAS control solenoid valve (determined by ECM according to the input signals) is indicated.</li> <li>ON: VIAS control solenoid valve is operating.</li> <li>OFF: VIAS control solenoid valve is not operating.</li> </ul>	

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# TROUBLE DIAGNOSIS

[VQ TYPE 1]

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	Description	Remarks
AIR COND RLY [ON/OFF]		×	<ul style="list-style-type: none"> <li>The air conditioner relay control condition (determined by ECM according to the input signals) is indicated.</li> </ul>	
FUEL PUMP RLY [ON/OFF]		×	<ul style="list-style-type: none"> <li>Indicates the fuel pump relay control condition determined by ECM according to the input signals.</li> </ul>	
THRTL RELAY [ON/OFF]		×	<ul style="list-style-type: none"> <li>Indicates the throttle control motor relay control condition determined by the ECM according to the input signals.</li> </ul>	
COOLING FAN [HI/LOW/OFF]		×	<ul style="list-style-type: none"> <li>The control condition of the cooling fan (determined by ECM according to the input signals) is indicated.</li> <li>HI: High speed operation</li> <li>LOW: Low speed operation</li> <li>OFF: Stop</li> </ul>	
HO2S2 HTR (B1) [ON/OFF]			<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition of heated oxygen sensor 2 heater determined by ECM according to the input signals.</li> </ul>	
HO2S2 HTR (B2) [ON/OFF]				
I/P PULLY SPD [rpm]			<ul style="list-style-type: none"> <li>Indicates the engine speed computed from the turbine revolution sensor signal.</li> </ul>	
VEHICLE SPEED [km/h] or [MPH]			<ul style="list-style-type: none"> <li>Indicates the vehicle speed computed from the revolution sensor signal.</li> </ul>	
IDL A/V LEARN [YET/CMPLT]			<ul style="list-style-type: none"> <li>Display the condition of idle air volume learning</li> <li>YET: Idle Air Volume Learning has not been performed yet.</li> <li>CMPLT: Idle Air Volume Learning has already been performed successfully.</li> </ul>	
TRVL AFTER MIL [km] or [mile]			<ul style="list-style-type: none"> <li>Distance traveled while MIL is activated.</li> </ul>	
A/F S1 HTR (B1) [%]			<ul style="list-style-type: none"> <li>Air fuel ratio (A/F) sensor 1 heater control value computed by ECM according to the input signals.</li> <li>The current flow to the heater becomes larger as the value increases.</li> </ul>	
A/F S1 HTR (B2) [%]				
AC PRESS SEN [V]			<ul style="list-style-type: none"> <li>The signal voltage from the refrigerant pressure sensor is displayed.</li> </ul>	
VHCL SPEED SE [km/h] or [mph]			<ul style="list-style-type: none"> <li>The vehicle speed computed from the vehicle speed signal sent from TCM is displayed.</li> </ul>	
SET VHCL SPD [km/h] or [mph]			<ul style="list-style-type: none"> <li>The preset vehicle speed is displayed.</li> </ul>	
MAIN SW [ON/OFF]			<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from MAIN switch signal.</li> </ul>	
CANCEL SW [ON/OFF]			<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from CANCEL switch signal.</li> </ul>	
RESUME/ACC SW [ON/OFF]			<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from RESUME/ACCELERATE switch signal.</li> </ul>	
SET SW [ON/OFF]			<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from SET/COAST switch signal.</li> </ul>	
BRAKE SW1 [ON/OFF]			<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from ASCD brake switch signal.</li> </ul>	



# TROUBLE DIAGNOSIS

[VQ TYPE 1]

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	Description	Remarks
BRAKE SW2 [ON/OFF]			<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition of stop lamp switch signal.</li> </ul>	
VHCL SPD CUT [NON/CUT]			<ul style="list-style-type: none"> <li>Indicates the vehicle cruise condition. NON: Vehicle speed is maintained at the ASCD set speed. CUT: Vehicle speed increased to excessively high compared with the ASCD set speed, and ASCD operation is cut off.</li> </ul>	
LO SPEED CUT [NON/CUT]			<ul style="list-style-type: none"> <li>Indicates the vehicle cruise condition. NON: Vehicle speed is maintained at the ASCD set speed. CUT: Vehicle speed decreased to excessively low compared with the ASCD set speed, and ASCD operation is cut off.</li> </ul>	
AT OD MONITOR [ON/OFF]			<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition of A/T O/D according to the input signal from the TCM.</li> </ul>	
AT OD CANCEL [ON/OFF]			<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition of A/T O/D cancel signal sent from the TCM.</li> </ul>	
CRUISE LAMP [ON/OFF]			<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition of CRUISE lamp determined by the ECM according to the input signals.</li> </ul>	
SET LAMP [ON/OFF]			<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition of SET lamp determined by the ECM according to the input signals.</li> </ul>	
Voltage [V]			<ul style="list-style-type: none"> <li>Voltage, frequency, duty cycle or pulse width measured by the probe.</li> </ul>	<ul style="list-style-type: none"> <li>Only # is displayed if item is unable to be measured.</li> <li>Figures with #s are temporary ones. They are the same figures as an actual piece of data which was just previously measured.</li> </ul>
Frequency [msec], [Hz] or [%]				
DUTY-HI				
DUTY-LOW				
PLS WIDTH-HI				
PLS WIDTH-LOW				

**NOTE:**

Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

## DATA MONITOR (SPEC) MODE

### Monitored Item

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	Description	Remarks
ENG SPEED [rpm]	×	×	<ul style="list-style-type: none"> <li>Indicates the engine speed computed from the signal of the crankshaft position sensor (POS) and camshaft position sensor (PHASE).</li> </ul>	
MAS A/F SE-B1 [V]	×	×	<ul style="list-style-type: none"> <li>The signal voltage of the mass air flow sensor specification is displayed.</li> </ul>	<ul style="list-style-type: none"> <li>When engine is running specification range is indicated.</li> </ul>

# TROUBLE DIAGNOSIS

[VQ TYPE 1]

Monitored item [Unit]	ECM INPUT SIGNALS	MAIN SIGNALS	Description	Remarks
B/FUEL SCHDL [msec]		×	<ul style="list-style-type: none"> <li>● "Base fuel schedule" indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction.</li> </ul>	<ul style="list-style-type: none"> <li>● When engine is running specification range is indicated.</li> </ul>
A/F ALPHA-B1 [%] A/F ALPHA-B2 [%]		×	<ul style="list-style-type: none"> <li>● The mean value of the air-fuel ratio feedback correction factor per cycle is indicated.</li> </ul>	<ul style="list-style-type: none"> <li>● When engine is running specification range is indicated.</li> <li>● This data also includes the data for the air-fuel ratio learning control.</li> </ul>

**NOTE:**

Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

## ACTIVE TEST MODE

### Test Item

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
FUEL INJECTION	<ul style="list-style-type: none"> <li>● Engine: Return to the original trouble condition</li> <li>● Change the amount of fuel injection using CONSULT-II.</li> </ul>	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> <li>● Harness and connectors</li> <li>● Fuel injector</li> <li>● Air fuel ratio (A/F) sensor 1</li> </ul>
IGNITION TIMING	<ul style="list-style-type: none"> <li>● Engine: Return to the original trouble condition</li> <li>● Timing light: Set</li> <li>● Retard the ignition timing using CONSULT-II.</li> </ul>	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> <li>● Perform Idle Air Volume Learning.</li> </ul>
POWER BALANCE	<ul style="list-style-type: none"> <li>● Engine: After warming up, idle the engine.</li> <li>● A/C switch: OFF</li> <li>● Shift lever: P or N (A/T), Neutral (M/T)</li> <li>● Cut off each fuel injector signal one at a time using CONSULT-II.</li> </ul>	Engine runs rough or dies.	<ul style="list-style-type: none"> <li>● Harness and connectors</li> <li>● Compression</li> <li>● Fuel injector</li> <li>● Power transistor</li> <li>● Spark plug</li> <li>● Ignition coil</li> </ul>
COOLING FAN*	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> <li>● Turn the cooling fan HI, LOW and OFF using CONSULT-II.</li> </ul>	Cooling fan moves and stops.	<ul style="list-style-type: none"> <li>● Harness and connectors</li> <li>● Cooling fan motor</li> <li>● IPDM E/R</li> </ul>
ENG COOLANT TEMP	<ul style="list-style-type: none"> <li>● Engine: Return to the original trouble condition</li> <li>● Change the engine coolant temperature using CONSULT-II.</li> </ul>	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> <li>● Harness and connectors</li> <li>● Engine coolant temperature sensor</li> <li>● Fuel injector</li> </ul>
FUEL PUMP RELAY	<ul style="list-style-type: none"> <li>● Ignition switch: ON (Engine stopped)</li> <li>● Turn the fuel pump relay ON and OFF using CONSULT-II and listen to operating sound.</li> </ul>	Fuel pump relay makes the operating sound.	<ul style="list-style-type: none"> <li>● Harness and connectors</li> <li>● Fuel pump relay</li> </ul>
VIAS SOL VALVE	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> <li>● Turn solenoid valve ON and OFF with CONSULT-II and listen for operating sound.</li> </ul>	Solenoid valve makes an operating sound.	<ul style="list-style-type: none"> <li>● Harness and connectors</li> <li>● Solenoid valve</li> </ul>

# TROUBLE DIAGNOSIS

**[VQ TYPE 1]**

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
PURG VOL CONT/V	<ul style="list-style-type: none"> <li>● Engine: After warming up, run engine at 1,500 rpm.</li> <li>● Change the EVAP canister purge volume control solenoid valve opening percent using CONSULT-II.</li> </ul>	Engine speed changes according to the opening percent.	<ul style="list-style-type: none"> <li>● Harness and connectors</li> <li>● Solenoid valve</li> </ul>
V/T ASSIGN ANGLE	<ul style="list-style-type: none"> <li>● Engine: Return to the original trouble condition</li> <li>● Change intake valve timing using CONSULT-II.</li> </ul>	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> <li>● Harness and connectors</li> <li>● Intake valve timing control solenoid valve</li> </ul>

\*: Leaving cooling fan OFF with CONSULT-II while engine is running may cause the engine to overheat.

## DTC & SRT CONFIRMATION MODE

### SRT STATUS Mode

For details, refer to [EC-49, "SYSTEM READINESS TEST \(SRT\) CODE"](#) .

### SRT Work Support Mode

This mode enables a technician to drive a vehicle to set the SRT while monitoring the SRT status.

### DTC Work Support Mode

Test mode	Test item	Condition	Reference page
A/F SEN1	A/F SEN1 (B1) P1276	Refer to corresponding trouble diagnosis for DTC.	<a href="#">EC-410</a>
	A/F SEN1 (B1) P1278/P1279		<a href="#">EC-420, EC-432</a>
	A/F SEN1 (B2) P1286		<a href="#">EC-410</a>
	A/F SEN1 (B2) P1288/P1289		<a href="#">EC-420, EC-432</a>
HO2S2	HO2S2 (B1) P0139		<a href="#">EC-196</a>
	HO2S2 (B1) P1146		<a href="#">EC-329</a>
	HO2S2 (B1) P1147	<a href="#">EC-340</a>	
	HO2S2 (B2) P0159	<a href="#">EC-196</a>	
	HO2S2 (B2) P1166	<a href="#">EC-329</a>	
	HO2S2 (B2) P1167	<a href="#">EC-340</a>	

## REAL TIME DIAGNOSIS IN DATA MONITOR MODE (RECORDING VEHICLE DATA)

### Description

CONSULT-II has two kinds of triggers and they can be selected by touching "SETTING" in "DATA MONITOR" mode.

1. "AUTO TRIG" (Automatic trigger):

- The malfunction will be identified on the CONSULT-II screen in real time.

In other words, DTC/1st trip DTC and malfunction item will be displayed if the malfunction is detected by ECM.



At the moment a malfunction is detected by ECM, "MONITOR" in "DATA MONITOR" screen is changed to "Recording Data ... xx%" as shown at right, and the data after the malfunction detection is recorded. Then when the percentage reached 100%, "REAL-TIME DIAG" screen is displayed. If "STOP" is touched on the screen during "Recording Data ... xx%", "REAL-TIME DIAG" screen is also displayed.

The recording time after the malfunction detection and the recording speed can be changed by "TRIGGER POINT" and "Recording Speed". Refer to CONSULT-II OPERATION MANUAL.

2. "MANU TRIG" (Manual trigger):

- DTC/1st trip DTC and malfunction item will not be displayed automatically on CONSULT-II screen even though a malfunction is detected by ECM.

DATA MONITOR can be performed continuously even though a malfunction is detected.




## Operation

### 1. "AUTO TRIG"

- While trying to detect the DTC/1st trip DTC by performing the DTC Confirmation Procedure, be sure to select to "DATA MONITOR (AUTO TRIG)" mode. You can confirm the malfunction at the moment it is detected.
- While narrowing down the possible causes, CONSULT-II should be set in "DATA MONITOR (AUTO TRIG)" mode, especially in case the incident is intermittent. When you are inspecting the circuit by gently shaking (or twisting) the suspicious connectors, components and harness in the DTC Confirmation Procedure, the moment a malfunction is found the DTC/1st trip DTC will be displayed. (Refer to "INCIDENT SIMULATION TESTS" in [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#) .)

### 2. "MANU TRIG"


- If the malfunction is displayed as soon as "DATA MONITOR" is selected, reset CONSULT-II to "MANU TRIG". By selecting "MANU TRIG" you can monitor and store the data. The data can be utilized for further diagnosis, such as a comparison with the value for the normal operating condition.



## Generic Scan Tool (GST) Function DESCRIPTION

GBS000IH

Generic Scan Tool (OBDII scan tool) complying with ISO 15031-4 has 8 different functions explained below. ISO9141 is used as the protocol. The name GST or Generic Scan Tool is used in this service manual.




## FUNCTION


Diagnostic test mode		Function
Service \$01	READINESS TESTS	This diagnostic service gains access to current emission-related data values, including analog inputs and outputs, digital inputs and outputs, and system status information.
Service \$02	(FREEZE DATA)	This diagnostic service gains access to emission-related data value which were stored by ECM during the freeze frame. For details, refer to <a href="#">EC-111, "Freeze Frame Data and 1st Trip Freeze Frame Data"</a> .
Service \$03	DTCs	This mode gains access to emission-related power train trouble codes which were stored by ECM.
Service \$04	CLEAR DIAG INFO	This diagnostic service can clear all emission-related diagnostic information. This includes: <ul style="list-style-type: none"> <li>● Clear number of diagnostic trouble codes (Service \$01)</li> <li>● Clear diagnostic trouble codes (Service \$03)</li> <li>● Clear trouble code for freeze frame data (Service \$01)</li> <li>● Clear freeze frame data (Service \$02)</li> <li>● Reset status of system monitoring test (Service \$01)</li> <li>● Clear on board monitoring test results (Service \$06 and Service \$07)</li> </ul>
Service \$06	(ON BOARD TESTS)	This diagnostic service accesses the results of on board diagnostic monitoring tests of specific components/systems that are not continuously monitored.
Service \$07	(ON BOARD TESTS)	This diagnostic service enables the off board test drive to obtain test results for emission-related power train components/systems that are continuously monitored during normal driving conditions.
Service \$08	—	This diagnostic service is not applicable on this vehicle.
Service \$09	(CALIBRATION ID)	This diagnostic service enables the off-board test device to request specific vehicle information such as Vehicle Identification Number (VIN) and Calibration IDs.

## INSPECTION PROCEDURE


1. Turn ignition switch OFF.
2. Connect GST to data link connector (1), which is located under LH dash panel near the hood opener handle.



3. Turn ignition switch ON.
4. Enter the program according to instruction on the screen or in the operation manual.  
(\*: Regarding GST screens in this section, sample screens are shown.)



5. Perform each diagnostic mode according to each service procedure.  
**For further information, see the GST Operation Manual of the tool maker.**



A

EC

C

D

E

F

G

H

I

J

K

L

M

## CONSULT-II Reference Value in Data Monitor

GBS0001

**Remarks:**

- Specification data are reference values.
- Specification data are output/input values which are detected or supplied by the ECM at the connector.
- \* Specification data may not be directly related to their components signals/values/operations.  
i.e. Adjust ignition timing with a timing light before monitoring IGN TIMING, because the monitor may show the specification data in spite of the ignition timing not being adjusted to the specification data. This IGN TIMING monitors the data calculated by the ECM according to the signals input from the camshaft position sensor and other ignition timing related sensors.

MONITOR ITEM	CONDITION	SPECIFICATION
ENG SPEED	● Run engine and compare CONSULT-II value with the tachometer indication.	Almost the same speed as the tachometer indication.
MAS A/F SE-B1	See <a href="#">EC-127, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE"</a> .	
B/FUEL SCHDL	See <a href="#">EC-127, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE"</a> .	
A/F ALPHA-B1 A/F ALPHA-B2	See <a href="#">EC-127, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE"</a> .	
COOLAN TEMP/S	● Engine: After warming up	More than 70°C (158°F)
A/F SEN1 (B1) A/F SEN1 (B2)	● Engine: After warming up Maintaining engine speed at 2,000 rpm	Fluctuates around 1.5 V
HO2S2 (B1) HO2S2 (B2)	● Revving engine from idle to 3,000 rpm quickly after the following conditions are met – Engine: After warming up – Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)	● Revving engine from idle to 3,000 rpm quickly after the following conditions are met – Engine: After warming up – Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load	LEAN ↔ RICH
VHCL SPEED SE	● Turn drive wheels and compare CONSULT-II value with the speedometer indication.	Almost the same speed as the speedometer indication
BATTERY VOLT	● Ignition switch: ON (Engine stopped)	11 - 14V
ACCEL SEN 1 ACCEL SEN 2*	● Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released Accelerator pedal: Fully depressed
THRTL SEN 1 THRTL SEN 2*	● Ignition switch: ON (Engine stopped) ● Shift lever: D (A/T), 1st (M/T)	Accelerator pedal: Fully released Accelerator pedal: Fully depressed
START SIGNAL	● Ignition switch: ON → START → ON	OFF → ON → OFF
CLSD THL POS	● Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released Accelerator pedal: Slightly depressed
AIR COND SIG	● Engine: After warming up, idle the engine	Air conditioner switch: OFF Air conditioner switch: ON (Compressor operates.)
P/N POSI SW	● Ignition switch: ON	Shift lever: P or N (A/T), Neutral (M/T) Shift lever: Except above
PW/ST SIGNAL	● Engine: After warming up, idle the engine	Steering wheel: Not being turned Steering wheel: Being turned.
LOAD SIGNAL	● Ignition switch: ON	Rear window defogger switch is ON and/or lighting switch is in 2nd Rear window defogger switch and lighting switch is OFF
IGNITION SW	● Ignition switch: ON → OFF → ON	ON → OFF → ON



# TROUBLE DIAGNOSIS

[VQ TYPE 1]

MONITOR ITEM	CONDITION	SPECIFICATION
HEATER FAN SW	<ul style="list-style-type: none"> <li>● Engine: After warming up, idle the engine</li> </ul>	Heater fan switch: ON ON
		Heater fan switch: OFF OFF
BRAKE SW	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> </ul>	Brake pedal: Fully released OFF
		Brake pedal: Slightly depressed ON
INJ PULSE-B1 INJ PULSE-B2	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Shift lever: P or N (A/T), Neutral (M/T)</li> <li>● Air conditioner switch: OFF</li> <li>● No load</li> </ul>	Idle 2.0 - 3.0 msec
		2,000 rpm 1.9 - 2.9 msec
IGN TIMING	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Shift lever: P or N (A/T), Neutral (M/T)</li> <li>● Air conditioner switch: OFF</li> <li>● No load</li> </ul>	Idle 13 - 18° BTDC
		2,000 rpm 25 - 45° BTDC
CAL/LD VALUE	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Shift lever: P or N (A/T), Neutral (M/T)</li> <li>● Air conditioner switch: OFF</li> <li>● No load</li> </ul>	Idle 5 - 35%
		2,500 rpm 5 - 35%
MASS AIRFLOW	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Shift lever: P or N (A/T), Neutral (M/T)</li> <li>● Air conditioner switch: OFF</li> <li>● No load</li> </ul>	Idle 2.0 - 6.0 g-m/s
		2,500 rpm 7.0 - 20.0 g-m/s
PURG VOL C/V	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Shift lever: P or N (A/T), Neutral (M/T)</li> <li>● Air conditioner switch: OFF</li> <li>● No load</li> </ul>	Idle (Accelerator pedal is not depressed even slightly, after engine starting) 0%
		2,000 rpm —
INT/V TIM (B1) INT/V TIM (B2)	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Shift lever: P or N (A/T), Neutral (M/T)</li> <li>● Air conditioner switch: OFF</li> <li>● No load</li> </ul>	Idle -5 - 5°C
		2,000 rpm Approx. 0 - 30°C
INT/V SOL (B1) INT/V SOL (B2)	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Shift lever: P or N (A/T), Neutral (M/T)</li> <li>● Air conditioner switch: OFF</li> <li>● No load</li> </ul>	Idle 0% - 2%
		2,000 rpm Approx. 0 - 50%
VIAS S/V	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> </ul>	2,200 - 3,300 rpm ON
		Except above conditions OFF
AIR COND RLY	<ul style="list-style-type: none"> <li>● Engine: After warming up, idle the engine</li> </ul>	Air conditioner switch: OFF OFF
		Air conditioner switch: ON (Compressor operates) ON
FUEL PUMP RLY	<ul style="list-style-type: none"> <li>● For 1 second after turning ignition switch ON</li> <li>● Engine running or cranking</li> <li>● Except above conditions</li> </ul>	ON
		OFF
THRTL RELAY	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> </ul>	ON

A

EC

C

D

E

F

G

H

I

J

K

L

M

# TROUBLE DIAGNOSIS

**[VQ TYPE 1]**

MONITOR ITEM	CONDITION	SPECIFICATION
COOLING FAN	<ul style="list-style-type: none"> <li>● Engine: After warming up, idle the engine</li> <li>● Air conditioner switch: OFF</li> </ul>	Engine coolant temperature: 97°C (207°F) or less OFF
		Engine coolant temperature: Between 98°C (208°F) and 104°C (219°F) LOW
		Engine coolant temperature: 105°C (221°F) or more HI
HO2S2 HTR (B1) HO2S2 HTR (B2)	<ul style="list-style-type: none"> <li>● Engine speed is below 3,600 rpm after the following conditions are met.                             <ul style="list-style-type: none"> <li>– Engine: After warming up</li> <li>– Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	ON
	<ul style="list-style-type: none"> <li>● Engine speed: Above 3,600 rpm</li> </ul>	OFF
I/P PULLY SPD	<ul style="list-style-type: none"> <li>● Vehicle speed: More than 20 km/h (12 MPH)</li> </ul>	Almost the same speed as the speedometer indication
VEHICLE SPEED	<ul style="list-style-type: none"> <li>● Turn drive wheels and compare the CONSULT-II value with speedometer indication.</li> </ul>	Almost the same speed as the speedometer indication
TRVL AFTER MIL	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> </ul>	Vehicle has traveled after MIL has turned ON. 0 - 65,535 km (0 - 40,723 mile)
A/F S1 HTR (B1) A/F S1 HTR (B2)	<ul style="list-style-type: none"> <li>● Engine: After warming up, idle the engine</li> </ul>	0 - 100%
AC PRESS SEN	<ul style="list-style-type: none"> <li>● Engine: Idle</li> <li>● Both A/C switch and blower fan switch: ON (Compressor operates)</li> </ul>	1.0 - 4.0V
VHCL SPEED SE	<ul style="list-style-type: none"> <li>● Turn drive wheels and compare speedometer indication with the CONSULT-II value.</li> </ul>	Almost the same speed as the CONSULT-II value
SET VHCL SPD	<ul style="list-style-type: none"> <li>● Engine: Running</li> </ul>	ASCD: Operating. The preset vehicle speed is displayed.
MAIN SW	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> </ul>	MAIN switch: Pressed ON
		MAIN switch: Released OFF
CANCEL SW	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> </ul>	CANCEL switch: Pressed ON
		CANCEL switch: Released OFF
RESUME/ACC SW	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> </ul>	RESUME/ACCELERATE switch: Pressed ON
		RESUME/ACCELERATE switch: Released OFF
SET SW	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> </ul>	SET/COAST switch: Pressed ON
		SET/COAST switch: Released OFF
BRAKE SW1	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> </ul>	Brake pedal: Fully released (A/T) Clutch pedal and brake pedal: Fully released (M/T) ON
		Brake pedal: Slightly depressed (A/T) Clutch pedal and/or brake pedal: Slightly depressed (M/T) OFF
BRAKE SW2	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> </ul>	Brake pedal: Fully released OFF
		Brake pedal: Slightly depressed ON
CRUISE LAMP	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> </ul>	MAIN switch: pressed at the 1st time → at the 2nd time ON → OFF
SET LAMP	<ul style="list-style-type: none"> <li>● MAIN switch: ON</li> <li>● When vehicle speed is between 40km/h (25MPH) and 175km/h (109MPH)</li> </ul>	ASCD: Operating ON
		ASCD: Not operating OFF


\*: Accelerator pedal position sensor 2 signal and throttle position sensor 2 signal are converted by ECM internally. Thus, they differ from ECM terminals voltage signal.

**Major Sensor Reference Graph in Data Monitor Mode**

The following are the major sensor reference graphs in "DATA MONITOR" mode.


**CLSD THL POS, ACCEL SEN 1, THRTL SEN 1**


Below is the data for "CLSD THL POS", "ACCEL SEN 1" and "THRTL SEN 1" when depressing the accelerator pedal with the ignition switch ON and with selector lever in D position (A/T), 1st position (M/T). The signal of "ACCEL SEN 1" and "THRTL SEN 1" should rise gradually without any intermittent drop or rise after "CLSD THL POS" is changed from ON to OFF.




**ENG SPEED, MAS A/F SE-B1, THRTL SEN 1, HO2S2 (B1), INJ PULSE-B1**

Below is the data for "ENG SPEED", "MAS A/F SE-B1", "THRTL SEN 1", "HO2S2 (B1)" and "INJ PULSE-B1" when revving engine quickly up to 4,800 rpm under no load after warming up engine sufficiently. Each value is for reference, the exact value may vary.






- "THRTL SEN1" should increase while depressing the accelerator pedal and should decrease while releasing it.



- "HO2S2 (B1)" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.



- "INJ PULSE-B1" should increase when depressing the accelerator pedal and should decrease when the pedal is released.

TROUBLE DIAGNOSIS - SPECIFICATION VALUE

PFP:00031

Description

GBS000IK

The specification (SP) value indicates the tolerance of the value that is displayed in “DATA MONITOR (SPEC)” mode of CONSULT-II during normal operation of the Engine Control System. When the value in “DATA MONITOR (SPEC)” mode is within the SP value, the Engine Control System is confirmed OK. When the value in “DATA MONITOR (SPEC)” mode is NOT within the SP value, the Engine Control System may have one or more malfunctions.

The SP value is used to detect malfunctions that may affect the Engine Control System, but will not light the MIL.

The SP value will be displayed for the following three items:

- B/FUEL SCHDL (The fuel injection pulse width programmed into ECM prior to any learned on board correction)
- A/F ALPHA-B1/B2 (The mean value of air-fuel ratio feedback correction factor per cycle)
- MAS A/F SE-B1 (The signal voltage of the mass air flow sensor)

Testing Condition

GBS000IL

- Vehicle driven distance: More than 5,000 km (3,107 miles)
- Barometric pressure: 98.3 - 104.3 kPa (0.983 - 1.043 bar, 1.003 - 1.064 kg/cm<sup>2</sup> , 14.25 - 15.12 psi)
- Atmospheric temperature: 20 - 30°C (68 - 86°F)
- Engine coolant temperature: 75 - 95°C (167 - 203°F)
- Engine speed: Idle
- Transmission: Warmed-up
- A/T models: After the engine is warmed up to normal operating temperature, drive vehicle until “FLUID TEMP SE” (A/T fluid temperature sensor signal) indicates more than 60°C (140°F).
- M/T models: After the engine is warmed up to normal operating temperature, drive vehicle for 5 minutes.
- Electrical load: Not applied
- Rear window defogger switch, air conditioner switch, lighting switch are OFF. Steering wheel is straight ahead.


Inspection Procedure

GBS000IM


NOTE:

Perform “DATA MONITOR (SPEC)” mode in maximum scale display.

1. Perform [EC-65, "Basic Inspection"](#) .
2. Confirm that the testing conditions indicated above are met.
3. Select “B/FUEL SCHDL”, “A/F ALPHA-B1”, “A/F ALPHA-B2” and “MAS A/F SE-B1” in “DATA MONITOR (SPEC)” mode with CONSULT-II.
4. Make sure that monitor items are within the SP value.
5. If NG, go to [EC-128, "Diagnostic Procedure"](#) .




**Diagnostic Procedure  
OVERALL SEQUENCE**



# TROUBLE DIAGNOSIS - SPECIFICATION VALUE

[VQ TYPE 1]



A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M


## DETAILED PROCEDURE

### 1. CHECK "A/F ALPHA-B1", "A/F ALPHA-B2"

1. Start engine.
2. Confirm that the testing conditions are met. Refer to [EC-127, "Testing Condition"](#) .
3. Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "DATA MONITOR (SPEC)" mode, and make sure that the each indication is within the SP value.

**NOTE:**

Check "A/F ALPHA-B1", "A/F ALPHA-B2" for approximately 1 minute because they may fluctuate. It is NG if the indication is out of the SP value even a little.



OK or NG


- OK >> GO TO 17.  
 NG (Less than the SP value)>>GO TO 2.  
 NG (More than the SP value)>>GO TO 3.

### 2. CHECK "B/FUEL SCHDL"

Select "B/FUEL SCHDL" in "DATA MONITOR (SPEC)" mode, and make sure that the indication is within the SP value.

OK or NG

- OK >> GO TO 4.  
 NG (More than the SP value)>>GO TO 19.




### 3. CHECK "B/FUEL SCHDL"

Select "B/FUEL SCHDL" in "DATA MONITOR (SPEC)" mode, and make sure that the indication is within the SP value.

OK or NG

- OK >> GO TO 6.  
 NG (More than the SP value)>>GO TO 6.  
 NG (Less than the SP value)>>GO TO 25.



### 4. CHECK "A/F ALPHA-B1", "A/F ALPHA-B2"

1. Stop the engine.
2. Disconnect PCV hose, and then plug it.
3. Start engine.
4. Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "DATA MONITOR (SPEC)" mode, and make sure that the each indication is within the SP value.

OK or NG

- OK >> GO TO 5.  
 NG >> GO TO 6.



**5. CHANGE ENGINE OIL**

1. Stop the engine.
2. Change engine oil.

**NOTE:**

This symptom may occur when a large amount of gasoline is mixed with engine oil because of driving conditions (such as when engine oil temperature does not rise enough since a journey distance is too short during winter). The symptom will not be detected after changing engine oil or changing driving condition.

>> **INSPECTION END**

**6. CHECK FUEL PRESSURE**

Check fuel pressure. (Refer to [EC-74, "Fuel Pressure Check"](#) .)

OK or NG

OK >> GO TO 9.

NG (Fuel pressure is too high)>>Replace fuel pressure regulator, refer to [EC-74](#) . GO TO 8.

NG (Fuel pressure is too low)>>GO TO 7.

**7. DETECT MALFUNCTIONING PART**

1. Check the following.
  - Clogged and bent fuel hose and fuel tube
  - Clogged fuel filter
  - Fuel pump and its circuit (Refer to [EC-537](#) .)
2. If NG, repair or replace the malfunctioning part. (Refer to [EC-74](#) .)  
If OK, replace fuel pressure regulator.

>> GO TO 8.

**8. CHECK "A/F ALPHA-B1", "A/F ALPHA-B2"**

1. Start engine.
2. Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "DATA MONITOR (SPEC)" mode, and make sure that the each indication is within the SP value.

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 9.

**9. PERFORM POWER BALANCE TEST**

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Make sure that the each cylinder produces a momentary engine speed drop.

OK or NG

OK >> GO TO 12.

NG >> GO TO 10.

ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0133E

## 10. DETECT MALFUNCTIONING PART

---

1. Check the following.
  - Ignition coil and its circuit (Refer to [EC-543](#) .)
  - Fuel injector and its circuit (Refer to [EC-530](#) .)
  - Intake air leakage
  - Low compression pressure (Refer to [EM-91, "CHECKING COMPRESSION PRESSURE"](#) .)
2. If NG, repair or replace the malfunctioning part.  
If OK, replace fuel injector. (It may be caused by leakage from fuel injector or clogging.)

>> GO TO 11.

## 11. CHECK "A/F ALPHA-B1", "A/F ALPHA-B2"

---

1. Start engine.
2. Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "DATA MONITOR (SPEC)" mode, and make sure that the each indication is within the SP value.

OK or NG

OK >> **INSPECTION END**  
NG >> GO TO 12.

## 12. CHECK A/F SENSOR 1 FUNCTION

---

Perform all DTC Confirmation Procedure related with A/F sensor 1.

- For DTC P1271, P1281, refer to [EC-372, "DTC Confirmation Procedure"](#) .
- For DTC P1272, P1282, refer to [EC-381, "DTC Confirmation Procedure"](#) .
- For DTC P1273, P1283, refer to [EC-390, "DTC Confirmation Procedure"](#) .
- For DTC P1274, P1284, refer to [EC-400, "DTC Confirmation Procedure"](#) .
- For DTC P1276, P1286, refer to [EC-410, "DTC Confirmation Procedure"](#) .
- For DTC P1278, P1288, refer to [EC-421, "DTC Confirmation Procedure"](#) .
- For DTC P1279, P1289, refer to [EC-433, "DTC Confirmation Procedure"](#) .

OK or NG

OK >> GO TO 15.  
NG >> GO TO 13.

## 13. CHECK A/F SENSOR 1 CIRCUIT

---

Perform Diagnostic Procedure according to corresponding DTC.

>> GO TO 14.

## 14. CHECK "A/F ALPHA-B1", "A/F ALPHA-B2"

---

1. Start engine.
2. Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "DATA MONITOR (SPEC)" mode, and make sure that the each indication is within the SP value.

OK or NG

OK >> **INSPECTION END**  
NG >> GO TO 15.

**15. DISCONNECT AND RECONNECT ECM HARNESS CONNECTOR**

1. Stop the engine.
2. Disconnect ECM harness connector. Check pin terminal and connector for damage, and then reconnect it.

>> GO TO 16.

**16. CHECK "A/F ALPHA-B1", "A/F ALPHA-B2"**

1. Start engine.
2. Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "DATA MONITOR (SPEC)" mode, and make sure that the each indication is within the SP value.

OK or NG

OK >> **INSPECTION END**

NG >> Detect malfunctioning part according to [EC-85, "Symptom Matrix Chart"](#).

**17. CHECK "B/FUEL SCHDL"**


Select "B/FUEL SCHDL" in "DATA MONITOR (SPEC)" mode, and make sure that the indication is within the SP value.

OK or NG

OK >> **INSPECTION END**

NG (More than the SP value)>>GO TO 18.

NG (Less than the SP value)>>GO TO 25.

**18. DETECT MALFUNCTIONING PART**

1. Check for the cause of large engine friction. Refer to the following.
  - Engine oil level is too high
  - Engine oil viscosity
  - Belt tension of power steering, alternator, A/C compressor, etc. is excessive
  - Noise from engine
  - Noise from transmission, etc.
2. Check for the cause of insufficient combustion. Refer to the following.
  - Valve clearance malfunction
  - Intake valve timing control function malfunction
  - Camshaft sprocket installation malfunction, etc.

>> Repair or replace malfunctioning part, and then GO TO 30.

**19. CHECK INTAKE SYSTEM**

Check for the cause of uneven air flow through mass air flow sensor. Refer to the following.

- Crushed air ducts
- Malfunctioning seal of air cleaner element
- Uneven dirt of air cleaner element
- Improper specification of intake air system

OK or NG

OK >> GO TO 21.

NG >> Repair or replace malfunctioning part, and then GO TO 20.

**20. CHECK "A/F ALPHA-B1", "A/F ALPHA-B2", AND "B/FUEL SCHDL"**

Select "A/F ALPHA-B1", "A/F ALPHA-B2", and "B/FUEL SCHDL" in "DATA MONITOR (SPEC)" mode, and make sure that the each indication is within the SP value.

OK or NG

OK >> **INSPECTION END**

NG ("B/FUEL SCHDL" is more, "A/F ALPHA-B1", "A/F ALPHA-B2" are less than the SP value)>>GO TO 21.

**21. DISCONNECT AND RECONNECT MASS AIR FLOW SENSOR HARNESS CONNECTOR**

1. Stop the engine.
2. Disconnect mass air flow sensor harness connector. Check pin terminal and connector for damage and then reconnect it again.

>> GO TO 22.

**22. CHECK "A/F ALPHA-B1", "A/F ALPHA-B2"**

1. Start engine.
2. Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "DATA MONITOR (SPEC)" mode, and make sure that the each indication is within the SP value.

OK or NG

OK >> 1. Detect malfunctioning part of mass air flow sensor circuit and repair it. Refer to [EC-163](#) .

2. GO TO 29.

NG >> GO TO 23.


**23. CHECK "MAS A/F SE-B1"**

Select "MAS A/F SE-B1" in "DATA MONITOR (SPEC)" mode, and make sure that the indication is within the SP value.

OK or NG

OK >> GO TO 24.

NG (More than the SP value)>>Replace mass air flow sensor, and then GO TO 29.

**24. REPLACE ECM**

1. Replace ECM.
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [BL-83, "ECM Re-communicating Function"](#) .
3. Perform [EC-71, "Accelerator Pedal Released Position Learning"](#) .
4. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
5. Perform [EC-71, "Idle Air Volume Learning"](#) .

>> GO TO 29.

## 25. CHECK INTAKE SYSTEM

Check for the cause of uneven air flow through mass air flow sensor. Refer to the following.

- Crushed air ducts
- Malfunctioning seal of air cleaner element
- Uneven dirt of air cleaner element
- Improper specification of intake air system

OK or NG

OK >> GO TO 27.

NG >> Repair or replace malfunctioning part, and then GO TO 26.

## 26. CHECK "B/FUEL SCHDL"

Select "B/FUEL SCHDL" in "DATA MONITOR (SPEC)" mode, and make sure that the indication is within the SP value.

OK or NG

OK >> **INSPECTION END**

NG (Less than the SP value)>>GO TO 27.


## 27. CHECK "MAS A/F SE-B1"

Select "MAS A/F SE-B1" in "DATA MONITOR (SPEC)" mode, and make sure that the indication is within the SP value.

OK or NG

OK >> GO TO 28.

NG (Less than the SP value)>>Replace mass air flow sensor, and then GO TO 30.



## 28. CHECK INTAKE SYSTEM

Check for the cause of air leak after the mass air flow sensor. Refer to the following.

- Disconnection, looseness, and cracks in air duct
- Looseness of oil filler cap
- Disconnection of oil level gauge
- Open stuck, breakage, hose disconnection, or cracks of PCV valve
- Disconnection or cracks of EVAP purge hose, open stuck of EVAP canister purge volume control solenoid valve
- Malfunctioning seal of rocker cover gasket
- Disconnection, looseness, or cracks of hoses, such as vacuum hose, connecting to intake air system parts
- Malfunctioning seal of intake air system, etc.

>> GO TO 30.

## 29. CHECK "A/F ALPHA-B1", "A/F ALPHA-B2", AND "B/FUEL SCHDL"

Select "A/F ALPHA-B1", "A/F ALPHA-B2", and "B/FUEL SCHDL" in "DATA MONITOR (SPEC)" mode, and make sure that the each indication is within the SP value.

OK or NG

OK >> **INSPECTION END**

NG >> Detect malfunctioning part according to [EC-85, "Symptom Matrix Chart"](#) .

---

## 30. CHECK "B/FUEL SCHDL"

---

Select "B/FUEL SCHDL" in "DATA MONITOR (SPEC)" mode, and then make sure that the indication is within the SP value.

OK or NG

OK >> **INSPECTION END**

NG >> Detect malfunctioning part according to [EC-85, "Symptom Matrix Chart"](#) .

## TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT

PFP:00006

## Description

GBS00010

Intermittent incidents may occur. In many cases, the malfunction resolves itself (the part or circuit function returns to normal without intervention). It is important to realize that the symptoms described in the customer's complaint often do not recur on (1st trip) DTC visits. Realize also that the most frequent cause of intermittent incidents occurrences is poor electrical connections. Because of this, the conditions under which the incident occurred may not be clear. Therefore, circuit checks made as part of the standard diagnostic procedure may not indicate the specific malfunctioning area.

## Common Intermittent Incidents Report Situations

STEP in Work Flow	Situation
2	The CONSULT-II is used. The SELF-DIAG RESULTS screen shows time data other than [0] or [1t].
3 or 4	The symptom described by the customer does not recur.
5	(1st trip) DTC does not appear during the DTC Confirmation Procedure.
10	The Diagnostic Procedure for PXXXX does not indicate the malfunctioning area.

## Diagnostic Procedure

GBS0001P

## 1. INSPECTION START

Erase (1st trip) DTCs. Refer to [EC-56, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).

>> GO TO 2.

## 2. CHECK GROUND TERMINALS

Check ground terminals for corroding or loose connection. Refer to [EC-145, "Ground Inspection"](#).

OK or NG

OK >> GO TO 3.

NG >> Repair or replace.

## 3. SEARCH FOR ELECTRICAL INCIDENT

Perform [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#), "INCIDENT SIMULATION TESTS".

OK or NG

OK >> **INSPECTION END**

NG >> Repair or replace.

POWER SUPPLY AND GROUND CIRCUIT



PFP:24110

Wiring Diagram


GBS0001Q

EC-MAIN-01


— : DETECTABLE LINE FOR DTC  
 - - - : NON-DETECTABLE LINE FOR DTC



(E12) W H.S.



(E20) B H.S.



(F4) W

REFER TO THE FOLLOWING.

(M91) - SUPER MULTIPLE JUNCTION (SMJ)

(M88) - FUSE BLOCK - JUNCTION BOX (J/B)



# POWER SUPPLY AND GROUND CIRCUIT

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
109	R	Ignition switch	[Ignition switch: OFF]	0V
			[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14V)
111	BR	ECM relay (Self shut-off)	[Engine is running] [Ignition switch: OFF] ● For a few seconds after turning ignition switch OFF	0 - 1.5V
			[Ignition switch: OFF] ● More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14V)
119 120	R P	Power supply for ECM	[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14V)




A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# POWER SUPPLY AND GROUND CIRCUIT

[VQ TYPE 1]

## EC-MAIN-02

— : DETECTABLE LINE FOR DTC  
 — : NON-DETECTABLE LINE FOR DTC



# POWER SUPPLY AND GROUND CIRCUIT

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
1	B	ECM ground	[Engine is running] ● Idle speed	Body ground
115 116	B B	ECM ground	[Engine is running] ● Idle speed	Body ground

## Diagnostic Procedure

GBS000IR

### 1. INSPECTION START

Start engine.

**Is engine running?**

Yes or No

Yes >> GO TO 8.

No >> GO TO 2.

### 2. CHECK ECM POWER SUPPLY CIRCUIT-I


1. Turn ignition switch OFF and then ON.
2. Check voltage between ECM terminal 109 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

OK >> GO TO 4.

NG >> GO TO 3.



### 3. DETECT MALFUNCTIONING PART


Check the following.

- Harness connectors M91, E101
- Fuse block (J/B) connector M88
- 10A fuse
- Harness for open or short between ECM and fuse

>> Repair harness or connectors.

## 4. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-145, "Ground Inspection"](#) .



← : Vehicle front

- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

### OK or NG

- OK >> GO TO 5.  
 NG >> Repair or replace ground connections.

## 5. CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT-I

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminals 1, 115, 116 and ground. Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to power.

### OK or NG

- OK >> GO TO 7.  
 NG >> GO TO 6.

## 6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F4, E9
- Harness for open or short between ECM and ground

>> Repair open circuit or short to power in harness or connectors.


**7. CHECK ECM POWER SUPPLY CIRCUIT-II**

1. Reconnect ECM harness connector.
2. Turn ignition switch ON.
3. Check voltage between IPDM E/R connector E12 terminal 3 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> Go to [EC-543, "IGNITION SIGNAL"](#) .  
 NG >> GO TO 8.




**8. CHECK ECM POWER SUPPLY CIRCUIT-III**

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON and then OFF.
3. Check voltage between ECM terminals 119, 120 and ground with CONSULT-II or tester.

**Voltage: After turning ignition switch OFF, battery voltage will exist for a few seconds, then drop approximately 0V.**

OK or NG

- OK >> GO TO 13.  
 NG (Battery voltage does not exist.)>>GO TO 9.  
 NG (Battery voltage exists for more than a few seconds.)>>GO TO 11.




**9. CHECK ECM POWER SUPPLY CIRCUIT-IV**

Check voltage between ECM terminal 111 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 10.  
 NG >> GO TO 11.



**10. CHECK ECM POWER SUPPLY CIRCUIT-V**

1. Disconnect ECM harness connector.
2. Disconnect IPDM E/R harness connector E12.
3. Check harness continuity between ECM terminals 119, 120 and IPDM E/R terminal 4. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 16.  
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.

A  
 EC  
 C  
 D  
 E  
 F  
 G  
 H  
 I  
 J  
 K  
 L  
 M

## 11. CHECK ECM POWER SUPPLY CIRCUIT-VI

1. Disconnect ECM harness connector.
2. Disconnect IPDM E/R harness connector E12.
3. Check harness continuity between ECM terminal 111 and IPDM E/R terminal 7.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 12.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 12. CHECK 20A FUSE

1. Disconnect 20 A fuse from IPDM E/R.
2. Check 20A fuse.


OK or NG

OK >> GO TO 16.

NG >> Replace 20A fuse.

## 13. CHECK GROUND CONNECTIONS

1. Loosen and retighten three ground screws on the body. Refer to [EC-145. "Ground Inspection"](#).



← : Vehicle front

1. Body ground E21

2. ECM

3. Body ground E41

4. A/C high-pressure service valve

5. ABS actuator and electric unit  
(control unit)

6. Body ground E61

OK or NG

OK >> GO TO 14.

NG >> Repair or replace ground connections.

## 14. CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT-II

1. Check harness continuity between ECM terminals 1, 115, 116 and ground.  
Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to power.

OK or NG

OK >> GO TO 16.

NG >> GO TO 15.

## 15. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F4, E9
- Harness for open or short between ECM and ground

>> Repair open circuit or short to power in harness or connectors.

## 16. CHECK INTERMITTENT INCIDENT

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

OK >> Replace IPDM E/R.

NG >> Repair open circuit or short to power in harness or connectors.

### Ground Inspection

GBS000/S


Ground connections are very important to the proper operation of electrical and electronic circuits. Ground connections are often exposed to moisture, dirt and other corrosive elements. The corrosion (rust) can become an unwanted resistance. This unwanted resistance can change the way a circuit works.

Electronically controlled circuits are very sensitive to proper grounding. A loose or corroded ground can drastically affect an electronically controlled circuit. A poor or corroded ground can easily affect the circuit. Even when the ground connection looks clean, there can be a thin film of rust on the surface.

When inspecting a ground connection follow these rules:

- Remove the ground bolt or screw.
- Inspect all mating surfaces for tarnish, dirt, rust, etc.
- Clean as required to assure good contact.
- Reinstall bolt or screw securely.
- Inspect for "add-on" accessories which may be interfering with the ground circuit.
- If several wires are crimped into one ground eyelet terminal, check for proper crimps. Make sure all of the wires are clean, securely fastened and providing a good ground path. If multiple wires are cased in one eyelet make sure no ground wires have excess wire insulation.

For detailed ground distribution information, refer to [PG-27, "Ground Distribution"](#) .



## DTC U1000, U1001 CAN COMMUNICATION LINE

PFP:23710

### Description

*GBS000IT*

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### On Board Diagnosis Logic

*GBS000IU*

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
U1000*1 1000*1	CAN communication line	<ul style="list-style-type: none"> <li>● ECM cannot communicate to other control units.</li> <li>● ECM cannot communicate for more than the specified time.</li> </ul>	<ul style="list-style-type: none"> <li>● Harness or connectors (CAN communication line is open or shorted)</li> </ul>
U1001*2 1001*2			

\*1: This self-diagnosis has the one trip detection logic.

\*2: The MIL will not light up for this diagnosis.

### DTC Confirmation Procedure

*GBS000IV*

1. Turn ignition switch ON and wait at least 3 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. If 1st trip DTC is detected, go to [EC-148, "Diagnostic Procedure"](#).



# DTC U1000, U1001 CAN COMMUNICATION LINE




[VQ TYPE 1]



## Wiring Diagram

GBS0001W

EC-CAN-01

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

-  : DETECTABLE LINE FOR DTC
-  : NON-DETECTABLE LINE FOR DTC
-  : DATA LINE



MBWA1276E

---

**Diagnostic Procedure**

GBS000IX

Go to [LAN-3, "Precautions When Using CONSULT-II"](#) .

DTC P0011, P0021 IVT CONTROL


PFP:23796

Description  
SYSTEM DESCRIPTION

GBS0001Y

Sensor	Input signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS)	Engine speed and piston position	Intake valve timing control	Intake valve timing control solenoid valve
Camshaft position sensor (PHASE)			
Engine coolant temperature sensor	Engine coolant temperature		
Wheel sensor	Vehicle speed*		

\*: This signal is sent to the ECM through CAN communication line



This mechanism hydraulically controls cam phases continuously with the fixed operating angle of the intake valve.

The ECM receives signals such as crankshaft position, camshaft position, engine speed, and engine coolant temperature. Then, the ECM sends ON/OFF pulse duty signals to the intake valve timing control solenoid valve depending on driving status. This makes it possible to control the shut/open timing of the intake valve to increase engine torque in low/mid speed range and output in high-speed range.

CONSULT-II Reference Value in Data Monitor Mode

GBS0001Z

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
INT/V TIM (B1) INT/V TIM (B2)	● Engine: After warming up ● Shift lever: P or N (A/T), Neutral (M/T) ● Air conditioner switch: OFF ● No load Idle	-5 - 5°C
	2,000 rpm	Approx. 0 - 30°C
INT/V SOL (B1) INT/V SOL (B2)	● Engine: After warming up ● Shift lever: P or N (A/T), Neutral (M/T) ● Air conditioner switch: OFF ● No load Idle	0 - 2%
	2,000 rpm	Approx. 0 - 50%

## On Board Diagnosis Logic

The MIL will not light up for this diagnosis.

DTC No.	Trouble diagnosis name	Detecting condition	Possible cause
P0011 0011 (Bank 1)	Intake valve timing control performance	There is a gap between angle of target and phase-control angle degree.	<ul style="list-style-type: none"> <li>● Crankshaft position sensor (POS)</li> <li>● Camshaft position sensor (PHASE)</li> <li>● Intake valve timing control solenoid valve</li> <li>● Accumulation of debris to the signal pick-up portion of the camshaft</li> <li>● Timing chain installation</li> <li>● Foreign matter caught in the oil groove for intake valve timing control</li> </ul>
P0021 0021 (Bank 2)			

### FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode.

Detected items	Engine operating condition in fail-safe mode
Intake valve timing control	The signal is not energized to the solenoid valve and the valve control does not function.

### DTC Confirmation Procedure

#### CAUTION:

Always drive at a safe speed.

#### NOTE:

- If DTC P0011 or P0021 is displayed with DTC P1111 or P1136, first perform trouble diagnosis for DTC P1111 or P1136. Refer to [EC-303](#).
- If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10V and 16V at idle.

#### WITH CONSULT-II

1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to the normal operating temperature.
3. Maintain the following conditions for at least 6 consecutive seconds. Hold the accelerator pedal as steady as possible.

ENG SPEED	1,200 - 2,000 rpm
COOLAN TEMP/S	More than 60°C (140°F)
B/FUEL SCHDL	More than 3.5 msec
Selector lever	P or N position (A/T) Neutral position (M/T)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
B/FUEL SCHDL	XXX msec

PBIB0164E

4. Stop vehicle with engine running and let engine idle for 10 seconds.
5. If the 1st trip DTC is detected, go to [EC-151, "Diagnostic Procedure"](#).  
If the 1st trip DTC is not detected, go to next step.
6. Maintain the following conditions for at least 20 consecutive seconds.

ENG SPEED	1,700 - 3,175 rpm (A constant rotation is maintained.)
COOLAN TEMP/S	70 - 105°C (158 - 221°F)

Selector lever	1st or 2nd position
Driving location uphill	Driving vehicle uphill (Increased engine load will help maintain the driving conditions required for this test.)

7. If the 1st trip DTC is detected, go to [EC-151, "Diagnostic Procedure"](#) .

**WITH GST**

Follow the procedure "WITH CONSULT-II" above.

## Diagnostic Procedure


GBS000J2

### 1. CHECK OIL PRESSURE WARNING LAMP

1. Start engine.
2. Check oil pressure warning lamp and confirm it is not illuminated.

OK or NG

- OK >> GO TO 2.
- KG >> Go to [LU-7, "ENGINE OIL PRESSURE CHECK"](#) .



### 2. CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE

Refer to [EC-152, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 3.
- NG >> Replace intake valve timing control solenoid valve.

### 3. CHECK CRANKSHAFT POSITION SENSOR (POS)

Refer to [EC-258, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> Replace crankshaft position sensor (POS).

### 4. CHECK CAMSHAFT POSITION SENSOR (PHASE)

Refer to [EC-267, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 5.
- NG >> Replace camshaft position sensor (PHASE).

## 5. CHECK CAMSHAFT (INTAKE)


Check the following.

- Accumulation of debris to the signal plate of camshaft rear end
- Chipping signal plate of camshaft rear end

OK or NG

OK >> GO TO 6.

NG >> Remove debris and clean the signal plate of camshaft rear end or replace camshaft.



## 6. CHECK TIMING CHAIN INSTALLATION

Check service records for any recent repairs that may cause timing chain misaligned.

**Are there any service records that may cause timing chain misaligned?**

Yes or No

Yes >> Check timing chain installation. Refer to [EM-53, "TIMING CHAIN"](#).

No >> GO TO 7.

## 7. CHECK LUBRICATION CIRCUIT

Refer to [EM-82, "Inspection of Camshaft Sprocket \(INT\) Oil Groove"](#).

OK or NG

OK >> GO TO 8.

NG >> Clean lubrication line.

## 8. CHECK INTERMITTENT INCIDENT

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

For Wiring Diagram, refer to [EC-254](#) for CKP sensor (POS) and [EC-261](#) for CMP sensor (PHASE).

>> INSPECTION END

### Component Inspection INTAKE VALVE TIMING CONTROL SOLENOID VALVE


GBS000J3

1. Disconnect intake valve timing control solenoid valve harness connector.
2. Check resistance between intake valve timing control solenoid valve as follows.

Terminal	Resistance
1 and 2	7.0 - 7.7Ω [at 20°C (68°F)]
1 or 2 and ground	∞Ω (Continuity should not exist.)

If NG, replace intake valve timing control solenoid valve.  
If OK, go to next step.

3. Remove intake valve timing control solenoid valve.



PBIB0193E

## DTC P0011, P0021 IVT CONTROL

[VQ TYPE 1]

4. Provide 12V DC between intake valve timing control solenoid valve terminals and then interrupt it. Make sure that the plunger moves as shown in the figure.


**CAUTION:**

Do not apply 12V DC continuously for 5 seconds or more. Doing so may result in damage to the coil in intake valve timing control solenoid valve.

If NG, replace intake valve timing control solenoid valve.

**NOTE:**

Always replace O-ring when intake valve timing control solenoid valve is removed.



GBS000J4

### Removal and Installation INTAKE VALVE TIMING CONTROL SOLENOID VALVE

Refer to [EM-53, "TIMING CHAIN"](#) .

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# DTC P0037, P0038, P0057, P0058 HO2S2 HEATER

[VQ TYPE 1]

## DTC P0037, P0038, P0057, P0058 HO2S2 HEATER

PFP:226A0

### Description SYSTEM DESCRIPTION

GBS000J5

Sensor	Input signal to ECM	ECM function	Actuator
Camshaft position sensor (PHASE) Crankshaft position sensor (POS)	Engine speed	Heated oxygen sensor 2 heater control	Heated oxygen sensor 2 heater
Engine coolant temperature sensor	Engine coolant temperature		
Mass air flow sensor	Amount of intake air		

The ECM performs ON/OFF control of the heated oxygen sensor 2 heater corresponding to the engine speed, amount of intake air and engine coolant temperature.

### OPERATION

Engine speed rpm	Heated oxygen sensor 2 heater
Above 3,600	OFF
Below 3,600 rpm after the following conditions are met. <ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul>	ON

### CONSULT-II Reference Value in Data Monitor Mode

GBS000J6

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S2 HTR (B1) HO2S2 HTR (B2)	<ul style="list-style-type: none"> <li>● Engine speed is below 3,600 rpm after the following conditions are met.                             <ul style="list-style-type: none"> <li>– Engine: After warming up</li> <li>– Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	ON
	<ul style="list-style-type: none"> <li>● Engine speed: Above 3,600 rpm</li> </ul>	OFF

### On Board Diagnosis Logic

GBS000J7

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0037 0037 (Bank 1)	Heated oxygen sensor 2 heater control circuit low input	The current amperage in the heated oxygen sensor 2 heater circuit is out of the normal range. (An excessively low voltage signal is sent to ECM through the heated oxygen sensor 2 heater.)	<ul style="list-style-type: none"> <li>● Harness or connectors (The heated oxygen sensor 2 heater circuit is open or shorted.)</li> <li>● Heater oxygen sensor 2 heater</li> </ul>
P0057 0057 (Bank 2)			
P0038 0038 (Bank 1)	Heated oxygen sensor 2 heater control circuit high input	The current amperage in the heated oxygen sensor 2 heater circuit is out of the normal range. (An excessively high voltage signal is sent to ECM through the heated oxygen sensor 2 heater.)	<ul style="list-style-type: none"> <li>● Harness or connectors (The heated oxygen sensor 2 heater circuit is shorted.)</li> <li>● Heater oxygen sensor 2 heater</li> </ul>
P0058 0058 (Bank 2)			



**DTC Confirmation Procedure**

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is between 10.5V and 16V at idle.

**WITH CONSULT-II**

1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to the normal operating temperature.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Start the engine and keep the engine speed between 3,500 rpm and 4,000 rpm for at least 1 minute under no load.
5. Let engine idle for 1 minute.
6. If 1st trip DTC is detected, go to [EC-159, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h

SEP176Y

**WITH GST**

Follow the procedure "WITH CONSULT-II" above.

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



# DTC P0037, P0038, P0057, P0058 HO2S2 HEATER

[VQ TYPE 1]


GBS000J9

## Wiring Diagram BANK 1


EC-O2H2B1-01



(E12)  
W



(F1)  
B



(F2)  
W



(F31)  
L

MBWA1277E

# DTC P0037, P0038, P0057, P0058 HO2S2 HEATER

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
25	SB	Heated oxygen sensor 2 heater (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed is below 3,600 rpm after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: after warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - 1.0V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> </ul> <b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed: Above 3,600 rpm</li> </ul>	BATTERY VOLTAGE (11 - 14V)
74	O	Heated oxygen sensor 2 (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Revving engine from idle to 3,000 rpm quickly after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: after warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - Approximately 1.0V
78	B	Sensor ground (Heated oxygen sensor 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● <b>Warm-up condition</b></li> <li>● Idle speed</li> </ul>	Approximately 0V



A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# DTC P0037, P0038, P0057, P0058 HO2S2 HEATER

[VQ TYPE 1]

BANK 2

EC-O2H2B2-01



Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
6	R	Heated oxygen sensor 2 heater (Bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed is below 3,600 rpm after the following conditions are met.                             <ul style="list-style-type: none"> <li>- Engine: after warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - 1.0V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> </ul> <b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed: Above 3,600 rpm</li> </ul>	BATTERY VOLTAGE (11 - 14V)
55	G	Heated oxygen sensor 2 (Bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Revving engine from idle to 3,000 rpm quickly after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: after warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - Approximately 1.0V
78	B	Sensor ground (Heated oxygen sensor 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 0V

**Diagnostic Procedure**

GBS000JA

**1. CHECK GROUND CONNECTIONS**

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-145, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

## 2. CHECK HO2S2 POWER SUPPLY CIRCUIT

1. Disconnect heated oxygen sensor 2 harness connector.




1. Heated oxygen sensor 2 (bank 2)
2. Heated oxygen sensor 2 (bank 2) harness connector
3. Heated oxygen sensor 2 (bank 1) harness connector
4. Heated oxygen sensor 2 (bank 1)

2. Turn ignition switch ON.
3. Check voltage between HO2S2 terminal 3 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 4.  
 NG >> GO TO 3.



## 3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E8, F2
- IPDM E/R harness connector E12
- 10A fuse
- Harness for open or short between heated oxygen sensor 2 and fuse

>> Repair harness or connectors.

4. CHECK HO2S2 OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal and HO2S2 terminal as follows.  
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0037, P0038	25	2	1
P0057, P0058	6	2	2

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 2 HEATER

Refer to [EC-161, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> Replace malfunctioning heated oxygen sensor 2.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection  
HEATED OXYGEN SENSOR 2 HEATER

GBS000JB


1. Check resistance between HO2S2 terminals as follows.

Terminal No.	Resistance
2 and 3	9.9 - 13.3 Ω [at 25°C (77°F)]
1 and 2, 3, 4	∞ Ω (Continuity should not exist)
4 and 1, 2, 3	

2. If NG, replace heated oxygen sensor 2.

**CAUTION:**

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.



SEF249Y

---

**Removal and Installation**  
**HEATED OXYGEN SENSOR 2**

GBS000JC

Refer to [EM-23, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#) .



DTC P0102, P0103 MAF SENSOR


PFP:22680

Component Description

GBS000JD

The mass air flow sensor (1) is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. The mass air flow sensor controls the temperature of the hot wire to a certain amount. The heat generated by the hot wire is reduced as the intake air flows around it. The more air, the greater the heat loss.

Therefore, electric current is supplied to hot wire is changed to maintain the temperature of the hot wire as air flow increases. The ECM detects the air flow by means of this current change.



CONSULT-II Reference Value in Data Monitor Mode

GBS000JE

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
MAS A/F SE-B1	See <a href="#">EC-127, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE"</a> .		
CAL/LD VALUE	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Shift lever: P or N (A/T), Neutral (M/T)</li> <li>● Air conditioner switch: OFF</li> <li>● No load</li> </ul>	Idle	5 - 35%
		2,500 rpm	5 - 35%
MASS AIRFLOW	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Shift lever: P or N (A/T), Neutral (M/T)</li> <li>● Air conditioner switch: OFF</li> <li>● No load</li> </ul>	Idle	2.0 - 6.0 g-m/s
		2,500 rpm	7.0 - 20.0 g-m/s

On Board Diagnosis Logic

GBS000JF

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0102 0102	Mass air flow sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> <li>● Harness or connectors (The sensor circuit is open or shorted.)</li> <li>● Intake air leaks</li> <li>● Mass air flow sensor</li> </ul>
P0103 0103	Mass air flow sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> <li>● Harness or connectors (The sensor circuit is open or shorted.)</li> <li>● Mass air flow sensor</li> </ul>

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.

Detected items	Engine operating condition in fail-safe mode
Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.

## DTC Confirmation Procedure

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### PROCEDURE FOR DTC P0102

#### With CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and wait at least 5 seconds.
4. If DTC is detected, go to [EC-166, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

#### With GST

Follow the procedure "With CONSULT-II" above.

### PROCEDURE FOR DTC P0103

#### With CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-166, "Diagnostic Procedure"](#) .  
If DTC is not detected, go to next step.
5. Start engine and wait at least 5 seconds.
6. If DTC is detected, go to [EC-166, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

#### With GST

Follow the procedure "With CONSULT-II" above.

# DTC P0102, P0103 MAF SENSOR



[VQ TYPE 1]

GBS000JH

## Wiring Diagram

EC-MAFS-01

— : DETECTABLE LINE FOR DTC  
 - - - : NON-DETECTABLE LINE FOR DTC



MBWA1279E

# DTC P0102, P0103 MAF SENSOR

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
51	P	Mass air flow sensor	[Ignition switch: ON]	Approximately 0.4V
			[Engine is running] ● Warm-up condition ● Idle speed	0.9 - 1.2V
			[Engine is running] ● Warm-up condition ● Engine is revving from idle to about 4,000 rpm	0.9 - 1.2 to Approximately 2.4V (Check for linear voltage rise in response to engine being increased to about 4,000 rpm)
67	GR	Sensor ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
111	BR	ECM relay (Self shut-off)	[Engine is running] [Ignition switch: OFF] ● For a few seconds after turning ignition switch OFF	0 - 1.5V
			[Ignition switch: OFF] ● More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14V)
119 120	R P	Power supply for ECM	[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14V)

## Diagnostic Procedure

GBS000JI

### 1. INSPECTION START

Which malfunction (P0102 or P0103) is duplicated?

P0102 or P0103

- P0102 >> GO TO 2.
- P0103 >> GO TO 3.

### 2. CHECK INTAKE SYSTEM

Check the following for connection.


- Air duct
- Vacuum hoses
- Intake air passage between air duct and intake manifold

OK or NG

- OK >> GO TO 3.
- NG >> Reconnect the parts.

### 3. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-145, "Ground Inspection"](#).



↔ : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

**OK or NG**

- OK >> GO TO 4.  
 NG >> Repair or replace ground connections.

### 4. CHECK MAF SENSOR POWER SUPPLY CIRCUIT

1. Disconnect mass air flow (MAF) sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between MAF sensor terminal 5 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

**OK or NG**

- OK >> GO TO 6.  
 NG >> GO TO 5.



## 5. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors E9, F4
- Harness for open or short between IPDM E/R and mass air flow sensor
- Harness for open or short between mass air flow sensor and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 6. CHECK MAF SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

---

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between MAF sensor terminal 4 and ECM terminal 67.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 7.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 7. CHECK MAF SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

1. Check harness continuity between MAF sensor terminal 3 and ECM terminal 51.  
Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 8.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 8. CHECK MASS AIR FLOW SENSOR

---

Refer to [EC-168, "Component Inspection"](#) .

OK or NG

OK >> GO TO 9.

NG >> Replace mass air flow sensor.

## 9. CHECK INTERMITTENT INCIDENT

---

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

### Component Inspection MASS AIR FLOW SENSOR

GBS000JJ

#### With CONSULT-II

1. Reconnect all harness connectors disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Connect CONSULT-II and select "DATA MONITOR" mode.

# DTC P0102, P0103 MAF SENSOR

[VQ TYPE 1]

4. Select "MAS A/F SE-B1" and check indication under the following conditions.

Condition	MAS A/F SE-B1 (V)
Ignition switch ON (Engine stopped.)	Approx. 0.4
Idle (Engine is warmed-up to normal operating temperature.)	0.9 - 1.2
Idle to about 4,000 rpm	0.9 - 1.2 to Approx. 2.4*

\*: Check for linear voltage rise in response to engine being increased to about 4,000 rpm.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C

SEF178Y


5. If the voltage is out of specification, proceed the following.
- Check for the cause of uneven air flow through mass air flow sensor. Refer to following.
    - Crushed air ducts
    - Malfunctioning seal of air cleaner element
    - Uneven dirt of air cleaner element
    - Improper specification of intake air system parts
  - If NG, repair or replace malfunctioning part and perform step 2 to 4 again. If OK, go to next step.
6. Turn ignition switch OFF.
7. Disconnect mass air flow sensor harness connector and reconnect it again.
8. Perform step 2 to 4 again.
9. If NG, clean or replace mass air flow sensor.

## ⊗ Without CONSULT-II

- Reconnect all harness connectors disconnected.
- Start engine and warm it up to normal operating temperature.
- Check voltage between ECM terminal 51 (Mass air flow sensor signal) and ground.

Condition	Voltage V
Ignition switch ON (Engine stopped.)	Approx. 0.4
Idle (Engine is warmed-up to normal operating temperature.)	0.9 - 1.2
Idle to about 4,000 rpm	0.9 - 1.2 to Approx. 2.4*

\*: Check for linear voltage rise in response to engine being increased to about 4,000 rpm.



4. If the voltage is out of specification, proceed the following.
- Check for the cause of uneven air flow through mass air flow sensor. Refer to following.
    - Crushed air ducts
    - Malfunctioning seal of air cleaner element
    - Uneven dirt of air cleaner element
    - Improper specification of intake air system parts
  - If NG, repair or replace malfunctioning part and perform step 2 to 3 again. If OK, go to next step.
5. Turn ignition switch OFF.
6. Disconnect mass air flow sensor harness connector and reconnect it again.
7. Perform step 2 and 3 again.
8. If NG, clean or replace mass air flow sensor.

## Removal and Installation MASS AIR FLOW SENSOR

Refer to [EM-17, "AIR CLEANER AND AIR DUCT"](#) .

GBS000JK

## DTC P0112, P0113 IAT SENSOR


PFP:22630

### Component Description

GBS000JL

The intake air temperature sensor is built-into mass air flow sensor (1). The sensor detects intake air temperature and transmits a signal to the ECM.


The temperature sensing unit uses a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.



### <Reference data>

Intake air temperature °C (°F)	Voltage* V	Resistance kΩ
25 (77)	3.3	1.800 - 2.200
80 (176)	1.2	0.283 - 0.359

\*: This data is reference value and is measured between ECM terminal 34 (Intake air temperature sensor) and ground.



### CAUTION:

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

### On Board Diagnosis Logic

GBS000JM

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0112 0112	Intake air temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> <li>● Harness or connectors (The sensor circuit is open or shorted.)</li> <li>● Intake air temperature sensor</li> </ul>
P0113 0113	Intake air temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

### DTC Confirmation Procedure


GBS000JN

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### Ⓟ WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If 1st trip DTC is detected, go to [EC-173, "Diagnostic Procedure"](#)





# DTC P0112, P0113 IAT SENSOR

[VQ TYPE 1]

 **WITH GST**

Follow the procedure "WITH CONSULT-II" above.

A

**EC**

C

D

E

F

G

H

I

J

K

L

M

# DTC P0112, P0113 IAT SENSOR




[VQ TYPE 1]

## Wiring Diagram

GBS000J0

### EC-IATS-01


: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



## Diagnostic Procedure

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-145, "Ground Inspection"](#).



↙ : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

### 2. CHECK INTAKE AIR TEMPERATURE SENSOR POWER SUPPLY CIRCUIT

1. Disconnect mass air flow sensor (intake air temperature sensor is built-into) harness connector.
2. Turn ignition switch ON.




3. Check voltage between mass air flow sensor terminal 2 and ground.

**Voltage: Approximately 5V**

#### OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness or connectors.



**3. CHECK INTAKE AIR TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between mass air flow sensor terminal 1 and ECM terminal 67.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**4. CHECK INTAKE AIR TEMPERATURE SENSOR**

Refer to [EC-174, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace mass air flow sensor (with intake air temperature sensor).

**5. CHECK INTERMITTENT INCIDENT**

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


**Component Inspection  
INTAKE AIR TEMPERATURE SENSOR**

GBS000JQ


1. Check resistance between mass air flow sensor (1) terminals 1 and 2 under the following conditions.

Intake air temperature °C (°F)	Resistance kΩ
25 (77)	1.800 - 2.200

2. If NG, replace mass air flow sensor (with intake air temperature sensor).



PBIA9559J



SEF012P

**Removal and Installation  
MASS AIR FLOW SENSOR**

GBS000JR

Refer to [EM-17, "AIR CLEANER AND AIR DUCT"](#) .


## DTC P0117, P0118 ECT SENSOR

PFP:22630

### Component Description

GBS000JS


The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.



### <Reference data>

Engine coolant temperature °C (°F)	Voltage* V	Resistance kΩ
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	0.9	0.236 - 0.260

\*: This data is reference value and is measured between ECM terminal 73 (Engine coolant temperature sensor) and ground.



### CAUTION:

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

### On Board Diagnosis Logic

GBS000JT

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P0117 0117	Engine coolant temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> <li>● Harness or connectors (The sensor circuit is open or shorted.)</li> <li>● Engine coolant temperature sensor</li> </ul>
P0118 0118	Engine coolant temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

### FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.

Detected items	Engine operating condition in fail-safe mode	
Engine coolant temperature sensor circuit	Engine coolant temperature will be determined by ECM based on the time after turning ignition switch ON or START. CONSULT-II displays the engine coolant temperature decided by ECM.	
	Condition	Engine coolant temperature decided (CONSULT-II display)
	Just as ignition switch is turned ON or START	40°C (104°F)
	More than approx. 4 minutes after ignition ON or START	80°C (176°F)
	Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)
When the fail-safe system for engine coolant temperature sensor is activated, the cooling fan operates while engine is running.		

**DTC Confirmation Procedure**

GBS000JU

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**④ WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-178, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

**④ WITH GST**

Follow the procedure "WITH CONSULT-II" above.

# DTC P0117, P0118 ECT SENSOR



[VQ TYPE 1]

## Wiring Diagram

GBS000JV

EC-ECTS-01


: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



## Diagnostic Procedure

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-145, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

### 2. CHECK ECT SENSOR POWER SUPPLY CIRCUIT

1. Disconnect engine coolant temperature (ECT) sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between ECT sensor terminal 1 and ground with CONSULT-II or tester.

**Voltage: Approximately 5V**

#### OK or NG

- OK >> GO TO 3.  
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.





**3. CHECK ECT SENSOR GROUND CIRCUIT FOR OPEN AND SHORT**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECT sensor terminal 2 and ECM terminal 67.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**4. CHECK ENGINE COOLANT TEMPERATURE SENSOR**

Refer to [EC-179, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace engine coolant temperature sensor.

**5. CHECK INTERMITTENT INCIDENT**


Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

**Component Inspection  
ENGINE COOLANT TEMPERATURE SENSOR**

GBS000JX

1. Check resistance between engine coolant temperature sensor terminals 1 and 2 as shown in the figure.




PBIB2005E

**<Reference data>**

Engine coolant temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

2. If NG, replace engine coolant temperature sensor.



SEF012P

**Removal and Installation  
ENGINE COOLANT TEMPERATURE SENSOR**

GBS000JY

Refer to [CO-29, "WATER OUTLET AND WATER PIPING"](#) .

**DTC P0122, P0123 TP SENSOR**


PFP:16119

**Component Description**

GBS000JZ

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



**CONSULT-II Reference Value in Data Monitor Mode**

GBS000K0

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
THRTL SEN 1 THRTL SEN 2*	<ul style="list-style-type: none"> <li>Ignition switch: ON (Engine stopped)</li> <li>Shift lever: D (A/T), 1st (M/T)</li> </ul>	Accelerator pedal: Fully released	More than 0.36V
		Accelerator pedal: Fully depressed	Less than 4.75V

\*: Throttle position sensor 2 signal is converted by ECM internally. Thus, it differs from ECM terminal voltage signal.

**On Board Diagnosis Logic**

GBS000K1

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0122 0122	Throttle position sensor 2 circuit low input	An excessively low voltage from the TP sensor 2 is sent to ECM.	<ul style="list-style-type: none"> <li>Harness or connectors (The TP sensor 2 circuit is open or shorted.) (The APP sensor 2 circuit is shorted.)</li> <li>Electric throttle control actuator (TP sensor 2)</li> <li>Accelerator pedal position sensor (APP sensor 2)</li> </ul>
P0123 0123	Throttle position sensor 2 circuit high input	An excessively high voltage from the TP sensor 2 is sent to ECM.	

**FAIL-SAFE MODE**

When the malfunction is detected, ECM enters fail-safe mode and the MIL lights up.

Engine operation condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

**DTC Confirmation Procedure**

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION:**

**Before performing the following procedure, confirm that battery voltage is more than 10V at idle.**

**WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-184, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

**WITH GST**

Follow the procedure "WITH CONSULT-II" above.

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# DTC P0122, P0123 TP SENSOR



[VQ TYPE 1]

## Wiring Diagram

GBS000K3

### EC-TPS2-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



MBWA1282E

# DTC P0122, P0123 TP SENSOR

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	W	Sensor power supply (Throttle position sensor)	<b>[Ignition switch: ON]</b>	Approximately 5V
50	W	Throttle position sensor 1	<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully released</li> </ul>	More than 0.36V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully depressed</li> </ul>	Less than 4.75V
66	B	Sensor ground (Throttle position sensor)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 0V
69	R	Throttle position sensor 2	<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully released</li> </ul>	Less than 4.75V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully depressed</li> </ul>	More than 0.36V
91	G	Sensor power supply (APP sensor 2)	<b>[Ignition switch: ON]</b>	Approximately 5V

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

**Diagnostic Procedure**

**1. CHECK GROUND CONNECTIONS**

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-145, "Ground Inspection"](#) .



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

**2. CHECK THROTTLE POSITION SENSOR 2 POWER SUPPLY CIRCUIT-I**

1. Disconnect electric throttle control actuator harness connector.
2. Turn ignition switch ON.




3. Check voltage between electric throttle control actuator terminal 2 and ground with CONSULT-II or tester.

**Voltage: Approximately 5V**

OK or NG

- OK >> GO TO 7.  
 NG >> GO TO 3.



**3. CHECK THROTTLE POSITION SENSOR 2 POWER SUPPLY CIRCUIT-II**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between electric throttle control actuator terminal 2 and ECM terminal 47. Refer to Wiring Diagram.

**Continuity should exist.**

OK or NG

- OK >> GO TO 4.  
 NG >> Repair open circuit.

**4. CHECK THROTTLE POSITION SENSOR 2 POWER SUPPLY CIRCUIT-III**

Check harness for short to power and short to ground, between the following terminals.

ECM terminal	Sensor terminal	Reference Wiring Diagram
47	Electric throttle control actuator terminal 2	<a href="#">EC-182</a>
91	APP sensor terminal 1	<a href="#">EC-486</a>

OK or NG

- OK >> GO TO 5.  
 NG >> Repair short to ground or short to power in harness or connectors.

**5. CHECK APP SENSOR**

Refer to [EC-490, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 11.  
 NG >> GO TO 6.

**6. REPLACE ACCELERATOR PEDAL ASSEMBLY**

1. Replace accelerator pedal assembly.
2. Perform [EC-71, "Accelerator Pedal Released Position Learning"](#) .
3. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
4. Perform [EC-71, "Idle Air Volume Learning"](#) .

**>> INSPECTION END**

**7. CHECK THROTTLE POSITION SENSOR 2 GROUND CIRCUIT FOR OPEN AND SHORT**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between electric throttle control actuator terminal 4 and ECM terminal 66. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.  
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**8. CHECK THROTTLE POSITION SENSOR 2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

1. Check harness continuity between ECM terminal 69 and electric throttle control actuator terminal 3. Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 9.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**9. CHECK THROTTLE POSITION SENSOR**

Refer to [EC-186, "Component Inspection"](#) .

OK or NG

OK >> GO TO 11.

NG >> GO TO 10.

**10. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR**

1. Replace the electric throttle control actuator.
2. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-71, "Idle Air Volume Learning"](#) .

>> INSPECTION END

**11. CHECK INTERMITTENT INCIDENT**

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


**Component Inspection  
THROTTLE POSITION SENSOR**

GBS000K5

1. Reconnect all harness connectors disconnected.
2. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
3. Turn ignition switch ON.
4. Set selector lever to D position (A/T), 1st position (M/T).
5. Check voltage between ECM terminals 50 (TP sensor 1 signal), 69 (TP sensor 2 signal) and ground under the following conditions.

Terminal	Accelerator pedal	Voltage
50 (Throttle position sensor 1)	Fully released	More than 0.36V
	Fully depressed	Less than 4.75V
69 (Throttle position sensor 2)	Fully released	Less than 4.75V
	Fully depressed	More than 0.36V

6. If NG, replace electric throttle control actuator and go to the next step.
7. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
8. Perform [EC-71, "Idle Air Volume Learning"](#) .



**Removal and Installation  
ELECTRIC THROTTLE CONTROL ACTUATOR**

GBS000K6

Refer to [EM-18, "INTAKE MANIFOLD COLLECTOR"](#) .




**DTC P0138, P0158 HO2S2**

PFP:226A0

**Component Description**

GBS000K7

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas on each bank. Even if switching characteristics of the air fuel ratio (A/F) sensor 1 are shifted, the air-fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2. This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



**CONSULT-II Reference Value in Data Monitor Mode**

GBS000K8


Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S2 (B1) HO2S2 (B2)	<ul style="list-style-type: none"> <li>● Revving engine from idle to 3,000 rpm quickly after the following conditions are met</li> </ul>	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)	<ul style="list-style-type: none"> <li>- Engine: After warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul>	LEAN ↔ RICH

**On Board Diagnosis Logic**

GBS000K9

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the air fuel ratio (A/F) sensor 1. The oxygen storage capacity of the three way catalyst (manifold) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the voltage is unusually high during the various driving condition such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0138 0138 (Bank 1)	Heated oxygen sensor 2 circuit high voltage	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> <li>● Harness or connectors (The sensor circuit is open or shorted)</li> <li>● Heated oxygen sensor 2</li> </ul>
P0158 0158 (Bank 2)			

## DTC Confirmation Procedure

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### WITH CONSULT-II

1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to the normal operating temperature.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
5. Let engine idle for 2 minutes.
6. If 1st trip DTC is detected, go to [EC-192. "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C


SEF174Y

### WITH GST


Follow the procedure "WITH CONSULT-II" above.

Wiring Diagram  
BANK 1

EC-O2S2B1-01



A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



## DTC P0138, P0158 HO2S2

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.



**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
25	SB	Heated oxygen sensor 2 heater (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed is below 3,600 rpm after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: after warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - 1.0V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> </ul> <b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed: Above 3,600 rpm</li> </ul>	BATTERY VOLTAGE (11 - 14V)
74	O	Heated oxygen sensor 2 (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Revving engine from idle to 3,000 rpm quickly after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: after warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - Approximately 1.0V
78	B	Sensor ground (Heated oxygen sensor 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● <b>Warm-up condition</b></li> <li>● Idle speed</li> </ul>	Approximately 0V

BANK 2

EC-O2S2B2-01



Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
6	R	Heated oxygen sensor 2 heater (Bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed is below 3,600 rpm after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: after warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - 1.0V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> </ul> <b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed: Above 3,600 rpm</li> </ul>	BATTERY VOLTAGE (11 - 14V)
55	G	Heated oxygen sensor 2 (Bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Revving engine from idle to 3,000 rpm quickly after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: after warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - Approximately 1.0V
78	B	Sensor ground (Heated oxygen sensor 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 0V

**Diagnostic Procedure**

GBS000KC

**1. CHECK GROUND CONNECTIONS**

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-145, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

## 2. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Disconnect heated oxygen sensor 2 harness connector.



1. Heated oxygen sensor 2 (bank 2)
2. Heated oxygen sensor 2 (bank 2) harness connector
3. Heated oxygen sensor 2 (bank 1) harness connector
4. Heated oxygen sensor 2 (bank 1)

2. Disconnect ECM harness connector.
3. Check harness continuity between HO2S2 terminal 4 and ECM terminal 78. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to ground or short to power in harness or connectors.

## 3. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal and HO2S2 terminal as follows. Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0138	74	1	1
P0158	55	1	2

**Continuity should exist.**

2. Check harness continuity between the following terminals and ground. Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0138	74	1	1
P0158	55	1	2

**Continuity should not exist.**

3. Also check harness for short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

#### 4. CHECK HO2S2 CONNECTOR FOR WATER

Check connectors for water.

**Water should not exist.**

OK or NG

- OK >> GO TO 5.
- NG >> Repair or replace harness or connectors.

#### 5. CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-194, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> Replace malfunctioning heated oxygen sensor 2.

#### 6. CHECK INTERMITTENT INCIDENT

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

### Component Inspection HEATED OXYGEN SENSOR 2

GBS000KD

#### ④ With CONSULT-II

1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
  2. Start engine and warm it up to the normal operating temperature.
  3. Turn ignition switch OFF and wait at least 10 seconds.
  4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
  5. Let engine idle for 1 minute.
- 
6. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C


SEF174Y

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S2 (B1)	XXX V
HO2S2 (B2)	XXX V

PBIB1672E



7. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to  $\pm 25\%$ .




"HO2S2 (B1)/(B2)" should be above 0.68V at least once when the "FUEL INJECTION" is +25%.  
 "HO2S2 (B1)/(B2)" should be below 0.18V at least once when the "FUEL INJECTION" is -25%.

**CAUTION:**

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

⊗ **Without CONSULT-II**

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
4. Let engine idle for 1 minute.
5. Set voltmeter probes between ECM terminal 74 [HO2S2 (B1) signal] or 55 [HO2S2 (B2) signal] and ground.
6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.  
 (Depress and release accelerator pedal as soon as possible.)  
**The voltage should be above 0.68V at least once during this procedure.**  
**If the voltage is above 0.68V at step 6, step 7 is not necessary.**
7. Keep vehicle at idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in D position with "OD" OFF (A/T), 4th gear position (M/T).  
**The voltage should be below 0.18V at least once during this procedure.**
8. If NG, replace heated oxygen sensor 2.



**CAUTION:**

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

**Removal and Installation  
 HEATED OXYGEN SENSOR 2**

GBS000KE

Refer to [EM-23, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#) .

**DTC P0139, P0159 HO2S2**

PFP:226A0

**Component Description**


GBS000KF

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas on each bank.

Even if switching characteristics of the air fuel ratio (A/F) sensor 1 are shifted, the air-fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



**CONSULT-II Reference Value in Data Monitor Mode**

GBS000KG


Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S2 (B1) HO2S2 (B2)	<ul style="list-style-type: none"> <li>● Revving engine from idle to 3,000 rpm quickly after the following conditions are met</li> </ul>	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)	<ul style="list-style-type: none"> <li>- Engine: After warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul>	LEAN ↔ RICH

**On Board Diagnosis Logic**

GBS000KH

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the air fuel ratio (A/F) sensor 1. The oxygen storage capacity before the three way catalyst (manifold) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the switching response of the sensor's voltage is faster than specified during the various driving condition such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0139 0139 (Bank 1)	Heated oxygen sensor 2 circuit slow response	It takes more time for the sensor to respond between rich and lean than the specified time.	<ul style="list-style-type: none"> <li>● Harness or connectors (The sensor circuit is open or shorted)</li> <li>● Heated oxygen sensor 2</li> <li>● Fuel pressure</li> <li>● Fuel injector</li> <li>● Intake air leaks</li> </ul>
P0159 0159 (Bank 2)			

**DTC Confirmation Procedure**

**CAUTION:**

Always drive vehicle at a safe speed.

**NOTE:**

- “COMPLETED” will appear on CONSULT-II screen when all tests “COND1”, “COND2” and “COND3” are completed.
- If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION:**

Never stop engine during this procedure. If the engine is stopped, retry this procedure from step 2 in Procedure for COND1.

**WITH CONSULT-II**

**Procedure for COND1**

For the best results, perform “DTC WORK SUPPORT” at a temperature of 0 to 30°C (32 to 86°F)

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
4. Let engine idle 1 minute.
5. Select “HO2S2 (B1) P0139” or “HO2S2 (B2) P0159” of “HO2S2” in “DTC WORK SUPPORT” mode with CONSULT-II.
6. Touch “START”.
7. Let engine idle for at least 30 seconds.
8. Rev engine up to 2,000 rpm two or three times quickly under no load.  
If “COMPLETED” appears on CONSULT-II screen, go to step 2 in Procedure for COND3.  
If “COMPLETED” does not appear on CONSULT-II screen, go to the following step.
9. When the following conditions are met, “TESTING” will be displayed at “COND1” on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 60 seconds.)

ENG SPEED	More than 1,000 rpm
B/FUEL SCHDL	More than 1.0 msec
COOLAN TEMP/S	70 - 105 °C
Shift lever	Suitable position

<table border="1"> <tr><th colspan="2">HO2S2 (B1) P0139</th></tr> <tr><td>COND1:</td><td>OUT OF CONDITION</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P0139		COND1:	OUT OF CONDITION	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	<table border="1"> <tr><th colspan="2">HO2S2 (B1) P0139</th></tr> <tr><td>COND1:</td><td>TESTING</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P0139		COND1:	TESTING	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	<table border="1"> <tr><th colspan="2">HO2S2 (B1) P0139</th></tr> <tr><td>COND1:</td><td>COMPLETED</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P0139		COND1:	COMPLETED	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec
HO2S2 (B1) P0139																																												
COND1:	OUT OF CONDITION																																											
COND2:	INCOMPLETE																																											
COND3:	INCOMPLETE																																											
MONITOR																																												
ENG SPEED	XXX rpm																																											
B/FUEL SCHDL	XXX msec																																											
HO2S2 (B1) P0139																																												
COND1:	TESTING																																											
COND2:	INCOMPLETE																																											
COND3:	INCOMPLETE																																											
MONITOR																																												
ENG SPEED	XXX rpm																																											
B/FUEL SCHDL	XXX msec																																											
HO2S2 (B1) P0139																																												
COND1:	COMPLETED																																											
COND2:	INCOMPLETE																																											
COND3:	INCOMPLETE																																											
MONITOR																																												
ENG SPEED	XXX rpm																																											
B/FUEL SCHDL	XXX msec																																											

PBIB0552E

**NOTE:**


- If “TESTING” is not displayed after 5 minutes, retry from step 2 in Procedure for COND1.
- If “COMPLETED” already appears at “COND2” on CONSULT-II screen before Procedure for COND2 is conducted, it is unnecessary to conduct step 1 in Procedure for COND2.

**Procedure for COND2**

1. While driving, release accelerator pedal completely with "OD" OFF (A/T models only) from the above condition [step 9] until "INCOMPLETE" at "COND2" on CONSULT-II screen has turned to "COMPLETED". (It will take approximately 4 seconds.)


**NOTE:**

If "COMPLETED" already appears at "COND3" on CONSULT-II screen before Procedure for COND3 is conducted, it is unnecessary to conduct step 1 in Procedure for COND3.



**Procedure for COND3**

1. Stop vehicle and let it idle until "INCOMPLETE" of "COND3" on CONSULT-II screen has turned to "COMPLETED". (It will take a maximum of approximately 6 minutes.)
2. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".  
If "NG" is displayed, refer to [EC-202, "Diagnostic Procedure"](#).  
If "CAN NOT BE DIAGNOSED" is displayed, perform the following.
  - a. Turn ignition switch OFF and leave the vehicle in a cool place (soak the vehicle).
  - b. Turn ignition switch ON and select "COOLAN TEMP/S" in "DATA MONITOR" mode with CONSULT-II.
  - c. Start engine and warm it up while monitoring "COOLAN TEMP/S" indication on CONSULT-II.
  - d. When "COOLAN TEMP/S" indication reaches to 70°C (158°F), go to step 3 in Procedure for COND 1.




**Overall Function Check**

GBS000KJ

Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a 1st trip DTC might not be confirmed.


**WITH GST**

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
4. Let engine idle for 1 minute.
5. Set voltmeter probes between ECM terminal 74 [HO2S2 (B1) signal] or 55 [HO2S2 (B2) signal] and ground.
6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.  
(Depress and release accelerator pedal as soon as possible.)  
**A change of voltage should be more than 0.06V for 1 second during this procedure.**  
**If the voltage can be confirmed in step 6, step 7 is not necessary.**
7. Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in D position with "OD" OFF (A/T), 4th gear position (M/T).  
**A change of voltage should be more than 0.06V for 1 second during this procedure.**
8. If NG, go to [EC-202, "Diagnostic Procedure"](#).




Wiring Diagram  
BANK 1

EC-O2S2B1-01



A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



# DTC P0139, P0159 HO2S2

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.


**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
25	SB	Heated oxygen sensor 2 heater (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed is below 3,600 rpm after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: after warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - 1.0V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> </ul> <b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed: Above 3,600 rpm</li> </ul>	BATTERY VOLTAGE (11 - 14V)
74	O	Heated oxygen sensor 2 (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Revving engine from idle to 3,000 rpm quickly after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: after warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - Approximately 1.0V
78	B	Sensor ground (Heated oxygen sensor 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● <b>Warm-up condition</b></li> <li>● Idle speed</li> </ul>	Approximately 0V

BANK 2

EC-O2S2B2-01



A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
6	R	Heated oxygen sensor 2 heater (Bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed is below 3,600 rpm after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: after warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - 1.0V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> </ul> <b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed: Above 3,600 rpm</li> </ul>	BATTERY VOLTAGE (11 - 14V)
55	G	Heated oxygen sensor 2 (Bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Revving engine from idle to 3,000 rpm quickly after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: after warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - Approximately 1.0V
78	B	Sensor ground (Heated oxygen sensor 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 0V

**Diagnostic Procedure**

GBS000KL

**1. CHECK GROUND CONNECTIONS**

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-145, "Ground Inspection"](#).



← : Vehicle front

- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

**OK or NG**


- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.



**2. CLEAR THE SELF-LEARNING DATA**


**🔧 With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.  
**Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected?  
 Is it difficult to start engine?**



**⊗ Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-56, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.  
**Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected?  
 Is it difficult to start engine?**




Yes or No

- Yes >> Perform trouble diagnosis for DTC P0171, P0174 or P0172, P0175. Refer to [EC-207](#) or [EC-219](#).
- No >> GO TO 3.

### 3. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect heated oxygen sensor 2 harness connector.



- |                                    |  |  |
|------------------------------------|--|--|
| 1. Heated oxygen sensor 2 (bank 2) | 2. Heated oxygen sensor 2 (bank 2) harness connector | 3. Heated oxygen sensor 2 (bank 1) harness connector |
| 4. Heated oxygen sensor 2 (bank 1) |  |  |

3. Disconnect ECM harness connector.
4. Check harness continuity between HO2S2 terminal 4 and ECM terminal 78. Refer to Wiring Diagram.

**Continuity should exist.**

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

### 4. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal and HO2S2 terminal as follows. Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0139	74	1	1
P0159	55	1	2

**Continuity should exist.**

2. Check harness continuity between the following terminals and ground. Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0139	74	1	1
P0159	55	1	2

**Continuity should not exist.**

3. Also check harness for short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**5. CHECK HEATED OXYGEN SENSOR 2**

Refer to [EC-205, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> Replace malfunctioning heated oxygen sensor 2.

**6. CHECK INTERMITTENT INCIDENT**

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

**Component Inspection  
HEATED OXYGEN SENSOR 2**

GBS000KM

Ⓟ With CONSULT-II

1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to the normal operating temperature.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
5. Let engine idle for 1 minute.
6. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II.


DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S2 (B1)	XXX V
HO2S2 (B2)	XXX V

PBIB1672E

7. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to ±25%.



"HO2S2 (B1)/(B2)" should be above 0.68V at least once when the "FUEL INJECTION" is +25%.  
 "HO2S2 (B1)/(B2)" should be below 0.18V at least once when the "FUEL INJECTION" is -25%.


**CAUTION:**

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

⊗ Without CONSULT-II

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
4. Let engine idle for 1 minute.
5. Set voltmeter probes between ECM terminal 74 [HO2S2 (B1) signal] or 55 [HO2S2 (B2) signal] and ground.
6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.  
(Depress and release accelerator pedal as soon as possible.)  
**The voltage should be above 0.68V at least once during this procedure.**  
**If the voltage is above 0.68V at step 6, step 7 is not necessary.**
7. Keep vehicle at idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in D position with "OD" OFF (A/T), 4th gear position (M/T).  
**The voltage should be below 0.18V at least once during this procedure.**
8. If NG, replace heated oxygen sensor 2.



**CAUTION:**

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

## Removal and Installation HEATED OXYGEN SENSOR 2

GBS000KN

Refer to [EM-23, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#) .

# DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION

[VQ TYPE 1]

## DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION

FFP:16600

### On Board Diagnosis Logic

GBS000KO

With the Air-Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the air fuel ratio (A/F) sensor 1. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios.

In case the amount of the compensation value is extremely large (the actual mixture ratio is too lean.), the ECM judges the condition as the fuel injection system malfunction and lights up the MIL (2 trip detection logic).

Sensor	Input signal to ECM	ECM function	Actuator
A/F sensor 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)	Fuel injection control	Fuel injector

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0171 0171 (Bank 1)	Fuel injection system too lean	<ul style="list-style-type: none"> <li>Fuel injection system does not operate properly.</li> <li>The amount of mixture ratio compensation is too large. (The mixture ratio is too lean.)</li> </ul>	<ul style="list-style-type: none"> <li>Intake air leaks</li> <li>Air fuel ratio (A/F) sensor 1</li> <li>Fuel injector</li> <li>Exhaust gas leaks</li> <li>Incorrect fuel pressure</li> <li>Lack of fuel</li> <li>Mass air flow sensor</li> <li>Incorrect PCV hose connection</li> </ul>
P0174 0174 (Bank 2)			

### DTC Confirmation Procedure

GBS000KP

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.


#### WITH CONSULT-II

- Start engine and warm it up to normal operating temperature.
- Turn ignition switch OFF and wait at least 10 seconds.
- Turn ignition switch ON and select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
- Clear the self-learning control coefficient by touching "CLEAR".
- Select "DATA MONITOR" mode with CONSULT-II.
- Start engine again and let it idle for at least 10 minutes. The 1st trip DTC P0171 or P0174 should be detected at this stage, if a malfunction exists. If so, go to [EC-213. "Diagnostic Procedure"](#).

#### NOTE:

If 1st trip DTC is not detected during above procedure, performing the following procedure is advised.

- Turn ignition switch OFF and wait at least 10 seconds.
- Start engine and drive the vehicle under the similar conditions to (1st trip) Freeze Frame Data for 10 minutes. Refer to the table below. **Hold the accelerator pedal as steady as possible.**



The similar conditions to (1st trip) Freeze Frame Data means the vehicle operation that the following conditions should be satisfied at the same time.

Engine speed	Engine speed in the freeze frame data $\pm$ 400 rpm
Vehicle speed	Vehicle speed in the freeze frame data $\pm$ 10 km/h (6 MPH)

# DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION


[VQ TYPE 1]

Engine coolant temperature (T) condition	When the freeze frame data shows lower than 70 °C (158 °F), T should be lower than 70 °C (158 °F).
	When the freeze frame data shows higher than or equal to 70 °C (158 °F), T should be higher than or equal to 70 °C (158 °F).

7. If it is difficult to start engine at step 6, the fuel injection system has a malfunction, too.
8. Crank engine while depressing accelerator pedal. If engine starts, go to [EC-213, "Diagnostic Procedure"](#). If engine does not start, check exhaust and intake air leak visually.

## WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Disconnect mass air flow sensor harness connector.
4. Restart engine and let it idle for at least 5 seconds.
5. Stop engine and reconnect mass air flow sensor harness connector.
6. Select Service \$03 with GST. Make sure DTC P0102 is detected.
7. Select Service \$04 with GST and erase the DTC P0102.
8. Start engine again and let it idle for at least 10 minutes.
9. Select Service \$07 with GST. The 1st trip DTC P0171 or P0174 should be detected at this stage, if a malfunction exists. If so, go to [EC-213, "Diagnostic Procedure"](#).



### NOTE:

If 1st trip DTC is not detected during above procedure, performing the following procedure is advised.

- a. Turn ignition switch OFF and wait at least 10 seconds.
- b. Start engine and drive the vehicle under the similar conditions to (1st trip) Freeze Frame Data for 10 minutes. Refer to the table below.

**Hold the accelerator pedal as steady as possible.**

The similar conditions to (1st trip) Freeze Frame Data means the vehicle operation that the following conditions should be satisfied at the same time.

Engine speed	Engine speed in the freeze frame data $\pm$ 400 rpm
Vehicle speed	Vehicle speed in the freeze frame data $\pm$ 10 km/h (6 MPH)
Engine coolant temperature (T) condition	When the freeze frame data shows lower than 70 °C (158 °F), T should be lower than 70 °C (158 °F).
	When the freeze frame data shows higher than or equal to 70 °C (158 °F), T should be higher than or equal to 70 °C (158 °F).

10. If it is difficult to start engine at step 8, the fuel injection system has a malfunction.
11. Crank engine while depressing accelerator pedal. If engine starts, go to [EC-213, "Diagnostic Procedure"](#). If engine does not start, check exhaust and intake air leak visually.










# DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION

[VQ TYPE 1]

GBS000KQ

## Wiring Diagram BANK 1

EC-FUELB1-01



MBWA1285E




# DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECMs transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
2	L	A/F sensor 1 heater (Bank 1)	<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	<p>Approximately 5V★</p>  <p>PBIB1584E</p>
16	SB	A/F sensor 1 (Bank 1)	<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 3.1V
35	O			Approximately 2.6V
56	LG			Approximately 2.3V
75	P			Approximately 2.3V
21 22 23	W LG SB	Fuel injector No. 5 Fuel injector No. 3 Fuel injector No. 1	<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p>SEC984C</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p>SEC985C</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)




# DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION






[VQ TYPE 1]

## BANK 2

## EC-FUELB2-01



A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M






# DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECMs transistor. Use a ground other than ECM terminals, such as the ground.**


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
24	G	A/F sensor 1 heater (Bank 2)	<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	<p>Approximately 5V★</p>  <p>PBIB1584E</p>
40 41 42	V R O	Fuel injector No. 6 Fuel injector No. 4 Fuel injector No. 2	<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p>SEC984C</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p>SEC985C</p>
57	GR	A/F sensor 1 (Bank 2)	<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 2.6V
58	O			Approximately 2.3V
76	V			Approximately 3.1V
77	Y			Approximately 2.3V

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

### 1. CHECK EXHAUST GAS LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust gas leak before three way catalyst (manifold).



#### OK or NG

- OK >> GO TO 2.
- NG >> Repair or replace.

### 2. CHECK FOR INTAKE AIR LEAK

1. Listen for an intake air leak after the mass air flow sensor.
2. Check PCV hose connection.

#### OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace.


A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION

[VQ TYPE 1]

## 3. CHECK A/F SENSOR 1 INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect corresponding A/F sensor 1 harness connector.



3. Disconnect ECM harness connector.
4. Check harness continuity between the following terminals. Refer to Wiring Diagram.

	A/F sensor 1 terminal	ECM terminal
Bank 1	1	16
	2	75
	5	35
	6	56
Bank 2	1	76
	2	77
	5	57
	6	58

**Continuity should exist.**

5. Check harness continuity between the following terminals and ground. Refer to Wiring Diagram.

Bank 1		Bank 2	
A/F sensor 1 terminal	ECM terminal	A/F sensor 1 terminal	ECM terminal
1	16	1	76
2	75	2	77
5	35	5	57
6	56	6	58

**Continuity should not exist.**

6. Also check harness for short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 4. CHECK FUEL PRESSURE

1. Release fuel pressure to zero. Refer to [EC-74, "FUEL PRESSURE RELEASE"](#) .
2. Install fuel pressure gauge and check fuel pressure. Refer to [EC-74, "FUEL PRESSURE CHECK"](#) .

**At idling: 350 kPa (3.57 kg/cm<sup>2</sup> , 51 psi)**

### OK or NG

- OK (With CONSULT-II)>>GO TO 6.  
 OK (Without CONSULT-II)>>GO TO 7.  
 NG >> GO TO 5.

## 5. DETECT MALFUNCTIONING PART

Check the following.

- Fuel pump and circuit (Refer to [EC-537, "FUEL PUMP"](#) .)
- Fuel pressure regulator (Refer to [EC-74, "FUEL PRESSURE CHECK"](#) .)
- Fuel lines
- Fuel filter for clogging

>> Repair or replace.

## 6. CHECK MASS AIR FLOW SENSOR

### Ⓟ With CONSULT-II

1. Install all removed parts.
2. Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-II.

**2.0 - 6.0 g-m/sec: at idling**  
**7.0 - 20.0 g-m/sec: at 2,500 rpm**

### OK or NG

- OK >> GO TO 8.  
 NG >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or ground. Refer to [EC-163](#) .

## 7. CHECK MASS AIR FLOW SENSOR

### Ⓢ With GST

1. Install all removed parts.
2. Check mass air flow sensor signal in Service \$01 with GST.

**2.0 - 6.0 g-m/sec: at idling**  
**7.0 - 20.0 g-m/sec: at 2,500 rpm**

### OK or NG

- OK (P0171)>>GO TO 9.  
 OK (P0174)>>GO TO 11.  
 NG >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or ground. Refer to [EC-163](#) .

## 8. CHECK FUNCTION OF FUEL INJECTOR

④ **With CONSULT-II**

1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
3. Make sure that each circuit produces a momentary engine speed drop.

ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0133E


OK or NG

- OK     >> GO TO 12.
- NG     >> Perform trouble diagnosis for FUEL INJECTOR, refer to [EC-530](#) .

## 9. CHECK FUNCTION OF FUEL INJECTOR-I

**⊗ Without CONSULT-II**


1. Stop engine.
2. Disconnect harness connector F101 (1), F7 (2).
  - ⇐ Vehicle front
3. Turn ignition switch ON.



4. Check voltage between harness connector F7 terminal 3 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

5. Turn ignition switch OFF.
6. Disconnect ECM harness connector.
7. Check harness continuity between harness connector F7 and ECM as follows.  
Refer to Wiring Diagram.



Cylinder	Harness connector F7 terminal	ECM terminal
1	2	23
3	1	22
5	4	21

**Continuity should exist.**

8. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 10.


NG >> Perform trouble diagnosis for FUEL INJECTOR, refer to [EC-530](#).

## 10. CHECK FUNCTION OF FUEL INJECTOR-II

Provide battery voltage between harness connector F101 as follows and then interrupt it. Listen to each fuel injector operating sound.

Cylinder	Harness connector F101 terminal	
	(+)	(-)
1	3	2
3	3	1
5	3	4

**Operating sound should exist.**



OK or NG

OK >> GO TO 12.

NG >> Perform trouble diagnosis for FUEL INJECTOR, refer to [EC-530](#).

## 11. CHECK FUNCTION OF FUEL INJECTOR


1. Start engine.
2. Listen to fuel injectors No.2, No.4, No.6 operating sound.

**Clicking noise should exist.**

OK or NG

OK >> GO TO 12.

NG >> Perform trouble diagnosis for FUEL INJECTOR, refer to [EC-530](#).



## 12. CHECK FUEL INJECTOR


1. Confirm that the engine is cooled down and there are no fire hazards near the vehicle.
2. Turn ignition switch OFF.
3. Disconnect all fuel injector harness connectors.
4. Remove fuel tube assembly. Refer to [EM-36, "FUEL INJECTOR AND FUEL TUBE"](#). Keep fuel hose and all fuel injectors connected to fuel tube.
5. For DTC P0171, reconnect fuel injector harness connectors on bank 1.  
For DTC P0174, reconnect fuel injector harness connectors on bank 2.
6. Disconnect all ignition coil harness connectors.
7. Prepare pans or saucers under each fuel injector.
8. Crank engine for about 3 seconds.  
For DTC P0171, make sure that fuel sprays out from fuel injectors on bank 1.  
For DTC P0174, make sure that fuel sprays out from fuel injectors on bank 2.

**Fuel should be sprayed evenly for each fuel injector.**

OK or NG

OK >> GO TO 13.

NG >> Replace fuel injectors from which fuel does not spray out. Always replace O-ring with new ones.



## 13. CHECK INTERMITTENT INCIDENT

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

>> INSPECTION END



# DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION

[VQ TYPE 1]

## DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION

PF16600

### On Board Diagnosis Logic

GBS000KS

With the Air-Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the air fuel ratio (A/F) sensor 1. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios.

In case the amount of the compensation value is extremely large (the actual mixture ratio is too rich.), the ECM judges the condition as the fuel injection system malfunction and lights up the MIL (2 trip detection logic).

Sensor	Input signal to ECM	ECM function	Actuator
A/F sensor 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)	Fuel injection control	Fuel injector

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0172 0172 (Bank 1)	Fuel injection system too rich	<ul style="list-style-type: none"> <li>Fuel injection system does not operate properly.</li> <li>The amount of mixture ratio compensation is too large. (The mixture ratio is too rich.)</li> </ul>	<ul style="list-style-type: none"> <li>Air fuel ratio (A/F) sensor 1</li> <li>Fuel injector</li> <li>Exhaust gas leaks</li> <li>Incorrect fuel pressure</li> <li>Mass air flow sensor</li> </ul>
P0175 0175 (Bank 2)			

### DTC Confirmation Procedure


GBS000KT

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### WITH CONSULT-II

- Start engine and warm it up to normal operating temperature.
- Turn ignition switch OFF and wait at least 10 seconds.
- Turn ignition switch ON and select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
- Clear the self-learning control coefficient by touching "CLEAR".
- Select "DATA MONITOR" mode with CONSULT-II.
- Start engine again and let it idle for at least 10 minutes. The 1st trip DTC P0172, P0175 should be detected at this stage, if a malfunction exists. If so, go to [EC-225, "Diagnostic Procedure"](#).



#### NOTE:

If 1st trip DTC is not detected during above procedure, performing the following procedure is advised.

- Turn ignition switch OFF and wait at least 10 seconds.
- Start engine and drive the vehicle under the similar conditions to (1st trip) Freeze Frame Data for a certain time. Refer to the table below.

**Hold the accelerator pedal as steady as possible.**

The similar conditions to (1st trip) Freeze Frame Data means the vehicle operation that the following conditions should be satisfied at the same time.

Engine speed	Engine speed in the freeze frame data $\pm$ 400 rpm
Vehicle speed	Vehicle speed in the freeze frame data $\pm$ 10 km/h (6 MPH)
Engine coolant temperature (T) condition	When the freeze frame data shows lower than 70 °C (158 °F), T should be lower than 70 °C (158 °F).
	When the freeze frame data shows higher than or equal to 70 °C (158 °F), T should be higher than or equal to 70 °C (158 °F).

- If it is difficult to start engine at step 6, the fuel injection system has a malfunction, too.


# DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION

[VQ TYPE 1]

8. Crank engine while depressing accelerator pedal.  
If engine starts, go to [EC-225, "Diagnostic Procedure"](#) . If engine does not start, remove ignition plugs and check for fouling, etc.

 **WITH GST**

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Disconnect mass air flow sensor harness connector. Then restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Select Service \$03 with GST. Make sure DTC P0102 is detected.
6. Select Service \$04 with GST and erase the DTC P0102.
7. Start engine again and let it idle for at least 10 minutes.
8. Select Service \$07 with GST. The 1st trip DTC P0172 or P0175 should be detected at this stage, if a malfunction exists. If so, go to [EC-225, "Diagnostic Procedure"](#) .



**NOTE:**

If 1st trip DTC is not detected during above procedure, performing the following procedure is advised.

- a. Turn ignition switch OFF and wait at least 10 seconds.
- b. Start engine and drive the vehicle under the similar conditions to (1st trip) Freeze Frame Data for a certain time. Refer to the table below.

**Hold the accelerator pedal as steady as possible.**

The similar conditions to (1st trip) Freeze Frame Data means the vehicle operation that the following conditions should be satisfied at the same time.

Engine speed	Engine speed in the freeze frame data $\pm$ 400 rpm
Vehicle speed	Vehicle speed in the freeze frame data $\pm$ 10 km/h (6 MPH)
Engine coolant temperature (T) condition	When the freeze frame data shows lower than 70 °C (158 °F), T should be lower than 70 °C (158 °F).
	When the freeze frame data shows higher than or equal to 70 °C (158 °F), T should be higher than or equal to 70 °C (158 °F).

9. If it is difficult to start engine at step 7, the fuel injection system has a malfunction.
10. Crank engine while depressing accelerator pedal.  
If engine starts, go to [EC-225, "Diagnostic Procedure"](#) . If engine does not start, remove ignition plugs and check for fouling, etc.









# DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION

[VQ TYPE 1]

GBS000KU

## Wiring Diagram BANK 1

EC-FUELB1-01



MBWA1285E




# DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECMs transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
2	L	A/F sensor 1 heater (Bank 1)	<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	<p>Approximately 5V★</p>  <p style="text-align: right; font-size: small;">PB1B1584E</p>
16	SB	A/F sensor 1 (Bank 1)	<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 3.1V
35	O			Approximately 2.6V
56	LG			Approximately 2.3V
75	P			Approximately 2.3V
21 22 23	W LG SB	Fuel injector No. 5 Fuel injector No. 3 Fuel injector No. 1	<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p style="text-align: right; font-size: small;">SEC984C</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p style="text-align: right; font-size: small;">SEC985C</p>


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION







[VQ TYPE 1]

## BANK 2

## EC-FUELB2-01



A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M






# DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECMs transistor. Use a ground other than ECM terminals, such as the ground.**


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
24	G	A/F sensor 1 heater (Bank 2)	<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	<p>Approximately 5V★</p>  <p>PBIB1584E</p>
40 41 42	V R O	Fuel injector No. 6 Fuel injector No. 4 Fuel injector No. 2	<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p>SEC984C</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p>SEC985C</p>
57	GR	A/F sensor 1 (Bank 2)	<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 2.6V
58	O			Approximately 2.3V
76	V			Approximately 3.1V
77	Y			Approximately 2.3V

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

### 1. CHECK EXHAUST GAS LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust gas leak before three way catalyst (manifold).



#### OK or NG

- OK >> GO TO 2.
- NG >> Repair or replace.

### 2. CHECK FOR INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

#### OK or NG


- OK >> GO TO 3.
- NG >> Repair or replace.

# DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION

[VQ TYPE 1]

## 3. CHECK A/F SENSOR 1 INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect corresponding A/F sensor 1 harness connector.



3. Disconnect ECM harness connector.
4. Check harness continuity between the following terminals. Refer to Wiring Diagram.

	A/F sensor 1 terminal	ECM terminal
Bank 1	1	16
	2	75
	5	35
	6	56
Bank 2	1	76
	2	77
	5	57
	6	58

**Continuity should exist.**

5. Check harness continuity between the following terminals and ground. Refer to Wiring Diagram.

Bank 1		Bank 2	
A/F sensor 1 terminal	ECM terminal	A/F sensor 1 terminal	ECM terminal
1	16	1	76
2	75	2	77
5	35	5	57
6	56	6	58

**Continuity should not exist.**

6. Also check harness for short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



#### 4. CHECK FUEL PRESSURE

1. Release fuel pressure to zero. Refer to [EC-74, "FUEL PRESSURE RELEASE"](#) .
2. Install fuel pressure gauge and check fuel pressure. Refer to [EC-74, "FUEL PRESSURE CHECK"](#) .

**At idling: 350 kPa (3.57 kg/cm<sup>2</sup> , 51 psi)**

OK or NG

- OK (With CONSULT-II)>>GO TO 6.  
 OK (Without CONSULT-II)>>GO TO 7.  
 NG >> GO TO 5.

#### 5. DETECT MALFUNCTIONING PART

Check the following.

- Fuel pump and circuit (Refer to, [EC-537, "FUEL PUMP"](#) .)
- Fuel pressure regulator (Refer to [EC-74, "FUEL PRESSURE CHECK"](#) .)

>> Repair or replace.

#### 6. CHECK MASS AIR FLOW SENSOR

 **With CONSULT-II**

1. Install all removed parts.
2. Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-II.

**2.0 - 6.0 g-m/sec: at idling**  
**7.0 - 20.0 g-m/sec: at 2,500 rpm**

OK or NG

- OK >> GO TO 8.  
 NG >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or ground. Refer to [EC-163](#) .

#### 7. CHECK MASS AIR FLOW SENSOR

 **With GST**

1. Install all removed parts.
2. Check mass air flow sensor signal in Service \$01 with GST.

**2.0 - 6.0 g-m/sec: at idling**  
**7.0 - 20.0 g-m/sec: at 2,500 rpm**

OK or NG

- OK (P0172)>>GO TO 9.  
 OK (P0175)>>GO TO 11.  
 NG >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or ground. Refer to [EC-163](#) .

## 8. CHECK FUNCTION OF FUEL INJECTOR

④ **With CONSULT-II**

1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
3. Make sure that each circuit produces a momentary engine speed drop.

ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0133E


OK or NG

- OK     >> GO TO 12.
- NG     >> Perform trouble diagnosis for FUEL INJECTOR, refer to [EC-530](#) .

## 9. CHECK FUNCTION OF FUEL INJECTOR-I

⊗ Without CONSULT-II


1. Stop engine.
2. Disconnect harness connector F101 (1), F7 (2).
  - ⇐ Vehicle front
3. Turn ignition switch ON.



4. Check voltage between harness connector F7 terminal 3 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

5. Turn ignition switch OFF.
6. Disconnect ECM harness connector.
7. Check harness continuity between harness connector F7 and ECM as follows.  
Refer to Wiring Diagram.



Cylinder	Harness connector F7 terminal	ECM terminal
1	2	23
3	1	22
5	4	21

**Continuity should exist.**

8. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 10.


NG >> Perform trouble diagnosis for FUEL INJECTOR, refer to [EC-530](#).

## 10. CHECK FUNCTION OF FUEL INJECTOR-II

Provide battery voltage between harness connector F101 as follows and then interrupt it. Listen to each fuel injector operating sound.

Cylinder	Harness connector F101 terminal	
	(+)	(-)
1	3	2
3	3	1
5	3	4

**Operating sound should exist.**



OK or NG

OK >> GO TO 12.

NG >> Perform trouble diagnosis for FUEL INJECTOR, refer to [EC-530](#).


## 11. CHECK FUNCTION OF FUEL INJECTOR

1. Start engine.
2. Listen to fuel injectors No.2, No.4, No.6 operating sound.

**Clicking noise should exist.**

### OK or NG

- OK >> GO TO 12.  
 NG >> Perform trouble diagnosis for FUEL INJECTOR, refer to [EC-530](#).



## 12. CHECK FUEL INJECTOR

1. Remove fuel tube assembly. Refer to [EM-36, "FUEL INJECTOR AND FUEL TUBE"](#).  
Keep fuel hose and all fuel injectors connected to fuel tube.
2. Confirm that the engine is cooled down and there are no fire hazards near the vehicle.
3. Disconnect all fuel injector harness connectors.
4. Disconnect all ignition coil harness connectors.
5. Prepare pans or saucers under each fuel injectors.
6. Crank engine for about 3 seconds.  
Make sure fuel does not drip from fuel injector.

### OK or NG

- OK (Does not drip.)>>GO TO 13.  
 NG (Drips.)>>Replace the fuel injectors from which fuel is dripping. Always replace O-ring with new one.

## 13. CHECK INTERMITTENT INCIDENT

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

>> **INSPECTION END**

DTC P0222, P0223 TP SENSOR


PFP:16119

Component Description

GBS000KW

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



CONSULT-II Reference Value in Data Monitor Mode

GBS000KX

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
THRTL SEN 1 THRTL SEN 2*	<ul style="list-style-type: none"> <li>Ignition switch: ON (Engine stopped)</li> <li>Shift lever: D (A/T), 1st (M/T)</li> </ul>	Accelerator pedal: Fully released	More than 0.36V
		Accelerator pedal: Fully depressed	Less than 4.75V

\*: Throttle position sensor 2 signal is converted by ECM internally. Thus, it differs from ECM terminal voltage signal.

On Board Diagnosis Logic

GBS000KY

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0222 0222	Throttle position sensor 1 circuit low input	An excessively low voltage from the TP sensor 1 is sent to ECM.	<ul style="list-style-type: none"> <li>Harness or connectors (The TP sensor 1 circuit is open or shorted.) (The APP sensor 2 circuit is shorted.)</li> <li>Electric throttle control actuator (TP sensor 1)</li> <li>Accelerator pedal position sensor. (APP sensor 2)</li> </ul>
P0223 0223	Throttle position sensor 1 circuit high input	An excessively high voltage from the TP sensor 1 is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, ECM enters fail-safe mode and the MIL lights up.

Engine operation condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

**DTC Confirmation Procedure**

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

**WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-235, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

**WITH GST**

Follow the procedure "WITH CONSULT-II" above.

# DTC P0222, P0223 TP SENSOR



[VQ TYPE 1]

## Wiring Diagram

GBS000L0

### EC-TPS1-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



## DTC P0222, P0223 TP SENSOR

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	W	Sensor power supply (Throttle position sensor)	<b>[Ignition switch: ON]</b>	Approximately 5V
50	W	Throttle position sensor 1	<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully released</li> </ul>	More than 0.36V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully depressed</li> </ul>	Less than 4.75V
66	B	Sensor ground (Throttle position sensor)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 0V
69	R	Throttle position sensor 2	<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully released</li> </ul>	Less than 4.75V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully depressed</li> </ul>	More than 0.36V
91	G	Sensor power supply (APP sensor 2)	<b>[Ignition switch: ON]</b>	Approximately 5V



**Diagnostic Procedure**

**1. CHECK GROUND CONNECTIONS**

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-145, "Ground Inspection"](#).



↔ : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

**2. CHECK THROTTLE POSITION SENSOR 1 POWER SUPPLY CIRCUIT-I**

1. Disconnect electric throttle control actuator harness connector.
2. Turn ignition switch ON.




3. Check voltage between electric throttle control actuator terminal 2 and ground with CONSULT-II or tester.

**Voltage: Approximately 5V**

OK or NG

- OK >> GO TO 7.  
 NG >> GO TO 3.



**3. CHECK THROTTLE POSITION SENSOR 1 POWER SUPPLY CIRCUIT-II**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between electric throttle control actuator terminal 2 and ECM terminal 47.  
Refer to Wiring Diagram.

**Continuity should exist.**

OK or NG

- OK >> GO TO 4.  
NG >> Repair open circuit.

**4. CHECK THROTTLE POSITION SENSOR 1 POWER SUPPLY CIRCUIT-III**

Check harness for short to power and short to ground, between the following terminals.

ECM terminal	Sensor terminal	Reference Wiring Diagram
47	Electric throttle control actuator terminal 2	<a href="#">EC-233</a>
91	APP sensor terminal 1	<a href="#">EC-486</a>

OK or NG

- OK >> GO TO 5.  
NG >> Repair short to ground or short to power in harness or connectors.

**5. CHECK APP SENSOR**

Refer to [EC-490, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 11.  
NG >> GO TO 6.

**6. REPLACE ACCELERATOR PEDAL ASSEMBLY**

1. Replace accelerator pedal assembly.
2. Perform [EC-71, "Accelerator Pedal Released Position Learning"](#) .
3. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
4. Perform [EC-71, "Idle Air Volume Learning"](#) .

>> **INSPECTION END**

**7. CHECK THROTTLE POSITION SENSOR 1 GROUND CIRCUIT FOR OPEN AND SHORT**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between electric throttle control actuator terminal 4 and ECM terminal 66.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.  
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**8. CHECK THROTTLE POSITION SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

1. Check harness continuity between ECM terminal 50 and electric throttle control actuator terminal 1. Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 9.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**9. CHECK THROTTLE POSITION SENSOR**

Refer to [EC-237, "Component Inspection"](#) .

OK or NG

OK >> GO TO 11.

NG >> GO TO 10.

**10. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR**

1. Replace the electric throttle control actuator.
2. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-71, "Idle Air Volume Learning"](#) .

>> INSPECTION END

**11. CHECK INTERMITTENT INCIDENT**

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


**Component Inspection  
THROTTLE POSITION SENSOR**

GBS000L2

1. Reconnect all harness connectors disconnected.
2. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
3. Turn ignition switch ON.
4. Set selector lever to D position (A/T), 1st position (M/T).
5. Check voltage between ECM terminals 50 (TP sensor 1 signal), 69 (TP sensor 2 signal) and ground under the following conditions.

Terminal	Accelerator pedal	Voltage
50 (Throttle position sensor 1)	Fully released	More than 0.36V
	Fully depressed	Less than 4.75V
69 (Throttle position sensor 2)	Fully released	Less than 4.75V
	Fully depressed	More than 0.36V

6. If NG, replace electric throttle control actuator and go to the next step.
7. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
8. Perform [EC-71, "Idle Air Volume Learning"](#) .



**Removal and Installation  
ELECTRIC THROTTLE CONTROL ACTUATOR**

GBS000L3

Refer to [EM-18, "INTAKE MANIFOLD COLLECTOR"](#) .

# DTC P0300 - P0306 MULTIPLE CYLINDER MISFIRE, NO. 1 - 6 CYLINDER MISFIRE

[VQ TYPE 1]

## DTC P0300 - P0306 MULTIPLE CYLINDER MISFIRE, NO. 1 - 6 CYLINDER MISFIRE

PFP:00000

### On Board Diagnosis Logic

GBS000L4

When a misfire occurs, engine speed will fluctuate. If the engine speed fluctuates enough to cause the crankshaft position (CKP) sensor (POS) signal to vary, ECM can determine that a misfire is occurring.

Sensor	Input Signal to ECM	ECM function
Crankshaft position sensor (POS)	Engine speed	On board diagnosis of misfire

The misfire detection logic consists of the following two conditions.

- One Trip Detection Logic (Three Way Catalyst Damage)**  
 On the first trip that a misfire condition occurs that can damage the three way catalyst (TWC) due to overheating, the MIL will blink.  
 When a misfire condition occurs, the ECM monitors the CKP sensor signal every 200 engine revolutions for a change.  
 When the misfire condition decreases to a level that will not damage the TWC, the MIL will turn off.  
 If another misfire condition occurs that can damage the TWC on a second trip, the MIL will blink.  
 When the misfire condition decreases to a level that will not damage the TWC, the MIL will remain on.  
 If another misfire condition occurs that can damage the TWC, the MIL will begin to blink again.
- Two Trip Detection Logic (Exhaust quality deterioration)**  
 For misfire conditions that will not damage the TWC (but will affect vehicle emissions), the MIL will only light when the misfire is detected on a second trip. During this condition, the ECM monitors the CKP sensor signal every 1,000 engine revolutions.  
 A misfire malfunction can be detected on any one cylinder or on multiple cylinders.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0300 0300	Multiple cylinder misfire detected	Multiple cylinder misfire.	<ul style="list-style-type: none"> <li>● Improper spark plug</li> <li>● Insufficient compression</li> <li>● Incorrect fuel pressure</li> <li>● The fuel injector circuit is open or shorted</li> <li>● Fuel injector</li> <li>● Intake air leak</li> <li>● The ignition signal circuit is open or shorted</li> <li>● Lack of fuel</li> <li>● Signal plate</li> <li>● Air fuel ratio (A/F) sensor 1</li> <li>● Incorrect PCV hose connection</li> </ul>
P0301 0301	No.1 cylinder misfire detected	No. 1 cylinder misfires.	
P0302 0302	No. 2 cylinder misfire detected	No. 2 cylinder misfires.	
P0303 0303	No. 3 cylinder misfire detected	No. 3 cylinder misfires.	
P0304 0304	No. 4 cylinder misfire detected	No. 4 cylinder misfires.	
P0305 0305	No. 5 cylinder misfire detected	No. 5 cylinder misfires.	
P0306 0306	No. 6 cylinder misfire detected	No. 6 cylinder misfires.	

### DTC Confirmation Procedure

GBS000L5

#### CAUTION:

Always drive vehicle in safe manner according to traffic conditions and obey all traffic laws when driving.

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**Ⓟ WITH CONSULT-II**

1. Turn ignition switch ON, and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to normal operating temperature.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Restart engine and let it idle for about 15 minutes.
5. If 1st trip DTC is detected, go to [EC-239, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
B/FUEL SCHDL	XXX msec
PBIB0164E	

**NOTE:**

If 1st trip DTC is not detected during above procedure, performing the following procedure is advised.

- a. Turn ignition switch OFF and wait at least 10 seconds.
- b. Start engine and drive the vehicle under the similar conditions to (1st trip) Freeze Frame Data for a certain time. Refer to the table below.

**Hold the accelerator pedal as steady as possible.**

The similar conditions to (1st trip) Freeze Frame Data means the vehicle operation that the following conditions should be satisfied at the same time.

Engine speed	Engine speed in the freeze frame data ± 400 rpm
Vehicle speed	Vehicle speed in the freeze frame data ± 10 km/h (6 MPH)
Engine coolant temperature (T) condition	When the freeze frame data shows lower than 70 °C (158 °F), T should be lower than 70 °C (158 °F).
	When the freeze frame data shows higher than or equal to 70 °C (158 °F), T should be higher than or equal to 70 °C (158 °F).

The time to driving varies according to the engine speed in the freeze frame data.

Engine speed	Time
Around 1,000 rpm	Approximately 10 minutes
Around 2,000 rpm	Approximately 5 minutes
More than 3,000 rpm	Approximately 3.5 minutes

**Ⓢ WITH GST**

Follow the procedure "WITH CONSULT-II" above.

## Diagnostic Procedure

GBS000L6

### 1. CHECK FOR INTAKE AIR LEAK AND PCV HOSE

1. Start engine and run it at idle speed.
2. Listen for the sound of the intake air leak.
3. Check PCV hose connection.

OK or NG

- OK >> GO TO 2.  
 NG >> Discover air leak location and repair.

### 2. CHECK FOR EXHAUST SYSTEM CLOGGING

Stop engine and visually check exhaust tube, three way catalyst and muffler for dents.

OK or NG

- OK (With CONSULT-II)>>GO TO 3.  
 OK (Without CONSULT-II)>>GO TO 4.  
 NG >> Repair or replace it.

## 3. PERFORM POWER BALANCE TEST

**With CONSULT-II**

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Is there any cylinder which does not produce a momentary engine speed drop?

ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0133E


Yes or No

- Yes    >> GO TO 4.  
 No     >> GO TO 10.

## 4. CHECK FUNCTION OF FUEL INJECTOR-I

**Without CONSULT-II**


1. Turn ignition switch OFF.
2. Disconnect harness connector F101 (1), F7 (2).  
 - ←: Vehicle front
3. Turn ignition switch ON.



4. Check voltage between harness connector F7 terminal 3 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

5. Turn ignition switch OFF.
6. Disconnect ECM harness connector.
7. Check harness continuity between harness connector F7 and ECM as follows.  
 Refer to Wiring Diagram.



Cylinder	Harness connector F7 terminal	ECM terminal
1	2	23
3	1	22
5	4	21

**Continuity should exist.**

8. Also check harness for short to ground and short to power.

OK or NG


- OK     >> GO TO 5.  
 NG     >> Perform trouble diagnosis for FUEL INJECTOR, refer to [EC-530](#) .

### 5. CHECK FUNCTION OF FUEL INJECTOR-II

Provide battery voltage between harness connector F101 as follows and then interrupt it. Listen to each fuel injector operating sound.

Cylinder	Harness connector F101 terminal	
	(+)	(-)
1	3	2
3	3	1
5	3	4

**Operating sound should exist.**



OK or NG

OK >> GO TO 6.

NG >> Perform trouble diagnosis for FUEL INJECTOR, refer to [EC-530](#).

### 6. CHECK FUNCTION OF FUEL INJECTOR-III


1. Reconnect all harness connector disconnected.
2. Start engine.
3. Listen to fuel injectors No. 2, No. 4, No.6 operating sound.

**Clicking noise should exist.**

OK or NG

OK >> GO TO 7.

NG >> Perform trouble diagnosis for FUEL INJECTOR, refer to [EC-530](#).



## 7. CHECK FUNCTION OF IGNITION COIL-I

**CAUTION:**

Do the following procedure in the place where ventilation is good without the combustible.

1. Turn ignition switch OFF.
2. Remove fuel pump fuse in IPDM E/R to release fuel pressure.

**NOTE:**

Do not use CONSULT-II to release fuel pressure, or fuel pressure applies again during the following procedure.

3. Start engine.
4. After engine stalls, crank it two or three times to release all fuel pressure.
5. Turn ignition switch OFF.
6. Remove all ignition coil harness connectors to avoid the electrical discharge from the ignition coils.
7. Remove ignition coil and spark plug of the cylinder to be checked.
8. Crank engine for five seconds or more to remove combustion gas in the cylinder.
9. Connect spark plug and harness connector to ignition coil.
10. Fix ignition coil using a rope etc. with gap of 13 - 17 mm between the edge of the spark plug and grounded metal portion as shown in the figure.
11. Crank engine for about three seconds, and check whether spark is generated between the spark plug and the grounded metal portion.

**Spark should be generated.**

**CAUTION:**

- Do not approach to the spark plug and the ignition coil within 50cm. Be careful not to get an electrical shock while checking, because the electrical discharge voltage becomes 20kV or more.



- It might cause to damage the ignition coil if the gap of more than 17 mm is taken.

**NOTE:**

When the gap is less than 13 mm, the spark might be generated even if the coil is malfunctioning.

OK or NG

- OK >> GO TO 11.  
 NG >> GO TO 8.



## 8. CHECK FUNCTION OF IGNITION COIL-II

1. Turn ignition switch OFF.
2. Disconnect spark plug and connect a known-good spark plug.
3. Crank engine for about three seconds, and recheck whether spark is generated between the spark plug and the grounded metal portion.

**Spark should be generated.**

OK or NG

- OK >> GO TO 9.  
 NG >> Check ignition coil, power transistor and their circuits. Refer to [EC-543, "IGNITION SIGNAL"](#).




## 9. CHECK SPARK PLUG

Check the initial spark plug for fouling, etc.

OK or NG

- OK >> Replace spark plug(s) with standard type one(s). For spark plug type, refer to [MA-23, "Changing Spark Plugs \(Platinum-Tipped Type\)"](#).
- NG >> 1. Repair or clean spark plug.  
2. GO TO 10.



## 10. CHECK FUNCTION OF IGNITION COIL-III

1. Reconnect the initial spark plugs.
2. Crank engine for about 3 seconds, and recheck whether spark is generated between the spark plug and the grounded portion.

**Spark should be generated.**

OK or NG

- OK >> **INSPECTION END**
- NG >> Replace spark plug(s) with standard type one(s). For spark plug type, refer to [MA-23, "Changing Spark Plugs \(Platinum-Tipped Type\)"](#).

## 11. CHECK COMPRESSION PRESSURE

Check compression pressure. Refer to [EM-91, "CHECKING COMPRESSION PRESSURE"](#).

OK or NG

- OK >> GO TO 12.
- NG >> Check pistons, piston rings, valves, valve seats and cylinder head gaskets.

## 12. CHECK FUEL PRESSURE

1. Install all removed parts.
2. Release fuel pressure to zero. Refer to [EC-74, "FUEL PRESSURE RELEASE"](#).
3. Install fuel pressure gauge and check fuel pressure. Refer to [EC-74, "FUEL PRESSURE CHECK"](#).

**At idle: Approx. 350 kPa (3.57 kg/cm<sup>2</sup> , 51 psi)**

OK or NG

- OK >> GO TO 14.
- NG >> GO TO 13.

## 13. DETECT MALFUNCTIONING PART

Check the following.

- Fuel pump and circuit (Refer to [EC-537, "FUEL PUMP"](#) .)
- Fuel pressure regulator (Refer to [EC-74, "FUEL PRESSURE CHECK"](#) .)
- Fuel lines
- Fuel filter for clogging

>> Repair or replace.

---

## 14. CHECK IGNITION TIMING

---

Check the following items. Refer to [EC-65, "Basic Inspection"](#) .

Items	Specifications
Target idle speed	A/T: $625 \pm 50$ rpm (in P or N position) M/T: $625 \pm 50$ rpm (in Neutral position)
Ignition timing	A/T: $15 \pm 5^\circ$ BTDC (in P or N position) M/T: $15 \pm 5^\circ$ BTDC (in Neutral position)


### OK or NG

OK >> GO TO 15.

NG >> Follow the [EC-65, "Basic Inspection"](#) .

## 15. CHECK A/F SENSOR 1 INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect A/F sensor 1 harness connector.



3. Disconnect ECM harness connector.
4. Check harness continuity between the following terminals. Refer to Wiring Diagram.

	A/F sensor 1 terminal	ECM terminal
Bank 1	1	16
	2	75
	5	35
	6	56
Bank 2	1	76
	2	77
	5	57
	6	58

**Continuity should exist.**

5. Check harness continuity between the following terminals and ground. Refer to Wiring Diagram.

Bank 1		Bank 2	
A/F sensor 1 terminal	ECM terminal	A/F sensor 1 terminal	ECM terminal
1	16	1	76
2	75	2	77
5	35	5	57
6	56	6	58

**Continuity should not exist.**

6. Also check harness for short to power.

**OK or NG**

OK >> GO TO 16.

NG >> Repair open circuit or short to ground or short to power in harness or connectors between ECM and A/F sensor 1.

## 16. CHECK A/F SENSOR 1 HEATER

Refer to [EC-298, "Component Inspection"](#) .

**OK or NG**

OK >> GO TO 18.

NG >> GO TO 17.

---

## 17. REPLACE AIR FUEL RATIO (A/F) SENSOR 1

---

Replace air fuel ratio (A/F) sensor 1.

**CAUTION:**

- Discard any air fuel ratio (A/F) sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new air fuel ratio (A/F) sensor, clean exhaust system threads using Heated Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

>> INSPECTION END

---

## 18. CHECK MASS AIR FLOW SENSOR

---

 **With CONSULT-II**

Check mass air flow sensor signal in "DATA MONITOR" mode with CONSULT-II.

**2.0 - 6.0 g-m/sec: at idling**  
**7.0 - 20.0 g-m/sec: at 2,500 rpm**

 **With GST**

Check mass air flow sensor signal in Service \$01 with GST.

**2.0 - 6.0 g-m/sec: at idling**  
**7.0 - 20.0 g-m/sec: at 2,500 rpm**

OK or NG

OK >> GO TO 19.

NG >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or ground. Refer to [EC-163](#) .

---

## 19. CHECK SYMPTOM MATRIX CHART

---

Check items on the rough idle symptom in [EC-85, "Symptom Matrix Chart"](#) .

OK or NG

OK >> GO TO 20.

NG >> Repair or replace.

---

## 20. ERASE THE 1ST TRIP DTC

---

Some tests may cause a 1st trip DTC to be set.

Erase the 1st trip DTC from the ECM memory after performing the tests. Refer to [EC-56, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#) .

>> GO TO 21.

---

## 21. CHECK INTERMITTENT INCIDENT

---

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

**DTC P0327, P0328, P0332, P0333 KS**


PFP:22060

**Component Description**

GBS000L7

The knock sensor (1) is attached to the cylinder block. It senses engine knocking using a piezoelectric element. A knocking vibration from the cylinder block is sensed as vibrational pressure. This pressure is converted into a voltage signal and sent to the ECM.

- ↶: Vehicle front



GBS000L8

**On Board Diagnosis Logic**

The MIL will not light up for these diagnoses.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0327 0327 (bank 1)	Knock sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> <li>• Harness or connectors (The sensor circuit is open or shorted.)</li> <li>• Knock sensor</li> </ul>
P0332 0332 (bank 2)			
P0328 0328 (bank 1)	Knock sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	
P0333 0333 (bank 2)			

**DTC Confirmation Procedure**

GBS000L9

**NOTE:**


If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

**WITH CONSULT-II**

1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and run it for at least 5 seconds at idle speed.
3. If 1st trip DTC is detected, go to [EC-249, "Diagnostic Procedure"](#)






**WITH GST**

Follow the procedure "WITH CONSULT-II" above.

EC-KS-01

Wiring Diagram



Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
15	W	Knock sensor (Bank 1)	[Engine is running] ● Idle speed	Approximately 2.5V
36	W	Knock sensor (Bank 2)		

**Diagnostic Procedure**

GBS000LB

**1. CHECK KNOCK SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT-I**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check resistance between ECM terminals 15, 36 and ground. Refer to Wiring Diagram.

**NOTE:**

It is necessary to use an ohmmeter which can measure more than 10 MΩ.

**Resistance: Approximately 532 - 588 kΩ [at 20°C (68°F)]**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 2.

**2. CHECK KNOCK SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT-II**


1. Disconnect knock sensor (1) harness connector.
  - ← Vehicle front
2. Check harness continuity between ECM terminal 15 and knock sensor (bank1) terminal 1, ECM terminal 36 and knock sensor (bank 2) terminal 1. Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



**3. DETECT MALFUNCTIONING PART**

Check the following.

- Harness connectors F29, F151
- Harness for open or short between ECM and knock sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

**4. CHECK KNOCK SENSOR**


Refer to [EC-251, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 5.
- NG >> Replace knock sensor.

## 5. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body.  
Refer to [EC-145, "Ground Inspection"](#).



← : Vehicle front

- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

### OK or NG

- OK >> GO TO 6.  
NG >> Repair or replace ground connections.

## 6. CHECK KNOCK SENSOR SHIELD CIRCUIT FOR OPEN AND SHORT

1. Disconnect knock sensor harness connector.
2. Check harness continuity between knock sensor terminal 2 and ground. Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check for short to power.

### OK or NG

- OK >> GO TO 8.  
NG >> GO TO 7.

## 7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F29, F151
- Harness connectors F2, E8
- Harness for open or short between knock sensor and ground

>> Repair open circuit or short power in harness or connectors.

## 8. CHECK INTERMITTENT INCIDENT

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

>> INSPECTION END



## Component Inspection

### KNOCK SENSOR

Check resistance between knock sensor terminal 1 and ground.


#### NOTE:

It is necessary to use an ohmmeter which can measure more than 10 M $\Omega$ .

**Resistance: Approximately 532 - 588 k $\Omega$  [at 20°C (68°F)]**

#### CAUTION:

Do not use any knock sensors that have been dropped or physically damaged. Use only new ones.



## Removal and Installation

### KNOCK SENSOR

Refer to [EM-107, "CYLINDER BLOCK"](#) .

## DTC P0335 CKP SENSOR (POS)

PFP:23731

### Component Description

GBS000LE

The crankshaft position sensor (POS) is located on the oil pan facing the gear teeth (cogs) of the signal plate. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet and Hall IC.



When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.

ECM receives the signals as shown in the figure.



### CONSULT-II Reference Value in Data Monitor Mode

GBS000LF

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
ENG SPEED	<ul style="list-style-type: none"> <li>Run engine and compare CONSULT-II value with the tachometer indication.</li> </ul>	Almost the same speed as the tachometer indication.

### On Board Diagnosis Logic

GBS000LG

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0335 0335	Crankshaft position sensor (POS) circuit	<ul style="list-style-type: none"> <li>The crankshaft position sensor (POS) signal is not detected by the ECM during the first few seconds of engine cranking.</li> <li>The proper pulse signal from the crankshaft position sensor (POS) is not sent to ECM while the engine is running.</li> <li>The crankshaft position sensor (POS) signal is not in the normal pattern during engine running.</li> </ul>	<ul style="list-style-type: none"> <li>Harness or connectors (The sensor circuit is open or shorted)</li> <li>Crankshaft position sensor (POS)</li> <li>Signal plate</li> </ul>

## DTC Confirmation Procedure

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V with ignition switch ON.

### ④ WITH CONSULT-II

1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
2. Crank engine for at least 2 seconds and run it for at least 5 seconds at idle speed.
3. If 1st trip DTC is detected, go to [EC-256, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEP058Y

### ④ WITH GST

Follow the procedure "WITH CONSULT-II" above.

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# DTC P0335 CKP SENSOR (POS)







[VQ TYPE 1]

GBS000LI

## Wiring Diagram

EC-POS-01

— : DETECTABLE LINE FOR DTC  
 - - - : NON-DETECTABLE LINE FOR DTC



MBWA1290E



# DTC P0335 CKP SENSOR (POS)

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
13	G	Crankshaft position sensor (POS)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <b>NOTE:</b> The pulse cycle changes depending on rpm at idle	Approximately 10V★  PBIB1041E
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed: 2,000 rpm</li> </ul>	Approximately 10V★  PBIB1042E
111	BR	ECM relay (Self shut-off)	<b>[Engine is running]</b> <b>[Ignition switch: OFF]</b> <ul style="list-style-type: none"> <li>● For a few seconds after turning ignition switch OFF</li> </ul>	0 - 1.5V
			<b>[Ignition switch: OFF]</b> <ul style="list-style-type: none"> <li>● More than a few seconds after turning ignition switch OFF</li> </ul>	BATTERY VOLTAGE (11 - 14V)
119 120	R P	Power supply for ECM	<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-145, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

### 2. CHECK CRANKSHAFT POSITION (CKP) SENSOR (POS) POWER SUPPLY CIRCUIT

1. Disconnect crankshaft position (CKP) sensor (POS) harness connector.
2. Turn ignition switch ON.




3. Check voltage between CKP sensor (POS) terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

#### OK or NG

- OK >> GO TO 4.  
 NG >> GO TO 3.



### 3. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors F4, E9
- Harness for open or short between crankshaft position sensor (POS) and ECM
- Harness for open or short between crankshaft position sensor (POS) and IPDM E/R

>> Repair open circuit or short to ground or short to power in harness or connectors.

### 4. CHECK CKP SENSOR (POS) GROUND CIRCUIT FOR OPEN AND SHORT

---

1. Turn ignition switch OFF.
2. Check harness continuity between CKP sensor (POS) terminal 3 and ground. Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.

### 5. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors F4, E9
- Harness for open or short between crankshaft position sensor (POS) and ground

>> Repair open circuit or short to power in harness or connectors.

### 6. CHECK CKP SENSOR (POS) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 13 and CKP sensor (POS) terminal 2. Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

### 7. CHECK CRANKSHAFT POSITION SENSOR (POS)

---

Refer to [EC-258, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 8.
- NG >> Replace crankshaft position sensor (POS).

### 8. CHECK GEAR TOOTH

---

Visually check for chipping signal plate gear tooth.

OK or NG

- OK >> GO TO 9.
- NG >> Replace the signal plate.

**9. CHECK INTERMITTENT INCIDENT**


Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

**Component Inspection  
CRANKSHAFT POSITION SENSOR (POS)**

GBS000LK


1. Loosen the fixing bolt of the sensor.
2. Disconnect crankshaft position sensor (POS) harness connector.
3. Remove the sensor.
4. Visually check the sensor for chipping.



PBIB0563E

5. Check resistance as shown in the figure.

Terminal No. (Polarity)	Resistance $\Omega$ [at 25°C (77°F)]
1 (+) - 2 (-)	Except 0 or $\infty$
1 (+) - 3 (-)	
2 (+) - 3 (-)	



PBIB0564E

**Removal and Installation  
CRANKSHAFT POSITION SENSOR (POS)**

GBS000LL

Refer to [EM-28, "OIL PAN AND OIL STRAINER"](#) .



DTC P0340, P0345 CMP SENSOR (PHASE)

PFP:23731

Component Description

GBS000LM

The camshaft position sensor (PHASE) senses the retraction of intake valve camshaft to identify a particular cylinder. The camshaft position sensor (PHASE) senses the piston position.

When the crankshaft position sensor (POS) system becomes inoperative, the camshaft position sensor (PHASE) provides various controls of engine parts instead, utilizing timing of cylinder identification signals.


The sensor consists of a permanent magnet and Hall IC.

When engine is running, the high and low parts of the teeth cause the gap with the sensor to change.


The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

ECM receives the signals as shown in the figure.



PBIB0562E



PBIB2744E

CONSULT-II Reference Value in Data Monitor Mode

GBS000LN

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
ENG SPEED	<ul style="list-style-type: none"> <li>Run engine and compare CONSULT-II value with the tachometer indication.</li> </ul>	Almost the same speed as the tachometer indication.

On Board Diagnosis Logic

GBS000LO

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0340 0340 (Bank 1)	Camshaft position sensor (PHASE) circuit	<ul style="list-style-type: none"> <li>The cylinder No. signal is not sent to ECM for the first few seconds during engine cranking.</li> </ul>	<ul style="list-style-type: none"> <li>Harness or connectors (The sensor circuit is open or shorted)</li> <li>Camshaft position sensor (PHASE)</li> </ul>
P0345 0345 (Bank 2)		<ul style="list-style-type: none"> <li>The cylinder No. signal is not sent to ECM during engine running.</li> <li>The cylinder No. signal is not in the normal pattern during engine running.</li> </ul>	<ul style="list-style-type: none"> <li>Camshaft (Intake)</li> <li>Starter motor (Refer to SC-30.)</li> <li>Starting system circuit (Refer to SC-30.)</li> <li>Dead (Weak) battery</li> </ul>

**DTC Confirmation Procedure****NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION:**

**Before performing the following procedure, confirm that battery voltage is more than 10.5V with ignition switch ON.**

**CONSULT-II WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Crank engine for at least 2 seconds and run it for at least 5 seconds at idle speed.
4. If 1st trip DTC is detected, go to [EC-264, "Diagnostic Procedure"](#).  
If 1st trip DTC is not detected, go to next step.
5. Maintaining engine speed at more than 800 rpm for at least 5 seconds.
6. If 1st trip DTC is detected, go to [EC-264, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

**CONSULT WITH GST**

Follow the procedure "WITH CONSULT-II" above.

# DTC P0340, P0345 CMP SENSOR (PHASE)



[VQ TYPE 1]

GBS000LQ

## Wiring Diagram BANK 1

EC-PHSB1-01

— : DETECTABLE LINE FOR DTC  
— : NON-DETECTABLE LINE FOR DTC



MBWA1291E



# DTC P0340, P0345 CMP SENSOR (PHASE)

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
33	L	Camshaft position sensor (PHASE) (Bank 1)	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	<p>1.0 - 4.0V★</p>  <p style="text-align: right;">PBIB1039E</p>
			<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>1.0 - 4.0V★</p>  <p style="text-align: right;">PBIB1040E</p>
111	BR	ECM relay (Self shut-off)	<p><b>[Engine is running]</b> <b>[Ignition switch: OFF]</b></p> <ul style="list-style-type: none"> <li>● For a few seconds after turning ignition switch OFF</li> </ul>	0 - 1.5V
			<p><b>[Ignition switch: OFF]</b></p> <ul style="list-style-type: none"> <li>● More than a few seconds after turning ignition switch OFF</li> </ul>	BATTERY VOLTAGE (11 - 14V)
119 120	R P	Power supply for ECM	<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)



★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# DTC P0340, P0345 CMP SENSOR (PHASE)

[VQ TYPE 1]

## BANK 2

EC-PHSB2-01



MBWA1292E



# DTC P0340, P0345 CMP SENSOR (PHASE)

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
14	Y	Camshaft position sensor (PHASE) (Bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <b>NOTE:</b> The pulse cycle changes depending on rpm at idle	1.0 - 4.0V★  <small>PBIB1039E</small>
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed: 2,000 rpm</li> </ul>	1.0 - 4.0V★  <small>PBIB1040E</small>
111	BR	ECM relay (Self shut-off)	<b>[Engine is running]</b> <b>[Ignition switch: OFF]</b> <ul style="list-style-type: none"> <li>● For a few seconds after turning ignition switch OFF</li> </ul>	0 - 1.5V
			<b>[Ignition switch: OFF]</b> <ul style="list-style-type: none"> <li>● More than a few seconds after turning ignition switch OFF</li> </ul>	BATTERY VOLTAGE (11 - 14V)
119 120	R P	Power supply for ECM	<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

GBS000LR

### 1. CHECK STARTING SYSTEM

Turn ignition switch to START position.

**Does the engine turn over?**

**Does the starter motor operate?**


Yes or No

Yes >> GO TO 2.

No >> Check starting system. (Refer to [SC-30, "STARTING SYSTEM"](#) .)

## 2. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-145, "Ground Inspection"](#).



↶ : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

### OK or NG

- OK >> GO TO 3.  
 NG >> Repair or replace ground connections.

## 3. CHECK CAMSHAFT POSITION (CMP) SENSOR (PHASE) POWER SUPPLY CIRCUIT

1. Disconnect camshaft position (CMP) sensor (PHASE) harness connector.
2. Turn ignition switch ON.




3. Check voltage between CMP sensor (PHASE) terminal 3 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

### OK or NG

- OK >> GO TO 5.  
 NG >> GO TO 4.



---

## 4. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors E9, F4
- Harness for open or short between camshaft position sensor (PHASE) and ECM
- Harness for open or short between camshaft position sensor (PHASE) and IPDM E/R

>> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 5. CHECK CMP SENSOR (PHASE) GROUND CIRCUIT FOR OPEN AND SHORT

---

1. Turn ignition switch OFF.
2. Check harness continuity between CMP sensor (PHASE) terminal 1 and ground.

**Continuity should exist.**

3. Also check harness for short to power.

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.

---

## 6. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors F4, E9
- Harness for open or short between CMP sensor (PHASE) and ground

>> Repair open circuit or short to power in harness or connectors.

---

## 7. CHECK CMP SENSOR (PHASE) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 33 (bank 1) or 14 (bank 2) and CMP sensor (PHASE) terminal 2.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 8.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 8. CHECK CAMSHAFT POSITION SENSOR (PHASE)

---

Refer to [EC-267, "Component Inspection"](#).

OK or NG

OK >> GO TO 9.

NG >> Replace camshaft position sensor (PHASE).




**9. CHECK CAMSHAFT (INTAKE)**

Check the following.

- Accumulation of debris to the signal plate of camshaft rear end
- Chipping signal plate of camshaft rear end

OK or NG

- OK >> GO TO 10.
- NG >> Remove debris and clean the signal plate of camshaft rear end or replace camshaft.



**10. CHECK INTERMITTENT INCIDENT**


Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

**Component Inspection  
CAMSHAFT POSITION SENSOR (PHASE)**


GBS000LS

1. Loosen the fixing bolt of the sensor.
2. Disconnect camshaft position sensor (PHASE) harness connector.
3. Remove the sensor.
4. Visually check the sensor for chipping.



5. Check resistance as shown in the figure.

Terminal No. (Polarity)	Resistance $\Omega$ [at 25°C (77°F)]
1 (+) - 2 (-)	Except 0 or $\infty$
1 (+) - 3 (-)	
2 (+) - 3 (-)	



**Removal and Installation  
CAMSHAFT POSITION SENSOR (PHASE)**

GBS000LT

Refer to [EM-73, "CAMSHAFT"](#) .

# DTC P0420, P0430 THREE WAY CATALYST FUNCTION

[VQ TYPE 1]

## DTC P0420, P0430 THREE WAY CATALYST FUNCTION

PF20905


### On Board Diagnosis Logic

GBS000LU

The ECM monitors the switching frequency ratio of air fuel ratio (A/F) sensor 1 and heated oxygen sensor 2.

A three way catalyst (manifold) with high oxygen storage capacity will indicate a low switching frequency of heated oxygen sensor 2. As oxygen storage capacity decreases, the heated oxygen sensor 2 switching frequency will increase.

When the frequency ratio of air fuel ratio (A/F) sensor 1 and heated oxygen sensor 2 approaches a specified limit value, the three way catalyst (manifold) malfunction is diagnosed.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0420 0420 (Bank 1)	Catalyst system efficiency below threshold	<ul style="list-style-type: none"> <li>● Three way catalyst (manifold) does not operate properly.</li> <li>● Three way catalyst (manifold) does not have enough oxygen storage capacity.</li> </ul>	<ul style="list-style-type: none"> <li>● Three way catalyst (manifold)</li> <li>● Exhaust tube</li> <li>● Intake air leaks</li> <li>● Fuel injector</li> <li>● Fuel injector leaks</li> <li>● Spark plug</li> <li>● Improper ignition timing</li> </ul>
P0430 0430 (Bank 2)			

### DTC Confirmation Procedure

GBS000LV

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### Ⓜ WITH CONSULT-II

#### TESTING CONDITION:

**Do not hold engine speed for more than the specified minutes below.**

1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to the normal operating temperature.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
5. Let engine idle for 1 minute.
6. Make sure that "COOLAN TEMP/S" indicates more than 70°C (158°F).  
If not, warm up engine and go to next step when "COOLAN TEMP/S" indication reaches to 70°C (158°F).
7. Open engine hood.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
B/FUEL SCHDL	XXX msec

SEF189Y

# DTC P0420, P0430 THREE WAY CATALYST FUNCTION

[VQ TYPE 1]

8. Select "DTC & SRT CONFIRMATION" then "SRT WORK SUPPORT" mode with CONSULT-II.
9. Rev engine up to 2,000 to 3,000 rpm and hold it for 3 consecutive minutes then release the accelerator pedal completely. If "INCMP" of "CATALYST" changed to "CMPLT", go to step 12.
10. Wait 5 seconds at idle.

SRT WORK SUPPORT	
CATALYST	INCMP
HO2S HTR	CMPLT
HO2S	INCMP
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec

PBIB0566E

11. Rev engine up to 2,000 to 3,000 rpm and maintain it until "INCMP" of "CATALYST" changes to "CMPLT" (It will take approximately 5 minutes). If not "CMPLT", stop engine and cool it down to less than 70°C (158°F) and then retest from step 1.

SRT WORK SUPPORT	
CATALYST	CMPLT
HO2S HTR	CMPLT
HO2S	INCMP
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec

PBIB0567E

12. Select "SELF-DIAG RESULTS" mode with CONSULT-II.
13. Confirm that the 1st trip DTC is not detected. If the 1st trip DTC is detected, go to [EC-270, "Diagnostic Procedure"](#).

SELF DIAG RESULTS	
DTC RESULTS	TIME
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	

SEF535Z

## Overall Function Check

GBS000LW


Use this procedure to check the overall function of the three way catalyst (manifold). During this check, a 1st trip DTC might not be confirmed.

### WITH GST

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
4. Let engine idle for 1 minute.
5. Open engine hood.
6. Set voltmeter probe between ECM terminals 74 [HO2S2 (bank 1) signal], 55 [HO2S2 (bank 2) signal] and ground.
7. Keep engine speed at 2,500 rpm constant under no load.
8. Make sure that the voltage does not vary for more than 5 seconds.

If the voltage fluctuation cycle takes less than 5 seconds, go to [EC-270, "Diagnostic Procedure"](#).

- 1 cycle: 0.6 - 1.0 → 0 - 0.3 → 0.6 - 1.0



## Diagnostic Procedure

### 1. CHECK EXHAUST SYSTEM

Visually check exhaust tubes and muffler for dent.


OK or NG

OK >> GO TO 2.

NG >> Repair or replace.

### 2. CHECK EXHAUST GAS LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust gas leak before the three way catalyst (manifold).



OK or NG

OK >> GO TO 3.

NG >> Repair or replace.

### 3. CHECK INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

OK or NG

OK >> GO TO 4.

NG >> Repair or replace.

### 4. CHECK IGNITION TIMING

Check the following items. Refer to [EC-65, "Basic Inspection"](#) .

Items	Specifications
Target idle speed	A/T: 625 ± 50 rpm (in P or N position) M/T: 625 ± 50 rpm (in Neutral position)
Ignition timing	A/T: 15 ± 5° BTDC (in P or N position) M/T: 15 ± 5° BTDC (in Neutral position)

OK or NG

OK >> GO TO 5.

NG >> Follow the [EC-65, "Basic Inspection"](#) .

## 5. CHECK FUEL INJECTOR


1. Stop engine and then turn ignition switch ON.
2. Check voltage between ECM terminals 21, 22, 23, 40, 41, 42 and ground with CONSULT-II or tester.  
Refer to Wiring Diagram for fuel injectors, [EC-531](#).

**Voltage: Battery voltage**

OK or NG

OK >> GO TO 6.

NG >> Perform [EC-532, "Diagnostic Procedure"](#).



## 6. CHECK FUNCTION OF IGNITION COIL-I

### CAUTION:

Do the following procedure in the place where ventilation is good without the combustible.

1. Turn ignition switch OFF.
2. Remove fuel pump fuse in IPDM E/R to release fuel pressure.

### NOTE:

Do not use CONSULT-II to release fuel pressure, or fuel pressure applies again during the following procedure.

3. Start engine.
4. After engine stalls, crank it two or three times to release all fuel pressure.
5. Turn ignition switch OFF.
6. Remove all ignition coil harness connectors to avoid the electrical discharge from the ignition coils.
7. Remove ignition coil and spark plug of the cylinder to be checked.
8. Crank engine for five seconds or more to remove combustion gas in the cylinder.
9. Connect spark plug and harness connector to ignition coil.
10. Fix ignition coil using a rope etc. with gap of 13 - 17 mm between the edge of the spark plug and grounded metal portion as shown in the figure.
11. Crank engine for about three seconds, and check whether spark is generated between the spark plug and the grounded metal portion.

**Spark should be generated.**

### CAUTION:

- Do not approach to the spark plug and the ignition coil within 50cm. Be careful not to get an electrical shock while checking, because the electrical discharge voltage becomes 20kV or more.

- It might cause to damage the ignition coil if the gap of more than 17 mm is taken.



### NOTE:

When the gap is less than 13 mm, the spark might be generated even if the coil is malfunctioning.

OK or NG

OK >> GO TO 10.

NG >> GO TO 7.



## 7. CHECK FUNCTION OF IGNITION COIL-II

1. Turn ignition switch OFF.
2. Disconnect spark plug and connect a known-good spark plug.
3. Crank engine for about 3 seconds, and recheck whether spark is generated between the spark plug and the grounded metal portion.

**Spark should be generated.**

### OK or NG

OK >> GO TO 8.

NG >> Check ignition coil, power transistor and their circuits. Refer to [EC-543, "IGNITION SIGNAL"](#) .


## 8. CHECK SPARK PLUG

Check the initial spark plug for fouling, etc.

### OK or NG

OK >> Replace spark plug(s) with standard type one(s). For spark plug type, refer to [MA-23, "Changing Spark Plugs \(Platinum-Tipped Type\)"](#) .

NG >> 1. Repair or clean spark plug.  
2. GO TO 9.



## 9. CHECK FUNCTION OF IGNITION COIL-III

1. Reconnect the initial spark plugs.
2. Crank engine for about three seconds, and recheck whether spark is generated between the spark plug and the grounded portion.

**Spark should be generated.**

### OK or NG

OK >> **INSPECTION END**

NG >> Replace spark plug(s) with standard type one(s). For spark plug type, refer to [MA-23, "Changing Spark Plugs \(Platinum-Tipped Type\)"](#) .

## 10. CHECK FUEL INJECTOR

1. Turn ignition switch OFF.
2. Remove fuel tube assembly.  
Refer to [EM-36, "FUEL INJECTOR AND FUEL TUBE"](#) .  
Keep fuel hose and all fuel injectors connected to fuel tube.
3. Reconnect all fuel injector harness connectors.
4. Disconnect all ignition coil harness connectors.
5. Turn ignition switch ON.  
Make sure fuel does not drip from fuel injector.

### OK or NG

OK (Does not drip.)>>GO TO 11.

NG (Drips.)>>Replace the fuel injector(s) from which fuel is dripping.

---

**11. CHECK INTERMITTENT INCIDENT**

---

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

Trouble is fixed.>>**INSPECTION END**

Trouble is not fixed.>>Replace three way catalyst (manifold).

A

EC

C

D

E

F

G

H

I

J

K

L

M

# DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[VQ TYPE 1]

## DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

PFP:14920

### Description SYSTEM DESCRIPTION

GBS000LY

Sensor	Input signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed* <sup>1</sup>	EVAP canister purge flow control	EVAP canister purge vol- ume control solenoid valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Battery	Battery voltage* <sup>1</sup>		
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Accelerator pedal position		
Air fuel ratio (A/F) sensor 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)		
Fuel tank temperature sensor	Fuel temperature in fuel tank		
Wheel sensor	Vehicle speed* <sup>2</sup>		


\*1: ECM determines the start signal status by the signals of engine speed and battery voltage.

\*2: This signal is sent to the ECM through CAN communication line.

This system controls flow rate of fuel vapor from the EVAP canister. The opening of the vapor by-pass passage in the EVAP canister purge volume control solenoid valve changes to control the flow rate. The EVAP canister purge volume control solenoid valve repeats ON/OFF operation according to the signal sent from the ECM. The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions. When the engine is operating, the flow rate of fuel vapor from the EVAP canister is regulated as the air flow changes.

### COMPONENT DESCRIPTION

The EVAP canister purge volume control solenoid valve uses a ON/OFF duty to control the flow rate of fuel vapor from the EVAP canister. The EVAP canister purge volume control solenoid valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of fuel vapor that will flow through the valve.



### CONSULT-II Reference Value in Data Monitor Mode

GBS000LZ

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
PURG VOL C/V	<ul style="list-style-type: none"> <li>Engine: After warming up</li> <li>Shift lever: P or N (A/T), Neutral (M/T)</li> </ul>	Idle (Accelerator pedal is not depressed even slightly, after engine starting)
	<ul style="list-style-type: none"> <li>Air conditioner switch: OFF</li> <li>No load</li> </ul>	2,000 rpm



# DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[VQ TYPE 1]

## On Board Diagnosis Logic

GBS000M0

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0444 0444	EVAP canister purge volume control solenoid valve circuit open	An excessively low voltage signal is sent to ECM through the valve	<ul style="list-style-type: none"> <li>● Harness or connectors (The solenoid valve circuit is open or shorted.)</li> <li>● EVAP canister purge volume control solenoid valve</li> </ul>
P0445 0445	EVAP canister purge volume control solenoid valve circuit shorted	An excessively high voltage signal is sent to ECM through the valve	<ul style="list-style-type: none"> <li>● Harness or connectors (The solenoid valve circuit is shorted.)</li> <li>● EVAP canister purge volume control solenoid valve</li> </ul>

## DTC Confirmation Procedure

GBS000M1

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### TESTING CONDITION:

**Before performing the following procedure, confirm battery voltage is more than 11V at idle.**

### WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for at least 13 seconds.
4. If 1st trip DTC is detected, go to [EC-278, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

### WITH GST

Follow the procedure "WITH CONSULT-II" above.

# DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE




[VQ TYPE 1]

GBS000M2

## Wiring Diagram

EC-PGC/V-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



MBWA1293E



# DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
45	P	EVAP canister purge volume control solenoid valve	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Idle speed</li> <li>● Accelerator pedal is not depressed even slightly, after engine starting</li> </ul>	BATTERY VOLTAGE (11 - 14V)★  <small>10.0 V/Div 50 ms/Div</small> SEC990C
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed: About 2,000 rpm (More than 100 seconds after starting engine)</li> </ul>	BATTERY VOLTAGE (11 - 14V)★  <small>10.0 V/Div 50 ms/Div</small> SEC991C
111	BR	ECM relay (Self shut-off)	<b>[Engine is running]</b> <b>[Ignition switch: OFF]</b> <ul style="list-style-type: none"> <li>● For a few seconds after turning ignition switch OFF</li> </ul>	0 - 1.5V
			<b>[Ignition switch: OFF]</b> <ul style="list-style-type: none"> <li>● More than a few seconds after turning ignition switch OFF</li> </ul>	BATTERY VOLTAGE (11 - 14V)
119 120	R P	Power supply for ECM	<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

### 1. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect EVAP canister purge volume control solenoid valve (1) harness connector.
  - ⇐: Vehicle front
3. Turn ignition switch ON.




4. Check voltage between EVAP canister purge volume control solenoid valve terminal 2 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



### 2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E9, F4
- Harness for open or short between EVAP canister purge volume control solenoid valve and IPDM E/R
- Harness for open or short between EVAP canister purge volume control solenoid valve and ECM

>> Repair harness or connectors.

### 3. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 45 and EVAP canister purge volume control solenoid valve terminal 1. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK (With CONSULT-II) >> GO TO 4.
- OK (Without CONSULT-II) >> GO TO 5.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

# DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[VQ TYPE 1]

## 4. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

### With CONSULT-II

1. Reconnect all harness connectors disconnected.
2. Start engine.
3. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.

### OK or NG

- OK >> GO TO 6.  
 NG >> GO TO 5.

ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XX %
A/F ALPHA-B2	XX %

PBIB1678E

## 5. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Refer to [EC-279, "Component Inspection"](#) .

### OK or NG

- OK >> GO TO 6.  
 NG >> Replace EVAP canister purge volume control solenoid valve.

## 6. CHECK INTERMITTENT INCIDENT

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


## Component Inspection EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

GBS000M4

### With CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.


Condition (PURG VOL CONT/V value)	Air passage continuity between (A) and (B)
100%	Yes
0%	No



### Without CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.

Condition	Air passage continuity between (A) and (B)
12V direct current supply between terminals 1 and 2	Yes
No supply	No



# DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[VQ TYPE 1]

---

## Removal and Installation

GBS000M5

### EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Refer to [EM-18, "INTAKE MANIFOLD COLLECTOR"](#) .

DTC P0500 VSS

PFPP:32702

Description

GBS000M6

NOTE:

If DTC P0500 is displayed with DTC U1000 or U1001, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-146, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#).

The vehicle speed signal is sent to the combination meter from the "ABS actuator and electric unit (control unit)" by CAN communication line. The combination meter then sends a signal to the ECM by CAN communication line.

On Board Diagnosis Logic

GBS000M7

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0500 0500	Vehicle speed sensor	The almost 0 km/h (0 MPH) signal from vehicle speed sensor is sent to ECM even when vehicle is being driven.	<ul style="list-style-type: none"> <li>● Harness or connectors (The CAN communication line is open or shorted)</li> <li>● Harness or connectors (The vehicle speed signal circuit is open or shorted)</li> <li>● Wheel sensor</li> <li>● Combination meter</li> <li>● ABS actuator and electric unit (control unit)</li> </ul>

DTC Confirmation Procedure

GBS000M8

**CAUTION:**

Always drive vehicle at a safe speed.

NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Steps 1 and 2 may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

 WITH CONSULT-II

1. Start engine.
2. Read "VHCL SPEED SE" in "DATA MONITOR" mode with CONSULT-II. The vehicle speed on CONSULT-II should exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.  
If NG, go to [EC-282, "Diagnostic Procedure"](#).  
If OK, go to following step.
3. Select "DATA MONITOR" mode with CONSULT-II.
4. Warm engine up to normal operating temperature.
5. Maintain the following conditions for at least 60 consecutive seconds.

ENG SPEED	1,700 - 6,000 rpm (A/T) 1,600 - 6,000 rpm (M/T)
COOLAN TEMP/S	More than 70°C (158°F)
B/FUEL SCHDL	7.3 - 31.8 msec (A/T) 6.5 - 31.8 msec (M/T)
Selector lever	Except P or N position (A/T) Except Neutral position (M/T)
PW/ST SIGNAL	OFF

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
B/FUEL SCHDL	XXX msec
PW/ST SIGNAL	OFF
VHCL SPEED SE	XXX km/h

SEF196Y

6. If 1st trip DTC is detected, go to [EC-282, "Diagnostic Procedure"](#).

Overall Function Check

GBS000M9

Use this procedure to check the overall function of the vehicle speed sensor circuit. During this check, a 1st trip DTC might not be confirmed.

**WITH GST**

1. Lift up drive wheels.
2. Start engine.
3. Read vehicle speed sensor signal in Service \$01 with GST.  
The vehicle speed sensor on GST should be able to exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.
4. If NG, go to [EC-282, "Diagnostic Procedure"](#) .

**Diagnostic Procedure**

GBS000MA

**1. CHECK DTC WITH "ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)"**

Refer to [BRC-8, "TROUBLE DIAGNOSIS"](#) .

OK or NG

- OK >> GO TO 2.  
NG >> Repair or replace.

**2. CHECK COMBINATION METER FUNCTION**

Refer to [DI-4, "COMBINATION METERS"](#) .

>> INSPECTION END




**DTC P0550 PSP SENSOR**

PF:49763

**Component Description**

GBS000MB

Power steering pressure (PSP) sensor is installed to the power steering high-pressure tube and detects a power steering load. This sensor is a potentiometer which transforms the power steering load into output voltage, and emits the voltage signal to the ECM. The ECM controls the electric throttle control actuator and adjusts the throttle valve opening angle to increase the engine speed and adjusts the idle speed for the increased load.



**CONSULT-II Reference Value in Data Monitor Mode**

GBS000MC

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
PW/ST SIGNAL	● Engine: After warming up, idle the engine	Steering wheel: Not being turned.	OFF
		Steering wheel: Being turned.	ON

**On Board Diagnosis Logic**

GBS000MD

The MIL will not light up for this diagnosis.

**NOTE:**

If DTC P0550 is displayed with DTC P1229, first perform the trouble diagnosis for DTC P1229. Refer to [EC-365, "DTC P1229 SENSOR POWER SUPPLY"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0550 0550	Power steering pressure sensor circuit	An excessively low or high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> <li>● Harness or connectors (The sensor circuit is open or shorted)</li> <li>● Power steering pressure sensor</li> </ul>

**DTC Confirmation Procedure**


GBS000ME

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for at least 5 seconds.
4. If 1st trip DTC is detected, go to [EC-285, "Diagnostic Procedure"](#)



**WITH GST**

Follow the procedure "WITH CONSULT-II" above.

# DTC P0550 PSP SENSOR



[VQ TYPE 1]

## Wiring Diagram

GBS000MF

EC-PS/SEN-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



MBWA1296E

# DTC P0550 PSP SENSOR

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
12	P	Power steering pressure sensor	[Engine is running] ● Steering wheel: Being turned	0.5 - 4.5V
			[Engine is running] ● Steering wheel: Not being turned	0.4 - 0.8V
67	GR	Sensor ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
68	V	Sensor power supply (Power steering pressure sensor)	[Ignition switch: ON]	Approximately 5V

## Diagnostic Procedure

GBS000MG

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-145, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

## 2. CHECK PSP SENSOR POWER SUPPLY CIRCUIT

1. Disconnect PSP sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between PSP sensor terminal 3 and ground with CONSULT-II or tester.

**Voltage: Approximately 5V**

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



## 3. CHECK PSP SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between PSP sensor terminal 1 and ECM terminal 67. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 4. CHECK PSP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 12 and PSP sensor terminal 2.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 5. CHECK PSP SENSOR

Refer to [EC-287, "Component Inspection"](#).

OK or NG

OK >> GO TO 6.

NG >> Replace PSP sensor.

**6. CHECK INTERMITTENT INCIDENT**

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

### Component Inspection POWER STEERING PRESSURE SENSOR

GBS000MH

1. Reconnect all harness connectors disconnected.
2. Start engine and let it idle.
3. Check voltage between ECM terminal 12 and ground under the following conditions.

Condition	Voltage
Steering wheel: Being turned.	0.5 - 4.5V
Steering wheel: Not being turned.	0.4 - 0.8V



GBS000MI

### Removal and Installation POWER STEERING PRESSURE SENSOR

Refer to [PS-33, "HYDRAULIC LINE"](#) .


**DTC P0605 ECM**

PFP:23710

**Component Description**

GBS000MJ

The ECM consists of a microcomputer and connectors for signal input and output and for power supply. The ECM controls the engine.



**On Board Diagnosis Logic**

GBS000MK

This self-diagnosis has one or two trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition		Possible cause
P0605 0605	Engine control module	A)	ECM calculation function is malfunctioning.	● ECM
		B)	ECM EEPROM system is malfunctioning.	
		C)	ECM self shut-off function is malfunctioning.	

**FAIL-SAFE MODE**

ECM enters fail-safe mode when the malfunction A is detected.

Detected items	Engine operation condition in fail-safe mode
Malfunction A	<ul style="list-style-type: none"> <li>● ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.</li> <li>● ECM deactivates ASCD operation.</li> </ul>

**DTC Confirmation Procedure**

GBS000ML

Perform **PROCEDURE FOR MALFUNCTION A** first. If the 1st trip DTC cannot be confirmed, perform **PROCEDURE FOR MALFUNCTION B**. If there is no malfunction on **PROCEDURE FOR MALFUNCTION B**, perform **PROCEDURE FOR MALFUNCTION C**.


**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**PROCEDURE FOR MALFUNCTION A**

Ⓜ **With CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. If 1st trip DTC is detected, go to [EC-289, "Diagnostic Procedure"](#)



Ⓜ **With GST**

Follow the procedure "With CONSULT-II" above.

**PROCEDURE FOR MALFUNCTION B**

**With CONSULT-II**

1. Turn ignition switch ON and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Turn ignition switch OFF, wait at least 10 seconds, and then turn ON.
4. If 1st trip DTC is detected, go to [EC-289, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

**With GST**

Follow the procedure "With CONSULT-II" above.

**PROCEDURE FOR MALFUNCTION C**

**With CONSULT-II**

1. Turn ignition switch ON and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Turn ignition switch OFF, wait at least 10 seconds, and then turn ON.
4. Repeat step 3 for 32 times.
5. If 1st trip DTC is detected, go to [EC-289, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

**With GST**

Follow the procedure "With CONSULT-II" above.

**Diagnostic Procedure**

**1. INSPECTION START**

GBS000MM

**With CONSULT-II**

1. Turn ignition switch ON.
2. Select "SELF DIAG RESULTS" mode with CONSULT-II.
3. Touch "ERASE".
4. **Perform DTC Confirmation Procedure.**  
See [EC-288, "DTC Confirmation Procedure"](#) .
5. Is the 1st trip DTC P0605 displayed again?

**With GST**

1. Turn ignition switch ON.
2. Select Service \$04 with GST.
3. **Perform DTC Confirmation Procedure.**  
See [EC-288, "DTC Confirmation Procedure"](#) .
4. Is the 1st trip DTC P0605 displayed again?

Yes or No

- Yes >> GO TO 2.  
 No >> **INSPECTION END**

---

## 2. REPLACE ECM

---

1. Replace ECM.
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [BL-83, "ECM Re-communicating Function"](#) .
3. Perform [EC-71, "Accelerator Pedal Released Position Learning"](#) .
4. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
5. Perform [EC-71, "Idle Air Volume Learning"](#) .

>> INSPECTION END



# DTC P1031, P1032, P1051, P1052 A/F SENSOR 1 HEATER

[VQ TYPE 1]

## DTC P1031, P1032, P1051, P1052 A/F SENSOR 1 HEATER

PFP:22693

### Description SYSTEM DESCRIPTION

GBS000MN

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor (PHASE) Crankshaft position sensor (POS)	Engine speed	Air fuel ratio (A/F) sensor 1 heater control	Air fuel ratio (A/F) sensor 1 heater
Mass air flow sensor	Amount of intake air		

The ECM performs ON/OFF duty control of the air fuel ratio (A/F) sensor 1 heater corresponding to the engine operating condition to keep the temperature of air fuel ratio (A/F) sensor 1 element at the specified range.

### CONSULT-II Reference Value in Data Monitor Mode

GBS000MO

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
A/F S1 HTR (B1) A/F S1 HTR (B2)	● Engine: After warming up, idle the engine	0 - 100%

### On Board Diagnosis Logic

GBS000MP

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1031 1031 (Bank 1)	Air fuel ratio (A/F) sensor 1 heater control circuit low input	The current amperage in the air fuel ratio (A/F) sensor 1 heater circuit is out of the normal range. (An excessively low voltage signal is sent to ECM through the air fuel ratio (A/F) sensor 1 heater.)	<ul style="list-style-type: none"> <li>● Harness or connectors (The air fuel ratio (A/F) sensor 1 heater circuit is open or shorted.)</li> <li>● Air fuel ratio (A/F) sensor 1 heater</li> </ul>
P1051 1051 (Bank 2)			
P1032 1032 (Bank 1)	Air fuel ratio (A/F) sensor 1 heater control circuit high input	The current amperage in the air fuel ratio (A/F) sensor 1 heater circuit is out of the normal range. (An excessively high voltage signal is sent to ECM through the air fuel ratio (A/F) sensor 1 heater.)	<ul style="list-style-type: none"> <li>● Harness or connectors (The air fuel ratio (A/F) sensor 1 heater circuit is shorted.)</li> <li>● Air fuel ratio (A/F) sensor 1 heater</li> </ul>
P1052 1052 (Bank 2)			

### DTC Confirmation Procedure

GBS000MQ

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10.5V and 16V at idle.

#### WITH CONSULT-II

1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and let it idle for at least 10 seconds.
3. If 1st trip DTC is detected, go to [EC-296, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

# DTC P1031, P1032, P1051, P1052 A/F SENSOR 1 HEATER

[VQ TYPE 1]

---

 **WITH GST**

Follow the procedure "WITH CONSULT-II" above.






# DTC P1031, P1032, P1051, P1052 A/F SENSOR 1 HEATER

[VQ TYPE 1]

GBS000MR

## Wiring Diagram BANK 1

EC-AF1HB1-01




# DTC P1031, P1032, P1051, P1052 A/F SENSOR 1 HEATER

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
2	L	A/F sensor 1 heater (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 5V★ 
16	SB	A/F sensor 1 (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 3.1V
35	O			Approximately 2.6V
56	LG			Approximately 2.3V
75	P			Approximately 2.3V






★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# DTC P1031, P1032, P1051, P1052 A/F SENSOR 1 HEATER

[VQ TYPE 1]

BANK 2

EC-AF1HB2-01




# DTC P1031, P1032, P1051, P1052 A/F SENSOR 1 HEATER

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
24	G	A/F sensor 1 heater (Bank 2)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 5V★  PBIB1584E
57	GR	A/F sensor 1 (Bank 2)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 2.6V
58	O			Approximately 2.3V
76	V			Approximately 3.1V
77	Y			Approximately 2.3V


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

GBS000MS

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-145, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

**OK or NG**

- OK >> GO TO 2.  
NG >> Repair or Replace ground connections.

## 2. CHECK AIR FUEL RATIO (A/F) SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect air fuel ratio (A/F) sensor 1 harness connector.




2. Turn ignition switch ON.
3. Check voltage between air fuel ratio sensor 1 terminal 3 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



## 3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E8, F2
- IPDM E/R harness connector E12
- 10A fuse
- Harness for open or short between air fuel ratio sensor 1 and fuse

>> Repair or replace harness or connectors.

## 4. CHECK AIR FUEL RATIO (A/F) SENSOR 1 HEATER OUTPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 2 (bank 1) or 24 (bank 2) and air fuel ratio (A/F) sensor 1 terminal 4.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 5. CHECK AIR FUEL RATIO (A/F) SENSOR 1 HEATER

Refer to [EC-298, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 7.

## 6. CHECK INTERMITTENT INCIDENT

Perform [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> GO TO 7.
- NG >> Repair or replace.

## 7. REPLACE AIR FUEL RATIO (A/F) SENSOR 1

Replace air fuel ratio (A/F) sensor 1.

### CAUTION:

- Discard any air fuel ratio (A/F) sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new air fuel ratio (A/F) sensor, clean exhaust system threads using Heated Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

>> INSPECTION END

## Component Inspection AIR FUEL RATIO (A/F) SENSOR 1 HEATER

GBS000MT

Check resistance between terminals 3 and 4.

**Resistance: 2.3 - 4.3Ω [at 25°C (77°F)]**


Check continuity between terminals 3 and 1, 2, 5, 6, terminals 4 and 1, 2, 5, 6.

**Continuity should not exist.**

If NG, replace the air fuel ratio (A/F) sensor 1.

### CAUTION:

- Discard any air fuel ratio (A/F) sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new air fuel ratio (A/F) sensor, clean exhaust system threads using Heated Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.



PBIB1684E

## Removal and Installation AIR FUEL RATIO (A/F) SENSOR 1

GBS000MU

Refer to [EM-23, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#) .




## DTC P1065 ECM POWER SUPPLY

PFP:23710

### Component Description

GBS000MV

Battery voltage is supplied to the ECM even when the ignition switch is turned OFF for the ECM memory function of the DTC memory, the air-fuel ratio feedback compensation value memory, the idle air volume learning value memory, etc.



GBS000MW

### On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1065 1065	ECM power supply circuit	ECM back-up RAM system does not function properly.	<ul style="list-style-type: none"> <li>● Harness or connectors [ECM power supply (back-up) circuit is open or shorted.]</li> <li>● ECM</li> </ul>

### DTC Confirmation Procedure


GBS000MX

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**Ⓟ WITH CONSULT-II**

1. Turn ignition switch ON and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. Turn ignition switch OFF, wait at least 10 seconds, and then turn ON.
5. Repeat steps 3 and 4 for 4 times.
6. If 1st trip DTC is detected, go to [EC-301, "Diagnostic Procedure"](#)



**Ⓢ WITH GST**

Follow the procedure "WITH CONSULT-II" above.

# DTC P1065 ECM POWER SUPPLY



[VQ TYPE 1]

## Wiring Diagram

GBS000MY

### EC-ECM/PW-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



MBWA1299E

# DTC P1065 ECM POWER SUPPLY

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.

## CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
121	V	Power supply for ECM (Back-up)	[Ignition switch: OFF]	BATTERY VOLTAGE (11 - 14V)

## Diagnostic Procedure

GBS000MZ


### 1. CHECK ECM POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check voltage between ECM terminal 121 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



### 2. DETECT MALFUNCTIONING PART

Check the following.

- 20A fuse
- IPDM E/R harness connector E30
- Harness for open or short between ECM and battery

>> Repair open circuit in harness or connectors.

### 3. CHECK INTERMITTENT INCIDENT

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace harness or connectors.

---

## 4. PERFORM DTC CONFIRMATION PROCEDURE

---

### With CONSULT-II

1. Turn ignition switch ON.
2. Select "SELF DIAG RESULTS" mode with CONSULT-II.
3. Touch "ERASE".
4. **Perform DTC Confirmation Procedure.**  
See [EC-299, "DTC Confirmation Procedure"](#) .
5. Is the 1st trip DTC P1065 displayed again?

### With GST

1. Turn ignition switch ON.
2. Select Service \$04 with GST.
3. **Perform DTC Confirmation Procedure.**  
See [EC-299, "DTC Confirmation Procedure"](#) .
4. Is the 1st trip DTC P1065 displayed again?

Yes or No

Yes >> GO TO 5.

No >> **INSPECTION END**

---

## 5. REPLACE ECM

---

1. Replace ECM.
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [BL-83, "ECM Re-communicating Function"](#) .
3. Perform [EC-71, "Accelerator Pedal Released Position Learning"](#) .
4. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
5. Perform [EC-71, "Idle Air Volume Learning"](#) .

>> **INSPECTION END**

## DTC P1111, P1136 IVT CONTROL SOLENOID VALVE

PFP:23796

### Component Description

GBS000N0


Intake valve timing control solenoid valve is activated by ON/OFF pulse duty (ratio) signals from the ECM.

The intake valve timing control solenoid valve changes the oil amount and direction of flow through intake valve timing control unit or stops oil flow.

The longer pulse width advances valve angle.

The shorter pulse width retards valve angle.

When ON and OFF pulse widths become equal, the solenoid valve stops oil pressure flow to fix the intake valve angle at the control position.



### CONSULT-II Reference Value in Data Monitor Mode

GBS000N1

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
INT/V SOL (B1) INT/V SOL (B2)	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Shift lever: P or N (A/T), Neutral (M/T)</li> </ul>	Idle	0 - 2%
	<ul style="list-style-type: none"> <li>● Air conditioner switch: OFF</li> <li>● No load</li> </ul>	2,000 rpm	Approx. 0 - 50%

### On Board Diagnosis Logic

GBS000N2

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1111 1111 (Bank 1)	Intake valve timing control solenoid valve circuit	An improper voltage is sent to the ECM through intake valve timing control solenoid valve.	<ul style="list-style-type: none"> <li>● Harness or connectors (Intake valve timing control solenoid valve circuit is open or shorted.)</li> <li>● Intake valve timing control solenoid valve</li> </ul>
P1136 1136 (Bank 2)			

### DTC Confirmation Procedure

GBS000N3

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 5 seconds.
4. If 1st trip DTC is detected, go to [EC-308, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

#### WITH GST

Following the procedure "WITH CONSULT-II" above.







# DTC P1111, P1136 IVT CONTROL SOLENOID VALVE

[VQ TYPE 1]

GBS000N4

## Wiring Diagram BANK 1

EC-IVCB1-01



MBWA1300E


# DTC P1111, P1136 IVT CONTROL SOLENOID VALVE

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
11	V	Intake valve timing control solenoid valve (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	BATTERY VOLTAGE (11 - 14V)
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,500 rpm</li> </ul>	7 - 12V★ 
111	BR	ECM relay (Self shut-off)	<b>[Engine is running]</b> <b>[Ignition switch: OFF]</b> <ul style="list-style-type: none"> <li>● For a few seconds after turning ignition switch OFF</li> </ul>	0 - 1.5V
			<b>[Ignition switch: OFF]</b> <ul style="list-style-type: none"> <li>● More than a few seconds after turning ignition switch OFF</li> </ul>	BATTERY VOLTAGE (11 - 14V)
119 120	R P	Power supply for ECM	<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)



★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# DTC P1111, P1136 IVT CONTROL SOLENOID VALVE

[VQ TYPE 1]

BANK 2

EC-IVCB2-01






# DTC P1111, P1136 IVT CONTROL SOLENOID VALVE

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
10	W	Intake valve timing control solenoid valve (Bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	BATTERY VOLTAGE (11 - 14V)
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,500 rpm</li> </ul>	7 - 12V★ 
111	BR	ECM relay (Self shut-off)	<b>[Engine is running]</b> <b>[Ignition switch: OFF]</b> <ul style="list-style-type: none"> <li>● For a few seconds after turning ignition switch OFF</li> </ul>	0 - 1.5V
			<b>[Ignition switch: OFF]</b> <ul style="list-style-type: none"> <li>● More than a few seconds after turning ignition switch OFF</li> </ul>	BATTERY VOLTAGE (11 - 14V)
119 120	R P	Power supply for ECM	<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

### 1. CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect intake valve timing control solenoid valve harness connector.




3. Turn ignition switch ON.
4. Check voltage between intake valve timing control solenoid valve terminal 2 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



### 2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E9, F4 (bank 1)
- Harness connectors F6, F125 (bank 1)
- Harness for open or short between intake valve timing control solenoid valve and IPDM E/R
- Harness for open or short between intake valve timing control solenoid valve and ECM

>> Repair harness or connectors.

### 3. CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 11 (bank 1) or 10 (bank 2) and intake valve timing control solenoid valve terminal 1. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F125, F6 (bank 1)
- Harness for open and short between ECM and intake valve timing control solenoid valve

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE

Refer to [EC-309, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> Replace intake valve timing control solenoid valve.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection  
INTAKE VALVE TIMING CONTROL SOLENOID VALVE

GBS000N6

1. Disconnect intake valve timing control solenoid valve harness connector.
2. Check resistance between intake valve timing control solenoid valve as follows.

Terminal	Resistance
1 and 2	7.0 - 7.7Ω [at 20°C (68°F)]
1 or 2 and ground	∞Ω (Continuity should not exist.)

If NG, replace intake valve timing control solenoid valve.  
If OK, go to next step.

3. Remove intake valve timing control solenoid valve.
4. Provide 12V DC between intake valve timing control solenoid valve terminals and then interrupt it. Make sure that the plunger moves as shown in the figure.



**CAUTION:**

Do not apply 12V DC continuously for 5 seconds or more. Doing so may result in damage to the coil in intake valve timing control solenoid valve.

If NG, replace intake valve timing control solenoid valve.

**NOTE:**

Always replace O-ring when intake valve timing control solenoid valve is removed.



Removal and Installation  
INTAKE VALVE TIMING CONTROL SOLENOID VALVE

GBS000N7

Refer to [EM-53, "TIMING CHAIN"](#) .

## DTC P1121 ELECTRIC THROTTLE CONTROL ACTUATOR

PFP:16119

### Component Description

GBS000N8

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc. The throttle control motor is operated by the ECM and it opens and closes the throttle valve. The throttle position sensor detects the throttle valve position, and the opening and closing speed of the throttle valve and feeds the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

### On Board Diagnosis Logic

GBS000N9

**This self-diagnosis has the one trip detection logic.**

DTC No.	Trouble diagnosis name	DTC detecting condition		Possible cause
P1121 1121	Electric throttle control actuator	A)	Electric throttle control actuator does not function properly due to the return spring malfunction.	● Electric throttle control actuator
		B)	Throttle valve opening angle in fail-safe mode is not in specified range.	
		C)	ECM detect the throttle valve is stuck open.	

### FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.

Detected items	Engine operating condition in fail-safe mode
Malfunction A	The ECM controls the electric throttle actuator by regulating the throttle opening around the idle position. The engine speed will not rise more than 2,000 rpm.
Malfunction B	ECM controls the electric throttle control actuator by regulating the throttle opening to 20 degrees or less.
Malfunction C	While the vehicle is driving, it slows down gradually by fuel cut. After the vehicle stops, the engine stalls. The engine can restart in N or P position (A/T), Neutral position (M/T) and engine speed will not exceed 1,000 rpm or more.

### DTC Confirmation Procedure

GBS000NA

#### NOTE:

- Perform **PROCEDURE FOR MALFUNCTION A AND B** first. If the DTC cannot be confirmed, perform **PROCEDURE FOR MALFUNCTION C**.
- If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### PROCEDURE FOR MALFUNCTION A AND B

##### ☑ With CONSULT-II

1. Turn ignition switch ON and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Shift selector lever to D position (A/T) or 1st position (M/T) and wait at least 3 seconds.
4. Shift selector lever to P position (A/T) or neutral position (M/T).
5. Turn ignition switch OFF and wait at least 10 seconds.
6. Turn ignition switch ON and wait at least 1 second.
7. Shift selector lever to D position (A/T) or 1st position (M/T) and wait at least 3 seconds.
8. Shift selector lever to P position (A/T) or neutral position (M/T).
9. Turn ignition switch OFF, wait at least 10 seconds, and then turn ON.
10. If DTC is detected, go to [EC-311, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y


**With GST**

Follow the procedure "WITH CONSULT-II" above.

## PROCEDURE FOR MALFUNCTION C

**With CONSULT-II**

1. Turn ignition switch ON and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Shift selector lever to D position (A/T) or 1st position (M/T) and wait at least 3 seconds.
4. Shift selector lever to P or N position (A/T) or neutral position (M/T).
5. Start engine and let it idle for 3 seconds.
6. If DTC is detected, go to [EC-311, "Diagnostic Procedure"](#) .



**With GST**

Follow the procedure "WITH CONSULT-II" above.


## Diagnostic Procedure

### 1. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY

1. Remove the intake air duct.
2. Check if a foreign matter is caught between the throttle valve (1) and the housing.

**OK or NG**

- OK >> GO TO 2.  
 NG >> Remove the foreign matter and clean the electric throttle control actuator inside.



### 2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-71, "Idle Air Volume Learning"](#) .

>> INSPECTION END

# DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION

[VQ TYPE 1]

## DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION

PF16:16119

### Description

GBS000NC

#### NOTE:

If DTC P1122 is displayed with DTC P1121 or 1126, first perform the trouble diagnosis for DTC P1121 or P1126. Refer to [EC-310](#) or [EC-318](#).

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc.

The throttle control motor is operated by the ECM and it opens and closes the throttle valve.

The current opening angle of the throttle valve is detected by the throttle position sensor and it provides feedback to the ECM to control the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

### On Board Diagnosis Logic

GBS000ND

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1122 1122	Electric throttle control performance	Electric throttle control function does not operate properly.	<ul style="list-style-type: none"><li>● Harness or connectors (Throttle control motor circuit is open or shorted)</li><li>● Electric throttle control actuator</li></ul>

### FAIL-SAFE MODE

When the malfunction is detected, ECM enters fail-safe mode and the MIL lights up.

Engine operating condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

### DTC Confirmation Procedure

GBS000NE

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11V when the engine is running.

#### WITH CONSULT-II

1. Turn ignition switch ON and wait at least 2 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 5 seconds.
4. If DTC is detected, go to [EC-314, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

#### WITH GST

Follow the procedure "WITH CONSULT-II" above.

# DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION



[VQ TYPE 1]

GBS000NF

## Wiring Diagram

EC-ETC1-01

— : DETECTABLE LINE FOR DTC  
 - - - : NON-DETECTABLE LINE FOR DTC



MBWA1302E



# DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
3	BR	Throttle control motor relay power supply	[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14V)
4	L/W	Throttle control motor (Close)	[Ignition switch: ON] ● Engine: Stopped ● Shift lever: D (A/T), 1st (M/T) ● Accelerator pedal: Fully released	0 - 14V★  PBIB1104E
5	L/B	Throttle control motor (Open)	[Ignition switch: ON] ● Engine: Stopped ● Shift lever: D (A/T), 1st (M/T) ● Accelerator pedal: Fully depressed	0 - 14V★  PBIB1105E
104	O	Throttle control motor relay	[Ignition switch: OFF]	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch: ON]	0 - 1.0V


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

GBS000NG

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF
2. Loosen and retighten three ground screws on the body. Refer to [EC-145, "Ground Inspection"](#).



← : Vehicle front

- |                                  |  |                    |
|----------------------------------|--|--------------------|
| 1. Body ground E21               | 2. ECM   | 3. Body ground E41 |
| 4. A/C hi-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

**OK or NG**

- OK >> GO TO 2.  
NG >> Repair or replace ground connections.



# DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION

[VQ TYPE 1]


## 2. CHECK THROTTLE CONTROL MOTOR RELAY INPUT SIGNAL CIRCUIT-I

1. Check voltage between ECM terminal 3 and ground under the following conditions with CONSULT-II or tester.

Ignition switch	Voltage
OFF	Approximately 0V
ON	Battery voltage (11 - 14V)

OK or NG

- OK >> GO TO 9.
- NG >> GO TO 3.




## 3. CHECK THROTTLE CONTROL MOTOR RELAY POWER SUPPLY CIRCUIT-I

1. Turn ignition switch OFF.
2. Check voltage between ECM terminal 104 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 4.



## 4. CHECK THROTTLE CONTROL MOTOR RELAY POWER SUPPLY CIRCUIT-II

1. Disconnect ECM harness connector.
2. Disconnect IPDM E/R harness connector E17.
3. Check continuity between ECM terminal 104 and IPDM E/R terminal 47. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 5. CHECK FUSE

1. Disconnect 20A fuse.
2. Check 20A fuse for blown.

OK or NG

- OK >> GO TO 8.
- NG >> Replace 20A fuse.

## 6. CHECK THROTTLE CONTROL MOTOR RELAY INPUT SIGNAL CIRCUIT-II

1. Disconnect ECM harness connector.
2. Disconnect IPDM E/R harness connector E12.
3. Check continuity between ECM terminal 3 and IPDM E/R terminal 6.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK     >> GO TO 8.
- NG     >> GO TO 7.

## 7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E9, F4
- Harness for open or short between ECM and IPDM E/R

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 8. CHECK INTERMITTENT INCIDENT

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


OK or NG

- OK     >> Replace IPDM E/R. Refer to [PG-14, "IPDM E/R \(INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM\)"](#) .
- NG     >> Repair or replace harness or connectors.

## 9. CHECK THROTTLE CONTROL MOTOR OUTPUT SIGNAL CIRCUIT FOR OPEN OR SHORT

1. Turn ignition switch OFF.
2. Disconnect electric throttle control actuator harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between the following terminals.  
Refer to Wiring Diagram.

Electric throttle control actuator terminal	ECM terminal	Continuity
5	5	Should not exist
	4	Should exist
6	5	Should exist
	4	Should not exist



5. Also check harness for short to ground and short to power.

OK or NG

- OK     >> GO TO 10.
- NG     >> Repair or replace.


## 10. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY

1. Remove the intake air duct.
2. Check if foreign matter is caught between the throttle valve (1) and the housing.

OK or NG

OK >> GO TO 11.

NG >> Remove the foreign matter and clean the electric throttle control actuator inside.



## 11. CHECK THROTTLE CONTROL MOTOR

Refer to [EC-317, "Component Inspection"](#) .

OK or NG

OK >> GO TO 12.

NG >> GO TO 13.

## 12. CHECK INTERMITTENT INCIDENT

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

OK >> GO TO 13.

NG >> Repair or replace harness or connectors.

## 13. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-71, "Idle Air Volume Learning"](#) .

>> INSPECTION END


### Component Inspection THROTTLE CONTROL MOTOR

GBS000NH

1. Disconnect electric throttle control actuator harness connector.
2. Check resistance between terminals 5 and 6.

**Resistance: Approximately 1 - 15 Ω [at 25 °C (77°F)]**

3. If NG, replace electric throttle control actuator and go to next step.
4. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
5. Perform [EC-71, "Idle Air Volume Learning"](#) .



GBS000NI

### Removal and Installation ELECTRIC THROTTLE CONTROL ACTUATOR

Refer to [EM-18, "INTAKE MANIFOLD COLLECTOR"](#) .

# DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY

[VQ TYPE 1]

## DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY

PFP:16119

### Component Description

GBS000NJ

Power supply for the throttle control motor is provided to the ECM via throttle control motor relay. The throttle control motor relay is ON/OFF controlled by the ECM. When the ignition switch is turned ON, the ECM sends an ON signal to throttle control motor relay and battery voltage is provided to the ECM. When the ignition switch is turned OFF, the ECM sends an OFF signal to throttle control motor relay and battery voltage is not provided to the ECM.

### CONSULT-II Reference Value in Data Monitor Mode

GBS000NK

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
THRTL RELAY	● Ignition switch: ON	ON

### On Board Diagnosis Logic

GBS000NL

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1124 1124	Throttle control motor relay circuit short	ECM detects the throttle control motor relay is stuck ON.	<ul style="list-style-type: none"><li>● Harness or connectors (Throttle control motor relay circuit is shorted)</li><li>● Throttle control motor relay</li></ul>
P1126 1126	Throttle control motor relay circuit open	ECM detects a voltage of power source for throttle control motor is excessively low.	<ul style="list-style-type: none"><li>● Harness or connectors (Throttle control motor relay circuit is open)</li><li>● Throttle control motor relay</li></ul>

### FAIL-SAFE MODE

When the malfunction is detected, ECM enters fail-safe mode and the MIL lights up.

Engine operating condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

### DTC Confirmation Procedure

GBS000NM

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### PROCEDURE FOR DTC P1124

##### TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 8V.

##### ④ With CONSULT-II

1. Turn ignition switch ON and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. If DTC is detected, go to [EC-321, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

# DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY

[VQ TYPE 1]

## With GST

Follow the procedure "With CONSULT-II" above.

### PROCEDURE FOR DTC P1126

## With CONSULT-II

1. Turn ignition switch ON and wait at least 2 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 5 seconds.
4. If DTC is detected, go to [EC-321, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

## With GST

Follow the procedure "With CONSULT-II" above.

A

EC

C

D

E

F

G

H

I

J

K

L

M

# DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY



[VQ TYPE 1]

GBS000NN

## Wiring Diagram

EC-ETC2-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



MBWA1303E



# DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
3	BR	Throttle control motor relay power supply	<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)
4	L/W	Throttle control motor (Close)	<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully released</li> </ul>	0 - 14V★  PBIB1104E
5	L/B	Throttle control motor (Open)	<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully depressed</li> </ul>	0 - 14V★  PBIB1105E
104	O	Throttle control motor relay	<b>[Ignition switch: OFF]</b>	BATTERY VOLTAGE (11 - 14V)
			<b>[Ignition switch: ON]</b>	0 - 1.0V

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

GBS000NO


### 1. CHECK THROTTLE CONTROL MOTOR RELAY POWER SUPPLY CIRCUIT-I

1. Turn ignition switch OFF.
2. Check voltage between ECM terminal 104 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 2.



## 2. CHECK THROTTLE CONTROL MOTOR RELAY POWER SUPPLY CIRCUIT-II

1. Disconnect ECM harness connector.
2. Disconnect IPDM E/R harness connector E17.
3. Check continuity between ECM terminal 104 and IPDM E/R terminal 47.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 3. CHECK FUSE

1. Disconnect 20A fuse.
2. Check 20A fuse for blown.

OK or NG

OK >> GO TO 7.

NG >> Replace 20A fuse.

## 4. CHECK THROTTLE CONTROL MOTOR RELAY INPUT SIGNAL CIRCUIT-I


1. Check voltage between ECM terminal 3 and ground under the following conditions with CONSULT-II or tester.

Ignition switch	Voltage
OFF	Approximately 0V
ON	Battery voltage (11 - 14V)

OK or NG

OK >> GO TO 7.

NG >> GO TO 5.



## 5. CHECK THROTTLE CONTROL MOTOR RELAY INPUT SIGNAL CIRCUIT-II

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Disconnect IPDM E/R harness connector E12.
4. Check continuity between ECM terminal 3 and IPDM E/R terminal 6.  
Refer to Wiring Diagram.

**Continuity should exist.**

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.

## 6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E9, F4
- Harness for open or short between ECM and IPDM E/R

>> Repair open circuit or short to ground or short to power in harness or connectors.



---

**7. CHECK INTERMITTENT INCIDENT**

---

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-14, "IPDM E/R \(INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM\)"](#) .
- NG >> Repair or replace harness or connectors.

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

## DTC P1128 THROTTLE CONTROL MOTOR

PFP:16119

### Component Description

GBS000NP

The throttle control motor is operated by the ECM and it opens and closes the throttle valve. The current opening angle of the throttle valve is detected by the throttle position sensor and it provides feedback to the ECM to control the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

### On Board Diagnosis Logic

GBS000NQ

**This self-diagnosis has the one trip detection logic.**

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1128 1128	Throttle control motor circuit short	ECM detects short in both circuits between ECM and throttle control motor.	<ul style="list-style-type: none"> <li>● Harness or connectors (Throttle control motor circuit is shorted.)</li> <li>● Electric throttle control actuator (Throttle control motor)</li> </ul>

### FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.

Engine operating condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

### DTC Confirmation Procedure

GBS000NR

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### WITH CONSULT-II

1. Turn ignition switch ON and wait at least 2 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 5 seconds.
4. If DTC is detected, go to [EC-326, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

#### WITH GST

Follow the procedure "WITH CONSULT-II" above.

# DTC P1128 THROTTLE CONTROL MOTOR

[VQ TYPE 1]



GBS000NS

## Wiring Diagram

EC-ETC3-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



MBWA1304E



# DTC P1128 THROTTLE CONTROL MOTOR

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
3	BR	Throttle control motor relay power supply	<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)
4	L/W	Throttle control motor (Close)	<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Shift lever: D (A/T), 1st (M/T) ● Accelerator pedal: Fully released	0 - 14V★  PBIB1104E
5	L/B	Throttle control motor (Open)	<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Shift lever: D (A/T), 1st (M/T) ● Accelerator pedal: Fully depressed	0 - 14V★  PBIB1105E
104	O	Throttle control motor relay	<b>[Ignition switch: OFF]</b>	BATTERY VOLTAGE (11 - 14V)
			<b>[Ignition switch: ON]</b>	0 - 1.0V


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

GBS000NT

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-145, "Ground Inspection"](#).



← : Vehicle front

- |                                  |  |                    |
|----------------------------------|--|--------------------|
| 1. Body ground E21               | 2. ECM   | 3. Body ground E41 |
| 4. A/C hi-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |


OK or NG

- OK >> GO TO 2.  
NG >> Repair or replace ground connections.

## 2. CHECK THROTTLE CONTROL MOTOR OUTPUT SIGNAL CIRCUIT FOR OPEN OR SHORT

1. Disconnect electric throttle control actuator harness connector.
2. Disconnect ECM harness connector.
3. Check harness continuity between the following terminals. Refer to Wiring Diagram.

Electric throttle control actuator terminal	ECM terminal	Continuity
5	5	Should not exist
	4	Should exist
6	5	Should exist
	4	Should not exist



4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 3.  
 NG >> Repair or replace.

## 3. CHECK THROTTLE CONTROL MOTOR

Refer to [EC-327, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 4.  
 NG >> GO TO 5.

## 4. CHECK INTERMITTENT INCIDENT

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> GO TO 5.  
 NG >> Repair or replace harness or connectors.

## 5. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-71, "Idle Air Volume Learning"](#) .

>> INSPECTION END


### Component Inspection THROTTLE CONTROL MOTOR

GBS000NU

1. Disconnect electric throttle control actuator harness connector.
2. Check resistance between terminals 5 and 6.

**Resistance: Approximately 1 - 15 Ω [at 25 °C (77°F)]**

3. If NG, replace electric throttle control actuator and go to next step.
4. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
5. Perform [EC-71, "Idle Air Volume Learning"](#) .



---

**Removal and Installation**  
**ELECTRIC THROTTLE CONTROL ACTUATOR**

GBS000NV

Refer to [EM-18, "INTAKE MANIFOLD COLLECTOR"](#) .


**DTC P1146, P1166 HO2S2**

PFP:226A0

**Component Description**

GBS000NW

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas on each bank. Even if switching characteristics of the air fuel ratio (A/F) sensor 1 are shifted, the air-fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2. This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



**CONSULT-II Reference Value in Data Monitor Mode**

GBS000NX


Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S2 (B1) HO2S2 (B2)	<ul style="list-style-type: none"> <li>● Revving engine from idle to 3,000 rpm quickly after the following conditions are met</li> </ul>	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)	<ul style="list-style-type: none"> <li>- Engine: After warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul>	LEAN ↔ RICH

**On Board Diagnosis Logic**

GBS000NY

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the air fuel ratio (A/F) sensor 1. The oxygen storage capacity of the three way catalyst (manifold) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the minimum voltage of sensor is sufficiently low during the various driving condition such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1146 1146 (Bank 1)	Heated oxygen sensor 2 minimum voltage monitoring	The minimum voltage from the sensor is not reached to the specified voltage.	<ul style="list-style-type: none"> <li>● Harness or connectors (The sensor circuit is open or shorted)</li> <li>● Heated oxygen sensor 2</li> <li>● Fuel pressure</li> <li>● Fuel injector</li> </ul>
P1166 1166 (Bank 2)			

**DTC Confirmation Procedure**

**CAUTION:**

Always drive vehicle at a safe speed.

**NOTE:**

- “COMPLETED” will appear on CONSULT-II screen when all tests “COND1”, “COND2” and “COND3” are completed.
- If DTC confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION:**

Never stop engine during this procedure. If the engine is stopped, retry procedure from step 2 in Procedure for COND1.

**WITH CONSULT-II**

**Procedure for COND1**

For the best results, perform “DTC WORK SUPPORT” at a temperature of 0 to 30°C (32 to 86°F).

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
4. Let engine idle for 1 minute.
5. Select “HO2S2 (B1) P1146” or “HO2S2 (B2) P1166” of “HO2S2” in “DTC WORK SUPPORT” mode with CONSULT-II.
6. Touch “START”.
7. Let engine idle for at least 30 seconds.
8. Rev engine up to 2,000 rpm two or three times quickly under no load.  
If “COMPLETED” appears on CONSULT-II screen, go to step 2 in Procedure for COND3.  
If “COMPLETED” does not appear on CONSULT-II screen, go to the following step.
9. When the following conditions are met, “TESTING” will be displayed at “COND1” on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 60 seconds.)

ENG SPEED	More than 1,000 rpm
B/FUEL SCHDL	More than 1.0 msec
COOLAN TEMP/S	70 - 105°C
Shift lever	Suitable position

<table border="1"> <tr><th colspan="2">HO2S2 (B1) P1146</th></tr> <tr><td>COND1:</td><td>OUT OF CONDITION</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P1146		COND1:	OUT OF CONDITION	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	<table border="1"> <tr><th colspan="2">HO2S2 (B1) P1146</th></tr> <tr><td>COND1:</td><td>TESTING</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P1146		COND1:	TESTING	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	<table border="1"> <tr><th colspan="2">HO2S2 (B1) P1146</th></tr> <tr><td>COND1:</td><td>COMPLETED</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P1146		COND1:	COMPLETED	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec
HO2S2 (B1) P1146																																												
COND1:	OUT OF CONDITION																																											
COND2:	INCOMPLETE																																											
COND3:	INCOMPLETE																																											
MONITOR																																												
ENG SPEED	XXX rpm																																											
B/FUEL SCHDL	XXX msec																																											
HO2S2 (B1) P1146																																												
COND1:	TESTING																																											
COND2:	INCOMPLETE																																											
COND3:	INCOMPLETE																																											
MONITOR																																												
ENG SPEED	XXX rpm																																											
B/FUEL SCHDL	XXX msec																																											
HO2S2 (B1) P1146																																												
COND1:	COMPLETED																																											
COND2:	INCOMPLETE																																											
COND3:	INCOMPLETE																																											
MONITOR																																												
ENG SPEED	XXX rpm																																											
B/FUEL SCHDL	XXX msec																																											

PBIB0555E

**NOTE:**

- If “TESTING” is not displayed after 5 minutes, retry from step 2 in Procedure for COND1.
- If “COMPLETED” already appears at “COND2” on CONSULT-II screen before Procedure for COND2 is conducted, it is unnecessary to conduct step 1 in Procedure for COND2.




**Procedure for COND2**

1. While driving, release accelerator pedal completed with "OD" OFF (A/T models only) from the above condition [step 9] until "INCOMPLETE" at "COND2" on CONSULT-II screen has turned to "COMPLETED" (It will take approximately 4 seconds.)


**NOTE:**

If "COMPLETE" already appears at "COND3" on CONSULT-II screen before Procedure for COND3 is conducted, it is unnecessary to conduct step 1 in Procedure for COND3.



**Procedure for COND3**

1. Stop vehicle and let it idle until "INCOMPLETE" of "COND3" on CONSULT-II screen has turned to "COMPLETED". (It will take a maximum of approximately 6 minutes.)
2. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".  
If "NG" is displayed, refer to [EC-335, "Diagnostic Procedure"](#).  
If "CAN NOT BE DIAGNOSED" is displayed, perform the following.
  - a. Turn ignition switch OFF and leave the vehicle in a cool place (soak the vehicle).
  - b. Turn ignition switch ON and select "COOLAN TEMP/S" in "DATA MONITOR" mode with CONSULT-II
  - c. Start engine and warm it up while monitoring "COOLAN TEMP/S" indication on CONSULT-II.
  - d. When "COOLAN TEMP/S" indication reaches to 70°C (158°F), go to step 3 in Procedure for COND 1.




**Overall Function Check**

GBS00000

Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a 1st trip DTC might not be confirmed.



**WITH GST**

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
4. Let engine idle for 1 minute.
5. Set voltmeter probes between ECM terminal 74 [HO2S2 (B1) signal] or 55 [HO2S2 (B2) signal] and ground.  
6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.  
(Depress and release accelerator pedal as soon as possible.)  
**The voltage should be below 0.18V at least once during this procedure.**  
**If the voltage can be confirmed in step 6, step 7 is not necessary.**
7. Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in D position with "OD" OFF (A/T), 4th gear position (M/T).  
**The voltage should be below 0.18V at least once during this procedure.**
8. If NG, go to [EC-335, "Diagnostic Procedure"](#).




**Wiring Diagram**  
**BANK 1**


**EC-O2S2B1-01**



(E12)  
W



(F1)  
B



(F2)  
W



(F31)  
L

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**



Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
25	SB	Heated oxygen sensor 2 heater (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed is below 3,600 rpm after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: after warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - 1.0V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> </ul> <b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed: Above 3,600 rpm</li> </ul>	BATTERY VOLTAGE (11 - 14V)
74	O	Heated oxygen sensor 2 (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Revving engine from idle to 3,000 rpm quickly after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: after warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - Approximately 1.0V
78	B	Sensor ground (Heated oxygen sensor 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● <b>Warm-up condition</b></li> <li>● Idle speed</li> </ul>	Approximately 0V

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

BANK 2

EC-O2S2B2-01



Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
6	R	Heated oxygen sensor 2 heater (Bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed is below 3,600 rpm after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: after warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - 1.0V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> </ul> <b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed: Above 3,600 rpm</li> </ul>	BATTERY VOLTAGE (11 - 14V)
55	G	Heated oxygen sensor 2 (Bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Revving engine from idle to 3,000 rpm quickly after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: after warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - Approximately 1.0V
78	B	Sensor ground (Heated oxygen sensor 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● <b>Warm-up condition</b></li> <li>● Idle speed</li> </ul>	Approximately 0V

**Diagnostic Procedure**

GBS00002

**1. CHECK GROUND CONNECTIONS**

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-145, "Ground Inspection"](#).



← : Vehicle front

- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |


**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

## 2. CLEAR THE SELF-LEARNING DATA


### ④ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.  
**Is the 1st trip DTC P0172 or P0175 detected?  
Is it difficult to start engine?**



### ⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-56, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.  
**Is the 1st trip DTC P0172 or P0175 detected?  
Is it difficult to start engine?**




### Yes or No

- Yes >> Perform trouble diagnosis for DTC P0172, P0175. Refer to [EC-219](#).
- No >> GO TO 3.

**3. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT**

1. Turn ignition switch OFF.
2. Disconnect heated oxygen sensor 2 harness connector.



- |                                    |  |  |
|------------------------------------|--|--|
| 1. Heated oxygen sensor 2 (bank 2) | 2. Heated oxygen sensor 2 (bank 2) harness connector | 3. Heated oxygen sensor 2 (bank 1) harness connector |
| 4. Heated oxygen sensor 2 (bank 1) |  |  |

3. Disconnect ECM harness connector.
4. Check harness continuity between HO2S2 terminal 4 and ECM terminal 78. Refer to Wiring Diagram.

**Continuity should exist.**

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**4. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

1. Check harness continuity between ECM terminal and HO2S2 terminal as follows. Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P1146	74	1	1
P1166	55	1	2

**Continuity should exist.**

2. Check harness continuity between the following terminals and ground. Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P1146	74	1	1
P1166	55	1	2

**Continuity should not exist.**

3. Also check harness for short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 5. CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-338, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> Replace malfunctioning heated oxygen sensor 2.

## 6. CHECK INTERMITTENT INCIDENT

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

### Component Inspection HEATED OXYGEN SENSOR 2

GBS00003

 With CONSULT-II

1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to the normal operating temperature.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
5. Let engine idle for 1 minute.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLANT TEMP/S	XXX °C


SEF174Y

6. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II.

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S2 (B1)	XXX V
HO2S2 (B2)	XXX V

PBIB1672E

7. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to  $\pm 25\%$ .



"HO2S2 (B1)/(B2)" should be above 0.68V at least once when the "FUEL INJECTION" is +25%.

"HO2S2 (B1)/(B2)" should be below 0.18V at least once when the "FUEL INJECTION" is -25%.

### CAUTION:


- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.



- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

⊗ **Without CONSULT-II**

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
4. Let engine idle for 1 minute.
5. Set voltmeter probes between ECM terminal 74 [HO2S2 (B1) signal] or 55 [HO2S2 (B2) signal] and ground.
6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.  
(Depress and release accelerator pedal as soon as possible.)  
**The voltage should be above 0.68V at least once during this procedure.**  
**If the voltage is above 0.68V at step 6, step 7 is not necessary.**
7. Keep vehicle at idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in D position with "OD" OFF (A/T), 4th gear position (M/T).  
**The voltage should be below 0.18V at least once during this procedure.**
8. If NG, replace heated oxygen sensor 2.



**CAUTION:**

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

## Removal and Installation HEATED OXYGEN SENSOR 2

GBS00004

Refer to [EM-23, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#) .

**DTC P1147, P1167 HO2S2**

PFP:226A0

**Component Description**


GBS00005

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas on each bank.

Even if switching characteristics of the air fuel ratio (A/F) sensor 1 are shifted, the air-fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



**CONSULT-II Reference Value in Data Monitor Mode**

GBS00006


Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S2 (B1) HO2S2 (B2)	<ul style="list-style-type: none"> <li>● Revving engine from idle to 3,000 rpm quickly after the following conditions are met</li> </ul>	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)	<ul style="list-style-type: none"> <li>- Engine: After warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul>	LEAN ↔ RICH

**On Board Diagnosis Logic**

GBS00007

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the air fuel ratio (A/F) sensor 1. The oxygen storage capacity of the three way catalyst (manifold) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the maximum voltage of the sensor is sufficiently high during the various driving condition such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1147 1147 (Bank 1)	Heated oxygen sensor 2 maximum voltage monitoring	The maximum voltage from the sensor is not reached to the specified voltage.	<ul style="list-style-type: none"> <li>● Harness or connectors (The sensor circuit is open or shorted)</li> <li>● Heated oxygen sensor 2</li> <li>● Fuel pressure</li> <li>● Fuel injector</li> <li>● Intake air leaks</li> </ul>
P1167 1167 (Bank 2)			

**DTC Confirmation Procedure**

**CAUTION:**

Always drive vehicle at a safe speed.

**NOTE:**

- “COMPLETED” will appear on CONSULT-II screen when all tests “COND1”, “COND2” and “COND3” are completed.
- If DTC confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION:**

Never stop engine during this procedure. If the engine is stopped, retry procedure from step 2 in Procedure for COND1.

**WITH CONSULT-II**

**Procedure for COND1**

For the best results, perform “DTC WORK SUPPORT” at a temperature of 0 to 30°C (32 to 86°F).

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
4. Let engine idle for 1 minute.
5. Select “HO2S2 (B1) P1147” or “HO2S2 (B2) P1167” of “HO2S2” in “DTC WORK SUPPORT” mode with CONSULT-II.
6. Touch “START”.
7. Let engine idle for at least 30 seconds.
8. Rev engine up to 2,000 rpm two or three times quickly under no load.  
If “COMPLETED” appears on CONSULT-II screen, go to step 2 in Procedure for COND3.  
If “COMPLETED” does not appear on CONSULT-II screen, go to the following step.
9. When the following conditions are met, “TESTING” will be displayed at “COND1” on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 60 seconds.)

ENG SPEED	More than 1,000 rpm
B/FUEL SCHDL	More than 1.0 msec
COOLAN TEMP/S	70 - 105°C
Shift lever	Suitable position

<table border="1"> <tr> <th colspan="2">HO2S2 (B1) P1147</th> </tr> <tr> <td>COND1:</td> <td>OUT OF CONDITION</td> </tr> <tr> <td>COND2:</td> <td>INCOMPLETE</td> </tr> <tr> <td>COND3:</td> <td>INCOMPLETE</td> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <td>ENG SPEED</td> <td>XXX rpm</td> </tr> <tr> <td>B/FUEL SCHDL</td> <td>XXX msec</td> </tr> </table>	HO2S2 (B1) P1147		COND1:	OUT OF CONDITION	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	<table border="1"> <tr> <th colspan="2">HO2S2 (B1) P1147</th> </tr> <tr> <td>COND1:</td> <td>TESTING</td> </tr> <tr> <td>COND2:</td> <td>INCOMPLETE</td> </tr> <tr> <td>COND3:</td> <td>INCOMPLETE</td> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <td>ENG SPEED</td> <td>XXX rpm</td> </tr> <tr> <td>B/FUEL SCHDL</td> <td>XXX msec</td> </tr> </table>	HO2S2 (B1) P1147		COND1:	TESTING	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	<table border="1"> <tr> <th colspan="2">HO2S2 (B1) P1147</th> </tr> <tr> <td>COND1:</td> <td>COMPLETED</td> </tr> <tr> <td>COND2:</td> <td>INCOMPLETE</td> </tr> <tr> <td>COND3:</td> <td>INCOMPLETE</td> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <td>ENG SPEED</td> <td>XXX rpm</td> </tr> <tr> <td>B/FUEL SCHDL</td> <td>XXX msec</td> </tr> </table>	HO2S2 (B1) P1147		COND1:	COMPLETED	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec
HO2S2 (B1) P1147																																												
COND1:	OUT OF CONDITION																																											
COND2:	INCOMPLETE																																											
COND3:	INCOMPLETE																																											
MONITOR																																												
ENG SPEED	XXX rpm																																											
B/FUEL SCHDL	XXX msec																																											
HO2S2 (B1) P1147																																												
COND1:	TESTING																																											
COND2:	INCOMPLETE																																											
COND3:	INCOMPLETE																																											
MONITOR																																												
ENG SPEED	XXX rpm																																											
B/FUEL SCHDL	XXX msec																																											
HO2S2 (B1) P1147																																												
COND1:	COMPLETED																																											
COND2:	INCOMPLETE																																											
COND3:	INCOMPLETE																																											
MONITOR																																												
ENG SPEED	XXX rpm																																											
B/FUEL SCHDL	XXX msec																																											

PBIB0557E

**NOTE:**


- If “TESTING” is not displayed after 5 minutes, retry from step 2 in Procedure for COND1.
- If “COMPLETED” already appears at “COND2” on CONSULT-II screen before Procedure for COND2 is conducted, it is unnecessary to conduct step 1 in Procedure for COND2.

**Procedure for COND2**

1. While driving, release accelerator pedal completed with "OD" OFF (A/T models only) from the above condition [step 9] until "INCOMPLETE" at "COND2" on CONSULT-II screen has turned to "COMPLETED" (It will take approximately 4 seconds.)


**NOTE:**

If "COMPLETE" already appears at "COND3" on CONSULT-II screen before Procedure for COND3 is conducted, it is unnecessary to conduct step 1 in Procedure for COND3.



**Procedure for COND3**

1. Stop vehicle and let it idle until "INCOMPLETE" of "COND3" on CONSULT-II screen has turned to "COMPLETED". (It will take a maximum of approximately 6 minutes.)
2. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".  
If "NG" is displayed, refer to [EC-346. "Diagnostic Procedure"](#) .  
If "CAN NOT BE DIAGNOSED" is displayed, perform the following.
  - a. Turn ignition switch OFF and leave the vehicle in a cool place (soak the vehicle).
  - b. Turn ignition switch ON and select "COOLAN TEMP/S" in "DATA MONITOR" mode with CONSULT-II
  - c. Start engine and warm it up while monitoring "COOLAN TEMP/S" indication on CONSULT-II.
  - d. When "COOLAN TEMP/S" indication reaches to 70°C (158°F), go to step 3 in Procedure for COND 1.




**Overall Function Check**

GBS00009

Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a 1st trip DTC might not be confirmed.





**WITH GST**

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
4. Let engine idle for 1 minute.
5. Set voltmeter probes between ECM terminal 74 [HO2S2 (B1) signal] or 55 [HO2S2 (B2) signal] and ground.
6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.  
(Depress and release accelerator pedal as soon as possible.)  
**The voltage should be above 0.68V at least once during this procedure.**  
**If the voltage can be confirmed in step 6, step 7 is not necessary.**
7. Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in D position with "OD" OFF (A/T), 4th gear position (M/T).  
**The voltage should be above 0.68V at least once during this procedure.**
8. If NG, go to [EC-346. "Diagnostic Procedure"](#) .



Wiring Diagram  
BANK 1

EC-O2S2B1-01



## DTC P1147, P1167 HO2S2

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.



**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
25	SB	Heated oxygen sensor 2 heater (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed is below 3,600 rpm after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: after warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - 1.0V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> </ul> <b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed: Above 3,600 rpm</li> </ul>	BATTERY VOLTAGE (11 - 14V)
74	O	Heated oxygen sensor 2 (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Revving engine from idle to 3,000 rpm quickly after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: after warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - Approximately 1.0V
78	B	Sensor ground (Heated oxygen sensor 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● <b>Warm-up condition</b></li> <li>● Idle speed</li> </ul>	Approximately 0V

BANK 2

EC-O2S2B2-01



Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
6	R	Heated oxygen sensor 2 heater (Bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed is below 3,600 rpm after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: after warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - 1.0V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> </ul> <b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed: Above 3,600 rpm</li> </ul>	BATTERY VOLTAGE (11 - 14V)
55	G	Heated oxygen sensor 2 (Bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Revving engine from idle to 3,000 rpm quickly after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: after warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - Approximately 1.0V
78	B	Sensor ground (Heated oxygen sensor 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● <b>Warm-up condition</b></li> <li>● Idle speed</li> </ul>	Approximately 0V

**Diagnostic Procedure**

GBS0000B

**1. CHECK GROUND CONNECTIONS**

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-145, "Ground Inspection"](#).



← : Vehicle front

- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

**OK or NG**


- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.



**2. CLEAR THE SELF-LEARNING DATA**


**④ With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.  
**Is the 1st trip DTC P0171 or P0174 detected?**  
**Is it difficult to start engine?**



**⊗ Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-56, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.  
**Is the 1st trip DTC P0171 or P0174 detected?**  
**Is it difficult to start engine?**




Yes or No

- Yes >> Perform trouble diagnosis for DTC P0171 or P0174. Refer to [EC-207](#).
- No >> GO TO 3.

### 3. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect heated oxygen sensor 2 harness connector.



1. Heated oxygen sensor 2 (bank 2)
2. Heated oxygen sensor 2 (bank 2) harness connector
3. Heated oxygen sensor 2 (bank 1) harness connector
4. Heated oxygen sensor 2 (bank 1)

3. Disconnect ECM harness connector.
4. Check harness continuity between HO2S2 terminal 4 and ECM terminal 78. Refer to Wiring Diagram.

**Continuity should exist.**

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

### 4. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal and HO2S2 terminal as follows. Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P1147	74	1	1
P1167	55	1	2

**Continuity should exist.**

2. Check harness continuity between the following terminals and ground. Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P1147	74	1	1
P1167	55	1	2

**Continuity should not exist.**

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**5. CHECK HEATED OXYGEN SENSOR 2**

Refer to [EC-349, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> Replace malfunctioning heated oxygen sensor 2.

**6. CHECK INTERMITTENT INCIDENT**

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

**Component Inspection  
HEATED OXYGEN SENSOR 2**

GBS0000C

Ⓟ With CONSULT-II

1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to the normal operating temperature.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
5. Let engine idle for 1 minute.
6. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II.


DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S2 (B1)	XXX V
HO2S2 (B2)	XXX V

PBIB1672E

7. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to ±25%.



"HO2S2 (B1)/(B2)" should be above 0.68V at least once when the "FUEL INJECTION" is +25%.  
 "HO2S2 (B1)/(B2)" should be below 0.18V at least once when the "FUEL INJECTION" is -25%.


**CAUTION:**

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

⊗ Without CONSULT-II

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
4. Let engine idle for 1 minute.
5. Set voltmeter probes between ECM terminal 74 [HO2S2 (B1) signal] or 55 [HO2S2 (B2) signal] and ground.
6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.  
(Depress and release accelerator pedal as soon as possible.)  
**The voltage should be above 0.68V at least once during this procedure.**  
**If the voltage is above 0.68V at step 6, step 7 is not necessary.**
7. Keep vehicle at idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in D position with "OD" OFF (A/T), 4th gear position (M/T).  
**The voltage should be below 0.18V at least once during this procedure.**
8. If NG, replace heated oxygen sensor 2.



**CAUTION:**

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

## Removal and Installation HEATED OXYGEN SENSOR 2

GBS0000D

Refer to [EM-23, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#) .

## DTC P1217 ENGINE OVER TEMPERATURE

PFP:00000

### Description SYSTEM DESCRIPTION

GBS0000M

**NOTE:**

If DTC P1217 is displayed with DTC U1000 or U1001, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-146, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#).

### Cooling Fan Control


Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed*1	Cooling fan control	IPDM E/R (Cooling fan relays)
Battery	Battery voltage*1		
Wheel sensor	Vehicle speed*2		
Engine coolant temperature sensor	Engine coolant temperature		
Air conditioner switch	Air conditioner ON signal*2		
Refrigerant pressure sensor	Refrigerant pressure		

\*1: The ECM determines the start signal status by the signals of engine speed and battery voltage.

\*2: This signal is sent to ECM through CAN communication line.

The ECM controls the cooling fan corresponding to the vehicle speed, engine coolant temperature, refrigerant pressure, and air conditioner ON signal. The control system has 3-step control [HIGH/LOW/OFF].

### Cooling Fan Operation



# DTC P1217 ENGINE OVER TEMPERATURE

[VQ TYPE 1]

## Cooling Fan Relay Operation

The ECM controls cooling fan relays in the IPDM E/R through CAN communication line.

Cooling fan speed	Cooling fan relay	
	1	2
Stop (OFF)	OFF	OFF
Low (LOW)	ON	OFF
High (HI)	OFF	ON

## COMPONENT DESCRIPTION

### Cooling Fan Motor

The cooling fan operates at each speed when the current flows in the cooling fan motor as follows.

Cooling fan speed	Cooling fan motor terminals	
	(+)	(-)
Low (LOW)	1	3
High (HI)	2	3

## CONSULT-II Reference Value in Data Monitor Mode

GBS0000N

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
AIR COND SIG	● Engine: After warming up, idle the engine	Air conditioner switch: OFF OFF
		Air conditioner switch: ON (Compressor operates.) ON
COOLING FAN	● Engine: After warming up, idle the engine ● Air conditioner switch: OFF	Engine coolant temperature: 97°C (207°F) or less OFF
		Engine coolant temperature: Between 98°C (208°F) and 104°C (219°F) LOW
		Engine coolant temperature: 105°C (221°F) or more HI

## On Board Diagnosis Logic

GBS00000

If the cooling fan or another component in the cooling system malfunctions, engine coolant temperature will rise.

When the engine coolant temperature reaches an abnormally high temperature condition, a malfunction is indicated.

**This self-diagnosis has the one trip detection logic.**

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1217 1217	Engine over temperature (Overheat)	<ul style="list-style-type: none"> <li>● Cooling fan does not operate properly (Overheat).</li> <li>● Cooling fan system does not operate properly (Overheat).</li> <li>● Engine coolant level was not added to the system using the proper filling method.</li> <li>● Engine coolant is not within the specified range.</li> </ul>	<ul style="list-style-type: none"> <li>● Harness or connectors (The cooling fan circuit is open or shorted.)</li> <li>● IPDM E/R</li> <li>● Cooling fan</li> <li>● Cooling fan (Crankshaft driven)</li> <li>● Radiator hose</li> <li>● Radiator</li> <li>● Radiator cap</li> <li>● Reservoir tank</li> <li>● Reservoir tank cap</li> <li>● Water pump</li> <li>● Thermostat</li> </ul> <p>For more information, refer to <a href="#">EC-359</a>, "<a href="#">Main 12 Causes of Overheating</a>".</p>

**CAUTION:**

When a malfunction is indicated, be sure to replace the coolant. Refer to [MA-17, "Changing Engine Coolant"](#). Also, replace the engine oil. Refer to [MA-20, "Changing Engine Oil"](#).

1. Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute. Be sure to use coolant with the proper mixture ratio. Refer to [MA-15, "Engine Coolant Mixture Ratio"](#).
2. After refilling coolant, run engine to ensure that no water-flow noise is emitted.

## Overall Function Check

GBS0000P

Use this procedure to check the overall function of the cooling fan. During this check, a DTC might not be confirmed.

**WARNING:**

Never remove a radiator cap and/or a reservoir tank cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator and/or reservoir tank.

Wrap a thick cloth around cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.

**WITH CONSULT-II**


1. Check the coolant level in the reservoir tank and radiator.

**NOTE:**

**Allow engine to cool before checking coolant level.**

If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to [EC-357, "Diagnostic Procedure"](#).

2. Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to [EC-357, "Diagnostic Procedure"](#).
3. Turn ignition switch ON.



# DTC P1217 ENGINE OVER TEMPERATURE

[VQ TYPE 1]

4. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II.
5. If the results are NG, go to [EC-357, "Diagnostic Procedure"](#) .

ACTIVE TEST	
COOLING FAN	OFF
MONITOR	
COOLANT TEMP/S	XXX °C

SEF646X

## WITH GST


1. Check the coolant level in the reservoir tank and radiator.

### NOTE:

**Allow engine to cool before checking coolant level.**

If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to [EC-357, "Diagnostic Procedure"](#) .

2. Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to [EC-357, "Diagnostic Procedure"](#) .
3. Perform IPDM E/R auto active test and check cooling fan motors operation, refer to [PG-19, "Auto Active Test"](#) .
4. If NG, go to [EC-357, "Diagnostic Procedure"](#) .








# DTC P1217 ENGINE OVER TEMPERATURE

[VQ TYPE 1]

GBS0000Q

## Wiring Diagram


A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



# DTC P1217 ENGINE OVER TEMPERATURE

[VQ TYPE 1]

## EC-COOL/F-02



21	20	19
24	23	22

(E14)  
W



3	1	2
---	---	---

(E42)  
GR

MBWA1384E

## Diagnostic Procedure

### 1. CHECK COOLING FAN (CRANKSHAFT DRIVEN) OPERATION

1. Start engine and let it idle.
2. Make sure that cooling fan (crankshaft driven) operates normally.

OK or NG

OK (With CONSULT-II)>>GO TO 2.

OK (Without CONSULT-II)>>GO TO 3.

NG >> Check cooling fan (crankshaft driven). Refer to [CO-21, "Removal and Installation \(Crankshaft Driven Type\)"](#) .

### 2. CHECK COOLING FAN OPERATION

#### Ⓜ With CONSULT-II

1. Start engine and let it idle.
2. Select "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II.
3. Make sure that cooling fan operate at each speed (LOW/HI).

OK or NG

OK >> GO TO 4.

NG >> Check cooling fan control circuit. (Go to [EC-358, "PROCEDURE A"](#) .)

ACTIVE TEST	
COOLING FAN	LOW
MONITOR	
COOLANT TEMP/S	XXX °C

SEF784Z

### 3. CHECK COOLING FAN OPERATION

#### ⓧ Without CONSULT-II

1. Perform IPDM E/R auto active test and check cooling fan motor operation, refer to [PG-19, "Auto Active Test"](#) .
2. Make sure that cooling fan operate at each speed (Low/High).

OK or NG

OK >> GO TO 4.

NG >> Check cooling fan control circuit. (Go to [EC-358, "PROCEDURE A"](#) .)

### 4. CHECK COOLING SYSTEM FOR LEAK

Refer to [CO-10, "CHECKING RADIATOR SYSTEM FOR LEAKS"](#) .

OK or NG

OK >> GO TO 5.

NG >> Check the following for leak. Refer to [CO-10, "CHECKING RADIATOR SYSTEM FOR LEAKS"](#) .

- Hose
- Radiator
- Radiator cap
- Water pump
- Reservoir tank

### 5. CHECK RESERVOIR TANK CAP

Refer to [CO-15, "Checking Reservoir Tank Cap"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace reservoir tank cap.

## 6. CHECK COMPONENT PARTS

Check the following.

- Thermostat. Refer to [CO-27, "WATER INLET AND THERMOSTAT ASSEMBLY"](#) .
- Engine coolant temperature sensor. Refer to [EC-179, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 7.
- NG >> Replace malfunctioning component.

## 7. CHECK MAIN 12 CAUSES

If the cause cannot be isolated, go to [EC-359, "Main 12 Causes of Overheating"](#) .

>> INSPECTION END

### PROCEDURE A


#### 1. CHECK COOLILNG FAN POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R harness connectors E14.
3. Check voltage between IPDM E/R terminal 22 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



#### 2. DETECT MALFUNCTIONING PART

Check the following.

- 40A fusible link
- Harness for open or short between IPDM E/R and battery

>> Repair open circuit or short to ground in harness or connectors.

#### 3. CHECK IPDM E/R GROUND CIRCUIT

1. Disconnect IPDM E/R harness connectors E17, E18.
2. Check harness continuity between IPDM E/R terminal 38, 59 and ground. Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 4.
- NG >> Repair open circuit or short to power in harness or connectors.

## 4. CHECK COOLING FAN MOTOR CIRCUIT FOR OPEN AND SHORT


1. Disconnect cooling fan motor harness connector (1).
2. Check harness continuity between the following; cooling fan motor terminal 1 and IPDM E/R terminal 20, cooling fan motor terminal 2 and IPDM E/R terminal 24. Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

**OK or NG**

- OK >> GO TO 5.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.



## 5. CHECK COOLING FAN MOTOR GROUND CIRCUIT FOR OPEN OR SHORT

1. Check harness continuity between cooling fan motor terminal 3 and ground. Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to power.

**OK or NG**

- OK >> GO TO 6.
- NG >> Repair open circuit or short to power in harness or connectors.

## 6. CHECK COOLING FAN MOTOR

Refer to [EC-360, "Component Inspection"](#) .

**OK or NG**

- OK >> GO TO 7.
- NG >> Replace cooling fan motors.

## 7. CHECK INTERMITTENT INCIDENT

Perform [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

**OK or NG**

- OK >> Replace IPDM E/R. Refer to [PG-14, "IPDM E/R \(INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM\)"](#) .
- NG >> Repair or replace harness or connector.

## Main 12 Causes of Overheating

GBS0000S

Engine	Step	Inspection item	Equipment	Standard	Reference page
OFF	1	<ul style="list-style-type: none"> <li>● Blocked radiator</li> <li>● Blocked condenser</li> <li>● Blocked radiator grille</li> <li>● Blocked bumper</li> </ul>	● Visual	No blocking	—
	2	● Coolant mixture	● Coolant tester	50 - 50% coolant mixture	<a href="#">MA-15</a>
	3	● Coolant level	● Visual	Coolant up to MAX level in reservoir tank and radiator filler neck	<a href="#">MA-17</a>
	4	● Reservoir tank cap	● Pressure tester	59 - 117.8 kPa (0.59 - 1.18 bar, 0.6 - 1.2 kg/cm <sup>2</sup> , 9 - 17 psi) (Limit)	<a href="#">CO-15</a>
ON*2	5	● Coolant leaks	● Visual	No leaks	<a href="#">CO-10</a>

# DTC P1217 ENGINE OVER TEMPERATURE

[VQ TYPE 1]

Engine	Step	Inspection item	Equipment	Standard	Reference page
ON*2	6	● Thermostat	● Touch the upper and lower radiator hoses	Both hoses should be hot	<a href="#">CO-27</a>
ON*1	7	● Cooling fan	● CONSULT-II	Operating	See trouble diagnosis for DTC P1217 ( <a href="#">EC-351</a> ).
ON*2	7	● Cooling fan (Crankshaft driven)	● Visual	Operating	See <a href="#">CO-21</a> .
OFF	8	● Combustion gas leak	● Color checker chemical tester 4 Gas analyzer	Negative	—
ON*3	9	● Coolant temperature gauge	● Visual	Gauge less than 3/4 when driving	—
		● Coolant overflow to reservoir tank	● Visual	No overflow during driving and idling	<a href="#">MA-17</a>
OFF*4	10	● Coolant return from reservoir tank to radiator	● Visual	Should be initial level in reservoir tank	<a href="#">MA-17</a>
OFF	11	● Cylinder head	● Straight gauge feeler gauge	0.1 mm (0.004 in) Maximum distortion (warping)	<a href="#">EM-93</a>
	12	● Cylinder block and pistons	● Visual	No scuffing on cylinder walls or piston	<a href="#">EM-107</a>

\*1: Turn the ignition switch ON.

\*2: Engine running at 3,000 rpm for 10 minutes.

\*3: Drive at 90 km/h (55 MPH) for 30 minutes and then let idle for 10 minutes.

\*4: After 60 minutes of cool down time.

For more information, refer to [CO-6, "OVERHEATING CAUSE ANALYSIS"](#).

## Component Inspection COOLING FAN MOTOR


GBS0000T

1. Disconnect cooling fan motor harness connector.
2. Supply cooling fan motor terminals with battery voltage and check operation.

Cooling fan speed	Cooling fan motor terminals	
	(+)	(-)
Low	1	3
High	2	3

**Cooling fan motor should operate.**

If NG, replace cooling fan motor.



MBIB1241E

**DTC P1225 TP SENSOR**


PF16119

**Component Description**

GBS0000U

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



**On Board Diagnosis Logic**

GBS0000V

The MIL will not light up for this diagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1225 1225	Closed throttle position learning performance	Closed throttle position learning value is excessively low.	<ul style="list-style-type: none"> <li>Electric throttle control actuator (TP sensor 1 and 2)</li> </ul>

**DTC Confirmation Procedure**

GBS0000W

**NOTE:**


If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

**WITH CONSULT-II**

- Turn ignition switch ON.
- Select "DATA MONITOR" mode with CONSULT-II.
- Turn ignition switch OFF and wait at least 10 seconds.
- Turn ignition switch ON.
- If 1st trip DTC is detected, go to [EC-362. "Diagnostic Procedure"](#)



**WITH GST**

Follow the procedure "WITH CONSULT-II" above.

**Diagnostic Procedure**

GBS0000X


**1. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY**

1. Turn ignition switch OFF.
2. Remove the intake air duct.
3. Check if foreign matter is caught between the throttle valve (1) and the housing.

**OK or NG**

OK &gt;&gt; GO TO 2.

NG &gt;&gt; Remove the foreign matter and clean the electric throttle control actuator inside.

**2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR**

1. Replace the electric throttle control actuator.
2. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-71, "Idle Air Volume Learning"](#) .

&gt;&gt; INSPECTION END

**Removal and Installation  
ELECTRIC THROTTLE CONTROL ACTUATOR**

GBS0000Y

Refer to [EM-18, "INTAKE MANIFOLD COLLECTOR"](#) .



**DTC P1226 TP SENSOR**


PF0:16119

**Component Description**

GBS000OZ

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



**On Board Diagnosis Logic**

GBS000P0

The MIL will not light up for this diagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1226 1226	Closed throttle position learning performance	Closed throttle position learning is not performed successfully, repeatedly.	<ul style="list-style-type: none"> <li>Electric throttle control actuator (TP sensor 1 and 2)</li> </ul>

**DTC Confirmation Procedure**

GBS000P1

**NOTE:**


If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

**WITH CONSULT-II**

- Turn ignition switch ON.
- Select "DATA MONITOR" mode with CONSULT-II.
- Turn ignition switch OFF and wait at least 10 seconds.
- Turn ignition switch ON.
- Repeat steps 3 and 4 for 32 times.
- If 1st trip DTC is detected, go to [EC-364, "Diagnostic Procedure"](#)



**WITH GST**

Follow the procedure "WITH CONSULT-II" above.


**Diagnostic Procedure****1. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY**

1. Turn ignition switch OFF.
2. Remove the intake air duct.
3. Check if foreign matter is caught between the throttle valve (1) and the housing.

**OK or NG**

OK &gt;&gt; GO TO 2.

NG &gt;&gt; Remove the foreign matter and clean the electric throttle control actuator inside.

**2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR**

1. Replace the electric throttle control actuator.
2. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-71, "Idle Air Volume Learning"](#) .

&gt;&gt; INSPECTION END

**Removal and Installation  
ELECTRIC THROTTLE CONTROL ACTUATOR**Refer to [EM-18, "INTAKE MANIFOLD COLLECTOR"](#) .

# DTC P1229 SENSOR POWER SUPPLY

[VQ TYPE 1]

## DTC P1229 SENSOR POWER SUPPLY

PF16119

### On Board Diagnosis Logic

GBS000P4

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1229 1229	Sensor power supply circuit short	ECM detects a voltage of power source for sensor is excessively low or high.	<ul style="list-style-type: none"> <li>● Harness or connectors (APP sensor 1 circuit is shorted.) (PSP sensor circuit is shorted.) (Refrigerant pressure sensor circuit is shorted.) (EVAP control system pressure sensor circuit is shorted.)</li> <li>● Accelerator pedal position sensor (APP sensor 1)</li> <li>● EVAP control system pressure sensor</li> <li>● Power steering pressure sensor</li> <li>● Refrigerant pressure sensor</li> </ul>

### FAIL-SAFE MODE

When the malfunction is detected, ECM enters fail-safe mode and the MIL lights up.

Engine operation condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

### DTC Confirmation Procedure

GBS000P5

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

#### WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-369, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

#### WITH GST

Follow the procedure "WITH CONSULT-II" above.

# DTC P1229 SENSOR POWER SUPPLY



[VQ TYPE 1]

GBS000P6

## Wiring Diagram

### EC-SEN/PW-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



MBWA1307E

# DTC P1229 SENSOR POWER SUPPLY

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**




TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
49	P	Sensor power supply (Refrigerant pressure sensor)	<b>[Ignition switch: ON]</b>	Approximately 5V
68	V	Sensor power supply (Power steering pressure sensor)	<b>[Ignition switch: ON]</b>	Approximately 5V
82	B	Sensor ground (APP sensor 1)	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed	Approximately 0V
83	O	Sensor ground (APP sensor 2)	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed	Approximately 0V
90	L	Sensor power supply (APP sensor 1)	<b>[Ignition switch: ON]</b>	Approximately 5V
91	G	Sensor power supply (APP sensor 2)	<b>[Ignition switch: ON]</b>	Approximately 5V
98	GR	Accelerator pedal position sensor 2	<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully released	0.3 - 0.45V
			<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully depressed	Less than 2.4V
106	R	Accelerator pedal position sensor 1	<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully released	0.6 - 0.95V
			<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully depressed	Less than 4.75V

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# DTC P1229 SENSOR POWER SUPPLY

[VQ TYPE 1]

## EC-SEN/PW-02



REFER TO THE FOLLOWING.  
 (C1) - SUPER MULTIPLE JUNCTION (SMJ)

# DTC P1229 SENSOR POWER SUPPLY

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECMs transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
32	W	EVAP control system pressure sensor	[Ignition switch: ON]	Approximately 1.8 - 4.8V
48	SB	Sensor power supply (EVAP control system pressure sensor)	[Ignition switch: ON]	Approximately 5V
67	GR	Sensor ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V

## Diagnostic Procedure

GBS000P7

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground three screws on the body. Refer to [EC-145, "Ground Inspection"](#) .



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

## 2. CHECK ACCELERATOR PEDAL POSITION SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect accelerator pedal position (APP) sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between APP sensor terminal 2 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 6.  
 NG >> GO TO 3.



## 3. CHECK SENSOR POWER SUPPLY CIRCUITS

Check harness for short to power and short to ground, between the following terminals.

ECM terminal	Sensor terminal	Reference Wiring Diagram
90	APP sensor terminal 2	<a href="#">EC-366</a>
48	EVAP control system pressure sensor terminal 3	<a href="#">EC-366</a>
49	Refrigerant pressure sensor terminal 3	<a href="#">EC-557</a>
68	PSP sensor terminal 3	<a href="#">EC-284</a>

OK or NG

- OK >> GO TO 4.  
 NG >> Repair short to ground or short to power in harness or connectors.

## 4. CHECK COMPONENTS

Check the following.

- Refrigerant pressure sensor (Refer to [MTC-77, "COMPONENT INSPECTION"](#) .)
- Power steering pressure sensor (Refer to [EC-287, "Component Inspection"](#) .)


OK or NG

- OK >> GO TO 5.  
 NG >> Replace malfunctioning component.



**5. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR**

1. Remove EVAP control system pressure sensor with its harness connector connected from EVAP canister. **Always replace O-ring with a new one.**




2. Install a vacuum pump to EVAP control system pressure sensor.
3. Turn ignition switch ON and check output voltage between ECM terminal 32 and ground under the following conditions.

Applied vacuum kPa (mbar, mmHg, inHg)	Voltage V
Not applied	1.8 - 4.8
-26.7 (-267, -200, -7.87)	2.1 to 2.5V lower than above value

**CAUTION:**

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-933 mbar, -700 mmHg, -27.56 inHg) or pressure over 101.3 kPa (1013 mbar, 760 mmHg, 29.92 inHg).



OK or NG

- OK >> GO TO 8.
- NG >> Replace EVAP control system pressure sensor.

**6. CHECK APP SENSOR**

Refer to [EC-483, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

**7. REPLACE ACCELERATOR PEDAL ASSEMBLY**

1. Replace accelerator pedal assembly.
2. Perform [EC-71, "Accelerator Pedal Released Position Learning"](#) .
3. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
4. Perform [EC-71, "Idle Air Volume Learning"](#) .

>> INSPECTION END

**8. CHECK INTERMITTENT INCIDENT**

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

DTC P1271, P1281 A/F SENSOR 1

PFP:22693


Component Description

GBS000P8


The air fuel ratio (A/F) sensor is a planar dual-cell limit current sensor. The sensor element of the air fuel ratio (A/F) sensor is the combination of a Nernst concentration cell (sensor cell) with an oxygen-pump cell, which transports ions. It has a heater in the element.

The sensor is capable of precise measurement  $\lambda = 1$ , but also in the lean and rich range. Together with its control electronics, the sensor outputs a clear, continuous signal throughout a wide  $\lambda$  range ( $0.7 < \lambda < \text{air}$ ).

The exhaust gas components diffuse through the diffusion gap at the electrode of the oxygen pump and Nernst concentration cell, where they are brought to thermodynamic balance.



An electronic circuit controls the pump current through the oxygen-pump cell so that the composition of the exhaust gas in the diffusion gap remains constant at  $\lambda = 1$ . Therefore, the air fuel ratio (A/F) sensor is able to indicate air/fuel ratio by this pumping of current. In addition, a heater is integrated in the sensor to ensure the required operating temperature of 700 - 800°C (1,292 - 1,472°F).



CONSULT-II Reference Value in Data Monitor Mode

GBS000P9

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
A/F SEN1 (B1) A/F SEN1 (B2)	● Engine: After warming up Maintaining engine speed at 2,000 rpm	Fluctuates around 1.5V

On Board Diagnosis Logic

GBS000PA

To judge the malfunction, the diagnosis checks that the A/F signal computed by ECM from the air fuel ratio (A/F) sensor 1 signal is not inordinately low.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause
P1271 1271 (Bank 1)	Air fuel ratio (A/F) sensor 1 circuit no activity detected	● The A/F signal computed by ECM from the air fuel ratio (A/F) sensor 1 signal is constantly approx. 0V.	<ul style="list-style-type: none"> <li>● Harness or connectors (The air fuel ratio (A/F) sensor 1 circuit is open or shorted.)</li> <li>● Air fuel ratio (A/F) sensor 1</li> </ul>
P1281 1281 (Bank 2)			

DTC Confirmation Procedure

GBS000PB

**CAUTION:**

Always drive vehicle at a safe speed.

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

**WITH CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Select "A/F SEN1 (B1)" or "A/F SEN1 (B2)" in "DATA MONITOR" mode with CONSULT-II.

# DTC P1271, P1281 A/F SENSOR 1

[VQ TYPE 1]

3. Check "A/F SEN1 (B1)" or "A/F SEN1 (B2)" indication.  
If the indication is constantly approx. 0V, go to [EC-377, "Diagnostic Procedure"](#).  
If the indication is not constantly approx. 0V, go to next step.
4. Turn ignition switch OFF, wait at least 10 seconds and then restart engine.
5. Drive and accelerate vehicle to more than 40 km/h (25 MPH) within 20 seconds after restarting engine.
6. Maintain the following conditions for about 20 consecutive seconds.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
A/F SEN1 (B1)	XXX V

SEF581Z

ENG SPEED	1,000 - 3,200 rpm
VHCL SPEED SE	More than 40 km/h (25 MPH)
B/FUEL SCHDL	1.5 - 9.0 msec
Gear position	Suitable position

**NOTE:**

- Keep the accelerator pedal as steady as possible during the cruising.
  - If this procedure is not completed within 1 minute after restarting engine at step 4, return to step 4.
7. If 1st trip DTC is displayed, go to [EC-377, "Diagnostic Procedure"](#).

 **WITH GST**

Follow the procedure "WITH CONSULT-II" above.



# DTC P1271, P1281 A/F SENSOR 1

[VQ TYPE 1]


GBS000PC

## Wiring Diagram BANK 1


EC-AF1B1-01




(E12)  
W



(F1)  
B



(F2)  
W



(F28)  
B


# DTC P1271, P1281 A/F SENSOR 1

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
2	L	A/F sensor 1 heater (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 5V★  PBIB1584E
16	SB	A/F sensor 1 (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 3.1V
35	O			Approximately 2.6V
56	LG			Approximately 2.3V
75	P			Approximately 2.3V






★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# DTC P1271, P1281 A/F SENSOR 1

[VQ TYPE 1]

BANK 2

EC-AF1B2-01




# DTC P1271, P1281 A/F SENSOR 1

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
24	G	A/F sensor 1 heater (Bank 2)	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed	Approximately 5V★  PBIB1584E
57	GR	A/F sensor 1 (Bank 2)	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed	Approximately 2.6V
58	O			Approximately 2.3V
76	V			Approximately 3.1V
77	Y			Approximately 2.3V


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

GBS000PD

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-145, "Ground Inspection"](#).



↔ : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

**OK or NG**

- OK >> GO TO 2.  
NG >> Repair or replace ground connections.

## 2. CHECK AIR FUEL RATIO (A/F) SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect air fuel ratio (A/F) sensor 1 harness connector.




2. Turn ignition switch ON.
3. Check voltage between air fuel ratio (A/F) sensor 1 terminal 3 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



## 3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E8, F2
- IPDM E/R connector E12
- 10A fuse
- Harness for open or short between air fuel ratio (A/F) sensor 1 and fuse

>> Repair or replace harness or connectors.



**4. CHECK AIR FUEL RATIO (A/F) SENSOR 1 INPUT SIGNAL CIRCUIT**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between the following terminals.  
Refer to Wiring Diagram.

	A/F sensor 1 terminal	ECM terminal
Bank1	1	16
	2	75
	5	35
	6	56
Bank 2	1	76
	2	77
	5	57
	6	58

**Continuity should exist.**

4. Check harness continuity between the following terminals and ground.  
Refer to Wiring Diagram.

Bank 1		Bank 2	
A/F sensor 1 terminal	ECM terminal	A/F sensor 1 terminal	ECM terminal
1	16	1	76
2	75	2	77
5	35	5	57
6	56	6	58

**Continuity should not exist.**

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**5. CHECK INTERMITTENT INCIDENT**

Perform [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> Repair or replace.

**6. REPLACE AIR FUEL RATIO (A/F) SENSOR 1**

Replace air fuel ratio (A/F) sensor 1.

**CAUTION:**

- Discard any air fuel ratio (A/F) sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new air fuel ratio (A/F) sensor, clean exhaust system threads using Heated Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

>> INSPECTION END

---

**Removal and Installation**  
**AIR FUEL RATIO (A/F) SENSOR 1**

GBS000PE

Refer to [EM-23, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#) .

**DTC P1272, P1282 A/F SENSOR 1**

PFP:22693


**Component Description**

GBS000PF


The air fuel ratio (A/F) sensor is a planar dual-cell limit current sensor. The sensor element of the air fuel ratio (A/F) sensor is the combination of a Nernst concentration cell (sensor cell) with an oxygen-pump cell, which transports ions. It has a heater in the element.

The sensor is capable of precise measurement  $\lambda = 1$ , but also in the lean and rich range. Together with its control electronics, the sensor outputs a clear, continuous signal throughout a wide  $\lambda$  range ( $0.7 < \lambda < \text{air}$ ).

The exhaust gas components diffuse through the diffusion gap at the electrode of the oxygen pump and Nernst concentration cell, where they are brought to thermodynamic balance.



An electronic circuit controls the pump current through the oxygen-pump cell so that the composition of the exhaust gas in the diffusion gap remains constant at  $\lambda = 1$ . Therefore, the air fuel ratio (A/F) sensor is able to indicate air/fuel ratio by this pumping of current. In addition, a heater is integrated in the sensor to ensure the required operating temperature of 700 - 800°C (1,292 - 1,472°F).



**CONSULT-II Reference Value in Data Monitor Mode**

GBS000PG

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
A/F SEN1 (B1) A/F SEN1 (B2)	● Engine: After warming up Maintaining engine speed at 2,000 rpm	Fluctuates around 1.5V

**On Board Diagnosis Logic**

GBS000PH

To judge the malfunction, the diagnosis checks that the A/F signal computed by ECM from the air fuel ratio (A/F) sensor 1 signal is not inordinately high.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause
P1272 1272 (Bank 1)	Air fuel ratio (A/F) sensor 1 circuit no activity detected	● The A/F signal computed by ECM from the air fuel ratio (A/F) sensor 1 signal is constantly approx. 5V.	<ul style="list-style-type: none"> <li>● Harness or connectors (The air fuel ratio (A/F) sensor 1 circuit is open or shorted.)</li> <li>● Air fuel ratio (A/F) sensor 1</li> </ul>
P1282 1282 (Bank 2)			

**DTC Confirmation Procedure**

GBS000PI

**CAUTION:**

Always drive vehicle at a safe speed.

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

**WITH CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Select "A/F SEN1 (B1)" or "A/F SEN1 (B2)" in "DATA MONITOR" mode with CONSULT-II.

# DTC P1272, P1282 A/F SENSOR 1

[VQ TYPE 1]

3. Check "A/F SEN1 (B1)" or "A/F SEN1 (B2)" indication.  
If the indication is constantly approx. 5V, go to [EC-386. "Diagnostic Procedure"](#) .  
If the indication is not constantly approx. 5V, go to next step.
4. Turn ignition switch OFF, wait at least 10 seconds and then restart engine.
5. Drive and accelerate vehicle to more than 40 km/h (25 MPH) within 20 seconds after restarting engine.
6. Maintain the following conditions for about 20 consecutive seconds.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
A/F SEN1 (B1)	XXX V

SEF581Z

ENG SPEED	1,000 - 3,200 rpm
VHCL SPEED SE	More than 40 km/h (25 MPH)
B/FUEL SCHDL	1.5 - 9.0 msec
Shift lever	Suitable position

**NOTE:**

- Keep the accelerator pedal as steady as possible during the cruising.
  - If this procedure is not completed within 1 minute after restarting engine at step 4, return to step 4.
7. If 1st trip DTC is displayed, go to [EC-386. "Diagnostic Procedure"](#) .

 **WITH GST**

Follow the procedure "WITH CONSULT-II" above.






# DTC P1272, P1282 A/F SENSOR 1

[VQ TYPE 1]

## Wiring Diagram BANK 1

GBS000PJ

EC-AF1B1-01




# DTC P1272, P1282 A/F SENSOR 1

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
2	L	A/F sensor 1 heater (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 5V★  <small>PBIB1584E</small>
16	SB	A/F sensor 1 (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 3.1V
35	O			Approximately 2.6V
56	LG			Approximately 2.3V
75	P			Approximately 2.3V






★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# DTC P1272, P1282 A/F SENSOR 1

[VQ TYPE 1]

BANK 2

EC-AF1B2-01



# DTC P1272, P1282 A/F SENSOR 1

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
24	G	A/F sensor 1 heater (Bank 2)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 5V★  PBB1584E
57	GR	A/F sensor 1 (Bank 2)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 2.6V
58	O			Approximately 2.3V
76	V			Approximately 3.1V
77	Y			Approximately 2.3V


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

GBS000PK

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws. Refer to [EC-145, "Ground Inspection"](#).



↔ : Vehicle front

- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |


**OK or NG**

- OK >> GO TO 2.  
NG >> Repair or replace ground connections.



## 2. CHECK AIR FUEL RATIO (A/F) SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect air fuel ratio (A/F) sensor 1 harness connector.




2. Turn ignition switch ON.
3. Check voltage between air fuel ratio (A/F) sensor 1 terminal 3 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



## 3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E8, F2
- IPDM E/R connector E12
- 10A fuse
- Harness for open or short between air fuel ratio (A/F) sensor 1 and fuse

>> Repair or replace harness or connectors.

#### 4. CHECK AIR FUEL RATIO (A/F) SENSOR 1 INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between the following terminals.  
Refer to Wiring Diagram.

	A/F sensor 1 terminal	ECM terminal
Bank1	1	16
	2	75
	5	35
	6	56
Bank 2	1	76
	2	77
	5	57
	6	58

**Continuity should exist.**

4. Check harness continuity between the following terminals and ground.  
Refer to Wiring Diagram.

Bank 1		Bank 2	
A/F sensor 1 terminal	ECM terminal	A/F sensor 1 terminal	ECM terminal
1	16	1	76
2	75	2	77
5	35	5	57
6	56	6	58

**Continuity should not exist.**

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

#### 5. CHECK INTERMITTENT INCIDENT

Perform [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

OK >> GO TO 6.

NG >> Repair or replace.

#### 6. REPLACE AIR FUEL RATIO (A/F) SENSOR 1

Replace air fuel ratio (A/F) sensor 1.

**CAUTION:**

- Discard any air fuel ratio (A/F) sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new air fuel ratio (A/F) sensor, clean exhaust system threads using Heated Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

>> INSPECTION END

**Removal and Installation**  
**AIR FUEL RATIO (A/F) SENSOR 1**

GBS000PL

A

Refer to [EM-23, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#) .

EC

C

D

E

F

G

H

I

J

K

L

M

**DTC P1273, P1283 A/F SENSOR 1**

PFP:22693


**Component Description**

GBS000PM


The air fuel ratio (A/F) sensor is a planar dual-cell limit current sensor. The sensor element of the air fuel ratio (A/F) sensor is the combination of a Nernst concentration cell (sensor cell) with an oxygen-pump cell, which transports ions. It has a heater in the element.

The sensor is capable of precise measurement  $\lambda = 1$ , but also in the lean and rich range. Together with its control electronics, the sensor outputs a clear, continuous signal throughout a wide  $\lambda$  range ( $0.7 < \lambda < \text{air}$ ).

The exhaust gas components diffuse through the diffusion gap at the electrode of the oxygen pump and Nernst concentration cell, where they are brought to thermodynamic balance.



An electronic circuit controls the pump current through the oxygen-pump cell so that the composition of the exhaust gas in the diffusion gap remains constant at  $\lambda = 1$ . Therefore, the air fuel ratio (A/F) sensor is able to indicate air/fuel ratio by this pumping of current. In addition, a heater is integrated in the sensor to ensure the required operating temperature of 700 - 800°C (1,292 - 1,472°F).



**CONSULT-II Reference Value in Data Monitor Mode**

GBS000PN

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
A/F SEN1 (B1) A/F SEN1 (B2)	● Engine: After warming up Maintaining engine speed at 2,000 rpm	Fluctuates around 1.5V

**On Board Diagnosis Logic**

GBS000PO

To judge the malfunction, the A/F signal computed by ECM from the air fuel ratio (A/F) sensor 1 signal is monitored not to be shifted to LEAN side or RICH side.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause
P1273 1273 (Bank 1)	Air fuel ratio (A/F) sensor 1 lean shift monitoring	● The output voltage computed by ECM from the air fuel ratio (A/F) sensor 1 signal is shifted to the lean side for a specified period.	<ul style="list-style-type: none"> <li>● Air fuel ratio (A/F) sensor 1</li> <li>● Air fuel ratio (A/F) sensor 1 heater</li> <li>● Fuel pressure</li> <li>● Fuel injector</li> <li>● Intake air leaks</li> </ul>
P1283 1283 (Bank 2)			

**DTC Confirmation Procedure**

GBS000PP

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

**Ⓟ WITH CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Turn ignition switch ON and select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.

# DTC P1273, P1283 A/F SENSOR 1

[VQ TYPE 1]


4. Clear the self-learning coefficient by touching "CLEAR".
5. Turn ignition switch OFF and wait at least 10 seconds.
6. Start engine and keep the engine speed between 3,500 and 4,000 rpm for 1 minute under no load.
7. Let engine idle for 1 minute.
8. Keep engine speed between 2,500 and 3,000 rpm for 20 minutes.
9. If 1st trip DTC is detected, go to [EC-395, "Diagnostic Procedure"](#).

WORK SUPPORT		
SELF-LEARNING CONT	CLEAR	B1 100 %
		B2 100 %

SEF968Y

## WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Disconnect mass air flow sensor harness connector.
4. Start engine and let it idle for at least 5 seconds.
5. Stop engine and reconnect mass air flow sensor harness connector.
6. Select Service \$03 with GST and make sure that DTC P0102 is detected.
7. Select Service \$04 with GST and erase the DTC P0102.
8. Start engine and keep the engine speed between 3,500 and 4,000 rpm for 1 minute under no load.
9. Let engine idle for 1 minute.
10. Keep engine speed between 2,500 and 3,000 rpm for 20 minutes.
11. Select Service \$07 with GST.  
If 1st trip DTC is detected, go to [EC-395, "Diagnostic Procedure"](#).








# DTC P1273, P1283 A/F SENSOR 1

[VQ TYPE 1]

## Wiring Diagram BANK 1

GBS000PQ

EC-AF1B1-01



MBWA1336E

# DTC P1273, P1283 A/F SENSOR 1

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
2	L	A/F sensor 1 heater (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 5V★  PBIB1584E
16	SB	A/F sensor 1 (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 3.1V
35	O			Approximately 2.6V
56	LG			Approximately 2.3V
75	P			Approximately 2.3V



★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# DTC P1273, P1283 A/F SENSOR 1


[VQ TYPE 1]

BANK 2


EC-AF1B2-01




(E12)  
W



(F1)  
B



(F2)  
W



(F23)  
B




# DTC P1273, P1283 A/F SENSOR 1

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
24	G	A/F sensor 1 heater (Bank 2)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 5V★  PBIB1584E
57	GR	A/F sensor 1 (Bank 2)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 2.6V
58	O			Approximately 2.3V
76	V			Approximately 3.1V
77	Y			Approximately 2.3V


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

GBS000PR

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-145, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

**OK or NG**

- OK >> GO TO 2.  
NG >> Repair or replace ground connections.

## 2. RETIGHTEN AIR FUEL RATIO (A/F) SENSOR 1

Loosen and retighten the air fuel ratio (A/F) sensor 1.




**Tightening torque: 50 N-m (5.1 kg-m, 37 ft-lb)**

>> GO TO 3.

## 3. CLEAR THE SELF-LEARNING DATA.


### ④ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.  
**Is the 1st trip DTC P0171 or P0174 detected?  
Is it difficult to start engine?**



### ⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect mass air flow sensor harness connector.
4. Restart engine and let it idle for at least 5 seconds.
5. Stop engine and reconnect mass air flow sensor harness connector.
6. Make sure DTC P0102 is displayed.
7. Erase the DTC memory. Refer to [EC-56, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
8. Make sure DTC P0000 is displayed.
9. Run engine for at least 10 minutes at idle speed.  
**Is the 1st trip DTC P0171 or P0174 detected?  
Is it difficult to start engine?**




Yes or No

- Yes >> Perform trouble diagnosis for DTC P0171 or P0174. Refer to [EC-207, "DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION"](#).
- No >> GO TO 4.

**4. CHECK AIR FUEL RATIO (A/F) SENSOR 1 POWER SUPPLY CIRCUIT**

1. Turn ignition switch OFF.
2. Disconnect air fuel ratio (A/F) sensor 1 harness connector.




3. Turn ignition switch ON.
4. Check voltage between air fuel ratio (A/F) sensor 1 terminal 3 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



**5. DETECT MALFUNCTIONING PART**

Check the following.

- Harness connectors E8, F2
- IPDM E/R connector E12
- 10A fuse
- Harness for open or short between air fuel ratio (A/F) sensor 1 and fuse

>> Repair or replace harness or connectors.

**6. CHECK AIR FUEL RATIO (A/F) SENSOR 1 INPUT SIGNAL CIRCUIT**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between the following terminals.  
Refer to Wiring Diagram.

	A/F sensor 1 terminal	ECM terminal
Bank1	1	16
	2	75
	5	35
	6	56
Bank 2	1	76
	2	77
	5	57
	6	58

**Continuity should exist.**

4. Check harness continuity between the following terminals and ground.  
Refer to Wiring Diagram.

Bank 1		Bank 2	
A/F sensor 1 terminal	ECM terminal	A/F sensor 1 terminal	ECM terminal
1	16	1	76
2	75	2	77
5	35	5	57
6	56	6	58

**Continuity should not exist.**

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 7.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**7. CHECK AIR FUEL RATIO (A/F) SENSOR 1 HEATER**

Refer to [EC-298, "Component Inspection"](#) .

OK or NG

OK >> GO TO 8.

NG >> GO TO 9.

**8. CHECK INTERMITTENT INCIDENT**

Perform [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

OK >> GO TO 9.

NG >> Repair or replace.

---

**9. REPLACE AIR FUEL RATIO (A/F) SENSOR 1**

---

Replace air fuel ratio (A/F) sensor 1.

**CAUTION:**

- Discard any air fuel ratio (A/F) sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new air fuel ratio (A/F) sensor, clean exhaust system threads using Heated Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

>> INSPECTION END

**Removal and Installation**  
**AIR FUEL RATIO (A/F) SENSOR 1**

GBS000PS

Refer to [EM-23, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#) .

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

**DTC P1274, P1284 A/F SENSOR 1**

PFP:22693


**Component Description**

GBS000PT


The air fuel ratio (A/F) sensor is a planar dual-cell limit current sensor. The sensor element of the air fuel ratio (A/F) sensor is the combination of a Nernst concentration cell (sensor cell) with an oxygen-pump cell, which transports ions. It has a heater in the element.

The sensor is capable of precise measurement  $\lambda = 1$ , but also in the lean and rich range. Together with its control electronics, the sensor outputs a clear, continuous signal throughout a wide  $\lambda$  range ( $0.7 < \lambda < \text{air}$ ).

The exhaust gas components diffuse through the diffusion gap at the electrode of the oxygen pump and Nernst concentration cell, where they are brought to thermodynamic balance.



An electronic circuit controls the pump current through the oxygen-pump cell so that the composition of the exhaust gas in the diffusion gap remains constant at  $\lambda = 1$ . Therefore, the air fuel ratio (A/F) sensor is able to indicate air/fuel ratio by this pumping of current. In addition, a heater is integrated in the sensor to ensure the required operating temperature of 700 - 800°C (1,292 - 1,472°F).



**CONSULT-II Reference Value in Data Monitor Mode**

GBS000PU

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
A/F SEN1 (B1) A/F SEN1 (B2)	● Engine: After warming up Maintaining engine speed at 2,000 rpm	Fluctuates around 1.5V

**On Board Diagnosis Logic**

GBS000PV

To judge the malfunction, the A/F signal computed by ECM from the air fuel ratio (A/F) sensor 1 signal is monitored not to be shifted to LEAN side or RICH side.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause
P1274 1274 (Bank 1)	Air fuel ratio (A/F) sensor 1 rich shift monitoring	● The A/F signal computed by ECM from the air fuel ratio (A/F) sensor 1 signal is shifted to the rich side for a specified period.	<ul style="list-style-type: none"> <li>● Air fuel ratio (A/F) sensor 1</li> <li>● Air fuel ratio (A/F) sensor 1 heater</li> <li>● Fuel pressure</li> <li>● Fuel injector</li> </ul>
P1284 1244 (Bank 2)			

**DTC Confirmation Procedure**

GBS000PW

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 11V at idle.


Ⓟ **WITH CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Turn ignition switch ON and select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.

# DTC P1274, P1284 A/F SENSOR 1


[VQ TYPE 1]

4. Clear the self-learning coefficient by touching "CLEAR".
5. Turn ignition switch OFF and wait at least 10 seconds.
6. Start engine and keep the engine speed between 3,500 and 4,000 rpm for 1 minute under no load.
7. Let engine idle for 1 minute.
8. Keep engine speed between 2,500 and 3,000 rpm for 20 minutes.
9. If 1st trip DTC is detected, go to [EC-405, "Diagnostic Procedure"](#).



## WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Disconnect mass air flow sensor harness connector.
4. Start engine and let it idle for at least 5 seconds.
5. Stop engine and reconnect mass air flow sensor harness connector.
6. Select Service \$03 with GST and make sure that DTC P0102 is detected.
7. Select Service \$04 with GST and erase the DTC P0102.
8. Start engine and keep the engine speed between 3,500 and 4,000 rpm for 1 minute under no load.
9. Let engine idle for 1 minute.
10. Keep engine speed between 2,500 and 3,000 rpm for 20 minutes.
11. Select Service \$07 with GST.  
If 1st trip DTC is detected, go to [EC-405, "Diagnostic Procedure"](#).








# DTC P1274, P1284 A/F SENSOR 1

[VQ TYPE 1]

GBS000PX

## Wiring Diagram BANK 1

EC-AF1B1-01






# DTC P1274, P1284 A/F SENSOR 1

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
2	L	A/F sensor 1 heater (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 5V★ 
16	SB	A/F sensor 1 (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 3.1V
35	O			Approximately 2.6V
56	LG			Approximately 2.3V
75	P			Approximately 2.3V






★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# DTC P1274, P1284 A/F SENSOR 1

[VQ TYPE 1]

BANK 2

EC-AF1B2-01




# DTC P1274, P1284 A/F SENSOR 1

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
24	G	A/F sensor 1 heater (Bank 2)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 5V★  PBIB1584E
57	GR	A/F sensor 1 (Bank 2)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 2.6V
58	O			Approximately 2.3V
76	V			Approximately 3.1V
77	Y			Approximately 2.3V


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

GBS000PY

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-145, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
NG >> Repair or replace ground connections.

## 2. RETIGHTEN AIR FUEL RATIO (A/F) SENSOR 1

Loosen and retighten the air fuel ratio (A/F) sensor 1.




**Tightening torque: 50 N-m (5.1 kg-m, 37 ft-lb)**

>> GO TO 3.

## 3. CLEAR THE SELF-LEARNING DATA.


### ④ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.  
**Is the 1st trip DTC P0172 or P0175 detected?  
 Is it difficult to start engine?**



### ⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect mass air flow sensor harness connector.
4. Restart engine and let it idle for at least 5 seconds.
5. Stop engine and reconnect mass air flow sensor harness connector.
6. Make sure DTC P0102 is displayed.
7. Erase the DTC memory. Refer to [EC-56, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
8. Make sure DTC P0000 is displayed.
9. Run engine for at least 10 minutes at idle speed.  
**Is the 1st trip DTC P0172 or P0175 detected?  
 Is it difficult to start engine?**




Yes or No

- Yes >> Perform trouble diagnosis for DTC P0172 or P0175. Refer to [EC-219, "DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION"](#).
- No >> GO TO 4.

#### 4. CHECK HARNESS CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect air fuel ratio (A/F) sensor 1 harness connector.



3. Check harness connector for water.  
**Water should not exit.**

OK or NG

- OK >> GO TO 5.
- NG >> Repair or replace harness connector.


#### 5. CHECK AIR FUEL RATIO (A/F) SENSOR 1 POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between air fuel ratio (A/F) sensor 1 terminal 3 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 7.
- NG >> GO TO 6.



#### 6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E8, F2
- IPDM E/R connector E12
- 10A fuse
- Harness for open or short between air fuel ratio (A/F) sensor 1 and fuse

>> Repair or replace harness or connectors.

**7. CHECK AIR FUEL RATIO (A/F) SENSOR 1 INPUT SIGNAL CIRCUIT**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between the following terminals.  
Refer to Wiring Diagram.

	A/F sensor 1 terminal	ECM terminal
Bank1	1	16
	2	75
	5	35
	6	56
Bank 2	1	76
	2	77
	5	57
	6	58

**Continuity should exist.**

4. Check harness continuity between the following terminals and ground.  
Refer to Wiring Diagram.

Bank 1		Bank 2	
A/F sensor 1 terminal	ECM terminal	A/F sensor 1 terminal	ECM terminal
1	16	1	76
2	75	2	77
5	35	5	57
6	56	6	58

**Continuity should not exist.**

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 8.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**8. CHECK AIR FUEL RATIO (A/F) SENSOR 1 HEATER**

Refer to [EC-298, "Component Inspection"](#) .

OK or NG

OK >> GO TO 9.

NG >> GO TO 10.

**9. CHECK INTERMITTENT INCIDENT**

Perform [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

OK >> GO TO 10.

NG >> Repair or replace.

---

**10. REPLACE AIR FUEL RATIO (A/F) SENSOR 1**

---

Replace air fuel ratio (A/F) sensor 1.

**CAUTION:**

- Discard any air fuel ratio (A/F) sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new air fuel ratio (A/F) sensor, clean exhaust system threads using Heated Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

>> INSPECTION END

**Removal and Installation**  
**AIR FUEL RATIO (A/F) SENSOR 1**

GBS000PZ

Refer to [EM-23, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#) .

A

EC

C

D

E

F

G

H

I

J

K

L

M

**DTC P1276, P1286 A/F SENSOR 1**

PF2:22693


**Component Description**

GBS000Q0


The air fuel ratio (A/F) sensor is a planar dual-cell limit current sensor. The sensor element of the air fuel ratio (A/F) sensor is the combination of a Nernst concentration cell (sensor cell) with an oxygen-pump cell, which transports ions. It has a heater in the element.

The sensor is capable of precise measurement  $\lambda = 1$ , but also in the lean and rich range. Together with its control electronics, the sensor outputs a clear, continuous signal throughout a wide  $\lambda$  range ( $0.7 < \lambda < \text{air}$ ).

The exhaust gas components diffuse through the diffusion gap at the electrode of the oxygen pump and Nernst concentration cell, where they are brought to thermodynamic balance.



An electronic circuit controls the pump current through the oxygen-pump cell so that the composition of the exhaust gas in the diffusion gap remains constant at  $\lambda = 1$ . Therefore, the air fuel ratio (A/F) sensor is able to indicate air/fuel ratio by this pumping of current. In addition, a heater is integrated in the sensor to ensure the required operating temperature of 700 - 800°C (1,292 - 1,472°F).



**CONSULT-II Reference Value in Data Monitor Mode**

GBS000Q1

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
A/F SEN1 (B1) A/F SEN1 (B2)	● Engine: After warming up Maintaining engine speed at 2,000 rpm	Fluctuates around 1.5V

**On Board Diagnosis Logic**

GBS000Q2

To judge the malfunction, the diagnosis checks that the A/F signal computed by ECM from the air fuel ratio (A/F) sensor 1 signal fluctuates according to fuel feedback control.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause
P1276 1276 (Bank 1)	Air fuel ratio (A/F) sensor 1 circuit high voltage	● The A/F signal computed by ECM from the air fuel ratio (A/F) sensor 1 signal is constantly approx. 1.5V.	<ul style="list-style-type: none"> <li>● Harness or connectors (The air fuel ratio (A/F) sensor 1 circuit is open or shorted.)</li> <li>● Air fuel ratio (A/F) sensor 1</li> </ul>
P1286 1286 (Bank 2)			

**DTC Confirmation Procedure**

GBS000Q3

**CAUTION:**

Always drive vehicle at a safe speed.

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

**WITH CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Select "A/F SEN1 (B1)" or "A/F SEN1 (B2)" in "DATA MONITOR" mode with CONSULT-II.
3. Check "A/F SEN1 (B1)" or "A/F SEN1 (B2)" indication.



# DTC P1276, P1286 A/F SENSOR 1

[VQ TYPE 1]

If the indication is constantly approx. 1.5V and does not fluctuates, go to [EC-416, "Diagnostic Procedure"](#).  
If the indication fluctuates around 1.5V, go to next step.

4. Select "A/F SEN1 (B1) P1276" or "A/F SEN1 (B2) P1286" of "A/F SEN1" in "DTC WORK SUPPORT" mode with CONSULT-II.
5. Touch "START".
6. When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen.

ENG SPEED	1,750 - 3,200 rpm
VHCL SPEED SE	More than 64 km/h (40 MPH)
B/FUEL SCHDL	1.0 - 8.0 msec
Selector lever	D position with "OD" OFF (A/T) 5th position (M/T)

**If "TESTING" is not displayed after 20 seconds, retry from step 2.**

A/F SEN1 (B1) P1276	
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLANT TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h

SEF576Z

7. Release accelerator pedal fully.

**NOTE:**

Never apply brake during releasing the accelerator pedal.

A/F SEN1 (B1) P1276	
TESTING	
SELECT 3RD GEAR AND THEN RELEASE ACCELERATOR PEDAL OFF	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLANT TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h

SEF577Z

8. Make sure that "TESTING" changes to "COMPLETED".  
**If "TESTING" changed to "OUT OF CONDITION", retry from step 6.**
9. Make sure that "OK" is displayed after touching "SELF-DIAG RESULT".  
If "NG" is displayed, go to [EC-416, "Diagnostic Procedure"](#).

A/F SEN1 (B1) P1276	
COMPLETED	

SEF578Z

## Overall Function Check

GBS000Q4

Use this procedure to check the overall function of the air fuel ratio (A/F) sensor 1 circuit. During this check, a 1st trip DTC might not be confirmed.

 **WITH GST**

1. Start engine and warm it up to normal operating temperature.
2. Drive the vehicle at a speed of 80 km/h (50 MPH) for a few minutes in the suitable gear position.
3. Set D position with "OD" OFF (A/T) or 5th position (M/T), then release the accelerator pedal fully until the vehicle speed decreases to 50 km/h (30 MPH).

**NOTE:**

Never apply brake during releasing the accelerator pedal.

4. Repeat steps 2 to 3 for five times.
5. Stop the vehicle and turn ignition switch OFF.
6. Wait at least 10 seconds and restart engine.
7. Repeat steps 2 to 3 for five times.

8. Stop the vehicle and connect GST to the vehicle.
9. Make sure that no DTC is displayed.  
If the DTC is displayed, go to [EC-416, "Diagnostic Procedure"](#) .






# DTC P1276, P1286 A/F SENSOR 1

[VQ TYPE 1]

## Wiring Diagram BANK 1

GBS000Q5

EC-AF1B1-01




# DTC P1276, P1286 A/F SENSOR 1

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
2	L	A/F sensor 1 heater (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 5V★  <small>PBIB1584E</small>
16	SB	A/F sensor 1 (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 3.1V
35	O			Approximately 2.6V
56	LG			Approximately 2.3V
75	P			Approximately 2.3V






★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# DTC P1276, P1286 A/F SENSOR 1

[VQ TYPE 1]

BANK 2

EC-AF1B2-01




# DTC P1276, P1286 A/F SENSOR 1

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
24	G	A/F sensor 1 heater (Bank 2)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 5V★  PBB1584E
57	GR	A/F sensor 1 (Bank 2)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 2.6V
58	O			Approximately 2.3V
76	V			Approximately 3.1V
77	Y			Approximately 2.3V


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

GBS000Q6

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-145, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

**OK or NG**

- OK >> GO TO 2.  
NG >> Repair or replace ground connections.

## 2. CHECK AIR FUEL RATIO (A/F) SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect air fuel ratio (A/F) sensor 1 harness connector.




2. Turn ignition switch ON.
3. Check voltage between air fuel ratio (A/F) sensor 1 terminal 3 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



## 3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E8, F2
- IPDM E/R connector E12
- 10A fuse
- Harness for open or short between air fuel ratio (A/F) sensor 1 and fuse

>> Repair or replace harness or connectors.

#### 4. CHECK AIR FUEL RATIO (A/F) SENSOR 1 INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between the following terminals.  
Refer to Wiring Diagram.

	A/F sensor 1 terminal	ECM terminal
Bank1	1	16
	2	75
	5	35
	6	56
Bank 2	1	76
	2	77
	5	57
	6	58

**Continuity should exist.**

4. Check harness continuity between the following terminals and ground.  
Refer to Wiring Diagram.

Bank 1		Bank 2	
A/F sensor 1 terminal	ECM terminal	A/F sensor 1 terminal	ECM terminal
1	16	1	76
2	75	2	77
5	35	5	57
6	56	6	58

**Continuity should not exist.**

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

#### 5. CHECK INTERMITTENT INCIDENT

Perform [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

OK >> GO TO 6.

NG >> Repair or replace.

#### 6. REPLACE AIR FUEL RATIO (A/F) SENSOR 1

Replace air fuel ratio (A/F) sensor 1.

**CAUTION:**

- Discard any air fuel ratio (A/F) sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new air fuel ratio (A/F) sensor, clean exhaust system threads using Heated Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

>> INSPECTION END



**Removal and Installation**  
**AIR FUEL RATIO (A/F) SENSOR 1**

GBS00007

A

Refer to [EM-23, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#) .

EC

C

D

E

F

G

H

I

J

K

L

M

**DTC P1278, P1288 A/F SENSOR 1**


PFP:22693

**Component Description**


GBS000Q8

The air fuel ratio (A/F) sensor 1 is a planar dual-cell limit current sensor. The sensor element of the air fuel ratio (A/F) sensor 1 is the combination of a Nernst concentration cell (sensor cell) with an oxygen-pump cell, which transports ions. It has a heater in the element. The sensor is capable of precise measurement  $\lambda = 1$ , but also in the lean and rich range. Together with its control electronics, the sensor outputs a clear, continuous signal throughout a wide  $\lambda$  range ( $0.7 < \lambda < \text{air}$ ).

The exhaust gas components diffuse through the diffusion gap at the electrode of the oxygen pump and Nernst concentration cell, where they are brought to thermodynamic balance.



An electronic circuit controls the pump current through the oxygen-pump cell so that the composition of the exhaust gas in the diffusion gap remains constant at  $\lambda = 1$ . Therefore, the air fuel ratio (A/F) sensor 1 is able to indicate air/fuel ratio by this pumping of current. In addition, a heater is integrated in the sensor to ensure the required operating temperature of 700 - 800°C (1,292 - 1,472°F).



**CONSULT-II Reference Value in Data Monitor Mode**

GBS000Q9

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
A/F SEN1 (B1) A/F SEN1 (B2)	● Engine: After warming up Maintaining engine speed at 2,000 rpm	Fluctuates around 1.5V

**On Board Diagnosis Logic**

GBS000Q4

To judge the malfunction of air fuel ratio (A/F) sensor 1, this diagnosis measures response time of the A/F signal computed by ECM from the air fuel ratio (A/F) sensor 1 signal. The time is compensated by engine operating (speed and load), fuel feedback control constant, and the air fuel ratio (A/F) sensor 1 temperature index. Judgment is based on whether the compensated time (the A/F signal cycling time index) is inordinately long or not.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause
P1278 1278 (Bank 1)	Air fuel ratio (A/F) sensor 1 circuit slow response	● The response (from RICH to LEAN) of the A/F signal computed by ECM from air fuel ratio (A/F) sensor 1 signal takes more than the specified time.	<ul style="list-style-type: none"> <li>● Harness or connectors (The air fuel ratio (A/F) sensor 1 circuit is open or shorted.)</li> <li>● Air fuel ratio (A/F) sensor 1</li> <li>● Air fuel ratio (A/F) sensor 1 heater</li> <li>● Fuel pressure</li> <li>● Fuel injector</li> <li>● Intake air leaks</li> <li>● Exhaust gas leaks</li> <li>● PCV</li> <li>● Mass air flow sensor</li> </ul>
P1288 1288 (Bank 2)			

## DTC Confirmation Procedure

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### TESTING CONDITION:

**Before performing the following procedure, confirm that battery voltage is more than 11V at idle.**

#### WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
4. Let engine idle for 1 minute.
5. Select "A/F SEN1(B1) P1278/P1279" or "A/F SEN1(B1) P1288/P1289" of "A/F SEN1" in "DTC WORK SUPPORT" mode with CONSULT-II.
6. Touch "START".  
 If "COMPLETED" appears on CONSULT-II screen, go to step 10.  
 If "COMPLETED" does not appear on CONSULT-II screen, go to the following step.

A/F SEN1 (B1) P1278/P1279	
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h

PBIB0756E

7. After perform the following procedure, "TESTING" will be displayed on the CONSULT-II screen.
  - a. Increase the engine speed up to 4,000 to 5,000 rpm and keep it for 10 seconds.
  - b. Fully release accelerator pedal and then let engine idle for about 10 seconds.  
**If "TESTING" is not displayed after 10 seconds, refer to [EC-127, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE"](#) .**
8. Wait for about 20 seconds at idle at under the condition that "TESTING" is displayed on the CONSULT-II screen.

A/F SEN1 (B1) P1278/P1279	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h

PBIB1925E

9. Make sure that "TESTING" changes to "COMPLETED".  
**If "TESTING" changed to "OUT OF CONDITION", refer to [EC-127, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE"](#) .**
10. Make sure that "OK" is displayed after touching "SELF-DIAG RESULT".  
 If "NG" is displayed, go to [EC-426, "Diagnostic Procedure"](#) .

A/F SEN1 (B1) P1278/P1279	
COMPLETED	

PBIB0758E

#### WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Select Service \$01 with GST.
3. Calculate the total value of "Short term fuel trim" and "Long term fuel trim" indications.  
 Make sure that the total percentage should be within  $\pm 15\%$ .  
 If OK, go to the following step.  
 If NG, check the following.

- Intake air leaks
  - Exhaust gas leaks
  - Incorrect fuel pressure
  - Lack of fuel
  - Fuel injector
  - Incorrect PCV hose connection
  - PCV valve
  - Mass air flow sensor
4. Turn ignition switch OFF and wait at least 10 seconds.
  5. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
  6. Let engine idle for 1 minute.
  7. Increase the engine speed up to 4,000 to 5,000 rpm and keep it for 10 seconds.
  8. Fully release accelerator pedal and then let engine idle for about 1 minute.
  9. Select Service \$07 with GST.  
If the 1st trip DTC is displayed, go to [EC-426. "Diagnostic Procedure"](#) .






# DTC P1278, P1288 A/F SENSOR 1

[VQ TYPE 1]

## Wiring Diagram BANK 1

GBS0000C

EC-AF1B1-01




# DTC P1278, P1288 A/F SENSOR 1

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
2	L	A/F sensor 1 heater (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 5V★ 
16	SB	A/F sensor 1 (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 3.1V
35	O			Approximately 2.6V
56	LG			Approximately 2.3V
75	P			Approximately 2.3V






★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# DTC P1278, P1288 A/F SENSOR 1

[VQ TYPE 1]

BANK 2

EC-AF1B2-01




# DTC P1278, P1288 A/F SENSOR 1

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
24	G	A/F sensor 1 heater (Bank 2)	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed	Approximately 5V★  PBIB1584E
57	GR	A/F sensor 1 (Bank 2)	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed	Approximately 2.6V
58	O			Approximately 2.3V
76	V			Approximately 3.1V
77	Y			Approximately 2.3V


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

GBS000QD

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-145, "Ground Inspection"](#).



← : Vehicle front

- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |


**OK or NG**

- OK >> GO TO 2.  
NG >> Repair or replace ground connections.



## 2. RETIGHTEN AIR FUEL RATIO (A/F) SENSOR 1

Loosen and retighten the air fuel ratio (A/F) sensor 1.




**Tightening torque: 50 N-m (5.1 kg-m, 37 ft-lb)**

>> GO TO 3.

## 3. CHECK EXHAUST GAS LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust gas leak before three way catalyst (manifold).



OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace.

## 4. CHECK FOR INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.


OK or NG

- OK >> GO TO 5.
- NG >> Repair or replace.

**5. CLEAR THE SELF-LEARNING DATA**


**With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR" or "START".
4. Run engine for at least 10 minutes at idle speed.  
**Is the 1st trip DTC P0171, P172, P0174 or P0175 detected?**  
**Is it difficult to start engine?**



**Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect mass air flow sensor harness connector.
4. Restart engine and let it idle for at least 5 seconds.
5. Stop engine and reconnect mass air flow sensor harness connector.
6. Make sure DTC P0102 is displayed.
7. Erase the DTC memory. Refer to [EC-56, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#) .
8. Make sure DTC P0000 is displayed.
9. Run engine for at least 10 minutes at idle speed.  
**Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected?**  
**Is it difficult to start engine?**




Yes or No

Yes >> Perform trouble diagnosis for DTC P0171, P0174 or P0172, P0175. Refer to [EC-207, "DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION"](#) or [EC-219, "DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION"](#) .

No >> GO TO 6.

**6. CHECK AIR FUEL RATIO (A/F) SENSOR 1 POWER SUPPLY CIRCUIT**

1. Turn ignition switch OFF.
2. Disconnect air fuel ratio (A/F) sensor 1 harness connector.




3. Turn ignition switch ON.
4. Check voltage between air fuel ratio (A/F) sensor 1 terminal 3 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.



**7. DETECT MALFUNCTIONING PART**

Check the following.

- Harness connectors E8, F2
- IPDM E/R connector E12
- 10A fuse
- Harness for open or short between air fuel ratio (A/F) sensor 1 and fuse

>> Repair or replace harness or connectors.

**8. CHECK AIR FUEL RATIO (A/F) SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between the following terminals.  
Refer to Wiring Diagram.

	A/F sensor 1 terminal	ECM terminal
Bank1	1	16
	2	75
	5	35
	6	56
Bank 2	1	76
	2	77
	5	57
	6	58

**Continuity should exist.**

4. Check harness continuity between the following terminals and ground.  
Refer to Wiring Diagram.

Bank 1		Bank 2	
A/F sensor 1 terminal	ECM terminal	A/F sensor 1 terminal	ECM terminal
1	16	1	76
2	75	2	77
5	35	5	57
6	56	6	58

**Continuity should not exist.**

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 9.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**9. CHECK AIR FUEL RATIO (A/F) SENSOR 1 HEATER**

Refer to [EC-298, "Component Inspection"](#) .

OK or NG

OK >> GO TO 10.

NG >> GO TO 13.

**10. CHECK MASS AIR FLOW SENSOR**

Refer to [EC-168, "Component Inspection"](#) .

OK or NG

OK >> GO TO 11.

NG >> Replace mass air flow sensor.

**11. CHECK PCV VALVE**

Refer to [EC-41, "POSITIVE CRANKCASE VENTILATION"](#) .

OK or NG

- OK >> GO TO 12.
- NG >> Repair or replace PCV valve.

**12. CHECK INTERMITTENT INCIDENT**

Perform [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> GO TO 13.
- NG >> Repair or replace.

**13. REPLACE AIR FUEL RATIO (A/F) SENSOR 1**

Replace air fuel ratio (A/F) sensor 1.

**CAUTION:**

- Discard any air fuel ratio (A/F) sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new air fuel ratio (A/F) sensor, clean exhaust system threads using Heated Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

>> INSPECTION END

**Removal and Installation**  
**AIR FUEL RATIO (A/F) SENSOR 1**

GBS000QE

Refer to [EM-23, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#) .


**DTC P1279, P1289 A/F SENSOR 1**

PFP:22693


**Component Description**

GBS000QF

The air fuel ratio (A/F) sensor 1 is a planar dual-cell limit current sensor. The sensor element of the air fuel ratio (A/F) sensor 1 is the combination of a Nernst concentration cell (sensor cell) with an oxygen-pump cell, which transports ions. It has a heater in the element. The sensor is capable of precise measurement  $\lambda = 1$ , but also in the lean and rich range. Together with its control electronics, the sensor outputs a clear, continuous signal throughout a wide  $\lambda$  range ( $0.7 < \lambda < \text{air}$ ). The exhaust gas components diffuse through the diffusion gap at the electrode of the oxygen pump and Nernst concentration cell, where they are brought to thermodynamic balance.



An electronic circuit controls the pump current through the oxygen-pump cell so that the composition of the exhaust gas in the diffusion gap remains constant at  $\lambda = 1$ . Therefore, the air fuel ratio (A/F) sensor 1 is able to indicate air/fuel ratio by this pumping of current. In addition, a heater is integrated in the sensor to ensure the required operating temperature of 700 - 800°C (1,292 - 1,472°F).



**CONSULT-II Reference Value in Data Monitor Mode**

GBS000QG

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
A/F SEN1 (B1) A/F SEN1 (B2)	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> </ul>	Maintaining engine speed at 2,000 rpm  Fluctuates around 1.5V

**On Board Diagnosis Logic**

GBS000QH

To judge the malfunction of air fuel ratio (A/F) sensor 1, this diagnosis measures response time of the A/F signal computed by ECM from the air fuel ratio (A/F) sensor 1 signal. The time is compensated by engine operating (speed and load), fuel feedback control constant, and the air fuel ratio (A/F) sensor 1 temperature index. Judgment is based on whether the compensated time (the A/F signal cycling time index) is inordinately long or not.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause
P1279 1279 (Bank 1)	Air fuel ratio (A/F) sensor 1 circuit slow response	<ul style="list-style-type: none"> <li>● The response (from LEAN to RICH) of the A/F signal computed by ECM from air fuel ratio (A/F) sensor 1 signal takes more than the specified time.</li> </ul>	<ul style="list-style-type: none"> <li>● Harness or connectors (The air fuel ratio (A/F) sensor 1 circuit is open or shorted.)</li> <li>● Air fuel ratio (A/F) sensor 1</li> <li>● Air fuel ratio (A/F) sensor 1 heater</li> <li>● Fuel pressure</li> <li>● Fuel injector</li> <li>● Intake air leaks</li> <li>● Exhaust gas leaks</li> <li>● PCV</li> <li>● Mass air flow sensor</li> </ul>
P1289 1289 (Bank 2)			

## DTC Confirmation Procedure

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### TESTING CONDITION:

**Before performing the following procedure, confirm that battery voltage is more than 11V at idle.**

#### WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
4. Let engine idle for 1 minute.
5. Select "A/F SEN1(B1) P1278/P1279" or "A/F SEN1(B1) P1288/P1289" of "A/F SEN1" in "DTC WORK SUPPORT" mode with CONSULT-II.
6. Touch "START".  
If "COMPLETED" appears on CONSULT-II screen, go to step 10.  
If "COMPLETED" does not appear on CONSULT-II screen, go to the following step.

A/F SEN1 (B1) P1278/P1279	
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h

PBIB0756E

7. After perform the following procedure, "TESTING" will be displayed on the CONSULT-II screen.
  - a. Increase the engine speed up to 4,000 to 5,000 rpm and keep it for 10 seconds.
  - b. Fully release accelerator pedal and then let engine idle for about 10 seconds.  
**If "TESTING" is not displayed after 10 seconds, refer to [EC-127, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE"](#) .**
8. Wait for about 20 seconds at idle at under the condition that "TESTING" is displayed on the CONSULT-II screen.

A/F SEN1 (B1) P1278/P1279	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h

PBIB1925E

9. Make sure that "TESTING" changes to "COMPLETED".  
**If "TESTING" changed to "OUT OF CONDITION", refer to [EC-127, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE"](#) .**
10. Make sure that "OK" is displayed after touching "SELF-DIAG RESULT".  
If "NG" is displayed, go to [EC-438, "Diagnostic Procedure"](#) .

A/F SEN1 (B1) P1278/P1279	
COMPLETED	

PBIB0758E

#### WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Select Service \$01 with GST.
3. Calculate the total value of "Short term fuel trim" and "Long term fuel trim" indications.  
Make sure that the total percentage should be within  $\pm 15\%$ .  
If OK, go to the following step.  
If NG, check the following.

- Intake air leaks
  - Exhaust gas leaks
  - Incorrect fuel pressure
  - Lack of fuel
  - Fuel injector
  - Incorrect PCV hose connection
  - PCV valve
  - Mass air flow sensor
4. Turn ignition switch OFF and wait at least 10 seconds.
  5. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
  6. Let engine idle for 1 minute.
  7. Increase the engine speed up to 4,000 to 5,000 rpm and keep it for 10 seconds.
  8. Fully release accelerator pedal and then let engine idle for about 1 minute.
  9. Select Service \$07 with GST.  
If the 1st trip DTC is displayed, go to [EC-438. "Diagnostic Procedure"](#) .








# DTC P1279, P1289 A/F SENSOR 1

[VQ TYPE 1]

## Wiring Diagram BANK 1

GBS000QJ

EC-AF1B1-01




# DTC P1279, P1289 A/F SENSOR 1

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
2	L	A/F sensor 1 heater (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 5V★ 
16	SB	A/F sensor 1 (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 3.1V
35	O			Approximately 2.6V
56	LG			Approximately 2.3V
75	P			Approximately 2.3V






★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# DTC P1279, P1289 A/F SENSOR 1

[VQ TYPE 1]

BANK 2

EC-AF1B2-01




# DTC P1279, P1289 A/F SENSOR 1

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
24	G	A/F sensor 1 heater (Bank 2)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 5V★  PBIB1584E
57	GR	A/F sensor 1 (Bank 2)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 2.6V
58	O			Approximately 2.3V
76	V			Approximately 3.1V
77	Y			Approximately 2.3V


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

GBS0000K

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-145, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

**OK or NG**

- OK >> GO TO 2.  
NG >> Repair or replace ground connections.

## 2. RETIGHTEN AIR FUEL RATIO (A/F) SENSOR 1

Loosen and retighten the air fuel ratio (A/F) sensor 1.




**Tightening torque: 50 N-m (5.1 kg-m, 37 ft-lb)**

>> GO TO 3.

## 3. CHECK EXHAUST GAS LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust gas leak before three way catalyst (manifold).



OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace.

## 4. CHECK FOR INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.


OK or NG

- OK >> GO TO 5.
- NG >> Repair or replace.

**5. CLEAR THE SELF-LEARNING DATA**


**With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR" or "START".
4. Run engine for at least 10 minutes at idle speed.  
**Is the 1st trip DTC P0171, P172, P0174 or P0175 detected?  
 Is it difficult to start engine?**



**Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect mass air flow sensor harness connector.
4. Restart engine and let it idle for at least 3 seconds.
5. Stop engine and reconnect mass air flow sensor harness connector.
6. Make sure DTC P0102 is displayed.
7. Erase the DTC memory. Refer to [EC-56, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#) .
8. Make sure DTC P0000 is displayed.
9. Run engine for at least 10 minutes at idle speed.  
**Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected?  
 Is it difficult to start engine?**




Yes or No

Yes >> Perform trouble diagnosis for DTC P0171, P0174 or P0172, P0175. Refer to [EC-207, "DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION"](#) or [EC-219, "DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION"](#) .

No >> GO TO 6.

**6. CHECK AIR FUEL RATIO (A/F) SENSOR 1 POWER SUPPLY CIRCUIT**

1. Turn ignition switch OFF.
2. Disconnect air fuel ratio (A/F) sensor 1 harness connector.




3. Turn ignition switch ON.
4. Check voltage between air fuel ratio (A/F) sensor 1 terminal 3 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.



**7. DETECT MALFUNCTIONING PART**

Check the following.

- Harness connectors E8, F2
- IPDM E/R connector E12
- 10A fuse
- Harness for open or short between air fuel ratio (A/F) sensor 1 and fuse

>> Repair or replace harness or connectors.

**8. CHECK AIR FUEL RATIO (A/F) SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between the following terminals.  
Refer to Wiring Diagram.

	A/F sensor 1 terminal	ECM terminal
Bank1	1	16
	2	75
	5	35
	6	56
Bank 2	1	76
	2	77
	5	57
	6	58

**Continuity should exist.**

4. Check harness continuity between the following terminals and ground.  
Refer to Wiring Diagram.

Bank 1		Bank 2	
A/F sensor 1 terminal	ECM terminal	A/F sensor 1 terminal	ECM terminal
1	16	1	76
2	75	2	77
5	35	5	57
6	56	6	58

**Continuity should not exist.**

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 9.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**9. CHECK AIR FUEL RATIO (A/F) SENSOR 1 HEATER**

Refer to [EC-298, "Component Inspection"](#) .

OK or NG

OK >> GO TO 10.

NG >> GO TO 13.

**10. CHECK MASS AIR FLOW SENSOR**

Refer to [EC-168, "Component Inspection"](#) .

OK or NG

OK >> GO TO 11.

NG >> Replace mass air flow sensor.



**11. CHECK PCV VALVE**

Refer to [EC-41, "POSITIVE CRANKCASE VENTILATION"](#) .

OK or NG

- OK >> GO TO 12.
- NG >> Repair or replace PCV valve.

**12. CHECK INTERMITTENT INCIDENT**

Perform [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> GO TO 13.
- NG >> Repair or replace.

**13. REPLACE AIR FUEL RATIO (A/F) SENSOR 1**

Replace air fuel ratio (A/F) sensor 1.

**CAUTION:**

- Discard any air fuel ratio (A/F) sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new air fuel ratio (A/F) sensor, clean exhaust system threads using Heated Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

>> INSPECTION END

**Removal and Installation**  
**AIR FUEL RATIO (A/F) SENSOR 1**

GBS000QL

Refer to [EM-23, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#)


## DTC P1564 ASCD STEERING SWITCH

PFP:25551

### Component Description

GBS000QM

ASCD steering switch has variant values of electrical resistance for each button. ECM reads voltage variation of switch, and determines which button is operated.



Refer to [EC-34, "AUTOMATIC SPEED CONTROL DEVICE \(ASCD\)"](#) for the ASCD function.

### CONSULT-II Reference Value in Data Monitor Mode

GBS000QN

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
MAIN SW	● Ignition switch: ON	MAIN switch: Pressed	ON
		MAIN switch: Released	OFF
CANCEL SW	● Ignition switch: ON	CANCEL switch: Pressed	ON
		CANCEL switch: Released	OFF
RESUME/ACC SW	● Ignition switch: ON	RESUME/ACCELERATE switch: Pressed	ON
		RESUME/ACCELERATE switch: Released	OFF
SET SW	● Ignition switch: ON	SET/COAST switch: Pressed	ON
		SET/COAST switch: Released	OFF

### On Board Diagnosis Logic

GBS000QO

**This self-diagnosis has the one trip detection logic.  
The MIL will not light up for this diagnosis.**

**NOTE:**

**If DTC P1564 is displayed with DTC P0605, first perform the trouble diagnosis for DTC P0605. Refer to [EC-288](#).**

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P1564 1564	ASCD steering switch	<ul style="list-style-type: none"> <li>● An excessively high voltage signal from the ASCD steering switch is sent to ECM.</li> <li>● ECM detects that input signal from the ASCD steering switch is out of the specified range.</li> <li>● ECM detects that the ASCD steering switch is stuck ON.</li> </ul>	<ul style="list-style-type: none"> <li>● Harness or connectors (The switch circuit is open or shorted.)</li> <li>● ASCD steering switch</li> <li>● ECM</li> </ul>

**DTC Confirmation Procedure**

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 10 seconds.
4. Press MAIN switch for at least 10 seconds, then release it and wait at least 10 seconds.
5. Press CANCEL switch for at least 10 seconds, then release it and wait at least 10 seconds.
6. Press RESUME/ACCELERATE switch for at least 10 seconds, then release it and wait at least 10 seconds.
7. Press SET/COAST switch for at least 10 seconds, then release it and wait at least 10 seconds.
8. If DTC is detected, go to [EC-447, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

**WITH GST**

Follow the procedure "WITH CONSULT-II" above.

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# DTC P1564 ASCD STEERING SWITCH



[VQ TYPE 1]

## Wiring Diagram

GBS0000Q

### EC-ASC/SW-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



# DTC P1564 ASCD STEERING SWITCH

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
67	GR	Sensor ground	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed	Approximately 0V
99	SB	ASCD steering switch	<b>[Ignition switch: ON]</b> ● ASCD steering switch: OFF	Approximately 4.0V
			<b>[Ignition switch: ON]</b> ● MAIN switch: Pressed	Approximately 0V
			<b>[Ignition switch: ON]</b> ● CANCEL switch: Pressed	Approximately 1V
			<b>[Ignition switch: ON]</b> ● RESUME/ACCELERATE switch: Pressed	Approximately 3V
			<b>[Ignition switch: ON]</b> ● SET/COAST switch: Pressed	Approximately 2V

## Diagnostic Procedure

GBS000QR

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-145, "Ground Inspection"](#).



← : Vehicle front

- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

**OK or NG**


- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

## 2. CHECK ASCD STEERING SWITCH CIRCUIT

### With CONSULT-II

1. Turn ignition switch ON.
2. Select "MAIN SW", "CANCEL SW", "RESUME/ACC SW" and "SET SW" in "DATA MONITOR" mode with CONSULT-II.
3. Check each item indication under the following conditions.


Switch	Monitor item	Condition	Indication
MAIN switch	MAIN SW	Pressed	ON
		Released	OFF
CANCEL switch	CANCEL SW	Pressed	ON
		Released	OFF
RESUME/ACCELERATE switch	RESUME/ACC SW	Pressed	ON
		Released	OFF
SET/COAST switch	SET SW	Pressed	ON
		Released	OFF



### Without CONSULT-II

1. Turn ignition switch ON.
2. Check voltage between ECM terminal 99 and ground with pressing each button.

Switch	Condition	Voltage [V]
MAIN switch	Pressed	Approx. 0
	Released	Approx. 4
CANCEL switch	Pressed	Approx. 1
	Released	Approx. 4
RESUME/ACCELERATE switch	Pressed	Approx. 3
	Released	Approx. 4
SET/COAST switch	Pressed	Approx. 2
	Released	Approx. 4



#### OK or NG

- OK >> GO TO 8.  
 NG >> GO TO 3.

## 3. CHECK ASCD STEERING SWITCH GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect combination switch harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between combination switch terminal 17 and ECM terminal 67. Refer to Wiring Diagram.

**Continuity should exist.**

5. Also check harness for short to ground and short to power.

#### OK or NG

- OK >> GO TO 5.  
 NG >> GO TO 4.

---

#### 4. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors M91, E101
- Harness connectors E8, F2
- Combination switch (spiral cable)
- Harness for open and short between ECM and combination switch

>> Repair open circuit or short to ground or short to power in harness or connectors.

---

#### 5. CHECK ASCD STEERING SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

1. Check harness continuity between ECM terminal 99 and combination switch terminal 18.  
Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.

---

#### 6. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors M91, E101
- Combination switch (spiral cable)
- Harness for open and short between ECM and combination switch

>> Repair open circuit or short to ground or short to power in harness or connectors.

---

#### 7. CHECK ASCD STEERING SWITCH

---

Refer to [EC-450, "Component Inspection"](#) .

OK or NG

OK >> GO TO 8.

NG >> Replace steering switch.

---

#### 8. CHECK INTERMITTENT INCIDENT

---

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

# DTC P1564 ASCD STEERING SWITCH


[VQ TYPE 1]

GBS0000S

## Component Inspection ASCD STEERING SWITCH

1. Disconnect combination switch (spiral cable) harness connector M302.
2. Check continuity between combination switch (spiral cable) terminals 17 and 18 with pushing each switch.

Switch	Condition	Resistance [ $\Omega$ ]
MAIN switch	Pressed	Approx. 0
	Released	Approx. 4,000
CANCEL switch	Pressed	Approx. 250
	Released	Approx. 4,000
RESUME/ACCELERATE switch	Pressed	Approx. 1,480
	Released	Approx. 4,000
SET/COAST switch	Pressed	Approx. 660
	Released	Approx. 4,000






## DTC P1572 ASCD BRAKE SWITCH

PFP:25320

### Component Description

GBS000QT

When the brake pedal is depressed, ASCD brake switch (1) is turned OFF and stop lamp switch (2) is turned ON. ECM detects the state of the brake pedal by this input of two kinds (ON/OFF signal). Refer to [EC-34, "AUTOMATIC SPEED CONTROL DEVICE \(ASCD\)"](#) for the ASCD function.



### CONSULT-II Reference Value in Data Monitor Mode

GBS000QU

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
BRAKE SW 1 (ASCD brake switch)	● Ignition switch: ON Brake pedal: Fully released (A/T) Clutch pedal and brake pedal: Fully released (M/T)	ON
	Brake pedal: Slightly depressed (A/T) Clutch pedal and/or brake pedal: Slightly depressed (M/T)	OFF
BRAKE SW2 (Stop lamp switch)	● Ignition switch: ON Brake pedal: Fully released	OFF
	Brake pedal: Slightly depressed	ON

### On Board Diagnosis Logic

GBS000QV

**This self-diagnosis has the one trip detection logic.  
The MIL will not light up for this diagnosis.**

**NOTE:**

- If DTC P 1572 is displayed with DTC P0605, first perform the trouble diagnosis for DTC P0605. Refer to [EC-288](#)
- This self-diagnosis has the one trip detection logic. When malfunction A is detected, DTC is not stored in ECM memory. And in that case, 1st trip DTC and 1st trip freeze frame data are displayed. 1st trip DTC is erased when ignition switch OFF. And even when malfunction A is detected in two consecutive trips, DTC is not stored in ECM memory.

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P1572 1572	ASCD brake switch	A) When the vehicle speed is above 30km/h (19 MPH), ON signals from the stop lamp switch and the ASCD brake switch are sent to ECM at the same time.	<ul style="list-style-type: none"> <li>● Harness or connectors (The stop lamp switch circuit is shorted.)</li> <li>● Harness or connectors (The ASCD brake switch circuit is shorted.)</li> </ul>
		B) ASCD brake switch signal is not sent to ECM for extremely long time while the vehicle is driving	<ul style="list-style-type: none"> <li>● Stop lamp switch</li> <li>● ASCD brake switch</li> <li>● Incorrect stop lamp switch installation</li> <li>● Incorrect ASCD brake switch installation</li> <li>● ECM</li> </ul>

## DTC Confirmation Procedure

**CAUTION:**

Always drive vehicle at a safe speed.

**NOTE:**

- If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.
- Procedure for malfunction B is not described here. It takes extremely long time to complete procedure for malfunction B. By performing procedure for malfunction A, the incident that causes malfunction B can be detected.

**TESTING CONDITION:**

**Steps 4 and 5 may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.**

**WITH CONSULT-II**

1. Start engine.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Press MAIN switch and make sure that CRUISE indicator lights up.
4. Drive the vehicle for at least 5 consecutive seconds under the following condition.

VHCL SPEED SE	More than 30 km/h (19 MPH)
Selector lever	Suitable position

If 1st trip DTC is detected, go to [EC-454, "Diagnostic Procedure"](#)

If 1st trip DTC is not detected, go to the following step.

5. Drive the vehicle for at least 5 consecutive seconds under the following condition.

VHCL SPEED SE	More than 30 km/h (19 MPH)
Selector lever	Suitable position
Driving location	Depress the brake pedal for more than five seconds so as not to come off from the above-mentioned vehicle speed.

6. If 1st trip DTC is detected, go to [EC-454, "Diagnostic Procedure"](#).

**WITH GST**

Follow the procedure "WITH CONSULT-II" above.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
VHCL SPEED SE	XXX km/h
CRUISE LAMP	ON
BRAKE SW 1	ON
BRAKE SW 2	OFF

PBIB2386E


# DTC P1572 ASCD BRAKE SWITCH

[VQ TYPE 1]



GBS000QX

## Wiring Diagram

### EC-ASC/BS-01



- : DETECTABLE LINE FOR DTC
- : NON-DETECTABLE LINE FOR DTC
- ⬡ A : WITH A/T
- ⬡ M : WITH M/T
- \*1 1: ⬡ A
- 2: ⬡ M
- \*2 2: ⬡ A
- 1: ⬡ M
- \*3 LG: ⬡ A
- V: ⬡ M



REFER TO THE FOLLOWING.  
 ⬡ E103 - FUSE BLOCK - JUNCTION BOX (J/B)



# DTC P1572 ASCD BRAKE SWITCH

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
101	V	Stop lamp switch	[Ignition switch: OFF] ● Brake pedal: Fully released	Approximately 0V
			[Ignition switch: OFF] ● Brake pedal: Slightly depressed	BATTERY VOLTAGE (11 - 14V)
108	LG	ASCD brake switch	[Ignition switch: ON] ● Brake pedal: Slightly depressed (A/T) ● Clutch pedal and/or brake pedal: Slightly depressed (M/T)	Approximately 0V
			[Ignition switch: ON] ● Brake pedal: Fully released (A/T) ● Clutch pedal and brake pedal: Fully released (M/T)	BATTERY VOLTAGE (11 - 14V)

## Diagnostic Procedure A/T MODELS


GBS000QY

### 1. CHECK OVERALL FUNCTION-I

 **With CONSULT-II**

- Turn ignition switch ON.
- Select "BRAKE SW1" in "DATA MONITOR" mode with CONSULT-II.
- Check "BRAKE SW1" indication under the following conditions.

CONDITION	INDICATION
Brake pedal: Slightly depressed	OFF
Brake pedal: Fully released	ON



SEC011D


 **Without CONSULT-II**

- Turn ignition switch ON.
- Check voltage between ECM terminal 108 and ground under the following conditions.

CONDITION	VOLTAGE
Brake pedal: Slightly depressed	Approximately 0V
Brake pedal: Fully released	Battery voltage

**OK or NG**

- OK >> GO TO 2.  
NG >> GO TO 3.



MBIB0061E

# DTC P1572 ASCD BRAKE SWITCH


[VQ TYPE 1]

## 2. CHECK OVERALL FUNCTION-II

### With CONSULT-II

Check "BRAKE SW2" indication in "DATA MONITOR" mode.

CONDITION	INDICATION
Brake pedal: Fully released	OFF
Brake pedal: Slightly depressed	ON




### Without CONSULT-II

Check voltage between ECM terminal 101 and ground under the following conditions.

CONDITION	VOLTAGE
Brake pedal: Fully released	Approximately 0V
Brake pedal: Slightly depressed	Battery voltage


OK or NG

- OK >> GO TO 11.
- NG >> GO TO 7.



## 3. CHECK ASCD BRAKE SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch (1) harness connector.
  - Stop lamp switch (2)
3. Turn ignition switch ON.




4. Check voltage between ASCD brake switch terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.



## 4. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse
- Harness for open or short between ASCD brake switch and fuse

>> Repair open circuit or short to ground in harness or connectors.

## 5. CHECK ASCD BRAKE SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 108 and ASCD brake switch terminal 2. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 6.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 6. CHECK ASCD BRAKE SWITCH

Refer to [EC-462, "Component Inspection"](#)


OK or NG

OK >> GO TO 11.

NG >> Replace ASCD brake switch.

## 7. CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch (2) harness connector.
- ASCD brake switch (1)




3. Check voltage between stop lamp switch terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

OK >> GO TO 9.

NG >> GO TO 8.



---

## 8. DETECT MALFUNCTIONING PART

---

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse
- Harness for open or short between stop lamp switch and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 9. CHECK STOP LAMP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 101 and stop lamp switch terminal 2.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 10.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 10. CHECK STOP LAMP SWITCH

---

Refer to [EC-462, "Component Inspection"](#)

OK or NG

OK >> GO TO 11.

NG >> Replace stop lamp switch.

---

## 11. CHECK INTERMITTENT INCIDENT

---

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**


## M/T MODELS

### 1. CHECK OVERALL FUNCTION-I

**④ With CONSULT-II**

1. Turn ignition switch ON.
2. Select "BRAKE SW1" in "DATA MONITOR" mode with CONSULT-II.
3. Check "BRAKE SW1" indication under the following conditions.


CONDITION	INDICATION
Clutch pedal and/or brake pedal: Slightly depressed	OFF
Clutch pedal and brake pedal: Fully released	ON



**⊗ Without CONSULT-II**

1. Turn ignition switch ON.
2. Check voltage between ECM terminal 108 and ground under the following conditions.

CONDITION	VOLTAGE
Clutch pedal and/or brake pedal: Slightly depressed	Approximately 0V
Clutch pedal and brake pedal: Fully released	Battery voltage



OK or NG

- OK    >> GO TO 2.  
 NG    >> GO TO 3.




## 2. CHECK OVERALL FUNCTION-II

**With CONSULT-II**

Check "BRAKE SW2" indication in "DATA MONITOR" mode.

CONDITION	INDICATION
Brake pedal: Fully released	OFF
Brake pedal: Slightly depressed	ON




**Without CONSULT-II**

Check voltage between ECM terminal 101 and ground under the following conditions.

CONDITION	VOLTAGE
Brake pedal: Fully released	Approximately 0V
Brake pedal: Slightly depressed	Battery voltage


OK or NG

- OK >> GO TO 14.
- NG >> GO TO 10.



## 3. CHECK ASCD CLUTCH SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ASCD clutch switch harness connector.
3. Turn ignition switch ON.




4. Check voltage between ASCD clutch switch terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage


OK or NG

- OK >> GO TO 8.
- NG >> GO TO 4.



## 4. CHECK ASCD BRAKE SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch harness connector.
3. Turn ignition switch ON.




4. Check voltage between ASCD brake switch terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



## 5. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse
- Harness for open or short between ASCD brake switch and fuse

>> Repair open circuit or short to ground in harness or connectors.

## 6. CHECK ASCD BRAKE SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Check harness continuity between ASCD brake switch terminal 2 and ASCD clutch switch terminal 1. Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 7. CHECK ASCD BRAKE SWITCH

Refer to [EC-462, "Component Inspection"](#).

OK or NG

- OK >> GO TO 14.
- NG >> Replace ASCD brake switch.

## 8. CHECK ASCD BRAKE SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 108 and ASCD clutch switch terminal 2.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 9.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 9. CHECK ASCD CLUTCH SWITCH

Refer to [EC-462, "Component Inspection"](#) .


OK or NG

OK >> GO TO 14.

NG >> Replace ASCD clutch switch.

## 10. CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch harness connector.




3. Check voltage between stop lamp switch terminal 2 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

OK >> GO TO 12.

NG >> GO TO 11.



## 11. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse
- Harness for open or short between stop lamp switch and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 12. CHECK STOP LAMP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 101 and stop lamp switch terminal 1. Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

**OK or NG**

OK >> GO TO 13.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 13. CHECK STOP LAMP SWITCH

Refer to [EC-462, "Component Inspection"](#) .

**OK or NG**

OK >> GO TO 14.

NG >> Replace stop lamp switch.

## 14. CHECK INTERMITTENT INCIDENT

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**


### Component Inspection ASC D BRAKE SWITCH

GBS000QZ

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch harness connector.
3. Check continuity between ASCD brake switch terminals 1 and 2 under the following conditions.

Condition	Continuity
Brake pedal: Fully released	Should exist
Brake pedal: Slightly depressed	Should not exist

If NG, adjust ASCD brake switch installation, refer to [BR-6, "BRAKE PEDAL"](#) , and perform step 3 again.




### ASC D CLUTCH SWITCH

1. Turn ignition switch OFF.
2. Disconnect ASCD clutch switch harness connector.
3. Check continuity between ASCD clutch switch terminals 1 and 2 under the following conditions.


Condition	Continuity
Clutch pedal: Fully released	Should exist
Clutch pedal: Slightly depressed	Should not exist

If NG, adjust ASCD clutch switch installation, refer to [CL-6, "CLUTCH PEDAL"](#) , and perform step 3 again.



## STOP LAMP SWITCH

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch harness connector.
3. Check continuity between stop lamp switch terminals 1 and 2 under the following conditions.



Condition	Continuity
Brake pedal: Fully released	Should not exist
Brake pedal: Slightly depressed	Should exist

If NG, adjust stop lamp switch installation, refer to [BR-6, "BRAKE PEDAL"](#), and perform step 3 again.

A  
 EC  
 C  
 D  
 E  
 F  
 G  
 H  
 I  
 J  
 K  
 L  
 M

## DTC P1574 ASCD VEHICLE SPEED SENSOR

PFP:31036

### Component Description

GBS0014E

The ECM receives two vehicle speed sensor signals via CAN communication line. One is sent from combination meter, and the other is from TCM (Transmission control module). The ECM uses these signals for ASCD control. Refer to [EC-34, "AUTOMATIC SPEED CONTROL DEVICE \(ASCD\)"](#) for ASCD functions.

### On Board Diagnosis Logic

GBS0014F

This self-diagnosis has the one trip detection logic.  
The MIL will not light up for this diagnosis.

**NOTE:**

- If DTC P1574 is displayed with DTC U1000 or U1001, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-146, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#) .
- If DTC P1574 is displayed with DTC P0500, first perform the trouble diagnosis for DTC P0500. Refer to [EC-281, "DTC P0500 VSS"](#)
- If DTC P1574 is displayed with DTC P0605, first perform the trouble diagnosis for DTC P0605. Refer to [EC-288, "DTC P0605 ECM"](#)

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P1574 1574	ASCD vehicle speed sensor	ECM detects a difference between two vehicle speed signals is out of the specified range.	<ul style="list-style-type: none"> <li>● Harness or connectors (The CAN communication line is open or shorted.)</li> <li>● Combination meter</li> <li>● ABS actuator and electric unit (control unit)</li> <li>● Wheel sensor</li> <li>● TCM (A/T models)</li> <li>● ECM</li> </ul>

### DTC Confirmation Procedure

GBS0014G

**CAUTION:**

Always drive vehicle at a safe speed.

**NOTE:**


If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION:**

Step 3 may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

**WITH CONSULT-II**

1. Start engine.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Drive the vehicle at more than 40 km/h (25 MPH).
4. If DTC is detected, go to [EC-465, "Diagnostic Procedure"](#) .



**WITH GST**

Follow the procedure "WITH CONSULT-II" above.

### Diagnostic Procedure

#### 1. CHECK DTC WITH TCM

Check DTC with TCM. Refer to [AT-35, "TROUBLE DIAGNOSIS"](#) .

OK or NG

OK >> GO TO 2.

NG >> Perform trouble shooting relevant to DTC indicated.

#### 2. CHECK DTC WITH "ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)"

Refer to [BRC-8, "TROUBLE DIAGNOSIS"](#) .

OK or NG

OK >> GO TO 3.

NG >> Repair or replace.

#### 3. CHECK COMBINATION METER

Refer to [DI-4, "COMBINATION METERS"](#) .

>> INSPECTION END

A

EC

C

D

E

F

G

H

I

J

K

L

M

## DTC P1706 PNP SWITCH

PFP:32006

### Component Description

GBS000R0

When the selector lever position is P or N (A/T), Neutral (M/T), park/neutral position (PNP) switch is ON. ECM detects the position because the continuity of the line (the ON signal) exists.

### CONSULT-II Reference Value in Data Monitor Mode

GBS000R1

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
P/N POSI SW	● Ignition switch: ON	Shift lever: P or N (A/T), Neutral (M/T) ON
		Shift lever: Except above OFF

### On Board Diagnosis Logic

GBS000R2

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1706 1706	Park/neutral position switch	The signal of the park/neutral position (PNP) switch is not changed in the process of engine starting and driving.	<ul style="list-style-type: none"> <li>● Harness or connectors [The park/neutral position (PNP) switch circuit is open or shorted.]</li> <li>● Park/neutral position (PNP) switch</li> <li>● Combination meter</li> <li>● TCM (A/T models)</li> </ul>

### DTC Confirmation Procedure

GBS000R3

#### CAUTION:

**Always drive vehicle at a safe speed.**

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "P/N POSI SW" in "DATA MONITOR" mode with CONSULT-II. Then check the "P/N POSI SW" signal under the following conditions.

Position (Selector lever)	Known-good signal
P or N position (A/T) Neutral position (M/T)	ON
Except above position	OFF

If NG, go to [EC-469, "Diagnostic Procedure"](#) .  
If OK, go to following step.

3. Select "DATA MONITOR" mode with CONSULT-II.
4. Start engine and warm it up to normal operating temperature.
5. Maintain the following conditions for at least 60 consecutive seconds.

ENG SPEED	1,400 - 6,375 rpm
COOLAN TEMP/S	More than 70°C (158°F)
B/FUEL SCHDL	2.0 - 31.8 msec
VHCL SPEED SE	More than 64 km/h (40 MPH)
Selector lever	Suitable position

6. If 1st trip DTC is detected, go to [EC-469, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
P/N POSI SW	ON

SEF212Y

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
P/N POSI SW	OFF
B/FUEL SCHDL	XXX msec

SEF213Y



## Overall Function Check


Use this procedure to check the overall function of the park/neutral position (PNP) switch circuit. During this check, a 1st trip DTC might not be confirmed.

**WITH GST**

1. Turn ignition switch ON.
2. Check voltage between ECM terminal 102 (PNP switch signal) and ground under the following conditions.

Condition (Gear position)	Voltage V (Known-good data)
P or N position (A/T) Neutral position (M/T)	Approx. 0
Except above position	BATTERY VOLTAGE (11 - 14V)

3. If NG, go to [EC-469, "Diagnostic Procedure"](#) .



A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



# DTC P1706 PNP SWITCH

[VQ TYPE 1]

GBS000R5




## Wiring Diagram

### EC-PNP/SW-01



REFER TO THE FOLLOWING.

(M91) -SUPER MULTIPLE JUNCTION (SMJ)



\* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

MBWA1310E

# DTC P1706 PNP SWITCH

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.

## CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
102	G (A/T) O (M/T)	PNP switch	<b>[Ignition switch: ON]</b> ● Shift lever: P or N (A/T), Neutral (M/T)	Approximately 0V
			<b>[Ignition switch: ON]</b> ● Except above position	BATTERY VOLTAGE (11 - 14V)

## Diagnostic Procedure A/T MODELS

GBS000R6

### 1. CHECK DTC WITH TCM

Refer to [AT-35, "TROUBLE DIAGNOSIS"](#).

OK or NG

- OK >> GO TO 2.
- NG >> Repair or replace.

### 2. CHECK STARTING SYSTEM

Turn ignition switch OFF, then turn it to START.

**Does starter motor operate?**

Yes or No

- Yes >> GO TO 3.
- No >> Refer to [SC-30, "STARTING SYSTEM"](#).

### 3. CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT-I

1. Turn ignition switch OFF.
2. Disconnect A/T assembly harness connector.
3. Disconnect combination meter harness connector.
4. Check harness continuity between A/T assembly terminal 9 and combination meter terminal 17.  
Refer to Wiring Diagram.

**Continuity should exist.**

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

### 4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M91, E101
- Harness connectors E8, F2
- Harness for open or short between A/T assembly and combination meter.

>> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 5. CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT-II

---

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 102 and combination meter terminal 7.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.  
NG >> GO TO 6.

---

## 6. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors E101, M91
- Harness for open or short between ECM and combination meter

>> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 7. CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT-III

---

1. Check harness continuity between A/T assembly terminal 9 and TCM terminal 8.  
Refer to [AT-99, "DTC P0615 START SIGNAL CIRCUIT"](#) .

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.  
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 8. CHECK INTERMITTENT INCIDENT

---

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> GO TO 9.  
NG >> Repair or replace.

---

## 9. REPLACE COMBINATION METER

---

Refer to [DI-4, "COMBINATION METERS"](#) .

>> INSPECTION END

**M/T MODELS****1. CHECK PNP SWITCH GROUND CIRCUIT**

1. Turn ignition switch OFF.
2. Disconnect park/neutral position (PNP) switch harness connector.
3. Check harness continuity between PNP switch terminal 2 and ground.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to power.

OK or NG

- OK >> GO TO 3  
NG >> GO TO 2.

**2. DETECT MALFUNCTIONING PART**

Check the following.

- Harness connectors F2, E8
- Harness for open or short between PNP switch and ground

>> Repair open circuit or short to power in harness or connectors.

**3. CHECK PNP SWITCH INPUT SIGNAL CIRCUIT**

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 102 and PNP switch terminal 1.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.  
NG >> GO TO 4.

**4. DETECT MALFUNCTIONING PART**

Check the following.

- Harness connectors E8, F2
- Harness for open or short between PNP switch and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

**5. CHECK PNP SWITCH**

Refer to [MT-12, "PARK/NEUTRAL POSITION \(PNP\) SWITCH"](#) .

OK or NG

- OK >> GO TO 6.  
NG >> Replace PNP switch.

**6. CHECK INTERMITTENT INCIDENT**

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

# DTC P1715 INPUT SPEED SENSOR (TURBINE REVOLUTION SENSOR)

[VQ TYPE 1]

## DTC P1715 INPUT SPEED SENSOR (TURBINE REVOLUTION SENSOR)

PF3:31935

### Description

GBS000R7

ECM receives turbine revolution sensor signal from TCM through CAN communication line. ECM uses this signal for engine control.

### CONSULT-II Reference Value in Data Monitor Mode

GBS000R8

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
I/P PULLY SPD	● Vehicle speed: More than 20 km/h (12MPH)	Almost the same speed as the tachometer indication

### On Board Diagnosis Logic

GBS000R9

#### NOTE:

- If DTC P1715 is displayed with DTC U1000, U1001 first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-146, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#) .
- If DTC P1715 is displayed with DTC P0605, first perform the trouble diagnosis for DTC P0605. Refer to [EC-288, "DTC P0605 ECM"](#) .
- If DTC P1715 is displayed with DTC P0335, first perform the trouble diagnosis for DTC P0335. Refer to [EC-252, "DTC P0335 CKP SENSOR \(POS\)"](#) .
- If DTC P1715 is displayed with DTC P0340, P0345 first perform the trouble diagnosis for DTC P0340, P0345. Refer to [EC-259, "DTC P0340, P0345 CMP SENSOR \(PHASE\)"](#) .

The MIL will not lights up for this diagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1715 1715	Input speed sensor (Turbine revolution sensor) (TCM output)	Turbine revolution sensor signal is different from the theoretical value calculated by ECM from revolution sensor signal and engine rpm signal.	<ul style="list-style-type: none"><li>● Harness or connectors (The CAN communication line is open or shorted)</li><li>● Harness or connectors (Turbine revolution sensor circuit is open or shorted)</li><li>● TCM</li></ul>

### Diagnostic Procedure

GBS000RA

#### 1. CHECK DTC WITH TCM

Check DTC with TCM. Refer to [AT-35, "TROUBLE DIAGNOSIS"](#) .

OK or NG

OK >> GO TO 2.

NG >> Perform trouble shooting relevant to DTC indicated.

#### 2. REPLACE TCM

Replace TCM. Refer to [AT-35, "TROUBLE DIAGNOSIS"](#) .

>> INSPECTION END

# DTC P1805 BRAKE SWITCH

[VQ TYPE 1]

## DTC P1805 BRAKE SWITCH

PF2:25320

### Description

GBS000RB

Brake switch signal is applied to the ECM through the stop lamp switch when the brake pedal is depressed. This signal is used mainly to decrease the engine speed when the vehicle is driving.

### CONSULT-II Reference Value in Data Monitor Mode

GBS000RC

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
BRAKE SW	● Ignition switch: ON	Brake pedal: Fully released	OFF
		Brake pedal: Slightly depressed	ON

### On Board Diagnosis Logic

GBS000RD

The MIL will not light up for this diagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1805 1805	Brake switch	A brake switch signal is not sent to ECM for extremely long time while the vehicle is driving.	<ul style="list-style-type: none"> <li>● Harness or connectors (Stop lamp switch circuit is open or shorted.)</li> <li>● Stop lamp switch</li> </ul>

### FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode.

Engine operating condition in fail-safe mode

ECM controls the electric throttle control actuator by regulating the throttle opening to a small range. Therefore, acceleration will be poor.

Vehicle condition	Driving condition
When engine is idling	Normal
When accelerating	Poor acceleration

### DTC Confirmation Procedure

GBS000RE

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### WITH CONSULT-II

1. Turn ignition switch ON.
2. Fully depress the brake pedal for at least 5 seconds.
3. Erase the DTC with CONSULT-II.
4. Select "DATA MONITOR" mode with CONSULT-II.
5. If 1st trip DTC is detected, go to [EC-475, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

#### WITH GST

Follow the procedure "WITH CONSULT-II" above.


# DTC P1805 BRAKE SWITCH

[VQ TYPE 1]

GBS000RF

## Wiring Diagram


### EC-BRK/SW-01



: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC

A : WITH A/T  
M : WITH M/T

- \*1 1: A
- 2: M
- \*2 2: A
- 1: M



E20  
B



4	3
2	1

 E109  
B

1	2
---	---

 E116  
B

REFER TO THE FOLLOWING.

E103 - FUSE BLOCK -  
 JUNCTION BOX (J/B)

MBWA1420E



# DTC P1805 BRAKE SWITCH

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
101	V	Stop lamp switch	[Ignition switch: OFF] ● Brake pedal: Fully released	Approximately 0V
			[Ignition switch: OFF] ● Brake pedal: Slightly depressed	BATTERY VOLTAGE (11 - 14V)

## Diagnostic Procedure

GBS000RG

### 1. CHECK STOP LAMP SWITCH CIRCUIT

- Turn ignition switch OFF.
- Check the stop lamp when depressing and releasing the brake pedal.


Brake pedal	Stop lamp
Fully released	Not illuminated
Slightly depressed	Illuminated

**OK or NG**


- OK >> GO TO 4.
- NG >> GO TO 2.

### 2. CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

- Disconnect stop lamp switch (2) harness connector.
  - ASCD brake switch (1)



- Check voltage between stop lamp switch terminal 1 (A/T) or 2 (M/T) and ground with CONSULT-II or tester.



M/T models

A/T models

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 4.  
 NG >> GO TO 3.

**3. DETECT MALFUNCTIONING PART**

Check the following.

- 10A fuse
- Fuse block (J/B) connector E103
- Harness for open and short between stop lamp switch and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

**4. CHECK STOP LAMP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**


1. Disconnect ECM harness connector.
2. Disconnect stop lamp switch (2) harness connector.
  - ASCD brake switch (1)
3. Check harness continuity between ECM terminal 101 and stop lamp switch terminal 2 (A/T) or 1 (M/T). Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.  
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**5. CHECK STOP LAMP SWITCH**Refer to [EC-477, "Component Inspection"](#) .


OK or NG

- OK >> GO TO 6.  
 NG >> Replace stop lamp switch.


**6. CHECK INTERMITTENT INCIDENT**Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .**>> INSPECTION END**

## Component Inspection STOP LAMP SWITCH

1. Disconnect stop lamp switch (2) harness connector.
  - ASCD brake switch (1)



2. Check continuity between stop lamp switch terminals 1 and 2 under the following conditions.



Conditions	Continuity
Brake pedal: Fully released	Should not exist.
Brake pedal: Slightly depressed	Should exist.

3. If NG, adjust stop lamp switch installation, refer to [BR-6, "BRAKE PEDAL"](#) , and perform step 2 again.

DTC P2122, P2123 APP SENSOR

PFP:18002


Component Description

GBS000RI

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometers which transform the accelerator pedal position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the accelerator pedal and feed the voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these signals.

Idle position of the accelerator pedal is determined by the ECM receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for the engine operation such as fuel cut.



CONSULT-II Reference Value in Data Monitor Mode

GBS000RJ

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
ACCEL SEN 1 ACCEL SEN 2*	● Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	0.6 - 0.95V
		Accelerator pedal: Fully depressed	Less than 4.75V
CLSD THL POS	● Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	ON
		Accelerator pedal: Slightly depressed	OFF

\*: Accelerator pedal position sensor 2 signal is converted by ECM internally. Thus, it differs from ECM terminal voltage.

On Board Diagnosis Logic

GBS000RK

These self-diagnoses have the one trip detection logic.

NOTE:

If DTC P2122 or P2123 is displayed with DTC P1229, first perform the trouble diagnosis for DTC P1229. Refer to [EC-365, "DTC P1229 SENSOR POWER SUPPLY"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P2122 2122	Accelerator pedal position sensor 1 circuit low input	An excessively low voltage from the APP sensor 1 is sent to ECM.	<ul style="list-style-type: none"> <li>● Harness or connectors (The APP sensor 1 circuit is open or shorted.)</li> <li>● Accelerator pedal position sensor (APP sensor 1)</li> </ul>
P2123 2123	Accelerator pedal position sensor 1 circuit high input	An excessively high voltage from the APP sensor 1 is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, ECM enters fail-safe mode and the MIL lights up.

Engine operating condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

## DTC Confirmation Procedure

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

#### WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-481, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

#### WITH GST

Follow the procedure "WITH CONSULT-II" above.

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



# DTC P2122, P2123 APP SENSOR



[VQ TYPE 1]

GBS000RM

## Wiring Diagram

EC-APPS1-01

 : DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



MBWA1313E

# DTC P2122, P2123 APP SENSOR

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
82	B	Sensor ground (APP sensor 1)	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed	Approximately 0V
83	O	Sensor ground (APP sensor 2)	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed	Approximately 0V
90	L	Sensor power supply (APP sensor 1)	<b>[Ignition switch: ON]</b>	Approximately 5V
91	G	Sensor power supply (APP sensor 2)	<b>[Ignition switch: ON]</b>	Approximately 5V
98	GR	Accelerator pedal position sensor 2	<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully released	0.3 - 0.45V
			<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully depressed	Less than 2.4V
106	R	Accelerator pedal position sensor 1	<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully released	0.6 - 0.95V
			<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully depressed	Less than 4.75V

## Diagnostic Procedure

GBS000RN

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-145, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

## 2. CHECK APP SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect accelerator pedal position (APP) sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between APP sensor terminal 2 and ground with CONSULT-II or tester.

**Voltage: Approximately 5V**

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



## 3. CHECK APP SENSOR 1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between APP sensor terminal 4 and ECM terminal 82. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 4. CHECK APP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 106 and APP sensor terminal 3. Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 5. CHECK APP SENSOR

Refer to [EC-483, "Component Inspection"](#).

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.



**6. REPLACE ACCELERATOR PEDAL ASSEMBLY**

1. Replace accelerator pedal assembly.
2. Perform [EC-71, "Accelerator Pedal Released Position Learning"](#) .
3. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
4. Perform [EC-71, "Idle Air Volume Learning"](#) .

>> INSPECTION END

**7. CHECK INTERMITTENT INCIDENT**

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

**Component Inspection  
ACCELERATOR PEDAL POSITION SENSOR**

GBS000RO

1. Reconnect all harness connectors disconnected.
2. Turn ignition switch ON.
3. Check voltage between ECM terminals 106 (APP sensor 1 signal), 98 (APP sensor 2 signal) and ground under the following conditions.

Terminal	Accelerator pedal	Voltage
106 (Accelerator pedal position sensor 1)	Fully released	0.6 - 0.95V
	Fully depressed	Less than 4.75V
98 (Accelerator pedal position sensor 2)	Fully released	0.3 - 0.45V
	Fully depressed	Less than 2.4V



4. If NG, replace accelerator pedal assembly and go to next step.
5. Perform [EC-71, "Accelerator Pedal Released Position Learning"](#) .
6. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
7. Perform [EC-71, "Idle Air Volume Learning"](#) .

**Removal and Installation  
ACCELERATOR PEDAL**

GBS000RP

Refer to [ACC-2, "ACCELERATOR CONTROL SYSTEM"](#) .

DTC P2127, P2128 APP SENSOR

PFP:18002


Component Description

GBS000RO

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometers which transform the accelerator pedal position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the accelerator pedal and feed the voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these signals.

Idle position of the accelerator pedal is determined by the ECM receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for the engine operation such as fuel cut.



CONSULT-II Reference Value in Data Monitor Mode

GBS000RR

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
ACCEL SEN 1 ACCEL SEN 2*	● Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	0.6 - 0.95V
		Accelerator pedal: Fully depressed	Less than 4.75V
CLSD THL POS	● Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	ON
		Accelerator pedal: Slightly depressed	OFF

\*: Accelerator pedal position sensor 2 signal is converted by ECM internally. Thus, it differs from ECM terminal voltage.

On Board Diagnosis Logic

GBS000RS

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P2127 2127	Accelerator pedal position sensor 2 circuit low input	An excessively low voltage from the APP sensor 2 is sent to ECM.	<ul style="list-style-type: none"> <li>● Harness or connectors (The APP sensor 2 circuit is open or shorted.) (The TP sensor circuit shorted.)</li> <li>● Accelerator pedal position sensor (APP sensor 2)</li> <li>● Electric throttle control actuator (TP sensor 1 and 2)</li> </ul>
P2128 2128	Accelerator pedal position sensor 2 circuit high input	An excessively high voltage from the APP sensor 2 is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, ECM enters fail-safe mode and the MIL lights up.

Engine operating condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

## DTC Confirmation Procedure

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION:**

**Before performing the following procedure, confirm that battery voltage is more than 10V at idle.**

 **WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-488, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
<small>SEF058Y</small>	

 **WITH GST**

Follow the procedure "WITH CONSULT-II" above.

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# DTC P2127, P2128 APP SENSOR



[VQ TYPE 1]

GBS000RU

## Wiring Diagram

EC-APPS2-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



MBWA1314E

# DTC P2127, P2128 APP SENSOR

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	W	Sensor power supply (Throttle position sensor)	[Ignition switch: ON]	Approximately 5V
82	B	Sensor ground (APP sensor 1)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
83	O	Sensor ground (APP sensor 2)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
90	L	Sensor power supply (APP sensor 1)	[Ignition switch: ON]	Approximately 5V
91	G	Sensor power supply (APP sensor 2)	[Ignition switch: ON]	Approximately 5V
98	GR	Accelerator pedal position sensor 2	[Ignition switch: ON] ● Engine: Stopped ● Accelerator pedal: Fully released	0.3 - 0.45V
			[Ignition switch: ON] ● Engine: Stopped ● Accelerator pedal: Fully depressed	Less than 2.4V
106	R	Accelerator pedal position sensor 1	[Ignition switch: ON] ● Engine: Stopped ● Accelerator pedal: Fully released	0.6 - 0.95V
			[Ignition switch: ON] ● Engine: Stopped ● Accelerator pedal: Fully depressed	Less than 4.75V

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

## Diagnostic Procedure

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body, Refer to [EC-145, "Ground Inspection"](#) .



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

### 2. CHECK APP SENSOR 2 POWER SUPPLY CIRCUIT-I

1. Disconnect accelerator pedal position (APP) sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between APP sensor terminal 1 and ground with CONSULT-II or tester.

**Voltage: Approximately 5V**

#### OK or NG

- OK >> GO TO 7.  
 NG >> GO TO 3.



**3. CHECK APP SENSOR 2 POWER SUPPLY CIRCUIT-II**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between APP sensor terminal 1 and ECM terminal 91.  
Refer to wiring diagram.

**Continuity should exist.**

OK or NG

- OK >> GO TO 4.  
NG >> Repair open circuit.

**4. CHECK THROTTLE POSITION SENSOR 2 POWER SUPPLY CIRCUIT-III**

Check harness for short to power and short to ground, between the following terminals.

ECM terminal	Sensor terminal	Reference Wiring Diagram
91	APP sensor terminal 1	<a href="#">EC-486</a>
47	Electric throttle control actuator terminal 2	<a href="#">EC-233</a>

OK or NG

- OK >> GO TO 5.  
NG >> Repair short to ground or short to power in harness or connectors.

**5. CHECK THROTTLE POSITION SENSOR**

Refer to [EC-237, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 11.  
NG >> GO TO 6.

**6. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR**

1. Replace electric throttle control actuator.
2. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-71, "Idle Air Volume Learning"](#) .

**>> INSPECTION END**

**7. CHECK APP SENSOR 2 GROUND CIRCUIT FOR OPEN AND SHORT**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between APP sensor terminal 5 and ECM terminal 83.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.  
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**8. CHECK APP SENSOR 2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

1. Check harness continuity between ECM terminal 98 and APP sensor terminal 6.  
Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 9.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**9. CHECK APP SENSOR**

Refer to [EC-490, "Component Inspection"](#) .

OK or NG

OK >> GO TO 11.

NG >> GO TO 10.

**10. REPLACE ACCELERATOR PEDAL ASSEMBLY**

1. Replace accelerator pedal assembly.
2. Perform [EC-71, "Accelerator Pedal Released Position Learning"](#) .
3. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
4. Perform [EC-71, "Idle Air Volume Learning"](#) .

>> INSPECTION END

**11. CHECK INTERMITTENT INCIDENT**

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

**Component Inspection  
ACCELERATOR PEDAL POSITION SENSOR**

GBS000RW

1. Reconnect all harness connectors disconnected.
2. Turn ignition switch ON.
3. Check voltage between ECM terminals 106 (APP sensor 1 signal), 98 (APP sensor 2 signal) and ground under the following conditions.

Terminal	Accelerator pedal	Voltage
106 (Accelerator pedal position sensor 1)	Fully released	0.6 - 0.95V
	Fully depressed	Less than 4.75V
98 (Accelerator pedal position sensor 2)	Fully released	0.3 - 0.45V
	Fully depressed	Less than 2.4V



4. If NG, replace accelerator pedal assembly and go to next step.
5. Perform [EC-71, "Accelerator Pedal Released Position Learning"](#) .
6. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
7. Perform [EC-71, "Idle Air Volume Learning"](#) .

**Removal and Installation  
ACCELERATOR PEDAL**

GBS000RX

Refer to [ACC-2, "ACCELERATOR CONTROL SYSTEM"](#) .



**DTC P2135 TP SENSOR**


PF1:16119

**Component Description**

GBS000RY

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



**CONSULT-II Reference Value in Data Monitor Mode**

GBS000RZ

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
THRTL SEN 1 THRTL SEN 2*	<ul style="list-style-type: none"> <li>Ignition switch: ON (Engine stopped)</li> <li>Shift lever: D (A/T), 1st (M/T)</li> </ul>	Accelerator pedal: Fully released	More than 0.36V
		Accelerator pedal: Fully depressed	Less than 4.75V

\*: Throttle position sensor 2 signal is converted by ECM internally. Thus, it differs from ECM terminal voltage signal.

**On Board Diagnosis Logic**

GBS000S0

**This self-diagnosis has the one trip detection logic.**

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P2135 2135	Throttle position sensor circuit range/performance	Rationally incorrect voltage is sent to ECM compared with the signals from TP sensor 1 and TP sensor 2.	<ul style="list-style-type: none"> <li>Harness or connector (The TP sensor 1 and 2 circuit is open or shorted.) (The APP sensor 2 circuit is shorted).</li> <li>Electric throttle control actuator (TP sensor 1 and 2)</li> <li>Accelerator pedal position sensor (APP sensor 2)</li> </ul>

**FAIL-SAFE MODE**

When the malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.

Engine operation condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

## DTC Confirmation Procedure

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

#### WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-495, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

#### WITH GST

Follow the procedure "WITH CONSULT-II" above.

# DTC P2135 TP SENSOR





[VQ TYPE 1]

## Wiring Diagram

GBS000S2

EC-TPS3-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



MBWA1315E

## DTC P2135 TP SENSOR

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**


**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	W	Sensor power supply (Throttle position sensor)	<b>[Ignition switch: ON]</b>	Approximately 5V
50	W	Throttle position sensor 1	<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully released</li> </ul>	More than 0.36V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully depressed</li> </ul>	Less than 4.75V
66	B	Sensor ground (Throttle position sensor)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 0V
69	R	Throttle position sensor 2	<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully released</li> </ul>	Less than 4.75V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully depressed</li> </ul>	More than 0.36V
91	G	Sensor power supply (APP sensor 2)	<b>[Ignition switch: ON]</b>	Approximately 5V

**Diagnostic Procedure**

**1. CHECK GROUND CONNECTIONS**

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body.  
Refer to [EC-145, "Ground Inspection"](#) .



↔ : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

**2. CHECK THROTTLE POSITION SENSOR POWER SUPPLY CIRCUIT-I**

1. Disconnect electric throttle control actuator harness connector.
2. Turn ignition switch ON.




3. Check voltage between electric throttle control actuator terminal 2 and ground with CONSULT-II or tester.

**Voltage: Approximately 5V**

OK or NG

- OK >> GO TO 7.  
 NG >> GO TO 3.



### 3. CHECK THROTTLE POSITION SENSOR POWER SUPPLY CIRCUIT-II

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between electric throttle control actuator terminal 2 and ECM terminal 47.  
Refer to Wiring Diagram.

**Continuity should exist.**

OK or NG

- OK >> GO TO 4.  
NG >> Repair open circuit.

### 4. CHECK THROTTLE POSITION SENSOR POWER SUPPLY CIRCUIT-III

Check harness for short to power and short to ground, between the following terminals.

ECM terminal	Sensor terminal	Reference Wiring Diagram
47	Electric throttle control actuator terminal 2	<a href="#">EC-493</a>
91	APP sensor terminal 1	<a href="#">EC-486</a>

OK or NG

- OK >> GO TO 5.  
NG >> Repair short to ground or short to power in harness or connectors.

### 5. CHECK APP SENSOR

Refer to [EC-490, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 11.  
NG >> GO TO 6.

### 6. REPLACE ACCELERATOR PEDAL ASSEMBLY

1. Replace accelerator pedal assembly.
2. Perform [EC-71, "Accelerator Pedal Released Position Learning"](#) .
3. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
4. Perform [EC-71, "Idle Air Volume Learning"](#) .

>> **INSPECTION END**

### 7. CHECK THROTTLE POSITION SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between electric throttle control actuator terminal 4 and ECM terminal 66.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.  
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**8. CHECK THROTTLE POSITION SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

1. Check harness continuity between ECM terminal 50 and electric throttle control actuator terminal 1, ECM terminal 69 and electric throttle control actuator terminal 3.  
Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 9.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**9. CHECK THROTTLE POSITION SENSOR**

Refer to [EC-497, "Component Inspection"](#).

OK or NG

OK >> GO TO 11.

NG >> GO TO 10.

**10. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR**

1. Replace the electric throttle control actuator.
2. Perform [EC-71, "Throttle Valve Closed Position Learning"](#).
3. Perform [EC-71, "Idle Air Volume Learning"](#).

>> INSPECTION END

**11. CHECK INTERMITTENT INCIDENT**

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

>> INSPECTION END


**Component Inspection  
THROTTLE POSITION SENSOR**

GBS000S4

1. Reconnect all harness connectors disconnected.
2. Perform [EC-71, "Throttle Valve Closed Position Learning"](#).
3. Turn ignition switch ON.
4. Set selector lever to D position (A/T), 1st position (M/T).
5. Check voltage between ECM terminals 50 (TP sensor 1 signal), 69 (TP sensor 2 signal) and ground under the following conditions.

Terminal	Accelerator pedal	Voltage
50 (Throttle position sensor 1)	Fully released	More than 0.36V
	Fully depressed	Less than 4.75V
69 (Throttle position sensor 2)	Fully released	Less than 4.75V
	Fully depressed	More than 0.36V

6. If NG, replace electric throttle control actuator and go to the next step.
7. Perform [EC-71, "Throttle Valve Closed Position Learning"](#).
8. Perform [EC-71, "Idle Air Volume Learning"](#).



PBIB1170E

---

**Removal and Installation**  
**ELECTRIC THROTTLE CONTROL ACTUATOR**

GBS000S5

Refer to [EM-18, "INTAKE MANIFOLD COLLECTOR"](#) .



DTC P2138 APP SENSOR


PFP:18002

Component Description

GBS000S6

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometers which transform the accelerator pedal position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the accelerator pedal and feed the voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these signals.



Idle position of the accelerator pedal is determined by the ECM receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for the engine operation such as fuel cut.

CONSULT-II Reference Value in Data Monitor Mode

GBS000S7

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
ACCEL SEN 1 ACCEL SEN 2*	● Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	0.6 - 0.95V
		Accelerator pedal: Fully depressed	Less than 4.75V
CLSD THL POS	● Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	ON
		Accelerator pedal: Slightly depressed	OFF

\*: Accelerator pedal position sensor 2 signal is converted by ECM internally. Thus, it differs from ECM terminal voltage.

On Board Diagnosis Logic

GBS000S8

This self-diagnosis has the one trip detection logic.

NOTE:

If DTC P2138 is displayed with DTC P1229, first perform the trouble diagnosis for DTC P1229. Refer to [EC-365, "DTC P1229 SENSOR POWER SUPPLY"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P2138 2138	Accelerator pedal position sensor circuit range/performance	Rationally incorrect voltage is sent to ECM compared with the signals from APP sensor 1 and APP sensor 2.	<ul style="list-style-type: none"> <li>● Harness or connector (The APP sensor 1 and 2 circuit is open or shorted.) (The TP sensor circuit is shorted.)</li> <li>● Accelerator pedal position sensor 1 and 2</li> <li>● Electric throttle control actuator (TP sensor 1 and 2)</li> </ul>

FAIL-SAFE MODE

When the malfunction is detected, ECM enters fail-safe mode and the MIL lights up.

Engine operating condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

## DTC Confirmation Procedure

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

#### WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-503, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

#### WITH GST

Follow the procedure "WITH CONSULT-II" above.

# DTC P2138 APP SENSOR



[VQ TYPE 1]

## Wiring Diagram

GBS000SA

EC-APPS3-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



MBWA1316E

# DTC P2138 APP SENSOR

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**


**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	W	Sensor power supply (Throttle position sensor)	<b>[Ignition switch: ON]</b>	Approximately 5V
82	B	Sensor ground (APP sensor 1)	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed	Approximately 0V
83	O	Sensor ground (APP sensor 2)	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed	Approximately 0V
90	L	Sensor power supply (APP sensor 1)	<b>[Ignition switch: ON]</b>	Approximately 5V
91	G	Sensor power supply (APP sensor 2)	<b>[Ignition switch: ON]</b>	Approximately 5V
98	GR	Accelerator pedal position sensor 2	<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully released	0.3 - 0.45V
			<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully depressed	Less than 2.4V
106	R	Accelerator pedal position sensor 1	<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully released	0.6 - 0.95V
			<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully depressed	Less than 4.75V

## Diagnostic Procedure

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-145, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

### 2. CHECK APP SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect accelerator pedal position (APP) sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between APP sensor terminal 2 and ground with CONSULT-II or tester.

**Voltage: Approximately 5V**

#### OK or NG

- OK >> GO TO 3.  
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.




### 3. CHECK APP SENSOR 2 POWER SUPPLY CIRCUIT-I

Check voltage between APP sensor terminal 1 and ground with CONSULT-II or tester.

**Voltage: Approximately 5V**

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 4.



### 4. CHECK APP SENSOR 2 POWER SUPPLY CIRCUIT-II

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between APP sensor terminal 1 and ECM terminal 91. Refer to wiring diagram.

**Continuity should exist.**

OK or NG

- OK >> GO TO 5.
- NG >> Repair open circuit.

### 5. CHECK APP SENSOR 2 POWER SUPPLY CIRCUIT-III

Check harness for short to power and short to ground, between the following terminals.

ECM terminal	Sensor terminal	Reference Wiring Diagram
91	APP sensor terminal 1	<a href="#">EC-501</a>
47	Electric throttle control actuator terminal 2	<a href="#">EC-493</a>

OK or NG

- OK >> GO TO 6.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

### 6. CHECK THROTTLE POSITION SENSOR

Refer to [EC-237, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 12.
- NG >> GO TO 7.

### 7. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace electric throttle control actuator.
2. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-71, "Idle Air Volume Learning"](#) .

>> INSPECTION END

**8. CHECK APP SENSOR GROUND CIRCUIT FOR OPEN AND SHORT**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between APP sensor terminals 4 and ECM terminal 82, APP sensor terminal 5 and ECM terminal 83.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 9.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**9. CHECK APP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

1. Check harness continuity between ECM terminal 106 and APP sensor terminal 3, ECM terminal 98 and APP sensor terminal 6.  
Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 10.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**10. CHECK APP SENSOR**

Refer to [EC-505, "Component Inspection"](#) .

OK or NG

OK >> GO TO 12.

NG >> GO TO 11.

**11. REPLACE ACCELERATOR PEDAL ASSEMBLY**

1. Replace accelerator pedal assembly.
2. Perform [EC-71, "Accelerator Pedal Released Position Learning"](#) .
3. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .
4. Perform [EC-71, "Idle Air Volume Learning"](#) .

**>> INSPECTION END**

**12. CHECK INTERMITTENT INCIDENT**

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

**>> INSPECTION END**

### Component Inspection

#### ACCELERATOR PEDAL POSITION SENSOR

GBS000SC


1. Reconnect all harness connectors disconnected.
2. Turn ignition switch ON.

# DTC P2138 APP SENSOR

[VQ TYPE 1]

3. Check voltage between ECM terminals 106 (APP sensor 1 signal), 98 (APP sensor 2 signal) and ground under the following conditions.

Terminal	Accelerator pedal	Voltage
106 (Accelerator pedal position sensor 1)	Fully released	0.6 - 0.95V
	Fully depressed	Less than 4.75V
98 (Accelerator pedal position sensor 2)	Fully released	0.3 - 0.45V
	Fully depressed	Less than 2.4V



4. If NG, replace accelerator pedal assembly and go to next step.  
5. Perform [EC-71, "Accelerator Pedal Released Position Learning"](#) .  
6. Perform [EC-71, "Throttle Valve Closed Position Learning"](#) .  
7. Perform [EC-71, "Idle Air Volume Learning"](#) .

## Removal and Installation ACCELERATOR PEDAL

GBS000SD

Refer to [ACC-2, "ACCELERATOR CONTROL SYSTEM"](#) .



# ASCD BRAKE SWITCH

[VQ TYPE 1]


## ASCD BRAKE SWITCH

PFP:25320

### Component Description

GBS000SE

When the brake pedal is depressed, ASCD brake switch (1) is turned OFF and stop lamp switch (2) is turned ON. ECM detects the state of the brake pedal by this input of two kinds (ON/OFF signal). Refer to [EC-34, "AUTOMATIC SPEED CONTROL DEVICE \(ASCD\)"](#) for the ASCD function.



### CONSULT-II Reference Value in Data Monitor Mode

GBS000SF

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
BRAKE SW 1 (ASCD brake switch)	● Ignition switch: ON	Brake pedal: Fully released (A/T) Clutch pedal and brake pedal: Fully released (M/T)	ON
		Brake pedal: Slightly depressed (A/T) Clutch pedal and/or brake pedal: Slightly depressed (M/T)	OFF
BRAKE SW 2 (Stop lamp switch)	● Ignition switch: ON	Brake pedal: Fully released	OFF
		Brake pedal: Slightly depressed	ON



# ASC D BRAKE SWITCH

[VQ TYPE 1]

GBS000SG

## Wiring Diagram

### EC-ASCBOF-01



(E20) B



4 3  
2 1

(E109) W

2  
1

(E110) BR

1 2  
(E111) L

1 2  
(E116) B

REFER TO THE FOLLOWING.

(E103) - FUSE BLOCK - JUNCTION BOX (J/B)

MBWA1421E

# ASCD BRAKE SWITCH

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
101	V	Stop lamp switch	<b>[Ignition switch: OFF]</b> ● Brake pedal: Fully released	Approximately 0V
			<b>[Ignition switch: OFF]</b> ● Brake pedal: Slightly depressed	BATTERY VOLTAGE (11 - 14V)
108	LG	ASCD brake switch	<b>[Ignition switch: ON]</b> ● Brake pedal: Slightly depressed (A/T) ● Clutch pedal and/or brake pedal: Slightly depressed (M/T)	Approximately 0V
			<b>[Ignition switch: ON]</b> ● Brake pedal: Fully released (A/T) ● Clutch pedal and brake pedal: Fully released (M/T)	BATTERY VOLTAGE (11 - 14V)

## Diagnostic Procedure A/T MODELS


GBS000SH

### 1. CHECK OVERALL FUNCTION-I

**With CONSULT-II**

- Turn ignition switch ON.
- Select "BRAKE SW1" in "DATA MONITOR" mode with CONSULT-II.
- Check "BRAKE SW1" indication under the following conditions.

CONDITION	INDICATION
Brake pedal: Slightly depressed	OFF
Brake pedal: Fully released	ON




**Without CONSULT-II**

- Turn ignition switch ON.
- Check voltage between ECM terminal 108 and ground under the following conditions.

CONDITION	VOLTAGE
Brake pedal: Slightly depressed	Approximately 0V
Brake pedal: Fully released	Battery voltage

**OK or NG**

- OK >> GO TO 2.  
NG >> GO TO 3.




## 2. CHECK OVERALL FUNCTION-II

**With CONSULT-II**

Check "BRAKE SW2" indication in "DATA MONITOR" mode.

CONDITION	INDICATION
Brake pedal: Fully released	OFF
Brake pedal: Slightly depressed	ON




**Without CONSULT-II**

Check voltage between ECM terminal 101 and ground under the following conditions.

CONDITION	VOLTAGE
Brake pedal: Fully released	Approximately 0V
Brake pedal: Slightly depressed	Battery voltage


OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 7.



## 3. CHECK ASCD BRAKE SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch (1) harness connector.
  - Stop lamp switch (2)
3. Turn ignition switch ON.




4. Check voltage between ASCD brake switch terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.



## 4. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse
- Harness for open or short between ASCD brake switch and fuse

>> Repair open circuit or short to ground in harness or connectors.

## 5. CHECK ASCD BRAKE SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 108 and ASCD brake switch terminal 2. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 6.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 6. CHECK ASCD BRAKE SWITCH

Refer to [EC-518, "Component Inspection"](#)


OK or NG

OK >> GO TO 11.

NG >> Replace ASCD brake switch.

## 7. CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch (2) harness connector.
- ASCD brake switch (1)




3. Check voltage between stop lamp switch terminal 1 and ground with CONSULT -II or tester.

**Voltage: Battery voltage**

OK or NG

OK >> GO TO 9.

NG >> GO TO 8.



---

## 8. DETECT MALFUNCTIONING PART

---

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse
- Harness for open or short between stop lamp switch and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 9. CHECK STOP LAMP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 101 and stop lamp switch terminal 2.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 10.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 10. CHECK STOP LAMP SWITCH

---

Refer to [EC-518, "Component Inspection"](#)

OK or NG

OK >> GO TO 11.

NG >> Replace stop lamp switch.

## 11. CHECK INTERMITTENT INCIDENT

---

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**


**M/T MODELS**

**1. CHECK OVERALL FUNCTION-I**

**Ⓜ With CONSULT-II**

1. Turn ignition switch ON.
2. Select "BRAKE SW1" in "DATA MONITOR" mode with CONSULT-II.
3. Check "BRAKE SW1" indication under the following conditions.


CONDITION	INDICATION
Clutch pedal and/or brake pedal: Slightly depressed	OFF
Clutch pedal and brake pedal: Fully released	ON



**ⓧ Without CONSULT-II**

1. Turn ignition switch ON.
2. Check voltage between ECM terminal 108 and ground under the following conditions.

CONDITION	VOLTAGE
Clutch pedal and/or brake pedal: Slightly depressed	Approximately 0V
Clutch pedal and brake pedal: Fully released	Battery voltage



**OK or NG**

- OK >> GO TO 2.
- NG >> GO TO 3.

# ASCD BRAKE SWITCH


[VQ TYPE 1]

## 2. CHECK OVERALL FUNCTION-II

### ④ With CONSULT-II

Check "BRAKE SW2" indication in "DATA MONITOR" mode.


CONDITION	INDICATION
Brake pedal: Fully released	OFF
Brake pedal: Slightly depressed	ON



### ⊗ Without CONSULT-II

Check voltage between ECM terminal 101 and ground under the following conditions.

CONDITION	VOLTAGE
Brake pedal: Fully released	Approximately 0V
Brake pedal: Slightly depressed	Battery voltage




### OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 10.



## 3. CHECK ASCD CLUTCH SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ASCD clutch switch harness connector.
3. Turn ignition switch ON.




4. Check voltage between ASCD clutch switch terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**


OK or NG

- OK >> GO TO 8.  
 NG >> GO TO 4.



## 4. CHECK ASCD BRAKE SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch harness connector.
3. Turn ignition switch ON.




4. Check voltage between ASCD brake switch terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 6.  
 NG >> GO TO 5.



---

## 5. DETECT MALFUNCTIONING PART

---

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse
- Harness for open or short between ASCD brake switch and fuse

>> Repair open circuit or short to ground in harness or connectors.

---

## 6. CHECK ASCD BRAKE SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

1. Turn ignition switch OFF.
2. Check harness continuity between ASCD brake switch terminal 2 and ASCD clutch switch terminal 1. Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 7.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 7. CHECK ASCD BRAKE SWITCH

---

Refer to [EC-518, "Component Inspection"](#) .

OK or NG

OK >> GO TO 14.

NG >> Replace ASCD brake switch.

---

## 8. CHECK ASCD BRAKE SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 108 and ASCD clutch switch terminal 2. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 9.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 9. CHECK ASCD CLUTCH SWITCH

---

Refer to [EC-518, "Component Inspection"](#) .


OK or NG

OK >> GO TO 14.

NG >> Replace ASCD clutch switch.

## 10. CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch harness connector.




3. Check voltage between stop lamp switch terminal 2 and ground with CONSULT -II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 12.
- NG >> GO TO 11.



## 11. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse
- Harness for open or short between stop lamp switch and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 12. CHECK STOP LAMP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 101 and stop lamp switch terminal 1. Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 13.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 13. CHECK STOP LAMP SWITCH

Refer to [EC-518, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 14.
- NG >> Replace stop lamp switch.

## 14. CHECK INTERMITTENT INCIDENT

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


### Component Inspection ASC D BRAKE SWITCH

GBS000SI

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch harness connector.
3. Check continuity between ASCD brake switch terminals 1 and 2 under the following conditions.

Condition	Continuity
Brake pedal: Fully released	Should exist
Brake pedal: Slightly depressed	Should not exist

If NG, adjust ASCD brake switch installation, refer to [BR-6, "BRAKE PEDAL"](#) , and perform step 3 again.




### ASC D CLUTCH SWITCH

1. Turn ignition switch OFF.
2. Disconnect ASCD clutch switch harness connector.
3. Check continuity between ASCD clutch switch terminals 1 and 2 under the following conditions.


Condition	Continuity
Clutch pedal: Fully released	Should exist
Clutch pedal: Slightly depressed	Should not exist

If NG, adjust ASCD clutch switch installation, refer to [CL-6, "CLUTCH PEDAL"](#) , and perform step 3 again.



### STOP LAMP SWITCH

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch harness connector.
3. Check continuity between stop lamp switch terminals 1 and 2 under the following conditions.



Condition	Continuity
Brake pedal: Fully released	Should not exist
Brake pedal: Slightly depressed	Should exist

# ASCD BRAKE SWITCH

[VQ TYPE 1]

---

If NG, adjust stop lamp switch installation, refer to [BR-6, "BRAKE PEDAL"](#) , and perform step 3 again.

A

EC

C

D

E

F

G

H

I

J

K

L

M

## ASC D INDICATOR

PFP:24814

### Component Description

*GBS000SJ*

ASC D indicator lamp illuminates to indicate ASC D operation status. Lamp has two indicators, CRUISE and SET, and is integrated in combination meter.

CRUISE indicator illuminates when MAIN switch on ASC D steering switch is turned ON to indicated that ASC D system is ready for operation.

SET indicator illuminates when following conditions are met.

- CRUISE indicator is illuminated.
- SET/COAST switch on ASC D steering switch is turned ON while vehicle speed is within the range of ASC D setting.

SET indicator remains lit during ASC D control.

Refer to [EC-34, "AUTOMATIC SPEED CONTROL DEVICE \(ASC D\)"](#) for the ASC D function.

### CONSULT-II Reference Value in Data Monitor Mode

*GBS000SK*

Specification data are reference value.

MONITOR ITEM	CONDITION		SPECIFICATION
CRUISE LAMP	● Ignition switch: ON	● MAIN switch: Pressed at the 1st time → at the 2nd time	ON → OFF
SET LAMP	● MAIN switch: ON	● ASC D: Operating	ON
	● When vehicle speed is between 40 km/h (25 MPH) and 175 km/h (109 MPH)	● ASC D: Not operating	OFF




# ASCND INDICATOR

[VQ TYPE 1]

GBS000SL

## Wiring Diagram

### EC-ASCIND-01



REFER TO THE FOLLOWING.

(M91) - SUPER MULTIPLE JUNCTION (SMJ)

(M88) - FUSE BLOCK - JUNCTION BOX (J/B)

MBWA1325E

## Diagnostic Procedure

### 1. CHECK OVERALL FUNCTION

Check ASC D indicator under the following conditions.

ASC D INDICATOR	CONDITION		SPECIFICATION
CRUISE LAMP	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> </ul>	<ul style="list-style-type: none"> <li>● MAIN switch: pressed at the 1st time → at the 2nd time</li> </ul>	ON → OFF
SET LAMP	<ul style="list-style-type: none"> <li>● MAIN switch: ON</li> <li>● When vehicle speed is between 40 km/h (25 MPH) and 175 km/h (109 MPH)</li> </ul>	<ul style="list-style-type: none"> <li>● ASC D: Operating</li> <li>● ASC D: Not operating</li> </ul>	ON  OFF

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 2.

### 2. CHECK DTC

Check that DTC U1000 or U1001 is not displayed.

OK or NG

- OK >> GO TO 3.
- NG >> Perform trouble diagnoses for DTC U1000, U1001. Refer to [EC-146, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#) .

### 3. CHECK COMBINATION METER FUNCTION

Refer to [DI-4, "COMBINATION METERS"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> Go to [DI-7, "Arrangement of Combination Meter"](#) .

### 4. CHECK INTERMITTENT INCIDENT

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**



## ELECTRICAL LOAD SIGNAL

PFP:25350

### Description

GBS000SN

The electrical load signal (Headlamp switch signal, etc.) is transferred through the CAN communication line from BCM to ECM via IPDM E/R.

### CONSULT-II Reference Value in Data Monitor Mode

GBS000SO

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
LOAD SIGNAL	● Ignition switch: ON	Rear window defogger switch ON and/or lighting switch is in 2nd. ON
		Rear window defogger switch and lighting switch are OFF. OFF
HEATER FAN SW	● Engine: After warming up, idle the engine	Heater fan switch: ON ON
		Heater fan switch: OFF OFF

### Diagnostic Procedure

GBS000SP


#### 1. CHECK LOAD SIGNAL CIRCUIT OVERALL FUNCTION-I

1. Turn ignition switch ON.
2. Connect CONSULT-II and select "DATA MONITOR" mode.
3. Select "LOAD SIGNAL" and check indication under the following conditions.

Condition	Indication
Rear window defogger switch: ON	ON
Rear window defogger switch: OFF	OFF

#### OK or NG

- OK >> GO TO 2.  
 NG >> GO TO 4.




#### 2. CHECK LOAD SIGNAL CIRCUIT OVERALL FUNCTION-II

Check "LOAD SIGNAL" indication under the following conditions.

Condition	Indication
Lighting switch: ON at 2nd position	ON
Lighting switch: OFF	OFF

#### OK or NG

- OK >> GO TO 3.  
 NG >> GO TO 5.



**3. CHECK HEATER FAN SIGNAL CIRCUIT OVERALL FUNCTION**

Select "HEATER FAN SW" and check indication under the following conditions.

Condition	Indication
Heater fan control switch: ON	ON
Heater fan control switch: OFF	OFF

**OK or NG**

OK >> **INSPECTION END**  
 NG >> GO TO 6.

DATA MONITOR	
MONITORING	NO DTC
HEATER FAN SW	ON

PBIB1995E

**4. CHECK REAR WINDOW DEFOGGER SYSTEM**

Refer to [GW-45, "REAR WINDOW DEFOGGER"](#) .

>> **INSPECTION END**

**5. CHECK HEADLAMP SYSTEM**

Refer to [LT-4, "HEADLAMP"](#) or [LT-31, "HEADLAMP AIMING CONTROL \(MANUAL\)"](#) .

>> **INSPECTION END**

**6. CHECK HEATER FAN CONTROL SYSTEM**

Refer to [MTC-32, "TROUBLE DIAGNOSIS"](#) .

>> **INSPECTION END**

## EVAP CANISTER VENT CONTROL VALVE

PF14935



### Component Description

GBS000SQ

The EVAP canister vent control valve is located on the EVAP canister.

This solenoid valve is not used for engine control, and always remains open.

If the vent is closed by any reason under EVAP purge conditions, the evaporative emission control system is depressured and EVAP canister may be damaged.



A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# EVAP CANISTER VENT CONTROL VALVE

[VQ TYPE 1]



GBS000SR

## Wiring Diagram


### EC-VENT-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC


REFER TO PG-POWER.



E12  
W



E20  
B



C5  
B

REFER TO THE FOLLOWING.

(C1) - SUPER MULTIPLE JUNCTION (SMJ)

# EVAP CANISTER VENT CONTROL VALVE

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
111	BR	ECM relay (Self shut-off)	[Engine is running] [Ignition switch: OFF] ● For a few seconds after turning ignition switch OFF	0 - 1.5V
			[Ignition switch: OFF] ● More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14V)
117	G	EVAP canister vent control valve	[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14V)

## Diagnostic Procedure

GBS000SS

### 1. CHECK OVERALL FUNCTION


1. Turn ignition switch OFF.
2. Remove EVAP canister vent control valve with its harness connector connected from EVAP canister.
3. Start engine.



4. Blow air into port **A** and check that it flows freely out of port **B**.

OK or NG

- OK >> **INSPECTION END**  
 NG >> GO TO 2.




## 2. CHECK EVAP CANISTER VENT CONTROL VALVE POWER SUPPLY CIRCUIT

1. Disconnect EVAP canister vent control valve harness connector.
2. Turn ignition switch ON.
3. Check voltage between EVAP canister vent control valve terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



## 3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E107, C1
- Harness for open or short between EVAP canister vent control valve and IPDM E/R

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 4. CHECK EVAP CANISTER VENT CONTROL VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 117 and EVAP canister vent control valve terminal 2. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.

## 5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors C1, E107
- Harness for open or short between EVAP canister vent control valve and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 6. CHECK EVAP CANISTER VENT CONTROL VALVE

Refer to [EC-529, "Component Inspection"](#).

OK or NG

- OK >> GO TO 7.
- NG >> Replace EVAP canister vent control valve.

## 7. CHECK INTERMITTENT INCIDENT


Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

### Component Inspection EVAP CANISTER VENT CONTROL VALVE

GBS000ST

1. Remove EVAP canister vent control valve from EVAP canister.
2. Check portion **B** of EVAP canister vent control valve for being rusted.



3. Check air passage continuity and operation delay time under the following conditions.


**Make sure new O-ring is installed properly.**

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	No
OFF	Yes

**Operation takes less than 1 second.**

If NG, replace EVAP canister vent control valve.  
If OK, go to next step.

4. Clean the air passage (Portion **A** to **B** ) of EVAP canister vent control valve using an air blower.
5. Perform step 3 again.




## FUEL INJECTOR

PFP:16600

### Component Description

GBS000SU

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the fuel injector circuit, the coil in the fuel injector is energized. The energized coil pulls the ball valve back and allows fuel to flow through the fuel injector into the intake manifold. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the fuel injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.



### CONSULT-II Reference Value in Data Monitor Mode

GBS000SV

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
B/FUEL SCHDL	See <a href="#">EC-127, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE"</a> .		
INJ PULSE-B1 INJ PULSE-B2	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Shift lever: P or N (A/T), Neutral (M/T)</li> <li>● Air conditioner switch: OFF</li> <li>● No load</li> </ul>	Idle	2.0 - 3.0 msec
		2,000 rpm	1.9 - 2.9 msec





# FUEL INJECTOR

[VQ TYPE 1]

## Wiring Diagram

GBS000SW

### EC-INJECT-01



MBWA1321E



# FUEL INJECTOR

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
21	W	Fuel injector No. 5	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <b>NOTE:</b> The pulse cycle changes depending on rpm at idle	BATTERY VOLTAGE (11 - 14V)★ 
22	LG	Fuel injector No. 3		BATTERY VOLTAGE (11 - 14V)★ 
23	SB	Fuel injector No. 1		SEC984C
40	V	Fuel injector No. 6		SEC985C
41	R	Fuel injector No. 4		
42	O	Fuel injector No. 2		

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

GBS000SX

### 1. INSPECTION START

Turn ignition switch to START.

**Is any cylinder ignited?**

Yes or No

Yes (With CONSULT-II)>>GO TO 2.

Yes (Without CONSULT-II)>>GO TO 3.

No >> GO TO 7.

### 2. CHECK OVERALL FUNCTION

Ⓟ **With CONSULT-II**

1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
3. Make sure that each circuit produces a momentary engine speed drop.

ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0133E

OK or NG


OK >> **INSPECTION END**

NG >> GO TO 7.

## 3. CHECK FUNCTION OF FUEL INJECTOR-I

⊗ Without CONSULT-II


1. Stop engine.
2. Disconnect harness connector F101 (1), F7 (2).
  - ⇐ Vehicle front
3. Turn ignition switch ON.



4. Check voltage between harness connector F7 terminal 3 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

5. Turn ignition switch OFF.
6. Disconnect ECM harness connector.
7. Check harness continuity between harness connector F7 and ECM as follows.  
Refer to Wiring Diagram.



Cylinder	Harness connector F7 terminal	ECM terminal
1	2	23
3	1	22
5	4	21

**Continuity should exist.**

8. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

## 4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E9, F4
- IPDM E/R harness connector E12
- 15A fuse
- Harness for open or short between harness connector F7 and fuse
- Harness for open or short between harness connector F7 and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 5. CHECK FUNCTION OF FUEL INJECTOR-II

Provide battery voltage between harness connector F101 as follows and then interrupt it. Listen to each fuel injector operating sound.


Cylinder	Harness connector F101 terminal	
	(+)	(-)
1	3	2
3	3	1
5	3	4

**Operating sound should exist.**

OK or NG

OK >> GO TO 6.

NG >> GO TO 7.



## 6. CHECK FUNCTION OF FUEL INJECTOR-III


1. Reconnect all harness connector disconnected.
2. Start engine.
3. Listen to fuel injectors No. 2, No. 4, No.6 operating sound.

**Clicking noise should exist.**

OK or NG


OK >> **INSPECTION END**

NG >> GO TO 7.



## 7. CHECK FUEL INJECTOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect fuel injector harness connector (1).




3. Turn ignition switch ON.
4. Check voltage between fuel injector terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 9.
- NG >> GO TO 8.



## 8. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E9, F4
- Harness connectors F7, F101
- IPDM E/R harness connector E12
- 15A fuse
- Harness for open or short between fuel injector and fuse

>> Repair harness or connectors.

## 9. CHECK FUEL INJECTOR OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between fuel injector terminal 2 and ECM terminals 21, 22, 23, 40, 41, 42. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 11.
- NG >> GO TO 10.

## 10. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F101, F7 (bank 1)
- Harness for open or short between fuel injector and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 11. CHECK FUEL INJECTOR

Refer to [EC-536, "Component Inspection"](#) .

OK or NG

OK >> GO TO 12.

NG >> Replace fuel injector.

## 12. CHECK INTERMITTENT INCIDENT

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

### Component Inspection FUEL INJECTOR

GBS000SY

1. Disconnect fuel injector harness connector.
2. Check resistance between terminals as shown in the figure.

**Resistance: 11.1 - 14.5Ω [at 10 - 60°C (50 - 140°F)]**



GBS000SZ

### Removal and Installation FUEL INJECTOR

Refer to [EM-36, "FUEL INJECTOR AND FUEL TUBE"](#) .

# FUEL PUMP

[VQ TYPE 1]

## FUEL PUMP

PF17042

### Description SYSTEM DESCRIPTION

GBS000T0

Sensor	Input Signal to ECM	ECM Function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed*	Fuel pump control	Fuel pump relay
Battery	Battery voltage*		

\*: ECM determines the start signal status by the signals of engine speed and battery voltage.


The ECM activates the fuel pump for several seconds after the ignition switch is turned ON to improve engine start ability. If the ECM receives a engine speed signal from the camshaft position sensor (PHASE), it knows that the engine is rotating, and causes the pump to operate. If the engine speed signal is not received when the ignition switch is ON, the engine stalls. The ECM stops pump operation and prevents battery discharging, thereby improving safety. The ECM does not directly drive the fuel pump. It controls the ON/OFF fuel pump relay, which in turn controls the fuel pump.

Condition	Fuel pump operation
Ignition switch is turned to ON.	Operates for 1 second.
Engine running and cranking	Operates.
When engine is stopped	Stops in 1.5 seconds.
Except as shown above	Stops.

### COMPONENT DESCRIPTION

A turbine type design fuel pump is used in the fuel tank.

- Fuel level sensor unit and fuel pump
- Fuel pressure regulator



### CONSULT-II Reference Value in Data Monitor Mode

GBS000T1

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
FUEL PUMP RLY	<ul style="list-style-type: none"> <li>● For 1 second after turning ignition switch ON</li> <li>● Engine running or cranking</li> </ul>	ON
	<ul style="list-style-type: none"> <li>● Except above conditions</li> </ul>	OFF

# FUEL PUMP


[VQ TYPE 1]

GBS00072


## Wiring Diagram

### EC-F/PUMP-01

— : DETECTABLE LINE FOR DTC  
 - - - : NON-DETECTABLE LINE FOR DTC



REFER TO PG-POWER.



REFER TO THE FOLLOWING.

(C1) - SUPER MULTIPLE JUNCTION (SMJ)

MBWA1322E



# FUEL PUMP

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
113	V	Fuel pump relay	<b>[Ignition switch: ON]</b> ● For 1 second after turning ignition switch ON <b>[Engine is running]</b>	0 - 1.5V
			<b>[Ignition switch: ON]</b> ● More than 1 second after turning ignition switch ON	BATTERY VOLTAGE (11 - 14V)

## Diagnostic Procedure


GBS00073

### 1. CHECK OVERALL FUNCTION

1. Turn ignition switch ON.
2. Pinch fuel feed hose with two fingers.  
**Fuel pressure pulsation should be felt on the fuel feed hose for 1 second after ignition switch is turned ON.**

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 2.




### 2. CHECK FUEL PUMP POWER SUPPLY CIRCUIT-I

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Turn ignition switch ON.
4. Check voltage between ECM terminal 113 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 3.




## 3. CHECK FUEL PUMP POWER SUPPLY CIRCUIT-II

Check voltage between IPDM E/R terminal 46 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 12.




## 4. DETECT MALFUNCTIONING PART

Check harness for open or short between IPDM E/R and ECM

>> Repair harness or connectors.

## 5. CHECK FUEL PUMP POWER SUPPLY CIRCUIT-III

1. Turn ignition switch OFF.
2. Reconnect all harness connectors disconnected.
3. Disconnect "fuel level sensor unit and fuel pump" harness connector.
4. Turn ignition switch ON.




5. Check voltage between "fuel level sensor unit and fuel pump" terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage should exist for 1 second after ignition switch is turned ON.**

OK or NG

- OK >> GO TO 9.
- NG >> GO TO 6.



## 6. CHECK 15A FUSE

1. Turn ignition switch OFF.
2. Disconnect 15A fuse.
3. Check 15A fuse.

OK or NG

- OK >> GO TO 7.
- NG >> Replace fuse.

**7. CHECK FUEL PUMP POWER SUPPLY CURCUIT-IV**

1. Disconnect IPDM E/R harness connector E12.
2. Check harness continuity between “fuel level sensor unit and fuel pump” terminal 1 and IPDM E/R terminal 13.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 12.
- NG >> GO TO 8.

**8. DETECT MALFUNCTIONING PART**

Check the following.

- Harness connectors C1, E107
- Harness for open or short between “fuel level sensor unit and fuel pump” and IPDM E/R

>> Repair open circuit or short to ground or short to power in harness or connectors.

**9. CHECK FUEL PUMP GROUND CIRCUIT FOR OPEN AND SHORT**

1. Check harness continuity between “fuel level sensor unit and fuel pump” terminal 3 and ground.  
Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground.

OK or NG

- OK >> GO TO 11.
- NG >> GO TO 10.

**10. DETECT MALFUNCTIONING PART**

Check the following.

- Harness connectors C1, E107
- Harness for open or short between “fuel level sensor unit and fuel pump” and ground

>> Repair open circuit or short to power in harness or connectors.

**11. CHECK FUEL PUMP**

Refer to [EC-542, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 12.
- NG >> Replace fuel pump.

**12. CHECK INTERMITTENT INCIDENT**

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG


- OK >> Replace IPDM E/R.
- NG >> Repair or replace harness or connectors.

### Component Inspection FUEL PUMP

GBS00074

1. Disconnect "fuel level sensor unit and fuel pump" harness connector.
2. Check resistance between "fuel level sensor unit and fuel pump" terminals 1 and 3.

**Resistance: Approximately 0.2 - 5.0Ω [at 25°C (77°F)]**



### Removal and Installation FUEL PUMP

GBS00075

Refer to [FL-10, "FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY"](#) .

### IGNITION SIGNAL


PFP:22448

#### Component Description

GBS00076

#### IGNITION COIL & POWER TRANSISTOR

The ignition signal from the ECM is sent to and amplified by the power transistor. The power transistor turns ON and OFF the ignition coil primary circuit. This ON/OFF operation induces the proper high voltage in the coil secondary circuit.



A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



# IGNITION SIGNAL

[VQ TYPE 1]


GBS00077

## Wiring Diagram


### EC-IGNSYS-01



E12  
W




E20  
B



F4  
W



F6  
G



F24  
GR

MBWA1317E

# IGNITION SIGNAL

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
111	BR	ECM relay (Self shut-off)	<b>[Engine is running]</b> <b>[Ignition switch: OFF]</b> <ul style="list-style-type: none"> <li>For a few seconds after turning ignition switch OFF</li> </ul>	0 - 1.5V
			<b>[Ignition switch: OFF]</b> <ul style="list-style-type: none"> <li>More than a few seconds after turning ignition switch OFF</li> </ul>	BATTERY VOLTAGE (11 - 14V)
119 120	R P	Power supply for ECM	<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)




A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# IGNITION SIGNAL

[VQ TYPE 1]

## EC-IGNSYS-02

— : DETECTABLE LINE FOR DTC  
 - - - : NON-DETECTABLE LINE FOR DTC



MBWA1318E





# IGNITION SIGNAL

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
60 61 62	V L Y	Ignition signal No. 5 Ignition signal No. 3 Ignition signal No. 1	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	<p>0 - 0.2V★</p> 
			<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,500 rpm</li> </ul>	<p>0.1 - 0.4V★</p> 




★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# IGNITION SIGNAL

[VQ TYPE 1]

## EC-IGNSYS-03

— : DETECTABLE LINE FOR DTC  
 - - - : NON-DETECTABLE LINE FOR DTC



MBWA1319E



# IGNITION SIGNAL

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
79	P	Ignition signal No. 6	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <b>NOTE:</b> The pulse cycle changes depending on rpm at idle	0 - 0.2V★  SEC986C
80	GR	Ignition signal No. 4		0.1 - 0.4V★  SEC987C
81	G	Ignition signal No. 2		

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

GBS00078

### 1. CHECK ENGINE START

Turn ignition switch OFF, and restart engine.

**Is engine running?**

Yes or No

Yes (With CONSULT-II)>>GO TO 2.

Yes (Without CONSULT-II)>>GO TO 3.

No >> GO TO 4.

### 2. CHECK OVERALL FUNCTION

🔧 **With CONSULT-II**

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
2. Make sure that each circuit produces a momentary engine speed drop.

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 10.

ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0133E


## 3. CHECK OVERALL FUNCTION

⊗ **Without CONSULT-II**


1. Let engine idle.
2. Read the voltage signal between ECM terminals 60, 61, 62, 79, 80, 81 and ground with an oscilloscope.
3. Verify that the oscilloscope screen shows the signal wave as shown below.

**NOTE:**

The pulse cycle changes depending on rpm at idle.



SEC986C



OK or NG

- OK >> **INSPECTION END**  
 NG >> GO TO 10.


## 4. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-I

1. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
2. Check voltage between ECM terminals 119, 120 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**


OK or NG

- OK >> GO TO 5.  
 NG >> Go to [EC-138, "POWER SUPPLY AND GROUND CIRCUIT"](#) .



## 5. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-II

1. Turn ignition switch OFF.
2. Disconnect condenser-1 harness connector.
3. Turn ignition switch ON.




4. Check voltage between condenser-1 terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 8.  
 NG >> GO TO 6.



## 6. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-III

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R harness connector E12.
3. Check harness continuity between IPDM E/R terminal 3 and condenser-1 terminal 1. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 17.  
 NG >> GO TO 7.

## 7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E9, F4
- Harness for open or short between condenser-1 and IPDM E/R

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 8. CHECK CONDENSER-1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Check harness continuity between condenser-1 terminal 2 and ground.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to power.

OK or NG

OK >> GO TO 9.

NG >> Repair open circuit or short to power in harness or connectors.

## 9. CHECK CONDENSER-1

Refer to [EC-554, "Component Inspection"](#) .


OK or NG

OK >> GO TO 10.

NG >> Replace condenser-1.

## 10. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-IV

1. Turn ignition switch OFF.
2. Reconnect all harness connectors disconnected.
3. Disconnect ignition coil harness connector.




4. Turn ignition switch ON.
5. Check voltage between ignition coil terminal 3 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

OK >> GO TO 12.

NG >> GO TO 11.



## 11. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F6, F125
- Harness for open or short between ignition coil and harness connector F4

>> Repair or replace harness or connectors.

---

## 12. CHECK IGNITION COIL GROUND CIRCUIT FOR OPEN AND SHORT

---

1. Turn ignition switch OFF.
2. Check harness continuity between ignition coil terminal 2 and ground.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 14.  
NG >> GO TO 13.

---

## 13. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors F125, F6
- Harness for open or short between ignition coil and ground

>> Repair open circuit or short to power in harness or connectors.

---

## 14. CHECK IGNITION COIL OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminals 60, 61, 62, 79, 80, 81 and ignition coil terminal 1.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 16.  
NG >> GO TO 15.

---

## 15. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors F6, F125
- Harness for open or short between ignition coil and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 16. CHECK IGNITION COIL WITH POWER TRANSISTOR

---

Refer to [EC-554, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 17.  
NG >> Replace ignition coil with power transistor.

---

## 17. CHECK INTERMITTENT INCIDENT

---

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

## Component Inspection IGNITION COIL WITH POWER TRANSISTOR

**CAUTION:**

Do the following procedure in the place where ventilation is good without the combustible.

1. Turn ignition switch OFF.
2. Disconnect ignition coil harness connector.
3. Check resistance between ignition coil terminals as follows.

Terminal No. (Polarity)	Resistance $\Omega$ [at 25°C (77°F)]
1 and 2	Except 0 or $\infty$
1 and 3	Except 0
2 and 3	

4. If NG, Replace ignition coil with power transistor.  
If OK, go to next step.
5. Turn ignition switch OFF.
6. Reconnect all harness connectors disconnected.
7. Remove fuel pump fuse in IPDM E/R to release fuel pressure.

**NOTE:**

Do not use CONSULT-II to release fuel pressure, or fuel pressure applies again during the following procedure.

8. Start engine.
9. After engine stalls, crank it two or three times to release all fuel pressure.
10. Turn ignition switch OFF.
11. Remove ignition coil harness connectors to avoid the electrical discharge from the ignition coils.
12. Remove ignition coil and spark plug of the cylinder to be checked.
13. Crank engine for 5 seconds or more to remove combustion gas in the cylinder.
14. Connect spark plug and harness connector to ignition coil.
15. Fix ignition coil using a rope etc. with gap of 13 - 17 mm between the edge of the spark plug and grounded metal portion as shown in the figure.
16. Crank engine for about three seconds, and check whether spark is generated between the spark plug and the grounded part.

**Spark should be generated.**

**CAUTION:**

- Do not approach to the spark plug and the ignition coil within 50cm. Be careful not to get an electrical shock while checking, because the electrical discharge voltage becomes 20kV or more.

- It might cause to damage the ignition coil if the gap of more than 17 mm is taken.




**NOTE:**

When the gap is less than 13 mm, the spark might be generated even if the coil is malfunctioning.

17. If NG, Replace ignition coil with power transistor.

### CONDENSER-1

1. Turn ignition switch OFF.
2. Disconnect condenser-1 harness connector.






# IGNITION SIGNAL

[VQ TYPE 1]

3. Check resistance between condenser-1 terminals 1 and 2.

Resistance	Above 1 M $\Omega$ at 25°C (77°F)
------------	-----------------------------------



GBS0007A

## Removal and Installation IGNITION COIL WITH POWER TRANSISTOR

Refer to [EM-33, "IGNITION COIL"](#) .

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# REFRIGERANT PRESSURE SENSOR

[VQ TYPE 1]



## REFRIGERANT PRESSURE SENSOR

PFP:92136

### Component Description

GBS0007B

The refrigerant pressure sensor is installed at the condenser of the air conditioner system. The sensor uses an electrostatic volume pressure transducer to convert refrigerant pressure to voltage. The voltage signal is sent to ECM, and ECM controls cooling fan system.



# REFRIGERANT PRESSURE SENSOR



[VQ TYPE 1]

## Wiring Diagram

GBS0007C

EC-RP/SEN-01

— : DETECTABLE LINE FOR DTC  
 - - - : NON-DETECTABLE LINE FOR DTC



MBWA1323E

# REFRIGERANT PRESSURE SENSOR

[VQ TYPE 1]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
49	P	Sensor power supply (Refrigerant pressure sensor)	[Ignition switch: ON]	Approximately 5V
67	GR	Sensor ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
70	BR	Refrigerant pressure sensor	[Engine is running] ● Warm-up condition ● Both A/C switch and blower switch: ON (Compressor operates)	1.0 - 4.0V

## Diagnostic Procedure

GBS0007D


### 1. CHECK REFRIGERANT PRESSURE SENSOR OVERALL FUNCTION

1. Start engine and warm it up to normal operating temperature.
2. Turn A/C switch and blower switch ON.
3. Check voltage between ECM terminal 70 and ground with CONSULT-II or tester.

**Voltage: 1.0 - 4.0V**


OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 2.



## 2. CHECK GROUND CONNECTIONS

1. Turn A/C switch and blower switch OFF.
2. Turn ignition switch OFF.
3. Loosen and retighten three ground screws on the body. Refer to [EC-145, "Ground Inspection"](#).



↶ : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

OK or NG

- OK >> GO TO 3.  
 NG >> Repair or replace ground connections.

## 3. CHECK REFRIGERANT PRESSURE SENSOR POWER SUPPLY CIRCUIT

1. Disconnect refrigerant pressure sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between refrigerant pressure sensor terminal 3 and ground with CONSULT-II or tester.

**Voltage: Approximately 5V**

OK or NG

- OK >> GO TO 5.  
 NG >> GO TO 4.



---

## 4. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors E8, F2
- Harness for open or short between ECM and refrigerant pressure sensor

>> Repair harness or connectors.

---

## 5. CHECK REFRIGERANT PRESSURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

---

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between refrigerant pressure sensor terminal 1 and ECM terminal 67. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.  
NG >> GO TO 6.

---

## 6. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors E8, F2
- Harness for open or short between ECM and refrigerant pressure sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 7. CHECK REFRIGERANT PRESSURE SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

1. Check harness continuity between ECM terminal 70 and refrigerant pressure sensor terminal 2. Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 9.  
NG >> GO TO 8.

---

## 8. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors E8, F2
- Harness for open or short between ECM and refrigerant pressure sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 9. CHECK INTERMITTENT INCIDENT

---

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> Replace refrigerant pressure sensor.  
NG >> Repair or replace.

### Removal and Installation REFRIGERANT PRESSURE SENSOR

GBS0007E

Refer to [MTC-121, "Removal and Installation for Refrigerant Pressure Sensor"](#) .

A

EC

C

D

E

F

G

H

I

J

K

L

M

**VIAS**


PFP:14956

**Description  
SYSTEM DESCRIPTION**

GBS0007F

Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed*	VIAS control	VIAS control solenoid valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Accelerator pedal position		
Battery	Battery voltage*		

\*: ECM determines the start signal status by the signals of engine speed and battery voltage.



When the engine is running at medium speed, the ECM sends the ON signal to the VIAS control solenoid valve. This signal introduces the intake manifold vacuum into the power valve actuator and therefore closes the power valve.

Under this condition, the effective intake manifold length is equivalent to the total length of passage A and passage B. This long intake manifold provides increased amount of intake air, which results in improved suction efficiency and higher torque.


When engine is running at low or high speed, the ECM sends the OFF signal to the VIAS control solenoid valve and the power valve is opened.

Under this condition, the effective intake manifold length is equivalent to the length of passage B. This shortened intake manifold length results in enhanced engine output due to reduced suction resistance under high speeds.

**COMPONENT DESCRIPTION**

**Power Valve**


The power valve is installed in intake manifold collector and used to control the suction passage of the variable induction air control system. It is set in the fully closed or fully opened position by the power valve actuator operated by the vacuum stored in the surge tank. The vacuum in the surge tank is controlled by the VIAS control solenoid valve.





**VIAS Control Solenoid Valve**

The VIAS control solenoid valve cuts the intake manifold vacuum signal for power valve control. It responds to ON/OFF signals from the ECM. When the solenoid is OFF, the vacuum signal from the intake manifold is cut. When the ECM sends an ON signal the coil pulls the plunger downward and feeds the vacuum signal to the power valve actuator.



**CONSULT-II Reference Value in Data Monitor Mode**

GBS0007G





Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
VIAS S/V	● Engine: After warming up	2,200 - 3,300 rpm	ON
		Except above conditions	OFF

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

Wiring Diagram

EC-VIAS-01



# VIAS

**[VQ TYPE 1]**

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
29	GR	VIAS control solenoid valve	<b>[Engine is running]</b> ● Idle speed	BATTERY VOLTAGE (11 - 14V)
			<b>[Engine is running]</b> ● Engine speed: Between 2,200 and 3,300 rpm	0 - 1.0V
111	BR	ECM relay (Self shut-off)	<b>[Engine is running]</b> <b>[Ignition switch: OFF]</b> ● For a few seconds after turning ignition switch OFF	0 - 1.5V
			<b>[Ignition switch: OFF]</b> ● More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14V)
119 120	R P	Power supply for ECM	<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

**Diagnostic Procedure**

**1. CHECK OVERALL FUNCTION**


**④ With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Perform "VIAS SOL VALVE" in "ACTIVE TEST" mode with CONSULT-II.

ACTIVE TEST	
VIAS SOL VALVE	OFF
MONITOR	
ENG SPEED	XXX rpm

PBIB0844E

3. Turn VIAS control solenoid valve "ON" and "OFF", and make sure that power valve actuator (1) rod moves.




**⊗ Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Rev engine up to between 2,200 and 3,300 rpm and make sure that power valve actuator (1) rod moves.

**OK or NG**

- OK >> **INSPECTION END**
- NG (With CONSULT-II) >>GO TO 2.
- NG (Without CONSULT-II) >>GO TO 3.




## 2. CHECK VACUUM EXISTENCE

**With CONSULT-II**

1. Stop engine and disconnect vacuum hose connected to power valve actuator.
2. Start engine and let it idle.
3. Perform "VIAS SOL VALVE" in "ACTIVE TEST" mode with CONSULT-II.
4. Turn VIAS control solenoid valve "ON" and "OFF", and check vacuum existence under the following conditions.

VIAS SOL VALVE	Vacuum
ON	Should exist.
OFF	Should not exist.



**OK or NG**


- OK >> Repair or replace power valve actuator.
- NG >> GO TO 4.

## 3. CHECK VACUUM EXISTENCE

**Without CONSULT-II**

1. Stop engine and disconnect vacuum hose connected to power valve actuator.
2. Disconnect VIAS control solenoid valve harness connector.
3. Start engine and let it idle.
4. Apply 12V of direct current between VIAS control solenoid valve terminals 1 and 2.
5. Check vacuum existence under the following conditions.

Condition	Vacuum
12V direct current supply	Should exist.
No supply	Should not exist.



**OK or NG**


- OK >> Repair or replace power valve actuator.
- NG >> GO TO 4.

## 4. CHECK VACUUM HOSE

1. Stop engine.
2. Check hoses and tubes between intake manifold and power valve actuator for crack, clogging, improper connection or disconnection. Refer to [EC-96, "Vacuum Hose Drawing"](#).

**OK or NG**

- OK >> GO TO 5.
- NG >> Repair hoses or tubes.



## 5. CHECK VACUUM TANK


Refer to [EC-569, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.  
 NG >> Replace vacuum tank.

## 6. CHECK VIAS CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect VIAS control solenoid valve harness connector.
3. Turn ignition switch ON.




4. Check voltage between VIAS control solenoid valve terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 8.  
 NG >> GO TO 7.



## 7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E9, F4
- Harness for open or short between VIAS control solenoid valve and IPDM E/R
- Harness for open or short between VIAS control solenoid valve and ECM

>> Repair harness or connectors.

## 8. CHECK VIAS CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 29 and VIAS control solenoid valve terminal 2.  
 Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 9.  
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**9. CHECK VIAS CONTROL SOLENOID VALVE**

Refer to [EC-569, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 10.
- NG >> Replace VIAS control solenoid valve.

**10. CHECK INTERMITTENT INCIDENT**

Refer to [EC-137, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

**Component Inspection  
VIAS CONTROL SOLENOID VALVE**


GBS0007J

**Ⓟ With CONSULT-II**

1. Reconnect harness connectors disconnected.
2. Turn ignition switch ON.
3. Perform "VIAS SOL VALVE" in "ACTIVE TEST" mode.
4. Check air passage continuity and operation delay time under the following conditions.

Condition VIAS SOL VALVE	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
ON	Yes	No
OFF	No	Yes

**Operation takes less than 1 second.**




**ⓧ Without CONSULT-II**

Check air passage continuity and operation delay time under the following conditions.


Condition	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12V direct current supply between terminals 1 and 2	Yes	No
No supply	No	Yes

**Operation takes less than 1 second.**



**VACUUM TANK**

1. Disconnect vacuum hose connected to vacuum tank.
2. Connect a vacuum pump to the port A of vacuum tank.
3. Apply vacuum and make sure that vacuum exists at the port B.



---

**Removal and Installation**  
**VIAS CONTROL SOLENOID VALVE**

GBS000TK

Refer to [EM-21, "INTAKE MANIFOLD"](#) .



# MIL AND DATA LINK CONNECTOR

[VQ TYPE 1]




## MIL AND DATA LINK CONNECTOR

PPF:24814

### Wiring Diagram

GBS000TL

### EC-MIL/DL-01






REFER TO THE FOLLOWING.  
 (M88) - FUSE BLOCK -  
 JUNCTION BOX (J/B)

# MIL AND DATA LINK CONNECTOR

[VQ TYPE 1]

## EC-MIL/DL-02

— : DETECTABLE LINE FOR DTC  
 - - - : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

- (M91) - SUPER MULTIPLE JUNCTION (SMJ)
- (M88) - FUSE BLOCK - JUNCTION BOX (J/B)

# SERVICE DATA AND SPECIFICATIONS (SDS)

[VQ TYPE 1]

## SERVICE DATA AND SPECIFICATIONS (SDS)

PPF:00030

### Fuel Pressure

GBS000TM

Fuel pressure at idling kPa (bar, kg/cm <sup>2</sup> , psi)	Approximately 350 (3.5, 3.57, 51)
---	-----------------------------------

### Idle Speed and Ignition Timing

GBS000TN

Target idle speed	No load* [in P or N position (A/T), Neutral position (M/T)]	625 ± 50 rpm
Air conditioner: ON	In P or N position (A/T), Neutral position (M/T)	775 rpm or more
Ignition timing	In P or N position (A/T), Neutral position (M/T)	15 ± 5° BTDC

\*: Under the following conditions:

- Air conditioner switch: OFF
- Electric load: OFF (Lights, heater fan & rear window defogger)
- Steering wheel: Kept in straight-ahead position

### Calculated Load Value

GBS000TO

Condition	Calculated load value% (Using CONSULT-II or GST)
At idle	5 - 35
At 2,500 rpm	5 - 35

### Mass Air Flow Sensor

GBS000TP

Supply voltage	Battery voltage (11 - 14V)
Output voltage at idle	0.9 - 1.2V*
Mass air flow (Using CONSULT-II or GST)	2.0 - 6.0 g-m/sec at idle* 7.0 - 20.0 g-m/sec at 2,500 rpm*

\*: Engine is warmed up to normal operating temperature and running under no load.

### Intake Air Temperature Sensor

GBS000TQ

Temperature °C (°F)	Resistance kΩ
25 (77)	1.800 - 2.200

### Engine Coolant Temperature Sensor

GBS000TR

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

### Air Fuel Ratio (A/F) Sensor 1 Heater

GBS000TS

Resistance [at 25°C (77°F)]	2.3 - 4.3Ω
-----------------------------	------------

### Heated Oxygen sensor 2 Heater

GBS000TT

Resistance [at 25°C (77°F)]	9.9 - 13.3Ω
-----------------------------	-------------

### Crankshaft Position Sensor (POS)

GBS000TU

Refer to [EC-258, "Component Inspection"](#) .

### Camshaft Position Sensor (PHASE)

GBS000TV

Refer to [EC-267, "Component Inspection"](#) .

### Throttle Control Motor

GBS000TW

Resistance [at 25°C (77°F)]	Approximately 1 - 15Ω
-----------------------------	-----------------------

# SERVICE DATA AND SPECIFICATIONS (SDS)

[VQ TYPE 1]

## Fuel Injector

*GBS000TX*

Resistance [at 10 - 60°C (50 - 140°F)]

11.1 - 14.5Ω

## Fuel Pump

*GBS000TY*

Resistance [at 25°C (77°F)]

0.2 - 5.0Ω

# INDEX FOR DTC

[VQ TYPE 2]

## INDEX FOR DTC

PFP:00024

### DTC No. Index

GBS000TZ

**NOTE:**

If DTC U1000 or U1001 is displayed with other DTC, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-686, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#) .

DTC*1		Items (CONSULT-II screen terms)	Reference page
CONSULT-II	ECM*2		
U1000	1000*3	CAN COMM CIRCUIT	<a href="#">EC-686</a>
U1001	1001*3	CAN COMM CIRCUIT	<a href="#">EC-686</a>
<b>P0000</b>	<b>0000</b>	<b>NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.</b>	—
P0011	0011	INT/V TIM CONT-B1	<a href="#">EC-689</a>
P0021	0021	INT/V TIM CONT-B2	<a href="#">EC-689</a>
P0102	0102	MAF SEN/CIRCUIT	<a href="#">EC-694</a>
P0103	0103	MAF SEN/CIRCUIT	<a href="#">EC-694</a>
P0117	0117	ECT SEN/CIRC	<a href="#">EC-701</a>
P0118	0118	ECT SEN/CIRC	<a href="#">EC-701</a>
P0122	0122	TP SEN 2/CIRC	<a href="#">EC-706</a>
P0123	0123	TP SEN 2/CIRC	<a href="#">EC-706</a>
P0222	0222	TP SEN 1/CIRC	<a href="#">EC-713</a>
P0223	0223	TP SEN 1/CIRC	<a href="#">EC-713</a>
P0327	0327	KNOCK SEN/CIRC-B1	<a href="#">EC-720</a>
P0328	0328	KNOCK SEN/CIRC-B1	<a href="#">EC-720</a>
P0332	0332	KNOCK SEN/CIRC-B2	<a href="#">EC-720</a>
P0333	0333	KNOCK SEN/CIRC-B2	<a href="#">EC-720</a>
P0335	0335	CKP SEN/CIRCUIT	<a href="#">EC-725</a>
P0340	0340	CMP SEN/CIRC-B1	<a href="#">EC-732</a>
P0345	0345	CMP SEN/CIRC-B2	<a href="#">EC-732</a>
P0550	0550	PW ST P SEN/CIRC	<a href="#">EC-741</a>
P0605	0605	ECM	<a href="#">EC-746</a>
P1031	1031	A/F SEN1 HTR (B1)	<a href="#">EC-749</a>
P1032	1032	A/F SEN1 HTR (B1)	<a href="#">EC-749</a>
P1051	1051	A/F SEN1 HTR (B2)	<a href="#">EC-749</a>
P1052	1052	A/F SEN1 HTR (B2)	<a href="#">EC-749</a>
P1065	1065	ECM BACK UP/CIRCUIT	<a href="#">EC-757</a>
P1111	1111	INT/V TIM V/CIR-B1	<a href="#">EC-761</a>
P1121	1121	ETC ACTR	<a href="#">EC-769</a>
P1122	1122	ETC FUNCTION/CIRC	<a href="#">EC-772</a>
P1124	1124	ETC MOT PWR	<a href="#">EC-778</a>
P1126	1126	ETC MOT PWR	<a href="#">EC-778</a>
P1128	1128	ETC MOT	<a href="#">EC-784</a>
P1136	1136	INT/V TIM V/CIR-B2	<a href="#">EC-761</a>
P1217	1217	ENG OVER TEMP	<a href="#">EC-789</a>
P1225	1225	CTP LEARNING	<a href="#">EC-799</a>

# INDEX FOR DTC

**[VQ TYPE 2]**

DTC*1		Items (CONSULT-II screen terms)	Reference page
CONSULT-II	ECM*2		
P1226	1226	CTP LEARNING	<a href="#">EC-801</a>
P1229	1229	SENSOR POWER/CIRC	<a href="#">EC-803</a>
P1271	1271	A/F SENSOR1 (B1)	<a href="#">EC-810</a>
P1272	1272	A/F SENSOR1 (B1)	<a href="#">EC-819</a>
P1276	1276	A/F SENSOR1 (B1)	<a href="#">EC-828</a>
P1281	1281	A/F SENSOR1 (B2)	<a href="#">EC-810</a>
P1282	1282	A/F SENSOR1 (B2)	<a href="#">EC-819</a>
P1286	1286	A/F SENSOR1 (B2)	<a href="#">EC-828</a>
P1564	1564	ASCD SW	<a href="#">EC-837</a>
P1572	1572	ASCD BRAKE SW	<a href="#">EC-844</a>
P1610 - P1615	1610 - 1615	NATS MALFUNCTION	<a href="#">EC-600</a>
P1706	1706	P-N POS SW/CIRCUIT	<a href="#">EC-858</a>
P1715	1715	IN PLUY SPEED	<a href="#">EC-863</a>
P1805	1805	BRAKE SW/CIRCUIT	<a href="#">EC-864</a>
P2122	2122	APP SEN 1/CIRC	<a href="#">EC-870</a>
P2123	2123	APP SEN 1/CIRC	<a href="#">EC-870</a>
P2127	2127	APP SEN 2/CIRC	<a href="#">EC-876</a>
P2128	2128	APP SEN 2/CIRC	<a href="#">EC-876</a>
P2135	2135	TP SENSOR	<a href="#">EC-883</a>
P2138	2138	APP SENSOR	<a href="#">EC-891</a>

\*1: 1st trip DTC No. is the same as DTC No.

\*2: In Diagnostic Test Mode II (Self-diagnostic results), this number is controlled by NISSAN.

\*3: The troubleshooting for this DTC needs CONSULT-II.

## Alphabetical Index

**NOTE:**

If DTC U1000 or U1001 is displayed with other DTC, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-686, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#).

Items (CONSULT-II screen terms)	DTC*1		Reference page
	CONSULT-II	ECM*2	
A/F SENSOR1 (B1)	P1271	1271	<a href="#">EC-810</a>
A/F SENSOR1 (B1)	P1272	1272	<a href="#">EC-819</a>
A/F SENSOR1 (B1)	P1276	1276	<a href="#">EC-828</a>
A/F SENSOR1 (B2)	P1281	1281	<a href="#">EC-810</a>
A/F SENSOR1 (B2)	P1282	1282	<a href="#">EC-819</a>
A/F SENSOR1 (B2)	P1286	1286	<a href="#">EC-828</a>
A/F SEN1 HTR (B1)	P1031	1031	<a href="#">EC-749</a>
A/F SEN1 HTR (B1)	P1032	1032	<a href="#">EC-749</a>
A/F SEN1 HTR (B2)	P1051	1051	<a href="#">EC-749</a>
A/F SEN1 HTR (B2)	P1052	1052	<a href="#">EC-749</a>
APP SEN 1/CIRC	P2122	2122	<a href="#">EC-870</a>
APP SEN 1/CIRC	P2123	2123	<a href="#">EC-870</a>
APP SEN 2/CIRC	P2127	2127	<a href="#">EC-876</a>
APP SEN 2/CIRC	P2128	2128	<a href="#">EC-876</a>
APP SENSOR	P2138	2138	<a href="#">EC-891</a>
ASCD BRAKE SW	P1572	1572	<a href="#">EC-844</a>
ASCD SW	P1564	1564	<a href="#">EC-837</a>
BRAKE SW/CIRCUIT	P1805	1805	<a href="#">EC-864</a>
CAN COMM CIRCUIT	U1000	1000*3	<a href="#">EC-686</a>
CAN COMM CIRCUIT	U1001	1001*3	<a href="#">EC-686</a>
CKP SEN/CIRCUIT	P0335	0335	<a href="#">EC-725</a>
CMP SEN/CIRC-B1	P0340	0340	<a href="#">EC-732</a>
CMP SEN/CIRC-B2	P0345	0345	<a href="#">EC-732</a>
CTP LEARNING	P1225	1225	<a href="#">EC-799</a>
CTP LEARNING	P1226	1226	<a href="#">EC-801</a>
ECM	P0605	0605	<a href="#">EC-746</a>
ECM BACK UP/CIRCUIT	P1065	1065	<a href="#">EC-757</a>
ECT SEN/CIRC	P0117	0117	<a href="#">EC-701</a>
ECT SEN/CIRC	P0118	0118	<a href="#">EC-701</a>
ENG OVER TEMP	P1217	1217	<a href="#">EC-789</a>
ETC ACTR	P1121	1121	<a href="#">EC-769</a>
ETC FUNCTION/CIRC	P1122	1122	<a href="#">EC-772</a>
ETC MOT	P1128	1128	<a href="#">EC-784</a>
ETC MOT PWR	P1124	1124	<a href="#">EC-778</a>
ETC MOT PWR	P1126	1126	<a href="#">EC-778</a>
IN PULY SPEED	P1715	1715	<a href="#">EC-863</a>
INT/V TIM CONT-B1	P0011	0011	<a href="#">EC-689</a>
INT/V TIM CONT-B2	P0021	0021	<a href="#">EC-689</a>
INT/V TIM V/CIR-B1	P1111	1111	<a href="#">EC-761</a>

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# INDEX FOR DTC

[VQ TYPE 2]

Items (CONSULT-II screen terms)	DTC*1		Reference page
	CONSULT-II	ECM*2	
INT/V TIM V/CIR-B2	P1136	1136	<a href="#">EC-761</a>
KNOCK SEN/CIRC-B1	P0327	0327	<a href="#">EC-720</a>
KNOCK SEN/CIRC-B1	P0328	0328	<a href="#">EC-720</a>
KNOCK SEN/CIRC-B2	P0332	0332	<a href="#">EC-720</a>
KNOCK SEN/CIRC-B2	P0333	0333	<a href="#">EC-720</a>
MAF SEN/CIRCUIT	P0102	0102	<a href="#">EC-694</a>
MAF SEN/CIRCUIT	P0103	0103	<a href="#">EC-694</a>
NATS MALFUNCTION	P1610 - P1615	1610 - 1615	<a href="#">EC-600</a>
<b>NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.</b>	<b>P0000</b>	<b>0000</b>	—
P-N POS SW/CIRCUIT	P1706	1706	<a href="#">EC-858</a>
PW ST P SEN/CIRC	P0550	0550	<a href="#">EC-741</a>
SENSOR POWER/CIRC	P1229	1229	<a href="#">EC-803</a>
TP SEN 1/CIRC	P0222	0222	<a href="#">EC-713</a>
TP SEN 1/CIRC	P0223	0223	<a href="#">EC-713</a>
TP SEN 2/CIRC	P0122	0122	<a href="#">EC-706</a>
TP SEN 2/CIRC	P0123	0123	<a href="#">EC-706</a>
TP SENSOR	P2135	2135	<a href="#">EC-883</a>

\*1: 1st trip DTC No. is the same as DTC No.

\*2: In Diagnostic Test Mode II (Self-diagnostic results), this number is controlled by NISSAN.

\*3: The troubleshooting for this DTC needs CONSULT-II.



PRECAUTIONS

PF0:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

GBS000U1

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

On Board Diagnostic (OBD) System of Engine

GBS000U2

The ECM has an on board diagnostic system. It will light up the malfunction indicator lamp (MIL) to warn the driver of a malfunction causing emission deterioration.


**CAUTION:**

- Be sure to turn the ignition switch OFF and disconnect the negative battery cable before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MIL to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MIL to light up due to the open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Certain systems and components, especially those related to OBD, may use a new style slide-locking type harness connector. For description and how to disconnect, refer to [PG-65, "HARNESS CONNECTOR"](#) .
- Be sure to route and secure the harnesses properly after work. The interference of the harness with a bracket, etc. may cause the MIL to light up due to the short circuit.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the ECM before returning the vehicle to the customer.

Precaution

GBS000U3

- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.
- Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect negative battery cable. Failure to do so may damage the ECM because battery voltage is applied to ECM even if ignition switch is turned OFF.
- Before removing parts, turn ignition switch OFF and then disconnect negative battery cable.





SEF289H



# PRECAUTIONS

[VQ TYPE 2]

- Do not disassemble ECM.
- If a battery cable is disconnected, the memory will return to the ECM value.  
The ECM will now start to self-control at its initial value. Engine operation can vary slightly when the terminal is disconnected. However, this is not an indication of a malfunction. Do not replace parts because of a slight variation.
- If the battery is disconnected, the following emission-related diagnostic information will be lost within 24 hours.
  - Diagnostic trouble codes
  - 1st trip diagnostic trouble codes
  - Freeze frame data
  - 1st trip freeze frame data
- When connecting ECM harness connector, fasten it securely with levers as far as they will go as shown in the figure.




- When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break).  
Make sure that there are not any bends or breaks on ECM pin terminal, when connecting pin connectors.
- Securely connect ECM harness connectors.  
A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep engine control system harness at least 10 cm (4 in) away from adjacent harness, to prevent engine control system malfunctions due to receiving external noise, degraded operation of ICs, etc.
- Keep engine control system parts and harness dry.
- Before replacing ECM, perform "ECM Terminals and Reference Value" inspection and make sure ECM functions properly. Refer to [EC-642. "ECM Terminals and Reference Value"](#).
- Handle mass air flow sensor carefully to avoid damage.
- Do not disassemble mass air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Do not disassemble electric throttle control actuator.
- Even a slight leak in the air intake system can cause serious incidents.
- Do not shock or jar the camshaft position sensor (PHASE), crankshaft position sensor (POS).




# PRECAUTIONS

[VQ TYPE 2]


- After performing each TROUBLE DIAGNOSIS, perform DTC Confirmation Procedure or Overall Function Check. The DTC should not be displayed in the DTC Confirmation Procedure if the repair is completed. The Overall Function Check should be a good result if the repair is completed.



- When measuring ECM signals with a circuit tester, never allow the two tester probes to contact. Accidental contact of probes will cause a short circuit and damage the ECM power transistor.
- Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.




- B1 indicates the bank 1, B2 indicates the bank 2 as shown in the figure.




## PRECAUTIONS

[VQ TYPE 2]


- **Do not operate fuel pump when there is no fuel in lines.**
  - Fuel level sensor unit and fuel pump (1)
  - Fuel pressure regulator (2)
- **Tighten fuel hose clamps to the specified torque.**



- **Do not depress accelerator pedal when starting.**
- **Immediately after starting, do not rev up engine unnecessarily.**
- **Do not rev up engine just prior to shutdown.**



- **When installing C.B. ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on installation location.**
  - **Keep the antenna as far as possible from the electronic control units.**
  - **Keep the antenna feeder line more than 20 cm (8 in) away from the harness of electronic controls. Do not let them run parallel for a long distance.**
  - **Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller.**
  - **Be sure to ground the radio to vehicle body.**



PREPARATION

Special Service Tools

Tool number Tool name	Description
EG17650301 Radiator cap tester adapter	Adapting radiator cap tester to radiator cap and radiator filler neck <b>a: 28 (1.10) dia.</b> <b>b: 31.4 (1.236) dia.</b> <b>c: 41.3 (1.626) dia.</b> Unit: mm (in)
KV10117100 Heated oxygen sensor wrench	Loosening or tightening heated oxygen sensor with 22 mm (0.87 in) hexagon nut
KV10114400 Heated oxygen sensor wrench	Loosening or tightening air fuel ratio (A/F) sensor <b>a: 22 mm (0.87 in)</b>
KV109E0010 Break-out box	Measuring the ECM signals with a circuit tester
KV109E0080 Y-cable adapter	Measuring the ECM signals with a circuit tester
KV101118400 Fuel tube adapter	Measuring fuel pressure

EC

C

D

E

F

G

H

I

J






K

L

M

## Commercial Service Tools

GBS000U6

Tool name	Description
<p>Quick connector release</p> <div style="text-align: center;">  <p>PBIC0198E</p> </div>	<p>Remove fuel tube quick connectors in engine room</p>
<p>Fuel filler cap adapter</p> <div style="text-align: center;">  <p>S-NT653</p> </div>	<p>Checking fuel tank vacuum relief valve opening pressure</p>
<p>Socket wrench</p> <div style="text-align: center;">  <p>S-NT705</p> </div>	<p>Removing and installing engine coolant temperature sensor</p>
<p>Oxygen sensor thread cleaner</p> <div style="text-align: center;">  <p>AEM488</p> </div>	<p>Reconditioning the exhaust system threads before installing a new oxygen sensor. Use with anti-seize lubricant shown below.  <b>a: 18 mm diameter with pitch 1.5 mm for Zirconia Oxygen Sensor</b>  <b>b: 12 mm diameter with pitch 1.25 mm for Titania Oxygen Sensor</b></p>
<p>Anti-seize lubricant  i.e.: (Permatex™ 133AR or equivalent meeting MIL specification MIL-A-907)</p> <div style="text-align: center;">  <p>S-NT779</p> </div>	<p>Lubricating oxygen sensor thread cleaning tool when reconditioning exhaust system threads.</p>


## ENGINE CONTROL SYSTEM

PFP:23710

### System Diagram

GBS000U7

EC



\*: This sensor/actuator is not for controlling the engine system, nor for the on board diagnosis.

## Multipoint Fuel Injection (MFI) System INPUT/OUTPUT SIGNAL CHART

GBS000U8

Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS)	Engine speed*3	Fuel injection & mixture ratio control	Fuel injector
Camshaft position sensor (PHASE)	Piston position		
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Air fuel ratio (A/F) sensor 1	Density of oxygen in exhaust gas		
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Accelerator pedal position		
Park/neutral position (PNP) switch	Gear position		
Knock sensor	Engine knocking condition		
Battery	Battery voltage*3		
Power steering pressure sensor	Power steering operation		
Heated oxygen sensor 2*1	Density of oxygen in exhaust gas		
Air conditioner switch	Air conditioner operation*2		
Wheel sensor	Vehicle speed*2		

\*1: This sensor is not used to control the engine system under normal conditions.

\*2: This signal is sent to the ECM through CAN communication line.

\*3: ECM determines the start signal status by the signals of engine speed and battery voltage.

### SYSTEM DESCRIPTION

The amount of fuel injected from the fuel injector is determined by the ECM. The ECM controls the length of time the valve remains open (injection pulse duration). The amount of fuel injected is a program value in the ECM memory. The program value is preset by engine operating conditions. These conditions are determined by input signals (for engine speed and intake air) from both the crankshaft position sensor and the mass air flow sensor.

### VARIOUS FUEL INJECTION INCREASE/DECREASE COMPENSATION

In addition, the amount of fuel injected is compensated to improve engine performance under various operating conditions as listed below.

<Fuel increase>


- During warm-up
- When starting the engine
- During acceleration
- Hot-engine operation
- When selector lever is changed from N to D (A/T models)
- High-load, high-speed operation

<Fuel decrease>

- During deceleration
- During high engine speed operation



## MIXTURE RATIO FEEDBACK CONTROL (CLOSED LOOP CONTROL)



The mixture ratio feedback system provides the best air-fuel mixture ratio for driveability and emission control. The three way catalyst (manifold) can then better reduce CO, HC and NOx emissions. This system uses air fuel ratio (A/F) sensor 1 in the exhaust manifold to monitor whether the engine operation is rich or lean. The ECM adjusts the injection pulse width according to the sensor voltage signal. For more information about air fuel ratio (A/F) sensor 1, refer to [EC-810](#). This maintains the mixture ratio within the range of stoichiometric (ideal air-fuel mixture).

This stage is referred to as the closed loop control condition.

Heated oxygen sensor 2 is located downstream of the three way catalyst (manifold). Even if the switching characteristics of air fuel ratio (A/F) sensor 1 shift, the air-fuel ratio is controlled to stoichiometric by the signal from heated oxygen sensor 2.

### Open Loop Control

The open loop system condition refers to when the ECM detects any of the following conditions. Feedback control stops in order to maintain stabilized fuel combustion.

- Deceleration and acceleration
- High-load, high-speed operation
- Malfunction of air fuel ratio (A/F) sensor 1 or its circuit
- Insufficient activation of air fuel ratio (A/F) sensor 1 at low engine coolant temperature
- High engine coolant temperature
- During warm-up
- After shifting from N to D (A/T models)
- When starting the engine

### MIXTURE RATIO SELF-LEARNING CONTROL

The mixture ratio feedback control system monitors the mixture ratio signal transmitted from air fuel ratio (A/F) sensor 1. This feedback signal is then sent to the ECM. The ECM controls the basic mixture ratio as close to the theoretical mixture ratio as possible. However, the basic mixture ratio is not necessarily controlled as originally designed. Both manufacturing differences (i.e., mass air flow sensor hot wire) and characteristic changes during operation (i.e., fuel injector clogging) directly affect mixture ratio.


Accordingly, the difference between the basic and theoretical mixture ratios is monitored in this system. This is then computed in terms of "injection pulse duration" to automatically compensate for the difference between the two ratios.

"Fuel trim" refers to the feedback compensation value compared against the basic injection duration. Fuel trim includes short term fuel trim and long term fuel trim.

"Short term fuel trim" is the short-term fuel compensation used to maintain the mixture ratio at its theoretical value. The signal from air fuel ratio (A/F) sensor 1 indicates whether the mixture ratio is RICH or LEAN compared to the theoretical value. The signal then triggers a reduction in fuel volume if the mixture ratio is rich, and an increase in fuel volume if it is lean.

"Long term fuel trim" is overall fuel compensation carried out long-term to compensate for continual deviation of the short term fuel trim from the central value. Such deviation will occur due to individual engine differences, wear over time and changes in the usage environment.

## FUEL INJECTION TIMING



Two types of systems are used.

### Sequential Multiport Fuel Injection System

Fuel is injected into each cylinder during each engine cycle according to the firing order. This system is used when the engine is running.

### Simultaneous Multiport Fuel Injection System

Fuel is injected simultaneously into all six cylinders twice each engine cycle. In other words, pulse signals of the same width are simultaneously transmitted from the ECM.

The six fuel injectors will then receive the signals two times for each engine cycle.

This system is used when the engine is being started and/or if the fail-safe system (CPU) is operating.

### FUEL SHUT-OFF

Fuel to each cylinder is cut off during deceleration, operation of the engine at excessively high speeds or operation of the vehicle at excessively high speeds.

### Electronic Ignition (EI) System

GBS000U9

#### INPUT/OUTPUT SIGNAL CHART

Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS)	Engine speed*2 Piston position	Ignition timing control	Power transistor
Camshaft position sensor (PHASE)			
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Accelerator pedal position		
Knock sensor	Engine knocking		
Park/neutral position (PNP) switch	Gear position		
Battery	Battery voltage*2		
Wheel sensor	Vehicle speed*1		

\*1: This signal is sent to the ECM through CAN communication line.

\*2: ECM determines the start signal status by the signals of engine speed and battery voltage.

### SYSTEM DESCRIPTION

Firing order: 1-2-3-4-5-6

The ignition timing is controlled by the ECM to maintain the best air-fuel ratio for every running condition of the engine. The ignition timing data is stored in the ECM.

The ECM receives information such as the injection pulse width and camshaft position sensor signal. Computing this information, ignition signals are transmitted to the power transistor.

During the following conditions, the ignition timing is revised by the ECM according to the other data stored in the ECM.

- At starting
- During warm-up
- At idle
- At low battery voltage

- During acceleration

The knock sensor retard system is designed only for emergencies. The basic ignition timing is programmed within the anti-knocking zone, if recommended fuel is used under dry conditions. The retard system does not operate under normal driving conditions. If engine knocking occurs, the knock sensor monitors the condition. The signal is transmitted to the ECM. The ECM retards the ignition timing to eliminate the knocking condition.

## Fuel Cut Control (at No Load and High Engine Speed) INPUT/OUTPUT SIGNAL CHART

GBS000UA

Sensor	Input Signal to ECM	ECM function	Actuator
Park/neutral position (PNP) switch	Neutral position	Fuel cut control	Fuel injector
Accelerator pedal position sensor	Accelerator pedal position		
Engine coolant temperature sensor	Engine coolant temperature		
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed		
Wheel sensor	Vehicle speed*		

\*: This signal is sent to the ECM through CAN communication line.

### SYSTEM DESCRIPTION

If the engine speed is above 1,800 rpm under no load (for example, the shift position is neutral and engine speed is over 1,800 rpm) fuel will be cut off after some time. The exact time when the fuel is cut off varies based on engine speed.

Fuel cut will be operated until the engine speed reaches 1,500 rpm, then fuel cut will be cancelled.

#### NOTE:

This function is different from deceleration control listed under [EC-586, "Multiport Fuel Injection \(MFI\) System"](#)

## AIR CONDITIONING CUT CONTROL

PFP:23710

### Input/Output Signal Chart

GBS000UB

Sensor	Input Signal to ECM	ECM function	Actuator
Air conditioner switch	Air conditioner ON signal* <sup>1</sup>	Air conditioner cut control	Air conditioner relay
Accelerator pedal position sensor	Accelerator pedal position		
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed* <sup>2</sup>		
Engine coolant temperature sensor	Engine coolant temperature		
Battery	Battery voltage* <sup>2</sup>		
Refrigerant pressure sensor	Refrigerant pressure		
Power steering pressure sensor	Power steering operation		
Wheel sensor	Vehicle speed* <sup>1</sup>		

\*1: This signal is sent to the ECM through CAN communication line.

\*2: ECM determines the start signal status by the signals of engine speed and battery voltage.

### System Description

GBS000UC

This system improves engine operation when the air conditioner is used. Under the following conditions, the air conditioner is turned OFF.

- When the accelerator pedal is fully depressed.
- When cranking the engine.
- At high engine speeds.
- When the engine coolant temperature becomes excessively high.
- When operating power steering during low engine speed or low vehicle speed.
- When engine speed is excessively low.
- When refrigerant pressure is excessively low or high.

**AUTOMATIC SPEED CONTROL DEVICE (ASCD)**

PFP:18930

**System Description  
INPUT/OUTPUT SIGNAL CHART**

GBS000UD

Sensor	Input signal to ECM	ECM function	Actuator
ASCD brake switch	Brake pedal operation	ASCD vehicle speed control	Electric throttle control actuator
Stop lamp switch	Brake pedal operation		
ASCD steering switch	ASCD steering switch operation		
Park/Neutral position (PNP) switch	Gear position		
Combination meter	Vehicle speed*		
TCM	Powertrain revolution*		

\*: This signal is sent to the ECM through CAN communication line.

**BASIC ASCD SYSTEM**

Refer to Owner's Manual for ASCD operating instructions.

Automatic Speed Control Device (ASCD) allows a driver to keep vehicle at predetermined constant speed without depressing accelerator pedal. Driver can set vehicle speed in advance between approximately 40 km/h (25 MPH) and 175 km/h (109 MPH).

ECM controls throttle angle of electric throttle control actuator to regulate engine speed.

Operation status of ASCD is indicated by CRUISE indicator and SET indicator in combination meter. If any malfunction occurs in ASCD system, it automatically deactivates control.

**NOTE:**

Always drive vehicle in safe manner according to traffic conditions and obey all traffic laws.

**SET OPERATION**

Press MAIN switch. (The CRUISE indicator in combination meter illuminates.)

When vehicle speed reaches a desired speed between approximately 40 km/h (25 MPH) and 175 km/h (109 MPH), press SET/COAST switch. (Then SET indicator in combination meter illuminates.)

**ACCELERATE OPERATION**

If the RESUME/ACCELERATE switch is pressed during cruise control driving, increase the vehicle speed until the switch is released or vehicle speed reaches maximum speed controlled by the system.

And then ASCD will keep the new set speed.

**CANCEL OPERATION**

When any of following conditions exist, cruise operation will be canceled.

- CANCEL switch is pressed
- More than 2 switches at ASCD steering switch are pressed at the same time (Set speed will be cleared)
- Brake pedal is depressed
- Clutch pedal is depressed or gear position is changed to the neutral position (M/T models)
- Selector lever is changed to N, P, R position (A/T models)
- Vehicle speed decreased to 13 km/h (8 MPH) lower than the set speed

When the ECM detects any of the following conditions, the ECM will cancel the cruise operation and inform the driver by blinking indicator lamp.

- Engine coolant temperature is slightly higher than the normal operating temperature, CRUISE lamp may blink slowly.  
When the engine coolant temperature decreases to the normal operating temperature, CRUISE lamp will stop blinking and the cruise operation will be able to work by depressing SET/COAST switch or RESUME/ACCELERATE switch.
- Malfunction for some self-diagnoses regarding ASCD control: SET lamp will blink quickly.

If MAIN switch is turned to OFF during ASCD is activated, all of ASCD operations will be canceled and vehicle speed memory will be erased.

---

## COAST OPERATION

When the SET/COAST switch is pressed during cruise control driving, decrease vehicle set speed until the switch is released. And then ASCD will keep the new set speed.

## RESUME OPERATION

When the RESUME/ACCELERATE switch is pressed after cancel operation other than depressing MAIN switch is performed, vehicle speed will return to last set speed. To resume vehicle set speed, vehicle condition must meet following conditions.

- Brake pedal is released
- Clutch pedal is released (M/T models)
- Selector lever is in other than P and N positions (A/T models)
- Vehicle speed is greater than 40 km/h (25 MPH) and less than 175 km/h (109 MPH)

## Component Description

### ASCD STEERING SWITCH

Refer to [EC-837](#) .

### ASCD BRAKE SWITCH

Refer to [EC-844](#) and [EC-899](#) .

### STOP LAMP SWITCH

Refer to [EC-844](#) , [EC-864](#) and [EC-899](#) .

### ELECTRIC THROTTLE CONTROL ACTUATOR

Refer to [EC-769](#) , [EC-772](#) , [EC-778](#) and [EC-784](#) .

### ASCD INDICATOR

Refer to [EC-912](#) .

GBS000UE

## CAN COMMUNICATION

PFP:23710

### System Description

GBS000UF

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Refer to [LAN-21, "CAN COMMUNICATION"](#) , about CAN communication for detail.

A

EC

C

D

E

F

G

H

I

J

K

L


M

## EVAPORATIVE EMISSION SYSTEM

PFP:14950

### Description SYSTEM DESCRIPTION

GBS000UG



The evaporative emission system is used to reduce hydrocarbons emitted into the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the EVAP canister. The fuel vapor in the sealed fuel tank is led into the EVAP canister which contains activated carbon and the vapor is stored there when the engine is not operating or when refueling to the fuel tank. The vapor in the EVAP canister is purged by the air through the purge line to the intake manifold when the engine is operating. EVAP canister purge volume control solenoid valve is controlled by ECM. When the engine operates, the flow rate of vapor controlled by EVAP canister purge volume control solenoid valve is proportionally regulated as the air flow increases. EVAP canister purge volume control solenoid valve also shuts off the vapor purge line during decelerating and idling.



## EVAPORATIVE EMISSION LINE DRAWING

A

EC

C

D

E

F

G

H


I

J

K

L


M




**NOTE:** Do not use soapy water or any type of solvent while installing vacuum hose or purge hoses.

# EVAPORATIVE EMISSION SYSTEM

[VQ TYPE 2]



View from under the vehicle




BBIA0594E

### Component Inspection EVAP CANISTER


Check EVAP canister as follows:

1. Block port **B** .
2. Blow air into port **A** and check that it flows freely out of port **C** .
3. Release blocked port **B** .
4. Apply vacuum pressure to port **B** and check that vacuum pressure exists at the ports **A** and **C** .
5. Block port **A** and **B** .
6. Apply pressure to port **C** and check that there is no leakage.



### FUEL TANK VACUUM RELIEF VALVE (BUILT INTO FUEL FULLER CAP)

1. Wipe clean valve housing.




2. Check valve opening pressure and vacuum.

**Pressure:** 15.3 - 20.0 kPa (0.153 - 0.200 bar, 0.156 - 0.204 kg/cm<sup>2</sup>, 2.22 - 2.90 psi)

**Vacuum:** -6.0 to -3.3 kPa (-0.060 to -0.033 bar, -0.061 to -0.034 kg/cm<sup>2</sup>, -0.87 to -0.48 psi)

3. If out of specification, replace fuel filler cap as an assembly.



### EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Refer to [EC-923](#) .

### EVAP CANISTER VENT CONTROL VALVE


Refer to [EC-928](#) .

## POSITIVE CRANKCASE VENTILATION

PFP:11810

### Description SYSTEM DESCRIPTION


GBS000UJ



This system returns blow-by gas to the intake manifold.

The positive crankcase ventilation (PCV) valve is provided to conduct crankcase blow-by gas to the intake manifold. During partial throttle operation of the engine, the intake manifold sucks the blow-by gas through the PCV valve. Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air. The ventilating air is then drawn from the air inlet tubes into the crankcase. In this process the air passes through the hose connecting air inlet tubes to rocker cover. Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the valve. The flow goes through the hose connection in the reverse direction.


On vehicles with an excessively high blow-by, the valve does not meet the requirement. This is because some of the flow will go through the hose connection to the air inlet tubes under all conditions.



GBS000UJ


### Component Inspection PCV (POSITIVE CRANKCASE VENTILATION) VALVE

With engine running at idle, remove PCV valve from rocker cover. A properly working valve makes a hissing noise as air passes through it. A strong vacuum should be felt immediately when a finger is placed over valve inlet.



### PCV VALVE VENTILATION HOSE

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.



A

EC

C

D

E

F

G

H

I

J

K

L

M

## NATS (NISSAN ANTI-THEFT SYSTEM)

PFP:25386

### Description

GBS000UK

- If the security indicator lights up with the ignition switch in the ON position or “NATS MALFUNCTION” is displayed on “SELF-DIAG RESULTS” screen, perform self-diagnostic results mode with CONSULT-II using NATS program card. Refer to [BL-81, "NATS\(Nissan Anti-Theft System\)"](#) .
- Confirm no self-diagnostic results of NATS is displayed before touching “ERASE” in “SELF-DIAG RESULTS” mode with CONSULT-II.
- When replacing ECM, initialization of NATS system and registration of all NATS ignition key IDs must be carried out with CONSULT-II using NATS program card.  
Therefore, be sure to receive all keys from vehicle owner.  
Regarding the procedures of NATS initialization and all NATS ignition key ID registration, refer to CONSULT-II Operation Manual, NATS.

SELF DIAG RESULTS	
DTC RESULTS	TIME
NATS MALFUNCTION [P1610]	0

SEF543X

## ON BOARD DIAGNOSTIC (OBD) SYSTEM

PFP:00028

### Introduction

GBS000UL

The ECM has an on board diagnostic system, which detects malfunctions related to engine sensors or actuators. The ECM also records various emission-related diagnostic information including:

#### Emission-related diagnostic information

Diagnostic Trouble Code (DTC)
Freeze Frame data
1st Trip Diagnostic Trouble Code (1st Trip DTC)
1st Trip Freeze Frame data

The above information can be checked using procedures listed in the table below.

x: Applicable —: Not applicable

	DTC	1st trip DTC	Freeze Frame data	1st trip Freeze Frame data
CONSULT-II	x	x	x	x
ECM	x	x*	—	—

\*: When DTC and 1st trip DTC simultaneously appear on the display, they cannot be clearly distinguished from each other.

The malfunction indicator lamp (MIL) on the instrument panel lights up when the same malfunction is detected in two consecutive trips (Two trip detection logic), or when the ECM enters fail-safe mode. (Refer to [EC-627, "Fail-Safe Chart"](#) .)

### Two Trip Detection Logic

GBS000UM

When a malfunction is detected for the 1st time, 1st trip DTC and 1st trip Freeze Frame data are stored in the ECM memory. The MIL will not light up at this stage. <1st trip>

If the same malfunction is detected again during the next drive, the DTC and Freeze Frame data are stored in the ECM memory, and the MIL lights up. The MIL lights up at the same time when the DTC is stored. <2nd trip> The "trip" in the "Two Trip Detection Logic" means a driving mode in which self-diagnosis is performed during vehicle operation. When the ECM enters fail-safe mode (Refer to [EC-627, "Fail-Safe Chart"](#) ), the DTC is stored in the ECM memory even in the 1st trip.

When there is an open circuit on MIL circuit, the ECM cannot warn the driver by lighting up MIL when there is malfunction on engine control system.

Therefore, when electrical controlled throttle and part of ECM related diagnoses are continuously detected as NG for 5 trips, ECM warns the driver that engine control system malfunctions and MIL circuit is open by means of operating fail-safe function.

The fail-safe function also operates when above diagnoses except MIL circuit are detected and demands the driver to repair the malfunction.

Engine operating condition in fail-safe mode	Engine speed will not rise more than 2,500 rpm due to the fuel cut
--	--

### Emission-Related Diagnostic Information

GBS000UN

#### EMISSION-RELATED DIAGNOSTIC INFORMATION ITEMS

x: Applicable —: Not applicable

Items (CONSULT-II screen terms)	DTC*1		Trip	MIL	Reference page
	CONSULT-II	ECM*2			
CAN COMM CIRCUIT	U1000	1000*3	2	—	<a href="#">EC-686</a>
CAN COMM CIRCUIT	U1001	1001*3	2	—	<a href="#">EC-686</a>
<b>NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.</b>	<b>P0000</b>	<b>0000</b>	—	—	—
INT/V TIM CONT-B1	P0011	0011	2	—	<a href="#">EC-689</a>
INT/V TIM CONT-B2	P0021	0021	2	—	<a href="#">EC-689</a>
MAF SEN/CIRCUIT	P0102	0102	1	x	<a href="#">EC-694</a>
MAF SEN/CIRCUIT	P0103	0103	1	x	<a href="#">EC-694</a>

# ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VQ TYPE 2]

Items (CONSULT-II screen terms)	DTC*1		Trip	MIL	Reference page
	CONSULT-II	ECM*2			
ECT SEN/CIRC	P0117	0117	2	×	<a href="#">EC-701</a>
ECT SEN/CIRC	P0118	0118	2	×	<a href="#">EC-701</a>
TP SEN 2/CIRC	P0122	0122	1	×	<a href="#">EC-706</a>
TP SEN 2/CIRC	P0123	0123	1	×	<a href="#">EC-706</a>
TP SEN 1/CIRC	P0222	0222	1	×	<a href="#">EC-713</a>
TP SEN 1/CIRC	P0223	0223	1	×	<a href="#">EC-713</a>
KNOCK SEN/CIRC-B1	P0327	0327	2	—	<a href="#">EC-720</a>
KNOCK SEN/CIRC-B1	P0328	0328	2	—	<a href="#">EC-720</a>
KNOCK SEN/CIRC-B2	P0332	0332	2	—	<a href="#">EC-720</a>
KNOCK SEN/CIRC-B2	P0333	0333	2	—	<a href="#">EC-720</a>
CKP SEN/CIRCUIT	P0335	0335	2	×	<a href="#">EC-725</a>
CMP SEN/CIRC-B1	P0340	0340	2	×	<a href="#">EC-732</a>
CMP SEN/CIRC-B2	P0345	0345	2	×	<a href="#">EC-732</a>
PW ST P SEN/CIRC	P0550	0550	2	—	<a href="#">EC-741</a>
ECM	P0605	0605	1 or 2	× or —	<a href="#">EC-746</a>
A/F SEN1 HTR (B1)	P1031	1031	2	×	<a href="#">EC-749</a>
A/F SEN1 HTR (B1)	P1032	1032	2	×	<a href="#">EC-749</a>
A/F SEN1 HTR (B2)	P1051	1051	2	×	<a href="#">EC-749</a>
A/F SEN1 HTR (B2)	P1052	1052	2	×	<a href="#">EC-749</a>
ECM BACK UP/CIRC	P1065	1065	2	×	<a href="#">EC-757</a>
INT/V TIM V/CIR-B1	P1111	1111	2	×	<a href="#">EC-761</a>
ETC ACTR	P1121	1121	1	×	<a href="#">EC-769</a>
ETC FUNCTION/CIRC	P1122	1122	1	×	<a href="#">EC-772</a>
ETC MOT PWR	P1124	1124	1	×	<a href="#">EC-778</a>
ETC MOT PWR	P1126	1126	1	×	<a href="#">EC-778</a>
ETC MOT	P1128	1128	1	×	<a href="#">EC-784</a>
INT/V TIM V/CIR-B2	P1136	1136	2	×	<a href="#">EC-761</a>
ENG OVER TEMP	P1217	1217	1	×	<a href="#">EC-789</a>
CTP LEARNING	P1225	1225	2	—	<a href="#">EC-799</a>
CTP LEARNING	P1226	1226	2	—	<a href="#">EC-801</a>
SENSOR POWER/CIRC	P1229	1229	1	×	<a href="#">EC-803</a>
A/F SENSOR1 (B1)	P1271	1271	2	×	<a href="#">EC-810</a>
A/F SENSOR1 (B1)	P1272	1272	2	×	<a href="#">EC-819</a>
A/F SENSOR1 (B1)	P1276	1276	2	×	<a href="#">EC-828</a>
A/F SENSOR1 (B2)	P1281	1281	2	×	<a href="#">EC-810</a>
A/F SENSOR1 (B2)	P1282	1282	2	×	<a href="#">EC-819</a>
A/F SENSOR1 (B2)	P1286	1286	2	×	<a href="#">EC-828</a>
ASCD SW	P1564	1564	1	—	<a href="#">EC-837</a>
ASCD BRAKE SW	P1572	1572	1	—	<a href="#">EC-844</a>
NATS MALFUNCTION	P1610 - P1615	1610 - 1615	2	—	<a href="#">EC-600</a>
P-N POS SW/CIRCUIT	P1706	1706	2	×	<a href="#">EC-858</a>
IN PULY SPEED	P1715	1715	2	—	<a href="#">EC-863</a>
BRAKE SW/CIRCUIT	P1805	1805	1	×	<a href="#">EC-864</a>



Items (CONSULT-II screen terms)	DTC*1		Trip	MIL	Reference page
	CONSULT-II	ECM*2			
APP SEN 1/CIRC	P2122	2122	1	×	<a href="#">EC-870</a>
APP SEN 1/CIRC	P2123	2123	1	×	<a href="#">EC-870</a>
APP SEN 2/CIRC	P2127	2127	1	×	<a href="#">EC-876</a>
APP SEN 2/CIRC	P2128	2128	1	×	<a href="#">EC-876</a>
TP SENSOR	P2135	2135	1	×	<a href="#">EC-883</a>
APP SENSOR	P2138	2138	1	×	<a href="#">EC-891</a>

\*1: 1st trip DTC No. is the same as DTC No.

\*2: In Diagnostic Test Mode II (Self-diagnostic results), this number is controlled by NISSAN.

\*3: The troubleshooting for this DTC need CONSULT-II.

## DTC AND 1ST TRIP DTC

The 1st trip DTC (whose number is the same as the DTC number) is displayed for the latest self-diagnostic result obtained. If the ECM memory was cleared previously, and the 1st trip DTC did not reoccur, the 1st trip DTC will not be displayed.

If a malfunction is detected during the 1st trip, the 1st trip DTC is stored in the ECM memory. The MIL will not light up (two trip detection logic). If the same malfunction is not detected in the 2nd trip (meeting the required driving pattern), the 1st trip DTC is cleared from the ECM memory. If the same malfunction is detected in the 2nd trip, both the 1st trip DTC and DTC are stored in the ECM memory and the MIL lights up. In other words, the DTC is stored in the ECM memory and the MIL lights up when the same malfunction occurs in two consecutive trips. If a 1st trip DTC is stored and a non-diagnostic operation is performed between the 1st and 2nd trips, only the 1st trip DTC will continue to be stored. For fail-safe items, the DTC is stored in the ECM memory even in the 1st trip.

Procedures for clearing the DTC and the 1st trip DTC from the ECM memory are described in [EC-604, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).

When a 1st trip DTC is detected, check, print out or write down and erase (1st trip) DTC and Freeze Frame data as specified in Work Flow procedure Step 2, refer to [EC-621, "WORK FLOW"](#). Then perform DTC Confirmation Procedure or Overall Function Check to try to duplicate the malfunction. If the malfunction is duplicated, the item requires repair.

## How to Read DTC and 1st Trip DTC

DTC and 1st trip DTC can be read by the following methods.

### With CONSULT-II

CONSULT-II Examples: P0117, P0340, P1065, etc.

(CONSULT-II also displays the malfunctioning component or system.)

### No Tools

The number of blinks of the MIL in the Diagnostic Test Mode II (Self-Diagnostic Results) indicates the DTC. Example: 0117, 0340, 1065, etc.

These DTCs are controlled by NISSAN.

- **1st trip DTC No. is the same as DTC No.**
- **Output of a DTC indicates a malfunction. However the Diagnostic Test Mode II do not indicate whether the malfunction is still occurring or has occurred in the past and has returned to normal. CONSULT-II can identify malfunction status as shown below. Therefore, using CONSULT-II (if available) is recommended.**

A sample of CONSULT-II display for DTC and 1st trip DTC is shown below. DTC or 1st trip DTC of a malfunction is displayed in "SELF-DIAGNOSTIC RESULTS" mode of CONSULT-II. Time data indicates how many times the vehicle was driven after the last detection of a DTC.

If the DTC is being detected currently, the time data will be [0].

If a 1st trip DTC is stored in the ECM, the time data will be [1t].

DTC display	SELF DIAG RESULTS		1st trip DTC display	SELF DIAG RESULTS	
	DTC RESULTS	TIME		DTC RESULTS	TIME
	CKP SEN/CIRCUIT [P0335]	0		CKP SEN/CIRCUIT [P0335]	1t

PBIB0911E

## FREEZE FRAME DATA AND 1ST TRIP FREEZE FRAME DATA

The ECM records the driving conditions such as fuel system status, calculated load value, engine coolant temperature, short term fuel trim, long term fuel trim, engine speed, vehicle speed, base fuel schedule and intake air temperature at the moment a malfunction is detected.

Data which are stored in the ECM memory, along with the 1st trip DTC, are called 1st trip freeze frame data. The data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT-II. For details, see [EC-654, "Freeze Frame Data and 1st Trip Freeze Frame Data"](#).

Only one set of freeze frame data (either 1st trip freeze frame data or freeze frame data) can be stored in the ECM. 1st trip freeze frame data is stored in the ECM memory along with the 1st trip DTC. There is no priority for 1st trip freeze frame data and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data (2nd trip detection/MIL on) is stored in the ECM memory, 1st trip freeze frame data is no longer stored. Remember, only one set of freeze frame data can be stored in the ECM.

Both 1st trip freeze frame data and freeze frame data (along with the DTCs) are cleared when the ECM memory is erased. Procedures for clearing the ECM memory are described in [EC-604, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).

## HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION

### How to Erase DTC

#### WITH CONSULT-II

The emission related diagnostic information in the ECM can be erased by selecting "ERASE" in the "SELF-DIAG RESULTS" mode with CONSULT-II.

1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 10 seconds and then turn it ON (engine stopped) again.
2. Turn CONSULT-II ON and touch "ENGINE".
3. Touch "SELF-DIAG RESULTS".
4. Touch "ERASE". (The DTC in the ECM will be erased.)

**How to erase DTC (With CONSULT-II)**

1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 10 seconds and then turn it ON again.

SELECT SYSTEM
ENGINE

2. Turn CONSULT-II "ON" and touch "ENGINE".

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
DATA MONITOR (SPEC)
CAN DIAG SUPPORT MNTR
ACTIVE TEST

3. Touch "SELF-DIAG RESULTS".

SELF DIAG RESULTS	
DTC RESULTS	TIME
MAF SEN/CIRCUIT [P0102]	0

4. Touch "ERASE". (The DTC in the ECM will be erased.)

PBIB2392E

**⊗ WITHOUT CONSULT-II**

1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once.
  2. Wait at least 10 seconds and then turn it ON (engine stopped) again.
  3. Change the diagnostic test mode from Mode II to Mode I by depressing the accelerator pedal.  
Refer to [EC-606, "HOW TO SWITCH DIAGNOSTIC TEST MODE"](#) .
- **If the battery is disconnected, the emission-related diagnostic information will be lost within 24 hours.**
  - **The following data are cleared when the ECM memory is erased.**
    - Diagnostic trouble codes
    - 1st trip diagnostic trouble codes
    - Freeze frame data
    - 1st trip freeze frame data


Actual work procedures are explained using a DTC as an example. Be careful so that not only the DTC, but all of the data listed above, are cleared from the ECM memory during work procedures.

## Malfunction Indicator Lamp (MIL) DESCRIPTION

GBS000UO






The MIL is located on the instrument panel.

1. The MIL will light up when the ignition switch is turned ON without the engine running. This is a bulb check.  
If the MIL does not light up, refer to [DI-32, "WARNING LAMPS"](#) , or see [EC-993](#) .
2. When the engine is started, the MIL should go off.  
If the MIL remains on, the on board diagnostic system has detected an engine system malfunction.



## ON BOARD DIAGNOSTIC SYSTEM FUNCTION

The on board diagnostic system has the following three functions.

Diagnostic Test Mode	KEY and ENG. Status	Function	Explanation of Function
Mode I	Ignition switch in ON position  Engine stopped 	BULB CHECK	This function checks the MIL bulb for damage (blown, open circuit, etc.). If the MIL does not come on, check MIL circuit.
	Engine running 	MALFUNCTION WARNING	This is a usual driving condition. When a malfunction is detected twice in two consecutive driving cycles (two trip detection logic), the MIL will light up to inform the driver that a malfunction has been detected. One trip detection diagnoses will light up the MIL in the 1st trip.
Mode II	Ignition switch in ON position  Engine stopped 	SELF-DIAGNOSTIC RESULTS	This function allows DTCs and 1st trip DTCs to be read.

When there is an open circuit on MIL circuit, the ECM cannot warn the driver by lighting up MIL when there is malfunction on engine control system.  
 Therefore, when electrical controlled throttle and part of ECM related diagnoses are continuously detected as NG for 5 trips, ECM warns the driver that engine control system malfunctions and MIL circuit is open by means of operating fail-safe function.  
 The fail-safe function also operates when above diagnoses except MIL circuit are detected and demands the driver to repair the malfunction.

Engine operating condition in fail-safe mode	Engine speed will not rise more than 2,500 rpm due to the fuel cut
--	--


## HOW TO SWITCH DIAGNOSTIC TEST MODE

### NOTE:

- It is better to count the time accurately with a clock.
- It is impossible to switch the diagnostic mode when an accelerator pedal position sensor circuit has a malfunction.
- Always ECM returns to Diagnostic Test Mode I after ignition switch is turned OFF.

### How to Set Diagnostic Test Mode II (Self-diagnostic Results)

1. Confirm that accelerator pedal is fully released, turn ignition switch ON and wait 3 seconds.
2. Repeat the following procedure quickly five times within 5 seconds.
  - a. Fully depress the accelerator pedal.
  - b. Fully release the accelerator pedal.
3. Wait 7 seconds, fully depress the accelerator pedal and keep it for approx. 10 seconds until the MIL starts blinking.
4. Fully release the accelerator pedal.  
 ECM has entered to Diagnostic Test Mode II (Self-diagnostic results).



### How to Erase Diagnostic Test Mode II (Self-diagnostic Results)

1. Set ECM in Diagnostic Test Mode II (Self-diagnostic results). Refer to [EC-606, "How to Set Diagnostic Test Mode II \(Self-diagnostic Results\)"](#).
2. Fully depress the accelerator pedal and keep it for more than 10 seconds.  
 The emission-related diagnostic information has been erased from the backup memory in the ECM.
3. Fully release the accelerator pedal, and confirm the DTC 0000 is displayed.

### DIAGNOSTIC TEST MODE I — BULB CHECK

In this mode, the MIL on the instrument panel should stay ON. If it remains OFF, check the bulb. Refer to [DI-32, "WARNING LAMPS"](#) or see [EC-993](#).

### DIAGNOSTIC TEST MODE I — MALFUNCTION WARNING


MIL	Condition
ON	When the malfunction is detected.
OFF	No malfunction.

This DTC number is clarified in Diagnostic Test Mode II (SELF-DIAGNOSTIC RESULTS)

### DIAGNOSTIC TEST MODE II — SELF-DIAGNOSTIC RESULTS

In this mode, the DTC and 1st trip DTC are indicated by the number of blinks of the MIL as shown below. The DTC and 1st trip DTC are displayed at the same time. If the MIL does not illuminate in diagnostic test mode I (Malfunction warning), all displayed items are 1st trip DTCs. If only one code is displayed when the MIL

illuminates in diagnostic test mode II (SELF-DIAGNOSTIC RESULTS), it is a DTC; if two or more codes are displayed, they may be either DTCs or 1st trip DTCs. DTC No. is same as that of 1st trip DTC. These unidentified codes can be identified by using the CONSULT-II. A DTC will be used as an example for how to read a code.



A particular trouble code can be identified by the number of four-digit numeral flashes. The “zero” is indicated by the number of ten flashes. The length of time the 1,000th-digit numeral flashes on and off is 1.2 seconds consisting of an ON (0.6-second) - OFF (0.6-second) cycle.

The 100th-digit numeral and lower digit numerals consist of a 0.3-second ON and 0.3-second OFF cycle.

A change from one digit numeral to another occurs at an interval of 1.0-second OFF. In other words, the later numeral appears on the display 1.3 seconds after the former numeral has disappeared.

A change from one trouble code to another occurs at an interval of 1.8-second OFF.

In this way, all the detected malfunctions are classified by their DTC numbers. The DTC 0000 refers to no malfunction. (See [EC-575, "INDEX FOR DTC"](#) )

### How to Erase Diagnostic Test Mode II (Self-diagnostic Results)

The DTC can be erased from the back up memory in the ECM by depressing accelerator pedal. Refer to [EC-606, "How to Set Diagnostic Test Mode II \(Self-diagnostic Results\)"](#) .

- If the battery is disconnected, the DTC will be lost from the backup memory within 24 hours.
- Be careful not to erase the stored memory before starting trouble diagnoses.

## BASIC SERVICE PROCEDURE



PFP:00018

### Basic Inspection

GBS000UP

#### 1. INSPECTION START


1. Check service records for any recent repairs that may indicate a related malfunction, or a current need for scheduled maintenance.
2. Open engine hood and check the following:
  - Harness connectors for improper connections
  - Wiring harness for improper connections, pinches and cut
  - Vacuum hoses for splits, kinks and improper connections
  - Hoses and ducts for leaks
  - Air cleaner clogging
  - Gasket
3. Confirm that electrical or mechanical loads are not applied.
  - Headlamp switch is OFF.
  - Air conditioner switch is OFF.
  - Rear window defogger switch is OFF.
  - Steering wheel is in the straight-ahead position, etc.
4. Start engine and warm it up until engine coolant temperature indicator points the middle of gauge.  
Ensure engine stays below 1,000 rpm.



5. Run engine at about 2,000 rpm for about 2 minutes under no load.
6. Make sure that no DTC is displayed with CONSULT-II.

#### OK or NG

- OK    >> GO TO 3.  
 NG    >> GO TO 2.



#### 2. REPAIR OR REPLACE


Repair or replace components as necessary according to corresponding Diagnostic Procedure.

>> GO TO 3.

**3. CHECK TARGET IDLE SPEED**

**④ With CONSULT-II**

1. Run engine at about 2,000 rpm for about 2 minutes under no load.
2. Rev engine (2,000 to 3,000 rpm) two or three times under no load, then run engine at idle speed for about 1 minute.



3. Read idle speed in "DATA MONITOR" mode with CONSULT-II. Refer to [EC-612, "IDLE SPEED"](#) .

**M/T: 625 ± 50 rpm (in Neutral position)**  
**A/T: 625 ± 50 rpm (in P or N position)**

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

**⊗ Without CONSULT-II**

1. Run engine at about 2,000 rpm for about 2 minutes under no load.
2. Rev engine (2,000 to 3,000 rpm) two or three times under no load, then run engine at idle speed for about 1 minute.
3. Check idle speed. Refer to [EC-612, "IDLE SPEED"](#) .

**M/T: 625 ± 50 rpm (in Neutral position)**  
**A/T: 625 ± 50 rpm (in P or N position)**

OK or NG

- OK >> GO TO 10.  
 NG >> GO TO 4.

**4. PERFORM ACCELERATOR PEDAL RELEASED POSITION LEARNING**

1. Stop engine.
2. Perform [EC-614, "Accelerator Pedal Released Position Learning"](#) .

>> GO TO 5.

**5. PERFORM THROTTLE VALVE CLOSED POSITION LEARNING**

Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .

>> GO TO 6.

## 6. PERFORM IDLE AIR VOLUME LEARNING

Refer to [EC-614, "Idle Air Volume Learning"](#) .

Is Idle Air Volume Learning carried out successfully?

Yes or No

- Yes >> GO TO 7.  
 No >> 1. Follow the instruction of Idle Air Volume Learning.  
 2. GO TO 4.

## 7. CHECK TARGET IDLE SPEED AGAIN

### With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Read idle speed in "DATA MONITOR" mode with CONSULT-II.  
 Refer to [EC-612, "IDLE SPEED"](#) .

**M/T: 625 ± 50 rpm (in Neutral position)**

**A/T: 625 ± 50 rpm (in P or N position)**

### Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Check idle speed.  
 Refer to [EC-612, "IDLE SPEED"](#) .

**M/T: 625 ± 50 rpm (in Neutral position)**

**A/T: 625 ± 50 rpm (in P or N position)**

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y

OK or NG

- OK >> GO TO 10.  
 NG >> GO TO 8.

## 8. DETECT MALFUNCTIONING PART

Check the following.

- Check camshaft position sensor (PHASE) and circuit. Refer to [EC-732](#) .
- Check crankshaft position sensor (POS) and circuit. Refer to [EC-725](#) .

OK or NG

- OK >> GO TO 9.  
 NG >> 1. Repair or replace.  
 2. GO TO 4.

## 9. CHECK ECM FUNCTION

1. Substitute another known-good ECM to check ECM function. (ECM may be the cause of an incident, but this is a rare case.)
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [BL-83, "ECM Re-communicating Function"](#) .

>> GO TO 4.




**10. CHECK IGNITION TIMING**

1. Run engine at idle.
2. Check ignition timing with a timing light. Refer to [EC-613, "IGNITION TIMING"](#).

**M/T: 15 ± 5° BTDC (in Neutral position)**  
**A/T: 15 ± 5° BTDC (in P or N position)**

OK or NG

- OK >> **INSPECTION END**  
 NG >> GO TO 11.



**11. PERFORM ACCELERATOR PEDAL RELEASED POSITION LEARNING**

1. Stop engine.
2. Perform [EC-614, "Accelerator Pedal Released Position Learning"](#).

>> GO TO 12.

**12. PERFORM THROTTLE VALVE CLOSED POSITION LEARNING**

Perform [EC-614, "Throttle Valve Closed Position Learning"](#).

>> GO TO 13.

**13. PERFORM IDLE AIR VOLUME LEARNING**

Refer to [EC-614, "Idle Air Volume Learning"](#).  
**Is Idle Air Volume Learning carried out successfully?**

Yes or No

- Yes >> GO TO 14.  
 No >> 1. Follow the instruction of Idle Air Volume Learning.  
 2. GO TO 4.

**14. CHECK TARGET IDLE SPEED AGAIN**

**With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Read idle speed in "DATA MONITOR" mode with CONSULT-II. Refer to [EC-612, "IDLE SPEED"](#).

**M/T: 625 ± 50 rpm (in Neutral position)**  
**A/T: 625 ± 50 rpm (in P or N position)**

**Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Check idle speed. Refer to [EC-612, "IDLE SPEED"](#).

**M/T: 625 ± 50 rpm (in Neutral position)**  
**A/T: 625 ± 50 rpm (in P or N position)**

OK or NG

- OK >> GO TO 15.  
 NG >> GO TO 17.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y

## 15. CHECK IGNITION TIMING AGAIN

1. Run engine at idle.
2. Check ignition timing with a timing light. Refer to [EC-613, "IGNITION TIMING"](#).


**M/T: 15 ± 5° BTDC (in Neutral position)**

**A/T: 15 ± 5° BTDC (in P or N position)**

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 16.



## 16. CHECK TIMING CHAIN INSTALLATION

Check timing chain installation. Refer to [EM-53, "TIMING CHAIN"](#).

OK or NG

OK >> GO TO 17.

NG >> 1. Repair the timing chain installation.  
2. GO TO 4.

## 17. DETECT MALFUNCTIONING PART

Check the following.

- Check camshaft position sensor (PHASE) and circuit. Refer to [EC-732](#).
- Check crankshaft position sensor (POS) and circuit. Refer to [EC-725](#).

OK or NG

OK >> GO TO 18.

NG >> 1. Repair or replace.  
2. GO TO 4.

## 18. CHECK ECM FUNCTION

1. Substitute another known-good ECM to check ECM function. (ECM may be the cause of an incident, but this is a rare case.)
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [BL-83, "ECM Re-communicating Function"](#).

>> GO TO 4.

## Idle Speed and Ignition Timing Check IDLE SPEED

GBS000UQ

**With CONSULT-II**

Check idle speed in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

### ⊗ Without CONSULT-II

Check idle speed by installing the pulse type tachometer clamp on the loop wire or on suitable high-tension wire with installed between No.4 ignition coil and No.4 spark plug.

#### NOTE:


For the method of installing the tachometer, refer to [EC-613, "IGNITION TIMING"](#).

### IGNITION TIMING


Any of following two methods may be used.

#### Method A

1. Attach timing light to loop wire as shown.




2. Check ignition timing.





#### Method B

1. Remove No. 4 ignition coil.




2. Connect No. 4 ignition coil and No. 4 spark plug with suitable high-tension wire as shown, and attach timing light clamp to this wire.





3. Check ignition timing.



## Accelerator Pedal Released Position Learning DESCRIPTION

GBS000UR

Accelerator Pedal Released Position Learning is an operation to learn the fully released position of the accelerator pedal by monitoring the accelerator pedal position sensor output signal. It must be performed each time harness connector of accelerator pedal position sensor or ECM is disconnected.

### OPERATION PROCEDURE

1. Make sure that accelerator pedal is fully released.
2. Turn ignition switch ON and wait at least 2 seconds.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Turn ignition switch ON and wait at least 2 seconds.
5. Turn ignition switch OFF and wait at least 10 seconds.

## Throttle Valve Closed Position Learning DESCRIPTION

GBS000US

Throttle Valve Closed Position Learning is an operation to learn the fully closed position of the throttle valve by monitoring the throttle position sensor output signal. It must be performed each time harness connector of electric throttle control actuator or ECM is disconnected.

### OPERATION PROCEDURE

1. Make sure that accelerator pedal is fully released.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.  
Make sure that throttle valve moves during above 10 seconds by confirming the operating sound.

## Idle Air Volume Learning DESCRIPTION

GBS000UT

Idle Air Volume Learning is an operation to learn the idle air volume that keeps each engine within the specific range. It must be performed under any of the following conditions:

- Each time electric throttle control actuator or ECM is replaced.
- Idle speed or ignition timing is out of specification.

### PREPARATION


Before performing Idle Air Volume Learning, make sure that all of the following conditions are satisfied. Learning will be cancelled if any of the following conditions are missed for even a moment.

- Battery voltage: More than 12.9V (At idle)
- Engine coolant temperature: 70 - 100°C (158 - 212°F)
- PNP switch: ON
- Electric load switch: OFF  
(Air conditioner, headlamp, rear window defogger)
- Steering wheel: Neutral (Straight-ahead position)
- Vehicle speed: Stopped
- Transmission: Warmed-up
  - A/T models
- With CONSULT-II: Drive vehicle until "ATF TEMP SE 1" in "DATA MONITOR" mode of "A/T" system indicates less than 0.9V.
- Without CONSULT-II: Drive vehicle for 10 minutes.
  - M/T models
- Drive vehicle for 10 minutes.


## OPERATION PROCEDURE

### ① With CONSULT-II

1. Perform [EC-614, "Accelerator Pedal Released Position Learning"](#) .
2. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
3. Start engine and warm it up to normal operating temperature.
4. Check that all items listed under the topic PREPARATION (previously mentioned) are in good order.
5. Select "IDLE AIR VOL LEARN" in "WORK SUPPORT" mode.



6. Touch "START" and wait 20 seconds.



# BASIC SERVICE PROCEDURE

[VQ TYPE 2]

7. Make sure that "CMPLT" is displayed on CONSULT-II screen. If "CMPLT" is not displayed, Idle Air Volume Learning will not be carried out successfully. In this case, find the cause of the incident by referring to the Diagnostic Procedure below.
8. Rev up the engine two or three times and make sure that idle speed and ignition timing are within the specifications.

WORK SUPPORT	
IDLE AIR VOL LEARN	CMPLT
MONITOR	
ENG SPEED	XXX rpm
START	


MBIB0238E

ITEM	SPECIFICATION
Idle speed	M/T: 625 ± 50 rpm (in Neutral position) A/T: 625 ± 50 rpm (in P or N position)
Ignition timing	M/T: 15 ± 5° BTDC (in Neutral position) A/T: 15 ± 5° BTDC (in P or N position)

**⊗ Without CONSULT-II**

**NOTE:**

- It is better to count the time accurately with a clock.
  - It is impossible to switch the diagnostic mode when an accelerator pedal position sensor circuit has a malfunction.
1. Perform [EC-614, "Accelerator Pedal Released Position Learning"](#) .
  2. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
  3. Start engine and warm it up to normal operating temperature.
  4. Check that all items listed under the topic PREPARATION (previously mentioned) are in good order.
  5. Turn ignition switch OFF and wait at least 10 seconds.
  6. Confirm that accelerator pedal is fully released, then turn ignition switch ON and wait 3 seconds.
  7. Repeat the following procedure quickly five times within 5 seconds.
    - a. Fully depress the accelerator pedal.
    - b. Fully release the accelerator pedal.
  8. Wait 7 seconds, fully depress the accelerator pedal and keep it for approx. 20 seconds until the MIL stops blinking and turned ON.
  9. Fully release the accelerator pedal within 3 seconds after the MIL turned ON.
  10. Start engine and let it idle.
  11. Wait 20 seconds.



12. Rev up the engine two or three times and make sure that idle speed and ignition timing are within the specifications.

ITEM	SPECIFICATION
Idle speed	M/T: 625 ± 50 rpm (in Neutral position) A/T: 625 ± 50 rpm (in P or N position)
Ignition timing	M/T: 15 ± 5° BTDC (in Neutral position) A/T: 15 ± 5° BTDC (in P or N position)

13. If idle speed and ignition timing are not within the specification, Idle Air Volume Learning will not be carried out successfully. In this case, find the cause of the incident by referring to the DIAGNOSTIC PROCEDURE below.

## DIAGNOSTIC PROCEDURE

If idle air volume learning cannot be performed successfully, proceed as follows:


1. Check that throttle valve is fully closed.
2. Check PCV valve operation.
3. Check that downstream of throttle valve is free from air leakage.
4. When the above three items check out OK, engine component parts and their installation condition are questionable. Check and eliminate the cause of the incident.  
It is useful to perform [EC-667, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE"](#).
5. If any of the following conditions occur after the engine has started, eliminate the cause of the incident and perform Idle air volume learning all over again:
  - Engine stalls.
  - Erroneous idle.

## Fuel Pressure Check FUEL PRESSURE RELEASE

GBS000UU


### With CONSULT-II

1. Turn ignition switch ON.
2. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode with CONSULT-II.
3. Start engine.
4. After engine stalls, crank it two or three times to release all fuel pressure.
5. Turn ignition switch OFF.



### Without CONSULT-II

1. Remove fuel pump fuse located in IPDM E/R.
2. Start engine.
3. After engine stalls, crank it two or three times to release all fuel pressure.
4. Turn ignition switch OFF.
5. Reinstall fuel pump fuse after servicing fuel system.



## FUEL PRESSURE CHECK

### CAUTION:

- Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger.
- The fuel hose connection method used when taking fuel pressure check must not be used for other purposes.
- Be careful not to scratch or put debris around connection area when servicing, so that the quick connector maintains sealability with O-rings inside.
- Do not perform fuel pressure check with electrical systems operating (i.e. lights, rear defogger, A/C, etc.) Fuel pressure gauge may indicate false readings due to varying engine load and changes in manifold vacuum.

### NOTE:



Prepare pans or saucers under the disconnected fuel line because the fuel may spill out. The fuel pressure cannot be completely released because D40 models do not have fuel return system.


1. Release fuel pressure to zero. Refer to [EC-617, "FUEL PRESSURE RELEASE"](#).

# BASIC SERVICE PROCEDURE

[VQ TYPE 2]

2. Prepare fuel hose for fuel pressure check B and fuel tube adapter (KV10118400) D, then connect fuel pressure gauge A.

- : To quick connector
- : To fuel tube (engine side)
- C: Clamp
- Use suitable fuel hose for fuel pressure check (genuine NISSAN fuel hose without quick connector).
- To avoid unnecessary force or tension to hose, use moderately long fuel hose for fuel pressure check.
- Do not use the fuel hose for checking fuel pressure with damage or cracks on it.
- Use Pressure Gauge to check fuel pressure.




3. Remove fuel hose. Refer to [EM-36. "FUEL INJECTOR AND FUEL TUBE"](#) .

- Do not twist or kink fuel hose because it is plastic hose.

4. Connect fuel hose for fuel pressure check (1) to fuel tube (engine side) with clamp (2) as shown in the figure.

- No.2 spool (5)
- Wipe off oil or dirt from hose insertion part using cloth moistened with gasoline.
- Apply proper amount of gasoline between top of the fuel tube (3) and No.1 spool (4).
- Insert fuel hose for fuel pressure check until it touches the No.1 spool on fuel tube.
- Use NISSAN genuine hose clamp (part number: 16439 N4710 or 16439 40U00).
- When reconnecting fuel line, always use new clamps.
- Use a torque driver to tighten clamps.
- Install hose clamp to the position within 1 - 2 mm (0.04 - 0.08 in).



**Tightening torque: 1 - 1.5 N·m (0.1 - 0.15 kg·m, 9 - 13 in-lb)**

- Make sure that clamp screw does not contact adjacent parts.

5. Connect fuel tube adapter to quick connector.

- A: Fuel pressure gauge
- B: Fuel hose for fuel pressure check


6. After connecting fuel hose for fuel pressure check, pull the hose with a force of approximately 98 N (10 kg, 22 lb) to confirm fuel tube does not come off.

7. Turn ignition switch ON and check for fuel leakage.

8. Start engine and check for fuel leakage.

9. Read the indication of fuel pressure gauge.

- Do not perform fuel pressure check with system operating. Fuel pressure gauge may indicate false readings.
- During fuel pressure check, confirm for fuel leakage from fuel connection every 3 minutes.



**At idling: Approximately 350 kPa (3.5 bar, 3.57 kg/cm<sup>2</sup> , 51 psi)**

10. If result is unsatisfactory, go to next step.

11. Check the following.

- Fuel hoses and fuel tubes for clogging
- Fuel filter for clogging
- Fuel pump
- Fuel pressure regulator for clogging



# BASIC SERVICE PROCEDURE

[VQ TYPE 2]

---

If OK, replace fuel pressure regulator.  
If NG, repair or replace.

A

**EC**

C

D

E

F

G

H

I

J

K

L

M


## TROUBLE DIAGNOSIS

PFP:00004


Trouble Diagnosis Introduction  
INTRODUCTION

GBS000UV

The engine has an ECM to control major systems such as fuel control, ignition control, idle air control system, etc. The ECM accepts input signals from sensors and instantly drives actuators. It is essential that both input and output signals are proper and stable. At the same time, it is important that there are no malfunctions such as vacuum leaks, fouled spark plugs, or other malfunctions with the engine.




It is much more difficult to diagnose an incident that occurs intermittently rather than continuously. Most intermittent incidents are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.



A visual check only may not find the cause of the incidents. A road test with CONSULT-II or a circuit tester connected should be performed. Follow the WORK FLOW on [EC-621](#).


Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such incidents, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A Diagnostic Worksheet like the example on [EC-625](#) should be used.

Start your diagnosis by looking for conventional malfunctions first. This will help troubleshoot driveability malfunctions on an electronically controlled engine vehicle.



**WORK FLOW**  
**Overall Sequence**

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



\*1: Include 1st trip DTC.

\*2: Include 1st trip freeze frame data.

---

**Detailed Flow****1. GET INFORMATION FOR SYMPTOM**

---

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred) using the [EC-624, "DIAGNOSTIC WORKSHEET"](#) .

>> GO TO 2.

**2. CHECK DTC\*<sup>1</sup>**

---

1. Check DTC\*<sup>1</sup> .
2. Perform the following procedure if DTC\*<sup>1</sup> is displayed.
  - Record DTC\*<sup>1</sup> and freeze frame data\*<sup>2</sup> . (Print them out with CONSULT-II.)
  - Erase DTC\*<sup>1</sup> . (Refer to [EC-604, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#) .)
  - Study the relationship between the cause detected by DTC\*<sup>1</sup> and the symptom described by the customer. (Symptom Matrix Chart is useful. Refer to [EC-628](#) .)
3. Check related service bulletins for information.

Is any symptom described and any DTC detected?

Symptom is described, DTC\*<sup>1</sup> is displayed>>GO TO 3.

Symptom is described, DTC\*<sup>1</sup> is not displayed>>GO TO 4.

Symptom is not described, DTC\*<sup>1</sup> is displayed>>GO TO 5.

**3. CONFIRM THE SYMPTOM**

---

Try to confirm the symptom described by the customer (except MIL ON).

DIAGNOSIS WORK SHEET is useful to verify the incident.

Connect CONSULT-II to the vehicle in "DATA MONITOR (AUTO TRIG)" mode and check real time diagnosis results.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

**4. CONFIRM THE SYMPTOM**

---

Try to confirm the symptom described by the customer.

DIAGNOSIS WORK SHEET is useful to verify the incident.

Connect CONSULT-II to the vehicle in "DATA MONITOR (AUTO TRIG)" mode and check real time diagnosis results.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

## 5. PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC Confirmation Procedure for the displayed DTC\*<sup>1</sup>, and then make sure that DTC\*<sup>1</sup> is detected again.

At this time, always connect CONSULT-II to the vehicle, and check diagnostic results in real time on "DATA MONITOR (AUTO TRIG)".

If two or more DTCs\*<sup>1</sup> are detected, refer to [EC-626, "DTC Inspection Priority Chart"](#) and determine trouble diagnosis order.

### NOTE:

- Freeze frame data\*<sup>2</sup> is useful if the DTC\*<sup>1</sup> is not detected.
- Perform Overall Function Check if DTC Confirmation Procedure is not included on Service Manual. This simplified check procedure is an effective alternative though DTC\*<sup>1</sup> cannot be detected during this check. If the result of Overall Function Check is NG, it is the same as the detection of DTC\*<sup>1</sup> by DTC Confirmation Procedure.

Is DTC\*<sup>1</sup> detected?

Yes >> GO TO 10.

No >> Check according to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

## 6. PERFORM BASIC INSPECTION

Perform [EC-608, "Basic Inspection"](#).

With CONSULT-II>>GO TO 7.

Without CONSULT-II>>GO TO 9.

## 7. PERFORM DATA MONITOR (SPEC) MODE


### With CONSULT-II

Make sure that "MAS A/F SE-B1", "B/FUEL SCHDL", and "A/F ALPHA-B1", "A/F ALPHA-B2" are within the SP value using CONSULT-II "DATA MONITOR (SPEC)" mode. Refer to [EC-668, "Diagnostic Procedure"](#).

Are they within the SP value?

Yes >> GO TO 9.

No >> GO TO 8.



## 8. DETECT MALFUNCTIONING PART BY TROUBLE DIAGNOSIS - SPECIFICATION VALUE

Detect malfunctioning part according to [EC-667, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE"](#).

Is malfunctioning part detected?

Yes >> GO TO 11.

No >> GO TO 9.

## 9. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM MATRIX CHART

Detect malfunctioning system according to [EC-628, "Symptom Matrix Chart"](#) based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

>> GO TO 10.

## 10. DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

### NOTE:

The Diagnostic Procedure in EC section described based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure. For details, refer to Circuit Inspection in [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#) .

Is malfunctioning part detected?

Yes >> GO TO 11.

No >> Monitor input data from related sensors or check voltage of related ECM terminals using CONSULT-II. Refer to [EC-662, "CONSULT-II Reference Value in Data Monitor"](#) , [EC-642, "ECM Terminals and Reference Value"](#) .

## 11. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure again after repair and replacement.
3. Check DTC. If DTC is displayed, erase it, refer to [EC-604, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#) .

>> GO TO 12.

## 12. FINAL CHECK

When DTC was detected in step 2, perform DTC Confirmation Procedure or Overall Function Check again, and then make sure that the malfunction have been repaired securely.

When symptom was described from the customer, refer to confirmed symptom in step 3 or 4, and make sure that the symptom is not detected.

OK or NG

NG (DTC\*<sup>1</sup> is detected)>>GO TO 10.

NG (Symptom remains)>>GO TO 6.

OK >> 1. Before returning the vehicle to the customer, make sure to erase unnecessary DTC\*<sup>1</sup> in ECM. (Refer to [EC-604, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#) .)

### 2. INSPECTION END

\*1: Include 1st trip DTC.

\*2: Include 1st trip freeze frame data.

## DIAGNOSTIC WORKSHEET

### Description

There are many operating conditions that lead to the malfunction of engine components. A good grasp of such conditions can make troubleshooting faster and more accurate.

In general, each customer feels differently about a incident. It is important to fully understand the symptoms or conditions for a customer complaint.

Utilize a diagnostic worksheet like the one on the next page in order to organize all the information for troubleshooting.

### KEY POINTS

**WHAT** ..... Vehicle & engine model  
**WHEN** ..... Date, Frequencies  
**WHERE**..... Road conditions  
**HOW** ..... Operating conditions,  
 Weather conditions,  
 Symptoms

SEF907L



## DTC Inspection Priority Chart

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

**NOTE:**

If DTC U1000 and/or U1001 is displayed with other DTC, first perform the trouble diagnosis for DTC U1000, U1001. Refer to **EC-686, "DTC U1000, U1001 CAN COMMUNICATION LINE"** .

Priority	Detected items (DTC)
1	<ul style="list-style-type: none"> <li>● U1000 U1001 CAN communication line</li> <li>● P0102 P0103 Mass air flow sensor</li> <li>● P0117 P0118 Engine coolant temperature sensor</li> <li>● P0122 P0123 P0222 P0223 P1225 P1226 P2135 Throttle position sensor</li> <li>● P0327 P0328 P0332 P0333 Knock sensor</li> <li>● P0335 Crankshaft position sensor (POS)</li> <li>● P0340 P0345 Camshaft position sensor (PHASE)</li> <li>● P0605 ECM</li> <li>● P1229 Sensor power supply</li> <li>● P1610 - P1615 NATS</li> <li>● P1706 Park/Neutral position (PNP) switch</li> <li>● P2122 P2123 P2127 P2128 P2138 Accelerator pedal position sensor</li> </ul>
2	<ul style="list-style-type: none"> <li>● P0550 Power steering pressure sensor</li> <li>● P1031 P1032 P1051 P1052 Air fuel ratio (A/F) sensor 1 heater</li> <li>● P1065 ECM power supply</li> <li>● P1111 P1136 Intake valve timing control solenoid valve</li> <li>● P1122 Electric throttle control function</li> <li>● P1124 P1126 P1128 Electric throttle control actuator</li> <li>● P1217 Engine over temperature (OVERHEAT)</li> <li>● P1271 P1272 P1276 P1281 P1282 P1286 Air fuel ratio (A/F) sensor 1</li> <li>● P1805 Brake switch</li> </ul>
3	<ul style="list-style-type: none"> <li>● P0011 P0021 Intake valve timing control</li> <li>● P1121 Electric throttle control actuator</li> <li>● P1564 ASCD steering switch</li> <li>● P1572 ASCD brake switch</li> <li>● P1715 Turbine revolution sensor</li> </ul>



# TROUBLE DIAGNOSIS

[VQ TYPE 2]

GBS000UX

## Fail-Safe Chart

When the DTC listed below is detected, the ECM enters fail-safe mode and the MIL lights up.

DTC No.	Detected items	Engine operating condition in fail-safe mode						
P0102 P0103	Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.						
P0122 P0123 P0222 P0223 P2135	Throttle position sensor	The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees. The ECM regulates the opening speed of the throttle valve to be slower than the normal condition. So, the acceleration will be poor.						
P1121	Electric throttle control actuator	(When electric throttle control actuator does not function properly due to the return spring malfunction:) ECM controls the electric throttle actuator by regulating the throttle opening around the idle position. The engine speed will not rise more than 2,000 rpm.  (When throttle valve opening angle in fail-safe mode is not in specified range:) ECM controls the electric throttle control actuator by regulating the throttle opening to 20 degrees or less.  (When ECM detects the throttle valve is stuck open:) While the vehicle is driving, it slows down gradually by fuel cut. After the vehicle stops, the engine stalls. The engine can restart in N or P position (A/T), neutral position (M/T) and engine speed will not exceed 1,000 rpm or more.						
P1122	Electric throttle control function	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.						
P1124 P1126	Throttle control motor relay	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.						
P1128	Throttle control motor	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.						
P1229	Sensor power supply	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.						
P1805	Brake switch	ECM controls the electric throttle control actuator by regulating the throttle opening to a small range. Therefore, acceleration will be poor. <table border="1" style="width: 100%; margin-top: 5px;"> <thead> <tr> <th style="text-align: center;">Vehicle condition</th> <th style="text-align: center;">Driving condition</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">When engine is idling</td> <td style="text-align: center;">Normal</td> </tr> <tr> <td style="text-align: center;">When accelerating</td> <td style="text-align: center;">Poor acceleration</td> </tr> </tbody> </table>	Vehicle condition	Driving condition	When engine is idling	Normal	When accelerating	Poor acceleration
Vehicle condition	Driving condition							
When engine is idling	Normal							
When accelerating	Poor acceleration							
P2122 P2123 P2127 P2128 P2138	Accelerator pedal position sensor	The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees. The ECM regulates the opening speed of the throttle valve to be slower than the normal condition. So, the acceleration will be poor.						

When there is an open circuit on MIL circuit, the ECM cannot warn the driver by lighting up MIL when there is malfunction on engine control system.

Therefore, when electrical controlled throttle and part of ECM related diagnoses are continuously detected as NG for 5 trips, ECM warns the driver that engine control system malfunctions and MIL circuit is open by means of operating fail-safe function.

The fail-safe function also operates when above diagnoses except MIL circuit are detected and demands the driver to repair the malfunction.

Engine operating condition in fail-safe mode	Engine speed will not rise more than 2,500 rpm due to the fuel cut
--	--

# TROUBLE DIAGNOSIS

[VQ TYPE 2]

## Symptom Matrix Chart SYSTEM — BASIC ENGINE CONTROL SYSTEM

GBS000UY

		SYMPTOM												Reference page												
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION		BATTERY DEAD (UNDER CHARGE)											
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA												
Fuel	Fuel pump circuit	1	1	2	3	2		2	2			3		2	<a href="#">EC-936</a>											
	Fuel pressure regulator system	3	3	4	4	4	4	4	4	4		4			<a href="#">EC-617</a>											
	Fuel injector circuit	1	1	2	3	2		2	2			2			<a href="#">EC-929</a>											
	Evaporative emission system	3	3	4	4	4	4	4	4	4		4			<a href="#">EC-594</a>											
Air	Positive crankcase ventilation system	3	3	4	4	4	4	4	4	4		4	1		<a href="#">EC-598</a>											
	Incorrect idle speed adjustment						1	1	1	1		1			<a href="#">EC-608</a>											
	Electric throttle control actuator	1	1	2	3	3	2	2	2	2		2		2	<a href="#">EC-769</a> , <a href="#">EC-772</a>											
Ignition	Incorrect ignition timing adjustment	3	3	1	1	1		1	1			1			<a href="#">EC-608</a>											
	Ignition circuit	1	1	2	2	2		2	2			2			<a href="#">EC-964</a>											
Power supply and ground circuit		2	2	3	3	3		3	3		2	3			<a href="#">EC-678</a>											
Mass air flow sensor circuit		1			2										<a href="#">EC-694</a>											
Engine coolant temperature sensor circuit					3																					<a href="#">EC-701</a>
Air fuel ratio (A/F) sensor					3																					
Throttle position sensor circuit			1	2		2		2	2			2			<a href="#">EC-706</a> , <a href="#">EC-713</a> , <a href="#">EC-799</a> , <a href="#">EC-801</a> , <a href="#">EC-883</a>											
Accelerator pedal position sensor circuit				3	2	1									<a href="#">EC-803</a> , <a href="#">EC-870</a> , <a href="#">EC-876</a> , <a href="#">EC-891</a>											
Knock sensor circuit				2								3			<a href="#">EC-720</a>											
Crankshaft position sensor (POS) circuit		2	2												<a href="#">EC-725</a>											
Camshaft position sensor (PHASE) circuit		3	2												<a href="#">EC-732</a>											
Vehicle speed signal circuit			2	3		3						3			<a href="#">EC-992</a>											
Power steering pressure sensor circuit			2					3	3						<a href="#">EC-741</a>											
ECM		2	2	3	3	3	3	3	3	3	3	3			<a href="#">EC-746</a> , <a href="#">EC-757</a>											

# TROUBLE DIAGNOSIS

[VQ TYPE 2]

	SYMPTOM													Reference page
	HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Intake valve timing control solenoid valve circuit		3	2		1	3	2	2	3		3			<a href="#">EC-761</a>
PNP switch circuit			3		3		3	3			3			<a href="#">EC-858</a>
VIAS control solenoid valve circuit					1									<a href="#">EC-983</a>
Refrigerant pressure sensor circuit		2				3			3		4			<a href="#">EC-977</a>
Electrical load signal circuit							3							<a href="#">EC-915</a>
Air conditioner circuit	2	2	3	3	3	3	3	3	3		3		2	<a href="#">MTC-32</a>
ABS actuator and electric unit (control unit)			4											<a href="#">BRC-8</a>

1 - 6: The numbers refer to the order of inspection.  
(continued on next page)

## SYSTEM — ENGINE MECHANICAL & OTHER

		SYMPTOM													Reference page	
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)		
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA		
Fuel	Fuel tank	5	5												<a href="#">FL-5</a>	
	Fuel piping			5	5	5		5	5			5			<a href="#">FL-3</a>	
	Vapor lock															—
	Valve deposit															—
	Poor fuel (Heavy weight gasoline, Low octane)	5			5	5	5		5	5			5			—

# TROUBLE DIAGNOSIS

[VQ TYPE 2]

		SYMPTOM												Reference page	
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION		BATTERY DEAD (UNDER CHARGE)
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Air	Air duct														<a href="#">EM-17</a>
	Air cleaner														<a href="#">EM-17</a>
	Air leakage from air duct (Mass air flow sensor — electric throttle control actuator)	5	5	5		5		5	5			5			<a href="#">EM-17</a>
	Electric throttle control actuator	5			5		5			5					<a href="#">EM-18</a>
	Air leakage from intake manifold/ Collector/Gasket														<a href="#">EM-18</a> , <a href="#">EM-21</a>
Cranking	Battery	1	1	1		1		1	1					1	<a href="#">SC-5</a>
	Generator circuit														<a href="#">SC-14</a>
	Starter circuit	3										1			<a href="#">SC-30</a>
	Signal plate	6													<a href="#">EM-107</a>
	PNP switch	4													<a href="#">MT-12</a> , <a href="#">AT-104</a>
Engine	Cylinder head	5	5	5	5	5		5	5			5			<a href="#">EM-91</a>
	Cylinder head gasket										4		3		
	Cylinder block														
	Piston												4		
	Piston ring														
	Connecting rod	6	6	6	6	6		6	6			6			<a href="#">EM-107</a>
	Bearing														
	Crankshaft														
Valve mechanism	Timing chain														<a href="#">EM-53</a>
	Camshaft														<a href="#">EM-73</a>
	Intake valve timing control	5	5	5	5	5		5	5			5		<a href="#">EM-53</a>	
	Intake valve												3		<a href="#">EM-91</a>
	Exhaust valve														
Exhaust	Exhaust manifold/Tube/Muffler/ Gasket	5	5	5	5	5		5	5			5			<a href="#">EM-23</a> , <a href="#">EX-2</a>
	Three way catalyst														
Lubrication	Oil pan/Oil strainer/Oil pump/Oil filter/Oil gallery/Oil cooler	5	5	5	5	5		5	5			5			<a href="#">EM-28</a> , <a href="#">LU-13</a> , <a href="#">LU-10</a> , <a href="#">LU-11</a>
	Oil level (Low)/Filthy oil														<a href="#">LU-7</a>

# TROUBLE DIAGNOSIS

[VQ TYPE 2]


		SYMPTOM												Reference page	
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION		BATTERY DEAD (UNDER CHARGE)
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Cooling	Radiator/Hose/Radiator filler cap														<a href="#">CO-13</a>
	Thermostat									5					<a href="#">CO-27</a>
	Water pump														<a href="#">CO-23</a>
	Water gallery	5	5	5	5	5		5	5		4	5			<a href="#">CO-29</a>
	Cooling fan										5				<a href="#">CO-21</a>
	Coolant level (Low)/Contaminated coolant										5				<a href="#">CO-10</a>
NATS (Nissan Anti-theft system)		1	1												<a href="#">EC-600</a> or <a href="#">BL-81</a>

1 - 6: The numbers refer to the order of inspection.

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M






## Engine Control Component Parts Location

GBS000UZ



MBIB1270E

- |   |   |   |
|---|---|---|
| 1. ECM  | 2. Refrigerant pressure sensor                                    | 3. Electric throttle control actuator                             |
| 4. Power steering pressure sensor                             | 5. Power valve actuator   | 6. Cooling fan motor  |
| 7. VIAS control solenoid valve                                | 8. EVAP canister purge volume control solenoid valve              | 9. Intake valve timing control solenoid valve (bank 2)            |
| 10. Mass air flow sensor (with intake air temperature sensor) | 11. Ignition coil (with power transistor) and spark plug (bank 2) | 12. Camshaft position sensor (PHASE) (bank 2)                     |
| 13. Fuel injector (bank 2)                                    | 14. Knock sensor  | 15. Camshaft position sensor (PHASE) (bank 1)                     |
| 16. Engine coolant temperature sensor                         | 17. Fuel injector (bank 1)  | 18. Ignition coil (with power transistor) and spark plug (bank 1) |
| 19. Intake valve timing control solenoid valve (bank 1)       | 20. IPDM E/R  |   |









↶ : Vehicle front

- |   |   |   |
|---|---|---|
| 1. Mass air flow sensor                                   | 2. Engine coolant temperature sensor                        | 3. Electric throttle control actuator                       |
| 4. Fuel level sensor unit and fuel pump harness connector | 5. Air fuel ratio (A/F) sensor 1 (bank 1) harness connector | 6. Air fuel ratio (A/F) sensor 1 (bank 2) harness connector |

MBIB1271E

# TROUBLE DIAGNOSIS

[VQ TYPE 2]



← : Vehicle front

MBIB1409E




- |  |  |  |
|--|--|--|
| 1. EVAP canister purge volume control solenoid valve | 2. EVAP control system pressure sensor                 | 3. EVAP canister                                       |
| 4. EVAP canister vent control valve                  | 5. Power steering pressure sensor                      | 6. Throttle valve                                      |
| 7. Electric throttle control actuator                | 8. Intake valve timing control solenoid valve (bank 1) | 9. Intake valve timing control solenoid valve (bank 2) |



# TROUBLE DIAGNOSIS

[VQ TYPE 2]






A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



MBIB1273E

↔ : Vehicle front







- |  |   |  |
|--|---|--|
| 1. Air fuel ratio (A/F) sensor 1 (bank 1)            | 2. Air fuel ratio (A/F) sensor 1 (bank 2) | 3. Heated oxygen sensor 2 (bank 2)                   |
| 4. Heated oxygen sensor 2 (bank 2) harness connector | 5. Heated oxygen sensor 2 (bank 1)        | 6. Heated oxygen sensor 2 (bank 1) harness connector |



← : Vehicle front

- |  |   |   |
|--|---|---|
| 1. Accelerator pedal position sensor harness connector | 2. IPDM E/R                                 | 3. Fuel pump fuse (15A)                     |
| 4. ECM harness connectors                              | 5. Fuel injector (bank 1) harness connector | 6. Fuel injector (bank 2) harness connector |
| 7. Knock sensor (bank 2)                               | 8. Knock sensor (bank 1)                    |   |

MBIB1274E








A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

↶ : Vehicle front

- |   |   |  |
|---|---|--|
| 1. ASCD brake switch                              | 2. Stop lamp switch                               | 3. Condenser-1                                   |
| 4. Ignition coil (with power transistor) (bank 1) | 5. Ignition coil (with power transistor) (bank 2) | 6. Refrigerant pressure sensor harness connector |
| 7. Power valve actuator                           | 8. VIAS control solenoid valve                    |  |

MBIB1275E



- |  |  |  |
|--|--|--|
| 1. Crankshaft position sensor (POS)      | 2. Camshaft position sensor (PHASE) (bank 2) | 3. Camshaft position sensor (PHASE) (bank 1)   |
| 4. ASCD steering switch                  | 5. RESUME/ACCELERATE switch                  | 6. SET/COAST switch                            |
| 7. MAIN switch                           | 8. CANCEL switch                             | 9. Cooling fan control motor harness connector |
| 10. Fuel level sensor unit and fuel pump | 11. Fuel pressure regulator                  |  |

MBIB1276E

Vacuum Hose Drawing

GBS000V0

A

EC

C

D

E

F

G

H


I

J

K

L

M




NOTE: Do not use soapy water or any type of solvent while installing vacuum hose or purge hoses.

Refer to [EC-585, "System Diagram"](#) for Vacuum Control System.

PBIB2529E


## Circuit Diagram

GBS000V1



# TROUBLE DIAGNOSIS


[VQ TYPE 2]



A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

## ECM Harness Connector Terminal Layout

GBS000V2




MBIB0045E

## ECM Terminals and Reference Value PREPARATION


GBS000V3

1. ECM located in the engine room passenger side behind reservoir tank.
2. Remove ECM harness connector.



BBIA0537E

3. When disconnecting ECM harness connector, loosen it with levers as far as they will go as shown in the figure.
4. Connect a break-out box (SST) and Y-cable adapter (SST) between the ECM and ECM harness connector.
  - Use extreme care not to touch 2 pins at one time.
  - Data is for comparison and may not be exact.



PBIB1512E

## ECM INSPECTION TABLE

Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-II.

### CAUTION:

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECMs transistor. Use a ground other than ECM terminals, such as the ground.**





TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
1	B	ECM ground	<b>[Engine is running]</b> ● Idle speed	Body ground
2	L	A/F sensor 1 heater (Bank 1)	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed	Approximately 5V★ 

PBIB1584E



# TROUBLE DIAGNOSIS





**[VQ TYPE 2]**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
3	BR	Throttle control motor relay power supply	<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)
4	L/W	Throttle control motor (Close)	<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully released</li> </ul>	0 - 14V★  <small>PBIB1104E</small>
5	L/B	Throttle control motor (Open)	<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully depressed</li> </ul>	0 - 14V★  <small>PBIB1105E</small>
6	R	Heated oxygen sensor 2 heater (Bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed is below 3,600 rpm after the following conditions are met               <ul style="list-style-type: none"> <li>- Engine: After warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - 1.0V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> </ul> <b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed: Above 3,600 rpm</li> </ul>	BATTERY VOLTAGE (11 - 14V)
10	W	Intake valve timing control solenoid valve (Bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	BATTERY VOLTAGE (11 - 14V)
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,500 rpm</li> </ul>	7 - 12V★  <small>PBIB1790E</small>
11	V	Intake valve timing control solenoid valve (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	BATTERY VOLTAGE (11 - 14V)
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,500 rpm</li> </ul>	7 - 12V★  <small>PBIB1790E</small>

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M




# TROUBLE DIAGNOSIS

[VQ TYPE 2]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
12	P	Power steering pressure sensor	[Engine is running] ● Steering wheel: Being turned	0.5 - 4.5V
			[Engine is running] ● Steering wheel: Not being turned	0.4 - 0.8V
13	G	Crankshaft position sensor (POS)	[Engine is running] ● Warm-up condition ● Idle speed <b>NOTE:</b> The pulse cycle changes depending on rpm at idle	Approximately 10V★  PBIB1041E
			[Engine is running] ● Engine speed: 2,000 rpm	Approximately 10V★  PBIB1042E
14	Y	Camshaft position sensor (PHASE) (Bank 2)	[Engine is running] ● Warm-up condition ● Idle speed <b>NOTE:</b> The pulse cycle changes depending on rpm at idle	1.0 - 4.0V★  PBIB1039E
			[Engine is running] ● Engine speed: 2,000 rpm	1.0 - 4.0V★  PBIB1040E
15	W	Knock sensor (Bank 1)	[Engine is running] ● Idle speed	Approximately 2.5V
16	SB	A/F sensor 1 (Bank 1)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 3.1V
35	O			Approximately 2.6V
56	LG			Approximately 2.3V
75	P			Approximately 2.3V

# TROUBLE DIAGNOSIS





[VQ TYPE 2]

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
21 22 23	W LG SB	Fuel injector No. 5 Fuel injector No. 3 Fuel injector No. 1	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p style="text-align: right; font-size: small;">SEC984C</p>
			<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p style="text-align: right; font-size: small;">SEC985C</p>
24	G	A/F sensor 1 heater (Bank 2)	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	<p>Approximately 5V★</p>  <p style="text-align: right; font-size: small;">PBIB1584E</p>
25	SB	Heated oxygen sensor 2 heater (Bank 1)	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Engine speed is below 3,600 rpm after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: After warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - 1.0V
			<p><b>[Ignition switch: ON]</b></p> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> </ul> <p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Engine speed: Above 3,600 rpm</li> </ul>	BATTERY VOLTAGE (11 - 14V)
29	GR	VIAS control solenoid valve	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Idle speed</li> </ul>	BATTERY VOLTAGE (11 - 14V)
			<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Engine speed: Between 2,200 and 3,300 rpm</li> </ul>	0 - 1.0V
32	W	EVAP control system pressure sensor	<b>[Ignition switch: ON]</b>	Approximately 1.8 - 4.8V

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



# TROUBLE DIAGNOSIS

[VQ TYPE 2]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
33	L	Camshaft position sensor (PHASE) (Bank 1)	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	<p>1.0 - 4.0V★</p>  <p style="text-align: right; font-size: small;">PBIB1039E</p>
			<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>1.0 - 4.0V★</p>  <p style="text-align: right; font-size: small;">PBIB1040E</p>
34	BR	Intake air temperature sensor	<p><b>[Engine is running]</b></p>	<p>Approximately 0 - 4.8V Output voltage varies with intake air temperature.</p>
36	W	Knock sensor (Bank 2)	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Idle speed</li> </ul>	<p>Approximately 2.5V</p>
40 41 42	V R O	Fuel injector No. 6 Fuel injector No. 4 Fuel injector No. 2	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p style="text-align: right; font-size: small;">SEC984C</p>
			<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p style="text-align: right; font-size: small;">SEC985C</p>

# TROUBLE DIAGNOSIS



[VQ TYPE 2]

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
45	P	EVAP canister purge volume control solenoid valve	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Idle speed</li> <li>● Accelerator pedal is not depressed even slightly, after engine starting</li> </ul>	BATTERY VOLTAGE (11 - 14V)★ 
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed: About 2,000 rpm (More than 100 seconds after starting engine)</li> </ul>	BATTERY VOLTAGE (11 - 14V)★ 
47	W	Sensor power supply (Throttle position sensor)	<b>[Ignition switch: ON]</b>	Approximately 5V
48	SB	Sensor power supply (EVAP control system pressure sensor)	<b>[Ignition switch: ON]</b>	Approximately 5V
49	P	Sensor power supply (Refrigerant pressure sensor)	<b>[Ignition switch: ON]</b>	Approximately 5V
50	W	Throttle position sensor 1	<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully released</li> </ul>	More than 0.36V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully depressed</li> </ul>	Less than 4.75V
51	P	Mass air flow sensor	<b>[Ignition switch: ON]</b>	Approximately 0.4V
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	0.9 - 1.2V
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine is revving from idle to about 4,000 rpm</li> </ul>	0.9 - 1.2 to Approximately 2.4V (Check for linear voltage rise in response to engine being increased to about 4,000 rpm)
55	G	Heated oxygen sensor 2 (Bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Revving engine from idle to 3,000 rpm quickly after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: After warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - Approximately 1.0V

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



# TROUBLE DIAGNOSIS

[VQ TYPE 2]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
57	GR	A/F sensor 1 (Bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 2.6V
58	O			Approximately 2.3V
76	V			Approximately 3.1V
77	Y			Approximately 2.3V
60 61 62	V L Y	Ignition signal No. 5 Ignition signal No. 3 Ignition signal No. 1	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	0 - 0.2V★  <small>SEC986C</small>
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,500 rpm</li> </ul>	0.1 - 0.4V★  <small>SEC987C</small>
66	B	Sensor ground (Throttle position sensor)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 0V
67	GR	Sensor ground	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 0V
68	V	Sensor power supply (Power steering pressure sensor)	<b>[Ignition switch: ON]</b>	Approximately 5V
69	R	Throttle position sensor 2	<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully released</li> </ul>	Less than 4.75V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully depressed</li> </ul>	More than 0.36V
70	BR	Refrigerant pressure sensor	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Both A/C switch and blower switch: ON (Compressor operates)</li> </ul>	1.0 - 4.0V
73	Y	Engine coolant temperature sensor	<b>[Engine is running]</b>	Approximately 0 - 4.8V Output voltage varies with engine coolant temperature.

# TROUBLE DIAGNOSIS

[VQ TYPE 2]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
74	O	Heated oxygen sensor 2 (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Revving engine from idle to 3,000 rpm quickly after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: After warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - Approximately 1.0V
78	B	Sensor ground (Heated oxygen sensor 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● <b>Warm-up condition</b></li> <li>● Idle speed</li> </ul>	Approximately 0V
79 80 81	P GR G	Ignition signal No. 6 Ignition signal No. 4 Ignition signal No. 2	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● <b>Warm-up condition</b></li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	0 - 0.2V★ 
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● <b>Warm-up condition</b></li> <li>● Engine speed: 2,500 rpm</li> </ul>	0.1 - 0.4V★ 
82	B	Sensor ground (APP sensor 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● <b>Warm-up condition</b></li> <li>● Idle speed</li> </ul>	Approximately 0V
83	O	Sensor ground (APP sensor 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● <b>Warm-up condition</b></li> <li>● Idle speed</li> </ul>	Approximately 0V
85	SB	Data link connector	<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● CONSULT-II: Disconnected</li> </ul>	Approximately 5V - Battery voltage (11 - 14V)
86	P	CAN communication line	<b>[Ignition switch: ON]</b>	Approximately 1.1 - 2.3V Output voltage varies with the communication status.
90	L	Sensor power supply (APP sensor 1)	<b>[Ignition switch: ON]</b>	Approximately 5V
91	G	Sensor power supply (APP sensor 2)	<b>[Ignition switch: ON]</b>	Approximately 5V
94	L	CAN communication line	<b>[Ignition switch: ON]</b>	Approximately 2.6 - 3.2V Output voltage varies with the communication status.
98	GR	Accelerator pedal position sensor 2	<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Accelerator pedal: Fully released</li> </ul>	0.3 - 0.45V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Accelerator pedal: Fully depressed</li> </ul>	Less than 2.4V

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# TROUBLE DIAGNOSIS

**[VQ TYPE 2]**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
99	SB	ASCDC steering switch	<b>[Ignition switch: ON]</b> ● ASCDC steering switch: OFF	Approximately 4.0V
			<b>[Ignition switch: ON]</b> ● MAIN switch: Pressed	Approximately 0V
			<b>[Ignition switch: ON]</b> ● CANCEL switch: Pressed	Approximately 1V
			<b>[Ignition switch: ON]</b> ● RESUME/ACCELERATE switch: Pressed	Approximately 3V
			<b>[Ignition switch: ON]</b> ● SET/COAST switch: Pressed	Approximately 2V
101	V	Stop lamp switch	<b>[Ignition switch: OFF]</b> ● Brake pedal: Fully released	Approximately 0V
			<b>[Ignition switch: OFF]</b> ● Brake pedal: Slightly depressed	BATTERY VOLTAGE (11 - 14V)
102	G (A/T) O (M/T)	PNP switch	<b>[Ignition switch: ON]</b> ● Shift lever: P or N (A/T), Neutral (M/T)	Approximately 0V
			<b>[Ignition switch: ON]</b> ● Except above position	BATTERY VOLTAGE (11 - 14V)
104	O	Throttle control motor relay	<b>[Ignition switch: OFF]</b>	BATTERY VOLTAGE (11 - 14V)
			<b>[Ignition switch: ON]</b>	0 - 1.0V
106	R	Accelerator pedal position sensor 1	<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully released	0.6 - 0.95V
			<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully depressed	Less than 4.75V
108	LG	ASCDC brake switch	<b>[Ignition switch: ON]</b> ● Brake pedal: Slightly depressed (A/T) ● Clutch pedal and/or brake pedal: Slightly depressed (M/T)	Approximately 0V
			<b>[Ignition switch: ON]</b> ● Brake pedal: Fully released (A/T) ● Clutch pedal and brake pedal: Fully released (M/T)	BATTERY VOLTAGE (11 - 14V)
109	R	Ignition switch	<b>[Ignition switch: OFF]</b>	0V
			<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)
111	BR	ECM relay (Self shut-off)	<b>[Engine is running]</b> <b>[Ignition switch: OFF]</b> ● For a few seconds after turning ignition switch OFF	0 - 1.5V
			<b>[Ignition switch: OFF]</b> ● More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14V)



# TROUBLE DIAGNOSIS

[VQ TYPE 2]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
113	V	Fuel pump relay	<b>[Ignition switch: ON]</b> ● For 1 second after turning ignition switch ON	0 - 1.5V
			<b>[Engine is running]</b> ● More than 1 second after turning ignition switch ON	BATTERY VOLTAGE (11 - 14V)
115 116	B B	ECM ground	<b>[Engine is running]</b> ● Idle speed	Body ground
117	G	EVAP canister vent control valve	<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)
119 120	R P	Power supply for ECM	<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)
121	V	Power supply for ECM (Back-up)	<b>[Ignition switch: OFF]</b>	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## CONSULT-II Function (ENGINE) FUNCTION

GBS000V4

Diagnostic test mode	Function
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT-II unit.
Self-diagnostic results	Self-diagnostic results such as 1st trip DTC, DTCs and 1st trip freeze frame data or freeze frame data can be read and erased quickly.*
Data monitor	Input/Output data in the ECM can be read.
Data monitor (SPEC)	Input/Output of the specification for Basic fuel schedule, AFM, A/F feedback control value and the other data monitor items can be read.
CAN diagnostic support monitor	The results of transmit/receive diagnosis of CAN communication can be read.
Active test	Diagnostic Test Mode in which CONSULT-II drives some actuators apart from the ECMs and also shifts some parameters in a specified range.
Function test	This mode is used to inform customers when their vehicle condition requires periodic maintenance.
ECM part number	ECM part number can be read.

\*: The following emission-related diagnostic information is cleared when the ECM memory is erased.

- Diagnostic trouble codes
- 1st trip diagnostic trouble codes
- Freeze frame data
- 1st trip freeze frame data

# TROUBLE DIAGNOSIS

[VQ TYPE 2]

## ENGINE CONTROL COMPONENT PARTS/CONTROL SYSTEMS APPLICATION

		DIAGNOSTIC TEST MODE						
		WORK SUPPORT	SELF-DIAGNOSTIC RESULTS		DATA MONITOR	DATA MONITOR (SPEC)	ACTIVE TEST	
			DTC*1	FREEZE FRAME DATA*2				
ENGINE CONTROL COMPONENT PARTS	INPUT	Crankshaft position sensor (POS)		×	×	×	×	
	Camshaft position sensor (PHASE)		×	×	×	×		
	Mass air flow sensor		×		×	×		
	Engine coolant temperature sensor		×	×	×	×	×	
	Air fuel ratio (A/F) sensor 1		×		×	×		
	Heated oxygen sensor 2				×	×		
	Wheel sensor			×	×	×		
	Accelerator pedal position sensor		×		×	×		
	Throttle position sensor		×		×	×		
	Intake air temperature sensor			×	×	×		
	Knock sensor		×					
	Refrigerant pressure sensor				×	×		
	Closed throttle position switch (accelerator pedal position sensor signal)				×	×		
	Air conditioner switch				×	×		
	Park/neutral position (PNP) switch		×		×	×		
	Stop lamp switch		×		×	×		
	Power steering pressure sensor		×		×	×		
	Battery voltage				×	×		
	Load signal				×	×		
	ASCD steering switch		×		×	×		
ASCD brake switch		×		×	×			
ASCD clutch switch		×		×	×			
ENGINE CONTROL COMPONENT PARTS	OUTPUT	Fuel injector				×	×	×
	Power transistor (Ignition timing)					×	×	×
	Throttle control motor relay		×			×	×	
	Throttle control motor		×					
	Air conditioner relay					×	×	
	Fuel pump relay	×				×	×	×
	Cooling fan relay		×			×	×	×
	Air fuel ratio (A/F) sensor 1 heater		×			×	×	
	Heated oxygen sensor 2 heater					×	×	
	Intake valve timing control solenoid valve		×			×	×	×
	VIAS control solenoid valve					×	×	×

X: Applicable

\*1: This item includes 1st trip DTCs.


\*2: This mode includes 1st trip freeze frame data or freeze frame data. The items appear on CONSULT-II screen in freeze frame data mode only if a 1st trip DTC or DTC is detected. For details, refer to [EC-654](#).

## INSPECTION PROCEDURE


**CAUTION:**

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. Turn ignition switch OFF.
2. Connect CONSULT-II and CONSULT-II CONVERTER to data link connector (1), which is located under LH dash panel near the hood opener handle.
3. Turn ignition switch ON.




4. Touch "START (NISSAN BASED VHCL)".



5. Touch "ENGINE".  
If "ENGINE" is not indicated, go to [GI-47, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



6. Perform each diagnostic test mode according to each service procedure.  
**For further information, see the CONSULT-II Operation Manual.**



A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

## WORK SUPPORT MODE

### Work Item

WORK ITEM	CONDITION	USAGE
FUEL PRESSURE RELEASE	<ul style="list-style-type: none"> <li>FUEL PUMP WILL STOP BY TOUCHING "START" DURING IDLING. CRANK A FEW TIMES AFTER ENGINE STALLS.</li> </ul>	When releasing fuel pressure from fuel line
IDLE AIR VOL LEARN	<ul style="list-style-type: none"> <li>THE IDLE AIR VOLUME THAT KEEPS THE ENGINE WITHIN THE SPECIFIED RANGE IS MEMORIZED IN ECM.</li> </ul>	When learning the idle air volume
SELF-LEARNING CONT	<ul style="list-style-type: none"> <li>THE COEFFICIENT OF SELF-LEARNING CONTROL MIXTURE RATIO RETURNS TO THE ORIGINAL COEFFICIENT.</li> </ul>	When clearing the coefficient of self-learning control value
TARGET IDLE RPM ADJ*	<ul style="list-style-type: none"> <li>IDLE CONDITION</li> </ul>	When setting target idle speed
TARGET IGN TIM ADJ*	<ul style="list-style-type: none"> <li>IDLE CONDITION</li> </ul>	When adjusting target ignition timing

\*: This function is not necessary in the usual service procedure.

## SELF-DIAG RESULTS MODE

### Self Diagnostic Item

Regarding items of DTC and 1st trip DTC, refer to [EC-601, "EMISSION-RELATED DIAGNOSTIC INFORMATION ITEMS"](#).

### Freeze Frame Data and 1st Trip Freeze Frame Data

Freeze frame data item*	Description
DIAG TROUBLE CODE [PXXXX]	<ul style="list-style-type: none"> <li>The engine control part/control system has a trouble code, it is displayed as "PXXXX". (Refer to <a href="#">EC-575, "INDEX FOR DTC"</a>.)</li> </ul>
FUEL SYS-B1	<ul style="list-style-type: none"> <li>"Fuel injection system status" at the moment a malfunction is detected is displayed.</li> </ul>
FUEL SYS-B2	<ul style="list-style-type: none"> <li>One mode in the following is displayed.                             <ul style="list-style-type: none"> <li>"Mode2": Open loop due to detected system malfunction</li> <li>"Mode3": Open loop due to driving conditions (power enrichment, deceleration enrichment)</li> <li>"Mode4": Closed loop - using oxygen sensor(s) as feedback for fuel control</li> <li>"Mode5": Open loop - has not yet satisfied condition to go to closed loop</li> </ul> </li> </ul>
COOLANT TEMP [°C] or [°F]	<ul style="list-style-type: none"> <li>The engine coolant temperature at the moment a malfunction is detected is displayed.</li> </ul>
L-FUEL TRM-B1 [%]	<ul style="list-style-type: none"> <li>"Long-term fuel trim" at the moment a malfunction is detected is displayed.</li> </ul>
L-FUEL TRM-B2 [%]	<ul style="list-style-type: none"> <li>The long-term fuel trim indicates much more gradual feedback compensation to the base fuel schedule than short-term fuel trim.</li> </ul>
S-FUEL TRM-B1 [%]	<ul style="list-style-type: none"> <li>"Short-term fuel trim" at the moment a malfunction is detected is displayed.</li> </ul>
S-FUEL TRM-B2 [%]	<ul style="list-style-type: none"> <li>The short-term fuel trim indicates dynamic or instantaneous feedback compensation to the base fuel schedule.</li> </ul>
ENGINE SPEED [rpm]	<ul style="list-style-type: none"> <li>The engine speed at the moment a malfunction is detected is displayed.</li> </ul>
VEHICL SPEED [km/h] or [mph]	<ul style="list-style-type: none"> <li>The vehicle speed at the moment a malfunction is detected is displayed.</li> </ul>
B/FUEL SCHDL [msec]	<ul style="list-style-type: none"> <li>The base fuel schedule at the moment a malfunction is detected is displayed.</li> </ul>
INT/A TEMP SE [°C] or [°F]	<ul style="list-style-type: none"> <li>The intake air temperature at the moment a malfunction is detected is displayed.</li> </ul>

\*: The items are the same as those of 1st trip freeze frame data.

# TROUBLE DIAGNOSIS

[VQ TYPE 2]

## DATA MONITOR MODE

### Monitored Item

×: Applicable

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	Description	Remarks
ENG SPEED [rpm]	×	×	<ul style="list-style-type: none"> <li>Indicates the engine speed computed from the signal of the crankshaft position sensor (POS) and camshaft position sensor (PHASE).</li> </ul>	<ul style="list-style-type: none"> <li>Accuracy becomes poor if engine speed drops below the idle rpm.</li> <li>If the signal is interrupted while the engine is running, an abnormal value may be indicated.</li> </ul>
MAS A/F SE-B1 [V]	×	×	<ul style="list-style-type: none"> <li>The signal voltage of the mass air flow sensor is displayed.</li> </ul>	<ul style="list-style-type: none"> <li>When the engine is stopped, a certain value is indicated.</li> </ul>
B/FUEL SCHDL [msec]		×	<ul style="list-style-type: none"> <li>"Base fuel schedule" indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction.</li> </ul>	
A/F ALPHA-B1 [%]		×	<ul style="list-style-type: none"> <li>The mean value of the air-fuel ratio feedback correction factor per cycle is indicated.</li> </ul>	<ul style="list-style-type: none"> <li>When the engine is stopped, a certain value is indicated.</li> </ul>
A/F ALPHA-B2 [%]		×		<ul style="list-style-type: none"> <li>This data also includes the data for the air-fuel ratio learning control.</li> </ul>
COOLAN TEMP/S [°C] or [°F]	×	×	<ul style="list-style-type: none"> <li>The engine coolant temperature (determined by the signal voltage of the engine coolant temperature sensor) is displayed.</li> </ul>	<ul style="list-style-type: none"> <li>When the engine coolant temperature sensor is open or short-circuited, ECM enters fail-safe mode. The engine coolant temperature determined by the ECM is displayed.</li> </ul>
A/F SEN1 (B1) [V]	×	×	<ul style="list-style-type: none"> <li>The A/F signal computed from the input signal of the air fuel ratio (A/F) sensor 1 is displayed.</li> </ul>	
A/F SEN1 (B2) [V]	×			
HO2S2 (B1) [V]	×		<ul style="list-style-type: none"> <li>The signal voltage of the heated oxygen sensor 2 is displayed.</li> </ul>	
HO2S2 (B2) [V]	×			
HO2S2 MNTR (B1) [RICH/LEAN]	×		<ul style="list-style-type: none"> <li>Display of heated oxygen sensor 2 signal: RICH: Means the amount of oxygen after three way catalyst is relatively small. LEAN: Means the amount of oxygen after three way catalyst is relatively large.</li> </ul>	<ul style="list-style-type: none"> <li>When the engine is stopped, a certain value is indicated.</li> </ul>
HO2S2 MNTR (B2) [RICH/LEAN]	×			
VHCL SPEED SE [km/h] or [mph]	×	×	<ul style="list-style-type: none"> <li>The vehicle speed computed from the vehicle speed signal sent from combination meter is displayed.</li> </ul>	
BATTERY VOLT [V]	×	×	<ul style="list-style-type: none"> <li>The power supply voltage of ECM is displayed.</li> </ul>	
ACCEL SEN 1 [V]	×	×	<ul style="list-style-type: none"> <li>The accelerator pedal position sensor signal voltage is displayed.</li> </ul>	<ul style="list-style-type: none"> <li>ACCEL SEN 2 signal is converted by ECM internally. Thus, it differs from ECM terminal voltage signal.</li> </ul>
ACCEL SEN 2 [V]	×			
THRTL SEN 1 [V]	×	×	<ul style="list-style-type: none"> <li>The throttle position sensor signal voltage is displayed.</li> </ul>	<ul style="list-style-type: none"> <li>THRTL SEN 2 signal is converted by ECM internally. Thus, it differs from ECM terminal voltage signal.</li> </ul>
THRTL SEN 2 [V]	×			
INT/A TEMP SE [°C] or [°F]	×	×	<ul style="list-style-type: none"> <li>The intake air temperature (determined by the signal voltage of the intake air temperature sensor) is indicated.</li> </ul>	
START SIGNAL [ON/OFF]	×	×	<ul style="list-style-type: none"> <li>Indicates start signal status [ON/OFF] computed by the ECM according to the signals of engine speed and battery voltage.</li> </ul>	<ul style="list-style-type: none"> <li>After starting the engine, [OFF] is displayed regardless of the starter signal.</li> </ul>
CLSD THL POS [ON/OFF]	×	×	<ul style="list-style-type: none"> <li>Indicates idle position [ON/OFF] computed by ECM according to the accelerator pedal position sensor signal.</li> </ul>	

# TROUBLE DIAGNOSIS

[VQ TYPE 2]

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	Description	Remarks
AIR COND SIG [ON/OFF]	×	×	<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition of the air conditioner switch as determined by the air conditioner signal.</li> </ul>	
P/N POSI SW [ON/OFF]	×	×	<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from the park/neutral position (PNP) switch signal.</li> </ul>	
PW/ST SIGNAL [ON/OFF]	×	×	<ul style="list-style-type: none"> <li>[ON/OFF] condition of the power steering system (determined by the signal voltage of the power steering pressure sensor signal) is indicated.</li> </ul>	
LOAD SIGNAL [ON/OFF]	×	×	<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from the electrical load signal.</li> <li>ON: Rear window defogger switch is ON and/or lighting switch is in 2nd position.</li> <li>OFF: Both rear window defogger switch and lighting switch are OFF.</li> </ul>	
IGNITION SW [ON/OFF]	×		<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from ignition switch signal.</li> </ul>	
HEATER FAN SW [ON/OFF]	×		<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from the heater fan switch signal.</li> </ul>	
BRAKE SW [ON/OFF]	×		<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from the stop lamp switch signal.</li> </ul>	
INJ PULSE-B1 [msec]		×	<ul style="list-style-type: none"> <li>Indicates the actual fuel injection pulse width compensated by ECM according to the input signals.</li> </ul>	<ul style="list-style-type: none"> <li>When the engine is stopped, a certain computed value is indicated.</li> </ul>
INJ PULSE-B2 [msec]				
IGN TIMING [BTDC]		×	<ul style="list-style-type: none"> <li>Indicates the ignition timing computed by ECM according to the input signals.</li> </ul>	<ul style="list-style-type: none"> <li>When the engine is stopped, a certain value is indicated.</li> </ul>
PURG VOL C/V [%]			<ul style="list-style-type: none"> <li>Indicates the EVAP canister purge volume control solenoid valve control value computed by the ECM according to the input signals.</li> <li>The opening becomes larger as the value increases.</li> </ul>	
INT/V TIM (B1) [°CA]			<ul style="list-style-type: none"> <li>Indicates [°CA] of intake camshaft advanced angle.</li> </ul>	
INT/V TIM (B2) [°CA]				
INT/V SOL (B1) [%]			<ul style="list-style-type: none"> <li>The control condition of the intake valve timing control solenoid valve (determined by ECM according to the input signals) is indicated.</li> <li>The advance angle becomes larger as the value increases.</li> </ul>	
INT/V SOL (B2) [%]				
VIAS S/V [ON/OFF]			<ul style="list-style-type: none"> <li>The control condition of the VIAS control solenoid valve (determined by ECM according to the input signals) is indicated.</li> <li>ON: VIAS control solenoid valve is operating.</li> <li>OFF: VIAS control solenoid valve is not operating.</li> </ul>	
AIR COND RLY [ON/OFF]		×	<ul style="list-style-type: none"> <li>The air conditioner relay control condition (determined by ECM according to the input signals) is indicated.</li> </ul>	

# TROUBLE DIAGNOSIS

[VQ TYPE 2]

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	Description	Remarks
FUEL PUMP RLY [ON/OFF]		×	<ul style="list-style-type: none"> <li>Indicates the fuel pump relay control condition determined by ECM according to the input signals.</li> </ul>	A EC
THRTL RELAY [ON/OFF]		×	<ul style="list-style-type: none"> <li>Indicates the throttle control motor relay control condition determined by the ECM according to the input signals.</li> </ul>	C
COOLING FAN [HI/LOW/OFF]		×	<ul style="list-style-type: none"> <li>The control condition of the cooling fan (determined by ECM according to the input signals) is indicated. HI: High speed operation LOW: Low speed operation OFF: Stop</li> </ul>	D E
HO2S2 HTR (B1) [ON/OFF]			<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition of heated oxygen sensor 2 heater determined by ECM according to the input signals.</li> </ul>	F
HO2S2 HTR (B2) [ON/OFF]				
I/P PULLY SPD [rpm]			<ul style="list-style-type: none"> <li>Indicates the engine speed computed from the turbine revolution sensor signal.</li> </ul>	G
VEHICLE SPEED [km/h] or [MPH]			<ul style="list-style-type: none"> <li>Indicates the vehicle speed computed from the revolution sensor signal.</li> </ul>	H
IDL A/V LEARN [YET/CMPLT]			<ul style="list-style-type: none"> <li>Display the condition of idle air volume learning YET: Idle Air Volume Learning has not been performed yet. CMPLT: Idle Air Volume Learning has already been performed successfully.</li> </ul>	I
TRVL AFTER MIL [km] or [mile]			<ul style="list-style-type: none"> <li>Distance traveled while MIL is activated.</li> </ul>	J
A/F S1 HTR (B1) [%]			<ul style="list-style-type: none"> <li>Air fuel ratio (A/F) sensor 1 heater control value computed by ECM according to the input signals.</li> <li>The current flow to the heater becomes larger as the value increases.</li> </ul>	K
A/F S1 HTR (B2) [%]				
AC PRESS SEN [V]			<ul style="list-style-type: none"> <li>The signal voltage from the refrigerant pressure sensor is displayed.</li> </ul>	L
VHCL SPEED SE [km/h] or [mph]			<ul style="list-style-type: none"> <li>The vehicle speed computed from the vehicle speed signal sent from TCM is displayed.</li> </ul>	M
SET VHCL SPD [km/h] or [mph]			<ul style="list-style-type: none"> <li>The preset vehicle speed is displayed.</li> </ul>	
MAIN SW [ON/OFF]			<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from MAIN switch signal.</li> </ul>	
CANCEL SW [ON/OFF]			<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from CANCEL switch signal.</li> </ul>	
RESUME/ACC SW [ON/OFF]			<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from RESUME/ACCELERATE switch signal.</li> </ul>	
SET SW [ON/OFF]			<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from SET/COAST switch signal.</li> </ul>	
BRAKE SW1 [ON/OFF]			<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from ASCD brake switch signal.</li> </ul>	
BRAKE SW2 [ON/OFF]			<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition of stop lamp switch signal.</li> </ul>	

# TROUBLE DIAGNOSIS

[VQ TYPE 2]

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	Description	Remarks
VHCL SPD CUT [NON/CUT]			<ul style="list-style-type: none"> <li>Indicates the vehicle cruise condition. NON: Vehicle speed is maintained at the ASCD set speed. CUT: Vehicle speed increased to excessively high compared with the ASCD set speed, and ASCD operation is cut off.</li> </ul>	
LO SPEED CUT [NON/CUT]			<ul style="list-style-type: none"> <li>Indicates the vehicle cruise condition. NON: Vehicle speed is maintained at the ASCD set speed. CUT: Vehicle speed decreased to excessively low compared with the ASCD set speed, and ASCD operation is cut off.</li> </ul>	
AT OD MONITOR [ON/OFF]			<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition of A/T O/D according to the input signal from the TCM.</li> </ul>	
AT OD CANCEL [ON/OFF]			<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition of A/T O/D cancel signal sent from the TCM.</li> </ul>	
CRUISE LAMP [ON/OFF]			<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition of CRUISE lamp determined by the ECM according to the input signals.</li> </ul>	
SET LAMP [ON/OFF]			<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition of SET lamp determined by the ECM according to the input signals.</li> </ul>	
Voltage [V]			<ul style="list-style-type: none"> <li>Voltage, frequency, duty cycle or pulse width measured by the probe.</li> </ul>	<ul style="list-style-type: none"> <li>Only # is displayed if item is unable to be measured.</li> <li>Figures with #s are temporary ones. They are the same figures as an actual piece of data which was just previously measured.</li> </ul>
Frequency [msec], [Hz] or [%]				
DUTY-HI				
DUTY-LOW				
PLS WIDTH-HI				
PLS WIDTH-LOW				

**NOTE:**

Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

## DATA MONITOR (SPEC) MODE

### Monitored Item

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	Description	Remarks
ENG SPEED [rpm]	×	×	<ul style="list-style-type: none"> <li>Indicates the engine speed computed from the signal of the crankshaft position sensor (POS) and camshaft position sensor (PHASE).</li> </ul>	
MAS A/F SE-B1 [V]	×	×	<ul style="list-style-type: none"> <li>The signal voltage of the mass air flow sensor specification is displayed.</li> </ul>	<ul style="list-style-type: none"> <li>When engine is running specification range is indicated.</li> </ul>
B/FUEL SCHDL [msec]		×	<ul style="list-style-type: none"> <li>"Base fuel schedule" indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction.</li> </ul>	<ul style="list-style-type: none"> <li>When engine is running specification range is indicated.</li> </ul>
A/F ALPHA-B1 [%] A/F ALPHA-B2 [%]		×	<ul style="list-style-type: none"> <li>The mean value of the air-fuel ratio feedback correction factor per cycle is indicated.</li> </ul>	<ul style="list-style-type: none"> <li>When engine is running specification range is indicated.</li> <li>This data also includes the data for the air-fuel ratio learning control.</li> </ul>



# TROUBLE DIAGNOSIS

[VQ TYPE 2]

**NOTE:**

Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

## ACTIVE TEST MODE

### Test Item

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
FUEL INJECTION	<ul style="list-style-type: none"> <li>● Engine: Return to the original trouble condition</li> <li>● Change the amount of fuel injection using CONSULT-II.</li> </ul>	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> <li>● Harness and connectors</li> <li>● Fuel injector</li> <li>● Air fuel ratio (A/F) sensor 1</li> </ul>
IGNITION TIMING	<ul style="list-style-type: none"> <li>● Engine: Return to the original trouble condition</li> <li>● Timing light: Set</li> <li>● Retard the ignition timing using CONSULT-II.</li> </ul>	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> <li>● Perform Idle Air Volume Learning.</li> </ul>
POWER BALANCE	<ul style="list-style-type: none"> <li>● Engine: After warming up, idle the engine.</li> <li>● A/C switch: OFF</li> <li>● Shift lever: P or N (A/T), Neutral (M/T)</li> <li>● Cut off each fuel injector signal one at a time using CONSULT-II.</li> </ul>	Engine runs rough or dies.	<ul style="list-style-type: none"> <li>● Harness and connectors</li> <li>● Compression</li> <li>● Fuel injector</li> <li>● Power transistor</li> <li>● Spark plug</li> <li>● Ignition coil</li> </ul>
COOLING FAN*	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> <li>● Turn the cooling fan HI, LOW and OFF using CONSULT-II.</li> </ul>	Cooling fan moves and stops.	<ul style="list-style-type: none"> <li>● Harness and connectors</li> <li>● Cooling fan motor</li> <li>● IPDM E/R</li> </ul>
ENG COOLANT TEMP	<ul style="list-style-type: none"> <li>● Engine: Return to the original trouble condition</li> <li>● Change the engine coolant temperature using CONSULT-II.</li> </ul>	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> <li>● Harness and connectors</li> <li>● Engine coolant temperature sensor</li> <li>● Fuel injector</li> </ul>
FUEL PUMP RELAY	<ul style="list-style-type: none"> <li>● Ignition switch: ON (Engine stopped)</li> <li>● Turn the fuel pump relay ON and OFF using CONSULT-II and listen to operating sound.</li> </ul>	Fuel pump relay makes the operating sound.	<ul style="list-style-type: none"> <li>● Harness and connectors</li> <li>● Fuel pump relay</li> </ul>
VIAS SOL VALVE	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> <li>● Turn solenoid valve ON and OFF with CONSULT-II and listen for operating sound.</li> </ul>	Solenoid valve makes an operating sound.	<ul style="list-style-type: none"> <li>● Harness and connectors</li> <li>● Solenoid valve</li> </ul>
PURG VOL CONT/V	<ul style="list-style-type: none"> <li>● Engine: After warming up, run engine at 1,500 rpm.</li> <li>● Change the EVAP canister purge volume control solenoid valve opening percent using CONSULT-II.</li> </ul>	Engine speed changes according to the opening percent.	<ul style="list-style-type: none"> <li>● Harness and connectors</li> <li>● Solenoid valve</li> </ul>
V/T ASSIGN ANGLE	<ul style="list-style-type: none"> <li>● Engine: Return to the original trouble condition</li> <li>● Change intake valve timing using CONSULT-II.</li> </ul>	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> <li>● Harness and connectors</li> <li>● Intake valve timing control solenoid valve</li> </ul>

\*: Leaving cooling fan OFF with CONSULT-II while engine is running may cause the engine to overheat.

## REAL TIME DIAGNOSIS IN DATA MONITOR MODE (RECORDING VEHICLE DATA)

### Description

CONSULT-II has two kinds of triggers and they can be selected by touching "SETTING" in "DATA MONITOR" mode.


1. "AUTO TRIG" (Automatic trigger):

- The malfunction will be identified on the CONSULT-II screen in real time.

In other words, DTC/1st trip DTC and malfunction item will be displayed if the malfunction is detected by ECM.

At the moment a malfunction is detected by ECM, "MONITOR" in "DATA MONITOR" screen is changed to "Recording Data ... xx%" as shown at right, and the data after the malfunction detection is recorded. Then when the percentage reached 100%, "REAL-TIME DIAG" screen is displayed. If "STOP" is touched on the screen during "Recording Data ... xx%", "REAL-TIME DIAG" screen is also displayed.


The recording time after the malfunction detection and the recording speed can be changed by "TRIGGER POINT" and "Recording Speed". Refer to CONSULT-II OPERATION MANUAL.



2. "MANU TRIG" (Manual trigger):

- DTC/1st trip DTC and malfunction item will not be displayed automatically on CONSULT-II screen even though a malfunction is detected by ECM.

DATA MONITOR can be performed continuously even though a malfunction is detected.




## Operation

### 1. "AUTO TRIG"

- While trying to detect the DTC/1st trip DTC by performing the DTC Confirmation Procedure, be sure to select to "DATA MONITOR (AUTO TRIG)" mode. You can confirm the malfunction at the moment it is detected.
- While narrowing down the possible causes, CONSULT-II should be set in "DATA MONITOR (AUTO TRIG)" mode, especially in case the incident is intermittent. When you are inspecting the circuit by gently shaking (or twisting) the suspicious connectors, components and harness in the DTC Confirmation Procedure, the moment a malfunction is found the DTC/1st trip DTC will be displayed. (Refer to "INCIDENT SIMULATION TESTS" in [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#) .)

### 2. "MANU TRIG"

- If the malfunction is displayed as soon as "DATA MONITOR" is selected, reset CONSULT-II to "MANU TRIG". By selecting "MANU TRIG" you can monitor and store the data. The data can be utilized for further diagnosis, such as a comparison with the value for the normal operating condition.



PBIB0197E

## CONSULT-II Reference Value in Data Monitor

GBS000V5

**Remarks:**

- Specification data are reference values.
- Specification data are output/input values which are detected or supplied by the ECM at the connector.
- \* Specification data may not be directly related to their components signals/values/operations.  
i.e. Adjust ignition timing with a timing light before monitoring IGN TIMING, because the monitor may show the specification data in spite of the ignition timing not being adjusted to the specification data. This IGN TIMING monitors the data calculated by the ECM according to the signals input from the camshaft position sensor and other ignition timing related sensors.

MONITOR ITEM	CONDITION	SPECIFICATION
ENG SPEED	● Run engine and compare CONSULT-II value with the tachometer indication.	Almost the same speed as the tachometer indication.
MAS A/F SE-B1	See <a href="#">EC-667, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE"</a> .	
B/FUEL SCHDL	See <a href="#">EC-667, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE"</a> .	
A/F ALPHA-B1 A/F ALPHA-B2	See <a href="#">EC-667, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE"</a> .	
COOLAN TEMP/S	● Engine: After warming up	More than 70°C (158°F)
A/F SEN1 (B1) A/F SEN1 (B2)	● Engine: After warming up Maintaining engine speed at 2,000 rpm	Fluctuates around 1.5 V
HO2S2 (B1) HO2S2 (B2)	● Revving engine from idle to 3,000 rpm quickly after the following conditions are met. – Engine: After warming up – Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)	● Revving engine from idle to 3,000 rpm quickly after the following conditions are met. – Engine: After warming up – Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load	LEAN ↔ RICH
VHCL SPEED SE	● Turn drive wheels and compare CONSULT-II value with the speedometer indication.	Almost the same speed as the speedometer indication
BATTERY VOLT	● Ignition switch: ON (Engine stopped)	11 - 14V
ACCEL SEN 1 ACCEL SEN 2*	● Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released Accelerator pedal: Fully depressed
THRTL SEN 1 THRTL SEN 2*	● Ignition switch: ON (Engine stopped) ● Shift lever: D (A/T), 1st (M/T)	Accelerator pedal: Fully released Accelerator pedal: Fully depressed
START SIGNAL	● Ignition switch: ON → START → ON	OFF → ON → OFF
CLSD THL POS	● Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released Accelerator pedal: Slightly depressed
AIR COND SIG	● Engine: After warming up, idle the engine	Air conditioner switch: OFF Air conditioner switch: ON (Compressor operates.)
P/N POSI SW	● Ignition switch: ON	Shift lever: P or N (A/T), Neutral (M/T) Shift lever: Except above
PW/ST SIGNAL	● Engine: After warming up, idle the engine	Steering wheel: Not being turned Steering wheel: Being turned.
LOAD SIGNAL	● Ignition switch: ON	Rear window defogger switch is ON and/or lighting switch is in 2nd Rear window defogger switch and lighting switch is OFF
IGNITION SW	● Ignition switch: ON → OFF → ON	ON → OFF → ON

# TROUBLE DIAGNOSIS

[VQ TYPE 2]

MONITOR ITEM	CONDITION	SPECIFICATION	
HEATER FAN SW	● Engine: After warming up, idle the engine	Heater fan switch: ON	ON
		Heater fan switch: OFF	OFF
BRAKE SW	● Ignition switch: ON	Brake pedal: Fully released	OFF
		Brake pedal: Slightly depressed	ON
INJ PULSE-B1 INJ PULSE-B2	● Engine: After warming up ● Shift lever: P or N (A/T), Neutral (M/T) ● Air conditioner switch: OFF ● No load	Idle	2.0 - 3.0 msec
		2,000 rpm	1.9 - 2.9 msec
IGN TIMING	● Engine: After warming up ● Shift lever: P or N (A/T), Neutral (M/T) ● Air conditioner switch: OFF ● No load	Idle	13 - 18° BTDC
		2,000 rpm	25 - 45° BTDC
PURG VOL C/V	● Engine: After warming up ● Shift lever: P or N (A/T), Neutral (M/T) ● Air conditioner switch: OFF ● No load	Idle (Accelerator pedal is not depressed even slightly, after engine starting)	0%
		2,000 rpm	—
INT/V TIM (B1) INT/V TIM (B2)	● Engine: After warming up ● Shift lever: P or N (A/T), Neutral (M/T) ● Air conditioner switch: OFF ● No load	Idle	-5 - 5°C
		2,000 rpm	Approx. 0 - 30°C
INT/V SOL (B1) INT/V SOL (B2)	● Engine: After warming up ● Shift lever: P or N (A/T), Neutral (M/T) ● Air conditioner switch: OFF ● No load	Idle	0 - 2%
		2,000 rpm	Approx. 0 - 50%
VIAS S/V	● Engine: After warming up	2,200 - 3,300 rpm	ON
		Except above conditions	OFF
AIR COND RLY	● Engine: After warming up, idle the engine	Air conditioner switch: OFF	OFF
		Air conditioner switch: ON (Compressor operates)	ON
FUEL PUMP RLY	● For 1 second after turning ignition switch ON ● Engine running or cranking		ON
	● Except above conditions		OFF
THRTL RELAY	● Ignition switch: ON		ON
COOLING FAN	● Engine: After warming up, idle the engine ● Air conditioner switch: OFF	Engine coolant temperature: 97°C (207°F) or less	OFF
		Engine coolant temperature: Between 98°C (208°F) and 104°C (219°F)	LOW
		Engine coolant temperature: 105°C (221°F) or more	HI
HO2S2 HTR (B1) HO2S2 HTR (B2)	● Engine speed is below 3,600 rpm after the following conditions are met. - Engine: After warming up - Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load		ON
	● Engine speed: Above 3,600 rpm		OFF

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# TROUBLE DIAGNOSIS

**[VQ TYPE 2]**

MONITOR ITEM	CONDITION	SPECIFICATION	
I/P PULLY SPD	<ul style="list-style-type: none"> <li>Vehicle speed: More than 20 km/h (12 MPH)</li> </ul>	Almost the same speed as the speedometer indication	
VEHICLE SPEED	<ul style="list-style-type: none"> <li>Turn drive wheels and compare the CONSULT-II value with speedometer indication.</li> </ul>	Almost the same speed as the speedometer indication	
TRVL AFTER MIL	<ul style="list-style-type: none"> <li>Ignition switch: ON</li> </ul> Vehicle has traveled after MIL has turned ON.	0 - 65,535 km (0 - 40,723 mile)	
A/F S1 HTR (B1) A/F S1 HTR (B2)	<ul style="list-style-type: none"> <li>Engine: After warming up, idle the engine</li> </ul>	0 - 100%	
AC PRESS SEN	<ul style="list-style-type: none"> <li>Engine: Idle</li> <li>Both A/C switch and blower fan switch: ON (Compressor operates)</li> </ul>	1.0 - 4.0V	
VHCL SPEED SE	<ul style="list-style-type: none"> <li>Turn drive wheels and compare speedometer indication with the CONSULT-II value.</li> </ul>	Almost the same speed as the CONSULT-II value	
SET VHCL SPD	<ul style="list-style-type: none"> <li>Engine: Running</li> </ul> ASCD: Operating.	The preset vehicle speed is displayed.	
MAIN SW	<ul style="list-style-type: none"> <li>Ignition switch: ON</li> </ul>	MAIN switch: Pressed	ON
		MAIN switch: Released	OFF
CANCEL SW	<ul style="list-style-type: none"> <li>Ignition switch: ON</li> </ul>	CANCEL switch: Pressed	ON
		CANCEL switch: Released	OFF
RESUME/ACC SW	<ul style="list-style-type: none"> <li>Ignition switch: ON</li> </ul>	RESUME/ACCELERATE switch: Pressed	ON
		RESUME/ACCELERATE switch: Released	OFF
SET SW	<ul style="list-style-type: none"> <li>Ignition switch: ON</li> </ul>	SET/COAST switch: Pressed	ON
		SET/COAST switch: Released	OFF
BRAKE SW1	<ul style="list-style-type: none"> <li>Ignition switch: ON</li> </ul>	Brake pedal: Fully released (A/T) Clutch pedal and brake pedal: Fully released (M/T)	ON
		Brake pedal: Slightly depressed (A/T) Clutch pedal and/or brake pedal: Slightly depressed (M/T)	OFF
BRAKE SW2	<ul style="list-style-type: none"> <li>Ignition switch: ON</li> </ul>	Brake pedal: Fully released	OFF
		Brake pedal: Slightly depressed	ON
CRUISE LAMP	<ul style="list-style-type: none"> <li>Ignition switch: ON</li> </ul>	MAIN switch: pressed at the 1st time → at the 2nd time	ON → OFF
SET LAMP	<ul style="list-style-type: none"> <li>MAIN switch: ON</li> <li>When vehicle speed is between 40km/h (25MPH) and 175km/h (109MPH)</li> </ul>	ASCD: Operating	ON
		ASCD: Not operating	OFF


\*: Accelerator pedal position sensor 2 signal and throttle position sensor 2 signal are converted by ECM internally. Thus, they differ from ECM terminals voltage signal.

## Major Sensor Reference Graph in Data Monitor Mode

The following are the major sensor reference graphs in "DATA MONITOR" mode.


### CLSD THL POS, ACCEL SEN 1, THRTL SEN 1


Below is the data for "CLSD THL POS", "ACCEL SEN 1" and "THRTL SEN 1" when depressing the accelerator pedal with the ignition switch ON and with selector lever in D position (A/T), 1st position (M/T). The signal of "ACCEL SEN 1" and "THRTL SEN 1" should rise gradually without any intermittent drop or rise after "CLSD THL POS" is changed from ON to OFF.




### ENG SPEED, MAS A/F SE-B1, THRTL SEN 1, HO2S2 (B1), INJ PULSE-B1

Below is the data for "ENG SPEED", "MAS A/F SE-B1", "THRTL SEN 1", "HO2S2 (B1)" and "INJ PULSE-B1" when revving engine quickly up to 4,800 rpm under no load after warming up engine sufficiently. Each value is for reference, the exact value may vary.






- "THRTL SEN1" should increase while depressing the accelerator pedal and should decrease while releasing it.



- "HO2S2 (B1)" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.



- "INJ PULSE-B1" should increase when depressing the accelerator pedal and should decrease when the pedal is released.



TROUBLE DIAGNOSIS - SPECIFICATION VALUE

PFP:00031

Description

GBS000V7

The specification (SP) value indicates the tolerance of the value that is displayed in “DATA MONITOR (SPEC)” mode of CONSULT-II during normal operation of the Engine Control System. When the value in “DATA MONITOR (SPEC)” mode is within the SP value, the Engine Control System is confirmed OK. When the value in “DATA MONITOR (SPEC)” mode is NOT within the SP value, the Engine Control System may have one or more malfunctions.

The SP value is used to detect malfunctions that may affect the Engine Control System, but will not light the MIL.

The SP value will be displayed for the following three items:

- B/FUEL SCHDL (The fuel injection pulse width programmed into ECM prior to any learned on board correction)
- A/F ALPHA-B1/B2 (The mean value of air-fuel ratio feedback correction factor per cycle)
- MAS A/F SE-B1 (The signal voltage of the mass air flow sensor)

Testing Condition

GBS000V8

- Vehicle driven distance: More than 5,000 km (3,107 miles)
- Barometric pressure: 98.3 - 104.3 kPa (0.983 - 1.043 bar, 1.003 - 1.064 kg/cm<sup>2</sup> , 14.25 - 15.12 psi)
- Atmospheric temperature: 20 - 30°C (68 - 86°F)
- Engine coolant temperature: 75 - 95°C (167 - 203°F)
- Engine speed: Idle
- Transmission: Warmed-up
- A/T models: After the engine is warmed up to normal operating temperature, drive vehicle until “FLUID TEMP SE” (A/T fluid temperature sensor signal) indicates more than 60°C (140°F).
- M/T models: After the engine is warmed up to normal operating temperature, drive vehicle for 5 minutes.
- Electrical load: Not applied
- Rear window defogger switch, air conditioner switch, lighting switch are OFF. Steering wheel is straight ahead.


Inspection Procedure

GBS000V9

NOTE:

Perform “DATA MONITOR (SPEC)” mode in maximum scale display.

1. Perform [EC-608, "Basic Inspection"](#) .
2. Confirm that the testing conditions indicated above are met.
3. Select “B/FUEL SCHDL”, “A/F ALPHA-B1”, “A/F ALPHA-B2” and “MAS A/F SE-B1” in “DATA MONITOR (SPEC)” mode with CONSULT-II.
4. Make sure that monitor items are within the SP value.
5. If NG, go to [EC-668, "Diagnostic Procedure"](#) .




# TROUBLE DIAGNOSIS - SPECIFICATION VALUE

[VQ TYPE 2]

GBS000VA


## Diagnostic Procedure OVERALL SEQUENCE



PBIB2268E

# TROUBLE DIAGNOSIS - SPECIFICATION VALUE

[VQ TYPE 2]



A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

PBIB2548E


## DETAILED PROCEDURE

### 1. CHECK "A/F ALPHA-B1", "A/F ALPHA-B2"

1. Start engine.
2. Confirm that the testing conditions are met. Refer to [EC-667, "Testing Condition"](#) .
3. Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "DATA MONITOR (SPEC)" mode, and make sure that the each indication is within the SP value.

**NOTE:**

Check "A/F ALPHA-B1", "A/F ALPHA-B2" for approximately 1 minute because they may fluctuate. It is NG if the indication is out of the SP value even a little.



OK or NG


- OK >> GO TO 17.  
 NG (Less than the SP value)>>GO TO 2.  
 NG (More than the SP value)>>GO TO 3.

### 2. CHECK "B/FUEL SCHDL"

Select "B/FUEL SCHDL" in "DATA MONITOR (SPEC)" mode, and make sure that the indication is within the SP value.

OK or NG

- OK >> GO TO 4.  
 NG (More than the SP value)>>GO TO 19.




### 3. CHECK "B/FUEL SCHDL"

Select "B/FUEL SCHDL" in "DATA MONITOR (SPEC)" mode, and make sure that the indication is within the SP value.

OK or NG

- OK >> GO TO 6.  
 NG (More than the SP value)>>GO TO 6.  
 NG (Less than the SP value)>>GO TO 25.



### 4. CHECK "A/F ALPHA-B1", "A/F ALPHA-B2"

1. Stop the engine.
2. Disconnect PCV hose, and then plug it.
3. Start engine.
4. Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "DATA MONITOR (SPEC)" mode, and make sure that the each indication is within the SP value.

OK or NG

- OK >> GO TO 5.  
 NG >> GO TO 6.

**5. CHANGE ENGINE OIL**

1. Stop the engine.
2. Change engine oil.

**NOTE:**

This symptom may occur when a large amount of gasoline is mixed with engine oil because of driving conditions (such as when engine oil temperature does not rise enough since a journey distance is too short during winter). The symptom will not be detected after changing engine oil or changing driving condition.

>> **INSPECTION END**

**6. CHECK FUEL PRESSURE**

Check fuel pressure. (Refer to [EC-617, "Fuel Pressure Check"](#) .)

OK or NG

OK >> GO TO 9.

NG (Fuel pressure is too high)>>Replace fuel pressure regulator, refer to [EC-617, "Fuel Pressure Check"](#) .  
GO TO 8.

NG (Fuel pressure is too low)>>GO TO 7.

**7. DETECT MALFUNCTIONING PART**

1. Check the following.
  - Clogged and bent fuel hose and fuel tube
  - Clogged fuel filter
  - Fuel pump and its circuit (Refer to [EC-936](#) .)
2. If NG, repair or replace the malfunctioning part. (Refer to [EC-617](#) .)  
If OK, replace fuel pressure regulator.

>> GO TO 8.

**8. CHECK "A/F ALPHA-B1", "A/F ALPHA-B2"**

1. Start engine.
2. Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "DATA MONITOR (SPEC)" mode, and make sure that the each indication is within the SP value.

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 9.

**9. PERFORM POWER BALANCE TEST**

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Make sure that the each cylinder produces a momentary engine speed drop.

OK or NG

OK >> GO TO 12.

NG >> GO TO 10.

ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0133E

---

## 10. DETECT MALFUNCTIONING PART

---

1. Check the following.
  - Ignition coil and its circuit (Refer to [EC-964](#) .)
  - Fuel injector and its circuit (Refer to [EC-929](#) .)
  - Intake air leakage
  - Low compression pressure (Refer to [EM-91, "CHECKING COMPRESSION PRESSURE"](#) .)
2. If NG, repair or replace the malfunctioning part.  
If OK, replace fuel injector. (It may be caused by leakage from fuel injector or clogging.)

>> GO TO 11.

---

## 11. CHECK "A/F ALPHA-B1", "A/F ALPHA-B2"

---

1. Start engine.
2. Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "DATA MONITOR (SPEC)" mode, and make sure that the each indication is within the SP value.

OK or NG

OK >> **INSPECTION END**  
NG >> GO TO 12.

---

## 12. CHECK A/F SENSOR 1 FUNCTION

---

Perform all DTC Confirmation Procedure related with A/F sensor 1.

- For DTC P1271, P1281, refer to [EC-810, "DTC Confirmation Procedure"](#) .
- For DTC P1272, P1282, refer to [EC-819, "DTC Confirmation Procedure"](#) .
- For DTC P1276, P1286, refer to [EC-828, "Overall Function Check"](#) .

OK or NG

OK >> GO TO 15.  
NG >> GO TO 13.

---

## 13. CHECK A/F SENSOR 1 CIRCUIT

---

Perform Diagnostic Procedure according to corresponding DTC.

>> GO TO 14.

---

## 14. CHECK "A/F ALPHA-B1", "A/F ALPHA-B2"

---

1. Start engine.
2. Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "DATA MONITOR (SPEC)" mode, and make sure that the each indication is within the SP value.

OK or NG

OK >> **INSPECTION END**  
NG >> GO TO 15.

---

## 15. DISCONNECT AND RECONNECT ECM HARNESS CONNECTOR

---

1. Stop the engine.
2. Disconnect ECM harness connector. Check pin terminal and connector for damage, and then reconnect it.

>> GO TO 16.

**16. CHECK "A/F ALPHA-B1", "A/F ALPHA-B2"**

1. Start engine.
2. Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "DATA MONITOR (SPEC)" mode, and make sure that the each indication is within the SP value.

OK or NG

OK >> **INSPECTION END**NG >> Detect malfunctioning part according to [EC-628, "Symptom Matrix Chart"](#) .**17. CHECK "B/FUEL SCHDL"**


Select "B/FUEL SCHDL" in "DATA MONITOR (SPEC)" mode, and make sure that the indication is within the SP value.

OK or NG

OK >> **INSPECTION END**

NG (More than the SP value)&gt;&gt;GO TO 18.

NG (Less than the SP value)&gt;&gt;GO TO 25.

**18. DETECT MALFUNCTIONING PART**

1. Check for the cause of large engine friction. Refer to the following.
  - Engine oil level is too high
  - Engine oil viscosity
  - Belt tension of power steering, alternator, A/C compressor, etc. is excessive
  - Noise from engine
  - Noise from transmission, etc.
2. Check for the cause of insufficient combustion. Refer to the following.
  - Valve clearance malfunction
  - Intake valve timing control function malfunction
  - Camshaft sprocket installation malfunction, etc.

&gt;&gt; Repair or replace malfunctioning part, and then GO TO 30.

**19. CHECK INTAKE SYSTEM**

Check for the cause of uneven air flow through mass air flow sensor. Refer to the following.

- Crushed air ducts
- Malfunctioning seal of air cleaner element
- Uneven dirt of air cleaner element
- Improper specification of intake air system

OK or NG

OK &gt;&gt; GO TO 21.

NG &gt;&gt; Repair or replace malfunctioning part, and then GO TO 20.

**20. CHECK "A/F ALPHA-B1", "A/F ALPHA-B2", AND "B/FUEL SCHDL"**

Select "A/F ALPHA-B1", "A/F ALPHA-B2", and "B/FUEL SCHDL" in "DATA MONITOR (SPEC)" mode, and make sure that the each indication is within the SP value.

OK or NG

OK >> **INSPECTION END**

NG ("B/FUEL SCHDL" is more, "A/F ALPHA-B1", "A/F ALPHA-B2" are less than the SP value)>>GO TO 21.

**21. DISCONNECT AND RECONNECT MASS AIR FLOW SENSOR HARNESS CONNECTOR**

1. Stop the engine.
2. Disconnect mass air flow sensor harness connector. Check pin terminal and connector for damage and then reconnect it again.

>> GO TO 22.

**22. CHECK "A/F ALPHA-B1", "A/F ALPHA-B2"**

1. Start engine.
2. Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "DATA MONITOR (SPEC)" mode, and make sure that the each indication is within the SP value.

OK or NG

OK >> 1. Detect malfunctioning part of mass air flow sensor circuit and repair it. Refer to [EC-694](#) .

2. GO TO 29.

NG >> GO TO 23.


**23. CHECK "MAS A/F SE-B1"**

Select "MAS A/F SE-B1" in "DATA MONITOR (SPEC)" mode, and make sure that the indication is within the SP value.

OK or NG

OK >> GO TO 24.

NG (More than the SP value)>>Replace mass air flow sensor, and then GO TO 29.

**24. REPLACE ECM**

1. Replace ECM.
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [BL-83, "ECM Re-communicating Function"](#) .
3. Perform [EC-614, "Accelerator Pedal Released Position Learning"](#) .
4. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
5. Perform [EC-614, "Idle Air Volume Learning"](#) .

>> GO TO 29.



## 25. CHECK INTAKE SYSTEM

Check for the cause of uneven air flow through mass air flow sensor. Refer to the following.

- Crushed air ducts
- Malfunctioning seal of air cleaner element
- Uneven dirt of air cleaner element
- Improper specification of intake air system

OK or NG

OK >> GO TO 27.

NG >> Repair or replace malfunctioning part, and then GO TO 26.

## 26. CHECK "B/FUEL SCHDL"

Select "B/FUEL SCHDL" in "DATA MONITOR (SPEC)" mode, and make sure that the indication is within the SP value.

OK or NG

OK >> **INSPECTION END**

NG (Less than the SP value)>>GO TO 27.


## 27. CHECK "MAS A/F SE-B1"

Select "MAS A/F SE-B1" in "DATA MONITOR (SPEC)" mode, and make sure that the indication is within the SP value.

OK or NG

OK >> GO TO 28.

NG (Less than the SP value)>>Replace mass air flow sensor, and then GO TO 30.



## 28. CHECK INTAKE SYSTEM

Check for the cause of air leak after the mass air flow sensor. Refer to the following.

- Disconnection, looseness, and cracks in air duct
- Looseness of oil filler cap
- Disconnection of oil level gauge
- Open stuck, breakage, hose disconnection, or cracks of PCV valve
- Disconnection or cracks of EVAP purge hose, open stuck of EVAP canister purge volume control solenoid valve
- Malfunctioning seal of rocker cover gasket
- Disconnection, looseness, or cracks of hoses, such as vacuum hose, connecting to intake air system parts
- Malfunctioning seal of intake air system, etc.

>> GO TO 30.

## 29. CHECK "A/F ALPHA-B1", "A/F ALPHA-B2", AND "B/FUEL SCHDL"

Select "A/F ALPHA-B1", "A/F ALPHA-B2", and "B/FUEL SCHDL" in "DATA MONITOR (SPEC)" mode, and make sure that the each indication is within the SP value.

OK or NG

OK >> **INSPECTION END**

NG >> Detect malfunctioning part according to [EC-628, "Symptom Matrix Chart"](#) .

---

## 30. CHECK "B/FUEL SCHDL"

---

Select "B/FUEL SCHDL" in "DATA MONITOR (SPEC)" mode, and then make sure that the indication is within the SP value.

OK or NG

OK >> **INSPECTION END**

NG >> Detect malfunctioning part according to [EC-628, "Symptom Matrix Chart"](#) .

## TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT

PFP:00006

## Description

GBS000VB

Intermittent incidents may occur. In many cases, the malfunction resolves itself (the part or circuit function returns to normal without intervention). It is important to realize that the symptoms described in the customer's complaint often do not recur on (1st trip) DTC visits. Realize also that the most frequent cause of intermittent incidents occurrences is poor electrical connections. Because of this, the conditions under which the incident occurred may not be clear. Therefore, circuit checks made as part of the standard diagnostic procedure may not indicate the specific malfunctioning area.

## Common Intermittent Incidents Report Situations

STEP in Work Flow	Situation
2	The CONSULT-II is used. The SELF-DIAG RESULTS screen shows time data other than [0] or [1t].
3 or 4	The symptom described by the customer does not recur.
5	(1st trip) DTC does not appear during the DTC Confirmation Procedure.
10	The Diagnostic Procedure for PXXXX does not indicate the malfunctioning area.

## Diagnostic Procedure

GBS000VC

## 1. INSPECTION START

Erase (1st trip) DTCs. Refer to [EC-604, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).

>> GO TO 2.

## 2. CHECK GROUND TERMINALS

Check ground terminals for corroding or loose connection.  
Refer to [EC-685, "Ground Inspection"](#).

OK or NG

OK >> GO TO 3.

NG >> Repair or replace.

## 3. SEARCH FOR ELECTRICAL INCIDENT

Perform [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#), "INCIDENT SIMULATION TESTS".

OK or NG

OK >> **INSPECTION END**

NG >> Repair or replace.

# POWER SUPPLY AND GROUND CIRCUIT

[VQ TYPE 2]

## POWER SUPPLY AND GROUND CIRCUIT



PFP:24110

### Wiring Diagram


GBS000VD

### EC-MAIN-01


— : DETECTABLE LINE FOR DTC  
 - - - : NON-DETECTABLE LINE FOR DTC



E12  
W H.S.



E20  
B H.S.



F4  
W

REFER TO THE FOLLOWING.  
 (M91) - SUPER MULTIPLE JUNCTION (SMJ)  
 (M88) - FUSE BLOCK - JUNCTION BOX (J/B)

# POWER SUPPLY AND GROUND CIRCUIT

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
109	R	Ignition switch	[Ignition switch: OFF]	0V
			[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14V)
111	BR	ECM relay (Self shut-off)	[Engine is running] [Ignition switch: OFF] ● For a few seconds after turning ignition switch OFF	0 - 1.5V
			[Ignition switch: OFF] ● More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14V)
119 120	R P	Power supply for ECM	[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14V)



A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# POWER SUPPLY AND GROUND CIRCUIT

[VQ TYPE 2]

EC-MAIN-02

— : DETECTABLE LINE FOR DTC  
 - - - : NON-DETECTABLE LINE FOR DTC



# POWER SUPPLY AND GROUND CIRCUIT

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
1	B	ECM ground	<b>[Engine is running]</b> ● Idle speed	Body ground
115 116	B B	ECM ground	<b>[Engine is running]</b> ● Idle speed	Body ground

## Diagnostic Procedure

GBS000VE

### 1. INSPECTION START

Start engine.

**Is engine running?**

Yes or No

Yes >> GO TO 8.

No >> GO TO 2.

### 2. CHECK ECM POWER SUPPLY CIRCUIT-I


1. Turn ignition switch OFF and then ON.
2. Check voltage between ECM terminal 109 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

OK >> GO TO 4.

NG >> GO TO 3.



### 3. DETECT MALFUNCTIONING PART


Check the following.

- Harness connectors M91, E101
- Fuse block (J/B) connector M88
- 10A fuse
- Harness for open or short between ECM and fuse

>> Repair harness or connectors.

## 4. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-685, "Ground Inspection"](#) .



← : Vehicle front

- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

### OK or NG

- OK >> GO TO 5.  
 NG >> Repair or replace ground connections.

## 5. CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT-I

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminals 1, 115, 116 and ground. Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to power.

### OK or NG

- OK >> GO TO 7.  
 NG >> GO TO 6.

## 6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F4, E9
- Harness for open or short between ECM and ground

>> Repair open circuit or short to power in harness or connectors.




**7. CHECK ECM POWER SUPPLY CIRCUIT-II**

1. Reconnect ECM harness connector.
2. Turn ignition switch ON.
3. Check voltage between IPDM E/R connector E12 terminal 3 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> Go to [EC-964, "IGNITION SIGNAL"](#).
- NG >> GO TO 8.




**8. CHECK ECM POWER SUPPLY CIRCUIT-III**

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON and then OFF.
3. Check voltage between ECM terminals 119, 120 and ground with CONSULT-II or tester.

**Voltage: After turning ignition switch OFF, battery voltage will exist for a few seconds, then drop approximately 0V.**

OK or NG

- OK >> GO TO 13.
- NG (Battery voltage does not exist.)>>GO TO 9.
- NG (Battery voltage exists for more than a few seconds.)>>GO TO 11.




**9. CHECK ECM POWER SUPPLY CIRCUIT-IV**

Check voltage between ECM terminal 111 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 10.
- NG >> GO TO 11.



**10. CHECK ECM POWER SUPPLY CIRCUIT-V**

1. Disconnect ECM harness connector.
2. Disconnect IPDM E/R harness connector E12.
3. Check harness continuity between ECM terminals 119, 120 and IPDM E/R terminal 4. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 16.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

## 11. CHECK ECM POWER SUPPLY CIRCUIT-VI

1. Disconnect ECM harness connector.
2. Disconnect IPDM E/R harness connector E12.
3. Check harness continuity between ECM terminal 111 and IPDM E/R terminal 7.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 12.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 12. CHECK 20A FUSE

1. Disconnect 20 A fuse from IPDM E/R.
2. Check 20A fuse.


OK or NG

OK >> GO TO 16.

NG >> Replace 20A fuse.

## 13. CHECK GROUND CONNECTIONS

1. Loosen and retighten three ground screws on the body. Refer to [EC-685, "Ground Inspection"](#).



← : Vehicle front

1. Body ground E21

2. ECM

3. Body ground E41

4. A/C high-pressure service valve

5. ABS actuator and electric unit  
(control unit)

6. Body ground E61

OK or NG

OK >> GO TO 14.

NG >> Repair or replace ground connections.

## 14. CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT-II

1. Check harness continuity between ECM terminals 1, 115, 116 and ground.  
Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to power.

OK or NG

OK >> GO TO 16.

NG >> GO TO 15.

## 15. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F4, E9
- Harness for open or short between ECM and ground

>> Repair open circuit or short to power in harness or connectors.

## 16. CHECK INTERMITTENT INCIDENT

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

OK >> Replace IPDM E/R.

NG >> Repair open circuit or short to power in harness or connectors.

### Ground Inspection

GBS000VF


Ground connections are very important to the proper operation of electrical and electronic circuits. Ground connections are often exposed to moisture, dirt and other corrosive elements. The corrosion (rust) can become an unwanted resistance. This unwanted resistance can change the way a circuit works.

Electronically controlled circuits are very sensitive to proper grounding. A loose or corroded ground can drastically affect an electronically controlled circuit. A poor or corroded ground can easily affect the circuit. Even when the ground connection looks clean, there can be a thin film of rust on the surface.

When inspecting a ground connection follow these rules:

- Remove the ground bolt or screw.
- Inspect all mating surfaces for tarnish, dirt, rust, etc.
- Clean as required to assure good contact.
- Reinstall bolt or screw securely.
- Inspect for "add-on" accessories which may be interfering with the ground circuit.
- If several wires are crimped into one ground eyelet terminal, check for proper crimps. Make sure all of the wires are clean, securely fastened and providing a good ground path. If multiple wires are cased in one eyelet make sure no ground wires have excess wire insulation.

For detailed ground distribution information, refer to [PG-27, "Ground Distribution"](#) .



## DTC U1000, U1001 CAN COMMUNICATION LINE

PFP:23710

### Description

GBS000VG

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### On Board Diagnosis Logic

GBS000VH

**The MIL will not light up for these diagnoses.**

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
U1000 1000	CAN communication line	<ul style="list-style-type: none"> <li>● ECM cannot communicate to other control units.</li> <li>● ECM cannot communicate for more than the specified time.</li> </ul>	<ul style="list-style-type: none"> <li>● Harness or connectors (CAN communication line is open or shorted)</li> </ul>
U1001 1001			

### DTC Confirmation Procedure

GBS000VI

1. Turn ignition switch ON and wait at least 3 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. If 1st trip DTC is detected, go to [EC-688, "Diagnostic Procedure"](#).

# DTC U1000, U1001 CAN COMMUNICATION LINE




[VQ TYPE 2]



## Wiring Diagram

GBS000VJ

EC-CAN-01

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

-  : DETECTABLE LINE FOR DTC
-  : NON-DETECTABLE LINE FOR DTC
-  : DATA LINE



---

**Diagnostic Procedure**

GBS000VK

Go to [LAN-3, "Precautions When Using CONSULT-II"](#) .

DTC P0011, P0021 IVT CONTROL


PFP:23796

Description  
SYSTEM DESCRIPTION

GBS000VL

Sensor	Input signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS)	Engine speed and piston position	Intake valve timing control	Intake valve timing control solenoid valve
Camshaft position sensor (PHASE)			
Engine coolant temperature sensor	Engine coolant temperature		
Wheel sensor	Vehicle speed*		

\*: This signal is sent to the ECM through CAN communication line



This mechanism hydraulically controls cam phases continuously with the fixed operating angle of the intake valve.

The ECM receives signals such as crankshaft position, camshaft position, engine speed, and engine coolant temperature. Then, the ECM sends ON/OFF pulse duty signals to the intake valve timing control solenoid valve depending on driving status. This makes it possible to control the shut/open timing of the intake valve to increase engine torque in low/mid speed range and output in high-speed range.

CONSULT-II Reference Value in Data Monitor Mode

GBS000VM

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
INT/V TIM (B1) INT/V TIM (B2)	● Engine: After warming up ● Shift lever: P or N (A/T), Neutral (M/T) ● Air conditioner switch: OFF ● No load	Idle -5 - 5°C
	2,000 rpm	Approx. 0 - 30°C
INT/V SOL (B1) INT/V SOL (B2)	● Engine: After warming up ● Shift lever: P or N (A/T), Neutral (M/T) ● Air conditioner switch: OFF ● No load	Idle 0 - 2%
	2,000 rpm	Approx. 0 - 50%

## On Board Diagnosis Logic

The MIL will not light up for this diagnosis.

DTC No.	Trouble diagnosis name	Detecting condition	Possible cause
P0011 0011 (Bank 1)	Intake valve timing control performance	There is a gap between angle of target and phase-control angle degree.	<ul style="list-style-type: none"> <li>● Crankshaft position sensor (POS)</li> <li>● Camshaft position sensor (PHASE)</li> <li>● Intake valve timing control solenoid valve</li> <li>● Accumulation of debris to the signal pick-up portion of the camshaft</li> <li>● Timing chain installation</li> <li>● Foreign matter caught in the oil groove for intake valve timing control</li> </ul>
P0021 0021 (Bank 2)			

### FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode.

Detected items	Engine operating condition in fail-safe mode
Intake valve timing control	The signal is not energized to the solenoid valve and the valve control does not function.

### DTC Confirmation Procedure

#### CAUTION:

Always drive at a safe speed.

#### NOTE:

- If DTC P0011 or P0021 is displayed with DTC P1111 or P1136, first perform trouble diagnosis for DTC P1111 or P1136. Refer to [EC-761](#).
- If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10V and 16V at idle.

#### WITH CONSULT-II

1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to the normal operating temperature.
3. Maintain the following conditions for at least 6 consecutive seconds. Hold the accelerator pedal as steady as possible.

ENG SPEED	1,200 - 2,000 rpm
COOLAN TEMP/S	More than 60°C (140°F)
B/FUEL SCHDL	More than 3.5 msec
Selector lever	P or N position (A/T) Neutral position (M/T)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
B/FUEL SCHDL	XXX msec

PBIB0164E

4. Stop vehicle with engine running and let engine idle for 10 seconds.
5. If the 1st trip DTC is detected, go to [EC-691, "Diagnostic Procedure"](#).  
If the 1st trip DTC is not detected, go to next step.
6. Maintain the following conditions for at least 20 consecutive seconds.

ENG SPEED	1,700 - 3,175 rpm (A constant rotation is maintained.)
COOLAN TEMP/S	70 - 105°C (158 - 221°F)



# DTC P0011, P0021 IVT CONTROL

[VQ TYPE 2]

Selector lever	1st or 2nd position
Driving location uphill	Driving vehicle uphill (Increased engine load will help maintain the driving conditions required for this test.)

7. If the 1st trip DTC is detected, go to [EC-691, "Diagnostic Procedure"](#) .


## Overall Function Check


GBS000VP

Use this procedure to check the overall function of the intake valve timing control system. During this check, a 1st trip DTC might not be confirmed.

### ⊗ WITHOUT CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Turn ignition switch ON.
4. Set the tester probe between ECM terminal 11 [IVT control solenoid valve (bank 1) signal] or 10 [IVT control solenoid valve (bank 2) signal] and ground.
5. Start engine and let it idle.
6. Check the voltage under the following conditions.  
Verify that the oscilloscope screen shows the signal wave as shown below.

Conditions	Voltage
At idle	BATTERY VOLTAGE (11 - 14V)
2,500 rpm	7V - 12V ★  PBIB1790E



★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

7. If NG, go to [EC-691, "Diagnostic Procedure"](#) .

## Diagnostic Procedure


GBS000VQ

### 1. CHECK OIL PRESSURE WARNING LAMP

1. Start engine.
2. Check oil pressure warning lamp and confirm it is not illuminated.

#### OK or NG

- OK >> GO TO 2.  
KG >> Go to [LU-7, "ENGINE OIL PRESSURE CHECK"](#) .



### 2. CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE

Refer to [EC-692, "Component Inspection"](#) .

#### OK or NG

- OK >> GO TO 3.  
NG >> Replace intake valve timing control solenoid valve.

### 3. CHECK CRANKSHAFT POSITION SENSOR (POS)

Refer to [EC-731, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> Replace crankshaft position sensor (POS).

### 4. CHECK CAMSHAFT POSITION SENSOR (PHASE)

Refer to [EC-740, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 5.
- NG >> Replace camshaft position sensor (PHASE).


### 5. CHECK CAMSHAFT (INTAKE)

Check the following.

- Accumulation of debris to the signal plate of camshaft rear end
- Chipping signal plate of camshaft rear end

OK or NG

- OK >> GO TO 6.
- NG >> Remove debris and clean the signal plate of camshaft rear end or replace camshaft.



### 6. CHECK TIMING CHAIN INSTALLATION

Check service records for any recent repairs that may cause timing chain misaligned.

**Are there any service records that may cause timing chain misaligned?**

Yes or No

- Yes >> Check timing chain installation. Refer to [EM-53, "TIMING CHAIN"](#) .
- No >> GO TO 7.

### 7. CHECK LUBRICATION CIRCUIT

Refer to [EM-82, "Inspection of Camshaft Sprocket \(INT\) Oil Groove"](#) .

OK or NG

- OK >> GO TO 8.
- NG >> Clean lubrication line.

### 8. CHECK INTERMITTENT INCIDENT

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

For Wiring Diagram, refer to [EC-727](#) for CKP sensor (POS) and [EC-734](#) for CMP sensor (PHASE).

>> INSPECTION END

## Component Inspection INTAKE VALVE TIMING CONTROL SOLENOID VALVE

GBS000VR

1. Disconnect intake valve timing control solenoid valve harness connector.

# DTC P0011, P0021 IVT CONTROL

[VQ TYPE 2]

- Check resistance between intake valve timing control solenoid valve as follows.

Terminal	Resistance
1 and 2	7.0 - 7.7Ω [at 20°C (68°F)]
1 or 2 and ground	∞Ω (Continuity should not exist.)



If NG, replace intake valve timing control solenoid valve.  
If OK, go to next step.

- Remove intake valve timing control solenoid valve.
- Provide 12V DC between intake valve timing control solenoid valve terminals and then interrupt it. Make sure that the plunger moves as shown in the figure.

**CAUTION:**  
Do not apply 12V DC continuously for 5 seconds or more. Doing so may result in damage to the coil in intake valve timing control solenoid valve.

If NG, replace intake valve timing control solenoid valve.

**NOTE:**  
Always replace O-ring when intake valve timing control solenoid valve is removed.



GBS000VS

## Removal and Installation INTAKE VALVE TIMING CONTROL SOLENOID VALVE

Refer to [EM-53, "TIMING CHAIN"](#) .

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

**DTC P0102, P0103 MAF SENSOR**


PFP:22680

**Component Description**

GBS000VT

The mass air flow sensor (1) is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. The mass air flow sensor controls the temperature of the hot wire to a certain amount. The heat generated by the hot wire is reduced as the intake air flows around it. The more air, the greater the heat loss.

Therefore, electric current is supplied to hot wire is changed to maintain the temperature of the hot wire as air flow increases. The ECM detects the air flow by means of this current change.



**CONSULT-II Reference Value in Data Monitor Mode**

GBS000VU

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
MAS A/F SE-B1	See <a href="#">EC-667, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE"</a> .	

**On Board Diagnosis Logic**

GBS000VV

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0102 0102	Mass air flow sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> <li>● Harness or connectors (The sensor circuit is open or shorted.)</li> <li>● Intake air leaks</li> <li>● Mass air flow sensor</li> </ul>
P0103 0103	Mass air flow sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> <li>● Harness or connectors (The sensor circuit is open or shorted.)</li> <li>● Mass air flow sensor</li> </ul>

**FAIL-SAFE MODE**

When the malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.

Detected items	Engine operating condition in fail-safe mode
Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.

## DTC Confirmation Procedure

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### PROCEDURE FOR DTC P0102

#### With CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and wait at least 5 seconds.
4. If DTC is detected, go to [EC-697, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

#### Without CONSULT-II

1. Start engine and wait at least 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-697, "Diagnostic Procedure"](#) .

### PROCEDURE FOR DTC P0103

#### With CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-697, "Diagnostic Procedure"](#) .  
If DTC is not detected, go to next step.
5. Start engine and wait at least 5 seconds.
6. If DTC is detected, go to [EC-697, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

#### Without CONSULT-II

1. Start engine and wait at least 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-697, "Diagnostic Procedure"](#) .  
If DTC is not detected, go to next step.
5. Turn ignition switch OFF and wait at least 10 seconds.
6. Start engine and wait at least 5 seconds.
7. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
8. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
9. If DTC is detected, go to [EC-697, "Diagnostic Procedure"](#) .

# DTC P0102, P0103 MAF SENSOR



[VQ TYPE 2]

GBS000VX

## Wiring Diagram

### EC-MAFS-01

— : DETECTABLE LINE FOR DTC  
 - - - : NON-DETECTABLE LINE FOR DTC



MBWA1279E

# DTC P0102, P0103 MAF SENSOR

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
51	P	Mass air flow sensor	[Ignition switch: ON]	Approximately 0.4V
			[Engine is running] ● Warm-up condition ● Idle speed	0.9 - 1.2V
			[Engine is running] ● Warm-up condition ● Engine is revving from idle to about 4,000 rpm	0.9 - 1.2 to Approximately 2.4V (Check for linear voltage rise in response to engine being increased to about 4,000 rpm)
67	GR	Sensor ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
111	BR	ECM relay (Self shut-off)	[Engine is running] [Ignition switch: OFF] ● For a few seconds after turning ignition switch OFF	0 - 1.5V
			[Ignition switch: OFF] ● More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14V)
119 120	R P	Power supply for ECM	[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14V)

## Diagnostic Procedure

GBS000VY

### 1. INSPECTION START

Which malfunction (P0102 or P0103) is duplicated?

P0102 or P0103

- P0102 >> GO TO 2.
- P0103 >> GO TO 3.

### 2. CHECK INTAKE SYSTEM

Check the following for connection.


- Air duct
- Vacuum hoses
- Intake air passage between air duct and intake manifold

OK or NG

- OK >> GO TO 3.
- NG >> Reconnect the parts.

## 3. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-685, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

### OK or NG

- OK >> GO TO 4.  
 NG >> Repair or replace ground connections.

## 4. CHECK MAF SENSOR POWER SUPPLY CIRCUIT

1. Disconnect mass air flow (MAF) sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between MAF sensor terminal 5 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

### OK or NG

- OK >> GO TO 6.  
 NG >> GO TO 5.





## 5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E9, F4
- Harness for open or short between IPDM E/R and mass air flow sensor
- Harness for open or short between mass air flow sensor and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 6. CHECK MAF SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between MAF sensor terminal 4 and ECM terminal 67.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 7.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 7. CHECK MAF SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between MAF sensor terminal 3 and ECM terminal 51.  
Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 8.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 8. CHECK MASS AIR FLOW SENSOR

Refer to [EC-699, "Component Inspection"](#) .

OK or NG

OK >> GO TO 9.

NG >> Replace mass air flow sensor.

## 9. CHECK INTERMITTENT INCIDENT

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

### Component Inspection MASS AIR FLOW SENSOR

GBS000VZ

#### With CONSULT-II

1. Reconnect all harness connectors disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Connect CONSULT-II and select "DATA MONITOR" mode.


# DTC P0102, P0103 MAF SENSOR

[VQ TYPE 2]

4. Select "MAS A/F SE-B1" and check indication under the following conditions.

Condition	MAS A/F SE-B1 (V)
Ignition switch ON (Engine stopped.)	Approx. 0.4
Idle (Engine is warmed-up to normal operating temperature.)	0.9 - 1.2
Idle to about 4,000 rpm	0.9 - 1.2 to Approx. 2.4*

\*: Check for linear voltage rise in response to engine being increased to about 4,000 rpm.




5. If the voltage is out of specification, proceed the following.
- Check for the cause of uneven air flow through mass air flow sensor. Refer to following.
    - Crushed air ducts
    - Malfunctioning seal of air cleaner element
    - Uneven dirt of air cleaner element
    - Improper specification of intake air system parts
  - If NG, repair or replace malfunctioning part and perform step 2 to 4 again. If OK, go to next step.
6. Turn ignition switch OFF.
7. Disconnect mass air flow sensor harness connector and reconnect it again.
8. Perform step 2 to 4 again.
9. If NG, clean or replace mass air flow sensor.

## ⊗ Without CONSULT-II

- Reconnect all harness connectors disconnected.
- Start engine and warm it up to normal operating temperature.
- Check voltage between ECM terminal 51 (Mass air flow sensor signal) and ground.

Condition	Voltage V
Ignition switch ON (Engine stopped.)	Approx. 0.4
Idle (Engine is warmed-up to normal operating temperature.)	0.9 - 1.2
Idle to about 4,000 rpm	0.9 - 1.2 to Approx. 2.4*

\*: Check for linear voltage rise in response to engine being increased to about 4,000 rpm.



4. If the voltage is out of specification, proceed the following.
- Check for the cause of uneven air flow through mass air flow sensor. Refer to following.
    - Crushed air ducts
    - Malfunctioning seal of air cleaner element
    - Uneven dirt of air cleaner element
    - Improper specification of intake air system parts
  - If NG, repair or replace malfunctioning part and perform step 2 to 3 again. If OK, go to next step.
5. Turn ignition switch OFF.
6. Disconnect mass air flow sensor harness connector and reconnect it again.
7. Perform step 2 and 3 again.
8. If NG, clean or replace mass air flow sensor.

## Removal and Installation MASS AIR FLOW SENSOR

Refer to [EM-17, "AIR CLEANER AND AIR DUCT"](#) .

GBS000W0


## DTC P0117, P0118 ECT SENSOR

PFP:22630

### Component Description

GBS000W1


The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.



### <Reference data>

Engine coolant temperature °C (°F)	Voltage* V	Resistance kΩ
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	0.9	0.236 - 0.260

\*: This data is reference value and is measured between ECM terminal 73 (Engine coolant temperature sensor) and ground.



### CAUTION:

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

### On Board Diagnosis Logic

GBS000W2

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P0117 0117	Engine coolant temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> <li>● Harness or connectors (The sensor circuit is open or shorted.)</li> <li>● Engine coolant temperature sensor</li> </ul>
P0118 0118	Engine coolant temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

### FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode.

Detected items	Engine operating condition in fail-safe mode	
Engine coolant temperature sensor circuit	Engine coolant temperature will be determined by ECM based on the time after turning ignition switch ON or START. CONSULT-II displays the engine coolant temperature decided by ECM.	
	Condition	Engine coolant temperature decided (CONSULT-II display)
	Just as ignition switch is turned ON or START	40°C (104°F)
	More than approx. 4 minutes after ignition ON or START	80°C (176°F)
	Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)
When the fail-safe system for engine coolant temperature sensor is activated, the cooling fan operates while engine is running.		

**DTC Confirmation Procedure****NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**④ WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If 1st trip DTC is detected, go to [EC-704, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

**⊗ WITHOUT CONSULT-II**

1. Turn ignition switch ON and wait at least 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If 1st trip DTC is detected, go to [EC-704, "Diagnostic Procedure"](#) .

# DTC P0117, P0118 ECT SENSOR



[VQ TYPE 2]

## Wiring Diagram

GBS000W4

EC-ECTS-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC




A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

## Diagnostic Procedure

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-685, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

### 2. CHECK ECT SENSOR POWER SUPPLY CIRCUIT

1. Disconnect engine coolant temperature (ECT) sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between ECT sensor terminal 1 and ground with CONSULT-II or tester.

**Voltage: Approximately 5V**

#### OK or NG

- OK >> GO TO 3.  
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.



**3. CHECK ECT SENSOR GROUND CIRCUIT FOR OPEN AND SHORT**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECT sensor terminal 2 and ECM terminal 67.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**4. CHECK ENGINE COOLANT TEMPERATURE SENSOR**

Refer to [EC-705, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace engine coolant temperature sensor.

**5. CHECK INTERMITTENT INCIDENT**


Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

**Component Inspection  
ENGINE COOLANT TEMPERATURE SENSOR**

GBS000W6


1. Check resistance between engine coolant temperature sensor terminals 1 and 2 as shown in the figure.



**<Reference data>**

Engine coolant temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

2. If NG, replace engine coolant temperature sensor.



SEF012P

**Removal and Installation  
ENGINE COOLANT TEMPERATURE SENSOR**

GBS000W7

Refer to [CO-29, "WATER OUTLET AND WATER PIPING"](#) .

**DTC P0122, P0123 TP SENSOR**


PFP:16119

**Component Description**

GBS000W8

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



**CONSULT-II Reference Value in Data Monitor Mode**

GBS000W9

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
THRTL SEN 1 THRTL SEN 2*	<ul style="list-style-type: none"> <li>Ignition switch: ON (Engine stopped)</li> <li>Shift lever: D (A/T), 1st (M/T)</li> </ul>	Accelerator pedal: Fully released	More than 0.36V
		Accelerator pedal: Fully depressed	Less than 4.75V

\*: Throttle position sensor 2 signal is converted by ECM internally. Thus, it differs from ECM terminal voltage signal.

**On Board Diagnosis Logic**

GBS000WA

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0122 0122	Throttle position sensor 2 circuit low input	An excessively low voltage from the TP sensor 2 is sent to ECM.	<ul style="list-style-type: none"> <li>Harness or connectors (The TP sensor 2 circuit is open or shorted.) (The APP sensor 2 circuit is shorted.)</li> <li>Electric throttle control actuator (TP sensor 2)</li> <li>Accelerator pedal position sensor (APP sensor 2)</li> </ul>
P0123 0123	Throttle position sensor 2 circuit high input	An excessively high voltage from the TP sensor 2 is sent to ECM.	

**FAIL-SAFE MODE**

When the malfunction is detected, ECM enters fail-safe mode and the MIL lights up.

Engine operation condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.



**DTC Confirmation Procedure**

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

**WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-710, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

**WITHOUT CONSULT-II**

1. Start engine and let it idle for 1 second.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-710, "Diagnostic Procedure"](#) .

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# DTC P0122, P0123 TP SENSOR



[VQ TYPE 2]

GBS000WC

## Wiring Diagram

### EC-TPS2-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



MBWA1282E

# DTC P0122, P0123 TP SENSOR

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	W	Sensor power supply (Throttle position sensor)	<b>[Ignition switch: ON]</b>	Approximately 5V
50	W	Throttle position sensor 1	<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully released</li> </ul>	More than 0.36V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully depressed</li> </ul>	Less than 4.75V
66	B	Sensor ground (Throttle position sensor)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 0V
69	R	Throttle position sensor 2	<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully released</li> </ul>	Less than 4.75V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully depressed</li> </ul>	More than 0.36V
91	G	Sensor power supply (APP sensor 2)	<b>[Ignition switch: ON]</b>	Approximately 5V

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

## Diagnostic Procedure

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-685, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

### 2. CHECK THROTTLE POSITION SENSOR 2 POWER SUPPLY CIRCUIT-I

1. Disconnect electric throttle control actuator harness connector.
2. Turn ignition switch ON.




3. Check voltage between electric throttle control actuator terminal 2 and ground with CONSULT-II or tester.

**Voltage: Approximately 5V**

OK or NG

- OK >> GO TO 7.  
 NG >> GO TO 3.



**3. CHECK THROTTLE POSITION SENSOR 2 POWER SUPPLY CIRCUIT-II**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between electric throttle control actuator terminal 2 and ECM terminal 47.  
Refer to Wiring Diagram.

**Continuity should exist.**

OK or NG

- OK >> GO TO 4.  
NG >> Repair open circuit.

**4. CHECK THROTTLE POSITION SENSOR 2 POWER SUPPLY CIRCUIT-III**

Check harness for short to power and short to ground, between the following terminals.

ECM terminal	Sensor terminal	Reference Wiring Diagram
47	Electric throttle control actuator terminal 2	<a href="#">EC-708</a>
91	APP sensor terminal 1	<a href="#">EC-878</a>

OK or NG

- OK >> GO TO 5.  
NG >> Repair short to ground or short to power in harness or connectors.

**5. CHECK APP SENSOR**

Refer to [EC-882, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 11.  
NG >> GO TO 6.

**6. REPLACE ACCELERATOR PEDAL ASSEMBLY**

1. Replace accelerator pedal assembly.
2. Perform [EC-614, "Accelerator Pedal Released Position Learning"](#) .
3. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
4. Perform [EC-614, "Idle Air Volume Learning"](#) .

**>> INSPECTION END**

**7. CHECK THROTTLE POSITION SENSOR 2 GROUND CIRCUIT FOR OPEN AND SHORT**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between electric throttle control actuator terminal 4 and ECM terminal 66.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.  
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**8. CHECK THROTTLE POSITION SENSOR 2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

1. Check harness continuity between ECM terminal 69 and electric throttle control actuator terminal 3. Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 9.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**9. CHECK THROTTLE POSITION SENSOR**

Refer to [EC-712, "Component Inspection"](#) .

OK or NG

OK >> GO TO 11.

NG >> GO TO 10.

**10. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR**

1. Replace the electric throttle control actuator.
2. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-614, "Idle Air Volume Learning"](#) .

>> INSPECTION END

**11. CHECK INTERMITTENT INCIDENT**

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


**Component Inspection  
THROTTLE POSITION SENSOR**

GBS000WE

1. Reconnect all harness connectors disconnected.
2. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
3. Turn ignition switch ON.
4. Set selector lever to D position (A/T), 1st position (M/T).
5. Check voltage between ECM terminals 50 (TP sensor 1 signal), 69 (TP sensor 2 signal) and ground under the following conditions.

Terminal	Accelerator pedal	Voltage
50 (Throttle position sensor 1)	Fully released	More than 0.36V
	Fully depressed	Less than 4.75V
69 (Throttle position sensor 2)	Fully released	Less than 4.75V
	Fully depressed	More than 0.36V

6. If NG, replace electric throttle control actuator and go to the next step.
7. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
8. Perform [EC-614, "Idle Air Volume Learning"](#) .



**Removal and Installation  
ELECTRIC THROTTLE CONTROL ACTUATOR**

GBS000WF

Refer to [EM-18, "INTAKE MANIFOLD COLLECTOR"](#) .

**DTC P0222, P0223 TP SENSOR**


PF1:16119

**Component Description**

GBS000WG

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



**CONSULT-II Reference Value in Data Monitor Mode**

GBS000WH

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
THRTL SEN 1 THRTL SEN 2*	<ul style="list-style-type: none"> <li>Ignition switch: ON (Engine stopped)</li> <li>Shift lever: D (A/T), 1st (M/T)</li> </ul>	Accelerator pedal: Fully released	More than 0.36V
		Accelerator pedal: Fully depressed	Less than 4.75V

\*: Throttle position sensor 2 signal is converted by ECM internally. Thus, it differs from ECM terminal voltage signal.

**On Board Diagnosis Logic**

GBS000WI

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0222 0222	Throttle position sensor 1 circuit low input	An excessively low voltage from the TP sensor 1 is sent to ECM.	<ul style="list-style-type: none"> <li>Harness or connectors (The TP sensor 1 circuit is open or shorted.) (The APP sensor 2 circuit is shorted.)</li> <li>Electric throttle control actuator (TP sensor 1)</li> <li>Accelerator pedal position sensor. (APP sensor 2)</li> </ul>
P0223 0223	Throttle position sensor 1 circuit high input	An excessively high voltage from the TP sensor 1 is sent to ECM.	

**FAIL-SAFE MODE**

When the malfunction is detected, ECM enters fail-safe mode and the MIL lights up.

Engine operation condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

**DTC Confirmation Procedure**

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

**④ WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-717, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

**⊗ WITHOUT CONSULT-II**

1. Start engine and let it idle for 1 second.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-717, "Diagnostic Procedure"](#) .



# DTC P0222, P0223 TP SENSOR



[VQ TYPE 2]

GBS000WK

## Wiring Diagram

EC-TPS1-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



MBWA1288E

## DTC P0222, P0223 TP SENSOR

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**


**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	W	Sensor power supply (Throttle position sensor)	<b>[Ignition switch: ON]</b>	Approximately 5V
50	W	Throttle position sensor 1	<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Shift lever: D (A/T), 1st (M/T) ● Accelerator pedal: Fully released	More than 0.36V
			<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Shift lever: D (A/T), 1st (M/T) ● Accelerator pedal: Fully depressed	Less than 4.75V
66	B	Sensor ground (Throttle position sensor)	<b>[Engine is running]</b> ● <b>Warm-up condition</b> ● Idle speed	Approximately 0V
69	R	Throttle position sensor 2	<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Shift lever: D (A/T), 1st (M/T) ● Accelerator pedal: Fully released	Less than 4.75V
			<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Shift lever: D (A/T), 1st (M/T) ● Accelerator pedal: Fully depressed	More than 0.36V
91	G	Sensor power supply (APP sensor 2)	<b>[Ignition switch: ON]</b>	Approximately 5V

**Diagnostic Procedure**

**1. CHECK GROUND CONNECTIONS**

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-685, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

**2. CHECK THROTTLE POSITION SENSOR 1 POWER SUPPLY CIRCUIT-I**

1. Disconnect electric throttle control actuator harness connector.
2. Turn ignition switch ON.




3. Check voltage between electric throttle control actuator terminal 2 and ground with CONSULT-II or tester.

**Voltage: Approximately 5V**

**OK or NG**

- OK >> GO TO 7.  
 NG >> GO TO 3.



**3. CHECK THROTTLE POSITION SENSOR 1 POWER SUPPLY CIRCUIT-II**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between electric throttle control actuator terminal 2 and ECM terminal 47.  
Refer to Wiring Diagram.

**Continuity should exist.**

OK or NG

- OK >> GO TO 4.  
NG >> Repair open circuit.

**4. CHECK THROTTLE POSITION SENSOR 1 POWER SUPPLY CIRCUIT-III**

Check harness for short to power and short to ground, between the following terminals.

ECM terminal	Sensor terminal	Reference Wiring Diagram
47	Electric throttle control actuator terminal 2	<a href="#">EC-715</a>
91	APP sensor terminal 1	<a href="#">EC-878</a>

OK or NG

- OK >> GO TO 5.  
NG >> Repair short to ground or short to power in harness or connectors.

**5. CHECK APP SENSOR**

Refer to [EC-882, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 11.  
NG >> GO TO 6.

**6. REPLACE ACCELERATOR PEDAL ASSEMBLY**

1. Replace accelerator pedal assembly.
2. Perform [EC-614, "Accelerator Pedal Released Position Learning"](#) .
3. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
4. Perform [EC-614, "Idle Air Volume Learning"](#) .

**>> INSPECTION END**

**7. CHECK THROTTLE POSITION SENSOR 1 GROUND CIRCUIT FOR OPEN AND SHORT**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between electric throttle control actuator terminal 4 and ECM terminal 66.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.  
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**8. CHECK THROTTLE POSITION SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

1. Check harness continuity between ECM terminal 50 and electric throttle control actuator terminal 1. Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 9.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**9. CHECK THROTTLE POSITION SENSOR**

Refer to [EC-719, "Component Inspection"](#) .

OK or NG

OK >> GO TO 11.

NG >> GO TO 10.

**10. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR**

1. Replace the electric throttle control actuator.
2. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-614, "Idle Air Volume Learning"](#) .

>> INSPECTION END

**11. CHECK INTERMITTENT INCIDENT**

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


**Component Inspection  
THROTTLE POSITION SENSOR**

GBS000WM

1. Reconnect all harness connectors disconnected.
2. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
3. Turn ignition switch ON.
4. Set selector lever to D position (A/T), 1st position (M/T).
5. Check voltage between ECM terminals 50 (TP sensor 1 signal), 69 (TP sensor 2 signal) and ground under the following conditions.

Terminal	Accelerator pedal	Voltage
50 (Throttle position sensor 1)	Fully released	More than 0.36V
	Fully depressed	Less than 4.75V
69 (Throttle position sensor 2)	Fully released	Less than 4.75V
	Fully depressed	More than 0.36V

6. If NG, replace electric throttle control actuator and go to the next step.
7. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
8. Perform [EC-614, "Idle Air Volume Learning"](#) .



**Removal and Installation  
ELECTRIC THROTTLE CONTROL ACTUATOR**

GBS000WN

Refer to [EM-18, "INTAKE MANIFOLD COLLECTOR"](#) .

DTC P0327, P0328, P0332, P0333 KS


PFP:22060

Component Description

GBS000W0

The knock sensor (1) is attached to the cylinder block. It senses engine knocking using a piezoelectric element. A knocking vibration from the cylinder block is sensed as vibrational pressure. This pressure is converted into a voltage signal and sent to the ECM.

- ↵: Vehicle front



On Board Diagnosis Logic

GBS000WP

The MIL will not light up for these diagnoses.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0327 0327 (bank 1)	Knock sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> <li>• Harness or connectors (The sensor circuit is open or shorted.)</li> <li>• Knock sensor</li> </ul>
P0332 0332 (bank 2)			
P0328 0328 (bank 1)	Knock sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	
P0333 0333 (bank 2)			

DTC Confirmation Procedure

GBS000W0

NOTE:


If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

Ⓜ WITH CONSULT-II

1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and run it for at least 5 seconds at idle speed.
3. If 1st trip DTC is detected, go to [EC-722, "Diagnostic Procedure"](#)



⊗ WITHOUT CONSULT-II





1. Start engine and run it for at least 5 seconds at idle speed.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If 1st trip DTC is detected, go to [EC-722, "Diagnostic Procedure"](#).

Wiring Diagram

GBS000WR

EC-KS-01

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
15	W	Knock sensor (Bank 1)	[Engine is running] ● Idle speed	Approximately 2.5V
36	W	Knock sensor (Bank 2)		

**Diagnostic Procedure**

GBS000WS

**1. CHECK KNOCK SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT-I**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check resistance between ECM terminals 15, 36 and ground. Refer to Wiring Diagram.

**NOTE:**

It is necessary to use an ohmmeter which can measure more than 10 MΩ.

**Resistance: Approximately 532 - 588 kΩ [at 20°C (68°F)]**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 2.

**2. CHECK KNOCK SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT-II**


1. Disconnect knock sensor (1) harness connector.
  - ←: Vehicle front
2. Check harness continuity between ECM terminal 15 and knock sensor (bank1) terminal 1, ECM terminal 36 and knock sensor (bank 2) terminal 1. Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



**3. DETECT MALFUNCTIONING PART**

Check the following.

- Harness connectors F29, F151
- Harness for open or short between ECM and knock sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

**4. CHECK KNOCK SENSOR**

Refer to [EC-724, "Component Inspection"](#).


OK or NG

- OK >> GO TO 5.
- NG >> Replace knock sensor.



## 5. CHECK GROUND CONNECTIONS

- Loosen and retighten three ground screws on the body.  
Refer to [EC-685, "Ground Inspection"](#) .



← : Vehicle front

- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

### OK or NG

- OK >> GO TO 6.  
NG >> Repair or replace ground connections.

## 6. CHECK KNOCK SENSOR SHIELD CIRCUIT FOR OPEN AND SHORT

- Disconnect knock sensor harness connector.
- Check harness continuity between knock sensor terminal 2 and ground. Refer to Wiring Diagram.

**Continuity should exist.**

- Also check for short to power.

### OK or NG

- OK >> GO TO 8.  
NG >> GO TO 7.

## 7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F29, F151
- Harness connectors F2, E8
- Harness for open or short between knock sensor and ground

>> Repair open circuit or short power in harness or connectors.

## 8. CHECK INTERMITTENT INCIDENT

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

## Component Inspection

### KNOCK SENSOR

GBS000WT

Check resistance between knock sensor terminal 1 and ground.


**NOTE:**

It is necessary to use an ohmmeter which can measure more than 10 M $\Omega$ .

**Resistance: Approximately 532 - 588 k $\Omega$  [at 20°C (68°F)]**

**CAUTION:**

Do not use any knock sensors that have been dropped or physically damaged. Use only new ones.



SEF227W

## Removal and Installation

### KNOCK SENSOR

GBS000WU

Refer to [EM-107, "CYLINDER BLOCK"](#) .

# DTC P0335 CKP SENSOR (POS)

[VQ TYPE 2]

## DTC P0335 CKP SENSOR (POS)

PFP:23731

### Component Description

GBS000WV

The crankshaft position sensor (POS) is located on the oil pan facing the gear teeth (cogs) of the signal plate. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet and Hall IC.



When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.

ECM receives the signals as shown in the figure.



### CONSULT-II Reference Value in Data Monitor Mode

GBS000WV

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
ENG SPEED	<ul style="list-style-type: none"> <li>Run engine and compare CONSULT-II value with the tachometer indication.</li> </ul>	Almost the same speed as the tachometer indication.

### On Board Diagnosis Logic

GBS000WX

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0335 0335	Crankshaft position sensor (POS) circuit	<ul style="list-style-type: none"> <li>The crankshaft position sensor (POS) signal is not detected by the ECM during the first few seconds of engine cranking.</li> <li>The proper pulse signal from the crankshaft position sensor (POS) is not sent to ECM while the engine is running.</li> <li>The crankshaft position sensor (POS) signal is not in the normal pattern during engine running.</li> </ul>	<ul style="list-style-type: none"> <li>Harness or connectors (The sensor circuit is open or shorted)</li> <li>Crankshaft position sensor (POS)</li> <li>Signal plate</li> </ul>

## DTC Confirmation Procedure

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V with ignition switch ON.

#### ④ WITH CONSULT-II

1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
2. Crank engine for at least 2 seconds and run it for at least 5 seconds at idle speed.
3. If 1st trip DTC is detected, go to [EC-729, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

#### ⊗ WITHOUT CONSULT-II



1. Crank engine for at least 2 seconds and run it for at least 5 seconds at idle speed.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If 1st trip DTC is detected, go to [EC-729, "Diagnostic Procedure"](#).

# DTC P0335 CKP SENSOR (POS)

[VQ TYPE 2]

GBS000WZ

## Wiring Diagram



MBWA1290E



# DTC P0335 CKP SENSOR (POS)

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
13	G	Crankshaft position sensor (POS)	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	<p>Approximately 10V★</p>  <p style="text-align: right;">PBIB1041E</p>
			<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>Approximately 10V★</p>  <p style="text-align: right;">PBIB1042E</p>
111	BR	ECM relay (Self shut-off)	<p><b>[Engine is running]</b> <b>[Ignition switch: OFF]</b></p> <ul style="list-style-type: none"> <li>● For a few seconds after turning ignition switch OFF</li> </ul>	0 - 1.5V
			<p><b>[Ignition switch: OFF]</b></p> <ul style="list-style-type: none"> <li>● More than a few seconds after turning ignition switch OFF</li> </ul>	BATTERY VOLTAGE (11 - 14V)
119 120	R P	Power supply for ECM	<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-685, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

### 2. CHECK CRANKSHAFT POSITION (CKP) SENSOR (POS) POWER SUPPLY CIRCUIT

1. Disconnect crankshaft position (CKP) sensor (POS) harness connector.
2. Turn ignition switch ON.




3. Check voltage between CKP sensor (POS) terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

#### OK or NG

- OK >> GO TO 4.  
 NG >> GO TO 3.



## 3. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors F4, E9
- Harness for open or short between crankshaft position sensor (POS) and ECM
- Harness for open or short between crankshaft position sensor (POS) and IPDM E/R

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 4. CHECK CKP SENSOR (POS) GROUND CIRCUIT FOR OPEN AND SHORT

---

1. Turn ignition switch OFF.
2. Check harness continuity between CKP sensor (POS) terminal 3 and ground. Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.

## 5. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors F4, E9
- Harness for open or short between crankshaft position sensor (POS) and ground

>> Repair open circuit or short to power in harness or connectors.

## 6. CHECK CKP SENSOR (POS) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 13 and CKP sensor (POS) terminal 2. Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 7. CHECK CRANKSHAFT POSITION SENSOR (POS)

---

Refer to [EC-731, "Component Inspection"](#).

OK or NG

- OK >> GO TO 8.
- NG >> Replace crankshaft position sensor (POS).

## 8. CHECK GEAR TOOTH

---

Visually check for chipping signal plate gear tooth.

OK or NG

- OK >> GO TO 9.
- NG >> Replace the signal plate.



9. CHECK INTERMITTENT INCIDENT


Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

**Component Inspection**  
**CRANKSHAFT POSITION SENSOR (POS)**


GBS000X1

1. Loosen the fixing bolt of the sensor.
2. Disconnect crankshaft position sensor (POS) harness connector.
3. Remove the sensor.
4. Visually check the sensor for chipping.



5. Check resistance as shown in the figure.

Terminal No. (Polarity)	Resistance $\Omega$ [at 25°C (77°F)]
1 (+) - 2 (-)	Except 0 or $\infty$
1 (+) - 3 (-)	
2 (+) - 3 (-)	



**Removal and Installation**  
**CRANKSHAFT POSITION SENSOR (POS)**

GBS000X2

Refer to [EM-28, "OIL PAN AND OIL STRAINER"](#) .

## DTC P0340, P0345 CMP SENSOR (PHASE)

PFP:23731

### Component Description

GBS000X3

The camshaft position sensor (PHASE) senses the retraction of intake valve camshaft to identify a particular cylinder. The camshaft position sensor (PHASE) senses the piston position.

When the crankshaft position sensor (POS) system becomes inoperative, the camshaft position sensor (PHASE) provides various controls of engine parts instead, utilizing timing of cylinder identification signals.


The sensor consists of a permanent magnet and Hall IC.

When engine is running, the high and low parts of the teeth cause the gap with the sensor to change.


The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

ECM receives the signals as shown in the figure.



PBIB0562E



PBIB2744E

### CONSULT-II Reference Value in Data Monitor Mode

GBS000X4

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
ENG SPEED	<ul style="list-style-type: none"> <li>Run engine and compare CONSULT-II value with the tachometer indication.</li> </ul>	Almost the same speed as the tachometer indication.

### On Board Diagnosis Logic

GBS000X5

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0340 0340 (Bank 1)	Camshaft position sensor (PHASE) circuit	<ul style="list-style-type: none"> <li>The cylinder No. signal is not sent to ECM for the first few seconds during engine cranking.</li> </ul>	<ul style="list-style-type: none"> <li>Harness or connectors (The sensor circuit is open or shorted)</li> <li>Camshaft position sensor (PHASE)</li> <li>Camshaft (Intake)</li> <li>Starter motor (Refer to <a href="#">SC-30</a> .)</li> <li>Starting system circuit (Refer to <a href="#">SC-30</a> .)</li> <li>Dead (Weak) battery</li> </ul>
P0345 0345 (Bank 2)		<ul style="list-style-type: none"> <li>The cylinder No. signal is not sent to ECM during engine running.</li> <li>The cylinder No. signal is not in the normal pattern during engine running.</li> </ul>	

**DTC Confirmation Procedure****NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 10.5V with ignition switch ON.

**WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Crank engine for at least 2 seconds and run it for at least 5 seconds at idle speed.
4. If 1st trip DTC is detected, go to [EC-737, "Diagnostic Procedure"](#).  
If 1st trip DTC is not detected, go to next step.
5. Maintaining engine speed at more than 800 rpm for at least 5 seconds.
6. If 1st trip DTC is detected, go to [EC-737, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

**WITHOUT CONSULT-II**

1. Crank engine for at least 2 seconds and run it for at least 5 seconds at idle speed.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If 1st trip DTC is detected, go to [EC-737, "Diagnostic Procedure"](#).  
If 1st trip DTC is not detected, go to next step.
5. Start engine and maintaining engine speed at more than 800 rpm for at least 5 seconds.
6. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
7. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
8. If 1st trip DTC is detected, go to [EC-737, "Diagnostic Procedure"](#).

# DTC P0340, P0345 CMP SENSOR (PHASE)




[VQ TYPE 2]

GBS000X7

## Wiring Diagram BANK 1

EC-PHSB1-01

— : DETECTABLE LINE FOR DTC  
— : NON-DETECTABLE LINE FOR DTC



MBWA1291E



# DTC P0340, P0345 CMP SENSOR (PHASE)

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
33	L	Camshaft position sensor (PHASE) (Bank 1)	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	<p>1.0 - 4.0V★</p>  <p>PBIB1039E</p>
			<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>1.0 - 4.0V★</p>  <p>PBIB1040E</p>
111	BR	ECM relay (Self shut-off)	<p><b>[Engine is running]</b> <b>[Ignition switch: OFF]</b></p> <ul style="list-style-type: none"> <li>● For a few seconds after turning ignition switch OFF</li> </ul>	0 - 1.5V
			<p><b>[Ignition switch: OFF]</b></p> <ul style="list-style-type: none"> <li>● More than a few seconds after turning ignition switch OFF</li> </ul>	BATTERY VOLTAGE (11 - 14V)
119 120	R P	Power supply for ECM	<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)




★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# DTC P0340, P0345 CMP SENSOR (PHASE)

[VQ TYPE 2]

BANK 2

EC-PHSB2-01





# DTC P0340, P0345 CMP SENSOR (PHASE)

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
14	Y	Camshaft position sensor (PHASE) (Bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <b>NOTE:</b> The pulse cycle changes depending on rpm at idle	1.0 - 4.0V★  PBIB1039E
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed: 2,000 rpm</li> </ul>	1.0 - 4.0V★  PBIB1040E
111	BR	ECM relay (Self shut-off)	<b>[Engine is running]</b> <b>[Ignition switch: OFF]</b> <ul style="list-style-type: none"> <li>● For a few seconds after turning ignition switch OFF</li> </ul>	0 - 1.5V
			<b>[Ignition switch: OFF]</b> <ul style="list-style-type: none"> <li>● More than a few seconds after turning ignition switch OFF</li> </ul>	BATTERY VOLTAGE (11 - 14V)
119 120	R P	Power supply for ECM	<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

GBS000X8

### 1. CHECK STARTING SYSTEM

Turn ignition switch to START position.

**Does the engine turn over?**

**Does the starter motor operate?**


Yes or No

Yes >> GO TO 2.

No >> Check starting system. (Refer to [SC-30, "STARTING SYSTEM"](#) .)

## 2. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-685, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

### OK or NG

- OK >> GO TO 3.  
 NG >> Repair or replace ground connections.

## 3. CHECK CAMSHAFT POSITION (CMP) SENSOR (PHASE) POWER SUPPLY CIRCUIT

1. Disconnect camshaft position (CMP) sensor (PHASE) harness connector.
2. Turn ignition switch ON.




3. Check voltage between CMP sensor (PHASE) terminal 3 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

### OK or NG

- OK >> GO TO 5.  
 NG >> GO TO 4.





---

#### 4. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors E9, F4
- Harness for open or short between camshaft position sensor (PHASE) and ECM
- Harness for open or short between camshaft position sensor (PHASE) and IPDM E/R

>> Repair open circuit or short to ground or short to power in harness or connectors.

---

#### 5. CHECK CMP SENSOR (PHASE) GROUND CIRCUIT FOR OPEN AND SHORT

---

1. Turn ignition switch OFF.
2. Check harness continuity between CMP sensor (PHASE) terminal 1 and ground.

**Continuity should exist.**

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 7.
- NG >> GO TO 6.

---

#### 6. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors F4, E9
- Harness for open or short between CMP sensor (PHASE) and ground

>> Repair open circuit or short to power in harness or connectors.

---

#### 7. CHECK CMP SENSOR (PHASE) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 33 (bank 1) or 14 (bank 2) and CMP sensor (PHASE) terminal 2.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

---

#### 8. CHECK CAMSHAFT POSITION SENSOR (PHASE)

---

Refer to [EC-740, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 9.
- NG >> Replace camshaft position sensor (PHASE).

**9. CHECK CAMSHAFT (INTAKE)**


Check the following.

- Accumulation of debris to the signal plate of camshaft rear end
- Chipping signal plate of camshaft rear end

OK or NG

OK >> GO TO 10.

NG >> Remove debris and clean the signal plate of camshaft rear end or replace camshaft.



**10. CHECK INTERMITTENT INCIDENT**


Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

**Component Inspection  
CAMSHAFT POSITION SENSOR (PHASE)**


GBS000X9

1. Loosen the fixing bolt of the sensor.
2. Disconnect camshaft position sensor (PHASE) harness connector.
3. Remove the sensor.
4. Visually check the sensor for chipping.



5. Check resistance as shown in the figure.

Terminal No. (Polarity)	Resistance $\Omega$ [at 25°C (77°F)]
1 (+) - 2 (-)	Except 0 or $\infty$
1 (+) - 3 (-)	
2 (+) - 3 (-)	



**Removal and Installation  
CAMSHAFT POSITION SENSOR (PHASE)**

GBS000XA

Refer to [EM-73, "CAMSHAFT"](#) .


**DTC P0550 PSP SENSOR**

PFP:49763

**Component Description**

GBS000XB

Power steering pressure (PSP) sensor is installed to the power steering high-pressure tube and detects a power steering load. This sensor is a potentiometer which transforms the power steering load into output voltage, and emits the voltage signal to the ECM. The ECM controls the electric throttle control actuator and adjusts the throttle valve opening angle to increase the engine speed and adjusts the idle speed for the increased load.



**CONSULT-II Reference Value in Data Monitor Mode**

GBS000XC

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
PW/ST SIGNAL	● Engine: After warming up, idle the engine	Steering wheel: Not being turned.	OFF
		Steering wheel: Being turned.	ON

**On Board Diagnosis Logic**

GBS000XD

The MIL will not light up for this diagnosis.

**NOTE:**

If DTC P0550 is displayed with DTC P1229, first perform the trouble diagnosis for DTC P1229. Refer to [EC-803, "DTC P1229 SENSOR POWER SUPPLY"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0550 0550	Power steering pressure sensor circuit	An excessively low or high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> <li>● Harness or connectors (The sensor circuit is open or shorted)</li> <li>● Power steering pressure sensor</li> </ul>

**DTC Confirmation Procedure**


GBS000XE

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for at least 5 seconds.
4. If 1st trip DTC is detected, go to [EC-743, "Diagnostic Procedure"](#)



**WITHOUT CONSULT-II**

1. Start engine and let it idle for at least 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If 1st trip DTC is detected, go to [EC-743, "Diagnostic Procedure"](#).

# DTC P0550 PSP SENSOR



[VQ TYPE 2]

## Wiring Diagram

GBS000XF

EC-PS/SEN-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



MBWA1296E

# DTC P0550 PSP SENSOR

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
12	P	Power steering pressure sensor	[Engine is running] ● Steering wheel: Being turned	0.5 - 4.5V
			[Engine is running] ● Steering wheel: Not being turned	0.4 - 0.8V
67	GR	Sensor ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
68	V	Sensor power supply (Power steering pressure sensor)	[Ignition switch: ON]	Approximately 5V

## Diagnostic Procedure

GBS000XG

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-685, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

## 2. CHECK PSP SENSOR POWER SUPPLY CIRCUIT

1. Disconnect PSP sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between PSP sensor terminal 3 and ground with CONSULT-II or tester.

**Voltage: Approximately 5V**

OK or NG

- OK >> GO TO 3.  
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.



## 3. CHECK PSP SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between PSP sensor terminal 1 and ECM terminal 67. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and to power.

OK or NG

- OK >> GO TO 4.  
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 4. CHECK PSP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 12 and PSP sensor terminal 2.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.  
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 5. CHECK PSP SENSOR

Refer to [EC-745, "Component Inspection"](#).

OK or NG

- OK >> GO TO 6.  
 NG >> Replace PSP sensor.

**6. CHECK INTERMITTENT INCIDENT**

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

**Component Inspection  
POWER STEERING PRESSURE SENSOR**

GBS000XH

1. Reconnect all harness connectors disconnected.
2. Start engine and let it idle.
3. Check voltage between ECM terminal 12 and ground under the following conditions.

Condition	Voltage
Steering wheel: Being turned.	0.5 - 4.5V
Steering wheel: Not being turned.	0.4 - 0.8V



GBS000XI

**Removal and Installation  
POWER STEERING PRESSURE SENSOR**

Refer to [PS-33, "HYDRAULIC LINE"](#) .


**DTC P0605 ECM**

PFP:23710

**Component Description**

GBS000XJ

The ECM consists of a microcomputer and connectors for signal input and output and for power supply. The ECM controls the engine.



**On Board Diagnosis Logic**

GBS000XK

This self-diagnosis has one or two trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition		Possible cause
P0605 0605	Engine control module	A)	ECM calculation function is malfunctioning.	● ECM
		B)	ECM EEPROM system is malfunctioning.	
		C)	ECM self shut-off function is malfunctioning.	

**FAIL-SAFE MODE**

ECM enters fail-safe mode when the malfunction A is detected.

Detected items	Engine operation condition in fail-safe mode
Malfunction A	<ul style="list-style-type: none"> <li>● ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.</li> <li>● ECM deactivates ASCD operation.</li> </ul>

**DTC Confirmation Procedure**

GBS000XL

Perform **PROCEDURE FOR MALFUNCTION A** first. If the 1st trip DTC cannot be confirmed, perform **PROCEDURE FOR MALFUNCTION B**. If there is no malfunction on **PROCEDURE FOR MALFUNCTION B**, perform **PROCEDURE FOR MALFUNCTION C**.


**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**PROCEDURE FOR MALFUNCTION A**

**④ With CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. If 1st trip DTC is detected, go to [EC-748, "Diagnostic Procedure"](#)



**⊗ Without CONSULT-II**

1. Turn ignition switch ON.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.



3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If 1st trip DTC is detected, go to [EC-748, "Diagnostic Procedure"](#) .

**PROCEDURE FOR MALFUNCTION B**

**With CONSULT-II**

1. Turn ignition switch ON and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Turn ignition switch OFF, wait at least 10 seconds, and then turn ON.
4. If 1st trip DTC is detected, go to [EC-748, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

**Without CONSULT-II**

1. Turn ignition switch ON and wait at least 1 second.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If 1st trip DTC is detected, go to [EC-748, "Diagnostic Procedure"](#) .

**PROCEDURE FOR MALFUNCTION C**

**With CONSULT-II**

1. Turn ignition switch ON and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Turn ignition switch OFF, wait at least 10 seconds, and then turn ON.
4. Repeat step 3 for 32 times.
5. If 1st trip DTC is detected, go to [EC-748, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

**Without CONSULT-II**

1. Turn ignition switch ON and wait at least 1 second.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Repeat step 1 to 2 for 32 times.
4. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
5. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
6. If 1st trip DTC is detected, go to [EC-748, "Diagnostic Procedure"](#) .

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

## Diagnostic Procedure

### 1. INSPECTION START

#### With CONSULT-II

1. Turn ignition switch ON.
2. Select "SELF DIAG RESULTS" mode with CONSULT-II.
3. Touch "ERASE".
4. **Perform DTC Confirmation Procedure.**  
See [EC-746, "DTC Confirmation Procedure"](#) .
5. Is the 1st trip DTC P0605 displayed again?

#### Without CONSULT-II

1. Turn ignition switch ON.
2. Erase the Diagnostic Test Mode II (Self-diagnostic results) memory.  
Refer to [EC-606, "DIAGNOSTIC TEST MODE II — SELF-DIAGNOSTIC RESULTS"](#) .
3. **Perform DTC Confirmation Procedure.**  
See [EC-746, "DTC Confirmation Procedure"](#) .
4. Is the 1st trip DTC 0605 displayed again?

#### Yes or No

- Yes >> GO TO 2.  
No >> **INSPECTION END**

### 2. REPLACE ECM

1. Replace ECM.
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [BL-83, "ECM Re-communicating Function"](#) .
3. Perform [EC-614, "Accelerator Pedal Released Position Learning"](#) .
4. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
5. Perform [EC-614, "Idle Air Volume Learning"](#) .

>> **INSPECTION END**

# DTC P1031, P1032, P1051, P1052 A/F SENSOR 1 HEATER

[VQ TYPE 2]

## DTC P1031, P1032, P1051, P1052 A/F SENSOR 1 HEATER

PPF:22693

### Description SYSTEM DESCRIPTION

GBS000XN

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor (PHASE) Crankshaft position sensor (POS)	Engine speed	Air fuel ratio (A/F) sensor 1 heater control	Air fuel ratio (A/F) sensor 1 heater
Mass air flow sensor	Amount of intake air		

The ECM performs ON/OFF duty control of the air fuel ratio (A/F) sensor 1 heater corresponding to the engine operating condition to keep the temperature of air fuel ratio (A/F) sensor 1 element at the specified range.

### CONSULT-II Reference Value in Data Monitor Mode

GBS000XO

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
A/F S1 HTR (B1) A/F S1 HTR (B2)	● Engine: After warming up, idle the engine	0 - 100%

### On Board Diagnosis Logic

GBS000XP

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1031 1031 (Bank 1)	Air fuel ratio (A/F) sensor 1 heater control circuit low input	The current amperage in the air fuel ratio (A/F) sensor 1 heater circuit is out of the normal range. (An excessively low voltage signal is sent to ECM through the air fuel ratio (A/F) sensor 1 heater.)	<ul style="list-style-type: none"> <li>● Harness or connectors (The air fuel ratio (A/F) sensor 1 heater circuit is open or shorted.)</li> <li>● Air fuel ratio (A/F) sensor 1 heater</li> </ul>
P1051 1051 (Bank 2)			
P1032 1032 (Bank 1)	Air fuel ratio (A/F) sensor 1 heater control circuit high input	The current amperage in the air fuel ratio (A/F) sensor 1 heater circuit is out of the normal range. (An excessively high voltage signal is sent to ECM through the air fuel ratio (A/F) sensor 1 heater.)	<ul style="list-style-type: none"> <li>● Harness or connectors (The air fuel ratio (A/F) sensor 1 heater circuit is shorted.)</li> <li>● Air fuel ratio (A/F) sensor 1 heater</li> </ul>
P1052 1052 (Bank 2)			

### DTC Confirmation Procedure

GBS000XQ

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10.5V and 16V at idle.

With CONSULT-II

#### WITH CONSULT-II

1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and let it idle for at least 10 seconds.
3. If 1st trip DTC is detected, go to [EC-754, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

**⊗ WITHOUT CONSULT-II**

1. Start engine and let it idle for at least 10 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If 1st trip DTC is detected, go to [EC-754, "Diagnostic Procedure"](#) .






# DTC P1031, P1032, P1051, P1052 A/F SENSOR 1 HEATER

[VQ TYPE 2]

GBS000XR

## Wiring Diagram BANK 1

EC-AF1HB1-01



MBWA1297E


# DTC P1031, P1032, P1051, P1052 A/F SENSOR 1 HEATER

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
2	L	A/F sensor 1 heater (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 5V★  <small>PBIB1584E</small>
16	SB	A/F sensor 1 (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 3.1V
35	O			Approximately 2.6V
56	LG			Approximately 2.3V
75	P			Approximately 2.3V






★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# DTC P1031, P1032, P1051, P1052 A/F SENSOR 1 HEATER

[VQ TYPE 2]

BANK 2

EC-AF1HB2-01




# DTC P1031, P1032, P1051, P1052 A/F SENSOR 1 HEATER

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
24	G	A/F sensor 1 heater (Bank 2)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 5V★  PBIB1584E
57	GR	A/F sensor 1 (Bank 2)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 2.6V
58	O			Approximately 2.3V
76	V			Approximately 3.1V
77	Y			Approximately 2.3V


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

GBS000XS

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-685, "Ground Inspection"](#).



↔ : Vehicle front

- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |


**OK or NG**

- OK >> GO TO 2.  
NG >> Repair or Replace ground connections.



## 2. CHECK AIR FUEL RATIO (A/F) SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect air fuel ratio (A/F) sensor 1 harness connector.




2. Turn ignition switch ON.
3. Check voltage between air fuel ratio sensor 1 terminal 3 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



## 3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E8, F2
- IPDM E/R harness connector E12
- 10A fuse
- Harness for open or short between air fuel ratio sensor 1 and fuse

>> Repair or replace harness or connectors.

## 4. CHECK AIR FUEL RATIO (A/F) SENSOR 1 HEATER OUTPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 2 (bank 1) or 24 (bank 2) and air fuel ratio (A/F) sensor 1 terminal 4.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 5. CHECK AIR FUEL RATIO (A/F) SENSOR 1 HEATER

Refer to [EC-756, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 7.

## 6. CHECK INTERMITTENT INCIDENT

Perform [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> GO TO 7.
- NG >> Repair or replace.

## 7. REPLACE AIR FUEL RATIO (A/F) SENSOR 1

Replace air fuel ratio (A/F) sensor 1.

### CAUTION:

- Discard any air fuel ratio (A/F) sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new air fuel ratio (A/F) sensor, clean exhaust system threads using Heated Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

>> INSPECTION END

## Component Inspection AIR FUEL RATIO (A/F) SENSOR 1 HEATER

GBS000XT

Check resistance between terminals 3 and 4.

**Resistance: 2.3 - 4.3Ω [at 25°C (77°F)]**


Check continuity between terminals 3 and 1, 2, 5, 6, terminals 4 and 1, 2, 5, 6.

**Continuity should not exist.**

If NG, replace the air fuel ratio (A/F) sensor 1.

### CAUTION:

- Discard any air fuel ratio (A/F) sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new air fuel ratio (A/F) sensor, clean exhaust system threads using Heated Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.



PBIB1684E

## Removal and Installation AIR FUEL RATIO (A/F) SENSOR 1

GBS000XT

Refer to [EM-23, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#) .


## DTC P1065 ECM POWER SUPPLY

PFP:23710

### Component Description

GBS000XV

Battery voltage is supplied to the ECM even when the ignition switch is turned OFF for the ECM memory function of the DTC memory, the air-fuel ratio feedback compensation value memory, the idle air volume learning value memory, etc.



GBS000XW

### On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1065 1065	ECM power supply circuit	ECM back-up RAM system does not function properly.	<ul style="list-style-type: none"> <li>● Harness or connectors [ECM power supply (back-up) circuit is open or shorted.]</li> <li>● ECM</li> </ul>

### DTC Confirmation Procedure


GBS000XX

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### ④ WITH CONSULT-II

1. Turn ignition switch ON and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. Turn ignition switch OFF, wait at least 10 seconds, and then turn ON.
5. Repeat steps 3 and 4 for 4 times.
6. If 1st trip DTC is detected, go to [EC-759, "Diagnostic Procedure"](#)



#### ⊗ WITHOUT CONSULT-II

1. Start engine and let it idle for 1 second.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Repeat steps 1 to 2 for 4 times.
4. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
5. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
6. If 1st trip DTC is detected, go to [EC-759, "Diagnostic Procedure"](#) .

# DTC P1065 ECM POWER SUPPLY



[VQ TYPE 2]

## Wiring Diagram

GBS000XY

### EC-ECM/PW-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



MBWA1299E

# DTC P1065 ECM POWER SUPPLY

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.

## CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
121	V	Power supply for ECM (Back-up)	[Ignition switch: OFF]	BATTERY VOLTAGE (11 - 14V)

## Diagnostic Procedure

GBS000XZ


### 1. CHECK ECM POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check voltage between ECM terminal 121 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



### 2. DETECT MALFUNCTIONING PART

Check the following.

- 20A fuse
- IPDM E/R harness connector E30
- Harness for open or short between ECM and battery

>> Repair open circuit in harness or connectors.

### 3. CHECK INTERMITTENT INCIDENT

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace harness or connectors.

---

## 4. PERFORM DTC CONFIRMATION PROCEDURE

---

### With CONSULT-II

1. Turn ignition switch ON.
2. Select "SELF DIAG RESULTS" mode with CONSULT-II.
3. Touch "ERASE".
4. **Perform DTC Confirmation Procedure.**  
See [EC-757, "DTC Confirmation Procedure"](#) .
5. Is the 1st trip DTC P1065 displayed again?

### Without CONSULT-II

1. Turn ignition switch ON.
2. Erase the Diagnostic Test Mode II (Self-diagnostic results) memory.  
Refer to [EC-606, "DIAGNOSTIC TEST MODE II — SELF-DIAGNOSTIC RESULTS"](#)
3. **Perform DTC Confirmation Procedure.**  
See [EC-757, "DTC Confirmation Procedure"](#) .
4. Is the 1st trip DTC 1065 displayed again?

Yes or No

Yes >> GO TO 5.

No >> **INSPECTION END**

---

## 5. REPLACE ECM

---

1. Replace ECM.
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [BL-83, "ECM Re-communicating Function"](#) .
3. Perform [EC-614, "Accelerator Pedal Released Position Learning"](#) .
4. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
5. Perform [EC-614, "Idle Air Volume Learning"](#) .

>> **INSPECTION END**

DTC P1111, P1136 IVT CONTROL SOLENOID VALVE

PFP:23796

Component Description

GBS000Y0


Intake valve timing control solenoid valve is activated by ON/OFF pulse duty (ratio) signals from the ECM.

The intake valve timing control solenoid valve changes the oil amount and direction of flow through intake valve timing control unit or stops oil flow.

The longer pulse width advances valve angle.

The shorter pulse width retards valve angle.

When ON and OFF pulse widths become equal, the solenoid valve stops oil pressure flow to fix the intake valve angle at the control position.



CONSULT-II Reference Value in Data Monitor Mode

GBS000Y1

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
INT/V SOL (B1) INT/V SOL (B2)	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Shift lever: P or N (A/T), Neutral (M/T)</li> </ul>	Idle	0 - 2%
	<ul style="list-style-type: none"> <li>● Air conditioner switch: OFF</li> <li>● No load</li> </ul>	2,000 rpm	Approx. 0 - 50%

On Board Diagnosis Logic

GBS000Y2

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1111 1111 (Bank 1)	Intake valve timing control solenoid valve circuit	An improper voltage is sent to the ECM through intake valve timing control solenoid valve.	<ul style="list-style-type: none"> <li>● Harness or connectors (Intake valve timing control solenoid valve circuit is open or shorted.)</li> <li>● Intake valve timing control solenoid valve</li> </ul>
P1136 1136 (Bank 2)			

DTC Confirmation Procedure


GBS000Y3

NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 5 seconds.
4. If 1st trip DTC is detected, go to [EC-767, "Diagnostic Procedure"](#)



WITHOUT CONSULT-II

1. Start engine and wait at least 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.

4. If 1st trip DTC is detected, go to [EC-767, "Diagnostic Procedure"](#) .








# DTC P1111, P1136 IVT CONTROL SOLENOID VALVE

[VQ TYPE 2]

## Wiring Diagram BANK 1

GBS000Y4

EC-IVCB1-01




# DTC P1111, P1136 IVT CONTROL SOLENOID VALVE

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
11	V	Intake valve timing control solenoid valve (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	BATTERY VOLTAGE (11 - 14V)
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,500 rpm</li> </ul>	7 - 12V★ 
111	BR	ECM relay (Self shut-off)	<b>[Engine is running]</b> <b>[Ignition switch: OFF]</b> <ul style="list-style-type: none"> <li>● For a few seconds after turning ignition switch OFF</li> </ul>	0 - 1.5V
			<b>[Ignition switch: OFF]</b> <ul style="list-style-type: none"> <li>● More than a few seconds after turning ignition switch OFF</li> </ul>	BATTERY VOLTAGE (11 - 14V)
119 120	R P	Power supply for ECM	<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)



★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# DTC P1111, P1136 IVT CONTROL SOLENOID VALVE

[VQ TYPE 2]

BANK 2

EC-IVCB2-01



MBWA1301E


# DTC P1111, P1136 IVT CONTROL SOLENOID VALVE

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
10	W	Intake valve timing control solenoid valve (Bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	BATTERY VOLTAGE (11 - 14V)
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,500 rpm</li> </ul>	7 - 12V★ 
111	BR	ECM relay (Self shut-off)	<b>[Engine is running]</b> <b>[Ignition switch: OFF]</b> <ul style="list-style-type: none"> <li>● For a few seconds after turning ignition switch OFF</li> </ul>	0 - 1.5V
			<b>[Ignition switch: OFF]</b> <ul style="list-style-type: none"> <li>● More than a few seconds after turning ignition switch OFF</li> </ul>	BATTERY VOLTAGE (11 - 14V)
119 120	R P	Power supply for ECM	<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

**Diagnostic Procedure**

**1. CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT**

1. Turn ignition switch OFF.
2. Disconnect intake valve timing control solenoid valve harness connector.




3. Turn ignition switch ON.
4. Check voltage between intake valve timing control solenoid valve terminal 2 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



**2. DETECT MALFUNCTIONING PART**

Check the following.

- Harness connectors E9, F4 (bank 1)
- Harness connectors F6, F125 (bank 1)
- Harness for open or short between intake valve timing control solenoid valve and IPDM E/R
- Harness for open or short between intake valve timing control solenoid valve and ECM

>> Repair harness or connectors.

**3. CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 11 (bank 1) or 10 (bank 2) and intake valve timing control solenoid valve terminal 1. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

## 4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F125, F6 (bank 1)
- Harness for open and short between ECM and intake valve timing control solenoid valve

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 5. CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE

Refer to [EC-768, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> Replace intake valve timing control solenoid valve.

## 6. CHECK INTERMITTENT INCIDENT

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

### Component Inspection INTAKE VALVE TIMING CONTROL SOLENOID VALVE

GBS000Y6

1. Disconnect intake valve timing control solenoid valve harness connector.
2. Check resistance between intake valve timing control solenoid valve as follows.

Terminal	Resistance
1 and 2	7.0 - 7.7Ω [at 20°C (68°F)]
1 or 2 and ground	∞Ω (Continuity should not exist.)

If NG, replace intake valve timing control solenoid valve.  
If OK, go to next step.

3. Remove intake valve timing control solenoid valve.
4. Provide 12V DC between intake valve timing control solenoid valve terminals and then interrupt it. Make sure that the plunger moves as shown in the figure.


**CAUTION:**

Do not apply 12V DC continuously for 5 seconds or more. Doing so may result in damage to the coil in intake valve timing control solenoid valve.


If NG, replace intake valve timing control solenoid valve.

**NOTE:**

Always replace O-ring when intake valve timing control solenoid valve is removed.



PBIB0193E



PBIB2275E

### Removal and Installation INTAKE VALVE TIMING CONTROL SOLENOID VALVE

GBS000Y7

Refer to [EM-53, "TIMING CHAIN"](#) .

# DTC P1121 ELECTRIC THROTTLE CONTROL ACTUATOR

[VQ TYPE 2]

## DTC P1121 ELECTRIC THROTTLE CONTROL ACTUATOR

PFP:16119

### Component Description

GBS000Y8

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc. The throttle control motor is operated by the ECM and it opens and closes the throttle valve. The throttle position sensor detects the throttle valve position, and the opening and closing speed of the throttle valve and feeds the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

### On Board Diagnosis Logic

GBS000Y9

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition		Possible cause
P1121 1121	Electric throttle control actuator	A)	Electric throttle control actuator does not function properly due to the return spring malfunction.	● Electric throttle control actuator
		B)	Throttle valve opening angle in fail-safe mode is not in specified range.	
		C)	ECM detect the throttle valve is stuck open.	

### FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.

Detected items	Engine operating condition in fail-safe mode
Malfunction A	The ECM controls the electric throttle actuator by regulating the throttle opening around the idle position. The engine speed will not rise more than 2,000 rpm.
Malfunction B	ECM controls the electric throttle control actuator by regulating the throttle opening to 20 degrees or less.
Malfunction C	While the vehicle is driving, it slows down gradually by fuel cut. After the vehicle stops, the engine stalls. The engine can restart in N or P position (A/T), Neutral position (M/T) and engine speed will not exceed 1,000 rpm or more.

### DTC Confirmation Procedure

GBS000YA

#### NOTE:

- Perform **PROCEDURE FOR MALFUNCTION A AND B** first. If the DTC cannot be confirmed, perform **PROCEDURE FOR MALFUNCTION C**.
- If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### PROCEDURE FOR MALFUNCTION A AND B

##### ④ With CONSULT-II

1. Turn ignition switch ON and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Set shift lever to D position (A/T) or 1st position (M/T) and wait at least 3 seconds.
4. Set shift lever to P position (A/T) or neutral position (M/T).
5. Turn ignition switch OFF and wait at least 10 seconds.
6. Turn ignition switch ON and wait at least 1 second.
7. Set shift lever to D position (A/T) or 1st position (M/T) and wait at least 3 seconds.
8. Set shift lever to P position (A/T) or neutral position (M/T).
9. Turn ignition switch OFF, wait at least 10 seconds, and then turn ON.
10. If DTC is detected, go to [EC-770, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEP058Y


**⊗ Without CONSULT-II**

1. Turn ignition witch ON and wait at least 1 second.
2. Set shift lever to D position (A/T) or 1st position (M/T) and wait at least 3 seconds.
3. Set shift lever to P position (A/T) or neutral position (M/T).
4. Turn ignition switch OFF and wait at least 10 seconds.
5. Turn ignition switch ON and wait at least 1 second.
6. Set shift lever to D position (A/T) or 1st position (M/T) and wait at least 3 seconds.
7. Set shift lever to P position (A/T) or neutral position (M/T).
8. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
9. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
10. If DTC is detected, go to [EC-770. "Diagnostic Procedure"](#) .

**PROCEDURE FOR MALFUNCTION C**

**Ⓜ With CONSULT-II**

1. Turn ignition switch ON and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Set shift lever to D position (A/T) or 1st position (M/T) and wait at least 3 seconds.
4. Set shift lever to P or N position (A/T) or neutral position (M/T).
5. Start engine and let it idle for 3 seconds.
6. If DTC is detected, go to [EC-770. "Diagnostic Procedure"](#) .



**⊗ Without CONSULT-II**

1. Turn ignition witch ON and wait at least 1 second.
2. Set shift lever to D position (A/T) or 1st position (M/T) and wait at least 3 seconds.
3. Set shift lever to P or N position (A/T) or neutral position (M/T).
4. Start engine and let it idle for 3 seconds.
5. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
6. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
7. If DTC is detected, go to [EC-770. "Diagnostic Procedure"](#) .

**Diagnostic Procedure**


GBS000YB

**1. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY**

1. Remove the intake air duct.
2. Check if a foreign matter is caught between the throttle valve (1) and the housing.

**OK or NG**

- OK     >> GO TO 2.
- NG     >> Remove the foreign matter and clean the electric throttle control actuator inside.





## 2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

---

1. Replace the electric throttle control actuator.
2. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-614, "Idle Air Volume Learning"](#) .

>> INSPECTION END

A

EC

C

D

E

F

G

H

I

J

K

L

M

# DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION

[VQ TYPE 2]

## DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION

PFP:16119

### Description

GBS000YC

#### NOTE:

If DTC P1122 is displayed with DTC P1121 or 1126, first perform the trouble diagnosis for DTC P1121 or P1126. Refer to [EC-769](#) or [EC-778](#).

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc.

The throttle control motor is operated by the ECM and it opens and closes the throttle valve.

The current opening angle of the throttle valve is detected by the throttle position sensor and it provides feedback to the ECM to control the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

### On Board Diagnosis Logic

GBS000YD

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1122 1122	Electric throttle control performance	Electric throttle control function does not operate properly.	<ul style="list-style-type: none"><li>● Harness or connectors (Throttle control motor circuit is open or shorted)</li><li>● Electric throttle control actuator</li></ul>

### FAIL-SAFE MODE

When the malfunction is detected, ECM enters fail-safe mode and the MIL lights up.

Engine operating condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

### DTC Confirmation Procedure

GBS000YE

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11V when the engine is running.

#### ④ WITH CONSULT-II

1. Turn ignition switch ON and wait at least 2 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 5 seconds.
4. If DTC is detected, go to [EC-774, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

#### ⊗ WITHOUT CONSULT-II

1. Turn ignition switch ON and wait at least 2 seconds.
2. Start engine and let it idle for 5 seconds.
3. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
4. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
5. If DTC is detected, go to [EC-774, "Diagnostic Procedure"](#).

# DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION



[VQ TYPE 2]

## Wiring Diagram

GBS000YF

EC-ETC1-01

— : DETECTABLE LINE FOR DTC  
 - - - : NON-DETECTABLE LINE FOR DTC



A  
 EC  
 C  
 D  
 E  
 F  
 G  
 H  
 I  
 J  
 K  
 L  
 M



# DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
3	BR	Throttle control motor relay power supply	[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14V)
4	L/W	Throttle control motor (Close)	[Ignition switch: ON] ● Engine: Stopped ● Shift lever: D (A/T), 1st (M/T) ● Accelerator pedal: Fully released	0 - 14V★  PBIB1104E
5	L/B	Throttle control motor (Open)	[Ignition switch: ON] ● Engine: Stopped ● Shift lever: D (A/T), 1st (M/T) ● Accelerator pedal: Fully depressed	0 - 14V★  PBIB1105E
104	O	Throttle control motor relay	[Ignition switch: OFF]	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch: ON]	0 - 1.0V


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

GBS000YG

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF
2. Loosen and retighten three ground screws on the body. Refer to [EC-685, "Ground Inspection"](#).



← : Vehicle front

- |                                  |  |                    |
|----------------------------------|--|--------------------|
| 1. Body ground E21               | 2. ECM   | 3. Body ground E41 |
| 4. A/C hi-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

**OK or NG**

- OK >> GO TO 2.  
NG >> Repair or replace ground connections.

# DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION

[VQ TYPE 2]


## 2. CHECK THROTTLE CONTROL MOTOR RELAY INPUT SIGNAL CIRCUIT-I

1. Check voltage between ECM terminal 3 and ground under the following conditions with CONSULT-II or tester.

Ignition switch	Voltage
OFF	Approximately 0V
ON	Battery voltage (11 - 14V)

OK or NG

- OK >> GO TO 9.
- NG >> GO TO 3.




## 3. CHECK THROTTLE CONTROL MOTOR RELAY POWER SUPPLY CIRCUIT-I

1. Turn ignition switch OFF.
2. Check voltage between ECM terminal 104 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 4.



## 4. CHECK THROTTLE CONTROL MOTOR RELAY POWER SUPPLY CIRCUIT-II

1. Disconnect ECM harness connector.
2. Disconnect IPDM E/R harness connector E17.
3. Check continuity between ECM terminal 104 and IPDM E/R terminal 47. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 5. CHECK FUSE

1. Disconnect 20A fuse.
2. Check 20A fuse for blown.

OK or NG

- OK >> GO TO 8.
- NG >> Replace 20A fuse.

## 6. CHECK THROTTLE CONTROL MOTOR RELAY INPUT SIGNAL CIRCUIT-II

1. Disconnect ECM harness connector.
2. Disconnect IPDM E/R harness connector E12.
3. Check continuity between ECM terminal 3 and IPDM E/R terminal 6.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

## 7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E9, F4
- Harness for open or short between ECM and IPDM E/R

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 8. CHECK INTERMITTENT INCIDENT

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-14, "IPDM E/R \(INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM\)"](#) .
- NG >> Repair or replace harness or connectors.

## 9. CHECK THROTTLE CONTROL MOTOR OUTPUT SIGNAL CIRCUIT FOR OPEN OR SHORT

1. Turn ignition switch OFF.
2. Disconnect electric throttle control actuator harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between the following terminals.  
Refer to Wiring Diagram.

Electric throttle control actuator terminal	ECM terminal	Continuity
5	5	Should not exist
	4	Should exist
6	5	Should exist
	4	Should not exist



5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 10.
- NG >> Repair or replace.


## 10. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY

1. Remove the intake air duct.
2. Check if foreign matter is caught between the throttle valve (1) and the housing.

OK or NG

OK >> GO TO 11.

NG >> Remove the foreign matter and clean the electric throttle control actuator inside.



## 11. CHECK THROTTLE CONTROL MOTOR

Refer to [EC-777, "Component Inspection"](#) .

OK or NG

OK >> GO TO 12.

NG >> GO TO 13.

## 12. CHECK INTERMITTENT INCIDENT

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

OK >> GO TO 13.

NG >> Repair or replace harness or connectors.

## 13. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-614, "Idle Air Volume Learning"](#) .

>> INSPECTION END


### Component Inspection THROTTLE CONTROL MOTOR

GBS000YH

1. Disconnect electric throttle control actuator harness connector.
2. Check resistance between terminals 5 and 6.

**Resistance: Approximately 1 - 15 Ω [at 25 °C (77°F)]**

3. If NG, replace electric throttle control actuator and go to next step.
4. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
5. Perform [EC-614, "Idle Air Volume Learning"](#) .



GBS000YI

### Removal and Installation ELECTRIC THROTTLE CONTROL ACTUATOR

Refer to [EM-18, "INTAKE MANIFOLD COLLECTOR"](#) .

# DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY

[VQ TYPE 2]

## DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY

PFP:16119

### Component Description

GBS000YJ

Power supply for the throttle control motor is provided to the ECM via throttle control motor relay. The throttle control motor relay is ON/OFF controlled by the ECM. When the ignition switch is turned ON, the ECM sends an ON signal to throttle control motor relay and battery voltage is provided to the ECM. When the ignition switch is turned OFF, the ECM sends an OFF signal to throttle control motor relay and battery voltage is not provided to the ECM.

### CONSULT-II Reference Value in Data Monitor Mode

GBS000YK

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
THRTL RELAY	● Ignition switch: ON	ON

### On Board Diagnosis Logic

GBS000YL

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1124 1124	Throttle control motor relay circuit short	ECM detects the throttle control motor relay is stuck ON.	<ul style="list-style-type: none"><li>● Harness or connectors (Throttle control motor relay circuit is shorted)</li><li>● Throttle control motor relay</li></ul>
P1126 1126	Throttle control motor relay circuit open	ECM detects a voltage of power source for throttle control motor is excessively low.	<ul style="list-style-type: none"><li>● Harness or connectors (Throttle control motor relay circuit is open)</li><li>● Throttle control motor relay</li></ul>

### FAIL-SAFE MODE

When the malfunction is detected, ECM enters fail-safe mode and the MIL lights up.

Engine operating condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

### DTC Confirmation Procedure

GBS000YM

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### PROCEDURE FOR DTC P1124

##### TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 8V.

##### ④ With CONSULT-II

1. Turn ignition switch ON and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. If DTC is detected, go to [EC-781, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y



# DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY

[VQ TYPE 2]

## ⊗ Without CONSULT-II

1. Turn ignition switch ON and wait at least 1 second.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-781, "Diagnostic Procedure"](#) .

## PROCEDURE FOR DTC P1126

### Ⓟ With CONSULT-II

1. Turn ignition switch ON and wait at least 2 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 5 seconds.
4. If DTC is detected, go to [EC-781, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

## ⊗ Without CONSULT-II

1. Turn ignition switch ON and wait at least 2 seconds.
2. Start engine and let it idle for 5 seconds.
3. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
4. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
5. If DTC is detected, go to [EC-781, "Diagnostic Procedure"](#) .

# DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY



[VQ TYPE 2]

GBS000YN

## Wiring Diagram

EC-ETC2-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



MBWA1303E

# DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
3	BR	Throttle control motor relay power supply	<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)
4	L/W	Throttle control motor (Close)	<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Shift lever: D (A/T), 1st (M/T) ● Accelerator pedal: Fully released	0 - 14V★  PBIB1104E
5	L/B	Throttle control motor (Open)	<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Shift lever: D (A/T), 1st (M/T) ● Accelerator pedal: Fully depressed	0 - 14V★  PBIB1105E
104	O	Throttle control motor relay	<b>[Ignition switch: OFF]</b>	BATTERY VOLTAGE (11 - 14V)
			<b>[Ignition switch: ON]</b>	0 - 1.0V

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

GBS000Y0


### 1. CHECK THROTTLE CONTROL MOTOR RELAY POWER SUPPLY CIRCUIT-I

- Turn ignition switch OFF.
- Check voltage between ECM terminal 104 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 2.



## 2. CHECK THROTTLE CONTROL MOTOR RELAY POWER SUPPLY CIRCUIT-II

1. Disconnect ECM harness connector.
2. Disconnect IPDM E/R harness connector E17.
3. Check continuity between ECM terminal 104 and IPDM E/R terminal 47.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 3. CHECK FUSE

1. Disconnect 20A fuse.
2. Check 20A fuse for blown.

OK or NG

OK >> GO TO 7.

NG >> Replace 20A fuse.

## 4. CHECK THROTTLE CONTROL MOTOR RELAY INPUT SIGNAL CIRCUIT-I


1. Check voltage between ECM terminal 3 and ground under the following conditions with CONSULT-II or tester.

Ignition switch	Voltage
OFF	Approximately 0V
ON	Battery voltage (11 - 14V)

OK or NG

OK >> GO TO 7.

NG >> GO TO 5.



## 5. CHECK THROTTLE CONTROL MOTOR RELAY INPUT SIGNAL CIRCUIT-II

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Disconnect IPDM E/R harness connector E12.
4. Check continuity between ECM terminal 3 and IPDM E/R terminal 6.  
Refer to Wiring Diagram.

**Continuity should exist.**

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.

## 6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E9, F4
- Harness for open or short between ECM and IPDM E/R

>> Repair open circuit or short to ground or short to power in harness or connectors.

---

**7. CHECK INTERMITTENT INCIDENT**

---

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

**OK or NG**

- OK >> Replace IPDM E/R. Refer to [PG-14, "IPDM E/R \(INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM\)"](#) .
- NG >> Repair or replace harness or connectors.

A

EC

C

D

E

F

G

H

I

J

K

L

M

## DTC P1128 THROTTLE CONTROL MOTOR

PFP:16119

### Component Description

GBS000YP

The throttle control motor is operated by the ECM and it opens and closes the throttle valve. The current opening angle of the throttle valve is detected by the throttle position sensor and it provides feedback to the ECM to control the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

### On Board Diagnosis Logic

GBS000YQ

**This self-diagnosis has the one trip detection logic.**

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1128 1128	Throttle control motor circuit short	ECM detects short in both circuits between ECM and throttle control motor.	<ul style="list-style-type: none"> <li>● Harness or connectors (Throttle control motor circuit is shorted.)</li> <li>● Electric throttle control actuator (Throttle control motor)</li> </ul>

### FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.

Engine operating condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

### DTC Confirmation Procedure


GBS000YR

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### WITH CONSULT-II

1. Turn ignition switch ON and wait at least 2 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 5 seconds.
4. If DTC is detected, go to [EC-786, "Diagnostic Procedure"](#) .



#### WITHOUT CONSULT-II

1. Turn ignition switch ON and wait at least 2 seconds.
2. Start engine and let it idle for 5 seconds.
3. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
4. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
5. If DTC is detected, go to [EC-786, "Diagnostic Procedure"](#) .

# DTC P1128 THROTTLE CONTROL MOTOR

[VQ TYPE 2]



GBS000YS

## Wiring Diagram

EC-ETC3-01

— : DETECTABLE LINE FOR DTC  
 - - - : NON-DETECTABLE LINE FOR DTC

A  
 EC  
 C  
 D  
 E  
 F  
 G  
 H  
 I  
 J  
 K  
 L  
 M



MBWA1304E



# DTC P1128 THROTTLE CONTROL MOTOR

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
3	BR	Throttle control motor relay power supply	<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)
4	L/W	Throttle control motor (Close)	<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully released</li> </ul>	0 - 14V★  <small>PBIB1104E</small>
5	L/B	Throttle control motor (Open)	<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully depressed</li> </ul>	0 - 14V★  <small>PBIB1105E</small>
104	O	Throttle control motor relay	<b>[Ignition switch: OFF]</b>	BATTERY VOLTAGE (11 - 14V)
			<b>[Ignition switch: ON]</b>	0 - 1.0V


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

GBS000YT

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-685, "Ground Inspection"](#).



← : Vehicle front

- |                                  |  |                    |
|----------------------------------|--|--------------------|
| 1. Body ground E21               | 2. ECM   | 3. Body ground E41 |
| 4. A/C hi-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

OK or NG


- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.



## 2. CHECK THROTTLE CONTROL MOTOR OUTPUT SIGNAL CIRCUIT FOR OPEN OR SHORT

1. Disconnect electric throttle control actuator harness connector.
2. Disconnect ECM harness connector.
3. Check harness continuity between the following terminals. Refer to Wiring Diagram.

Electric throttle control actuator terminal	ECM terminal	Continuity
5	5	Should not exist
	4	Should exist
6	5	Should exist
	4	Should not exist



4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace.

## 3. CHECK THROTTLE CONTROL MOTOR

Refer to [EC-787, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 5.

## 4. CHECK INTERMITTENT INCIDENT

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> GO TO 5.
- NG >> Repair or replace harness or connectors.

## 5. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-614, "Idle Air Volume Learning"](#) .

>> INSPECTION END


### Component Inspection THROTTLE CONTROL MOTOR

GBS000YU

1. Disconnect electric throttle control actuator harness connector.
2. Check resistance between terminals 5 and 6.

**Resistance: Approximately 1 - 15 Ω [at 25 °C (77°F)]**

3. If NG, replace electric throttle control actuator and go to next step.
4. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
5. Perform [EC-614, "Idle Air Volume Learning"](#) .



---

**Removal and Installation**  
**ELECTRIC THROTTLE CONTROL ACTUATOR**

GBS000YV

Refer to [EM-18, "INTAKE MANIFOLD COLLECTOR"](#) .

## DTC P1217 ENGINE OVER TEMPERATURE

PFP:00000

### Description SYSTEM DESCRIPTION

GBS000Z4

**NOTE:**

If DTC P1217 is displayed with DTC U1000 or U1001, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-686, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#).

### Cooling Fan Control


Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed*1	Cooling fan control	IPDM E/R (Cooling fan relays)
Battery	Battery voltage*1		
Wheel sensor	Vehicle speed*2		
Engine coolant temperature sensor	Engine coolant temperature		
Air conditioner switch	Air conditioner ON signal*2		
Refrigerant pressure sensor	Refrigerant pressure		

\*1: The ECM determines the start signal status by the signals of engine speed and battery voltage.

\*2: This signal is sent to ECM through CAN communication line.

The ECM controls the cooling fan corresponding to the vehicle speed, engine coolant temperature, refrigerant pressure, and air conditioner ON signal. The control system has 3-step control [HIGH/LOW/OFF].

### Cooling Fan Operation



# DTC P1217 ENGINE OVER TEMPERATURE

[VQ TYPE 2]

## Cooling Fan Relay Operation

The ECM controls cooling fan relays in the IPDM E/R through CAN communication line.

Cooling fan speed	Cooling fan relay	
	1	2
Stop (OFF)	OFF	OFF
Low (LOW)	ON	OFF
High (HI)	OFF	ON

## COMPONENT DESCRIPTION

### Cooling Fan Motor

The cooling fan operates at each speed when the current flows in the cooling fan motor as follows.

Cooling fan speed	Cooling fan motor terminals	
	(+)	(-)
Low (LOW)	1	3
High (HI)	2	3

## CONSULT-II Reference Value in Data Monitor Mode

GBS000Z5

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION	
AIR COND SIG	● Engine: After warming up, idle the engine	Air conditioner switch: OFF	OFF
		Air conditioner switch: ON (Compressor operates.)	ON
COOLING FAN	● Engine: After warming up, idle the engine ● Air conditioner switch: OFF	Engine coolant temperature: 97°C (207°F) or less	OFF
		Engine coolant temperature: Between 98°C (208°F) and 104°C (219°F)	LOW
		Engine coolant temperature: 105°C (221°F) or more	HI

## On Board Diagnosis Logic

If the cooling fan or another component in the cooling system malfunctions, engine coolant temperature will rise.

When the engine coolant temperature reaches an abnormally high temperature condition, a malfunction is indicated.

**This self-diagnosis has the one trip detection logic.**

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1217 1217	Engine over temperature (Overheat)	<ul style="list-style-type: none"> <li>● Cooling fan does not operate properly (Overheat).</li> <li>● Cooling fan system does not operate properly (Overheat).</li> <li>● Engine coolant level was not added to the system using the proper filling method.</li> <li>● Engine coolant is not within the specified range.</li> </ul>	<ul style="list-style-type: none"> <li>● Harness or connectors (The cooling fan circuit is open or shorted.)</li> <li>● IPDM E/R</li> <li>● Cooling fan</li> <li>● Cooling fan (Crankshaft driven)</li> <li>● Radiator hose</li> <li>● Radiator</li> <li>● Radiator cap</li> <li>● Reservoir tank</li> <li>● Reservoir tank cap</li> <li>● Water pump</li> <li>● Thermostat</li> </ul> <p>For more information, refer to <a href="#">EC-797</a>, "<a href="#">Main 12 Causes of Overheating</a>".</p>

### CAUTION:

When a malfunction is indicated, be sure to replace the coolant. Refer to [MA-17, "Changing Engine Coolant"](#). Also, replace the engine oil. Refer to [MA-20, "Changing Engine Oil"](#).

1. Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute. Be sure to use coolant with the proper mixture ratio. Refer to [MA-15, "Engine Coolant Mixture Ratio"](#).
2. After refilling coolant, run engine to ensure that no water-flow noise is emitted.

## Overall Function Check

Use this procedure to check the overall function of the cooling fan. During this check, a DTC might not be confirmed.


### WARNING:

Never remove a radiator cap and/or a reservoir tank cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator and/or reservoir tank.

Wrap a thick cloth around cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.

### WITH CONSULT-II

1. Check the coolant level in the reservoir tank and radiator.  
**Allow engine to cool before checking coolant level.**  
If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to [EC-795, "Diagnostic Procedure"](#).
2. Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to [EC-795, "Diagnostic Procedure"](#).
3. Turn ignition switch ON.



# DTC P1217 ENGINE OVER TEMPERATURE

[VQ TYPE 2]


4. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II.
5. If the results are NG, go to [EC-795, "Diagnostic Procedure"](#) .

ACTIVE TEST	
COOLING FAN	OFF
MONITOR	
COOLANT TEMP/S	XXX °C

SEF646X

## ⊗ WITHOUT CONSULT-II

1. Check the coolant level in the reservoir tank and radiator.  
**Allow engine to cool before checking coolant level.**  
If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to [EC-795, "Diagnostic Procedure"](#) .
2. Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to [EC-795, "Diagnostic Procedure"](#) .
3. Perform IPDM E/R auto active test and check cooling fan motors operation, refer to [PG-19, "Auto Active Test"](#) .
4. If NG, go to [EC-795, "Diagnostic Procedure"](#) .






# DTC P1217 ENGINE OVER TEMPERATURE

[VQ TYPE 2]

GBS000Z8

## Wiring Diagram


A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



# DTC P1217 ENGINE OVER TEMPERATURE

[VQ TYPE 2]

## EC-COOL/F-02



E14  
W



E42  
GR



## Diagnostic Procedure

### 1. CHECK COOLING FAN (CRANKSHAFT DRIVEN) OPERATION

1. Start engine and let it idle.
2. Make sure that cooling fan (crankshaft driven) operates normally.

OK or NG

OK (With CONSULT-II)>>GO TO 2.

OK (Without CONSULT-II)>>GO TO 3.

NG >> Check cooling fan (crankshaft driven). Refer to [CO-21, "Removal and Installation \(Crankshaft Driven Type\)"](#) .

### 2. CHECK COOLING FAN OPERATION

#### Ⓜ With CONSULT-II

1. Start engine and let it idle.
2. Select "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II.
3. Make sure that cooling fan operate at each speed (LOW/HI).

OK or NG

OK >> GO TO 4.

NG >> Check cooling fan control circuit. (Go to [EC-796, "PROCEDURE A"](#) .)

ACTIVE TEST	
COOLING FAN	LOW
MONITOR	
COOLANT TEMP/S	XXX °C

SEF784Z

### 3. CHECK COOLING FAN OPERATION

#### ⊗ Without CONSULT-II

1. Perform IPDM E/R auto active test and check cooling fan motor operation, refer to [PG-19, "Auto Active Test"](#) .
2. Make sure that cooling fan operate at each speed (Low/High).

OK or NG

OK >> GO TO 4.

NG >> Check cooling fan control circuit. (Go to [EC-796, "PROCEDURE A"](#) .)

### 4. CHECK COOLING SYSTEM FOR LEAK

Refer to [CO-10, "CHECKING RADIATOR SYSTEM FOR LEAKS"](#) .

OK or NG

OK >> GO TO 5.

NG >> Check the following for leak. Refer to [CO-10, "CHECKING RADIATOR SYSTEM FOR LEAKS"](#) .

- Hose
- Radiator
- Radiator cap
- Water pump
- Reservoir tank

### 5. CHECK RESERVOIR TANK CAP

Refer to [CO-15, "Checking Reservoir Tank Cap"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace reservoir tank cap.

## 6. CHECK COMPONENT PARTS

Check the following.

- Thermostat. Refer to [CO-27, "WATER INLET AND THERMOSTAT ASSEMBLY"](#) .
- Engine coolant temperature sensor. Refer to [EC-705, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 7.  
 NG >> Replace malfunctioning component.

## 7. CHECK MAIN 12 CAUSES

If the cause cannot be isolated, go to [EC-797, "Main 12 Causes of Overheating"](#) .

>> INSPECTION END

### PROCEDURE A


#### 1. CHECK COOLILNG FAN POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R harness connectors E14.
3. Check voltage between IPDM E/R terminal 22 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 3.  
 NG >> GO TO 2.



#### 2. DETECT MALFUNCTIONING PART

Check the following.

- 40A fusible link
- Harness for open or short between IPDM E/R and battery

>> Repair open circuit or short to ground in harness or connectors.

#### 3. CHECK IPDM E/R GROUND CIRCUIT

1. Disconnect IPDM E/R harness connectors E17, E18.
2. Check harness continuity between IPDM E/R terminal 38, 59 and ground. Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 4.  
 NG >> Repair open circuit or short to power in harness or connectors.

## 4. CHECK COOLING FAN MOTOR CIRCUIT FOR OPEN AND SHORT

1. Disconnect cooling fan motor harness connector (1).
2. Check harness continuity between the following; cooling fan motor terminal 1 and IPDM E/R terminal 20, cooling fan motor terminal 2 and IPDM E/R terminal 24. Refer to Wiring Diagram.


**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



## 5. CHECK COOLING FAN MOTOR GROUND CIRCUIT FOR OPEN OR SHORT

1. Check harness continuity between cooling fan motor terminal 3 and ground. Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to power.

OK or NG

OK >> GO TO 6.

NG >> Repair open circuit or short to power in harness or connectors.

## 6. CHECK COOLING FAN MOTOR

Refer to [EC-798, "Component Inspection"](#) .

OK or NG

OK >> GO TO 7.

NG >> Replace cooling fan motors.

## 7. CHECK INTERMITTENT INCIDENT

Perform [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

OK >> Replace IPDM E/R. Refer to [PG-14, "IPDM E/R \(INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM\)"](#) .

NG >> Repair or replace harness or connector.

## Main 12 Causes of Overheating

GBS000ZA

Engine	Step	Inspection item	Equipment	Standard	Reference page
OFF	1	<ul style="list-style-type: none"> <li>● Blocked radiator</li> <li>● Blocked condenser</li> <li>● Blocked radiator grille</li> <li>● Blocked bumper</li> </ul>	● Visual	No blocking	—
	2	● Coolant mixture	● Coolant tester	50 - 50% coolant mixture	<a href="#">MA-15</a>
	3	● Coolant level	● Visual	Coolant up to MAX level in reservoir tank and radiator filler neck	<a href="#">MA-17</a>
	4	● Reservoir tank cap	● Pressure tester	59 - 117.8 kPa (0.59 - 1.18 bar, 0.6 - 1.2 kg/cm <sup>2</sup> , 9 - 17 psi) (Limit)	<a href="#">CO-15</a>
ON*2	5	● Coolant leaks	● Visual	No leaks	<a href="#">CO-10</a>

# DTC P1217 ENGINE OVER TEMPERATURE

[VQ TYPE 2]

Engine	Step	Inspection item	Equipment	Standard	Reference page
ON*2	6	● Thermostat	● Touch the upper and lower radiator hoses	Both hoses should be hot	<a href="#">CO-27</a>
ON*1	7	● Cooling fan	● CONSULT-II	Operating	See trouble diagnosis for DTC P1217 ( <a href="#">EC-789</a> ).
ON*2	7	● Cooling fan (Crankshaft driven)	● Visual	Operating	See <a href="#">CO-21</a> .
OFF	8	● Combustion gas leak	● Color checker chemical tester 4 Gas analyzer	Negative	—
ON*3	9	● Coolant temperature gauge	● Visual	Gauge less than 3/4 when driving	—
		● Coolant overflow to reservoir tank	● Visual	No overflow during driving and idling	<a href="#">MA-17</a>
OFF*4	10	● Coolant return from reservoir tank to radiator	● Visual	Should be initial level in reservoir tank	<a href="#">MA-17</a>
OFF	11	● Cylinder head	● Straight gauge feeler gauge	0.1 mm (0.004 in) Maximum distortion (warping)	<a href="#">EM-93</a>
	12	● Cylinder block and pistons	● Visual	No scuffing on cylinder walls or piston	<a href="#">EM-107</a>

\*1: Turn the ignition switch ON.

\*2: Engine running at 3,000 rpm for 10 minutes.

\*3: Drive at 90 km/h (55 MPH) for 30 minutes and then let idle for 10 minutes.

\*4: After 60 minutes of cool down time.

For more information, refer to [CO-6, "OVERHEATING CAUSE ANALYSIS"](#).

## Component Inspection COOLING FAN MOTOR


GBS0002B

1. Disconnect cooling fan motor harness connector.
2. Supply cooling fan motor terminals with battery voltage and check operation.

Cooling fan speed	Cooling fan motor terminals	
	(+)	(-)
Low	1	3
High	2	3

**Cooling fan motor should operate.**

If NG, replace cooling fan motor.



MBIB1241E

**DTC P1225 TP SENSOR**


PF16119

**Component Description**

GBS0002C

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



**On Board Diagnosis Logic**

GBS0002D

The MIL will not light up for this diagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1225 1225	Closed throttle position learning performance	Closed throttle position learning value is excessively low.	● Electric throttle control actuator (TP sensor 1 and 2)

**DTC Confirmation Procedure**

GBS0002E

**NOTE:**


If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

**WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Turn ignition switch ON.
5. If 1st trip DTC is detected, go to [EC-800, "Diagnostic Procedure"](#)



**WITHOUT CONSULT-II**

1. Turn ignition switch ON.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If 1st trip DTC is detected, go to [EC-800, "Diagnostic Procedure"](#).

**Diagnostic Procedure**

GBS000ZF


**1. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY**

1. Turn ignition switch OFF.
2. Remove the intake air duct.
3. Check if foreign matter is caught between the throttle valve (1) and the housing.

**OK or NG**

OK &gt;&gt; GO TO 2.

NG &gt;&gt; Remove the foreign matter and clean the electric throttle control actuator inside.

**2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR**

1. Replace the electric throttle control actuator.
2. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-614, "Idle Air Volume Learning"](#) .

&gt;&gt; INSPECTION END

**Removal and Installation  
ELECTRIC THROTTLE CONTROL ACTUATOR**

GBS000ZG

Refer to [EM-18, "INTAKE MANIFOLD COLLECTOR"](#) .

DTC P1226 TP SENSOR


PF16119

Component Description

GBS000ZH

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



On Board Diagnosis Logic

GBS000ZI

The MIL will not light up for this diagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1226 1226	Closed throttle position learning performance	Closed throttle position learning is not performed successfully, repeatedly.	● Electric throttle control actuator (TP sensor 1 and 2)

DTC Confirmation Procedure

GBS000ZJ

NOTE:


If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Turn ignition switch ON.
5. Repeat steps 3 and 4 for 32 times.
6. If 1st trip DTC is detected, go to [EC-802, "Diagnostic Procedure"](#)



WITHOUT CONSULT-II

1. Turn ignition switch ON.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Repeat step 2 for 32 times.
4. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
5. If 1st trip DTC is detected, go to [EC-802, "Diagnostic Procedure"](#).


**Diagnostic Procedure****1. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY**

1. Turn ignition switch OFF.
2. Remove the intake air duct.
3. Check if foreign matter is caught between the throttle valve (1) and the housing.

**OK or NG**

OK &gt;&gt; GO TO 2.

NG &gt;&gt; Remove the foreign matter and clean the electric throttle control actuator inside.

**2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR**

1. Replace the electric throttle control actuator.
2. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-614, "Idle Air Volume Learning"](#) .

&gt;&gt; INSPECTION END

**Removal and Installation  
ELECTRIC THROTTLE CONTROL ACTUATOR**Refer to [EM-18, "INTAKE MANIFOLD COLLECTOR"](#) .



## DTC P1229 SENSOR POWER SUPPLY

PFP:16119

### On Board Diagnosis Logic

GBS000ZM

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1229 1229	Sensor power supply circuit short	ECM detects a voltage of power source for sensor is excessively low or high.	<ul style="list-style-type: none"> <li>● Harness or connectors (APP sensor 1 circuit is shorted.) (PSP sensor circuit is shorted.) (Refrigerant pressure sensor circuit is shorted.) (EVAP control system pressure sensor circuit is shorted.)</li> <li>● Accelerator pedal position sensor (APP sensor 1)</li> <li>● EVAP control system pressure sensor</li> <li>● Power steering pressure sensor</li> <li>● Refrigerant pressure sensor</li> </ul>

### FAIL-SAFE MODE

When the malfunction is detected, ECM enters fail-safe mode and the MIL lights up.

Engine operation condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

### DTC Confirmation Procedure

GBS000ZM

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

#### ④ WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-807, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

#### ⊗ WITHOUT CONSULT-II

1. Start engine and let it idle for 1 second.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-807, "Diagnostic Procedure"](#) .

# DTC P1229 SENSOR POWER SUPPLY



[VQ TYPE 2]

GBS000Z0

## Wiring Diagram

### EC-SEN/PW-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



MBWA1307E

# DTC P1229 SENSOR POWER SUPPLY

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**



TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
49	P	Sensor power supply (Refrigerant pressure sensor)	<b>[Ignition switch: ON]</b>	Approximately 5V
68	V	Sensor power supply (Power steering pressure sensor)	<b>[Ignition switch: ON]</b>	Approximately 5V
82	B	Sensor ground (APP sensor 1)	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed	Approximately 0V
83	O	Sensor ground (APP sensor 2)	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed	Approximately 0V
90	L	Sensor power supply (APP sensor 1)	<b>[Ignition switch: ON]</b>	Approximately 5V
91	G	Sensor power supply (APP sensor 2)	<b>[Ignition switch: ON]</b>	Approximately 5V
98	GR	Accelerator pedal position sensor 2	<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully released	0.3 - 0.45V
			<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully depressed	Less than 2.4V
106	R	Accelerator pedal position sensor 1	<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully released	0.6 - 0.95V
			<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully depressed	Less than 4.75V

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M


# DTC P1229 SENSOR POWER SUPPLY

[VQ TYPE 2]

## EC-SEN/PW-02



REFER TO THE FOLLOWING.  
 (C1) - SUPER MULTIPLE JUNCTION (SMJ)



# DTC P1229 SENSOR POWER SUPPLY

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECMs transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
32	W	EVAP control system pressure sensor	[Ignition switch: ON]	Approximately 1.8 - 4.8V
48	SB	Sensor power supply (EVAP control system pressure sensor)	[Ignition switch: ON]	Approximately 5V
67	GR	Sensor ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V

## Diagnostic Procedure

GBS000ZP

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground three screws on the body. Refer to [EC-685, "Ground Inspection"](#) .



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

## 2. CHECK ACCELERATOR PEDAL POSITION SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect accelerator pedal position (APP) sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between APP sensor terminal 2 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 6.  
 NG >> GO TO 3.



## 3. CHECK SENSOR POWER SUPPLY CIRCUITS

Check harness for short to power and short to ground, between the following terminals.

ECM terminal	Sensor terminal	Reference Wiring Diagram
90	APP sensor terminal 2	<a href="#">EC-804</a>
48	EVAP control system pressure sensor terminal 3	<a href="#">EC-804</a>
49	Refrigerant pressure sensor terminal 3	<a href="#">EC-978</a>
68	PSP sensor terminal 3	<a href="#">EC-742</a>

OK or NG

- OK >> GO TO 4.  
 NG >> Repair short to ground or short to power in harness or connectors.

## 4. CHECK COMPONENTS

Check the following.


- Refrigerant pressure sensor (Refer to [MTC-77, "COMPONENT INSPECTION"](#) .)
- Power steering pressure sensor (Refer to [EC-745, "Component Inspection"](#) .)

OK or NG

- OK >> GO TO 5.  
 NG >> Replace malfunctioning component.

**5. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR**

1. Remove EVAP control system pressure sensor with its harness connector connected from EVAP canister. **Always replace O-ring with a new one.**




2. Install a vacuum pump to EVAP control system pressure sensor.
3. Turn ignition switch ON and check output voltage between ECM terminal 32 and ground under the following conditions.

Applied vacuum kPa (mbar, mmHg, inHg)	Voltage V
Not applied	1.8 - 4.8
-26.7 (-267, -200, -7.87)	2.1 to 2.5V lower than above value

**CAUTION:**

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-933 mbar, -700 mmHg, -27.56 inHg) or pressure over 101.3 kPa (1013 mbar, 760 mmHg, 29.92 inHg).



OK or NG

- OK >> GO TO 8.
- NG >> Replace EVAP control system pressure sensor.

**6. CHECK APP SENSOR**

Refer to [EC-882, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

**7. REPLACE ACCELERATOR PEDAL ASSEMBLY**

1. Replace accelerator pedal assembly.
2. Perform [EC-614, "Accelerator Pedal Released Position Learning"](#) .
3. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
4. Perform [EC-614, "Idle Air Volume Learning"](#) .

>> INSPECTION END

**8. CHECK INTERMITTENT INCIDENT**

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

DTC P1271, P1281 A/F SENSOR 1

PFP:22693


Component Description

GBS000Z0


The air fuel ratio (A/F) sensor is a planar dual-cell limit current sensor. The sensor element of the air fuel ratio (A/F) sensor is the combination of a Nernst concentration cell (sensor cell) with an oxygen-pump cell, which transports ions. It has a heater in the element.

The sensor is capable of precise measurement  $\lambda = 1$ , but also in the lean and rich range. Together with its control electronics, the sensor outputs a clear, continuous signal throughout a wide  $\lambda$  range ( $0.7 < \lambda < \text{air}$ ).

The exhaust gas components diffuse through the diffusion gap at the electrode of the oxygen pump and Nernst concentration cell, where they are brought to thermodynamic balance.



An electronic circuit controls the pump current through the oxygen-pump cell so that the composition of the exhaust gas in the diffusion gap remains constant at  $\lambda = 1$ . Therefore, the air fuel ratio (A/F) sensor is able to indicate air/fuel ratio by this pumping of current. In addition, a heater is integrated in the sensor to ensure the required operating temperature of 700 - 800°C (1,292 - 1,472°F).



CONSULT-II Reference Value in Data Monitor Mode

GBS000Z0

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
A/F SEN1 (B1) A/F SEN1 (B2)	<ul style="list-style-type: none"> <li>Engine: After warming up</li> </ul> Maintaining engine speed at 2,000 rpm	Fluctuates around 1.5V

On Board Diagnosis Logic

GBS000Z0

To judge the malfunction, the diagnosis checks that the A/F signal computed by ECM from the air fuel ratio (A/F) sensor 1 signal is not inordinately low.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause
P1271 1271 (Bank 1)	Air fuel ratio (A/F) sensor 1 circuit no activity detected	<ul style="list-style-type: none"> <li>The A/F signal computed by ECM from the air fuel ratio (A/F) sensor 1 signal is constantly approx. 0V.</li> </ul>	<ul style="list-style-type: none"> <li>Harness or connectors (The air fuel ratio (A/F) sensor 1 circuit is open or shorted.)</li> <li>Air fuel ratio (A/F) sensor 1</li> </ul>
P1281 1281 (Bank 2)			

DTC Confirmation Procedure

GBS000ZT

**CAUTION:**

Always drive vehicle at a safe speed.

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

**WITH CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Select "A/F SEN1 (B1)" or "A/F SEN1 (B2)" in "DATA MONITOR" mode with CONSULT-II.



# DTC P1271, P1281 A/F SENSOR 1

[VQ TYPE 2]

3. Check "A/F SEN1 (B1)" or "A/F SEN1 (B2)" indication.  
If the indication is constantly approx. 0V, go to [EC-815, "Diagnostic Procedure"](#).  
If the indication is not constantly approx. 0V, go to next step.
4. Turn ignition switch OFF, wait at least 10 seconds and then restart engine.
5. Drive and accelerate vehicle to more than 40 km/h (25 MPH) within 20 seconds after restarting engine.
6. Maintain the following conditions for about 20 consecutive seconds.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
A/F SEN1 (B1)	XXX V

SEF581Z

ENG SPEED	1,000 - 3,200 rpm
VHCL SPEED SE	More than 40 km/h (25 MPH)
B/FUEL SCHDL	1.5 - 9.0 msec
Shift lever	Suitable position

**NOTE:**

- Keep the accelerator pedal as steady as possible during the cruising.
- If this procedure is not completed within 1 minute after restarting engine at step 4, return to step 4.

7. If 1st trip DTC is displayed, go to [EC-815, "Diagnostic Procedure"](#).

## Overall Function Check

GBS000ZU

Use this procedure to check the overall function of the A/F sensor 1 circuit. During this check, a 1st trip DTC might not be confirmed.

**⊗ WITHOUT CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF, wait at least 10 seconds and then restart engine.
3. Drive and accelerate vehicle to more than 40 km/h (25 MPH) within 20 seconds after restarting engine.
4. Maintain the following conditions for about 20 consecutive seconds.

Engine Speed	1,000 - 3,200 rpm
Vehicle Speed	More than 40 km/h (25 MPH)
Shift lever	Suitable position
Driving location	Driving at level road (To avoid overloading will help maintain the driving conditions required for this test.)

**NOTE:**

- Keep the accelerator pedal as steady as possible during the cruising.
- If this procedure is not completed within 1 minute after restarting engine at step 2, return to step 2.

5. Repeat steps 2 to 4.
6. Stop the vehicle.
7. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
8. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
9. Make sure that no DTC is detected.  
If 1st trip DTC is displayed, go to [EC-815, "Diagnostic Procedure"](#).






# DTC P1271, P1281 A/F SENSOR 1

[VQ TYPE 2]

## Wiring Diagram BANK 1

GBS000ZV

EC-AF1B1-01




# DTC P1271, P1281 A/F SENSOR 1

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
2	L	A/F sensor 1 heater (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 5V★  PBIB1584E
16	SB	A/F sensor 1 (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 3.1V
35	O			Approximately 2.6V
56	LG			Approximately 2.3V
75	P			Approximately 2.3V






★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# DTC P1271, P1281 A/F SENSOR 1

[VQ TYPE 2]

BANK 2

EC-AF1B2-01




# DTC P1271, P1281 A/F SENSOR 1

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
24	G	A/F sensor 1 heater (Bank 2)	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed	Approximately 5V★  PBIB1584E
57	GR	A/F sensor 1 (Bank 2)	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed	Approximately 2.6V
58	O			Approximately 2.3V
76	V			Approximately 3.1V
77	Y			Approximately 2.3V


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

GBS000ZW

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-685, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
NG >> Repair or replace ground connections.

## 2. CHECK AIR FUEL RATIO (A/F) SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect air fuel ratio (A/F) sensor 1 harness connector.




2. Turn ignition switch ON.
3. Check voltage between air fuel ratio (A/F) sensor 1 terminal 3 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



## 3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E8, F2
- IPDM E/R connector E12
- 10A fuse
- Harness for open or short between air fuel ratio (A/F) sensor 1 and fuse

>> Repair or replace harness or connectors.

**4. CHECK AIR FUEL RATIO (A/F) SENSOR 1 INPUT SIGNAL CIRCUIT**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between the following terminals.  
Refer to Wiring Diagram.

	A/F sensor 1 terminal	ECM terminal
Bank1	1	16
	2	75
	5	35
	6	56
Bank 2	1	76
	2	77
	5	57
	6	58

**Continuity should exist.**

4. Check harness continuity between the following terminals and ground.  
Refer to Wiring Diagram.

Bank 1		Bank 2	
A/F sensor 1 terminal	ECM terminal	A/F sensor 1 terminal	ECM terminal
1	16	1	76
2	75	2	77
5	35	5	57
6	56	6	58

**Continuity should not exist.**

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**5. CHECK INTERMITTENT INCIDENT**

Perform [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> Repair or replace.

**6. REPLACE AIR FUEL RATIO (A/F) SENSOR 1**

Replace air fuel ratio (A/F) sensor 1.

**CAUTION:**

- Discard any air fuel ratio (A/F) sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new air fuel ratio (A/F) sensor, clean exhaust system threads using Heated Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

>> INSPECTION END

---

**Removal and Installation**  
**AIR FUEL RATIO (A/F) SENSOR 1**

GBS000ZX

Refer to [EM-23, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#) .



**DTC P1272, P1282 A/F SENSOR 1**

PFP:22693


**Component Description**

GBS000ZY


The air fuel ratio (A/F) sensor is a planar dual-cell limit current sensor. The sensor element of the air fuel ratio (A/F) sensor is the combination of a Nernst concentration cell (sensor cell) with an oxygen-pump cell, which transports ions. It has a heater in the element.

The sensor is capable of precise measurement  $\lambda = 1$ , but also in the lean and rich range. Together with its control electronics, the sensor outputs a clear, continuous signal throughout a wide  $\lambda$  range ( $0.7 < \lambda < \text{air}$ ).

The exhaust gas components diffuse through the diffusion gap at the electrode of the oxygen pump and Nernst concentration cell, where they are brought to thermodynamic balance.



An electronic circuit controls the pump current through the oxygen-pump cell so that the composition of the exhaust gas in the diffusion gap remains constant at  $\lambda = 1$ . Therefore, the air fuel ratio (A/F) sensor is able to indicate air/fuel ratio by this pumping of current. In addition, a heater is integrated in the sensor to ensure the required operating temperature of 700 - 800°C (1,292 - 1,472°F).



**CONSULT-II Reference Value in Data Monitor Mode**

GBS000ZZ

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
A/F SEN1 (B1) A/F SEN1 (B2)	● Engine: After warming up Maintaining engine speed at 2,000 rpm	Fluctuates around 1.5V

**On Board Diagnosis Logic**

GBS00100

To judge the malfunction, the diagnosis checks that the A/F signal computed by ECM from the air fuel ratio (A/F) sensor 1 signal is not inordinately high.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause
P1272 1272 (Bank 1)	Air fuel ratio (A/F) sensor 1 circuit no activity detected	● The A/F signal computed by ECM from the air fuel ratio (A/F) sensor 1 signal is constantly approx. 5V.	<ul style="list-style-type: none"> <li>● Harness or connectors (The air fuel ratio (A/F) sensor 1 circuit is open or shorted.)</li> <li>● Air fuel ratio (A/F) sensor 1</li> </ul>
P1282 1282 (Bank 2)			

**DTC Confirmation Procedure**

GBS00101

**CAUTION:**

Always drive vehicle at a safe speed.

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

**WITH CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Select "A/F SEN1 (B1)" or "A/F SEN1 (B2)" in "DATA MONITOR" mode with CONSULT-II.

# DTC P1272, P1282 A/F SENSOR 1

[VQ TYPE 2]

3. Check "A/F SEN1 (B1)" or "A/F SEN1 (B2)" indication.  
If the indication is constantly approx. 5V, go to [EC-824, "Diagnostic Procedure"](#) .  
If the indication is not constantly approx. 5V, go to next step.
4. Turn ignition switch OFF, wait at least 10 seconds and then restart engine.
5. Drive and accelerate vehicle to more than 40 km/h (25 MPH) within 20 seconds after restarting engine.
6. Maintain the following conditions for about 20 consecutive seconds.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
A/F SEN1 (B1)	XXX V

SEF581Z

ENG SPEED	1,000 - 3,200 rpm
VHCL SPEED SE	More than 40 km/h (25 MPH)
B/FUEL SCHDL	1.5 - 9.0 msec
Shift lever	Suitable position

**NOTE:**

- Keep the accelerator pedal as steady as possible during the cruising.
  - If this procedure is not completed within 1 minute after restarting engine at step 4, return to step 4.
7. If 1st trip DTC is displayed, go to [EC-824, "Diagnostic Procedure"](#) .

## Overall Function Check

GBS00102

Use this procedure to check the overall function of the A/F sensor 1 circuit. During this check, a 1st trip DTC might not be confirmed.

### WITHOUT CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF, wait at least 10 seconds and then restart engine.
3. Drive and accelerate vehicle to more than 40 km/h (25 MPH) within 20 seconds after restarting engine.
4. Maintain the following conditions for about 20 consecutive seconds.

Engine Speed	1,000 - 3,200 rpm
Vehicle Speed	More than 40 km/h (25 MPH)
Shift lever	Suitable position
Driving location	Driving at level road (To avoid overloading will help maintain the driving conditions required for this test.)

**NOTE:**

- Keep the accelerator pedal as steady as possible during the cruising.
  - If this procedure is not completed within 1 minute after restarting engine at step 2, return to step 2.
5. Repeat steps 2 to 4.
  6. Stop the vehicle.
  7. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
  8. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
  9. Make sure that no DTC is detected.  
If 1st trip DTC is displayed, go to [EC-824, "Diagnostic Procedure"](#) .






# DTC P1272, P1282 A/F SENSOR 1

[VQ TYPE 2]

## Wiring Diagram BANK 1

GBS00103

EC-AF1B1-01




# DTC P1272, P1282 A/F SENSOR 1

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
2	L	A/F sensor 1 heater (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 5V★ 
16	SB	A/F sensor 1 (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 3.1V
35	O			Approximately 2.6V
56	LG			Approximately 2.3V
75	P			Approximately 2.3V






★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# DTC P1272, P1282 A/F SENSOR 1

[VQ TYPE 2]

BANK 2

EC-AF1B2-01




# DTC P1272, P1282 A/F SENSOR 1

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
24	G	A/F sensor 1 heater (Bank 2)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 5V★  PBB1584E
57	GR	A/F sensor 1 (Bank 2)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 2.6V
58	O			Approximately 2.3V
76	V			Approximately 3.1V
77	Y			Approximately 2.3V


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

GBS00104

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws. Refer to [EC-685, "Ground Inspection"](#).



↔ : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

**OK or NG**

- OK >> GO TO 2.  
NG >> Repair or replace ground connections.

## 2. CHECK AIR FUEL RATIO (A/F) SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect air fuel ratio (A/F) sensor 1 harness connector.




2. Turn ignition switch ON.
3. Check voltage between air fuel ratio (A/F) sensor 1 terminal 3 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



## 3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E8, F2
- IPDM E/R connector E12
- 10A fuse
- Harness for open or short between air fuel ratio (A/F) sensor 1 and fuse

>> Repair or replace harness or connectors.

#### 4. CHECK AIR FUEL RATIO (A/F) SENSOR 1 INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between the following terminals.  
Refer to Wiring Diagram.

	A/F sensor 1 terminal	ECM terminal
Bank1	1	16
	2	75
	5	35
	6	56
Bank 2	1	76
	2	77
	5	57
	6	58

**Continuity should exist.**

4. Check harness continuity between the following terminals and ground.  
Refer to Wiring Diagram.

Bank 1		Bank 2	
A/F sensor 1 terminal	ECM terminal	A/F sensor 1 terminal	ECM terminal
1	16	1	76
2	75	2	77
5	35	5	57
6	56	6	58

**Continuity should not exist.**

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

#### 5. CHECK INTERMITTENT INCIDENT

Perform [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

OK >> GO TO 6.

NG >> Repair or replace.

#### 6. REPLACE AIR FUEL RATIO (A/F) SENSOR 1

Replace air fuel ratio (A/F) sensor 1.

**CAUTION:**

- Discard any air fuel ratio (A/F) sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new air fuel ratio (A/F) sensor, clean exhaust system threads using Heated Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

>> INSPECTION END



**Removal and Installation**  
**AIR FUEL RATIO (A/F) SENSOR 1**

GBS00105

A

Refer to [EM-23, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#) .

EC

C

D

E

F

G

H

I

J

K

L

M

DTC P1276, P1286 A/F SENSOR 1

PFP:22693


Component Description

GBS00106


The air fuel ratio (A/F) sensor is a planar dual-cell limit current sensor. The sensor element of the air fuel ratio (A/F) sensor is the combination of a Nernst concentration cell (sensor cell) with an oxygen-pump cell, which transports ions. It has a heater in the element.

The sensor is capable of precise measurement  $\lambda = 1$ , but also in the lean and rich range. Together with its control electronics, the sensor outputs a clear, continuous signal throughout a wide  $\lambda$  range ( $0.7 < \lambda < \text{air}$ ).

The exhaust gas components diffuse through the diffusion gap at the electrode of the oxygen pump and Nernst concentration cell, where they are brought to thermodynamic balance.



An electronic circuit controls the pump current through the oxygen-pump cell so that the composition of the exhaust gas in the diffusion gap remains constant at  $\lambda = 1$ . Therefore, the air fuel ratio (A/F) sensor is able to indicate air/fuel ratio by this pumping of current. In addition, a heater is integrated in the sensor to ensure the required operating temperature of 700 - 800°C (1,292 - 1,472°F).



CONSULT-II Reference Value in Data Monitor Mode

GBS00107

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
A/F SEN1 (B1) A/F SEN1 (B2)	● Engine: After warming up Maintaining engine speed at 2,000 rpm	Fluctuates around 1.5V

On Board Diagnosis Logic

GBS00108

To judge the malfunction, the diagnosis checks that the A/F signal computed by ECM from the air fuel ratio (A/F) sensor 1 signal fluctuates according to fuel feedback control.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause
P1276 1276 (Bank 1)	Air fuel ratio (A/F) sensor 1 circuit high voltage	● The A/F signal computed by ECM from the air fuel ratio (A/F) sensor 1 signal is constantly approx. 1.5V.	<ul style="list-style-type: none"> <li>● Harness or connectors (The air fuel ratio (A/F) sensor 1 circuit is open or shorted.)</li> <li>● Air fuel ratio (A/F) sensor 1</li> </ul>
P1286 1286 (Bank 2)			

Overall Function Check

GBS00109

Use this procedure to check the overall function of the A/F sensor 1 circuit. During this check, a 1st trip DTC might not be confirmed.

**CAUTION:**

Always drive vehicle at a safe speed.

**WITH CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Select "A/F SEN1 (B1)" or "A/F SEN1 (B2)" in "DATA MONITOR" mode with CONSULT-II.
3. Check "A/F SEN1 (B1)" or "A/F SEN1 (B2)" indication.  
If the indication is constantly approx. 1.5V and does not fluctuates, go to [EC-833, "Diagnostic Procedure"](#).  
If the indication fluctuates around 1.5V, go to next step.

4. Turn ignition switch OFF and wait at least 10 seconds.
5. Start engine and warm it up to normal operating temperature.
6. Select "DATA MONITOR" mode with CONSULT-II.
7. Drive the vehicle at a speed of 80 km/h (50 MPH) for a few minutes in the suitable gear position.
8. Set selector lever to D position with "OD" OFF (A/T) or 5th position (M/T), then release the accelerator pedal fully until the vehicle speed decreases to 50 km/h (30 MPH).

**NOTE:**

Never apply brake during releasing the accelerator pedal.

9. Repeat steps 7 to 8 for five times.
10. Stop the vehicle and turn ignition switch OFF.
11. Wait at least 10 seconds and restart engine.
12. Repeat steps 7 to 8 for five times.
13. Make sure that no DTC is detected.  
If the 1st trip DTC is detected, go to [EC-833, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
B/FUEL SCHDL	XXX msec

SEF189Y

**⊗ WITHOUT CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Drive the vehicle at a speed of 80 km/h (50 MPH) for a few minutes in the suitable gear position.
3. Set selector lever to D position with "OD" OFF (A/T) or 5th position (M/T) then release the accelerator pedal fully until the vehicle speed decreases to 50 km/h (30 MPH).

**NOTE:**

Never apply brake during releasing the accelerator pedal.

4. Repeat steps 2 to 3 for five times.
5. Stop the vehicle and turn ignition switch OFF.
6. Wait at least 10 seconds and restart engine.
7. Repeat steps 2 to 3 for five times.
8. Stop the vehicle.
9. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
10. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
11. Make sure that no DTC is detected.  
If the 1st trip DTC is detected, go to [EC-833, "Diagnostic Procedure"](#).






# DTC P1276, P1286 A/F SENSOR 1

[VQ TYPE 2]

GBS0010A

## Wiring Diagram BANK 1

EC-AF1B1-01



MBWA1336E


# DTC P1276, P1286 A/F SENSOR 1

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
2	L	A/F sensor 1 heater (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 5V★ 
16	SB	A/F sensor 1 (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 3.1V
35	O			Approximately 2.6V
56	LG			Approximately 2.3V
75	P			Approximately 2.3V



★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# DTC P1276, P1286 A/F SENSOR 1


[VQ TYPE 2]

BANK 2


EC-AF1B2-01




E12 W



F1 B



F2 W



F23 B


# DTC P1276, P1286 A/F SENSOR 1

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
24	G	A/F sensor 1 heater (Bank 2)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 5V★  PBIB1584E
57	GR	A/F sensor 1 (Bank 2)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 2.6V
58	O			Approximately 2.3V
76	V			Approximately 3.1V
77	Y			Approximately 2.3V


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

GBS0010B

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-685, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
NG >> Repair or replace ground connections.

## 2. CHECK AIR FUEL RATIO (A/F) SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect air fuel ratio (A/F) sensor 1 harness connector.




2. Turn ignition switch ON.
3. Check voltage between air fuel ratio (A/F) sensor 1 terminal 3 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



## 3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E8, F2
- IPDM E/R connector E12
- 10A fuse
- Harness for open or short between air fuel ratio (A/F) sensor 1 and fuse

>> Repair or replace harness or connectors.



**4. CHECK AIR FUEL RATIO (A/F) SENSOR 1 INPUT SIGNAL CIRCUIT**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between the following terminals.  
Refer to Wiring Diagram.

	A/F sensor 1 terminal	ECM terminal
Bank1	1	16
	2	75
	5	35
	6	56
Bank 2	1	76
	2	77
	5	57
	6	58

**Continuity should exist.**

4. Check harness continuity between the following terminals and ground.  
Refer to Wiring Diagram.

Bank 1		Bank 2	
A/F sensor 1 terminal	ECM terminal	A/F sensor 1 terminal	ECM terminal
1	16	1	76
2	75	2	77
5	35	5	57
6	56	6	58

**Continuity should not exist.**

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**5. CHECK INTERMITTENT INCIDENT**

Perform [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> Repair or replace.

**6. REPLACE AIR FUEL RATIO (A/F) SENSOR 1**

Replace air fuel ratio (A/F) sensor 1.

**CAUTION:**

- Discard any air fuel ratio (A/F) sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new air fuel ratio (A/F) sensor, clean exhaust system threads using Heated Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

>> INSPECTION END

---

**Removal and Installation**  
**AIR FUEL RATIO (A/F) SENSOR 1**

GBS0010C

Refer to [EM-23, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#) .


DTC P1564 ASCD STEERING SWITCH

PFP:25551

Component Description

GBS0010D

ASCD steering switch has variant values of electrical resistance for each button. ECM reads voltage variation of switch, and determines which button is operated.



Refer to [EC-591, "AUTOMATIC SPEED CONTROL DEVICE \(ASCD\)"](#) for the ASCD function.

CONSULT-II Reference Value in Data Monitor Mode

GBS0010E

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
MAIN SW	● Ignition switch: ON	MAIN switch: Pressed	ON
		MAIN switch: Released	OFF
CANCEL SW	● Ignition switch: ON	CANCEL switch: Pressed	ON
		CANCEL switch: Released	OFF
RESUME/ACC SW	● Ignition switch: ON	RESUME/ACCELERATE switch: Pressed	ON
		RESUME/ACCELERATE switch: Released	OFF
SET SW	● Ignition switch: ON	SET/COAST switch: Pressed	ON
		SET/COAST switch: Released	OFF

On Board Diagnosis Logic

GBS0010F

This self-diagnosis has the one trip detection logic.  
The MIL will not light up for this diagnosis.

NOTE:

If DTC P1564 is displayed with DTC P0605, first perform the trouble diagnosis for DTC P0605. Refer to [EC-746](#).

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P1564 1564	ASCD steering switch	<ul style="list-style-type: none"> <li>● An excessively high voltage signal from the ASCD steering switch is sent to ECM.</li> <li>● ECM detects that input signal from the ASCD steering switch is out of the specified range.</li> <li>● ECM detects that the ASCD steering switch is stuck ON.</li> </ul>	<ul style="list-style-type: none"> <li>● Harness or connectors (The switch circuit is open or shorted.)</li> <li>● ASCD steering switch</li> <li>● ECM</li> </ul>


## DTC Confirmation Procedure

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**④ WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 10 seconds.
4. Press MAIN switch for at least 10 seconds, then release it and wait at least 10 seconds.
5. Press CANCEL switch for at least 10 seconds, then release it and wait at least 10 seconds.
6. Press RESUME/ACCELERATE switch for at least 10 seconds, then release it and wait at least 10 seconds.
7. Press SET/COAST switch for at least 10 seconds, then release it and wait at least 10 seconds.
8. If DTC is detected, go to [EC-840, "Diagnostic Procedure"](#) .



**⊗ WITHOUT CONSULT-II**

1. Turn ignition switch ON and wait at least 10 seconds.
2. Press MAIN switch for at least 10 seconds, then release it and wait at least 10 seconds.
3. Press CANCEL switch for at least 10 seconds, then release it and wait at least 10 seconds.
4. Press RESUME/ACCELERATE switch for at least 10 seconds, then release it and wait at least 10 seconds.
5. Press SET/COAST switch for at least 10 seconds, then release it and wait at least 10 seconds.
6. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
7. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
8. If DTC is detected, go to [EC-840, "Diagnostic Procedure"](#) .

# DTC P1564 ASCD STEERING SWITCH



[VQ TYPE 2]

## Wiring Diagram



GBS0010H

EC-ASC/SW-01

— : DETECTABLE LINE FOR DTC  
 - - - : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.  
 (M91) - SUPER MULTIPLE JUNCTION (SMJ)



\* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

# DTC P1564 ASCD STEERING SWITCH

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
67	GR	Sensor ground	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 0V
99	SB	ASCD steering switch	<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● ASCD steering switch: OFF</li> </ul>	Approximately 4.0V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● MAIN switch: Pressed</li> </ul>	Approximately 0V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● CANCEL switch: Pressed</li> </ul>	Approximately 1V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● RESUME/ACCELERATE switch: Pressed</li> </ul>	Approximately 3V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● SET/COAST switch: Pressed</li> </ul>	Approximately 2V

## Diagnostic Procedure

GBS0010I

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-685, "Ground Inspection"](#).



← : Vehicle front

- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

**OK or NG**


- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

**2. CHECK ASCD STEERING SWITCH CIRCUIT**

**With CONSULT-II**

1. Turn ignition switch ON.
2. Select "MAIN SW", "CANCEL SW", "RESUME/ACC SW" and "SET SW" in "DATA MONITOR" mode with CONSULT-II.
3. Check each item indication under the following conditions.


Switch	Monitor item	Condition	Indication
MAIN switch	MAIN SW	Pressed	ON
		Released	OFF
CANCEL switch	CANCEL SW	Pressed	ON
		Released	OFF
RESUME/ACCELERATE switch	RESUME/ACC SW	Pressed	ON
		Released	OFF
SET/COAST switch	SET SW	Pressed	ON
		Released	OFF



**Without CONSULT-II**

1. Turn ignition switch ON.
2. Check voltage between ECM terminal 99 and ground with pressing each button.

Switch	Condition	Voltage [V]
MAIN switch	Pressed	Approx. 0
	Released	Approx. 4
CANCEL switch	Pressed	Approx. 1
	Released	Approx. 4
RESUME/ACCELERATE switch	Pressed	Approx. 3
	Released	Approx. 4
SET/COAST switch	Pressed	Approx. 2
	Released	Approx. 4



OK or NG

- OK >> GO TO 8.
- NG >> GO TO 3.

**3. CHECK ASCD STEERING SWITCH GROUND CIRCUIT FOR OPEN AND SHORT**

1. Turn ignition switch OFF.
2. Disconnect combination switch harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between combination switch terminal 17 and ECM terminal 67. Refer to Wiring Diagram.

**Continuity should exist.**

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

---

## 4. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors M91, E101
- Harness connectors E8, F2
- Combination switch (spiral cable)
- Harness for open and short between ECM and combination switch

>> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 5. CHECK ASCD STEERING SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

1. Check harness continuity between ECM terminal 99 and combination switch terminal 18.  
Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.  
NG >> GO TO 6.

---

## 6. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors M91, E101
- Combination switch (spiral cable)
- Harness for open and short between ECM and combination switch

>> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 7. CHECK ASCD STEERING SWITCH

---

Refer to [EC-843, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 8.  
NG >> Replace steering switch.

---

## 8. CHECK INTERMITTENT INCIDENT

---

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**



# DTC P1564 ASCD STEERING SWITCH


[VQ TYPE 2]

GBS0010J

## Component Inspection ASCD STEERING SWITCH

1. Disconnect combination switch (spiral cable) harness connector M302.
2. Check continuity between combination switch (spiral cable) terminals 17 and 18 with pushing each switch.

Switch	Condition	Resistance [ $\Omega$ ]
MAIN switch	Pressed	Approx. 0
	Released	Approx. 4,000
CANCEL switch	Pressed	Approx. 250
	Released	Approx. 4,000
RESUME/ACCELERATE switch	Pressed	Approx. 1,480
	Released	Approx. 4,000
SET/COAST switch	Pressed	Approx. 660
	Released	Approx. 4,000



A

EC

C

D

E

F

G

H

I

J

K

L

M


## DTC P1572 ASCD BRAKE SWITCH

PFP:25320

### Component Description

GBS0010K

When the brake pedal is depressed, ASCD brake switch (1) is turned OFF and stop lamp switch (2) is turned ON. ECM detects the state of the brake pedal by this input of two kinds (ON/OFF signal). Refer to [EC-591, "AUTOMATIC SPEED CONTROL DEVICE \(ASCD\)"](#) for the ASCD function.



### CONSULT-II Reference Value in Data Monitor Mode

GBS0010L

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
BRAKE SW1 (ASCD brake switch)	● Ignition switch: ON Brake pedal: Fully released (A/T) Clutch pedal and brake pedal: Fully released (M/T)	ON
	Brake pedal: Slightly depressed (A/T) Clutch pedal and/or brake pedal: Slightly depressed (M/T)	OFF
BRAKE SW2 (Stop lamp switch)	● Ignition switch: ON Brake pedal: Fully released	OFF
	Brake pedal: Slightly depressed	ON

### On Board Diagnosis Logic

GBS0010M

**This self-diagnosis has the one trip detection logic.  
The MIL will not light up for this diagnosis.**

**NOTE:**

- If DTC P 1572 is displayed with DTC P0605, first perform the trouble diagnosis for DTC P0605. Refer to [EC-746](#)
- This self-diagnosis has the one trip detection logic. When malfunction A is detected, DTC is not stored in ECM memory. And in that case, 1st trip DTC and 1st trip freeze frame data are displayed. 1st trip DTC is erased when ignition switch OFF. And even when malfunction A is detected in two consecutive trips, DTC is not stored in ECM memory.

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P1572 1572	ASCD brake switch	A) When the vehicle speed is above 30km/h (19 MPH), ON signals from the stop lamp switch and the ASCD brake switch are sent to ECM at the same time.	<ul style="list-style-type: none"> <li>● Harness or connectors (The stop lamp switch circuit is shorted.)</li> <li>● Harness or connectors (The ASCD brake switch circuit is shorted.)</li> </ul>
		B) ASCD brake switch signal is not sent to ECM for extremely long time while the vehicle is driving	<ul style="list-style-type: none"> <li>● Stop lamp switch</li> <li>● ASCD brake switch</li> <li>● Incorrect stop lamp switch installation</li> <li>● Incorrect ASCD brake switch installation</li> <li>● ECM</li> </ul>

## DTC Confirmation Procedure

**CAUTION:**

Always drive vehicle at a safe speed.

**NOTE:**

- If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.
- Procedure for malfunction B is not described here. It takes extremely long time to complete procedure for malfunction B. By performing procedure for malfunction A, the incident that causes malfunction B can be detected.

**TESTING CONDITION:**

**Steps 4 and 5 may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.**

**WITH CONSULT-II**

1. Start engine.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Press MAIN switch and make sure that CRUISE indicator lights up.
4. Drive the vehicle for at least 5 consecutive seconds under the following condition.

VHCL SPEED SE	More than 30 km/h (19 MPH)
Selector lever	Suitable position

If 1st trip DTC is detected, go to [EC-848, "Diagnostic Procedure"](#)

If 1st trip DTC is not detected, go to the following step.

5. Drive the vehicle for at least 5 consecutive seconds under the following condition.

VHCL SPEED SE	More than 30 km/h (19 MPH)
Selector lever	Suitable position
Driving location	Depress the brake pedal for more than five seconds so as not to come off from the above-mentioned vehicle speed.

6. If 1st trip DTC is detected, go to [EC-848, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
VHCL SPEED SE	XXX km/h
CRUISE LAMP	ON
BRAKE SW 1	ON
BRAKE SW 2	OFF

PBIB2386E

## Overall Function Check

Use this procedure to check the overall function of the ASCD brake switch circuit. During this check, a 1st trip DTC might not be confirmed.

**WITHOUT CONSULT-II**

1. Turn ignition switch ON.
2. Check voltage between ECM terminal 108 (ASCD brake switch signal) and ground under the following conditions.


**A/T models**

CONDITION	VOLTAGE
Brake pedal: Slightly depressed	Approximately 0V
Brake pedal: Fully released	Battery voltage

**M/T models**

CONDITION	VOLTAGE
Clutch pedal and/or brake pedal: Slightly depressed	Approximately 0V
Clutch pedal and brake pedal: Fully released	Battery voltage

3. If NG, go to [EC-848, "Diagnostic Procedure"](#) .  
If OK, go to next step.




# DTC P1572 ASCD BRAKE SWITCH

[VQ TYPE 2]

4. Check voltage between ECM terminal 101 (stop lamp switch signal) and ground under the following conditions.

CONDITION	VOLTAGE
Brake pedal: Fully released	Approximately 0V
Brake pedal: Slightly depressed	Battery voltage

5. If NG, go to [EC-848, "Diagnostic Procedure"](#) .





# DTC P1572 ASCD BRAKE SWITCH

[VQ TYPE 2]

GBS0010P

## Wiring Diagram



(E20) B



4 3 (E109) W  
 2 1

2 (E110) BR  
 1

1 2 (E111) L

1 2 (E116) B

REFER TO THE FOLLOWING.

(E103) - FUSE BLOCK - JUNCTION BOX (J/B)

# DTC P1572 ASCD BRAKE SWITCH

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
101	V	Stop lamp switch	[Ignition switch: OFF] ● Brake pedal: Fully released	Approximately 0V
			[Ignition switch: OFF] ● Brake pedal: Slightly depressed	BATTERY VOLTAGE (11 - 14V)
108	LG	ASCD brake switch	[Ignition switch: ON] ● Brake pedal: Slightly depressed (A/T) ● Clutch pedal and/or brake pedal: Slightly depressed (M/T)	Approximately 0V
			[Ignition switch: ON] ● Brake pedal: Fully released (A/T) ● Clutch pedal and brake pedal: Fully released (M/T)	BATTERY VOLTAGE (11 - 14V)

## Diagnostic Procedure A/T MODELS


GBS0010Q

### 1. CHECK OVERALL FUNCTION-I

 **With CONSULT-II**

- Turn ignition switch ON.
- Select "BRAKE SW1" in "DATA MONITOR" mode with CONSULT-II.
- Check "BRAKE SW1" indication under the following conditions.

CONDITION	INDICATION
Brake pedal: Slightly depressed	OFF
Brake pedal: Fully released	ON



SEC011D


 **Without CONSULT-II**

- Turn ignition switch ON.
- Check voltage between ECM terminal 108 and ground under the following conditions.

CONDITION	VOLTAGE
Brake pedal: Slightly depressed	Approximately 0V
Brake pedal: Fully released	Battery voltage

**OK or NG**

- OK >> GO TO 2.  
NG >> GO TO 3.



MBIB0061E

# DTC P1572 ASCD BRAKE SWITCH


[VQ TYPE 2]

## 2. CHECK OVERALL FUNCTION-II

### With CONSULT-II

Check "BRAKE SW2" indication in "DATA MONITOR" mode.

CONDITION	INDICATION
Brake pedal: Fully released	OFF
Brake pedal: Slightly depressed	ON




### Without CONSULT-II

Check voltage between ECM terminal 101 and ground under the following conditions.

CONDITION	VOLTAGE
Brake pedal: Fully released	Approximately 0V
Brake pedal: Slightly depressed	Battery voltage


OK or NG

- OK >> GO TO 11.
- NG >> GO TO 7.



## 3. CHECK ASCD BRAKE SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch (1) harness connector.
  - Stop lamp switch (2)
3. Turn ignition switch ON.




4. Check voltage between ASCD brake switch terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.



## 4. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse
- Harness for open or short between ASCD brake switch and fuse

>> Repair open circuit or short to ground in harness or connectors.

## 5. CHECK ASCD BRAKE SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 108 and ASCD brake switch terminal 2. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 6.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 6. CHECK ASCD BRAKE SWITCH

Refer to [EC-856, "Component Inspection"](#)


OK or NG

OK >> GO TO 11.

NG >> Replace ASCD brake switch.

## 7. CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch (2) harness connector.
  - ASCD brake switch (1)




3. Check voltage between stop lamp switch terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

OK >> GO TO 9.

NG >> GO TO 8.





---

## 8. DETECT MALFUNCTIONING PART

---

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse
- Harness for open or short between stop lamp switch and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 9. CHECK STOP LAMP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 101 and stop lamp switch terminal 2.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 10.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 10. CHECK STOP LAMP SWITCH

---

Refer to [EC-856, "Component Inspection"](#)

OK or NG

OK >> GO TO 11.

NG >> Replace stop lamp switch.

---

## 11. CHECK INTERMITTENT INCIDENT

---

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

# DTC P1572 ASCD BRAKE SWITCH

[VQ TYPE 2]


## M/T MODELS

### 1. CHECK OVERALL FUNCTION-I

#### ④ With CONSULT-II

1. Turn ignition switch ON.
2. Select "BRAKE SW1" in "DATA MONITOR" mode with CONSULT-II.
3. Check "BRAKE SW1" indication under the following conditions.


CONDITION	INDICATION
Clutch pedal and/or brake pedal: Slightly depressed	OFF
Clutch pedal and brake pedal: Fully released	ON



#### ⊗ Without CONSULT-II

1. Turn ignition switch ON.
2. Check voltage between ECM terminal 108 and ground under the following conditions.

CONDITION	VOLTAGE
Clutch pedal and/or brake pedal: Slightly depressed	Approximately 0V
Clutch pedal and brake pedal: Fully released	Battery voltage



#### OK or NG


- OK >> GO TO 2.
- NG >> GO TO 3.

## 2. CHECK OVERALL FUNCTION-II

**With CONSULT-II**

Check "BRAKE SW2" indication in "DATA MONITOR" mode.

CONDITION	INDICATION
Brake pedal: Fully released	OFF
Brake pedal: Slightly depressed	ON




**Without CONSULT-II**

Check voltage between ECM terminal 101 and ground under the following conditions.

CONDITION	VOLTAGE
Brake pedal: Fully released	Approximately 0V
Brake pedal: Slightly depressed	Battery voltage


OK or NG

- OK >> GO TO 14.
- NG >> GO TO 10.



## 3. CHECK ASCD CLUTCH SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ASCD clutch switch harness connector.
3. Turn ignition switch ON.




4. Check voltage between ASCD clutch switch terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**


OK or NG

- OK >> GO TO 8.
- NG >> GO TO 4.



## 4. CHECK ASCD BRAKE SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch harness connector.
3. Turn ignition switch ON.




4. Check voltage between ASCD brake switch terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



## 5. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse
- Harness for open or short between ASCD brake switch and fuse

>> Repair open circuit or short to ground in harness or connectors.

## 6. CHECK ASCD BRAKE SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Check harness continuity between ASCD brake switch terminal 2 and ASCD clutch switch terminal 1. Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 7. CHECK ASCD BRAKE SWITCH

Refer to [EC-856, "Component Inspection"](#)

OK or NG

- OK >> GO TO 14.
- NG >> Replace ASCD brake switch.

## 8. CHECK ASCD BRAKE SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 108 and ASCD clutch switch terminal 2.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 9.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 9. CHECK ASCD CLUTCH SWITCH

Refer to [EC-856, "Component Inspection"](#) .


OK or NG

OK >> GO TO 14.

NG >> Replace ASCD clutch switch.

## 10. CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch harness connector.




3. Check voltage between stop lamp switch terminal 2 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

OK >> GO TO 12.

NG >> GO TO 11.



## 11. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse
- Harness for open or short between stop lamp switch and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 12. CHECK STOP LAMP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 101 and stop lamp switch terminal 1.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 13.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 13. CHECK STOP LAMP SWITCH

Refer to [EC-856, "Component Inspection"](#)

OK or NG

OK >> GO TO 14.

NG >> Replace stop lamp switch.

## 14. CHECK INTERMITTENT INCIDENT

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**


### Component Inspection ASC D BRAKE SWITCH

GBS0010R

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch harness connector.
3. Check continuity between ASCD brake switch terminals 1 and 2 under the following conditions.

Condition	Continuity
Brake pedal: Fully released	Should exist
Brake pedal: Slightly depressed	Should not exist

If NG, adjust ASCD brake switch installation, refer to [BR-6, "BRAKE PEDAL"](#) , and perform step 3 again.




### ASC D CLUTCH SWITCH

1. Turn ignition switch OFF.
2. Disconnect ASCD clutch switch harness connector.
3. Check continuity between ASCD clutch switch terminals 1 and 2 under the following conditions.


Condition	Continuity
Clutch pedal: Fully released	Should exist
Clutch pedal: Slightly depressed	Should not exist

If NG, adjust ASCD clutch switch installation, refer to [CL-6, "CLUTCH PEDAL"](#) , and perform step 3 again.



## STOP LAMP SWITCH

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch harness connector.
3. Check continuity between stop lamp switch terminals 1 and 2 under the following conditions.



Condition	Continuity
Brake pedal: Fully released	Should not exist
Brake pedal: Slightly depressed	Should exist

If NG, adjust stop lamp switch installation, refer to [BR-6, "BRAKE PEDAL"](#) , and perform step 3 again.

A  
 EC  
 C  
 D  
 E  
 F  
 G  
 H  
 I  
 J  
 K  
 L  
 M

## DTC P1706 PNP SWITCH

PFP:32006

### Component Description

GBS0010S

When the selector lever position is P or N (A/T), Neutral (M/T), park/neutral position (PNP) switch is ON. ECM detects the position because the continuity of the line (the ON signal) exists.

### CONSULT-II Reference Value in Data Monitor Mode

GBS0010U

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
P/N POSI SW	● Ignition switch: ON	Shift lever: P or N (A/T), Neutral (M/T) ON
		Shift lever: Except above OFF

### On Board Diagnosis Logic

GBS0010U

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1706 1706	Park/neutral position switch	The signal of the park/neutral position (PNP) switch is not changed in the process of engine starting and driving.	<ul style="list-style-type: none"> <li>● Harness or connectors [The park/neutral position (PNP) switch circuit is open or shorted.]</li> <li>● Park/neutral position (PNP) switch</li> <li>● Combination meter</li> <li>● TCM (A/T models)</li> </ul>

### Overall Function Check

GBS0010V


Use this procedure to check the overall function of the park/neutral position (PNP) switch circuit. During this check, a 1st trip DTC might not be confirmed.

#### WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "P/N POSI SW" in "DATA MONITOR" mode with CONSULT-II. Then check the "P/N POSI SW" signal under the following conditions.

Position (Selector lever)	Known-good signal
P or N position (A/T)	ON
Neutral position (M/T)	ON
Except above position	OFF

If NG, go to [EC-860, "Diagnostic Procedure"](#) .




#### WITHOUT CONSULT-II

1. Turn ignition switch ON.
2. Check voltage between ECM terminal 102 (PNP switch signal) and ground under the following conditions.

Condition (Selector lever)	Voltage (Known-good data)
P or N position (A/T)	Approx. 0V
Neutral position (M/T)	
Except above position	BATTERY VOLTAGE (11 - 14V)

3. If NG, go to [EC-860, "Diagnostic Procedure"](#) .







# DTC P1706 PNP SWITCH

[VQ TYPE 2]

## Wiring Diagram





GBS0010W

### EC-PNP/SW-01



REFER TO THE FOLLOWING.

(M91) -SUPER MULTIPLE JUNCTION (SMJ)



\* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

MBWA1310E

# DTC P1706 PNP SWITCH

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
102	G (A/T) O (M/T)	PNP switch	<b>[Ignition switch: ON]</b> ● Shift lever: P or N (A/T), Neutral (M/T)	Approximately 0V
			<b>[Ignition switch: ON]</b> ● Except above position	BATTERY VOLTAGE (11 - 14V)

## Diagnostic Procedure A/T MODELS

GBS0010X

### 1. CHECK DTC WITH TCM

Refer to [AT-35, "TROUBLE DIAGNOSIS"](#) .

OK or NG

- OK >> GO TO 2.
- NG >> Repair or replace.

### 2. CHECK STARTING SYSTEM

Turn ignition switch OFF, then turn it to START.

**Does starter motor operate?**

Yes or No

- Yes >> GO TO 3.
- No >> Refer to [SC-30, "STARTING SYSTEM"](#) .

### 3. CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT-I

1. Turn ignition switch OFF.
2. Disconnect A/T assembly harness connector.
3. Disconnect combination meter harness connector.
4. Check harness continuity between A/T assembly terminal 9 and combination meter terminal 17.  
Refer to Wiring Diagram.

**Continuity should exist.**

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

### 4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M91, E101
- Harness connectors E8, F2
- Harness for open or short between A/T assembly and combination meter.

>> Repair open circuit or short to ground or short to power in harness or connectors.

---

**5. CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT-II**

---

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 102 and combination meter terminal 7.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.  
NG >> GO TO 6.

---

**6. DETECT MALFUNCTIONING PART**

---

Check the following.

- Harness connectors E101, M91
- Harness for open or short between ECM and combination meter

>> Repair open circuit or short to ground or short to power in harness or connectors.

---

**7. CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT-III**

---

1. Check harness continuity between A/T assembly terminal 9 and TCM terminal 8.  
Refer to [AT-99, "DTC P0615 START SIGNAL CIRCUIT"](#) .

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.  
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

---

**8. CHECK INTERMITTENT INCIDENT**

---

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> GO TO 9.  
NG >> Repair or replace.

---

**9. REPLACE COMBINATION METER**

---

Refer to [DI-4, "COMBINATION METERS"](#) .

>> **INSPECTION END**

---

## M/T MODELS

### 1. CHECK PNP SWITCH GROUND CIRCUIT

---

1. Turn ignition switch OFF.
2. Disconnect park/neutral position (PNP) switch harness connector.
3. Check harness continuity between PNP switch terminal 2 and ground.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to power.

OK or NG

- OK >> GO TO 3  
NG >> GO TO 2.

### 2. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors F2, E8
- Harness for open or short between PNP switch and ground

>> Repair open circuit or short to power in harness or connectors.

### 3. CHECK PNP SWITCH INPUT SIGNAL CIRCUIT

---

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 102 and PNP switch terminal 1.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.  
NG >> GO TO 4.

### 4. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors E8, F2
- Harness for open or short between PNP switch and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

### 5. CHECK PNP SWITCH

---

Refer to [MT-12, "PARK/NEUTRAL POSITION \(PNP\) SWITCH"](#) .

OK or NG

- OK >> GO TO 6.  
NG >> Replace PNP switch.

### 6. CHECK INTERMITTENT INCIDENT

---

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

# DTC P1715 INPUT SPEED SENSOR (TURBINE REVOLUTION SENSOR)

[VQ TYPE 2]

## DTC P1715 INPUT SPEED SENSOR (TURBINE REVOLUTION SENSOR)

PPF:31935

### Description

GBS0010Y

ECM receives turbine revolution sensor signal from TCM through CAN communication line. ECM uses this signal for engine control.

### CONSULT-II Reference Value in Data Monitor Mode

GBS0010Z

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
I/P PULLY SPD	● Vehicle speed: More than 20 km/h (12MPH)	Almost the same speed as the tachometer indication

### On Board Diagnosis Logic

GBS00110

#### NOTE:

- If DTC P1715 is displayed with DTC U1000, U1001 first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-686, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#).
- If DTC P1715 is displayed with DTC P0605, first perform the trouble diagnosis for DTC P0605. Refer to [EC-746, "DTC P0605 ECM"](#).
- If DTC P1715 is displayed with DTC P0335, first perform the trouble diagnosis for DTC P0335. Refer to [EC-725, "DTC P0335 CKP SENSOR \(POS\)"](#).
- If DTC P1715 is displayed with DTC P0340, P0345 first perform the trouble diagnosis for DTC P0340, P0345. Refer to [EC-732, "DTC P0340, P0345 CMP SENSOR \(PHASE\)"](#).

The MIL will not lights up for this diagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1715 1715	Input speed sensor (Turbine revolution sensor) (TCM output)	Turbine revolution sensor signal is different from the theoretical value calculated by ECM from revolution sensor signal and engine rpm signal.	<ul style="list-style-type: none"><li>● Harness or connectors (The CAN communication line is open or shorted)</li><li>● Harness or connectors (Turbine revolution sensor circuit is open or shorted)</li><li>● TCM</li></ul>

### Diagnostic Procedure

GBS00111

#### 1. CHECK DTC WITH TCM

Check DTC with TCM. Refer to [AT-35, "TROUBLE DIAGNOSIS"](#).

OK or NG

OK >> GO TO 2.

NG >> Perform trouble shooting relevant to DTC indicated.

#### 2. REPLACE TCM

Replace TCM. Refer to [AT-35, "TROUBLE DIAGNOSIS"](#).

>> INSPECTION END

## DTC P1805 BRAKE SWITCH

PFP:25320

### Description

GBS00112

Brake switch signal is applied to the ECM through the stop lamp switch when the brake pedal is depressed. This signal is used mainly to decrease the engine speed when the vehicle is driving.

### CONSULT-II Reference Value in Data Monitor Mode

GBS00113

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
BRAKE SW	● Ignition switch: ON	Brake pedal: Fully released
		Brake pedal: Slightly depressed
		OFF
		ON

### On Board Diagnosis Logic

GBS00114

This self-diagnosis has one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1805 1805	Brake switch	A brake switch signal is not sent to ECM for extremely long time while the vehicle is driving.	<ul style="list-style-type: none"> <li>● Harness or connectors (Stop lamp switch circuit is open or shorted.)</li> <li>● Stop lamp switch</li> </ul>

### FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MIL light up.

Engine operating condition in fail-safe mode

ECM controls the electric throttle control actuator by regulating the throttle opening to a small range. Therefore, acceleration will be poor.

Vehicle condition	Driving condition
When engine is idling	Normal
When accelerating	Poor acceleration

### DTC Confirmation Procedure

GBS00115

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### ④ WITH CONSULT-II

1. Turn ignition switch ON.
2. Fully depress the brake pedal for at least 5 seconds.
3. Erase the DTC with CONSULT-II.
4. Select "DATA MONITOR" mode with CONSULT-II.
5. If DTC is detected, go to [EC-867, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

#### ⊗ WITHOUT CONSULT-II

1. Turn ignition switch ON.
2. Fully depress the brake pedal for at least 5 seconds.
3. Erase the Diagnostic Test Mode II (Self-diagnostic results) memory.

## DTC P1805 BRAKE SWITCH

[VQ TYPE 2]

Refer to [EC-606, "DIAGNOSTIC TEST MODE II — SELF-DIAGNOSTIC RESULTS"](#) .

4. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
5. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
6. If DTC is detected, go to [EC-867, "Diagnostic Procedure"](#) .

A

EC

C

D

E

F

G

H

I

J

K

L

M


# DTC P1805 BRAKE SWITCH

[VQ TYPE 2]


GBS00116

## Wiring Diagram

### EC-BRK/SW-01



- : DETECTABLE LINE FOR DTC
- : NON-DETECTABLE LINE FOR DTC
- ⬡ : WITH A/T
- ⬢ : WITH M/T
- \*1 1: ⬡
- 2: ⬢
- \*2 2: ⬡
- 1: ⬢



E20  
B



4 3  
2 1 E109  
B

1 2 E116  
B

REFER TO THE FOLLOWING.

ⓔ103 - FUSE BLOCK -  
JUNCTION BOX (J/B)

MBWA1420E



# DTC P1805 BRAKE SWITCH

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
101	V	Stop lamp switch	[Ignition switch: OFF] ● Brake pedal: Fully released	Approximately 0V
			[Ignition switch: OFF] ● Brake pedal: Slightly depressed	BATTERY VOLTAGE (11 - 14V)

## Diagnostic Procedure

GBS00117

### 1. CHECK STOP LAMP SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Check the stop lamp when depressing and releasing the brake pedal.


Brake pedal	Stop lamp
Fully released	Not illuminated
Slightly depressed	Illuminated

**OK or NG**


- OK >> GO TO 4.
- NG >> GO TO 2.

### 2. CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

1. Disconnect stop lamp switch (2) harness connector.
  - ASCD brake switch (1)



2. Check voltage between stop lamp switch terminal 1 (A/T) or 2 (M/T) and ground with CONSULT-II or tester.



M/T models

A/T models

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 4.  
 NG >> GO TO 3.

**3. DETECT MALFUNCTIONING PART**

Check the following.

- 10A fuse
- Fuse block (J/B) connector E103
- Harness for open and short between stop lamp switch and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

**4. CHECK STOP LAMP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**


1. Disconnect ECM harness connector.
2. Disconnect stop lamp switch (2) harness connector.
  - ASCD brake switch (1)
3. Check harness continuity between ECM terminal 101 and stop lamp switch terminal 2 (A/T) or 1 (M/T). Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.  
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**5. CHECK STOP LAMP SWITCH**Refer to [EC-869, "Component Inspection"](#) .


OK or NG

- OK >> GO TO 6.  
 NG >> Replace stop lamp switch.


**6. CHECK INTERMITTENT INCIDENT**Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .**>> INSPECTION END**

## Component Inspection STOP LAMP SWITCH

1. Disconnect stop lamp switch (2) harness connector.
  - ASCD brake switch (1)



2. Check continuity between stop lamp switch terminals 1 and 2 under the following conditions.



Conditions	Continuity
Brake pedal: Fully released	Should not exist.
Brake pedal: Slightly depressed	Should exist.

3. If NG, adjust stop lamp switch installation, refer to [BR-6, "BRAKE PEDAL"](#) , and perform step 2 again.

DTC P2122, P2123 APP SENSOR

PFP:18002


Component Description

GBS00119

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometers which transform the accelerator pedal position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the accelerator pedal and feed the voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these signals.

Idle position of the accelerator pedal is determined by the ECM receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for the engine operation such as fuel cut.



CONSULT-II Reference Value in Data Monitor Mode

GBS0011A

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
ACCEL SEN 1 ACCEL SEN 2*	● Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	0.6 - 0.95V
		Accelerator pedal: Fully depressed	Less than 4.75V
CLSD THL POS	● Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	ON
		Accelerator pedal: Slightly depressed	OFF

\*: Accelerator pedal position sensor 2 signal is converted by ECM internally. Thus, it differs from ECM terminal voltage.

On Board Diagnosis Logic

GBS0011B

These self-diagnoses have the one trip detection logic.

NOTE:

If DTC P2122 or P2123 is displayed with DTC P1229, first perform the trouble diagnosis for DTC P1229. Refer to [EC-803, "DTC P1229 SENSOR POWER SUPPLY"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P2122 2122	Accelerator pedal position sensor 1 circuit low input	An excessively low voltage from the APP sensor 1 is sent to ECM.	● Harness or connectors (The APP sensor 1 circuit is open or shorted.) ● Accelerator pedal position sensor (APP sensor 1)
P2123 2123	Accelerator pedal position sensor 1 circuit high input	An excessively high voltage from the APP sensor 1 is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, ECM enters fail-safe mode and the MIL lights up.

Engine operating condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

**DTC Confirmation Procedure****NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

④ **WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-873, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

⊗ **WITHOUT CONSULT-II**

1. Start engine and let it idle for 1 second.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-873, "Diagnostic Procedure"](#) .

# DTC P2122, P2123 APP SENSOR



[VQ TYPE 2]

## Wiring Diagram

GBS0011D

### EC-APPS1-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



MBWA1313E

# DTC P2122, P2123 APP SENSOR

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
82	B	Sensor ground (APP sensor 1)	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed	Approximately 0V
83	O	Sensor ground (APP sensor 2)	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed	Approximately 0V
90	L	Sensor power supply (APP sensor 1)	<b>[Ignition switch: ON]</b>	Approximately 5V
91	G	Sensor power supply (APP sensor 2)	<b>[Ignition switch: ON]</b>	Approximately 5V
98	GR	Accelerator pedal position sensor 2	<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully released	0.3 - 0.45V
			<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully depressed	Less than 2.4V
106	R	Accelerator pedal position sensor 1	<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully released	0.6 - 0.95V
			<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully depressed	Less than 4.75V

## Diagnostic Procedure

GBS0011E

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-685, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

## 2. CHECK APP SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect accelerator pedal position (APP) sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between APP sensor terminal 2 and ground with CONSULT-II or tester.

**Voltage: Approximately 5V**

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



## 3. CHECK APP SENSOR 1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between APP sensor terminal 4 and ECM terminal 82. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 4. CHECK APP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 106 and APP sensor terminal 3. Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 5. CHECK APP SENSOR

Refer to [EC-875, "Component Inspection"](#).

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.



**6. REPLACE ACCELERATOR PEDAL ASSEMBLY**

1. Replace accelerator pedal assembly.
2. Perform [EC-614, "Accelerator Pedal Released Position Learning"](#) .
3. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
4. Perform [EC-614, "Idle Air Volume Learning"](#) .

>> INSPECTION END

**7. CHECK INTERMITTENT INCIDENT**

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

**Component Inspection  
ACCELERATOR PEDAL POSITION SENSOR**

GBS0011F

1. Reconnect all harness connectors disconnected.
2. Turn ignition switch ON.
3. Check voltage between ECM terminals 106 (APP sensor 1 signal), 98 (APP sensor 2 signal) and ground under the following conditions.

Terminal	Accelerator pedal	Voltage
106 (Accelerator pedal position sensor 1)	Fully released	0.6 - 0.95V
	Fully depressed	Less than 4.75V
98 (Accelerator pedal position sensor 2)	Fully released	0.3 - 0.45V
	Fully depressed	Less than 2.4V



4. If NG, replace accelerator pedal assembly and go to next step.
5. Perform [EC-614, "Accelerator Pedal Released Position Learning"](#) .
6. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
7. Perform [EC-614, "Idle Air Volume Learning"](#) .

**Removal and Installation  
ACCELERATOR PEDAL**

GBS0011G

Refer to [ACC-2, "ACCELERATOR CONTROL SYSTEM"](#) .

DTC P2127, P2128 APP SENSOR

PFP:18002


Component Description

GBS0011H

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometers which transform the accelerator pedal position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the accelerator pedal and feed the voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these signals.

Idle position of the accelerator pedal is determined by the ECM receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for the engine operation such as fuel cut.



CONSULT-II Reference Value in Data Monitor Mode

GBS0011I

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
ACCEL SEN 1 ACCEL SEN 2*	● Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	0.6 - 0.95V
		Accelerator pedal: Fully depressed	Less than 4.75V
CLSD THL POS	● Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	ON
		Accelerator pedal: Slightly depressed	OFF

\*: Accelerator pedal position sensor 2 signal is converted by ECM internally. Thus, it differs from ECM terminal voltage.

On Board Diagnosis Logic

GBS0011J

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P2127 2127	Accelerator pedal position sensor 2 circuit low input	An excessively low voltage from the APP sensor 2 is sent to ECM.	<ul style="list-style-type: none"> <li>● Harness or connectors (The APP sensor 2 circuit is open or shorted.) (The TP sensor circuit shorted.)</li> <li>● Accelerator pedal position sensor (APP sensor 2)</li> <li>● Electric throttle control actuator (TP sensor 1 and 2)</li> </ul>
P2128 2128	Accelerator pedal position sensor 2 circuit high input	An excessively high voltage from the APP sensor 2 is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, ECM enters fail-safe mode and the MIL lights up.

Engine operating condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

**DTC Confirmation Procedure****NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

**① WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-880, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

**⊗ WITHOUT CONSULT-II**

1. Start engine and let it idle for 1 second.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-880, "Diagnostic Procedure"](#) .

# DTC P2127, P2128 APP SENSOR



[VQ TYPE 2]

GBS0011L

## Wiring Diagram

EC-APPS2-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



MBWA1314E

# DTC P2127, P2128 APP SENSOR

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	W	Sensor power supply (Throttle position sensor)	[Ignition switch: ON]	Approximately 5V
82	B	Sensor ground (APP sensor 1)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
83	O	Sensor ground (APP sensor 2)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
90	L	Sensor power supply (APP sensor 1)	[Ignition switch: ON]	Approximately 5V
91	G	Sensor power supply (APP sensor 2)	[Ignition switch: ON]	Approximately 5V
98	GR	Accelerator pedal position sensor 2	[Ignition switch: ON] ● Engine: Stopped ● Accelerator pedal: Fully released	0.3 - 0.45V
			[Ignition switch: ON] ● Engine: Stopped ● Accelerator pedal: Fully depressed	Less than 2.4V
106	R	Accelerator pedal position sensor 1	[Ignition switch: ON] ● Engine: Stopped ● Accelerator pedal: Fully released	0.6 - 0.95V
			[Ignition switch: ON] ● Engine: Stopped ● Accelerator pedal: Fully depressed	Less than 4.75V

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

## Diagnostic Procedure

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body, Refer to [EC-685, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

### 2. CHECK APP SENSOR 2 POWER SUPPLY CIRCUIT-I

1. Disconnect accelerator pedal position (APP) sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between APP sensor terminal 1 and ground with CONSULT-II or tester.

**Voltage: Approximately 5V**

#### OK or NG

- OK >> GO TO 7.  
 NG >> GO TO 3.



**3. CHECK APP SENSOR 2 POWER SUPPLY CIRCUIT-II**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between APP sensor terminal 1 and ECM terminal 91.  
Refer to wiring diagram.

**Continuity should exist.**

OK or NG

- OK >> GO TO 4.  
NG >> Repair open circuit.

**4. CHECK THROTTLE POSITION SENSOR 2 POWER SUPPLY CIRCUIT-III**

Check harness for short to power and short to ground, between the following terminals.

ECM terminal	Sensor terminal	Reference Wiring Diagram
91	APP sensor terminal 1	<a href="#">EC-878</a>
47	Electric throttle control actuator terminal 2	<a href="#">EC-885</a>

OK or NG

- OK >> GO TO 5.  
NG >> Repair short to ground or short to power in harness or connectors.

**5. CHECK THROTTLE POSITION SENSOR**

Refer to [EC-889, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 11.  
NG >> GO TO 6.

**6. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR**

1. Replace electric throttle control actuator.
2. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-614, "Idle Air Volume Learning"](#) .

**>> INSPECTION END**

**7. CHECK APP SENSOR 2 GROUND CIRCUIT FOR OPEN AND SHORT**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between APP sensor terminal 5 and ECM terminal 83.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.  
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**8. CHECK APP SENSOR 2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

1. Check harness continuity between ECM terminal 98 and APP sensor terminal 6.  
Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 9.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**9. CHECK APP SENSOR**

Refer to [EC-882, "Component Inspection"](#) .

OK or NG

OK >> GO TO 11.

NG >> GO TO 10.

**10. REPLACE ACCELERATOR PEDAL ASSEMBLY**

1. Replace accelerator pedal assembly.
2. Perform [EC-614, "Accelerator Pedal Released Position Learning"](#) .
3. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
4. Perform [EC-614, "Idle Air Volume Learning"](#) .

>> INSPECTION END

**11. CHECK INTERMITTENT INCIDENT**

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

**Component Inspection  
ACCELERATOR PEDAL POSITION SENSOR**

GBS0011N

1. Reconnect all harness connectors disconnected.
2. Turn ignition switch ON.
3. Check voltage between ECM terminals 106 (APP sensor 1 signal), 98 (APP sensor 2 signal) and ground under the following conditions.

Terminal	Accelerator pedal	Voltage
106 (Accelerator pedal position sensor 1)	Fully released	0.6 - 0.95V
	Fully depressed	Less than 4.75V
98 (Accelerator pedal position sensor 2)	Fully released	0.3 - 0.45V
	Fully depressed	Less than 2.4V



4. If NG, replace accelerator pedal assembly and go to next step.
5. Perform [EC-614, "Accelerator Pedal Released Position Learning"](#) .
6. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
7. Perform [EC-614, "Idle Air Volume Learning"](#) .

**Removal and Installation  
ACCELERATOR PEDAL**

GBS0011O

Refer to [ACC-2, "ACCELERATOR CONTROL SYSTEM"](#) .



**DTC P2135 TP SENSOR**


PF:16119

**Component Description**

GBS0011P

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



**CONSULT-II Reference Value in Data Monitor Mode**

GBS0011Q

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
THRTL SEN 1 THRTL SEN 2*	<ul style="list-style-type: none"> <li>Ignition switch: ON (Engine stopped)</li> <li>Shift lever: D (A/T), 1st (M/T)</li> </ul>	Accelerator pedal: Fully released	More than 0.36V
		Accelerator pedal: Fully depressed	Less than 4.75V

\*: Throttle position sensor 2 signal is converted by ECM internally. Thus, it differs from ECM terminal voltage signal.

**On Board Diagnosis Logic**

GBS0011R

**This self-diagnosis has the one trip detection logic.**

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P2135 2135	Throttle position sensor circuit range/performance	Rationally incorrect voltage is sent to ECM compared with the signals from TP sensor 1 and TP sensor 2.	<ul style="list-style-type: none"> <li>Harness or connector (The TP sensor 1 and 2 circuit is open or shorted.) (The APP sensor 2 circuit is shorted).</li> <li>Electric throttle control actuator (TP sensor 1 and 2)</li> <li>Accelerator pedal position sensor (APP sensor 2)</li> </ul>

**FAIL-SAFE MODE**

When the malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.

Engine operation condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

**DTC Confirmation Procedure****NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

**① WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-887, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

**⊗ WITHOUT CONSULT-II**

1. Start engine and let it idle for 1 second.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-887, "Diagnostic Procedure"](#) .

# DTC P2135 TP SENSOR



[VQ TYPE 2]

## Wiring Diagram

GBS0011T

EC-TPS3-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



MBWA1315E

# DTC P2135 TP SENSOR

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**


**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	W	Sensor power supply (Throttle position sensor)	<b>[Ignition switch: ON]</b>	Approximately 5V
50	W	Throttle position sensor 1	<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully released</li> </ul>	More than 0.36V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully depressed</li> </ul>	Less than 4.75V
66	B	Sensor ground (Throttle position sensor)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 0V
69	R	Throttle position sensor 2	<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully released</li> </ul>	Less than 4.75V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Shift lever: D (A/T), 1st (M/T)</li> <li>● Accelerator pedal: Fully depressed</li> </ul>	More than 0.36V
91	G	Sensor power supply (APP sensor 2)	<b>[Ignition switch: ON]</b>	Approximately 5V

**Diagnostic Procedure**

**1. CHECK GROUND CONNECTIONS**

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body.  
Refer to [EC-685, "Ground Inspection"](#) .



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

**2. CHECK THROTTLE POSITION SENSOR POWER SUPPLY CIRCUIT-I**

1. Disconnect electric throttle control actuator harness connector.
2. Turn ignition switch ON.




3. Check voltage between electric throttle control actuator terminal 2 and ground with CONSULT-II or tester.

**Voltage: Approximately 5V**

OK or NG

- OK >> GO TO 7.  
 NG >> GO TO 3.



### 3. CHECK THROTTLE POSITION SENSOR POWER SUPPLY CIRCUIT-II

---

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between electric throttle control actuator terminal 2 and ECM terminal 47.  
Refer to Wiring Diagram.

**Continuity should exist.**

OK or NG

- OK >> GO TO 4.  
NG >> Repair open circuit.

### 4. CHECK THROTTLE POSITION SENSOR POWER SUPPLY CIRCUIT-III

---

Check harness for short to power and short to ground, between the following terminals.

ECM terminal	Sensor terminal	Reference Wiring Diagram
47	Electric throttle control actuator terminal 2	<a href="#">EC-885</a>
91	APP sensor terminal 1	<a href="#">EC-878</a>

OK or NG

- OK >> GO TO 5.  
NG >> Repair short to ground or short to power in harness or connectors.

### 5. CHECK APP SENSOR

---

Refer to [EC-882, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 11.  
NG >> GO TO 6.

### 6. REPLACE ACCELERATOR PEDAL ASSEMBLY

---

1. Replace accelerator pedal assembly.
2. Perform [EC-614, "Accelerator Pedal Released Position Learning"](#) .
3. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
4. Perform [EC-614, "Idle Air Volume Learning"](#) .

>> INSPECTION END

### 7. CHECK THROTTLE POSITION SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

---

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between electric throttle control actuator terminal 4 and ECM terminal 66.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.  
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**8. CHECK THROTTLE POSITION SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

1. Check harness continuity between ECM terminal 50 and electric throttle control actuator terminal 1, ECM terminal 69 and electric throttle control actuator terminal 3.  
Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 9.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**9. CHECK THROTTLE POSITION SENSOR**

Refer to [EC-889, "Component Inspection"](#).

OK or NG

OK >> GO TO 11.

NG >> GO TO 10.

**10. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR**

1. Replace the electric throttle control actuator.
2. Perform [EC-614, "Throttle Valve Closed Position Learning"](#).
3. Perform [EC-614, "Idle Air Volume Learning"](#).

>> INSPECTION END

**11. CHECK INTERMITTENT INCIDENT**

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

>> INSPECTION END


**Component Inspection  
THROTTLE POSITION SENSOR**

GBS0011V

1. Reconnect all harness connectors disconnected.
2. Perform [EC-614, "Throttle Valve Closed Position Learning"](#).
3. Turn ignition switch ON.
4. Set selector lever to D position (A/T), 1st position (M/T).
5. Check voltage between ECM terminals 50 (TP sensor 1 signal), 69 (TP sensor 2 signal) and ground under the following conditions.

Terminal	Accelerator pedal	Voltage
50 (Throttle position sensor 1)	Fully released	More than 0.36V
	Fully depressed	Less than 4.75V
69 (Throttle position sensor 2)	Fully released	Less than 4.75V
	Fully depressed	More than 0.36V

6. If NG, replace electric throttle control actuator and go to the next step.
7. Perform [EC-614, "Throttle Valve Closed Position Learning"](#).
8. Perform [EC-614, "Idle Air Volume Learning"](#).



---

**Removal and Installation**  
**ELECTRIC THROTTLE CONTROL ACTUATOR**

GBS0011W

Refer to [EM-18, "INTAKE MANIFOLD COLLECTOR"](#) .



DTC P2138 APP SENSOR

PFP:18002


Component Description

GBS0011X

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometers which transform the accelerator pedal position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the accelerator pedal and feed the voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these signals.

Idle position of the accelerator pedal is determined by the ECM receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for the engine operation such as fuel cut.



CONSULT-II Reference Value in Data Monitor Mode

GBS0011Y

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
ACCEL SEN 1 ACCEL SEN 2*	● Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	0.6 - 0.95V
		Accelerator pedal: Fully depressed	Less than 4.75V
CLSD THL POS	● Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	ON
		Accelerator pedal: Slightly depressed	OFF

\*: Accelerator pedal position sensor 2 signal is converted by ECM internally. Thus, it differs from ECM terminal voltage.

On Board Diagnosis Logic

GBS0011Z

This self-diagnosis has the one trip detection logic.

NOTE:

If DTC P2138 is displayed with DTC P1229, first perform the trouble diagnosis for DTC P1229. Refer to [EC-803, "DTC P1229 SENSOR POWER SUPPLY"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P2138 2138	Accelerator pedal position sensor circuit range/performance	Rationally incorrect voltage is sent to ECM compared with the signals from APP sensor 1 and APP sensor 2.	<ul style="list-style-type: none"> <li>● Harness or connector (The APP sensor 1 and 2 circuit is open or shorted.) (The TP sensor circuit is shorted.)</li> <li>● Accelerator pedal position sensor 1 and 2</li> <li>● Electric throttle control actuator (TP sensor 1 and 2)</li> </ul>

FAIL-SAFE MODE

When the malfunction is detected, ECM enters fail-safe mode and the MIL lights up.

Engine operating condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

## DTC Confirmation Procedure

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION:**

**Before performing the following procedure, confirm that battery voltage is more than 10V at idle.**

**④ WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-895, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

**⊗ WITHOUT CONSULT-II**

1. Start engine and let it idle for 1 second.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-895, "Diagnostic Procedure"](#) .



# DTC P2138 APP SENSOR



[VQ TYPE 2]

GBS00121

## Wiring Diagram

EC-APPS3-01

 : DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



MBWA1316E

# DTC P2138 APP SENSOR

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**


**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	W	Sensor power supply (Throttle position sensor)	<b>[Ignition switch: ON]</b>	Approximately 5V
82	B	Sensor ground (APP sensor 1)	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed	Approximately 0V
83	O	Sensor ground (APP sensor 2)	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed	Approximately 0V
90	L	Sensor power supply (APP sensor 1)	<b>[Ignition switch: ON]</b>	Approximately 5V
91	G	Sensor power supply (APP sensor 2)	<b>[Ignition switch: ON]</b>	Approximately 5V
98	GR	Accelerator pedal position sensor 2	<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully released	0.3 - 0.45V
			<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully depressed	Less than 2.4V
106	R	Accelerator pedal position sensor 1	<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully released	0.6 - 0.95V
			<b>[Ignition switch: ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully depressed	Less than 4.75V

## Diagnostic Procedure

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-685, "Ground Inspection"](#).



↙ : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

### 2. CHECK APP SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect accelerator pedal position (APP) sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between APP sensor terminal 2 and ground with CONSULT-II or tester.

**Voltage: Approximately 5V**

#### OK or NG

- OK >> GO TO 3.  
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.




### 3. CHECK APP SENSOR 2 POWER SUPPLY CIRCUIT-I

Check voltage between APP sensor terminal 1 and ground with CONSULT-II or tester.

**Voltage: Approximately 5V**

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 4.



### 4. CHECK APP SENSOR 2 POWER SUPPLY CIRCUIT-II

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between APP sensor terminal 1 and ECM terminal 91. Refer to wiring diagram.

**Continuity should exist.**

OK or NG

- OK >> GO TO 5.
- NG >> Repair open circuit.

### 5. CHECK APP SENSOR 2 POWER SUPPLY CIRCUIT-III

Check harness for short to power and short to ground, between the following terminals.

ECM terminal	Sensor terminal	Reference Wiring Diagram
91	APP sensor terminal 1	<a href="#">EC-893</a>
47	Electric throttle control actuator terminal 2	<a href="#">EC-885</a>

OK or NG

- OK >> GO TO 6.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

### 6. CHECK THROTTLE POSITION SENSOR

Refer to [EC-889, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 12.
- NG >> GO TO 7.

### 7. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace electric throttle control actuator.
2. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-614, "Idle Air Volume Learning"](#) .

>> INSPECTION END

**8. CHECK APP SENSOR GROUND CIRCUIT FOR OPEN AND SHORT**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between APP sensor terminals 4 and ECM terminal 82, APP sensor terminal 5 and ECM terminal 83.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 9.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**9. CHECK APP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

1. Check harness continuity between ECM terminal 106 and APP sensor terminal 3, ECM terminal 98 and APP sensor terminal 6.  
Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 10.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**10. CHECK APP SENSOR**

Refer to [EC-897, "Component Inspection"](#) .

OK or NG

OK >> GO TO 12.

NG >> GO TO 11.

**11. REPLACE ACCELERATOR PEDAL ASSEMBLY**

1. Replace accelerator pedal assembly.
2. Perform [EC-614, "Accelerator Pedal Released Position Learning"](#) .
3. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .
4. Perform [EC-614, "Idle Air Volume Learning"](#) .

**>> INSPECTION END**

**12. CHECK INTERMITTENT INCIDENT**

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

**>> INSPECTION END**

### Component Inspection

#### ACCELERATOR PEDAL POSITION SENSOR

GBS00123


1. Reconnect all harness connectors disconnected.
2. Turn ignition switch ON.

# DTC P2138 APP SENSOR

[VQ TYPE 2]

3. Check voltage between ECM terminals 106 (APP sensor 1 signal), 98 (APP sensor 2 signal) and ground under the following conditions.

Terminal	Accelerator pedal	Voltage
106 (Accelerator pedal position sensor 1)	Fully released	0.6 - 0.95V
	Fully depressed	Less than 4.75V
98 (Accelerator pedal position sensor 2)	Fully released	0.3 - 0.45V
	Fully depressed	Less than 2.4V



4. If NG, replace accelerator pedal assembly and go to next step.  
5. Perform [EC-614, "Accelerator Pedal Released Position Learning"](#) .  
6. Perform [EC-614, "Throttle Valve Closed Position Learning"](#) .  
7. Perform [EC-614, "Idle Air Volume Learning"](#) .

## Removal and Installation ACCELERATOR PEDAL

GBS00124

Refer to [ACC-2, "ACCELERATOR CONTROL SYSTEM"](#) .



# ASCD BRAKE SWITCH

[VQ TYPE 2]


## ASCD BRAKE SWITCH

PPF:25320

### Component Description

GBS00125

When the brake pedal is depressed, ASCD brake switch (1) is turned OFF and stop lamp switch (2) is turned ON. ECM detects the state of the brake pedal by this input of two kinds (ON/OFF signal). Refer to [EC-591, "AUTOMATIC SPEED CONTROL DEVICE \(ASCD\)"](#) for the ASCD function.



### CONSULT-II Reference Value in Data Monitor Mode

GBS00126

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
BRAKE SW 1 (ASCD brake switch)	● Ignition switch: ON	Brake pedal: Fully released (A/T) Clutch pedal and brake pedal: Fully released (M/T)	ON
		Brake pedal: Slightly depressed (A/T) Clutch pedal and/or brake pedal: Slightly depressed (M/T)	OFF
BRAKE SW 2 (Stop lamp switch)	● Ignition switch: ON	Brake pedal: Fully released	OFF
		Brake pedal: Slightly depressed	ON



# ASC D BRAKE SWITCH

[VQ TYPE 2]

GBS00127

## Wiring Diagram

### EC-ASCBOF-01



(E20) B



4 3  
2 1

(E109) W

2 1  
(E110) BR

1 2  
(E111) L

1 2  
(E116) B

REFER TO THE FOLLOWING.

(E103) - FUSE BLOCK - JUNCTION BOX (J/B)

MBWA1421E

# ASCD BRAKE SWITCH

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
101	V	Stop lamp switch	<b>[Ignition switch: OFF]</b> ● Brake pedal: Fully released	Approximately 0V
			<b>[Ignition switch: OFF]</b> ● Brake pedal: Slightly depressed	BATTERY VOLTAGE (11 - 14V)
108	LG	ASCD brake switch	<b>[Ignition switch: ON]</b> ● Brake pedal: Slightly depressed (A/T) ● Clutch pedal and/or brake pedal: Slightly depressed (M/T)	Approximately 0V
			<b>[Ignition switch: ON]</b> ● Brake pedal: Fully released (A/T) ● Clutch pedal and brake pedal: Fully released (M/T)	BATTERY VOLTAGE (11 - 14V)

## Diagnostic Procedure A/T MODELS


GBS00128

### 1. CHECK OVERALL FUNCTION-I

**With CONSULT-II**

- Turn ignition switch ON.
- Select "BRAKE SW1" in "DATA MONITOR" mode with CONSULT-II.
- Check "BRAKE SW1" indication under the following conditions.

CONDITION	INDICATION
Brake pedal: Slightly depressed	OFF
Brake pedal: Fully released	ON




**Without CONSULT-II**

- Turn ignition switch ON.
- Check voltage between ECM terminal 108 and ground under the following conditions.

CONDITION	VOLTAGE
Brake pedal: Slightly depressed	Approximately 0V
Brake pedal: Fully released	Battery voltage

**OK or NG**

- OK >> GO TO 2.  
NG >> GO TO 3.




## 2. CHECK OVERALL FUNCTION-II

**With CONSULT-II**

Check "BRAKE SW2" indication in "DATA MONITOR" mode.

CONDITION	INDICATION
Brake pedal: Fully released	OFF
Brake pedal: Slightly depressed	ON




**Without CONSULT-II**

Check voltage between ECM terminal 101 and ground under the following conditions.

CONDITION	VOLTAGE
Brake pedal: Fully released	Approximately 0V
Brake pedal: Slightly depressed	Battery voltage


OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 7.



## 3. CHECK ASCD BRAKE SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch (1) harness connector.
  - Stop lamp switch (2)
3. Turn ignition switch ON.




4. Check voltage between ASCD brake switch terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.



## 4. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse
- Harness for open or short between ASCD brake switch and fuse

>> Repair open circuit or short to ground in harness or connectors.

## 5. CHECK ASCD BRAKE SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 108 and ASCD brake switch terminal 2.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 6.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 6. CHECK ASCD BRAKE SWITCH

Refer to [EC-910, "Component Inspection"](#)


OK or NG

OK >> GO TO 11.

NG >> Replace ASCD brake switch.

## 7. CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch (2) harness connector.
- ASCD brake switch (1)




3. Check voltage between stop lamp switch terminal 1 and ground with CONSULT -II or tester.

**Voltage: Battery voltage**

OK or NG

OK >> GO TO 9.

NG >> GO TO 8.



---

## 8. DETECT MALFUNCTIONING PART

---

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse
- Harness for open or short between stop lamp switch and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 9. CHECK STOP LAMP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 101 and stop lamp switch terminal 2.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 10.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 10. CHECK STOP LAMP SWITCH

---

Refer to [EC-910, "Component Inspection"](#)

OK or NG

OK >> GO TO 11.

NG >> Replace stop lamp switch.

---

## 11. CHECK INTERMITTENT INCIDENT

---

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**


**M/T MODELS**

**1. CHECK OVERALL FUNCTION-I**

**② With CONSULT-II**

1. Turn ignition switch ON.
2. Select "BRAKE SW1" in "DATA MONITOR" mode with CONSULT-II.
3. Check "BRAKE SW1" indication under the following conditions.


CONDITION	INDICATION
Clutch pedal and/or brake pedal: Slightly depressed	OFF
Clutch pedal and brake pedal: Fully released	ON



**⊗ Without CONSULT-II**

1. Turn ignition switch ON.
2. Check voltage between ECM terminal 108 and ground under the following conditions.

CONDITION	VOLTAGE
Clutch pedal and/or brake pedal: Slightly depressed	Approximately 0V
Clutch pedal and brake pedal: Fully released	Battery voltage



**OK or NG**

- OK >> GO TO 2.
- NG >> GO TO 3.

# ASCD BRAKE SWITCH


[VQ TYPE 2]

## 2. CHECK OVERALL FUNCTION-II

### ④ With CONSULT-II

Check "BRAKE SW2" indication in "DATA MONITOR" mode.


CONDITION	INDICATION
Brake pedal: Fully released	OFF
Brake pedal: Slightly depressed	ON



### ⊗ Without CONSULT-II

Check voltage between ECM terminal 101 and ground under the following conditions.

CONDITION	VOLTAGE
Brake pedal: Fully released	Approximately 0V
Brake pedal: Slightly depressed	Battery voltage




### OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 10.



## 3. CHECK ASCD CLUTCH SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ASCD clutch switch harness connector.
3. Turn ignition switch ON.




4. Check voltage between ASCD clutch switch terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**


OK or NG

- OK >> GO TO 8.  
 NG >> GO TO 4.



## 4. CHECK ASCD BRAKE SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch harness connector.
3. Turn ignition switch ON.




4. Check voltage between ASCD brake switch terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 6.  
 NG >> GO TO 5.



---

## 5. DETECT MALFUNCTIONING PART

---

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse
- Harness for open or short between ASCD brake switch and fuse

>> Repair open circuit or short to ground in harness or connectors.

---

## 6. CHECK ASCD BRAKE SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

1. Turn ignition switch OFF.
2. Check harness continuity between ASCD brake switch terminal 2 and ASCD clutch switch terminal 1. Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 7.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 7. CHECK ASCD BRAKE SWITCH

---

Refer to [EC-910, "Component Inspection"](#) .

OK or NG

OK >> GO TO 14.

NG >> Replace ASCD brake switch.

---

## 8. CHECK ASCD BRAKE SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 108 and ASCD clutch switch terminal 2. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 9.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 9. CHECK ASCD CLUTCH SWITCH

---

Refer to [EC-910, "Component Inspection"](#) .


OK or NG

OK >> GO TO 14.

NG >> Replace ASCD clutch switch.

## 10. CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch harness connector.




3. Check voltage between stop lamp switch terminal 2 and ground with CONSULT -II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 12.
- NG >> GO TO 11.



## 11. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse
- Harness for open or short between stop lamp switch and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 12. CHECK STOP LAMP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 101 and stop lamp switch terminal 1. Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 13.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 13. CHECK STOP LAMP SWITCH

Refer to [EC-910, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 14.
- NG >> Replace stop lamp switch.

## 14. CHECK INTERMITTENT INCIDENT

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


### Component Inspection ASC D BRAKE SWITCH

GBS00129

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch harness connector.
3. Check continuity between ASCD brake switch terminals 1 and 2 under the following conditions.

Condition	Continuity
Brake pedal: Fully released	Should exist
Brake pedal: Slightly depressed	Should not exist

If NG, adjust ASCD brake switch installation, refer to [BR-6, "BRAKE PEDAL"](#) , and perform step 3 again.




### ASC D CLUTCH SWITCH

1. Turn ignition switch OFF.
2. Disconnect ASCD clutch switch harness connector.
3. Check continuity between ASCD clutch switch terminals 1 and 2 under the following conditions.


Condition	Continuity
Clutch pedal: Fully released	Should exist
Clutch pedal: Slightly depressed	Should not exist

If NG, adjust ASCD clutch switch installation, refer to [CL-6, "CLUTCH PEDAL"](#) , and perform step 3 again.



### STOP LAMP SWITCH

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch harness connector.
3. Check continuity between stop lamp switch terminals 1 and 2 under the following conditions.



Condition	Continuity
Brake pedal: Fully released	Should not exist
Brake pedal: Slightly depressed	Should exist

# ASCD BRAKE SWITCH

[VQ TYPE 2]

---

If NG, adjust stop lamp switch installation, refer to [BR-6, "BRAKE PEDAL"](#) , and perform step 3 again.

A

EC

C

D

E

F

G

H

I

J

K

L

M

## ASC D INDICATOR

PFP:24814

### Component Description

GBS0012A

ASC D indicator lamp illuminates to indicate ASC D operation status. Lamp has two indicators, CRUISE and SET, and is integrated in combination meter.

CRUISE indicator illuminates when MAIN switch on ASC D steering switch is turned ON to indicated that ASC D system is ready for operation.

SET indicator illuminates when following conditions are met.

- CRUISE indicator is illuminated.
- SET/COAST switch on ASC D steering switch is turned ON while vehicle speed is within the range of ASC D setting.

SET indicator remains lit during ASC D control.

Refer to [EC-591, "AUTOMATIC SPEED CONTROL DEVICE \(ASC D\)"](#) for the ASC D function.

### CONSULT-II Reference Value in Data Monitor Mode

GBS0012B

Specification data are reference value.

MONITOR ITEM	CONDITION		SPECIFICATION
CRUISE LAMP	● Ignition switch: ON	● MAIN switch: Pressed at the 1st time → at the 2nd time	ON → OFF
SET LAMP	● MAIN switch: ON ● When vehicle speed is between 40 km/h (25 MPH) and 175 km/h (109 MPH)	● ASC D: Operating ● ASC D: Not operating	ON OFF




# ASC D INDICATOR

[VQ TYPE 2]

GBS0012C

## Wiring Diagram

### EC-ASCIND-01



REFER TO THE FOLLOWING.

(M91) - SUPER MULTIPLE JUNCTION (SMJ)

(M88) - FUSE BLOCK - JUNCTION BOX (J/B)

MBWA1325E

## Diagnostic Procedure

### 1. CHECK OVERALL FUNCTION

Check ASC D indicator under the following conditions.

ASC D INDICATOR	CONDITION		SPECIFICATION
CRUISE LAMP	<ul style="list-style-type: none"> <li>Ignition switch: ON</li> </ul>	<ul style="list-style-type: none"> <li>MAIN switch: pressed at the 1st time → at the 2nd time</li> </ul>	ON → OFF
SET LAMP	<ul style="list-style-type: none"> <li>MAIN switch: ON</li> <li>When vehicle speed is between 40 km/h (25 MPH) and 175 km/h (109 MPH)</li> </ul>	<ul style="list-style-type: none"> <li>ASC D: Operating</li> </ul>	ON
		<ul style="list-style-type: none"> <li>ASC D: Not operating</li> </ul>	OFF

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 2.

### 2. CHECK DTC

Check that DTC U1000 or U1001 is not displayed.

OK or NG

OK >> GO TO 3.

NG >> Perform trouble diagnoses for DTC U1000, U1001. Refer to [EC-686, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#) .

### 3. CHECK COMBINATION METER FUNCTION

Refer to [DI-4, "COMBINATION METERS"](#) .

OK or NG

OK >> GO TO 4.

NG >> Go to [DI-4, "COMBINATION METERS"](#) .

### 4. CHECK INTERMITTENT INCIDENT

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**



## ELECTRICAL LOAD SIGNAL

PFP:25350

### Description

GBS0012E

The electrical load signal (Headlamp switch signal, etc.) is transferred through the CAN communication line from BCM to ECM via IPDM E/R.

### CONSULT-II Reference Value in Data Monitor Mode

GBS0012F

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
LOAD SIGNAL	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> </ul>	Rear window defogger switch ON and/or lighting switch is in 2nd. <span style="float: right;">ON</span>
		Rear window defogger switch and lighting switch are OFF. <span style="float: right;">OFF</span>
HEATER FAN SW	<ul style="list-style-type: none"> <li>● Engine: After warning up, idle the engine</li> </ul>	Heater fan switch: ON <span style="float: right;">ON</span>
		Heater fan switch: OFF <span style="float: right;">OFF</span>

### Diagnostic Procedure

GBS0012G


#### 1. CHECK LOAD SIGNAL CIRCUIT OVERALL FUNCTION-I

1. Turn ignition switch ON.
2. Connect CONSULT-II and select "DATA MONITOR" mode.
3. Select "LOAD SIGNAL" and check indication under the following conditions.

Condition	Indication
Rear window defogger switch: ON	ON
Rear window defogger switch: OFF	OFF

#### OK or NG

- OK >> GO TO 2.
- NG >> GO TO 4.




#### 2. CHECK LOAD SIGNAL CIRCUIT OVERALL FUNCTION-II

Check "LOAD SIGNAL" indication under the following conditions.

Condition	Indication
Lighting switch: ON at 2nd position	ON
Lighting switch: OFF	OFF

#### OK or NG

- OK >> GO TO 3.
- NG >> GO TO 5.



**3. CHECK HEATER FAN SIGNAL CIRCUIT OVERALL FUNCTION**

Select "HEATER FAN SW" and check indication under the following conditions.

Condition	Indication
Heater fan control switch: ON	ON
Heater fan control switch: OFF	OFF

**OK or NG**

OK >> **INSPECTION END**  
 NG >> GO TO 6.

DATA MONITOR	
MONITORING	NO DTC
HEATER FAN SW	ON

PBIB1995E

**4. CHECK REAR WINDOW DEFOGGER SYSTEM**

Refer to [GW-45, "REAR WINDOW DEFOGGER"](#) .

>> **INSPECTION END**

**5. CHECK HEADLAMP SYSTEM**

Refer to [LT-4, "HEADLAMP"](#) or [LT-31, "HEADLAMP AIMING CONTROL \(MANUAL\)"](#) .

>> **INSPECTION END**

**6. CHECK HEATER FAN CONTROL SYSTEM**

Refer to [MTC-32, "TROUBLE DIAGNOSIS"](#) .

>> **INSPECTION END**

# EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[VQ TYPE 2]

## EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

PFP:14920

### Description SYSTEM DESCRIPTION

GBS0012H

Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed*1	EVAP canister purge flow control	EVAP canister purge vol- ume control solenoid valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Battery	Battery voltage*1		
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Accelerator pedal position		
Air fuel ratio (A/F) sensor 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)		
Wheel sensor	Vehicle speed*2		


\*1: ECM determines the start signal status by the signals of engine speed and battery voltage.

\*2: This signal is sent to the ECM through CAN communication line.

This system controls flow rate of fuel vapor from the EVAP canister. The opening of the vapor by-pass passage in the EVAP canister purge volume control solenoid valve changes to control the flow rate. The EVAP canister purge volume control solenoid valve repeats ON/OFF operation according to the signal sent from the ECM. The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions. When the engine is operating, the flow rate of fuel vapor from the EVAP canister is regulated as the air flow changes.

### COMPONENT DESCRIPTION

The EVAP canister purge volume control solenoid valve uses a ON/OFF duty to control the flow rate of fuel vapor from the EVAP canister. The EVAP canister purge volume control solenoid valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of fuel vapor that will flow through the valve.



### CONSULT-II Reference Value in Data Monitor Mode

GBS0012I

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
PURG VOL C/V	● Engine: After warming up	Idle	0%
	● Shift lever: P or N (A/T), Neutral (M/T)	2,000 rpm	—
	● Air conditioner switch: OFF		
	● No load		

# EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE




[VQ TYPE 2]

GBS0012J

## Wiring Diagram

### EC-PRGVLV-01

— : DETECTABLE LINE FOR DTC  
 - - - : NON-DETECTABLE LINE FOR DTC



MBWA1335E



# EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
45	P	EVAP canister purge volume control solenoid valve	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Idle speed</li> <li>● Accelerator pedal is not depressed even slightly, after engine starting</li> </ul>	<p>BATTERY VOLTAGE (11 - 14V)★</p> 
			<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Engine speed: About 2,000 rpm (More than 100 seconds after starting engine)</li> </ul>	<p>BATTERY VOLTAGE (11 - 14V)★</p> 
111	BR	ECM relay (Self shut-off)	<p><b>[Engine is running]</b> <b>[Ignition switch: OFF]</b></p> <ul style="list-style-type: none"> <li>● For a few seconds after turning ignition switch OFF</li> </ul>	0 - 1.5V
			<p><b>[Ignition switch: OFF]</b></p> <ul style="list-style-type: none"> <li>● More than a few seconds after turning ignition switch OFF</li> </ul>	BATTERY VOLTAGE (11 - 14V)
119 120	R P	Power supply for ECM	<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[VQ TYPE 2]


GBS0012K

## Diagnostic Procedure

### 1. CHECK OVERALL FUNCTION

#### With CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect the EVAP purge hose connected to the EVAP canister.
3. Turn ignition switch ON.



4. Select "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II.
5. Start engine and let it idle.
6. Change the valve opening percentage with touching "Qu" or "Qd" on CONSULT-II screen, and check for vacuum existence at the EVAP purge hose under the following conditions.

Conditions (PURG VOL CONT/V)	Vacuum
0%	Should not exist.
100%	Should exist.


ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XX %
A/F ALPHA-B2	XX %

PBI B1678E

#### Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect the EVAP purge hose connected to the EVAP canister.
3. Start engine and let it idle for at least 100 seconds.
4. Check for vacuum existence at the EVAP purge hose under the following conditions.

Conditions	Vacuum
At idle	Should not exist.
Engine speed: About 2,000 rpm.	Should exist.



#### OK or NG

- OK >> GO TO 2.  
 NG >> GO TO 3.

### 2. CHECK EVAP CANISTER

Refer to [EC-597, "Component Inspection"](#).

#### OK or NG

- OK >> **INSPECTION END**  
 NG >> Replace EVAP canister.

# EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[VQ TYPE 2]

## 3. CHECK EVAP PURGE LINE


Check EVAP purge line (pipe, rubber tube, fuel tank and EVAP canister) for cracks or improper connection. Refer to [EC-595, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 4.
- NG >> Repair or reconnect the hose.

## 4. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect EVAP canister purge volume control solenoid valve (1) harness connector.
  - ⇐: Vehicle front
3. Turn ignition switch ON.




4. Check voltage between EVAP canister purge volume control solenoid valve terminal 2 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



## 5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E9, F4
- Harness for open or short between EVAP canister purge volume control solenoid valve and IPDM E/R
- Harness for open or short between EVAP canister purge volume control solenoid valve and ECM

>> Repair harness or connectors.

# EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[VQ TYPE 2]

## 6. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 45 and EVAP canister purge volume control solenoid valve terminal 1. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK (With CONSULT-II)>>GO TO 7.

OK (Without CONSULT-II)>>GO TO 8.

NG >> Repair open circuit or short to ground or short to power in harness connectors.

## 7. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

 **With CONSULT-II**

1. Reconnect all harness connectors disconnected.
2. Start engine.
3. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.

OK or NG

OK >> GO TO 9.

NG >> GO TO 8.

ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XX %
A/F ALPHA-B2	XX %

PBIB1678E

## 8. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Refer to [EC-923, "Component Inspection"](#) .

OK or NG

OK >> GO TO 9.

NG >> Replace EVAP canister purge volume control solenoid valve.

## 9. CHECK INTERMITTENT INCIDENT

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END



# EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[VQ TYPE 2]

GBS0012L


## Component Inspection

### EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

#### ④ With CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve using "ACTIVE TEST" mode with CONSULT-II under the following conditions.


Condition (PURG VOL CONT/V value)	Air passage continuity between (A) and (B)
100%	Yes
0%	No



#### ⊗ Without CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.

Condition	Air passage continuity between (A) and (B)
12V direct current supply between terminals 1 and 2	Yes
No supply	No



## Removal and Installation

### EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Refer to [EM-18, "INTAKE MANIFOLD COLLECTOR"](#) .

GBS0012M

## EVAP CANISTER VENT CONTROL VALVE

PFP:14935



### Component Description

GBS0012N

The EVAP canister vent control valve is located on the EVAP canister.

This solenoid valve is not used for engine control, and always remains open.

If the vent is closed by any reason under EVAP purge conditions, the evaporative emission control system is depressured and EVAP canister may be damaged.




# EVAP CANISTER VENT CONTROL VALVE

[VQ TYPE 2]

GBS00120

## Wiring Diagram


### EC-VENT-01



: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC

REFER TO PG-POWER.

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



REFER TO THE FOLLOWING.

(C1) - SUPER MULTIPLE JUNCTION (SMJ)

# EVAP CANISTER VENT CONTROL VALVE

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
111	BR	ECM relay (Self shut-off)	[Engine is running] [Ignition switch: OFF] ● For a few seconds after turning ignition switch OFF	0 - 1.5V
			[Ignition switch: OFF] ● More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14V)
117	G	EVAP canister vent control valve	[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14V)

## Diagnostic Procedure

GBS0012P

### 1. CHECK OVERALL FUNCTION


1. Turn ignition switch OFF.
2. Remove EVAP canister vent control valve with its harness connector connected from EVAP canister.
3. Start engine.



4. Blow air into port **A** and check that it flows freely out of port **B**.

OK or NG

- OK >> **INSPECTION END**  
 NG >> GO TO 2.




## 2. CHECK EVAP CANISTER VENT CONTROL VALVE POWER SUPPLY CIRCUIT

1. Disconnect EVAP canister vent control valve harness connector.
2. Turn ignition switch ON.
3. Check voltage between EVAP canister vent control valve terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



## 3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E107, C1
- Harness for open or short between EVAP canister vent control valve and IPDM E/R

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 4. CHECK EVAP CANISTER VENT CONTROL VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 117 and EVAP canister vent control valve terminal 2. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.

## 5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors C1, E107
- Harness for open or short between EVAP canister vent control valve and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 6. CHECK EVAP CANISTER VENT CONTROL VALVE

Refer to [EC-928, "Component Inspection"](#).

OK or NG

- OK >> GO TO 7.
- NG >> Replace EVAP canister vent control valve.

## 7. CHECK INTERMITTENT INCIDENT


Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

### Component Inspection EVAP CANISTER VENT CONTROL VALVE

GBS0012Q

1. Remove EVAP canister vent control valve from EVAP canister.
2. Check portion **B** of EVAP canister vent control valve for being rusted.




3. Check air passage continuity and operation delay time under the following conditions.  
**Make sure new O-ring is installed properly.**

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	No
OFF	Yes

**Operation takes less than 1 second.**

If NG, replace EVAP canister vent control valve.  
If OK, go to next step.

4. Clean the air passage (Portion **A** to **B** ) of EVAP canister vent control valve using an air blower.
5. Perform step 3 again.




## FUEL INJECTOR

PDF:16600

### Component Description

GBS0012R

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the fuel injector circuit, the coil in the fuel injector is energized. The energized coil pulls the ball valve back and allows fuel to flow through the fuel injector into the intake manifold. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the fuel injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.



### CONSULT-II Reference Value in Data Monitor Mode

GBS0012S

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
B/FUEL SCHDL	See <a href="#">EC-667</a> , "TROUBLE DIAGNOSIS - SPECIFICATION VALUE".		
INJ PULSE-B1 INJ PULSE-B2	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Shift lever: P or N (A/T), Neutral (M/T)</li> <li>● Air conditioner switch: OFF</li> <li>● No load</li> </ul>	Idle	2.0 - 3.0 msec
		2,000 rpm	1.9 - 2.9 msec



# FUEL INJECTOR

[VQ TYPE 2]

GBS0012T

## Wiring Diagram

### EC-INJECT-01



MBWA1321E





# FUEL INJECTOR

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	
21	W	Fuel injector No. 5	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p>SEC984C</p>	
22	LG	Fuel injector No. 3		<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p>SEC985C</p>
23	SB	Fuel injector No. 1			
40	V	Fuel injector No. 6			
41	R	Fuel injector No. 4			
42	O	Fuel injector No. 2			

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

GBS0012U

### 1. INSPECTION START

Turn ignition switch to START.

**Is any cylinder ignited?**

Yes or No

Yes (With CONSULT-II)>>GO TO 2.

Yes (Without CONSULT-II)>>GO TO 3.

No >> GO TO 7.

### 2. CHECK OVERALL FUNCTION

Ⓟ **With CONSULT-II**

1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
3. Make sure that each circuit produces a momentary engine speed drop.

ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0133E

OK or NG


OK >> **INSPECTION END**

NG >> GO TO 7.

## 3. CHECK FUNCTION OF FUEL INJECTOR-I

⊗ Without CONSULT-II


1. Stop engine.
2. Disconnect harness connector F101 (1), F7 (2).
  - ⇐: Vehicle front
3. Turn ignition switch ON.



4. Check voltage between harness connector F7 terminal 3 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

5. Turn ignition switch OFF.
6. Disconnect ECM harness connector.
7. Check harness continuity between harness connector F7 and ECM as follows.  
Refer to Wiring Diagram.



Cylinder	Harness connector F7 terminal	ECM terminal
1	2	23
3	1	22
5	4	21

**Continuity should exist.**

8. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

## 4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E9, F4
- IPDM E/R harness connector E12
- 15A fuse
- Harness for open or short between harness connector F7 and fuse
- Harness for open or short between harness connector F7 and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 5. CHECK FUNCTION OF FUEL INJECTOR-II


Provide battery voltage between harness connector F101 as follows and then interrupt it. Listen to each fuel injector operating sound.

Cylinder	Harness connector F101 terminal	
	(+)	(-)
1	3	2
3	3	1
5	3	4

**Operating sound should exist.**

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 7.




## 6. CHECK FUNCTION OF FUEL INJECTOR-III

1. Reconnect all harness connector disconnected.
2. Start engine.
3. Listen to fuel injectors No. 2, No. 4, No.6 operating sound.

**Clicking noise should exist.**


OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 7.



## 7. CHECK FUEL INJECTOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect fuel injector harness connector (1).




3. Turn ignition switch ON.
4. Check voltage between fuel injector terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 9.  
 NG >> GO TO 8.



## 8. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E9, F4
- Harness connectors F7, F101
- IPDM E/R harness connector E12
- 15A fuse
- Harness for open or short between fuel injector and fuse

>> Repair harness or connectors.

## 9. CHECK FUEL INJECTOR OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between fuel injector terminal 2 and ECM terminals 21, 22, 23, 40, 41, 42. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 11.  
 NG >> GO TO 10.

## 10. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F101, F7 (bank 1)
- Harness for open or short between fuel injector and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 11. CHECK FUEL INJECTOR

Refer to [EC-935, "Component Inspection"](#) .

OK or NG

OK >> GO TO 12.

NG >> Replace fuel injector.

## 12. CHECK INTERMITTENT INCIDENT

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

### Component Inspection FUEL INJECTOR

GBS0012V

1. Disconnect fuel injector harness connector.
2. Check resistance between terminals as shown in the figure.

**Resistance: 11.1 - 14.5Ω [at 10 - 60°C (50 - 140°F)]**



PBIB1727E

### Removal and Installation FUEL INJECTOR

GBS0012W

Refer to [EM-36, "FUEL INJECTOR AND FUEL TUBE"](#) .

# FUEL PUMP

[VQ TYPE 2]

## FUEL PUMP

PFV:17042

### Description SYSTEM DESCRIPTION

GBS0012X

Sensor	Input Signal to ECM	ECM Function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed*	Fuel pump control	Fuel pump relay
Battery	Battery voltage*		

\*: ECM determines the start signal status by the signals of engine speed and battery voltage.


The ECM activates the fuel pump for several seconds after the ignition switch is turned ON to improve engine start ability. If the ECM receives a engine speed signal from the camshaft position sensor (PHASE), it knows that the engine is rotating, and causes the pump to operate. If the engine speed signal is not received when the ignition switch is ON, the engine stalls. The ECM stops pump operation and prevents battery discharging, thereby improving safety. The ECM does not directly drive the fuel pump. It controls the ON/OFF fuel pump relay, which in turn controls the fuel pump.

Condition	Fuel pump operation
Ignition switch is turned to ON.	Operates for 1 second.
Engine running and cranking	Operates.
When engine is stopped	Stops in 1.5 seconds.
Except as shown above	Stops.

### COMPONENT DESCRIPTION

A turbine type design fuel pump is used in the fuel tank.

- Fuel level sensor unit and fuel pump (1)
- Fuel pressure regulator (2)



### CONSULT-II Reference Value in Data Monitor Mode

GBS0012Y

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
FUEL PUMP RLY	<ul style="list-style-type: none"> <li>● For 1 second after turning ignition switch ON</li> <li>● Engine running or cranking</li> </ul>	ON
	<ul style="list-style-type: none"> <li>● Except above conditions</li> </ul>	OFF

# FUEL PUMP


[VQ TYPE 2]

## Wiring Diagram


GBS0012Z

### EC-F/PUMP-01

— : DETECTABLE LINE FOR DTC  
 - - - : NON-DETECTABLE LINE FOR DTC



REFER TO PG-POWER.



REFER TO THE FOLLOWING.  
 C1 - SUPER MULTIPLE JUNCTION (SMJ)

A  
 EC  
 C  
 D  
 E  
 F  
 G  
 H  
 I  
 J  
 K  
 L  
 M

# FUEL PUMP

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
113	V	Fuel pump relay	[Ignition switch: ON] ● For 1 second after turning ignition switch ON	0 - 1.5V
			[Engine is running] [Ignition switch: ON] ● More than 1 second after turning ignition switch ON	BATTERY VOLTAGE (11 - 14V)

## Diagnostic Procedure


GBS00130

### 1. CHECK OVERALL FUNCTION

- Turn ignition switch ON.
- Pinch fuel feed hose with two fingers.  
**Fuel pressure pulsation should be felt on the fuel feed hose for 1 second after ignition switch is turned ON.**

OK or NG

- OK >> **INSPECTION END**  
 NG >> GO TO 2.




### 2. CHECK FUEL PUMP POWER SUPPLY CIRCUIT-I

- Turn ignition switch OFF.
- Disconnect ECM harness connector.
- Turn ignition switch ON.
- Check voltage between ECM terminal 113 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 5.  
 NG >> GO TO 3.






## 3. CHECK FUEL PUMP POWER SUPPLY CIRCUIT-II

Check voltage between IPDM E/R terminal 46 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 12.




## 4. DETECT MALFUNCTIONING PART

Check harness for open or short between IPDM E/R and ECM

>> Repair harness or connectors.

## 5. CHECK FUEL PUMP POWER SUPPLY CIRCUIT-III

1. Turn ignition switch OFF.
2. Reconnect all harness connectors disconnected.
3. Disconnect "fuel level sensor unit and fuel pump" harness connector.
4. Turn ignition switch ON.




5. Check voltage between "fuel level sensor unit and fuel pump" terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage should exist for 1 second after ignition switch is turned ON.**

OK or NG

- OK >> GO TO 9.
- NG >> GO TO 6.



## 6. CHECK 15A FUSE

1. Turn ignition switch OFF.
2. Disconnect 15A fuse.
3. Check 15A fuse.

OK or NG

- OK >> GO TO 7.
- NG >> Replace fuse.

## 7. CHECK FUEL PUMP POWER SUPPLY CURCUIT-IV

1. Disconnect IPDM E/R harness connector E12.
2. Check harness continuity between “fuel level sensor unit and fuel pump” terminal 1 and IPDM E/R terminal 13.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

- |    |              |
|----|--------------|
| OK | >> GO TO 12. |
| NG | >> GO TO 8.  |

## 8. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors C1, E107
- Harness for open or short between “fuel level sensor unit and fuel pump” and IPDM E/R

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 9. CHECK FUEL PUMP GROUND CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between “fuel level sensor unit and fuel pump” terminal 3 and ground.  
Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground.

OK or NG

- |    |              |
|----|--------------|
| OK | >> GO TO 11. |
| NG | >> GO TO 10. |

## 10. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors C1, E107
- Harness for open or short between “fuel level sensor unit and fuel pump” and ground

>> Repair open circuit or short to power in harness or connectors.

## 11. CHECK FUEL PUMP

Refer to [EC-941, "Component Inspection"](#) .

OK or NG

- |    |                       |
|----|-----------------------|
| OK | >> GO TO 12.          |
| NG | >> Replace fuel pump. |

## 12. CHECK INTERMITTENT INCIDENT

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


OK or NG

- |    |   |
|----|---|
| OK | >> Replace IPDM E/R.                        |
| NG | >> Repair or replace harness or connectors. |

## Component Inspection FUEL PUMP

1. Disconnect "fuel level sensor unit and fuel pump" harness connector.
2. Check resistance between "fuel level sensor unit and fuel pump" terminals 1 and 3.

**Resistance: Approximately 0.2 - 5.0Ω [at 25°C (77°F)]**



## Removal and Installation FUEL PUMP

Refer to [FL-10, "FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY"](#) .

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

**HO2S2**

PFP:226A0

**Component Description**


GBS00133

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas on each bank.

Even if switching characteristics of the air fuel ratio (A/F) sensor 1 are shifted, the air-fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



**CONSULT-II Reference Value in Data Monitor Mode**


GBS00134

Specification data are reference values.


MONITOR ITEM	CONDITION	SPECIFICATION
HO2S2 (B1) HO2S2 (B2)	<ul style="list-style-type: none"> <li>● Revving engine from idle to 3,000 rpm quickly after the following conditions are met.</li> </ul>	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)	<ul style="list-style-type: none"> <li>- Engine: After warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul>	LEAN ↔ RICH

**Wiring Diagram**  
**BANK 1**


**EC-RRO2B1-01**




A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



E12  
W



F1  
B



F2  
W



F31  
L

Specification data are reference values and are measured between each terminal and ground.


**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
25	SB	Heated oxygen sensor 2 heater (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed is below 3,600 rpm after the following conditions are met               <ul style="list-style-type: none"> <li>- Engine: After warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - 1.0V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> </ul> <b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed: Above 3,600 rpm</li> </ul>	BATTERY VOLTAGE (11 - 14V)
74	O	Heated oxygen sensor 2 (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Revving engine from idle to 3,000 rpm quickly after the following conditions are met               <ul style="list-style-type: none"> <li>- Engine: After warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - Approximately 1.0V
78	B	Sensor ground (Heated oxygen sensor 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● <b>Warm-up condition</b></li> <li>● Idle speed</li> </ul>	Approximately 0V

BANK 2

EC-RRO2B2-01



A  
 EC  
 C  
 D  
 E  
 F  
 G  
 H  
 I  
 J  
 K  
 L  
 M



Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
6	R	Heated oxygen sensor 2 heater (Bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed is below 3,600 rpm after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: After warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - 1.0V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> </ul> <b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed: Above 3,600 rpm</li> </ul>	BATTERY VOLTAGE (11 - 14V)
55	G	Heated oxygen sensor 2 (Bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Revving engine from idle to 3,000 rpm quickly after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: After warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - Approximately 1.0V
78	B	Sensor ground (Heated oxygen sensor 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● <b>Warm-up condition</b></li> <li>● Idle speed</li> </ul>	Approximately 0V

**Diagnostic Procedure**

GBS00136


**1. CHECK OVERALL FUNCTION - I**

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
4. Let engine idle for 1 minute.
5. Set voltmeter probes between ECM terminal 74 [HO2S2 (B1) signal] or 55 [HO2S2 (B2) signal] and ground.
6. Check the voltage while revving engine up to 4,000 rpm under no load at least 10 times.  
(Depress and release the accelerator pedal as quickly as possible.)

**The voltage does not remain in the range of 0.2 - 0.4V**

OK or NG

- OK >> **INSPECTION END**
- NG >> **GO TO 2.**





## 2. CHECK OVERALL FUNCTION - II

Keep engine at idle for 10 minutes, then check the voltage between ECM terminal 74 [HO2S2 (B1) signal] or 55 [HO2S2 (B2) signal] and ground, or check the voltage when coasting at 80 km/h (50 MPH) in D position with "OD" OFF (A/T), 4th gear position (M/T).


**The voltage does not remain in the range of 0.2 - 0.4V**

OK or NG

- OK >> **INSPECTION END**  
 NG >> GO TO 3.

## 3. RETIGHTEN GROUND SCREWS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body.  
Refer to [EC-685, "Ground Inspection"](#).




↔ : Vehicle front

- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

- OK >> GO TO 4.  
 NG >> Repair or replace ground connections.

**4. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT**

1. Disconnect ECM harness connector.
2. Disconnect heated oxygen sensor 2 harness connector.



1. Heated oxygen sensor 2 (bank 2)
2. Heated oxygen sensor 2 (bank 2) harness connector
3. Heated oxygen sensor 2 (bank 1) harness connector
4. Heated oxygen sensor 2 (bank 1)

3. Check harness continuity between HO2S2 terminal 4 and ECM terminal 78. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**5. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal and HO2S2 terminal as follows. Refer to Wiring Diagram.

Terminals		Bank
ECM	Sensor	
74	1	1
55	1	2

**Continuity should exist.**

3. Check harness continuity between the following terminals and ground. Refer to Wiring Diagram.

Terminals		Bank
ECM	Sensor	
74	1	1
55	1	2

**Continuity should not exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 6.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**6. CHECK HEATED OXYGEN SENSOR 2**

Refer to [EC-949, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 7.
- NG >> Replace malfunctioning heated oxygen sensor 2.

**7. CHECK INTERMITTENT INCIDENT**

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

**Component Inspection  
HEATED OXYGEN SENSOR 2**

GBS00137

Ⓟ With CONSULT-II

1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
  2. Start engine and warm it up to the normal operating temperature.
  3. Turn ignition switch OFF and wait at least 10 seconds.
  4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
  5. Let engine idle for 1 minute.
6. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II.


DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

7. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to ±25%.



"HO2S2 (B1)/(B2)" should be above 0.68V at least once when the "FUEL INJECTION" is +25%.  
 "HO2S2 (B1)/(B2)" should be below 0.18V at least once when the "FUEL INJECTION" is -25%.


**CAUTION:**

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

### ⊗ Without CONSULT-II

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
4. Let engine idle for 1 minute.
5. Set voltmeter probes between ECM terminal 74 [HO2S2 (B1) signal] or 55 [HO2S2 (B2) signal] and ground.
6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.  
(Depress and release accelerator pedal as soon as possible.)  
**The voltage should be above 0.68V at least once during this procedure.**  
**If the voltage is above 0.68V at step 6, step 7 is not necessary.**
7. Keep vehicle at idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in D position with "OD" OFF (A/T), 4th gear position (M/T).  
**The voltage should be below 0.18V at least once during this procedure.**
8. If NG, replace heated oxygen sensor 2.



### CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.

## Removal and Installation HEATED OXYGEN SENSOR 2

GBS00138

Refer to [EM-23, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#) .

# HO2S2 HEATER

[VQ TYPE 2]

## HO2S2 HEATER

PFP:226A0

### Description SYSTEM DESCRIPTION

GBS00139

Sensor	Input signal to ECM	ECM function	Actuator
Camshaft position sensor (PHASE) Crankshaft position sensor (POS)	Engine speed	Heated oxygen sensor 2 heater control	Heated oxygen sensor 2 heater
Engine coolant temperature sensor	Engine coolant temperature		
Mass air flow sensor	Amount of intake air		

The ECM performs ON/OFF control of the heated oxygen sensor 2 heater corresponding to the engine speed, amount of intake air and engine coolant temperature.

### OPERATION

Engine speed rpm	Heated oxygen sensor 2 heater
Above 3,600	OFF
Below 3,600 rpm after the following conditions are met. <ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul>	ON

### CONSULT-II Reference Value in Data Monitor Mode

GBS0013A

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S2 HTR (B1) HO2S2 HTR (B2)	<ul style="list-style-type: none"> <li>● Engine speed is below 3,600 rpm after the following conditions are met. <ul style="list-style-type: none"> <li>- Engine: After warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	ON
	<ul style="list-style-type: none"> <li>● Engine speed: Above 3,600 rpm</li> </ul>	OFF



# HO2S2 HEATER

[VQ TYPE 2]


GBS0013B

## Wiring Diagram BANK 1


EC-RRO2B1-01




(E12)  
W



(F1)  
B



(F2)  
W



MBWA1423E

# HO2S2 HEATER

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
25	SB	Heated oxygen sensor 2 heater (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed is below 3,600 rpm after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: After warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - 1.0V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> </ul> <b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed: Above 3,600 rpm</li> </ul>	BATTERY VOLTAGE (11 - 14V)
74	O	Heated oxygen sensor 2 (Bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Revving engine from idle to 3,000 rpm quickly after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: After warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - Approximately 1.0V
78	B	Sensor ground (Heated oxygen sensor 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● <b>Warm-up condition</b></li> <li>● Idle speed</li> </ul>	Approximately 0V



A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# HO2S2 HEATER

[VQ TYPE 2]

BANK 2

EC-RRO2B2-01





# HO2S2 HEATER

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
6	R	Heated oxygen sensor 2 heater (Bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed is below 3,600 rpm after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: After warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - 1.0V
			<b>[Ignition switch: ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> </ul> <b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed: Above 3,600 rpm</li> </ul>	BATTERY VOLTAGE (11 - 14V)
55	G	Heated oxygen sensor 2 (Bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Revving engine from idle to 3,000 rpm quickly after the following conditions are met                             <ul style="list-style-type: none"> <li>- Engine: After warming up</li> <li>- Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul> </li> </ul>	0 - Approximately 1.0V
78	B	Sensor ground (Heated oxygen sensor 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● <b>Warm-up condition</b></li> <li>● Idle speed</li> </ul>	Approximately 0V

## Diagnostic Procedure

GBS0013C


### 1. CHECK OVERALL FUNCTION CHECK

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
4. Let engine idle for 1 minute.
5. Set voltmeter probes between ECM terminal 25 [HO2S2 (B1) heater signal] or 6 [HO2S2 (B2) heater signal] and ground.
6. Check the voltage under the following conditions.

Conditions	Voltage
At idle	0 - 1V
Engine speed: Above 3,600 rpm	BATTERY VOLTAGE (11 - 14V)


OK or NG

- OK >> **INSPECTION END**  
 NG >> **GO TO 2.**



## 2. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-685, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

### OK or NG

- OK >> GO TO 3.  
 NG >> Repair or replace ground connections.

## 3. CHECK HO2S2 POWER SUPPLY CIRCUIT

1. Disconnect heated oxygen sensor 2 harness connector.




- |                                    |  |  |
|------------------------------------|--|--|
| 1. Heated oxygen sensor 2 (bank 2) | 2. Heated oxygen sensor 2 (bank 2) harness connector | 3. Heated oxygen sensor 2 (bank 1) harness connector |
| 4. Heated oxygen sensor 2 (bank1)  |  |  |

2. Turn ignition switch ON.
3. Check voltage between HO2S2 terminal 3 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

### OK or NG

- OK >> GO TO 5.  
 NG >> GO TO 4.



**4. DETECT MALFUNCTIONING PART**

Check the following.

- Harness connectors E8, F2
- IPDM E/R connector E12
- 10A fuse
- Harness for open or short between heated oxygen sensor 2 and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

**5. CHECK HO2S2 OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal and HO2S2 terminal as follows. Refer to Wiring Diagram.

Terminals		Bank
ECM	Sensor	
25	2	1
6	2	2

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**6. CHECK HEATED OXYGEN SENSOR 2 HEATER**

Refer to [EC-958, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 7.
- NG >> Replace malfunctioning heated oxygen sensor 2.

**7. CHECK INTERMITTENT INCIDENT**

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

## Component Inspection HEATED OXYGEN SENSOR 2 HEATER


1. Check resistance between HO2S2 terminals as follows.

Terminal No.	Resistance
2 and 3	9.9 - 13.3 Ω [at 25°C (77°F)]
1 and 2, 3, 4	∞ Ω (Continuity should not exist)
4 and 1, 2, 3	

2. If NG, replace heated oxygen sensor 2.

### CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant.



## Removal and Installation HEATED OXYGEN SENSOR 2

Refer to [EM-23, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#) .

## IAT SENSOR


PFP:22630

### Component Description

GBS0013F

The intake air temperature sensor is built-into mass air flow sensor (1). The sensor detects intake air temperature and transmits a signal to the ECM.

The temperature sensing unit uses a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.




### <Reference data>

Intake air temperature °C (°F)	Voltage* V	Resistance kΩ
25 (77)	3.3	1.800 - 2.200
80 (176)	1.2	0.283 - 0.359

\*: This data is reference value and is measured between ECM terminal 34 (Intake air temperature sensor) and ground.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**



# IAT SENSOR




[VQ TYPE 2]

## Wiring Diagram

GBS0013G

### EC-IATSEN-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



## Diagnostic Procedure


### 1. CHECK OVERALL FUNCTION

1. Turn ignition switch ON.
2. Check voltage between ECM terminal 34 and ground with CONSULT-II or tester.

**Voltage: Approximately 0 - 4.8V**


OK or NG

- OK >> **INSPECTION END**  
 NG >> GO TO 2.



### 2. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-685, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

OK or NG

- OK >> GO TO 3.  
 NG >> Repair or replace ground connections.

## 3. CHECK INTAKE AIR TEMPERATURE SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect mass air flow sensor (intake air temperature sensor is built-into) harness connector.
3. Turn ignition switch ON.




4. Check voltage between mass air flow sensor terminal 2 and ground.

**Voltage: Approximately 5V**

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



## 4. CHECK INTAKE AIR TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between mass air flow sensor terminal 1 and ECM terminal 67. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 5. CHECK INTAKE AIR TEMPERATURE SENSOR

Refer to [EC-963, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace mass air flow sensor (with intake air temperature sensor).

## 6. CHECK INTERMITTENT INCIDENT

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**



# IAT SENSOR

[VQ TYPE 2]

GBS0013I



## Component Inspection

### INTAKE AIR TEMPERATURE SENSOR

1. Check resistance between mass air flow sensor (1) terminals 1 and 2 under the following conditions.

Intake air temperature °C (°F)	Resistance kΩ
25 (77)	1.800 - 2.200

2. If NG, replace mass air flow sensor (with intake air temperature sensor).



## Removal and Installation

### MASS AIR FLOW SENSOR

Refer to [EM-17, "AIR CLEANER AND AIR DUCT"](#) .

GBS0013J


### IGNITION SIGNAL

PFP:22448

#### Component Description IGNITION COIL & POWER TRANSISTOR

GBS0013K

The ignition signal from the ECM is sent to and amplified by the power transistor. The power transistor turns ON and OFF the ignition coil primary circuit. This ON/OFF operation induces the proper high voltage in the coil secondary circuit.



# IGNITION SIGNAL






[VQ TYPE 2]

## Wiring Diagram

GBS0013L

### EC-IGNSYS-01

— : DETECTABLE LINE FOR DTC  
 - - - : NON-DETECTABLE LINE FOR DTC



# IGNITION SIGNAL

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**



TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
111	BR	ECM relay (Self shut-off)	<b>[Engine is running]</b> <b>[Ignition switch: OFF]</b> <ul style="list-style-type: none"><li>● For a few seconds after turning ignition switch OFF</li></ul>	0 - 1.5V
			<b>[Ignition switch: OFF]</b> <ul style="list-style-type: none"><li>● More than a few seconds after turning ignition switch OFF</li></ul>	BATTERY VOLTAGE (11 - 14V)
119 120	R P	Power supply for ECM	<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)

# IGNITION SIGNAL

[VQ TYPE 2]

## EC-IGNSYS-02

— : DETECTABLE LINE FOR DTC  
 - - - : NON-DETECTABLE LINE FOR DTC



F1  
B



F126  
GR

F127  
GR

F128  
GR

MBWA1318E

# IGNITION SIGNAL



[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.

Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
60 61 62	V L Y	Ignition signal No. 5 Ignition signal No. 3 Ignition signal No. 1	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	<p>0 - 0.2V★</p>  <p>SEC986C</p>
			<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,500 rpm</li> </ul>	<p>0.1 - 0.4V★</p>  <p>SEC987C</p>




★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# IGNITION SIGNAL

[VQ TYPE 2]

## EC-IGNSYS-03

— : DETECTABLE LINE FOR DTC  
 - - - : NON-DETECTABLE LINE FOR DTC



MBWA1319E



# IGNITION SIGNAL

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
79 80 81	P GR G	Ignition signal No. 6 Ignition signal No. 4 Ignition signal No. 2	<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	<p>0 - 0.2V★</p> 
			<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,500 rpm</li> </ul>	<p>0.1 - 0.4V★</p> 

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnostic Procedure

GBS0013M

### 1. CHECK ENGINE START

Turn ignition switch OFF, and restart engine.

**Is engine running?**

Yes or No

- Yes (With CONSULT-II)>>GO TO 2.
- Yes (Without CONSULT-II)>>GO TO 3.
- No >> GO TO 4.

### 2. CHECK OVERALL FUNCTION

Ⓜ **With CONSULT-II**

- Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
- Make sure that each circuit produces a momentary engine speed drop.

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 10.

ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0133E




## 3. CHECK OVERALL FUNCTION

### ⊗ Without CONSULT-II


1. Let engine idle.
2. Read the voltage signal between ECM terminals 60, 61, 62, 79, 80, 81 and ground with an oscilloscope.
3. Verify that the oscilloscope screen shows the signal wave as shown below.

**NOTE:**

The pulse cycle changes depending on rpm at idle.



SEC986C



PBIB1186E

OK or NG

- OK >> **INSPECTION END**  
 NG >> GO TO 10.


## 4. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-I

1. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
2. Check voltage between ECM terminals 119, 120 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG


- OK >> GO TO 5.  
 NG >> Go to [EC-678, "POWER SUPPLY AND GROUND CIRCUIT"](#).



MBIB0034E

## 5. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-II

1. Turn ignition switch OFF.
2. Disconnect condenser-1 harness connector.
3. Turn ignition switch ON.




4. Check voltage between condenser-1 terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK    >> GO TO 8.  
 NG    >> GO TO 6.



## 6. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-III

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R harness connector E12.
3. Check harness continuity between IPDM E/R terminal 3 and condenser-1 terminal 1. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK    >> GO TO 17.  
 NG    >> GO TO 7.

## 7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E9, F4
- Harness for open or short between condenser-1 and IPDM E/R

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 8. CHECK CONDENSER-1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Check harness continuity between condenser-1 terminal 2 and ground.  
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 9.

NG >> Repair open circuit or short to power in harness or connectors.

## 9. CHECK CONDENSER-1

Refer to [EC-975, "Component Inspection"](#) .


OK or NG

OK >> GO TO 10.

NG >> Replace condenser-1.

## 10. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-IV

1. Turn ignition switch OFF.
2. Reconnect all harness connectors disconnected.
3. Disconnect ignition coil harness connector.




4. Turn ignition switch ON.
5. Check voltage between ignition coil terminal 3 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

OK >> GO TO 12.

NG >> GO TO 11.



## 11. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F6, F125
- Harness for open or short between ignition coil and harness connector F4

>> Repair or replace harness or connectors.

---

## 12. CHECK IGNITION COIL GROUND CIRCUIT FOR OPEN AND SHORT

---

1. Turn ignition switch OFF.
2. Check harness continuity between ignition coil terminal 2 and ground.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 14.  
NG >> GO TO 13.

---

## 13. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors F125, F6
- Harness for open or short between ignition coil and ground

>> Repair open circuit or short to power in harness or connectors.

---

## 14. CHECK IGNITION COIL OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminals 60, 61, 62, 79, 80, 81 and ignition coil terminal 1.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 16.  
NG >> GO TO 15.

---

## 15. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors F6, F125
- Harness for open or short between ignition coil and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 16. CHECK IGNITION COIL WITH POWER TRANSISTOR

---

Refer to [EC-975, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 17.  
NG >> Replace ignition coil with power transistor.

---

## 17. CHECK INTERMITTENT INCIDENT

---

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

## Component Inspection IGNITION COIL WITH POWER TRANSISTOR

### CAUTION:

Do the following procedure in the place where ventilation is good without the combustible.

1. Turn ignition switch OFF.
2. Disconnect ignition coil harness connector.
3. Check resistance between ignition coil terminals as follows.

Terminal No. (Polarity)	Resistance $\Omega$ [at 25°C (77°F)]
1 and 2	Except 0 or $\infty$
1 and 3	Except 0
2 and 3	

4. If NG, Replace ignition coil with power transistor.  
If OK, go to next step.
5. Turn ignition switch OFF.
6. Reconnect all harness connectors disconnected.
7. Remove fuel pump fuse in IPDM E/R to release fuel pressure.

### NOTE:

Do not use CONSULT-II to release fuel pressure, or fuel pressure applies again during the following procedure.

8. Start engine.
9. After engine stalls, crank it two or three times to release all fuel pressure.
10. Turn ignition switch OFF.
11. Remove ignition coil harness connectors to avoid the electrical discharge from the ignition coils.
12. Remove ignition coil and spark plug of the cylinder to be checked.
13. Crank engine for 5 seconds or more to remove combustion gas in the cylinder.
14. Connect spark plug and harness connector to ignition coil.
15. Fix ignition coil using a rope etc. with gap of 13 - 17 mm between the edge of the spark plug and grounded metal portion as shown in the figure.
16. Crank engine for about three seconds, and check whether spark is generated between the spark plug and the grounded part.

**Spark should be generated.**

### CAUTION:

- Do not approach to the spark plug and the ignition coil within 50cm. Be careful not to get an electrical shock while checking, because the electrical discharge voltage becomes 20kV or more.

- It might cause to damage the ignition coil if the gap of more than 17 mm is taken.




### NOTE:

When the gap is less than 13 mm, the spark might be generated even if the coil is malfunctioning.

17. If NG, Replace ignition coil with power transistor.

## CONDENSER-1

1. Turn ignition switch OFF.
2. Disconnect condenser-1 harness connector.




# IGNITION SIGNAL

[VQ TYPE 2]

3. Check resistance between condenser-1 terminals 1 and 2.

Resistance	Above 1 M $\Omega$ at 25°C (77°F)
------------	-----------------------------------



## Removal and Installation IGNITION COIL WITH POWER TRANSISTOR

Refer to [EM-33, "IGNITION COIL"](#) .

GBS00130

# REFRIGERANT PRESSURE SENSOR

[VQ TYPE 2]



## REFRIGERANT PRESSURE SENSOR

PFP:92136

### Component Description

GBS0013P

The refrigerant pressure sensor is installed at the condenser of the air conditioner system. The sensor uses an electrostatic volume pressure transducer to convert refrigerant pressure to voltage. The voltage signal is sent to ECM, and ECM controls cooling fan system.



# REFRIGERANT PRESSURE SENSOR



[VQ TYPE 2]

## Wiring Diagram

GBS0013Q

EC-RP/SEN-01

— : DETECTABLE LINE FOR DTC  
 - - - : NON-DETECTABLE LINE FOR DTC



MBWA1323E



# REFRIGERANT PRESSURE SENSOR

[VQ TYPE 2]

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
49	P	Sensor power supply (Refrigerant pressure sensor)	[Ignition switch: ON]	Approximately 5V
67	GR	Sensor ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
70	BR	Refrigerant pressure sensor	[Engine is running] ● Warm-up condition ● Both A/C switch and blower switch: ON (Compressor operates)	1.0 - 4.0V

## Diagnostic Procedure

GBS0013R


### 1. CHECK REFRIGERANT PRESSURE SENSOR OVERALL FUNCTION

1. Start engine and warm it up to normal operating temperature.
2. Turn A/C switch and blower switch ON.
3. Check voltage between ECM terminal 70 and ground with CONSULT-II or tester.

**Voltage: 1.0 - 4.0V**


OK or NG

- OK >> **INSPECTION END**
- NG >> **GO TO 2.**



## 2. CHECK GROUND CONNECTIONS

1. Turn A/C switch and blower switch OFF.
2. Turn ignition switch OFF.
3. Loosen and retighten three ground screws on the body. Refer to [EC-685, "Ground Inspection"](#) .



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

OK or NG

- OK >> GO TO 3.  
 NG >> Repair or replace ground connections.

## 3. CHECK REFRIGERANT PRESSURE SENSOR POWER SUPPLY CIRCUIT

1. Disconnect refrigerant pressure sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between refrigerant pressure sensor terminal 3 and ground with CONSULT-II or tester.

**Voltage: Approximately 5V**

OK or NG

- OK >> GO TO 5.  
 NG >> GO TO 4.



---

#### 4. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors E8, F2
- Harness for open or short between ECM and refrigerant pressure sensor

>> Repair harness or connectors.

---

#### 5. CHECK REFRIGERANT PRESSURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

---

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between refrigerant pressure sensor terminal 1 and ECM terminal 67.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.  
NG >> GO TO 6.

---

#### 6. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors E8, F2
- Harness for open or short between ECM and refrigerant pressure sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

---

#### 7. CHECK REFRIGERANT PRESSURE SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

1. Check harness continuity between ECM terminal 70 and refrigerant pressure sensor terminal 2.  
Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 9.  
NG >> GO TO 8.

---

#### 8. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors E8, F2
- Harness for open or short between ECM and refrigerant pressure sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

---

#### 9. CHECK INTERMITTENT INCIDENT

---

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> Replace refrigerant pressure sensor.  
NG >> Repair or replace.

# REFRIGERANT PRESSURE SENSOR

[VQ TYPE 2]

---

## Removal and Installation REFRIGERANT PRESSURE SENSOR

GBS0013S


Refer to [MTC-121, "Removal and Installation for Refrigerant Pressure Sensor"](#) .

**VIAS**

**Description  
SYSTEM DESCRIPTION**

Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed*	VIAS control	VIAS control solenoid valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Accelerator pedal position		
Battery	Battery voltage*		

\*: ECM determines the start signal status by the signals of engine speed and battery voltage.



When the engine is running at medium speed, the ECM sends the ON signal to the VIAS control solenoid valve. This signal introduces the intake manifold vacuum into the power valve actuator and therefore closes the power valve.

Under this condition, the effective intake manifold length is equivalent to the total length of passage A and passage B. This long intake manifold provides increased amount of intake air, which results in improved suction efficiency and higher torque.


When engine is running at low or high speed, the ECM sends the OFF signal to the VIAS control solenoid valve and the power valve is opened.

Under this condition, the effective intake manifold length is equivalent to the length of passage B. This shortened intake manifold length results in enhanced engine output due to reduced suction resistance under high speeds.

**COMPONENT DESCRIPTION**


**Power Valve**

The power valve is installed in intake manifold collector and used to control the suction passage of the variable induction air control system. It is set in the fully closed or fully opened position by the power valve actuator operated by the vacuum stored in the surge tank. The vacuum in the surge tank is controlled by the VIAS control solenoid valve.



**VIAS Control Solenoid Valve**

The VIAS control solenoid valve cuts the intake manifold vacuum signal for power valve control. It responds to ON/OFF signals from the ECM. When the solenoid is OFF, the vacuum signal from the intake manifold is cut. When the ECM sends an ON signal the coil pulls the plunger downward and feeds the vacuum signal to the power valve actuator.



**CONSULT-II Reference Value in Data Monitor Mode**

GBS0013U





Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
VIAS S/V	● Engine: After warming up	2,200 - 3,300 rpm	ON
		Except above conditions	OFF

Wiring Diagram

GBS0013V

EC-VIAS-01



# VIAS

**[VQ TYPE 2]**

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
29	GR	VIAS control solenoid valve	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Idle speed</li> </ul>	BATTERY VOLTAGE (11 - 14V)
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed: Between 2,200 and 3,300 rpm</li> </ul>	0 - 1.0V
111	BR	ECM relay (Self shut-off)	<b>[Engine is running]</b> <b>[Ignition switch: OFF]</b> <ul style="list-style-type: none"> <li>● For a few seconds after turning ignition switch OFF</li> </ul>	0 - 1.5V
			<b>[Ignition switch: OFF]</b> <ul style="list-style-type: none"> <li>● More than a few seconds after turning ignition switch OFF</li> </ul>	BATTERY VOLTAGE (11 - 14V)
119 120	R P	Power supply for ECM	<b>[Ignition switch: ON]</b>	BATTERY VOLTAGE (11 - 14V)



**Diagnostic Procedure**

**1. CHECK OVERALL FUNCTION**


**① With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Perform "VIAS SOL VALVE" in "ACTIVE TEST" mode with CONSULT-II.

ACTIVE TEST	
VIAS SOL VALVE	OFF
MONITOR	
ENG SPEED	XXX rpm

PBIB0844E

3. Turn VIAS control solenoid valve "ON" and "OFF", and make sure that power valve actuator (1) rod moves.




**⊗ Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Rev engine up to between 2,200 and 3,300 rpm and make sure that power valve actuator (1) rod moves.

**OK or NG**

- OK >> **INSPECTION END**
- NG (With CONSULT-II) >>GO TO 2.
- NG (Without CONSULT-II) >>GO TO 3.




A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

## 2. CHECK VACUUM EXISTENCE

**With CONSULT-II**

1. Stop engine and disconnect vacuum hose connected to power valve actuator.
2. Start engine and let it idle.
3. Perform "VIAS SOL VALVE" in "ACTIVE TEST" mode with CONSULT-II.
4. Turn VIAS control solenoid valve "ON" and "OFF", and check vacuum existence under the following conditions.

VIAS SOL VALVE	Vacuum
ON	Should exist.
OFF	Should not exist.



**OK or NG**


- OK >> Repair or replace power valve actuator.
- NG >> GO TO 4.

## 3. CHECK VACUUM EXISTENCE

**Without CONSULT-II**

1. Stop engine and disconnect vacuum hose connected to power valve actuator.
2. Disconnect VIAS control solenoid valve harness connector.
3. Start engine and let it idle.
4. Apply 12V of direct current between VIAS control solenoid valve terminals 1 and 2.
5. Check vacuum existence under the following conditions.

Condition	Vacuum
12V direct current supply	Should exist.
No supply	Should not exist.



**OK or NG**


- OK >> Repair or replace power valve actuator.
- NG >> GO TO 4.

## 4. CHECK VACUUM HOSE

1. Stop engine.
2. Check hoses and tubes between intake manifold and power valve actuator for crack, clogging, improper connection or disconnection. Refer to [EC-639, "Vacuum Hose Drawing"](#).

**OK or NG**

- OK >> GO TO 5.
- NG >> Repair hoses or tubes.



## 5. CHECK VACUUM TANK


Refer to [EC-990, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.  
 NG >> Replace vacuum tank.

## 6. CHECK VIAS CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect VIAS control solenoid valve harness connector.
3. Turn ignition switch ON.




4. Check voltage between VIAS control solenoid valve terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 8.  
 NG >> GO TO 7.



## 7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E9, F4
- Harness for open or short between VIAS control solenoid valve and IPDM E/R
- Harness for open or short between VIAS control solenoid valve and ECM

>> Repair harness or connectors.

## 8. CHECK VIAS CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 29 and VIAS control solenoid valve terminal 2. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 9.  
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**9. CHECK VIAS CONTROL SOLENOID VALVE**

Refer to [EC-990, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 10.
- NG >> Replace VIAS control solenoid valve.

**10. CHECK INTERMITTENT INCIDENT**

Refer to [EC-677, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

**Component Inspection  
VIAS CONTROL SOLENOID VALVE**


GBS0013X

**With CONSULT-II**

1. Reconnect harness connectors disconnected.
2. Turn ignition switch ON.
3. Perform "VIAS SOL VALVE" in "ACTIVE TEST" mode.
4. Check air passage continuity and operation delay time under the following conditions.

Condition VIAS SOL VALVE	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
ON	Yes	No
OFF	No	Yes

**Operation takes less than 1 second.**




**Without CONSULT-II**

Check air passage continuity and operation delay time under the following conditions.


Condition	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12V direct current supply between terminals 1 and 2	Yes	No
No supply	No	Yes

**Operation takes less than 1 second.**



**VACUUM TANK**

1. Disconnect vacuum hose connected to vacuum tank.
2. Connect a vacuum pump to the port A of vacuum tank.
3. Apply vacuum and make sure that vacuum exists at the port B.



**Removal and Installation**  
**VIAS CONTROL SOLENOID VALVE**

Refer to [EM-21, "INTAKE MANIFOLD"](#) .

A

EC

C

D

E

F

G

H

I

J

K

L

M

**VSS**

PFP:32702

**Description**

GBS0013Z

The vehicle speed signal is sent to the combination meter from the "ABS actuator and electric unit (control unit)" by CAN communication line. The combination meter then sends a signal to the ECM by CAN communication line.

**Diagnostic Procedure**

GBS00140

**1. INSPECTION START**

Do you have CONSULT-II?

Yes or No

- Yes >> GO TO 2.  
No >> GO TO 3.

**2. CHECK OVERALL FUNCTION**

1. Turn ignition switch OFF.
2. Lift up the vehicle.
3. Start engine and let it idle.
4. Select "VHCL SPEED SE" in "DATA MONITOR" mode with CONSULT-II.
5. Select "VHCL SPEED SE" indication when rotating wheels with suitable gear position.

**"VHCL SPEED SE" indication should exceed 10 km/h (6 MPH).**

OK or NG

- OK >> **INSPECTION END**  
NG >> GO TO 3.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
B/FUEL SCHDL	XXX msec

PBIB0164E

**3. CHECK DTC WITH "ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)"**

Refer to [BRC-8, "TROUBLE DIAGNOSIS"](#) .

OK or NG

- OK >> GO TO 4.  
NG >> Repair or replace.

**4. CHECK COMBINATION METER FUNCTION**

Refer to [DI-4, "COMBINATION METERS"](#) .

>> **INSPECTION END**

# MIL AND DATA LINK CONNECTOR

[VQ TYPE 2]




## MIL AND DATA LINK CONNECTOR

PPF:24814

### Wiring Diagram

GBS00141

### EC-MIL/DL-01





REFER TO THE FOLLOWING.  
 (M88) - FUSE BLOCK -  
 JUNCTION BOX (J/B)

# MIL AND DATA LINK CONNECTOR


[VQ TYPE 2]

## EC-MIL/DL-02

— : DETECTABLE LINE FOR DTC  
 - - - : NON-DETECTABLE LINE FOR DTC



M45  
W



E20  
B



REFER TO THE FOLLOWING.

- (M91) - SUPER MULTIPLE JUNCTION (SMJ)
- (M88) - FUSE BLOCK - JUNCTION BOX (J/B)



## SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

### Fuel Pressure

GBS00142

Fuel pressure at idling kPa (bar, kg/cm <sup>2</sup> , psi)	Approximately 350 (3.5, 3.57, 51)
---	-----------------------------------

### Idle Speed and Ignition Timing

GBS00143

Target idle speed	No load* [in P or N position (A/T), Neutral position (M/T)]	625 ± 50 rpm
Air conditioner: ON	In P or N position (A/T), Neutral position (M/T)	775 rpm or more
Ignition timing	In P or N position (A/T), Neutral position (M/T)	15 ± 5° BTDC

\*: Under the following conditions:

- Air conditioner switch: OFF
- Electric load: OFF (Lights, heater fan & rear window defogger)
- Steering wheel: Kept in straight-ahead position

### Mass Air Flow Sensor

GBS00144

Supply voltage	Battery voltage (11 - 14V)
Output voltage at idle	0.9 - 1.2V*

\*: Engine is warmed up to normal operating temperature and running under no load.

### Intake Air Temperature Sensor

GBS00145

Temperature °C (°F)	Resistance kΩ
25 (77)	1.800 - 2.200

### Engine Coolant Temperature Sensor

GBS00146

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

### Air Fuel Ratio (A/F) Sensor 1 Heater

GBS00147

Resistance [at 25°C (77°F)]	2.3 - 4.3Ω
-----------------------------	------------

### Heated Oxygen sensor 2 Heater

GBS00148

Resistance [at 25°C (77°F)]	9.9 - 13.3Ω
-----------------------------	-------------

### Crankshaft Position Sensor (POS)

GBS00149

Refer to [EC-731, "Component Inspection"](#) .

### Camshaft Position Sensor (PHASE)

GBS0014A

Refer to [EC-740, "Component Inspection"](#) .

### Throttle Control Motor

GBS0014B

Resistance [at 25°C (77°F)]	Approximately 1 - 15Ω
-----------------------------	-----------------------

### Fuel Injector

GBS0014C

Resistance [at 10 - 60°C (50 - 140°F)]	11.1 - 14.5Ω
--	--------------

### Fuel Pump

GBS0014D

Resistance [at 25°C (77°F)]	0.2 - 5.0Ω
-----------------------------	------------

# INDEX FOR DTC

[YD]

## INDEX FOR DTC

PFP:00024

### DTC No. Index

GBS0002N

**NOTE:**

If DTC U1000 is displayed with other DTC, first perform the trouble diagnosis for DTC U1000. Refer to [EC-1067, "DTC U1000 CAN COMMUNICATION LINE"](#).

X: Applicable —: Not applicable

DTC		Items (CONSULT-II screen item)	MIL lighting up	Reference page
CONSULT-II	ECM*1			
U1000	1000*2	CAN COMM CIRCUIT	—	<a href="#">EC-1067</a>
<b>P0000</b>	<b>0000</b>	<b>NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.</b>	—	—
P0016	0016	CMP/CKP RELATION	—	<a href="#">EC-1070</a>
P0088	0088	HIGH FUEL PRESS	×	<a href="#">EC-1072</a>
P0089	0089	FUEL PUMP	—	<a href="#">EC-1074</a>
P0093	0093	FUEL LEAK	×	<a href="#">EC-1076</a>
P0102	0102	MAF SEN/CIRCUIT	—	<a href="#">EC-1080</a>
P0103	0103	MAF SEN/CIRCUIT	—	<a href="#">EC-1080</a>
P0112	0112	IAT SEN/CIRCUIT	—	<a href="#">EC-1086</a>
P0113	0113	IAT SEN/CIRCUIT	—	<a href="#">EC-1086</a>
P0117	0117	ECT SEN/CIRCUIT	—	<a href="#">EC-1091</a>
P0118	0118	ECT SEN/CIRCUIT	—	<a href="#">EC-1091</a>
P0122	0122	APP SEN 1/CIRCUIT	—	<a href="#">EC-1096</a>
P0123	0123	APP SEN 1/CIRCUIT	—	<a href="#">EC-1096</a>
P0182	0182	FUEL TEMP SEN/CIRC	—	<a href="#">EC-1101</a>
P0183	0183	FUEL TEMP SEN/CIRC	—	<a href="#">EC-1101</a>
P0192	0192	FRP SEN/CIRC	—	<a href="#">EC-1106</a>
P0193	0193	FRP SEN/CIRC	—	<a href="#">EC-1106</a>
P0200	0200	INJECTOR	×	<a href="#">EC-1111</a>
P0201	0201	CYL1 INJECTOR	×	<a href="#">EC-1113</a>
P0202	0202	CYL2 INJECTOR	×	<a href="#">EC-1113</a>
P0203	0203	CYL3 INJECTOR	×	<a href="#">EC-1113</a>
P0204	0204	CYL4 INJECTOR	×	<a href="#">EC-1113</a>
P0217	0217	ENG OVER TEMP	×	<a href="#">EC-1120</a>
P0222	0222	APP SEN 2/CIRCUIT	—	<a href="#">EC-1130</a>
P0223	0223	APP SEN 2/CIRCUIT	—	<a href="#">EC-1130</a>
P0234	0234	TC SYSTEM	—	<a href="#">EC-1135</a>
P0237	0237	TC BOOST SEN/CIRC	—	<a href="#">EC-1141</a>
P0238	0238	TC BOOST SEN/CIRC	—	<a href="#">EC-1141</a>
P0335	0335	CKP SEN/CIRCUIT	×	<a href="#">EC-1147</a>
P0336	0336	CKP SENSOR	×	<a href="#">EC-1153</a>
P0340	0340	CMP SEN/CIRCUIT	×	<a href="#">EC-1159</a>
P0341	0341	CMP SENSOR	×	<a href="#">EC-1165</a>
P0501	0501	VEHICLE SPEED	—	<a href="#">EC-1171</a>
P0502	0502	VEHICLE SPEED	—	<a href="#">EC-1173</a>
P0503	0503	VEHICLE SPEED	—	<a href="#">EC-1175</a>

# INDEX FOR DTC

[YD]

DTC		Items (CONSULT-II screen item)	MIL lighting up	Reference page	
CONSULT-II	ECM*1				
P0504	0504	BRAKE SW/CIRCUIT	—	<a href="#">EC-1177</a>	A
P0563	0563	BATTERY VOLTAGE	—	<a href="#">EC-1191</a>	EC
P0580	0580	STRG SW/CIRC	—	<a href="#">EC-1194</a>	
P0581	0581	STRG SW/CIRC	—	<a href="#">EC-1194</a>	
P0605	0605	ECM	×	<a href="#">EC-1201</a>	C
P0606	0606	ECM	×	<a href="#">EC-1203</a>	
P0628	0628	FUEL PUMP/CIRC	×	<a href="#">EC-1205</a>	D
P0629	0629	FUEL PUMP/CIRC	×	<a href="#">EC-1205</a>	
P0642	0642	SENSOR PWR/CIRC1	—	<a href="#">EC-1210</a>	E
P0643	0643	SENSOR PWR/CIRC1	—	<a href="#">EC-1210</a>	
P0652	0652	SENSOR PWR/CIRC2	—	<a href="#">EC-1215</a>	F
P0653	0653	SENSOR PWR/CIRC2	—	<a href="#">EC-1215</a>	
P0686	0686	ECM RELAY	—	<a href="#">EC-1220</a>	
P1268	1268	INJECTOR 1	—	<a href="#">EC-1225</a>	G
P1269	1269	INJECTOR 2	—	<a href="#">EC-1225</a>	
P1270	1270	INJECTOR 3	—	<a href="#">EC-1225</a>	
P1271	1271	INJECTOR 4	—	<a href="#">EC-1225</a>	H
P1272	1272	FRP RELIEF VALVE	—	<a href="#">EC-1233</a>	
P1273	1273	FUEL PUMP	—	<a href="#">EC-1239</a>	I
P1274	1274	FUEL PUMP	×	<a href="#">EC-1246</a>	
P1275	1275	FUEL PUMP	×	<a href="#">EC-1251</a>	
P1610 - P1615	1610 - 1615	NATS MALFUNTION	—	<a href="#">BL-87</a>	J
P1616	1616	ECM	—	<a href="#">EC-1257</a>	
P1622	1622	INJ ADJ VAL UNRGST	—	<a href="#">EC-1259</a>	K
P1623	1623	INJ ADJ VAL ERROR	—	<a href="#">EC-1261</a>	
P2135	2135	APP SENSOR	—	<a href="#">EC-1263</a>	L
P2146	2146	INJ PWR/CIRC	×	<a href="#">EC-1269</a>	
P2147	2147	INJECTOR/CIRC	×	<a href="#">EC-1274</a>	
P2148	2148	INJECTOR/CIRC	×	<a href="#">EC-1274</a>	M
P2149	2149	INJ PWR/CIRC	×	<a href="#">EC-1269</a>	
P2228	2228	BARO SEN/CIRC	—	<a href="#">EC-1281</a>	
P2229	2229	BARO SEN/CIRC	—	<a href="#">EC-1281</a>	

\*1: In Diagnostic Test Mode II.

\*2: The troubleshooting for this DTC needs CONSULT-II.

# INDEX FOR DTC

[YD]

GBS00020

## Alphabetical Index

### NOTE:

If DTC U1000 is displayed with other DTC, first perform the trouble diagnosis for DTC U1000. Refer to [EC-1067, "DTC U1000 CAN COMMUNICATION LINE"](#).

X: Applicable —: Not applicable

Items (CONSULT-II screen terms)	DTC		MIL lighting up	Reference page
	CONSULT-II	ECM*1		
APP SEN 1/CIRCUIT	P0122	0122	—	<a href="#">EC-1096</a>
APP SEN 1/CIRCUIT	P0123	0123	—	<a href="#">EC-1096</a>
APP SEN 2/CIRCUIT	P0222	0222	—	<a href="#">EC-1130</a>
APP SEN 2/CIRCUIT	P0223	0223	—	<a href="#">EC-1130</a>
APP SENSOR	P2135	2135	—	<a href="#">EC-1263</a>
BARO SEN/CIRC	P2228	2228	—	<a href="#">EC-1281</a>
BARO SEN/CIRC	P2229	2229	—	<a href="#">EC-1281</a>
BATTERY VOLTAGE	P0563	0563	—	<a href="#">EC-1191</a>
BRAKE SW/CIRCUIT	P0504	0504	—	<a href="#">EC-1177</a>
CAN COMM CIRCUIT	U1000	1000*2	—	<a href="#">EC-1067</a>
CKP SEN/CIRCUIT	P0335	0335	×	<a href="#">EC-1147</a>
CKP SENSOR	P0336	0336	×	<a href="#">EC-1153</a>
CMP SEN/CIRCUIT	P0340	0340	×	<a href="#">EC-1159</a>
CMP SENSOR	P0341	0341	×	<a href="#">EC-1165</a>
CMP/CKP RELATION	P0016	0016	—	<a href="#">EC-1070</a>
CYL1 INJECTOR	P0201	0201	×	<a href="#">EC-1113</a>
CYL2 INJECTOR	P0202	0202	×	<a href="#">EC-1113</a>
CYL3 INJECTOR	P0203	0203	×	<a href="#">EC-1113</a>
CYL4 INJECTOR	P0204	0204	×	<a href="#">EC-1113</a>
ECM	P0605	0605	×	<a href="#">EC-1201</a>
ECM	P0606	0606	×	<a href="#">EC-1203</a>
ECM	P1616	1616	—	<a href="#">EC-1257</a>
ECM RELAY	P0686	0686	—	<a href="#">EC-1220</a>
ECT SEN/CIRCUIT	P0117	0117	—	<a href="#">EC-1091</a>
ECT SEN/CIRCUIT	P0118	0118	—	<a href="#">EC-1091</a>
ENG OVER TEMP	P0217	0217	×	<a href="#">EC-1120</a>
FRP RELIEF VALVE	P1272	1272	—	<a href="#">EC-1233</a>
FRP SEN/CIRC	P0192	0192	—	<a href="#">EC-1106</a>
FRP SEN/CIRC	P0193	0193	—	<a href="#">EC-1106</a>
FUEL LEAK	P0093	0093	×	<a href="#">EC-1076</a>
FUEL PUMP	P0089	0089	—	<a href="#">EC-1074</a>
FUEL PUMP	P1273	1273	—	<a href="#">EC-1239</a>
FUEL PUMP	P1274	1274	×	<a href="#">EC-1246</a>
FUEL PUMP	P1275	1275	×	<a href="#">EC-1251</a>
FUEL PUMP/CIRC	P0628	0628	×	<a href="#">EC-1205</a>
FUEL PUMP/CIRC	P0629	0629	×	<a href="#">EC-1205</a>
FUEL TEMP SEN/CIRC	P0182	0182	—	<a href="#">EC-1101</a>
FUEL TEMP SEN/CIRC	P0183	0183	—	<a href="#">EC-1101</a>
HIGH FUEL PRESS	P0088	0088	×	<a href="#">EC-1072</a>

# INDEX FOR DTC

[YD]

Items (CONSULT-II screen terms)	DTC		MIL lighting up	Reference page	
	CONSULT-II	ECM*1			
IAT SEN/CIRCUIT	P0112	0112	—	<a href="#">EC-1086</a>	A
IAT SEN/CIRCUIT	P0113	0113	—	<a href="#">EC-1086</a>	EC
INJ ADJ VAL ERROR	P1623	1623	—	<a href="#">EC-1261</a>	
INJ ADJ VAL UNRGST	P1622	1622	—	<a href="#">EC-1259</a>	
INJ PWR/CIRC	P2146	2146	×	<a href="#">EC-1269</a>	C
INJ PWR/CIRC	P2149	2149	×	<a href="#">EC-1269</a>	
INJECTOR	P0200	0200	×	<a href="#">EC-1111</a>	D
INJECTOR/CIRC	P2147	2147	×	<a href="#">EC-1274</a>	
INJECTOR/CIRC	P2148	2148	×	<a href="#">EC-1274</a>	
INJECTOR 1	P1268	1268	—	<a href="#">EC-1225</a>	E
INJECTOR 2	P1269	1269	—	<a href="#">EC-1225</a>	
INJECTOR 3	P1270	1270	—	<a href="#">EC-1225</a>	F
INJECTOR 4	P1271	1271	—	<a href="#">EC-1225</a>	
MAF SEN/CIRCUIT	P0102	0102	—	<a href="#">EC-1080</a>	
MAF SEN/CIRCUIT	P0103	0103	—	<a href="#">EC-1080</a>	G
NATS MALFUNCTION	P1610 - P1615	1610 - 1615	—	<a href="#">BL-87</a>	
<b>NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.</b>	<b>P0000</b>	<b>0000</b>	—	—	H
SENSOR PWR/CIRC1	P0642	0642	—	<a href="#">EC-1210</a>	
SENSOR PWR/CIRC1	P0643	0643	—	<a href="#">EC-1210</a>	I
SENSOR PWR/CIRC2	P0652	0652	—	<a href="#">EC-1215</a>	
SENSOR PWR/CIRC2	P0653	0653	—	<a href="#">EC-1215</a>	J
STRG SW/CIRC	P0580	0580	—	<a href="#">EC-1194</a>	
STRG SW/CIRC	P0581	0581	—	<a href="#">EC-1194</a>	
TC BOOST SEN/CIRC	P0237	0237	—	<a href="#">EC-1141</a>	K
TC BOOST SEN/CIRC	P0238	0238	—	<a href="#">EC-1141</a>	
TC SYSTEM	P0234	0234	—	<a href="#">EC-1135</a>	L
VEHICLE SPEED	P0501	0501	—	<a href="#">EC-1171</a>	
VEHICLE SPEED	P0502	0502	—	<a href="#">EC-1173</a>	
VEHICLE SPEED	P0503	0503	—	<a href="#">EC-1175</a>	M

\*1: In Diagnostic Test Mode II.

\*2: The troubleshooting for this DTC needs CONSULT-II.

## PRECAUTIONS

PFP:00001

### Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

GBS0002P

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### On Board Diagnostic (OBD) System of Engine

GBS0002Q

The ECM has an on board diagnostic system. It will light up the malfunction indicator lamp (MIL) to warn the driver of a malfunction causing emission deterioration.


**CAUTION:**

- Be sure to turn the ignition switch OFF and disconnect the battery negative cable before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MIL to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MIL to light up due to the open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Certain systems and components, especially those related to OBD, may use a new style slide-locking type harness connector. For description and how to disconnect, refer to [PG-65, "HARNESS CONNECTOR"](#).
- Be sure to route and secure the harnesses properly after work. The interference of the harness with a bracket, etc. may cause the MIL to light up due to the short circuit.
- Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MIL to light up due to the malfunction of the fuel system, etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the ECM before returning the vehicle to the customer.

### Precautions

GBS0002R


- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.
- Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect battery negative cable. Failure to do so may damage the ECM because battery voltage is applied to ECM even if ignition switch is turned off.
- Before removing parts, turn ignition switch OFF and then disconnect battery negative cable.




# PRECAUTIONS

[YD]

- Do not disassemble ECM.




- When connecting ECM harness connector, fasten it securely with levers as far as they will go as shown in the figure.



- When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break).


Make sure that there are not any bends or breaks on ECM pin terminal, when connecting pin connectors.

- Securely connect ECM harness connectors. A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to IC's.
- Keep engine control system harness at least 10cm (4 in) away from adjacent harness, to prevent engine control system malfunctions due to receiving external noise, degraded operation of IC's, etc.
- Keep engine control system parts and harness dry.



- Before replacing ECM, perform ECM Terminals and Reference Value inspection and make sure ECM functions properly. Refer to [EC-1041, "ECM Terminals And Reference Value"](#).


- Handle mass air flow sensor carefully to avoid damage.
- Do not disassemble mass air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Even a slight leak in the air intake system can cause serious incidents.
- Do not shock or jar the camshaft position sensor, crankshaft position sensor.




# PRECAUTIONS

[YD]


- After performing each TROUBLE DIAGNOSIS, perform DTC Confirmation Procedure or Overall Function Check. The DTC should not be displayed in the DTC Confirmation Procedure if the repair is completed. The Overall Function Check should be a good result if the repair is completed.




- When measuring ECM signals with a circuit tester, never allow the two tester probes to contact. Accidental contact of probes will cause a short circuit and damage the ECM power transistor.
- Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.
- Do not disassemble fuel pump. If NG, take proper action.
- Do not disassemble fuel injector. If NG, replace fuel injector.



- Do not depress accelerator pedal when starting.
- Immediately after starting, do not rev up engine unnecessarily.
- Do not rev up engine just prior to shutdown.



- When installing C.B. ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on installation location.
  - Keep the antenna as far as possible from the electronic control units.
  - Keep the antenna feeder line more than 20 cm (8 in) away from the harness of electronic controls. Do not let them run parallel for a long distance.
  - Adjust the antenna and feeder line so that the standingwave ratio can be kept smaller.
  - Be sure to ground the radio to vehicle body.





# PREPARATION




[YD]

## PREPARATION

PF0:00002


### Special Service Tools

GBS0002T

Tool number Tool name	Description
EG17650301 Radiator cap tester adapter  <p style="text-align: center;">S-NT564</p>	Adapting radiator cap tester to radiator cap and radiator filler neck <b>a: 28 (1.10) dia.</b> <b>b: 31.4 (1.236) dia.</b> <b>c: 41.3 (1.626) dia.</b> Unit: mm (in)
KV109E0010 Break-out box  <p style="text-align: center;">S-NT825</p>	Measuring the ECM signals with a circuit tester
KV109E0080 Y-cable adapter  <p style="text-align: center;">S-NT826</p>	Measuring the ECM signals with a circuit tester

### Commercial Service Tools

GBS0002U


Tool name	Description
Socket wrench  <p style="text-align: center;">S-NT705</p>	Removing and installing engine coolant temperature sensor

## ENGINE CONTROL SYSTEM

PFP:23710

### System Diagram

GBS0002V



## Vacuum Hose Drawing

GBS0002W

### LEFT SIDE OF THE ENGINE ROOM

A

EC

C

D

E

F

G

H


I

J

K

L

M



MBIB1387E

← : Vehicle front

1. Turbocharger boost control solenoid valve


2. Turbocharger control actuator

A. From next page

**NOTE: Do not use soapy water or any type of solvent while installing vacuum hose.**

Refer to [EC-1004, "System Diagram"](#) for Vacuum Control System.

## RIGHT SIDE OF THE ENGINE ROOM



← : Vehicle front

- |                                      |  |                |
|--------------------------------------|--|----------------|
| 1. Fuel rail                         | 2. Intake air control valve control solenoid valve | 3. Vacuum pump |
| 4. Intake air control valve actuator | A. To previous page                                |                |

**NOTE: Do not use soapy water or any type of solvent while installing vacuum hose.**

Refer to [EC-1004, "System Diagram"](#) for Vacuum Control System.

MBIB1288E

## System Chart

GBS0002X

Input (Sensor)	ECM Function	Output (Actuator)
<ul style="list-style-type: none"> <li>● Accelerator pedal position sensor</li> <li>● Fuel rail pressure sensor</li> <li>● Fuel pump temperature sensor</li> <li>● Engine coolant temperature sensor</li> <li>● Mass air flow sensor</li> <li>● Intake air temperature sensor</li> <li>● Crankshaft position sensor</li> <li>● Camshaft position sensor</li> <li>● Turbocharger boost sensor</li> <li>● Wheel sensor*<sup>1</sup></li> <li>● Ignition switch</li> <li>● ASCD steering switch</li> <li>● ASCD brake switch</li> <li>● ASCD clutch switch</li> <li>● Stop lamp switch</li> <li>● Air conditioner switch*<sup>1</sup></li> <li>● Park/neutral position switch</li> <li>● Refrigerant pressure sensor</li> <li>● Battery voltage</li> </ul>	Fuel injection control	Fuel injector and Fuel pump
	Fuel injection timing control	Fuel injector and Fuel pump
	Fuel cut control	Fuel injector and Fuel pump
	Glow control system	Glow relay and glow indicator lamp* <sup>2</sup>
	ASCD vehicle speed control	Fuel injector and Fuel pump
	On board diagnostic system	Malfunction indicator lamp (MIL)* <sup>2</sup>
	EGR volume control	EGR volume control valve
	Cooling fan control	Cooling fan relay* <sup>2</sup>
	Turbocharger boost control	Turbocharger boost control solenoid valve
	Intake air control valve control	Intake air control valve control solenoid valve
	Air conditioning cut control	Air conditioner relay* <sup>2</sup>

\*1: The input signal is sent to the ECM through CAN communication line.

\*2: The output signal is sent from the ECM through CAN communication line.

## Fuel Injection Control System SYSTEM DESCRIPTION

GBS0002Y

Three types of fuel injection control are provided to accommodate engine operating conditions; normal control, idle control and start control. The ECM determines the appropriate fuel injection control. Under each control, the amount of fuel injected is adjusted to improve engine performance.

Pulse signals are sent to fuel injectors according to the input signals to adjust the amount of fuel injected to preset value.


### START CONTROL

#### Input/Output Signal Chart

Sensor	Input Signal to ECM	ECM Function	Actuator
Engine coolant temperature sensor	Engine coolant temperature	Fuel injection control (start control)	Fuel injector Fuel pump
Crankshaft position sensor	Engine speed		
Camshaft position sensor	Piston position		
Ignition switch	Start signal		
Fuel rail pressure sensor	Fuel rail pressure		

When the ECM receives a start signal from the ignition switch, the ECM adapts the fuel injection system for the start control. The amount of fuel injected at engine starting is a preset program value in the ECM. The program is determined by the engine speed, engine coolant temperature and fuel rail pressure.

For better startability under cool engine conditions, the lower the coolant temperature becomes, the greater the amount of fuel injected. The ECM ends the start control when the engine speed reaches the specific value, and shifts the control to the normal or idle control.



## IDLE CONTROL

### Input/Output Signal Chart

Sensor	Input Signal to ECM	ECM Function	Actuator
Engine coolant temperature sensor	Engine coolant temperature	Fuel injection control (idle control)	Fuel injector Fuel pump
Crankshaft position sensor	Engine speed		
Battery	Battery voltage		
Accelerator pedal position sensor	Accelerator pedal position		
Fuel rail pressure sensor	Fuel rail pressure		
Wheel sensor	Vehicle speed*		
Air conditioner switch	Air conditioner ON signal*		

\*: The input signal is sent to the ECM through CAN communication line.

When the ECM determines that the engine speed is at idle, the fuel injection system is adapted for the idle control. The ECM regulates the amount of fuel injected corresponding to changes in load applied to the engine to keep engine speed constant. The ECM also provides the system with a fast idle control in response to the engine coolant temperature signal.


## NORMAL CONTROL

### Input/Output Signal Chart

Sensor	Input Signal to ECM	ECM Function	Actuator
Crankshaft position sensor	Engine speed	Fuel injection control (normal control)	Fuel injector Fuel pump
Accelerator pedal position sensor	Accelerator position		
Fuel rail pressure sensor	Fuel rail pressure		

The amount of fuel injected under normal driving conditions is determined according to sensor signals. The crankshaft position sensor detects engine speed, the accelerator pedal position sensor detects accelerator pedal position and fuel rail pressure sensor detects fuel rail pressure. These sensors send signals to the ECM.

The fuel injection data, predetermined by correlation between various engine speeds, accelerator pedal positions and fuel rail pressure are stored in the ECM memory, forming a map. The ECM determines the optimal amount of fuel to be injected using the sensor signals in comparison with the map.



## MAXIMUM AMOUNT CONTROL

### Input/Output Signal Chart

Sensor	Input Signal to ECM	ECM Function	Actuator
Mass air flow sensor	Amount of intake air	Fuel injection control (maximum amount control)	Fuel injector
Engine coolant temperature sensor	Engine coolant temperature		
Crankshaft position sensor	Engine speed		
Accelerator pedal position sensor	Accelerator pedal position		

The maximum injection amount is controlled to an optimum by the engine speed, intake air amount, engine coolant temperature, and accelerator opening in accordance with the driving conditions. This prevents the oversupply of the injection amount caused by decreased air density at a high altitude or during a system failure.

## DECELERATION CONTROL

### Input/Output Signal Chart

Sensor	Input Signal to ECM	ECM Function	Actuator
Accelerator pedal position sensor	Accelerator pedal position	Fuel injection control (deceleration control)	Fuel injector Fuel pump
Crankshaft position sensor	Engine speed		

The ECM sends a fuel cut signal to the fuel injectors and fuel pump during deceleration for better fuel efficiency. The ECM determines the time of deceleration according to signals from the accelerator pedal position sensor and crankshaft position sensor.

## Fuel Injection Timing Control System

GBS0002Z

### DESCRIPTION

The target fuel injection timing in accordance with the engine speed and the fuel injection amount are recorded as a map in the ECM beforehand. The ECM determines the optimum injection timing using sensor signals accordance with the map.

## Air Conditioning Cut Control

GBS00030

### INPUT / OUTPUT SIGNAL CHART

Sensor	Input Signal to ECM	ECM Function	Actuator
Air conditioner switch	Air conditioner ON signal* <sup>1</sup>	Air conditioner cut control	Air conditioner relay* <sup>2</sup>
Accelerator pedal position sensor	Accelerator pedal opening angle		
Wheel sensor	Vehicle speed* <sup>1</sup>		
Engine coolant temperature sensor	Engine coolant temperature		
Refrigerant pressure sensor	Refrigerant pressure		

\*1: The input signal is sent to the ECM through CAN communication line.

\*2: The output signal is sent from the ECM through CAN communication line.

### SYSTEM DESCRIPTION

This system improves acceleration when the air conditioner is used.

When the accelerator pedal is fully depressed, the air conditioner is turned off for a few seconds.

When engine coolant temperature becomes excessively high, the air conditioner is turned off. This continues until the engine coolant temperature returns to normal.

## Fuel Cut Control (At No Load & High Engine Speed)

GBS00031

### INPUT/OUTPUT SIGNAL CHART

Sensor	Input Signal to ECM	ECM Function	Actuator
Wheel sensor	Vehicle speed*	Fuel cut control	Fuel injector
Accelerator pedal position sensor	Accelerator pedal position		
Crankshaft position sensor	Engine speed		

\*: The input signal is sent to the ECM through CAN communication line.


If the engine speed is above 2,800 rpm under no load (for example, the shift position is neutral and engine speed is over 2,800 rpm) fuel will be cut off after some time. The exact time when the fuel is cut off varies based on engine speed. Fuel cut will be operated until the engine speed reaches 1,500 rpm, then fuel cut will be cancelled.

### NOTE:

This function is different from deceleration control listed under [EC-1007, "Fuel Injection Control System"](#).

## Crankcase Ventilation System DESCRIPTION


In this system, blow-by gas is sucked into the air duct after oil separation by oil separator in the rocker cover.



## INSPECTION

### Ventilation Hose

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.





## CAN Communication SYSTEM DESCRIPTION

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only. Refer to [LAN-26. "CAN Communication Unit"](#) , about CAN communication for detail.

A

EC

C

D

E

F

G

H

I

J

K

L

M

## BASIC SERVICE PROCEDURE

PFP:00018

### Fuel Filter DESCRIPTION


GBS00034

A water draining cock is on the lower side and a priming pump for bleeding air is on the upper side.

### AIR BLEEDING

Pump the priming pump (1) to bleed air.

- When air is bled completely, the pumping of the priming pump suddenly becomes heavy. Stop the operation at that time.
- If it is difficult to bleed air by the pumping of the priming pump (the pumping of the priming pump does not become heavy), disconnect the fuel supply hose between the fuel filter and the fuel gallery. Then, perform the operation described above, and make sure that fuel comes out. (Use a pan, etc. so as not to spill fuel. Do not let fuel get on engine and other parts.) After that, connect the hose, then bleed air again.
- Start engine and let it idle for at least 1 minute after performing air bleeding.



### WATER DRAINING

1. Remove the fuel filter, filter bracket, protector assembly from the dash panel as follows.
  - a. Remove the air cleaner case (upper), air duct assembly, and vacuum hose for brake booster (between the vacuum pump and vacuum pipe).

**CAUTION:**

**After the duct is removed, cover the opening with gum tape, etc. to prevent foreign object from getting into the engine during the operation.**

- b. Remove the mounting nuts on the dash panel, then remove the fuel filter, filter bracket, and protector assembly from the dash panel.
    - It is not necessary to disconnect the fuel hose.

2. Using a tool such as a pliers, loosen the water draining cock at the bottom of the fuel filter.

**Loosening drain cock four to five turns causes water to start draining.**

**Do not remove drain cock by loosening it excessively.**


If water does not drain properly, move the priming up and down.

**CAUTION:**

**When the water is drained, the fuel is also drained. Use a pan, etc. to avoid fuel adherence to the rubber parts such as the engine mount insulator.**

**Do not over-tighten the water draining cock. This will damage the cock thread, resulting in water or fuel leak.**

3. Bleed air of the fuel filter. Refer to [EC-1012, "AIR BLEEDING"](#).
4. Start the engine.



## Fuel Pump Learning Value Clearing

### DESCRIPTION

In order to always keep optimum fuel pressure in fuel rail, the ECM controls fuel pump in high precision with monitoring the signal of fuel rail pressure sensor. Accordingly, the ECM always learns characteristic value of fuel pump. Fuel Pump Learning Value Clearing is an operation to clear the value of the fuel pump learning. Fuel Pump Learning Value Clearing should be performed under the following conditions.

- Fuel pump is changed.
- ECM is replaced with used one which stores the fuel pump learning value of other fuel pump.


### OPERATION PROCEDURE

#### NOTE:


When removing fuel pump, perform Fuel Pump Learning Value Clearing before starting engine.

#### Ⓟ With CONSULT-II


1. Turn ignition switch ON.
2. Select "PUMP LEARNT CLEAR" in "ACTIVE TEST" mode with CONSULT-II.



3. Touch "CLEAR" and wait a few seconds.



4. Make sure that "CMPLT" is displayed on CONSULT-II screen.



#### ⓧ Without CONSULT-II

Fuel pump learning value can be erased from the back up memory in the ECM by the same operation as erasing DTC. In detail, refer to [EC-1016, "Without CONSULT-II"](#).

## Injector Adjustment Value Registration DESCRIPTION


Injector adjustment value indicates manufacturing tolerance and the value is printed on the top of fuel injector. The injector adjustment value which is correctly stored in ECM is needed for precise fuel injection control. A performance of emission control and a drivability may effect when there is a mismatch between the following two values.

- The injector adjustment value stored in ECM
- The injector adjustment value of the injector which is installed on the vehicle

Injector Adjustment Value Registration must be performed after the following cases.

- Injector(s) are replaced.
- ECM is replaced.

For the first case, Injector Adjustment Value Registration for the replaced fuel injector must be performed. And for the second case, Injector Adjustment Value Registration for all the fuel injectors must be performed.



Example: Injector adjustment value = D021ABCD1A061234000000000000E6

## OPERATION PROCEDURE

### NOTE:

- Before performing this procedure, record injector adjustment value printed on a fuel injector.
- When all fuel injectors are replaced or ECM is replaced, it is recommended to perform “INJ ADJ VAL CLR” in “WORK SUPPORT” mode before performing this procedure. By performing “INJ ADJ VAL CLR” in “WORK SUPPORT” mode, injector adjustment value stored in ECM is initialized.

1. Turn ignition switch ON (engine stopped).
2. Select “ENTER INJECTOR CALIB DATA” in “WORK SUPPORT” mode with CONSULT-II.
3. Touch “START”.

### NOTE:

When touching “START”, CONSULT-II reads injector adjustment values stored in ECM.

4. Select the number of the cylinder which needs Injector Adjustment Value Registration.
  5. Input injector adjustment value, and touch “ENTER”.
- NOTE:**  
Input injector adjustment value is stored in CONSULT-II.
6. Repeat step 4 - 5 till there is no cylinder which needs Injector Adjustment Value Registration, and touch “START”.

### NOTE:

When touching “START”, injector adjustment values stored in CONSULT-II are written onto ECM memory.

7. After “CMND FINISHED” is displayed, make sure that the following values are same for each cylinder.
  - Injector adjustment value which is printed on a fuel injector.
  - Injector adjustment value which is displayed on CONSULT-II screen.

### NOTE:

In this step, CONSULT-II reads injector adjustment values stored in ECM and displays the values on the CONSULT-II screen. This is for checking if injector adjustment values are written onto ECM memory correctly.

# BASIC SERVICE PROCEDURE

[YD]

- If DTC is detected, perform DTC Confirmation Procedure for the DTC, and check if the same DTC is detected again.

1. Turn ignition switch ON (engine stopped).

SELECT WORK ITEM	
ENTER INJCTR CALIB DATA	

2. Select "ENTER INJECTOR CALIB DATA" in "WORK SUPPORT" mode with CONSULT-II.

ENTER INJCTR CALIB DATA	
IGNITION ON AND ENGINE STOPPED.	
START	

3. Touch "START".

ENTER INJCTR CALIB DATA	
SET VALUE	
CYL1	D0002A1933140E00 000000000000CA
CYL2	D0000B0032ECF600 000000000000F3
CYL3	D0D9EC00FOECE00 00000000000017
CYL4	D0D5F3F1F3E9EA00 000000000000F7
CYL1	CYL2
CYL3	CYL4
END	START

4. Select the number of the cylinder which needs Injector Adjustment Value Registration.

KEYBOARD		HEX	
_0002A1933140E0000000000000CA			
A	B	C	D
7	8	9	E
4	5	6	F
1	2	3	
<<	>>	0	00
CLEAR	BKSPC	ENTER	

5. Input injector adjustment value, and touch "ENTER".

ENTER INJCTR CALIB DATA	
SET VALUE	
CYL1	D021ABCDEF881234 000000000000E6
CYL2	D0000B0032ECF600 000000000000F3
CYL3	D0D9EC00FOECE00 00000000000017
CYL4	D0D5F3F1F3E9EA00 000000000000F7
CYL1	CYL2
CYL3	CYL4
END	START

6. Repeat step 4 - 5 till there is no cylinder which needs Injector Adjustment Value Registration, and touch "START".

ENTER INJCTR CALIB DATA	
CMND FINISHED	
SET VALUE	
CYL1	D021ABCDEF881234 000000000000E6
CYL2	D0000B0032ECF600 000000000000F3
CYL3	D0D9EC00FOECE00 00000000000017
CYL4	D0D5F3F1F3E9EA00 000000000000F7

7. After "CMND FINISHED" is displayed, make sure that the following values are same for each cylinder.

- Injector adjustment value which is printed on a injector.
- Injector adjustment value which is displayed on CONSULT-II screen.

MBIB1254E

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

## ON BOARD DIAGNOSTIC (OBD) SYSTEM

PFP:00028

### DTC Detection Logic

GBS00037

When a malfunction is detected, the malfunction (DTC) and freeze frame data are stored in the ECM memory. The MIL will light up each time the ECM detects malfunction. For diagnostic items causing the MIL to light up, refer to [EC-996, "INDEX FOR DTC"](#) .

### Diagnostic Trouble Code (DTC)

GBS00038

#### HOW TO READ DTC

The DTC can be read by the following methods.

#### ④ With CONSULT-II

CONSULT-II displays the DTC in "SELF-DIAG RESULTS" mode. Example: P0117, P0335, P1268, etc. (CONSULT-II also displays the malfunctioning component or system.)

#### ⊗ Without CONSULT-II

The number of blinks of the MIL in the Diagnostic Test Mode II (Self-Diagnostic Results) indicates the DTC. Example: 0117, 0335, 1260, etc.

- **Output of a DTC indicates a malfunction. However, the Diagnostic Test Mode II does not indicate whether the malfunction is still occurring or has occurred in the past and has returned to normal. CONSULT-II can identify malfunction status as shown below. Therefore, using CONSULT-II (if available) is recommended.**

#### HOW TO ERASE DTC

##### ④ With CONSULT-II

1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 5 seconds and then turn it ON (engine stopped) again.
2. Touch "ENGINE".
3. Touch "SELF-DIAG RESULTS".
4. Touch "ERASE". (The DTC in the ECM will be erased.)

**How to erase DTC (With CONSULT-II)**

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 5 seconds and then turn it "ON" again.

SELECT SYSTEM
ENGINE

2. Turn CONSULT-II "ON" and touch "ENGINE".

➔

SELECT DIAG MODE
SELF-DIAG RESULTS
DATA MONITOR
CAN DIAG SUPPORT MNTR
ACTIVE TEST
FUNCTION TEST
ECM PART NUMBER

3. Touch "SELF-DIAG RESULTS".

➔

SELF DIAG RESULTS	
DTC RESULTS	TIME
ECT SEN/CIRCUIT [P0118]	0

4. Touch "ERASE". (The DTC in the ECM will be erased.)

PBIB2452E

The emission related diagnostic information in the ECM can be erased by selecting "ERASE" in the "SELF-DIAG RESULTS" mode with CONSULT-II.

#### ⊗ Without CONSULT-II

1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once.
2. Wait at least 10 seconds and then turn it ON (engine stopped) again.
3. Change the diagnostic test mode from Mode II to Mode I by depressing the accelerator pedal. Refer to [EC-1018, "HOW TO SWITCH DIAGNOSTIC TEST MODE"](#) .

- If the battery is disconnected, the emission-related diagnostic information will be lost within 24 hours.
- The following data are cleared when the ECM memory is erased.
  - Diagnostic trouble codes
  - Freeze frame data
  - Fuel pump learning value

Actual work procedures are explained using a DTC as an example. Be careful so that not only the DTC, but all of the data listed above, are cleared from the ECM memory during work procedures.

## Freeze Frame Data

GBS00039

The ECM records the driving conditions such as calculated load value, engine coolant temperature, engine speed, vehicle speed and intake manifold pressure at the moment a malfunction is detected.

The data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT-II. For details, see [EC-1017, "Freeze Frame Data"](#).

Only one set of freeze frame data can be stored in the ECM. If freeze frame data is stored in the ECM memory and another freeze frame data occurs later, the first (original) freeze frame data remains unchanged in the ECM memory.

Freeze frame data (along with the DTCs) are cleared when the ECM memory is erased. Procedures for clearing the ECM memory are described in [EC-1016, "HOW TO ERASE DTC"](#).

## NATS (Nissan Anti-theft System)

GBS0003A

- If the security indicator lights up with the ignition switch in the ON position or "NATS MALFUNCTION" is displayed on "SELF-DIAG RESULTS" screen, perform self-diagnostic results mode with CONSULT-II using NATS program card. Refer to [BL-81, "NATS\(Nissan Anti-Theft System\)"](#).
- Confirm no self-diagnostic results of NATS is displayed before touching "ERASE" in "SELF-DAIG RESULTS" mode with CONSULT-II.
- When replacing ECM, initialization of NATS system and registration of all NATS ignition key IDs must be carried out with CONSULT-II using NATS program card.

SELF DIAG RESULTS	
DTC RESULTS	TIME
NATS MALFUNCTION [P1610]	0

SEF543X

Therefore, be sure to receive all keys from vehicle owner.

Regarding the procedure of NATS initialization and all NATS ignition key ID registration, refer to CONSULT-II operation manual, NATS.


## Malfunction Indicator Lamp (MIL)

GBS0003B

### DESCRIPTION

The MIL is located on the combination meter.

1. The MIL will light up when the ignition switch is turned ON without the engine running. This is a bulb check.
  - If the MIL does not light up, refer to [EC-1336, "MIL AND DATA LINK CONNECTOR"](#).
2. When the engine is started, the MIL should go off. If the MIL remains on, the on board diagnostic system has detected an engine system malfunction.








## ON BOARD DIAGNOSTIC SYSTEM FUNCTION

The on board diagnostic system has the following three functions.

# ON BOARD DIAGNOSTIC (OBD) SYSTEM

[YD]

Diagnostic Test Mode	KEY and ENG. Status	Function	Explanation of Function
Mode I	Ignition switch in ON position  Engine stopped 	BULB CHECK	This function checks the MIL bulb for damage (blown, open circuit, etc.). If the MIL does not come on, check MIL circuit. (See <a href="#">EC-1336, "MIL AND DATA LINK CONNECTOR"</a> .)
	Engine running 	MALFUNCTION WARNING	This is a usual driving condition. When ECM detects a malfunction, the MIL will light up to inform the driver that a malfunction has been detected.
Mode II	Ignition switch in ON position  Engine stopped 	SELF-DIAGNOSTIC RESULTS	This function allows DTCs to be read.


## HOW TO SWITCH DIAGNOSTIC TEST MODE

### NOTE:

- It is better to count the time accurately with a clock.
- It is impossible to switch the diagnostic mode when an accelerator pedal position sensor circuit has a malfunction.
- Always ECM returns to Diagnostic Test Mode I after ignition switch is turned OFF.

### How to Set Diagnostic Test Mode II (Self-diagnostic Results)

1. Confirm that accelerator pedal is fully released, turn ignition switch ON and wait 3 seconds.
2. Repeat the following procedure quickly five times within 5 seconds.
  - a. Fully depress the accelerator pedal.
  - b. Fully release the accelerator pedal.
3. Wait 7 seconds, fully depress the accelerator pedal and keep it for approx. 10 seconds until the MIL starts blinking.
4. Fully release the accelerator pedal.  
ECM has entered to Diagnostic Test Mode II (Self-diagnostic results).





## How to Erase Diagnostic Test Mode II (Self-diagnostic Results)

1. Set ECM in Diagnostic Test Mode II (Self-diagnostic results). Refer to [EC-1018, "How to Set Diagnostic Test Mode II \(Self-diagnostic Results\)"](#) .
2. Fully depress the accelerator pedal and keep it for more than 10 seconds.  
The emission-related diagnostic information has been erased from the backup memory in the ECM.
3. Fully release the accelerator pedal, and confirm the DTC 0000 is displayed.

## DIAGNOSTIC TEST MODE I — BULB CHECK

In this mode, the MIL on the combination meter should stay ON. If it remains OFF, check the bulb. Refer to [EC-1336, "MIL AND DATA LINK CONNECTOR"](#) .


## DIAGNOSTIC TEST MODE I — MALFUNCTION WARNING

MIL	Condition
ON	When the malfunction is detected.
OFF	No malfunction.

These DTC numbers are clarified in Diagnostic Test Mode II (SELF-DIAGNOSTIC RESULTS)

## DIAGNOSTIC TEST MODE II — SELF-DIAGNOSTIC RESULTS

In this mode, the DTC is indicated by the number of blinks of the MIL as shown below. A DTC will be used as an example for how to read a code.



A particular trouble code can be identified by the number of four-digit numeral flashes. The "zero" is indicated by the number of ten flashes. The length of time the 1,000th-digit numeral flashes on and off is 1.2 seconds consisting of an ON (0.6-second) - OFF (0.6-second) cycle.

The 100th-digit numeral and lower digit numerals consist of a 0.3-second ON and 0.3-second OFF cycle.

A change from one digit numeral to another occurs at an interval of 1.0-second OFF. In other words, the later numeral appears on the display 1.3 seconds after the former numeral has disappeared.

A change from one trouble code to another occurs at an interval of 1.8-second OFF.

In this way, all the detected malfunctions are classified by their DTC numbers. The DTC 0000 refers to no malfunction. (See [EC-996, "INDEX FOR DTC"](#) )


## How to Erase Diagnostic Test Mode II (Self-diagnostic Results)

The DTC can be erased from the back up memory in the ECM by depressing accelerator pedal. Refer to [EC-1018, "How to Set Diagnostic Test Mode II \(Self-diagnostic Results\)"](#) .

- If the battery is disconnected, the DTC will be lost from the backup memory within 24 hours.
- Be careful not to erase the stored memory before starting trouble diagnoses.

## Relationship Between MIL, DTC, CONSULT-II and Driving Patterns

GBS0003C



PBIB2990E

\*1: When a malfunction is detected, MIL will light up.


\*2: MIL will not light up after ignition switch is turned OFF.

\*3: When a malfunction is detected for the first time, the DTC will be stored in ECM.

\*4: Other screens except SELF-DIAGNOSTIC RESULTS & DATA MONITOR (AUTO TRIG) cannot display the malfunction. DATA MONITOR (AUTO TRIG) can display the malfunction at the moment it is detected.

\*5: The DTC will not be displayed any longer after vehicle is driven 40 times (Driving pattern A) without the same malfunction. (The DTC still remain in ECM.)

## DRIVING PATTERN A



- The counter will be cleared when the malfunction is detected regardless of (1) - (4).
- The counter will be counted up when (1) - (4) are satisfied without the same malfunction.
- The DTC will not be displayed after the counter reaches 40.

A  
 EC  
 C  
 D  
 E  
 F  
 G  
 H  
 I  
 J  
 K  
 L  
 M


## TROUBLE DIAGNOSIS

PFP:00004


### Trouble Diagnosis Introduction INTRODUCTION

GBS0003D

The engine has an ECM to control major systems such as fuel injection control, fuel injection timing control, glow control system, etc. The ECM accepts input signals from sensors and instantly actuators. It is essential that both input and output signals are proper and stable. At the same time, it is important that there are no malfunctions such as vacuum leaks, or other malfunctions with the engine.




It is much more difficult to diagnose a malfunction that occurs intermittently rather than continuously. Most intermittent malfunctions are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.



A visual check only may not find the cause of the incidents. A road test with CONSULT-II or a circuit tester connected should be performed. Follow the [EC-1023, "WORK FLOW"](#).

Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such incidents, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A Diagnostic Worksheet like the example on next page should be used.

Start your diagnosis by looking for "conventional" incidents first. This will help troubleshoot driveability incidents on an electronically controlled engine vehicle.




# TROUBLE DIAGNOSIS

[YD]

## WORK FLOW

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



PBIB0477E

\*1 If time data of "SELF-DIAG RESULTS" is other than "0", perform [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

\*2 If the incident cannot be verified, perform [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

\*3 If the on board diagnostic system cannot be performed, check main power supply and ground circuit. Refer to [EC-1059, "POWER SUPPLY AND GROUND CIRCUIT"](#) .

\*4 If malfunctioning part cannot be detected, perform [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

# TROUBLE DIAGNOSIS

[YD]

## Description for Work Flow

STEP	DESCRIPTION
STEP I	Get detailed information about the conditions and the environment when the incident/symptom occurred using the <a href="#">EC-1024, "DIAGNOSTIC WORK SHEET"</a> .
STEP II	Before confirming the concern, check and write down (print out using CONSULT-II) the DTC and the freeze frame data, then erase the DTC. The DTC and the freeze frame data can be used when duplicating the incident at STEP III & IV. Refer to <a href="#">EC-1016</a> . If the incident cannot be verified, perform <a href="#">EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"</a> . Study the relationship between the cause, specified by DTC, and the symptom described by the customer. (The "Symptom Matrix Chart" will be useful. Refer to <a href="#">EC-1031</a> .) Also check related service bulletins for information.
STEP III	Try to confirm the symptom and under what conditions the incident occurs. The "DIAGNOSTIC WORK SHEET" and the freeze frame data are useful to verify the incident. Connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform <a href="#">EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"</a> . If the malfunction code is detected, skip STEP IV and perform STEP V.
STEP IV	Try to detect the DTC by driving in (or performing) the DTC Confirmation Procedure. Check and read the DTC and the freeze frame data by using CONSULT-II. During the DTC verification, be sure to connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform <a href="#">EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"</a> . In case the DTC Confirmation Procedure is not available, perform the Overall Function Check instead. The DTC cannot be displayed by this check, however, this simplified "check" is an effective alternative. The "NG" result of the Overall Function Check is the same as the DTC detection.
STEP V	Take the appropriate action based on the results of STEP I through IV. If the malfunction code is indicated, proceed to Trouble Diagnosis for DTC PXXXX. If the normal code is indicated, proceed to the Basic Inspection, <a href="#">EC-1027</a> . Then perform inspections according to the Symptom Matrix Chart. Refer to <a href="#">EC-1031</a> .
STEP VI	Identify where to begin diagnosis based on the relationship study between symptom and possible causes. Inspect the system for mechanical binding, loose connectors or wiring damage using (tracing) Harness Layouts. Gently shake the related connectors, components or wiring harness with CONSULT-II set in "DATA MONITOR (AUTO TRIG)" mode. Check the voltage of the related ECM terminals or monitor the output data from the related sensors with CONSULT-II. Refer to <a href="#">EC-1041</a> or <a href="#">EC-1054</a> . The Diagnostic Procedure in EC section contains a description based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure. For details, refer to <a href="#">GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"</a> , "Circuit Inspection". Repair or replace the malfunction parts. If the malfunctioning part cannot be detected, perform <a href="#">EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"</a> .
STEP VII	Once you have repaired the circuit or replaced a component, you need to run the engine in the same conditions and circumstances which resulted in the customer's initial complaint. Perform the DTC Confirmation Procedure and confirm the normal code (DTC P0000) is detected. If the incident is still detected in the final check, perform STEP VI by using a different method from the previous one. Before returning the vehicle to the customer, be sure to erase the unnecessary (already fixed) DTC in ECM. (Refer to <a href="#">EC-1016</a> .)

## DIAGNOSTIC WORK SHEET

There are many operating conditions that lead to the malfunction of engine components. A good grasp of such conditions can make troubleshooting faster and more accurate.

In general, each customer feels differently about an incident. It is important to fully understand the symptoms or conditions for a customer complaint.

Utilize a diagnostic worksheet like the one shown below in order to organize all the information for troubleshooting.

<b>KEY POINTS</b>	
<b>WHAT</b> .....	Vehicle & engine model
<b>WHEN</b> .....	Date, Frequencies
<b>WHERE</b> .....	Road conditions
<b>HOW</b> .....	Operating conditions, Weather conditions, Symptoms

SEF907L



## DTC Inspection Priority Chart

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

**NOTE:**

**If DTC U1000 is displayed with other DTC, first perform the trouble diagnosis for DTC U1000. Refer to [EC-1067, "DTC U1000 CAN COMMUNICATION LINE"](#) .**

Priority	Detected items (DTC)
1	<ul style="list-style-type: none"> <li>● U1000 CAN communication line</li> <li>● P0016 Crankshaft position - camshaft position correlation</li> <li>● P0102 P0103 Mass air flow sensor</li> <li>● P0112 P0113 Intake air temperature sensor</li> <li>● P0117 P0118 Engine coolant temperature sensor</li> <li>● P0122 P0123 P0222 P0223 P2135 Accelerator pedal position sensor</li> <li>● P0182 P0183 Fuel pump temperature sensor</li> <li>● P0192 P0193 Fuel rail pressure sensor</li> <li>● P0237 P0238 Turbocharger boost sensor</li> <li>● P0335 P0336 Crankshaft position sensor</li> <li>● P0340 P0341 Camshaft position sensor</li> <li>● P0563 Battery voltage</li> <li>● P0605 P0606 P1616 ECM</li> <li>● P0642 P0643 P0652 P0653 Sensor power supply</li> <li>● P1610 - P1615 NATS</li> <li>● P1622 P1623 Injector adjustment value</li> <li>● P2228 P2229 Barometric pressure sensor</li> </ul>
2	<ul style="list-style-type: none"> <li>● P0089 P0628 P0629 P1272 - P1275 Fuel pump</li> <li>● P0200 - P0204 P1268 - P1271 P2146 - P2149 Fuel injector</li> <li>● P0686 ECM relay</li> </ul>
3	<ul style="list-style-type: none"> <li>● P0088 P0093 Fuel system</li> <li>● P0217 Engine over temperature (OVERHEAT)</li> <li>● P0234 Turbocharger system</li> <li>● P0501 P0502 P0503 ASCD vehicle speed sensor</li> <li>● P0504 ASCD brake switch</li> <li>● P0580 P0581 ASCD steering switch</li> </ul>



## Basic Inspection

### Precaution:


Perform Basic Inspection without electrical or mechanical loads applied;

- Headlamp switch is OFF.
- On vehicles equipped with daytime light systems, set lighting switch to the 1st position to light only small lamps.
- Air conditioner switch is OFF.
- Heater fan switch is OFF.
- Rear defogger switch is OFF.
- Steering wheel is in the straight-ahead position, etc.

## 1. INSPECTION START

1. Check service records for any recent repairs that may indicate a related incident.
2. Check the current need for scheduled maintenance, especially for fuel filter and air cleaner filter. Refer to [MA-8, "PERIODIC MAINTENANCE \(EXCEPT FOR EUROPE\)"](#).
3. Open engine hood and check the following:
  - Harness connectors for improper connections
  - Vacuum hoses for splits, kinks, or improper connections
  - Wiring for improper connections, pinches, or cuts
4. Start engine and warm it up to the normal operating temperature.

>> GO TO 2.



## 2. PREPARATION FOR CHECKING IDLE SPEED

### ④ With CONSULT-II

Connect CONSULT-II to the data link connector.

### ⊗ Without CONSULT-II

Install diesel tachometer to the vehicle.

>> GO TO 3.

### 3. CHECK IDLE SPEED

#### With CONSULT-II

1. Select "CKPS-RPM (TDC)" in "DATA MONITOR" mode with CONSULT-II.
2. Read idle speed.

**M/T: 750±25 rpm (in Neutral position)**

**A/T: 750±25 rpm (in P or N position)**

#### Without CONSULT-II

Read idle speed.

**M/T: 750±25 rpm (in Neutral position)**

**A/T: 750±25 rpm (in P or N position)**

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 4.

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

### 4. CHECK FOR INTAKE AIR LEAK

1. Stop engine.
2. Listen for an intake air leak after the mass air flow sensor.

OK or NG

OK >> GO TO 5.

NG >> Repair or replace.

### 5. BLEED AIR FROM FUEL SYSTEM

Use priming pump to bleed air from fuel system. Refer to [EC-1012, "AIR BLEEDING"](#) .

>> GO TO 6.

### 6. CHECK IDLE SPEED AGAIN

#### With CONSULT-II

1. Start engine and let it idle.
2. Select "CKPS-RPM (TDC)" in "DATA MONITOR" mode with CONSULT-II.
3. Read idle speed.

**M/T: 750±25 rpm (in Neutral position)**

**A/T: 750±25 rpm (in P or N position)**

#### Without CONSULT-II

Read idle speed.

**M/T: 750±25 rpm (in Neutral position)**

**A/T: 750±25 rpm (in P or N position)**

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 7.

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

### 7. DRAIN WATER FROM FUEL FILTER

1. Stop engine.
2. Drain water from fuel filter. Refer to [EC-1012, "WATER DRAINING"](#) .

>> GO TO 8.

**8. CHECK IDLE SPEED AGAIN****With CONSULT-II**

1. Start engine and let it idle.
2. Select "CKPS-RPM (TDC)" in "DATA MONITOR" mode with CONSULT-II.
3. Read idle speed.

**M/T: 750±25 rpm (in Neutral position)**

**A/T: 750±25 rpm (in P or N position)**

**Without CONSULT-II**

Read idle speed.

**M/T: 750±25 rpm (in Neutral position)**

**A/T: 750±25 rpm (in P or N position)**

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 9.

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

**9. CHECK AIR CLEANER FILTER**

1. Stop engine.
2. Check air cleaner filter for clogging or breaks.

OK or NG

OK >> GO TO 10.

NG >> Replace air cleaner filter.

**10. CHECK BATTERY VOLTAGE**

Check battery voltage.

**Voltage: More than 12.13V**

OK or NG

OK >> GO TO 12.

NG >> GO TO 11.

**11. CHECK BATTERY**

Refer to [SC-5, "BATTERY"](#) .

OK or NG

OK >> Check charging system. Refer to [SC-14, "CHARGING SYSTEM"](#) .

NG >> Repair or replace.

**12. CHECK COMPRESSION PRESSURE**

Check compression pressure. Refer to [EM-236, "CHECKING COMPRESSION PRESSURE"](#) .

OK or NG

OK >> GO TO 13.

NG >> Follow the instruction of "CHECKING COMPRESSION PRESSURE".

**13. CHECK IDLE SPEED AGAIN**

**With CONSULT-II**

1. Start engine and let it idle.
2. Select "CKPS-RPM (TDC)" in "DATA MONITOR" mode with CONSULT-II.
3. Read idle speed.

**M/T: 750±25 rpm (in Neutral position)**

**A/T: 750±25 rpm (in P or N position)**

**Without CONSULT-II**

Read idle speed.

**M/T: 750±25 rpm (in Neutral position)**

**A/T: 750±25 rpm (in P or N position)**

OK or NG

- OK >> **INSPECTION END**
- NG >> 1. Replace fuel injector.  
2. GO TO 3.

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

# TROUBLE DIAGNOSIS

[YD]

## Symptom Matrix Chart

GBS0003G

	SYMPTOM												Reference page		
	HARD/NO START/RESTART (EXCP. HA)				ENGINE STALL			HESITATION/SURGING/FLAT SPOT	KNOCK/DETONATION	LACK OF POWER	POOR ACCELERATION	HI IDLE		LOW IDLE	
	NO START (with first firing)	NO START (without first firing)	HARD TO START WHEN ENGINE IS COLD	HARD TO START WHEN ENGINE IS HOT	AT IDLE	DURING DRIVING	WHEN DECELERATING								
SYSTEM — Basic engine control system	AA				AB			AC	AD	AE		AF			
Warranty symptom code															
Fuel pump	5	5	5	5	5	5	5	5		5	5		5	—	
Fuel injector	3	3	3	3	3	3	3	3	3	4	4	3	3	<a href="#">EC-1113</a>	
Glow control system	1	1	1	1					1					<a href="#">EC-1283</a>	
Engine body	3	3	3	3	3	3	3		3	4	4		3	<a href="#">EM-250</a>	
EGR system										3	3			<a href="#">EC-1290</a>	
Air cleaner and duct										3	3			<a href="#">EM-159</a>	
Fuel rail pressure relief valve	3	3	3	3	3	3	3	3		3	3		3	<a href="#">EC-1076</a>	
ENGINE CONTROL	Fuel pump circuit	4	4	4	4	4	4	4	4		4	4		4	<a href="#">EC-1205</a>
	Fuel injector circuit	1	1	1	1	1	1	1	1	1	1	1	1	1	<a href="#">EC-1113</a>
	Fuel injector adjustment valve								1	1	1	1			<a href="#">EC-1014</a>
	Mass air flow sensor circuit								1		1	1			<a href="#">EC-1080</a>
	Engine coolant temperature circuit			1		1		1						1	<a href="#">EC-1091</a>
	Vehicle speed signal circuit											1			<a href="#">LAN-26</a>
	Accelerator pedal position sensor circuit								1		1	1			<a href="#">EC-1096</a> , <a href="#">EC-1130</a> , <a href="#">EC-1263</a>
	Fuel rail pressure sensor circuit														<a href="#">EC-1106</a>

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# TROUBLE DIAGNOSIS

[YD]

SYSTEM — Basic engine control system		SYMPTOM												Reference page	
		HARD/NO START/RESTART (EXCP. HA)				ENGINE STALL									
		NO START (with first firing)	NO START (without first firing)	HARD TO START WHEN ENGINE IS COLD	HARD TO START WHEN ENGINE IS HOT	AT IDLE	DURING DRIVING	WHEN DECELERATING	HESITATION/SURGING/FLAT SPOT	KNOCK/DETONATION	LACK OF POWER	POOR ACCELERATION	HI IDLE	LOW IDLE	
Warranty symptom code		AA				AB			AC	AD	AE		AF		
ENGINE CONTROL	Crankshaft position sensor circuit		1	1	1	1	1	1	1	1	1	1			<a href="#">EC-1147</a>
	Camshaft position sensor circuit			3	3										<a href="#">EC-1159</a>
	Turbocharger boost sensor circuit								1		1	1			<a href="#">EC-1141</a>
	Turbocharger boost control solenoid valve circuit								1		1	1			<a href="#">EC-1297</a>
	Intake air control valve control solenoid valve circuit	1	1	1	1	1	1	1	1						<a href="#">EC-1302</a>
	Start signal circuit	1	1	1	1	1		1	1		1	1			<a href="#">EC-1330</a>
	Ignition switch circuit		1			1	1	1							<a href="#">EC-1059</a>
	Power supply for ECM circuit		1			1	1	1							<a href="#">EC-1059</a>
	Cooling fan relay circuit														<a href="#">EC-1120</a>
	EGR volume control valve circuit								1		1	1			<a href="#">EC-1290</a>
	Glow relay circuit	1	1	1											<a href="#">EC-1283</a>
	ECM relay (Self shut-off) circuit		1				1	1	1						<a href="#">EC-1220</a>
	ECM	2	2	2	2	2	2	2	2	2	2	2	2	2	<a href="#">EC-1201</a> , <a href="#">EC-1203</a> , <a href="#">EC-1257</a>
NATS (Nissan Anti-theft System)			1											<a href="#">EC-1017</a>	

1 - 5: The numbers refer to the order of inspection.  
(continued on next page)

# TROUBLE DIAGNOSIS

[YD]

	SYMPTOM										Reference page	
	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEAT/HIGH ENGINE COOLANT TEMPERATURE	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	ABNORMAL SMOKE COLOR		DEAD BATTERY (UNDER CHARGE)	Malfunction indicator lamp illuminates.		Can be detected by CONSULT-II?
Warranty symptom code	AG	AH	AJ	AK	AL	AM	BLACK SMOKE	WHITE SMOKE	HA			
Fuel pump	5	5	5		5					1	1	—
Fuel injector	3	3	3		4		3	3		1	1	<a href="#">EC-1113</a>
Glow control system								1				<a href="#">EC-1283</a>
Engine body		3	3	3	3	1		3				<a href="#">EM-250</a>
EGR system							3					<a href="#">EC-1290</a>
Air cleaner and duct							3					<a href="#">EM-159</a>
Fuel rail pressure relief valve	3	3	3		3							<a href="#">EC-1076</a>
ENGINE CONTROL	Fuel pump circuit	4	4	4	4					1	1	<a href="#">EC-1205</a>
	Fuel injector circuit	1	1	1	1		1	1		1	1	<a href="#">EC-1113</a>
	Fuel injector adjustment value	1	1			1	1	1			1	<a href="#">EC-1014</a>
	Mass air flow sensor circuit						1			1	1	<a href="#">EC-1080</a>
	Engine coolant temperature circuit	1	1		1					1	1	<a href="#">EC-1091</a>
	Vehicle speed signal circuit									1	1	<a href="#">LAN-26</a>
	Accelerator pedal position sensor circuit			1						1	1	<a href="#">EC-1096</a> , <a href="#">EC-1130</a> , <a href="#">EC-1263</a>
	Fuel rail pressure sensor circuit									1	1	<a href="#">EC-1106</a>

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# TROUBLE DIAGNOSIS

[YD]

		SYMPTOM										Reference page	
		ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEAT/HIGH ENGINE COOLANT TEMPERATURE	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	ABNORMAL SMOKE COLOR		DEAD BATTERY (UNDER CHARGE)	Malfunction indicator lamp illuminates.		Can be detected by CONSULT-II?
Warranty symptom code		AG	AH	AJ	AK	AL	AM	AP		HA			
ENGINE CONTROL	Crankshaft position sensor circuit	1	1								1	1	<a href="#">EC-1147</a>
	Camshaft position sensor circuit										1	1	<a href="#">EC-1159</a>
	Turbocharger boost sensor circuit										1	1	<a href="#">EC-1141</a>
	Turbocharger boost control solenoid valve circuit							1	1				<a href="#">EC-1297</a>
	Start signal circuit												<a href="#">EC-1330</a>
	Ignition switch circuit												<a href="#">EC-1059</a>
	Power supply for ECM circuit										1	1	<a href="#">EC-1059</a>
	Cooling fan relay circuit				2								<a href="#">EC-1120</a>
	EGR volume control valve circuit							1					<a href="#">EC-1290</a>
	Glow relay circuit								1				<a href="#">EC-1283</a>
	ECM relay (Self shut-off) circuit											1	<a href="#">EC-1220</a>
	ECM	2	2	2	2	2	2	2	2	2	2	2	<a href="#">EC-1201</a> , <a href="#">EC-1203</a> , <a href="#">EC-1257</a>
NATS (Nissan Anti-theft System)												1	<a href="#">EC-1017</a>

1 - 5: The numbers refer to the order of inspection.



## Engine Control Component Parts Location

GBS0003H

A

**EC**

C

D

E

F

G

H


I

J

K







L

M



MBIB1198E







- |   |  |   |
|---|--|---|
| <ul style="list-style-type: none"> <li>1. IPDM E/R</li> <li>4. Turbocharger boost sensor</li> <li>7. Fuel pump</li> <li>10. Turbocharger boost control solenoid valve</li> <li>13. Camshaft position sensor</li> <li>16. Fuel rail pressure sensor</li> </ul> | <ul style="list-style-type: none"> <li>2. ECM</li> <li>5. Refrigerant pressure sensor</li> <li>8. Cooling fan motor</li> <li>11. Mass air flow sensor</li> <li>14. Glow plug</li> <li>17. Intake air control valve control solenoid valve</li> </ul> | <ul style="list-style-type: none"> <li>3. Glow relay</li> <li>6. Engine coolant temperature sensor</li> <li>9. Intake air control valve actuator</li> <li>12. Turbocharger boost control actuator</li> <li>15. Fuel injector</li> <li>18. EGR volume control valve</li> </ul> |
|---|--|---|



↔ : Vehicle front

- |                                 |                                      |                                    |
|---------------------------------|--------------------------------------|------------------------------------|
| 1. Fuel pump temperature sensor | 2. Fuel pump                         | 3. Fuel rail pressure relief valve |
| 4. Fuel rail                    | 5. Engine coolant temperature sensor | 6. EGR volume control valve        |
| 7. Fuel rail pressure sensor    | 8. Camshaft position sensor          | 9. Refrigerant pressure sensor     |

MBIB1388E








← : Vehicle front

- |  |                      |  |
|--|----------------------|--|
| 1. Glow relay  | 2. ECM               | 3. Crankshaft position sensor<br>(View from under the vehicle) |
| 4. Turbocharger boost sensor<br>(View with front grille removed) | 5. ASCD brake switch | 6. Stop lamp switch  |
| 7. Accelerator pedal position sensor                             |                      |  |

MBIB1249E

# TROUBLE DIAGNOSIS

[YD]




← : Vehicle front

- |   |  |   |
|---|--|---|
| 1. Turbocharger boost control solenoid valve (View with air cleaner upper case removed) | 2. Turbocharger boost control actuator | 3. PNP switch (M/T) (View from under the vehicle) |
| 4. Intake air control valve control solenoid valve                                      | 5. ASCD steering switch                | 6. RESUME/ACCELERATE switch                       |
| 7. SET/COAST switch   | 8. MAIN switch                         | 9. CANCEL switch                                  |


MBIB1289E

## Circuit Diagram

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M




\*: This relay is built into the IPDM E/R (Intelligent power distribution module engine room)



## ECM Harness Connector Terminal Layout


GBS0003J




## ECM Terminals And Reference Value PREPARATION

GBS0003K

1. ECM located in the engine room passenger side behind coolant reservoir tank.
2. Remove ECM harness connector.



3. When disconnecting ECM harness connector, loosen it with levers as far as they will go as shown in the figure.
4. Connect a break-out box (SST) and Y-cable adapter (SST) between the ECM and ECM harness connector.
  - Use extreme care not to touch 2 pins at one time.
  - Data is for comparison and may not be exact.



## ECM INSPECTION TABLE

Remarks: Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-II.







**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
1	B	ECM ground	<b>[Engine is running]</b> ● Idle speed	Approximately 0V
2	B			
3	B			

# TROUBLE DIAGNOSIS







[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
4 5	V G	Fuel injector power supply (For cylinder No. 1 and 4) Fuel injector power supply (For cylinder No. 2 and 3)	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	<p>Approximately 7.5V ★</p>  <p style="text-align: right; font-size: small;">MBIB1295E</p>
			<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>Approximately 8.0V ★</p>  <p style="text-align: right; font-size: small;">MBIB1296E</p>
6	BR	Turbocharger boost control solenoid valve	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	<p>Approximately 6.3V ★</p>  <p style="text-align: right; font-size: small;">MBIB0889E</p>
			<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>Approximately 8.6V ★</p>  <p style="text-align: right; font-size: small;">MBIB0890E</p>
10	G	Fuel pump	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	<p>Approximately 5.8V ★</p>  <p style="text-align: right; font-size: small;">MBIB0885E</p>
			<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>Approximately 5.5V ★</p>  <p style="text-align: right; font-size: small;">MBIB0886E</p>
15	GR	Intake air control valve control solenoid valve	<p><b>[Engine is running]</b></p>	<p>BATTERY VOLTAGE (11 - 14V)</p>
			<p><b>[Ignition switch OFF]</b></p> <ul style="list-style-type: none"> <li>● For a few seconds after turning ignition switch OFF</li> </ul>	<p>Approximately 0.3V</p>



# TROUBLE DIAGNOSIS





[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
21 22 23 24	G P W W	Fuel injector No. 2 Fuel injector No. 2 Fuel injector No. 3 Fuel injector No. 3	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <b>NOTE:</b> The pulse cycle changes depending on rpm at idle	Approximately 7.5V ★  <p style="text-align: right; font-size: small;">MBIB1297E</p>
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	Approximately 8.0V ★  <p style="text-align: right; font-size: small;">MBIB1298E</p>
25 26 27 28	Y O GR V	EGR volume control valve	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	0.1 - 14V (Voltage signals of each ECM terminals differ according to the control position of EGR volume control valve.)
29	B	Fuel pump	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	0.5 - 1.0V ★  <p style="text-align: right; font-size: small;">MBIB0887E</p>
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	0.5 - 1.0V ★  <p style="text-align: right; font-size: small;">MBIB0888E</p>
37	G	Glow relay	Refer to <a href="#">EC-1283, "GLOW CONTROL SYSTEM"</a> .	
40 41 42 43	W GR W B	Fuel injector No. 4 Fuel injector No. 4 Fuel injector No. 1 Fuel injector No. 1	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <b>NOTE:</b> The pulse cycle changes depending on rpm at idle	Approximately 7.5V ★  <p style="text-align: right; font-size: small;">MBIB1297E</p>
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	Approximately 8.0V ★  <p style="text-align: right; font-size: small;">MBIB1298E</p>

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# TROUBLE DIAGNOSIS

[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
44	W	Crankshaft position sensor power supply	[Ignition switch ON]	Approximately 5.3V
45	W	Camshaft position sensor power supply	[Ignition switch ON]	Approximately 5.3V
46	R	Crankshaft position sensor	<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	<p>Approximately 3.7V ★</p>  <p style="text-align: right; font-size: small;">MBIB0879E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>Approximately 3.7V ★</p>  <p style="text-align: right; font-size: small;">MBIB0880E</p>
47	R	Camshaft position sensor	<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	<p>Approximately 4.9V ★</p>  <p style="text-align: right; font-size: small;">MBIB0877E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>Approximately 4.9V ★</p>  <p style="text-align: right; font-size: small;">MBIB0878E</p>
48 49	L B	Fuel rail pressure sensor	<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	1.7 - 2.0V
			<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	2.0 - 2.3V
50	Y	Fuel pump temperature sensor	<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> </ul>	<p>Approximately 0.3 - 5.3V</p> <p>Output voltage varies with fuel pump temperature</p>
51	SB	Engine coolant temperature sensor	<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> </ul>	<p>Approximately 0.3 - 5.3V</p> <p>Output voltage varies with engine coolant temperature</p>

# TROUBLE DIAGNOSIS

[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)	A
52	BR	Turbocharger boost sensor	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	2.1 - 2.4V	EC
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	2.3 - 2.6V	C
53	W	Refrigerant pressure sensor	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Both A/C switch and blower switch: ON (Compressor operates)</li> </ul>	1.0 - 4.0V	D
54	G	Mass air flow sensor	<b>[Ignition switch: ON]</b>	Approximately 0.7V	E
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	1.6 - 2.0V	F
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine is revving from idle to about 4,000 rpm.</li> </ul>	1.6 - 2.0V to Approximately 4.3V (Check for liner voltage rise in response to engine being increased to about 4,000 rpm)	G
55	W	Intake air temperature sensor	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> </ul>	Approximately 0.3 - 5.2V Output voltage varies with intake air temperature	H
63	R	Fuel rail pressure sensor power supply	<b>[Ignition switch ON]</b>	Approximately 5.3V	I
64	V	Sensor power supply (Turbocharger boost sensor/ Refrigerant pressure sensor)	<b>[Ignition switch ON]</b>	Approximately 5.3V	J
65	B	Crankshaft position sensor ground	<b>[Ignition switch ON]</b>	Approximately 0.3V	K
66	B	Camshaft position sensor ground	<b>[Ignition switch ON]</b>	Approximately 0.3V	L
67	—	Sensor ground (Sensor shield circuit)	<b>[Ignition switch ON]</b>	Approximately 0.3V	M
68	W	Fuel rail pressure sensor ground	<b>[Ignition switch ON]</b>	Approximately 0.3V	
69	B	Fuel pump temperature sensor ground	<b>[Ignition switch ON]</b>	Approximately 0.3V	
70	LG	Engine coolant temperature sensor ground	<b>[Ignition switch ON]</b>	Approximately 0.3V	
71	L	Turbocharger boost sensor ground	<b>[Ignition switch ON]</b>	Approximately 0.3V	
72	BR	Refrigerant pressure sensor ground	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 0.3V	
73	B	Mass air flow sensor ground	<b>[Ignition switch ON]</b>	Approximately 0.3V	
74	R	Intake air temperature sensor ground	<b>[Ignition switch ON]</b>	Approximately 0.3V	
82	W	Accelerator pedal position sensor 1 power supply	<b>[Ignition switch ON]</b>	Approximately 5.3V	

# TROUBLE DIAGNOSIS

[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
83	R	Accelerator pedal position sensor 1	<b>[Ignition switch ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Accelerator pedal: Fully released</li> </ul>	0.95 - 1.17V
			<b>[Ignition switch ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Accelerator pedal: Fully depressed</li> </ul>	More than 4.6V
84	B	Accelerator pedal position sensor 1 ground	<b>[Ignition switch ON]</b>	Approximately 0.3V
85	—	Sensor ground (Accelerator pedal position sensor shield circuit)	<b>[Ignition switch ON]</b>	Approximately 0.3V
87	P	CAN communication line	<b>[Ignition switch ON]</b>	Approximately 2.0 - 2.6V Output voltage varies with the communication status.
89	SB	Data link connector	<b>[Ignition switch ON]</b> <ul style="list-style-type: none"> <li>● CONSULT-II: Disconnected</li> </ul>	Approximately 0V - Battery voltage (11 - 14V)
90	W	Accelerator pedal position sensor 2 power supply	<b>[Ignition switch ON]</b>	Approximately 5.3V
91	R	Accelerator pedal position sensor 2	<b>[Ignition switch ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Accelerator pedal: Fully released</li> </ul>	0.58 - 0.78V
			<b>[Ignition switch ON]</b> <ul style="list-style-type: none"> <li>● Engine: Stopped</li> <li>● Accelerator pedal: Fully depressed</li> </ul>	More than 2.3V
92	B	Accelerator pedal position sensor 2 ground	<b>[Ignition switch ON]</b>	Approximately 0.3V
95	L	CAN communication line	<b>[Ignition switch ON]</b>	Approximately 2.6 - 3.2V Output voltage varies with the communication status.
99	V	Start signal	<b>[Ignition switch ON]</b>	Approximately 0.3V
			<b>[Ignition switch START]</b>	BATTERY VOLTAGE (11 - 14V)
100	V	Stop lamp switch	<b>[Ignition switch OFF]</b> <ul style="list-style-type: none"> <li>● Brake pedal: Fully released</li> </ul>	Approximately 0V
			<b>[Ignition switch OFF]</b> <ul style="list-style-type: none"> <li>● Brake pedal: Slightly depressed</li> </ul>	BATTERY VOLTAGE (11 - 14V)
101	W	ASCD brake switch	<b>[Ignition switch ON]</b> <ul style="list-style-type: none"> <li>● Brake pedal: Fully released (A/T)</li> <li>● Clutch pedal and brake pedal: Fully released (M/T)</li> </ul>	BATTERY VOLTAGE (11 - 14V)
			<b>[Ignition switch ON]</b> <ul style="list-style-type: none"> <li>● Brake pedal: Slightly depressed (A/T)</li> <li>● Clutch pedal and/or brake pedal: Slightly depressed (M/T)</li> </ul>	Approximately 0V

# TROUBLE DIAGNOSIS

[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
102	SB	ASCD steering switch	<b>[Ignition switch ON]</b> ● ASCD steering switch: OFF	Approximately 4.3V
			<b>[Ignition switch ON]</b> ● ON/OFF switch: Pressed	Approximately 0.3V
			<b>[Ignition switch ON]</b> ● CANCEL switch: Pressed	Approximately 1.3V
			<b>[Ignition switch ON]</b> ● RESUME/ACCELERATE switch: Pressed	Approximately 3.3V
			<b>[Ignition switch ON]</b> ● SET/COAST switch: Pressed	Approximately 2.3V
103	B	ASCD steering switch ground	<b>[Ignition switch ON]</b>	Approximately 0.3V
105	BR	ECM relay (self shut-off)	<b>[Ignition switch ON]</b> <b>[Ignition switch OFF]</b> ● For a few seconds after turning ignition switch OFF	Approximately 1.0V
			<b>[Ignition switch OFF]</b> ● More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14V)
107 108	R R	Ignition switch	<b>[Ignition switch ON]</b>	BATTERY VOLTAGE (11 - 14V)
110	G (A/T) O (M/T)	Park/Neutral position switch	<b>[Ignition switch ON]</b> ● Shift lever: P or N (A/T), Neutral (M/T)	Approximately 0V
			<b>[Ignition switch ON]</b> ● Except the above position	BATTERY VOLTAGE (11 - 14V)
113	BR	ECM relay (self shut-off)	<b>[Ignition switch ON]</b> <b>[Ignition switch OFF]</b> ● For a few seconds after turning ignition switch OFF	Approximately 1.0V
			<b>[Ignition switch OFF]</b> ● More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14V)
114	B	ECM ground	<b>[Engine is running]</b> ● Idle speed	Approximately 0V
119 120	R G	Power supply for ECM	<b>[Ignition switch ON]</b>	BATTERY VOLTAGE (11 - 14V)
121	V	Power supply for ECM (Back-up)	<b>[Ignition switch OFF]</b>	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## CONSULT-II Function (ENGINE) FUNCTION

GBS0003L

Diagnostic test mode	Function
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT-II unit.
Self-diagnostic results	Self-diagnostic results such as DTC and freeze frame data can be read and erased quickly.*
Data monitor	Input/Output data in the ECM can be read.
CAN diagnostic support monitor	The results of transmit/receive diagnosis of CAN communication can be read.

# TROUBLE DIAGNOSIS

[YD]

Diagnostic test mode	Function
Active test	Diagnostic Test Mode in which CONSULT-II drives some actuators apart from the ECMs and also shifts some parameters in a specified range.
Function test	This mode is used to inform customers when their vehicle condition requires periodic maintenance.
ECM part number	ECM part number can be read.

\*: The following emission-related diagnostic information is cleared when the ECM memory is erased.

- Diagnostic trouble codes
- Freeze frame data

## ENGINE CONTROL COMPONENT PARTS/CONTROL SYSTEMS APPLICATION

Item		DIAGNOSTIC TEST MODE					
		SELF-DIAG RESULTS		DATA MON- ITOR	ACTIVE TEST		
		DTC	FREEZE FRAME DATA				
ENGINE CONTROL COMPONENT PARTS	INPUT	Crankshaft position sensor	×	×	×		
		Camshaft position sensor	×				
		Engine coolant temperature sensor	×	×	×		×
		Vehicle speed signal	×	×	×		
		Fuel pump temperature sensor	×		×		
		Accelerator pedal position sensor 1	×		×		
		Accelerator pedal position sensor 2	×		×		
		Fuel rail pressure sensor	×		×		
		Mass air flow sensor	×		×		
		Intake air temperature sensor	×				
		Turbocharger boost sensor	×	×	×		
		Refrigerant pressure sensor			×		
		Battery voltage	×		×		
		Park/neutral position (PNP) switch			×		
		Stop lamp switch	×		×		
		Barometric pressure sensor (built-into ECM)	×		×		
		ASCD steering switch	×		×		
		ASCD brake switch	×		×		
	ASCD clutch switch	×		×			
	OUTPUT	Fuel pump	×		×		×
Fuel injector		×		×		×	
Glow relay				×		×	
Cooling fan relay		×		×		×	
Turbocharger boost control solenoid valve		×					
Intake air control valve control solenoid valve							
EGR volume control valve				×		×	


X: Applicable

## INSPECTION PROCEDURE


**CAUTION:**

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. Turn ignition switch OFF.
2. Connect CONSULT-II and CONSULT-II CONVERTER to data link connector, which is located under LH dash panel near the hood opener handle.
3. Turn ignition switch ON.




4. Touch "START (NISSAN BASED VHCL)".



5. Touch "ENGINE".  
If "ENGINE" is not indicated, go to [GI-47, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



6. Perform each diagnostic test mode according to each service procedure.  
**For further information, see the CONSULT-II Operation Manual.**



A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

## WORK SUPPORT MODE

### Work Item

WORK ITEM	DESCRIPTION	USAGE
ENTER INJCTR CALIB DATA	<ul style="list-style-type: none"> <li>Injector adjustment value is written onto ECM memory.</li> </ul>	When performing Injector Adjustment Value Registration.
CONFIG CLR	<ul style="list-style-type: none"> <li>ASCD application status stored in ECM is initialized.</li> </ul> <p><b>NOTE:</b> After the status is initialized, ECM recognizes ASCD application status when the following condition is met.</p> <ul style="list-style-type: none"> <li>For ASCD: ASCD MAIN switch is pressed.</li> </ul>	When initializing ASCD application status stored in ECM.
INJ ADJ VAL CLR	<ul style="list-style-type: none"> <li>Injector adjustment value stored in ECM is initialized.</li> </ul>	Before changing injector adjustment value stored in ECM, it is recommended to perform this work item.

## SELF-DIAGNOSTIC MODE

### Self Diagnostic Item

Regarding items detected in "SELF-DIAG RESULTS" mode, refer to [EC-996, "INDEX FOR DTC"](#) .

### Freeze Frame Data

Freeze frame data item	Description
DIAG TROUBLE CODE [PXXXX]	<ul style="list-style-type: none"> <li>The engine control component part/control system has a trouble code, it is displayed as "PXXXX". (Refer to <a href="#">EC-996, "INDEX FOR DTC"</a> .)</li> </ul>
CAL/LD VALUE [%]	<ul style="list-style-type: none"> <li>The calculated load value at the moment a malfunction is detected is displayed.</li> </ul>
COOLANT TEMP [°C] or [°F]	<ul style="list-style-type: none"> <li>The engine coolant temperature at the moment a malfunction is detected is displayed.</li> </ul>
ENGINE SPEED [rpm]	<ul style="list-style-type: none"> <li>The engine speed at the moment a malfunction is detected is displayed.</li> </ul>
VEHICL SPEED [km/h] or [mph]	<ul style="list-style-type: none"> <li>The vehicle speed at the moment a malfunction is detected is displayed.</li> </ul>
INT MANI PRES [kPa]	<ul style="list-style-type: none"> <li>The intake manifold pressure at the moment a malfunction is detected is displayed.</li> </ul>

## DATA MONITOR MODE

MONITOR ITEM	ECM INPUT SIGNAL	MAIN SIGNALS	CONDITION	SPECIFICATION
CKPS-RPM (TDC) [rpm]	×	×	<ul style="list-style-type: none"> <li>The engine speed computed from the crankshaft position sensor signal is displayed.</li> </ul>	
COOLAN TEMP/S [°C] or [°F]	×	×	<ul style="list-style-type: none"> <li>The engine coolant temperature (determined by the signal voltage of the engine coolant temperature sensor) is displayed.</li> </ul>	When the engine coolant temperature circuit is open or short, ECM enters fail-safe mode. The engine coolant temperature determined by the ECM is displayed.
VHCL SPEED SE [km/h] or [mph]	×	×	<ul style="list-style-type: none"> <li>The vehicle speed computed from the vehicle speed signal is displayed.</li> </ul>	
FUEL TEMP SEN [°C] or [°F]	×	×	<ul style="list-style-type: none"> <li>The fuel temperature (determined by the signal voltage of the fuel pump temperature sensor) is displayed.</li> </ul>	
ACCEL POS SEN [V]	×	×	<ul style="list-style-type: none"> <li>The accelerator pedal position sensor 1 signal voltage is displayed.</li> </ul>	This signal is converted by ECM internally. Thus, it differs from ECM terminals voltage.
ACCEL SEN 2 [V]	×	×	<ul style="list-style-type: none"> <li>The accelerator pedal position sensor 2 signal voltage is displayed.</li> </ul>	This signal is converted by ECM internally. Thus, it differs from ECM terminals voltage.



# TROUBLE DIAGNOSIS

[YD]

MONITOR ITEM	ECM INPUT SIGNAL	MAIN SIGNALS	CONDITION	SPECIFICATION
ACT CR PRESS [MPa]	×	×	<ul style="list-style-type: none"> <li>The Fuel rail pressure (determined by the signal voltage of the fuel rail pressure sensor) is displayed.</li> </ul>	
BATTERY VOLT [V]	×	×	<ul style="list-style-type: none"> <li>The power supply voltage of ECM is displayed.</li> </ul>	
P/N POSI SW [ON/OFF]	×	×	<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from the park/neutral position switch signal.</li> </ul>	
START SIGNAL [ON/OFF]	×	×	<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from the starter signal.</li> </ul>	
AIR COND SIG [ON/OFF]	×	×	<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition of the air conditioner switch as determined by the air conditioner signal.</li> </ul>	
BRAKE SW [ON/OFF]	×	×	<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from the stop lamp switch signal.</li> </ul>	
BRAKE SW2 [ON/OFF]	×	×	<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from the ASCD brake switch and ASCD clutch switch signal.</li> </ul>	
IGN SW [ON/OFF]	×	×	<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from ignition switch signal.</li> </ul>	
MAS AIR/FL SE [V]	×	×	<ul style="list-style-type: none"> <li>The signal voltage of the mass air flow sensor is displayed.</li> </ul>	This signal is converted by ECM internally. Thus, it differs from ECM terminals voltage.
MAIN INJ WID [msec]		×	<ul style="list-style-type: none"> <li>Indicates the actual fuel injection pulse width compensated by ECM according to the input signals.</li> </ul>	
PUMP CURRENT [mA]		×	<ul style="list-style-type: none"> <li>Indicates the fuel pump power supply current from the ECM.</li> </ul>	
GLOW RLY [ON/OFF]		×	<ul style="list-style-type: none"> <li>The glow relay control condition (determined by ECM according to the input signal) is displayed.</li> </ul>	
COOLING FAN [LOW/HI/OFF]		×	<ul style="list-style-type: none"> <li>Indicates the control condition of the cooling fans (determined by ECM according to the input signal). LOW ... Operates at low speed HI ... Operates at high speed OFF ... Stopped</li> </ul>	
EGR VOL CON/V [step]		×	<ul style="list-style-type: none"> <li>Indicates the EGR volume control value computed by the ECM according to the input signals.</li> <li>The opening becomes larger as the value increases.</li> </ul>	
INT/A VOLUME [mg/l]			<ul style="list-style-type: none"> <li>The intake air volume computed from the mass air flow sensor signal is displayed.</li> </ul>	
BARO SEN [kPa]	×	×	<ul style="list-style-type: none"> <li>The barometric pressure (determined by the signal voltage from the absolute pressure sensor built into the ECM) is displayed.</li> </ul>	
INT/M PRES SE [kPa]			<ul style="list-style-type: none"> <li>Turbocharger boost (determined by the signal voltage from the turbocharger boost sensor) is displayed.</li> </ul>	

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# TROUBLE DIAGNOSIS

[YD]

MONITOR ITEM	ECM INPUT SIGNAL	MAIN SIGNALS	CONDITION	SPECIFICATION
CYL COUNT [1/2/3/4]			<ul style="list-style-type: none"> <li>● The cylinder being injected is displayed.</li> <li>1 ... Cylinder No.1 is injected.</li> <li>2 ... Cylinder No.2 is injected.</li> <li>3 ... Cylinder No.3 is injected.</li> <li>4 ... Cylinder No.4 is injected.</li> </ul>	
SET SW [ON/OFF]	×		<ul style="list-style-type: none"> <li>● Indicates [ON/OFF] condition from SET/COAST switch signal.</li> </ul>	
RESUME/ACC SW [ON/OFF]	×		<ul style="list-style-type: none"> <li>● Indicates [ON/OFF] condition from RESUME/ACCEL switch signal.</li> </ul>	
CANCEL SW [ON/OFF]	×		<ul style="list-style-type: none"> <li>● Indicates [ON/OFF] condition from CANCEL switch signal.</li> </ul>	
MAIN SW [ON/OFF]	×		<ul style="list-style-type: none"> <li>● Indicates [ON/OFF] condition from MAIN switch signal.</li> </ul>	
ASCD APPLY [YES/NO]			<ul style="list-style-type: none"> <li>● Displaying ASCD application status stored in ECM.</li> </ul>	
VDC APPLY [YES/NO]			<ul style="list-style-type: none"> <li>● Displaying VDC application status stored in ECM.</li> </ul>	<ul style="list-style-type: none"> <li>● Always "NO" is displayed.</li> </ul>
AC PRESS SEN [V]			<ul style="list-style-type: none"> <li>● The signal voltage from the refrigerant pressure sensor is displayed.</li> </ul>	
Voltage [V]			Voltage, frequency, duty cycle or pulse width measured by the probe.	Only "#" is displayed if item is unable to be measured. Figures with "#s" are temporary ones. They are the same figures as an actual piece of data which was just previously measured. [Hz] or [%]
Frequency [msec], [Hz] or [%]				
DUTY-HI				
DUTY-LOW				
PLS WIDTH-HI				
PLS WIDTH-LOW				

**NOTE:**

Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

**ACTIVE TEST MODE**

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
POWER BAL-ANCE	<ul style="list-style-type: none"> <li>● Engine: After warming up, idle the engine.</li> <li>● A/C switch: OFF</li> <li>● Shift lever: P or N (A/T), Neutral (M/T)</li> <li>● Cut off each injector signal one at a time using CONSULT-II</li> </ul>	Engine runs rough or dies.	<ul style="list-style-type: none"> <li>● Harness and connectors</li> <li>● Compression</li> <li>● Fuel injector</li> </ul>
COOLING FAN *	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> <li>● Operate the cooling fan at LOW, HI speed and turn OFF using CONSULT-II.</li> </ul>	Cooling fan moves at LOW, HI speed and stops.	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Cooling fan motor</li> <li>● Cooling fan relay</li> </ul>
ENG COOLANT TEMP	<ul style="list-style-type: none"> <li>● Engine: Return to the original trouble condition</li> <li>● Change the engine coolant temperature using CONSULT-II.</li> </ul>	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> <li>● Harness and connectors</li> <li>● Engine coolant temperature sensor</li> <li>● Fuel injector</li> </ul>

# TROUBLE DIAGNOSIS

[YD]

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
GLOW RLY	<ul style="list-style-type: none"> <li>Ignition switch: ON (Engine stopped)</li> <li>Turn the glow relay ON and OFF using CONSULT-II and listen to operating sound.</li> </ul>	Glow relay makes the operating sound.	<ul style="list-style-type: none"> <li>Harness and connector</li> <li>Glow relay</li> </ul>
EGR VOL CONT/V	<ul style="list-style-type: none"> <li>Ignition switch: ON</li> <li>Change EGR volume control valve opening step using CONSULT-II.</li> </ul>	EGR volume control valve makes an operating sound.	<ul style="list-style-type: none"> <li>Harness and connector</li> <li>EGR volume control valve</li> </ul>
PRES REGULATOR	<ul style="list-style-type: none"> <li>Ignition switch: ON</li> <li>Change fuel rail pressure using CONSULT-II</li> </ul>	Fuel leaks.	<ul style="list-style-type: none"> <li>Fuel line</li> <li>Fuel pressure relief valve</li> </ul>
PUMP LEANT CLEAR	<ul style="list-style-type: none"> <li>This mode is used for performing Fuel Pump Learning Value Clearing. Refer to <a href="#">EC-1013. "Fuel Pump Learning Value Clearing"</a>.</li> </ul>		

\*: Leaving cooling fan OFF with CONSULT-II while engine is running may cause the engine to overheat.

## REAL TIME DIAGNOSIS IN DATA MONITOR MODE

CONSULT-II has two kinds of triggers and they can be selected by touching "SETTING" in "DATA MONITOR" mode.


### 1. "AUTO TRIG" (Automatic trigger):

- The malfunction will be identified on the CONSULT-II screen in real time.

In other words, DTC will be displayed if the malfunction is detected by ECM.

At the moment a malfunction is detected by ECM, "MONITOR" in "DATA MONITOR" screen is changed to "Recording Data ... xx%" as shown in the figure, and the data after the malfunction detection is recorded. Then when the percentage reached 100%, "REAL-TIME DIAG" screen is displayed. If "STOP" is touched on the screen during "Recording Data ... xx%", "REAL-TIME DIAG" screen is also displayed.

The recording time after the malfunction detection and the recording speed can be changed by "TRIGGER POINT" and "Recording Speed". Refer to CONSULT-II OPERATION MANUAL.



### 2. "MANU TRIG" (Manual trigger):

- DTC will not be displayed automatically on CONSULT-II screen even though a malfunction is detected by ECM.

DATA MONITOR can be performed continuously even though a malfunction is detected.

Use these triggers as follows:


#### 1. "AUTO TRIG"

- While trying to detect the DTC by performing the DTC Confirmation Procedure, be sure to select to "DATA MONITOR (AUTO TRIG)" mode. You can confirm the malfunction at the moment it is detected.

- While narrowing down the possible causes, CONSULT-II should be set in "DATA MONITOR (AUTO TRIG)" mode, especially in case the incident is intermittent.

When you are inspecting the circuit by gently shaking (or twisting) the suspicious connectors, components and harness in the DTC Confirmation Procedure, the moment a malfunction is found the DTC will be displayed. Refer to [GI-24. "How to Perform Efficient Diagnosis for an Electrical Incident"](#), "INCIDENT SIMULATION TESTS".


#### 2. "MANU TRIG"



# TROUBLE DIAGNOSIS

[YD]

- If the malfunction is displayed as soon as "DATA MONITOR" is selected, reset CONSULT-II to "MANU TRIG". By selecting "MANU TRIG" you can monitor and store the data. The data can be utilized for further diagnosis, such as a comparison with the value for the normal operating condition.



## FUNCTION TEST

This mode is used to inform customers of their vehicle condition of periodic maintenance.

## CONSULT-II Reference Value in Data Monitor Mode

GBS0003M

Remarks:

- Specification data are reference values.
- Specification data are output/input values which are detected or supplied by the ECM at the connector.
- \* Specification data may not be directly related to their components signals/values/operations.

MONITOR ITEM	CONDITION		SPECIFICATION
CKPS-RPM (TDC)	● Run engine and compare CONSULT-II value with the tachometer indication.		Almost the same speed as the tachometer indication
COOLAN TEMP/S	● Engine: After warming up		More than 70°C (158°F)
VHCL SPEED SE	● Turn drive wheels and compare CONSULT-II value with the speedometer indication		Almost the same speed as the speedometer indication
FUEL TEMP SEN	● Engine: After warming up		More than 40°C (104°F)
ACCEL POS SEN*	● Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	0.65 - 0.87V
		Accelerator pedal: Fully depressed	More than 4.3V
ACCEL SEN 2*	● Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	0.28 - 0.48V
		Accelerator pedal: Fully depressed	More than 2.0V
ACT CR PRESS	● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: P or N (A/T), Neutral (M/T) ● No load	Idle	25 - 35 MPa
		2,000 rpm	40 - 50 MPa
BATTERY VOLT	● Ignition switch: ON (Engine stopped)		11 - 14V

# TROUBLE DIAGNOSIS

[YD]

MONITOR ITEM	CONDITION	SPECIFICATION	
P/N POSI SW	● Ignition switch: ON	Shift lever: P or N (A/T), Neutral (M/T)	ON
		Except above	OFF
START SIGNAL	● Ignition switch: ON → START → ON	OFF → ON → OFF	
AIR COND SIG	● Engine: After warming up, idle the engine	Air conditioner switch: OFF	OFF
		Air conditioner switch: ON (Compressor operates.)	ON
BRAKE SW	● Ignition switch: ON	Brake pedal: Fully released	OFF
		Brake pedal: Slightly depressed	ON
BRAKE SW2	● Ignition switch: ON	● Brake pedal: Fully released (A/T) ● Clutch pedal and brake pedal: Fully released (M/T)	OFF
		● Brake pedal: Slightly depressed (A/T) ● Clutch pedal and/or brake pedal: Slightly depressed (M/T)	ON
IGN SW	● Ignition switch: ON → OFF	ON → OFF	
MAS AIR/FL SE*	● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: P or N (A/T), Neutral (M/T) ● No load	Ignition switch: ON (Engine stopped)	Approximately 0.4V
		Idle	1.3 - 1.7V
		Engine is revving from idle to about 4,000 rpm.	1.3 - 1.7V to Approximately 4.0V (Check for liner voltage rise in response to engine being increased to about 4,000 rpm)
MAIN INJ WID	● Engine: After warming up ● Shift lever: P or N (A/T), Neutral (M/T) ● Idle speed	No load	0.50 - 0.70 msec
		Blower fan switch: ON Rear window defogger switch: ON	0.50 - 0.80 msec
PUMP CURRENT	● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: P or N (A/T), Neutral (M/T) ● No load	Idle	1,600 - 2,000 mA
		2,000 rpm	1,500 - 1,900 mA
GLOW RLY	Refer to <a href="#">EC-1283, "GLOW CONTROL SYSTEM"</a> .		
COOLING FAN	● Engine: After warming up, idle the engine ● Air conditioner switch: OFF	Engine coolant temperature: 97°C (207°F) or less	OFF
		Engine coolant temperature: Between 98°C (208°F) and 104°C (219°F)	LOW
		Engine coolant temperature: 105°C (221°F) or more	HI
EGR VOL CON/V	● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: P or N (A/T), Neutral (M/T) ● No load	After 1 minute at idle	More than 10 steps
		Revving engine from idle to 3,200 rpm	0 step
INT/A VOLUME	● Engine: After warming up, idle the engine	150 - 450 mg/	

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# TROUBLE DIAGNOSIS

[YD]

MONITOR ITEM	CONDITION	SPECIFICATION						
BARO SEN	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> </ul>	Altitude Approx. 0m: Approx. 100.62 kPa (1.0062 bar, 1.026 kg/cm <sup>2</sup> , 14.59 psi) Approx. 1,000 m: Approx. 88.95 kPa (0.8895 bar, 0.907 kg/cm <sup>2</sup> , 12.90 psi) Approx. 1,500 m: Approx. 83.16 kPa (0.8316 bar, 0.848 kg/cm <sup>2</sup> , 12.06 psi) Approx. 2,000 m: Approx. 78.36 kPa (0.7836 bar, 0.799 kg/cm <sup>2</sup> , 11.36 psi)						
INT/M PRES SE [kPa]	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Air conditioner switch: OFF</li> <li>● Shift lever: P or N (A/T), Neutral (M/T)</li> <li>● No load</li> </ul>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center;">Idle</td> <td style="text-align: center;">Approx. 100.00 kPa</td> </tr> <tr> <td style="text-align: center;">3,600 rpm</td> <td style="text-align: center;">Approx. 140.00 kPa</td> </tr> <tr> <td style="text-align: center;">4,000 rpm</td> <td style="text-align: center;">Approx. 135.00 kPa</td> </tr> </table>	Idle	Approx. 100.00 kPa	3,600 rpm	Approx. 140.00 kPa	4,000 rpm	Approx. 135.00 kPa
Idle	Approx. 100.00 kPa							
3,600 rpm	Approx. 140.00 kPa							
4,000 rpm	Approx. 135.00 kPa							
CYL COUNT	<ul style="list-style-type: none"> <li>● Engine is running</li> </ul>	1 → 3 → 4 → 2						
SET SW	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> </ul>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center;">SET/COAST switch: Pressed</td> <td style="text-align: center;">ON</td> </tr> <tr> <td style="text-align: center;">SET/COAST switch: Released</td> <td style="text-align: center;">OFF</td> </tr> </table>	SET/COAST switch: Pressed	ON	SET/COAST switch: Released	OFF		
SET/COAST switch: Pressed	ON							
SET/COAST switch: Released	OFF							
RESUME/ACC SW	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> </ul>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center;">RESUME/ACCELERATE switch: Pressed</td> <td style="text-align: center;">ON</td> </tr> <tr> <td style="text-align: center;">RESUME/ACCELERATE switch: Released</td> <td style="text-align: center;">OFF</td> </tr> </table>	RESUME/ACCELERATE switch: Pressed	ON	RESUME/ACCELERATE switch: Released	OFF		
RESUME/ACCELERATE switch: Pressed	ON							
RESUME/ACCELERATE switch: Released	OFF							
CANCEL SW	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> </ul>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center;">CANCEL switch: Pressed</td> <td style="text-align: center;">ON</td> </tr> <tr> <td style="text-align: center;">CANCEL switch: Released</td> <td style="text-align: center;">OFF</td> </tr> </table>	CANCEL switch: Pressed	ON	CANCEL switch: Released	OFF		
CANCEL switch: Pressed	ON							
CANCEL switch: Released	OFF							
MAIN SW	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> </ul>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center;">MAIN switch: Pressed</td> <td style="text-align: center;">ON</td> </tr> <tr> <td style="text-align: center;">MAIN switch: Released</td> <td style="text-align: center;">OFF</td> </tr> </table>	MAIN switch: Pressed	ON	MAIN switch: Released	OFF		
MAIN switch: Pressed	ON							
MAIN switch: Released	OFF							
ASCD APPLY	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> </ul>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center;">Models with ASCD</td> <td style="text-align: center;">YES</td> </tr> <tr> <td style="text-align: center;">Models without ASCD</td> <td style="text-align: center;">NO</td> </tr> </table>	Models with ASCD	YES	Models without ASCD	NO		
Models with ASCD	YES							
Models without ASCD	NO							
VDC APPLY	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> </ul>	NO						
AC PRESS SEN	<ul style="list-style-type: none"> <li>● Engine: Idle</li> <li>● Both A/C switch and blower fan switch: ON (Compressor operates)</li> </ul>	1.0 - 4.0V						

**NOTE:**

Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.


\*: This signal is converted by ECM internally. Thus, it differs from ECM terminal voltage.

## Major Sensor Reference Graph in Data Monitor Mode

The following are the major sensor reference graphs in "DATA MONITOR" mode.

### ACCEL POS SEN, "CKPS-RPM (TDC)", "MAS AIR/FL SE"

Below is the data for "ACCEL POS SEN", "CKPS-RPM (TDC)" and "MAS AIR/FL SE" when revving engine quickly up to 3,000 rpm under no load after warming up engine to the normal operating temperature. Each value is for reference, the exact value may vary.



A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT

[YD]

## TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT

PFP:00006

### Description

GBS00030

Intermittent incidents may occur. In many cases, the incident resolves itself (the part or circuit function returns to normal without intervention). It is important to realize that the symptoms described in the customer's complaint often do not recur on DTC visits. Realize also that the most frequent cause of intermittent incidents occurrences is poor electrical connections. Because of this, the conditions under which the incident occurred may not be clear. Therefore, circuit checks made as part of the standard diagnostic procedure may not indicate the specific malfunctioning area.

### COMMON INTERMITTENT INCIDENT REPORT SITUATIONS

STEP in Work Flow	Situation
II	The CONSULT-II is used. The SELF-DIAG RESULTS screen shows time data other than "0".
III	The symptom described by the customer does not recur.
IV	DTC does not appear during the DTC Confirmation Procedure.
VI	The Diagnostic Procedure for XXXX does not indicate the malfunctioning area.

### Diagnostic Procedure

GBS0003P

#### 1. INSPECTION START

Erase DTCs. Refer to [EC-1016, "HOW TO ERASE DTC"](#) .

>> GO TO 2.

#### 2. CHECK GROUND TERMINALS

Check ground terminals for corroding or loose connection.  
Refer to [EC-1066, "Ground Inspection"](#) .

OK or NG

OK >> GO TO 3.

NG >> Repair or replace.

#### 3. SEARCH FOR ELECTRICAL INCIDENT

Perform [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#) , "INCIDENT SIMULATION TESTS".

OK or NG

OK >> **INSPECTION END**

NG >> Repair or replace.



# POWER SUPPLY AND GROUND CIRCUIT

[YD]

## POWER SUPPLY AND GROUND CIRCUIT

PFP:24110

### ECM Terminals and Reference Value

GBS0003Q

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
1 2 3	B B B	ECM ground	<b>[Engine is running]</b> ● Idle speed	Approximately 0V
105	BR	ECM relay (self shut-off)	<b>[Ignition switch ON]</b> <b>[Ignition switch OFF]</b> ● For a few seconds after turning ignition switch OFF	Approximately 1.0V
			<b>[Ignition switch OFF]</b> ● More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14V)
107 108	R R	Ignition switch	<b>[Ignition switch ON]</b>	BATTERY VOLTAGE (11 - 14V)
113	BR	ECM relay (self shut-off)	<b>[Ignition switch ON]</b> <b>[Ignition switch OFF]</b> ● For a few seconds after turning ignition switch OFF	Approximately 1.0V
			<b>[Ignition switch OFF]</b> ● More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14V)
114	B	ECM ground	<b>[Engine is running]</b> ● Idle speed	Approximately 0V
119 120	R G	Power supply for ECM	<b>[Ignition switch ON]</b>	BATTERY VOLTAGE (11 - 14V)
121	V	Power supply for ECM (Back-up)	<b>[Ignition switch OFF]</b>	BATTERY VOLTAGE (11 - 14V)

# POWER SUPPLY AND GROUND CIRCUIT


[YD]

GBS0003R

## Wiring Diagram



### EC-MAIN-01

— : DETECTABLE LINE FOR DTC  
 — : NON-DETECTABLE LINE FOR DTC




REFER TO THE FOLLOWING.

- (M88) - FUSE BLOCK-JUNCTION BOX (J/B)
- (M91) - SUPER MULTIPLE JUNCTION (SMJ)



(F1) B



(E20) B



MBWA1034E

## Diagnostic Procedure

### 1. INSPECTION START

Start engine.

**Is engine running?**

Yes or No

Yes >> GO TO 7.

No >> GO TO 2.

### 2. CHECK ECM POWER SUPPLY CIRCUIT-I


1. Turn ignition switch OFF and then ON.
2. Check voltage between ECM terminals 107, 108 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

OK >> GO TO 4.

NG >> GO TO 3.



### 3. DETECT MALFUNCTIONING PART


Check the following.

- Harness connectors M91, E101
- Fuse block (J/B) connector M88
- 10A fuse
- Harness for open or short between ECM and fuse

>> Repair harness or connectors.

#### 4. CHECK GROUND CONNECTIONS-I

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body.  
Refer to [EC-1066, "Ground Inspection"](#).



← : Vehicle front

- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 5.  
NG >> Repair or replace ground connections.

#### 5. CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT-I

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminals 1, 2, 3, 114 and ground.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to power.

#### OK or NG

- OK >> GO TO 7.  
NG >> GO TO 6.

#### 6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F4, E9
- Harness for open or short between ECM and ground

>> Repair open circuit or short to power in harness or connectors.

**7. CHECK ECM POWER SUPPLY CIRCUIT-II**

1. Turn ignition switch OFF.
2. Reconnect ECM harness connector.
3. Turn ignition switch ON and then OFF.
4. Check voltage between ECM terminals 119, 120 and ground with CONSULT-II or tester.


**Voltage:** After turning ignition switch OFF, battery voltage will exist for a few seconds, then drop approximately 0V.

OK or NG

OK >> GO TO 11.

NG (Battery voltage does not exist.)>>GO TO 8.

NG (Battery voltage exists for more than a few seconds.)>>GO TO 10.



**8. CHECK ECM POWER SUPPLY CIRCUIT-III**


1. Turn ignition switch OFF, and wait at least 10 seconds.
2. Check voltage between ECM terminals 105, 113 and ground with CONSULT-II or tester.

**Voltage:** Battery voltage

OK or NG

OK >> GO TO 9.

NG >> GO TO 10.



**9. CHECK ECM POWER SUPPLY CIRCUIT-IV**

1. Disconnect ECM harness connector.
2. Disconnect IPDM E/R harness connector E12.
3. Check harness continuity between ECM terminal 119 and IPDM E/R terminal 3, ECM terminal 120 and IPDM E/R terminal 4. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 12.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 10. CHECK ECM POWER SUPPLY CIRCUIT-V

1. Disconnect ECM harness connector.
2. Disconnect IPDM E/R harness connector E12.
3. Check harness continuity between ECM terminals 105, 113 and IPDM E/R terminal 7.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 11.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 11. CHECK ECM POWER SUPPLY CIRCUIT-VI


Check voltage between ECM terminal 121 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

OK >> GO TO 13.

NG >> GO TO 12.



## 12. CHECK 20A FUSE

1. Disconnect 20A fuse from IPDM E/R.
2. Check 20A fuse.


OK or NG

OK >> GO TO 13.

NG >> Replace 20A fuse.

### 13. CHECK GROUND CONNECTIONS-II

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body.  
Refer to [EC-1066, "Ground Inspection"](#).



↔ : Vehicle front

- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

**OK or NG**

- OK >> GO TO 14.  
 NG >> Repair or replace ground connections.

### 14. CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT-II

1. Check harness continuity between ECM terminals 1, 2, 3, 114 and ground.  
Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to power.

**OK or NG**

- OK >> GO TO 16.  
 NG >> GO TO 15.

### 15. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F4, E9
- Harness for open or short between ECM and ground

>> Repair open circuit or short to power in harness or connectors.

### 16. CHECK INTERMITTENT INCIDENT

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

**OK or NG**

- OK >> Replace IPDM E/R. Refer to [PG-14, "IPDM E/R \(INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM\)"](#).  
 NG >> Repair open circuit or short to power in harness or connectors.

## Ground Inspection


Ground connections are very important to the proper operation of electrical and electronic circuits. Ground connections are often exposed to moisture, dirt and other corrosive elements. The corrosion (rust) can become an unwanted resistance. This unwanted resistance can change the way a circuit works.

Electronically controlled circuits are very sensitive to proper grounding. A loose or corroded ground can drastically affect an electronically controlled circuit. A poor or corroded ground can easily affect the circuit. Even when the ground connection looks clean, there can be a thin film of rust on the surface.

When inspecting a ground connection follow these rules:

- Remove the ground bolt or screw.
- Inspect all mating surfaces for tarnish, dirt, rust, etc.
- Clean as required to assure good contact.
- Reinstall bolt or screw securely.
- Inspect for “add-on” accessories which may be interfering with the ground circuit.
- If several wires are crimped into one ground eyelet terminal, check for proper crimps. Make sure all of the wires are clean, securely fastened and providing a good ground path. If multiple wires are cased in one eyelet make sure no ground wires have excess wire insulation.

For detailed ground distribution information, refer to [PG-27, "Ground Distribution"](#) .





# DTC U1000 CAN COMMUNICATION LINE

[YD]

## DTC U1000 CAN COMMUNICATION LINE

PPF:23710

### Description

GBS0003U

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### On Board Diagnosis Logic

GBS0003V

The MIL will not light up for this self-diagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
U1000 1000	CAN communication line	<ul style="list-style-type: none"><li>● ECM can not communicate to other control unit.</li><li>● ECM can not communicate for more than the specified time.</li></ul>	<ul style="list-style-type: none"><li>● Harness or connectors (CAN communication line is open or shorted)</li></ul>

### DTC Confirmation Procedure

GBS0003W

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### ④ WITH CONSULT-II

1. Turn ignition switch ON and wait at least 3 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. If DTC is detected, go to [EC-1069, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y




# DTC U1000 CAN COMMUNICATION LINE



[YD]

## Wiring Diagram

GBS0003X

### EC-CAN-01

-  : DATA LINE
-  : DETECTABLE LINE FOR DTC
-  : NON-DETECTABLE LINE FOR DTC



MBWA1035E

---

**Diagnostic Procedure**

GBS0003Y

Go to [LAN-3, "Precautions When Using CONSULT-II"](#) .

A

**EC**

C

D

E

F

G

H

I

J

K

L

M

# DTC P0016 CKP - CMP CORRELATION

[YD]

## DTC P0016 CKP - CMP CORRELATION

PFP:10328

### On Board Diagnosis Logic

GBS0003Z

The MIL will not light up for this self-diagnosis.

#### NOTE:

If DTC P0016 is displayed with DTC P0652 or P0653, first perform the trouble diagnosis for DTC P0652 or P0653. Refer to [EC-1215, "DTC P0652, P0653 SENSOR POWER SUPPLY"](#) .

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0016 0016	Crankshaft position - camshaft position correlation	The correlation between crankshaft position sensor signal and camshaft position sensor signal is out of the normal range.	<ul style="list-style-type: none"><li>● Camshaft position sensor</li><li>● Crankshaft position sensor</li><li>● Timing chain</li><li>● Signal plate</li></ul>

### DTC Confirmation Procedure

GBS00040

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### ④ WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for at least 5 seconds.
4. If DTC is detected, go to [EC-1070, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

#### ⊗ WITHOUT CONSULT-II

1. Start engine and let it idle for at least 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-1070, "Diagnostic Procedure"](#) .

### Diagnostic Procedure

GBS00041

#### 1. CHECK CAMSHAFT POSITION SENSOR

Refer to [EC-1163, "Component Inspection"](#) .

##### OK or NG

- OK >> GO TO 2.  
NG >> Replace camshaft position sensor.

#### 2. CHECK SPROCKET

Visually check for chipping signal plate gear tooth.

##### OK or NG

- OK >> GO TO 3.  
NG >> Remove debris and clean the signal plate or replace sprocket.

---

**3. CHECK CRANKSHAFT POSITION SENSOR**

---

Refer to [EC-1152, "Component Inspection"](#) .

OK or NG

OK >> GO TO 4.

NG >> Replace crankshaft position sensor.

---

**4. CHECK GEAR TOOTH**

---

Visually check for chipping signal plate gear tooth.

OK or NG

OK >> GO TO 5.

NG >> Replace the signal plate.

---

**5. CHECK TIMING CHAIN**

---

Refer to [EM-217, "SECONDARY TIMING CHAIN"](#) and [EM-223, "PRIMARY TIMING CHAIN"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace timing chain.

---

**6. CHECK INTERMITTENT INCIDENT**

---

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

A

EC

C

D

E

F

G

H

I

J

K

L

M

## DTC P0088 FUEL SYSTEM

PFP:17520

### On Board Diagnosis Logic

GBS00042

**NOTE:**

If DTC P0088 is displayed with DTC P0652 or P0653, first perform the trouble diagnosis for DTC P0652 or P0653. Refer to [EC-1215, "DTC P0652, P0653 SENSOR POWER SUPPLY"](#) .

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0088 0088	Fuel rail pressure too high	Fuel pressure is too much higher than the specified value.	<ul style="list-style-type: none"> <li>● Fuel pump</li> <li>● Fuel injector</li> <li>● Fuel rail pressure sensor</li> </ul>

### DTC Confirmation Procedure


GBS00043

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**☑ WITH CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Keep engine speed more than 2,000 rpm for at least 20 seconds.
4. If DTC is detected, go to [EC-1072, "Diagnostic Procedure"](#) .



SEF817Y

**⊗ WITHOUT CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Keep engine speed more than 2,000 rpm for at least 20 seconds.
3. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
4. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
5. If DTC is detected, go to [EC-1072, "Diagnostic Procedure"](#) .

### Diagnostic Procedure

GBS00044

#### 1. CHECK FUEL RAIL PRESSURE SENSOR

Refer to [EC-1110, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 2.
- NG >> Replace fuel rail.

#### 2. CHECK FUEL INJECTOR

Refer to [EC-1118, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 3.
- NG >> Replace fuel injector.

---

### 3. CHECK FUEL PUMP

---

Refer to [EC-1209, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

---

### 4. REPLACE FUEL PUMP

---

1. Replace fuel pump.
2. Perform Fuel Pump Learning Value Clearing. Refer to [EC-1013, "Fuel Pump Learning Value Clearing"](#) .

>> INSPECTION END

---

### 5. CHECK INTERMITTENT INCIDENT

---

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

#### Removal and Installation FUEL INJECTOR

GBS00045

Refer to [EM-188, "INJECTION TUBE AND FUEL INJECTOR"](#) .

#### FUEL PUMP

Refer to [EM-193, "FUEL PUMP"](#) .

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

## DTC P0089 FUEL PUMP

PFP:16700

### On Board Diagnosis Logic

GBS00046

The MIL will not light up for this self-diagnosis.

**NOTE:**

If DTC P0089 is displayed with DTC P0652 or P0653, first perform the trouble diagnosis for DTC P0652 or P0653. Refer to [EC-1215, "DTC P0652, P0653 SENSOR POWER SUPPLY"](#) .

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0089 0089	Fuel pump performance	Fuel pressure is too much higher than the target value.	<ul style="list-style-type: none"> <li>● Fuel pump</li> <li>● Air mixed with fuel</li> <li>● Lack of fuel</li> <li>● Fuel rail pressure sensor</li> </ul>

### DTC Confirmation Procedure

GBS00047

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**④ WITH CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Let engine idle for at least 30 seconds.
4. If DTC is detected, go to [EC-1075, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

**⊗ WITHOUT CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Let engine idle for at least 30 seconds.
3. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
4. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
5. If DTC is detected, go to [EC-1075, "Diagnostic Procedure"](#) .



**Diagnostic Procedure****1. PERFORM FUEL PUMP LEARNING VALUE CLEARING****NOTE:**

If the DTC is detected because of air mixed with fuel (i.e.: caused by lack of fuel), it may become normal by performing following procedure.

**📞 With CONSULT-II**

1. Turn ignition switch ON.
2. Perform Fuel Pump Learning Value Clearing. Refer to [EC-1013, "Fuel Pump Learning Value Clearing"](#) .
3. Start engine and let it idle for at least 60 seconds.
4. Select "SELF-DIAG RESULT" mode with CONSULT-II.
5. Touch "ERASE".
6. Perform [EC-1074, "DTC Confirmation Procedure"](#) , again.
7. Is DTC detected again?

**🚫 Without CONSULT-II**

1. Turn ignition switch ON.
2. Perform Fuel Pump Learning Value Clearing. Refer to [EC-1013, "Fuel Pump Learning Value Clearing"](#) .
3. Start engine and let it idle for at least 60 seconds.
4. Erase the Diagnostic Test Mode II (Self-diagnostic results) memory. Refer to [EC-1016](#) .
5. Perform [EC-1074, "DTC Confirmation Procedure"](#) , again.
6. Is DTC detected again?

**Yes or No**

Yes >> GO TO 2.

No >> **INSPECTION END**

**2. CHECK FUEL RAIL PRESSURE SENSOR**

Refer to [EC-1110, "Component Inspection"](#) .

**OK or NG**

OK >> GO TO 3.

NG >> Replace fuel rail.

**3. CHECK FUEL PUMP**

Refer to [EC-1209, "Component Inspection"](#) .

**OK or NG**

OK >> GO TO 5.

NG >> GO TO 4.

**4. REPLACE FUEL PUMP**

1. Replace Fuel pump.
2. Perform Fuel Pump Learning Value Clearing. Refer to [EC-1013, "Fuel Pump Learning Value Clearing"](#) .

>> **INSPECTION END**

**5. CHECK INTERMITTENT INCIDENT**

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

**Removal and Installation  
FUEL PUMP**

Refer to [EM-193, "FUEL PUMP"](#) .

# DTC P0093 FUEL SYSTEM

[YD]

## DTC P0093 FUEL SYSTEM

PF:17520

### On Board Diagnosis Logic

GBS0004A

**NOTE:**

If DTC P0093 is displayed with DTC P0652 or P0653, first perform the trouble diagnosis for DTC P0652 or P0653. Refer to [EC-1215, "DTC P0652, P0653 SENSOR POWER SUPPLY"](#) .

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0093 0093	Fuel system leak	ECM detects a fuel system leak. (The relation between the output voltage to the fuel pump and input voltage from the fuel rail pressure sensor is out of the normal range.)	<ul style="list-style-type: none"> <li>● Fuel pump</li> <li>● Fuel rail</li> <li>● Fuel pipe</li> <li>● Fuel rail pressure relief valve</li> <li>● Air mixed with fuel</li> <li>● Lack of fuel</li> </ul>

### DTC Confirmation Procedure

GBS0004B

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**☑ WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and keep engine speed more than 4,000 rpm for at least 5 seconds.
4. If DTC is detected, go to [EC-1077, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

**⊗ WITHOUT CONSULT-II**

1. Start engine and keep engine speed more than 4,000 rpm for at least 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-1077, "Diagnostic Procedure"](#) .

**Diagnostic Procedure****1. PERFORM FUEL PUMP LEARNING VALUE CLEARING****NOTE:**

If the DTC is detected because of air mixed with fuel (i.e.: caused by lack of fuel), it may become normal by performing following procedure.

**📞 With CONSULT-II**

1. Turn ignition switch ON.
2. Perform Fuel Pump Learning Value Clearing. Refer to [EC-1013, "Fuel Pump Learning Value Clearing"](#) .
3. Start engine and let it idle for at least 60 seconds.
4. Select "SELF-DIAG RESULT" mode with CONSULT-II.
5. Touch "ERASE".
6. Perform [EC-1076, "DTC Confirmation Procedure"](#) , again.
7. Is DTC detected again?

**🚫 Without CONSULT-II**

1. Turn ignition switch ON.
2. Perform Fuel Pump Learning Value Clearing. Refer to [EC-1013, "Fuel Pump Learning Value Clearing"](#) .
3. Start engine and let it idle for at least 60 seconds.
4. Erase the Diagnostic Test Mode II (Self-diagnostic results) memory. Refer to [EC-1016](#) .
5. Perform [EC-1076, "DTC Confirmation Procedure"](#) , again.
6. Is DTC detected again?

**Yes or No**

Yes >> GO TO 2.

No >> **INSPECTION END**

**2. CHECK FUEL LINE FOR LEAK**

1. Start engine.
2. Visually check the following for fuel leak.
  - Fuel tube from fuel pump to fuel rail
  - Fuel rail
  - Fuel tube from fuel rail to fuel injector
3. Also check for improper connection or pinches.

**OK or NG**

OK >> GO TO 3.

NG >> Repair malfunctioning part.

**3. CHECK FUEL RAIL PRESSURE RELIEF VALVE**

Refer to [EC-1078, "Component Inspection"](#) .

**OK or NG**

OK >> GO TO 4.

NG >> Replace fuel rail.

**4. CHECK INTERMITTENT INCIDENT**

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

**OK or NG**

OK >> GO TO 5.

NG >> Repair or replace.

**5. REPLACE FUEL PUMP**

1. Replace fuel pump.
2. Perform Fuel Pump Learning Value Clearing. Refer to [EC-1013, "Fuel Pump Learning Value Clearing"](#).

>> INSPECTION END


**Component Inspection  
FUEL RAIL PRESSURE RELIEF VALVE**

GBS0004D

📱 With CONSULT-II

**WARNING:**

- Confirm that the engine is cooled down and there are no fire hazards near the vehicle.
  - Prepare pans or saucers under the disconnected fuel line because the fuel may spill out.
1. Turn ignition switch OFF.
  2. Remove fuel hose from fuel rail pressure relief valve.
  3. Attach a blind cap or plug to removed hose.
  4. Turn ignition switch ON.



5. Select "PRES REGULATOR" in "ACTIVE TEST MODE" with CONSULT-II.
6. Start engine and keep engine speed 2,000 rpm.
7. Raise fuel pressure to 180 MPa with touching "UP" or "Qu" on the CONSULT-II screen.
8. Confirm that the fuel does not come out from the fuel rail pressure relief valve.

**WARNING:**

- Be careful not to allow leaked fuel to contaminate engine compartment. Especially, ensure to keep engine mount insulator clear of fuel.
- If the fuel comes out, stop the engine immediately.

ACTIVE TEST	
PRES REGULATOR	XXX MPa
MONITOR	
CKPS-RPM (TDC)	XXX rpm
ACT CR PRESS	XXX MPa

PBIB0587E


⊗ Without CONSULT-II

**WARNING:**

- Confirm that the engine is cooled down and there are no fire hazards near the vehicle.
  - Prepare pans or saucers under the disconnected fuel line because the fuel may spill out.
1. Turn ignition switch OFF.
  2. Remove fuel hose from fuel rail pressure relief valve.
  3. Attach a blind cap or plug to removed hose.
  4. Start engine and keep engine speed more than 4,000 rpm for at least 5 seconds.
  5. Confirm that the fuel does not come out from the fuel rail pressure relief valve.

**WARNING:**

- Be careful not to allow leaked fuel to contaminate engine compartment. Especially, ensure to keep engine mount insulator clear of fuel.
- If the fuel comes out, stop the engine immediately.



## Removal and Installation

### FUEL RAIL

Refer to [EM-188, "INJECTION TUBE AND FUEL INJECTOR"](#) .

### FUEL PUMP

Refer to [EM-193, "FUEL PUMP"](#) .

A

EC

C

D

E

F

G

H

I

J

K

L

M

**DTC P0102, P0103 MAF SENSOR**


PFP:22680

**Component Description**

GBS0004F

The mass air flow sensor (1) is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. The mass air flow sensor controls the temperature of the hot wire to a certain amount. The heat generated by the hot wire is reduced as the intake air flows around it. The more air, the greater the heat loss.

Therefore, the electric current supplied to hot wire is changed to maintain the temperature of the hot wire as air flow increases. The ECM detects the air flow by means of this current change.



PBIA9559J

**CONSULT-II Reference Value in Data Monitor Mode**

GBS0004G

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
MAS AIR/FL SE*	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Air conditioner switch: OFF</li> <li>● Shift lever: P or N (A/T), Neutral (M/T)</li> <li>● No load</li> </ul>	Ignition switch: ON (Engine stopped)	Approximately 0.4V
		Idle	1.3 - 1.7V
		Engine is revving from idle to about 4,000 rpm.	1.3 - 1.7V to Approximately 4.0V (Check for liner voltage rise in response to engine being increased to about 4,000 rpm)

\*: This signal is converted by ECM internally. Thus, it differs from ECM terminal voltage.

**ECM Terminals and Reference Value**

GBS0004H

Specification data are reference values, and are measured between each terminal and ground.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
54	G	Mass air flow sensor	[Ignition switch: ON]	Approximately 0.7V
			[Engine is running]	1.6 - 2.0V
			<ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	
67	—	Sensor ground (Sensor shield circuit)	[Engine is running]	1.6 - 2.0V to Approximately 4.3V (Check for liner voltage rise in response to engine being increased to about 4,000 rpm)
			<ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine is revving from idle to about 4,000 rpm.</li> </ul>	
73	B	Mass air flow sensor ground	[Ignition switch ON]	Approximately 0.3V

# DTC P0102, P0103 MAF SENSOR

[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
105 113	BR BR	ECM relay (self shut-off)	<b>[Ignition switch ON]</b> <b>[Ignition switch OFF]</b> <ul style="list-style-type: none"> <li>● For a few seconds after turning ignition switch OFF</li> </ul>	Approximately 1.0V
			<b>[Ignition switch OFF]</b> <ul style="list-style-type: none"> <li>● More than a few seconds after turning ignition switch OFF</li> </ul>	BATTERY VOLTAGE (11 - 14V)
119 120	R G	Power supply for ECM	<b>[Ignition switch ON]</b>	BATTERY VOLTAGE (11 - 14V)

## On Board Diagnosis Logic

GBS0004I

The MIL will not light up for these self-diagnoses.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0102 0102	Mass air flow sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> <li>● Harness or connectors (The sensor circuit is open or shorted.)</li> <li>● Mass air flow sensor</li> </ul>
P0103 0103	Mass air flow sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

## DTC Confirmation Procedure

GBS0004J

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### Ⓟ WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-1083, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

### ⓧ WITHOUT CONSULT-II

1. Turn ignition switch ON and wait at least 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-1083, "Diagnostic Procedure"](#) .






# DTC P0102, P0103 MAF SENSOR

[YD]

## Wiring Diagram

GBS0004K

### EC-MAFS-01




MBWA1036E



## Diagnostic Procedure

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body.  
Refer to [EC-1066](#), "Ground Inspection".



↩ : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

### 2. CHECK MAFS POWER SUPPLY CIRCUIT

1. Disconnect mass air flow (MAF) sensor (1) harness connector.  
 - ↩: Vehicle front
2. Turn ignition switch ON.




3. Check voltage between MAF sensor terminal 5 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 4.  
 NG >> GO TO 3.



### 3. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors E9, F4
- Harness for open or short between IPDM E/R and mass air flow sensor
- Harness for open or short between ECM and mass air flow sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

### 4. CHECK MAFS GROUND CIRCUIT FOR OPEN AND SHORT

---

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between MAF sensor terminal 4 and ECM terminal 73.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

### 5. CHECK MAFS INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

1. Check harness continuity between MAF sensor terminal 3 and ECM terminal 54.  
Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 6.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

### 6. CHECK MASS AIR FLOW SENSOR

---

Refer to [EC-1084, "Component Inspection"](#) .

OK or NG

OK >> GO TO 7.

NG >> Replace mass air flow sensor.

### 7. CHECK INTERMITTENT INCIDENT

---

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

### Component Inspection MASS AIR FLOW SENSOR

GBS0004M

#### With CONSULT-II

1. Reconnect all harness connectors disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Connect CONSULT-II and select "DATA MONITOR" mode.

# DTC P0102, P0103 MAF SENSOR

[YD]

4. Select "MAS AIR/FL SE" and check indication under the following conditions.

Condition	MAS AIR/FL SE (V)
Ignition switch ON (Engine stopped.)	Approx. 0.4
Idle (Engine is warmed-up to normal operating temperature.)	1.3 - 1.7
Idle to about 4,000 rpm	1.3 - 1.7 to Approx. 4.0*

\*: Check for linear voltage rise in response to engine being increased to about 4,000 rpm.

5. If the voltage is out of specification, proceed the following.
- Check for the cause of uneven air flow through mass air flow sensor. Refer to following.
    - Crushed air ducts
    - Malfunctioning seal of air cleaner element
    - Uneven dirt of air cleaner element
    - Improper specification of intake air system parts
  - If NG, repair or replace malfunctioning part and perform step 2 to 4 again. If OK, go to next step.
6. Turn ignition switch OFF.
7. Disconnect mass air flow sensor harness connector and reconnect it again.
8. Perform step 2 to 4 again.
9. If NG, clean or replace mass air flow sensor.

## ⊗ Without CONSULT-II

- Reconnect all harness connectors disconnected.
- Start engine and warm it up to normal operating temperature.
- Check voltage between ECM terminal 54 (Mass air flow sensor signal) and ground.



Condition	Voltage V
Ignition switch ON (Engine stopped.)	Approx. 0.7
Idle (Engine is warmed-up to normal operating temperature.)	1.6 - 2.0
Idle to about 4,000 rpm	1.6 - 2.0 to Approx. 4.3*

\*: Check for linear voltage rise in response to engine being increased to about 4,000 rpm.

4. If the voltage is out of specification, proceed the following.
- Check for the cause of uneven air flow through mass air flow sensor. Refer to following.
    - Crushed air ducts
    - Malfunctioning seal of air cleaner element
    - Uneven dirt of air cleaner element
    - Improper specification of intake air system parts
  - If NG, repair or replace malfunctioning part and perform step 2 to 3 again. If OK, go to next step.
5. Turn ignition switch OFF.
6. Disconnect mass air flow sensor harness connector and reconnect it again.
7. Perform step 2 and 3 again.
8. If NG, clean or replace mass air flow sensor.

## Removal and Installation MASS AIR FLOW SENSOR

Refer to [EM-159, "AIR CLEANER AND AIR DUCT"](#) .



GBS0004N

# DTC P0112, P0113 IAT SENSOR

[YD]

## DTC P0112, P0113 IAT SENSOR


PFP:22630

### Component Description

GBS00040

The intake air temperature sensor is built into mass air flow sensor (1). The sensor detects intake air temperature and transmits a signal to the ECM.

The temperature sensing unit uses a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.




### <Reference data>

Intake air temperature °C (°F)	Voltage* V	Resistance kΩ
25 (77)	2.4	1.800 - 2.200
80 (176)	0.8	0.283 - 0.359

\*: This data is reference values and is measured between ECM terminal 55 (Intake air temperature sensor) and ground.

### CAUTION:

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**



### On Board Diagnosis Logic

GBS0004P

The MIL will not light up for these self-diagnoses.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0112 0112	Intake air temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> <li>● Harness or connectors (The sensor circuit is open or shorted.)</li> <li>● Intake air temperature sensor</li> </ul>
P0113 0113	Intake air temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

### DTC Confirmation Procedure


GBS0004Q

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-1089, "Diagnostic Procedure"](#).



#### WITHOUT CONSULT-II

1. Turn ignition switch ON and wait at least 5 seconds.

## DTC P0112, P0113 IAT SENSOR

[YD]

2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-1089, "Diagnostic Procedure"](#) .

A

EC

C

D

E

F

G

H

I

J

K

L

M




# DTC P0112, P0113 IAT SENSOR

[YD]

## Wiring Diagram

GBS0004R

EC-IATS-01




MBWA1037E

## Diagnostic Procedure

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body.  
Refer to [EC-1066](#), "Ground Inspection".



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
NG >> Repair or replace ground connections.

### 2. CHECK INTAKE AIR TEMPERATURE SENSOR POWER SUPPLY CIRCUIT

1. Disconnect mass air flow sensor (intake air temperature sensor is built-into) (1) harness connector.  
- ←: Vehicle front
2. Turn ignition switch ON.




3. Check voltage between MAF sensor terminal 2 and ground with CONSULT-II or tester.

**Voltage: Approximately 5.3V**

#### OK or NG

- OK >> GO TO 3.  
NG >> Repair harness or connectors.



**3. CHECK INTAKE AIR TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between MAF sensor terminal 1 and ECM terminal 74.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**4. CHECK INTAKE AIR TEMPERATURE SENSOR**

Refer to [EC-1090, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace mass air flow sensor (with intake air temperature sensor).

**5. CHECK INTERMITTENT INCIDENT**

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END



**Component Inspection  
INTAKE AIR TEMPERATURE SENSOR**

GBS0004T

1. Check resistance between mass air flow sensor (1) terminals 1 and 2 under the following conditions.

Intake air temperature °C (°F)	Resistance kΩ
25 (77)	1.800 - 2.200

2. If NG, replace mass air flow sensor (with intake air temperature sensor).



**Removal and Installation  
MASS AIR FLOW SENSOR**

GBS0004U

Refer to [EM-159, "AIR CLEANER AND AIR DUCT"](#) .



# DTC P0117, P0118 ECT SENSOR

[YD]


## DTC P0117, P0118 ECT SENSOR

PFP:22630

### Description

GBS0004V


The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.



### <Reference data>

Engine coolant temperature °C (°F)	Voltage* (V)	Resistance (kΩ)
-10 (14)	4.7	7.0 - 11.4
20 (68)	3.8	2.1 - 2.9
50 (122)	2.6	0.68 - 1.00
90 (194)	1.3	0.236 - 0.260

\*: This data is reference values and is measured between ECM terminal 51 (Engine coolant temperature sensor) and ground.



### CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

### On Board Diagnosis Logic

GBS0004W

The MIL will not light up for these self-diagnoses.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0117 0117	Engine coolant temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> <li>● Harness or connectors (The sensor circuit is open or shorted.)</li> <li>● Engine coolant temperature sensor</li> </ul>
P0118 0118	Engine coolant temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

### DTC Confirmation Procedure


GBS0004X

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-1094, "Diagnostic Procedure"](#).



---

⊗ **WITHOUT CONSULT-II**

1. Turn ignition switch ON and wait at least 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-1094, "Diagnostic Procedure"](#) .

# DTC P0117, P0118 ECT SENSOR



[YD]

## Wiring Diagram

GBS0004Y

EC-ECTS-01

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M




MBWA1038E

## Diagnostic Procedure

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body.  
Refer to [EC-1066, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
NG >> Repair or replace ground connections.

### 2. CHECK ECT SENSOR POWER SUPPLY CIRCUIT

1. Disconnect engine coolant temperature sensor (1) harness connector.  
- ←: Vehicle front  
- EGR volume control valve (2)
2. Turn ignition switch ON.




3. Check voltage between ECT sensor terminal 1 and ground with CONSULT-II or tester.

**Voltage: Approximately 5.3V**

#### OK or NG

- OK >> GO TO 3.  
NG >> Repair harness or connectors.



## 3. CHECK ECT SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECT sensor terminal 2 and ECM terminal 70. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 4. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Refer to [EC-1095, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace engine coolant temperature sensor.

## 5. CHECK INTERMITTENT INCIDENT


Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

### Component Inspection ENGINE COOLANT TEMPERATURE SENSOR

GBS00050


1. Check resistance between engine coolant temperature sensor terminals 1 and 2 as shown in the figure.



#### <Reference data>

Engine coolant temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

2. If NG, replace engine coolant temperature sensor.



SEF012P

### Removal and Installation ENGINE COOLANT TEMPERATURE SENSOR

GBS00051

Refer to [EM-236, "CYLINDER HEAD"](#) .


DTC P0122, P0123 APP SENSOR

PFP:18002

Description

GBS00052

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensors detect the accelerator pedal position and sends a signal to the ECM. The ECM uses the signal to determine the amount of fuel to be injected.



CONSULT-II Reference Value in Data Monitor Mode

GBS00053

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
ACCEL POS SEN*	● Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	0.65 - 0.87V
		Accelerator pedal: Fully depressed	More than 4.3V
ACCEL SEN 2*	● Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	0.28 - 0.48V
		Accelerator pedal: Fully depressed	More than 2.0V

\*: This signal is converted by ECM internally. Thus, it differs from ECM terminal voltage.

ECM Terminals and Reference Value

GBS00054

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
82	W	Accelerator pedal position sensor 1 power supply	[Ignition switch ON]	Approximately 5.3V
83	R	Accelerator pedal position sensor 1	[Ignition switch ON] ● Engine stopped ● Accelerator pedal: Fully released	0.95 - 1.17V
			[Ignition switch ON] ● Engine stopped ● Accelerator pedal: Fully depressed	More than 4.6V
84	B	Accelerator pedal position sensor 1 ground	[Ignition switch ON]	Approximately 0.3V
85	—	Sensor ground (Accelerator pedal position sensor shield circuit)	[Ignition switch ON]	Approximately 0.3V
90	W	Accelerator pedal position sensor 2 power supply	[Ignition switch ON]	Approximately 5.3V

# DTC P0122, P0123 APP SENSOR

[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
91	R	Accelerator pedal position sensor 2	[Ignition switch ON] ● Engine stopped ● Accelerator pedal: Fully released	0.58 - 0.78V
			[Ignition switch ON] ● Engine stopped ● Accelerator pedal: Fully depressed	More than 2.3V
92	B	Accelerator pedal position sensor 2 ground	[Ignition switch ON]	Approximately 0.3V

## On Board Diagnosis Logic

GBS00055

The MIL will not light up for these self-diagnoses.

### NOTE:

If DTC P0122 or P0123 is displayed with DTC P0642 or P0643, first perform the trouble diagnosis for DTC P0642 or P0643. Refer to [EC-1210, "DTC P0642, P0643 SENSOR POWER SUPPLY"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0122 0122	Accelerator pedal position sensor 1 circuit low input	An excessively low voltage from the APP sensor 1 is sent to ECM.	● Harness or connectors (The APP sensor 1 circuit is open or shorted.) ● Accelerator pedal position sensor (Accelerator pedal position sensor 1)
P0123 0123	Accelerator pedal position sensor 1 circuit high input	An excessively high voltage from the APP sensor 1 is sent to ECM.	

## DTC Confirmation Procedure

GBS00056

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### WITH CONSULT-II

- Turn ignition switch ON.
- Select "DATA MONITOR" mode with CONSULT-II.
- Wait at least 5 seconds.
- If DTC is detected, go to [EC-1099, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

### WITHOUT CONSULT-II

- Turn ignition switch ON and wait at least 5 seconds.
- Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- If DTC is detected, go to [EC-1099, "Diagnostic Procedure"](#).




# DTC P0122, P0123 APP SENSOR

[YD]

GBS00057

## Wiring Diagram

EC-APPS1-01






## Diagnostic Procedure

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body.  
Refer to [EC-1066](#), "Ground Inspection".



↙ : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
NG >> Repair or replace ground connections.

### 2. CHECK APP SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect accelerator pedal position (APP) sensor (1) harness connector.
2. Turn ignition switch ON.




3. Check voltage between APP sensor terminal 2 and ground with CONSULT-II or tester.

**Voltage: Approximately 5.3V**

#### OK or NG

- OK >> GO TO 3.  
NG >> Repair open circuit or short to ground or short to power in harness or connectors.



### 3. CHECK APP SENSOR 1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between APP sensor terminal 4 and ECM terminal 84.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

### 4. CHECK APP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 83 and APP sensor terminal 3.  
Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

### 5. CHECK APP SENSOR

Refer to [EC-1100, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace accelerator pedal assembly.

### 6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

### Component Inspection ACCELERATOR PEDAL POSITION SENSOR

GBS00059

1. Reconnect all harness connectors disconnected.
2. Turn ignition switch ON.
3. Check voltage between ECM terminals 83 (APP sensor 1 signal), 91 (APP sensor 2 signal) and ground under the following conditions.

Terminal	Accelerator pedal	Voltage
83 (Accelerator pedal position sensor 1)	Fully released	0.95 - 1.17V
	Fully depressed	More than 4.6V
91 (Accelerator pedal position sensor 2)	Fully released	0.58 - 0.78V
	Fully depressed	More than 2.3V



4. If NG, replace accelerator pedal assembly.

### Removal and Installation ACCELERATOR PEDAL

GBS0005A

Refer to [ACC-2, "ACCELERATOR CONTROL SYSTEM"](#) .

# DTC P0182, P0183 FUEL PUMP TEMPERATURE SENSOR

[YD]


## DTC P0182, P0183 FUEL PUMP TEMPERATURE SENSOR

PFP:16700

### Description

GBS0005B

Fuel pump temperature sensor (1) is built in the fuel pump (2). The sensor detects the fuel temperature in the fuel pump and calibrates the fuel injection amount change by fuel temperature.



### CONSULT-II Reference Value in Data Monitor Mode

GBS0005C

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
FUEL TEMP SEN	● Engine: After warming up	More than 40°C (104°F)

### ECM Terminals and Reference Value

GBS0005D

Specification data are reference values and are measured between each terminal and ground.

#### CAUTION:

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
50	Y	Fuel pump temperature sensor	<b>[Engine is running]</b> ● Warm-up condition	Approximately 0.3 - 5.3V Output voltage varies with fuel pump temperature
69	B	Fuel pump temperature sensor ground	<b>[Ignition switch ON]</b>	Approximately 0.3V

### On Board Diagnosis Logic

GBS0005E

The MIL will not light up for these self-diagnoses.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0182 0182	Fuel pump temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	● Harness or connectors (The sensor circuit is open or shorted.) ● Fuel pump temperature sensor
P0183 0183	Fuel pump temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

## DTC Confirmation Procedure

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### ④ WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-1104, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

### ⊗ WITHOUT CONSULT-II

1. Turn ignition switch ON and wait at least 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-1104, "Diagnostic Procedure"](#).

# DTC P0182, P0183 FUEL PUMP TEMPERATURE SENSOR



[YD]

## Wiring Diagram

GBS0005G

EC-FTS-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC




MBWA1040E

## Diagnostic Procedure

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body.  
Refer to [EC-1066, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
NG >> Repair or replace ground connections.

### 2. CHECK FUEL PUMP TEMPERATURE SENSOR POWER SUPPLY CIRCUIT

1. Disconnect fuel pump temperature sensor (1) harness connector.
  - Fuel pump (2)
2. Turn ignition switch ON.




3. Check voltage between fuel pump temperature sensor terminal 1 and ground with CONSULT-II or tester.

**Voltage: Approximately 5.3V**

#### OK or NG

- OK >> GO TO 3.  
NG >> Repair harness or connectors.



## 3. CHECK FUEL PUMP TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between fuel pump temperature sensor terminal 2 and ECM terminal 69. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 4. CHECK INTERMITTENT INCIDENT

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

OK >> GO TO 5.

NG >> Repair or replace.

## 5. REPLACE FUEL PUMP

1. Replace fuel pump.
2. Perform Fuel Pump Learning Value Clearing. Refer to [EC-1013, "Fuel Pump Learning Value Clearing"](#) .

>> **INSPECTION END**

## Removal and Installation FUEL PUMP

GBS0005I

Refer to [EM-193, "FUEL PUMP"](#) .

# DTC P0192, P0193 FRP SENSOR

[YD]

## DTC P0192, P0193 FRP SENSOR

PFP:16638

### Description

GBS0005J

The fuel rail pressure (FRP) sensor is placed to the fuel rail. It measures the fuel pressure in the fuel rail. The sensor sends voltage signal to the ECM. As the pressure increases, the voltage rises. The ECM controls the fuel pressure in the fuel rail by the inlet throttling device. The ECM uses the signal from fuel rail pressure sensor as a feedback signal.

### CONSULT-II Reference Value in Data Monitor Mode

GBS0005K

Specification data are reference values.

MONITOR	CONDITION		SPECIFICATOIN
ACT CR PRESS	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Air conditioner switch: OFF</li> <li>● Shift lever: P or N (A/T), Neutral (M/T)</li> <li>● No load</li> </ul>	Idle	25 - 35 MPa
		2,000 rpm	40 - 50 MPa

### ECM Terminals and Reference Value

GBS0005L

Specification data are reference values and are measured between each terminal and ground.

#### CAUTION:

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
48 49	L B	Fuel rail pressure sensor	[Engine is running] ● Warm-up condition ● Idle speed	1.7 - 2.0V
			[Engine is running] ● Warm-up condition ● Engine speed: 2,000 rpm	2.0 - 2.3V
63	R	Fuel rail pressure sensor power supply	[Ignition switch ON]	Approximately 5.3V
67	—	Sensor ground (Sensor shield circuit)	[Ignition switch ON]	Approximately 0.3V
68	W	Fuel rail pressure sensor ground	[Ignition switch ON]	Approximately 0.3V

### On Board Diagnosis Logic

GBS0005M

The MIL will not light up for these self-diagnoses.

#### NOTE:

If DTC P0192 or P0193 is displayed with DTC P0652 or P0653, first perform the trouble diagnosis for DTC P0652 or P0653. Refer to [EC-1215, "DTC P0652, P0653 SENSOR POWER SUPPLY"](#) .

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0192 0192	Fuel rail pressure sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> <li>● Harness or connectors (The sensor circuit is open or shorted.)</li> <li>● Fuel rail temperature sensor</li> </ul>
P0193 0193	Fuel rail pressure sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	



## DTC Confirmation Procedure

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**Ⓟ WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-1109, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

**ⓧ WITHOUT CONSULT-II**

1. Turn ignition switch ON and wait at least 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-1109, "Diagnostic Procedure"](#) .

# DTC P0192, P0193 FRP SENSOR



[YD]

## Wiring Diagram

GBS00050

### EC-FRPS-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



F1  
B




3 2 1 F11

## Diagnostic Procedure

### 1. CHECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body.  
Refer to [EC-1066](#), "Ground Inspection".



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
NG >> Repair or replace ground connections.

### 2. CHECK FUEL RAIL PRESSURE SENSOR POWER SUPPLY CIRCUIT

1. Disconnect fuel rail pressure sensor (1) harness connector.
2. Turn ignition switch ON.




3. Check voltage between fuel rail pressure sensor terminal 1 and ground with CONSULT-II or tester.

**Voltage: Approximately 5.3V**

#### OK or NG

- OK >> GO TO 3.  
NG >> Repair open circuit or short to ground or short to power in harness or connectors.



### 3. CHECK FUEL RAIL PRESSURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between fuel rail pressure sensor terminal 3 and ECM terminal 68.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

### 4. CHECK FUEL RAIL PRESSURE SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminals 48, 49 and fuel rail pressure sensor terminal 2.  
Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness connectors.

### 5. CHECK FUEL RAIL PRESSURE SENSOR

Refer to [EC-1110, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace fuel rail.

### 6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


### Component Inspection FUEL RAIL PRESSURE SENSOR

GBS0005Q

1. Reconnect harness connector disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Check voltage between ECM terminals 48, 49 (fuel rail pressure sensor signal) and ground under the following conditions.

Condition	Voltage V
Idle	1.7 - 2.0
2,000 rpm	2.0 - 2.3

4. If the voltage is out of specification, disconnect fuel rail pressure sensor harness connector and connect it again. Then repeat above check.
5. If NG, replace fuel rail.



GBS0005R

### Removal and Installation FUEL RAIL

Refer to [EM-188, "INJECTION TUBE AND FUEL INJECTOR"](#) .

# DTC P0200 FUEL INJECTOR

[YD]

## DTC P0200 FUEL INJECTOR

PF1:16600

### On Board Diagnosis Logic

GBS0005S

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0200 0200	Fuel injector power supply circuit	ECM detects a voltage of power source for the fuel injector is excessively high or low.	● ECM

### DTC Confirmation Procedure


GBS0005T

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for at least 5 seconds.
4. If DTC is detected, go to [EC-1111, "Diagnostic Procedure"](#).



DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

#### WITHOUT CONSULT-II

1. Start engine and let it idle for at least 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-1111, "Diagnostic Procedure"](#).

### Diagnostic Procedure

GBS0005U

#### 1. INSPECTION START

#### With CONSULT-II

1. Turn ignition switch ON.
2. Select "SELF DIAG RESULTS" mode with CONSULT-II.
3. Touch "ERASE".
4. Perform [EC-1111, "DTC Confirmation Procedure"](#), again.
5. Is DTC P0200 displayed again?

#### Without CONSULT-II

1. Turn ignition switch ON.
2. Erase the Diagnostic Test Mode II (Self-diagnostic results) memory. Refer to [EC-1016](#).
3. Perform [EC-1111, "DTC Confirmation Procedure"](#), again.
4. Is DTC 0200 displayed again?

#### Yes or No

- Yes >> GO TO 2.  
No >> **INSPECTION END**

---

## 2. REPLACE ECM

---

1. Replace ECM.
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [BL-83, "ECM Re-communicating Function"](#) .
3. Perform Fuel Pump Learning Value Clearing. Refer to [EC-1013, "Fuel Pump Learning Value Clearing"](#) .
4. Perform Injector Adjustment Value Registration. Refer to [EC-1014, "Injector Adjustment Value Registration"](#) .

>> INSPECTION END


**DTC P0201 - P0204 FUEL INJECTOR**

PF16600

**Component Description**

GBS0005V

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the fuel injector circuit, the coil in the fuel injector is energized. The energized coil pulls the needle valve back and allows fuel to flow through the fuel injector into the cylinder. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the fuel injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.



**CONSULT-II Reference Value in Data Monitor Mode**

GBS0005W

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
MAIN INJ WID	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> </ul>	No load	0.50 - 0.70 msec
	<ul style="list-style-type: none"> <li>● Shift lever: P or N (A/T), Neutral (M/T)</li> <li>● Idle speed</li> </ul>	Blower fan switch: ON Rear window defogger switch: ON	0.50 - 0.80 msec

**ECM Terminals and Reference Value**

GBS0005X

Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-II.





**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
4	V	Fuel injector power supply (For cylinder No. 1 and 4) Fuel injector power supply (For cylinder No. 2 and 3)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <b>NOTE:</b> The pulse cycle changes depending on rpm at idle	Approximately 7.5V ★ 
5	G		<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	Approximately 8.0V ★ 

# DTC P0201 - P0204 FUEL INJECTOR

[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
21 22 23 24	G P W W	Fuel injector No. 2 Fuel injector No. 2 Fuel injector No. 3 Fuel injector No. 3	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <b>NOTE:</b> The pulse cycle changes depending on rpm at idle	Approximately 7.5V ★  <small>MBIB1297E</small>
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	Approximately 8.0V ★  <small>MBIB1298E</small>
40 41 42 43	W GR W B	Fuel injector No. 4 Fuel injector No. 4 Fuel injector No. 1 Fuel injector No. 1	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <b>NOTE:</b> The pulse cycle changes depending on rpm at idle	Approximately 7.5V ★  <small>MBIB1297E</small>
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	Approximately 8.0V ★  <small>MBIB1298E</small>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## On Board Diagnosis Logic

GBS0005Y

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0201 0201	No. 1 cylinder fuel injector circuit open	An improper voltage signal is sent to ECM through No. 1 cylinder fuel injector.	<ul style="list-style-type: none"> <li>● Harness or connectors (The fuel injector circuit is open.)</li> <li>● Fuel injector</li> </ul>
P0202 0202	No. 2 cylinder fuel injector circuit open	An improper voltage signal is sent to ECM through No. 2 cylinder fuel injector.	
P0203 0203	No. 3 cylinder fuel injector circuit open	An improper voltage signal is sent to ECM through No. 3 cylinder fuel injector.	
P0204 0204	No. 4 cylinder fuel injector circuit open	An improper voltage signal is sent to ECM through No. 4 cylinder fuel injector.	



DTC Confirmation Procedure

NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION

Before performing the following procedure, confirm the ambient temperature is more than -20°C (-4°F).

WITH CONSULT-II

- 1. Turn ignition switch ON.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Start engine and let it idle for at least 5 seconds.
- 4. If DTC is detected, go to [EC-1117, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

WITHOUT CONSULT-II

- 1. Start engine and let it idle for at least 5 seconds.
- 2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 4. If DTC is detected, go to [EC-1117, "Diagnostic Procedure"](#).

# DTC P0201 - P0204 FUEL INJECTOR




[YD]

## Wiring Diagram

GBS00060

### EC-INJECT-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC




MBWA1042E

## Diagnostic Procedure

### 1. CHECK FUEL INJECTOR POWER SUPPLY FOR OPEN AND SHORT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Disconnect fuel injector (1) harness connector.
4. Check harness continuity between the following terminals corresponding to the malfunctioning cylinder. Refer to Wiring Diagram.



DTC	Terminal		Cylinder
	ECM	Fuel injector	
P0201	4	1	No.1
P0202	5	1	No.2
P0203	5	1	No.3
P0204	4	1	No.4

**Continuity should exist.**

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 2.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

### 2. CHECK FUEL INJECTOR OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between the following terminals corresponding to the malfunctioning cylinder. Refer to Wiring Diagram.

DTC	Terminal		Cylinder
	ECM	Fuel injector	
P0201	42, 43	2	No.1
P0202	21, 22	2	No.2
P0203	23, 24	2	No.3
P0204	40, 41	2	No.4

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

### 3. CHECK FUEL INJECTOR-I

Refer to [EC-1118, "Component Inspection"](#) .

OK or NG

OK >> GO TO 4.

NG >> Replace fuel injector.

## 4. CHECK FUEL INJECTOR-II

---

### With CONSULT-II

1. Remove two fuel injectors.

**NOTE:**

One is from malfunctioning cylinder and the other is from any cylinder other than the malfunctioning cylinder.

2. Swap the two fuel injectors to the other cylinder.
3. Reconnect ECM harness connector and fuel injector harness connectors.
4. Turn ignition switch ON.
5. Perform Injector Adjustment Value Registration. Refer to [EC-1014, "Injector Adjustment Value Registration"](#).
6. Select "SELF DIAG RESULTS" mode with CONSULT-II.
7. Touch "ERASE".
8. Perform [EC-1115, "DTC Confirmation Procedure"](#).
9. Is DTC displayed for the other cylinder?

### Without CONSULT-II

1. Remove two fuel injectors.

**NOTE:**

One is from malfunctioning cylinder and the other is from any cylinder other than the malfunctioning cylinder.

2. Swap the two fuel injectors to the other cylinder.
3. Reconnect ECM harness connector and fuel injector harness connectors.
4. Turn ignition switch ON.
5. Perform Injector Adjustment Value Registration. Refer to [EC-1014, "Injector Adjustment Value Registration"](#).
6. Erase the Diagnostic Test Mode II (Self-diagnostic results) memory. Refer to [EC-1016](#).
7. Perform DTC Confirmation Procedure, [EC-1115, "DTC Confirmation Procedure"](#).
8. Is DTC displayed for the other cylinder?

Yes or No

- Yes >> GO TO 5.  
No >> GO TO 6.

## 5. REPLACE FUEL INJECTOR

---

1. Replace fuel injector of malfunctioning cylinder.
2. Perform Injector Adjustment Value Registration. Refer to [EC-1014, "Injector Adjustment Value Registration"](#).

>> INSPECTION END

## 6. CHECK INTERMITTENT INCIDENT

---

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

>> INSPECTION END

### Component Inspection FUEL INJECTOR

1. Disconnect fuel injector harness connector.


# DTC P0201 - P0204 FUEL INJECTOR

[YD]

2. Check resistance between terminals as shown in the figure.

**Resistance: 0.2 - 0.8Ω [at 10 - 60°C (50 - 140°F)]**

3. If NG, replace fuel injector.



GBS00063

## Removal and Installation FUEL INJECTOR

Refer to [EM-188, "INJECTION TUBE AND FUEL INJECTOR"](#) .

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# DTC P0217 ENGINE OVER TEMPERATURE

[YD]

## DTC P0217 ENGINE OVER TEMPERATURE

PFP:21481

### Description SYSTEM DESCRIPTION

GBS00064

#### NOTE:

If DTC P0217 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [EC-1067, "DTC U1000 CAN COMMUNICATION LINE"](#).


### Cooling Fan Control

Sensor	Input Signal to ECM	ECM function	Actuator
Wheel sensor	Vehicle speed*	Cooling fan control	IPDM E/R (Cooling fan relays)
Engine coolant temperature sensor	Engine coolant temperature		
Air conditioner switch	Air conditioner ON signal*		
Refrigerant pressure sensor	Refrigerant pressure		

\*: This signal is sent to ECM through CAN communication line.

The ECM controls the cooling fan corresponding to the vehicle speed, engine coolant temperature, refrigerant pressure, and air conditioner ON signal. The control system has 3-step control [HIGH/LOW/OFF].

### Cooling Fan Operation



### Cooling Fan Relay Operation

The ECM controls cooling fan relays in the IPDM E/R through CAN communication line.

Cooling fan speed	Cooling fan relay	
	1	2
Stop (OFF)	OFF	OFF
Low (LOW)	ON	OFF
High (HI)	OFF	ON

### COMPONENT DESCRIPTION

#### Cooling Fan Motor

The cooling fan operates at each speed when the current flows in the cooling fan motor as follows.

Cooling fan speed	Cooling fan motor terminals	
	(+)	(-)
Low (LOW)	1	3
High (HI)	2	3

# DTC P0217 ENGINE OVER TEMPERATURE

[YD]

## CONSULT-II Reference Value in Data Monitor Mode

GBS00065

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
COOLING FAN	<ul style="list-style-type: none"> <li>● Engine: After warming up, idle the engine</li> <li>● Air conditioner switch: OFF</li> </ul>	Engine coolant temperature: 97°C (207°F) or less	OFF
		Engine coolant temperature: Between 98°C (208°F) and 104°C (219°F)	LOW
		Engine coolant temperature: 105°C (221°F) or more	HI

## On Board Diagnosis Logic

GBS00066

If the cooling fan or another component in the cooling system malfunctions, engine coolant temperature will rise.

When the engine coolant temperature reaches an abnormally high temperature condition, a malfunction is indicated.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0217 0217	Engine over temperature (Overheat)	<ul style="list-style-type: none"> <li>● Cooling fan does not operate properly (Overheat).</li> <li>● Cooling fan system does not operate properly (Overheat).</li> <li>● Engine coolant was not added to the system using the proper filling method.</li> <li>● Engine coolant is not within the specified range.</li> </ul>	<ul style="list-style-type: none"> <li>● Harness or connectors (The cooling fan circuit is open or shorted.)</li> <li>● IPDM E/R</li> <li>● Cooling fan</li> <li>● Cooling fan (Crankshaft driven)</li> <li>● Radiator hose</li> <li>● Radiator</li> <li>● Radiator cap</li> <li>● Reservoir tank</li> <li>● Reservoir tank cap</li> <li>● Water pump</li> <li>● Thermostat</li> </ul> <p>For more information, refer to <a href="#">EC-1128</a>, "<a href="#">Main 12 Causes of Overheating</a>".</p>

### CAUTION:

When a malfunction is indicated, be sure to replace the coolant. Refer to [CO-37](#), "[Changing Engine Coolant](#)". Also, replace the engine oil. Refer to [LU-21](#), "[Changing Engine Oil](#)".

1. Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute. Be sure to use coolant with the proper mixture ratio. Refer to [MA-15](#), "[Engine Coolant Mixture Ratio](#)".
2. After refilling coolant, run engine to ensure that no water-flow noise is emitted.

## Overall Function Check

GBS00067

Use this procedure to check the overall function of the cooling fan. During this check, a DTC might not be confirmed.

### WARNING:


- Never remove a radiator cap and/or a reservoir tank cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator and the reservoir tank.
- Wrap a thick cloth around cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.

# DTC P0217 ENGINE OVER TEMPERATURE

[YD]

## ④ WITH CONSULT-II

1. Check the coolant level in the reservoir tank and radiator.  
**Allow engine to cool before checking coolant level.**  
If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to [EC-1125, "Diagnostic Procedure"](#).
2. Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to [EC-1125, "Diagnostic Procedure"](#).
3. Turn ignition switch ON.
4. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II.
5. If the results are NG, go to [EC-1125, "Diagnostic Procedure"](#).




ACTIVE TEST	
COOLING FAN	OFF
MONITOR	
COOLAN TEMP/S	XXX °C

SEF111X

## ⊗ WITHOUT CONSULT-II

1. Check the coolant level in the reservoir tank and radiator.  
**Allow engine to cool before checking coolant level.**  
If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to [EC-1125, "Diagnostic Procedure"](#).
2. Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to [EC-1125, "Diagnostic Procedure"](#).
3. Perform IPDM E/R auto active test and check cooling fan motors operation, refer to [PG-19, "Auto Active Test"](#).
4. If NG, go to [EC-1125, "Diagnostic Procedure"](#).








# DTC P0217 ENGINE OVER TEMPERATURE

[YD]

GBS00068

## Wiring Diagram




MBWA1332E

# DTC P0217 ENGINE OVER TEMPERATURE

[YD]

## EC-COOL/F-02



(E14)  
W



(E42)  
GR

## Diagnostic Procedure

### 1. CHECK COOLING FAN (CRANKSHAFT DRIVEN) OPERATION

1. Start engine and let it idle.
2. Make sure that cooling fan (crankshaft driven) operates normally.

OK or NG

- OK (With CONSULT-II)>>GO TO 2.
- OK (Without CONSULT-II)>>GO TO 3.
- NG >> Check cooling fan (crankshaft driven). Refer to [CO-48, "Removal and Installation"](#) .

### 2. CHECK COOLING FAN OPERATION

#### Ⓟ With CONSULT-II

1. Start engine and let it idle.
2. Select "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II.
3. Make sure that cooling fan operate at each speed (LOW/HI).

OK or NG

- OK >> GO TO 4.
- NG >> Check cooling fan control circuit. (Go to [EC-1127, "PROCEDURE A"](#) .)

ACTIVE TEST	
COOLING FAN	LOW
MONITOR	
COOLANT TEMP/S	XXX °C

SEF784Z

### 3. CHECK COOLING FAN OPERATION

#### ⊗ Without CONSULT-II

1. Perform IPDM E/R auto active test and check cooling fan motors operation, refer to [PG-19, "Auto Active Test"](#) .
2. Make sure that cooling fan operate at each speed (Low/High).

OK or NG

- OK >> GO TO 4.
- NG >> Check cooling fan control circuit. (Go to [EC-1127, "PROCEDURE A"](#) .)

### 4. CHECK COOLING SYSTEM FOR LEAK

Apply pressure to the cooling system with a tester, and check if the pressure drops. Refer to [CO-37, "CHECKING RADIATOR SYSTEM FOR LEAKS"](#) .

- Reservoir tank (1)
- A: SST (EG17650301)


**CAUTION:**

Higher than the specified pressure may cause radiator damage. Pressure should not drop.

OK or NG

- OK >> GO TO 5.
- NG >> Check the following for leak. Refer to [CO-37, "CHECKING RADIATOR SYSTEM FOR LEAKS"](#) .

- Hose
- Radiator
- Radiator cap
- Water pump
- Reservoir tank



## 5. CHECK RESERVOIR TANK CAP


Apply pressure to cap with a tester and check reservoir tank cap relief pressure.

Refer to [CO-42, "Checking Reservoir Tank Cap"](#).

OK or NG

OK >> GO TO 6.

NG >> Replace reservoir tank cap.



## 6. CHECK COMPONENT PARTS

Check the following.

- Thermostat. Refer to [CO-52, "THERMOSTAT AND WATER PIPING"](#).
- Engine coolant temperature sensor. Refer to [EC-1095, "Component Inspection"](#).

OK or NG

OK >> GO TO 7.

NG >> Replace malfunctioning component.

## 7. CHECK MAIN 12 CAUSES

If the cause cannot be isolated, go to [EC-1128, "Main 12 Causes of Overheating"](#).

>> **INSPECTION END**

## PROCEDURE A


### 1. CHECK COOLING FAN POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R harness connectors E14.
3. Check voltage between IPDM E/R terminal 22 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



### 2. DETECT MALFUNCTIONING PART

Check the following.

- 40A fusible link
- Harness for open or short between IPDM E/R and battery

>> Repair open circuit or short to ground in harness or connectors.

### 3. CHECK COOLING FAN MOTOR CIRCUIT FOR OPEN AND SHORT


1. Disconnect cooling fan motor (1) harness connector.
  - ↶: Vehicle front
  - Radiator shroud (upper) (2)
2. Check harness continuity between the following;
  - cooling fan motor terminal 1 and IPDM E/R terminal 20,
  - cooling fan motor terminal 2 and IPDM E/R terminal 24.
 Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.



### 4. CHECK COOLING FAN MOTOR GROUND CIRCUIT FOR OPEN OR SHORT

1. Check harness continuity between cooling fan motor terminal 3 and ground.
  - Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
- NG >> Repair open circuit or short to power in harness or connectors.

## 5. CHECK COOLING FAN MOTOR

Refer to [EC-1129, "Component Inspection"](#) .

**OK or NG**

- OK >> GO TO 6.
- NG >> Replace cooling fan motors.

## 6. CHECK INTERMITTENT INCIDENT

Perform [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

**OK or NG**

- OK >> Replace IPDM E/R. Refer to [PG-14, "IPDM E/R \(INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM\)"](#) .
- NG >> Repair or replace harness or connector.

## Main 12 Causes of Overheating

GBS0006A

Engine	Step	Inspection item	Equipment	Standard	Reference page
OFF	1	<ul style="list-style-type: none"> <li>● Blocked radiator</li> <li>● Blocked condenser</li> <li>● Blocked radiator grille</li> <li>● Blocked bumper</li> </ul>	● Visual	No blocking	—
	2	<ul style="list-style-type: none"> <li>● Coolant mixture</li> </ul>	● Coolant tester	50 - 50% coolant mixture	See <a href="#">MA-15, "Engine Coolant Mixture Ratio"</a> .
	3	<ul style="list-style-type: none"> <li>● Coolant level</li> </ul>	● Visual	Coolant up to MAX level in reservoir tank and radiator filler neck	See <a href="#">CO-37, "LEVEL CHECK"</a> .
	4	<ul style="list-style-type: none"> <li>● Reservoir tank cap</li> </ul>	● Pressure tester	See <a href="#">CO-42, "Checking Reservoir Tank Cap"</a> .	
ON*2	5	<ul style="list-style-type: none"> <li>● Coolant leaks</li> </ul>	● Visual	No leaks	See <a href="#">CO-37, "CHECKING RADIATOR SYSTEM FOR LEAKS"</a> .
ON*2	6	<ul style="list-style-type: none"> <li>● Thermostat</li> </ul>	● Touch the upper and lower radiator hoses	Both hoses should be hot	See <a href="#">CO-52, "THERMOSTAT AND WATER PIPING"</a> .
ON*1	7	<ul style="list-style-type: none"> <li>● Cooling fan</li> </ul>	● CONSULT-II	Operating	See trouble diagnosis for DTC P0217 ( <a href="#">EC-1120</a> ) .
ON*2	7	<ul style="list-style-type: none"> <li>● Cooling fan (Crankshaft driven)</li> </ul>	● Visual	Operating	See <a href="#">CO-48, "COOLING FAN"</a> .
OFF	8	<ul style="list-style-type: none"> <li>● Combustion gas leak</li> </ul>	● Color checker chemical tester 4 Gas analyzer	Negative	—
ON*3	9	<ul style="list-style-type: none"> <li>● Coolant temperature gauge</li> </ul>	● Visual	Gauge less than 3/4 when driving	—
		<ul style="list-style-type: none"> <li>● Coolant overflow to reservoir tank</li> </ul>	● Visual	No overflow during driving and idling	See <a href="#">CO-37, "Changing Engine Coolant"</a> .
OFF*4	10	<ul style="list-style-type: none"> <li>● Coolant return from reservoir tank to radiator</li> </ul>	● Visual	Should be initial level in reservoir tank	See <a href="#">CO-37, "LEVEL CHECK"</a> .
OFF	11	<ul style="list-style-type: none"> <li>● Cylinder head</li> </ul>	● Straight gauge feeler gauge	0.1 mm (0.004 in) Maximum distortion (warping)	See <a href="#">EM-236, "CYLINDER HEAD"</a> .
	12	<ul style="list-style-type: none"> <li>● Cylinder block and pistons</li> </ul>	● Visual	No scuffing on cylinder walls or piston	See <a href="#">EM-254, "CYLINDER BLOCK"</a> .

\*1: Turn the ignition switch ON.

\*2: Engine running at 3,000 rpm for 10 minutes.

\*3: Drive at 90 km/h (55 MPH) for 30 minutes and then let idle for 10 minutes.

\*4: After 60 minutes of cool down time.

For more information, refer to [CO-34, "OVERHEATING CAUSE ANALYSIS"](#) .

# DTC P0217 ENGINE OVER TEMPERATURE

[YD]

GBS0006B


## Component Inspection COOLING FAN MOTOR

1. Disconnect cooling fan motor harness connectors.
2. Supply cooling fan motor terminals with battery voltage and check operation.

Cooling fan speed	Cooling fan motor terminals	
	(+)	(-)
Low (LOW)	1	3
High (HI)	2	3

**Cooling fan motor should operate.**

If NG, replace cooling fan motor.



A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M


DTC P0222, P0223 APP SENSOR

PFP:18002

Description

GBS0006C

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensors detect the accelerator pedal position and sends a signal to the ECM. The ECM uses the signal to determine the amount of fuel to be injected.



CONSULT-II Reference Value in Data Monitor Mode

GBS0006D

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
ACCEL POS SEN*	● Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	0.65 - 0.87V
		Accelerator pedal: Fully depressed	More than 4.3V
ACCEL SEN 2*	● Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	0.28 - 0.48V
		Accelerator pedal: Fully depressed	More than 2.0V

\*: This signal is converted by ECM internally. Thus, it differs from ECM terminal voltage.

ECM Terminals and Reference Value

GBS0006E

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
82	W	Accelerator pedal position sensor 1 power supply	[Ignition switch ON]	Approximately 5.3V
83	R	Accelerator pedal position sensor 1	[Ignition switch ON] ● Engine: Stopped ● Accelerator pedal: Fully released	0.95 - 1.17V
			[Ignition switch ON] ● Engine: Stopped ● Accelerator pedal: Fully depressed	More than 4.6V
84	B	Accelerator pedal position sensor 1 ground	[Ignition switch ON]	Approximately 0.3V
85	—	Sensor ground (Accelerator pedal position sensor shield circuit)	[Ignition switch ON]	Approximately 0.3V
90	W	Accelerator pedal position sensor 2 power supply	[Ignition switch ON]	Approximately 5.3V



# DTC P0222, P0223 APP SENSOR

[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
91	R	Accelerator pedal position sensor 2	[Ignition switch ON] ● Engine: Stopped ● Accelerator pedal: Fully released	0.58 - 0.78V
			[Ignition switch ON] ● Engine: Stopped ● Accelerator pedal: Fully depressed	More than 2.3V
92	B	Accelerator pedal position sensor 2 ground	[Ignition switch ON]	Approximately 0.3V

## On Board Diagnosis Logic

GBS0006F

The MIL will not light up for these self-diagnoses.

### NOTE:

If DTC P0222 or P0223 is displayed with DTC P0652 or P0653, first perform the trouble diagnosis for DTC P0652 or P0653. Refer to [EC-1215, "DTC P0652, P0653 SENSOR POWER SUPPLY"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0222 0222	Accelerator pedal position sensor 2 circuit low input	An excessively low voltage from the APP sensor 2 is sent to ECM.	● Harness or connectors (The APP sensor 2 circuit is open or shorted.) ● Accelerator pedal position sensor (Accelerator pedal position sensor 2)
P0223 0223	Accelerator pedal position sensor 2 circuit high input	An excessively high voltage from the APP sensor 2 is sent to ECM.	

## DTC Confirmation Procedure

GBS0006G

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### ④ WITH CONSULT-II

- Turn ignition switch ON.
- Select "DATA MONITOR" mode with CONSULT-II.
- Wait at least 5 seconds.
- If DTC is detected, go to [EC-1133, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

### ⊗ WITHOUT CONSULT-II

- Turn ignition switch ON and wait at least 5 seconds.
- Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- If DTC is detected, go to [EC-1133, "Diagnostic Procedure"](#).




# DTC P0222, P0223 APP SENSOR

[YD]

GBS0006H

## Wiring Diagram

EC-APPS2-01




MBWA1043E

## Diagnostic Procedure

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body.  
Refer to [EC-1066](#), "Ground Inspection".



↙ : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
NG >> Repair or replace ground connections.

### 2. CHECK APP SENSOR 2 POWER SUPPLY CIRCUIT

1. Disconnect accelerator pedal position (APP) sensor (1) harness connector.
2. Turn ignition switch ON.




3. Check voltage between APP sensor terminal 1 and ground with CONSULT-II or tester.

**Voltage: Approximately 5.3V**

#### OK or NG

- OK >> GO TO 3.  
NG >> Repair open circuit or short to ground or short to power in harness or connectors.



### 3. CHECK APP SENSOR 2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between APP sensor terminal 5 and ECM terminal 92.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

### 4. CHECK APP SENSOR 2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 91 and APP sensor terminal 6.  
Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

### 5. CHECK APP SENSOR

Refer to [EC-1134, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace accelerator pedal assembly.

### 6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

#### Component Inspection ACCELERATOR PEDAL POSITION SENSOR

GBS0006J

1. Reconnect all harness connectors disconnected.
2. Turn ignition switch ON.
3. Check voltage between ECM terminals 83 (APP sensor 1 signal), 91 (APP sensor 2 signal) and ground under the following conditions.

Terminal	Accelerator pedal	Voltage
83 (Accelerator pedal position sensor 1)	Fully released	0.95 - 1.17V
	Fully depressed	More than 4.6V
91 (Accelerator pedal position sensor 2)	Fully released	0.58 - 0.78V
	Fully depressed	More than 2.3V



4. If NG, replace accelerator pedal assembly.

#### Removal and Installation ACCELERATOR PEDAL

GBS0006K

Refer to [ACC-2, "ACCELERATOR CONTROL SYSTEM"](#) .


DTC P0234 TC SYSTEM

PFP:14411

Description


GBS0006L

The load from the turbocharger boost control solenoid valve controls the actuator. By changing the variable nozzle vane opening through the rods, the intake air volume is adjusted.



The turbocharger boost control solenoid valve (1) is moved by ON/OFF pulse from the ECM. The longer the ON pulse, the charge air pressure rises.

- ↶ : Vehicle front
- Alternator (2)



ECM Terminals and Reference Value

GBS0006M

Specification data are reference values, and are measured between each terminal and ground. Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
6	BR	Turbocharger boost control solenoid valve	<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>• Warm-up condition</li> <li>• Idle speed</li> </ul>	<p>Approximately 6.3V ★</p> <p>MBIB0889E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>• Warm-up condition</li> <li>• Engine speed: 2,000 rpm</li> </ul>	<p>Approximately 8.6V ★</p> <p>MBIB0890E</p>

# DTC P0234 TC SYSTEM

[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
105 113	BR BR	ECM relay (self shut-off)	<b>[Ignition switch ON]</b> <b>[Ignition switch OFF]</b> <ul style="list-style-type: none"> <li>For a few seconds after turning ignition switch OFF</li> </ul>	Approximately 1.0V
			<b>[Ignition switch OFF]</b> <ul style="list-style-type: none"> <li>More than a few seconds after turning ignition switch OFF</li> </ul>	BATTERY VOLTAGE (11 - 14V)
119 120	R G	Power supply for ECM	<b>[Ignition switch ON]</b>	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## On Board Diagnosis Logic

GBS0006V

The MIL will not light up for this self-diagnosis.

### NOTE:

If DTC P0234 is displayed with DTC P0652 or P0653, first perform the trouble diagnosis for DTC P0652 or P0653. Refer to [EC-1215, "DTC P0652, P0653 SENSOR POWER SUPPLY"](#).


DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0234 0234	Turbocharger overboost condition	ECM detects turbocharger boost pressure is excessively high.	<ul style="list-style-type: none"> <li>Turbocharger</li> <li>Vacuum pump</li> <li>Turbocharger boost sensor</li> <li>Turbocharger boost control solenoid valve</li> </ul>

## Overall Function Check

GBS0006O

Use this procedure to check the overall function of the turbocharger. During this check, a DTC might not be confirmed.

- Start engine and let it idle.
- Make sure that turbocharger control actuator (1) rod moves slightly when engine is started.
- If NG, go to [EC-1138, "Diagnostic Procedure"](#).




# DTC P0234 TC SYSTEM

[YD]





## Wiring Diagram

GBS0006P

### EC-TCC/V-01



A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



MBWA1044E

## Diagnostic Procedure


### 1. CHECK VACUUM SOURCE

1. Turn ignition switch OFF.
2. Disconnect vacuum hose connected to turbocharger control actuator (1).
3. Start engine and let it idle.
4. Check vacuum hose for vacuum existence.

**Vacuum should exist.**

OK or NG

- OK >> GO TO 8.  
 NG >> GO TO 2.




### 2. CHECK VACUUM HOSES AND VACUUM GALLERY

1. Turn ignition switch OFF.
2. Check vacuum hoses and vacuum gallery for clogging, cracks or improper connection.  
 Refer to [EC-1005, "Vacuum Hose Drawing"](#).


OK or NG

- OK >> GO TO 3.  
 NG >> Repair or replace vacuum hoses and vacuum gallery.



### 3. CHECK TURBOCHARGER BOOST CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT

1. Disconnect turbocharger boost control solenoid valve (1) harness connector.
  - ◀ : Vehicle front
  - Alternator (2)
2. Turn ignition switch ON.




3. Check voltage between turbocharger boost control solenoid valve terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 5.  
 NG >> GO TO 4.





## 4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E9, F4
- Harness for open or short between IPDM E/R and turbocharger boost control solenoid valve
- Harness for open or short between ECM and turbocharger boost control solenoid valve

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 5. CHECK TURBOCHARGER BOOST CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminals 6 and turbocharger boost control solenoid valve terminal 2.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 6.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 6. CHECK TURBOCHARGE BOOST CONTROL SOLENOID VALVE

Refer to [EC-1140, "Component Inspection"](#) .

OK or NG

OK >> GO TO 7.

NG >> Replace turbocharger boost control solenoid valve.

## 7. CHECK VACUUM PUMP

Refer to [EM-186, "VACUUM PUMP"](#) .

OK or NG

OK >> GO TO 8.

NG >> Replace vacuum pump assembly.


## 8. CHECK TURBOCHARGER BOOST CONTROL ACTUATOR

1. Turn ignition switch OFF.
2. Install a vacuum pump A to turbocharger boost control actuator (1).
3. Make sure that the turbocharger boost control actuator rod moves smoothly when applying vacuum of -53.3kPa (-533mbar, -400mmHg, -15.75inHg) and releasing it.

OK or NG

OK >> GO TO 9.

NG >> Replace turbocharger assembly.



**9. CHECK TURBOCHARGER BOOST SENSOR**

Refer to [EC-1146, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 10.
- NG >> Replace turbocharger boost sensor.

**10. CHECK INTERMITTENT INCIDENT**


Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

**Component Inspection  
TURBOCHARGER BOOST CONTROL SOLENOID VALVE**

GBS0006R

1. Disconnect turbocharger boost control solenoid valve (1) harness connector.
  - ↶ : Vehicle front
  - Alternator (2)




2. Apply 12V direct current between turbocharger boost control solenoid valve terminals.
3. Check air passage continuity of turbocharger boost control solenoid valve under the following conditions.

CONDITIONS	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12V direct current supply between terminals (1) and (2)	Yes	No
No supply	No	Yes

Operation takes less than 1 second.

If NG, replace turbocharger boost control solenoid valve.



**Removal and Installation  
TURBOCHARGER BOOST CONTROL SOLENOID VALVE**

GBS0006S

Refer to [EM-162, "CHARGE AIR COOLER"](#) .

# DTC P0237, P0238 TC BOOST SENSOR

[YD]



## DTC P0237, P0238 TC BOOST SENSOR

PFP:22365

### Component Description

GBS0006T

The turbocharger boost sensor detects pressure in the exit side of the charge air cooler. The sensor output voltage to the ECM increases as pressure increases.



### CONSULT-II Reference Value in Data Monitor Mode

GBS0006U

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
INT/M PRES SE [kPa]	<ul style="list-style-type: none"> <li>Engine: After warming up</li> <li>Air conditioner switch: OFF</li> <li>Shift lever: P or N (A/T), Neutral (M/T)</li> <li>No load</li> </ul>	Idle
		3,600 rpm
		4,000 rpm
		Approx. 100.00 kPa
		Approx. 140.00 kPa
		Approx. 135.00 kPa

### ECM Terminals and Reference Value

GBS0006V

Specification data are reference values, and are measured between each terminal and ground.

#### CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
52	BR	Turbocharger boost sensor	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>Warm-up condition</li> <li>Idle speed</li> </ul>	2.1 - 2.4V
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>Warm-up condition</li> <li>Engine speed: 2,000 rpm</li> </ul>	2.3 - 2.6V
64	V	Turbocharger boost sensor power supply	<b>[Ignition switch ON]</b>	Approximately 5.3V
71	L	Turbocharger boost sensor ground	<b>[Ignition switch ON]</b>	Approximately 0.3V

# DTC P0237, P0238 TC BOOST SENSOR

[YD]

GBS0006W

## On Board Diagnosis Logic

The MIL will not light up for these self-diagnoses.

### NOTE:

If DTC P0237 or P0238 is displayed with DTC P0652 or P0653, first perform the trouble diagnosis for DTC P0652 or P0653. Refer to [EC-1215, "DTC P0652, P0653 SENSOR POWER SUPPLY"](#) .

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0237 0237	Turbocharger boost sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	● Harness or connectors (The sensor circuit is open or shorted.) ● Turbocharger boost sensor
P0238 0238	Turbocharger boost sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

## DTC Confirmation Procedure


GBS0006X

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### ④ WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-1144, "Diagnostic Procedure"](#) .



DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

### ⊗ WITHOUT CONSULT-II

1. Turn ignition switch ON and wait at least 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-1144, "Diagnostic Procedure"](#) .

# DTC P0237, P0238 TC BOOST SENSOR






[YD]

## Wiring Diagram

GBS0006Y

### EC-BOOST-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC




MBWA1045E

## Diagnostic Procedure

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body.  
Refer to [EC-1066, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
NG >> Repair or replace ground connections.

### 2. CHECK TURBOCHARGER BOOST SENSOR POWER SUPPLY CIRCUIT

1. Disconnect turbocharge boost sensor (1) harness connector.
2. Turn ignition switch ON.




3. Check voltage between turbocharge boost sensor terminal 3 and ground with CONSULT-II or tester.

**Voltage: Approximately 5.3V**

#### OK or NG

- OK >> GO TO 3.  
NG >> Repair open circuit or short to ground or short to power in harness or connectors.



---

**3. CHECK TURBOCHARGER BOOST SENSOR GROUND CIRCUIT FOR OPEN AND SHORT**

---

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between turbocharger boost sensor terminal 1 and ECM terminal 71. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

---

**4. CHECK TURBOCHARGER BOOST SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

---

1. Check harness continuity between ECM terminal 52 and turbocharger boost sensor terminal 2. Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness connectors.

---

**5. CHECK TURBOCHARGER BOOST SENSOR**

---

Refer to [EC-1146, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace turbocharger boost sensor.

---

**6. CHECK INTERMITTENT INCIDENT**

---

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

**>> INSPECTION END**


## Component Inspection CHECK TURBOCHARGER BOOST SENSOR

1. Remove turbocharger boost sensor with its harness connected.
2. Turn ignition switch ON.
3. Use pump to apply pressure sensor as shown in the figure.

**CAUTION:**

- Always calibrate the pressure pump gauge when using it.
  - Inspection should be done at room temperature [10-30°C (50-86°F)].
4. Check the output voltage between ECM terminal 52 and ground under the following conditions.

Pressure (Relative to atmospheric pressure)	Voltage V
0 kPa (0 mbar, 0 mmHg, 0 inHg)	Approximately 2.3V
+40 kPa (400 mbar, 300mmHg, 11.81 inHg)	Approximately 2.9V



MBIB1093E

## Removal and Installation TURBOCHARGER BOOST SENSOR

Refer to [EM-162. "CHARGE AIR COOLER"](#) .



## DTC P0335 CKP SENSOR

PFP:23731


### Description

GBS00072

The crankshaft position (CKP) sensor is located on the cylinder block rear housing facing the gear teeth (cogs) of the signal plate at the end of the crankshaft. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet and Hall IC.

When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change. The changing gap causes the magnetic field near the sensor to change. Due to the changing magnetic field, the voltage from the sensor changes. The ECM receives the voltage signal and detects the fluctuation of the engine revolution.



### CONSULT-II Reference Value in Data Monitor Mode

GBS00073

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
CKPS-RPM (TDC)	<ul style="list-style-type: none"> <li>Run engine and compare CONSULT-II value with the tachometer indication.</li> </ul>	Almost the same speed as the tachometer indication



### ECM Terminals and Reference Value

GBS00074

Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
44	W	Crankshaft position sensor power supply	[Ignition switch ON]	Approximately 5.3V
46	R	Crankshaft position sensor	[Engine is running] <ul style="list-style-type: none"> <li>Warm-up condition</li> <li>Idle speed</li> </ul> <b>NOTE:</b> The pulse cycle changes depending on rpm at idle	Approximately 3.7V ★  MBIB0879E
			[Engine is running] <ul style="list-style-type: none"> <li>Warm-up condition</li> <li>Engine speed: 2,000 rpm</li> </ul>	Approximately 3.7V ★  MBIB0880E
65	B	Crankshaft position sensor ground	[Ignition switch ON]	Approximately 0.3V
67	—	Sensor ground (Sensor shield circuit)	[Ignition switch ON]	Approximately 0.3V

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## On Board Diagnosis Logic

**NOTE:**

If DTC P0335 is displayed with DTC P0652 or P0653, first perform the trouble diagnosis for DTC P0652 or P0653. Refer to [EC-1215, "DTC P0652, P0653 SENSOR POWER SUPPLY"](#) .

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0335 0335	Crankshaft position sensor circuit	Crankshaft position sensor signal is not detect by the ECM when engine is running.	<ul style="list-style-type: none"> <li>● Harness or connectors (The sensor circuit is open or shorted.)</li> <li>● Crankshaft position sensor</li> </ul>


## DTC Confirmation Procedure

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**④ WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for at least 5 seconds.  
If engine can not start, keep ignition switch at START position for 5 seconds.
4. If DTC is detected, go to [EC-1150, "Diagnostic Procedure"](#) .



**⊗ WITHOUT CONSULT-II**

1. Start engine and let it idle for at least 5 seconds.  
If engine can not start, keep ignition switch at START position for 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-1150, "Diagnostic Procedure"](#) .

# DTC P0335 CKP SENSOR



[YD]

## Wiring Diagram

GBS00077

EC-CKPS-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



(F1) B




(3 2 1) (F35) B

## Diagnostic Procedure

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body.  
Refer to [EC-1066](#), "Ground Inspection".



↔ : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
NG >> Repair or replace ground connections.

### 2. CHECK CKP SENSOR POWER SUPPLY CIRCUIT

1. Disconnect crankshaft position sensor (1) harness connector.
  - Illustration shows the view from under the vehicle
  - ↔: Vehicle front
  - Starter motor (2)
2. Turn ignition switch ON.




3. Check voltage between CKP sensor terminal 3 and ground with CONSULT-II or tester.

**Voltage: Approximately 5.3V**

#### OK or NG

- OK >> GO TO 3.  
NG >> Repair open circuit or short to ground or short to power in harness or connectors.



---

### 3. CHECK CKP SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

---

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 65 and CKP sensor terminal 2.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for and short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

---

### 4. CHECK CKP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

1. Check harness continuity between ECM terminal 46 and CKP sensor terminal 1.  
Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

---

### 5. CHECK CRANKSHAFT POSITION SENSOR

---

Refer to [EC-1152, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace crankshaft position sensor.

---

### 6. CHECK INTERMITTENT INCIDENT


---

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

## Component Inspection CRANKSHAFT POSITION SENSOR


1. Loosen the fixing bolt of the sensor.
2. Disconnect crankshaft position sensor harness connector.
3. Remove the sensor.
4. Visually check the sensor for chipping.



5. Check resistance as shown in the figure.

Terminal No. (Polarity)	Resistance $\Omega$ [at 25°C (77°F)]
1 (+) - 2 (-)	Except 0 or $\infty$
3 (+) - 1 (-)	
3 (+) - 2 (-)	

6. If NG, replace crankshaft position sensor.



## Removal and Installation CRANKSHAFT POSITION SENSOR

Refer to [EM-180, "OIL PAN AND OIL STRAINER"](#) .

DTC P0336 CKP SENSOR

PFP:23731


Description

GBS0007B

The crankshaft position (CKP) sensor is located on the cylinder block rear housing facing the gear teeth (cogs) of the signal plate at the end of the crankshaft. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet and Hall IC.

When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change. The changing gap causes the magnetic field near the sensor to change. Due to the changing magnetic field, the voltage from the sensor changes. The ECM receives the voltage signal and detects the fluctuation of the engine revolution.



CONSULT-II Reference Value in Data Monitor Mode

GBS0007C

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
CKPS-RPM (TDC)	<ul style="list-style-type: none"> <li>Run engine and compare CONSULT-II value with the tachometer indication.</li> </ul>	Almost the same speed as the tachometer indication.

ECM Terminals and Reference Value

GBS0007D

Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
44	W	Crankshaft position sensor power supply	[Ignition switch ON]	Approximately 5.3V
46	R	Crankshaft position sensor	[Engine is running] <ul style="list-style-type: none"> <li>Warm-up condition</li> <li>Idle speed</li> </ul> <b>NOTE:</b> The pulse cycle changes depending on rpm at idle	Approximately 3.7V ★ MBIB0879E
			[Engine is running] <ul style="list-style-type: none"> <li>Warm-up condition</li> <li>Engine speed: 2,000 rpm</li> </ul>	Approximately 3.7V ★ MBIB0880E
65	B	Crankshaft position sensor ground	[Ignition switch ON]	Approximately 0.3V
67	—	Sensor ground (Sensor shield circuit)	[Ignition switch ON]	Approximately 0.3V

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## On Board Diagnosis Logic

**NOTE:**

If DTC P0336 is displayed with DTC P0652 or P0653, first perform the trouble diagnosis for DTC P0652 or P0653. Refer to [EC-1215, "DTC P0652, P0653 SENSOR POWER SUPPLY"](#) .

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0336 0336	Crankshaft position sensor circuit range/performance	Crankshaft position sensor signal is not in the normal pattern when engine is running.	<ul style="list-style-type: none"> <li>● Harness or connectors (The sensor circuit is open or shorted.)</li> <li>● Crankshaft position sensor</li> <li>● Signal plate</li> </ul>

## DTC Confirmation Procedure

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for at least 5 seconds.  
If engine can not start, keep ignition switch at START position for 5 seconds.
4. If DTC is detected, go to [EC-1156, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

**WITHOUT CONSULT-II**

1. Start engine and let it idle for at least 5 seconds.  
If engine can not start, keep ignition switch at START position for 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-1156, "Diagnostic Procedure"](#) .



# DTC P0336 CKP SENSOR




[YD]

## Wiring Diagram

GBS0007G

EC-CKPS-01


: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



## Diagnostic Procedure

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body.  
Refer to [EC-1066](#), "Ground Inspection".



↔ : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
NG >> Repair or replace ground connections.

### 2. CHECK CKP SENSOR POWER SUPPLY CIRCUIT

1. Disconnect crankshaft position sensor (1) harness connector.
  - Illustration shows the view from under the vehicle
  - ↔: Vehicle front
  - Starter motor (2)
2. Turn ignition switch ON.




3. Check voltage between CKP sensor terminal 3 and ground with CONSULT-II or tester.

**Voltage: Approximately 5.3V**

4. Also check harness for short to ground and short to power.

#### OK or NG

- OK >> GO TO 3.  
NG >> Repair open circuit or short to ground or short to power in harness or connectors.



---

### 3. CHECK CKP SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

---

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 65 and CKP sensor terminal 2.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for and short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

---

### 4. CHECK CKP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

1. Check harness continuity between ECM terminal 46 and CKP sensor terminal 1.  
Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

---

### 5. CHECK CRANKSHAFT POSITION SENSOR

---

Refer to [EC-1158, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace crankshaft position sensor.

---

### 6. CHECK GEAR TOOTH

---

Visually check for chipping signal plate gear tooth.

OK or NG

OK >> GO TO 7.

NG >> Replace the signal plate.

---

### 7. CHECK INTERMITTENT INCIDENT


---

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

**>> INSPECTION END**

## Component Inspection CRANKSHAFT POSITION SENSOR

1. Loosen the fixing bolt of the sensor.
2. Disconnect crankshaft position sensor harness connector.
3. Remove the sensor.
4. Visually check the sensor for chipping.




MBIB0647E

5. Check resistance as shown in the figure.

Terminal No. (Polarity)	Resistance $\Omega$ [at 25°C (77°F)]
1 (+) - 2 (-)	Except 0 or $\infty$
3 (+) - 1 (-)	
3 (+) - 2 (-)	

6. If NG, replace crankshaft position sensor.



MBIB1385E

## Removal and Installation CRANKSHAFT POSITION SENSOR

Refer to [EM-180, "OIL PAN AND OIL STRAINER"](#) .

## DTC P0340 CMP SENSOR

PFP:23731

### Description

GBS0007K

The camshaft position (CMP) sensor senses the retraction with camshaft (left side) to identify a particular cylinder. The camshaft position (CMP) sensor senses the piston position.


When the crankshaft position (CKP) sensor system becomes inoperative, the camshaft position (CMP) sensor provides various controls of engine parts instead, utilizing timing of cylinder identification signals.

The sensor consists of a permanent magnet and Hall IC.

When engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.



### ECM Terminals and Reference Value

GBS0007L

Specification data are reference values and are measured between each terminal and ground.

Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
45	W	Camshaft position sensor power supply	[Ignition switch ON]	Approximately 5.3V
47	R	Camshaft position sensor	[Engine is running] <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <b>NOTE:</b> The pulse cycle changes depending on rpm at idle	Approximately 4.9V ★ <p style="text-align: right; font-size: small;">MBIB0877E</p>
			[Engine is running] <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	Approximately 4.9V ★ <p style="text-align: right; font-size: small;">MBIB0878E</p>
66	B	Camshaft position sensor ground	[Ignition switch ON]	Approximately 0.3V
67	—	Sensor ground (Sensor shield circuit)	[Ignition switch ON]	Approximately 0.3V

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# DTC P0340 CMP SENSOR

[YD]

GBS0007M

## On Board Diagnosis Logic

### NOTE:

If DTC P0340 is displayed with DTC P0652 or P0653, first perform the trouble diagnosis for DTC P0652 or P0653. Refer to [EC-1215, "DTC P0652, P0653 SENSOR POWER SUPPLY"](#) .

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0340 0340	Camshaft position sensor circuit	Camshaft position sensor signal is not detect by the ECM when engine is running.	<ul style="list-style-type: none"><li>● Harness or connectors (The sensor circuit is open or shorted.)</li><li>● Camshaft position sensor</li></ul>

## DTC Confirmation Procedure

GBS0007N

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### ④ WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for at least 5 seconds.  
If engine can not start, keep ignition switch at START position for 5 seconds.
4. If DTC is detected, go to [EC-1162, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

#### ⊗ WITHOUT CONSULT-II

1. Start engine and let it idle for at least 5 seconds.  
If engine can not start, keep ignition switch at START position for 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-1162, "Diagnostic Procedure"](#) .

# DTC P0340 CMP SENSOR




[YD]

## Wiring Diagram

GBS00070

EC-CMPS-01


: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



## Diagnostic Procedure

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body.  
Refer to [EC-1066, "Ground Inspection"](#).



↔ : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
NG >> Repair or replace ground connections.

### 2. CHECK CMP SENSOR POWER SUPPLY CIRCUIT

1. Disconnect camshaft position (CMP) sensor (1) harness connector.  
- ↔: Vehicle front
2. Turn ignition switch ON.




3. Check voltage between CMP sensor terminal 3 and ground with CONSULT-II or tester.

**Voltage: Approximately 5.3V**

#### OK or NG

- OK >> GO TO 3.  
NG >> Repair open circuit or short to ground or short to power in harness or connectors.





### 3. CHECK CMP SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 66 and CMP sensor terminal 2.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

### 4. CHECK CMP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 47 and CMP sensor terminal 1.  
Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

### 5. CHECK CAMSHAFT POSITION SENSOR

Refer to [EC-1163, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace camshaft position sensor.

### 6. CHECK INTERMITTENT INCIDENT


Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

#### Component Inspection CAMSHAFT POSITION SENSOR

GBS0007Q

1. Loosen the fixing bolt of the sensor.
2. Disconnect camshaft position sensor harness connector.
3. Remove the sensor.
4. Visually check the sensor for chipping.




# DTC P0340 CMP SENSOR

[YD]

5. Check resistance as shown in the figure.

Terminal No. (Polarity)	Resistance $\Omega$ [at 25°C (77°F)]
1 (+) - 2 (-)	Except 0 or $\infty$
3 (+) - 1 (-)	
3 (+) - 2 (-)	

6. If NG, replace camshaft position sensor.



## Removal and Installation CAMSHAFT POSITION SENSOR

Refer to [EM-203, "CAMSHAFT"](#) .

GBS0007R

DTC P0341 CMP SENSOR

PFP:23731

Description

GBS0007S

The camshaft position (CMP) sensor senses the retraction with camshaft (left side) to identify a particular cylinder. The camshaft position (CMP) sensor senses the piston position.


When the crankshaft position (CKP) sensor system becomes inoperative, the camshaft position (CMP) sensor provides various controls of engine parts instead, utilizing timing of cylinder identification signals.

The sensor consists of a permanent magnet and Hall IC.

When engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.



ECM Terminals and Reference Value

GBS0007T

Specification data are reference values and are measured between each terminal and ground.

Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
45	W	Camshaft position sensor power supply	[Ignition switch ON]	Approximately 5.3V
47	R	Camshaft position sensor	[Engine is running] ● Warm-up condition ● Idle speed <b>NOTE:</b> The pulse cycle changes depending on rpm at idle	Approximately 4.9V ★  MBIB0877E
			[Engine is running] ● Warm-up condition ● Engine speed: 2,000 rpm	Approximately 4.9V ★  MBIB0878E
66	B	Camshaft position sensor ground	[Ignition switch ON]	Approximately 0.3V
67	—	Sensor ground (Sensor shield circuit)	[Ignition switch ON]	Approximately 0.3V

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# DTC P0341 CMP SENSOR

[YD]

GBS0007U

## On Board Diagnosis Logic

### NOTE:

If DTC P0341 is displayed with DTC P0652 or P0653, first perform the trouble diagnosis for DTC P0652 or P0653. Refer to [EC-1215, "DTC P0652, P0653 SENSOR POWER SUPPLY"](#) .

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0341 0341	Camshaft position sensor circuit range/performance	Camshaft position sensor signal is not in the normal pattern when engine is running.	<ul style="list-style-type: none"> <li>● Harness connectors (The sensor circuit is opener shorted.)</li> <li>● Camshaft position sensor</li> <li>● Starter motor</li> <li>● Starting system circuit</li> <li>● Signal plate</li> </ul>

## DTC Confirmation Procedure

GBS0007V

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for at least 5 seconds.  
If engine can not start, keep ignition switch at START position for 5 seconds.
4. If DTC is detected, go to [EC-1168, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

#### WITHOUT CONSULT-II

1. Start engine and let it idle for at least 5 seconds.  
If engine can not start, keep ignition switch at START position for 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-1168, "Diagnostic Procedure"](#) .



# DTC P0341 CMP SENSOR




[YD]

## Wiring Diagram

GBS0007W

EC-CMPS-01

 : DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



**Diagnostic Procedure****1. CHECK STARTING SYSTEM**

Turn ignition switch to START position.

**Does the starter motor operate?**

**Does the engine turn over?**


Yes or No

Yes >> GO TO 2.

No >> Check starting system. (Refer to [SC-30, "STARTING SYSTEM"](#) .)

**2. CHECK GROUND CONNECTIONS**

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body.  
Refer to [EC-1066, "Ground Inspection"](#) .



← : Vehicle front

1. Body ground E21

2. ECM

3. Body ground E41

4. A/C high-pressure service valve

5. ABS actuator and electric unit  
(control unit)

6. Body ground E61


OK or NG

OK >> GO TO 3.

NG >> Repair or replace ground connections.

### 3. CHECK CMP SENSOR POWER SUPPLY CIRCUIT

1. Disconnect camshaft position (CMP) sensor (1) harness connector.
  - ⇐: Vehicle front
2. Turn ignition switch ON.




3. Check voltage between CMP sensor terminal 3 and ground with CONSULT-II or tester.

**Voltage: Approximately 5.3V**

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



### 4. CHECK CMP SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 66 and CMP sensor terminal 2.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

### 5. CHECK CMP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 47 and CMP sensor terminal 1. Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 6.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

### 6. CHECK CAMSHAFT POSITION SENSOR

Refer to [EC-1170, "Component Inspection"](#).

OK or NG

OK >> GO TO 7.

NG >> Replace camshaft position sensor.

**7. CHECK CAMSHAFT (LEFT SIDE)**


Check the following.

- Accumulation of debris to the signal plate of camshaft (left side) (1) rear end
- Chipping signal plate of camshaft (left side) rear end

OK or NG

OK >> GO TO 8.

NG >> Remove debris and clean the signal plate of camshaft (left side) rear end or replace signal plate.



**8. CHECK INTERMITTENT INCIDENT**


Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

**Component Inspection  
CAMSHAFT POSITION SENSOR**

GBS0007Y


1. Loosen the fixing bolt of the sensor.
2. Disconnect camshaft position sensor harness connector.
3. Remove the sensor.
4. Visually check the sensor for chipping.



5. Check resistance as shown in the figure.

Terminal No. (Polarity)	Resistance $\Omega$ [at 25°C (77°F)]
1 (+) - 2 (-)	Except 0 or $\infty$
3 (+) - 1 (-)	
3 (+) - 2 (-)	

6. If NG, replace camshaft position sensor.



GBS0007Z

**Removal and Installation  
CAMSHAFT POSITION SENSOR**

Refer to [EM-203, "CAMSHAFT"](#) .



# DTC P0501 ASCD VEHICLE SPEED SENSOR

[YD]

## DTC P0501 ASCD VEHICLE SPEED SENSOR

PFP:24810

### Component Description

GBS00080

The ECM receives vehicle speed sensor signal via CAN communication line. It is sent from combination meter. The ECM uses this signal for ASCD control. Refer to [EC-1337, "AUTOMATIC SPEED CONTROL DEVICE \(ASCD\)"](#) for ASCD functions.

### On Board Diagnosis Logic

GBS00081

The MIL will not light up for this self-diagnosis.

#### NOTE:

- If DTC P0501 is displayed with DTC U1000 first perform the trouble diagnosis for DTC U1000. Refer to [EC-1067, "DTC U1000 CAN COMMUNICATION LINE"](#).
- If DTC P0501 is displayed with DTC P0606, first perform the trouble diagnosis for DTC P0606. Refer to [EC-1203, "DTC P0606 ECM"](#).

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P0501 0501	Vehicle speed sensor range/performance	A change of vehicle speed signal is excessively large during specified time.	<ul style="list-style-type: none"><li>● Harness or connectors (The CAN communication line is open or shorted.)</li><li>● Combination meter</li><li>● ABS actuator and electric unit (control unit)</li><li>● Wheel sensor</li><li>● ECM</li></ul>

### DTC Confirmation Procedure

GBS00082

#### CAUTION:

Always drive vehicle at a safe speed.

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### TESTING CONDITION:

Step 3 may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

#### ④ WITH CONSULT-II

1. Start engine.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Drive the vehicle at more than 10 km/h (6 MPH) for at least 5 seconds.
4. If DTC is detected, go to [EC-1172, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm
VHCL SPEED SE	XXX km/h

MBIB1085E

---

**⊗ WITHOUT CONSULT-II**

**TESTING CONDITION:**

Step 2 may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

1. Start engine.
2. Drive the vehicle at more than 10 km/h (6 MPH).
3. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
4. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
5. If DTC is detected, go to [EC-1172, "Diagnostic Procedure"](#) .

**Diagnostic Procedure**

GBS00083

**1. CHECK DTC WITH ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)**

---

Refer to [BRC-8, "TROUBLE DIAGNOSIS"](#) .

OK or NG

- OK >> GO TO 2.
- NG >> Repair or replace.

**2. CHECK COMBINATION METER**

---

Check combination meter function.

Refer to [DI-4, "COMBINATION METERS"](#) .

>> **INSPECTION END**

# DTC P0502 ASCD VEHICLE SPEED SENSOR

[YD]

## DTC P0502 ASCD VEHICLE SPEED SENSOR

PFP:24810

### Component Description

GBS00084

The ECM receives vehicle speed sensor signal via CAN communication line. It is sent from combination meter. The ECM uses this signal for ASCD control. Refer to [EC-1337, "AUTOMATIC SPEED CONTROL DEVICE \(ASCD\)"](#) for ASCD functions.

### On Board Diagnosis Logic

GBS00085

The MIL will not light up for this self-diagnosis.

#### NOTE:

- If DTC P0502 is displayed with DTC U1000 first perform the trouble diagnosis for DTC U1000. Refer to [EC-1067, "DTC U1000 CAN COMMUNICATION LINE"](#).
- If DTC P0502 is displayed with DTC P0606, first perform the trouble diagnosis for DTC P0606. Refer to [EC-1203, "DTC P0606 ECM"](#).

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P0502 0502	Vehicle speed sensor circuit low input	Vehicle speed signal is excessively low compared with the driving condition.	<ul style="list-style-type: none"><li>● Harness or connectors (The CAN communication line is open or shorted.)</li><li>● Combination meter</li><li>● ABS actuator and electric unit (control unit)</li><li>● Wheel sensor</li><li>● ECM</li></ul>

### DTC Confirmation Procedure

GBS00086

#### CAUTION:

Always drive vehicle at a safe speed.

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### TESTING CONDITION:

Step 3 may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

#### ④ WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Maintain the following condition for at least 5 seconds.

CKPS-RPM (TDC)	More than 2,800 rpm
COOLAN TEMP/S	More than 60°C (140 °F)
Clutch pedal (M/T)	Released
Shift lever	1st position

4. If DTC is detected, go to [EC-1174, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h

MBIB1084E

**⊗ WITHOUT CONSULT-II****TESTING CONDITION:**

**Step 2 may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.**

1. Start engine and warm it up to normal operating temperature.
2. Maintain the following condition for at least 5 seconds.

Engine speed	More than 2,800 rpm
Clutch pedal (M/T)	Released
Shift lever	1st position

3. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
4. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
5. If DTC is detected, go to [EC-1176, "Diagnostic Procedure"](#) .

**Diagnostic Procedure**

GBS00087

**1. CHECK DTC WITH ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)**

Refer to [BRC-8, "TROUBLE DIAGNOSIS"](#) .

OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace.

**2. CHECK COMBINATION METER**

Check combination meter function.

Refer to [DI-4, "COMBINATION METERS"](#) .

>> **INSPECTION END**

# DTC P0503 ASCD VEHICLE SPEED SENSOR

[YD]

## DTC P0503 ASCD VEHICLE SPEED SENSOR

PFP:24810

### Component Description

GBS00088

The ECM receives vehicle speed sensor signal via CAN communication line. It is sent from combination meter. The ECM uses this signal for ASCD control. Refer to [EC-1337, "AUTOMATIC SPEED CONTROL DEVICE \(ASCD\)"](#) for ASCD functions.

### On Board Diagnosis Logic

GBS00089

The MIL will not light up for this self-diagnosis.

#### NOTE:

- If DTC P0503 is displayed with DTC U1000 first perform the trouble diagnosis for DTC U1000. Refer to [EC-1067, "DTC U1000 CAN COMMUNICATION LINE"](#).
- If DTC P0503 is displayed with DTC P0606, first perform the trouble diagnosis for DTC P0606. Refer to [EC-1203, "DTC P0606 ECM"](#).

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P0503 0503	Vehicle speed sensor circuit high input	Vehicle speed signal is excessively high compared with the driving condition.	<ul style="list-style-type: none"><li>● Harness or connectors (The CAN communication line is open or shorted.)</li><li>● Combination meter</li><li>● ABS actuator and electric unit (control unit)</li><li>● Wheel sensor</li><li>● ECM</li></ul>

### DTC Confirmation Procedure

GBS0008A

#### CAUTION:

Always drive vehicle at a safe speed.

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### TESTING CONDITION:

Step 3 may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

#### ④ WITH CONSULT-II

1. Start engine.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Drive the vehicle at more than 10 km/h (6 MPH) for at least 5 seconds.
4. If DTC is detected, go to [EC-1176, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm
VHCL SPEED SE	XXX km/h

MBIB1085E

---

⊗ **WITHOUT CONSULT-II**

**TESTING CONDITION:**

Step 2 may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

1. Start engine.
2. Drive the vehicle at more than 10 km/h (6 MPH).
3. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
4. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
5. If DTC is detected, go to [EC-1176, "Diagnostic Procedure"](#) .

**Diagnostic Procedure**

GBS0008B

**1. CHECK DTC WITH ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)**

---

Refer to [BRC-8, "TROUBLE DIAGNOSIS"](#) .

OK or NG

- OK >> GO TO 2.
- NG >> Repair or replace.

**2. CHECK COMBINATION METER**

---

Check combination meter function.

Refer to [DI-4, "COMBINATION METERS"](#) .

>> **INSPECTION END**

# DTC P0504 ASCD BRAKE SWITCH

[YD]

## DTC P0504 ASCD BRAKE SWITCH


PFP:25320

### Component Description

GBS0008C

When the brake pedal is depressed, ASCD brake switch (1) and stop lamp switch (2) are turned ON. ECM detects the state of the brake pedal by this input of two kinds (ON/OFF signal).

Refer to [EC-1337, "AUTOMATIC SPEED CONTROL DEVICE \(ASCD\)"](#) for the ASCD function.



### CONSULT-II Reference Value in Data Monitor Mode

GBS0008D

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
BRAKE SW (Stop lamp switch)	● Ignition switch: ON	Brake pedal: Fully released	OFF
		Brake pedal: Slightly depressed	ON
BRAKE SW2 (ASCD brake switch)	● Ignition switch: ON	● Brake pedal: Fully released (A/T) ● Clutch pedal and brake pedal: Fully released (M/T)	OFF
		● Brake pedal: Slightly depressed (A/T) ● Clutch pedal and/or brake pedal: Slightly depressed (M/T)	ON

### ECM Terminals and Reference Value

GBS0008E

Specification data are reference values and are measured between each terminal and ground.

#### CAUTION:

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
100	V	Stop lamp switch	<b>[Ignition switch OFF]</b> ● Brake pedal fully released	Approximately 0V
			<b>[Ignition switch OFF]</b> ● Brake pedal: Slightly depressed	BATTERY VOLTAGE (11 - 14V)
101	W	ASCD brake switch	<b>[Ignition switch ON]</b> ● Brake pedal: Fully released (A/T) ● Clutch pedal and brake pedal: Fully released (M/T)	BATTERY VOLTAGE (11 - 14V)
			<b>[Ignition switch ON]</b> ● Brake pedal: Slightly depressed (A/T) ● Clutch pedal and/or brake pedal: Slightly depressed (M/T)	Approximately 0V

# DTC P0504 ASCD BRAKE SWITCH

[YD]

GBS0008F

## On Board Diagnosis Logic

The MIL will not light up for this diagnosis.

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P0504 0504	ASCD brake switch	<ul style="list-style-type: none"> <li>When the vehicle speed is above 5 km/h (3 MPH), ON signal from the stop lamp switch and OFF signal from the ASCD brake switch are sent to the ECM at the same time.</li> </ul>	<ul style="list-style-type: none"> <li>Harness or connectors (The stop lamp switch circuit is open or shorted.)</li> <li>Harness or connectors (The ASCD brake switch circuit is open or shorted.)</li> <li>Harness or connectors (The ASCD clutch switch circuit is open or shorted.) (M/T)</li> <li>Stop lamp switch</li> <li>ASCD brake switch</li> <li>ASCD clutch switch (M/T)</li> <li>Incorrect stop lamp switch installation</li> <li>Incorrect ASCD brake switch installation</li> <li>Incorrect ASCD clutch switch installation (M/T)</li> <li>ECM</li> </ul>

## DTC confirmation Procedure

GBS0008G

### CAUTION:

Always drive vehicle at a safe speed.

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### TESTING CONDITION:

Steps 3 and 4 may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

### WITH CONSULT-II

- Start engine.
- Select "DATA MONITOR" mode with CONSULT-II.
- Press MAIN switch and make sure that CRUISE indicator lights up.
- Drive the vehicle for at least 5 consecutive seconds under the following condition.

VHCL SPEED SE	More than 5 km/h (3 MPH)
Selector lever	Suitable position

If DTC is detected, go to [EC-1181, "Diagnostic Procedure"](#).  
If DTC is not detected, go to the following step.

- Drive the vehicle for at least 5 consecutive seconds under the following condition.

VHCL SPEED SE	More than 5 km/h (3 MPH)
Selector lever	Suitable position
Driving location	Depress the brake pedal for more than five seconds so as not to come off from the above-mentioned condition.

- If DTC is detected, go to [EC-1181, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm
VHCL SPEED SE	XXX km/h

MBIB1085E



# DTC P0504 ASCD BRAKE SWITCH

[YD]

## ⊗ WITHOUT CONSULT-II

1. Start engine.
2. Press MAIN switch and make sure that CRUISE indicator lights up.
3. Drive the vehicle for at least 5 consecutive seconds under the following condition.

Vehicle speed	More than 5 km/h (3 MPH)
Selector lever	Suitable position

4. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
5. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.  
If DTC is detected, go to [EC-1181, "Diagnostic Procedure"](#) .  
If DTC is not detected, go to the following step.
6. Start engine.
7. Drive the vehicle for at least 5 consecutive seconds under the following condition.

Vehicle speed	More than 5 km/h (3 MPH)
Selector lever	Suitable position
Driving location	Depress the brake pedal for more than five seconds so as not to come off from the above-mentioned condition.

8. If DTC is detected, go to [EC-1181, "Diagnostic Procedure"](#) .

A

EC

C

D

E

F

G

H

I

J

K

L

M




# DTC P0504 ASCD BRAKE SWITCH

[YD]

GBS0008H


## Wiring Diagram

### EC-ASC/BS-01



REFER TO THE FOLLOWING.

(E103) - FUSE BLOCK- JUNCTION BOX (J/B)



MBWA1360E

# DTC P0504 ASCD BRAKE SWITCH

[YD]

GBS00081


## Diagnostic Procedure A/T MODELS

### 1. CHECK OVERALL FUNCTION-I

#### ④ With CONSULT-II

1. Turn ignition switch ON.
2. Select "BRAKE SW" in "DATA MONITOR" mode with CONSULT-II.
3. Check "BRAKE SW" indication under the following conditions.


CONDITION	INDICATION
Brake pedal: Fully released	OFF
Brake pedal: Slightly depressed	ON



#### ⊗ Without CONSULT-II

1. Turn ignition switch ON.
2. Check voltage between ECM terminal 100 and ground under the following conditions.

CONDITION	VOLTAGE
Brake pedal: Fully released	Approximately 0V
Brake pedal: Slightly depressed	Battery voltage



#### OK or NG


- OK >> GO TO 2.  
NG >> GO TO 3.

## 2. CHECK OVERALL FUNCTION-II

**With CONSULT-II**

Check "BRAKE SW2" indication in "DATA MONITOR" mode.

CONDITION	INDICATION
Brake pedal: Fully released	OFF
Brake pedal: Slightly depressed	ON




**Without CONSULT-II**

Check voltage between ECM terminal 101 and ground under the following conditions.

CONDITION	VOLTAGE
Brake pedal: Fully released	Battery voltage
Brake pedal: Slightly depressed	Approximately 0V


OK or NG

- OK >> GO TO 11.
- NG >> GO TO 7.



## 3. CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch harness connector.




3. Check voltage between stop lamp switch terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.



## 4. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse
- Harness for open or short between stop lamp switch and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 5. CHECK STOP LAMP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 100 and stop lamp switch terminal 2.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 6.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 6. CHECK STOP LAMP SWITCH

Refer to [EC-1190, "Component Inspection"](#) .


OK or NG

OK >> GO TO 11.

NG >> Replace stop lamp switch.

## 7. CHECK ASCD BRAKE SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch harness connector.
3. Turn ignition switch ON.




4. Check voltage between ASCD brake switch terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

OK >> GO TO 9.

NG >> GO TO 8.



---

## 8. DETECT MALFUNCTIONING PART

---

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse
- Harness for open or short between ASCD brake switch and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 9. CHECK ASCD BRAKE SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 101 and ASCD brake switch terminal 2.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 10.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 10. CHECK ASCD BRAKE SWITCH

---

Refer to [EC-1190, "Component Inspection"](#) .

OK or NG

OK >> GO TO 11.

NG >> Replace ASCD brake switch.

---

## 11. CHECK INTERMITTENT INCIDENT

---

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

# DTC P0504 ASCD BRAKE SWITCH

[YD]


## M/T MODELS

### 1. CHECK OVERALL FUNCTION-I

#### Ⓟ With CONSULT-II

1. Turn ignition switch ON.
2. Select "BRAKE SW" in "DATA MONITOR" mode with CONSULT-II.
3. Check "BRAKE SW" indication under the following conditions.


CONDITION	INDICATION
Brake pedal: Fully released	OFF
Brake pedal: Slightly depressed	ON



#### ⓧ Without CONSULT-II

1. Turn ignition switch ON.
2. Check voltage between ECM terminal 100 and ground under the following conditions.

CONDITION	VOLTAGE
Brake pedal: Fully released	Approximately 0V
Brake pedal: Slightly depressed	Battery voltage



#### OK or NG


- OK >> GO TO 2.
- NG >> GO TO 3.

## 2. CHECK OVERALL FUNCTION-II

**With CONSULT-II**

Check "BRAKE SW2" indication in "DATA MONITOR" mode.

CONDITION	INDICATION
Clutch pedal and brake pedal: Fully released	OFF
Clutch pedal and/or brake pedal: Slightly depressed	ON




**Without CONSULT-II**

Check voltage between ECM terminal 101 and ground under the following conditions.

CONDITION	VOLTAGE
Clutch pedal and brake pedal: Fully released	Battery voltage
Clutch pedal and/or brake pedal: Slightly depressed	Approximately 0V


OK or NG

- OK >> GO TO 14.
- NG >> GO TO 7.



## 3. CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch harness connector.




3. Check voltage between stop lamp switch terminal 2 and ground with CONSULT -II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.





## 4. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse
- Harness for open or short between stop lamp switch and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 5. CHECK STOP LAMP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 100 and stop lamp switch terminal 1.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 6.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 6. CHECK STOP LAMP SWITCH

Refer to [EC-1190, "Component Inspection"](#) .


OK or NG

OK >> GO TO 14.

NG >> Replace stop lamp switch.

## 7. CHECK ASCD BRAKE SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ASCD clutch switch harness connector.
3. Turn ignition switch ON.




4. Check voltage between ASCD clutch switch terminal 1 and ground under the following conditions with CONSULT-II or tester.

CONDITION	VOLTAGE
Brake pedal: Fully released	Battery voltage
Brake pedal: Slightly depressed	Approx. 0V

OK or NG


OK >> GO TO 12.

NG >> GO TO 8.



## 8. CHECK ASCD BRAKE SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch harness connector.
3. Turn ignition switch ON.




4. Check voltage between ASCD brake switch terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 10.
- NG >> GO TO 9.



## 9. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse
- Harness for open or short between ASCD brake switch and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 10. CHECK ASCD BRAKE SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Check harness continuity between ASCD brake switch terminal 2 and ASCD brake clutch switch terminal 1.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 11.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 11. CHECK ASCD BRAKE SWITCH

Refer to [EC-1190, "Component Inspection"](#).

OK or NG

- OK >> GO TO 14.
- NG >> Replace ASCD brake switch.

---

**12. CHECK ASCD CLUTCH SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

---

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 101 and ASCD clutch switch terminal 2.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground or short to power.

OK or NG

OK >> GO TO 13.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

---

**13. CHECK ASCD CLUTCH SWITCH**

---

Refer to [EC-1190, "Component Inspection"](#) .

OK or NG

OK >> GO TO 14.

NG >> Replace ASCD clutch switch.

---

**14. CHECK INTERMITTENT INCIDENT**

---

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

**>> INSPECTION END**

# DTC P0504 ASCD BRAKE SWITCH

[YD]


GBS0008J

## Component Inspection ASCD BRAKE SWITCH

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch harness connector.
3. Check continuity between ASCD brake switch terminals 1 and 2 under the following conditions.

Condition	Continuity
Brake pedal: Fully released	Should exist
Brake pedal: Slightly depressed	Should not exist

If NG, adjust ASCD brake switch installation, refer to [BR-6](#), "[BRAKE PEDAL](#)", and perform step 3 again.




## ASCD CLUTCH SWITCH

1. Turn ignition switch OFF.
2. Disconnect ASCD clutch switch harness connector.
3. Check continuity between ASCD clutch switch terminals 1 and 2 under the following conditions.


Condition	Continuity
Clutch pedal: Fully released	Should exist
Clutch pedal: Slightly depressed	Should not exist

If NG, adjust ASCD clutch switch installation, refer to [CL-6](#), "[CLUTCH PEDAL](#)", and perform step 3 again.



## STOP LAMP SWITCH

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch harness connector.
3. Check continuity between stop lamp switch terminals 1 and 2 under the following conditions.



Condition	Continuity
Brake pedal: Fully released	Should not exist
Brake pedal: Slightly depressed	Should exist

If NG, adjust stop lamp switch installation, refer to [BR-6](#), "[BRAKE PEDAL](#)", and perform step 3 again.

# DTC P0563 BATTERY VOLTAGE

[YD]

## DTC P0563 BATTERY VOLTAGE

PFP:24410

### On Board Diagnosis Logic

GBS0008K

The MIL will not light up for this self-diagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0563 0563	Battery voltage high	An excessively high voltage from the battery is sent to ECM.	<ul style="list-style-type: none"><li>● Battery</li><li>● Battery terminal</li><li>● Alternator</li><li>● Incorrect jump starting</li></ul>

### DTC Confirmation Procedure

GBS0008L

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### ④ WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for at least 35 seconds.
4. If DTC is detected, go to [EC-1191, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

#### ⊗ WITHOUT CONSULT-II

1. Start engine and let it idle for at least 35 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-1191, "Diagnostic Procedure"](#) .

### Diagnostic Procedure

GBS0008M

#### 1. INSPECTION START

Are jumper cables connected for the jump starting?

Yes or No

- Yes >> GO TO 3.  
No >> GO TO 2.

#### 2. CHECK BATTERY AND ALTERNATOR

Check that the proper type of battery and type of alternator are installed.


Refer to, [SC-5, "BATTERY"](#) and [SC-14, "CHARGING SYSTEM"](#) .

OK or NG

- OK >> GO TO 5.  
NG >> Replace with the proper one.

## 3. CHECK JUMPER CABLES INSTALLATION

Check that the jumper cables are connected in the correct sequence.



OK or NG

- OK >> GO TO 4.
- NG >> Reconnect jumper cables properly.

## 4. CHECK BATTERY FOR BOOSTER

Check that the battery for the booster is a 12V battery.

OK or NG

- OK >> GO TO 5.
- NG >> Change the vehicle for booster.

## 5. PERFORM DTC CONFIRMATION PROCEDURE AGAIN

**With CONSULT-II**

1. Select "SELF DIAG RESULTS" mode with CONSULT-II.
2. Touch "ERASE".
3. Perform [EC-1191, "DTC Confirmation Procedure"](#), again.
4. Is DTC P0563 displayed again?

**Without CONSULT-II**

1. Erase the Diagnostic Test Mode II (Self-diagnostic results) memory. Refer to [EC-1016](#).
2. Perform [EC-1191, "DTC Confirmation Procedure"](#), again.
3. Is DTC 0563 displayed again?

Yes or No

- Yes >> GO TO 6.
- No >> GO TO 7.

## 6. REPLACE ECM

1. Replace ECM.
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [BL-83, "ECM Re-communicating Function"](#).
3. Perform Fuel Pump Learning Value Clearing. Refer to [EC-1013, "Fuel Pump Learning Value Clearing"](#).
4. Perform Injector Adjustment Value Registration. Refer to [EC-1014, "Injector Adjustment Value Registration"](#).

>> INSPECTION END

---

## 7. CHECK ELECTRICAL PARTS DAMAGE

---

Check the following for damage.

- Wiring harness and harness connectors for burn
- Fuses for short

OK or NG

OK >> **INSPECTION END**

NG >> Repair or replace malfunctioning part.

A

EC

C

D

E

F

G

H

I

J

K

L

M

# DTC P0580, P0581 ASCD STEERING SWITCH

[YD]


## DTC P0580, P0581 ASCD STEERING SWITCH

PF2:25551

### Component Description

GBS0008N

ASCD steering switch has variant values of electrical resistance for each button. ECM reads voltage variation of switch, and determines which button is operated.



PBIB2645E

Refer to [EC-1337, "AUTOMATIC SPEED CONTROL DEVICE \(ASCD\)"](#) for the ASCD function.

### CONSULT-II Reference Value in Data Monitor Mode

GBS0008O

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
MAIN SW	● Ignition switch: ON	MAIN switch: Pressed	ON
		MAIN switch: Released	OFF
CANCEL SW	● Ignition switch: ON	CANCEL switch: Pressed	ON
		CANCEL switch: Released	OFF
RESUME/ACC SW	● Ignition switch: ON	RESUME/ACCELERATE switch: Pressed	ON
		RESUME/ACCELERATE switch: Released	OFF
SET SW	● Ignition switch: ON	SET/COAST switch: Pressed	ON
		SET/COAST switch: Released	OFF

### ECM Terminals and Reference Value

GBS0008P

Specification data are reference values and are measured between each terminal and ground.

#### CAUTION:

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
102	SB	ASCD steering switch	[Ignition switch ON] ● ASCD steering switch: OFF	Approximately 4.3V
			[Ignition switch ON] ● MAIN switch: Pressed	Approximately 0.3V
			[Ignition switch ON] ● CANCEL switch: Pressed	Approximately 1.3V
			[Ignition switch ON] ● RESUME/ACCELERATE switch: Pressed	Approximately 3.3V
			[Ignition switch ON] ● SET/COAST switch: Pressed	Approximately 2.3V
103	B	ASCD steering switch ground	[Ignition switch ON]	Approximately 0.3V



## On Board Diagnosis Logic

GBS0008Q

The MIL will not light up for these diagnoses.

**NOTE:**

If DTC P0580 or P0581 is displayed with DTC P0606, first perform the trouble diagnosis for DTC P0606. Refer to [EC-1203, "DTC P0606 ECM"](#).

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P0580 0580	ASCD steering switch circuit low input	<ul style="list-style-type: none"> <li>ECM detects that the ASCD steering switch is stuck ON.</li> </ul>	<ul style="list-style-type: none"> <li>Harness or connectors (The switch circuit is open or shorted.)</li> </ul>
P0581 0581	ASCD steering switch circuit high input	<ul style="list-style-type: none"> <li>An excessively high voltage signal from the ASCD steering switch is sent to ECM.</li> </ul>	<ul style="list-style-type: none"> <li>ASCD steering switch</li> <li>ECM</li> </ul>

## DTC Confirmation Procedure

GBS0008R

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**Ⓟ WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 10 seconds.
4. Press MAIN switch for at least 10 seconds, then release it and wait at least 10 seconds.
5. Press RESUME/ACCELERATE switch for at least 10 seconds, then release it and wait at least 10 seconds.
6. Press SET/COAST switch for at least 10 seconds, then release it and wait at least 10 seconds.
7. Press CANCEL switch for at least 10 seconds, then release it and wait at least 10 seconds.
8. If DTC is detected, go to [EC-1197, "Diagnostic Procedure"](#).

**ⓧ WITHOUT CONSULT-II**

1. Turn ignition switch ON and wait at least 10 seconds.
2. Press MAIN switch for at least 10 seconds, then release it and wait at least 10 seconds.
3. Press RESUME/ACCELERATE switch for at least 10 seconds, then release it and wait at least 10 seconds.
4. Press SET/COAST switch for at least 10 seconds, then release it and wait at least 10 seconds.
5. Press CANCEL switch for at least 10 seconds, then release it and wait at least 10 seconds.
6. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
7. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
8. If DTC is detected, go to [EC-1197, "Diagnostic Procedure"](#).

# DTC P0580, P0581 ASCD STEERING SWITCH




[YD]

## Wiring Diagram

GBS0006S

### EC-ASC/SW-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M91) -SUPER MULTIPLE JUNCTION (SMJ)


\* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

MBWA1422E

## Diagnostic Procedure

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body.  
Refer to [EC-1066](#), "Ground Inspection".



← : Vehicle front

- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

## 2. CHECK ASCD STEERING SWITCH CIRCUIT

### With CONSULT-II

1. Turn ignition switch ON.
2. Select "MAIN SW", "RESUME/ACC SW", "SET SW" and "CANCEL SW" in "DATA MONITOR" mode with CONSULT-II.
3. Check each item indication under the following conditions.

Switch	Monitor item	Condition	Indication
MAIN switch	MAIN SW	Pressed	ON
		Released	OFF
CANCEL switch	CANCEL SW	Pressed	ON
		Released	OFF
RESUME/ACCELERATE switch	RESUME/ACC SW	Pressed	ON
		Released	OFF
SET/COAST switch	SET SW	Pressed	ON
		Released	OFF


DATA MONITOR	
MONITOR	NO DTC
MAIN SW	OFF
CANCEL SW	OFF
RESUME/ACC SW	OFF
SET SW	OFF

SEC006D

### Without CONSULT-II

1. Turn ignition switch ON.
2. Check voltage between ECM terminal 102 and ground with pressing each button.

Switch	Condition	Voltage [V]
MAIN switch	Pressed	Approx. 0
	Released	Approx. 4.3
CANCEL switch	Pressed	Approx. 1.3
	Released	Approx. 4.3
RESUME/ACCELERATE switch	Pressed	Approx. 3.3
	Released	Approx. 4.3
SET/COAST switch	Pressed	Approx. 2.3
	Released	Approx. 4.3



#### OK or NG

- OK >> GO TO 8.  
 NG >> GO TO 3.

## 3. CHECK ASCD STEERING SWITCH GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect combination switch harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between combination switch terminal 17 and ECM terminal 103. Refer to Wiring Diagram.

**Continuity should exist.**

5. Also check harness for short to ground and short to power.

#### OK or NG

- OK >> GO TO 5.  
 NG >> GO TO 4.

---

#### 4. DETECT MALFUNCTIONING PART

---

A

Check the following.

- Combination switch (spiral cable)
- Harness connectors M91, E101
- Harness for open and short between ECM and combination switch

EC

>> Repair open circuit or short to ground short to power in harness or connectors.

C

---

#### 5. CHECK ASCD STEERING SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

D

1. Check harness continuity between ECM terminal 102 and combination switch terminal 18. Refer to Wiring Diagram.

**Continuity should exist.**

E

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.  
NG >> GO TO 6.

F

---

#### 6. DETECT MALFUNCTIONING PART

---

G

Check the following.

- Combination switch (spiral cable)
- Harness connectors M91, E101
- Harness for open and short between ECM and combination switch

H

>> Repair open circuit or short to ground or short to power in harness or connectors.

I

---

#### 7. CHECK ASCD STEERING SWITCH

---

J

Refer to [EC-1200, "Component Inspection"](#)

OK or NG

- OK >> GO TO 8.  
NG >> Replace ASCD steering switch.

K

---

#### 8. CHECK INTERMITTENT INCIDENT

---

L

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

M

# DTC P0580, P0581 ASCD STEERING SWITCH


[YD]

GBS0008U

## Component Inspection ASCD STEERING SWITCH

1. Disconnect combination switch.
2. Check continuity between combination switch terminals 17 and 18 with pushing each switch.

Switch	Condition	Resistance [ $\Omega$ ]
MAIN switch	Pressed	Approx. 0
	Released	Approx. 4,000
CANCEL switch	Pressed	Approx. 250
	Released	Approx. 4,000
RESUME/ACCELERATE switch	Pressed	Approx. 1,480
	Released	Approx. 4,000
SET/COAST switch	Pressed	Approx. 660
	Released	Approx. 4,000




**DTC P0605 ECM**

PF:23710

**Description**

GBS0008V

The ECM consists of a microcomputer and connectors for signal input and output and for power supply. The ECM controls the engine.



MBIB0625E

**On Board Diagnosis Logic**

GBS0008W

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0605 0605	Engine control module (ROM)	ECM ROM is malfunctioning.	● ECM

**DTC Confirmation Procedure**

GBS0008X

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-1202, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

**WITHOUT CONSULT-II**

1. Turn ignition switch ON and wait at least 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-1202, "Diagnostic Procedure"](#) .

## Diagnostic Procedure

### 1. INSPECTION START

---

#### With CONSULT-II

1. Turn ignition switch ON.
2. Select "SELF DIAG RESULTS" mode with CONSULT-II.
3. Touch "ERASE".
4. Perform [EC-1201, "DTC Confirmation Procedure"](#) , again.
5. Is DTC P0605 displayed again?

#### Without CONSULT-II

1. Turn ignition switch ON.
2. Erase the Diagnostic Test Mode II (Self-diagnostic results) memory. Refer to [EC-1016](#) .
3. Perform [EC-1201, "DTC Confirmation Procedure"](#) , again.
4. Is DTC 0605 displayed again?

Yes or No

Yes >> GO TO 2.

No >> **INSPECTION END**

### 2. REPLACE ECM

---

1. Replace ECM.
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [BL-83, "ECM Re-communicating Function"](#) .
3. Perform Fuel Pump Learning Value Clearing. Refer to [EC-1013, "Fuel Pump Learning Value Clearing"](#) .
4. Perform Injector Adjustment Value Registration. Refer to [EC-1014, "Injector Adjustment Value Registration"](#) .

>> **INSPECTION END**




**DTC P0606 ECM**

PF:23710

**Description**

GBS0008Z

The ECM consists of a microcomputer and connectors for signal input and output and for power supply. The ECM controls the engine.



**On Board Diagnosis Logic**

GBS00090

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0606 0606	Engine control module (Processor)	ECM calculation function is malfunctioning.	● ECM

**DTC Confirmation Procedure**


GBS00091

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-1204, "Diagnostic Procedure"](#) .



**WITHOUT CONSULT-II**

1. Turn ignition switch ON and wait at least 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-1204, "Diagnostic Procedure"](#) .

---

**Diagnostic Procedure****1. INSPECTION START**

---

**① With CONSULT-II**

1. Turn ignition switch ON.
2. Select "SELF DIAG RESULTS" mode with CONSULT-II.
3. Touch "ERASE".
4. Perform [EC-1203, "DTC Confirmation Procedure"](#) , again.
5. Is DTC P0606 displayed again?

**② Without CONSULT-II**

1. Turn ignition switch ON.
2. Erase the Diagnostic Test Mode II (Self-diagnostic results) memory. Refer to [EC-1016](#) .
3. Perform [EC-1203, "DTC Confirmation Procedure"](#) , again.
4. Is DTC 0606 displayed again?

Yes or No

Yes >> GO TO 2.

No >> **INSPECTION END**

**2. REPLACE ECM**

---

1. Replace ECM.
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [BL-83, "ECM Re-communicating Function"](#) .
3. Perform Fuel Pump Learning Value Clearing. Refer to [EC-1013, "Fuel Pump Learning Value Clearing"](#) .
4. Perform Injector Adjustment Value Registration. Refer to [EC-1014, "Injector Adjustment Value Registration"](#) .

>> **INSPECTION END**

# DTC P0628, P0629 FUEL PUMP

[YD]

## DTC P0628, P0629 FUEL PUMP

PFPP:16700

### Description

GBS00093

To control the amount of the fuel inhalation of the fuel pump, a plunger is built into the fuel pump. When the amount of the fuel inhalation of fuel increases, the fuel pump raises the fuel exhalation pressure. As a result, the fuel injection pressure is raised. When the load of the engine increases, the ECM sends a signal to the fuel pump to raise the injection pressure.

### CONSULT-II Reference Value in Data Monitor Mode

GBS00094

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
PUMP CURRENT	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Air conditioner switch: OFF</li> </ul> Idle	1,600 - 2,000 mA
	<ul style="list-style-type: none"> <li>● Shift lever: P or N (A/T), Neutral (M/T)</li> <li>● No load</li> </ul> 2,000 rpm	1,500 - 1,900 mA



### ECM Terminals and Reference Value

GBS00095

Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-II.



#### CAUTION:

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
10	G	Fuel pump	[Engine is running] <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 5.8V ★  MBIB0885E
			[Engine is running] <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	Approximately 5.5V ★  MBIB0886E

# DTC P0628, P0629 FUEL PUMP

[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
29	B	Fuel pump	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	<p>0.5 - 1.0V ★</p>  <p style="text-align: right; font-size: small;">MBIB0887E</p>
			<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>0.5 - 1.0V ★</p>  <p style="text-align: right; font-size: small;">MBIB0888E</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## On Board Diagnosis Logic

GBS00096

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0628 0628	Fuel pump control circuit low input	ECM detects a control circuit for the fuel pump is open or short to ground.	<ul style="list-style-type: none"> <li>● Harness or connectors (The fuel pump circuit is open or shorted.)</li> <li>● Fuel pump</li> </ul>
P0629 0629	Fuel pump control circuit high output	ECM detects a control circuit for the fuel pump is short to power.	

## DTC Confirmation Procedure

GBS00097

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### ④ WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Let engine idle for at least 5 seconds.
4. If DTC is detected, go to [EC-1208, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

### ⊗ WITHOUT CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Let engine idle for at least 5 seconds.
3. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
4. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
5. If DTC is detected, go to [EC-1208, "Diagnostic Procedure"](#) .

# DTC P0628, P0629 FUEL PUMP


[YD]

## Wiring Diagram

GBS00098

### EC-F/PUMP-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

4	5	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6
		43	42	41	40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25
	3	62	61	60	59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44
1	2	81	80	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64	63



## Diagnostic Procedure

### 1. CHECK ECM OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector and fuel pump (2) harness connector.
  - Fuel pump temperature sensor (1)
3. Check harness continuity between ECM terminal 10 and fuel pump terminal 1. Refer to Wiring Diagram.


**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 2.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



### 2. CHECK FUEL PUMP GROUND CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 29 and fuel pump terminal 2. Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

### 3. CHECK FUEL PUMP

Refer to [EC-1209, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> GO TO 4.

### 4. REPLACE FUEL PUMP

1. Replace fuel pump.
2. Perform Fuel Pump Learning Value Clearing. Refer to [EC-1013, "Fuel Pump Learning Value Clearing"](#) .

>> INSPECTION END

### 5. CHECK INTERMITTENT INCIDENT

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


## Component Inspection

### FUEL PUMP

1. Disconnect fuel pump harness connector.
2. Check resistance between fuel pump terminals 1 and 2.

**Resistance: 1.5 - 3.0Ω [at 10 - 60°C (50 - 140°F)]**

3. If NG, replace fuel pump.



## Removal and Installation

### FUEL PUMP

Refer to [EM-193, "FUEL PUMP"](#) .

A

EC

C

D

E

F

G

H

I

J

K

L

M

# DTC P0642, P0643 SENSOR POWER SUPPLY

[YD]

## DTC P0642, P0643 SENSOR POWER SUPPLY

PFP:18002

### ECM Terminals and Reference Value

GBS0009C

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
82	W	Accelerator pedal position sensor 1 power supply	<b>[Ignition switch ON]</b>	Approximately 5.3V
83	R	Accelerator pedal position sensor 1	<b>[Ignition switch ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully released	0.95 - 1.17V
			<b>[Ignition switch ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully depressed	More than 4.6V
84	B	Accelerator pedal position sensor 1 ground	<b>[Engine is running]</b> ● <b>Warm-up condition</b> ● Idle speed	Approximately 0.3V
85	—	Sensor ground (Accelerator pedal position sensor shield circuit)	<b>[Engine is running]</b> ● <b>Warm-up condition</b> ● Idle speed	Approximately 0.3V
90	W	Accelerator pedal position sensor 2 power supply	<b>[Ignition switch ON]</b>	Approximately 5.3V
91	R	Accelerator pedal position sensor 2	<b>[Ignition switch ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully released	0.58 - 0.78V
			<b>[Ignition switch ON]</b> ● Engine: Stopped ● Accelerator pedal: Fully depressed	More than 2.3V
92	B	Accelerator pedal position sensor 2 ground	<b>[Engine is running]</b> ● <b>Warm-up condition</b> ● Idle speed	Approximately 0.3V

### On Board Diagnosis Logic

GBS0009D

The MIL will not light up for these self-diagnoses.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0642	Sensor power supply circuit low	ECM detects a voltage of power source for sensor is excessively low.	<ul style="list-style-type: none"> <li>● Harness or connectors (The APP sensor 1 power supply circuit is shorted.)</li> <li>● Accelerator pedal position sensor (Accelerator pedal position sensor 1)</li> </ul>
P0643	Sensor power supply circuit high	ECM detects a voltage of power source for Sensor is excessively high.	



## DTC Confirmation Procedure

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**Ⓟ WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-1213, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

**ⓧ WITHOUT CONSULT-II**

1. Turn ignition switch ON and wait at least 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-1213, "Diagnostic Procedure"](#) .




# DTC P0642, P0643 SENSOR POWER SUPPLY

[YD]

GBS0009F

## Wiring Diagram


EC-APP1PW-01



## Diagnostic Procedure

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body.  
Refer to [EC-1066, "Ground Inspection"](#) .



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
NG >> Repair or replace ground connections.

### 2. CHECK APP SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect accelerator pedal position (APP) sensor (1) harness connector.
2. Turn ignition switch ON.




3. Check voltage between APP sensor terminal 2 and ground with CONSULT-II or tester.

**Voltage: Approximately 5.3V**

#### OK or NG

- OK >> GO TO 3.  
NG >> Repair open circuit or short to ground or short to power in harness or connectors.



### 3. CHECK APP SENSOR

Refer to [EC-1134, "Component Inspection"](#) .

#### OK or NG

- OK >> GO TO 4.  
NG >> Replace accelerator pedal assembly.

---

**4. CHECK INTERMITTENT INCIDENT**

---

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

# DTC P0652, P0653 SENSOR POWER SUPPLY

[YD]

## DTC P0652, P0653 SENSOR POWER SUPPLY

PF18002

### ECM Terminals and Reference Value

GBS0009H

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
44	W	Crankshaft position sensor power supply	[Ignition switch ON]	Approximately 5.3V
45	W	Camshaft position sensor power supply	[Ignition switch ON]	Approximately 5.3V
63	R	Fuel rail pressure sensor power supply	[Ignition switch ON]	Approximately 5.3V
64	V	Sensor power supply (Turbocharger boost sensor / Refrigerant pressure sensor)	[Ignition switch ON]	Approximately 5.3V
82	W	Accelerator pedal position sensor 1 power supply	[Ignition switch ON]	Approximately 5.3V
83	R	Accelerator pedal position sensor 1	[Ignition switch ON] ● Engine: Stopped ● Accelerator pedal: Fully released	0.95 - 1.17V
			[Ignition switch ON] ● Engine: Stopped ● Accelerator pedal: Fully depressed	More than 4.6V
84	B	Accelerator pedal position sensor 1 ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0.3V
85	—	Sensor ground (Accelerator pedal position sensor shield circuit)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0.3V
90	W	Accelerator pedal position sensor 2 power supply	[Ignition switch ON]	Approximately 5.3V
91	R	Accelerator pedal position sensor 2	[Ignition switch ON] ● Engine: Stopped ● Accelerator pedal: Fully released	0.58 - 0.78V
			[Ignition switch ON] ● Engine: Stopped ● Accelerator pedal: Fully depressed	More than 2.3V
92	B	Accelerator pedal position sensor 2 ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0.3V

## On Board Diagnosis Logic

The MIL will not light up for these self-diagnoses.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0652 0652	Sensor power supply circuit low	ECM detects a voltage of power source for sensor is excessively low.	<ul style="list-style-type: none"> <li>● Harness or connectors (APP sensor 2 power supply circuit is shorted.) (Crankshaft position sensor circuit is shorted.) (Camshaft position sensor circuit is shorted.) (Fuel rail pressure sensor circuit is shorted.) (Refrigerant pressure sensor circuit is shorted.) (Turbocharger boost sensor circuit is shorted.)</li> <li>● Accelerator pedal position sensor (APP sensor 2)</li> <li>● Crankshaft position sensor</li> <li>● Camshaft position sensor</li> <li>● Fuel rail pressure sensor</li> <li>● Refrigerant pressure sensor</li> <li>● Turbocharger boost sensor</li> </ul>
P0653 0653	Sensor power supply circuit high	ECM detects a voltage of power source for sensor is excessively high.	


## DTC Confirmation Procedure

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-1218, "Diagnostic Procedure"](#) .



### WITHOUT CONSULT-II

1. Turn ignition switch ON and wait at least 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-1218, "Diagnostic Procedure"](#) .




# DTC P0652, P0653 SENSOR POWER SUPPLY

[YD]

## Wiring Diagram

GBS0009K


EC-APP2PW-01



## Diagnostic Procedure

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body.  
Refer to [EC-1066, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
NG >> Repair or replace ground connections.

### 2. CHECK APP SENSOR 2 POWER SUPPLY CIRCUIT

1. Disconnect accelerator pedal position (APP) sensor (1) harness connector.
2. Turn ignition switch ON.




3. Check voltage between APP sensor terminal 1 and ground with CONSULT-II or tester.

**Voltage: Approximately 5.3V**

#### OK or NG

- OK >> GO TO 5.  
NG >> GO TO 3.





### 3. CHECK SENSOR POWER SUPPLY CIRCUITS

Check the following.

Harness for short to power and short to ground, between the following terminals.

ECM terminal	Sensor terminal	Reference Wiring Diagram
90	APP sensor terminal 1	<a href="#">EC-1217</a>
44	Crankshaft position sensor terminal 3	<a href="#">EC-1149</a>
45	Camshaft position sensor terminal 3	<a href="#">EC-1161</a>
63	Fuel rail pressure sensor terminal 1	<a href="#">EC-1108</a>
64	Refrigerant pressure sensor terminal 3	<a href="#">EC-1308</a>
64	Turbocharger boost sensor terminal 3	<a href="#">EC-1143</a>

OK or NG

OK >> GO TO 4.

NG >> Repair short to ground or short to power in harness or connectors.

### 4. CHECK COMPONENTS

Check the following.

- Crankshaft position sensor (Refer to [EC-1152, "Component Inspection"](#) .)
- Camshaft position sensor (Refer to [EC-1163, "Component Inspection"](#) .)
- Fuel rail pressure sensor (Refer to [EC-1110, "Component Inspection"](#) .)
- Refrigerant pressure sensor (Refer to [MTC-77, "COMPONENT INSPECTION"](#) .)
- Turbocharger boost sensor (Refer to [EC-1146, "Component Inspection"](#) .)

OK or NG

OK >> GO TO 5.

NG >> Replace malfunctioning component.

### 5. CHECK APP SENSOR

Refer to [EC-1134, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace accelerator pedal assembly.

### 6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

# DTC P0686 ECM RELAY

[YD]

## DTC P0686 ECM RELAY

PFP:25230

### ECM Terminals and Reference valve

GBS0009M

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
105 113	BR BR	ECM relay (self shut-off)	[Ignition switch ON] [Ignition switch OFF] ● For a few seconds after turning ignition switch OFF	Approximately 1.0V
			[Ignition switch OFF] ● More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14V)
107 108	R R	Ignition switch	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
119 120	R G	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)

### On Board Diagnosis Logic

GBS0009N

The MIL will not light up for this self-diagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0686 0686	ECM relay circuit	ECM detects ECM relay is stuck closed even if ignition switch OFF.	<ul style="list-style-type: none"> <li>● Harness or connectors (The ECM relay circuit is shorted.)</li> <li>● ECM relay</li> </ul>

### DTC Confirmation Procedure

GBS0009O

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**WITH CONSULT-II**

1. Turn ignition switch ON and then turn OFF.
2. Wait at least 30 seconds.
3. Turn ignition switch ON.
4. Select "DATA MONITOR" mode with CONSULT-II.
5. If DTC is detected, go to [EC-1223, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

**WITHOUT CONSULT-II**

1. Turn ignition switch ON and then turn OFF.
2. Wait at least 30 seconds.
3. Turn ignition switch ON.
4. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.

# DTC P0686 ECM RELAY

[YD]

- 
5. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
  6. If DTC is detected, go to [EC-1223, "Diagnostic Procedure"](#) .

A

EC

C

D

E

F

G

H

I

J

K

L

M

# DTC P0686 ECM RELAY



[YD]

## Wiring Diagram


GBS0009P

### EC-ECMRLY-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



E12  
W



E20  
B



REFER TO THE FOLLOWING.

- (M88) - FUSE BLOCK-JUNCTION BOX (J/B)
- (M91) - SUPER MULTIPLE JUNCTION (SMJ)


**Diagnostic Procedure****1. CHECK ECM RELAY INPUT SIGNAL CIRCUIT**

1. Turn ignition switch ON and then OFF.
2. Check voltage between ECM terminals 119, 120 and ground with CONSULT-II or tester.

**Voltage:** After turning ignition switch OFF, battery voltage will exist for a few seconds, then drop approximately 0V.

OK or NG

- OK >> GO TO 5.  
NG >> GO TO 2.


**2. CHECK ECM RELAY OUTPUT SIGNAL CIRCUIT**

1. Turn ignition switch OFF, and wait at least 10 seconds.
2. Check voltage between ECM terminals 105, 113 and ground with CONSULT-II or tester.

**Voltage:** Battery voltage

OK or NG

- OK >> GO TO 4.  
NG >> GO TO 3.

**3. CHECK ECM RELAY OUTPUT SIGNAL CIRCUIT FOR SHORT TO GROUND**

1. Disconnect ECM harness connector.
2. Disconnect IPDM E/R harness connector E12.
3. Check harness continuity between ECM terminals 105, 113 or IPDM E/R terminal 7 and ground. Refer to Wiring Diagram.

**Continuity should not exist.**

OK or NG

- OK >> GO TO 4.  
NG >> Repair short to ground in harness or connectors.

**4. CHECK ECM RELAY INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

1. Disconnect ECM harness connector.
2. Disconnect IPDM E/R harness connector E12.
3. Check harness continuity between ECM terminal 119 and IPDM E/R terminal 3, ECM terminal 120 and IPDM E/R terminal 4. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.  
NG >> Repair open circuit or short to power in harness or connectors.

---

## 5. CHECK INTERMITTENT INCIDENT

---

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

### OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-14, "IPDM E/R \(INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM\)"](#)
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

# DTC P1268 - P1271 FUEL INJECTOR

[YD]


## DTC P1268 - P1271 FUEL INJECTOR

PFP:16600

### Component Description

GBS0009R

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the fuel injector circuit, the coil in the fuel injector is energized. The energized coil pulls the needle valve back and allows fuel to flow through the fuel injector into the cylinder. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the fuel injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.



### CONSULT-II Reference Value in Data Monitor Mode

GBS0009S

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
MAIN INJ WID	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> </ul>	No load	0.50 - 0.70 msec
	<ul style="list-style-type: none"> <li>● Shift lever: P or N (A/T), Neutral (M/T)</li> <li>● Idle speed</li> </ul>	Blower fan switch: ON Rear window defogger switch: ON	0.50 - 0.80 msec

### ECM Terminals and Reference Value

GBS0009T

Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-II.





#### CAUTION:

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
4	V	Fuel injector power supply (For cylinder No. 1 and 4) Fuel injector power supply (For cylinder No. 2 and 3)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <b>NOTE:</b> The pulse cycle changes depending on rpm at idle	Approximately 7.5V ★ 
5	G		<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	Approximately 8.0V ★ 

# DTC P1268 - P1271 FUEL INJECTOR

[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
21 22 23 24	G P W W	Fuel injector No. 2 Fuel injector No. 2 Fuel injector No. 3 Fuel injector No. 3	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	<p>Approximately 7.5V ★</p>  <p style="text-align: right; font-size: small;">MBIB1297E</p>
			<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>Approximately 8.0V ★</p>  <p style="text-align: right; font-size: small;">MBIB1298E</p>
40 41 42 43	W GR W B	Fuel injector No. 4 Fuel injector No. 4 Fuel injector No. 1 Fuel injector No. 1	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	<p>Approximately 7.5V ★</p>  <p style="text-align: right; font-size: small;">MBIB1297E</p>
			<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>Approximately 8.0V ★</p>  <p style="text-align: right; font-size: small;">MBIB1298E</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## On Board Diagnosis Logic

GBS0009U

**The MIL will not light up for these self-diagnoses.**

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1268 1268	No. 1 cylinder fuel injector	The valve built into No. 1 cylinder fuel injector is not closed properly (stuck open) when the injector is not energized.	<ul style="list-style-type: none"> <li>● Injector adjustment value</li> <li>● Fuel injector</li> </ul>
P1269 1269	No. 2 cylinder fuel injector	The valve built into No. 2 cylinder fuel injector is not closed properly (stuck open) when the injector is not energized.	
P1270 1270	No. 3 cylinder fuel injector	The valve built into No. 3 cylinder fuel injector is not closed properly (stuck open) when the injector is not energized.	
P1271 1271	No. 4 cylinder fuel injector	The valve built into No. 4 cylinder fuel injector is not closed properly (stuck open) when the injector is not energized.	



## DTC Confirmation Procedure

**CAUTION:**

Always drive vehicle in safe manner according to traffic conditions and obey all traffic laws when driving.


**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**WITH CONSULT-II**

1. Turn ignition switch ON, and select "DATA MONITOR" mode with CONSULT-II.
2. Restart engine and let it idle for about 15 minutes.
3. If DTC is detected, go to [EC-1229, "Diagnostic Procedure"](#) .  
If DTC is not detected, go to next step.
4. Drive vehicle and maintain the following conditions for at least 60 seconds.

CKPS-RPM	700 - 2,000 rpm (A constant rotation is maintained)
COOLAN TEMP/S	Less than 75°C (167°F)
Shift lever	Suitable position
Accelerator pedal	Hold the accelerator pedal as steady as possible.



5. If DTC is detected, go to [EC-1229, "Diagnostic Procedure"](#) .

**WITHOUT CONSULT-II**

1. Start engine and let it idle for about 15 minutes.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-1229, "Diagnostic Procedure"](#) .  
If DTC is not detected, go to next step.
5. Set voltmeter probes between ECM terminal 70 (engine coolant temperature sensor signal) and ground.
6. Restart engine and drive vehicle and maintain the following conditions for at least 60 seconds.

Engine speed	700 - 2,000 rpm (A constant rotation is maintained)
Voltage between ECM terminal 70 and ground	More than 0.6V
Shift lever	Suitable position
Accelerator pedal	Hold the accelerator pedal as steady as possible.

7. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
8. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
9. If DTC is detected, go to [EC-1229, "Diagnostic Procedure"](#) .

# DTC P1268 - P1271 FUEL INJECTOR





[YD]

## Wiring Diagram

GBS0009W

### EC-INJECT-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



MBWA1042E

## Diagnostic Procedure

### 1. CHECK INJECTOR ADJUSTMENT VALUE

1. Turn ignition switch ON.
2. Select "ENTER INJECTOR CALIB DATA" in "WORK SUPPORT" mode with CONSULT-II.
3. Check injector adjustment values displayed on CONSULT-II screen.

**The value displayed on CONSULT-II screen should be same as injector adjustment value printed on each fuel injector.**

OK or NG

- OK >> GO TO 2.  
 NG >> Perform Injector Adjustment Value Registration. Refer to [EC-1014, "Injector Adjustment Value Registration"](#).


ENTER INJECTR CALIB DATA	
SET VALUE	
CYL1	D0002A1933140E00 000000000000CA
CYL2	D0000B0032ECF600 000000000000F3
CYL3	D0D9EC00F0CEEE00 00000000000017
CYL4	D0D5F3F1F3E9EA00 000000000000F7
CYL1	CYL2
CYL3	CYL4
END	START

MBIB1255E

### 2. CHECK FUEL INJECTOR POWER SUPPLY CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Disconnect fuel injector (1) harness connector.
4. Check harness continuity between the following terminals corresponding to the malfunctioning cylinder. Refer to Wiring Diagram.

DTC	Terminal		Cylinder
	ECM	Fuel injector	
P1268	4	1	No.1
P1269	5	1	No.2
P1270	5	1	No.3
P1271	4	1	No.4



**Continuity should exist.**

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 3.  
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**3. CHECK ECM OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

1. Check harness continuity between the following terminals corresponding to the malfunctioning cylinder. Refer to Wiring Diagram.

DTC	Terminal		Cylinder
	ECM	Fuel injector	
P1268	42, 43	2	No.1
P1269	21, 22	2	No.2
P1270	23, 24	2	No.3
P1271	40, 41	2	No.4

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**4. CHECK FUEL INJECTOR-I**

Refer to [EC-1231, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace fuel injector.

**5. CHECK FUEL INJECTOR-II**

**🔧 With CONSULT-II**

1. Remove two fuel injectors.

**NOTE:**

One is from malfunctioning cylinder and the other is from any cylinder other than the malfunctioning cylinder.

2. Swap the two fuel injectors to the other cylinder.
3. Reconnect ECM harness connector and fuel injector harness connector.
4. Turn ignition switch ON.
5. Perform Injector Adjustment Value Registration. Refer to [EC-1014, "Injector Adjustment Value Registration"](#) .
6. Select "SELF DIAG RESULTS" mode with CONSULT-II.
7. Touch "ERASE".
8. Perform [EC-1227, "DTC Confirmation Procedure"](#) .
9. Is DTC displayed for the other cylinder?

**🔧 Without CONSULT-II**

1. Remove two fuel injectors.

**NOTE:**

One is from malfunctioning cylinder and the other is from any cylinder other than the malfunctioning cylinder.

2. Swap the two fuel injectors to the other cylinder.
3. Reconnect ECM harness connector and fuel injector harness connector.
4. Turn ignition switch ON.
5. Perform Injector Adjustment Value Registration. Refer to [EC-1014, "Injector Adjustment Value Registration"](#) .
6. Erase the Diagnostic Test Mode II (Self-diagnostic results) memory. Refer to [EC-1016](#) .
7. Perform [EC-1227, "DTC Confirmation Procedure"](#) .
8. Is DTC displayed for the other cylinder?

Yes or No

- Yes >> GO TO 6.  
 No >> GO TO 7.

**6. REPLACE FUEL INJECTOR**

1. Replace fuel injector of malfunctioning cylinder.
2. Perform Injector Adjustment Value Registration. Refer to [EC-1014, "Injector Adjustment Value Registration"](#) .

>> INSPECTION END

**7. CHECK INTERMITTENT INCIDENT**

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

**Component Inspection  
 FUEL INJECTOR**

GBS0009Y

1. Disconnect fuel injector harness connector.


## DTC P1268 - P1271 FUEL INJECTOR

[YD]

2. Check resistance between terminals as shown in the figure.

**Resistance: 0.2 - 0.8Ω [at 10 - 60°C (50 - 140°F)]**

3. If NG, replace fuel injector.



### Removal and Installation FUEL INJECTOR

Refer to [EM-188, "INJECTION TUBE AND FUEL INJECTOR"](#) .

GBS0009Z


## DTC P1272 FUEL PUMP

PFP:16700

### Description

When the fuel pressure in fuel rail increases to excessively high, fuel pressure relief valve (1) opens to carry excess fuel to the return hose.

- ↔: Vehicle front
- Fuel rail (2)



### CONSULT-II Reference Value in Data Monitor Mode

GBS000A1

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
PUMP CURRENT	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Air conditioner switch: OFF</li> <li>● Shift lever: P or N (A/T), Neutral (M/T)</li> <li>● No load</li> </ul>	Idle 1,600 - 2,000 mA
	2,000 rpm	1,500 - 1,900 mA

### ECM Terminals and Reference Value

GBS000A2

Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-II.



**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
10	G	Fuel pump	<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	<p>Approximately 5.8V ★</p> <p style="text-align: right; font-size: x-small;">MBIB0885E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>Approximately 5.5V ★</p> <p style="text-align: right; font-size: x-small;">MBIB0886E</p>

# DTC P1272 FUEL PUMP

[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
29	B	Fuel pump	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	0.5 - 1.0V ★ 
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	0.5 - 1.0V ★ 

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## On Board Diagnosis Logic

GBS000A3

The MIL will not light up for this self-diagnosis.

### NOTE:

If DTC P1272 is displayed with DTC P0652 or P0653, first perform the trouble diagnosis for DTC P0652 or P0653. Refer to [EC-1215, "DTC P0652, P0653 SENSOR POWER SUPPLY"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1272 1272	Fuel rail pressure relief valve open	Fuel rail pressure relief valve is open because of fuel pressure control system malfunction.	<ul style="list-style-type: none"> <li>● Harness or connectors (Fuel pump circuit is open or shorted.)</li> <li>● Fuel pump</li> <li>● Fuel rail pressure sensor</li> <li>● Air mixed with fuel</li> <li>● Lack of fuel</li> </ul>

## DTC Confirmation Procedure

GBS000A4

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and keep engine speed more than 4,000 rpm for at least 5 seconds, then release the accelerator pedal.
4. If DTC is detected, go to [EC-1237, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

#### WITHOUT CONSULT-II

1. Start engine and keep engine speed more than 4,000 rpm for at least 5 seconds, then release the accelerator pedal.



## DTC P1272 FUEL PUMP

[YD]

2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-1237, "Diagnostic Procedure"](#) .

A

EC

C

D

E

F

G

H

I

J

K

L

M

# DTC P1272 FUEL PUMP



[YD]

## Wiring Diagram

GBS000A5

### EC-F/PUMP-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



MBWA1050E

**Diagnostic Procedure****1. PERFORM FUEL PUMP LEARNING VALUE CLEARING****NOTE:**

If the DTC is detected because of air mixed with fuel (i.e.: caused by lack of fuel), it may become normal by performing following procedure.

**☑ With CONSULT-II**

1. Turn ignition switch ON.
2. Perform Fuel Pump Learning Value Clearing. Refer to [EC-1013, "Fuel Pump Learning Value Clearing"](#) .
3. Start engine and let it idle for at least 60 seconds.
4. Select "SELF-DIAG RESULT" mode with CONSULT-II.
5. Touch "ERASE".
6. Perform [EC-1234, "DTC Confirmation Procedure"](#) , again.
7. Is DTC detected again?

**☒ Without CONSULT-II**

1. Turn ignition switch ON.
2. Perform Fuel Pump Learning Value Clearing. Refer to [EC-1013, "Fuel Pump Learning Value Clearing"](#) .
3. Start engine and let it idle for at least 60 seconds.
4. Erase the Diagnostic Test Mode II (Self-diagnostic results) memory. Refer to [EC-1016](#) .
5. Perform [EC-1234, "DTC Confirmation Procedure"](#) , again.
6. Is DTC displayed again?

**Yes or No**

Yes >> GO TO 2.

No >> **INSPECTION END**

**2. CHECK FUEL PUMP POWER SUPPLY CIRCUIT FOR OPEN AND SHORT**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector and fuel pump (2) harness connector.
  - Fuel pump temperature sensor (1)
3. Check harness continuity between ECM terminal 10 and fuel pump terminal 1. Refer to Wiring Diagram.


**Continuity should exist.**

4. Also check harness for short to ground and short to power.

**OK or NG**

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**3. CHECK FUEL PUMP GROUND CIRCUIT FOR OPEN AND SHORT**

1. Check harness continuity between ECM terminal 29 and fuel pump terminal 2. Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

**OK or NG**

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 4. CHECK FUEL PUMP

Refer to [EC-1238, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 7.

## 5. CHECK FUEL RAIL PRESSURE SENSOR

Refer to [EC-1110, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> Replace fuel rail.

## 6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> GO TO 7.
- NG >> Repair or replace.

## 7. REPLACE FUEL PUMP

1. Replace fuel pump.
2. Perform Fuel Pump Learning Value Clearing. Refer to [EC-1013, "Fuel Pump Learning Value Clearing"](#) .

>> INSPECTION END


### Component Inspection FUEL PUMP

GBS000A7

1. Disconnect fuel pump harness connector.
2. Check resistance between fuel pump terminals 1 and 2.

**Resistance: 1.5 - 3.0Ω [at 10 - 60°C (50 - 140°F)]**

3. If NG, replace fuel pump.



GBS000A8

### Removal and Installation FUEL RAIL

Refer to [EM-188, "INJECTION TUBE AND FUEL INJECTOR"](#) .

### FUEL PUMP

Refer to [EM-193, "FUEL PUMP"](#) .

# DTC P1273 FUEL PUMP

[YD]

## DTC P1273 FUEL PUMP

PFPP:16700

### Description

GBS000A9

To control the amount of the fuel inhalation of the fuel pump, a plunger is built into the fuel pump. When the amount of the fuel inhalation of fuel pump increases, the fuel raises the fuel exhalation pressure. As a result, the fuel injection pressure is raised. When the load of the engine increases, the ECM sends a signal to the fuel pump to raise the injection pressure.

### CONSULT-II Reference Value in Data Monitor Mode

GBS000AA

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
PUMP CURRENT	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Air conditioner switch: OFF</li> </ul>	Idle	1,600 - 2,000 mA
	<ul style="list-style-type: none"> <li>● Shift lever: P or N (A/T), Neutral (M/T)</li> <li>● No load</li> </ul>	2,000 rpm	1,500 - 1,900 mA



### ECM Terminals and Reference Value

GBS000AB

Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-II.



#### CAUTION:

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
10	G	Fuel pump	<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	<p>Approximately 5.8V ★</p>  <p>MBIB0885E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>Approximately 5.5V ★</p>  <p>MBIB0886E</p>

# DTC P1273 FUEL PUMP

[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
29	B	Fuel pump	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	0.5 - 1.0V ★  <small>MBIB0887E</small>
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	0.5 - 1.0V ★  <small>MBIB0888E</small>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## On Board Diagnosis Logic

GBS000AC

The MIL will not light up for this self-diagnosis.

### NOTE:

If DTC P1273 is displayed with DTC P0652 or P0653, first perform the trouble diagnosis for DTC P0652 or P0653. Refer to [EC-1215, "DTC P0652, P0653 SENSOR POWER SUPPLY"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1273 1273	Fuel pump insufficient flow	ECM detects the abnormal pulse of fuel pressure.	<ul style="list-style-type: none"> <li>● Harness or connectors (The fuel pump circuit is open or shorted.)</li> <li>● Fuel pump</li> <li>● Injector adjustment value</li> <li>● Air mixed with fuel</li> <li>● Lack of fuel</li> <li>● Fuel rail pressure sensor</li> </ul>

## DTC Confirmation Procedure

GBS000AD

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Keep engine speed more than 2,000 rpm for at least 10 seconds.
4. If DTC is detected, go to [EC-1243, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

### WITHOUT CONSULT-II

1. Start engine and warm it up to normal operating temperature.

## DTC P1273 FUEL PUMP

[YD]

2. Keep engine speed more than 2,000 rpm for at least 10 seconds.
3. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
4. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
5. If DTC is detected, go to [EC-1243, "Diagnostic Procedure"](#) .

A

EC

C

D

E

F

G

H

I

J

K

L

M

# DTC P1273 FUEL PUMP



[YD]

## Wiring Diagram

GBS000AE

### EC-F/PUMP-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



MBWA1050E



**Diagnostic Procedure****1. CHECK INJECTOR ADJUSTMENT VALUE**

1. Turn ignition switch ON.
2. Select "ENTER INJECTOR CALIB DATA" in "WORK SUPPORT" mode with CONSULT-II.
3. Check injector adjustment values displayed on CONSULT-II screen.

**The value displayed on CONSULT-II screen should be same as injector adjustment value printed on each fuel injector.**

**OK or NG**

- OK >> GO TO 2.  
 NG >> Perform Injector Adjustment Value Registration. Refer to [EC-1014, "Injector Adjustment Value Registration"](#).

ENTER INJECTR CALIB DATA	
SET VALUE	
CYL1	D0002A1933140E00 000000000000CA
CYL2	D0000B0032ECF600 000000000000F3
CYL3	D0D9EC00F0ECE00 00000000000017
CYL4	D0D5F3F1F3E9EA00 000000000000F7
CYL1	CYL2
CYL3	CYL4
END	START

MBIB1255E

**2. PERFORM FUEL PUMP LEARNING VALUE CLEARING****NOTE:**

If the DTC is detected because of air mixed with fuel (i.e.: caused by lack of fuel), it may become normal by performing following procedure.

**Ⓟ With CONSULT-II**

1. Turn ignition switch ON.
2. Perform Fuel Pump Learning value clearing. Refer to [EC-1013, "Fuel Pump Learning Value Clearing"](#).
3. Start engine and let it idle for at least 60 seconds.
4. Select "SELF-DIAG RESULT" mode with CONSULT-II.
5. Touch "ERASE".
6. Perform [EC-1240, "DTC Confirmation Procedure"](#), again.
7. Is DTC detected again?

**ⓧ Without CONSULT-II**

1. Turn ignition switch ON.
2. Clear fuel pump learning value. Refer to [EC-1013, "Fuel Pump Learning Value Clearing"](#).
3. Start engine and let it idle for at least 60 seconds.
4. Erase the Diagnostic Test Mode II (Self-diagnostic results) memory. Refer to [EC-1016](#).
5. Perform [EC-1240, "DTC Confirmation Procedure"](#), again.
6. Is DTC displayed again?

**Yes or No**

- Yes >> GO TO 3.  
 No >> **INSPECTION END**

### 3. CHECK FUEL PUMP POWER SUPPLY CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector and fuel pump (2) harness connector.
  - Fuel pump temperature sensor (1)
3. Check harness continuity between ECM terminal 10 and fuel pump terminal 1.  
Refer to Wiring Diagram.


**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



### 4. CHECK FUEL PUMP GROUND CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 29 and fuel pump terminal 2.  
Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

### 5. CHECK FUEL RAIL PRESSURE SENSOR

Refer to [EC-1110, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace fuel rail.

### 6. CHECK FUEL PUMP

Refer to [EC-1245, "Component Inspection"](#) .

OK or NG

OK >> GO TO 8.

NG >> GO TO 7.

### 7. REPLACE FUEL PUMP

1. Replace fuel pump.
2. Perform Fuel Pump Learning Valve Clearing. Refer to [EC-1013, "Fuel Pump Learning Value Clearing"](#) .

>> **INSPECTION END**

### 8. CHECK INTERMITTENT INCIDENT

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**


## Component Inspection

### FUEL PUMP

1. Disconnect fuel pump harness connector.
2. Check resistance between fuel pump terminals 1 and 2.

**Resistance: 1.5 - 3.0Ω [at 10 - 60°C (50 - 140°F)]**

3. If NG, replace fuel pump.



## Removal and Installation

### FUEL PUMP

Refer to [EM-193, "FUEL PUMP"](#) .

A

EC

C

D

E

F

G

H

I

J

K

L

M

# DTC P1274 FUEL PUMP

[YD]

## DTC P1274 FUEL PUMP

PFP:16700

### Description

GBS000AI

To control the amount of the fuel inhalation of the fuel pump, a plunger is built into the fuel pump. When the amount of the fuel inhalation of fuel increases, the fuel pump raises the fuel exhalation pressure. As a result, the fuel injection pressure is raised. When the load of the engine increases, the ECM sends a signal to the fuel pump to raise the injection pressure.

### CONSULT-II Reference Value in Data Monitor Mode

GBS000AJ

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
PUMP CURRENT	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Air conditioner switch: OFF</li> </ul>	Idle 1,600 - 2,000 mA
	<ul style="list-style-type: none"> <li>● Shift lever: P or N (A/T), Neutral (M/T)</li> <li>● No load</li> </ul>	2,000 rpm 1,500 - 1,900 mA



### ECM Terminals and Reference Value

GBS000AK

Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-II.



#### CAUTION:

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
10	G	Fuel pump	<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	<p>Approximately 5.8V ★</p>  <p>MBIB0885E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>Approximately 5.5V ★</p>  <p>MBIB0886E</p>

# DTC P1274 FUEL PUMP

[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
29	B	Fuel pump	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	0.5 - 1.0V ★ 
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	0.5 - 1.0V ★ 

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## On Board Diagnosis Logic

GBS000AL

### NOTE:

If DTC P1274 is displayed with DTC P0652 or P0653, first perform the trouble diagnosis for DTC P0652 or P0653. Refer to [EC-1215, "DTC P0652, P0653 SENSOR POWER SUPPLY"](#) .

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1274 1274	Fuel pump protection	Fuel pressure is too much higher than the target value.	<ul style="list-style-type: none"> <li>● Harness or connectors (The fuel pump circuit is open or shorted.)</li> <li>● Fuel pump</li> <li>● Fuel rail pressure sensor</li> </ul>

## DTC Confirmation Procedure

GBS000AM

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### ④ WITH CONSULT-II

1. Tuning ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let idle for at least 5 seconds.
4. If DTC is detected, go to [EC-1249, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

### ⊗ WITHOUT CONSULT-II

1. Start engine and let idle for at least 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-1249, "Diagnostic Procedure"](#) .

# DTC P1274 FUEL PUMP



[YD]

## Wiring Diagram

GBS000AN

### EC-F/PUMP-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



MBWA1050E

## Diagnostic Procedure

### 1. CHECK ECM OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector and fuel pump (2) harness connector.
  - Fuel pump temperature sensor (1)
3. Check harness continuity between ECM terminal 10 and fuel pump terminal 1. Refer to Wiring Diagram.


**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 2.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



### 2. CHECK FUEL PUMP GROUND CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 29 and fuel pump terminal 2. Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

### 3. CHECK FUEL RAIL PRESSURE SENSOR

Refer to [EC-1110, "Component Inspection"](#) .

OK or NG

OK >> GO TO 4.

NG >> Replace fuel rail.

### 4. CHECK FUEL PUMP

Refer to [EC-1250, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> GO TO 5.

### 5. REPLACE FUEL PUMP

1. Replace fuel pump.
2. Perform Fuel Pump Learning Valve Clearing. Refer to [EC-1013, "Fuel Pump Learning Value Clearing"](#) .

>> INSPECTION END

### 6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


## Component Inspection

### FUEL PUMP

1. Disconnect fuel pump harness connector.
2. Check resistance between fuel pump terminals 1 and 2.

**Resistance: 1.5 - 3.0Ω [at 10 - 60°C (50 - 140°F)]**

3. If NG, replace fuel pump.



## Removal and Installation

### FUEL PUMP

Refer to [EM-193, "FUEL PUMP"](#) .



# DTC P1275 FUEL PUMP

[YD]

## DTC P1275 FUEL PUMP

PFPP:16700

### Description

GBS000AR

To control the amount of the fuel inhalation of the fuel pump, a plunger is built into the fuel pump. When the amount of the fuel inhalation of fuel increases, the fuel pump raises the fuel exhalation pressure. As a result, the fuel injection pressure is raised. When the load of the engine increases, the ECM sends a signal to fuel pump to raise the injection pressure.

### CONSULT-II Reference Value in Data Monitor Mode

GBS000AS

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
PUMP CURRENT	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Air conditioner switch: OFF</li> <li>● Shift lever: P or N (A/T), Neutral (M/T)</li> <li>● No load</li> </ul>	Idle	1,600 - 2,000 mA
		2,000 rpm	1,500 - 1,900 mA



### ECM Terminals and Reference Value

GBS000AT

Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-II.



#### CAUTION:

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
10	G	Fuel pump	<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	<p>Approximately 5.8V ★</p>  <p>MBIB0885E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>Approximately 5.5V ★</p>  <p>MBIB0886E</p>

# DTC P1275 FUEL PUMP

[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
29	B	Fuel pump	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	0.5 - 1.0V ★  <small>MBIB0887E</small>
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	0.5 - 1.0V ★  <small>MBIB0888E</small>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## On Board Diagnosis Logic

GBS000AU

### NOTE:

If DTC P1275 is displayed with DTC P0652 or P0653, first perform the trouble diagnosis for DTC P0652 or P0653. Refer to [EC-1215, "DTC P0652, P0653 SENSOR POWER SUPPLY"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1275 1275	Fuel pump exchange	Fuel pressure is too much higher than the target value.	<ul style="list-style-type: none"> <li>● Harness or connectors (The fuel pump circuit is open or shorted.)</li> <li>● Fuel pump</li> <li>● Fuel rail pressure sensor</li> </ul>

## DTC Confirmation Procedure

GBS000AV

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### ④ WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Keep engine speed more than 2,000 rpm for at least 60 seconds.
4. If DTC is detected, go to [EC-1255, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

### ⊗ WITHOUT CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Keep engine speed more than 2,000 rpm for at least 60 seconds.
3. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
4. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.

# DTC P1275 FUEL PUMP

[YD]

5. If DTC is detected, go to [EC-1255, "Diagnostic Procedure"](#) .

A

EC

C

D

E

F

G

H

I

J

K

L

M

# DTC P1275 FUEL PUMP



[YD]

## Wiring Diagram

GBS000AW

### EC-F/PUMP-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



**Diagnostic Procedure****1. CHECK ECM OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector and fuel pump (2) harness connectors.
  - Fuel pump temperature sensor (1)
3. Check harness continuity between ECM terminal 10 and fuel pump terminal 1. Refer to Wiring Diagram.


**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 2.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**2. CHECK FUEL PUMP GROUND CIRCUIT FOR OPEN AND SHORT**

1. Check harness continuity between ECM terminal 29 and fuel pump terminal 2. Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**3. CHECK FUEL RAIL PRESSURE SENSOR**

Refer to [EC-1110, "Component Inspection"](#) .

OK or NG

OK >> GO TO 4.

NG >> Replace fuel rail.

**4. CHECK FUEL PUMP**

Refer to [EC-1256, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> GO TO 5.

**5. REPLACE FUEL PUMP**

1. Replace fuel pump.
2. Perform Fuel Pump Learning Valve Clearing. Refer to [EC-1013, "Fuel Pump Learning Value Clearing"](#) .

>> INSPECTION END

**6. CHECK INTERMITTENT INCIDENT**

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


## Component Inspection FUEL PUMP

GBS000AY

1. Disconnect fuel pump harness connector.
2. Check resistance between fuel pump terminals 1 and 2.

**Resistance: 1.5 - 3.0Ω [at 10 - 60°C (50 - 140°F)]**

3. If NG, replace fuel pump.



GBS000AZ

## Removal and Installation FUEL PUMP

Refer to [EM-193, "FUEL PUMP"](#) .


**DTC P1616 ECM**

PF:23710

**Description**

GBS000B0

The ECM consists of a microcomputer and connectors for signal input and output and for power supply. The ECM controls the engine.



**On Board Diagnosis Logic**

GBS000B1

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1616 1616	Engine control module (ROM)	ECM ROM is malfunctioning.	● ECM

**DTC Confirmation Procedure**


GBS000B2

**NOTE:**

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-1258, "Diagnostic Procedure"](#) .



**WITHOUT CONSULT-II**

1. Turn ignition switch ON and wait at least 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-1258, "Diagnostic Procedure"](#) .

---

**Diagnostic Procedure****1. INSPECTION START**

---

**① With CONSULT-II**

1. Turn ignition switch ON.
2. Select "SELF DIAG RESULTS" mode with CONSULT-II.
3. Touch "ERASE".
4. Perform [EC-1257, "DTC Confirmation Procedure"](#) , again.
5. Is DTC P1616 displayed again?

**② Without CONSULT-II**

1. Turn ignition switch ON.
2. Erase the Diagnostic Test Mode II (Self-diagnostic results) memory. Refer to [EC-1016](#) .
3. Perform [EC-1257, "DTC Confirmation Procedure"](#) , again.
4. Is DTC 1616 displayed again?

Yes or No

Yes >> GO TO 2.

No >> **INSPECTION END**

**2. REPLACE ECM**

---

1. Replace ECM.
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [BL-83, "ECM Re-communicating Function"](#) .
3. Perform Fuel Pump Learning Value Clearing. Refer to [EC-1013, "Fuel Pump Learning Value Clearing"](#) .
4. Perform Injector Adjustment Value Registration. Refer to [EC-1014, "Injector Adjustment Value Registration"](#) .

>> **INSPECTION END**



# DTC P1622 INJECTOR ADJUSTMENT VALUE

[YD]

## DTC P1622 INJECTOR ADJUSTMENT VALUE


PPF:23710

### Description

GBS000B4

Injector adjustment value indicates manufacturing tolerance and the value is printed on the top of fuel injector. The injector adjustment value which is correctly stored in ECM is needed for precise fuel injection control. A performance of emission control and a drivability may effect when there is a mismatch between the following two values.

- The injector adjustment value stored in ECM
- The injector adjustment value of the fuel injector which is installed on the vehicle



Example: Injector adjustment value = D021ABCD1A061234000000000000E6

### On Board Diagnosis Logic

GBS000B5

The MIL will not light up for this self-diagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1622 1622	Injector adjustment value data uninput	Injector adjustment value is not stored in ECM.	<ul style="list-style-type: none"> <li>● Injector adjustment value (Injector adjustment value has not been written onto ECM memory yet, or the value has been initialized.)</li> </ul>

### DTC Confirmation Procedure


GBS000B6

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### ④ WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-1260, "Diagnostic Procedure"](#) .



#### ⊗ WITHOUT CONSULT-II

1. Turn ignition switch ON and wait at least 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-1260, "Diagnostic Procedure"](#) .

# DTC P1622 INJECTOR ADJUSTMENT VALUE

[YD]

---

## Diagnostic Procedure

GBS000B7

### 1. PERFORM INJECTOR ADJUSTMENT VALUE REGISTRATION

---

Perform Injector Adjustment Value Registration. Refer to [EC-1014, "Injector Adjustment Value Registration"](#) .

>> INSPECTION END

# DTC P1623 INJECTOR ADJUSTMENT VALUE

[YD]

## DTC P1623 INJECTOR ADJUSTMENT VALUE


PPF:23710

### Description

GBS000B8

Injector adjustment value indicates manufacturing tolerance and the value is printed on the top of fuel injector. The injector adjustment value which is correctly stored in ECM is needed for precise fuel injection control. A performance of emission control and a drivability may effect when there is a mismatch between the following two values.

- The injector adjustment value stored in ECM
- The injector adjustment value of the fuel injector which is installed on the vehicle



MBIB1251E

Example: Injector adjustment value = D021ABCD1A061234000000000000E6

### On Board Diagnosis Logic

GBS000B9

The MIL will not light up for this self-diagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1623 1623	Injector adjustment value data error	ECM detects the abnormal value of injector adjustment value.	<ul style="list-style-type: none"> <li>• CONSULT-II communication status (The status of CONSULT-II communication becomes improper during Injector Adjustment Value Registration.)</li> <li>• ECM</li> </ul>

#### NOTE:

This DTC is not detected when injector adjustment value (not correct but existent) is stored in ECM.

### DTC Confirmation Procedure


GBS000BA

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-1262, "Diagnostic Procedure"](#) .



SEF817Y

#### WITHOUT CONSULT-II

1. Turn ignition switch ON and wait at least 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.

4. If DTC is detected, go to [EC-1262, "Diagnostic Procedure"](#) .

## Diagnostic Procedure

GBS000BB

### 1. CHECK INJECTOR ADJUSTMENT VALUE

1. Turn ignition switch ON.
2. Select "ENTER INJECTOR CALIB DATA" in "WORK SUPPORT" mode with CONSULT-II.
3. Check injector adjustment values displayed on CONSULT-II screen.

**The value displayed on CONSULT-II screen should be same as injector adjustment value printed on each fuel injector.**

ENTER INJCTR CALIB DATA	
SET VALUE	
CYL1	D0002A1933140E00 000000000000CA
CYL2	D0000B0032ECF600 000000000000F3
CYL3	D0D9EC00F0ECE00 00000000000017
CYL4	D0D5F3F1F3E9EA00 000000000000F7
CYL1	CYL2
CYL3	CYL4
END	START

MBIB1255E

OK or NG

- OK     >> GO TO 3.  
 NG     >> GO TO 2.

### 2. PERFORM INJECTOR ADJUSTMENT VALUE REGISTRATION

Perform Injector Adjustment Value Registration. Refer to [EC-1014, "Injector Adjustment Value Registration"](#) .

**NOTE:**

When two or more injector adjustment value are improper, it is useful to perform "INJ ADJ VAL CLR" in "WORK SUPPORT" mode with CONSULT-II. And then perform Injector Adjustment Value Registration.

>> GO TO 3.

### 3. PERFORM DTC CONFIRMATION PROCEDURE

**With CONSULT-II**

1. Select "SELF DIAG RESULTS" mode with CONSULT-II.
2. Touch "ERASE".
3. Perform [EC-1261, "DTC Confirmation Procedure"](#) , again.
4. Is DTC P1623 displayed again?

**Without CONSULT-II**

1. Erase the Diagnostic Test Mode II (Self-diagnostic results) memory. Refer to [EC-1016](#) .
2. Perform [EC-1261, "DTC Confirmation Procedure"](#) , again.
3. Is DTC 1623 displayed again?

Yes or No

- Yes     >> GO TO 4.  
 No     >> **INSPECTION END**

### 4. REPLACE ECM

1. Replace ECM.
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [BL-83, "ECM Re-communicating Function"](#) .
3. Perform Fuel Pump Learning Value Clearing. Refer to [EC-1013, "Fuel Pump Learning Value Clearing"](#) .
4. Perform Injector Adjustment Value Registration. Refer to [EC-1014, "Injector Adjustment Value Registration"](#) .

>> **INSPECTION END**


DTC P2135 APP SENSOR

PFP:18002

Description

GBS000BC

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensors detect the accelerator pedal position and sends a signal to the ECM. The ECM uses the signal to determine the amount of fuel to be injected.



CONSULT-II Reference Value in Data Monitor Mode

GBS000BD

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
ACCEL POS SEN*	● Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	0.65 - 0.87V
		Accelerator pedal: Fully depressed	More than 4.3V
ACCEL SEN 2*	● Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	0.28 - 0.48V
		Accelerator pedal: Fully depressed	More than 2.0V

\*: This signal is converted by ECM internally. Thus, it differs from ECM terminal voltage.

ECM Terminals and Reference Value

GBS000BE

Specification data are reference values and are measured between each terminal and ground.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
82	W	Accelerator pedal position sensor 1 power supply	[Ignition switch ON]	Approximately 5.3V
83	R	Accelerator pedal position sensor 1	[Ignition switch ON] ● Engine: Stopped ● Accelerator pedal: Fully released	0.95 - 1.17V
			[Ignition switch ON] ● Engine: Stopped ● Accelerator pedal: Fully depressed	More than 4.6V
84	B	Accelerator pedal position sensor 1 ground	[Ignition switch ON]	Approximately 0.3V
85	—	Sensor ground (Accelerator pedal position sensor shield circuit)	[Ignition switch ON]	Approximately 0.3V
90	W	Accelerator pedal position sensor 2 power supply	[Ignition switch ON]	Approximately 5.3V

# DTC P2135 APP SENSOR

[YD]

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
91	R	Accelerator pedal position sensor 2	[Ignition switch ON] ● Engine: Stopped ● Accelerator pedal: Fully released	0.58 - 0.78V
			[Ignition switch ON] ● Engine: Stopped ● Accelerator pedal: Fully depressed	More than 2.3V
92	B	Accelerator pedal position sensor 2 ground	[Ignition switch ON]	Approximately 0.3V

## On Board Diagnosis Logic

GBS000BF

The MIL will not light up for this self-diagnosis.

### NOTE:

- If DTC P2135 is displayed with DTC P0642 or P0643, first perform the trouble diagnosis for DTC P0642 or P0643. Refer to [EC-1210, "DTC P0642, P0643 SENSOR POWER SUPPLY"](#).
- If DTC P2135 is displayed with DTC P0652 or P0653, first perform the trouble diagnosis for DTC P0652 or P0653. Refer to [EC-1215, "DTC P0652, P0653 SENSOR POWER SUPPLY"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P2135 2135	Accelerator pedal position sensor 1, 2 signal correlation	The correlation between APP sensor 1 signal and APP sensor 2 signal is out of the normal range.	<ul style="list-style-type: none"> <li>● Harness or connectors (The APP sensor circuit is open or shorted.)</li> <li>● Accelerator pedal position sensor</li> </ul>

## DTC Confirmation Procedure

GBS000BG

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### ④ WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. Depress accelerator pedal slowly spending 5 seconds, and then release it slowly spending 5 seconds.
5. If DTC is detected, go to [EC-1266, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

### ⊗ WITHOUT CONSULT-II

1. Turn ignition switch ON and wait at least 5 seconds.
2. Depress accelerator pedal slowly spending 5 seconds, and then release it slowly spending 5 seconds.
3. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
4. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
5. If DTC is detected, go to [EC-1266, "Diagnostic Procedure"](#).




# DTC P2135 APP SENSOR

[YD]

## Wiring Diagram

GBS000BH


EC-APPS3-01



## Diagnostic Procedure

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body.  
Refer to [EC-1066](#), "Ground Inspection".



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
NG >> Repair or replace ground connections.

### 2. CHECK APP SENSOR POWER SUPPLY CIRCUIT

1. Disconnect accelerator pedal position (APP) sensor (1) harness connector.
2. Turn ignition switch ON.




3. Check voltage between APP sensor terminals 1, 2 and ground with CONSULT-II or tester.

**Voltage: Approximately 5.3V**

#### OK or NG

- OK >> GO TO 3.  
NG >> Repair open circuit or short to ground or short to power in harness or connectors.





**3. CHECK APP SENSOR GROUND CIRCUIT FOR OPEN AND SHORT**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between APP sensor terminal 4 and ECM terminal 84, APP sensor terminal 5 and ECM terminal 92.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**4. CHECK APP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

1. Check harness continuity between ECM terminal 83 and APP sensor terminal 3, ECM terminal 91 and APP sensor terminal 6.  
Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**5. CHECK APP SENSOR**

Refer to [EC-1267, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace accelerator pedal assembly.

**6. CHECK INTERMITTENT INCIDENT**

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> **INSPECTION END**

**Component Inspection  
ACCELERATOR PEDAL POSITION SENSOR**

GBS000BJ

1. Reconnect all harness connectors disconnected.
2. Turn ignition switch ON.
3. Check voltage between ECM terminals 83 (APP sensor 1 signal), 91 (APP sensor 2 signal) and ground under the following conditions.

Terminal	Accelerator pedal	Voltage
83 (Accelerator pedal position sensor 1)	Fully released	0.95 - 1.17V
	Fully depressed	More than 4.6V
91 (Accelerator pedal position sensor 2)	Fully released	0.58 - 0.78V
	Fully depressed	More than 2.3V



4. If NG, replace accelerator pedal assembly.

---

## Removal and Installation ACCELERATOR PEDAL

GBS000BK

Refer to [ACC-2, "ACCELERATOR CONTROL SYSTEM"](#) .

# DTC P2146, P2149 FUEL INJECTOR POWER SUPPLY

[YD]


## DTC P2146, P2149 FUEL INJECTOR POWER SUPPLY

PPF:16600

### Component Description

GBS000BL

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the fuel injector circuit, the coil in the fuel injector is energized. The energized coil pulls the needle valve back and allows fuel to flow through the fuel injector into the cylinder. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the fuel injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.



### CONSULT-II Reference Value in Data Monitor Mode

GBS000BM

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
MAIN INJ WID	<ul style="list-style-type: none"> <li>Engine: After warming up</li> </ul> No load	0.50 - 0.70 msec
	<ul style="list-style-type: none"> <li>Shift lever: P or N (A/T), Neutral (M/T)</li> <li>Idle speed</li> </ul> Blower fan switch: ON Rear window defogger switch: ON	0.50 - 0.80 msec

### ECM Terminals and Reference Value

GBS000BN

Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-II.





#### CAUTION:

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
4	V	Fuel injector power supply (For cylinder No. 1 and 4) Fuel injector power supply (For cylinder No. 2 and 3)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>Warm-up condition</li> <li>Idle speed</li> </ul> <b>NOTE:</b> The pulse cycle changes depending on rpm at idle	Approximately 7.5V ★ MBIB1295E
5	G		<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>Warm-up condition</li> <li>Engine speed: 2,000 rpm</li> </ul>	Approximately 8.0V ★ MBIB1296E

# DTC P2146, P2149 FUEL INJECTOR POWER SUPPLY

[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
21 22 23 24	G P W W	Fuel injector No. 2 Fuel injector No. 2 Fuel injector No. 3 Fuel injector No. 3	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	<p>Approximately 7.5V ★</p>  <p>MBIB1297E</p>
			<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>Approximately 8.0V ★</p>  <p>MBIB1298E</p>
40 41 42 43	W GR W B	Fuel injector No. 4 Fuel injector No. 4 Fuel injector No. 1 Fuel injector No. 1	<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	<p>Approximately 7.5V ★</p>  <p>MBIB1297E</p>
			<p><b>[Engine is running]</b></p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>Approximately 8.0V ★</p>  <p>MBIB1298E</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## On Board Diagnosis Logic

GBS000B0

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P2146 2146	No. 1 and 4 cylinder fuel injector power supply circuit open	An improper voltage signal is sent to ECM through No. 1 and 4 cylinder fuel injector.	<ul style="list-style-type: none"> <li>● Harness or connectors (The fuel injector circuit is open.)</li> </ul>
P2149 2149	No. 2 and 3 cylinder fuel injector power supply circuit open	An improper voltage signal is sent to ECM through No. 2 and 3 cylinder fuel injector.	

## DTC Confirmation Procedure

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### TESTING CONDITION

Before performing the following procedure, confirm the ambient temperature is more than -20°C (-4°F).

#### ④ WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for at least 5 seconds.
4. If DTC is detected, go to [EC-1273, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

#### ⊗ WITHOUT CONSULT-II

1. Start engine and let it idle for at least 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-1273, "Diagnostic Procedure"](#) .

# DTC P2146, P2149 FUEL INJECTOR POWER SUPPLY



[YD]

## Wiring Diagram

GBS000BQ

### EC-INJ/PW-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC




## Diagnostic Procedure

### 1. CHECK FUEL INJECTOR POWER CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Disconnect fuel injector (1) harness connector.
4. Check harness continuity between the following terminals corresponding to the malfunctioning cylinder.  
Refer to Wiring Diagram.

Terminal		Cylinder
ECM	Fuel injector	
4	1	No.1
5	1	No.2
5	1	No.3
4	1	No.4



**Continuity should exist.**

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 2.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

### 2. CHECK INTERMITTENT INCIDENT

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

**>> INSPECTION END**

# DTC P2147, P2148 FUEL INJECTOR CIRCUIT

[YD]


## DTC P2147, P2148 FUEL INJECTOR CIRCUIT

PF16600

### Component Description

GBS000BS

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the fuel injector circuit, the coil in the fuel injector is energized. The energized coil pulls the needle valve back and allows fuel to flow through the fuel injector into the cylinder. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the fuel injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.



### CONSULT-II Reference Value in Data Monitor Mode

GBS000BT

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
MAIN INJ WID	<ul style="list-style-type: none"> <li>Engine: After warming up</li> </ul>	No load	0.50 - 0.70 msec
	<ul style="list-style-type: none"> <li>Shift lever: P or N (A/T), Neutral (M/T)</li> <li>Idle speed</li> </ul>	Blower fan switch: ON Rear window defogger switch: ON	0.50 - 0.80 msec

### ECM Terminals and Reference Value

GBS000BU

Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-II.

#### CAUTION:




**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
4	V	Fuel injector power supply (For cylinder No. 1 and 4) Fuel injector power supply (For cylinder No. 2 and 3)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>Warm-up condition</li> <li>Idle speed</li> </ul> <b>NOTE:</b> The pulse cycle changes depending on rpm at idle	Approximately 7.5V ★ MBIB1295E
5	G		<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>Warm-up condition</li> <li>Engine speed: 2,000 rpm</li> </ul>	Approximately 8.0V ★ MBIB1296E
21 22 23 24	G P W W	Fuel injector No. 2 Fuel injector No. 2 Fuel injector No. 3 Fuel injector No. 3	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>Warm-up condition</li> <li>Idle speed</li> </ul> <b>NOTE:</b> The pulse cycle changes depending on rpm at idle	Approximately 7.5V ★ MBIB1297E



# DTC P2147, P2148 FUEL INJECTOR CIRCUIT

[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
			<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>Approximately 8.0V ★</p>  <p>MBIB1298E</p>
40 41 42 43	W GR W B	Fuel injector No. 4 Fuel injector No. 4 Fuel injector No. 1 Fuel injector No. 1	<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul> <p><b>NOTE:</b> The pulse cycle changes depending on rpm at idle</p>	<p>Approximately 7.5V ★</p>  <p>MBIB1297E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	<p>Approximately 8.0V ★</p>  <p>MBIB1298E</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## On Board Diagnosis Logic

GBS000BV

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P2147 2147	Fuel injector circuit low input	ECM detects the fuel injector circuit is shorted to ground.	<ul style="list-style-type: none"> <li>● Harness or connectors (The fuel injector circuit is shorted.)</li> </ul>
P2148 2148	Fuel injector circuit high input	ECM detects the fuel injector circuit is shorted to power.	

## DTC Confirmation Procedure

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### ④ WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for at least 5 seconds.
4. If DTC is detected, go to [EC-1278, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

### ⊗ WITHOUT CONSULT-II

1. Start engine and let it idle for at least 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-1278, "Diagnostic Procedure"](#) .

# DTC P2147, P2148 FUEL INJECTOR CIRCUIT


[YD]

## Wiring Diagram

GBS000BX

### EC-INJECT-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC




4	5	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6
		43	42	41	40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25
	3	62	61	60	59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44
1	2	81	80	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64	63



## Diagnostic Procedure

### 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body.  
Refer to [EC-1066, "Ground Inspection"](#).



← : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace ground connections.

**2. CHECK ECM OUTPUT SIGNAL CIRCUIT FOR OPEN OR SHORT**

1. Disconnect fuel injector (1) harness connector.
2. Disconnect ECM harness connector.
3. Check harness continuity between the following terminals corresponding to the malfunctioning cylinder. Refer to Wiring Diagram.



Cylinder	Terminal		Continuity
	Fuel injector	ECM	
No.1	1	42, 43	Should not exist
		4	Should exist
	2	42,43	Should exist
		4	Should not exist
No.2	1	21, 22	Should not exist
		5	Should exist
	2	21, 22	Should exist
		5	Should not exist
No.3	1	23, 24	Should not exist
		5	Should exist
	2	23, 24	Should exist
		5	Should not exist
No.4	1	40, 41	Should not exist
		4	Should exist
	2	40, 41	Should exist
		4	Should not exist

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace.

**3. CHECK FUEL INJECTOR**

Refer to [EC-1280, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

**4. REPLACE FUEL INJECTOR**

1. Replace fuel injector of malfunctioning cylinder.
2. Perform Injector Adjustment Value Registration. Refer to [EC-1014, "Injector Adjustment Value Registration"](#) .

>> INSPECTION END

**5. CHECK INTERMITTENT INCIDENT**

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


**Component Inspection****FUEL INJECTOR**

GBS000BZ

1. Disconnect fuel injector harness connector.
2. Check resistance between terminals as shown in the figure.

**Resistance: 0.2 - 0.8Ω [at 10 - 60°C (50 - 140°F)]**

3. If NG, replace fuel injector.

**Removal and Installation****FUEL INJECTOR**

GBS000C0

Refer to [EM-188, "INJECTION TUBE AND FUEL INJECTOR"](#) .


## DTC P2228, P2229 BARO SENSOR

PFP:23731

### Description

GBS000C1

The barometric pressure sensor is built into ECM. The sensor detects ambient barometric pressure and sends the voltage signal to the microcomputer.



GBS000C2

### On Board Diagnosis Logic

The MIL will not light up for these self-diagnoses.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P2228 2228	Barometric pressure sensor circuit low input	An excessively low voltage from the barometric pressure sensor (built-into ECM) is sent to ECM.	● ECM
P2229 2228	Barometric pressure sensor circuit high input	An excessively high voltage from the barometric pressure sensor (built-into ECM) is sent to ECM.	

### DTC Confirmation Procedure


GBS000C3

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### Ⓟ WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-1282. "Diagnostic Procedure"](#) .



#### ⓧ WITHOUT CONSULT-II

1. Turn ignition switch ON and wait at least 5 seconds.
2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
4. If DTC is detected, go to [EC-1282. "Diagnostic Procedure"](#) .

---

**Diagnostic Procedure****1. INSPECTION START**

---

**① With CONSULT-II**

1. Turn ignition switch ON.
2. Select "SELF DIAG RESULTS" mode with CONSULT-II.
3. Touch "ERASE".
4. Perform [EC-1281, "DTC Confirmation Procedure"](#) , again.
5. Is DTC P2228 or P2229 displayed again?

**② Without CONSULT-II**

1. Turn ignition switch ON.
2. Erase the Diagnostic Test Mode II (Self-diagnostic results) memory. Refer to [EC-1016](#) .
3. Perform [EC-1281, "DTC Confirmation Procedure"](#) , again.
4. Is DTC 2228 or 2229 displayed again?

Yes or No

Yes >> GO TO 2.

No >> **INSPECTION END**

**2. REPLACE ECM**

---

1. Replace ECM.
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [BL-83, "ECM Re-communicating Function"](#) .
3. Perform Fuel Pump Learning Valve Clearing. Refer to [EC-1013, "Fuel Pump Learning Value Clearing"](#) .
4. Perform Injector Adjustment Value Registration. Refer to [EC-1014, "Injector Adjustment Value Registration"](#) .

>> **INSPECTION END**



# GLOW CONTROL SYSTEM

[YD]

## GLOW CONTROL SYSTEM

PFP:25230

### Description SYSTEM DESCRIPTION

GBS000C5

Sensor	Input Signal to ECM	ECM Function	Actuator
Crankshaft position sensor	Engine speed	Glow control	Glow lamp*
Engine coolant temperature sensor	Engine coolant temperature		Glow relay Glow plugs

\*: The output signal is sent from the ECM through CAN communication line.

When engine coolant temperature is more than approximately 80°C (176°F), the glow relay turns off.  
When engine coolant temperature is lower than approximately 80°C (176°F):


- Ignition switch ON  
After ignition switch has turned to ON, the glow relay turns ON for a certain period of time in relation to engine coolant temperature, allowing current to flow through glow plug.
- Cranking  
The glow relay turns ON, allowing current to flow through glow plug.
- Starting  
After engine has started, current continues to flow through glow plug (after-glow mode) for a certain period in relation to engine coolant temperature.

The glow indicator lamp turns ON for a certain period of time in relation to engine coolant temperature at the time glow relay is turned ON.

### COMPONENT DESCRIPTION

#### Glow Plug

The glow plug is provided with a ceramic heating element to obtain a high-temperature resistance. It glows in response to a signal sent from the ECM, allowing current to flow through the glow plug via the glow relay.





# GLOW CONTROL SYSTEM

[YD]

## Wiring Diagram

GBS000C6

EC-GLOW-01



MBWA1329E

## Diagnostic Procedure

### 1. INSPECTION START

Check fuel level, fuel supplying system, starter motor, etc.

OK or NG


- OK >> GO TO 2.
- NG >> Correct.

### 2. CHECK INSTALLATION

Check that glow plug nut (1) and all glow plug connecting plate nuts (2) are installed properly.

OK or NG


- OK >> GO TO 3.
- NG >> Install properly.



### 3. CHECK GLOW INDICATOR LAMP OPERATION


#### Ⓜ With CONSULT-II

1. Turn ignition switch ON.
2. Select "COOLAN TEMP/S" in "DATA MONITOR" mode with CONSULT-II.
3. Confirm that "COOLAN TEMP/S" indicates below 80°C (176°F). If it indicates above 80°C (176°F), cool down engine.
4. Turn ignition switch OFF, wait at least 5 seconds and then turn ON.
5. Make sure that glow indicator lamp is turned ON for 1.5 seconds or more after turning ignition switch ON, and then glow indicator lamp turned OFF.



#### ⊗ Without CONSULT-II

1. Set the tester probe between ECM terminal 51 (engine coolant temperature sensor signal) and ground.
2. Confirm that the voltage indicates above 1.53V. If it indicates below 1.53V, cool down engine.
3. Turn ignition switch OFF, wait at least 5 seconds and then turn ON.
4. Make sure that glow indicator lamp is turned ON for 1.5 seconds or more after turning ignition switch ON, and then glow indicator lamp turned OFF.




OK or NG

- OK >> GO TO 4.
- NG >> GO TO 5.

## 4. CHECK GLOW CONTROL SYSTEM OVERALL FUNCTION


### ☑ With CONSULT-II

1. Select "COOLAN TEMP/S" in "DATA MONITOR" mode with CONSULT-II.
2. Confirm that "COOLAN TEMP/S" indicates approximately 25°C (77°F). If NG, cool down engine.
3. Turn ignition switch OFF.
4. Set voltmeter probe between glow plug and engine body.
5. Turn ignition switch ON.




6. Check the voltage between glow plug and engine body under the following conditions.

Conditions	Voltage
For 20 seconds after turning ignition switch ON	Battery voltage
More than 20 seconds after turning ignition switch ON	Approx. 0V




### ☒ Without CONSULT-II

1. Set the tester probe between ECM terminal 51 (engine coolant temperature sensor signal) and ground.
2. Confirm that the voltage indicates approximately 3.62V. If NG, cool down engine.
3. Turn ignition switch OFF.
4. Set voltmeter probe between glow plug and engine body.
5. Turn ignition switch ON.



6. Check the voltage between glow plug and engine body under the following conditions.

Conditions	Voltage
For 20 seconds after turning ignition switch ON	Battery voltage
More than 20 seconds after turning ignition switch ON	Approx. 0V



OK or NG

- OK >> **INSPECTION END**  
 NG >> GO TO 7.

## 5. CHECK DTC

Check that DTC U1000 is not displayed.

Yes or No

- Yes >> Perform trouble diagnoses for DTC U1000, refer to [EC-1067, "DTC U1000 CAN COMMUNICATION LINE"](#).
- No >> GO TO 6.

## 6. CHECK COMBINATON METER OPERATION


Does combination meter operate normally?

Yes or No

- Yes >> GO TO 14.
- No >> Check combination meter circuit. Refer to [DI-4, "COMBINATION METERS"](#).

## 7. CHECK GLOW RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect glow relay (1).




3. Check voltage between glow relay terminals 1, 3 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 9.
- NG >> GO TO 8.



## 8. DETECT MALFUNCTIONING PART

Check the following.

- 60A fusible link
- Harness for open or short between glow relay and battery

>> Repair harness or connectors.

---

## 9. CHECK GLOW RELAY OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 37 and glow relay terminal 2.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 11.  
NG >> GO TO 10.

---

## 10. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors E8, F2
- Harness for open or short between glow relay and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 11. CHECK HARNESS CONTINUITY BETWEEN GLOW RELAY AND GLOW PLUG FOR OPEN AND SHORT

---

1. Disconnect glow plug harness connector.
2. Check harness continuity between glow relay terminal 5 and glow plug harness connector.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 13.  
NG >> GO TO 12.

---

## 12. DETECT MALFUNCTIONING PART

---

Check the following.

- Harness connectors E7, F8
- Harness for open or short between glow relay and glow plug

>> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 13. CHECK GLOW RELAY

---

Refer to [EC-1289, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 14.  
NG >> Replace glow relay.

---

## 14. CHECK GLOW PLUG

---

Refer to [EC-1289, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 15.  
NG >> Replace glow plug.

## 15. CHECK INTERMITTENT INCIDENT

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


### Component Inspection GLOW RELAY

GBS000C8

Check continuity between glow relay terminals (3) and (5) under the following conditions.

Conditions	Continuity
12V direct current supply between terminals (1) and (2)	Yes
No current supply	No

Operation takes less than 1 second.



### GLOW PLUG


1. Remove glow plug connecting plate.
2. Check glow plug resistance.

**Resistance: Approximately 0.8 Ω [at 25°C (77°F)]**

**NOTE:**

- Do not bump glow plug heating element. If it is bumped, replace glow plug with a new one.
- If glow plug is dropped from a height of 10 cm (3.94 in) or higher, replace with a new one.
- If glow plug installation hole is contaminated with carbon, remove it with a reamer or suitable tool.
- Hand-tighten glow plug by turning it two or three times, then tighten using a tool to specified torque.

: 20.1 N-m (2.1 kg-m, 15 ft-lb)



### Removal and Installation GLOW PLUG

GBS000C9

Refer to [EM-185, "GLOW PLUG"](#) .

## EGR VOLUME CONTROL SYSTEM

PFP:14710

### Description SYSTEM DESCRIPTION

GBS000CA


Sensor	Input Signal to ECM	ECM Function	Actuator
Crankshaft position sensor	Engine speed	EGR volume control	EGR volume control valve
Vehicle speed sensor*	Vehicle speed		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Accelerator pedal position sensor	Accelerator pedal position		
Mass air flow sensor	Amount of intake air		
Air conditioner switch*	Air conditioner operation		

\*: This signal is sent to the ECM through CAN communication line.

This system controls flow rate of EGR led from exhaust manifold to intake manifold. The opening of the EGR by-pass passage in the EGR volume control valve changes to control the flow rate. A built-in step motor moves the valve in steps corresponding to the ECM output pulses. The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions.

The EGR volume control valve remains close under the following conditions.


- Engine stopped
- Engine starting
- Low engine coolant temperature
- Excessively high engine coolant temperature
- High engine speed
- Accelerator pedal fully depressed



### COMPONENT DESCRIPTION

#### EGR Volume Control Valve

The EGR volume control valve uses a step motor to control the flow rate of EGR from exhaust manifold. This motor has four winding phases. It operates according to the output pulse signal of the ECM. Two windings are turned ON and OFF in sequence. Each time an ON pulse is issued, the valve opens or closes, changing the flow rate. When no change in the flow rate is needed, the ECM does not issue the pulse signal. A certain voltage signal is issued so that the valve remains at that particular opening.





# EGR VOLUME CONTROL SYSTEM

[YD]

## CONSULT-II Reference Value in Data Monitor Mode

GBS000CB

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
EGR VOL CON/V	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Air conditioner switch: OFF</li> <li>● Shift lever: P or N (A/T), Neutral (M/T)</li> <li>● No load</li> </ul>	After 1 minute at idle	More than 10 steps
		Revvng engine from idle to 3,200 rpm	0 step

## ECM Terminals and Reference Value

GBS000CC

Specification data are reference values and are measured between each terminal and ground.

### CAUTION:

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
25 26 27 28	Y O GR V	EGR volume control valve	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	0.1 - 14V (Voltage signals of each ECM terminals differ according to the control position of EGR volume control valve.)
105 113	BR BR	ECM relay (self shut-off)	<b>[Ignition switch ON]</b> <b>[Ignition switch OFF]</b> <ul style="list-style-type: none"> <li>● For a few seconds after turning ignition switch OFF</li> </ul>	Approximately 1.0V
			<b>[Ignition switch OFF]</b> <ul style="list-style-type: none"> <li>● More than a few seconds passed after turning ignition switch OFF</li> </ul>	BATTERY VOLTAGE (11 - 14V)
119 120	R G	Power supply for ECM	<b>[Ignition switch ON]</b>	BATTERY VOLTAGE (11 - 14V)

# EGR VOLUME CONTROL SYSTEM







[YD]

GBS000CD

## Wiring Diagram

### EC-EGRVLV-01

— : DETECTABLE LINE FOR DTC  
 — : NON-DETECTABLE LINE FOR DTC




MBWA1057E

## Diagnostic Procedure

### 1. CHECK EGR VOLUME CONTROL SYSTEM OVERALL FUNCTION

1. Turn ignition switch OFF.
2. Set the oscilloscope probe between ECM terminals 25, 26, 27, 28 and ground.
3. Start engine and let it idle.
4. Check the oscilloscope screen when revving engine up to 3,200 rpm and return to idle.




The pulse signal as shown in the figure should appear.

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 2.

### 2. CHECK EGR VOLUME CONTROL VALVE POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect EGR volume control valve (1) harness connector.
  - ↶ : Vehicle front
3. Turn ignition switch ON.




4. Check voltage between EGR volume control valve terminals 2, 5 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



## 3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E9, F4
- Harness for open and short between ECM and EGR volume control valve
- Harness for open and short between IPDM E/R and EGR volume control valve

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 4. CHECK EGR VOLUME CONTROL VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminals and EGR volume control valve terminals as follows. Refer to Wiring Diagram.

ECM terminal	EGR volume control valve terminal
25	1
26	6
27	3
28	4

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 5. CHECK EGR VOLUME CONTROL VALVE

Refer to [EC-1295, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace EGR volume control valve.

## 6. CHECK EGR PASSAGE

Check the following for clogging and cracks.

- EGR tube
- EGR cooler (A/T models)

OK or NG

OK >> GO TO 7.

NG >> Repair or replace EGR passage.

## 7. CHECK INTERMITTENT INCIDENT


Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

## Component Inspection EGR VOLUME CONTROL VALVE

① With CONSULT-II

1. Disconnect EGR volume control valve (1) harness connector.
  - ↶ : Vehicle front




2. Check resistance between the following terminals.
  - terminal 2 and terminals 1, 3
  - terminal 5 and terminals 4, 6

Temperature °C (°F)	Resistance Ω
20 (68)	13 - 17

If NG, replace EGR volume control valve.  
If OK, go to next step.

3. Remove EGR volume control valve from cylinder head.
4. Reconnect EGR volume control valve harness connector.
5. Turn ignition switch ON.



6. Perform "EGR VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that EGR volume control valve shaft moves smoothly forward and backward according to the valve opening.

ACTIVE TEST	
EGR VOL CONT/V	20 step
MONITOR	
CKPS-RPM (TDC)	XXX rpm

SEF819Y


If NG, replace the EGR volume control valve.

**NOTE:**

When installing the EGR volume control valve, make sure that the shaft is in the same position before checking.

⊗ **Without CONSULT-II**

1. Disconnect EGR volume control valve (1) harness connector.
  - ← : Vehicle front




2. Check resistance between the following terminals.
  - terminal 2 and terminals 1, 3
  - terminal 5 and terminals 4, 6

Temperature °C (°F)	Resistance Ω
20 (68)	13 - 17

If NG, replace EGR volume control valve.  
If OK, go to next step.


3. Remove EGR volume control valve from cylinder head.
4. Reconnect EGR volume control valve harness connector.
5. Turn ignition switch ON and OFF



6. Check that EGR volume control valve shaft moves smoothly forward and backward according to the ignition switch position. If NG, replace EGR volume control valve.

**NOTE:**

When installing the EGR volume control valve, make sure that the shaft is in the same position before checking.



## Removal and Installation EGR VOLUME CONTROL VALVE

Refer to [EM-164, "INTAKE MANIFOLD"](#) .


## TC BOOST CONTROL SOLENOID VALVE

PFP:14956

### Description


The load from the turbocharger boost control solenoid valve controls the actuator. By changing the variable nozzle vane opening through the rods, the intake air volume is adjusted.

GBS000CH



The turbocharger boost control solenoid valve (1) is moved by ON/OFF pulse from the ECM. The longer the ON pulse, the charge air pressure rises.

- ←: Vehicle front
- Alternator (2)



A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

# TC BOOST CONTROL SOLENOID VALVE

[YD]



GBS000CI

## ECM Terminals and Reference Value

Specification data are reference values, and are measured between each terminal and ground.  
Pulse signal is measured by CONSULT-II.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
6	BR	Turbocharger boost control solenoid valve	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 6.3V ★  <small>MBIB0889E</small>
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed: 2,000 rpm</li> </ul>	Approximately 8.6V ★  <small>MBIB0890E</small>
105 113	BR BR	ECM relay (self shut-off)	<b>[Ignition switch ON]</b> <b>[Ignition switch OFF]</b> <ul style="list-style-type: none"> <li>● For a few seconds after turning ignition switch OFF</li> </ul>	Approximately 1.0V
			<b>[Ignition switch OFF]</b> <ul style="list-style-type: none"> <li>● More than a few seconds after turning ignition switch OFF</li> </ul>	BATTERY VOLTAGE (11 - 14V)
119 120	R G	Power supply for ECM	<b>[Ignition switch ON]</b>	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)









# TC BOOST CONTROL SOLENOID VALVE

[YD]

## Wiring Diagram

GBS000CJ

### EC-TCCSV-01



MBWA1058E


## Diagnostic Procedure

### 1. CHECK OVERALL FUNCTION

1. Start engine and let it idle.
2. Make sure that turbocharger control actuator (1) rod moves slightly when engine is started.


OK or NG

- OK >> **INSPECTION END**  
 NG >> GO TO 2.



### 2. CHECK TURBOCHARGER BOOST CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect turbocharger boost control solenoid valve (1) harness connector.
  - ←: Vehicle front
  - Alternator (2)
3. Turn ignition switch ON.




4. Check voltage between turbocharger boost control solenoid valve terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 4.  
 NG >> GO TO 3.



### 3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E9, F4
- Harness for open or short between ECM and turbocharger boost control solenoid valve
- Harness for open or short between IPDM E/R and turbocharger boost control solenoid valve

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 4. CHECK TURBOCHARGER BOOST CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 6 and turbocharger boost control solenoid valve terminal 2. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 5. CHECK TURBOCHARGER BOOST CONTROL SOLENOID VALVE

Refer to [EC-1301, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace turbocharger boost control solenoid valve.

## 6. CHECK INTERMITTENT INCIDENT


Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

### Component Inspection TURBOCHARGER BOOST CONTROL SOLENOID VALVE

GBS000CL

1. Disconnect turbocharger boost control solenoid valve (1) harness connector.
  - ↶: Vehicle front
  - Alternator (2)




2. Apply 12V direct current between turbocharger boost control solenoid valve terminals.
3. Check air passage continuity of turbocharger boost control solenoid valve under the following conditions.

CONDITIONS	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12V direct current supply between terminals (1) and (2)	Yes	No
No supply	No	Yes

**Operation takes less than 1 second.**

If NG, replace turbocharger boost control solenoid valve.



### Removal and Installation TURBOCHARGER BOOST CONTROL SOLENOID VALVE

GBS000CM

Refer to [EM-162, "CHARGE AIR COOLER"](#) .

# INTAKE AIR CONTROL VALVE CONTROL SOLENOID VALVE

[YD]


## INTAKE AIR CONTROL VALVE CONTROL SOLENOID VALVE

PFP:16188

### Description

GBS000CN

Vibration when stopping the engine can be controlled by cutting intake air right before the fuel is cut. The intake air control valve control solenoid valve (1) controls the ON-OFF load of the intake air control valve actuator. As a result, the intake air control valve control solenoid valve will be turned ON when the ignition switch is turned OFF with the engine running and when the engine stalls. After the engine has stopped, the intake air control valve control solenoid valve will return to fully open.



- ⇐: Vehicle front
- Electronic controlled engine mount control solenoid valve (2)
- Oil filter (3)

### ECM Terminals and Reference Value

GBS000CO

Specification data are reference values, and are measured between each terminal and ground.

#### CAUTION:

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
15	GR	Intake air control valve control solenoid valve	[Engine is running]	BATTERY VOLTAGE (11 - 14V)
			[Engine is running] [Ignition switch OFF]	Approximately 0.3V ● For a few seconds after turning ignition switch OFF
105 113	BR BR	ECM relay (self shut-off)	[Ignition switch OFF]	Approximately 1.0V ● For a few seconds after turning ignition switch OFF
			[Ignition switch OFF]	BATTERY VOLTAGE (11 - 14V) ● More than a few seconds after turning ignition switch OFF
119 120	R G	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)


# INTAKE AIR CONTROL VALVE CONTROL SOLENOID VALVE

[YD]





## Wiring Diagram

GBS000CP

EC-INT/V-01



A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M




## Diagnostic Procedure

### 1. CHECK OVERALL FUNCTION

1. Start engine and let it idle.
2. Make sure that intake air control valve actuator (1) rod moves when turning ignition switch OFF.

OK or NG

- OK >> **INSPECTION END**  
 NG >> GO TO 2.




### 2. CHECK VACUUM SOURCE

1. Turn ignition switch OFF.
2. Disconnect vacuum hose connected to intake air control valve actuator (1).
3. Start engine and let it idle.
4. Check vacuum hose for vacuum existence under the following conditions.

CONDITIONS	vacuum
For a few seconds after turning ignition switch OFF	should exist
Except above	should not exist

OK or NG

- OK >> GO TO 9.  
 NG >> GO TO 3.




### 3. CHECK VACUUM HOSE

1. Turn ignition switch OFF.
2. Check vacuum hoses and vacuum gallery for clogging, cracks or improper connection.  
 Refer to [EC-1005, "Vacuum Hose Drawing"](#) .


OK or NG

- OK >> GO TO 4.  
 NG >> Repair or replace vacuum hoses and vacuum gallery.



## 4. CHECK INTAKE AIR CONTROL VALVE CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect intake air control valve control solenoid valve (1) harness connector.
  - ⇐: Vehicle front
  - Electronic controlled engine mount control solenoid valve (2)
  - Oil filter (3)
3. Turn ignition switch ON.




4. Check voltage between intake air control valve control solenoid valve terminal 2 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



## 5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E9, F4
- Harness for open or short between IPDM E/R and intake air control valve control solenoid valve
- Harness for open or short between ECM and intake air control valve control solenoid valve

>> Repair open circuit or short to power in harness or connectors.

## 6. CHECK INTAKE AIR CONTROL VALVE CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 15 and intake air control valve control solenoid valve terminal 1. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 7. CHECK INTAKE AIR CONTROL VALVE CONTROL SOLENOID VALVE

Refer to [EC-1306, "Component Inspection"](#).

OK or NG

- OK >> GO TO 8.
- NG >> Replace intake air control valve control solenoid valve.

## 8. CHECK VACUUM PUMP

Refer to [EM-186, "VACUUM PUMP"](#) .

OK or NG


- OK >> GO TO 9.
- NG >> Replace vacuum pump assembly.

## 9. CHECK INTAKE AIR CONTROL VALVE ACTUATOR

1. Turn ignition switch OFF.
2. Install a vacuum pump A to intake air control valve actuator (1).
3. Make sure that the intake air control valve actuator rod moves smoothly when applying vacuum of  $-53.3\text{ kPa}$  ( $-533\text{ mbar}$ ,  $-400\text{ mmHg}$ ,  $-15.75\text{ inHg}$ ) and releasing it.

OK or NG

- OK >> GO TO 10.
- NG >> Replace intake air control valve actuator.



## 10. CHECK INTERMITTENT INCIDENT


Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

### Component Inspection INTAKE AIR CONTROL VALVE CONTROL SOLENOID VALVE

GBS000CR

1. Disconnect intake air control valve control solenoid valve (1) harness connector.
  - Vehicle front
  - Electronic controlled engine mount control solenoid valve (2)
  - Oil filter (3)
2. Apply 12V direct current between turbocharger boost control solenoid valve terminals.




3. Check air passage continuity of intake air control valve control solenoid valve under the following conditions.

CONDITIONS	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12V direct current supply between terminals (1) and (2)	Yes	No
No supply	No	Yes

**Operation takes less than 1 second.**

If NG, replace intake air control valve control solenoid valve.





# REFRIGERANT PRESSURE SENSOR

[YD]

## REFRIGERANT PRESSURE SENSOR



PFP:92136

### Component Description

GBS000CY

The refrigerant pressure sensor (1) is installed at the condenser of the air conditioner system. The sensor uses an electrostatic volume pressure transducer to convert refrigerant pressure to voltage. The voltage signal is sent to ECM, and ECM controls cooling fan system.

-  Vehicle front



### ECM Terminals and Reference Value

GBS000CZ

Specification data are reference values, and are measured between each terminal and ground.

**CAUTION:**

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
53	W	Refrigerant pressure sensor	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>• Warm-up condition</li> <li>• Both A/C switch and blower switch: ON (Compressor operates)</li> </ul>	1.0 - 4.0V
64	V	Sensor power supply (Refrigerant pressure sensor)	<b>[Ignition switch ON]</b>	Approximately 5.3V
72	BR	Refrigerant pressure sensor ground	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>• Warm-up condition</li> <li>• Idle speed</li> </ul>	Approximately 0.3V

# REFRIGERANT PRESSURE SENSOR



[YD]

## Wiring Diagram

GBS000D0

### EC-RP/SEN-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



MBWA1064E

## Diagnostic Procedure


### 1. CHECK REFRIGERANT PRESSURE SENSOR OVERALL FUNCTION

1. Start engine and warm it up to normal operating temperature.
2. Turn A/C switch and blower switch ON.
3. Check voltage between ECM terminal 53 and ground with CONSULT-II or tester.

Voltage: 1.0 - 4.0V


OK or NG

- OK >> **INSPECTION END**  
 NG >> GO TO 2.



### 2. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.
2. Loosen and retighten three ground screws on the body. Refer to [EC-1066](#), "Ground Inspection".



↙ : Vehicle front


- |                                    |  |                    |
|------------------------------------|--|--------------------|
| 1. Body ground E21                 | 2. ECM   | 3. Body ground E41 |
| 4. A/C high-pressure service valve | 5. ABS actuator and electric unit (control unit) | 6. Body ground E61 |

OK or NG

- OK >> GO TO 3.  
 NG >> Repair or replace ground connections.

### 3. CHECK REFRIGERANT PRESSURE SENSOR POWER SUPPLY CIRCUIT

1. Disconnect refrigerant pressure sensor (1) harness connector.
  - ⇐: Vehicle front
2. Turn ignition switch ON.




3. Check voltage between refrigerant pressure sensor terminal 3 and ground with CONSULT-II or tester.

**Voltage: Approximately 5.3V**

OK or NG

- OK >> GO TO 5.  
NG >> GO TO 4.



### 4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E8, F2
- Harness for open or short between ECM and refrigerant pressure sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

### 5. CHECK REFRIGERANT PRESSURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between refrigerant pressure sensor terminal 1 and ECM terminal 72. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.  
NG >> GO TO 6.

### 6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E8, F2
- Harness for open or short between ECM and refrigerant pressure sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

---

**7. CHECK REFRIGERANT PRESSURE SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

---

1. Check harness continuity between ECM terminal 53 and refrigerant pressure sensor terminal 2.  
Refer to Wiring Diagram.

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 9.
- NG >> GO TO 8.

---

**8. DETECT MALFUNCTIONING PART**

---

Check the following.

- Harness connectors E8, F2
- Harness for open or short between ECM and refrigerant pressure sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

---

**9. CHECK INTERMITTENT INCIDENT**

---

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> Replace refrigerant pressure sensor.
- NG >> Repair or replace.

**Removal and Installation**  
**REFRIGERANT PRESSURE SENSOR**

GBS000D2

Refer to [MTC-121, "Removal and Installation for Refrigerant Pressure Sensor"](#) .

# BRAKE SWITCH

[YD]


## BRAKE SWITCH

PFP:25230

### Description STOP LAMP SWITCH

GBS000D3

The stop lamp switch is installed to brake pedal bracket. The switch senses brake pedal position and sends an ON-OFF signal to the ECM. The ECM uses the signal to control the fuel injection control system.



### ASC D BRAKE SWITCH (MODELS WITH ASC D)

When depress on the brake pedal, ASC D brake switch is turned OFF and stop lamp switch is turned ON. ECM detects the state of the brake pedal by this input of two kinds (ON/OFF signal)

Refer to [EC-1337, "AUTOMATIC SPEED CONTROL DEVICE \(ASC D\)"](#) for the ASC D function.

### CONSULT-II Reference Value in Data Monitor Mode

GBS000D4

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
BRAKE SW (Stop lamp switch)	● Ignition switch: ON	Brake pedal: Fully released	OFF
		Brake pedal: Slightly depressed	ON
BRAKE SW2 (ASC D brake switch)	● Ignition switch: ON	● Brake pedal: Fully released (A/T) ● Clutch pedal and brake pedal: Fully released (M/T)	OFF
		● Brake pedal: Slightly depressed (A/T) ● Clutch pedal and/or brake pedal: Slightly depressed (M/T)	ON

### ECM Terminals and Reference Value

GBS000D5

Specification data are reference values and are measured between each terminal and ground.

#### CAUTION:

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
100	V	Stop lamp switch	[Ignition switch OFF] ● Brake pedal: Fully released	Approximately 0V
			[Ignition switch OFF] ● Brake pedal: Slightly depressed	BATTERY VOLTAGE (11 - 14V)
101	W	ASC D brake switch	[Ignition switch ON] ● Brake pedal: Fully released (A/T) ● Clutch pedal and brake pedal: Fully released (M/T)	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch ON] ● Brake pedal: Slightly depressed (A/T) ● Clutch pedal and/or brake pedal: Slightly depressed (M/T)	Approximately 0V


# BRAKE SWITCH

[YD]



## Wiring Diagram

GBS000D6

### EC-ASCBOF-01



- : DETECTABLE LINE FOR DTC
- : NON-DETECTABLE LINE FOR DTC
- ⬡ : WITH A/T
- ⬢ : WITH M/T
- \*1 W : ⬡ V : ⬢
- \*2 1 : ⬡ 2 : ⬢
- \*3 2 : ⬡ 1 : ⬢



REFER TO THE FOLLOWING.  
 (E103) - FUSE BLOCK-JUNCTION BOX (J/B)

A  
 EC  
 C  
 D  
 E  
 F  
 G  
 H  
 I  
 J  
 K  
 L  
 M

# BRAKE SWITCH

[YD]

GBS000D7


## Diagnostic Procedure A/T MODELS

### 1. CHECK OVERALL FUNCTION-I

#### ④ With CONSULT-II

1. Turn ignition switch ON.
2. Select "BRAKE SW" in "DATA MONITOR" mode with CONSULT-II.
3. Check "BRAKE SW" indication under the following conditions.


CONDITION	INDICATION
Brake pedal: Fully released	OFF
Brake pedal: Slightly depressed	ON



#### ⊗ Without CONSULT-II

1. Turn ignition switch ON.
2. Check voltage between ECM terminal 100 and ground under the following conditions.

CONDITION	VOLTAGE
Brake pedal: Fully released	Approximately 0V
Brake pedal: Slightly depressed	Battery voltage



#### OK or NG

OK (Models with ASCD)>>GO TO 2.

OK (Models without ASCD)>>**INSPECTION END**

NG >> GO TO 3.



# BRAKE SWITCH


[YD]

## 2. CHECK OVERALL FUNCTION-II

### With CONSULT-II

Check "BRAKE SW2" indication in "DATA MONITOR" mode.

CONDITION	INDICATION
Brake pedal: Fully released	OFF
Brake pedal: Slightly depressed	ON




### Without CONSULT-II

Check voltage between ECM terminal 101 and ground under the following conditions.

CONDITION	VOLTAGE
Brake pedal: Fully released	Battery voltage
Brake pedal: Slightly depressed	Approximately 0V


OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 7.



## 3. CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch harness connector.




3. Check voltage between stop lamp switch terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.



## 4. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse
- Harness for open or short between stop lamp switch and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 5. CHECK STOP LAMP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 100 and stop lamp switch terminal 2. Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 6.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 6. CHECK STOP LAMP SWITCH

Refer to [EC-1323, "Component Inspection"](#) .


OK or NG

OK >> GO TO 11.

NG >> Replace stop lamp switch.

## 7. CHECK ASCD BRAKE SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch harness connector.
3. Turn ignition switch ON.




4. Check voltage between ASCD brake switch terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

OK >> GO TO 9.

NG >> GO TO 8.



---

## 8. DETECT MALFUNCTIONING PART

---

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse
- Harness for open or short between ASCD brake switch and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 9. CHECK ASCD BRAKE SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 101 and ASCD brake lamp switch terminal 2.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 10.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 10. CHECK ASCD BRAKE SWITCH

---

Refer to [EC-1323, "Component Inspection"](#)

OK or NG

OK >> GO TO 11.

NG >> Replace ASCD brake switch.

---

## 11. CHECK INTERMITTENT INCIDENT

---

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

# BRAKE SWITCH

[YD]


## M/T MODELS

### 1. CHECK OVERALL FUNCTION-I

#### ② With CONSULT-II

1. Turn ignition switch ON.
2. Select "BRAKE SW" in "DATA MONITOR" mode with CONSULT-II.
3. Check "BRAKE SW" indication under the following conditions.


CONDITION	INDICATION
Brake pedal: Fully released	OFF
Brake pedal: Slightly depressed	ON



#### ⊗ Without CONSULT-II

1. Turn ignition switch ON.
2. Check voltage between ECM terminal 100 and ground under the following conditions.

CONDITION	VOLTAGE
Brake pedal: Fully released	Approximately 0V
Brake pedal: Slightly depressed	Battery voltage



#### OK or NG


- OK (Models with ASCD)>>GO TO 2.
- OK (Models without ASCD)>>**INSPECTION END**
- NG >> GO TO 3.

## 2. CHECK OVERALL FUNCTION-II

### With CONSULT-II

Check "BRAKE SW2" indication in "DATA MONITOR" mode.

CONDITION	INDICATION
Clutch pedal and brake pedal: Fully released	OFF
Clutch pedal and/or brake pedal: Slightly depressed	ON




### Without CONSULT-II

Check voltage between ECM terminal 101 and ground under the following conditions.

CONDITION	VOLTAGE
Clutch pedal and brake pedal: Fully released	Battery voltage
Clutch pedal and/or brake pedal: Slightly depressed	Approximately 0V


OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 7.



## 3. CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch harness connector.




3. Check voltage between stop lamp switch terminal 2 and ground with CONSULT -II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.



## 4. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse
- Harness for open or short between stop lamp switch and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 5. CHECK STOP LAMP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 100 and stop lamp switch terminal 1.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 6.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 6. CHECK STOP LAMP SWITCH

Refer to [EC-1323, "Component Inspection"](#) .


OK or NG

OK >> GO TO 14.

NG >> Replace stop lamp switch.

## 7. CHECK ASCD BRAKE SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ASCD clutch switch harness connector.
3. Turn ignition switch ON.




4. Check voltage between ASCD clutch switch terminal 1 and ground under the following conditions with CONSULT-II or tester.

CONDITION	VOLTAGE
Brake pedal: Fully released	Battery voltage
Brake pedal: Slightly depressed	Approx. 0V

OK or NG


OK >> GO TO 12.

NG >> GO TO 8.



**8. CHECK ASCD BRAKE SWITCH POWER SUPPLY CIRCUIT**

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch harness connector.
3. Turn ignition switch ON.




4. Check voltage between ASCD brake switch terminal 1 and ground with CONSULT-II or tester.

**Voltage: Battery voltage**

OK or NG

- OK >> GO TO 10.  
NG >> GO TO 9.

**9. DETECT MALFUNCTIONING PART**

Check the following.

- Fuse block (J/B) connector E103
- 10A fuse
- Harness for open or short between ASCD brake switch and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

**10. CHECK ASCD BRAKE SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

1. Turn ignition switch OFF.
2. Check harness continuity between ASCD brake switch terminal 2 and ASCD brake clutch switch terminal 1.  
Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 11.  
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**11. CHECK ASCD BRAKE SWITCH**

Refer to [EC-1323, "Component Inspection"](#).

OK or NG

- OK >> GO TO 14.  
NG >> Replace ASCD brake switch.

---

## 12. CHECK ASCD CLUTCH SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 101 and ASCD clutch switch terminal 2.  
Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground or short to power.

OK or NG

OK >> GO TO 13.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

---

## 13. CHECK ASCD CLUTCH SWITCH

---

Refer to [EC-1323, "Component Inspection"](#) .

OK or NG

OK >> GO TO 14.

NG >> Replace ASCD clutch switch.

---

## 14. CHECK INTERMITTENT INCIDENT

---

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

**>> INSPECTION END**



# BRAKE SWITCH

[YD]


GBS000D8

## Component Inspection ASCD BRAKE SWITCH

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch harness connector.
3. Check continuity between ASCD brake switch terminals 1 and 2 under the following conditions.

Condition	Continuity
Brake pedal: Fully released	Should exist
Brake pedal: Slightly depressed	Should not exist

If NG, adjust ASCD brake switch installation, refer to [BR-6](#), "[BRAKE PEDAL](#)", and perform step 3 again.




## ASCD CLUTCH SWITCH

1. Turn ignition switch OFF.
2. Disconnect ASCD clutch switch harness connector.
3. Check continuity between ASCD clutch switch terminals 1 and 2 under the following conditions.


Condition	Continuity
Clutch pedal: Fully released	Should exist
Clutch pedal: Slightly depressed	Should not exist

If NG, adjust ASCD clutch switch installation, refer to [CL-6](#), "[CLUTCH PEDAL](#)", and perform step 3 again.



## STOP LAMP SWITCH

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch harness connector.
3. Check continuity between stop lamp switch terminals 1 and 2 under the following conditions.



Condition	Continuity
Brake pedal: Fully released	Should not exist
Brake pedal: Slightly depressed	Should exist

If NG, adjust stop lamp switch installation, refer to [BR-6](#), "[BRAKE PEDAL](#)", and perform step 3 again.

# PNP SWITCH

[YD]

## PNP SWITCH

PFP:32006

### Description

GBS000D9

When the gear position is in P or N (A/T), Neutral (M/T), park/neutral position is ON. ECM detects the position because the continuity of the line (the ON signal) exists.

### CONSULT-II Reference Value in Data Monitor Mode

GBS000DA

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
P/N POSI SW	● Ignition switch: ON	Shift lever: P or N (A/T), Neutral (M/T)	ON
		Shift lever: Except above	OFF

### ECM Terminals and Reference Value

GBS000DB

Specification data are reference values and are measured between each terminal and ground.

#### CAUTION:

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
110	G (A/T) O (M/T)	Park/Neutral position switch	[Ignition switch ON] ● Shift lever: P or N (A/T), Neutral (M/T)	Approximately 0V
			[Ignition switch ON] ● Shift lever: Except above	BATTERY VOLTAGE (11 - 14V)


# PNP SWITCH

[YD]






## Wiring Diagram

GBS000DC

### EC-PNP/SW-01



A  
EC  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



REFER TO THE FOLLOWING.  
 (M91) -SUPER MULTIPLE JUNCTION (SMJ)

\* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.


## Diagnostic Procedure A/T MODELS

### 1. CHECK OVERALL FUNCTION

**Ⓟ With CONSULT-II**

1. Turn ignition switch ON.
2. Select "P/N POSI SW" in "DATA MONITOR" mode with CONSULT-II.
3. Check "P/N POSI SW" signal under the following conditions.


Shift lever position	P/N POSI SW
P or N	ON
Except above	OFF



**ⓧ Without CONSULT-II**

1. Turn ignition switch ON.
2. Check voltage between ECM terminal 110 and ground under the following conditions.

Shift lever position	Voltage
P or N	Approximately 0V
Except above	Battery voltage



OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 2.

### 2. CHECK DTC WITH TCM

Check DTC with TCM. Refer to [AT-35, "TROUBLE DIAGNOSIS"](#) .

OK or NG

- OK >> GO TO 3.
- NG >> Perform trouble shooting relevant to DTC indicated.

### 3. CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT-I

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Disconnect combination meter harness connector.
4. Check harness continuity between ECM terminal 110 and combination meter terminal 7.  
Refer to Wiring Diagram.

**Continuity should exist.**

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

## 4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E101, M91
- Harness for open or short between ECM and combination meter

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 5. CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT-II


1. Disconnect A/T assembly harness connector (1).  
 - Illustration shows the view from under the vehicle  
 - ↶ : Vehicle front  
 - A/T oil pan (2)
2. Check harness continuity between A/T assembly terminal 9 and combination meter terminal 17.  
 Refer to Wiring Diagram.

**Continuity should exist.**

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.  
 NG >> GO TO 6.



## 6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M91, E101
- Harness connectors E8, F2
- Harness for open or short between A/T assembly and combination meter.

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 7. CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT-III

1. Check harness continuity between A/T assembly terminal 9 and TCM terminal 8.  
 Refer to [AT-99, "DTC P0615 START SIGNAL CIRCUIT"](#) .

**Continuity should exist.**

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.  
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 8. CHECK INTERMITTENT INCIDENT

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> GO TO 9.  
 NG >> Repair or replace.

## 9. REPLACE COMBINATION METER

Refer to [DI-4, "COMBINATION METERS"](#) .

>> INSPECTION END


## M/T MODELS

### 1. CHECK OVERALL FUNCTION

**Ⓜ With CONSULT-II**

1. Turn ignition switch ON.
2. Select "P/N POSI SW" in "DATA MONITOR" mode with CONSULT-II.
3. Check "P/N POSI SW" signal under the following conditions.


Shift lever position	P/N POSI SW
Neutral	ON
Except above	OFF



**ⓧ Without CONSULT-II**

1. Turn ignition switch ON.
2. Check voltage between ECM terminal 110 and ground under the following conditions.

Shift lever position	Voltage
Neutral	Approximately 0V
Except above	Battery voltage



**OK or NG**

- OK >> **INSPECTION END**
- NG >> GO TO 2.

### 2. CHECK PNP SWITCH GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch OFF.
2. Disconnect park/neutral position (PNP) switch (1) harness connector.
  - Illustration shows the view from under the vehicle
  - ⇐ : Vehicle front
  - Back-up lamp switch (2)
3. Check harness continuity between PNP switch terminal 2 and ground. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to power.

**OK or NG**

- OK >> GO TO 4.
- NG >> GO TO 3.



---

### 3. DETECT MALFUNCTIONING PART

---

A

Check the following.

- Harness connectors E8, F2
- Harness for open or short between ECM and PNP switch

EC

>> Repair open circuit or short to ground or short to power in harness or connectors.

C

---

### 4. CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

---

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 110 and PNP switch terminal 1.  
Refer to Wiring Diagram.

D

**Continuity should exist.**

E

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.

F

---

### 5. DETECT MALFUNCTIONING PART

---

G

Check the following.

- Harness connectors E8, F2
- Harness for open or short between ECM and PNP switch

H

>> Repair open circuit or short to ground or short to power in harness or connectors.

I

---

### 6. CHECK PARK/NEUTRAL POSITION SWITCH

---

J

Refer to [MT-12, "POSITION SWITCH"](#) .

OK or NG

- OK >> GO TO 7.
- NG >> Replace park/neutral position switch.

K

---

### 7. CHECK INTERMITTENT INCIDENT

---

L

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

M

# START SIGNAL

[YD]


## START SIGNAL Wiring Diagram

PFP:48750

GBS000DE

### EC-S/SIG-01


**—** : DETECTABLE LINE FOR DTC  
**—** : NON-DETECTABLE LINE FOR DTC



M2  
W



M33  
W



E20  
B



REFER TO THE FOLLOWING.

(M88) - FUSE BLOCK-  
JUNCTION BOX (J/B)

(M91) - SUPER MULTIPLE  
JUNCTION (SMJ)



# START SIGNAL

[YD]

GBS000DF


## Diagnostic Procedure

### 1. CHECK START SIGNAL OVERALL FUNCTION

#### With CONSULT-II

1. Turn ignition switch ON.
2. Check "START SIGNAL" in "DATA MONITOR" mode with CONSULT-II under the following conditions.


Condition	START SIGNAL
Ignition switch ON	OFF
Ignition switch START	ON



#### Without CONSULT-II

Check voltage between ECM terminal 99 and ground under the following conditions.

Condition	Voltage
Ignition switch ON	Approximately 0V
Ignition switch START	Battery voltage



#### OK or NG

- OK >> **INSPECTION END**  
NG >> GO TO 2.

### 2. CHECK START SIGNAL INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector and ignition switch harness connector.
3. Check harness continuity between ECM terminal 99 and ignition switch terminal 6. Refer to Wiring Diagram.

**Continuity should exist.**

4. Also check harness for short to ground and short to power.

#### OK or NG

- OK >> GO TO 4.  
NG >> GO TO 3.

### 3. DETECT MALFUNCTIONING PART

Check the following.

- 10A fuse
- Fuse block (J/B) connector M88
- Harness connectors M91, E101
- Harness for open or short between ECM and ignition switch

>> Repair open circuit or short to ground or short to power in harness or connectors.

---

**4. CHECK INTERMITTENT INCIDENT**

---

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

**>> INSPECTION END**

## ASCD INDICATOR

PFP:24814

### Component Description

GBS000DG

ASCD indicator lamp illuminates to indicate ASCD operation status. Lamp has two indicators, CRUISE and SET, and is integrated in combination meter.

CRUISE indicator illuminates when MAIN switch on ASCD steering switch is turned ON to indicated that ASCD system is ready for operation.

SET indicator illuminates when following conditions are met.

- CRUISE indicator is illuminated.
- SET/COAST switch on ASCD steering switch is turned ON while vehicle speed is within the range of ASCD setting.

SET indicator remains lit during ASCD control.

Refer to [EC-1337, "AUTOMATIC SPEED CONTROL DEVICE \(ASCD\)"](#) for the ASCD function.

A

EC

C

D

E

F

G

H

I

J

K

L

M


# ASCINDICATOR

[YD]


GBS000DH

## Wiring Diagram

### EC-ASCIND-01



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	(M23) W
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	



REFER TO THE FOLLOWING.

(M88) - FUSE BLOCK-JUNCTION BOX (J/B)

# ASCD INDICATOR

[YD]

GBS000DI

## Diagnostic Procedure

### 1. CHECK OVERALL FUNCTION

Check ASCD indicator under the following conditions.

ASCD INDICATOR	CONDITION		SPECIFICATION
CRUISE LAMP	● Ignition switch: ON	● MAIN switch: Pressed at the first time → at the 2nd time	ON → OFF
SET LAMP	● MAIN switch: ON ● When vehicle speed is between 40 km/h (25 MPH) and 185 km/h (115 MPH)	● ASCD: Operating	ON
		● ASCD: Not operating	OFF

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 2.

### 2. CHECK DTC

Check that DTC U1000 is not displayed.

OK or NG

OK >> Perform trouble diagnoses for DTC U1000. Refer to [EC-1067, "DTC U1000 CAN COMMUNICATION LINE"](#).

NG >> GO TO 3.

### 3. CHECK COMBINATION METER OPERATION

Does combination meter operate normally?

Yes or No

Yes >> GO TO 4.

No >> Check combination meter circuit. Refer to [DI-4, "COMBINATION METERS"](#).

### 4. CHECK INTERMITTENT INCIDENT

Refer to [EC-1058, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

>> **INSPECTION END**

# MIL AND DATA LINK CONNECTOR

[YD]





## MIL AND DATA LINK CONNECTOR

PFP:24814

### Wiring Diagram

GBS000DJ

### EC-MIL/DL-01



REFER TO THE FOLLOWING.

- (M88) - FUSE BLOCK- JUNCTION BOX (J/B)
- (M91) - SUPER MULTIPLE JUNCTION (SMJ)

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

[YD]

## AUTOMATIC SPEED CONTROL DEVICE (ASCD)

PPF:18930

### System Description INPUT/OUTPUT SIGNAL CHART

GBS000DK

Sensor	Input signal to ECM	ECM function	Actuator
ASCD brake switch	Brake pedal operation	ASCD vehicle speed control	Fuel injector and Fuel pump
Stop lamp switch	Brake pedal operation		
ASCD clutch switch (M/T)	Clutch pedal operation		
ASCD steering switch	ASCD steering switch operation		
Park/Neutral position (PNP) switch	Gear position		
Combination meter*	Vehicle speed		
TCM*	Powertrain revolution		

\*: This signal is sent to the ECM through CAN communication line.

### BASIC ASCD SYSTEM

Refer to Owner's Manual for ASCD operating instructions.

Automatic Speed Control Device (ASCD) allows a driver to keep vehicle at predetermined constant speed without depressing accelerator pedal. Driver can set vehicle speed in advance between approximately 40 km/h (25 MPH) and 185 km/h (115 MPH).

ECM controls fuel injection value to regulate engine speed.

Operation status of ASCD is indicated by CRUISE indicator and SET indicator in combination meter. If any malfunction occurs in ASCD system, it automatically deactivates control.

### SET OPERATION

Press ASCD MAIN switch. (The CRUISE indicator in combination meter illuminates.)

When vehicle speed reaches a desired speed between approximately 40 km/h (25 MPH) and 185 km/h (115 MPH), press SET/COST switch. (Then SET indicator in combination meter illuminates.)

### ACCELERATE OPERATION

If the RESUME/ACCELERATE switch is depressed during cruise control driving, increase the vehicle speed until the switch is released or vehicle speed reaches maximum speed controlled by the system.

And then ASCD will keep the new set speed.

### CANCEL OPERATION

When any of following conditions exist, cruise operation will be canceled.

- CANCEL switch is depressed
- More than 2 switches at ASCD steering switch are depressed at the same time (Set speed will be cleared)
- Brake pedal is depressed
- Clutch pedal is depressed or gear position is changed to the neutral position (M/T models)
- Selector lever is changed to N, P, R position (A/T models)
- Vehicle speed decreased to 13 km/h (8 MPH) lower than the set speed

When the ECM detects any of the following conditions, the ECM will cancel the cruise operation and inform the driver by blinking indicator lamp.

- Malfunction for some self-diagnoses regarding ASCD control: SET lamp will blink quickly.

If MAIN switch is turned to OFF during ASCD is activated, all of ASCD operations will be canceled and vehicle speed memory will be erased.

### COAST OPERATION

When the SET/COAST switch is depressed during cruise control driving, decrease vehicle set speed until the switch is released. And then ASCD will keep the new set speed.

### RESUME OPERATION

When the RESUME/ACCELERATE switch is depressed after cancel operation other than depressing MAIN switch is performed, vehicle speed will return to last set speed. To resume vehicle set speed, vehicle condition must meet following conditions.

- Brake pedal is released
- Clutch pedal is released (M/T models)
- Selector lever is in other than P and N positions (A/T models)
- Vehicle speed is greater than 40 km/h (25 MPH) and less than 185 km/h (115 MPH)

## Component Description

### ASCD STEERING SWITCH

Refer to [EC-1194](#) .

### ASCD BRAKE SWITCH

Refer to [EC-1177](#) and [EC-1312](#) .

### ASCD CLUTCH SWITCH

Refer to [EC-1177](#) and [EC-1312](#) .

### STOP LAMP SWITCH

Refer to [EC-1177](#) and [EC-1312](#) .

### ASCD INDICATOR

Refer to [EC-1333](#) .

GBS000DL



# SERVICE DATA AND SPECIFICATIONS (SDS)

[YD]

## SERVICE DATA AND SPECIFICATIONS (SDS)

PPF:00100

### General Specifications

GBS000DM

Target idle speed	A/T	No load* (in P or N position)	750±25 rpm
	M/T	No load* (in Neutral position)	
Air conditioner: ON	A/T	In P or N position	750 rpm or more
	M/T	In Neutral position	800 rpm or more
Maximum engine speed			4,900 rpm

\*: Under the following conditions:

- Air conditioner switch: OFF
- Electric load: OFF (Lights, heater fan & rear window defogger)
- Steering wheel: Kept in straight-ahead position

### Mass Air Flow Sensor

GBS000DN

Supply voltage	Battery voltage (11 - 14V)
Ignition switch ON (Engine stopped.)	Approx. 0.4V
Idle (Engine is warmed up to normal operating temperature.)	1.3 - 1.7V *

\*: Engine is warmed up to normal operating temperature and running under no load.

### Intake Air Temperature Sensor

GBS000DO

Temperature °C (°F)	Resistance kΩ
25 (77)	1.800 - 2.200
80 (176)	0.283 - 0.359

### Engine Coolant Temperature Sensor

GBS000DP

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

### Fuel Rail Pressure Sensor

GBS000DQ

Supply voltage	Approximately 5V
Idle (Engine is warmed up to normal operating temperature.)	1.7 - 2.0V
2,000 rpm (Engine is warmed up to normal operating temperature.)	2.0 - 2.3V

### Fuel Injector

GBS000DR

Resistance [at 10 - 60°C (50 - 140°F)]	0.2 - 0.8Ω
--	------------

### Glow Plug

GBS000DS

Resistance [at 25°C (77°F)]	Approximately 0.8Ω
-----------------------------	--------------------

### EGR Volume Control Valve

GBS000DT

Resistance [at 25°C (77°F)]	13 - 17Ω
-----------------------------	----------

### Crankshaft Position Sensor

GBS000DU

Refer to [EC-1152, "Component Inspection"](#).

### Camshaft Position Sensor

GBS000DV

Refer to [EC-1163, "Component Inspection"](#).

# SERVICE DATA AND SPECIFICATIONS (SDS)

[YD]

## Fuel Pump

GBS000DW

Resistance [at 10 - 60°C (50 - 140°F)]

1.5 - 3.0Ω