

SECTION **LAN**  
LAN SYSTEM

CONTENTS

<b>CAN</b>		
<b>PRECAUTIONS</b> .....	<b>3</b>	
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	3	
Precautions When Using CONSULT-II .....	3	
CHECK POINTS FOR USING CONSULT-II .....	3	
Precautions for Trouble Diagnosis .....	3	
CAN SYSTEM .....	3	
Precautions for Harness Repair .....	4	
CAN SYSTEM .....	4	
<b>TROUBLE DIAGNOSES WORK FLOW</b> .....	<b>5</b>	
When Displaying CAN Communication System Errors .....	5	
WHEN A MALFUNCTION IS DETECTED BY CAN COMMUNICATION SYSTEM .....	5	
WHEN A MALFUNCTION IS DETECTED EXCEPT CAN COMMUNICATION SYSTEM .....	5	
TROUBLE DIAGNOSIS FLOW CHART .....	6	
Diagnosis Procedure .....	7	
SELECTING CAN SYSTEM TYPE (HOW TO USE SPECIFICATION TABLE) .....	7	
ACQUISITION OF DATA BY CONSULT-II .....	8	
HOW TO USE CHECK SHEET TABLE .....	9	
CAN Diagnostic Support Monitor .....	15	
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR ECM .....	15	
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR TCM .....	17	
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR BCM .....	18	
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR TRANSFER CONTROL UNIT .....	19	
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) .....	19	
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR IPDM E/R .....	20	
<b>CAN COMMUNICATION</b> .....	<b>21</b>	
System Description .....	21	
Component Parts and Harness Connector Location .....	21	
Schematic .....	22	
Wiring Diagram — CAN — .....	23	
CAN Communication Unit .....	26	
TYPE 1 .....	26	
TYPE 2 .....	27	
TYPE 3 .....	29	
TYPE 4 .....	30	
TYPE 5/ TYPE 6 .....	32	
TYPE 7/ TYPE 8 .....	34	
TYPE 9/ TYPE 10 .....	36	
TYPE 11/ TYPE 12 .....	37	
<b>CAN SYSTEM (TYPE 1)</b> .....	<b>40</b>	
Component Parts and Harness Connector Location .....	40	
Schematic .....	40	
Wiring Diagram — CAN — .....	40	
Check Sheet .....	41	
CHECK SHEET RESULTS (EXAMPLE) .....	43	
<b>CAN SYSTEM (TYPE 2)</b> .....	<b>51</b>	
Component Parts and Harness Connector Location .....	51	
Schematic .....	51	
Wiring Diagram — CAN — .....	51	
Check Sheet .....	52	
CHECK SHEET RESULTS (EXAMPLE) .....	54	
<b>CAN SYSTEM (TYPE 3)</b> .....	<b>64</b>	
Component Parts and Harness Connector Location .....	64	
Schematic .....	64	
Wiring Diagram — CAN — .....	64	
Check Sheet .....	65	
CHECK SHEET RESULTS (EXAMPLE) .....	67	
<b>CAN SYSTEM (TYPE 4)</b> .....	<b>75</b>	
Component Parts and Harness Connector Location .....	75	
Schematic .....	75	
Wiring Diagram — CAN — .....	75	
Check Sheet .....	76	
CHECK SHEET RESULTS (EXAMPLE) .....	78	
<b>CAN SYSTEM (TYPE 5)</b> .....	<b>88</b>	
Component Parts and Harness Connector Location .....	88	

Schematic .....	88	Wiring Diagram — CAN — .....	144
Wiring Diagram — CAN — .....	88	Check Sheet .....	145
Check Sheet .....	89	CHECK SHEET RESULTS (EXAMPLE) .....	147
CHECK SHEET RESULTS (EXAMPLE) .....	91	<b>CAN SYSTEM (TYPE 11) .....</b>	<b>156</b>
<b>CAN SYSTEM (TYPE 6) .....</b>	<b>97</b>	Component Parts and Harness Connector Location .....	156
Component Parts and Harness Connector Location .....	97	Schematic .....	156
Schematic .....	97	Wiring Diagram — CAN — .....	156
Wiring Diagram — CAN — .....	97	Check Sheet .....	157
Check Sheet .....	98	CHECK SHEET RESULTS (EXAMPLE) .....	159
CHECK SHEET RESULTS (EXAMPLE) .....	100	<b>CAN SYSTEM (TYPE 12) .....</b>	<b>168</b>
<b>CAN SYSTEM (TYPE 7) .....</b>	<b>109</b>	Component Parts and Harness Connector Location .....	168
Component Parts and Harness Connector Location .....	109	Schematic .....	168
Schematic .....	109	Wiring Diagram — CAN — .....	168
Wiring Diagram — CAN — .....	109	Check Sheet .....	169
Check Sheet .....	110	CHECK SHEET RESULTS (EXAMPLE) .....	171
CHECK SHEET RESULTS (EXAMPLE) .....	112	<b>TROUBLE DIAGNOSIS FOR SYSTEM .....</b>	<b>182</b>
<b>CAN SYSTEM (TYPE 8) .....</b>	<b>121</b>	Inspection Between TCM and Data Link Connector	
Component Parts and Harness Connector Location .....	121	Circuit .....	182
Schematic .....	121	Inspection Between Data Link Connector and ABS	
Wiring Diagram — CAN — .....	121	Actuator and Electric Unit (Control Unit) Circuit ...	183
Check Sheet .....	122	ECM Circuit Inspection for M/T Model .....	184
CHECK SHEET RESULTS (EXAMPLE) .....	124	ECM Circuit Inspection for A/T Model .....	185
<b>CAN SYSTEM (TYPE 9) .....</b>	<b>135</b>	TCM Circuit Inspection .....	187
Component Parts and Harness Connector Location .....	135	Data Link Connector Circuit Inspection .....	187
Schematic .....	135	BCM Circuit Inspection .....	188
Wiring Diagram — CAN — .....	135	Combination Meter Circuit Inspection .....	188
Check Sheet .....	136	Transfer Control Unit Circuit Inspection .....	189
CHECK SHEET RESULTS (EXAMPLE) .....	138	ABS Actuator and Electric Unit (Control Unit) Circuit	
<b>CAN SYSTEM (TYPE 10) .....</b>	<b>144</b>	Inspection .....	189
Component Parts and Harness Connector Location .....	144	IPDM E/R Circuit Inspection .....	190
Schematic .....	144	CAN Communication Circuit Inspection .....	190
		IPDM E/R Ignition Relay Circuit Inspection .....	192

**PRECAUTIONS**

PF0:00001

**Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”**

GKS0008A

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

**Precautions When Using CONSULT-II**

GKS0008B

When connecting CONSULT-II to data link connector, connect them through CONSULT-II CONVERTER.

**CAUTION:**

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

**CHECK POINTS FOR USING CONSULT-II**

1. Has CONSULT-II been used without connecting CONSULT-II CONVERTER on this vehicle?
  - If YES, GO TO 2.
  - If NO, GO TO 5.
2. Is there any indication other than indications relating to CAN communication system in the self-diagnosis results?
  - If YES, GO TO 3.
  - If NO, GO TO 4.
3. Based on self-diagnosis results unrelated to CAN communication, carry out the inspection.
4. Malfunctions may be detected in self-diagnosis depending on control units carrying out CAN communication. Therefore, erase the self-diagnosis results.
5. Diagnose CAN communication system. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#) .

**Precautions for Trouble Diagnosis CAN SYSTEM**

GKS0008C


- Do not apply voltage of 7.0 V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0 V or less.
- Be sure to turn ignition switch OFF and disconnect the battery cable from the negative terminal before checking the circuit.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M


LAN

### Precautions for Harness Repair CAN SYSTEM

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in).]



- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)



## TROUBLE DIAGNOSES WORK FLOW

PFP:00004

### When Displaying CAN Communication System Errors

GKS0008E

#### WHEN A MALFUNCTION IS DETECTED BY CAN COMMUNICATION SYSTEM

- CAN communication line is open. (CAN H, CAN L, or both)
- CAN communication line is shorted. (Ground, between CAN lines, or other harnesses)
- The areas related to CAN communication of unit is malfunctioning.

#### WHEN A MALFUNCTION IS DETECTED EXCEPT CAN COMMUNICATION SYSTEM

- Removal and installation of parts: When the units that perform CAN communication or the sensors related to CAN communication are removed and installed, malfunction may be detected (or DTC other than CAN communication may be detected).
- Fuse blown out (removed): CAN communication of the unit may be stopped at such time.
- Low voltage: If the voltage decreases because of battery discharge when IGN is ON, malfunction may be detected by self-diagnosis according to the units.

A

B

C

D

E

F

G

H

I


J

LAN

L

M

## TROUBLE DIAGNOSIS FLOW CHART



- Step 1: Refer to [LAN-7, "SELECTING CAN SYSTEM TYPE \(HOW TO USE SPECIFICATION TABLE\)"](#) .
- Step 2: Refer to [LAN-8, "ACQUISITION OF DATA BY CONSULT-II"](#) .
- Step 3: Refer to [LAN-9, "HOW TO USE CHECK SHEET TABLE"](#) .
- Step 4: Refer to [LAN-10, "Example of Filling in Check Sheet When Initial Conditions Are Reproduced"](#) .
- Step 5: Refer to [LAN-182, "TROUBLE DIAGNOSIS FOR SYSTEM"](#) .

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

GKS0008F

## Diagnosis Procedure SELECTING CAN SYSTEM TYPE (HOW TO USE SPECIFICATION TABLE)

Determine CAN system type from the equipment of the vehicle to select applicable check sheet.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

(Example) Truck/4WD/VQ40DE/AT/ABS

### CAN Communication Unit

Go to CAN system, when selecting your CAN system type from the following table.

Body type	Truck											
Axle	2WD				4WD							
Engine	VQ40DE		YD25DDTi		VQ40DE				YD25DDTi			
Transmission	M/T	A/T	M/T	A/T	M/T	A/T	A/T	M/T	A/T	M/T	A/T	
Brake control	ABS				ABS	ABS	ABS	ABS	ABS	ABS	ABS	
CAN system type	1	2	3	4	5	6	7	8	9	10	11	12
CAN system trouble diagnosis	XXXX	XXXX	XXXX	XXXX	XXXX	XXXX	XXXX	XXXX	XXXX	XXXX	XXXX	XXXX

Check basic specification of the vehicle.

Which number is selected when sequentially selecting from the top of the specification table?  
The number is "CAN system type" of the applicable vehicle.

In the case of this example:  
It corresponds to type 8.

PKIC3781E

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

## ACQUISITION OF DATA BY CONSULT-II

Attach the data acquired by CONSULT-II on the check sheet determined according to CAN system type.

Copy "SELECT SYSTEM" screen of CONSULT-II.

SELECT SYSTEM		SELECT SYSTEM	
AT		ABS	
ABS		ENGINE	
ENGINE		AIR BAG	
AIR BAG		IPDM E/R	
IPDM E/R		METER	
METER		ALL MODE AWD/4WD	
Page Down		Page Up	
BACK	LIGHT	COPY	
BACK	LIGHT	COPY	

Check sheet table

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
		ECM	TCM	BCM (SEC)	METER/M&A	AWD/4WD	VDC/TCS/ABS	IPDM E/R		
ENGINE	--	NG	UNKNWN	--	UNKNWN	UNKNWN	UNKNWN	--	UNKNWN	--
A/T	--	NG	UNKNWN	--	UNKNWN	UNKNWN	UNKNWN	--	UNKNWN	--
BCM	No indication	NG	UNKNWN	--	--	UNKNWN	--	--	UNKNWN	CAN COMM CIRCUIT (U1000)
METER	No indication	--	--	--	--	--	--	--	--	CAN COMM CIRCUIT (U1000)
ALL MODE AWD/4WD	--	NG	UNKNWN	UNKNWN	UNKNWN	--	UNKNWN	--	--	CAN COMM CIRCUIT (U1000)
ABS	--	NG	UNKNWN	UNKNWN	--	--	--	--	--	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	--	UNKNWN	UNKNWN	--	UNKNWN	--	--	--	CAN COMM CIRCUIT (U1000)

Symptoms :

Attach copy of SELECT SYSTEM

Attach copy of SELECT SYSTEM

Copy "SELF-DIAG RESULTS" screen of CONSULT-II.

SELF-DIAG RESULTS	
DTC RESULTS	
CAN COMM CIRCUIT (U1000)	
ERASE PRINT	
MODE BACK LIGHT COPY	

SELF-DIAG RESULTS	
DTC RESULTS	
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	
ERASE PRINT	
MODE BACK LIGHT COPY	

Attach copy of ENGINE SELF-DIAG RESULTS

Attach copy of A/T SELF-DIAG RESULTS

Attach copy of BCM SELF-DIAG RESULTS

Attach copy of METER SELF-DIAG RESULTS

Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS

Attach copy of ABS SELF-DIAG RESULTS

Attach copy of IPDM E/R SELF-DIAG RESULTS

Attach copy of ENGINE CAN DIAG SUPPORT MNTR

Attach copy of A/T CAN DIAG SUPPORT MNTR

Attach copy of BCM CAN DIAG SUPPORT MNTR

Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR

Attach copy of ABS CAN DIAG SUPPORT MNTR

Copy "CAN DIAG SUPPORT MNTR" screen of CONSULT-II.

CAN DIAG SUPPORT MNTR	
ENGINE	
INITIAL DIAG	PRSNLT
TRANSMIT DIAG	OK
TCM	OK
VDC/TCS/ABS	UNKNWN
METER/M&A	OK
ICM	UNKNWN
BCM/SEC	UNKNWN
IPDM E/R	OK
AWD/4WD/4WD	OK
PRINT	Scroll Down
MODE	BACK LIGHT COPY

CAN DIAG SUPPORT MNTR	
ABS	
INITIAL DIAG	PRSNLT
TRANSMIT DIAG	OK
ECM	OK
DIFFLOCK	OK
PRINT	
MODE	BACK LIGHT COPY



## HOW TO USE CHECK SHEET TABLE

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC3783E

1. Unit names displayed on CONSULT-II.
2. "No indication": Put a check mark to it if the unit name described in step 1 is not displayed on "SELECT SYSTEM" screen of CONSULT-II. (Unit communicating with CONSULT-II via CAN communication line)  
"—": Column not used (Unit communicating with CONSULT-II excluding CAN communication line)
3. "NG": Display "NG" when malfunction is detected in the initial diagnosis of the diagnosed unit. Replace the unit if "NG" is displayed.  
"—": Column not used (Initial diagnosis is not performed.)
4. "UNKWN": Display "UNKWN" when the diagnosed unit does not transmit the data normally. Put a check mark to it if "UNKWN" is displayed on CONSULT-II.  
"—": Column not used (Transmit diagnosis is not performed.)
5. "UNKWN": Display "UNKWN" when the diagnosed unit does not receive the data normally. Put a check mark to it if "UNKWN" is displayed on CONSULT-II.  
"—": Column not used (It is not necessary for CAN communication trouble diagnosis.)

**NOTE:**

CAN communication diagnosis checks if CAN communication works normally. (Contents of data are not diagnosed.)

- When the initial conditions are reproduced, refer to [LAN-10, "Example of Filling in Check Sheet When Initial Conditions Are Reproduced"](#) .
- When the initial conditions are not reproduced, refer to [LAN-13, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#) .

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

## Example of Filling in Check Sheet When Initial Conditions Are Reproduced

The diagram illustrates the process of filling a check sheet based on diagnostic information. It features two 'CAN DIAG SUPPORT MNTR' screens, a central 'Check sheet table', and two 'SELECT SYSTEM' screens. Arrows indicate the flow of data from the diagnostic screens to the check sheet table.

**CAN DIAG SUPPORT MNTR (Left):**

ENGINE	
INITIAL DIAG	PRSN
INITIAL DIAG	OK
TRANSMIT DIAG	OK
TCM	OK
VDC/TCS/ABS	UNKWN
METER/M&A	OK
ICC	UNKWN
BCM/SEC	UNKWN
IPDM E/R	OK
AWD/4WD/e4WD	OK
PRINT	Scroll Down
MODE	BACK LIGHT COPY

**CAN DIAG SUPPORT MNTR (Right):**

ENGINE	
TRANSMIT DIAG	PRSN
TRANSMIT DIAG	OK
TCM	OK
VDC/TCS/ABS	UNKWN
METER/M&A	OK
ICC	UNKWN
BCM/SEC	UNKWN
IPDM E/R	OK
AWD/4WD/e4WD	OK
EPS	UNKWN
PRINT	Scroll Up
MODE	BACK LIGHT COPY

**Check sheet table:**

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
	Initial diagnosis	Transmit diagnosis	Receive diagnosis							IPDM E/R		
			ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

**SELECT SYSTEM (Left):**

SELECT SYSTEM
A/T
ABS
ENGINE
AIR BAG
IPDM E/R
METER
Page Down
BACK LIGHT COPY

**SELECT SYSTEM (Right):**

SELECT SYSTEM
ABS
ENGINE
AIR BAG
IPDM E/R
METER
ALL MODE AWD/4WD
Page Up
BACK LIGHT COPY

PKIC3784E

- Put a check mark to "No indication" if some of unit names listed on the column of diagnosis system selection screen of a check sheet table are not displayed on "SELECT SYSTEM" screen attached to the check sheet.

**NOTE:**

Put a check mark to "No indication" of BCM because BCM is not displayed on "SELECT SYSTEM" screen.


- Confirm the unit name that "UNKWN" is displayed from the copy of "CAN DIAG SUPPORT MNTR" screen of "ENGINE" attached to the check sheet, and then put a check mark to the check sheet table.

**NOTE:**

In "CAN DIAG SUPPORT MNTR" screen, "UNKWN" is displayed on "VDC/TCS/ABS", "ICC", "BCM/SEC" and "EPS". But put a check mark to "BCM/SEC" because "UNKWN" is listed on the column of reception diagnosis of the check sheet table.

# TROUBLE DIAGNOSES WORK FLOW

[CAN]



- Confirm the unit name that “UNKWN” is displayed on the copy of “CAN DIAG SUPPORT MNTR” screen of “A/T”, “ALL MODE AWD/4WD”, “ABS” and “IPDM E/R” as well as “ENGINE”. And then, put a check mark to the check sheet table.

**NOTE:**

- For “A/T”, “UNKWN” is displayed on “ICC/e4WD”. But, do not put a check mark to their columns of reception diagnosis of the check sheet table because “UNKWN” is not listed.
- For “ALL MODE AWD/4WD”, “UNKWN” is not displayed. Do not put a check mark to it.
- For “ABS”, “UNKWN” is not displayed. Do not put a check mark to it.
- For “IPDM E/R”, “UNKWN” is displayed on “BCM/SEC”. Put a check mark to it.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

The arranged results of CAN diagnosis support monitor

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS			
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	UNKW	—	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKW	UNKW	—	—	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKW	UNKW	—	—	UNKW	—	—	UNKW	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	UNKW	—	UNKW	—	UNKW	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	UNKW	—	—	—	—	CAN COMM CIRCUIT (U1000)	—


Choose similar indications between the results of CAN diagnosis support monitor and the results of the check sheet. Malfunctioning parts are found.

Case 6  
Check BCM circuit.

Check sheet results (example)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS			
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	UNKW	—	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKW	UNKW	—	—	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKW	UNKW	—	—	UNKW	—	—	UNKW	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	UNKW	—	UNKW	—	UNKW	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	UNKW	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

//// : Malfunctioning part



PKIC3786E

## NOTE:

There is a case that some of "CAN DIAG SUPPORT MNTR" and "SELF-DIAG RESULTS" are not needed for diagnosis. In the case, "UNKW" and "CAN COMM CIRCUIT [U1000]" in "Check sheet results (example)" change to "—". Then, ignore check marks on the check sheet table.

- Perform system diagnosis for possible causes identified.
- Perform diagnosis again after inspection and repair. Make sure that repair is completely performed, and then end the procedure.

Start CAN system trouble diagnosis if this procedure can be confirmed. Refer to [LAN-26, "CAN Communication Unit"](#).

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

## Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

SYSTEM ENGINE	SYSTEM A/T	SYSTEM BCM	SYSTEM METER
SELF-DIAG RESULTS	SELF-DIAG RESULTS	SELF-DIAG RESULTS	SELF-DIAG RESULTS
DTC RESULTS	DTC RESULTS	DTC RESULTS	DTC RESULTS
CAN COMM CIRCUIT [U1001]	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	CAN COMM CIRCUIT [U1000]
TIME 1t		TIME	TIME 2
SYSTEM ALL MODE AWD/4WD	SYSTEM ABS	SYSTEM IPDM E/R	
SELF-DIAG RESULTS	SELF-DIAG RESULTS	SELF-DIAG RESULTS	
DTC RESULTS	DTC RESULTS	DTC RESULTS	
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	CAN COMM CIRCUIT [U1000]	
		PAST	

- See "SELF-DIAG RESULTS" of all units attached to the check sheet. If "CAN COMM CIRCUIT", "CAN COMM CIRCUIT [U1000]" or "CAN COMM CIRCUIT [U1001]" is displayed, put a check mark to the applicable column of self-diagnostic results of the check sheet table.

**NOTE:**

- For "ENGINE", "CAN COMM CIRCUIT [U1001]" is displayed. Put a check mark to it.
- For "A/T", "NO DTC IS DETECTED" is displayed. Do not put a check mark to it.
- For "BCM", "NO DTC IS DETECTED" is displayed. Do not put a check mark to it.
- For "METER", "CAN COMM CIRCUIT [U1000]" is displayed. Put a check mark to it.
- For "ALL MODE AWD/4WD", "NO DTC IS DETECTED" is displayed. Do not put a check mark to it.
- For "ABS", "NO DTC IS DETECTED" is displayed. Do not put a check mark to it.
- For "IPDM E/R", "CAN COMM CIRCUIT [U1000]" is displayed. Put a check mark to it.

The arranged results of self-diagnosis

Check sheet table

SELECT SYSTEM screen	Initial diagnosis	Transmit diagnosis	CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
			Receive diagnosis									
			ECM	TCM	BCM /SEC	METER /MAA	AWD/4WD /AWD	VDC/CTS /ABS	IPDM /E/R			
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	CAN COMM CIRCUIT [U1000]
A/T	-	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-	CAN COMM CIRCUIT [U1000]	-
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-	CAN COMM CIRCUIT [U1000]	-
METER	No indication	-	-	-	-	-	-	-	-	-	CAN COMM CIRCUIT [U1000]	-
ALL MODE AWD/4WD	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	CAN COMM CIRCUIT [U1000]	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-	CAN COMM CIRCUIT [U1000]	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	UNKWN	-	-	-	-	CAN COMM CIRCUIT [U1000]	-



When the arranged results of self-diagnosis and check sheet results (example) are corresponding, possible causes can be selected.

Case 6  
Check BCM circuit.

SELECT SYSTEM screen	Initial diagnosis	Transmit diagnosis	CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
			Receive diagnosis									
			ECM	TCM	BCM /SEC	METER /MAA	AWD/4WD /AWD	VDC/CTS /ABS	IPDM /E/R			
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	CAN COMM CIRCUIT [U1000]
A/T	-	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-	CAN COMM CIRCUIT [U1000]	-
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-	CAN COMM CIRCUIT [U1000]	-
METER	No indication	-	-	-	-	-	-	-	-	-	CAN COMM CIRCUIT [U1000]	-
ALL MODE AWD/4WD	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	CAN COMM CIRCUIT [U1000]	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-	CAN COMM CIRCUIT [U1000]	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	UNKWN	-	-	-	-	CAN COMM CIRCUIT [U1000]	-

Case 10  
Check IPDM E/R circuit.

SELECT SYSTEM screen	Initial diagnosis	Transmit diagnosis	CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
			Receive diagnosis									
			ECM	TCM	BCM /SEC	METER /MAA	AWD/4WD /AWD	VDC/CTS /ABS	IPDM /E/R			
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	CAN COMM CIRCUIT [U1000]
A/T	-	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-	CAN COMM CIRCUIT [U1000]	-
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-	CAN COMM CIRCUIT [U1000]	-
METER	No indication	-	-	-	-	-	-	-	-	-	CAN COMM CIRCUIT [U1000]	-
ALL MODE AWD/4WD	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	CAN COMM CIRCUIT [U1000]	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-	CAN COMM CIRCUIT [U1000]	-
IPDM E/R	No indication	UNKWN	UNKWN	-	UNKWN	-	-	-	-	-	CAN COMM CIRCUIT [U1000]	-



PKIC3788E

**NOTE:**

There is a case that some of “CAN DIAG SUPPORT MNTR” and “SELF-DIAG RESULTS” are not needed for diagnosis. In the case, “UNKWN” and “CAN COMM CIRCUIT [U1000]” in “Check sheet results (example)” change to “-”. Then, ignore check marks on the check sheet table.

- For the selected possible causes, it is expected that malfunctions have been found in the past.

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

GKS0008G

## CAN Diagnostic Support Monitor

### DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR ECM

#### VQ40DE

(Example)	CAN DIAG SUPPORT MNTR				CAN DIAG SUPPORT MNTR			
	ENGINE				ENGINE			
				PRSNT				PRSNT
	INITIAL DIAG			OK	TRANSMIT DIAG			OK
	TRANSMIT DIAG			OK	TCM			OK
	TCM			OK	VDC/TCS/ABS			UNKWN
	VDC/TCS/ABS			UNKWN	METER/M&A			OK
	METER/M&A			OK	ICC			UNKWN
	ICC			UNKWN	BCM/SEC			OK
	BCM/SEC			OK	IPDM E/R			OK
	IPDM E/R			OK	AWD/4WD/e4WD			OK
	AWD/4WD/e4WD			OK	EPS			UNKWN
	PRINT				PRINT		Scroll Up	
	MODE	BACK	LIGHT	COPY	MODE	BACK	LIGHT	COPY
					PKIC3812E			

"SELECT SYSTEM" screen	"CAN DIAG SUPPORT MNTR" screen	Description	Present
ENGINE	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	TCM	Make sure of normal reception from TCM.	OK/UNKWN
	VDC/TCS/ABS	VDC/TCS/ABS is not diagnosed.	UNKWN
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWN
	ICC	ICC is not diagnosed.	UNKWN
	BCM/SEC	Make sure of normal reception from BCM.	OK/UNKWN
	IPDM E/R	Make sure of normal reception from IPDM E/R.	OK/UNKWN
	AWD/4WD/e4WD	Make sure of normal reception from transfer control unit.	OK/UNKWN
EPS	EPS is not diagnosed.	UNKWN	

#### Display Results (Present)

- OK: Normal
- NG: Malfunction
- UNKWN: The diagnosed unit does not transmit or receive the applicable data normally.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# TROUBLE DIAGNOSES WORK FLOW

**[CAN]**

**YD25DDTi**

(Example)	CAN DIAG SUPPORT MNTR			
	ENGINE			
		PRSNT		
	INITIAL DIAG	OK		
	TRANSMIT DIAG	OK		
	TCM	OK		
	VDC/TCS/ABS	OK		
	METER/M&A	OK		
	BCM/SEC	OK		
	HVAC	UNKWN		
	PRINT			
	MODE	BACK	LIGHT	COPY

PKIC3798E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
ENGINE	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	TCM	Make sure of normal reception from TCM.	OK/UNKWN
	VDC/TCS/ABS	VDC/TCS/ABS is not diagnosed.	OK
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWN
	BCM/SEC	Make sure of normal reception from BCM.	OK/UNKWN
	HVAC	HVAC is not diagnosed.	UNKWN

**Display Results (Present)**

- OK: Normal
- NG: Malfunction
- UNKWN: The diagnosed unit does not transmit or receive the applicable data normally.



# TROUBLE DIAGNOSES WORK FLOW

**[CAN]**

## DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR TCM

(Example)

CAN DIAG SUPPORT MNTR			
A/T			
		PRSNT	
INITIAL DIAG		OK	
TRANSMIT DIAG		OK	
ECM		OK	
VDC/TCS/ABS		OK	
METER/M&A		OK	
ICC/e4WD		UNKWN	
AWD/4WD		OK	
PRINT			
MODE	BACK	LIGHT	COPY

SKIB2335E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
A/T	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	ECM	Make sure of normal reception from ECM.	OK/UNKWN
	VDC/TCS/ABS	VDC/TCS/ABS is not diagnosed.	OK
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWN
	ICC/e4WD	ICC/e4WD is not diagnosed.	UNKWN
	AWD/4WD	Make sure of normal reception from transfer control unit.	OK/UNKWN

### Display Results (Present)

- OK: Normal
- NG: Malfunction
- UNKWN: The diagnosed unit does not transmit or receive the applicable data normally.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# TROUBLE DIAGNOSES WORK FLOW

**[CAN]**

## DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR BCM

(Example)

CAN DIAG SUPPORT MNTR			
BCM			
		PRSNT	
INITIAL DIAG		OK	
TRANSMIT DIAG		OK	
ECM		OK	
IPDM E/R		OK	
METER/M&A		OK	
I-KEY		UNKWN	
PRINT			
MODE	BACK	LIGHT	COPY

PKIC2532E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
BCM	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	ECM	Make sure of normal reception from ECM.	OK/UNKWN
	IPDM E/R	Make sure of normal reception from IPDM E/R.	OK/UNKWN
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWN
	I-KEY	I-KEY is not diagnosed.	UNKWN

### Display Results (Present)

- OK: Normal
- NG: Malfunction
- UNKWN: The diagnosed unit does not transmit or receive the applicable data normally.

# TROUBLE DIAGNOSES WORK FLOW

**[CAN]**

## DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR TRANSFER CONTROL UNIT

(Example)

CAN DIAG SUPPORT MNTR			
ALL MODE AWD/4WD			
		PRSNT	
INITIAL DIAG		OK	
TRANSMIT DIAG		OK	
ECM		OK	
VDC/TCS/ABS		OK	
TCM		OK	
METER/M&A		OK	
PRINT			
MODE	BACK	LIGHT	COPY

PKIC2594E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
ALL MODE AWD/ 4WD	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	ECM	Make sure of normal reception from ECM.	OK/UNKWN
	VDC/TCS/ABS	Make sure of normal reception from ABS actuator and electric unit (control unit).	OK/UNKWN
	TCM	Make sure of normal reception from TCM.	OK/UNKWN
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWN

### Display Results (Present)

- OK: Normal
- NG: Malfunction
- UNKWN: The diagnosed unit does not transmit or receive the applicable data normally.

## DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

(Example)

CAN DIAG SUPPORT MNTR			
ABS			
		PRSNT	
INITIAL DIAG		OK	
TRANSMIT DIAG		OK	
ECM		OK	
PRINT			
MODE	BACK	LIGHT	COPY

PKIA8949E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
ABS	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	ECM	Make sure of normal reception from ECM.	OK/UNKWN

### Display Results (Present)

- OK: Normal
- NG: Malfunction
- UNKWN: The diagnosed unit does not transmit or receive the applicable data normally.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# TROUBLE DIAGNOSES WORK FLOW

**[CAN]**

## DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR IPDM E/R

(Example)

CAN DIAG SUPPORT MNTR			
IPDM E/R			
	PRSNT	PAST	
TRANSMIT DIAG	OK	OK	
ECM	OK	OK	
BCM/SEC	OK	OK	
PRINT			
MODE	BACK	LIGHT	COPY

SKIB0595E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present	Past
IPDM E/R	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN/–	OK/0/1 – 39/–
	ECM	Make sure of normal reception from ECM.	OK/UNKWN/–	
	BCM/SEC	Make sure of normal reception from BCM.	OK/UNKWN/–	

### Display Results (Present)

- OK: Normal
- UNKWN: The diagnosed unit does not transmit or receive the applicable data normally.
- –: There is no received unit or the unit is not in the condition that reception diagnosis is performed.

### Display Results (Past)

- OK: Normal
- 0: There is malfunction now.
- 1 – 39: Displays when it is normal at present and finds malfunction in the past. It increases like 0→1→2...38→39 after returning to the normal condition whenever IGN OFF→ON. If it is over 39, it is fixed to 39 until the self-diagnostic results are erased. It returns to 0 when malfunction is detected again in the process.
- –: Undiagnosed

## CAN COMMUNICATION

PFP:23710


### System Description

GKS0008H

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### Component Parts and Harness Connector Location

GKS0008I



A

B

C

D

E

F

G

H

I

J

LAN

L

M

# CAN COMMUNICATION


[CAN]

GKS0008J

## Schematic

VQ : With VQ engine  
YD : With YD engine  
 \*1 94 : VQ  
 95 : YD  
 \*2 86 : VQ  
 87 : YD

A : With A/T  
AB : With ABS  
4W : With 4WD



MKWA4151E

# CAN COMMUNICATION


[CAN]

## Wiring Diagram — CAN —

GKS0008K






### LAN-CAN-01

- ▬ : DATA LINE
- ⬡ : WITH A/T
- ⬢ : WITH M/T
- ⬤ : WITH VQ ENGINE
- ⬥ : WITH YD ENGINE



- \*1 94: ⬤
- 95: ⬥
- \*2 86: ⬤
- 87: ⬥


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M



REFER TO THE FOLLOWING.

(M91) - SUPER MULTIPLE JUNCTION (SMJ)

\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

(M23) W

1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30
31	32	33	34	35	36	37	38	39	40


(M42) B

16	15	14	13	12	11	10	9
8	7	6	5	4	3	2	1

(M45) W

6	5	4	3	2	1					
17	16	15	14	13	12	11	10	9	8	7
26	25	24	23	22	21	20	19	18		

(M105) W







## LAN-CAN-03

▬ : DATA LINE

⬡ : WITH ABS



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M



# CAN COMMUNICATION

[CAN]

GKS0008L

## CAN Communication Unit


Go to CAN system, when selecting your CAN system type from the following table.

Body type	Truck											
Axle	2WD				4WD							
Engine	VQ40DE		YD25DDTi		VQ40DE				YD25DDTi			
Transmission	M/T	A/T	M/T	A/T	M/T		A/T		M/T		A/T	
Brake control	ABS				ABS		ABS		ABS		ABS	
CAN system type	1	2	3	4	5	6	7	8	9	10	11	12
CAN system trouble diagnosis	<a href="#">LAN-40</a>	<a href="#">LAN-51</a>	<a href="#">LAN-64</a>	<a href="#">LAN-75</a>	<a href="#">LAN-88</a>	<a href="#">LAN-97</a>	<a href="#">LAN-109</a>	<a href="#">LAN-121</a>	<a href="#">LAN-135</a>	<a href="#">LAN-144</a>	<a href="#">LAN-156</a>	<a href="#">LAN-168</a>
CAN communication unit												
ECM	×	×	×	×	×	×	×	×	×	×	×	×
TCM		×		×			×	×			×	×
Data link connector	×	×	×	×	×	×	×	×	×	×	×	×
Combination meter	×	×	×	×	×	×	×	×	×	×	×	×
Transfer control unit					×	×	×	×	×	×	×	×
ABS actuator and electric unit (control unit)	×	×	×	×		×		×		×		×
IPDM E/R	×	×	×	×	×	×	×	×	×	×	×	×

### TYPE 1

#### System diagram

- Type 1



#### Input/output signal chart

T: Transmit R: Receive

Signals	ECM	BCM	Combination meter	ABS actuator and electric unit (control unit)	IPDM E/R
A/C compressor request signal	T				R
ASCD CRUISE lamp signal	T		R		
ASCD SET lamp signal	T		R		
Cooling fan speed request signal	T				R
Engine coolant temperature signal	T		R		

# CAN COMMUNICATION

[CAN]


Signals	ECM	BCM	Combination meter	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T		R		
Engine status signal	T	R			
Malfunction indicator lamp signal	T		R		
A/C switch signal	R	T			
Blower fan motor switch signal	R	T			
Buzzer output signal		T	R		
Door switch signal		T	R		R
Front fog light request signal		T	R		R
Front wiper request signal		T			R
High beam request signal		T	R		R
Horn chirp signal		T			R
Low beam request signal		T			R
Position light request signal		T	R		R
Rear window defogger switch signal		T			R
Sleep wake up signal		T	R		R
Theft warning horn request signal		T			R
Turn indicator signal		T	R		
Vehicle speed signal			R	T	
	R	R	T		
ABS warning lamp signal			R	T	
Front wiper stop position signal		R			T
High beam status signal	R				T
Hood switch signal		R			T
Low beam status signal	R				T
Oil pressure switch signal			R		T
Rear window defogger control signal	R				T

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

## TYPE 2

### System diagram

- Type 2



PKIC3083E

# CAN COMMUNICATION

[CAN]

## Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	BCM	Combina- tion meter	ABS actua- tor and elec- tric unit (control unit)	IPDM E/R
A/C compressor request signal	T					R
Accelerator pedal position signal	T	R				
ASCD CRUISE lamp signal	T			R		
ASCD OD cancel request	T	R				
ASCD operation signal	T	R				
ASCD SET lamp signal	T			R		
Battery voltage signal	T	R				
Closed throttle position signal	T	R				
Cooling fan speed request signal	T					R
Engine coolant temperature signal	T			R		
Engine speed signal	T	R		R		
Engine status signal	T		R			
Malfunction indicator lamp signal	T			R		
Wide open throttle position signal	T	R				
A/T fluid temperature sensor signal		T		R		
A/T position indicator lamp signal		T		R		
OD OFF indicator lamp signal		T		R		
Output shaft revolution signal	R	T				
Turbine revolution signal	R	T				
A/C switch signal	R		T			
Blower fan motor switch signal	R		T			
Buzzer output signal			T	R		
Door switch signal			T	R		R
Front fog light request signal			T	R		R
Front wiper request signal			T			R
High beam request signal			T	R		R
Horn chirp signal			T			R
Low beam request signal			T			R
Position light request signal			T	R		R
Rear window defogger switch signal			T			R
Sleep wake up signal			T	R		R
Theft warning horn request signal			T			R
Turn indicator signal			T	R		
1st position switch signal		R		T		
Overdrive control switch signal		R		T		
Stop lamp switch signal		R		T		
Vehicle speed signal				R	T	
	R	R	R	T		
A/T shift schedule change demand signal		R			T	
ABS operation signal		R			T	
ABS warning lamp signal				R	T	

# CAN COMMUNICATION


[CAN]

Signals	ECM	TCM	BCM	Combina- tion meter	ABS actua- tor and elec- tric unit (control unit)	IPDM E/R
Front wiper stop position signal			R			T
High beam status signal	R					T
Hood switch signal			R			T
Low beam status signal	R					T
Oil pressure switch signal				R		T
Rear window defogger control signal	R					T

## TYPE 3

### System diagram

- Type 3



### Input/output signal chart

T: Transmit R: Receive

Signals	ECM	BCM	Combina- tion meter	ABS actuator and electric unit (control unit)	IPDM E/R
A/C compressor request signal	T				R
ASCD CRUISE lamp signal	T		R		
ASCD SET lamp signal	T		R		
Cooling fan speed request signal	T				R
Engine coolant temperature signal	T		R		
Engine speed signal	T		R		
Engine status signal	T	R			
Glow indicator signal	T		R		
Malfunction indicator lamp signal	T		R		
A/C switch signal	R	T			
Buzzer output signal		T	R		
Door switch signal		T	R		R
Front fog light request signal		T	R		R
Front wiper request signal		T			R
High beam request signal		T	R		R
Horn chirp signal		T			R

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

LAN

L  
M

# CAN COMMUNICATION


[CAN]

Signals	ECM	BCM	Combination meter	ABS actuator and electric unit (control unit)	IPDM E/R
Low beam request signal		T			R
Position light request signal		T	R		R
Rear window defogger switch signal		T			R
Sleep wake up signal		T	R		R
Theft warning horn request signal		T			R
Turn indicator signal		T	R		
Vehicle speed signal			R	T	
	R	R	T		
ABS warning lamp signal			R	T	
Front wiper stop position signal		R			T
Hood switch signal		R			T
Oil pressure switch signal			R		T
Rear window defogger control signal		R			T

## TYPE 4

### System diagram

- Type 4



### Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	BCM	Combination meter	ABS actuator and electric unit (control unit)	IPDM E/R
A/C compressor request signal	T					R
Accelerator pedal position signal	T	R				
ASCD CRUISE lamp signal	T			R		
ASCD OD cancel request	T	R				
ASCD operation signal	T	R				
ASCD SET lamp signal	T			R		
Battery voltage signal	T	R				
Closed throttle position signal	T	R				
Cooling fan speed request signal	T					R

# CAN COMMUNICATION

**[CAN]**


Signals	ECM	TCM	BCM	Combina- tion meter	ABS actua- tor and elec- tric unit (control unit)	IPDM E/R	A B C D E F G H I J L M
Engine coolant temperature signal	T			R			
Engine speed signal	T	R		R			
Engine status signal	T		R				
Glow indicator signal	T			R			
Malfunction indicator lamp signal	T			R			
Wide open throttle position signal	T	R					
A/T fluid temperature sensor signal		T		R			
A/T position indicator lamp signal		T		R			
OD OFF indicator lamp signal		T		R			
Output shaft revolution signal	R	T					
Turbine revolution signal	R	T					
A/C switch signal	R		T				
Buzzer output signal			T	R			
Door switch signal			T	R		R	
Front fog light request signal			T	R		R	
Front wiper request signal			T			R	
High beam request signal			T	R		R	
Horn chirp signal			T			R	
Low beam request signal			T			R	
Position light request signal			T	R		R	
Rear window defogger switch signal			T			R	
Sleep wake up signal			T	R		R	
Theft warning horn request signal			T			R	
Turn indicator signal			T	R			
1st position switch signal		R		T			
Overdrive control switch signal		R		T			
Stop lamp switch signal		R		T			
Vehicle speed signal				R	T		
	R	R	R	T			
A/T shift schedule change demand signal		R			T		
ABS operation signal		R			T		
ABS warning lamp signal				R	T		
Front wiper stop position signal			R			T	
Hood switch signal			R			T	
Oil pressure switch signal				R		T	
Rear window defogger control signal			R			T	

LAN


## TYPE 5/ TYPE 6

### System diagram

- Type 5



- Type 6



### Input/output signal chart

T: Transmit R: Receive

Signals	ECM	BCM	Combination meter	Transfer control unit	ABS actuator and electric unit (control unit)*1	IPDM E/R
A/C compressor request signal	T					R
ASCD CRUISE lamp signal	T		R			
ASCD SET lamp signal	T		R			
Cooling fan speed request signal	T					R
Engine coolant temperature signal	T		R			
Engine speed signal	T		R	R		
Engine status signal	T	R				
Malfunction indicator lamp signal	T		R			
A/C switch signal	R	T				



# CAN COMMUNICATION

[CAN]

Signals	ECM	BCM	Combination meter	Transfer control unit	ABS actuator and electric unit (control unit)* <sup>1</sup>	IPDM E/R
Blower fan motor switch signal	R	T				
Buzzer output signal		T	R			
Door switch signal		T	R			R
Front fog light request signal		T	R			R
Front wiper request signal		T				R
High beam request signal		T	R			R
Horn chirp signal		T				R
Low beam request signal		T				R
Position light request signal		T	R			R
Rear window defogger switch signal		T				R
Sleep wake up signal		T	R			R
Theft warning horn request signal		T				R
Turn indicator signal		T	R			
Vehicle speed signal			R <sup>*1</sup>	R <sup>*1</sup>	T	
	R	R	T	R <sup>*2</sup>		
ABS warning lamp signal			R <sup>*1</sup>		T	
Stop lamp switch signal				R <sup>*1</sup>	T	
Front wiper stop position signal		R				T
High beam status signal	R					T
Hood switch signal		R				T
Low beam status signal	R					T
Oil pressure switch signal			R			T
Rear window defogger control signal	R					T

**NOTE:**


- \*1: ABS model only
- \*2: Except for ABS model

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M


## TYPE 7/ TYPE 8

### System diagram

- Type 7



- Type 8



### Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	BCM	Combina- tion meter	Transfer control unit	ABS actu- ator and electric unit (con- trol unit)*1	IPDM E/R
A/C compressor request signal	T						R
Accelerator pedal position signal	T	R					
ASCD CRUISE lamp signal	T			R			
ASCD OD cancel request	T	R					
ASCD operation signal	T	R					
ASCD SET lamp signal	T			R			
Battery voltage signal	T	R					
Closed throttle position signal	T	R					
Cooling fan speed request signal	T						R

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	BCM	Combina- tion meter	Transfer control unit	ABS actu- ator and electric unit (con- trol unit)* <sup>1</sup>	IPDM E/R
Engine coolant temperature signal	T			R			
Engine speed signal	T	R		R	R		
Engine status signal	T		R				
Malfunction indicator lamp signal	T			R			
Wide open throttle position signal	T	R					
A/T fluid temperature sensor signal		T		R			
A/T position indicator lamp signal		T		R	R		
OD OFF indicator lamp signal		T		R			
Output shaft revolution signal	R	T			R		
Turbine revolution signal	R	T					
A/C switch signal	R		T				
Blower fan motor switch signal	R		T				
Buzzer output signal			T	R			
Door switch signal			T	R			R
Front fog light request signal			T	R			R
Front wiper request signal			T				R
High beam request signal			T	R			R
Horn chirp signal			T				R
Low beam request signal			T				R
Position light request signal			T	R			R
Rear window defogger switch signal			T				R
Sleep wake up signal			T	R			R
Theft warning horn request signal			T				R
Turn indicator signal			T	R			
1st position switch signal		R		T			
Overdrive control switch signal		R		T			
Stop lamp switch signal		R		T			
Vehicle speed signal				R* <sup>1</sup>	R* <sup>1</sup>	T	
	R	R	R	T	R* <sup>2</sup>		
A/T shift schedule change demand signal		R* <sup>1</sup>				T	
ABS operation signal		R* <sup>1</sup>				T	
ABS warning lamp signal				R* <sup>1</sup>		T	
Stop lamp switch signal					R* <sup>1</sup>	T	
Front wiper stop position signal			R				T
High beam status signal	R						T
Hood switch signal			R				T
Low beam status signal	R						T
Oil pressure switch signal				R			T
Rear window defogger control signal	R						T

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

**NOTE:**


- \*1: ABS model only

- \*2: Except for ABS model


## TYPE 9/ TYPE 10

### System diagram

- Type 9



- Type 10



### Input/output signal chart

T: Transmit R: Receive

Signals	ECM	BCM	Combination meter	Transfer control unit	ABS actuator and electric unit (control unit) <sup>*1</sup>	IPDM E/R
A/C compressor request signal	T					R
ASCD CRUISE lamp signal	T		R			
ASCD SET lamp signal	T		R			
Cooling fan speed request signal	T					R
Engine coolant temperature signal	T		R			
Engine speed signal	T		R	R		
Engine status signal	T	R				
Glow indicator signal	T		R			

# CAN COMMUNICATION

[CAN]

Signals	ECM	BCM	Combination meter	Transfer control unit	ABS actuator and electric unit (control unit)*1	IPDM E/R
Malfunction indicator lamp signal	T		R			
A/C switch signal	R	T				
Buzzer output signal		T	R			
Door switch signal		T	R			R
Front fog light request signal		T	R			R
Front wiper request signal		T				R
High beam request signal		T	R			R
Horn chirp signal		T				R
Low beam request signal		T				R
Position light request signal		T	R			R
Rear window defogger switch signal		T				R
Sleep wake up signal		T	R			R
Theft warning horn request signal		T				R
Turn indicator signal		T	R			
Vehicle speed signal			R*1	R*1	T	
	R	R	T	R*2		
ABS warning lamp signal			R*1		T	
Stop lamp switch signal				R*1	T	
Front wiper stop position signal		R				T
Hood switch signal		R				T
Oil pressure switch signal			R			T
Rear window defogger control signal		R				T


**NOTE:**

- \*1: ABS model only
- \*2: Except for ABS model

**TYPE 11/ TYPE 12**

**System diagram**


- Type 11



# CAN COMMUNICATION

[CAN]

● Type 12



## Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	BCM	Combina- tion meter	Transfer control unit	ABS actu- ator and electric unit (con- trol unit)*1	IPDM E/R
A/C compressor request signal	T						R
Accelerator pedal position signal	T	R					
ASCD CRUISE lamp signal	T			R			
ASCD OD cancel request	T	R					
ASCD operation signal	T	R					
ASCD SET lamp signal	T			R			
Battery voltage signal	T	R					
Closed throttle position signal	T	R					
Cooling fan speed request signal	T						R
Engine coolant temperature signal	T			R			
Engine speed signal	T	R		R	R		
Engine status signal	T		R				
Glow indicator signal	T			R			
Malfunction indicator lamp signal	T			R			
Wide open throttle position signal	T	R					
A/T fluid temperature sensor signal		T		R			
A/T position indicator lamp signal		T		R	R		
OD OFF indicator lamp signal		T		R			
Output shaft revolution signal	R	T			R		
Turbine revolution signal	R	T					
A/C switch signal	R		T				
Buzzer output signal			T	R			
Door switch signal			T	R			R
Front fog light request signal			T	R			R
Front wiper request signal			T				R

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	BCM	Combina- tion meter	Transfer control unit	ABS actu- ator and electric unit (con- trol unit) <sup>*1</sup>	IPDM E/R
High beam request signal			T	R			R
Horn chirp signal			T				R
Low beam request signal			T				R
Position light request signal			T	R			R
Rear window defogger switch signal			T				R
Sleep wake up signal			T	R			R
Theft warning horn request signal			T				R
Turn indicator signal			T	R			
1st position switch signal		R		T			
Overdrive control switch signal		R		T			
Stop lamp switch signal		R		T			
Vehicle speed signal				R <sup>*1</sup>	R <sup>*1</sup>	T	
	R	R	R	T	R <sup>*2</sup>		
A/T shift schedule change demand signal		R <sup>*1</sup>				T	
ABS operation signal		R <sup>*1</sup>				T	
ABS warning lamp signal				R <sup>*1</sup>		T	
Stop lamp switch signal					R <sup>*1</sup>	T	
Front wiper stop position signal			R				T
Hood switch signal			R				T
Oil pressure switch signal				R			T
Rear window defogger control signal			R				T

**NOTE:**

- \*1: ABS model only
- \*2: Except for ABS model

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

---

### CAN SYSTEM (TYPE 1)

PFP:23710

#### Component Parts and Harness Connector Location

GKS000DJ

Refer to [LAN-21, "Component Parts and Harness Connector Location"](#) .

#### Schematic

GKS000DK

Refer to [LAN-22, "Schematic"](#) .

#### Wiring Diagram — CAN —

GKS000DL

Refer to [LAN-23, "Wiring Diagram — CAN —"](#) .



# CAN SYSTEM (TYPE 1)

**[CAN]**

GKS000DM

## Check Sheet

**NOTE:**

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

LAN

# CAN SYSTEM (TYPE 1)

[CAN]

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
METER  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIB6517E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-183. "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKW N	UNKW N	—	UNKW N	UNKW N	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW N	UNKW N	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW N	UNKW N	UNKW N	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7252E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 1)

[CAN]


## Case 2

Check ECM circuit. Refer to [LAN-184, "ECM Circuit Inspection for M/T Model"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7253E

//// : Malfunctioning part



PKIC3097E

# CAN SYSTEM (TYPE 1)


[CAN]

## Case 3

Check data link connector circuit. Refer to [LAN-187, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	N <del>o</del> indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	N <del>o</del> indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	N <del>o</del> indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7254E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 1)

[CAN]


## Case 4

Check BCM circuit. Refer to [LAN-188, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN ✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7255E

//// : Malfunctioning part



PKIC3099E

# CAN SYSTEM (TYPE 1)


[CAN]

## Case 5

Check combination meter circuit. Refer to [LAN-188, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7256E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 1)

[CAN]


## Case 6

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-189, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7257E

//// : Malfunctioning part



PKIC3101E




## Case 7

Check IPDM E/R circuit. Refer to [LAN-190, "IPDM E/R Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del> ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del> ✓	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7258E



## Case 8

Check CAN communication circuit. Refer to [LAN-190, "CAN Communication Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKW <del>N</del> ✓	—	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG ✓	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication ✓	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7259E

# CAN SYSTEM (TYPE 1)

[CAN]

## Case 9

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-192. "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKW	UNKW	—	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7260E

## Case 10

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-192. "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKW	UNKW	—	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7261E

# CAN SYSTEM (TYPE 2)

[CAN]

---

## CAN SYSTEM (TYPE 2)

PFP:23710

### Component Parts and Harness Connector Location

GKS000DN

A

Refer to [LAN-21, "Component Parts and Harness Connector Location"](#) .

### Schematic

GKS000DO

B

Refer to [LAN-22, "Schematic"](#) .

### Wiring Diagram — CAN —

GKS000DP

C

Refer to [LAN-23, "Wiring Diagram — CAN —"](#) .

D

E

F

G

H

I

J

LAN

L

M

# CAN SYSTEM (TYPE 2)

[CAN]

GKS000DQ

## Check Sheet

**NOTE:**

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

# CAN SYSTEM (TYPE 2)

[CAN]

A

B

C

D

E

F

G

H

I

J

LAN

L

M

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
METER  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIB5017E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-182, "Inspection Between TCM and Data Link Connector Circuit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWVN	—	UNKWVN	UNKWVN	UNKWVN	UNKWVN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWVN	UNKWVN	—	—	UNKWVN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWVN	UNKWVN	—	—	UNKWVN	UNKWVN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWVN	UNKWVN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWVN	UNKWVN	—	UNKWVN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7272E



PKIC3103E

# CAN SYSTEM (TYPE 2)


[CAN]

## Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-183, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7273E



PKIC3104E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LAN

# CAN SYSTEM (TYPE 2)

[CAN]


## Case 3

Check ECM circuit. Refer to [LAN-185, "ECM Circuit Inspection for A/T Model"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	CAN COMM CIRCUIT (U100) <sup>✓</sup>	CAN COMM CIRCUIT (U101) <sup>✓</sup>
A/T	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	—	CAN COMM CIRCUIT (U100) <sup>✓</sup>	—
BCM	No indication	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	CAN COMM CIRCUIT (U1000) <sup>✓</sup>	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) <sup>✓</sup>	—
ABS	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	—	CAN COMM CIRCUIT (U100) <sup>✓</sup>	—
IPDM E/R	No indication	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	—	CAN COMM CIRCUIT (U100) <sup>✓</sup>	—

PKIB7274E

//// : Malfunctioning part



PKIC3105E



# CAN SYSTEM (TYPE 2)


[CAN]

## Case 4

Check TCM circuit. Refer to [LAN-187, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	—	UNKWN ✓	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7275E



PKIC3106E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 2)

[CAN]


## Case 5

Check data link connector circuit. Refer to [LAN-187, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7276E

//// : Malfunctioning part



PKIC3107E

# CAN SYSTEM (TYPE 2)


[CAN]

## Case 6

Check BCM circuit. Refer to [LAN-188, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7277E



PKIC3108E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 2)

[CAN]


## Case 7

Check combination meter circuit. Refer to [LAN-188, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN ✓	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7278E

//// : Malfunctioning part



PKIC3109E

# CAN SYSTEM (TYPE 2)


[CAN]

## Case 8

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-189, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7279E



PKIC3110E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 2)


[CAN]

## Case 9

Check IPDM E/R circuit. Refer to [LAN-190, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS			
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R				
ENGINE	—	NG	UNKWVN	—	UNKWVN	UNKWVN	UNKWVN	UNKWVN	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWVN	UNKWVN	—	—	UNKWVN	—	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWVN	UNKWVN	—	—	UNKWVN	UNKWVN	✓	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWVN	UNKWVN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	✓	UNKWVN	UNKWVN	—	UNKWVN	—	—	—	✓	CAN COMM CIRCUIT (U1000)	—

PKIB7280E



PKIC3111E

## Case 10

Check CAN communication circuit. Refer to [LAN-190, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS				
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R					
ENGINE	—	NG	✓	—	✓	✓	✓	✓	✓	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWVN	UNKWVN	—	—	UNKWVN	—	—	✓	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWVN	UNKWVN	—	—	UNKWVN	UNKWVN	—	—	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	✓	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	✓	UNKWVN	—	—	—	—	—	✓	✓	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWVN	UNKWVN	—	UNKWVN	—	—	—	✓	✓	CAN COMM CIRCUIT (U1000)	—

PKIB7281E

# CAN SYSTEM (TYPE 2)

[CAN]

## Case 11

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-192, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7282E

## Case 12

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-192, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7283E

---

### CAN SYSTEM (TYPE 3)

PFP:23710

#### Component Parts and Harness Connector Location

GKS000DR

Refer to [LAN-21, "Component Parts and Harness Connector Location"](#) .

#### Schematic

GKS000DS

Refer to [LAN-22, "Schematic"](#) .

#### Wiring Diagram — CAN —

GKS000DT

Refer to [LAN-23, "Wiring Diagram — CAN —"](#) .



# CAN SYSTEM (TYPE 3)

[CAN]

GKS000DU

## Check Sheet

### NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

LAN

# CAN SYSTEM (TYPE 3)

[CAN]

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
METER  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIB6517E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-183. "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	✓	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKWN	✓	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)

PKIC3141E



PKIC3096E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M


LAN

## Case 2

Check ECM circuit. Refer to [LAN-184, "ECM Circuit Inspection for M/T Model"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWVN ✓	—	UNKWVN ✓	UNKWVN ✓	—	CAN COMM CIRCUIT (U000) ✓
BCM	No indication	NG	UNKWVN	UNKWVN ✓	—	UNKWVN	UNKWVN	CAN COMM CIRCUIT (U1000) ✓
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U000) ✓
ABS	—	NG	UNKWVN	UNKWVN ✓	—	—	—	CAN COMM CIRCUIT (U000) ✓
IPDM E/R	No indication	—	UNKWVN	UNKWVN ✓	UNKWVN	—	—	CAN COMM CIRCUIT (U000) ✓

PKIC3142E



PKIC3097E

# CAN SYSTEM (TYPE 3)

[CAN]


## Case 3

Check data link connector circuit. Refer to [LAN-187, "Data Link Connector Circuit Inspection"](#) .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)

PKIC3143E




## Case 4

Check BCM circuit. Refer to [LAN-188, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U000) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U000) ✓
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U000) ✓

PKIC3144E

//// : Malfunctioning part



PKIC3099E

# CAN SYSTEM (TYPE 3)


[CAN]

## Case 5

Check combination meter circuit. Refer to [LAN-188, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U000)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U000)
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)

PKIC3145E



PKIC3100E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M


## Case 6

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-189, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U000)
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U000)
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)

PKIC3146E

//// : Malfunctioning part



PKIC3101E




## Case 7

Check IPDM E/R circuit. Refer to [LAN-190, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN ✓	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓

PKIC3147E



## Case 8

Check CAN communication circuit. Refer to [LAN-190, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—	CAN COMM CIRCUIT (U1000) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication ✓	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓
ABS	—	NG ✓	UNKWN ✓	UNKWN ✓	—	—	—	CAN COMM CIRCUIT (U1000) ✓
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓

PKIC3148E

## Case 9

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-192, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)

PKIC3149E

## Case 10

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-192, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)

PKIC3150E

# CAN SYSTEM (TYPE 4)

[CAN]

---

## CAN SYSTEM (TYPE 4)

PFP:23710

### Component Parts and Harness Connector Location

GKS000DV

A

Refer to [LAN-21, "Component Parts and Harness Connector Location"](#) .

### Schematic

GKS000DW

B

Refer to [LAN-22, "Schematic"](#) .

### Wiring Diagram — CAN —

GKS000DX

C

Refer to [LAN-23, "Wiring Diagram — CAN —"](#) .

D

E

F

G

H

I

J

LAN

L

M

# CAN SYSTEM (TYPE 4)

[CAN]

GKS000DY

## Check Sheet

**NOTE:**

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

# CAN SYSTEM (TYPE 4)

[CAN]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
METER  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIB5017E

## CHECK SHEET RESULTS (EXAMPLE)

**NOTE:**


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

**Case 1**

Check harness between TCM and data link connector. Refer to [LAN-182, "Inspection Between TCM and Data Link Connector Circuit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	—	CAN COMM CIRCUIT (U100) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN ✓	—	CAN COMM CIRCUIT (U100) ✓
BCM	No indication	NG	UNKWN	UNKWN ✓	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U100) ✓
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U100) ✓
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	UNKWN	—	—	CAN COMM CIRCUIT (U100) ✓

PKIC3151E



PKIC3103E

# CAN SYSTEM (TYPE 4)


[CAN]

## Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-183, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	✓	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U00)
ABS	—	NG	UNKWN	✓	—	—	—	—	CAN COMM CIRCUIT (U00)
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U00)

PKIC3152E



PKIC3104E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 4)

[CAN]


## Case 3

Check ECM circuit. Refer to [LAN-185, "ECM Circuit Inspection for A/T Model"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	CAN COMM CIRCUIT (U100) ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	—	UNKWN	—	CAN COMM CIRCUIT (U100) ✓
BCM	No indication	NG	UNKWN	UNKWN ✓	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U100) ✓
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	UNKWN	—	—	CAN COMM CIRCUIT (U100) ✓

PKIC3153E

//// : Malfunctioning part



PKIC3105E



# CAN SYSTEM (TYPE 4)


[CAN]

## Case 4

Check TCM circuit. Refer to [LAN-187, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U000) ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	—	UNKWN ✓	—	CAN COMM CIRCUIT (U000) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000) ✓
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)

PKIC3154E



PKIC3106E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 4)

[CAN]


## Case 5

Check data link connector circuit. Refer to [LAN-187, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication ✓	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)

PKIC3155E

//// : Malfunctioning part



PKIC3107E

# CAN SYSTEM (TYPE 4)

[CAN]

## Case 6


Check BCM circuit. Refer to [LAN-188, "BCM Circuit Inspection"](#) .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	CAN COMM. CIRCUIT (U000) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM. CIRCUIT (U1000)
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM. CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	CAN COMM. CIRCUIT (U000) ✓
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM. CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN ✓	—	—	CAN COMM. CIRCUIT (U000) ✓

PKIC3156E

//// : Malfunctioning part



PKIC3108E

# CAN SYSTEM (TYPE 4)

[CAN]


## Case 7

Check combination meter circuit. Refer to [LAN-188, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	—	CAN COMM CIRCUIT (U1000) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN ✓	—	CAN COMM CIRCUIT (U1000) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication ✓	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)

PKIC3157E

//// : Malfunctioning part



PKIC3109E

# CAN SYSTEM (TYPE 4)


[CAN]

## Case 8

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-189, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)

PKIC3158E



PKIC3110E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 4)

[CAN]


## Case 9

Check IPDM E/R circuit. Refer to [LAN-190, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	—	CAN COMM CIRCUIT (U1000)
A/T	—	NG	UNKW	UNKW	—	—	UNKW	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKW	UNKW	—	—	UNKW	UNKW	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKW	UNKW	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKW	UNKW	—	UNKW	—	—	CAN COMM CIRCUIT (U1000)

PKIC3159E

//// : Malfunctioning part



PKIC3111E

## Case 10

Check CAN communication circuit. Refer to [LAN-190, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	—	CAN COMM CIRCUIT (U1000)
A/T	—	NG	UNKW	UNKW	—	—	UNKW	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKW	UNKW	—	—	UNKW	UNKW	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKW	UNKW	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKW	UNKW	—	UNKW	—	—	CAN COMM CIRCUIT (U1000)

PKIC3160E

# CAN SYSTEM (TYPE 4)

[CAN]

## Case 11

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-192, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)

PKIC3161E

## Case 12

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-192, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)
A/T	—	NG	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)

PKIC3162E

---

**CAN SYSTEM (TYPE 5)**

PFP:23710

**Component Parts and Harness Connector Location**

GKS000DZ

Refer to [LAN-21, "Component Parts and Harness Connector Location"](#) .

**Schematic**

GKS000E0

Refer to [LAN-22, "Schematic"](#) .

**Wiring Diagram — CAN —**

GKS000E1

Refer to [LAN-23, "Wiring Diagram — CAN —"](#) .



# CAN SYSTEM (TYPE 5)

[CAN]

GKS000E2

## Check Sheet

**NOTE:**

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

SKIB6133E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 5)

[CAN]

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
METER  
SELF-DIAG RESULTS

Attach copy of  
ALL MODE AWD/4WD  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ALL MODE AWD/4WD  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

SKIB6134E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check ECM circuit. Refer to [LAN-184, "ECM Circuit Inspection for M/T Model"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U101) ✓
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

SKIB6135E



PKIC3112E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 5)

[CAN]


## Case 2

Check data link connector circuit. Refer to [LAN-187, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB6136E

//// : Malfunctioning part



PKIC3113E

# CAN SYSTEM (TYPE 5)


[CAN]

## Case 3

Check BCM circuit. Refer to [LAN-188, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB6137E



PKIC3114E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 5)


[CAN]

## Case 4

Check combination meter circuit. Refer to [LAN-188, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	METER ✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB6138E



PKIC3115E

# CAN SYSTEM (TYPE 5)


[CAN]

## Case 5

Check transfer control unit circuit. Refer to [LAN-189, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB6139E



PKIC3116E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 5)


[CAN]

## Case 6

Check IPDM E/R circuit. Refer to [LAN-190, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	IPDM E/R			
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	UNKW	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKW	UNKW	—	UNKW	—	UNKW	✓	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKW	UNKW	UNKW	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

SKIB6140E



PKIC3117E

## Case 7

Check CAN communication circuit. Refer to [LAN-190, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	IPDM E/R			
ENGINE	—	NG	UNKW ✓	—	UNKW ✓	UNKW ✓	UNKW ✓	UNKW ✓	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication ✓	NG	UNKW	UNKW	—	UNKW	—	UNKW	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKW ✓	UNKW ✓	—	UNKW ✓	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication ✓	—	UNKW	UNKW	UNKW	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

SKIB6141E



# CAN SYSTEM (TYPE 6)

[CAN]

---

## CAN SYSTEM (TYPE 6)

PFP:23710

### Component Parts and Harness Connector Location

GKS000E3

A

Refer to [LAN-21, "Component Parts and Harness Connector Location"](#) .

### Schematic

GKS000E4

B

Refer to [LAN-22, "Schematic"](#) .

### Wiring Diagram — CAN —

GKS000E5

C

Refer to [LAN-23, "Wiring Diagram — CAN —"](#) .

D

E

F

G

H

I

J

LAN

L

M

# CAN SYSTEM (TYPE 6)

[CAN]

GKS000E6

## Check Sheet

**NOTE:**

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

# CAN SYSTEM (TYPE 6)

[CAN]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
METER  
SELF-DIAG RESULTS

Attach copy of  
ALL MODE AWD/4WD  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ALL MODE AWD/4WD  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIB6525E

# CAN SYSTEM (TYPE 6)

[CAN]

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-183, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7309E



PKIC3118E

# CAN SYSTEM (TYPE 6)


[CAN]

## Case 2

Check ECM circuit. Refer to [LAN-184, "ECM Circuit Inspection for M/T Model"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	✓ UNKWN	—	✓ UNKWN	✓ UNKWN	✓ UNKWN	—	✓ UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	✓ UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	✓ UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	✓ UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	✓ UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7310E



PKIC3119E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 6)


[CAN]

## Case 3

Check data link connector circuit. Refer to [LAN-187, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7311E



# CAN SYSTEM (TYPE 6)


[CAN]

## Case 4

Check BCM circuit. Refer to [LAN-188, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7312E



LAN

# CAN SYSTEM (TYPE 6)


[CAN]

## Case 5

Check combination meter circuit. Refer to [LAN-188, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7313E





# CAN SYSTEM (TYPE 6)


[CAN]

## Case 6

Check transfer control unit circuit. Refer to [LAN-189, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7314E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 6)


[CAN]

## Case 7

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-189, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG ✓	UNKWN ✓	UNKWN ✓	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7315E



# CAN SYSTEM (TYPE 6)


[CAN]

## Case 8

Check IPDM E/R circuit. Refer to [LAN-190, "IPDM E/R Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7316E



## Case 9

Check CAN communication circuit. Refer to [LAN-190, "CAN Communication Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7317E

# CAN SYSTEM (TYPE 6)

[CAN]

## Case 10

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-192, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7318E

## Case 11

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-192, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7319E

# CAN SYSTEM (TYPE 7)

[CAN]

---

## CAN SYSTEM (TYPE 7)

PFP:23710

### Component Parts and Harness Connector Location

GKS000E7

A

Refer to [LAN-21, "Component Parts and Harness Connector Location"](#) .

### Schematic

GKS000E8

B

Refer to [LAN-22, "Schematic"](#) .

### Wiring Diagram — CAN —

GKS000E9

C

Refer to [LAN-23, "Wiring Diagram — CAN —"](#) .

D

E

F

G

H

I

J

LAN

L

M

# CAN SYSTEM (TYPE 7)

[CAN]

GKS000EA

## Check Sheet

### NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

SKIB6060E

# CAN SYSTEM (TYPE 7)

[CAN]

A

B

C

D

E

F

G

H

I

J

LAN

L

M

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
METER  
SELF-DIAG RESULTS

Attach copy of  
ALL MODE AWD/4WD  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ALL MODE AWD/4WD  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

SKIB6105E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-182, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB6106E



PKIC3126E



# CAN SYSTEM (TYPE 7)


[CAN]

## Case 2

Check ECM circuit. Refer to [LAN-185, "ECM Circuit Inspection for A/T Model"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	IPDM E/R		
ENGINE	—	NG	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	CAN COMM CIRCUIT (U1000) <sup>✓</sup>	CAN COMM CIRCUIT (U1001) <sup>✓</sup>
A/T	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	CAN COMM CIRCUIT (U1000) <sup>✓</sup>	—
BCM	No indication	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	CAN COMM CIRCUIT (U1000) <sup>✓</sup>	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) <sup>✓</sup>	—
ALL MODE AWD/4WD	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	—	—	CAN COMM CIRCUIT (U1000) <sup>✓</sup>	—
IPDM E/R	No indication	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	—	—	CAN COMM CIRCUIT (U1000) <sup>✓</sup>	—

SKIB6107E



PKIC3127E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 7)

[CAN]


## Case 3

Check TCM circuit. Refer to [LAN-187, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	—	UNKWN ✓	UNKWN ✓	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN ✓	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB6108E

//// : Malfunctioning part



PKIC3128E

# CAN SYSTEM (TYPE 7)


[CAN]

## Case 4

Check data link connector circuit. Refer to [LAN-187, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
	Initial diagnosis	Transmit diagnosis	Receive diagnosis								
			ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB6109E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LAN

# CAN SYSTEM (TYPE 7)

[CAN]


## Case 5

Check BCM circuit. Refer to [LAN-188, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

SKIB6110E

//// : Malfunctioning part



PKIC3130E

# CAN SYSTEM (TYPE 7)


[CAN]

## Case 6

Check combination meter circuit. Refer to [LAN-188, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN ✓	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN ✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN ✓	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB611E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 7)


[CAN]

## Case 7

Check transfer control unit circuit. Refer to [LAN-189, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB6112E



PKIC3132E

# CAN SYSTEM (TYPE 7)


[CAN]

## Case 8

Check IPDM E/R circuit. Refer to [LAN-190, "IPDM E/R Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB6113E



## Case 9

Check CAN communication circuit. Refer to [LAN-190, "CAN Communication Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB6114E

# CAN SYSTEM (TYPE 7)

[CAN]

## Case 10

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-192, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN ✓	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB6115E

## Case 11

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-192, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB6116E



# CAN SYSTEM (TYPE 8)

**[CAN]**

---

## CAN SYSTEM (TYPE 8)

PPF:23710

### Component Parts and Harness Connector Location

GKS000EB

A

Refer to [LAN-21, "Component Parts and Harness Connector Location"](#) .

### Schematic

GKS000EC

B

Refer to [LAN-22, "Schematic"](#) .

### Wiring Diagram — CAN —

GKS000ED

C

Refer to [LAN-23, "Wiring Diagram — CAN —"](#) .

D

E

F

G

H

I

J

LAN

L

M

# CAN SYSTEM (TYPE 8)

[CAN]

GKS000EE

## Check Sheet

**NOTE:**

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

# CAN SYSTEM (TYPE 8)

[CAN]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
METER  
SELF-DIAG RESULTS

Attach copy of  
ALL MODE AWD/4WD  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ALL MODE AWD/4WD  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIB5022E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-182, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UN <del>KN</del> W <del>N</del>	UN <del>KN</del> W <del>N</del>	UN <del>KN</del> W <del>N</del>	—	UN <del>KN</del> W <del>N</del>	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UN <del>KN</del> W <del>N</del>	UN <del>KN</del> W <del>N</del>	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UN <del>KN</del> W <del>N</del>	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UN <del>KN</del> W <del>N</del>	UN <del>KN</del> W <del>N</del>	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UN <del>KN</del> W <del>N</del>	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UN <del>KN</del> W <del>N</del>	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7045E



# CAN SYSTEM (TYPE 8)


[CAN]

## Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-183, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
AT	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB7046E



PKIC3056E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 8)


[CAN]

## Case 3

Check ECM circuit. Refer to [LAN-185, "ECM Circuit Inspection for A/T Model"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U100) ✓	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN ✓	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—

PKIB7047E



PKIC3057E

# CAN SYSTEM (TYPE 8)


[CAN]

## Case 4

Check TCM circuit. Refer to [LAN-187, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U101)
AT	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U100)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U100)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7048E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 8)


[CAN]

## Case 5

Check data link connector circuit. Refer to [LAN-187, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7049E



PKIC3059E



# CAN SYSTEM (TYPE 8)


[CAN]

## Case 6

Check BCM circuit. Refer to [LAN-188, "BCM Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
AT	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7050E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LAN

# CAN SYSTEM (TYPE 8)


[CAN]

## Case 7

Check combination meter circuit. Refer to [LAN-188, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7051E



# CAN SYSTEM (TYPE 8)


[CAN]

## Case 8

Check transfer control unit circuit. Refer to [LAN-189, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
AT	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	✓	✓	✓	—	✓	—	✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7052E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 8)


[CAN]

## Case 9

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-189, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN ✓	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG ✓	UNKWN ✓	UNKWN ✓	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7053E



SKIB5995E

# CAN SYSTEM (TYPE 8)


[CAN]

## Case 10

Check IPDM E/R circuit. Refer to [LAN-190, "IPDM E/R Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	UNKW	—	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
AT	—	NG	UNKW	UNKW	—	—	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKW	UNKW	—	—	UNKW	—	—	UNKW	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	UNKW	—	UNKW	—	UNKW	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	UNKW	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7054E



## Case 11

Check CAN communication circuit. Refer to [LAN-190, "CAN Communication Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	✓	—	✓	✓	✓	✓	—	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
AT	—	NG	UNKW	✓	—	—	✓	✓	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKW	UNKW	—	—	UNKW	—	—	UNKW	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	✓	✓	✓	—	✓	—	✓	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	✓	✓	✓	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	UNKW	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7055E

# CAN SYSTEM (TYPE 8)

[CAN]

## Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-192. "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	✓	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	✓	—	UNKWN	—	✓	—	CAN COMM CIRCUIT (U100) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7056E

## Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-192. "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7057E

# CAN SYSTEM (TYPE 9)

**[CAN]**

---

## CAN SYSTEM (TYPE 9)

PFP:23710

### Component Parts and Harness Connector Location

GKS000DF

A

Refer to [LAN-21, "Component Parts and Harness Connector Location"](#) .

### Schematic

GKS000DG

B

Refer to [LAN-22, "Schematic"](#) .

### Wiring Diagram — CAN —

GKS000DH

C

Refer to [LAN-23, "Wiring Diagram — CAN —"](#) .

D

E

F

G

H

I

J

LAN

L

M

# CAN SYSTEM (TYPE 9)

[CAN]

GKS000DI

## Check Sheet

### NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

PKIC3089E



# CAN SYSTEM (TYPE 9)

[CAN]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
METER  
SELF-DIAG RESULTS

Attach copy of  
ALL MODE AWD/4WD  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ALL MODE AWD/4WD  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

SKIB6134E

## CHECK SHEET RESULTS (EXAMPLE)

**NOTE:**


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

**Case 1**

Check ECM circuit. Refer to [LAN-184, "ECM Circuit Inspection for M/T Model"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—	CAN COMM CIRCUIT (U000) ✓
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U000) ✓
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN ✓	—	UNKWN	—	CAN COMM CIRCUIT (U000) ✓
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	UNKWN	—	—	CAN COMM CIRCUIT (U000) ✓

PKIC3163E



PKIC3112E


## Case 2

Check data link connector circuit. Refer to [LAN-187, "Data Link Connector Circuit Inspection"](#) .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)

PKIC3164E



# CAN SYSTEM (TYPE 9)

[CAN]


## Case 3

Check BCM circuit. Refer to [LAN-188, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U000) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U000) ✓
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U000) ✓

PKIC3165E

//// : Malfunctioning part



PKIC3114E

# CAN SYSTEM (TYPE 9)

[CAN]


## Case 4

Check combination meter circuit. Refer to [LAN-188, "Combination Meter Circuit Inspection"](#) .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U000)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U000)
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)

PKIC3166E



PKIC3115E

# CAN SYSTEM (TYPE 9)


[CAN]

## Case 5

Check transfer control unit circuit. Refer to [LAN-189, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKW	—	UNKW	UNKW	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKW	UNKW	—	UNKW	UNKW	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	—	UNKW	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKW	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)

PKIC3167E



PKIC3116E

# CAN SYSTEM (TYPE 9)


[CAN]

## Case 6

Check IPDM E/R circuit. Refer to [LAN-190, "IPDM E/R Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN ✓	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓

PKIC3168E



## Case 7

Check CAN communication circuit. Refer to [LAN-190, "CAN Communication Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				
				ECM	BCM /SEC	METER /M&A	IPDM E/R	
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—	CAN COMM CIRCUIT (U1000) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication ✓	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓
ALL MODE AWD/4WD	—	NG	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—	CAN COMM CIRCUIT (U1000) ✓
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓

PKIC3169E

---

### CAN SYSTEM (TYPE 10)

PFP:23710

#### Component Parts and Harness Connector Location

GKS000DB

Refer to [LAN-21, "Component Parts and Harness Connector Location"](#) .

#### Schematic

GKS000DC

Refer to [LAN-22, "Schematic"](#) .

#### Wiring Diagram — CAN —

GKS000DD

Refer to [LAN-23, "Wiring Diagram — CAN —"](#) .



# CAN SYSTEM (TYPE 10)

[CAN]

GKS000DE

## Check Sheet

**NOTE:**

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

LAN

# CAN SYSTEM (TYPE 10)

[CAN]

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
METER  
SELF-DIAG RESULTS

Attach copy of  
ALL MODE AWD/4WD  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ALL MODE AWD/4WD  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIB6525E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-183. "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)

PKIC3170E



PKIC3118E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LAN

# CAN SYSTEM (TYPE 10)


[CAN]

## Case 2

Check ECM circuit. Refer to [LAN-184, "ECM Circuit Inspection for M/T Model"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	CAN COMM CIRCUIT (U <sup>✓</sup> 100)
BCM	No indication	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	CAN COMM CIRCUIT (U <sup>✓</sup> 1000)
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U <sup>✓</sup> 100)
ALL MODE AWD/4WD	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	CAN COMM CIRCUIT (U <sup>✓</sup> 100)
ABS	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	—	CAN COMM CIRCUIT (U <sup>✓</sup> 100)
IPDM E/R	No indication	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	CAN COMM CIRCUIT (U <sup>✓</sup> 100)

PKIC3171E



PKIC3119E

# CAN SYSTEM (TYPE 10)


[CAN]

## Case 3

Check data link connector circuit. Refer to [LAN-187, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)

PKIC3172E



PKIC3120E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 10)

[CAN]


## Case 4

Check BCM circuit. Refer to [LAN-188, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN ✓	—	—	—	CAN COMM CIRCUIT (U1000) ✓

PKIC3173E

//// : Malfunctioning part



PKIC3121E

# CAN SYSTEM (TYPE 10)


[CAN]

## Case 5

Check combination meter circuit. Refer to [LAN-188, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	—	—	CAN COMM. CIRCUIT (U100) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN	CAN COMM. CIRCUIT (U1000)
METER	No indication ✓	—	—	—	—	—	—	—	CAN COMM. CIRCUIT (U100) ✓
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN ✓	UNKWN	—	CAN COMM. CIRCUIT (U1000)
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM. CIRCUIT (U1000)
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM. CIRCUIT (U1000)

PKIC3174E



PKIC3122E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 10)


[CAN]

## Case 6

Check transfer control unit circuit. Refer to [LAN-189, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ALL MODE AWD/4WD	—	NG	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—	CAN COMM CIRCUIT (U1000) ✓
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)

PKIC3175E



PKIC3123E



# CAN SYSTEM (TYPE 10)


[CAN]

## Case 7

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-189, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)

PKIC3176E



PKIC3124E

LAN

# CAN SYSTEM (TYPE 10)


[CAN]

## Case 8

Check IPDM E/R circuit. Refer to [LAN-190, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKW	—	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKW	UNKW	—	UNKW	—	UNKW	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	—	UNKW	UNKW	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKW	UNKW	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKW	UNKW	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)

PKIC3177E



PKIC3125E

## Case 9

Check CAN communication circuit. Refer to [LAN-190, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKW	—	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKW	UNKW	—	UNKW	—	UNKW	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	—	UNKW	UNKW	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKW	UNKW	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKW	UNKW	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)

PKIC3178E

# CAN SYSTEM (TYPE 10)

[CAN]

## Case 10

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-192, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN ✓	—	CAN COMM CIRCUIT (U1000) ✓
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)

PKIC3179E

## Case 11

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-192, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)

PKIC3180E

---

## CAN SYSTEM (TYPE 11)

PFP:23710

### Component Parts and Harness Connector Location

GKS000D7

Refer to [LAN-21, "Component Parts and Harness Connector Location"](#) .

### Schematic

GKS000D8

Refer to [LAN-22, "Schematic"](#) .

### Wiring Diagram — CAN —

GKS000D9

Refer to [LAN-23, "Wiring Diagram — CAN —"](#) .

# CAN SYSTEM (TYPE 11)

[CAN]

GKS000DA

## Check Sheet

**NOTE:**

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

LAN

# CAN SYSTEM (TYPE 11)

[CAN]

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
METER  
SELF-DIAG RESULTS

Attach copy of  
ALL MODE AWD/4WD  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ALL MODE AWD/4WD  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

SKIB6105E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-182, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	IPDM E/R	
ENGINE	—	NG	UNKWVN	—	UNKWVN	UNKWVN	UNKWVN	—	—	CAN COMM CIRCUIT (U1000) ✓
A/T	—	NG	UNKWVN	UNKWVN	—	—	UNKWVN	UNKWVN	—	CAN COMM CIRCUIT (U1000) ✓
BCM	No indication	NG	UNKWVN	UNKWVN	—	—	UNKWVN	—	UNKWVN	CAN COMM CIRCUIT (U1000) ✓
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓
ALL MODE AWD/4WD	—	NG	UNKWVN	UNKWVN	UNKWVN	—	UNKWVN	—	—	CAN COMM CIRCUIT (U1000) ✓
IPDM E/R	No indication	—	UNKWVN	UNKWVN	—	UNKWVN	—	—	—	CAN COMM CIRCUIT (U1000) ✓

PKIC3181E



PKIC3126E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 11)

[CAN]


## Case 2

Check ECM circuit. Refer to [LAN-185, "ECM Circuit Inspection for A/T Model"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	IPDM E/R	
ENGINE	—	NG	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	CAN COMM CIRCUIT (U1000) ✓
A/T	—	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	CAN COMM CIRCUIT (U1000) ✓
BCM	No indication	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	CAN COMM CIRCUIT (U1000) ✓
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓
ALL MODE AWD/4WD	—	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	—	—	CAN COMM CIRCUIT (U1000) ✓
IPDM E/R	No indication	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	—	—	—	CAN COMM CIRCUIT (U1000) ✓

PKIC3182E

//// : Malfunctioning part



PKIC3127E



# CAN SYSTEM (TYPE 11)


[CAN]

## Case 3

Check TCM circuit. Refer to [LAN-187, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	IPDM E/R	
ENGINE	—	NG	UNKWVN	—	UNKWVN ✓	UNKWVN	UNKWVN	—	—	CAN COMM CIRCUIT (U100) ✓
A/T	—	NG	UNKWVN	UNKWVN ✓	—	—	UNKWVN ✓	UNKWVN ✓	—	CAN COMM CIRCUIT (U100) ✓
BCM	No indication	NG	UNKWVN	UNKWVN	—	—	UNKWVN	—	UNKWVN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓
ALL MODE AWD/4WD	—	NG	UNKWVN	UNKWVN	UNKWVN ✓	—	UNKWVN	—	—	CAN COMM CIRCUIT (U100) ✓
IPDM E/R	No indication	—	UNKWVN	UNKWVN	—	UNKWVN	—	—	—	CAN COMM CIRCUIT (U1000)

PKIC3183E



PKIC3128E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 11)

[CAN]


## Case 4

Check data link connector circuit. Refer to [LAN-187, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication ✓	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)

PKIC3184E

//// : Malfunctioning part



PKIC3129E

# CAN SYSTEM (TYPE 11)


[CAN]

## Case 5

Check BCM circuit. Refer to [LAN-188, "BCM Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	IPDM E/R	
ENGINE	—	NG	UNKWVN	—	UNKWVN	UNKWVN	UNKWVN	—	—	CAN COMM CIRCUIT (U000)
A/T	—	NG	UNKWVN	UNKWVN	—	—	UNKWVN	UNKWVN	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWVN	UNKWVN	—	—	UNKWVN	—	UNKWVN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000)
ALL MODE AWD/4WD	—	NG	UNKWVN	UNKWVN	UNKWVN	—	UNKWVN	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWVN	UNKWVN	—	UNKWVN	—	—	—	CAN COMM CIRCUIT (U000)

PKIC3185E



PKIC3130E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LAN

# CAN SYSTEM (TYPE 11)

[CAN]


## Case 6

Check combination meter circuit. Refer to [LAN-188, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U000) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U000) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication ✓	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000) ✓
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)

PKIC3186E

//// : Malfunctioning part



PKIC3131E

# CAN SYSTEM (TYPE 11)


[CAN]

## Case 7

Check transfer control unit circuit. Refer to [LAN-189, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	IPDM E/R	
ENGINE	—	NG	UNKWVN	—	UNKWVN	UNKWVN	UNKWVN	—	—	CAN COMM CIRCUIT (U1000)
A/T	—	NG	UNKWVN	UNKWVN	—	—	UNKWVN	✓	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWVN	UNKWVN	—	—	UNKWVN	—	UNKWVN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ALL MODE AWD/4WD	—	NG	✓	✓	✓	—	✓	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWVN	UNKWVN	—	UNKWVN	—	—	—	CAN COMM CIRCUIT (U1000)

PKIC3187E



PKIC3132E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 11)

[CAN]


## Case 8

Check IPDM E/R circuit. Refer to [LAN-190, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	IPDM E/R	
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)
A/T	—	NG	UNKW	UNKW	—	—	UNKW	UNKW	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKW	UNKW	—	—	UNKW	—	UNKW	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	UNKW	—	UNKW	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKW	UNKW	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)

PKIC3188E

//// : Malfunctioning part



PKIC3133E

## Case 9

Check CAN communication circuit. Refer to [LAN-190, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	IPDM E/R	
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)
A/T	—	NG	UNKW	UNKW	—	—	UNKW	UNKW	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKW	UNKW	—	—	UNKW	—	UNKW	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	UNKW	—	UNKW	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKW	UNKW	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)

PKIC3189E

# CAN SYSTEM (TYPE 11)

[CAN]

## Case 10

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-192, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	IPDM E/R	
ENGINE	—	NG	UNKWVN	—	UNKWVN	UNKWVN	UNKWVN	—	—	CAN COMM CIRCUIT (U1000)
A/T	—	NG	UNKWVN	UNKWVN	—	—	UNKWVN	UNKWVN	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWVN	UNKWVN	—	—	UNKWVN	—	UNKWVN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ALL MODE AWD/4WD	—	NG	UNKWVN	UNKWVN	UNKWVN	—	UNKWVN	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWVN	UNKWVN	—	UNKWVN	—	—	—	CAN COMM CIRCUIT (U1000)

PKIC3190E

## Case 11

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-192, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	IPDM E/R	
ENGINE	—	NG	UNKWVN	—	UNKWVN	UNKWVN	UNKWVN	—	—	CAN COMM CIRCUIT (U1000)
A/T	—	NG	UNKWVN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWVN	UNKWVN	—	—	UNKWVN	—	UNKWVN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ALL MODE AWD/4WD	—	NG	UNKWVN	UNKWVN	UNKWVN	—	UNKWVN	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWVN	UNKWVN	—	UNKWVN	—	—	—	CAN COMM CIRCUIT (U1000)

PKIC3191E

---

## CAN SYSTEM (TYPE 12)

PFP:23710

### Component Parts and Harness Connector Location

GKS000EF

Refer to [LAN-21, "Component Parts and Harness Connector Location"](#) .

### Schematic

GKS000EG

Refer to [LAN-22, "Schematic"](#) .

### Wiring Diagram — CAN —

GKS000EH

Refer to [LAN-23, "Wiring Diagram — CAN —"](#) .



# CAN SYSTEM (TYPE 12)

[CAN]

GKS000E1

## Check Sheet

### NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R	
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

PKIC3067E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 12)

[CAN]

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
METER  
SELF-DIAG RESULTS

Attach copy of  
ALL MODE AWD/4WD  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ALL MODE AWD/4WD  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIB5022E

## CHECK SHEET RESULTS (EXAMPLE)

**NOTE:**


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

**Case 1**

Check harness between TCM and data link connector. Refer to [LAN-182, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U000)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U000)
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000)
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U000)
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U000)
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)

PKIC3068E



PKIC3055E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 12)

[CAN]


## Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-183, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)
AT	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)

PKIC3069E

//// : Malfunctioning part



PKIC3056E

# CAN SYSTEM (TYPE 12)


[CAN]

## Case 3

Check ECM circuit. Refer to [LAN-185, "ECM Circuit Inspection for A/T Model"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	CAN COMM CIRCUIT (U000) <sup>✓</sup>
A/T	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	CAN COMM CIRCUIT (U000) <sup>✓</sup>
BCM	No indication	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	CAN COMM CIRCUIT (U1000) <sup>✓</sup>
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000) <sup>✓</sup>
ALL MODE AWD/4WD	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	CAN COMM CIRCUIT (U000) <sup>✓</sup>
ABS	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	—	—	—	CAN COMM CIRCUIT (U000) <sup>✓</sup>
IPDM E/R	No indication	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	—	—	—	CAN COMM CIRCUIT (U000) <sup>✓</sup>

PKIC3070E



PKIC3057E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LAN

# CAN SYSTEM (TYPE 12)

[CAN]


## Case 4

Check TCM circuit. Refer to [LAN-187, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U000) ✓
AT	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U000) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000) ✓
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U000) ✓
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)

PKIC3071E

//// : Malfunctioning part



PKIC3058E

# CAN SYSTEM (TYPE 12)


[CAN]

## Case 5

Check data link connector circuit. Refer to [LAN-187, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)

PKIC3072E



PKIC3059E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 12)

[CAN]


## Case 6

Check BCM circuit. Refer to [LAN-188, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓
AT	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓

PKIC3073E

//// : Malfunctioning part



PKIC3060E



# CAN SYSTEM (TYPE 12)


[CAN]

## Case 7

Check combination meter circuit. Refer to [LAN-188, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000) ✓
METER	No indication ✓	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓

PKIC3074E



PKIC3061E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 12)


[CAN]

## Case 8

Check transfer control unit circuit. Refer to [LAN-189, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)

PKIC3075E



PKIC3062E

# CAN SYSTEM (TYPE 12)


[CAN]

## Case 9

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-189, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)

PKIC3076E



PKIC3063E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 12)


[CAN]

## Case 10

Check IPDM E/R circuit. Refer to [LAN-190, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000)
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)

PKIC3077E



PKIC3064E

## Case 11

Check CAN communication circuit. Refer to [LAN-190, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U000)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U000)
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000)
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U000)
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U000)
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)

PKIC3078E

# CAN SYSTEM (TYPE 12)

[CAN]

## Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-192, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)

PKIC3079E

## Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-192, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)
A/T	—	NG	UNKWN	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)
ABS	—	NG	UNKWN	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)

PKIC3080E

**TROUBLE DIAGNOSIS FOR SYSTEM**

**Inspection Between TCM and Data Link Connector Circuit**

**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector F2
  - Harness connector E8
  - Harness connector E101
  - Harness connector M91


**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect A/T assembly connector and harness connector F2.
2. Check continuity between A/T assembly harness connector and harness connector.

A/T assembly connector		Harness connector		Continuity
Connector	Terminal	Connector	Terminal	
F36	3	F2	2	Yes
	8		3	Yes




**OK or NG**

- OK >> GO TO 3.  
 NG >> Repair harness.

**3. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect harness connector E101.
2. Check continuity between harness connector and SMJ harness connector.

Harness connector		SMJ harness connector		Continuity
Connector	Terminal	Connector	Terminal	
E8	2	E101	52G	Yes
	3		51G	Yes



**OK or NG**

- OK >> GO TO 4.  
 NG >> Repair harness.


## 4. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between SMJ harness connector and data link connector.

SMJ harness connector		Data link connector		Continuity
Connector	Terminal	Connector	Terminal	
M91	52G	M45	6	Yes
	51G		14	Yes

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness.



## Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

GKS000AL

### 1. CHECK CONNECTOR

- Turn ignition switch OFF.
- Disconnect the battery cable from the negative terminal.
- Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector M3
  - Harness connector E112

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

- Disconnect harness connector M3.
- Check continuity between data link connector and harness connector.

Data link connector		Harness connector		Continuity
Connector	Terminal	Connector	Terminal	
M45	6	M3	11	Yes
	14		10	Yes

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

## 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector and ABS actuator and electric unit (control unit) harness connector.

Harness connector		ABS actuator and electric unit (control unit) connector		Continuity
Connector	Terminal	Connector	Terminal	
E112	11	E63	11	Yes
	10		15	Yes



### OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness.

## ECM Circuit Inspection for M/T Model

GKS000AM

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - ECM connector
  - Harness connector E101
  - Harness connector M91

### OK or NG

- OK >> GO TO 2
- NG >> Repair terminal or connector.




## 2. CHECK HARNESS FOR OPEN CIRCUIT

VQ engine

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector terminals.


ECM connector	Terminal		Resistance (Approx.)
E20	94	86	108 – 132 Ω



YD engine

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector terminals.

ECM connector	Terminal		Resistance (Approx.)
E20	95	87	108 – 132 Ω



OK or NG

- OK >> Replace ECM.
- NG >> Repair harness between ECM and data link connector.

## ECM Circuit Inspection for A/T Model

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - ECM connector
  - Harness connector E9
  - Harness connector F4

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J


LAN

## 2. CHECK HARNESS FOR OPEN CIRCUIT

VQ engine

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector terminals.


ECM connector	Terminal		Resistance (Approx.)
E20	94	86	108 – 132 Ω



YD engine

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector terminals.

ECM connector	Terminal		Resistance (Approx.)
E20	95	87	108 – 132 Ω



**OK or NG**

- OK >> Replace ECM.
- NG >> Repair harness between ECM and A/T assembly.

## TCM Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector terminals.

A/T assembly connector	Terminal		Resistance (Approx.)
F36	3	8	54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.  
 NG >> Repair harness between A/T assembly and harness connector F2.



## Data Link Connector Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector terminals.

Data link connector	Terminal		Resistance (Approx.)
M45	6	14	54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-5. "TROUBLE DIAGNOSES WORK FLOW"](#) .  
 NG >> Repair harness between data link connector and BCM.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LAN

## BCM Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector terminals.

BCM connector	Terminal		Resistance (Approx.)
M42	22	21	54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-15, "Removal and Installation of BCM"](#) .  
 NG >> Repair harness between BCM and data link connector.



## Combination Meter Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector terminals.

Combination meter connector	Terminal		Resistance (Approx.)
M23	12	11	54 – 66 Ω

OK or NG

- OK >> Replace combination meter.  
 NG >> Repair harness between combination meter and data link connector.



## Transfer Control Unit Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector terminals.

Transfer control unit connector	Terminal		Resistance (Approx.)
M105	1	2	54 – 66 Ω

OK or NG

- OK >> Replace transfer control unit.  
 NG >> Repair harness between transfer control unit and data link connector.



## ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit) connector	Terminal		Resistance (Approx.)
E63	11	15	54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



## IPDM E/R Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connector for damage, bend and loose connection (control module side and harness side).
  - IPDM E/R connector
  - Harness connector E112 (Without ABS)
  - Harness connector M3 (Without ABS)

**OK or NG**

- OK >> ● GO TO 2 (With ABS).  
           ● GO TO 3 (Without ABS).
- NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector terminals.

IPDM E/R connector	Terminal		Resistance (Approx.)
E17	39	40	108 – 132 Ω

**OK or NG**

- OK >> Replace IPDM E/R.
- NG >> Repair harness between IPDM E/R and harness connector E112.




### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector terminals.

IPDM E/R connector	Terminal		Resistance (Approx.)
E17	39	40	108 – 132 Ω

**OK or NG**

- OK >> Replace IPDM E/R.
- NG >> Repair harness between IPDM E/R and data link connector.



## CAN Communication Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the harness connector for each unit on the CAN network and check terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.
- NG >> Repair terminal or connector as necessary.

## 2. CHECK HARNESS FOR SHORT CIRCUIT

With all module and control unit connectors disconnected, check continuity between data link connector terminals.


Data link connector	Terminal		Continuity
M45	6	14	No

OK or NG

OK >> GO TO 3.

NG >> ● Repair harness.

- Replace harness if shielded lines are used for the harness.



## 3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector terminals and ground.


Data link connector	Terminal	Ground	Continuity
M45	6		No
	14	No	

OK or NG

OK >> GO TO 4.

NG >> ● Repair harness.

- Replace harness if shielded lines are used for the harness.



## 4. ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals.

ECM	Terminal		Resistance (Approx.)
VQ engine	94	86	108 – 132 Ω
YD engine	95	87	108 – 132 Ω

3. Check resistance between IPDM E/R terminals.

Terminal		Resistance (Approx.)
39	40	108 – 132 Ω

OK or NG

OK >> GO TO 5.

NG >> Replace ECM and/or IPDM E/R.


## 5. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

Check results

Reproduced>>GO TO 6.

Not reproduced>>Refer to [LAN-13. "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#) .



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

---

## 6. UNIT REPRODUCIBILITY INSPECTION

---

Perform the following procedure for each unit on the CAN network, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced.

**NOTE:**

Malfunction (related to a unit that the connector is disconnected) is reproduced. Do not confuse the malfunction with the symptom filled in the column of "Symptom" on the check sheet.

Inspection results

Reproduced>>Connect the disconnected connector. Check other units applying the above procedure.

Not reproduced>>Replace the unit that the connector is disconnected.

### IPDM E/R Ignition Relay Circuit Inspection

GKS000AZ

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-24, "Check IPDM E/R Power Supply and Ground Circuit"](#) .
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .