

SECTION **RFD**
REAR FINAL DRIVE

A
B
C

RFD

CONTENTS

E
F
G
H
I
J
K
L
M

WITHOUT LIMITED SLIP DIFFERENTIAL

PRECAUTIONS 3
 Service Notice or Precautions 3
PREPARATION 4
 Special Service Tools 4
 Commercial Service Tools 5
NOISE, VIBRATION, AND HARSHNESS (NVH)
TROUBLESHOOTING 7
 NVH Troubleshooting Chart 7
DESCRIPTION 8
 Cross-Sectional View 8
DIFFERENTIAL GEAR OIL 9
 Changing Differential Gear Oil 9
 DRAINING 9
 FILLING 9
 Checking Differential Gear Oil 9
 OIL LEAKAGE AND OIL LEVEL 9
FRONT OIL SEAL 10
 Removal and Installation 10
 REMOVAL 10
 INSTALLATION 11
CARRIER COVER 13
 Removal and Installation 13
 REMOVAL 13
 INSTALLATION 13
REAR FINAL DRIVE ASSEMBLY 14
 Removal and Installation 14
 REMOVAL 14
 INSTALLATION 14
 Disassembly and Assembly 15
 COMPONENTS 15
 ASSEMBLY INSPECTION AND ADJUSTMENT.. 16
 DISASSEMBLY 19
 INSPECTION AFTER DISASSEMBLY 23
 SELECTION ADJUSTING WASHERS 23
 ASSEMBLY 25

SERVICE DATA AND SPECIFICATIONS (SDS) 34

General Specifications 34
 Inspection and Adjustment 34
 PRELOAD TORQUE 34
 BACKLASH 34
 COMPANION FLANGE RUNOUT 34
 SELECTIVE PARTS 35

WITH LIMITED SLIP DIFFERENTIAL

PRECAUTIONS 36
 Limited Slip Differential (LSD) Performance Judgment 36
 METHOD FOR TROUBLESHOOTING 36
 Service Notice or Precautions 36
PREPARATION 37
 Special Service Tools 37
 Commercial Service Tools 38
NOISE, VIBRATION, AND HARSHNESS (NVH)
TROUBLESHOOTING 40
 NVH Troubleshooting Chart 40
DESCRIPTION 41
 Cross-Sectional View 41
DIFFERENTIAL GEAR OIL 42
 Changing Differential Gear Oil 42
 DRAINING 42
 FILLING 42
 Checking Differential Gear Oil 42
 OIL LEAKAGE AND OIL LEVEL 42
FRONT OIL SEAL 43
 Removal and Installation 43
 REMOVAL 43
 INSTALLATION 44
CARRIER COVER 46
 Removal and Installation 46
 REMOVAL 46
 INSTALLATION 46
REAR FINAL DRIVE ASSEMBLY 47
 Removal and Installation 47
 REMOVAL 47

| | | | |
|---------------------------------------|----|--|-----------|
| INSTALLATION | 47 | SERVICE DATA AND SPECIFICATIONS (SDS) | 64 |
| Disassembly and Assembly | 48 | General Specifications | 64 |
| COMPONENTS | 48 | Inspection and Adjustment | 64 |
| ASSEMBLY INSPECTION AND ADJUSTMENT... | 49 | PRELOAD TORQUE | 64 |
| DISASSEMBLY | 52 | BACKLASH | 64 |
| INSPECTION AFTER DISASSEMBLY | 55 | COMPANION FLANGE RUNOUT | 64 |
| SELECTION ADJUSTING WASHERS | 56 | SELECTIVE PARTS | 65 |
| ASSEMBLY | 57 | | |

PRECAUTIONS

[WITHOUT LIMITED SLIP DIFFERENTIAL]

PRECAUTIONS

PPF:00001

Service Notice or Precautions

GDS0006E

- Check for the correct installation status prior to removal or disassembly. If matching marks are required, be certain they do not interfere with the function of the parts when applied.
- Overhaul should be done in a clean work area, it is preferable to work in dust proof area.
- Before disassembly completely remove sand and mud from the exterior of the unit, preventing them from entering into the unit during disassembly or assembly.
- Check appearance of the disassembled parts for damage, deformation, and unusual wear. Replace them with new ones if necessary.
- Gaskets, seals and O-rings should be replaced any time the unit is disassembled.
- In principle, tighten bolts or nuts gradually in several steps working diagonally from inside to outside. If tightening sequence is specified, observe it.
- Clean and flush the parts sufficiently and blow-dry them.
- Be careful not to damage sliding surfaces and mating surfaces.
- When applying sealant, remove the old sealant from the mounting surface; then remove any moisture, oil, and foreign materials from the application and mounting surfaces.
- Always use shop paper for cleaning the inside of components.
- Avoid using cotton gloves or shop rags to prevent entering of lint.
- During assembly, observe the specified tightening torque, and apply new differential gear oil, petroleum jelly, or multi-purpose grease as specified.

A

B

C

RFD

E

F

G

H

I

J

K

L

M








PREPARATION [WITHOUT LIMITED SLIP DIFFERENTIAL]

PREPARATION

PFP:00002



Special Service Tools

GDS0006F

| Tool number Tool name | Description |
|---|--|
| ST3127S000 Preload gauge set 1. GG91030000 Torque wrench 2. HT62940000 (1/2") Socket adapter 3. HT62900000 (3/8") Socket adapter |  Inspecting pinion bearing preload and total preload |
| KV40104000 Flange wrench a: 85 mm (3.35 in) dia. b: 65 mm (2.56 in) dia. |  Removing and installing drive pinion lock nut |
| KV381054S0 Puller |  Removing front oil seal |
| KV10111100 Seal cutter |  Removing carrier cover |
| KV38108800 Adjuster tool |  Removing and installing side bearing adjuster |
| ST30021000 Puller |  Removing drive pinion rear bearing inner race |
| ST23550000 Pin punch a: 4.5 mm (0.177 in) dia. |  Removing and installing lock pin |

PREPARATION [WITHOUT LIMITED SLIP DIFFERENTIAL]

| Tool number Tool name | Description |
|---|---|
| ST30022000 Drift a: 46 mm (1.81 in) dia. b: 110 mm (4.33 in) dia. | Installing drive pinion rear bearing outer race |
| KV38100300 Drift a: 54 mm (2.13 in) dia. b: 46 mm (1.81 in) dia. c: 32mm (1.26 in) dia. | Installing side bearing inner race |





Commercial Service Tools GDS0006G

| Tool name | Description |
|---|---|
| Puller | <ul style="list-style-type: none"> ● Removing companion flange ● Removing side bearing inner race |
| Drift a: 96mm (3.77 in) dia. b: 84 mm (3.30 in) dia. | Installing front oil seal |
| Adapter a: 43 mm (1.69 in) dia. | Removing and installing side bearing inner race |
| Puller | Removing side bearing inner race |
| Drift a: 89 mm (3.50 in) dia. b: 79 mm (3.11 in) dia. | Installing drive pinion rear bearing outer race |

A
B
C
RFD
E
F
G
H
I
J
K
L
M

PREPARATION

[WITHOUT LIMITED SLIP DIFFERENTIAL]

| Tool name | Description |
|---|--|
| <p>Drift a: 67 mm (2.63 in) dia.</p>  <p>PDIA0893E</p> | Installing drive pinion front bearing outer race |
| <p>Installer a: 51 mm (2.01 in) dia. b: 41 mm (1.61 in) dia.</p>  <p>NT065</p> | Installing drive pinion rear bearing inner race |

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING [WITHOUT LIMITED SLIP DIFFERENTIAL]

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

PPF:00003

NVH Troubleshooting Chart

GDS0006H

Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

| Symptom | Noise | Possible cause and SUSPECTED PARTS | Reference page |
|---------|-------|------------------------------------|--|
| × | × | Gear tooth rough | RFD-23, "INSPECTION AFTER DISASSEMBLY" |
| × | × | Gear contact improper | RFD-16, "Tooth Contact" |
| × | × | Tooth surfaces worn | RFD-23, "INSPECTION AFTER DISASSEMBLY" |
| × | × | Backlash incorrect | RFD-17, "Backlash" |
| × | × | Companion flange excessive runout | RFD-18, "Companion Flange Runout" |
| × | × | Gear oil improper | RFD-9, "Checking Differential Gear Oil" |
| × | × | PROPELLER SHAFT | PR-2, "NVH Troubleshooting Chart" |
| × | × | AXLE AND SUSPENSION | RAX-5, "NVH Troubleshooting Chart", RSU-4, "NVH Troubleshooting Chart" |
| × | × | TIRES | WT-2, "NVH Troubleshooting Chart" |
| × | × | ROAD WHEEL | RAX-5, "NVH Troubleshooting Chart" |
| × | × | AXLE SHAFT | BR-5, "NVH Troubleshooting Chart" |
| × | × | BRAKES | PS-5, "NVH Troubleshooting Chart" |
| × | × | STEERING | PS-5, "NVH Troubleshooting Chart" |

×: Applicable

A
B
C
RFD
E
F
G
H
I
J
K
L
M

DESCRIPTION


[WITHOUT LIMITED SLIP DIFFERENTIAL]

DESCRIPTION

PFP:00000

Cross-Sectional View

GDS0006I



SDIA3470E

- | | | |
|----------------------|----------------------|---------------|
| 1. Companion flange | 2. Drive pinion | 3. Drive gear |
| 4. Differential case | 5. Pinion mate gear | 6. Axle shaft |
| 7. Side gear | 8. Pinion mate shaft | |

DIFFERENTIAL GEAR OIL [WITHOUT LIMITED SLIP DIFFERENTIAL]


DIFFERENTIAL GEAR OIL

PFP:KLD30

Changing Differential Gear Oil DRAINING

GDS0006J

1. Stop engine.
2. Remove drain plug and drain gear oil.
3. Apply sealant to drain plug. Install drain plug to final drive assembly and tighten to the specified torque. Refer to [RFD-15, "COMPONENTS"](#).



FILLING

1. Remove filler plug. Fill with new gear oil until oil level reaches the specified limit near filler plug hole.


Oil grade and Viscosity:

Refer to [MA-13, "Fluids and Lubricants"](#).

Oil capacity:

Approx. 2.01 ℓ (3-1/2pt)

2. After refilling oil, check oil level. Apply sealant to filler plug. Install filler plug to final drive assembly and tighten to the specified torque. Refer to [RFD-15, "COMPONENTS"](#).



Checking Differential Gear Oil OIL LEAKAGE AND OIL LEVEL


GDS0006K

1. Make sure that gear oil is not leaking from final drive assembly or around it.
2. Check oil level from filler plug hole as shown.

CAUTION:

Do not start engine while checking oil level.

3. Apply sealant to filler plug. Install filler plug to final drive assembly and tighten to the specified torque. Refer to [RFD-15, "COMPONENTS"](#).



FRONT OIL SEAL [WITHOUT LIMITED SLIP DIFFERENTIAL]

PFP:38189


GDS006L

FRONT OIL SEAL

Removal and Installation REMOVAL


1. Remove the rear propeller shaft. Refer to [PR-8, "Removal and Installation"](#) .
2. Remove the rear tires.
3. Remove rear drum brake. Refer to [BR-31, "Removal and Installation of Drum Brake Assembly"](#) .
4. Rotate the drive pinion back and forth 2 to 3 times using Tool and record the rotating torque.

Tool number : ST3127S000



5. Remove the drive pinion lock nut and washer using Tool.


Tool number : KV40104000




6. Put a matching mark on the thread edge of drive pinion. The mark should be in line with the mark on companion flange.

CAUTION:

For matching mark, use paint. Do not damage drive pinion and companion flange.



7. Remove the companion flange using suitable tool.




FRONT OIL SEAL [WITHOUT LIMITED SLIP DIFFERENTIAL]

8. Remove the front oil seal using Tool.

Tool number : KV381054S0

CAUTION:
Do not damage axle housing.



A
B
C


RFD

INSTALLATION

1. Install the front oil seal into the axle housing using a suitable tool.


CAUTION:

- Do not reuse oil seal.
- Do not incline oil seal when installing.
- Apply multi-purpose grease onto oil seal lip, and gear oil onto the circumference of oil seal.



E
F
G

2. Align the matching mark of the drive pinion with the mark of the companion flange, then install the companion flange.




H
I
J

3. Install the washer and drive pinion lock nut. Tighten the nut until there is zero bearing end play using Tool.

Tool number : KV40104000

CAUTION:
Do not reuse drive pinion lock nut and washer.



L
M

FRONT OIL SEAL [WITHOUT LIMITED SLIP DIFFERENTIAL]


- Rotate the drive pinion using Tool. Rotating torque should be equal to the reading recorded in step 4 above during removal plus an additional 0.56 N·m (5 in-lb).

Tool number : ST3127S000

- If the rotating torque is low, continue to tighten the drive pinion lock nut in 6.8 N·m (5 ft-lb) increments without overtightening. Refer to [RFD-15, "COMPONENTS"](#) . Tighten until proper rotating torque is achieved.

CAUTION:

- Do not loosen the drive pinion lock nut to decrease drive pinion rear bearing rotating torque.
 - Do not exceed specified rotating preload torque. If preload torque or rotating torque is exceeded a new collapsible spacer must be installed.
 - Do not exceed maximum tightening torque. If maximum tightening torque is reached prior to reaching the required rotating torque, the collapsible spacer may have been damaged. Replace the collapsible spacer.
- Check the gear oil level. Refer to [RFD-9, "Checking Differential Gear Oil"](#) .
 - Install the remaining components in the reverse order of removal.



CARRIER COVER [WITHOUT LIMITED SLIP DIFFERENTIAL]

CARRIER COVER


PFP:38351

Removal and Installation

GDS0006M

REMOVAL

1. Remove the drain plug and drain the gear oil. Refer to [RFD-9, "DRAINING"](#) .
2. Disconnect the rear cable (LH) from the carrier cover. Refer to [PB-3, "Components"](#) .
3. Remove bracket from the axle housing.




4. Remove the carrier cover bolts. Then separate carrier cover from the axle housing using Tool.

Tool number : KV10111100

CAUTION:

- Be careful not to damage the mating surface.
- Do not insert flat-bladed screwdriver, this will damage the mating surface.




INSTALLATION


1. Apply sealant to mating surface of carrier cover. Refer to [RFD-15, "COMPONENTS"](#) .

CAUTION:

Remove old sealant adhering to mounting surfaces. Also remove any moisture, oil, or foreign material adhering to application and mounting surfaces.



2. Install carrier cover and bracket on axle housing. Then tighten carrier cover bolts to the specified torque. Refer to [RFD-15, "COMPONENTS"](#) .
3. Connect the rear cable (LH) to the carrier cover and tighten to the specified torque. Refer to [PB-3, "Components"](#) .
4. Fill with new gear oil until oil level reaches the specified limit near filler plug hole. Refer to [RFD-9, "Checking Differential Gear Oil"](#) .



A
B
C
RFD
E
F
G
H
I
J
K
L
M

REAR FINAL DRIVE ASSEMBLY [WITHOUT LIMITED SLIP DIFFERENTIAL]

REAR FINAL DRIVE ASSEMBLY

PFP:38300

Removal and Installation

GDS0006N

REMOVAL

1. Remove the rear propeller shaft. Refer to [PR-8, "Removal and Installation"](#) .
 - Plug rear end of transmission or transfer.
2. Remove the axle shafts and back plate and torque members. Refer to [RAX-7, "Removal and Installation"](#) .
3. Disconnect the following components from the rear final drive.
 - ABS sensor wire harness
 - Rear cable (LH) and rear cable (RH)
 - Brake hoses and brake tube

CAUTION:

Position the wire harness, cable and hoses away from the final drive assembly. Failure to do so may result in components being damaged during rear axle assembly removal.

4. Support the rear final drive using a suitable jack.
5. Remove rear shock absorber lower bolts. Refer to [RSU-8, "Removal and Installation"](#) .
6. Remove leaf spring U-bolt nuts. Refer to [RSU-9, "Removal and Installation"](#) .

WARNING:

Support the rear final drive assembly using suitable jack before removing leaf spring U-bolt nuts.

7. Remove rear final drive assembly using suitable jack.

INSTALLATION

Installation is the reverse order of removal.


- When oil leaks while removing rear final drive assembly, check oil level after the installation. Refer to [RFD-9, "Checking Differential Gear Oil"](#) .
- Refill brake fluid and bleed the air from the brake system. Refer to [BR-11, "Bleeding Brake System"](#) .

REAR FINAL DRIVE ASSEMBLY [WITHOUT LIMITED SLIP DIFFERENTIAL]

GDS00060

Disassembly and Assembly COMPONENTS

A
B
C
RFD
E
F
G
H
I
J
K
L
M



- | | | |
|--|--------------------------------|-------------------------------|
| 1. Drive pinion lock nut | 2. Washer | 3. Companion flange |
| 4. Front oil seal | 5. Front bearing thrust washer | 6. Drive pinion front bearing |
| 7. Axle housing | 8. Breather | 9. Drain plug |
| 10. Side bearing cap | 11. Adjuster lock plate | 12. Carrier cover |
| 13. Filler plug | 14. Bracket | 15. Drive pinion |
| 16. Drive pinion height adjusting washer | 17. Drive pinion rear bearing | 18. Collapsible spacer |
| 19. Side bearing adjuster | 20. Side bearing | 21. Pinion mate thrust washer |
| 22. Pinion mate gear | 23. Side gear thrust washer | 24. Side gear |
| 25. Pinion mate shaft | 26. Lock pin | 27. Differential case |
| 28. Drive gear | | |

REAR FINAL DRIVE ASSEMBLY [WITHOUT LIMITED SLIP DIFFERENTIAL]

ASSEMBLY INSPECTION AND ADJUSTMENT

- Before inspection and adjustment, drain gear oil.

Total Preload Torque

1. Rotate drive pinion back and forth 2 to 3 times to check for unusual noise and rotation malfunction.
2. Rotate drive pinion at least 20 times to check for smooth operation of the bearing.
3. Turn drive pinion in both directions several times to set bearing rollers.
4. Measure total preload with preload gauge.

Tool number : ST3127S000

Total preload

Gear ratio 3.133 Type:


2.38 - 4.46 N-m (0.25 - 0.45 kg-m, 21- 39 in-lb)

Gear ratio 3.357 Type:

2.38 - 4.46 N-m (0.25 - 0.45 kg-m, 21- 39 in-lb)

Gear ratio 3.538 Type:

2.34 - 4.34 N-m (0.24 - 0.44 kg-m, 21- 38 in-lb)



NOTE:

Total preload torque = Pinion bearing preload torque + Side bearing preload torque

- If measured value is out of the specification, disassemble it to check and adjust each part. Adjust pinion bearing preload and side bearing preload.
Adjust pinion bearing preload first, then adjust side bearing preload.

When the preload torque is greater than specification

On pinion bearings: Replace collapsible spacer.

On side bearings: Loosen side bearing adjuster.

When the preload torque is less than specification

On pinion bearings: Tighten drive pinion lock nut.

On side bearings: Tighten side bearing adjuster.


Tooth Contact

Checking gear tooth contact pattern is necessary to verify correct relationship between drive gear and drive pinion. Gears which are not positioned in proper arrangement may be noisy and/or have a short life. Check gear tooth contact pattern to obtain the best contact for low noise and long life.

1. Remove carrier cover. Refer to [RFD-13, "Removal and Installation"](#).
2. Thoroughly clean drive gear and drive pinion teeth.
3. Apply red lead to drive gear.


CAUTION:

Apply red lead to both the faces of 3 to 4 gears at 4 locations evenly spaced on drive gear.



REAR FINAL DRIVE ASSEMBLY [WITHOUT LIMITED SLIP DIFFERENTIAL]


4. Hold companion flange steady by hand and rotate drive gear in both directions.



A
B
C


RFD

Usually the pattern will be correct if washers are correctly calculated and the backlash is correct. However, in rare cases, trial and error processes may be employed to obtain a correct pattern. The tooth pattern is the best indication of how well a differential has been set up.



To correct, increase thickness of drive pinion height adjusting washer in order to bring drive pinion close to drive gear.

To correct, reduce thickness of drive pinion height adjusting washer in order to make drive pinion go away from drive gear.



When adjustment is completed, be sure to wipe off completely the red lead and oil or their equivalent.

SDIA2591E

E
F
G
H
I
J

5. If outside the standard, adjust drive pinion height adjusting washer and backlash. Refer to [RFD-24, "Drive Pinion Height Adjusting Washer"](#) and [RFD-17, "Backlash"](#).

Backlash

1. Remove carrier cover. Refer to [RFD-19, "Differential Assembly"](#).
2. Check drive gear to drive pinion backlash using a dial indicator at several points.


**Drive gear to drive pinion backlash:
0.08 - 0.13 mm (0.0031 - 0.0051 in)**

3. If outside the standard, adjust side bearing adjusters.

CAUTION:

Check tooth contact and total preload after adjusting side bearing adjusters. Refer to [RFD-16, "Total Preload Torque"](#), [RFD-16, "Tooth Contact"](#).

- a. Remove adjuster lock plates.
- b. Loosen side bearing cap bolts.




K
L
M


REAR FINAL DRIVE ASSEMBLY [WITHOUT LIMITED SLIP DIFFERENTIAL]

c. Tighten or loosen each side bearing adjusters using Tool.

Tool number : KV38108800




d. In case of excessive backlash, loosen side bearing adjuster A and tighten side bearing adjuster B. In case of insufficient backlash, loosen side bearing adjuster B and tighten side bearing adjuster A.



e. After adjusting backlash, tighten side bearing cap bolts to the specified torque. Refer to [RFD-15, "COMPONENTS"](#).

f. Install adjuster lock plates and tighten to the specified torque. Refer to [RFD-15, "COMPONENTS"](#).



Companion Flange Runout

1. Fit a dial indicator onto companion flange face (inner side of propeller shaft bolt holes).
2. Rotate companion flange to check for runout.


Runout limit : 0.10 mm (0.0039 in) or less

3. Fit a test indicator to the inner side of companion flange (socket diameter).
4. Rotate companion flange to check for runout.

Runout limit : 0.13 mm (0.0051 in) or less

5. If the runout value is outside the repair limit, follow the procedure below to adjust.

- a. Check for runout while changing the phase between companion flange and drive pinion by 90°, 180° and 270° and search for the point where the runout is the minimum.
- b. If the runout value is still outside of the limit after the phase has been changed, replace companion flange.
- c. If the runout value is still outside of the limit after companion flange has been replaced, check drive pinion front bearing, drive pinion rear bearing and drive pinion assembly.




REAR FINAL DRIVE ASSEMBLY [WITHOUT LIMITED SLIP DIFFERENTIAL]

DISASSEMBLY

Differential Assembly

1. Remove carrier cover bolts and bracket.




2. Separate carrier cover from axle housing using Tool.

Tool number : KV10111100

CAUTION:

- Be careful not to damage the mating surface.
- Do not insert flat-bladed screwdriver, this will damage the mating surface.




3. For proper reinstallation, paint matching mark on one side of side bearing cap and axle housing.


CAUTION:

- Side bearing caps are line-board for initial assembly. The matching marks are used to reinstall them in their original positions.
- For matching mark, use paint. Do not damage side bearing cap and axle housing.

4. Remove adjuster lock plates.



5. Remove side bearing caps.




A
B
C
RFD
E
F
G
H
I
J
K
L
M


REAR FINAL DRIVE ASSEMBLY [WITHOUT LIMITED SLIP DIFFERENTIAL]

6. Loosen side bearing adjusters using Tool.

Tool number : KV38108800




7. Keep side bearing outer races together with inner races. Do not mix them up. Also, keep side bearing adjusters together with bearing.
8. Remove side bearing adjusters from axle housing.



9. Remove side bearing inner races using suitable tools.

CAUTION:
Be careful not to damage differential case assembly.




10. For proper reinstallation, paint matching mark on differential case assembly and drive gear.

CAUTION:
For matching mark, use paint. Do not damage differential case assembly and drive gear.


11. Remove drive gear bolts.
12. Tap drive gear off differential case assembly using suitable tool.

CAUTION:
Tap evenly all around to keep drive gear from binding.




13. Pull lock pin out of pinion mate shaft, using pin punch.

Tool number : ST23550000 (—)




REAR FINAL DRIVE ASSEMBLY [WITHOUT LIMITED SLIP DIFFERENTIAL]

14. Remove pinion mate shaft.




15. Turn pinion mate gear, then remove pinion mate gear, pinion mate thrust washer, side gear and side gear thrust washer from differential case.



Drive Pinion Assembly

1. Remove differential case assembly. Refer to [RFD-19, "Differential Assembly"](#).
2. Remove drive pinion lock nut and washer using Tool.


Tool number : KV40104000



3. Put a matching mark on the thread edge of drive pinion. The mark should be in line with the mark on companion flange.


CAUTION:

For matching mark, use paint. Do not damage drive pinion and companion flange.



REAR FINAL DRIVE ASSEMBLY [WITHOUT LIMITED SLIP DIFFERENTIAL]

4. Remove companion flange using suitable tool.




5. Remove front oil seal using Tool.

Tool number : KV381054S0

CAUTION:
Be careful not to damage axle housing.


6. Remove front bearing thrust washer.



7. Press the drive pinion assembly and collapsible spacer from axle housing.

CAUTION:
Do not drop drive pinion assembly.

8. Remove drive pinion front bearing inner race from axle housing.




9. Tap drive pinion front bearing outer race uniformly with a brass bar or equivalent to remove.

CAUTION:
Be careful not to damage axle housing.

10. Tap drive pinion rear bearing outer race uniformly with a brass bar or equivalent for removal.


CAUTION:
Be careful not to damage axle housing.



11. Remove drive pinion rear bearing inner race and drive pinion height adjusting washer using Tool.

Tool number : ST30021000

12. Remove the breather.



REAR FINAL DRIVE ASSEMBLY [WITHOUT LIMITED SLIP DIFFERENTIAL]

INSPECTION AFTER DISASSEMBLY

Drive Gear and Drive Pinion

- If the gear teeth do not mesh or line-up correctly, determine the cause and adjust, repair, or replace as necessary.
- If the gears are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new gears.
- Drive gear and drive pinion are supplied in matched sets only. Matching numbers on both drive pinion and drive gear are etched for verification. If a new gear set is being used, verify the numbers of each drive pinion and drive gear before proceeding with assembly.

Bearing

- If bearings are chipped (by friction), pitted, worn, rusted, scratched, or unusual noise is coming from bearing, replace with new bearing assembly (as a new set).
- Bearing must be replaced with a new one whenever disassembled.

Side Gear, Pinion Mate and Pinion Mate Shaft

- Replace with a new one if found any cracks or damage on the surface of the tooth.
- Replace with a new one if found any worn or chipped mark on the contact sides of thrust washer.
- Replace both side gear and pinion mate gear as a set when replacing side gear or pinion mate gear.

Side Gear Thrust Washer and Pinion Mate Thrust Washer

- Replace with a new one if found that it is chipped (by friction), damaged, or unusual worn.


Differential Case Assembly

- If the gears are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new differential case assembly.

SELECTION ADJUSTING WASHERS

Side Gear Thrust Washer

1. Place differential case straight up so that side gear to be measured comes upward.



REAR FINAL DRIVE ASSEMBLY [WITHOUT LIMITED SLIP DIFFERENTIAL]

- Using a thickness gauge, measure the clearance between side gear back and differential case at 3 different points, while rotating side gear. Average the 3 readings, and then measure the clearance. (Measure the clearance of the other side as well.)

Side gear back clearance standard:

0.305 mm (0.0120 in) or less.

(Each gear should rotate smoothly without excessive resistance during differential motion.)

CAUTION:

To prevent side gear from tilting, insert thickness gauges with the same thickness from both sides.

- If the back clearance is outside the standard, use a thicker/thinner side gear thrust washer to adjust.

When the back clearance is greater than specification:


Use a thicker thrust washer.

When the back clearance is less than specification:

Use a thinner thrust washer.


CAUTION:

Select a side gear thrust washer for right and left individually.



Drive Pinion Height Adjusting Washer

- Drive gear and drive pinion are supplied in matched sets only. Matching numbers on both drive pinion and drive gear are etched for verification. If a new hypoid gear set is being used, verify the numbers of each drive pinion and drive gear before proceeding with assembly.



- The mounting distance from the center line of drive gear to the back face of drive pinion for the M226 final drive is 109.5 mm (4.312 in). On the button end of each drive pinion, there is etched a plus (+) number, a minus (-) number, or a zero (0), which indicates the best running position for each particular hypoid gear set. This dimension is controlled by a selective drive pinion height adjusting washer between drive pinion rear bearing inner race and drive pinion. For example: If a drive pinion is etched m+8 (+3), it would require 0.08 mm (0.003 in) less drive pinion height adjusting washer than a drive pinion etched "0". This means decreasing drive pinion height adjusting washer thickness; increases the mounting distance of drive pinion to 109.6 mm (4.315 in). If a drive pinion is etched m-8 (-3), it would require adding 0.08 mm (0.003 in) more to drive pinion height adjusting washer than would be required if drive pinion were etched "0". By adding 0.08 mm (0.003 in), the mounting distance of drive pinion was decreased to 109.4 mm (4.309 in) which is just what a m-8 (-3) etching indicated.
- To change drive pinion adjustment, use different drive pinion height adjusting washer which come in different thickness.
- Use the following tables as a guide for selecting the correct drive pinion height adjusting washer thickness to add or subtract from the old drive pinion height adjusting washer.

REAR FINAL DRIVE ASSEMBLY [WITHOUT LIMITED SLIP DIFFERENTIAL]

Unit: mm (in)

| OLD DRIVE PINION MARKING | NEW DRIVE PINION MARKING | | | | | | | | |
|--------------------------|--------------------------|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|
| | -10 (-4) | -8 (-3) | -5 (-2) | -3 (-1) | 0 | +3 (+1) | +5 (+2) | +8 (+3) | +10 (+4) |
| +10 (+4) | +0.20 (+0.008) | +0.18 (+0.007) | +0.15 (+0.006) | +0.13 (+0.005) | +0.10 (+0.004) | +0.08 (+0.003) | +0.05 (+0.002) | +0.02 (+0.001) | 0 (0) |
| +8 (+3) | +0.18 (+0.007) | +0.15 (+0.006) | +0.13 (+0.005) | +0.10 (+0.004) | +0.08 (+0.003) | +0.05 (+0.002) | +0.02 (+0.001) | 0 (0) | -0.02 (-0.001) |
| +5 (+2) | +0.15 (+0.006) | +0.13 (+0.005) | +0.10 (+0.004) | +0.08 (+0.003) | +0.05 (+0.002) | +0.02 (+0.001) | 0 (0) | -0.02 (-0.001) | -0.05 (-0.002) |
| +3 (+1) | +0.13 (+0.005) | +0.10 (+0.004) | +0.08 (+0.003) | +0.05 (+0.002) | +0.02 (+0.001) | 0 (0) | -0.02 (-0.001) | -0.05 (-0.002) | -0.08 (-0.003) |
| 0 | +0.10 (+0.004) | +0.08 (+0.003) | +0.05 (+0.002) | +0.02 (+0.001) | 0 (0) | -0.02 (-0.001) | -0.05 (-0.002) | -0.08 (-0.003) | -0.10 (-0.004) |
| -3 (-1) | +0.08 (+0.003) | +0.05 (+0.002) | +0.02 (+0.001) | 0 (0) | -0.02 (-0.001) | -0.05 (-0.002) | -0.08 (-0.003) | -0.10 (-0.004) | -0.13 (-0.005) |
| -5 (-2) | +0.05 (+0.002) | +0.02 (+0.001) | 0 (0) | -0.02 (-0.001) | -0.05 (-0.002) | -0.08 (-0.003) | -0.10 (-0.004) | -0.13 (-0.005) | -0.15 (-0.006) |
| -8 (-3) | +0.02 (+0.001) | 0 (0) | -0.02 (-0.001) | -0.05 (-0.002) | -0.08 (-0.003) | -0.10 (-0.004) | -0.13 (-0.005) | -0.15 (-0.006) | -0.18 (-0.007) |
| -10 (-4) | 0 (0) | -0.02 (-0.001) | -0.05 (-0.002) | -0.08 (-0.003) | -0.10 (-0.004) | -0.13 (-0.005) | -0.15 (-0.006) | -0.18 (-0.007) | -0.20 (-0.008) |

ASSEMBLY


Drive Pinion Assembly

1. Install the breather and then tighten to the specified torque. Refer to [RFD-15, "COMPONENTS"](#) .
2. Press a drive pinion rear bearing outer race into axle housing using suitable tool and Tool.

Tool number : ST30022000

CAUTION:


Do not reuse drive pinion rear bearing.



3. Press drive pinion front bearing outer race into axle housing using suitable tool.

CAUTION:

Do not reuse drive pinion front bearing.



REAR FINAL DRIVE ASSEMBLY [WITHOUT LIMITED SLIP DIFFERENTIAL]


4. Temporarily install drive pinion height adjusting washer.

When hypoid gear set has been replaced

- Select drive pinion height adjusting washer. Refer to [RFD-24, "Drive Pinion Height Adjusting Washer"](#).

When hypoid gear set has been reused

- Temporarily install the removed drive pinion height adjusting washer or same thickness washer to drive pinion.



5. Install selected drive pinion height adjusting washer to drive pinion, and press-fit drive pinion rear bearing inner race in it, using a press and suitable tool.

CAUTION:

Do not reuse drive pinion rear bearing.

6. Apply gear oil to drive pinion rear bearing and drive pinion front bearing.

7. Install drive pinion front bearing inner race in axle housing.

CAUTION:

Do not reuse drive pinion front bearing.

8. Install front bearing thrust washer to axle housing.

9. Perform checking and adjusting the tooth contact and backlash of the hypoid gear following the procedure below.

- a. Assemble the drive pinion assembly to the axle housing.



CAUTION:

Do not assemble a collapsible spacer.

- b. Insert companion flange onto drive pinion. Tap the companion flange with a soft hammer until fully seated.

CAUTION:

Do not assemble a front oil seal.




- c. Temporarily tighten removed drive pinion lock nut and washer to drive pinion.

Tool number : KV40104000

NOTE:

Use removed drive pinion lock nut and washer only for the pre-load measurement.

- d. Rotate drive pinion at least 20 times to check for smooth operation of the bearing.



REAR FINAL DRIVE ASSEMBLY [WITHOUT LIMITED SLIP DIFFERENTIAL]

- e. Tighten to drive pinion lock nut, while adjust pinion bearing preload torque.

Tool number : ST3127S000

Drive pinion lock nut tightening torque:


298 - 678 N·m (31 - 69 kg·m, 220 - 500 ft·lb)

Pinion bearing preload:

1.7 - 3.1 N·m (0.18 - 0.31 kg·m, 15 - 27 in·lb)


CAUTION:

- Adjust to the lower limit of the drive pinion lock nut tightening torque first.
 - Drive pinion lock nut is tightened with no collapsible spacer. Be careful not to overtighten it. While measuring the preload, tighten it by 5° to 10°.
 - After adjustment, rotate drive pinion back and forth 2 to 3 times to check for unusual noise, rotation malfunction and other malfunctions.
- f. Install side bearing adjusters into axle housing.




A
B
C

RFD



E
F
G
H

- g. Apply gear oil to side bearings. Install differential case assembly with side bearing outer races into axle housing.



I
J
K
L

- h. Align paint matching mark on side bearing cap with that on axle housing and install side bearing caps on axle housing.


- Do not tighten at this point. This allows further tightening of side bearing adjusters.

- i. Check and adjust the backlash and tooth contact. Refer to [RFD-17, "Backlash"](#) and [RFD-16, "Tooth Contact"](#).

- j. Remove side bearing caps.

- k. Remove differential case assembly.

- l. Remove companion flange.




M

REAR FINAL DRIVE ASSEMBLY [WITHOUT LIMITED SLIP DIFFERENTIAL]

- m. Press the drive pinion assembly from axle housing.


CAUTION:
Do not drop drive pinion assembly.



10. Install front oil seal into axle housing using suitable tool.

CAUTION:


- Do not reuse oil seal.
- Do not incline oil seal when installing.
- Apply multi-purpose grease onto oil seal lip, and gear oil onto the circumference of oil seal.




11. Install collapsible spacer to drive pinion. And then install drive pinion assembly in axle housing.

CAUTION:

- Do not reuse collapsible spacer.
- Be careful not to damage front oil seal.




12. Align the matching mark of the drive pinion with the mark of the companion flange, then install the companion flange.



13. Insert companion flange onto drive pinion. Tap the companion flange with a soft hammer until fully seated.

CAUTION:
Be careful not to damage companion flange and front oil seal.



REAR FINAL DRIVE ASSEMBLY [WITHOUT LIMITED SLIP DIFFERENTIAL]


14. Apply anti-corrosive oil to the thread and seat of drive pinion lock nut, and temporarily tighten drive pinion lock nut and washer to drive pinion.

Tool number : KV40104000

CAUTION:

Do not reuse drive pinion lock nut and washer.

15. Rotate drive pinion at least 20 times to check for smooth operation of the bearing.



16. Tighten to drive pinion lock nut, while adjust pinion bearing preload torque.

Tool number : ST3127S000

Drive pinion lock nut tightening torque:


298 - 678 N·m (31 - 69 kg·m, 220 - 500 ft·lb)

Pinion bearing preload:

1.7 - 3.1 N·m (0.18 - 0.31 kg·m, 15 - 27 in·lb)

CAUTION:

- Adjust the lower limit of the drive pinion lock nut tightening torque first.
- If the preload torque exceeds the specified value, replace collapsible spacer and tighten it again to adjust. Never loosen drive pinion lock nut to adjust the preload torque.
- After adjustment, rotate drive pinion back and forth 2 to 3 times to check for unusual noise, rotation malfunction, and other malfunctions.



17. Install differential case assembly. Refer to [RFD-30, "Differential Assembly"](#).

CAUTION:

Do not install carrier cover yet.


18. Check and adjust backlash, tooth contact and companion flange runout. Refer to [RFD-17, "Backlash"](#), [RFD-16, "Tooth Contact"](#) and [RFD-18, "Companion Flange Runout"](#). Recheck above items. Readjust the above description, if necessary.

19. Check total preload torque. Refer to [RFD-16, "Total Preload Torque"](#).

20. Apply sealant to mating surface of carrier cover. Refer to [RFD-15, "COMPONENTS"](#).


CAUTION:

Remove old sealant adhering to mounting surfaces. Also remove any moisture, oil, or foreign material adhering to application and mounting surfaces.




REAR FINAL DRIVE ASSEMBLY [WITHOUT LIMITED SLIP DIFFERENTIAL]

21. Install carrier cover and bracket on axle housing. Then tighten carrier cover bolts to the specified torque. Refer to [RFD-15, "COMPONENTS"](#).




Differential Assembly


1. Assemble side gear thrust washers with the same thickness as the ones installed prior to disassembly or reinstall the old ones on side gears.
2. Assemble side gear and side gear thrust washer into differential case.



3. Align 2 pinion mate gears in diagonally opposite positions, then rotate and assemble them into differential case after assembling pinion mate thrust washer to pinion mate gear.



4. Align lock pin holes on differential case and shaft, and assemble pinion mate shaft.
5. Measure side gear end play. If necessary, select the appropriate side gear thrust washers. Refer to [RFD-23, "Side Gear Thrust Washer"](#).




REAR FINAL DRIVE ASSEMBLY [WITHOUT LIMITED SLIP DIFFERENTIAL]


6. Drive a lock pin into pinion mate shaft, using pin punch.

Tool number : ST23550000 (—)

CAUTION:
Do not reuse lock pin.




7. Apply gear oil to gear tooth surfaces and thrust surfaces and check to see they turn properly.




8. Apply sealant to back face of drive gear. Refer to [RFD-15, "COMPONENTS"](#).

CAUTION:
Remove old sealant adhering to mounting surfaces. Also remove any moisture, oil, or foreign material adhering to application and mounting surfaces.




9. Align the matching mark of differential case assembly with the mark of drive gear, then install drive gear.



10. Apply thread locking sealant into the thread hole of drive gear. Refer to [RFD-15, "COMPONENTS"](#).

CAUTION:
Make sure threaded holes are clean.




A
B
C
RFD
E
F
G
H
I
J
K
L
M

REAR FINAL DRIVE ASSEMBLY [WITHOUT LIMITED SLIP DIFFERENTIAL]

11. Install the drive gear bolts, and then tighten to the specified torque. Refer to [RFD-15, "COMPONENTS"](#) .

CAUTION:

- Do not reuse the bolts.
- Tighten bolts in a crisscross fashion.




12. Press side bearing inner races to differential case assembly using suitable tool and Tool.


Tool number : KV38100300

CAUTION:


Do not reuse side bearings.



13. Install side bearing adjusters into axle housing.




14. Apply gear oil to side bearings. Install differential case assembly with side bearing outer races into axle housing.



15. Align paint matching mark on side bearing cap with that on axle housing and install side bearing caps on axle housing.

CAUTION:

Do not tighten at this point. This allows further tightening of side bearing adjusters.



REAR FINAL DRIVE ASSEMBLY [WITHOUT LIMITED SLIP DIFFERENTIAL]


16. Tighten each side bearing adjusters using Tool.

Tool number : KV38108800

17. Adjust backlash of drive gear and drive pinion. Refer to [RFD-17, "Backlash"](#) .

18. Check tooth contact. Refer to [RFD-16, "Tooth Contact"](#) .


19. Check total preload. Refer to [RFD-16, "Total Preload Torque"](#) .




20. Apply sealant to mating surface of carrier cover. Refer to [RFD-15, "COMPONENTS"](#) .

CAUTION:

Remove old sealant adhering to mounting surfaces. Also remove any moisture, oil, or foreign material adhering to application and mounting surfaces.



21. Install carrier cover and bracket on axle housing. Then tighten carrier cover bolts to the specified torque. Refer to [RFD-15, "COMPONENTS"](#) .



A
B
C
RFD
E
F
G
H
I
J
K
L
M

SERVICE DATA AND SPECIFICATIONS (SDS)
[WITHOUT LIMITED SLIP DIFFERENTIAL]

SERVICE DATA AND SPECIFICATIONS (SDS)

PF0:00030

General Specifications

GDS0006P

| Applied model | VQ40DE | | YD25DDTi | |
|---|--------------|-------|----------|-------|
| | 2WD | | | |
| | 6M/T | 5A/T | 6M/T | 5A/T |
| Grade | SE | | | |
| Final drive model | M226 | | | |
| Gear ratio | 3.538 | 3.133 | 3.538 | 3.357 |
| Number of pinion gears | 2 | | | |
| Number of teeth (Drive gear / drive pinion) | 46/13 | 47/15 | 46/13 | 47/14 |
| Oil capacity (Approx.) ℓ (Imp pt) | 2.01 (3-1/2) | | | |
| Drive pinion adjustment spacer type | Collapsible | | | |

Inspection and Adjustment
PRELOAD TORQUE

GDS0006Q

Unit: N·m (kg·m, in·lb)

| Item | Specification | | | |
|------------------------|------------------------------------|-----------------------|---------------------------------------|---------------------------------------|
| | Gear ratio 3.133 type | Gear ratio 3.357 type | Gear ratio 3.538 type | Gear ratio 3.692 type |
| Total preload | 2.38 - 4.46 (0.25 - 0.45, 21 - 39) | | 2.34 - 4.34 (0.24 - 0.44, 21 - 38) | 2.32 - 4.34 (0.24 - 0.44, 21 - 38) |
| Pinion bearing preload | 1.7 - 3.1 (0.18 - 0.31, 15 - 27) | | | |

BACKLASH

Unit: mm (in)

| Item | Standard |
|---------------------------------|-------------------------------|
| Drive gear to drive pinion gear | 0.08 - 0.13 (0.0031 - 0.0051) |

COMPANION FLANGE RUNOUT

Unit: mm (in)

| Item | Runout limit |
|--------------------------------|-----------------------|
| Companion flange face | 0.10 (0.0039) or less |
| Inner side of companion flange | 0.13 (0.0051) or less |

SERVICE DATA AND SPECIFICATIONS (SDS)
[WITHOUT LIMITED SLIP DIFFERENTIAL]

SELECTIVE PARTS

Drive Pinion Height Adjusting Washer

Unit: mm (in)

| Thickness | Package part number* |
|---|----------------------|
| 0.076 (0.030) 0.079 (0.031) 0.081 (0.032) 0.084 (0.033) 0.086 (0.034) | 38151 8S101 |
| 0.089 (0.035) 0.091 (0.036) 0.094 (0.037) 0.097 (0.038) 0.099 (0.039) | 38151 8S102 |
| 0.102 (0.040) 0.104 (0.041) 0.107 (0.042) 0.109 (0.043) 0.112 (0.044) | 38151 8S103 |
| 0.114 (0.045) 0.117 (0.046) 0.119 (0.047) 0.122 (0.048) 0.124 (0.049) | 38151 8S104 |
| 0.127 (0.050) 0.130 (0.051) 0.132 (0.052) 0.135 (0.053) 0.137 (0.054) | 38151 8S105 |

*Always check with the Parts Department for the latest parts information.

A
B
C
RFD
E
F
G
H
I
J
K
L
M

PRECAUTIONS

[WITH LIMITED SLIP DIFFERENTIAL]

PRECAUTIONS

PFP:00001

Limited Slip Differential (LSD) Performance Judgement

GDS00028

- Inspection is required when detecting any noise or malfunction while driving or turning. Improper condition of oil or differential case assembly is suspected. Refer to [RFD-36, "METHOD FOR TROUBLESHOOTING"](#) .

METHOD FOR TROUBLESHOOTING

1. Check differential gear oil level and differential gear oil leakage. Refer to [RFD-42, "Checking Differential Gear Oil"](#) .
2. Changing differential gear oil. Refer to [RFD-42, "Changing Differential Gear Oil"](#) .
3. Start engine. Drive for 10 min.
4. Again changing differential gear oil. Refer to [RFD-42, "Changing Differential Gear Oil"](#) .
5. Start engine. Drive for 10 min. Check if any noise or improper oil condition is detected.
 - If OK, check differential gear oil level and differential gear oil leakage. Refer to [RFD-42, "Checking Differential Gear Oil"](#) .
 - If NG, replace differential case assembly after checking each part of final drive. Refer to [RFD-48, "Disassembly and Assembly"](#) .

Service Notice or Precautions

GDS00029

- Check for the correct installation status prior to removal or disassembly. If matching marks are required, be certain they do not interfere with the function of the parts when applied.
- Overhaul should be done in a clean work area, it is preferable to work in dust proof area.
- Before disassembly completely remove sand and mud from the exterior of the unit, preventing them from entering into the unit during disassembly or assembly.
- Check appearance of the disassembled parts for damage, deformation, and unusual wear. Replace them with new ones if necessary.
- Gaskets, seals and O-rings should be replaced any time the unit is disassembled.
- In principle, tighten bolts or nuts gradually in several steps working diagonally from inside to outside. If tightening sequence is specified, observe it.
- Clean and flush the parts sufficiently and blow-dry them.
- Be careful not to damage sliding surfaces and mating surfaces.
- When applying sealant, remove the old sealant from the mounting surface; then remove any moisture, oil, and foreign materials from the application and mounting surfaces.
- Always use shop paper for cleaning the inside of components.
- Avoid using cotton gloves or shop rags to prevent entering of lint.
- During assembly, observe the specified tightening torque, and apply new differential gear oil, petroleum jelly, or multi-purpose grease as specified.

PREPARATION







[WITH LIMITED SLIP DIFFERENTIAL]

PREPARATION

PFP:00002

Special Service Tools

GDS0002A



| Tool number Tool name | Description |
|---|---|
| ST3127S000 Preload gauge set 1. GG91030000 Torque wrench 2. HT62940000 (1/2") Socket adapter 3. HT62900000 (3/8") Socket adapter |  Inspecting pinion bearing preload and total preload |
| KV40104000 Flange wrench a: 85 mm (3.35 in) dia. b: 65 mm (2.56 in) dia. |  Removing and installing drive pinion lock nut |
| KV381054S0 Puller |  Removing front oil seal |
| KV10111100 Seal cutter |  Removing carrier cover |
| KV38108800 Adjuster tool |  Removing and installing side bearing adjuster |
| ST30021000 Puller |  Removing drive pinion rear bearing inner race |

A
B
C
RFD
E
F
G
H
I
J
K
L
M

PREPARATION

[WITH LIMITED SLIP DIFFERENTIAL]

| Tool number Tool name | Description |
|---|---|
| ST30022000 Drift a: 46 mm (1.81 in) dia. b: 110 mm (4.33 in) dia. | Installing drive pinion rear bearing outer race |
| KV38100300 Drift a: 54 mm (2.13 in) dia. b: 46 mm (1.81 in) dia. c: 32mm (1.26 in) dia. | Installing side bearing inner race |





Commercial Service Tools

GDS0002B

| Tool name | Description |
|---|---|
| Puller | <ul style="list-style-type: none"> ● Removing companion flange ● Removing side bearing inner race |
| Drift a: 96mm (3.77 in) dia. b: 84 mm (3.30 in) dia. | Installing front oil seal |
| Adapter a: 43 mm (1.69 in) dia. | Removing and installing side bearing inner race |
| Puller | Removing side bearing inner race |
| Drift a: 89 mm (3.50 in) dia. b: 79 mm (3.11 in) dia. | Installing drive pinion rear bearing outer race |

PREPARATION

[WITH LIMITED SLIP DIFFERENTIAL]

| Tool name | Description |
|--|---|
| <p>Drift a: 67 mm (2.63 in) dia.</p>  <p style="text-align: right;">PDIA0893E</p> | <p>Installing drive pinion front bearing outer race</p> |
| <p>Installer a: 51 mm (2.01 in) dia. b: 41 mm (1.61 in) dia.</p>  <p style="text-align: right;">NT065</p> | <p>Installing drive pinion rear bearing inner race</p> |

A

B

C

RFD

E

F

G

H

I

J

K

L

M

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING [WITH LIMITED SLIP DIFFERENTIAL]

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

PFP:00003

NVH Troubleshooting Chart

GDS0002C

Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

| Symptom | Noise | Possible cause and SUSPECTED PARTS | Reference page |
|---------|-------|------------------------------------|--|
| | × | Gear tooth rough | RFD-55, "INSPECTION AFTER DISASSEMBLY" |
| | × | Gear contact improper | RFD-49, "Tooth Contact" |
| | × | Tooth surfaces worn | RFD-55, "INSPECTION AFTER DISASSEMBLY" |
| | × | Backlash incorrect | RFD-50, "Backlash" |
| | × | Companion flange excessive runout | RFD-51, "Companion Flange Runout" |
| | × | Gear oil improper | RFD-42, "Checking Differential Gear Oil" |
| | × | PROPELLER SHAFT | PR-2, "NVH Troubleshooting Chart" |
| | × | AXLE AND SUSPENSION | RAX-5, "NVH Troubleshooting Chart", RSU-4, "NVH Troubleshooting Chart" |
| | × | TIRES | WT-2, "NVH Troubleshooting Chart" |
| | × | ROAD WHEEL | |
| | × | AXLE SHAFT | RAX-5, "NVH Troubleshooting Chart" |
| | × | BRAKES | BR-5, "NVH Troubleshooting Chart" |
| | × | STEERING | PS-5, "NVH Troubleshooting Chart" |

×: Applicable

DESCRIPTION


[WITH LIMITED SLIP DIFFERENTIAL]

DESCRIPTION

PFP:00000

Cross-Sectional View

GDS0002D



- 1. Companion flange
- 4. Differential case
- 7. Side gear

- 2. Drive pinion
- 5. Pinion mate gear
- 8. Pinion mate shaft

- 3. Drive gear
- 6. Axle shaft

PDIA1037E

A
B
C
RFD
E
F
G
H
I
J
K
L
M

DIFFERENTIAL GEAR OIL [WITH LIMITED SLIP DIFFERENTIAL]


DIFFERENTIAL GEAR OIL

PFPP:KLD30

Changing Differential Gear Oil DRAINING

GDS0002E

1. Stop engine.
2. Remove drain plug and drain gear oil.
3. Apply sealant to drain plug. Install drain plug to final drive assembly and tighten to the specified torque. Refer to [RFD-48, "COMPONENTS"](#).



FILLING

1. Remove filler plug. Fill with new gear oil until oil level reaches the specified limit near filler plug hole.


Oil grade and Viscosity:

Refer to [MA-13, "Fluids and Lubricants"](#).

Oil capacity:

Approx. 2.01 l (3-1/2pt)

2. After refilling oil, check oil level. Apply sealant to filler plug. Install filler plug to final drive assembly and tighten to the specified torque. Refer to [RFD-48, "COMPONENTS"](#).



Checking Differential Gear Oil OIL LEAKAGE AND OIL LEVEL


GDS0002F

1. Make sure that gear oil is not leaking from final drive assembly or around it.
2. Check oil level from filler plug hole as shown.

CAUTION:

Do not start engine while checking oil level.

3. Apply sealant to filler plug. Install filler plug to final drive assembly and tighten to the specified torque. Refer to [RFD-48, "COMPONENTS"](#).



FRONT OIL SEAL

[WITH LIMITED SLIP DIFFERENTIAL]

FRONT OIL SEAL

PFP:38189


Removal and Installation

GDS0002G

REMOVAL


1. Remove the rear propeller shaft. Refer to [PR-8, "Removal and Installation"](#) .
2. Remove the rear tires.
3. Remove rear drum brake. Refer to [BR-31, "Removal and Installation of Drum Brake Assembly"](#) .
4. Rotate the drive pinion back and forth 2 to 3 times using Tool and record the rotating torque.

Tool number : ST3127S000



5. Remove the drive pinion lock nut and washer using Tool.


Tool number : KV40104000




6. Put a matching mark on the thread edge of drive pinion. The mark should be in line with the mark on companion flange.

CAUTION:

For matching mark, use paint. Do not damage drive pinion and companion flange.



7. Remove the companion flange using suitable tool.



A
B
C
RFD
E
F
G
H
I
J
K
L
M

FRONT OIL SEAL


[WITH LIMITED SLIP DIFFERENTIAL]

8. Remove the front oil seal using Tool.

Tool number : KV381054S0

CAUTION:

Do not damage axle housing.




INSTALLATION


1. Install the front oil seal into the axle housing using a suitable tool.

CAUTION:

- Do not reuse oil seal.
- Do not incline oil seal when installing.
- Apply multi-purpose grease onto oil seal lip, and gear oil onto the circumference of oil seal.



2. Align the matching mark of the drive pinion with the mark of the companion flange, then install the companion flange.




3. Install the washer and drive pinion lock nut. Tighten the nut until there is zero bearing end play using Tool.

Tool number : KV40104000

CAUTION:

Do not reuse drive pinion lock nut and washer.



FRONT OIL SEAL

[WITH LIMITED SLIP DIFFERENTIAL]


4. Rotate the drive pinion using Tool. Rotating torque should be equal to the reading recorded in step 4 above during removal plus an additional 0.56 N·m (5 in-lb).

Tool number : ST3127S000

5. If the rotating torque is low, continue to tighten the drive pinion lock nut in 6.8 N·m (5 ft-lb) increments without overtightening. Refer to [RFD-48, "COMPONENTS"](#). Tighten until proper rotating torque is achieved.

CAUTION:

- Do not loosen the drive pinion lock nut to decrease drive pinion rear bearing rotating torque.
 - Do not exceed specified rotating preload torque. If preload torque or rotating torque is exceeded a new collapsible spacer must be installed.
 - Do not exceed maximum tightening torque. If maximum tightening torque is reached prior to reaching the required rotating torque, the collapsible spacer may have been damaged. Replace the collapsible spacer.
6. Check the gear oil level. Refer to [RFD-42, "Checking Differential Gear Oil"](#).
7. Install the remaining components in the reverse order of removal.



A

B

C

RFD

E

F

G

H

I

J

K

L

M

CARRIER COVER

[WITH LIMITED SLIP DIFFERENTIAL]

CARRIER COVER


PFP:38351

Removal and Installation

GDS0002H

REMOVAL

1. Remove the drain plug and drain the gear oil. Refer to [RFD-42, "DRAINING"](#).
2. Disconnect the rear cable (LH) from the carrier cover. Refer to [PB-3, "Components"](#).
3. Remove bracket from the axle housing.




4. Remove the carrier cover bolts. Then separate carrier cover from the axle housing using Tool.

Tool number : KV10111100

CAUTION:

- Be careful not to damage the mating surface.
- Do not insert flat-bladed screwdriver, this will damage the mating surface.




INSTALLATION


1. Apply sealant to mating surface of carrier cover. Refer to [RFD-48, "COMPONENTS"](#).

CAUTION:

Remove old sealant adhering to mounting surfaces. Also remove any moisture, oil, or foreign material adhering to application and mounting surfaces.



2. Install carrier cover and bracket on axle housing. Then tighten carrier cover bolts to the specified torque. Refer to [RFD-48, "COMPONENTS"](#).
3. Connect the rear cable (LH) to the carrier cover and tighten to the specified torque. Refer to [PB-3, "Components"](#).
4. Fill with new gear oil until oil level reaches the specified limit near filler plug hole. Refer to [RFD-42, "Checking Differential Gear Oil"](#).



REAR FINAL DRIVE ASSEMBLY

[WITH LIMITED SLIP DIFFERENTIAL]

REAR FINAL DRIVE ASSEMBLY

PFP:38300

Removal and Installation

GDS00021

REMOVAL

1. Remove the rear propeller shaft. Refer to [PR-8, "Removal and Installation"](#) .
 - Plug rear end of transmission or transfer.
2. Remove the axle shafts and back plate and torque members. Refer to [RAX-7, "Removal and Installation"](#) .
3. Disconnect the following components from the rear final drive.
 - ABS sensor wire harness
 - Rear cable (LH) and rear cable (RH)
 - Brake hoses and brake tube

CAUTION:

Position the wire harness, cable and hoses away from the final drive assembly. Failure to do so may result in components being damaged during rear axle assembly removal.

4. Support the rear final drive using a suitable jack.
5. Remove rear shock absorber lower bolts. Refer to [RSU-8, "Removal and Installation"](#) .
6. Remove leaf spring U-bolt nuts. Refer to [RSU-9, "Removal and Installation"](#) .

WARNING:

Support the rear final drive assembly using suitable jack before removing leaf spring U-bolt nuts.

7. Remove rear final drive assembly using suitable jack.

INSTALLATION

Installation is the reverse order of removal.

- When oil leaks while removing rear final drive assembly, check oil level after the installation. Refer to [RFD-42, "Checking Differential Gear Oil"](#) .
- Refill brake fluid and bleed the air from the brake system. Refer to [BR-11, "Bleeding Brake System"](#) .


REAR FINAL DRIVE ASSEMBLY

[WITH LIMITED SLIP DIFFERENTIAL]

GDS0002J

Disassembly and Assembly COMPONENTS

SEC. 380



PDIA1083E

- | | | |
|--|--------------------------------|--------------------------------|
| 1. Drive pinion lock nut | 2. Washer | 3. Companion flange |
| 4. Front oil seal | 5. Front bearing thrust washer | 6. Drive pinion front bearing |
| 7. Axle housing | 8. Breather | 9. Drain plug |
| 10. Side bearing cap | 11. Adjuster lock plate | 12. Carrier cover |
| 13. Filler plug | 14. Bracket | 15. Drive pinion |
| 16. Drive pinion height adjusting washer | 17. Drive pinion rear bearing | 18. Collapsible spacer |
| 19. Side bearing adjuster | 20. Side bearing | 21. Differential case assembly |
| 22. Drive gear | | |

REAR FINAL DRIVE ASSEMBLY [WITH LIMITED SLIP DIFFERENTIAL]

ASSEMBLY INSPECTION AND ADJUSTMENT

- Before inspection and adjustment, drain gear oil.

Total Preload Torque

1. Rotate drive pinion back and forth 2 to 3 times to check for unusual noise and rotation malfunction.
2. Rotate drive pinion at least 20 times to check for smooth operation of the bearing.
3. Turn drive pinion in both directions several times to set bearing rollers.
4. Measure total preload with preload gauge.

Tool number : ST3127S000

Total preload

Gear ratio 3.133 Type:

2.38 - 4.46 N-m (0.25 - 0.45 kg-m, 21- 39 in-lb)

Gear ratio 3.357 Type:


2.38 - 4.46 N-m (0.25 - 0.45 kg-m, 21- 39 in-lb)

Gear ratio 3.538 Type:

2.34 - 4.34 N-m (0.24 - 0.44 kg-m, 21- 38 in-lb)

Gear ratio 3.692 Type:

2.32 - 4.34 N-m (0.24 - 0.44 kg-m, 21 - 38 in-lb)



NOTE:

Total preload torque = Pinion bearing preload torque + Side bearing preload torque

- If measured value is out of the specification, disassemble it to check and adjust each part. Adjust pinion bearing preload and side bearing preload.
Adjust pinion bearing preload first, then adjust side bearing preload.

When the preload torque is greater than specification

On pinion bearings: Replace collapsible spacer.

On side bearings: Loosen side bearing adjuster.

When the preload torque is less than specification

On pinion bearings: Tighten drive pinion lock nut.

On side bearings: Tighten side bearing adjuster.


Tooth Contact

Checking gear tooth contact pattern is necessary to verify correct relationship between drive gear and drive pinion. Gears which are not positioned in proper arrangement may be noisy and/or have a short life. Check gear tooth contact pattern to obtain the best contact for low noise and long life.

1. Remove carrier cover. Refer to [RFD-46, "Removal and Installation"](#).
2. Thoroughly clean drive gear and drive pinion teeth.
3. Apply red lead to drive gear.


CAUTION:

Apply red lead to both the faces of 3 to 4 gears at 4 locations evenly spaced on drive gear.




REAR FINAL DRIVE ASSEMBLY [WITH LIMITED SLIP DIFFERENTIAL]

4. Hold companion flange steady by hand and rotate drive gear in both directions.




Usually the pattern will be correct if washers are correctly calculated and the backlash is correct. However, in rare cases, trial and error processes may be employed to obtain a correct pattern. The tooth pattern is the best indication of how well a differential has been set up.



To correct, increase thickness of drive pinion height adjusting washer in order to bring drive pinion close to drive gear.

To correct, reduce thickness of drive pinion height adjusting washer in order to make drive pinion go away from drive gear.



When adjustment is completed, be sure to wipe off completely the red lead and oil or their equivalent.

5. If outside the standard, adjust drive pinion height adjusting washer and backlash. Refer to [RFD-56, "Drive Pinion Height Adjusting Washer"](#) and [RFD-50, "Backlash"](#).

Backlash

1. Remove carrier cover. Refer to [RFD-52, "Differential Assembly"](#).
2. Check drive gear to drive pinion backlash using a dial indicator at several points.


Drive gear to drive pinion backlash:
0.08 - 0.13 mm (0.0031 - 0.0051 in)

3. If outside the standard, adjust side bearing adjusters.

CAUTION:

Check tooth contact and total preload after adjusting side bearing adjusters. Refer to [RFD-49, "Total Preload Torque"](#), [RFD-49, "Tooth Contact"](#).


- a. Remove adjuster lock plates.
- b. Loosen side bearing cap bolts.




REAR FINAL DRIVE ASSEMBLY [WITH LIMITED SLIP DIFFERENTIAL]

c. Tighten or loosen each side bearing adjusters using Tool.

Tool number : KV38108800




d. In case of excessive backlash, loosen side bearing adjuster A and tighten side bearing adjuster B. In case of insufficient backlash, loosen side bearing adjuster B and tighten side bearing adjuster A.



e. After adjusting backlash, tighten side bearing cap bolts to the specified torque. Refer to [RFD-48, "COMPONENTS"](#).

f. Install adjuster lock plates and tighten to the specified torque. Refer to [RFD-48, "COMPONENTS"](#).



Companion Flange Runout

1. Fit a dial indicator onto companion flange face (inner side of propeller shaft bolt holes).

2. Rotate companion flange to check for runout.

Runout limit : 0.10 mm (0.0039 in) or less

3. Fit a test indicator to the inner side of companion flange (socket diameter).

4. Rotate companion flange to check for runout.


Runout limit : 0.13 mm (0.0051 in) or less

5. If the runout value is outside the repair limit, follow the procedure below to adjust.

a. Check for runout while changing the phase between companion flange and drive pinion by 90°, 180° and 270° and search for the point where the runout is the minimum.

b. If the runout value is still outside of the limit after the phase has been changed, replace companion flange.

c. If the runout value is still outside of the limit after companion flange has been replaced, check drive pinion front bearing, drive pinion rear bearing and drive pinion assembly.




REAR FINAL DRIVE ASSEMBLY [WITH LIMITED SLIP DIFFERENTIAL]

DISASSEMBLY

Differential Assembly

1. Remove carrier cover bolts and bracket.




2. Separate carrier cover from axle housing using Tool.

Tool number : KV10111100

CAUTION:

- Be careful not to damage the mating surface.
- Do not insert flat-bladed screwdriver, this will damage the mating surface.




3. For proper reinstallation, paint matching mark on one side of side bearing cap and axle housing.


CAUTION:

- Side bearing caps are line-board for initial assembly. The matching marks are used to reinstall them in their original positions.
- For matching mark, use paint. Do not damage side bearing cap and axle housing.

4. Remove adjuster lock plates.




5. Remove side bearing caps.




REAR FINAL DRIVE ASSEMBLY [WITH LIMITED SLIP DIFFERENTIAL]

6. Loosen side bearing adjusters using Tool.

Tool number : KV38108800




7. Keep side bearing outer races together with inner races. Do not mix them up. Also, keep side bearing adjusters together with bearing.
8. Remove side bearing adjusters from axle housing.



9. Remove side bearing inner races using suitable tools.

CAUTION:
Be careful not to damage differential case assembly.




10. For proper reinstallation, paint matching mark on differential case assembly and drive gear.

CAUTION:
For matching mark, use paint. Do not damage differential case assembly and drive gear.

11. Remove drive gear bolts.
12. Tap drive gear off differential case assembly using suitable tool.

CAUTION:
Tap evenly all around to keep drive gear from binding.




A
B
C
RFD
E
F
G
H
I
J
K
L
M

REAR FINAL DRIVE ASSEMBLY [WITH LIMITED SLIP DIFFERENTIAL]

Drive Pinion Assembly

1. Remove differential case assembly. Refer to [RFD-52, "Differential Assembly"](#) .
2. Remove drive pinion lock nut and washer using Tool.


Tool number : KV40104000




3. Put a matching mark on the thread edge of drive pinion. The mark should be in line with the mark on companion flange.

CAUTION:

For matching mark, use paint. Do not damage drive pinion and companion flange.



4. Remove companion flange using suitable tool.




5. Remove front oil seal using Tool.

Tool number : KV381054S0

CAUTION:

Be careful not to damage axle housing.

6. Remove front bearing thrust washer.



REAR FINAL DRIVE ASSEMBLY


[WITH LIMITED SLIP DIFFERENTIAL]

7. Press the drive pinion assembly and collapsible spacer from axle housing.

CAUTION:

Do not drop drive pinion assembly.

8. Remove drive pinion front bearing inner race from axle housing.



9. Tap drive pinion front bearing outer race uniformly with a brass bar or equivalent to remove.


CAUTION:

Be careful not to damage axle housing.

10. Tap drive pinion rear bearing outer race uniformly with a brass bar or equivalent for removal.

CAUTION:


Be careful not to damage axle housing.



11. Remove drive pinion rear bearing inner race and drive pinion height adjusting washer using Tool.

Tool number : ST30021000

12. Remove the breather.



INSPECTION AFTER DISASSEMBLY

Drive Gear and Drive Pinion

- If the gear teeth do not mesh or line-up correctly, determine the cause and adjust, repair, or replace as necessary.
- If the gears are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new gears.
- Drive gear and drive pinion are supplied in matched sets only. Matching numbers on both drive pinion and drive gear are etched for verification. If a new gear set is being used, verify the numbers of each drive pinion and drive gear before proceeding with assembly.

Bearing

- If bearings are chipped (by friction), pitted, worn, rusted, scratched, or unusual noise is coming from bearing, replace with new bearing assembly (as a new set).
- Bearing must be replaced with a new one whenever disassembled.

Differential Case Assembly

- If the gears are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new differential case assembly.

A
B
C
RFD
E
F
G
H
I
J
K
L
M


REAR FINAL DRIVE ASSEMBLY

[WITH LIMITED SLIP DIFFERENTIAL]

SELECTION ADJUSTING WASHERS

Drive Pinion Height Adjusting Washer

- Drive gear and drive pinion are supplied in matched sets only. Matching numbers on both drive pinion and drive gear are etched for verification. If a new hypoid gear set is being used, verify the numbers of each drive pinion and drive gear before proceeding with assembly.



- The mounting distance from the center line of drive gear to the back face of drive pinion for the M226 final drive is 109.5 mm (4.312 in). On the button end of each drive pinion, there is etched a plus (+) number, a minus (-) number, or a zero (0), which indicates the best running position for each particular hypoid gear set. This dimension is controlled by a selective drive pinion height adjusting washer between drive pinion rear bearing inner race and drive pinion. For example: If a drive pinion is etched m+8 (+3), it would require 0.08 mm (0.003 in) less drive pinion height adjusting washer than a drive pinion etched "0". This means decreasing drive pinion height adjusting washer thickness; increases the mounting distance of drive pinion to 109.6 mm (4.315 in). If a drive pinion is etched m-8 (-3), it would require adding 0.08 mm (0.003 in) more to drive pinion height adjusting washer than would be required if drive pinion were etched "0". By adding 0.08 mm (0.003 in), the mounting distance of drive pinion was decreased to 109.4 mm (4.309 in) which is just what a m-8 (-3) etching indicated.
- To change drive pinion adjustment, use different drive pinion height adjusting washer which come in different thickness.
- Use the following tables as a guide for selecting the correct drive pinion height adjusting washer thickness to add or subtract from the old drive pinion height adjusting washer.

Unit: mm (in)

| OLD DRIVE PINION MARKING | NEW DRIVE PINION MARKING | | | | | | | | |
|--------------------------|--------------------------|----------------|----------------|----------------|----------------|----------------|----------------|----------------|----------------|
| | -10 (-4) | -8 (-3) | -5 (-2) | -3 (-1) | 0 | +3 (+1) | +5 (+2) | +8 (+3) | +10 (+4) |
| +10 (+4) | +0.20 (+0.008) | +0.18 (+0.007) | +0.15 (+0.006) | +0.13 (+0.005) | +0.10 (+0.004) | +0.08 (+0.003) | +0.05 (+0.002) | +0.02 (+0.001) | 0 (0) |
| +8 (+3) | +0.18 (+0.007) | +0.15 (+0.006) | +0.13 (+0.005) | +0.10 (+0.004) | +0.08 (+0.003) | +0.05 (+0.002) | +0.02 (+0.001) | 0 (0) | -0.02 (-0.001) |
| +5 (+2) | +0.15 (+0.006) | +0.13 (+0.005) | +0.10 (+0.004) | +0.08 (+0.003) | +0.05 (+0.002) | +0.02 (+0.001) | 0 (0) | -0.02 (-0.001) | -0.05 (-0.002) |
| +3 (+1) | +0.13 (+0.005) | +0.10 (+0.004) | +0.08 (+0.003) | +0.05 (+0.002) | +0.02 (+0.001) | 0 (0) | -0.02 (-0.001) | -0.05 (-0.002) | -0.08 (-0.003) |
| 0 | +0.10 (+0.004) | +0.08 (+0.003) | +0.05 (+0.002) | +0.02 (+0.001) | 0 (0) | -0.02 (-0.001) | -0.05 (-0.002) | -0.08 (-0.003) | -0.10 (-0.004) |
| -3 (-1) | +0.08 (+0.003) | +0.05 (+0.002) | +0.02 (+0.001) | 0 (0) | -0.02 (-0.001) | -0.05 (-0.002) | -0.08 (-0.003) | -0.10 (-0.004) | -0.13 (-0.005) |
| -5 (-2) | +0.05 (+0.002) | +0.02 (+0.001) | 0 (0) | -0.02 (-0.001) | -0.05 (-0.002) | -0.08 (-0.003) | -0.10 (-0.004) | -0.13 (-0.005) | -0.15 (-0.006) |
| -8 (-3) | +0.02 (+0.001) | 0 (0) | -0.02 (-0.001) | -0.05 (-0.002) | -0.08 (-0.003) | -0.10 (-0.004) | -0.13 (-0.005) | -0.15 (-0.006) | -0.18 (-0.007) |
| -10 (-4) | 0 (0) | -0.02 (-0.001) | -0.05 (-0.002) | -0.08 (-0.003) | -0.10 (-0.004) | -0.13 (-0.005) | -0.15 (-0.006) | -0.18 (-0.007) | -0.20 (-0.008) |

REAR FINAL DRIVE ASSEMBLY [WITH LIMITED SLIP DIFFERENTIAL]

ASSEMBLY


Drive Pinion Assembly

1. Install the breather and then tighten to the specified torque. Refer to [RFD-48, "COMPONENTS"](#).
2. Press a drive pinion rear bearing outer race into axle housing using suitable tool and Tool.

Tool number : ST30022000

CAUTION:


Do not reuse drive pinion rear bearing.



3. Press drive pinion front bearing outer race into axle housing using suitable tool.

CAUTION:

Do not reuse drive pinion front bearing.




4. Temporarily install drive pinion height adjusting washer.

When hypoid gear set has been replaced

- Select drive pinion height adjusting washer. Refer to [RFD-56, "Drive Pinion Height Adjusting Washer"](#).

When hypoid gear set has been reused

- Temporarily install the removed drive pinion height adjusting washer or same thickness washer to drive pinion.



5. Install selected drive pinion height adjusting washer to drive pinion, and press-fit drive pinion rear bearing inner race in it, using a press and suitable tool.

CAUTION:

Do not reuse drive pinion rear bearing.

6. Apply gear oil to drive pinion rear bearing and drive pinion front bearing.
7. Install drive pinion front bearing inner race in axle housing.


CAUTION:

Do not reuse drive pinion front bearing.

8. Install front bearing thrust washer to axle housing.
9. Perform checking and adjusting the tooth contact and backlash of the hypoid gear following the procedure below.
- a. Assemble the drive pinion assembly to the axle housing.

CAUTION:

Do not assemble a collapsible spacer.




REAR FINAL DRIVE ASSEMBLY

[WITH LIMITED SLIP DIFFERENTIAL]

- b. Insert companion flange onto drive pinion. Tap the companion flange with a soft hammer until fully seated.

CAUTION:

Do not assemble a front oil seal.




- c. Temporarily tighten removed drive pinion lock nut and washer to drive pinion.

Tool number : KV40104000

NOTE:

Use removed drive pinion lock nut and washer only for the pre-load measurement.

- d. Rotate drive pinion at least 20 times to check for smooth operation of the bearing.



- e. Tighten to drive pinion lock nut, while adjust pinion bearing pre-load torque.

Tool number : ST3127S000

Drive pinion lock nut tightening torque:


298 - 678 N·m (31 - 69 kg·m, 220 - 500 ft·lb)

Pinion bearing preload:


1.7 - 3.1 N·m (0.18 - 0.31 kg·m, 15 - 27 in·lb)

CAUTION:

- Adjust to the lower limit of the drive pinion lock nut tightening torque first.
- Drive pinion lock nut is tightened with no collapsible spacer. Be careful not to overtighten it. While measuring the preload, tighten it by 5° to 10°.
- After adjustment, rotate drive pinion back and forth 2 to 3 times to check for unusual noise, rotation malfunction and other malfunctions.




- f. Install side bearing adjusters into axle housing.




REAR FINAL DRIVE ASSEMBLY [WITH LIMITED SLIP DIFFERENTIAL]

- g. Apply gear oil to side bearings. Install differential case assembly with side bearing outer races into axle housing.




- h. Align paint matching mark on side bearing cap with that on axle housing and install side bearing caps on axle housing.
- Do not tighten at this point. This allows further tightening of side bearing adjusters.
- i. Check and adjust the backlash and tooth contact. Refer to [RFD-50, "Backlash"](#) and [RFD-49, "Tooth Contact"](#).
- j. Remove side bearing caps.
- k. Remove differential case assembly.
- l. Remove companion flange.



- m. Press the drive pinion assembly from axle housing.


CAUTION:
Do not drop drive pinion assembly.



10. Install front oil seal into axle housing using suitable tool.

CAUTION:


- Do not reuse oil seal.
- Do not incline oil seal when installing.
- Apply multi-purpose grease onto oil seal lip, and gear oil onto the circumference of oil seal.



11. Install collapsible spacer to drive pinion. And then install drive pinion assembly in axle housing.

CAUTION:

- Do not reuse collapsible spacer.
- Be careful not to damage front oil seal.




A
B
C
RFD
E
F
G
H
I
J
K
L
M

REAR FINAL DRIVE ASSEMBLY

[WITH LIMITED SLIP DIFFERENTIAL]


12. Align the matching mark of the drive pinion with the mark of the companion flange, then install the companion flange.



13. Insert companion flange onto drive pinion. Tap the companion flange with a soft hammer until fully seated.

CAUTION:

Be careful not to damage companion flange and front oil seal.




14. Apply anti-corrosive oil to the thread and seat of drive pinion lock nut, and temporarily tighten drive pinion lock nut and washer to drive pinion.

Tool number : KV40104000

CAUTION:

Do not reuse drive pinion lock nut and washer.

15. Rotate drive pinion at least 20 times to check for smooth operation of the bearing.



16. Tighten to drive pinion lock nut, while adjust pinion bearing preload torque.

Tool number : ST3127S000

Drive pinion lock nut tightening torque:

298 - 678 N·m (31 - 69 kg·m, 220 - 500 ft·lb)

Pinion bearing preload:

1.7 - 3.1 N·m (0.18 - 0.31 kg·m, 15 - 27 in·lb)

CAUTION:


- **Adjust the lower limit of the drive pinion lock nut tightening torque first.**
- **If the preload torque exceeds the specified value, replace collapsible spacer and tighten it again to adjust. Never loosen drive pinion lock nut to adjust the preload torque.**
- **After adjustment, rotate drive pinion back and forth 2 to 3 times to check for unusual noise, rotation malfunction, and other malfunctions.**

17. Install differential case assembly. Refer to [RFD-61, "Differential Assembly"](#) .

CAUTION:

Do not install carrier cover yet.

18. Check and adjust backlash, tooth contact and companion flange runout. Refer to [RFD-50, "Backlash"](#) , [RFD-49, "Tooth Contact"](#) and [RFD-51, "Companion Flange Runout"](#) . Recheck above items. Readjust the above description, if necessary.




REAR FINAL DRIVE ASSEMBLY [WITH LIMITED SLIP DIFFERENTIAL]


19. Check total preload torque. Refer to [RFD-49, "Total Preload Torque"](#).
20. Apply sealant to mating surface of carrier cover. Refer to [RFD-48, "COMPONENTS"](#).

CAUTION:

Remove old sealant adhering to mounting surfaces. Also remove any moisture, oil, or foreign material adhering to application and mounting surfaces.



21. Install carrier cover and bracket on axle housing. Then tighten carrier cover bolts to the specified torque. Refer to [RFD-48, "COMPONENTS"](#).




Differential Assembly


1. Apply sealant to back face of drive gear. Refer to [RFD-48, "COMPONENTS"](#).

CAUTION:

Remove old sealant adhering to mounting surfaces. Also remove any moisture, oil, or foreign material adhering to application and mounting surfaces.



2. Align the matching mark of differential case assembly with the mark of drive gear, then install drive gear.




REAR FINAL DRIVE ASSEMBLY [WITH LIMITED SLIP DIFFERENTIAL]

3. Apply thread locking sealant into the thread hole of drive gear. Refer to [RFD-48, "COMPONENTS"](#).

CAUTION:


Make sure threaded holes are clean.



4. Install the drive gear bolts, and then tighten to the specified torque. Refer to [RFD-48, "COMPONENTS"](#).

CAUTION:

- Do not reuse the bolts.
- Tighten bolts in a crisscross fashion.




5. Press side bearing inner races to differential case assembly using suitable tool and Tool.


Tool number : KV38100300

CAUTION:


Do not reuse side bearings.



6. Install side bearing adjusters into axle housing.



7. Apply gear oil to side bearings. Install differential case assembly with side bearing outer races into axle housing.




REAR FINAL DRIVE ASSEMBLY [WITH LIMITED SLIP DIFFERENTIAL]

8. Align paint matching mark on side bearing cap with that on axle housing and install side bearing caps on axle housing.

CAUTION:


Do not tighten at this point. This allows further tightening of side bearing adjusters.



9. Tighten each side bearing adjusters using Tool.

Tool number : KV38108800


10. Adjust backlash of drive gear and drive pinion. Refer to [RFD-50, "Backlash"](#) .
11. Check tooth contact. Refer to [RFD-49, "Tooth Contact"](#) .
12. Check total preload. Refer to [RFD-49, "Total Preload Torque"](#) .




13. Apply sealant to mating surface of carrier cover. Refer to [RFD-48, "COMPONENTS"](#) .

CAUTION:

Remove old sealant adhering to mounting surfaces. Also remove any moisture, oil, or foreign material adhering to application and mounting surfaces.



14. Install carrier cover and bracket on axle housing. Then tighten carrier cover bolts to the specified torque. Refer to [RFD-48, "COMPONENTS"](#) .



A
B
C
RFD
E
F
G
H
I
J
K
L
M

SERVICE DATA AND SPECIFICATIONS (SDS) [WITH LIMITED SLIP DIFFERENTIAL]

SERVICE DATA AND SPECIFICATIONS (SDS)

PF0:00030

General Specifications VQ40DE engine models

GDS0002K

| Applied model | 2WD* | | 4WD | |
|---|--------------|-------|--------|-------|
| | 6M/T | 5A/T | 6M/T | 5A/T |
| Grade | SE | | SE, XE | |
| Final drive model | M226 | | | |
| Gear ratio | 3.538 | 3.133 | 3.692 | 3.357 |
| Number of pinion gears | 2 | | | |
| Number of teeth (Drive gear / drive pinion) | 46/13 | 47/15 | 48/13 | 47/14 |
| Oil capacity (Approx.) ℓ (Imp pt) | 2.01 (3-1/2) | | | |
| Drive pinion adjustment spacer type | Collapsible | | | |

*: Option

YD25DDTi engine models

| Applied model | 2WD* | | 4WD | | |
|---|--------------|-------|-------|-------|--------|
| | 6M/T | 5A/T | 6M/T | | 5A/T |
| Grade | SE | | XE* | XE | SE, XE |
| Final drive model | M226 | | | | |
| Gear ratio | 3.538 | 3.357 | 3.692 | 3.538 | |
| Number of pinion gears | 2 | | | | |
| Number of teeth (Drive gear / drive pinion) | 46/13 | 47/14 | 48/13 | 46/13 | |
| Oil capacity (Approx.) ℓ (Imp pt) | 2.01 (3-1/2) | | | | |
| Drive pinion adjustment spacer type | Collapsible | | | | |

*: Option

Inspection and Adjustment PRELOAD TORQUE

GDS0002L

Unit: N·m (kg·m, in·lb)

| Item | Specification | | | |
|------------------------|------------------------------------|-----------------------|---------------------------------------|---------------------------------------|
| | Gear ratio 3.133 type | Gear ratio 3.357 type | Gear ratio 3.538 type | Gear ratio 3.692 type |
| Total preload | 2.38 - 4.46 (0.25 - 0.45, 21 - 39) | | 2.34 - 4.34 (0.24 - 0.44, 21 - 38) | 2.32 - 4.34 (0.24 - 0.44, 21 - 38) |
| Pinion bearing preload | 1.7 - 3.1 (0.18 - 0.31, 15 - 27) | | | |

BACKLASH

Unit: mm (in)

| Item | Standard |
|---------------------------------|-------------------------------|
| Drive gear to drive pinion gear | 0.08 - 0.13 (0.0031 - 0.0051) |

COMPANION FLANGE RUNOUT

Unit: mm (in)

| Item | Runout limit |
|--------------------------------|-----------------------|
| Companion flange face | 0.10 (0.0039) or less |
| Inner side of companion flange | 0.13 (0.0051) or less |

SERVICE DATA AND SPECIFICATIONS (SDS)
[WITH LIMITED SLIP DIFFERENTIAL]

SELECTIVE PARTS

Drive Pinion Height Adjusting Washer

Unit: mm (in)

| Thickness | Package part number* |
|---|----------------------|
| 0.076 (0.030) 0.079 (0.031) 0.081 (0.032) 0.084 (0.033) 0.086 (0.034) | 38151 8S101 |
| 0.089 (0.035) 0.091 (0.036) 0.094 (0.037) 0.097 (0.038) 0.099 (0.039) | 38151 8S102 |
| 0.102 (0.040) 0.104 (0.041) 0.107 (0.042) 0.109 (0.043) 0.112 (0.044) | 38151 8S103 |
| 0.114 (0.045) 0.117 (0.046) 0.119 (0.047) 0.122 (0.048) 0.124 (0.049) | 38151 8S104 |
| 0.127 (0.050) 0.130 (0.051) 0.132 (0.052) 0.135 (0.053) 0.137 (0.054) | 38151 8S105 |

A
B
C
RFD
E
F
G
H
I
J
K
L
M

*Always check with the Parts Department for the latest parts information.

**SERVICE DATA AND SPECIFICATIONS (SDS)
[WITH LIMITED SLIP DIFFERENTIAL]**
