

# SECTION LAN

## LAN SYSTEM

A  
B  
C

### CONTENTS

D  
E

#### CAN

<b>PRECAUTIONS</b> .....	<b>3</b>
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	3
Precautions When Using CONSULT-II .....	3
CHECK POINTS FOR USING CONSULT-II .....	3
Precautions for Trouble Diagnosis .....	3
CAN SYSTEM .....	3
Precautions for Harness Repair .....	4
CAN SYSTEM .....	4
<b>TROUBLE DIAGNOSES WORK FLOW</b> .....	<b>5</b>
When Displaying CAN Communication System Errors .....	5
WHEN A MALFUNCTION IS DETECTED BY CAN COMMUNICATION SYSTEM .....	5
WHEN A MALFUNCTION IS DETECTED EXCEPT CAN COMMUNICATION SYSTEM .....	5
TROUBLE DIAGNOSIS FLOW CHART .....	6
Diagnosis Procedure .....	7
SELECTING CAN SYSTEM TYPE (HOW TO USE SPECIFICATION TABLE) .....	7
ACQUISITION OF DATA BY CONSULT-II .....	8
HOW TO USE CHECK SHEET TABLE .....	9
CAN Diagnostic Support Monitor .....	15
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR ECM .....	15
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR TCM .....	16
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR DIFFERENTIAL LOCK CONTROL UNIT .....	16
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR BCM .....	17
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR METER .....	18
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR TRANSFER CONTROL UNIT .....	19
DESCRIPTION OF "CAN DIAG SUPPORT	

MNTR" SCREEN FOR ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) .....	20
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR IPDM E/R .....	21
<b>CAN COMMUNICATION</b> .....	<b>22</b>
System Description .....	22
Component Parts and Harness Connector Location .....	22
Schematic .....	23
Wiring Diagram — CAN — .....	24
CAN Communication Unit .....	27
TYPE 1/TYPE 3 .....	28
TYPE 2/TYPE 5 .....	30
TYPE 4 .....	32
TYPE 6/TYPE 7 .....	33
TYPE 8 .....	36
TYPE 9/TYPE 10 .....	37
TYPE 11 .....	39
TYPE 12/TYPE 13 .....	41
TYPE 14/TYPE 15 .....	44
<b>CAN SYSTEM (TYPE 1)</b> .....	<b>47</b>
Component Parts and Harness Connector Location .....	47
Schematic .....	47
Wiring Diagram — CAN — .....	47
Check Sheet .....	48
CHECK SHEET RESULTS (EXAMPLE) .....	50
<b>CAN SYSTEM (TYPE 2)</b> .....	<b>58</b>
Component Parts and Harness Connector Location .....	58
Schematic .....	58
Wiring Diagram — CAN — .....	58
Check Sheet .....	59
CHECK SHEET RESULTS (EXAMPLE) .....	61
<b>CAN SYSTEM (TYPE 3)</b> .....	<b>71</b>
Component Parts and Harness Connector Location .....	71
Schematic .....	71
Wiring Diagram — CAN — .....	71
Check Sheet .....	72
CHECK SHEET RESULTS (EXAMPLE) .....	74
<b>CAN SYSTEM (TYPE 4)</b> .....	<b>82</b>
Component Parts and Harness Connector Location .....	82
Schematic .....	82

F  
G  
H  
I  
J

LAN

L  
M

Wiring Diagram — CAN — .....	82	<b>CAN SYSTEM (TYPE 12)</b> .....	<b>184</b>
Check Sheet .....	83	Component Parts and Harness Connector Location	184
CHECK SHEET RESULTS (EXAMPLE) .....	85	Schematic .....	184
<b>CAN SYSTEM (TYPE 5)</b> .....	<b>93</b>	Wiring Diagram — CAN — .....	184
Component Parts and Harness Connector Location	93	Check Sheet .....	185
Schematic .....	93	CHECK SHEET RESULTS (EXAMPLE) .....	187
Wiring Diagram — CAN — .....	93	<b>CAN SYSTEM (TYPE 13)</b> .....	<b>198</b>
Check Sheet .....	94	Component Parts and Harness Connector Location	198
CHECK SHEET RESULTS (EXAMPLE) .....	96	Schematic .....	198
<b>CAN SYSTEM (TYPE 6)</b> .....	<b>106</b>	Wiring Diagram — CAN — .....	198
Component Parts and Harness Connector Location	106	Check Sheet .....	199
Schematic .....	106	CHECK SHEET RESULTS (EXAMPLE) .....	201
Wiring Diagram — CAN — .....	106	<b>CAN SYSTEM (TYPE 14)</b> .....	<b>213</b>
Check Sheet .....	107	Component Parts and Harness Connector Location	213
CHECK SHEET RESULTS (EXAMPLE) .....	109	Schematic .....	213
<b>CAN SYSTEM (TYPE 7)</b> .....	<b>119</b>	Wiring Diagram — CAN — .....	213
Component Parts and Harness Connector Location	119	Check Sheet .....	214
Schematic .....	119	CHECK SHEET RESULTS (EXAMPLE) .....	216
Wiring Diagram — CAN — .....	119	<b>CAN SYSTEM (TYPE 15)</b> .....	<b>228</b>
Check Sheet .....	120	Component Parts and Harness Connector Location	228
CHECK SHEET RESULTS (EXAMPLE) .....	122	Schematic .....	228
<b>CAN SYSTEM (TYPE 8)</b> .....	<b>133</b>	Wiring Diagram — CAN — .....	228
Component Parts and Harness Connector Location	133	Check Sheet .....	229
Schematic .....	133	CHECK SHEET RESULTS (EXAMPLE) .....	231
Wiring Diagram — CAN — .....	133	<b>TROUBLE DIAGNOSIS FOR SYSTEM</b> .....	<b>244</b>
Check Sheet .....	134	Inspection Between TCM and Data Link Connector	
CHECK SHEET RESULTS (EXAMPLE) .....	136	Circuit .....	244
<b>CAN SYSTEM (TYPE 9)</b> .....	<b>145</b>	Inspection Between Data Link Connector and ABS	
Component Parts and Harness Connector Location	145	Actuator and Electric Unit (Control Unit) Circuit ...	245
Schematic .....	145	ECM Circuit Inspection .....	246
Wiring Diagram — CAN — .....	145	TCM Circuit Inspection .....	247
Check Sheet .....	146	Differential Lock Control Unit Circuit Inspection ...	247
CHECK SHEET RESULTS (EXAMPLE) .....	148	Steering Angle Sensor Circuit Inspection .....	248
<b>CAN SYSTEM (TYPE 10)</b> .....	<b>157</b>	Data Link Connector Circuit Inspection .....	248
Component Parts and Harness Connector Location	157	BCM Circuit Inspection .....	249
Schematic .....	157	Combination Meter Circuit Inspection .....	249
Wiring Diagram — CAN — .....	157	Transfer Control Unit Circuit Inspection .....	250
Check Sheet .....	158	ABS Actuator and Electric Unit (Control Unit) Circuit	
CHECK SHEET RESULTS (EXAMPLE) .....	160	Inspection .....	250
<b>CAN SYSTEM (TYPE 11)</b> .....	<b>170</b>	IPDM E/R Circuit Inspection .....	251
Component Parts and Harness Connector Location	170	CAN Communication Circuit Inspection .....	251
Schematic .....	170	IPDM E/R Ignition Relay Circuit Inspection .....	252
Wiring Diagram — CAN — .....	170		
Check Sheet .....	171		
CHECK SHEET RESULTS (EXAMPLE) .....	173		

**PRECAUTIONS**

PFP:00001

**Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”**

UKS003L0

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

**Precautions When Using CONSULT-II**

UKS003L1

When connecting CONSULT-II to data link connector, connect them through CONSULT-II CONVERTER.

**CAUTION:**

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

**CHECK POINTS FOR USING CONSULT-II**

1. Has CONSULT-II been used without connecting CONSULT-II CONVERTER on this vehicle?
  - If YES, GO TO 2.
  - If NO, GO TO 5.
2. Is there any indication other than indications relating to CAN communication system in the self-diagnosis results?
  - If YES, GO TO 3.
  - If NO, GO TO 4.
3. Based on self-diagnosis results unrelated to CAN communication, carry out the inspection.
4. Malfunctions may be detected in self-diagnosis depending on control units carrying out CAN communication. Therefore, erase the self-diagnosis results.
5. Diagnose CAN communication system. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#) .

**Precautions for Trouble Diagnosis CAN SYSTEM**

UKS003L2


- Do not apply voltage of 7.0 V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0 V or less.
- Be sure to turn ignition switch OFF and disconnect the battery cable from the negative terminal before checking the circuit.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M


LAN

### Precautions for Harness Repair CAN SYSTEM

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in).]



- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)



**TROUBLE DIAGNOSES WORK FLOW**

PFP:00004

**When Displaying CAN Communication System Errors**

UKS003L4

**WHEN A MALFUNCTION IS DETECTED BY CAN COMMUNICATION SYSTEM**

- CAN communication line is open. (CAN H, CAN L, or both)
- CAN communication line is shorted. (Ground, between CAN lines, or other harnesses)
- The areas related to CAN communication of unit is malfunctioning.

**WHEN A MALFUNCTION IS DETECTED EXCEPT CAN COMMUNICATION SYSTEM**

- Removal and installation of parts: When the units that perform CAN communication or the sensors related to CAN communication are removed and installed, malfunction may be detected (or DTC other than CAN communication may be detected).
- Fuse blown out (removed): CAN communication of the unit may be stopped at such time.
- Low voltage: If the voltage decreases because of battery discharge when IGN is ON, malfunction may be detected by self-diagnosis according to the units.

A

B

C

D

E

F

G

H

I

J


LAN

L

M

## TROUBLE DIAGNOSIS FLOW CHART

Depending on the control unit which performs CAN communication, "U1010" may be indicated as the result of self-diagnosis. Replace the control unit if "U1010" is indicated.



- Step 1: Refer to [LAN-7, "SELECTING CAN SYSTEM TYPE \(HOW TO USE SPECIFICATION TABLE\)"](#) .
- Step 2: Refer to [LAN-8, "ACQUISITION OF DATA BY CONSULT-II"](#) .
- Step 3: Refer to [LAN-9, "HOW TO USE CHECK SHEET TABLE"](#) .
- Step 4: Refer to [LAN-10, "Example of Filling in Check Sheet When Initial Conditions Are Reproduced"](#) .
- Step 5: Refer to [LAN-244, "TROUBLE DIAGNOSIS FOR SYSTEM"](#) .

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

UKS003L5

## Diagnosis Procedure

### SELECTING CAN SYSTEM TYPE (HOW TO USE SPECIFICATION TABLE)

Determine CAN system type from the equipment of the vehicle to select applicable check sheet.

(Example) Truck/4WD/VQ40DE/AT/VDC/Without electronic locking rear differential

#### CAN Communication Unit

Go to CAN system, when selecting your CAN system type from the following table.

Body type	Truck														
Axle	2WD							4WD							
Engine	QR25DE				VQ40DE										
Transmission	M/T	A/T	M/T		A/T		M/T		A/T		M/T		A/T		
Brake control	ABS		ABS	ABLS	ABS	ABLS	ABS	ABLS	ABS	ABLS	ABS	ABLS	VDC		
Electronic locking rear differential							x			x			x	x	
CAN system type	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
CAN system trouble diagnosis	XX: XX	XX: XX	XX: XX	XX: XX	XX: XX	XX: XX	XX: XX	XX: XX	XX: XX	XX: XX	XX: XX	XX: XX	XX: XX	XX: XX	XX: XX

Check basic specification of the vehicle.

Select "x" if it is model with electronic locking rear differential.

Which number is selected when sequentially selecting from the top of the specification table? The number is "CAN system type" of the applicable vehicle.

In the case of this example: It corresponds to type 14.

x : Applicable

PKIB6530E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

## ACQUISITION OF DATA BY CONSULT-II

Attach the data acquired by CONSULT-II on the check sheet determined according to CAN system type.

Copy "SELECT SYSTEM" screen of CONSULT-II.

SELECT SYSTEM		
ENGINE		
A/T		
ABS		
AIR BAG		
IPDM E/R		
METER		
Page Down		
BACK	LIGHT	COPY

SELECT SYSTEM		
A/T		
ABS		
AIR BAG		
IPDM E/R		
METER		
ALL MODE AWD/4WD		
Page Up		
BACK	LIGHT	COPY

Check sheet table

SH-FCT SYSTEM screen	Initial diagnosis	Transfer diagnosis	CAN DIAG SUPPORT MNTR										SELF DIAG RESULTS	
			ECM	TCM	STRG	BCM	METER	METER/MA	METER/ABS	IPDM E/R	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)		
ENGINE	--	--	UNKNW	--	UNKNW	--	UNKNW	UNKNW	UNKNW	UNKNW	UNKNW	UNKNW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	--	NG	UNKNW	UNKNW	--	--	UNKNW	UNKNW	UNKNW	UNKNW	UNKNW	UNKNW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	NG	NG	UNKNW	UNKNW	--	--	UNKNW	--	--	UNKNW	UNKNW	UNKNW	CAN COMM CIRCUIT (U1000)	--
METER	NG	NG	UNKNW	UNKNW	UNKNW	--	UNKNW	--	--	UNKNW	UNKNW	UNKNW	CAN COMM CIRCUIT (U1000)	--
ALL MODE AWD/4WD	--	NG	UNKNW	UNKNW	UNKNW	--	--	UNKNW	--	UNKNW	UNKNW	UNKNW	CAN COMM CIRCUIT (U1000)	--
AIRB	--	NG	UNKNW	UNKNW	UNKNW	UNKNW	--	--	UNKNW	--	--	--	CAN COMM CIRCUIT (U1000)	--
IPDM E/R	NG	NG	UNKNW	UNKNW	--	--	UNKNW	--	--	UNKNW	UNKNW	UNKNW	CAN COMM CIRCUIT (U1000)	--

Symptoms :

Attach copy of SH-FCT SYSTEM

Attach copy of SELECT SYSTEM

Copy "SELF-DIAG RESULTS" screen of CONSULT-II.

SELF-DIAG RESULTS	
DTC RESULTS	TIME
CAN COMM CIRCUIT (U1000)	
ERASE	PRINT
MODE BACK	LIGHT COPY

SELF-DIAG RESULTS	
DTC RESULTS	
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	
ERASE	PRINT
MODE BACK	LIGHT COPY

Attach copy of ENGINE SH-F-DIAG RESULTS

Attach copy of A/T SELF-DIAG RESULTS

Attach copy of BCM SH-F-DIAG RESULTS

Attach copy of METER SELF-DIAG RESULTS

Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS

Attach copy of ABS SELF-DIAG RESULTS

Attach copy of IPDM E/R SELF-DIAG RESULTS

Copy "CAN DIAG SUPPORT MNTR" screen of CONSULT-II.

CAN DIAG SUPPORT MNTR	
A/T	
INITIAL DIAG	OK
TRANSMIT DIAG	OK
ECM	OK
VDC/TCS/ABS	OK
METER/MA	OK
ICC&4WD	UNKNW
AWD/4WD	OK
PRINT	
MODE BACK	LIGHT COPY

CAN DIAG SUPPORT MNTR	
ABS	
INITIAL DIAG	OK
TRANSMIT DIAG	OK
ECM	OK
TCM	OK
METER/MA	UNKNW
STRG	OK
ICC	UNKNW
AWD/4WD	OK
PRINT	
MODE BACK	LIGHT COPY

CAN DIAG SUPPORT MNTR	
IPDM E/R	
INITIAL DIAG	OK
TRANSMIT DIAG	OK
ECM	OK
BCM/SC	UNKNW
PRINT	
MODE BACK	LIGHT COPY

Attach copy of A/T CAN DIAG SUPPORT MNTR

Attach copy of ABS CAN DIAG SUPPORT MNTR

Attach copy of BCM CAN DIAG SUPPORT MNTR

Attach copy of METER CAN DIAG SUPPORT MNTR

Attach copy of ENGINE CAN DIAG SUPPORT MNTR

Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR

Attach copy of ABS CAN DIAG SUPPORT MNTR

PKICS990E



## HOW TO USE CHECK SHEET TABLE

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS			
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							IPDM E/R			CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS					
ENGINE	—	—	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

①      ②      ③      ④      ⑤

PKIC5991E

1. Unit names displayed on CONSULT-II.
2. “No indication”: Put a check mark to it if the unit name described in step 1 is not displayed on “SELECT SYSTEM” screen of CONSULT-II. (Unit communicating with CONSULT-II via CAN communication line)  
“—”: Column not used (Unit communicating with CONSULT-II excluding CAN communication line)
3. “NG”: Display “NG” when malfunction is detected in the initial diagnosis of the diagnosed unit. Replace the unit if “NG” is displayed.  
“—”: Column not used (Initial diagnosis is not performed.)
4. “UNKWN”: Display “UNKWN” when the diagnosed unit does not transmit the data normally. Put a check mark to it if “UNKWN” is displayed on CONSULT-II.
5. “UNKWN”: Display “UNKWN” when the diagnosed unit does not receive the data normally. Put a check mark to it if “UNKWN” is displayed on CONSULT-II.  
“—”: Column not used (It is not necessary for CAN communication trouble diagnosis.)

**NOTE:**

CAN communication diagnosis checks if CAN communication works normally. (Contents of data are not diagnosed.)

- When the initial conditions are reproduced, refer to [LAN-10, "Example of Filling in Check Sheet When Initial Conditions Are Reproduced"](#) .
- When the initial conditions are not reproduced, refer to [LAN-13, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#) .

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

## Example of Filling in Check Sheet When Initial Conditions Are Reproduced

The diagram illustrates the process of filling a check sheet based on diagnostic information. It consists of several key components:

- CAN DIAG SUPPORT MNTR (Left):** A diagnostic screen showing 'ENGINE' status. The 'BCM/SEC' row is highlighted with a checkmark, indicating a fault.
- CAN DIAG SUPPORT MNTR (Right):** A diagnostic screen showing 'ENGINE' status. The 'METER/M&A' row is highlighted with a checkmark, indicating a fault.
- Check sheet table:** A table with columns for 'SELECT SYSTEM screen', 'Initial diagnosis', 'Transmit diagnosis', 'Receive diagnosis', and 'SELF-DIAG RESULTS'. The 'BCM' row has 'No indication' checked in the 'Initial diagnosis' column. The 'ENGINE' row has 'UNKWN' in the 'BCM/SEC' column of the 'Receive diagnosis' section.
- SELECT SYSTEM (Left):** A screen showing a list of system options: ENGINE, A/T, ABS, AIR BAG, IPDM E/R, and METER. The 'ENGINE' option is highlighted with a checkmark.
- SELECT SYSTEM (Right):** A screen showing a list of system options: A/T, ABS, AIR BAG, IPDM E/R, METER, and ALL MODE AWD/4WD. The 'METER' option is highlighted with a checkmark.

Arrows indicate the flow of information: from the diagnostic screens to the check sheet table, and from the check sheet table to the selection screens.

PKIC5992E

- Put a check mark to "No indication" if some of unit names listed on the column of diagnosis system selection screen of a check sheet table are not displayed on "SELECT SYSTEM" screen attached to the check sheet.

**NOTE:**

Put a check mark to "No indication" of BCM because BCM is not displayed on "SELECT SYSTEM" screen.


- Confirm the unit name that "UNKWN" is displayed from the copy of "CAN DIAG SUPPORT MNTR" screen of "ENGINE" attached to the check sheet, and then put a check mark to the check sheet table.

**NOTE:**

In "CAN DIAG SUPPORT MNTR" screen, "UNKWN" is displayed on "BCM/SEC". Put a check mark to it.

# TROUBLE DIAGNOSES WORK FLOW

[CAN]



3. Confirm the unit name that "UNKWN" is displayed on the copy of "CAN DIAG SUPPORT MNTR" screen of "A/T", "METER", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" as well as "ENGINE". And then, put a check mark to the check sheet table.

**NOTE:**

- For "A/T", "UNKWN" is displayed on "ICC/e4WD". But, do not put a check mark to their columns of reception diagnosis of the check sheet table because "UNKWN" is not listed.
- For "METER", "UNKWN" is displayed on "BCM/SEC". Put a check mark to it.
- For "ALL MODE AWD/4WD", "UNKWN" is not displayed. Do not put a check mark to it.
- For "ABS", "UNKWN" is displayed on "METER/M&A" and "ICC". But, do not put a check mark to their columns of reception diagnosis of the check sheet table because "UNKWN" is not listed.
- For "IPDM E/R", "UNKWN" is displayed on "BCM/SEC". Put a check mark to it.

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

The arranged results of CAN diagnosis support monitor

Check sheet table


SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							IPDM E/R		
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS			
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Choose similar indications between the results of CAN diagnosis support monitor and the results of the check sheet. Malfunctioning parts are found.

Case 7  
Check BCM circuit.

Check sheet results (example)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							IPDM E/R		
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS			
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—



PKIC594E

**NOTE:**

There is a case that some of “CAN DIAG SUPPORT MNTR” and “SELF-DIAG RESULTS” are not needed for diagnosis. In the case, “UNKWN” and “CAN COMM CIRCUIT [U1000]” in “Check sheet results (example)” change to “—”. Then, ignore check marks on the check sheet table.

4. Perform system diagnosis for possible causes identified.
5. Perform diagnosis again after inspection and repair. Make sure that repair is completely performed, and then end the procedure.

Start CAN system trouble diagnosis if this procedure can be confirmed. Refer to [LAN-27, "CAN Communication Unit"](#).

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

## Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

SYSTEM ENGINE

SELF-DIAG RESULTS

DTC RESULTS      TIME

CAN COMM CIRCUIT [U1001]      1t

SYSTEM A/T

SELF-DIAG RESULTS

DTC RESULTS

NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.

SYSTEM BCM

SELF-DIAG RESULTS

DTC RESULTS      TIME

NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.

SYSTEM METER

SELF-DIAG RESULTS

DTC RESULTS      TIME

CAN COMM CIRCUIT [U1000]      2

SYSTEM ALL MODE AWD/4WD

SELF-DIAG RESULTS

DTC RESULTS

NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.

SYSTEM ABS

SELF-DIAG RESULTS

DTC RESULTS      TIME

NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.

SYSTEM IPDM E/R

SELF-DIAG RESULTS

DTC RESULTS      TIME

CAN COMM CIRCUIT [U1000]      PAST

PKIC5995E

- See “SELF-DIAG RESULTS” of all units attached to the check sheet. If “CAN COMM CIRCUIT”, “CAN COMM CIRCUIT [U1000]” or “CAN COMM CIRCUIT [U1001]” is displayed, put a check mark to the applicable column of self-diagnostic results of the check sheet table.

**NOTE:**

- For “ENGINE”, “CAN COMM CIRCUIT [U1001]” is displayed. Put a check mark to it.
- For “A/T”, “NO DTC IS DETECTED” is displayed. Do not put a check mark to it.
- For “BCM”, “NO DTC IS DETECTED” is displayed. Do not put a check mark to it.
- For “METER”, “CAN COMM CIRCUIT [U1000]” is displayed. Put a check mark to it.
- For “ALL MODE AWD/4WD”, “NO DTC IS DETECTED” is displayed. Do not put a check mark to it.
- For “ABS”, “NO DTC IS DETECTED” is displayed. Do not put a check mark to it.
- For “IPDM E/R”, “CAN COMM CIRCUIT [U1000]” is displayed. Put a check mark to it.

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

The arranged results of self-diagnosis

Check sheet table

SELECT SYSTEM screen	Initial diagnosis	Transfer diagnosis	CAN DIAG SUPPORT MNT'R								SELF-DIAG RESULTS		
			FCM	TCM	STRG	BCM /SEC	METER /MBA	AWD/4WD	VOC/CS /ABS	IPDM E/R			
ENGINE	--	--	UNKWN	--	UNKWN	--	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	CAN COMM CIRCUIT [U1001]
AIT	--	NG	UNKWN	UNKWN	--	--	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	--
BCM	No indication	NG	UNKWN	UNKWN	--	--	UNKWN	--	--	UNKWN	--	CAN COMM CIRCUIT [U1000]	--
METER	No indication	--	UNKWN	UNKWN	UNKWN	--	UNKWN	--	--	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	--
ALL MODE AWD/4WD	--	NG	UNKWN	UNKWN	UNKWN	--	UNKWN	--	--	UNKWN	--	CAN COMM CIRCUIT [U1000]	--
ABS	--	NG	UNKWN	UNKWN	UNKWN	UNKWN	--	--	UNKWN	--	--	CAN COMM CIRCUIT [U1000]	--
IPDM E/R	No indication	--	UNKWN	UNKWN	--	--	UNKWN	--	--	UNKWN	--	CAN COMM CIRCUIT [U1000]	--



When the arranged results of self-diagnosis and check sheet results (example) are corresponding, possible causes can be selected.

Case 7  
Check BCM circuit.

SELECT SYSTEM screen	Initial diagnosis	Transfer diagnosis	CAN DIAG SUPPORT MNT'R								SELF-DIAG RESULTS		
			FCM	TCM	STRG	BCM /SEC	METER /MBA	AWD/4WD	VOC/CS /ABS	IPDM E/R			
ENGINE	--	--	UNKWN	--	UNKWN	--	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	CAN COMM CIRCUIT [U1001]
AIT	--	NG	UNKWN	UNKWN	--	--	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	--
BCM	No indication	NG	UNKWN	UNKWN	--	--	UNKWN	--	--	UNKWN	--	CAN COMM CIRCUIT [U1000]	--
METER	No indication	--	UNKWN	UNKWN	UNKWN	--	UNKWN	--	--	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	--
ALL MODE AWD/4WD	--	NG	UNKWN	UNKWN	UNKWN	--	UNKWN	--	--	UNKWN	--	CAN COMM CIRCUIT [U1000]	--
ABS	--	NG	UNKWN	UNKWN	UNKWN	UNKWN	--	--	UNKWN	--	--	CAN COMM CIRCUIT [U1000]	--
IPDM E/R	No indication	--	UNKWN	UNKWN	--	--	UNKWN	--	--	UNKWN	--	CAN COMM CIRCUIT [U1000]	--

Case 11  
Check IPDM E/R circuit.

SELECT SYSTEM screen	Initial diagnosis	Transfer diagnosis	CAN DIAG SUPPORT MNT'R								SELF-DIAG RESULTS		
			FCM	TCM	STRG	BCM /SEC	METER /MBA	AWD/4WD	VOC/CS /ABS	IPDM E/R			
ENGINE	--	--	UNKWN	--	UNKWN	--	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	CAN COMM CIRCUIT [U1001]
AIT	--	NG	UNKWN	UNKWN	--	--	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	--
BCM	No indication	NG	UNKWN	UNKWN	--	--	UNKWN	--	--	UNKWN	--	CAN COMM CIRCUIT [U1000]	--
METER	No indication	--	UNKWN	UNKWN	UNKWN	--	UNKWN	--	--	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	--
ALL MODE AWD/4WD	--	NG	UNKWN	UNKWN	UNKWN	--	UNKWN	--	--	UNKWN	--	CAN COMM CIRCUIT [U1000]	--
ABS	--	NG	UNKWN	UNKWN	UNKWN	UNKWN	--	--	UNKWN	--	--	CAN COMM CIRCUIT [U1000]	--
IPDM E/R	No indication	--	UNKWN	UNKWN	--	--	UNKWN	--	--	UNKWN	--	CAN COMM CIRCUIT [U1000]	--



PKIC5996E

**NOTE:**

There is a case that some of "CAN DIAG SUPPORT MNT'R" and "SELF-DIAG RESULTS" are not needed for diagnosis. In the case, "UNKWN" and "CAN COMM CIRCUIT [U1000]" in "Check sheet results (example)" change to "--". Then, ignore check marks on the check sheet table.

2. For the selected possible causes, it is expected that malfunctions have been found in the past.

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

UKS003L6

## CAN Diagnostic Support Monitor DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR ECM

(Example)	CAN DIAG SUPPORT MNTR	CAN DIAG SUPPORT MNTR																																																																													
	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="3">ENGINE</th></tr> <tr><td></td><th>PRSNT</th><th>PAST</th></tr> <tr><td>TRANSMIT DIAG</td><td>OK</td><td>OK</td></tr> <tr><td>VDC/TCS/ABS</td><td>OK</td><td>OK</td></tr> <tr><td>METER/M&amp;A</td><td>OK</td><td>OK</td></tr> <tr><td>BCM/SEC</td><td>OK</td><td>OK</td></tr> <tr><td>ICC</td><td>-</td><td>-</td></tr> <tr><td>HVAC</td><td>-</td><td>-</td></tr> <tr><td>TCM</td><td>OK</td><td>OK</td></tr> <tr><td>EPS</td><td>-</td><td>-</td></tr> <tr><td>IPDM E/R</td><td>OK</td><td>OK</td></tr> <tr><td colspan="2" style="text-align: center;">PRINT</td><td style="text-align: center;">Scroll Down</td></tr> <tr><td>MODE</td><td>BACK</td><td>LIGHT COPY</td></tr> </table>	ENGINE				PRSNT	PAST	TRANSMIT DIAG	OK	OK	VDC/TCS/ABS	OK	OK	METER/M&A	OK	OK	BCM/SEC	OK	OK	ICC	-	-	HVAC	-	-	TCM	OK	OK	EPS	-	-	IPDM E/R	OK	OK	PRINT		Scroll Down	MODE	BACK	LIGHT COPY	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="3">ENGINE</th></tr> <tr><td></td><th>PRSNT</th><th>PAST</th></tr> <tr><td>METER/M&amp;A</td><td>OK</td><td>OK</td></tr> <tr><td>BCM/SEC</td><td>OK</td><td>OK</td></tr> <tr><td>ICC</td><td>-</td><td>-</td></tr> <tr><td>HVAC</td><td>-</td><td>-</td></tr> <tr><td>TCM</td><td>OK</td><td>OK</td></tr> <tr><td>EPS</td><td>-</td><td>-</td></tr> <tr><td>IPDM E/R</td><td>OK</td><td>OK</td></tr> <tr><td>e4WD</td><td>-</td><td>-</td></tr> <tr><td>AWD/4WD</td><td>OK</td><td>OK</td></tr> <tr><td colspan="2" style="text-align: center;">PRINT</td><td style="text-align: center;">Scroll Up</td></tr> <tr><td>MODE</td><td>BACK</td><td>LIGHT COPY</td></tr> </table>	ENGINE				PRSNT	PAST	METER/M&A	OK	OK	BCM/SEC	OK	OK	ICC	-	-	HVAC	-	-	TCM	OK	OK	EPS	-	-	IPDM E/R	OK	OK	e4WD	-	-	AWD/4WD	OK	OK	PRINT		Scroll Up	MODE	BACK
ENGINE																																																																															
	PRSNT	PAST																																																																													
TRANSMIT DIAG	OK	OK																																																																													
VDC/TCS/ABS	OK	OK																																																																													
METER/M&A	OK	OK																																																																													
BCM/SEC	OK	OK																																																																													
ICC	-	-																																																																													
HVAC	-	-																																																																													
TCM	OK	OK																																																																													
EPS	-	-																																																																													
IPDM E/R	OK	OK																																																																													
PRINT		Scroll Down																																																																													
MODE	BACK	LIGHT COPY																																																																													
ENGINE																																																																															
	PRSNT	PAST																																																																													
METER/M&A	OK	OK																																																																													
BCM/SEC	OK	OK																																																																													
ICC	-	-																																																																													
HVAC	-	-																																																																													
TCM	OK	OK																																																																													
EPS	-	-																																																																													
IPDM E/R	OK	OK																																																																													
e4WD	-	-																																																																													
AWD/4WD	OK	OK																																																																													
PRINT		Scroll Up																																																																													
MODE	BACK	LIGHT COPY																																																																													

PKIC5987E

"SELECT SYSTEM" screen	"CAN DIAG SUPPORT MNTR" screen	Description	Present	Past
ENGINE	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN/-	OK/0/1 - 39/-
	VDC/TCS/ABS	Make sure of normal reception from ABS actuator and electric unit (control unit). (VDC model/ ABL S model)	OK/UNKWN/-	
		VDC/TCS/ABS is not diagnosed. (ABS model)	-	
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWN/-	
	BCM/SEC	Make sure of normal reception from BCM.	OK/UNKWN/-	
	ICC	ICC is not diagnosed.	-	
	HVAC	HVAC is not diagnosed.	-	
	TCM	Make sure of normal reception from TCM.	OK/UNKWN/-	
	EPS	EPS is not diagnosed.	-	
	IPDM E/R	Make sure of normal reception from IPDM E/R.	OK/UNKWN/-	
	e4WD	e4WD is not diagnosed.	-	
AWD/4WD	Make sure of normal reception from transfer control unit.	OK/UNKWN/-		

### Display Results (Present)

- OK: Normal
- UNKWN: The diagnosed unit does not transmit or receive the applicable data normally.
- -: There is no received unit or the unit is not in the condition that reception diagnosis is performed.

### Display Results (Past)

- OK: Normal
- 0: There is malfunction now.
- 1 - 39: Displays when it is normal at present and finds malfunction in the past. It increases like 0→1→2...38→39 after returning to the normal condition whenever IGN OFF→ON. If it is over 39, it is fixed to 39 until the self-diagnostic results are erased. It returns to 0 when malfunction is detected again in the process.
- -: Undiagnosed

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

## DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR TCM

(Example) CAN DIAG SUPPORT MNTR

A/T	
	PRSNT
INITIAL DIAG	OK
TRANSMIT DIAG	OK
ECM	OK
VDC/TCS/ABS	OK
METER/M&A	OK
ICC/e4WD	UNKWVN
AWD/4WD	OK
PRINT	
MODE	BACK LIGHT COPY

SKIB2335E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
A/T	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWVN
	ECM	Make sure of normal reception from ECM.	OK/UNKWVN
	VDC/TCS/ABS	Make sure of normal reception from ABS actuator and electric unit (control unit). (VDC model/ ABLS model)	OK/UNKWVN
		VDC/TCS/ABS is not diagnosed. (ABS model)	UNKWVN
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWVN
	ICC/e4WD	ICC/e4WD is not diagnosed.	UNKWVN
AWD/4WD	Make sure of normal reception from transfer control unit.	OK/UNKWVN	

### Display Results (Present)

- OK: Normal
- NG: Malfunction
- UNKWVN: The diagnosed unit does not transmit or receive the applicable data normally.

## DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR DIFFERENTIAL LOCK CONTROL UNIT

(Example) CAN DIAG SUPPORT MNTR

DIFF LOCK	
	PRSNT
INITIAL DIAG	OK
TRANSMIT DIAG	OK
ECM	OK
VDC/TCS/ABS	OK
AWD/4WD	OK
PRINT	
MODE	BACK LIGHT COPY

PKIB7196E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
DIFF LOCK	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWVN
	ECM	Make sure of normal reception from ECM.	OK/UNKWVN
	VDC/TCS/ABS	Make sure of normal reception from ABS actuator and electric unit (control unit).	OK/UNKWVN
	AWD/4WD	Make sure of normal reception from transfer control unit.	OK/UNKWVN

### Display Results (Present)

- OK: Normal
- NG: Malfunction
- UNKWVN: The diagnosed unit does not transmit or receive the applicable data normally.



# TROUBLE DIAGNOSES WORK FLOW

[CAN]

## DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR BCM

(Example)

CAN DIAG SUPPORT MNTR			
BCM			
		PRSNT	
INITIAL DIAG		OK	
TRANSMIT DIAG		OK	
ECM		OK	
IPDM E/R		OK	
METER/M&A		OK	
I-KEY		OK	
PRINT			
MODE	BACK	LIGHT	COPY

SKIB1625E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
BCM	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	ECM	Make sure of normal reception from ECM.	OK/UNKWN
	IPDM E/R	Make sure of normal reception from IPDM E/R.	OK/UNKWN
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWN
	I-KEY	I-KEY is not diagnosed.	OK

### Display Results (Present)

- OK: Normal
- NG: Malfunction
- UNKWN: The diagnosed unit does not transmit or receive the applicable data normally.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

## DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR METER

(Example)

CAN DIAG SUPPORT MNTR				CAN DIAG SUPPORT MNTR			
METER				METER			
	PRSNL	PAST			PRSNL	PAST	
TRANSMIT DIAG	OK	OK		IPDM E/R	OK	OK	
ECM	OK	OK		DISPLAY	-	-	
TCM	OK	OK		I-KEY	-	-	
BCM/SEC	OK	OK		EPS	-	-	
VDC/TCS/ABS	OK	OK		AWD/4WD	-	-	
IPDM E/R	OK	OK		e4WD	-	-	
DISPLAY	-	-		ICC	-	-	
I-KEY	-	-		LANE KEEP	-	-	
EPS	-	-		TIRE-P	-	-	
PRINT			Scroll Down	PRINT	Scroll Up		
MODE	BACK	LIGHT	COPY	MODE	BACK	LIGHT	COPY

PKIC6816E

"SELECT SYSTEM" screen	"CAN DIAG SUPPORT MNTR" screen	Description	Present	Past
METER	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN/-	OK/0/1 - 39/-
	ECM	Make sure of normal reception from ECM.	OK/UNKWN/-	
	TCM	Make sure of normal reception from TCM.	OK/UNKWN/-	
	BCM/SEC	Make sure of normal reception from BCM.	OK/UNKWN/-	
	VDC/TCS/ABS	Make sure of normal reception from ABS actuator and electric unit (control unit).	OK/UNKWN/-	
	IPDM E/R	Make sure of normal reception from IPDM E/R.	OK/UNKWN/-	
	DISPLAY	DISPLAY is not diagnosed.	-	
	I-KEY	I-KEY is not diagnosed.	-	
	EPS	EPS is not diagnosed.	-	
	AWD/4WD	AWD/4WD is not diagnosed.	-	
	e4WD	e4WD is not diagnosed.	-	
	ICC	ICC is not diagnosed.	-	
	LANE KEEP	LANE KEEP is not diagnosed.	-	
TIRE-P	TIRE-P is not diagnosed.	-		

### Display Results (Present)

- OK: Normal
- UNKWN: The diagnosed unit does not transmit or receive the applicable data normally.
- -: There is no received unit or the unit is not in the condition that reception diagnosis is performed.

### Display Results (Past)

- OK: Normal
- 0: There is malfunction now.
- 1 - 39: Displays when it finds malfunction in the past even if it is normal or there is a malfunction at present. Also, displays when diagnosis is not performed. It increase like 0→1→2...38→39 after returning to the normal condition whenever IGN OFF→ON. If it is over 39, it is fixed to 39 until the self-diagnostic results are erased. Keep this condition until resetting it.
- -: Undiagnosed

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

## DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR TRANSFER CONTROL UNIT

(Example)

CAN DIAG SUPPORT MNTR			
ALL MODE AWD/4WD			
			PRSENT
INITIAL DIAG	OK		
TRANSMIT DIAG	OK		
ECM	OK		
VDC/TCS/ABS	OK		
TCM	OK		
METER/M&A	OK		
PRINT			
MODE	BACK	LIGHT	COPY

PKIC2594E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
ALL MODE AWD/ 4WD	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	ECM	Make sure of normal reception from ECM.	OK/UNKWN
	VDC/TCS/ABS	Make sure of normal reception from ABS actuator and electric unit (control unit).	OK/UNKWN
	TCM	Make sure of normal reception from TCM.	OK/UNKWN
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWN

### Display Results (Present)

- OK: Normal
- NG: Malfunction
- UNKWN: The diagnosed unit does not transmit or receive the applicable data normally.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

## DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

### ABS model

(Example) CAN DIAG SUPPORT MNTR

ABS	
	PRSNT
INITIAL DIAG	OK
TRANSMIT DIAG	OK
ECM	OK
PRINT	
MODE	BACK LIGHT COPY

PKIA8949E

"SELECT SYSTEM" screen	"CAN DIAG SUPPORT MNTR" screen	Description	Present
ABS	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	ECM	Make sure of normal reception from ECM.	OK/UNKWN

### Display Results (Present)

- OK: Normal
- NG: Malfunction
- UNKWN: The diagnosed unit does not transmit or receive the applicable data normally.

### VDC model/ABLS model

(Example) CAN DIAG SUPPORT MNTR

ABS	
	PRSNT
INITIAL DIAG	OK
TRANSMIT DIAG	OK
ECM	OK
TCM	OK
METER/M&A	UNKWN
STRG	OK
ICC	UNKWN
AWD/4WD	OK
DIFF LOCK	OK
PRINT	
MODE	BACK LIGHT COPY

PKIB7433E

"SELECT SYSTEM" screen	"CAN DIAG SUPPORT MNTR" screen	Description	Present	
ABS	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG	
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN	
	ECM	Make sure of normal reception from ECM.	OK/UNKWN	
	TCM	Make sure of normal reception from TCM.	OK/UNKWN	
	METER/M&A	METER/M&A is not diagnosed.	UNKWN	
	STRG	STRG	Make sure of normal reception from steering angle sensor. (VDC model)	OK/UNKWN
			STRG is not diagnosed. (ABLS model)	UNKWN
	ICC	ICC is not diagnosed.	UNKWN	
	AWD/4WD	Make sure of normal reception from transfer control unit.	OK/UNKWN	
DIFF LOCK	Make sure of normal reception from differential lock control unit.	OK/UNKWN		

### Display Results (Present)

- OK: Normal
- NG: Malfunction
- UNKWN: The diagnosed unit does not transmit or receive the applicable data normally.

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

## DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR IPDM E/R

(Example)

CAN DIAG SUPPORT MNTR			
IPDM E/R			
	PRSNL	PAST	
TRANSMIT DIAG	OK	OK	OK
ECM	OK	OK	OK
BCM/SEC	OK	OK	OK
PRINT			
MODE	BACK	LIGHT	COPY

SKIB0595E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present	Past
IPDM E/R	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN/-	OK/0/1 - 39/-
	ECM	Make sure of normal reception from ECM.	OK/UNKWN/-	
	BCM/SEC	Make sure of normal reception from BCM.	OK/UNKWN/-	

### Display Results (Present)

- OK: Normal
- UNKWN: The diagnosed unit does not transmit or receive the applicable data normally.
- -: There is no received unit or the unit is not in the condition that reception diagnosis is performed.

### Display Results (Past)

- OK: Normal
- 0: There is malfunction now.
- 1 - 39: Displays when it is normal at present and finds malfunction in the past. It increases like 0→1→2...38→39 after returning to the normal condition whenever IGN OFF→ON. If it is over 39, it is fixed to 39 until the self-diagnostic results are erased. It returns to 0 when malfunction is detected again in the process.
- -: Undiagnosed

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

## CAN COMMUNICATION

PFP:23710


### System Description

UKS0030X

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### Component Parts and Harness Connector Location

UKS0052Z



BKIA0200E

- |   |   |  |
|---|---|--|
| 1. IPDM E/R E122  | 2. ECM E16  | 3. Combination meter M24                           |
| 4. BCM M18  | 5. ABS actuator and electric unit (control unit) E125 | 6. Transfer control unit M152 (with 4-wheel drive) |
| 7. Differential lock control unit M70 (with electronic locking rear differential) | 8. Data link connector M22                            | 9. Steering angle sensor M47 (with VDC)            |
| 10. Air bag diagnosis sensor unit M35   | 11. A/T assembly F9 (with A/T)                        |  |

# CAN COMMUNICATION


[CAN]

## Schematic

UKS00530

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

- 4W : WITH 4-WHEEL DRIVE
- A : WITH A/T
- DL : WITH ELECTRONIC LOCKING REAR DIFFERENTIAL
- VW : WITH VDC






LAN

BKWA0667E

## Wiring Diagram — CAN —

### LAN-CAN-01

- ▬ : DATA LINE
- ⬡ : WITH A/T
- ⬢ : WITH M/T




REFER TO THE FOLLOWING.  
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)




# CAN COMMUNICATION

[CAN]

LAN-CAN-02





A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M



BKWA0669E

## LAN-CAN-03



BKWA0670E

## CAN Communication Unit

Go to CAN system, when selecting your CAN system type from the following table.


Body type	Truck																
Axle	2WD							4WD									
Engine	QR25DE				VQ40DE												
Transmission	M/T	A/T	M/T				A/T				M/T				A/T		
Brake control	ABS		ABS	ABLS	ABS	ABLS	ABS	ABLS	ABS	ABLS	ABS	ABLS	VDC				
Electronic locking rear differential							×			×			×		×		
CAN system type	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15		
CAN system trouble diagnosis	<a href="#">LAN-47</a>	<a href="#">LAN-58</a>	<a href="#">LAN-71</a>	<a href="#">LAN-82</a>	<a href="#">LAN-93</a>	<a href="#">LAN-106</a>	<a href="#">LAN-119</a>	<a href="#">LAN-133</a>	<a href="#">LAN-145</a>	<a href="#">LAN-157</a>	<a href="#">LAN-170</a>	<a href="#">LAN-184</a>	<a href="#">LAN-198</a>	<a href="#">LAN-213</a>	<a href="#">LAN-228</a>		

×: Applicable


**NOTE:**

Confirming the presence of the following items helps to identify CAN system type.


- Models with 4WD



- Models with VDC




- Models with ABLS



# CAN COMMUNICATION


[CAN]

- Models with electronic locking rear differential




## TYPE 1/TYPER 3 System diagram

- Type 1



- Type 3



## Input/output signal chart

T: Transmit R: Receive

Signals	ECM	BCM	Combination meter	ABS actuator and electric unit (control unit)	IPDM E/R
A/C compressor request signal	T				R
Accelerator pedal position signal	T				

# CAN COMMUNICATION

[CAN]

Signals	ECM	BCM	Combination meter	ABS actuator and electric unit (control unit)	IPDM E/R	A
ASCD CRUISE lamp signal	T		R			A
ASCD SET lamp signal	T		R			B
Cooling fan speed request signal*	T				R	
Engine coolant temperature signal	T		R			C
Engine speed signal	T		R			
Engine status signal	T	R				
Fuel consumption monitor signal	T		R			D
Malfunction indicator lamp signal	T		R			
Power generation command value signal	T				R	E
A/C switch signal	R	T				
Blower fan motor switch signal	R	T				F
Buzzer output signal		T	R			
Day time running light request signal		T	R		R	
Door switch signal		T	R		R	G
Front fog light request signal		T	R		R	
Front wiper request signal		T			R	
High beam request signal		T	R		R	H
Horn chirp signal		T			R	
Ignition switch signal		T			R	I
Low beam request signal		T			R	
Position light request signal		T	R		R	
Rear window defogger switch signal		T			R	J
Sleep wake up signal		T	R		R	
Theft warning horn request signal		T			R	LAN
Turn indicator signal		T	R			
Fuel level sensor signal	R		T			
Seat belt buckle switch signal		R	T			L
Vehicle speed signal	R	R	T	T		
ABS warning lamp signal			R	T		M
Brake warning lamp signal			R	T		
Front wiper stop position signal		R			T	
High beam status signal	R				T	
Low beam status signal	R				T	
Rear window defogger control signal*	R				T	

\*: VQ engine models only.


**NOTE:**

CAN data of the air bag diagnosis sensor unit is not used by usual service work, thus it is omitted.


## TYPE 2/TYPE 5

### System diagram

- Type 2



- Type 5



### Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	BCM	Combination meter	ABS actuator and electric unit (control unit)	IPDM E/R
A/C compressor request signal	T					R
Accelerator pedal position signal	T	R				
ASCD CRUISE lamp signal	T			R		
ASCD OD cancel request	T	R				
ASCD operation signal	T	R				
ASCD SET lamp signal	T			R		
Battery voltage signal	T	R				
Closed throttle position signal	T	R				
Cooling fan speed request signal	T					R
Engine coolant temperature signal	T			R		

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	BCM	Combination meter	ABS actuator and electric unit (control unit)	IPDM E/R	A
Engine speed signal	T	R		R			B
Engine status signal	T		R				C
Fuel consumption monitor signal	T			R			D
Malfunction indicator lamp signal	T			R			E
Power generation command value signal	T					R	F
Wide open throttle position signal	T	R					G
A/T fluid temperature sensor signal		T		R			H
A/T position indicator lamp signal		T		R			I
A/T self-diagnosis signal	R	T					J
O/D OFF indicator signal		T		R			K
Output shaft revolution signal	R	T					L
Turbine revolution signal	R	T					M
A/C switch signal	R		T				N
Blower fan motor switch signal	R		T				O
Buzzer output signal			T	R			P
Day time running light request signal			T	R		R	Q
Door switch signal			T	R		R	R
Front fog light request signal			T	R		R	S
Front wiper request signal			T			R	T
High beam request signal			T	R		R	U
Horn chirp signal			T			R	V
Ignition switch signal			T			R	W
Low beam request signal			T			R	X
Position light request signal			T	R		R	Y
Rear window defogger switch signal			T			R	Z
Sleep wake up signal			T	R		R	AA
Theft warning horn request signal			T			R	AB
Turn indicator signal			T	R			AC
1st position switch signal		R		T			AD
Fuel level sensor signal	R			T			AE
Overdrive control switch signal		R		T			AF
Seat belt buckle switch signal			R	T			AG
Stop lamp switch signal		R		T			AH
Vehicle speed signal	R	R	R	T	T		AI
ABS warning lamp signal				R	T		AJ
Brake warning lamp signal				R	T		AK
Front wiper stop position signal			R			T	AL
High beam status signal	R					T	AM
Low beam status signal	R					T	AN
Rear window defogger control signal*	R					T	AO

\*: VQ engine models only.


**NOTE:**

CAN data of the air bag diagnosis sensor unit is not used by usual service work, thus it is omitted.

**TYPE 4**

**System diagram**

- Type 4



**Input/output signal chart**

T: Transmit R: Receive

Signals	ECM	BCM	Combination meter	ABS actuator and electric unit (control unit)	IPDM E/R
A/C compressor request signal	T				R
Accelerator pedal position signal	T			R	
ASCD CRUISE lamp signal	T		R		
ASCD SET lamp signal	T		R		
Cooling fan speed request signal	T				R
Engine coolant temperature signal	T		R		
Engine speed signal	T		R	R	
Engine status signal	T	R			
Fuel consumption monitor signal	T		R		
Malfunction indicator lamp signal	T		R		
Power generation command value signal	T				R
A/C switch signal	R	T			
Blower fan motor switch signal	R	T			
Buzzer output signal		T	R		
Day time running light request signal		T	R		R
Door switch signal		T	R		R
Front fog light request signal		T	R		R
Front wiper request signal		T			R
High beam request signal		T	R		R
Horn chirp signal		T			R
Ignition switch signal		T			R
Low beam request signal		T			R



# CAN COMMUNICATION

[CAN]

Signals	ECM	BCM	Combination meter	ABS actuator and electric unit (control unit)	IPDM E/R
Position light request signal		T	R		R
Rear window defogger switch signal		T			R
Sleep wake up signal		T	R		R
Theft warning horn request signal		T			R
Turn indicator signal		T	R		
Fuel level sensor signal	R		T		
Seat belt buckle switch signal		R	T		
Vehicle speed signal			R	T	
	R	R	T		
ABS warning lamp signal			R	T	
Brake warning lamp signal			R	T	
SLIP indicator lamp signal			R	T	
Front wiper stop position signal		R			T
High beam status signal	R				T
Low beam status signal	R				T
Rear window defogger control signal	R				T


**NOTE:**

CAN data of the air bag diagnosis sensor unit is not used by usual service work, thus it is omitted.

**TYPE 6/TYPE 7**

**System diagram**


- Type 6



# CAN COMMUNICATION

[CAN]

● Type 7



## Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Differential lock control unit*	BCM	Combina-tion meter	ABS actua-tor and electric unit (control unit)	IPDM E/R
A/C compressor request signal	T						R
Accelerator pedal position signal	T	R				R	
ASCD CRUISE lamp signal	T				R		
ASCD OD cancel request	T	R					
ASCD operation signal	T	R					
ASCD SET lamp signal	T				R		
Battery voltage signal	T	R					
Closed throttle position signal	T	R					
Cooling fan speed request signal	T						R
Engine coolant temperature signal	T				R		
Engine speed signal	T	R			R	R	
Engine status signal	T			R			
Fuel consumption monitor signal	T				R		
Malfunction indicator lamp signal	T				R		
Power generation command value signal	T						R
Wide open throttle position signal	T	R					
A/T fluid temperature sensor signal		T			R		
A/T position indicator lamp signal		T			R	R	
A/T self-diagnosis signal	R	T					
O/D OFF indicator signal		T			R		
Output shaft revolution signal	R	T					
Turbine revolution signal	R	T					
Differential lock indicator signal			T			R	
Differential lock switch signal			T			R	
A/C switch signal	R			T			

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Differential lock control unit*	BCM	Combina-tion meter	ABS actua-tor and electric unit (control unit)	IPDM E/R	A
Blower fan motor switch signal	R			T				B
Buzzer output signal				T	R			C
Day time running light request signal				T	R		R	D
Door switch signal				T	R		R	E
Front fog light request signal				T	R		R	F
Front wiper request signal				T			R	G
High beam request signal				T	R		R	H
Horn chirp signal				T			R	I
Ignition switch signal				T			R	J
Low beam request signal				T			R	K
Position light request signal				T	R		R	L
Rear window defogger switch signal				T			R	M
Sleep wake up signal				T	R		R	
Theft warning horn request signal				T			R	
Turn indicator signal				T	R			
1st position switch signal		R			T			
Fuel level sensor signal	R				T			
Overdrive control switch signal		R			T			
Seat belt buckle switch signal				R	T			
Stop lamp switch signal		R			T			
Vehicle speed signal			R		R	T		
	R	R		R	T			
ABS warning lamp signal					R	T		LAN
Brake warning lamp signal					R	T		
SLIP indicator lamp signal					R	T		
Front wiper stop position signal				R			T	L
High beam status signal	R						T	
Low beam status signal	R						T	
Rear window defogger control signal	R						T	M

\*: with electronic locking rear differential model only.


**NOTE:**

CAN data of the air bag diagnosis sensor unit is not used by usual service work, thus it is omitted.

## TYPE 8

### System diagram

- Type 8



### Input/output signal chart

T: Transmit R: Receive

Signals	ECM	BCM	Combination meter	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
A/C compressor request signal	T					R
Accelerator pedal position signal	T					
ASCD CRUISE lamp signal	T		R			
ASCD SET lamp signal	T		R			
Cooling fan speed request signal	T					R
Engine coolant temperature signal	T		R			
Engine speed signal	T		R	R		
Engine status signal	T	R				
Fuel consumption monitor signal	T		R			
Malfunction indicator lamp signal	T		R			
Power generation command value signal	T					R
A/C switch signal	R	T				
Blower fan motor switch signal	R	T				
Buzzer output signal		T	R			
Day time running light request signal		T	R			R
Door switch signal		T	R			R
Front fog light request signal		T	R			R
Front wiper request signal		T				R
High beam request signal		T	R			R
Horn chirp signal		T				R
Ignition switch signal		T				R
Low beam request signal		T				R
Position light request signal		T	R			R
Rear window defogger switch signal		T				R

# CAN COMMUNICATION

[CAN]

Signals	ECM	BCM	Combination meter	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Sleep wake up signal		T	R			R
Theft warning horn request signal		T				R
Turn indicator signal		T	R			
Fuel level sensor signal	R		T			
Seat belt buckle switch signal		R	T			
Vehicle speed signal			R	R	T	
	R	R	T			
ABS warning lamp signal			R		T	
Brake warning lamp signal			R		T	
Stop lamp switch signal				R	T	
Front wiper stop position signal		R				T
High beam status signal	R					T
Low beam status signal	R					T
Rear window defogger control signal	R					T


**NOTE:**

CAN data of the air bag diagnosis sensor unit is not used by usual service work, thus it is omitted.

**TYPE 9/TYPER 10**

**System diagram**


- Type 9



# CAN COMMUNICATION

[CAN]

● Type 10



## Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Differential lock control unit*	BCM	Combina-tion meter	Transfer control unit	ABS actua-tor and electric unit (control unit)	IPDM E/R
A/C compressor request signal	T						R
Accelerator pedal position signal	T					R	
ASCD CRUISE lamp signal	T			R			
ASCD SET lamp signal	T			R			
Cooling fan speed request signal	T						R
Engine coolant temperature signal	T			R			
Engine speed signal	T			R	R	R	
Engine status signal	T		R				
Fuel consumption monitor signal	T			R			
Malfunction indicator lamp signal	T			R			
Power generation command value signal	T						R
Differential lock indicator signal		T				R	
Differential lock switch signal		T				R	
A/C switch signal	R		T				
Blower fan motor switch signal	R		T				
Buzzer output signal			T	R			
Day time running light request signal			T	R			R
Door switch signal			T	R			R
Front fog light request signal			T	R			R
Front wiper request signal			T				R
High beam request signal			T	R			R
Horn chirp signal			T				R
Ignition switch signal			T				R
Low beam request signal			T				R
Position light request signal			T	R			R

# CAN COMMUNICATION

[CAN]

Signals	ECM	Differential lock control unit*	BCM	Combina- tion meter	Transfer control unit	ABS actua- tor and electric unit (control unit)	IPDM E/R
Rear window defogger switch signal			T				R
Sleep wake up signal			T	R			R
Theft warning horn request signal			T				R
Turn indicator signal			T	R			
Fuel level sensor signal	R			T			
Seat belt buckle switch signal			R	T			
Vehicle speed signal		R		R	R	T	
	R		R	T			
4WD shift switch signal		R			T		
ABS warning lamp signal				R		T	
Brake warning lamp signal				R		T	
SLIP indicator lamp signal				R		T	
Stop lamp switch signal					R	T	
Front wiper stop position signal			R				T
High beam status signal	R						T
Low beam status signal	R						T
Rear window defogger control signal	R						T

\*: with electronic locking rear differential model only.


**NOTE:**

CAN data of the air bag diagnosis sensor unit is not used by usual service work, thus it is omitted.

**TYPE 11**

**System diagram**

- Type 11



# CAN COMMUNICATION

[CAN]

## Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	BCM	Combina- tion meter	Transfer control unit	ABS actua- tor and electric unit (control unit)	IPDM E/R
A/C compressor request signal	T						R
Accelerator pedal position signal	T	R					
ASCD CRUISE lamp signal	T			R			
ASCD OD cancel request	T	R					
ASCD operation signal	T	R					
ASCD SET lamp signal	T			R			
Battery voltage signal	T	R					
Closed throttle position signal	T	R					
Cooling fan speed request signal	T						R
Engine coolant temperature signal	T			R			
Engine speed signal	T	R		R	R		
Engine status signal	T		R				
Fuel consumption monitor signal	T			R			
Malfunction indicator lamp signal	T			R			
Power generation command value signal	T						R
Wide open throttle position signal	T	R					
A/T fluid temperature sensor signal		T		R			
A/T position indicator lamp signal		T		R	R		
A/T self-diagnosis signal	R	T					
O/D OFF indicator signal		T		R			
Output shaft revolution signal	R	T			R		
Turbine revolution signal	R	T					
A/C switch signal	R		T				
Blower fan motor switch signal	R		T				
Buzzer output signal			T	R			
Day time running light request signal			T	R			R
Door switch signal			T	R			R
Front fog light request signal			T	R			R
Front wiper request signal			T				R
High beam request signal			T	R			R
Horn chirp signal			T				R
Ignition switch signal			T				R
Low beam request signal			T				R
Position light request signal			T	R			R
Rear window defogger switch signal			T				R
Sleep wake up signal			T	R			R
Theft warning horn request signal			T				R
Turn indicator signal			T	R			
1st position switch signal		R		T			



# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	BCM	Combina- tion meter	Transfer control unit	ABS actua- tor and electric unit (control unit)	IPDM E/R
Fuel level sensor signal	R			T			
Overdrive control switch signal		R		T			
Seat belt buckle switch signal			R	T			
Stop lamp switch signal		R		T			
					R	T	
Vehicle speed signal				R	R	T	
	R	R	R	T			
ABS warning lamp signal				R		T	
Brake warning lamp signal				R		T	
Front wiper stop position signal			R				T
High beam status signal	R						T
Low beam status signal	R						T
Rear window defogger control signal	R						T


**NOTE:**

CAN data of the air bag diagnosis sensor unit is not used by usual service work, thus it is omitted.

**TYPE 12/TYPER 13**

**System diagram**


- Type 12



# CAN COMMUNICATION

[CAN]

● Type 13



PKIC4995E

## Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Differential lock control unit*	BCM	Combination meter	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
A/C compressor request signal	T							R
Accelerator pedal position signal	T	R					R	
ASCD CRUISE lamp signal	T				R			
ASCD OD cancel request	T	R						
ASCD operation signal	T	R						
ASCD SET lamp signal	T				R			
Battery voltage signal	T	R						
Closed throttle position signal	T	R						
Cooling fan speed request signal	T							R
Engine coolant temperature signal	T				R			
Engine speed signal	T	R			R	R	R	
Engine status signal	T			R				
Fuel consumption monitor signal	T				R			
Malfunction indicator lamp signal	T				R			
Power generation command value signal	T							R
Wide open throttle position signal	T	R						
A/T fluid temperature sensor signal		T			R			
A/T position indicator lamp signal		T			R	R		
A/T self-diagnosis signal	R	T						
O/D OFF indicator signal		T			R			
Output shaft revolution signal	R	T				R		
Turbine revolution signal	R	T						
Differential lock indicator signal			T				R	
Differential lock switch signal			T				R	

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Differential lock control unit*	BCM	Combination meter	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R	A B C D E F G H I J L M
A/C switch signal	R			T					
Blower fan motor switch signal	R			T					
Buzzer output signal				T	R				
Day time running light request signal				T	R			R	
Door switch signal				T	R			R	
Front fog light request signal				T	R			R	
Front wiper request signal				T				R	
High beam request signal				T	R			R	
Horn chirp signal				T				R	
Ignition switch signal				T				R	
Low beam request signal				T				R	
Position light request signal				T	R			R	
Rear window defogger switch signal				T				R	
Sleep wake up signal				T	R			R	
Theft warning horn request signal				T				R	
Turn indicator signal				T	R				
1st position switch signal		R			T				
Fuel level sensor signal	R				T				
Overdrive control switch signal		R			T				
Seat belt buckle switch signal				R	T				
Stop lamp switch signal		R			T				
						R	T		
Vehicle speed signal			R		R	R	T		LAN
		R	R	R	T				
4WD shift switch signal			R			T			
ABS warning lamp signal					R		T		
Brake warning lamp signal					R		T		
SLIP indicator lamp signal					R		T		
Front wiper stop position signal				R				T	
High beam status signal	R							T	
Low beam status signal	R							T	
Rear window defogger control signal	R							T	

\*: with electronic locking rear differential model only.


**NOTE:**

CAN data of the air bag diagnosis sensor unit is not used by usual service work, thus it is omitted.


## TYPE 14/TYPE 15

### System diagram

- Type 14



- Type 15



### Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Differential lock control unit*	Steering angle sensor	BCM	Combination meter	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
A/C compressor request signal	T								R
Accelerator pedal position signal	T	R						R	
ASCD CRUISE lamp signal	T					R			
ASCD OD cancel request	T	R							
ASCD operation signal	T	R							
ASCD SET lamp signal	T					R			
Battery voltage signal	T	R							
Closed throttle position signal	T	R							

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Differential lock control unit*	Steering angle sensor	BCM	Combination meter	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Cooling fan speed request signal	T								R
Engine coolant temperature signal	T					R			
Engine speed signal	T	R				R	R	R	
Engine status signal	T				R				
Fuel consumption monitor signal	T					R			
Malfunction indicator lamp signal	T					R			
Power generation command value signal	T								R
Wide open throttle position signal	T	R							
A/T fluid temperature sensor signal		T				R			
A/T position indicator lamp signal		T				R	R	R	
A/T self-diagnosis signal	R	T							
O/D OFF indicator signal		T				R			
Output shaft revolution signal	R	T					R		
Turbine revolution signal	R	T							
Differential lock indicator signal			T					R	
Differential lock switch signal			T					R	
Steering angle sensor signal				T				R	
A/C switch signal	R				T				
Blower fan motor switch signal	R				T				
Buzzer output signal					T	R			
Day time running light request signal					T	R			R
Door switch signal					T	R			R
Front fog light request signal					T	R			R
Front wiper request signal					T				R
High beam request signal					T	R			R
Horn chirp signal					T				R
Ignition switch signal					T				R
Low beam request signal					T				R
Position light request signal					T	R			R
Rear window defogger switch signal					T				R
Sleep wake up signal					T	R			R
Theft warning horn request signal					T				R
Turn indicator signal					T	R			
1st position switch signal		R				T			
Fuel level sensor signal	R					T			
Overdrive control switch signal		R				T			
Seat belt buckle switch signal					R	T			
Stop lamp switch signal		R				T			
							R	T	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Differ- ential lock control unit*	Steer- ing angle sensor	BCM	Combi- nation meter	Trans- fer con- trol unit	ABS actua- tor and electric unit (control unit)	IPDM E/ R
Vehicle speed signal			R			R	R	T	
	R	R			R	T			
4WD shift switch signal			R				T		
ABS warning lamp signal						R		T	
Brake warning lamp signal						R		T	
HDC indicator lamp signal						R		T	
SLIP indicator lamp signal						R		T	
VDC OFF indicator lamp signal						R		T	
Front wiper stop position signal					R				T
High beam status signal	R								T
Low beam status signal	R								T
Rear window defogger control signal	R								T

\*: with electronic locking rear differential model only.

**NOTE:**

CAN data of the air bag diagnosis sensor unit is not used by usual service work, thus it is omitted.

# CAN SYSTEM (TYPE 1)

[CAN]

---

## CAN SYSTEM (TYPE 1)

PF2:23710

### Component Parts and Harness Connector Location

UKS0054M

A

Refer to [LAN-22, "Component Parts and Harness Connector Location"](#) .

### Schematic

UKS0054N

B

Refer to [LAN-23, "Schematic"](#) .

### Wiring Diagram — CAN —

UKS0054O

C

Refer to [LAN-24, "Wiring Diagram — CAN —"](#) .

D

E

F

G

H

I

J

LAN

L

M

# CAN SYSTEM (TYPE 1)

[CAN]

UKS0054P

## Check Sheet

### NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

PKIC5742E



# CAN SYSTEM (TYPE 1)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS	Attach copy of METER SELF-DIAG RESULTS
Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS	
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR	Attach copy of METER CAN DIAG SUPPORT MNTR
Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

PKIC7068E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-245, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5743E



PKIC5501E

# CAN SYSTEM (TYPE 1)


[CAN]

## Case 2

Check ECM circuit. Refer to [LAN-246, "ECM Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN ✓	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIC5744E




PKIC5502E

## Case 3

Check data link connector circuit. Refer to [LAN-248, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5745E



PKIC5503E

# CAN SYSTEM (TYPE 1)


[CAN]

## Case 4

Check BCM circuit. Refer to [LAN-249, "BCM Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN ✓	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN ✓	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN ✓	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIC5746E




PKIC5504E

## Case 5

Check combination meter circuit. Refer to [LAN-249, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN ✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5747E




PKIC5505E

## Case 6

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-250, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKW N	—	UNKW N	UNKW N	—	UNKW N	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKW N	UNKW N	—	UNKW N	—	UNKW N	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKW N	UNKW N	UNKW N	—	UNKW N	UNKW N	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW N	UNKW N	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW N	UNKW N	UNKW N	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5748E



# CAN SYSTEM (TYPE 1)


[CAN]

## Case 7

Check IPDM E/R circuit. Refer to [LAN-251, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	—	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN ✓	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN ✓	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5749E



## Case 8

Check CAN communication circuit. Refer to [LAN-251, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG ✓	UNKWN ✓	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5750E



# CAN SYSTEM (TYPE 1)

[CAN]

## Case 9

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5751E

## Case 10

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5752E

---

## CAN SYSTEM (TYPE 2)

PF2P:23710

### Component Parts and Harness Connector Location

UKS0054Q

Refer to [LAN-22, "Component Parts and Harness Connector Location"](#) .

### Schematic

UKS0054R

Refer to [LAN-23, "Schematic"](#) .

### Wiring Diagram — CAN —

UKS0054S

Refer to [LAN-24, "Wiring Diagram — CAN —"](#) .

# CAN SYSTEM (TYPE 2)

[CAN]

UKS0054T

## Check Sheet

**NOTE:**

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
AT	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

PKIC5765E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 2)

[CAN]

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
METER  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
METER  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIC7064E

# CAN SYSTEM (TYPE 2)

[CAN]

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-244, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	✓	✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	✓	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	✓	✓	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	✓	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	✓	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIC5766E



PKIC5516E

# CAN SYSTEM (TYPE 2)


[CAN]

## Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to LAN-245, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit" .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5767E



PKIC5517E

# CAN SYSTEM (TYPE 2)


[CAN]

## Case 3

Check ECM circuit. Refer to [LAN-246, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5768E



PKIC5518E

# CAN SYSTEM (TYPE 2)


[CAN]

## Case 4

Check TCM circuit. Refer to [LAN-247, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5769E



PKIC5519E



# CAN SYSTEM (TYPE 2)


[CAN]

## Case 5

Check data link connector circuit. Refer to [LAN-248, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
AT	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5770E



PKIC5520E

# CAN SYSTEM (TYPE 2)


[CAN]

## Case 6

Check BCM circuit. Refer to [LAN-249, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5771E




PKIC5521E

## Case 7

Check combination meter circuit. Refer to [LAN-249, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
AT	—	NG	UNKWN	UNKWN	—	—	UNKWN ✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN ✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5772E




PKIC5522E

## Case 8

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-250, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	✓	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC573E




PKIC5523E

## Case 9

Check IPDM E/R circuit. Refer to [LAN-251, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
AT	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5774E



## Case 10

Check CAN communication circuit. Refer to [LAN-251, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
AT	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5775E

# CAN SYSTEM (TYPE 2)

[CAN]

## Case 11

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5776E

## Case 12

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5777E

# CAN SYSTEM (TYPE 3)

[CAN]

---

## CAN SYSTEM (TYPE 3)

PF2:23710

### Component Parts and Harness Connector Location

UKS0054U

A

Refer to [LAN-22, "Component Parts and Harness Connector Location"](#) .

### Schematic

UKS0054V

B

Refer to [LAN-23, "Schematic"](#) .

### Wiring Diagram — CAN —

UKS0054W

C

Refer to [LAN-24, "Wiring Diagram — CAN —"](#) .

D

E

F

G

H

I

J

LAN

L

M

# CAN SYSTEM (TYPE 3)

[CAN]

UKS0054X

## Check Sheet

### NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

PKIC5742E



# CAN SYSTEM (TYPE 3)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS	Attach copy of METER SELF-DIAG RESULTS
Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS	
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR	Attach copy of METER CAN DIAG SUPPORT MNTR
Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

PKIC7068E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-245, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5743E



PKIC5501E

# CAN SYSTEM (TYPE 3)


[CAN]

## Case 2

Check ECM circuit. Refer to [LAN-246, "ECM Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN ✓	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIC5744E




PKIC5502E

## Case 3

Check data link connector circuit. Refer to [LAN-248, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5745E



PKIC5503E

# CAN SYSTEM (TYPE 3)


[CAN]

## Case 4

Check BCM circuit. Refer to [LAN-249, "BCM Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN ✓	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN ✓	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN ✓	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIC5746E




## Case 5

Check combination meter circuit. Refer to [LAN-249, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN ✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5747E




PKIC5505E

## Case 6

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-250, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5748E



PKIC5506E

# CAN SYSTEM (TYPE 3)


[CAN]

## Case 7

Check IPDM E/R circuit. Refer to [LAN-251, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	—	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN ✓	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN ✓	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5749E



## Case 8

Check CAN communication circuit. Refer to [LAN-251, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG ✓	UNKWN ✓	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5750E



# CAN SYSTEM (TYPE 3)

[CAN]

## Case 9

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5751E

## Case 10

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5752E

---

## CAN SYSTEM (TYPE 4)

PFP:23710

### Component Parts and Harness Connector Location

UKS0054Y

Refer to [LAN-22, "Component Parts and Harness Connector Location"](#) .

### Schematic

UKS0054Z

Refer to [LAN-23, "Schematic"](#) .

### Wiring Diagram — CAN —

UKS00550

Refer to [LAN-24, "Wiring Diagram — CAN —"](#) .

# CAN SYSTEM (TYPE 4)

[CAN]

UKS00551

## Check Sheet

**NOTE:**

If a check mark is put on “NG” on “INITIAL DIAG (Initial diagnosis)”, replace the control unit.

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

PKIC5873E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 4)

[CAN]

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
METER  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
METER  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIC7068E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-245, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN ✓	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5874E



# CAN SYSTEM (TYPE 4)


[CAN]

## Case 2

Check ECM circuit. Refer to [LAN-246, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5875E



# CAN SYSTEM (TYPE 4)


[CAN]

## Case 3

Check data link connector circuit. Refer to [LAN-248, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5876E



# CAN SYSTEM (TYPE 4)


[CAN]

## Case 4

Check BCM circuit. Refer to [LAN-249, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN ✓	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN ✓	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5877E





# CAN SYSTEM (TYPE 4)


[CAN]

## Case 5

Check combination meter circuit. Refer to [LAN-249, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5878E



# CAN SYSTEM (TYPE 4)


[CAN]

## Case 6

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-250, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	✓	UNKWN ✓	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5879E



PKIC5506E

# CAN SYSTEM (TYPE 4)


[CAN]

## Case 7

Check IPDM E/R circuit. Refer to [LAN-251, "IPDM E/R Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5880E



## Case 8

Check CAN communication circuit. Refer to [LAN-251, "CAN Communication Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5881E

# CAN SYSTEM (TYPE 4)

[CAN]

## Case 9

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5882E

## Case 10

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5883E

# CAN SYSTEM (TYPE 5)

[CAN]

---

## CAN SYSTEM (TYPE 5)

PF2:23710

### Component Parts and Harness Connector Location

UKS00552

A

Refer to [LAN-22, "Component Parts and Harness Connector Location"](#) .

### Schematic

UKS00553

B

Refer to [LAN-23, "Schematic"](#) .

### Wiring Diagram — CAN —

UKS00554

C

Refer to [LAN-24, "Wiring Diagram — CAN —"](#) .

D

E

F

G

H

I

J

LAN

L

M

# CAN SYSTEM (TYPE 5)

[CAN]

UKS00555

## Check Sheet

**NOTE:**

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

PKIC5765E

# CAN SYSTEM (TYPE 5)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of A/T SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS
Attach copy of METER SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of A/T CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR
Attach copy of METER CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

PKIC7064E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-244, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIC5766E



PKIC5516E



# CAN SYSTEM (TYPE 5)


[CAN]

## Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to LAN-245, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit".

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1011)
AT	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5767E



PKIC5517E

# CAN SYSTEM (TYPE 5)


[CAN]

## Case 3

Check ECM circuit. Refer to [LAN-246, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—	CAN COMM CIRCUIT (U100) ✓	—
BCM	No indication	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>	CAN COMM CIRCUIT (U1000) ✓	—
METER	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	CAN COMM CIRCUIT (U100) ✓	—
ABS	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
IPDM E/R	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	—	CAN COMM CIRCUIT (U100) ✓	—

PKIC5768E



PKIC5518E

# CAN SYSTEM (TYPE 5)


[CAN]

## Case 4

Check TCM circuit. Refer to [LAN-247, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5769E



PKIC5519E

# CAN SYSTEM (TYPE 5)


[CAN]

## Case 5

Check data link connector circuit. Refer to [LAN-248, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5770E




PKIC5520E

## Case 6

Check BCM circuit. Refer to [LAN-249, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN ✓	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIC5771E



# CAN SYSTEM (TYPE 5)


[CAN]

## Case 7

Check combination meter circuit. Refer to [LAN-249, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC572E




PKIC552E

## Case 8

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-250, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								IPDM E/R
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS				
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
AT	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIC5773E




## Case 9

Check IPDM E/R circuit. Refer to [LAN-251, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5774E



## Case 10

Check CAN communication circuit. Refer to [LAN-251, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5775E



# CAN SYSTEM (TYPE 5)

[CAN]

## Case 11

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
AT	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN ✓	UNKWN	—	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5776E

## Case 12

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
AT	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5777E

---

## CAN SYSTEM (TYPE 6)

PFP:23710

### Component Parts and Harness Connector Location

UKS00556

Refer to [LAN-22, "Component Parts and Harness Connector Location"](#) .

### Schematic

UKS00557

Refer to [LAN-23, "Schematic"](#) .

### Wiring Diagram — CAN —

UKS00558

Refer to [LAN-24, "Wiring Diagram — CAN —"](#) .

# CAN SYSTEM (TYPE 6)

[CAN]

UKS00559

## Check Sheet

### NOTE:

If a check mark is put on “NG” on “INITIAL DIAG (Initial diagnosis)”, replace the control unit.

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

PKIC5884E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 6)

[CAN]

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
METER  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
METER  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIC7064E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-244, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5885E



# CAN SYSTEM (TYPE 6)


[CAN]

## Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-245, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5886E



PKIC5517E

# CAN SYSTEM (TYPE 6)


[CAN]

## Case 3

Check ECM circuit. Refer to [LAN-246, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
METER	No indication	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U100) ✓	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U100) ✓	—

PKIC5887E



# CAN SYSTEM (TYPE 6)


[CAN]

## Case 4

Check TCM circuit. Refer to [LAN-247, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U101)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U100)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U100)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U100)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5888E






## Case 5

Check data link connector circuit. Refer to [LAN-248, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5889E




## Case 6

Check BCM circuit. Refer to [LAN-249, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN ✓	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5890E




## Case 7

Check combination meter circuit. Refer to [LAN-249, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN ✓	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN ✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5891E




## Case 8

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-250, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5892E




## Case 9

Check IPDM E/R circuit. Refer to [LAN-251, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5893E



## Case 10

Check CAN communication circuit. Refer to [LAN-251, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5894E

# CAN SYSTEM (TYPE 6)

[CAN]

## Case 11

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5895E

## Case 12

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5896E

# CAN SYSTEM (TYPE 7)

[CAN]

---

## CAN SYSTEM (TYPE 7)

PF2:23710

### Component Parts and Harness Connector Location

UKS0055A

A

Refer to [LAN-22, "Component Parts and Harness Connector Location"](#) .

### Schematic

UKS0055B

B

Refer to [LAN-23, "Schematic"](#) .

### Wiring Diagram — CAN —

UKS0055C

C

Refer to [LAN-24, "Wiring Diagram — CAN —"](#) .

D

E

F

G

H

I

J

LAN

L

M





# CAN SYSTEM (TYPE 7)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of A/T SELF-DIAG RESULTS	Attach copy of DIFF LOCK SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS
Attach copy of METER SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS	
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of A/T CAN DIAG SUPPORT MNTR	Attach copy of DIFF LOCK CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR
Attach copy of METER CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

PKIC7072E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-244, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5898E



# CAN SYSTEM (TYPE 7)


[CAN]

## Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to LAN-245, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit".

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R				
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—

PKIC5899E



PKIC5596E

# CAN SYSTEM (TYPE 7)


[CAN]

## Case 3

Check ECM circuit. Refer to [LAN-246, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	CAN COMM CIRCUIT (U1000) <sup>✓</sup>	CAN COMM CIRCUIT (U1001) <sup>✓</sup>
A/T	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	CAN COMM CIRCUIT (U1000) <sup>✓</sup>	—
DIFF LOCK	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	—	UNKW <sup>✓</sup> N	—	CAN COMM CIRCUIT (U1000) <sup>✓</sup>	—
BCM	No indication	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	CAN COMM CIRCUIT (U1000) <sup>✓</sup>	—
METER	No indication	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	CAN COMM CIRCUIT (U1000) <sup>✓</sup>	—
ABS	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	—	—	CAN COMM CIRCUIT (U1000) <sup>✓</sup>	—
IPDM E/R	No indication	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	UNKW <sup>✓</sup> N	—	—	CAN COMM CIRCUIT (U1000) <sup>✓</sup>	—

PKIC5900E



PKIC5597E

# CAN SYSTEM (TYPE 7)


[CAN]

## Case 4

Check TCM circuit. Refer to [LAN-247, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	—	UNKWN	—	✓ UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	✓ UNKWN	—	—	—	✓ UNKWN	✓ UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	✓ UNKWN	—	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	✓ UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5901E



# CAN SYSTEM (TYPE 7)


[CAN]

## Case 5

Check differential lock control unit circuit. Refer to [LAN-247, "Differential Lock Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
	Initial diagnosis	Transmit diagnosis	Receive diagnosis									
			ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN ✓	UNKWN ✓	—	—	—	—	UNKWN ✓	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5902E



# CAN SYSTEM (TYPE 7)


[CAN]

## Case 6

Check data link connector circuit. Refer to [LAN-248, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5903E



# CAN SYSTEM (TYPE 7)


[CAN]

## Case 7

Check BCM circuit. Refer to [LAN-249, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5904E



PKIC5601E




## Case 8

Check combination meter circuit. Refer to [LAN-249, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5905E




## Case 9

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-250, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	✓	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5906E



# CAN SYSTEM (TYPE 7)


[CAN]

## Case 10

Check IPDM E/R circuit. Refer to [LAN-251, "IPDM E/R Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5907E



## Case 11

Check CAN communication circuit. Refer to [LAN-251, "CAN Communication Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5908E

# CAN SYSTEM (TYPE 7)

[CAN]

## Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5909E

## Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	—	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5910E

# CAN SYSTEM (TYPE 8)

[CAN]

---

## CAN SYSTEM (TYPE 8)

PF2:23710

### Component Parts and Harness Connector Location

UKS0055E

Refer to [LAN-22, "Component Parts and Harness Connector Location"](#) .

### Schematic

UKS0055F

Refer to [LAN-23, "Schematic"](#) .

### Wiring Diagram — CAN —

UKS0055G

Refer to [LAN-24, "Wiring Diagram — CAN —"](#) .

A

B

C

D

E

F

G

H

I

J

LAN

L

M



# CAN SYSTEM (TYPE 8)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS	Attach copy of METER SELF-DIAG RESULTS
Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR	Attach copy of METER CAN DIAG SUPPORT MNTR
Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

PKIC7069E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-245, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5779E





# CAN SYSTEM (TYPE 8)


[CAN]

## Case 2

Check ECM circuit. Refer to [LAN-246, "ECM Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN ✓	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN ✓	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5780E



# CAN SYSTEM (TYPE 8)


[CAN]

## Case 3

Check data link connector circuit. Refer to [LAN-248, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5781E



# CAN SYSTEM (TYPE 8)


[CAN]

## Case 4

Check BCM circuit. Refer to [LAN-249, "BCM Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5782E



# CAN SYSTEM (TYPE 8)


[CAN]

## Case 5

Check combination meter circuit. Refer to [LAN-249, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5783E




PKIC5539E

## Case 6

Check transfer control unit circuit. Refer to [LAN-250, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5784E




## Case 7

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-250, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5785E




## Case 8

Check IPDM E/R circuit. Refer to [LAN-251, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN ✓	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN ✓	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5786E



## Case 9

Check CAN communication circuit. Refer to [LAN-251, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	No indication ✓	UNKWN ✓	UNKWN ✓	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5787E

# CAN SYSTEM (TYPE 8)

[CAN]

## Case 10

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5788E

## Case 11

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5789E



# CAN SYSTEM (TYPE 9)

[CAN]

---

## CAN SYSTEM (TYPE 9)

PF2:23710

### Component Parts and Harness Connector Location

UKS0055I

A

Refer to [LAN-22, "Component Parts and Harness Connector Location"](#) .

### Schematic

UKS0055J

B

Refer to [LAN-23, "Schematic"](#) .

### Wiring Diagram — CAN —

UKS0055K

C

Refer to [LAN-24, "Wiring Diagram — CAN —"](#) .

D

E

F

G

H

I

J

LAN

L

M

# CAN SYSTEM (TYPE 9)

[CAN]

UKS0055L

## Check Sheet

**NOTE:**

If a check mark is put on “NG” on “INITIAL DIAG (Initial diagnosis)”, replace the control unit.

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

PKIC5790E

# CAN SYSTEM (TYPE 9)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS	Attach copy of METER SELF-DIAG RESULTS
Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR	Attach copy of METER CAN DIAG SUPPORT MNTR
Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

PKIC7069E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-245, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5791E




PKIC5535E

## Case 2

Check ECM circuit. Refer to [LAN-246, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5792E




## Case 3

Check data link connector circuit. Refer to [LAN-248, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5793E



# CAN SYSTEM (TYPE 9)


[CAN]

## Case 4

Check BCM circuit. Refer to [LAN-249, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5794E




## Case 5

Check combination meter circuit. Refer to [LAN-249, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5795E






## Case 6

Check transfer control unit circuit. Refer to [LAN-250, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN ✓	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5796E



# CAN SYSTEM (TYPE 9)


[CAN]

## Case 7

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-250, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	✓	✓	✓	—	—	✓	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5797E




PKIC5541E

## Case 8

Check IPDM E/R circuit. Refer to [LAN-251, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5798E



## Case 9

Check CAN communication circuit. Refer to [LAN-251, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5799E

# CAN SYSTEM (TYPE 9)

[CAN]

## Case 10

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5800E

## Case 11

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5801E

# CAN SYSTEM (TYPE 10)

[CAN]

---

## CAN SYSTEM (TYPE 10)

PF:23710

### Component Parts and Harness Connector Location

UKS0055M

A

Refer to [LAN-22, "Component Parts and Harness Connector Location"](#) .

### Schematic

UKS0055N

B

Refer to [LAN-23, "Schematic"](#) .

### Wiring Diagram — CAN —

UKS0055O

C

Refer to [LAN-24, "Wiring Diagram — CAN —"](#) .

D

E

F

G

H

I

J

LAN

L

M

# CAN SYSTEM (TYPE 10)

[CAN]

UKS0055P

## Check Sheet

**NOTE:**

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

PKIC5911E

# CAN SYSTEM (TYPE 10)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of DIFF LOCK SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS	Attach copy of METER SELF-DIAG RESULTS
Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS	
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of DIFF LOCK CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR	Attach copy of METER CAN DIAG SUPPORT MNTR
Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

PKIC7070E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-245, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						VDC/TCS /ABS			IPDM E/R
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD					
ENGINE	—	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	✓	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	✓	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	✓	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	✓	✓	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	✓	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	✓	✓	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5912E






## Case 2

Check ECM circuit. Refer to [LAN-246, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	✓	—	—	✓	✓	✓	✓	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	✓	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	✓	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	✓	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	✓	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	✓	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	✓	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5913E



# CAN SYSTEM (TYPE 10)


[CAN]

## Case 3

Check differential lock control unit circuit. Refer to [LAN-247, "Differential Lock Control Unit Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN ✓	UNKWN ✓	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5914E




PKIC5607E

## Case 4

Check data link connector circuit. Refer to [LAN-248, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5915E



# CAN SYSTEM (TYPE 10)


[CAN]

## Case 5

Check BCM circuit. Refer to [LAN-249, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	—	✓	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	—	✓	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	✓	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5916E




## Case 6

Check combination meter circuit. Refer to [LAN-249, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	—	UNKWN	✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	✓	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	✓	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5917E




## Case 7

Check transfer control unit circuit. Refer to [LAN-250, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓	—	UNKWN ✓	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN ✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5918E




## Case 8

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-250, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5919E




## Case 9

Check IPDM E/R circuit. Refer to [LAN-251, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5920E



## Case 10

Check CAN communication circuit. Refer to [LAN-251, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5921E



# CAN SYSTEM (TYPE 10)

[CAN]

## Case 11

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5922E

## Case 12

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5923E

---

## CAN SYSTEM (TYPE 11)

PFP:23710

### Component Parts and Harness Connector Location

UKS0055Q

Refer to [LAN-22, "Component Parts and Harness Connector Location"](#) .

### Schematic

UKS0055R

Refer to [LAN-23, "Schematic"](#) .

### Wiring Diagram — CAN —

UKS0055S

Refer to [LAN-24, "Wiring Diagram — CAN —"](#) .

# CAN SYSTEM (TYPE 11)

[CAN]

UKS0055T

## Check Sheet

**NOTE:**

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

PKIC5829E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 11)

[CAN]

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
METER  
SELF-DIAG RESULTS

Attach copy of  
ALL MODE AWD/4WD  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
METER  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ALL MODE AWD/4WD  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIC7066E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-244, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R			
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS				
ENGINE	—	—	UNKWN	—	UNKWN	✓	✓	✓	✓	—	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	✓	✓	—	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	✓	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	✓	✓	UNKWN	—	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	✓	✓	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	✓	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	✓	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5830E




PKIC5562E

## Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-245, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5831E




## Case 3

Check ECM circuit. Refer to [LAN-246, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	✓	—	✓	✓	✓	✓	—	✓	CAN COMM CIRCUIT (U700) ✓	CAN COMM CIRCUIT (U701) ✓
A/T	—	NG	UNKWN	✓	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U700) ✓	—
BCM	No indication	NG	UNKWN	✓	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
METER	No indication	—	UNKWN	✓	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U700) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	✓	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U700) ✓	—
ABS	—	NG	UNKWN	✓	—	—	—	—	—	—	CAN COMM CIRCUIT (U700) ✓	—
IPDM E/R	No indication	—	UNKWN	✓	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U700) ✓	—

PKIC5832E



# CAN SYSTEM (TYPE 11)


[CAN]

## Case 4

Check TCM circuit. Refer to [LAN-247, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U100) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U100) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5833E



PKIC5565E




## Case 5

Check data link connector circuit. Refer to [LAN-248, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5834E




## Case 6

Check BCM circuit. Refer to [LAN-249, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5835E




## Case 7

Check combination meter circuit. Refer to [LAN-249, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	✓	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	✓	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	✓	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	✓	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5836E




## Case 8

Check transfer control unit circuit. Refer to [LAN-250, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	✓	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	✓	✓	✓	—	✓	—	✓	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5837E




## Case 9

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-250, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5838E




## Case 10

Check IPDM E/R circuit. Refer to [LAN-251, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5839E



## Case 11

Check CAN communication circuit. Refer to [LAN-251, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5840E

## Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	✓	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	✓	UNKWN	—	—	✓	UNKWN	CAN COMM CIRCUIT (U100) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	✓	—	UNKWN	—	✓	—	CAN COMM CIRCUIT (U100) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5841E

## Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5842E

---

## CAN SYSTEM (TYPE 12)

PF2P:23710

### Component Parts and Harness Connector Location

UKS0055U

Refer to [LAN-22, "Component Parts and Harness Connector Location"](#) .

### Schematic

UKS0055V

Refer to [LAN-23, "Schematic"](#) .

### Wiring Diagram — CAN —

UKS0055W

Refer to [LAN-24, "Wiring Diagram — CAN —"](#) .



# CAN SYSTEM (TYPE 12)

[CAN]

UKS0055X

## Check Sheet

**NOTE:**

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

PKIC5843E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 12)

[CAN]

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
METER  
SELF-DIAG RESULTS

Attach copy of  
ALL MODE AWD/4WD  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
METER  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ALL MODE AWD/4WD  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIC7066E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-244, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS			
ENGINE	—	—	UNKWN	—	UNKWN	✓	✓	✓	✓	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	✓	✓	✓	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	✓	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	✓	✓	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	✓	✓	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	✓	✓	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	✓	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5844E




PKIC5562E

## Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-245, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5845E




PKIC5563E

### Case 3

Check ECM circuit. Refer to [LAN-246, "ECM Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	✓	—	✓	✓	✓	✓	✓	✓	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	UNKWN	✓	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—
BCM	No indication	NG	UNKWN	✓	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
METER	No indication	—	UNKWN	✓	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U100) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	✓	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—
ABS	—	NG	UNKWN	✓	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U100) ✓	—
IPDM E/R	No indication	—	UNKWN	✓	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—

PKIC5846E



# CAN SYSTEM (TYPE 12)


[CAN]

## Case 4

Check TCM circuit. Refer to [LAN-247, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U101)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U100)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U100)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U100)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U100)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5847E




PKIC5565E

## Case 5

Check data link connector circuit. Refer to [LAN-248, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5848E




## Case 6

Check BCM circuit. Refer to [LAN-249, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5849E






## Case 7

Check combination meter circuit. Refer to [LAN-249, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	✓
A/T	—	NG	UNKWN	UNKWN	—	—	✓	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	✓	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	✓	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5850E




## Case 8

Check transfer control unit circuit. Refer to [LAN-250, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	✓	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5851E




## Case 9

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-250, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5852E




## Case 10

Check IPDM E/R circuit. Refer to [LAN-251, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5853E



## Case 11

Check CAN communication circuit. Refer to [LAN-251, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5854E

**Case 12**

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U100) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5855E

**Case 13**

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	—	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5856E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

---

## CAN SYSTEM (TYPE 13)

PFP:23710

### Component Parts and Harness Connector Location

UKS0055Y

Refer to [LAN-22, "Component Parts and Harness Connector Location"](#) .

### Schematic

UKS0055Z

Refer to [LAN-23, "Schematic"](#) .

### Wiring Diagram — CAN —

UKS00560

Refer to [LAN-24, "Wiring Diagram — CAN —"](#) .

# CAN SYSTEM (TYPE 13)

[CAN]

UKS00561

## Check Sheet

**NOTE:**

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

PKIC5924E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 13)

[CAN]

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
DIFF LOCK  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
METER  
SELF-DIAG RESULTS

Attach copy of  
ALL MODE AWD/4WD  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
DIFF LOCK  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
METER  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ALL MODE AWD/4WD  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIC7071E



## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-244, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	—	✓	✓	✓	✓	✓	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	✓	✓	✓	✓	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	✓	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	✓	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	✓	✓	—	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	✓	✓	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	✓	✓	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	✓	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5925E




## Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-245, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5926E




PKIC5615E

## Case 3

Check ECM circuit. Refer to [LAN-246, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	✓ UNKWN	—	✓ UNKWN	—	✓ UNKWN	✓ UNKWN	✓ UNKWN	✓ UNKWN	✓ UNKWN	✓ UNKWN	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	UNKWN	✓ UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U100) ✓	—
DIFF LOCK	—	NG	UNKWN	✓ UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U100) ✓	—
BCM	No indication	NG	UNKWN	✓ UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
METER	No indication	—	UNKWN	✓ UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	✓ UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	✓ UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
IPDM E/R	No indication	—	UNKWN	✓ UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—

PKIC5927E




## Case 4

Check TCM circuit. Refer to [LAN-247, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	—	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	CAN COMM CIRCUIT (U100) ✓	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U100) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U100) ✓	—
ABS	—	NG	UNKWN	UNKWN	UNKWN ✓	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5928E




## Case 5

Check differential lock control unit circuit. Refer to [LAN-247, "Differential Lock Control Unit Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN ✓	UNKWN ✓	—	—	—	—	UNKWN ✓	UNKWN ✓	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5929E



# CAN SYSTEM (TYPE 13)


[CAN]

## Case 6

Check data link connector circuit. Refer to [LAN-248, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						VDC/TCS /ABS			IPDM E/R
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD				
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5930E




## Case 7

Check BCM circuit. Refer to [LAN-249, "BCM Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5931E




## Case 8

Check combination meter circuit. Refer to [LAN-249, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5932E






## Case 9

Check transfer control unit circuit. Refer to [LAN-250, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5933E




PKIC5622E

## Case 10

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-250, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5934E




## Case 11

Check IPDM E/R circuit. Refer to [LAN-251, "IPDM E/R Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS				
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIC5935E



## Case 12

Check CAN communication circuit. Refer to [LAN-251, "CAN Communication Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS				
ENGINE	—	—	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	—	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—
DIFF LOCK	—	NG	UNKWN ✓	UNKWN ✓	—	—	—	—	UNKWN ✓	UNKWN ✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓	—	UNKWN ✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	No indication ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIC5936E

# CAN SYSTEM (TYPE 13)

[CAN]

## Case 13

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS				
ENGINE	—	—	UNKWN	—	UNKWN ✓	—	UNKWN	UNKWN	UNKWN	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓	
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN ✓	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	UNKWN	UNKWN	UNKWN ✓	—	UNKWN	—	—	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	—	UNKWN ✓	—	CAN COMM CIRCUIT (U1000) ✓	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIC5937E

## Case 14

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS				
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	—	—	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIC5938E

# CAN SYSTEM (TYPE 14)

[CAN]

---

## CAN SYSTEM (TYPE 14)

PFP:23710

### Component Parts and Harness Connector Location

UKS00562

A

Refer to [LAN-22, "Component Parts and Harness Connector Location"](#) .

### Schematic

UKS00563

B

Refer to [LAN-23, "Schematic"](#) .

### Wiring Diagram — CAN —

UKS00564

C

Refer to [LAN-24, "Wiring Diagram — CAN —"](#) .

D

E

F

G

H

I

J

LAN

L

M

# CAN SYSTEM (TYPE 14)

[CAN]

UKS00565

## Check Sheet

**NOTE:**

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table														
SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS				
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

PKIC5673E

# CAN SYSTEM (TYPE 14)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of A/T SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS	Attach copy of METER SELF-DIAG RESULTS
Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS	
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of A/T CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR	Attach copy of METER CAN DIAG SUPPORT MNTR
Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

PKIC7066E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-244, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS			
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R				
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5674E



PKIC5572E




## Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-245, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS			
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R	
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS					
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5675E




## Case 3

Check ECM circuit. Refer to [LAN-246, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)	—

PKIC5676E




## Case 4

Check TCM circuit. Refer to [LAN-247, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U101)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U100)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U100)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U100)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U100)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5677E



# CAN SYSTEM (TYPE 14)


[CAN]

## Case 5

Check steering angle sensor circuit. Refer to [LAN-248, "Steering Angle Sensor Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5678E



PKIC5576E

# CAN SYSTEM (TYPE 14)


[CAN]

## Case 6

Check data link connector circuit. Refer to [LAN-248, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5679E



PKIC5577E

# CAN SYSTEM (TYPE 14)


[CAN]

## Case 7

Check BCM circuit. Refer to [LAN-249, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5680E




## Case 8

Check combination meter circuit. Refer to [LAN-249, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5681E




## Case 9

Check transfer control unit circuit. Refer to [LAN-250, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	✓	UNKWN	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	✓	✓	✓	—	—	✓	—	✓	—	CAN COMM CIRCUIT (U000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	✓	—	—	CAN COMM CIRCUIT (U000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5682E






## Case 10

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-250, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5683E




## Case 11

Check IPDM E/R circuit. Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIC5684E



## Case 12

Check CAN communication circuit. Refer to [LAN-251, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U001) ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	—	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓	—	UNKWN ✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5685E

# CAN SYSTEM (TYPE 14)

[CAN]

## Case 13

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5686E

## Case 14

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	—	—	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5687E

---

## CAN SYSTEM (TYPE 15)

PF2P:23710

### Component Parts and Harness Connector Location

UKS00566

Refer to [LAN-22, "Component Parts and Harness Connector Location"](#) .

### Schematic

UKS00567

Refer to [LAN-23, "Schematic"](#) .

### Wiring Diagram — CAN —

UKS00568

Refer to [LAN-24, "Wiring Diagram — CAN —"](#) .

# CAN SYSTEM (TYPE 15)

[CAN]

UKS00569

## Check Sheet

**NOTE:**

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table															
SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
AT	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

PKIC5857E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 15)

[CAN]

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
DIFF LOCK  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
METER  
SELF-DIAG RESULTS

Attach copy of  
ALL MODE AWD/4WD  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
DIFF LOCK  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
METER  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ALL MODE AWD/4WD  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIC7071E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-244, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS			
	Initial diagnosis	Transmit diagnosis	Receive diagnosis												
			ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R				
ENGINE	—	—	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC588E




PKIC583E

## Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-245, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS			
	Initial diagnosis	Transmit diagnosis	Receive diagnosis												
			ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R				
ENGINE	—	—	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5859E



PKIC5584E




## Case 3

Check ECM circuit. Refer to [LAN-246, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS				
ENGINE	—	—	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓	
A/T	—	NG	UNKWN ✓	UNKWN ✓	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—	
DIFF LOCK	—	NG	UNKWN ✓	UNKWN ✓	—	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—	
BCM	No indication	NG	UNKWN ✓	UNKWN ✓	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—	
METER	No indication	—	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—	
ALL MODE AWD/4WD	—	NG	UNKWN ✓	UNKWN ✓	—	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—	
ABS	—	NG	UNKWN ✓	UNKWN ✓	UNKWN	UNKWN	—	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—	
IPDM E/R	No indication	—	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—	

PKIC5860E




## Case 4

Check TCM circuit. Refer to [LAN-247, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
	Initial diagnosis	Transmit diagnosis	Receive diagnosis											
			ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U101)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U100)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U100)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U100)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U100)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5861E




## Case 5

Check differential lock control unit circuit. Refer to [LAN-247, "Differential Lock Control Unit Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS			
ENGINE	—	—	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5862E




## Case 6

Check steering angle sensor circuit. Refer to [LAN-248, "Steering Angle Sensor Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
	Initial diagnosis	Transmit diagnosis	Receive diagnosis											
			ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5863E




## Case 7

Check data link connector circuit. Refer to [LAN-248, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS			
ENGINE	—	—	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	— N <del>o</del> indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	— N <del>o</del> indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	— N <del>o</del> indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5864E



# CAN SYSTEM (TYPE 15)


[CAN]

## Case 8

Check BCM circuit. Refer to [LAN-249, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
	Initial diagnosis	Transmit diagnosis	Receive diagnosis											
			ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5865E




## Case 9

Check combination meter circuit. Refer to [LAN-249, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5866E



# CAN SYSTEM (TYPE 15)


[CAN]

## Case 10

Check transfer control unit circuit. Refer to [LAN-250, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
	Initial diagnosis	Transmit diagnosis	Receive diagnosis											
			ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5867E



PKIC5592E




## Case 11

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-250, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
	Initial diagnosis	Transmit diagnosis	Receive diagnosis											
			ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	—	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	✓	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5868E



# CAN SYSTEM (TYPE 15)


[CAN]

## Case 12

Check IPDM E/R circuit. Refer to [LAN-251, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS			
	Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R	
			ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS					
ENGINE	—	—	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5869E



## Case 13

Check CAN communication circuit. Refer to [LAN-251, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS			
	Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R	
			ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS					
ENGINE	—	—	✓	✓	—	—	✓	✓	✓	✓	✓	✓	✓	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—
DIFF LOCK	—	NG	✓	✓	—	—	—	—	—	✓	✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	✓	✓	✓	—	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	✓	✓	✓	✓	✓	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIC5870E

# CAN SYSTEM (TYPE 15)

[CAN]

## Case 14

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS				
ENGINE	—	—	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIC5871E

## Case 15

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD	VDC/TCS /ABS				
ENGINE	—	—	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	—	—	—	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIC5872E

## TROUBLE DIAGNOSIS FOR SYSTEM

### Inspection Between TCM and Data Link Connector Circuit

#### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector F14
  - Harness connector E5
  - Harness connector E152
  - Harness connector M31

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


#### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector and harness connector.

A/T assembly connector		Harness connector		Continuity
Connector	Terminal	Connector	Terminal	
F9	3	F14	2	Yes
	8		3	Yes

**OK or NG**

- OK >> GO TO 3.  
 NG >> Repair harness.




#### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector and SMJ harness connector.

Harness connector		SMJ harness connector		Continuity
Connector	Terminal	Connector	Terminal	
E5	2	E152	52G	Yes
	3		51G	Yes

**OK or NG**

- OK >> GO TO 4.  
 NG >> Repair harness.




**4. CHECK HARNESS FOR OPEN CIRCUIT**

Check continuity between SMJ harness connector and data link connector.

SMJ harness connector		Data link connector		Continuity
Connector	Terminal	Connector	Terminal	
M31	52G	M22	6	Yes
	51G		14	Yes

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness.



**Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit**

UKS0052M

**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector M91
  - Harness connector E26

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect harness connector M91.
2. Check continuity between data link connector and harness connector.

Data link connector		Harness connector		Continuity
Connector	Terminal	Connector	Terminal	
M22	6	M91	11	Yes
	14		10	Yes

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector and ABS actuator and electric unit (control unit) harness connector.

Harness connector		ABS actuator and electric unit (control unit) connector		Continuity
Connector	Terminal	Connector	Terminal	
E26	11	E125	11	Yes
	10		15	Yes



**OK or NG**

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness.

### ECM Circuit Inspection

UKS0052N

#### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - M/T model
    - ECM connector
    - Harness connector E152
    - Harness connector M31
  - A/T model
    - ECM connector
    - Harness connector E2
    - Harness connector F32


**OK or NG**

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

#### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector terminals.

ECM connector	Terminal		Resistance (Approx.)
E16	94	86	108 – 132 Ω



**OK or NG**

- OK >> Replace ECM.
- NG >>
  - M/T model
    - Repair harness between ECM and data link connector.
  - A/T model
    - Repair harness between ECM and A/T assembly.

## TCM Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

**OK or NG**

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector terminals.

A/T assembly connector	Terminal		Resistance (Approx.)
F9	3	8	54 – 66 Ω

**OK or NG**

- OK >> Replace control valve with TCM.
- NG >> Repair harness between A/T assembly and harness connector F14.



## Differential Lock Control Unit Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of differential lock control unit for damage, bend and loose connection (control unit side and harness side).

**OK or NG**

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect differential lock control unit connector.
2. Check resistance between differential lock control unit harness connector terminals.

Differential lock control unit connector	Terminal		Resistance (Approx.)
M70	5	4	54 – 66 Ω

**OK or NG**

- OK >> Replace differential lock control unit.
- NG >> Repair harness between differential lock control unit and data link connector.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

## Steering Angle Sensor Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector terminals.

Steering angle sensor connector	Terminal		Resistance (Approx.)
M47	4	5	54 – 66 Ω

OK or NG

- OK >> Replace steering angle sensor.  
 NG >> Repair harness between steering angle sensor and data link connector.



## Data Link Connector Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check data link connector and terminals for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector terminals.

Data link connector	Terminal		Resistance (Approx.)
M22	6	14	54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#) .  
 NG >> Repair harness between data link connector and BCM.





## BCM Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

**OK or NG**

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector terminals.

BCM connector	Terminal		Resistance (Approx.)
M18	39	40	54 – 66 Ω

**OK or NG**

- OK >> Replace BCM. Refer to [BCS-26, "Removal and Installation"](#).
- NG >> Repair harness between BCM and data link connector.



## Combination Meter Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

**OK or NG**

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector terminals.

Combination meter connector	Terminal		Resistance (Approx.)
M24	12	11	54 – 66 Ω

**OK or NG**

- OK >> Replace combination meter.
- NG >> Repair harness between combination meter and data link connector.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

**Transfer Control Unit Circuit Inspection**

**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector terminals.

Transfer control unit connector	Terminal		Resistance (Approx.)
M152	1	2	54 – 66 Ω

OK or NG

- OK >> Replace transfer control unit.
- NG >> Repair harness between transfer control unit and data link connector.



**ABS Actuator and Electric Unit (Control Unit) Circuit Inspection**

**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit) connector	Terminal		Resistance (Approx.)
E125	11	15	54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
- NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



## IPDM E/R Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

**OK or NG**

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector terminals.

IPDM E/R connector	Terminal		Resistance (Approx.)
E122	39	40	108 – 132 Ω

**OK or NG**

- OK >> Replace IPDM E/R.
- NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



## CAN Communication Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the harness connector for each unit on the CAN network and check terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.
- NG >> Repair terminal or connector as necessary.


### 2. CHECK HARNESS FOR SHORT CIRCUIT

With all module and control unit connectors disconnected, check continuity between data link connector terminals.

Data link connector	Terminal		Continuity
M22	6	14	No

**OK or NG**

- OK >> GO TO 3.
- NG >>
  - Repair harness.
  - Replace harness if shielded lines are used for the harness.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

### 3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector terminals and ground.


Data link connector	Terminal	Ground	Continuity
M22	6	Ground	No
	14		No

OK or NG

OK >> GO TO 4.

NG >> ● Repair harness.

- Replace harness if shielded lines are used for the harness.



### 4. ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals.

Terminal	Terminal	Resistance (Approx.)
94	86	108 – 132 Ω


3. Check resistance between IPDM E/R terminals.

Terminal	Terminal	Resistance (Approx.)
39	40	108 – 132 Ω

OK or NG

OK >> GO TO 5.

NG >> Replace ECM and/or IPDM E/R.



### 5. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

Check results

Reproduced>>GO TO 6.

Not reproduced>>Refer to [LAN-13, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#) .

### 6. UNIT REPRODUCIBILITY INSPECTION

Perform the following procedure for each unit on the CAN network, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced.

**NOTE:**

Malfunction (related to a unit that the connector is disconnected) is reproduced. Do not confuse the malfunction with the symptom filled in the column of "Symptom" on the check sheet.

Inspection results

Reproduced>>Connect the disconnected connector. Check other units applying the above procedure.

Not reproduced>>Replace the unit that the connector is disconnected.

### IPDM E/R Ignition Relay Circuit Inspection

UKS0052Y

Check the following. If no malfunction is found, replace the IPDM E/R.

# TROUBLE DIAGNOSIS FOR SYSTEM

[CAN]

- IPDM E/R power supply circuit. Refer to [PG-31, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

A

B

C

D

E

F

G

H

I

J

LAN

L

M

