

SECTION **PR**
PROPELLER SHAFT

A
B
C

PR

CONTENTS

E

NOISE, VIBRATION AND HARSHNESS (NVH)			
TROUBLESHOOTING	2	APPEARANCE CHECKING	3
NVH Troubleshooting Chart	2	Removal and Installation	3
REAR PROPELLER SHAFT	3	REMOVAL	3
On-Vehicle Service	3	INSTALLATION	4
PROPELLER SHAFT VIBRATION	3	INSPECTION	5
		SERVICE DATA	6
		Propeller Shaft Runout Limit	6

F
G
H

I

J

K

L

M

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

PFP:00003

NVH Troubleshooting Chart

EDS000A3

Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Symptom		Possible cause and SUSPECTED PARTS														
		Reference page	Uneven rotation torque	Center bearing improper installation	Excessive center bearing axial end play	Center bearing mounting (insulator) cracks, damage or deterioration	Excessive joint angle	Rotation imbalance	Excessive runout	DIFFERENTIAL	AXLE AND SUSPENSION	TIRES	ROAD WHEEL	DRIVE SHAFT	BRAKES	STEERING
PROPELLER SHAFT	Noise	—	×	×	×	×	×	×	×	×	×	×	×	×	×	×
	Shake	—		×			×				×	×	×	×	×	×
	Vibration	—	×	×	×	×	×	×	×	×	×		×		×	×

×: Applicable

REAR PROPELLER SHAFT

REAR PROPELLER SHAFT

PFP:37000


On-Vehicle Service PROPELLER SHAFT VIBRATION

EDS000A5

If vibration is present at high speed, check mounting between propeller shaft and companion flange.

Make sure alignment marks A and C are located as close to each other as possible.

If not, change mounting as indicated in "Installation".




APPEARANCE CHECKING

- Inspect propeller shaft tube surface for dents or cracks. If damaged, replace propeller shaft assembly.
- If center bearing is noisy or damaged, replace propeller shaft assembly.

Removal and Installation

EDS00070




REMOVAL

1. Move A/T select lever to N range position.
2. Remove exhaust tube.
3. Remove floor reinforcement.
4. Remove propeller shaft.


REAR PROPELLER SHAFT

INSTALLATION

If companion flange has been removed, put new alignment marks C on it. Then, reassemble using the following procedure. (Perform step 2 when final drive and propeller shaft are separated from each other. Also perform step 2 when either of these parts is replaced with a new one.)




1. Erase original marks C from companion flange with suitable solvent.
2. Put mark C on flange perimeter.
 - a. Measure companion flange vertical runout.
 - b. Determine the position where maximum runout is read on dial gauge. Put mark (shown by C in figure at left) on flange perimeter corresponding to maximum runout position.
3. Tighten remaining nuts to specified torque.



Center Bearing Bracket Installation

- Position the bearing cushion overlap as illustrated.




REAR PROPELLER SHAFT

INSPECTION

- Inspect propeller shaft runout. If runout exceeds specifications, replace propeller shaft assembly.

Runout limit: 0.6 mm (0.024 in)



A
B
C
PR
E
F
G
H
I
J
K
L
M

SERVICE DATA

SERVICE DATA

PFP:00030

Propeller Shaft Runout Limit

EDS0007R

Model		3F-R-2VL107
Propeller shaft runout limit	mm(in)	0.6 (0.024)