

A  
B  
C  
D  
E

# SECTION **BRC**

## BRAKE CONTROL SYSTEM

### CONTENTS

		BRC
<b>ABS</b>		
<b>BASIC INSPECTION</b> .....	<b>6</b>	
<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	<b>6</b>	
Work Flow .....	6	
Diagnostic Work Sheet .....	8	
<b>FUNCTION DIAGNOSIS</b> .....	<b>9</b>	
<b>ABS</b> .....	<b>9</b>	
System Diagram .....	9	
System Description .....	9	
Component Parts Location .....	10	
Component Description .....	11	
<b>EBD</b> .....	<b>13</b>	
System Diagram .....	13	
System Description .....	13	
Component Parts Location .....	14	
Component Description .....	15	
<b>DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]</b> .....	<b>17</b>	
CONSULT-III Function (ABS) .....	17	
<b>COMPONENT DIAGNOSIS</b> .....	<b>20</b>	
<b>C1101, C1102, C1103, C1104 WHEEL SENSOR-1</b> .....	<b>20</b>	
Description .....	20	
DTC Logic .....	20	
Diagnosis Procedure .....	20	
Component Inspection .....	22	
<b>C1105, C1106, C1107, C1108 WHEEL SENSOR-2</b> .....	<b>23</b>	
Description .....	23	
DTC Logic .....	23	
Diagnosis Procedure .....	23	
Component Inspection .....	25	
<b>C1109 POWER AND GROUND SYSTEM</b> .....	<b>26</b>	
Description .....	26	
DTC Logic .....	26	
Diagnosis Procedure .....	26	
<b>C1110, C1153 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)</b> .....	<b>28</b>	
Description .....	28	
DTC Logic .....	28	
Diagnosis Procedure .....	28	
<b>C1111 ABS MOTOR, MOTOR RELAY SYSTEM</b> .....	<b>29</b>	
Description .....	29	
DTC Logic .....	29	
Diagnosis Procedure .....	29	
Component Inspection .....	30	
<b>C1113 G SENSOR</b> .....	<b>31</b>	
Description .....	31	
DTC Logic .....	31	
Diagnosis Procedure .....	31	
Component Inspection .....	32	
<b>C1114 ACTUATOR RELAY SYSTEM</b> .....	<b>33</b>	
Description .....	33	
DTC Logic .....	33	
Diagnosis Procedure .....	33	
Component Inspection .....	34	
<b>C1115 WHEEL SENSOR</b> .....	<b>35</b>	
Description .....	35	
DTC Logic .....	35	
Diagnosis Procedure .....	35	
Component Inspection .....	36	
<b>C1116 STOP LAMP SWITCH</b> .....	<b>38</b>	
Description .....	38	
DTC Logic .....	38	
Diagnosis Procedure .....	38	
Component Inspection .....	39	

<b>C1120, C1122, C1124, C1126 IN ABS SOL</b> ....	<b>40</b>	<b>PEDAL VIBRATION OR ABS OPERATION</b>	
Description .....	40	<b>SOUND OCCURS</b> .....	<b>62</b>
DTC Logic .....	40	Diagnosis Procedure .....	62
Diagnosis Procedure .....	40	<b>NORMAL OPERATING CONDITION</b> .....	<b>63</b>
Component Inspection .....	41	Description .....	63
<b>C1121, C1123, C1125, C1127 OUT ABS SOL</b> ..	<b>42</b>	<b>PRECAUTION</b> .....	<b>64</b>
Description .....	42	<b>PRECAUTIONS</b> .....	<b>64</b>
DTC Logic .....	42	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	64
Diagnosis Procedure .....	42	Precaution for Brake System .....	64
Component Inspection .....	43	Precaution for Brake Control .....	64
<b>U1000 CAN COMM CIRCUIT</b> .....	<b>44</b>	<b>PREPARATION</b> .....	<b>65</b>
Description .....	44	<b>PREPARATION</b> .....	<b>65</b>
DTC Logic .....	44	Special Service Tool .....	65
Diagnosis Procedure .....	44	<b>ON-VEHICLE REPAIR</b> .....	<b>66</b>
<b>BRAKE FLUID LEVEL SWITCH</b> .....	<b>45</b>	<b>WHEEL SENSOR</b> .....	<b>66</b>
Description .....	45	<b>FRONT WHEEL SENSOR</b> .....	<b>66</b>
Component Function Check .....	45	FRONT WHEEL SENSOR : Exploded View .....	66
Diagnosis Procedure .....	45	FRONT WHEEL SENSOR : Removal and Installation .....	66
Component Inspection .....	46	<b>REAR WHEEL SENSOR</b> .....	<b>66</b>
<b>PARKING BRAKE SWITCH</b> .....	<b>47</b>	REAR WHEEL SENSOR : Exploded View .....	67
Description .....	47	REAR WHEEL SENSOR : Removal and Installation .....	67
Diagnosis Procedure .....	47	<b>SENSOR ROTOR</b> .....	<b>68</b>
Component Function Check .....	47	<b>FRONT SENSOR ROTOR</b> .....	<b>68</b>
Component Inspection .....	47	FRONT SENSOR ROTOR : Exploded View .....	68
<b>ABS WARNING LAMP</b> .....	<b>49</b>	FRONT SENSOR ROTOR : Removal and Installation .....	68
Description .....	49	<b>REAR SENSOR ROTOR</b> .....	<b>68</b>
Component Function Check .....	49	REAR SENSOR ROTOR : Exploded View .....	68
Diagnosis Procedure .....	49	REAR SENSOR ROTOR : Removal and Installation .....	68
<b>BRAKE WARNING LAMP</b> .....	<b>50</b>	<b>ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)</b> .....	<b>69</b>
Description .....	50	Exploded View .....	69
Component Function Check .....	50	Removal and Installation .....	70
Diagnosis Procedure .....	50	<b>G SENSOR</b> .....	<b>72</b>
<b>ECU DIAGNOSIS</b> .....	<b>51</b>	Exploded View .....	72
<b>ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)</b> .....	<b>51</b>	Removal and Installation .....	72
Reference Value .....	51		
Wiring Diagram - BRAKE CONTROL SYSTEM - ...	53		
Fail-Safe .....	56		
DTC No. Index .....	57		
<b>SYMPTOM DIAGNOSIS</b> .....	<b>58</b>		
<b>EXCESSIVE ABS FUNCTION OPERATION FREQUENCY</b> .....	<b>58</b>		
Diagnosis Procedure .....	58		
<b>UNEXPECTED PEDAL REACTION</b> .....	<b>59</b>		
Diagnosis Procedure .....	59		
<b>THE BRAKING DISTANCE IS LONG</b> .....	<b>60</b>		
Diagnosis Procedure .....	60		
<b>ABS FUNCTION DOES NOT OPERATE</b> .....	<b>61</b>		
Diagnosis Procedure .....	61		

<b>INSPECTION AND ADJUSTMENT</b> .....	77	Diagnosis Procedure .....	102	
<b>ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT</b> .....	77	Component Inspection .....	104	A
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description .....	77	Special Repair Requirement .....	104	
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement .....	77	<b>C1109 POWER AND GROUND SYSTEM</b> .....	105	B
<b>ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION</b> .....	77	Description .....	105	
ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description .....	77	DTC Logic .....	105	C
ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement .....	77	Diagnosis Procedure .....	105	
		Special Repair Requirement .....	106	
<b>FUNCTION DIAGNOSIS</b> .....	79	<b>C1110, C1153, C1170 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)</b> .....	107	D
<b>ESP</b> .....	79	Description .....	107	
System Diagram .....	79	DTC Logic .....	107	E
System Description .....	79	Diagnosis Procedure .....	107	
Component Parts Location .....	80	Special Repair Requirement .....	107	
Component Description .....	82	<b>C1111 ABS MOTOR, MOTOR RELAY SYSTEM</b> .....	109	BRC
<b>TCS</b> .....	83	Description .....	109	
System Diagram .....	83	DTC Logic .....	109	G
System Description .....	83	Diagnosis Procedure .....	109	
Component Parts Location .....	84	Component Inspection .....	110	
Component Description .....	86	Special Repair Requirement .....	110	
<b>ABS</b> .....	87	<b>C1114 ACTUATOR RELAY SYSTEM</b> .....	112	H
System Diagram .....	87	Description .....	112	
System Description .....	87	DTC Logic .....	112	I
Component Parts Location .....	88	Diagnosis Procedure .....	112	
Component Description .....	90	Component Inspection .....	113	
<b>EBD</b> .....	91	Special Repair Requirement .....	113	
System Diagram .....	91	<b>C1115 WHEEL SENSOR</b> .....	114	J
System Description .....	91	Description .....	114	
Component Parts Location .....	92	DTC Logic .....	114	K
Component Description .....	94	Diagnosis Procedure .....	114	
<b>DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]</b> .....	95	Component Inspection .....	115	
CONSULT-III Function (ABS) .....	95	Special Repair Requirement .....	116	
<b>COMPONENT DIAGNOSIS</b> .....	99	<b>C1116 STOP LAMP SWITCH</b> .....	117	L
<b>C1101, C1102, C1103, C1104 WHEEL SENSOR-1</b> .....	99	Description .....	117	
Description .....	99	DTC Logic .....	117	M
DTC Logic .....	99	Diagnosis Procedure .....	117	
Diagnosis Procedure .....	99	Component Inspection .....	118	
Component Inspection .....	101	Special Repair Requirement .....	119	
Special Repair Requirement .....	101	<b>C1120, C1122, C1124, C1126 IN ABS SOL</b> ...	120	N
<b>C1105, C1106, C1107, C1108 WHEEL SENSOR-2</b> .....	102	Description .....	120	
Description .....	102	DTC Logic .....	120	O
DTC Logic .....	102	Diagnosis Procedure .....	120	
		Component Inspection .....	121	
		Special Repair Requirement .....	122	
		<b>C1121, C1123, C1125, C1127 OUT ABS SOL</b> .....	123	P
		Description .....	123	
		DTC Logic .....	123	
		Diagnosis Procedure .....	123	
		Component Inspection .....	124	
		Special Repair Requirement .....	125	
		<b>C1130, C1131, C1132 ENGINE SIGNAL</b> .....	126	

Description .....	126	Component Function Check .....	146
DTC Logic .....	126	Diagnosis Procedure .....	146
Diagnosis Procedure .....	126	Component Inspection .....	147
Special Repair Requirement .....	126		
<b>C1142 PRESS SENSOR .....</b>	<b>127</b>	<b>ABS WARNING LAMP .....</b>	<b>148</b>
Description .....	127	Description .....	148
DTC Logic .....	127	Component Function Check .....	148
Diagnosis Procedure .....	127	Diagnosis Procedure .....	148
Component Inspection .....	128		
Special Repair Requirement .....	128	<b>BRAKE WARNING LAMP .....</b>	<b>149</b>
		Description .....	149
<b>C1143, C1144 STEERING ANGLE SENSOR .</b>	<b>129</b>	Component Function Check .....	149
Description .....	129	Diagnosis Procedure .....	149
DTC Logic .....	129		
Diagnosis Procedure .....	129	<b>ESP OFF INDICATOR LAMP .....</b>	<b>150</b>
Component Inspection .....	130	Description .....	150
Special Repair Requirement .....	130	Component Function Check .....	150
		Diagnosis Procedure .....	150
<b>C1145 YAW RATE SENSOR .....</b>	<b>132</b>		
Description .....	132	<b>SLIP INDICATOR LAMP .....</b>	<b>151</b>
DTC Logic .....	132	Description .....	151
Diagnosis Procedure .....	132	Component Function Check .....	151
Component Inspection .....	134	Diagnosis Procedure .....	151
Special Repair Requirement .....	134		
		<b>ECU DIAGNOSIS .....</b>	<b>152</b>
<b>C1146 G SENSOR .....</b>	<b>135</b>	<b>ABS ACTUATOR AND ELECTRIC UNIT</b>	
Description .....	135	<b>(CONTROL UNIT) .....</b>	<b>152</b>
DTC Logic .....	135	Reference Value .....	152
Diagnosis Procedure .....	135	Wiring Diagram - BRAKE CONTROL SYSTEM - .	155
Component Inspection .....	136	Fail-Safe .....	158
Special Repair Requirement .....	136	DTC No. Index .....	159
<b>C1147, C1148, C1149, C1150 USV/HSV LINE</b>	<b>137</b>	<b>SYMPTOM DIAGNOSIS .....</b>	<b>161</b>
Description .....	137		
DTC Logic .....	137	<b>EXCESSIVE ABS FUNCTION OPERATION</b>	
Diagnosis Procedure .....	137	<b>FREQUENCY .....</b>	<b>161</b>
Component Inspection .....	138	Diagnosis Procedure .....	161
Special Repair Requirement .....	139		
		<b>UNEXPECTED PEDAL REACTION .....</b>	<b>162</b>
<b>C1155 BRAKE FLUID LEVEL SWITCH .....</b>	<b>140</b>	Diagnosis Procedure .....	162
Description .....	140		
DTC Logic .....	140	<b>THE BRAKING DISTANCE IS LONG .....</b>	<b>163</b>
Diagnosis Procedure .....	140	Diagnosis Procedure .....	163
Component Inspection .....	141		
Special Repair Requirement .....	142	<b>ABS FUNCTION DOES NOT OPERATE .....</b>	<b>164</b>
		Diagnosis Procedure .....	164
<b>U1000, U1002 CAN COMM CIRCUIT .....</b>	<b>143</b>		
Description .....	143	<b>PEDAL VIBRATION OR ABS OPERATION</b>	
DTC Logic .....	143	<b>SOUND OCCURS .....</b>	<b>165</b>
Diagnosis Procedure .....	143	Diagnosis Procedure .....	165
Special Repair Requirement .....	143		
		<b>VEHICLE JERKS DURING ESP/TCS/ABS</b>	
<b>PARKING BRAKE SWITCH .....</b>	<b>144</b>	<b>CONTROL .....</b>	<b>166</b>
Description .....	144	Diagnosis Procedure .....	166
Diagnosis Procedure .....	144		
Component Function Check .....	144	<b>NORMAL OPERATING CONDITION .....</b>	<b>167</b>
Component Inspection .....	144	Description .....	167
<b>ESP OFF SWITCH .....</b>	<b>146</b>	<b>PRECAUTION .....</b>	<b>168</b>
Description .....	146	<b>PRECAUTIONS .....</b>	<b>168</b>

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	168	<b>SENSOR ROTOR</b> .....	173	A
Precaution for Brake System .....	168	<b>FRONT SENSOR ROTOR</b> .....	173	
Precaution for Brake Control .....	168	FRONT SENSOR ROTOR : Exploded View .....	173	
<b>PREPARATION</b> .....	170	FRONT SENSOR ROTOR : Removal and Installation .....	173	B
<b>PREPARATION</b> .....	170	<b>REAR SENSOR ROTOR</b> .....	173	
Special Service Tool .....	170	REAR SENSOR ROTOR : Exploded View .....	173	C
<b>ON-VEHICLE REPAIR</b> .....	171	REAR SENSOR ROTOR : Removal and Installation .....	173	
<b>WHEEL SENSOR</b> .....	171	<b>ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)</b> .....	174	D
<b>FRONT WHEEL SENSOR</b> .....	171	Exploded View .....	174	
FRONT WHEEL SENSOR : Exploded View .....	171	Removal and Installation .....	175	E
FRONT WHEEL SENSOR : Removal and Installation .....	171	<b>YAW RATE/SIDE G SENSOR</b> .....	177	
<b>REAR WHEEL SENSOR</b> .....	171	Exploded View .....	177	
REAR WHEEL SENSOR : Exploded View .....	172	Removal and Installation .....	177	BRC
REAR WHEEL SENSOR : Removal and Installation .....	172	<b>STEERING ANGLE SENSOR</b> .....	178	
		Exploded View .....	178	G
		Removal and Installation .....	178	

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[ABS]


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000001181608

#### OVERALL SEQUENCE



JSFIA0010GB

DETAILED FLOW

# DIAGNOSIS AND REPAIR WORKFLOW

[ABS]

< BASIC INSPECTION >

## 1. COLLECT THE INFORMATION FROM THE CUSTOMER

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred) using the diagnosis worksheet. Refer to [BRC-8, "Diagnostic Work Sheet"](#).

>> GO TO 2.

## 2. PERFORM THE SELF-DIAGNOSIS

Check the DTC display with the self-diagnosis function. Refer to [BRC-17, "CONSULT-III Function \(ABS\)"](#).

Is there any DTC displayed?

YES >> GO TO 3.

NO >> GO TO 4.

## 3. PERFORM THE SYSTEM DIAGNOSIS

Perform the diagnosis applicable to the displayed DTC. Refer to [BRC-57, "DTC No. Index"](#).

>> GO TO 7.

## 4. CHECK THE SYMPTOM THAT IS NOT CONSIDERED A SYSTEM MALFUNCTION

Check that the symptom is a normal operation that is not considered a system malfunction. Refer to [BRC-63, "Description"](#).

Is the symptom is a normal operation?

YES >> INSPECTION END

NO >> GO TO 5.

## 5. CHECK THE WARNING LAMP FOR ILLUMINATION

Check that the warning lamp illuminate.

• ABS warning lamp: Refer to [BRC-49, "Description"](#).

• Brake warning lamp: Refer to [BRC-50, "Description"](#).

Is ON/OFF timing normal?

YES >> GO TO 6.

NO >> GO TO 2.

## 6. PERFORM THE DIAGNOSIS BY SYMPTOM

Perform the diagnosis applicable to the symptom.

>> GO TO 7.

## 7. REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 8.

## 8. FINAL CHECK

Perform the self-diagnosis again, and check that the malfunction is repaired completely. After checking, erase the self-diagnosis memory. Refer to [BRC-17, "CONSULT-III Function \(ABS\)"](#).

Is any DTC indicated?

YES >> GO TO 3.

NO >> INSPECTION END

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[ABS]

## Diagnostic Work Sheet

INFOID:000000001181609

Customer name MR/MS	Model & Year	VIN	
Engine #	Trans.	Mileage	
Incident Date	Manuf. Date	In Service Date	
Symptoms	<input type="checkbox"/> Noise and vibration (from engine compartment) <input type="checkbox"/> Noise and vibration (from axle)	<input type="checkbox"/> Warning / Indicator activate	<input type="checkbox"/> Firm pedal operation Large stroke pedal operation
	<input type="checkbox"/> ABS does not work (Wheels lock when braking)	<input type="checkbox"/> Lack of sense of acceleration	
Engine conditions	<input type="checkbox"/> When starting <input type="checkbox"/> After starting		
Road conditions	<input type="checkbox"/> Low friction road ( <input type="checkbox"/> Snow <input type="checkbox"/> Gravel <input type="checkbox"/> Other ) <input type="checkbox"/> Bumps / potholes		
Driving conditions	<input type="checkbox"/> Full-acceleration <input type="checkbox"/> High speed cornering <input type="checkbox"/> Vehicle speed: Greater than 10 km/h (6 MPH) <input type="checkbox"/> Vehicle speed: 10 km/h (6 MPH) or less <input type="checkbox"/> Vehicle is stopped		
Applying brake conditions	<input type="checkbox"/> Suddenly <input type="checkbox"/> Gradually		
Other conditions	<input type="checkbox"/> Operation of electrical equipment <input type="checkbox"/> Shift change <input type="checkbox"/> Other descriptions		


SFIA3264E



# FUNCTION DIAGNOSIS

## ABS

### System Diagram




### System Description

INFOID:000000001181611

- Anti-Lock Braking System is a function that detects wheel revolution while braking, electronically controls braking force, and prevents wheel locking during sudden braking. It improves handling stability and maneuverability for avoiding obstacles.
- Electrical system diagnosis by CONSULT-III is available.


LHD models



JSFIA0034ZZ

- |                                   |                             |  |
|-----------------------------------|-----------------------------|--|
| 1. ABS warning lamp               | 2. Brake warning lamp       | 3. ABS actuator and electric unit (control unit) |
| 4. Front wheel sensor             | 5. G sensor                 | 6. Rear wheel sensor (2WD models)                |
| 7. Rear wheel sensor (4WD models) |                             |  |
| A. Combination meter              | B. Engine room (right side) | C. Steering knuckle                              |
| D. Lower instrument cover RH      | E. Rear axle                |  |

RHD models



- |                                   |                            |  |
|-----------------------------------|----------------------------|--|
| 1. ABS warning lamp               | 2. Brake warning lamp      | 3. ABS actuator and electric unit (control unit) |
| 4. Front wheel sensor             | 5. G sensor                | 6. Rear wheel sensor (2WD models)                |
| 7. Rear wheel sensor (4WD models) |                            |  |
| A. Combination meter              | B. Engine room (left side) | C. Steering knuckle                              |
| D. Lower instrument cover RH      | E. Rear axle               |  |

## Component Description

INFOID:000000001181613

Component parts	Reference
ABS actuator and electric unit (control unit)	Pump <a href="#">BRC-29, "Description"</a>
	Motor <a href="#">BRC-33, "Description"</a>
	Actuator relay (Main relay) <a href="#">BRC-40, "Description"</a>
	Solenoid valve <a href="#">BRC-20, "Description"</a>
Wheel sensor	<a href="#">BRC-20, "Description"</a>

A  
B  
C  
D  
E  
**BRC**  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# ABS

< FUNCTION DIAGNOSIS >


[ABS]

Component parts	Reference
ABS warning lamp	<a href="#">BRC-49. "Description"</a>
Brake warning lamp	<a href="#">BRC-50. "Description"</a>

EBD

System Diagram

INFOID:000000001181614




A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

System Description

INFOID:000000001181615

- Electric Brake force Distribution is a following function. ABS actuator and electric unit (control unit) detects subtle slippages between the front and rear wheels during braking. Then is electronically controls the rear braking force (brake fluid pressure) to reducing and reduces rear wheel slippage. Accordingly it improves vehicle stability.
- Electrical system diagnosis by CONSULT-III is available.


LHD models



JSFIA0034ZZ

- |                                   |                             |  |
|-----------------------------------|-----------------------------|--|
| 1. ABS warning lamp               | 2. Brake warning lamp       | 3. ABS actuator and electric unit (control unit) |
| 4. Front wheel sensor             | 5. G sensor                 | 6. Rear wheel sensor (2WD models)                |
| 7. Rear wheel sensor (4WD models) |                             |  |
| A. Combination meter              | B. Engine room (right side) | C. Steering knuckle                              |
| D. Lower instrument cover RH      | E. Rear axle                |  |

RHD models



- 1. ABS warning lamp
- 2. Brake warning lamp
- 3. ABS actuator and electric unit (control unit)
- 4. Front wheel sensor
- 5. G sensor
- 6. Rear wheel sensor (2WD models)
- 7. Rear wheel sensor (4WD models)
- A. Combination meter
- B. Engine room (left side)
- C. Steering knuckle
- D. Lower instrument cover RH
- E. Rear axle

Component Description

INFOID:000000001181617

Component parts		Reference
ABS actuator and electric unit (control unit)	Pump	<a href="#">BRC-29, "Description"</a>
	Motor	
	Actuator relay (Main relay)	<a href="#">BRC-33, "Description"</a>
	Solenoid valve	<a href="#">BRC-40, "Description"</a>
Wheel sensor		<a href="#">BRC-20, "Description"</a>

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# EBD

< FUNCTION DIAGNOSIS >

[ABS]

Component parts	Reference
ABS warning lamp	<a href="#">BRC-49. "Description"</a>
Brake warning lamp	<a href="#">BRC-50. "Description"</a>



# DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< FUNCTION DIAGNOSIS >

[ABS]

## DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

### CONSULT-III Function (ABS)

INFOID:000000001181618

#### FUNCTION

CONSULT-III can display each diagnostic item using the diagnostic test modes shown following.

Diagnostic test mode	Function
Self-diagnostic results	Self-diagnostic results can be read and erased quickly.
Data monitor	Input/Output data in the ABS actuator and electric unit (control unit) can be read.
Active test	Diagnostic test mode is which CONSULT-III drives some actuators apart from the ABS actuator and electric unit (control unit) and also shifts some parameters in a specified range.
ECU part number	ABS actuator and electric unit (control unit) part number can be read.
Function test	Performed by CONSULT-III instead of a technician to determine whether each system is "OK" or "NG".
CAN diagnostic support monitor	The results of transmit/receive diagnosis of CAN communication can be read.

#### SELF-DIAG RESULTS MODE

##### Operation Procedure

- Before performing the self-diagnosis, start engine and drive vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.

##### How to Erase Self-diagnosis Results

- After erasing DTC memory, start engine and drive vehicle at 30 km/h (19 MPH) or more for approximately 1 minute as the final inspection, and make sure that the ABS warning lamp and brake warning lamp turn OFF.

**CAUTION:**

**If memory cannot be erased, perform applicably diagnosis.**

**NOTE:**

- When the wheel sensor malfunctions, after inspecting the wheel sensor system, the ABS warning lamp and brake warning lamp will not turn OFF even when the system is normal unless the vehicle is driving at approximately 30 km/h (19 MPH) or more for approximately 1 minute.
- Brake warning lamp will turn ON in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).

##### Display Item List

Refer to [BRC-57, "DTC No. Index"](#).

#### DATA MONITOR MODE

##### Display Item List

×: Applicable □: Optional item

Monitor item (Unit)	SELECT MONITOR ITEM		Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	
FR LH SENSOR [km/h (MPH)]	×	×	Wheel speed
FR RH SENSOR [km/h (MPH)]	×	×	
RR LH SENSOR [km/h (MPH)]	×	×	
RR RH SENSOR [km/h (MPH)]	×	×	
STOP LAMP SW (On/Off)	×	×	Stop lamp switch signal status

# DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< FUNCTION DIAGNOSIS >

[ABS]

Monitor item (Unit)	SELECT MONITOR ITEM		Remarks	
	ECU INPUT SIGNALS	MAIN SIGNALS		
BATTERY VOLT (V)	×	×	Battery voltage supplied to the ABS actuator and electric unit (control unit)	
DECEL G SENSOR (On/Off) <sup>NOTE 1</sup>	×	×	Vehicle on level surface or on slope	
FR RH IN SOL (On/Off)	<input type="checkbox"/>	×	Operation status of each solenoid valve	
FR RH OUT SOL (On/Off)	<input type="checkbox"/>	×		
FR LH IN SOL (On/Off)	<input type="checkbox"/>	×		
FR LH OUT SOL (On/Off)	<input type="checkbox"/>	×		
RR RH IN SOL (On/Off)	<input type="checkbox"/>	×		
RR RH OUT SOL (On/Off)	<input type="checkbox"/>	×		
RR LH IN SOL (On/Off)	<input type="checkbox"/>	×		
RR LH OUT SOL (On/Off)	<input type="checkbox"/>	×		
MOTOR RELAY (On/Off)	<input type="checkbox"/>	×		Motor and motor relay operation
ACTUATOR RLY (On/Off) <sup>NOTE 2</sup>	<input type="checkbox"/>	×		Actuator relay operation
ABS WARN LAMP (On/Off)	<input type="checkbox"/>	×	ABS warning lamp	
EBD SIGNAL (On/Off)	<input type="checkbox"/>	<input type="checkbox"/>	EBD operation	
ABS SIGNAL (On/Off)	<input type="checkbox"/>	<input type="checkbox"/>	ABS operation	
EBD FAIL SIG (On/Off)	<input type="checkbox"/>	<input type="checkbox"/>	EBD fail-safe signal	
ABS FAIL SIG (On/Off)	<input type="checkbox"/>	<input type="checkbox"/>	ABS fail-safe signal	

**NOTE:**

1: Only 4WD models

2: Every 20 seconds momentary switch to OFF.

**ACTIVE TEST MODE**

**CAUTION:**

- Do not perform active test while driving vehicle.
- Make sure to completely bleed air from brake system.
- The active test cannot be performed with the ABS warning lamp and brake warning lamp are ON.
- ABS warning lamp and brake warning lamp are ON during active test.

**NOTE:**

- When active test is performed while depressing the pedal, the pedal depression amount will change. This is normal. (Only solenoid valve and ABS motor.)
- "TEST IS STOPPED" is displayed 10 seconds after operation start.
- After "TEST IS STOPPED" is displayed, to perform test again.

Test Item

ABS SOLENOID VALVE

# DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< FUNCTION DIAGNOSIS >

[ABS]

- For ABS solenoid valve, touch “UP”, “KEEP”, and “DOWN”. Then use screen monitor to check that solenoid valve operates as shown in solenoid valve operation chart.

Solenoid valve operation chart

Test item	Display item	Display		
		UP	KEEP	DOWN
FR RH SOL	FR RH IN SOL	OFF	ON	ON
	FR RH OUT SOL	OFF	OFF	ON*
FR LH SOL	FR LH IN SOL	OFF	ON	ON
	FR LH OUT SOL	OFF	OFF	ON*
RR RH SOL	RR RH IN SOL	OFF	ON	ON
	RR RH OUT SOL	OFF	OFF	ON*
RR LH SOL	RR LH IN SOL	OFF	ON	ON
	RR LH OUT SOL	OFF	OFF	ON*

\*: ON for 1 to 2 seconds after the touch, and then OFF.

## ABS MOTOR

- Touch “ON” and “OFF” on screen. Make sure motor relay and actuator relay operates as shown in table below.

Test item	Display item	Display	
		ON	OFF
ABS MOTOR	MOTOR RELAY	ON	OFF
	ACTUATOR RLY <sup>NOTE</sup>	ON	ON

### NOTE:

A brief moment of ON/OFF condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.

A  
B  
C  
D  
E  
  
BRC  
  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# C1101, C1102, C1103, C1104 WHEEL SENSOR-1

[ABS]

< COMPONENT DIAGNOSIS >

## COMPONENT DIAGNOSIS

### C1101, C1102, C1103, C1104 WHEEL SENSOR-1

#### Description

INFOID:000000001181619

When the sensor rotor rotates, the magnetic field changes. The sensor converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

#### DTC Logic

INFOID:000000001181620

#### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1101	RR RH SENSOR-1	Circuit of rear RH wheel circuit is open or short circuit. Current signal from sensor is outside limits.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• Wheel sensor</li><li>• ABS actuator and electric unit (control unit)</li></ul>
C1102	RR LH SENSOR-1	Circuit of rear LH wheel circuit is open or short circuit. Current signal from sensor is outside limits.	
C1103	FR RH SENSOR-1	Circuit of front RH wheel circuit is open or short circuit. Current signal from sensor is outside limits.	
C1104	FR LH SENSOR-1	Circuit of front LH wheel circuit is open or short circuit. Current signal from sensor is outside limits.	

#### DTC CONFIRMATION PROCEDURE

##### 1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
RR RH SENSOR-1
RR LH SENSOR-1
FR RH SENSOR-1
FR LH SENSOR-1

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-20. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

#### Diagnosis Procedure

INFOID:000000001181621

#### **CAUTION:**

**Do not check between wheel sensor terminals.**

#### INSPECTION PROCEDURE

##### 1. CHECK SENSOR AND SENSOR ROTOR

- Check sensor rotor for damage.
- Check wheel sensor for damage, disconnection or looseness.

Are the sensor and sensor rotor normal?

- YES >> GO TO 2.  
NO >> Repair wheel sensor mount or replace sensor rotor. Then perform the self-diagnosis.

##### 2. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.

# C1101, C1102, C1103, C1104 WHEEL SENSOR-1

[ABS]

< COMPONENT DIAGNOSIS >

5. Reconnect connectors and then perform the self-diagnosis. Refer to [BRC-17. "CONSULT-III Function \(ABS\)".](#)

Is any item indicated on the self-diagnosis display?

YES >> GO TO 3.

NO >> Poor connection of connector terminal. Repair or replace connector.

## 3. CHECK WHEEL SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check continuity between terminals. (Also check continuity when steering wheel is turned right and left and when sensor harness inside the wheel house is moved.)

Measurement terminal for power supply circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E34	9	E39 (Front RH)	2	Existed
	16	E22 (Front LH)		
	8	B41 (Rear RH)		
	6	B44 (Rear LH)		

Measurement terminal for signal circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E34	10	E39 (Front RH)	1	Existed
	5	E22 (Front LH)		
	19	B41 (Rear RH)		
	17	B44 (Rear LH)		

Measurement terminal for ground circuit

ABS actuator and electric unit (control unit)				Continuity
Connector	Terminal	Connector	Terminal	
E34	9, 10	E34	1, 4	Not existed
	16, 5			
	8, 19			
	6, 17			

5. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning components.

## 4. CHECK WHEEL SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between wheel sensor harness connector power supply terminal and ground.

Wheel sensor		—	Voltage
Connector	Terminal		
E39 (Front RH)	2	Ground	8 V or more
E22 (Front LH)			
B41 (Rear RH)			
B44 (Rear LH)			

Is the inspection result normal?

# C1101, C1102, C1103, C1104 WHEEL SENSOR-1

[ABS]

## < COMPONENT DIAGNOSIS >

- YES >> Replace applicable wheel sensor.  
NO >> Replace ABS actuator and electric unit (control unit).

## Component Inspection

INFOID:000000001181622

### 1. CHECK DATA MONITOR

On "DATA MONITOR", select "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR", and "RR RH SENSOR", and check the vehicle speed.

Wheel sensor	Vehicle speed (DATA MONITOR)
FR LH SENSOR	Nearly matches the speedometer display ( $\pm 10\%$ or less)
FR RH SENSOR	
RR LH SENSOR	
RR RH SENSOR	

#### Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Go to diagnosis procedure. Refer to [BRC-20. "Diagnosis Procedure"](#).

# C1105, C1106, C1107, C1108 WHEEL SENSOR-2

[ABS]

< COMPONENT DIAGNOSIS >

## C1105, C1106, C1107, C1108 WHEEL SENSOR-2

### Description

INFOID:000000001181623

ABS unit continually monitors wheel speed sensors to detect abnormal signals.

### DTC Logic

INFOID:000000001181624

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1105	RR RH SENSOR-2	Signal from rear RH wheel sensor does not match other 3 wheel speed signals.	<ul style="list-style-type: none"><li>• Sensor not installed correctly</li><li>• Sensor rotor or encoder damaged</li><li>• Sensor rotor loose on axle</li><li>• Electrical interference</li><li>• Wheel not turning - e.g. vehicle driven on 2WD dyno</li><li>• Sensor damaged</li><li>• ABS unit damaged</li></ul>
C1106	RR LH SENSOR-2	Signal from rear LH wheel sensor does not match other 3 wheel speed signals.	
C1107	FR RH SENSOR-2	Signal from front RH wheel sensor does not match other 3 wheel speed signals.	
C1108	FR LH SENSOR-2	Signal from front LH wheel sensor does not match other 3 wheel speed signals.	

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
RR RH SENSOR-2
RR LH SENSOR-2
FR RH SENSOR-2
FR LH SENSOR-2

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-23. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000001181625

#### **CAUTION:**

**Do not check between wheel sensor terminals.**

### INSPECTION PROCEDURE

#### 1.CHECK SENSOR AND SENSOR ROTOR

- Check sensor rotor for damage.
- Check wheel sensor for damage, disconnection or looseness.

Are the sensor and sensor rotor normal?

- YES >> GO TO 2.  
NO >> Repair wheel sensor mount or replace sensor rotor. Then perform the self-diagnosis.

#### 2.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
5. Reconnect connectors and then perform the self-diagnosis. Refer to [BRC-17. "CONSULT-III Function \(ABS\)"](#).

Is any item indicated on the self-diagnosis display?

## C1105, C1106, C1107, C1108 WHEEL SENSOR-2

[ABS]

### < COMPONENT DIAGNOSIS >

YES >> GO TO 3.

NO >> Poor connection of connector terminal. Repair or replace connector.

### 3. CHECK WHEEL SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check continuity between terminals. (Also check continuity when steering wheel is turned right and left and when sensor harness inside the wheel house is moved.)

Measurement terminal for power supply circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E34	9	E39 (Front RH)	2	Existed
	16	E22 (Front LH)		
	8	B41 (Rear RH)		
	6	B44 (Rear LH)		

Measurement terminal for signal circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E34	10	E39 (Front RH)	1	Existed
	5	E22 (Front LH)		
	19	B41 (Rear RH)		
	17	B44 (Rear LH)		

Measurement terminal for ground circuit

ABS actuator and electric unit (control unit)				Continuity
Connector	Terminal	Connector	Terminal	
E34	9, 10	E34	1, 4	Not existed
	16, 5			
	8, 19			
	6, 17			

5. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning components.

### 4. CHECK WHEEL SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between wheel sensor harness connector power supply terminal and ground.

Wheel sensor		—	Voltage
Connector	Terminal		
E39 (Front RH)	2	Ground	8 V or more
E22 (Front LH)			
B41 (Rear RH)			
B44 (Rear LH)			

Is the inspection result normal?

YES >> Replace applicable wheel sensor.

NO >> Replace ABS actuator and electric unit (control unit).



# C1105, C1106, C1107, C1108 WHEEL SENSOR-2

< COMPONENT DIAGNOSIS >

[ABS]

## Component Inspection

INFOID:000000001181626

### 1. CHECK DATA MONITOR

On "DATA MONITOR", select "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR", and "RR RH SENSOR", and check the vehicle speed.

Wheel sensor	Vehicle speed (DATA MONITOR)
FR LH SENSOR	Nearly matches the speedometer display ( $\pm 10\%$ or less)
FR RH SENSOR	
RR LH SENSOR	
RR RH SENSOR	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-35. "Diagnosis Procedure"](#).

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

**BRC**

# C1109 POWER AND GROUND SYSTEM

[ABS]

< COMPONENT DIAGNOSIS >

## C1109 POWER AND GROUND SYSTEM

### Description

INFOID:000000001181627

Power is supply from the battery to ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000001181628

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1109	BATTERY VOLTAGE [ABNORMAL]	When the ABS actuator and electric unit (control unit) power supply is lower than normal and vehicle speed is greater than 6 km/h (4 MPH). Power supply is greater than normal limits.	<ul style="list-style-type: none"> <li>• Harness or connector</li> <li>• ABS actuator and electric unit (control unit)</li> <li>• Fuse</li> <li>• Vehicle electrical power system</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
BATTERY VOLTAGE [ABNORMAL]

Is above displayed on the self-diagnosis display?

YES >> Proceed to diagnosis procedure. Refer to [BRC-26, "Diagnosis Procedure"](#).

NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000001181629

### INSPECTION PROCEDURE

#### 1.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform the self-diagnosis. Refer to [BRC-17, "CONSULT-III Function \(ABS\)"](#).

Is any item indicated on the self-diagnosis display?

YES >> GO TO 2.

NO >> Poor connection of connector terminal. Repair or replace connector.

#### 2.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Turn ignition switch ON or OFF and check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Condition	Voltage
Connector	Terminal			
E34	18	Ground	Ignition switch: ON	Battery voltage
			Ignition switch: OFF	Approx. 0 V

4. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

YES >> GO TO 3.

# C1109 POWER AND GROUND SYSTEM

[ABS]

## < COMPONENT DIAGNOSIS >

NO >> Repair or replace malfunctioning components.

### 3. ABS POWER SUPPLY CHECK (UNDER LOAD CONDITIONS)

1. Use 12V lamp (normal rating 10 to 20W) connected between E34 terminals 18 and 4. With ignition switch ON check bulb illuminates correctly.
2. Check ABS motor supply under loaded condition (connector E34 terminals 1 and 2).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check both power supply and ground circuit.

### 4. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E34	1, 4	Ground	Existed

Is the inspection result normal?

YES >> Check battery for terminal looseness, low voltage, etc. if any malfunction is found, repair malfunctioning parts.

NO >> Repair or replace malfunctioning components (check ABS earth bolt for tightness and corrosion).

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BRC

# C1110, C1153 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< COMPONENT DIAGNOSIS >

[ABS]

## C1110, C1153 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

### Description

INFOID:000000001181630

ABS unit is continuously monitoring ECU hardware and software for correct operation.

### DTC Logic

INFOID:000000001181631

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1110	CONTROLLER FAILURE	Possible internal failure of control unit components.	<ul style="list-style-type: none"><li>Internal failure of control unit components</li><li>ABS solenoid valve or motor power supply/ground abnormality</li></ul>
C1153	EMERGENCY BRAKE	Continuous ABS/EBD control for more than 60 seconds.	<ul style="list-style-type: none"><li>ABS control unit software failure</li><li>Wheel speed sensor input abnormality</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSIS RESULTS

1. Check both ABS solenoid valve and motor supply and ground circuits using a suitable electrical load.
2. Check wheel speed sensor inputs.
3. Check the self-diagnosis results.

Self-diagnosis results

CONTROLLER FAILURE

EMERGENCY BRAKE

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-28. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000001181632

### INSPECTION PROCEDURE

#### 1. REPLACE ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

#### **CAUTION:**

Replace ABS actuator and electric unit (control unit) when self-diagnostic result shows items other than those applicable.

>> Replace ABS actuator and electric unit (control unit).

# C1111 ABS MOTOR, MOTOR RELAY SYSTEM

< COMPONENT DIAGNOSIS >

[ABS]

## C1111 ABS MOTOR, MOTOR RELAY SYSTEM

### Description

INFOID:000000001181633

#### PUMP

The pump returns the brake fluid stored in the reservoir to the master cylinder by reducing the pressure.

#### MOTOR

The motor drives the pump according to the signals transmitted by the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000001181634

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1111	PUMP MOTOR	During the actuator motor operating with ON, when the actuator motor turns OFF, or when the control line for actuator motor relay is open.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit)</li></ul>
		During the actuator motor operating with OFF, when the actuator motor turns ON, or when the control line for relay is shorted to ground.	

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
PUMP MOTOR

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-29, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000001181635

### INSPECTION PROCEDURE

#### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnect, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform the self-diagnosis. Refer to [BRC-17, "CONSULT-III Function \(ABS\)"](#).

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.  
NO >> Poor connection of connector terminal. Replace or repair connector.

#### 2. CHECK ABS MOTOR AND MOTOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between the ABS actuator and electric unit (control unit) harness connector terminal and ground.

# C1111 ABS MOTOR, MOTOR RELAY SYSTEM

[ABS]

## < COMPONENT DIAGNOSIS >

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E34	2	Ground	Battery voltage

4. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

### 3. ABS POWER SUPPLY CHECK (UNDER LOAD CONDITIONS)

Use 12V lamp (normal rating 10 to 20W) connected between E34 terminals 1 and 2. With ignition switch ON check bulb illuminates correctly.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check both power supply and ground circuit.

### 4. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E34	1, 4	Ground	Existed

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace malfunctioning components. (Check ABS each bolt for tightness and corrosion).

## Component Inspection

INFOID:000000001181636

### 1. CHECK ACTIVE TEST

1. On "ACTIVE TEST", select "ABS MOTOR".
2. Touch "ON" and "OFF" on screen. Make sure motor relay and actuator relay operates as shown in table below.

Test item	Display item	Display	
		ON	OFF
ABS MOTOR	MOTOR RELAY	ON	OFF
	ACTUATOR RLY <sup>NOTE</sup>	ON	ON

#### NOTE:

A brief moment of ON/OFF condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-29, "Diagnosis Procedure"](#).

# C1113 G SENSOR

[ABS]

< COMPONENT DIAGNOSIS >

## C1113 G SENSOR

### Description

INFOID:000000001181637

G sensor detects G affecting the vehicle, and transmits the data to the ABS actuator and electric unit (control unit) as an analog voltage signal.

### DTC Logic

INFOID:000000001181638

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1113	G SENSOR	G sensor is malfunctioning, or signal line of G sensor is open or shorted.	<ul style="list-style-type: none"> <li>• Harness or connector</li> <li>• ABS actuator and electric unit (control unit)</li> <li>• G sensor</li> <li>• Electrical interference</li> <li>• Vehicle driven on 4WD rolling road</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
G SENSOR

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-31. "Diagnosis Procedure"](#).  
 NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000001181639

### INSPECTION PROCEDURE

#### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect G sensor connector.
4. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
5. Reconnect connectors and then perform the self-diagnosis. Refer to [BRC-17. "CONSULT-III Function \(ABS\)"](#).

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.  
 NO >> Poor connection of connector terminal. Replace or repair connector.

#### 2. CHECK G SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect G sensor connector.
3. Turn ignition switch ON or OFF and check voltage between G sensor harness connector terminal and ground.

G sensor		—	Condition	Voltage
Connector	Terminal			
M71	3	Ground	Ignition switch: ON	Battery voltage
		Ground	Ignition switch: OFF	Approx. 0 V

# C1113 G SENSOR

[ABS]

## < COMPONENT DIAGNOSIS >

### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace malfunctioning components.

### 3.CHECK G SENSOR GROUND CIRCUIT

Check continuity between G sensor harness connector terminal and ground.

G sensor		—	Continuity
Connector	Terminal		
M71	1	Ground	Existed

### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair or replace malfunctioning components.

### 4.CHECK G SENSOR HARNESS

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between G sensor harness connector terminals and ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit)		G sensor		Continuity
Connector	Terminal	Connector	Terminal	
E34	14	M71	1	Existed
	21		2	
	24		3	

### Is the inspection result normal?

- YES >> Replace G sensor.  
NO >> Repair or replace malfunctioning components.

## Component Inspection

INFOID:000000001181640

### 1.CHECK DATA MONITOR

Select "DECEL G SENSOR", in "DATA MONITOR" and check G sensor signal.

Monitor item	DATA MONITOR
DECEL G SENSOR	ON/OFF

### Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Go to diagnosis procedure. Refer to [BRC-17. "CONSULT-III Function \(ABS\)".](#)



# C1114 ACTUATOR RELAY SYSTEM

[ABS]

< COMPONENT DIAGNOSIS >

## C1114 ACTUATOR RELAY SYSTEM

### Description

INFOID:000000001181641

Activates or deactivates each solenoid valve according to the signals transmitted by the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000001181642

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1114	MAIN RELAY	During the actuator relay operating with OFF, when the actuator relay turns ON, or when the control line for the relay is shorted to the ground.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit)</li></ul>
		During the actuator relay operating with ON, when the actuator relay turns ON, or when the control line for the relay is open.	

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
MAIN RELAY

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-33, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000001181643

### INSPECTION PROCEDURE

#### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform the self-diagnosis. Refer to [BRC-17, "CONSULT-III Function \(ABS\)"](#).

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.  
NO >> Poor connection of connector terminal. Replace or repair connector.

#### 2. CHECK ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E34	3	Ground	Battery voltage

4. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

# C1114 ACTUATOR RELAY SYSTEM

[ABS]

## < COMPONENT DIAGNOSIS >

- YES >> GO TO 3.  
NO >> Repair or replace malfunctioning components.

### 3. ABS POWER SUPPLY CHECK (UNDER LOAD CONDITIONS)

Use 12V lamp (normal rating 10 to 20W) connected between E34 terminals 1 and 3. With ignition switch ON check bulb illuminates correctly.

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Check both power supply and ground circuit.

### 4. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E34	1, 4	Ground	Existed

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit).  
NO >> Repair or replace malfunctioning components. (Check ABS each bolt for tightness and corrosion).

## Component Inspection

INFOID:000000001181644

### 1. CHECK ACTIVE TEST

1. On "ACTIVE TEST", select "ABS MOTOR".
2. Touch "ON" and "OFF" on screen. Make sure motor relay and actuator relay operates as shown in table below.

Test item	Display item	Display	
		ON	OFF
ABS MOTOR	MOTOR RELAY	ON	OFF
	ACTUATOR RLY <sup>NOTE</sup>	ON	ON

#### NOTE:

A brief moment of ON/OFF condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Go to diagnosis procedure. Refer to [BRC-33. "Diagnosis Procedure"](#).

# C1115 WHEEL SENSOR

[ABS]

< COMPONENT DIAGNOSIS >

## C1115 WHEEL SENSOR

### Description

INFOID:000000001181645

When the sensor rotor rotates, the magnetic field changes. The sensor converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000001181646

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1115	ABS SENSOR [ABNORMAL SIGNAL]	Miss-match between the 4 wheel speed sensor signals.	<ul style="list-style-type: none"><li>• Harness or connector not a possible cause.</li><li>• Other possible causes<ul style="list-style-type: none"><li>- Tire radius (due to wrong size or pressure) interference.</li></ul></li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
ABS SENSOR [ABNORMAL SIGNAL]

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-35. "Diagnosis Procedure"](#).
- NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000001181647

#### **CAUTION:**

**Do not check between wheel sensor terminals.**

### INSPECTION PROCEDURE

#### 1.CHECK SENSOR AND SENSOR ROTOR

- Check sensor rotor for damage.
- Check wheel sensor for damage, disconnection or looseness.

Are the sensor and sensor rotor normal?

- YES >> GO TO 2.
- NO >> Repair wheel sensor mount or replace sensor rotor. Then perform the self-diagnosis.

#### 2.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
5. Reconnect connectors and then perform the self-diagnosis. Refer to [BRC-17. "CONSULT-III Function \(ABS\)"](#).

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 3.
- NO >> Poor connection of connector terminal. Repair or replace connector.

#### 3.CHECK WHEEL SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.

# C1115 WHEEL SENSOR

[ABS]

## < COMPONENT DIAGNOSIS >

4. Check continuity between terminals. (Also check continuity when steering wheel is turned right and left and when sensor harness inside the wheel house is moved.)

Measurement terminal for power supply circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E34	9	E39 (Front RH)	2	Existed
	16	E22 (Front LH)		
	8	B41 (Rear RH)		
	6	B44 (Rear LH)		

Measurement terminal for signal circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E34	10	E39 (Front RH)	1	Existed
	5	E22 (Front LH)		
	19	B41 (Rear RH)		
	17	B44 (Rear LH)		

Measurement terminal for ground circuit

ABS actuator and electric unit (control unit)				Continuity
Connector	Terminal	Connector	Terminal	
E34	9, 10	E34	1, 4	Not existed
	16, 5			
	8, 19			
	6, 17			

5. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning components.

## 4.CHECK WHEEL SENSOR POWER SUPPLY CIRCUIT

- Turn ignition switch ON.
- Check voltage between wheel sensor harness connector power supply terminal and ground.

Wheel sensor		—	Voltage
Connector	Terminal		
E39 (Front RH)	2	Ground	8 V or more
E22 (Front LH)			
B41 (Rear RH)			
B44 (Rear LH)			

Is the inspection result normal?

YES >> Replace applicable wheel sensor.

NO >> Replace ABS actuator and electric unit (control unit).

## Component Inspection

INFOID:000000001181648

## 1.CHECK DATA MONITOR

On "DATA MONITOR", select "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR", and "RR RH SENSOR", and check the vehicle speed.

# C1115 WHEEL SENSOR

< COMPONENT DIAGNOSIS >

[ABS]

Wheel sensor	Vehicle speed (DATA MONITOR)
FR LH SENSOR	Nearly matches the speedometer display ( $\pm 10\%$ or less)
FR RH SENSOR	
RR LH SENSOR	
RR RH SENSOR	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-35, "Diagnosis Procedure"](#).

A

B

C

D

E

**BRC**

G

H

I

J

K

L

M

N

O

P

# C1116 STOP LAMP SWITCH

[ABS]

< COMPONENT DIAGNOSIS >

## C1116 STOP LAMP SWITCH

### Description

INFOID:000000001181649

The stop lamp switch transmits the stop lamp switch signal (ON/OFF) to the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000001181650

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1116	STOP LAMP SW	When stop lamp switch circuit is open.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• Stop lamp switch</li><li>• ABS actuator and electric unit (control unit)</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results

STOP LAMP SW

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-38. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000001181651

### INSPECTION PROCEDURE

#### 1.CHECK STOP LAMP ILLUMINATE

Press brake pedal and check stop lamp illuminate.

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace malfunctioning components.

#### 2.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect stop lamp switch connector.
4. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
5. Reconnect connectors securely.
6. Start engine.
7. Repeat pumping brake pedal carefully several times, and perform self-diagnosis.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 3.  
NO >> Poor connection of connector terminal. Replace or repair connector.

#### 3.CHECK STOP LAMP SWITCH

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch connector.
3. Check continuity between stop lamp switch connector terminals.

# C1116 STOP LAMP SWITCH

[ABS]

## < COMPONENT DIAGNOSIS >

Stop lamp switch Terminal	Condition	Continuity
1 - 2	Release stop lamp switch (When brake pedal is depressed.)	Existed
	Push stop lamp switch (When brake pedal is released.)	Not existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace stop lamp switch.

### 4.CHECK STOP LAMP SWITCH CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Connect stop lamp switch connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit) Connector		Terminal	Condition	Voltage
E34				
			Brake pedal is released	Approx. 0 V

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace malfunctioning components.

## Component Inspection

INFOID:000000001181652

### 1.CHECK STOP LAMP SWITCH

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch connector.
3. Check continuity between stop lamp switch connector terminals.

Stop lamp switch Terminal	Condition	Continuity
1 - 2	Release stop lamp switch (When brake pedal is depressed.)	Existed
	Push stop lamp switch (When brake pedal is released.)	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace stop lamp switch.

# C1120, C1122, C1124, C1126 IN ABS SOL

< COMPONENT DIAGNOSIS >

[ABS]

## C1120, C1122, C1124, C1126 IN ABS SOL

### Description

INFOID:000000001181653

The solenoid valve increases, holds or decreases the fluid pressure of each brake caliper according to the signals transmitted by the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000001181654

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1120	FR LH IN ABS SOL	When the control unit detects a malfunction in the front LH inlet solenoid circuit.	ABS actuator and electric unit (control unit)
C1122	FR RH IN ABS SOL	When the control unit detects a malfunction in the front RH inlet solenoid circuit.	
C1124	RR LH IN ABS SOL	When the control unit detects a malfunction in the rear LH inlet solenoid circuit.	
C1126	RR RH IN ABS SOL	When the control unit detects a malfunction in the rear RH inlet solenoid circuit.	

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
FR LH IN ABS SOL
FR RH IN ABS SOL
RR LH IN ABS SOL
RR RH IN ABS SOL

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-40. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000001181655

### INSPECTION PROCEDURE

#### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform the self-diagnosis. Refer to [BRC-17. "CONSULT-III Function \(ABS\)"](#).

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.  
NO >> Poor connection of connector terminal. Replace or repair connector.

#### 2. CHECK ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.



# C1120, C1122, C1124, C1126 IN ABS SOL

< COMPONENT DIAGNOSIS >

[ABS]

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E34	3	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

## 3.CHECK ACUATOR RELAY GROUND CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E34	1, 4	Ground	Existed

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace malfunctioning components.

## Component Inspection

INFOID:000000001181656

### 1.CHECK ACTIVE TEST

1. Select each test menu item on "ACTIVE TEST".
2. On the display, touch "UP", "KEEP", and "DOWN", and check that the system operates as shown in the table below.

Test item	Display item	Display		
		UP	KEEP	DOWN
FR RH SOL	FR RH IN SOL	OFF	ON	ON
	FR RH OUT SOL	OFF	OFF	ON*
FR LH SOL	FR LH IN SOL	OFF	ON	ON
	FR LH OUT SOL	OFF	OFF	ON*
RR RH SOL	RR RH IN SOL	OFF	ON	ON
	RR RH OUT SOL	OFF	OFF	ON*
RR LH SOL	RR LH IN SOL	OFF	ON	ON
	RR LH OUT SOL	OFF	OFF	ON*

\*: ON for 1 to 2 seconds after the touch, and then OFF.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-40, "Diagnosis Procedure"](#).

# C1121, C1123, C1125, C1127 OUT ABS SOL

< COMPONENT DIAGNOSIS >

[ABS]

## C1121, C1123, C1125, C1127 OUT ABS SOL

### Description

INFOID:000000001181657

The solenoid valve increases, holds or decreases the fluid pressure of each brake caliper according to the signals transmitted by the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000001181658

#### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1121	FR LH OUT ABS SOL	When the control unit detects a malfunction in the front LH outlet solenoid circuit.	ABS actuator and electric unit (control unit)
C1123	FR RH OUT ABS SOL	When the control unit detects a malfunction in the front RH outlet solenoid circuit.	
C1125	RR LH OUT ABS SOL	When the control unit detects a malfunction in the rear LH outlet solenoid circuit.	
C1127	RR RH OUT ABS SOL	When the control unit detects a malfunction in the rear RH outlet solenoid circuit.	

#### DTC CONFIRMATION PROCEDURE

##### 1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
FR LH OUT ABS SOL
FR RH OUT ABS SOL
RR LH OUT ABS SOL
RR RH OUT ABS SOL

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-42. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000001181659

#### INSPECTION PROCEDURE

##### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform the self-diagnosis. Refer to [BRC-17. "CONSULT-III Function \(ABS\)"](#).

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.  
NO >> Poor connection of connector terminal. Replace or repair connector.

##### 2. CHECK ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

# C1121, C1123, C1125, C1127 OUT ABS SOL

< COMPONENT DIAGNOSIS >

[ABS]

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E34	3	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

## 3.CHECK ACUATOR RELAY GROUND CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E34	1, 4	Ground	Existed

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace malfunctioning components.

## Component Inspection

INFOID:000000001181660

### 1.CHECK ACTIVE TEST

- Select each test menu item on "ACTIVE TEST".
- On the display, touch "UP", "KEEP", and "DOWN", and check that the system operates as shown in the table below.

Test item	Display item	Display		
		UP	KEEP	DOWN
FR RH SOL	FR RH IN SOL	OFF	ON	ON
	FR RH OUT SOL	OFF	OFF	ON*
FR LH SOL	FR LH IN SOL	OFF	ON	ON
	FR LH OUT SOL	OFF	OFF	ON*
RR RH SOL	RR RH IN SOL	OFF	ON	ON
	RR RH OUT SOL	OFF	OFF	ON*
RR LH SOL	RR LH IN SOL	OFF	ON	ON
	RR LH OUT SOL	OFF	OFF	ON*

\*: ON for 1 to 2 seconds after the touch, and then OFF.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-42. "Diagnosis Procedure"](#).

# U1000 CAN COMM CIRCUIT

< COMPONENT DIAGNOSIS >

[ABS]

## U1000 CAN COMM CIRCUIT

### Description

INFOID:000000001181661

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### DTC Logic

INFOID:000000001181662

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
U1000	CAN COMM CIRCUIT	When ABS actuator and electric unit (control unit) is not transmitting or receiving CAN communication signal for 2 seconds or more.	<ul style="list-style-type: none"><li>CAN communication line</li><li>ABS actuator and electric unit (control unit)</li></ul>

### Diagnosis Procedure

INFOID:000000001181663

#### INSPECTION PROCEDURE

#### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and perform self-diagnosis.

Self-diagnosis results

CAN COMM CIRCUIT

Is above displayed on the self-diagnosis display?

- YES >> Go to [LAN-13. "Trouble Diagnosis Flow Chart"](#).  
NO >> INSPECTION END

# BRAKE FLUID LEVEL SWITCH

[ABS]

< COMPONENT DIAGNOSIS >

## BRAKE FLUID LEVEL SWITCH

### Description

INFOID:000000001181664

The brake fluid level switch converts the brake fluid level to an electric signal and transmits it to the ABS actuator and electric unit (control unit).

### Component Function Check

INFOID:000000001181665

#### 1. CHECK BRAKE FLUID LEVEL SWITCH OPERATION

Operate the brake fluid level switch. Then check that the brake warning lamp in the combination meter turns ON/OFF correctly.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-45, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000001181666

#### INSPECTION PROCEDURE

##### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect brake fluid level switch connector and combination meter connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connectors and then perform component function check. Refer to [BRC-45, "Component Function Check"](#).

Is the inspection result normal?

YES >> Poor connection of connector terminal. Replace or repair connector.

NO >> GO TO 2.

##### 2. CHECK BRAKE FLUID LEVEL SWITCH

1. Turn ignition switch OFF.
2. Disconnect brake fluid level switch connector.
3. Check continuity between brake fluid level switch connector terminals.

Brake fluid level switch		Condition	Continuity
Connector	Terminal		
E37	1 - 2	When brake fluid is full in the reservoir tank.	Not existed
		When brake fluid is empty in the reservoir tank.	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Brake fluid level switch is malfunction. Replace reservoir tank.

##### 3. CHECK BRAKE FLUID LEVEL SWITCH CIRCUIT

1. Disconnect combination meter connector.
2. Check continuity between brake fluid level switch harness connector terminals and combination meter harness connector terminal and/or ground.

Combination meter		Brake fluid level switch		Continuity
Connector	Terminal	Connector	Terminal	
M34	27	E37	1	Existed

# BRAKE FLUID LEVEL SWITCH

[ABS]

## < COMPONENT DIAGNOSIS >

Combination meter		—	Continuity
Connector	Terminal		
M34	27	Ground	Not existed

Brake fluid level switch		—	Continuity
Connector	Terminal		
E37	2	Ground	Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace malfunctioning components.

## Component Inspection

INFOID:000000001181667

### 1. CHECK BRAKE FLUID LEVEL SWITCH

1. Turn ignition switch OFF.
2. Disconnect brake fluid level switch connector.
3. Check continuity between brake fluid level switch connector terminals.

Brake fluid level switch		Condition	Continuity
Connector	Terminal		
E37	1 – 2	When brake fluid is full in the reservoir tank.	Not existed
		When brake fluid is empty in the reservoir tank.	Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace reservoir tank.

# PARKING BRAKE SWITCH

[ABS]

< COMPONENT DIAGNOSIS >

## PARKING BRAKE SWITCH

### Description

INFOID:000000001181668

The parking brake switch converts the status of the parking brake pedal to an electric signal and transmits it to the ABS actuator and electric unit (control unit).

### Diagnosis Procedure

INFOID:000000001181669

#### 1. CHECK COMBINATION METER INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between combination meter harness connector terminal 26 and ground.

26 – Ground	
Parking brake ON	: Approx. 0 V
Parking brake OFF	: Approx. 5 V

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> GO TO 2.

#### 2. CHECK PARKING BRAKE SWITCH SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and parking brake switch connector.
3. Check continuity between combination meter harness connector terminal 26 and parking brake switch harness connector terminal 1.

26 – 1	: Continuity should exist.
--------	----------------------------

4. Check continuity between combination meter harness connector terminal 26 and ground.

26 – Ground	: Continuity should not exist.
-------------	--------------------------------

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Repair harness or connector.

### Component Function Check

INFOID:000000001181670

#### 1. CHECK PARKING BRAKE SWITCH OPERATION

Operate the parking brake pedal. Then check that the brake warning lamp in the combination meter turns on/off correctly.

Condition	Brake warning lamp illumination status
When the parking brake switch is operation	ON
When the parking brake switch is not operation.	OFF

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Go to diagnosis procedure. Refer to [BRC-47, "Diagnosis Procedure"](#).

### Component Inspection

INFOID:000000001181671

#### INSPECTION PROCEDURE

##### 1. CHECK PARKING BRAKE SWITCH

1. Turn ignition switch OFF.
2. Disconnect parking brake switch connector.

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BRC

# PARKING BRAKE SWITCH

< COMPONENT DIAGNOSIS >

[ABS]

3. Check continuity between parking brake switch terminal and ground.

Parking brake switch		—	Condition	Continuity
Connector	Terminal			
M103	1	Ground	When the parking brake switch is operated.	Existed
			When the parking brake switch is not operated.	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace parking brake switch.



# ABS WARNING LAMP

< COMPONENT DIAGNOSIS >

[ABS]

## ABS WARNING LAMP

### Description

INFOID:000000001181672

x: ON –: OFF

Condition	ABS warning lamp
Ignition switch OFF	–
For 1 second after turning ON ignition switch	x
1 second later after turning ON ignition switch	–
ABS function is malfunctioning.	x
EBD function is malfunctioning.	x

### Component Function Check

INFOID:000000001181673

#### 1.CHECK ABS WARNING LAMP OPERATION

Check that the lamp illuminates for approximately 1 second after the ignition switch is turned ON.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-49, "Diagnosis Procedure"](#).

#### Diagnosis Procedure

INFOID:000000001181674

#### 1.CHECK SELF-DIAGNOSIS

Perform ABS actuator and electric unit (control unit) self-diagnosis. Refer to [BRC-17, "CONSULT-III Function \(ABS\)"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check items displayed by self-diagnosis.

#### 2.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-25, "Diagnosis Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace combination meter.

# BRAKE WARNING LAMP

[ABS]

< COMPONENT DIAGNOSIS >

## BRAKE WARNING LAMP

### Description

INFOID:000000001181675

×: ON –: OFF

Condition	Brake warning lamp <sup>NOTE 1</sup>
Ignition switch OFF	–
For 1 second after turning ON ignition switch	× <sup>NOTE 2</sup>
1 second later after turning ON ignition switch	× <sup>NOTE 2</sup>
EBD function is malfunctioning.	×

#### NOTE:

- 1: Brake warning lamp will turn on in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).
- 2: After starting engine, brake warning lamp is turned off.

### Component Function Check

INFOID:000000001181676

#### 1. BRAKE WARNING LAMP OPERATION CHECK 1

Check that the lamp illuminates for approximately 1 second after the ignition switch is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Go to diagnosis procedure. Refer to [BRC-50. "Diagnosis Procedure"](#).

#### 2. BRAKE WARNING LAMP OPERATION CHECK 2

Check that the brake warning lamp in the combination meter turns ON/OFF correctly when operating the parking brake pedal.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check parking brake switch. Refer to [BRC-47. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000001181677

#### 1. CHECK PARKING BRAKE SWITCH

Check that the brake warning lamp in the combination meter turns ON/OFF correctly when operating the parking brake pedal.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check parking brake switch. Refer to [BRC-47. "Diagnosis Procedure"](#).

#### 2. CHECK SELF-DIAGNOSIS

Perform ABS actuator and electric unit (control unit) self-diagnosis.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check items displayed by self-diagnosis.

#### 3. CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-25. "Diagnosis Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace combination meter.

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS >

[ABS]

## ECU DIAGNOSIS

### ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Reference Value

INFOID:000000001181678

VALUES ON THE DIAGNOSIS TOOL

**CAUTION:**

The display shows the control unit calculation data, so a normal value might be displayed even in the event the output circuit (harness) is open or short-circuited.

Monitor item	Condition		Value/Status
FR LH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running <sup>NOTE 1</sup>	Nearly matches the speed meter display (± 10% or less)
FR RH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running <sup>NOTE 1</sup>	Nearly matches the speed meter display (± 10% or less)
RR LH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running <sup>NOTE 1</sup>	Nearly matches the speed meter display (± 10% or less)
RR RH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running <sup>NOTE 1</sup>	Nearly matches the speed meter display (± 10% or less)
STOP LAMP SW	Stop lamp switch signal status	When brake pedal is depressed	On
		When brake pedal is not depressed	Off
BATTERY VOLT	Battery voltage supplied to the ABS actuator and electric unit (control unit)	Ignition switch ON	10 – 16 V
DECEL G SENSOR <sup>NOTE 2</sup>	Decel G detected by decel G sensor	Vehicle on level surface or on slope	On/Off
FR RH IN SOL	Operation status of front RH inlet solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (in fail-safe mode)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
FR RH OUT SOL	Operation status of front RH outlet solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (in fail-safe mode)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
FR LH IN SOL	Operation status of front LH inlet solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (in fail-safe mode)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS >

[ABS]

Monitor item	Condition	Value/Status	
FR LH OUT SOL	Operation status of front LH outlet solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (in fail-safe mode)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
RR RH IN SOL	Operation status of rear RH inlet solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (in fail-safe mode)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
RR RH OUT SOL	Operation status of rear RH outlet solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (in fail-safe mode)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
RR LH IN SOL	Operation status of rear LH inlet solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (in fail-safe mode)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
RR LH OUT SOL	Operation status of rear LH outlet solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (in fail-safe mode)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
MOTOR RELAY	Motor and motor relay operation	When the motor relay and motor are operating	On
		When the motor relay and motor are not operating	Off
ACTUATOR RLY NOTE 3	Actuator relay operation	When the actuator relay is operating	On
		When the actuator relay is not operating	Off
ABS WARN LAMP	ABS warning lamp NOTE 4	When ABS warning lamp is ON	On
		When ABS warning lamp is OFF	Off
EBD SIGNAL	EBD operation	EBD is active	On
		EBD is inactive	Off
ABS SIGNAL	ABS operation	ABS is active	On
		ABS is inactive	Off
EBD FAIL SIG	EBD fail-safe signal	In EBD fail-safe	On
		EBD is normal	Off
ABS FAIL SIG	ABS fail-safe signal	In ABS fail-safe	On
		ABS is normal	Off

**NOTE:**

- 1: Confirm tire pressure is normal.
- 2: Only 4WD models.
- 3: Every 20 seconds momentary switch to OFF.
- 4: On and off timing for warning lamp and indicator lamp. Refer to [BRC-49, "Description"](#).

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)


[ABS]

< ECU DIAGNOSIS >

## Wiring Diagram - BRAKE CONTROL SYSTEM -

INFOID:000000001181679

### BRAKE CONTROL SYSTEM (WITHOUT ESP)



2007/04/27

JCFWA0054GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BRC


# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

[ABS]

< ECU DIAGNOSIS >

## BRAKE CONTROL SYSTEM (WITHOUT ESP)

Connector No.	B11
Connector Name	WIRE TO WIRE
Connector Type	TK10M/W-NSB



Terminal No.	Color of Wire	Signal Name [Specification]
5	G/O	-
6	G/Y	-
7	LG	-
8	P	-[2WD models without ESP]

Connector No.	B41
Connector Name	REAR WHEEL SENSOR RH
Connector Type	RK02FGY




Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
2	P	-[2WD models without ESP]

Connector No.	B44
Connector Name	REAR WHEEL SENSOR LH
Connector Type	RK02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	G/O	-
2	G/Y	-

Connector No.	E13
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	NS18FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
41	P	-

Connector No.	E22
Connector Name	FRONT WHEEL SENSOR LH
Connector Type	RK02MGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	R/L	-[Without ESP]
2	Y	-

Connector No.	E34
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Type	BAA2FB-AH24-LH



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	GND(MTR)
2	Y	+B(MTR)
3	W/R	+B(SOL)
4	B	GND(SOL)
5	R/L	DS FL
6	G/Y	DP RL
8	P	DP RR[2WD models]
9	V	DP RR[4WD models]
10	W	DS FR
11	O	BAG-K

Terminal No.	Color of Wire	Signal Name [Specification]
14	L	AGND
15	P	CAN-L
16	Y	DP FL
17	G/O	DS RL
18	P	IGN
19	LG	DS RR
20	R/W	STOP L SIG
21	W	AX
24	BR	LST
26	L	CAN-H

Connector No.	E37
Connector Name	BRAKE FLUID LEVEL SWITCH
Connector Type	YV02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	R/B	-
2	B	-

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS >

[ABS]


## BRAKE CONTROL SYSTEM (WITHOUT ESP)

Connector No.	E114
Connector Name	STOP LAMP SWITCH
Connector Type	M02FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	W	-

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-NS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
33	BR	-
44	W	-
51	P	-
52	L	-
54	L	-
60	R/B	-
82	V	-
89	O	-

Connector No.	E101
Connector Name	WIRE TO WIRE
Connector Type	TK10FW-NSS



Terminal No.	Color of Wire	Signal Name [Specification]
5	G/O	-
6	G/Y	-
7	LG	-
8	P	-
8	V	-

Connector No.	E114
Connector Name	STOP LAMP SWITCH
Connector Type	M02FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	R/W	-

Connector No.	E115
Connector Name	STOP LAMP SWITCH
Connector Type	M04FW-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	R/W	-
3	O	-
4	B	-

Connector No.	E118
Connector Name	STOP LAMP SWITCH
Connector Type	M04FW-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	R/W	-
3	O	-
4	W/L	-

Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW



Terminal No.	Color of Wire	Signal Name [Specification]
7	O	-

Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	SAB40FW




Terminal No.	Color of Wire	Signal Name [Specification]
21	L	CAN-H
22	P	CAN-L
26	V	PARKING BRAKE SW
27	BR	BRAKE FLUID LEVEL SW

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS >

[ABS]



## Fail-Safe

### ABS, EBD SYSTEM

In case of electrical malfunctions with the ABS, ABS warning lamp will turn ON. In case of electrical malfunctions with the EBD, brake warning lamp, ABS warning lamp will turn ON. Simultaneously, the ABS become one of the following conditions of the fail-safe function.

JCFWA0057GE

INFOID:000000001181680



# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

[ABS]

< ECU DIAGNOSIS >

- For malfunction of ABS, only the EBD is activated and the condition of vehicle is the same condition of vehicles without ABS system.

**NOTE:**

ABS self-diagnosis sound may be heard. That is a normal condition because a self-diagnosis for "Ignition switch ON" and "The first starting" are being performed.

- For malfunction of EBD, EBD and ABS become inoperative, and the condition of vehicle is the same as the condition of vehicles without ABS, EBD system.

## DTC No. Index

INFOID:000000001181681

DTC	Items (CONSULT screen terms)	Reference
C1101	RR RH SENSOR-1	<a href="#">BRC-20, "Description"</a>
C1102	RR LH SENSOR-1	
C1103	FR RH SENSOR-1	
C1104	FR LH SENSOR-1	
C1105	RR RH SENSOR-2	<a href="#">BRC-23, "Description"</a>
C1106	RR LH SENSOR-2	
C1107	FR RH SENSOR-2	
C1108	FR LH SENSOR-2	
C1109	BATTERY VOLTAGE [ABNORMAL]	<a href="#">BRC-26, "Description"</a>
C1110	CONTROLLER FAILURE	<a href="#">BRC-28, "Description"</a>
C1111	PUMP MOTOR	<a href="#">BRC-29, "Description"</a>
C1113	G SENSOR	<a href="#">BRC-31, "Description"</a>
C1114	MAIN RELAY	<a href="#">BRC-33, "Description"</a>
C1115	ABS SENSOR [ABNORMAL SIGNAL]	<a href="#">BRC-35, "Description"</a>
C1116	STOP LAMP SW	<a href="#">BRC-38, "Description"</a>
C1120	FR LH IN ABS SOL	<a href="#">BRC-40, "Description"</a>
C1121	FR LH OUT ABS SOL	<a href="#">BRC-42, "Description"</a>
C1122	FR RH IN ABS SOL	<a href="#">BRC-40, "Description"</a>
C1123	FR RH OUT ABS SOL	<a href="#">BRC-42, "Description"</a>
C1124	RR LH IN ABS SOL	<a href="#">BRC-40, "Description"</a>
C1125	RR LH OUT ABS SOL	<a href="#">BRC-42, "Description"</a>
C1126	RR RH IN ABS SOL	<a href="#">BRC-40, "Description"</a>
C1127	RR RH OUT ABS SOL	<a href="#">BRC-42, "Description"</a>
C1153	EMERGENCY BRAKE	<a href="#">BRC-28, "Description"</a>
U1000	CAN COMM CIRCUIT	<a href="#">BRC-44, "Description"</a>

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

**BRC**

## SYMPTOM DIAGNOSIS

### EXCESSIVE ABS FUNCTION OPERATION FREQUENCY

#### Diagnosis Procedure

INFOID:000000001181682

#### 1. CHECK START

Check front and rear brake force distribution using a brake tester. Refer to [BR-49. "General Specifications"](#) (LHD models), [BR-96. "General Specifications"](#) (RHD models).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Check brake system.

#### 2. CHECK FRONT AND REAR AXLE

Make sure that there is no excessive play in the front and rear axles.

- Front: [FAX-7. "Inspection"](#) (2WD models), [FAX-59. "Inspection"](#) (4WD models)
- Rear: [RAX-3. "Inspection"](#) (2WD models), [RAX-9. "Inspection"](#) (4WD models)

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace malfunctioning components.

#### 3. CHECK WHEEL SENSOR AND SENSOR ROTOR

Check the following.

- Wheel sensor installation for damage.
- Sensor rotor installation for damage.
- Wheel sensor connector connection.
- Wheel sensor harness inspection.

Is the inspection result normal?

- YES >> GO TO 4.
- NO >>
  - Replace wheel sensor or sensor rotor.
  - Repair harness.

#### 4. CHECK ABS WARNING LAMP DISPLAY

Make sure that the ABS warning lamp is turned off after the ignition switch is turned ON or when driving.

Is the ABS warning lamp illuminated?

- YES >> Perform self-diagnosis. Refer to [BRC-17. "CONSULT-III Function \(ABS\)"](#).
- NO >> INSPECTION END

# UNEXPECTED PEDAL REACTION

< SYMPTOM DIAGNOSIS >

[ABS]

## UNEXPECTED PEDAL REACTION

### Diagnosis Procedure

INFOID:000000001181683

#### 1.CHECK BRAKE PEDAL STROKE

Check brake pedal stroke. Refer to [BR-8, "Inspection and Adjustment"](#) (LHD models), [BR-55, "Inspection and Adjustment"](#) (RHD models).

Is the stroke too large?

- YES >>
- Bleed air from brake tube and hose. Refer to [BR-12, "Bleeding Brake System"](#) (LHD models), [BR-59, "Bleeding Brake System"](#) (RHD models).
  - Check brake pedal, brake booster, and master cylinder for mount play, looseness, brake system fluid leakage, etc.
    - Brake pedal: [BR-17, "Exploded View"](#) (LHD models), [BR-64, "Exploded View"](#) (RHD models).
    - Brake booster: [BR-30, "Exploded View"](#) (LHD models), [BR-77, "Exploded View"](#) (RHD models).
    - Brake master cylinder: [BR-27, "Exploded View"](#) (LHD models), [BR-74, "Exploded View"](#) (RHD models).
    - Brake fluid: [BR-11, "Inspection"](#) (LHD models), [BR-58, "Inspection"](#) (RHD models).

NO >> GO TO 2.

#### 2.CHECK FUNCTION

Disconnect ABS actuator and electric unit (control unit) connector to deactivate ABS. Check if braking force is normal in this condition. Connect connector after inspection.

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Check brake system.

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## THE BRAKING DISTANCE IS LONG

< SYMPTOM DIAGNOSIS >

[ABS]

---

### THE BRAKING DISTANCE IS LONG

#### Diagnosis Procedure

INFOID:000000001181684

**CAUTION:**

The stopping distance on slippery road surfaces might be longer with the ABS operating than when the ABS is not operating.

**1**.CHECK FUNCTION

---

Turn ignition switch OFF and disconnect ABS actuator and electric unit (control unit) connector to deactivate ABS. In this condition, check stopping distance. After inspection, connect connector.

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Check brake system.

# ABS FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[ABS]

## ABS FUNCTION DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000001181685

**CAUTION:**

**ABS does not operate when speed is 10 km/h (6 MPH) or lower.**

**1**.CHECK ABS WARNING LAMP DISPLAY

Make sure that the ABS warning lamp turns OFF after ignition switch is turned ON or when driving.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Perform self-diagnosis. Refer to [BRC-17, "CONSULT-III Function \(ABS\)".](#)

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

**BRC**

# PEDAL VIBRATION OR ABS OPERATION SOUND OCCURS

< SYMPTOM DIAGNOSIS >

[ABS]

## PEDAL VIBRATION OR ABS OPERATION SOUND OCCURS

### Diagnosis Procedure

INFOID:000000001181686

#### **CAUTION:**

Under the following conditions, ABS is activated and vibration is felt when brake pedal is lightly depressed (just place a foot on it). However, this is normal.

- When shifting gears
- When driving on slippery road
- During cornering at high speed
- When passing over bumps or grooves [at approximately 50 mm (1.97 in) or more]
- When pulling away just after starting engine [at approximately 10 km/h (6 MPH) or higher]

#### 1. SYMPTOM CHECK 1

Check that there are pedal vibrations when the engine is started.

Do vibrations occur?

YES >> GO TO 2.

NO >> Inspect the brake pedal.

#### 2. SYMPTOM CHECK 2

Check that there are ABS operation noises when the engine is started.

Do the operation noises occur?

YES >> GO TO 3.

NO >> Perform self-diagnosis. Refer to [BRC-17, "CONSULT-III Function \(ABS\)"](#).

#### 3. SYMPTOM CHECK 3

Check symptoms when electrical component (headlamps, etc.) switches are operated.

Do symptoms occur?

YES >> Check if there is a radio, antenna, antenna lead wire, or wiring close to the control unit. If there is, move it farther away.

NO >> INSPECTION END

# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[ABS]

## NORMAL OPERATING CONDITION

### Description

INFOID:000000001181687

Symptom	Result
Slight vibrations are felt on the brake pedal and the operation noises occur, when ABS is activated.	This is a normal condition due to the ABS activation.
Stopping distance is longer than that of vehicles without ABS when the vehicle drives on rough, gravel, or snow-covered (fresh, deep snow) roads.	
The brake pedal vibrates and motor operation noises occur from the engine room, after the engine starts and just after the vehicle starts.	This is a normal, and it is caused by the ABS operation check.

A

B

C

D

E

**BRC**

G

H

I

J

K

L

M

N

O

P

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000001583058

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIRBAG" and "SEAT BELT" of this Service Manual.

**WARNING:**

- **To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.**
- **Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIRBAG".**
- **Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.**


#### Precaution for Brake System

INFOID:000000001181689

**WARNING:**

**Clean brake pads and shoes with a waste cloth, then wipe with a dust collector.**

- Only use DOT 3 brake fluid. Refer to [MA-27, "Fluids and Lubricants"](#).
- Never to reuse drained brake fluid.
- Never to spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface.
- Never to use mineral oils such as gasoline or light oil. They may damage rubber parts and cause improper operation.
- Always loosen the brake tube flare nut with a flare nut wrench.
- Tighten the brake tube flare nut to the specified torque with a flare nut torque wrench.
- Always conform the specified tightening torque when installing the brake pipes.
- Brake system is an important safety part. If a brake fluid leak is detected, always disassemble the affected part. If a malfunction is detected, replace part with a new one.
- Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) connector or the battery negative terminal before performing the work.



#### Precaution for Brake Control

INFOID:000000001181690

- Just after starting vehicle after ignition switch ON, brake pedal may vibrate or motor operating noise may be heard from engine compartment. This is normal condition.
- When an error is indicated by ABS or another warning lamp, collect all necessary information from customer (what symptoms are present under what conditions) and check for simple causes before starting diagnostic servicing. Besides electrical system inspection, check brake booster operation, brake fluid level, and oil leaks.
- If tire size and type are used in an improper combination, or brake pads are not Genuine NISSAN parts, stopping distance or steering stability may deteriorate.
- ABS might be out of order or malfunctions by putting a radio (wiring inclusive), an antenna and a lead-in wire near the control unit.
- If aftermarket parts (car stereo, CD player, etc.) have been installed, check for incidents such as harness pinches, open circuits, and improper wiring.



# PREPARATION

< PREPARATION >


[ABS]

## PREPARATION

### PREPARATION

#### Special Service Tool

INFOID:000000001181691

Tool number Tool name	Description
<p>GG94310000 Flare nut torque wrench a: 10 mm (0.39 in)/ 12 mm (0.47 in)</p>  <p>S-NT406</p>	<p>Installing each brake piping</p>

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P


## ON-VEHICLE REPAIR

### WHEEL SENSOR

#### FRONT WHEEL SENSOR

#### FRONT WHEEL SENSOR : Exploded View

INFOID:000000001181692



1. Front LH wheel sensor

A. White line (slant line)

Refer to GI section [GI-4, "Components"](#) for symbols in the figure.

**NOTE:**

The above figure (front side) shows left side. Right side is the mirror image.

#### FRONT WHEEL SENSOR : Removal and Installation

INFOID:000000001181693

##### REMOVAL

Pay attention to the following when removing sensor.

**CAUTION:**

- Do not twist sensor harness as much as possible, when removing it. Pull sensors out without pulling on sensor harness.
- Take care to avoid damaging sensor edges or rotor teeth. Remove wheel sensor first before removing front or rear wheel hub. This is to avoid damage to sensor wiring and loss of sensor function.
- When you see the harness of the wheel sensor from the front side of the vehicle ensure that the white lines (A) are not twisted.

##### INSTALLATION

Pay attention to the following when installing wheel sensor. Tighten installation bolts to the specified torques. Refer to [BRC-66, "FRONT WHEEL SENSOR : Exploded View"](#).

- When installing, make sure there is no foreign material such as iron chips on and in the mounting hole of the wheel sensor. Make sure no foreign material has been caught in the sensor rotor. Remove any foreign material and clean the mount.
- When installing wheel sensor, be sure to press rubber grommets in until they lock at locations shown above in the figure. When installed, harness must not be twisted.

#### REAR WHEEL SENSOR


# WHEEL SENSOR

< ON-VEHICLE REPAIR >

[ABS]

## REAR WHEEL SENSOR : Exploded View

INFOID:000000001181694



1. Rear LH wheel sensor

A. 2WD models

B. 4WD models

Refer to GI section [GI-4, "Components"](#) for symbols in the figure.

### NOTE:

The above figure (front side) shows left side. Right side is the mirror image.

## REAR WHEEL SENSOR : Removal and Installation

INFOID:000000001181695

### REMOVAL

Pay attention to the following when removing sensor.

#### CAUTION:

- Do not twist sensor harness as much as possible, when removing it. Pull sensors out without pulling on sensor harness.
- Take care to avoid damaging sensor edges or rotor teeth. Remove wheel sensor first before removing front or rear wheel hub. This is to avoid damage to sensor wiring and loss of sensor function.

### INSTALLATION

Pay attention to the following when installing wheel sensor. Tighten installation bolts to the specified torques. Refer to [BRC-67, "REAR WHEEL SENSOR : Exploded View"](#).

- When installing, make sure there is no foreign material such as iron chips on and in the mounting hole of the wheel sensor. Make sure no foreign material has been caught in the sensor rotor. Remove any foreign material and clean the mount.
- When installing wheel sensor, be sure to press rubber grommets in until they lock at locations shown above in the figure. When installed, harness must not be twisted.

# SENSOR ROTOR

[ABS]

< ON-VEHICLE REPAIR >

## SENSOR ROTOR FRONT SENSOR ROTOR

### FRONT SENSOR ROTOR : Exploded View

INFOID:000000001181696

Refer to [FAX-9, "Exploded View"](#) (2WD models), [FAX-61, "Exploded View"](#) (4WD models).

### FRONT SENSOR ROTOR : Removal and Installation

INFOID:000000001181697

#### REMOVAL

Sensor rotor cannot be disassembled. Remove the sensor rotor together with wheel hub and bearing assembly. Refer to [FAX-9, "Removal and Installation"](#) (2WD models), [FAX-61, "Removal and Installation"](#) (4WD models).

#### INSTALLATION

Sensor rotor cannot be disassembled. Installation the sensor rotor together with wheel hub and bearing assembly. Refer to [FAX-9, "Removal and Installation"](#) (2WD models), [FAX-61, "Removal and Installation"](#) (4WD models).

## REAR SENSOR ROTOR

### REAR SENSOR ROTOR : Exploded View

INFOID:000000001181698

Refer to [RAX-4, "Exploded View"](#) (2WD models), [RAX-13, "Exploded View"](#) (4WD models).

### REAR SENSOR ROTOR : Removal and Installation

INFOID:000000001181699

#### 2WD MODELS

##### Removal

Sensor rotor cannot be disassembled. Remove the sensor rotor together with wheel hub and bearing assembly. Refer to [RAX-4, "Removal and Installation"](#).

##### Installation

Sensor rotor cannot be disassembled. Installation the sensor rotor together with wheel hub and bearing assembly. Refer to [RAX-4, "Removal and Installation"](#).

#### 4WD MODELS

For removal and installation of sensor rotor, refer to [RAX-14, "Disassembly and Assembly"](#).

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

[ABS]


< ON-VEHICLE REPAIR >

## ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Exploded View

INFOID:000000001181700

LHD models



- |  |  |                                      |
|--|--|--------------------------------------|
| 1. ABS actuator and electric unit (control unit) | 2. Connector                           | 3. Bushing                           |
| 4. Bracket                                       |  |                                      |
| A. To front LH brake caliper                     | B. To rear RH brake caliper            | C. To Rear LH brake caliper          |
| D. To front RH brake caliper                     | E. From master cylinder secondary side | F. From master cylinder primary side |

⇐: Vehicle front

Refer to GI section [GI-4. "Components"](#) for symbols in the figure.


A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ON-VEHICLE REPAIR >

[ABS]

RHD models



1. ABS actuator and electric unit (control unit)
  2. Connector
  3. Bushing
  4. Bracket
- A. To front LH brake caliper      B. To rear RH brake caliper      C. To Rear LH brake caliper  
D. To front RH brake caliper      E. From master cylinder secondary side      F. From master cylinder primary side

←: Vehicle front

Refer to GI section [GI-4. "Components"](#) for symbols in the figure.

## Removal and Installation

INFOID:000000001181701

### LHD MODELS

#### Removal

#### CAUTION:

- Before servicing, disconnect the battery cable from negative terminal.
- To remove brake tube, use a flare nut wrench to prevent flare nuts and brake tube from being damaged. To install, use flare nut crowfoot and torque wrench.
- Do not apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.
- Do not remove and install actuator by holding harness.
- After work is completed, bleed air from brake tube. Refer to [BR-12. "Bleeding Brake System"](#) (LHD models), [BR-59. "Bleeding Brake System"](#) (RHD models).

1. Remove cowl top cover. Refer to [EXT-19. "Exploded View"](#).
2. Remove exhaust manifold.
  - HR16DE: [EX-5. "Exploded View"](#).
  - MR20DE: [EX-10. "Exploded View"](#).
  - K9K: [EX-15. "Exploded View"](#).
  - M9R: [EM-369. "Exploded View"](#).
3. Disconnect ABS actuator and electric unit (control unit) connector.
4. Loosen brake tube flare nuts, then remove brake tubes from ABS actuator and electric unit (control unit).
5. Remove ABS actuator and electric unit (control unit) bracket mounting nut.
6. Remove ABS actuator and electric unit (control unit) from vehicle.

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

[ABS]

< ON-VEHICLE REPAIR >

## Installation

Note the following, and install in the reverse order of removal.

### CAUTION:

- Before servicing, disconnect the battery cable from negative terminal.
- To remove brake tube, use a flare nut wrench to prevent flare nuts and brake tube from being damaged. To install, use flare nut crowfoot and torque wrench.
- Do not apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.
- Do not remove and install actuator by holding harness.
- After work is completed, bleed air from brake tube. Refer to [BR-12, "Bleeding Brake System"](#) (LHD models), [BR-59, "Bleeding Brake System"](#) (RHD models).
- After installing harness connector in the ABS actuator and electric unit (control unit), make sure connector is securely locked.

## RHD MODELS

## Removal

### CAUTION:

- Before servicing, disconnect the battery cable from negative terminal.
  - To remove brake tube, use a flare nut wrench to prevent flare nuts and brake tube from being damaged. To install, use flare nut crowfoot and torque wrench.
  - Do not apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.
  - Do not remove and install actuator by holding harness.
  - After work is completed, bleed air from brake tube. Refer to [BR-12, "Bleeding Brake System"](#) (LHD models), [BR-59, "Bleeding Brake System"](#) (RHD models).
1. Remove cowl top cover. Refer to [EXT-19, "Exploded View"](#).
  2. Remove air cleaner and air duct.
    - HR16DE: [EM-28, "Exploded View"](#).
    - MR20DE: [EM-145, "Exploded View"](#).
    - K9K: [EM-266, "Exploded View"](#).
    - M9R: [EM-354, "Exploded View"](#).
  3. Disconnect ABS actuator and electric unit (control unit) connector.
  4. Loosen brake tube flare nuts, then remove brake tubes from ABS actuator and electric unit (control unit).
  5. Remove ABS actuator and electric unit (control unit) bracket mounting nut.
  6. Remove ABS actuator and electric unit (control unit) from vehicle.

## Installation

Note the following, and install in the reverse order of removal.

### CAUTION:

- Before servicing, disconnect the battery cable from negative terminal.
- To remove brake tube, use a flare nut wrench to prevent flare nuts and brake tube from being damaged. To install, use flare nut crowfoot and torque wrench.
- Do not apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.
- Do not remove and install actuator by holding harness.
- After work is completed, bleed air from brake tube. Refer to [BR-12, "Bleeding Brake System"](#) (LHD models), [BR-59, "Bleeding Brake System"](#) (RHD models).
- After installing harness connector in the ABS actuator and electric unit (control unit), make sure connector is securely locked.

# G SENSOR


< ON-VEHICLE REPAIR >

[ABS]

## G SENSOR

### Exploded View

INFOID:000000001181702



1. G sensor

↔: Vehicle front

Refer to GI section [GI-4, "Components"](#) for symbols in the figure.

### Removal and Installation

INFOID:000000001181703

#### REMOVAL

##### **CAUTION:**

- Do not drop or strike G sensor, because it has little endurance to impact.
- Do not use power tool etc., because G sensor is sensitive for the impact.

1. Remove lower instrument cover RH. Refer to [IP-11, "Exploded View"](#).
2. Disconnect G sensor harness connector.
3. Remove mounting nuts. Remove G sensor.

#### INSTALLATION

Note the following, and install in the reverse order of removal.

##### **CAUTION:**

- Do not drop or strike G sensor, because it has little endurance to impact.
- Do not use power tool etc., because G sensor is sensitive for the impact.



# BASIC INSPECTION

## DIAGNOSIS AND REPAIR WORKFLOW

### Work Flow

INFOID:000000001181704

### PRECAUTIONS FOR DIAGNOSIS

If steering angle sensor, steering system parts, suspension system parts, ABS actuator and electric unit (control unit) or tires have been replaced, or if wheel alignment has been adjusted, be sure to adjust neutral position of steering angle sensor before driving. Refer to [BRC-77, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

- A
- B
- C
- D
- E
- F
- G
- H
- I
- J
- K
- L
- M
- N
- O
- P


**BRC**

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[ESP/TCS/ABS]

## OVERALL SEQUENCE



### DETAILED FLOW

#### 1. COLLECT THE INFORMATION FROM THE CUSTOMER

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred) using the diagnosis worksheet. Refer to [BRC-76, "Diagnostic Work Sheet"](#).

>> GO TO 2.

# DIAGNOSIS AND REPAIR WORKFLOW

[ESP/TCS/ABS]

< BASIC INSPECTION >

## 2. PERFORM THE SELF-DIAGNOSIS

Check the DTC display with the self-diagnosis function. Refer to [BRC-95. "CONSULT-III Function \(ABS\)".](#)

Is there any DTC displayed?

YES >> GO TO 3.

NO >> GO TO 4.

## 3. PERFORM THE SYSTEM DIAGNOSIS

Perform the diagnosis applicable to the displayed DTC. Refer to [BRC-159. "DTC No. Index".](#)

>> GO TO 7.

## 4. CHECK THE SYMPTOM THAT IS NOT CONSIDERED A SYSTEM MALFUNCTION

Check that the symptom is a normal operation that is not considered a system malfunction. Refer to [BRC-167. "Description".](#)

Is the symptom is a normal operation?

YES >> INSPECTION END

NO >> GO TO 5.

## 5. CHECK THE WARNING LAMP AND INDICATOR LAMP FOR ILLUMINATION

Check that the warning lamp and indicator lamp illuminate.

- ABS warning lamp: Refer to [BRC-148. "Description".](#)
- Brake warning lamp: Refer to [BRC-149. "Description".](#)
- ESP OFF indicator lamp: Refer to [BRC-150. "Description".](#)
- SLIP indicator lamp: Refer to [BRC-151. "Description".](#)

Is ON/OFF timing normal?

YES >> GO TO 6.

NO >> GO TO 2.

## 6. PERFORM THE DIAGNOSIS BY SYMPTOM

Perform the diagnosis applicable to the symptom.

>> GO TO 7.

## 7. REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 8.

## 8. FINAL CHECK

Perform the self-diagnosis again, and check that the malfunction is repaired completely. After checking, erase the self-diagnosis memory. Refer to [BRC-95. "CONSULT-III Function \(ABS\)".](#)

Is any DTC indicated?

YES >> GO TO 3.

NO >> INSPECTION END

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[ESP/TCS/ABS]

## Diagnostic Work Sheet

INFOID:000000001181705

Customer name MR/MS	Model & Year	VIN	
Engine #	Trans.	Mileage	
Incident Date	Manuf. Date	In Service Date	
Symptoms	<input type="checkbox"/> Noise and vibration (from engine compartment) <input type="checkbox"/> Noise and vibration (from axle)	<input type="checkbox"/> Warning / Indicator activate	<input type="checkbox"/> Firm pedal operation Large stroke pedal operation
	<input type="checkbox"/> TCS does not work (Rear wheels slip when accelerating)	<input type="checkbox"/> ABS does not work (Wheels lock when braking)	<input type="checkbox"/> Lack of sense of acceleration
Engine conditions	<input type="checkbox"/> When starting <input type="checkbox"/> After starting		
Road conditions	<input type="checkbox"/> Low friction road ( <input type="checkbox"/> Snow <input type="checkbox"/> Gravel <input type="checkbox"/> Other ) <input type="checkbox"/> Bumps / potholes		
Driving conditions	<input type="checkbox"/> Full-acceleration <input type="checkbox"/> High speed cornering <input type="checkbox"/> Vehicle speed: Greater than 10 km/h (6 MPH) <input type="checkbox"/> Vehicle speed: 10 km/h (6 MPH) or less <input type="checkbox"/> Vehicle is stopped		
Applying brake conditions	<input type="checkbox"/> Suddenly <input type="checkbox"/> Gradually		
Other conditions	<input type="checkbox"/> Operation of electrical equipment <input type="checkbox"/> Shift change <input type="checkbox"/> Other descriptions		

SFIA3265E

## INSPECTION AND ADJUSTMENT

### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

#### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:000000001181706

After replacing the ABS actuator and electric unit (control unit), perform the neutral position adjustment for the steering angle sensor.

#### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement

INFOID:000000001181707

### 1. PERFORM THE NEUTRAL POSITION ADJUSTMENT FOR THE STEERING ANGLE SENSOR

Perform the neutral position adjustment for the steering angle sensor.

>> Refer to [BRC-77, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

## ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

### ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description

INFOID:000000001181708

In case of doing work that applies to the list below, make sure to adjust neutral position of steering angle sensor before running vehicle.

x: Required –: Not required

Situation	Adjustment of steering angle sensor neutral position
Removing/Installing ABS actuator and electric unit (control unit)	—
Replacing ABS actuator and electric unit (control unit)	x
Removing/Installing steering angle sensor	x
Replacing steering angle sensor	x
Removing/Installing steering components	x
Replacing steering components	x
Removing/Installing suspension components	x
Replacing suspension components	x
Change tires to new ones	—
Tire rotation	—
Adjusting wheel alignment	x

### ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement

INFOID:000000001181709

## ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

### **CAUTION:**

**To adjust neutral position of steering angle sensor, make sure to use CONSULT-III. (Adjustment cannot be done without CONSULT-III).**

### 1. ALIGN THE VEHICLE STATUS

Stop vehicle with front wheels in straight-ahead position.

>> GO TO 2.

### 2. PERFORM THE NEUTRAL POSITION ADJUSTMENT FOR THE STEERING ANGLE SENSOR

1. On the CONSULT-III screen, touch "WORK SUPPORT" and "ST ANG SENS ADJUSTMENT" in order.
2. Touch "START".

&lt; BASIC INSPECTION &gt;

**CAUTION:****Do not touch steering wheel while adjusting steering angle sensor.**

3. After approximately 10 seconds, touch "END".

**NOTE:**

After approximately 60 seconds, it ends automatically.

4. Turn ignition switch OFF, then turn it ON again.

**CAUTION:****Be sure to perform above operation.**

&gt;&gt; GO TO 3.

**3. CHECK DATA MONITOR**

1. Run vehicle with front wheels in straight-ahead position, then stop.
2. Select "DATA MONITOR". Then make sure "STR ANGLE SIG" is within  $0 \pm 2.5^\circ$ .

Is the steering angle within the specified range?

YES &gt;&gt; GO TO 4.

NO &gt;&gt; Perform the neutral position adjustment for the steering angle sensor again, GO TO 1.

**4. ERASE THE SELF-DIAGNOSIS MEMORY**

Erase the self-diagnosis memories of the ABS actuator and electric unit (control unit) and ECM.

- ABS actuator and electric unit (control unit): Refer to [BRC-95, "CONSULT-III Function \(ABS\)"](#).
- ECM
  - HR16DE (With EURO-OBD): [ECH-89, "CONSULT-III Function"](#).
  - HR16DE (Without EURO-OBD): [ECH-419, "CONSULT-III Function"](#).
  - MR20DE (With EURO-OBD): [ECM-91, "CONSULT-III Function"](#).
  - MR20DE (Without EURO-OBD): [ECM-425, "CONSULT-III Function"](#).
  - K9K: [ECK-63, "Diagnosis Description"](#).
  - M9R: [ECR-101, "CONSULT-III Function"](#).

Are the memories erased?


YES &gt;&gt; INSPECTION END

NO &gt;&gt; Check the items indicated by the self-diagnosis.

# FUNCTION DIAGNOSIS

## ESP

### System Diagram




### System Description

INFOID:000000001181711

- Electronic Stability Program system detects driver's steering operation amount and brake pedal travel from steering angle sensor and pressure sensor. Using information from yaw rate sensor, G sensor and wheel sensor, ESP judges driving condition (conditions of under steer and over steer) to improve vehicle driving stability by controlling brake application to 4 wheels and engine output.
- During ESP operation, it informs driver of system operation by flashing SLIP indicator lamp.
- Electrical system diagnosis by CONSULT-III is available.

LHD models



- |                           |                           |  |
|---------------------------|---------------------------|--|
| 1. Steering angle sensor  | 2. ABS warning lamp       | 3. Brake warning lamp                            |
| 4. ESP OFF indicator lamp | 5. SLIP indicator lamp    | 6. ABS actuator and electric unit (control unit) |
| 7. Front wheel sensor     | 8. Yaw rate/side G sensor | 9. ESP OFF switch                                |




# ESP

[ESP/TCS/ABS]

## < FUNCTION DIAGNOSIS >

- |                                    |                                    |                                  |
|------------------------------------|------------------------------------|----------------------------------|
| 10. Rear wheel sensor (2WD models) | 11. Rear wheel sensor (4WD models) |                                  |
| A. Back of spiral cable assembly   | B. Combination meter               | C. Right side in engine room     |
| D. Steering knuckle                | E. Lower instrument cover RH       | F. Instrument driver lower panel |
| G. Rear suspension arm             |                                    |                                  |

### RHD models



A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

**< FUNCTION DIAGNOSIS >**

- |                                    |                                    |  |
|------------------------------------|------------------------------------|--|
| 1. Steering angle sensor           | 2. ABS warning lamp                | 3. Brake warning lamp                            |
| 4. ESP OFF indicator lamp          | 5. SLIP indicator lamp             | 6. ABS actuator and electric unit (control unit) |
| 7. Front wheel sensor              | 8. Yaw rate/side G sensor          | 9. ESP OFF switch                                |
| 10. Rear wheel sensor (2WD models) | 11. Rear wheel sensor (4WD models) |  |
| A. Back of spiral cable assembly   | B. Combination meter               | C. Left side in engine room                      |
| D. Steering knuckle                | E. Lower instrument cover RH       | F. Instrument driver lower panel                 |
| G. Rear suspension arm             |                                    |  |


## Component Description

INFOID:000000001181713

Component parts	Reference	
ABS actuator and electric unit (control unit)	Pump	<a href="#">BRC-109, "Description"</a>
	Motor	
	Actuator relay (Main relay)	<a href="#">BRC-112, "Description"</a>
	Solenoid valve	<a href="#">BRC-120, "Description"</a>
	Pressure sensor	<a href="#">BRC-127, "Description"</a>
	ESP switch-over valve (USV1, USV2, HSV1, HSV2)	<a href="#">BRC-137, "Description"</a>
Wheel sensor	<a href="#">BRC-99, "Description"</a>	
Yaw rate sensor	<a href="#">BRC-132, "Description"</a>	
G sensor	<a href="#">BRC-135, "Description"</a>	
Steering angle sensor	<a href="#">BRC-129, "Description"</a>	
ESP OFF switch	<a href="#">BRC-146, "Description"</a>	
ABS warning lamp	<a href="#">BRC-148, "Description"</a>	
Brake warning lamp	<a href="#">BRC-149, "Description"</a>	
ESP OFF indicator lamp	<a href="#">BRC-150, "Description"</a>	
SLIP indicator lamp	<a href="#">BRC-151, "Description"</a>	

## TCS

## System Diagram




## System Description

INFOID:000000001181715

- Traction Control System is a function that electronically controls engine torque, brake fluid pressure and gear ratio (except M/T) to ensure the optimum slippage ratio at drive wheels by computing wheel speed signals from 4 wheel sensors. When ABS actuator and electric unit (control unit) detects a spin at drive wheels (rear wheels), it compares wheel speed signals from all 4 wheels. At this time, LH and RH rear brake fluid pressure are controlled, while fuel being cut to engine and throttle valve being closed to reduce engine torque by the control unit. Further more, throttle position is continuously controlled to ensure the optimum engine torque at all times.
- During TCS operation, it informs driver of system operation by flashing SLIP indicator lamp.
- Electrical system diagnosis by CONSULT-III is available.

LHD models



- |                           |                           |  |
|---------------------------|---------------------------|--|
| 1. Steering angle sensor  | 2. ABS warning lamp       | 3. Brake warning lamp                            |
| 4. ESP OFF indicator lamp | 5. SLIP indicator lamp    | 6. ABS actuator and electric unit (control unit) |
| 7. Front wheel sensor     | 8. Yaw rate/side G sensor | 9. ESP OFF switch                                |


# TCS

[ESP/TCS/ABS]

## < FUNCTION DIAGNOSIS >

- |                                    |                                    |                                  |
|------------------------------------|------------------------------------|----------------------------------|
| 10. Rear wheel sensor (2WD models) | 11. Rear wheel sensor (4WD models) |                                  |
| A. Back of spiral cable assembly   | B. Combination meter               | C. Right side in engine room     |
| D. Steering knuckle                | E. Lower instrument cover RH       | F. Instrument driver lower panel |
| G. Rear suspension arm             |                                    |                                  |

### RHD models



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BRC

**< FUNCTION DIAGNOSIS >**

- |                                    |                                    |  |
|------------------------------------|------------------------------------|--|
| 1. Steering angle sensor           | 2. ABS warning lamp                | 3. Brake warning lamp                            |
| 4. ESP OFF indicator lamp          | 5. SLIP indicator lamp             | 6. ABS actuator and electric unit (control unit) |
| 7. Front wheel sensor              | 8. Yaw rate/side G sensor          | 9. ESP OFF switch                                |
| 10. Rear wheel sensor (2WD models) | 11. Rear wheel sensor (4WD models) |  |
| A. Back of spiral cable assembly   | B. Combination meter               | C. Left side in engine room                      |
| D. Steering knuckle                | E. Lower instrument cover RH       | F. Instrument driver lower panel                 |
| G. Rear suspension arm             |                                    |  |

## Component Description


INFOID:000000001181717

Component parts	Reference	
ABS actuator and electric unit (control unit)	Pump	<a href="#">BRC-109, "Description"</a>
	Motor	
	Actuator relay (Main relay)	<a href="#">BRC-112, "Description"</a>
	Solenoid valve	<a href="#">BRC-120, "Description"</a>
	Pressure sensor	<a href="#">BRC-127, "Description"</a>
	ESP switch-over valve (USV1, USV2, HSV1, HSV2)	<a href="#">BRC-137, "Description"</a>
Wheel sensor	<a href="#">BRC-99, "Description"</a>	
Yaw rate sensor	<a href="#">BRC-132, "Description"</a>	
G sensor	<a href="#">BRC-135, "Description"</a>	
Steering angle sensor	<a href="#">BRC-129, "Description"</a>	
ESP OFF switch	<a href="#">BRC-146, "Description"</a>	
ABS warning lamp	<a href="#">BRC-148, "Description"</a>	
Brake warning lamp	<a href="#">BRC-149, "Description"</a>	
ESP OFF indicator lamp	<a href="#">BRC-150, "Description"</a>	
SLIP indicator lamp	<a href="#">BRC-151, "Description"</a>	

ABS

System Diagram

INFOID:000000001181718




A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

System Description

INFOID:000000001181719

- Anti-Lock Braking System is a function that detects wheel revolution while braking, electronically controls braking force, and prevents wheel locking during sudden braking. It improves handling stability and maneuverability for avoiding obstacles.
- Electrical system diagnosis by CONSULT-III is available.

LHD models



- |                           |                           |  |
|---------------------------|---------------------------|--|
| 1. Steering angle sensor  | 2. ABS warning lamp       | 3. Brake warning lamp                            |
| 4. ESP OFF indicator lamp | 5. SLIP indicator lamp    | 6. ABS actuator and electric unit (control unit) |
| 7. Front wheel sensor     | 8. Yaw rate/side G sensor | 9. ESP OFF switch                                |




# ABS

## < FUNCTION DIAGNOSIS >

[ESP/TCS/ABS]

- 10. Rear wheel sensor (2WD models)
- 11. Rear wheel sensor (4WD models)
- A. Back of spiral cable assembly
- B. Combination meter
- C. Right side in engine room
- D. Steering knuckle
- E. Lower instrument cover RH
- F. Instrument driver lower panel
- G. Rear suspension arm

### RHD models



A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# ABS

## < FUNCTION DIAGNOSIS >

[ESP/TCS/ABS]

- |                                    |                                    |  |
|------------------------------------|------------------------------------|--|
| 1. Steering angle sensor           | 2. ABS warning lamp                | 3. Brake warning lamp                            |
| 4. ESP OFF indicator lamp          | 5. SLIP indicator lamp             | 6. ABS actuator and electric unit (control unit) |
| 7. Front wheel sensor              | 8. Yaw rate/side G sensor          | 9. ESP OFF switch                                |
| 10. Rear wheel sensor (2WD models) | 11. Rear wheel sensor (4WD models) |  |
| A. Back of spiral cable assembly   | B. Combination meter               | C. Left side in engine room                      |
| D. Steering knuckle                | E. Lower instrument cover RH       | F. Instrument driver lower panel                 |
| G. Rear suspension arm             |                                    |  |

## Component Description


INFOID:000000001181721

Component parts		Reference
ABS actuator and electric unit (control unit)	Pump	<a href="#">BRC-109, "Description"</a>
	Motor	
	Actuator relay (Main relay)	<a href="#">BRC-112, "Description"</a>
	Solenoid valve	<a href="#">BRC-120, "Description"</a>
Wheel sensor		<a href="#">BRC-99, "Description"</a>
ABS warning lamp		<a href="#">BRC-148, "Description"</a>
Brake warning lamp		<a href="#">BRC-149, "Description"</a>

## EBD

## System Diagram

INFOID:000000001181722




## System Description

INFOID:000000001181723

- Electric Brake force Distribution is a following function. ABS actuator and electric unit (control unit) detects subtle slippages between the front and rear wheels during braking. Then is electronically controls the rear braking force (brake fluid pressure) to reducing and reduces rear wheel slippage. Accordingly it improves vehicle stability.
- Electrical system diagnosis by CONSULT-III is available.

LHD models




- |                           |                           |  |
|---------------------------|---------------------------|--|
| 1. Steering angle sensor  | 2. ABS warning lamp       | 3. Brake warning lamp                            |
| 4. ESP OFF indicator lamp | 5. SLIP indicator lamp    | 6. ABS actuator and electric unit (control unit) |
| 7. Front wheel sensor     | 8. Yaw rate/side G sensor | 9. ESP OFF switch                                |

< FUNCTION DIAGNOSIS >

- |                                    |                                    |                                  |
|------------------------------------|------------------------------------|----------------------------------|
| 10. Rear wheel sensor (2WD models) | 11. Rear wheel sensor (4WD models) |                                  |
| A. Back of spiral cable assembly   | B. Combination meter               | C. Right side in engine room     |
| D. Steering knuckle                | E. Lower instrument cover RH       | F. Instrument driver lower panel |
| G. Rear suspension arm             |                                    |                                  |

RHD models



A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

- |                                    |                                    |  |
|------------------------------------|------------------------------------|--|
| 1. Steering angle sensor           | 2. ABS warning lamp                | 3. Brake warning lamp                            |
| 4. ESP OFF indicator lamp          | 5. SLIP indicator lamp             | 6. ABS actuator and electric unit (control unit) |
| 7. Front wheel sensor              | 8. Yaw rate/side G sensor          | 9. ESP OFF switch                                |
| 10. Rear wheel sensor (2WD models) | 11. Rear wheel sensor (4WD models) |  |
| A. Back of spiral cable assembly   | B. Combination meter               | C. Left side in engine room                      |
| D. Steering knuckle                | E. Lower instrument cover RH       | F. Instrument driver lower panel                 |
| G. Rear suspension arm             |                                    |  |

## Component Description

INFOID:000000001181725

Component parts	Reference	
ABS actuator and electric unit (control unit)	Pump	<a href="#">BRC-109, "Description"</a>
	Motor	
	Actuator relay (Main relay)	<a href="#">BRC-112, "Description"</a>
	Solenoid valve	<a href="#">BRC-120, "Description"</a>
Wheel sensor	<a href="#">BRC-99, "Description"</a>	
ABS warning lamp	<a href="#">BRC-148, "Description"</a>	
Brake warning lamp	<a href="#">BRC-149, "Description"</a>	

# DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< FUNCTION DIAGNOSIS >

[ESP/TCS/ABS]

## DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

### CONSULT-III Function (ABS)

INFOID:000000001181726

#### FUNCTION

CONSULT-III can display each diagnostic item using the diagnostic test modes shown following.

Diagnostic test mode	Function
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on CONSULT-III.
Self-diagnostic results	Self-diagnostic results can be read and erased quickly.
Data monitor	Input/Output data in the ABS actuator and electric unit (control unit) can be read.
Active test	Diagnostic test mode is which CONSULT-III drives some actuators apart from the ABS actuator and electric unit (control unit) and also shifts some parameters in a specified range.
ECU part number	ABS actuator and electric unit (control unit) part number can be read.
CAN diagnostic support monitor	The results of transmit/receive diagnosis of CAN communication can be read.

#### SELF-DIAG RESULTS MODE

##### Operation Procedure

- Before performing the self-diagnosis, start engine and drive vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.

##### How to Erase Self-diagnosis Results

- After erasing DTC memory, start engine and drive vehicle at 30 km/h (19 MPH) or more for approximately 1 minute as the final inspection, and make sure that the ABS warning lamp, ESP OFF indicator lamp, SLIP indicator lamp and brake warning lamp turn OFF.

**CAUTION:**

**If memory cannot be erased, perform applicably diagnosis.**

**NOTE:**

- When the wheel sensor malfunctions, after inspecting the wheel sensor system, the ABS warning lamp, ESP OFF indicator lamp, SLIP indicator lamp and brake warning lamp will not turn OFF even when the system is normal unless the vehicle is driving at approximately 30 km/h (19 MPH) or more for approximately 1 minute.
- Brake warning lamp will turn ON in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).
- ESP OFF switch should not stay "ON" position.

##### Display Item List

Refer to [BRC-159, "DTC No. Index"](#).

#### DATA MONITOR MODE

##### Display Item List

×: Applicable □: Optional item

Monitor item (Unit)	SELECT MONITOR ITEM		Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	
FR LH SENSOR [km/h (MPH)]	×	×	Wheel speed
FR RH SENSOR [km/h (MPH)]	×	×	
RR LH SENSOR [km/h (MPH)]	×	×	
RR RH SENSOR [km/h (MPH)]	×	×	

# DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< FUNCTION DIAGNOSIS >

[ESP/TCS/ABS]

Monitor item (Unit)	SELECT MONITOR ITEM		Remarks	
	ECU INPUT SIGNALS	MAIN SIGNALS		
STOP LAMP SW (On/Off)	×	×	Stop lamp switch signal status	
BATTERY VOLT (V)	×	×	Battery voltage supplied to the ABS actuator and electric unit (control unit)	
GEAR	×	×	Gear position determined by TCM	
SLCT LVR POSI	×	×	Selector lever position (except M/T)	
OFF SW (On/Off)	☐	×	ESP OFF switch	
YAW RATE SEN (°/s)	×	×	Yaw rate detected by yaw rate/side G sensor	
ACCEL POS SIG (%)	×	☐	Throttle actuator opening/closing is displayed (Linked with accelerator pedal)	
SIDE G-SENSOR (m/s <sup>2</sup> )	×	☐	Transverse G detected by yaw rate/side G sensor	
STR ANGLE SIG (°)	×	☐	Steering angle detected by steering angle sensor	
PRESS SENSOR (bar)	×	☐	Brake fluid pressure detected by pressure sensor	
ENGINE RPM [tr/min (rpm)]	×	☐	Engine speed	
FLUID LEV SW (On/Off)	×	☐	Brake fluid level switch signal status	
PARK BRAKE SW (On/Off)	×	☐	Parking brake switch signal status	
FR RH IN SOL (On/Off)	☐	×	Operation status of each solenoid valve	
FR RH OUT SOL (On/Off)	☐	×		
FR LH IN SOL (On/Off)	☐	×		
FR LH OUT SOL (On/Off)	☐	×		
RR RH IN SOL (On/Off)	☐	×		
RR RH OUT SOL (On/Off)	☐	×		
RR LH IN SOL (On/Off)	☐	×		
RR LH OUT SOL (On/Off)	☐	×		
MOTOR RELAY (On/Off)	☐	×		Motor and motor relay operation
ACTUATOR RLY <sup>NOTE</sup> (On/Off)	☐	×		Actuator relay operation
ABS WARN LAMP (On/Off)	☐	×	ABS warning lamp	
OFF LAMP (On/Off)	☐	×	ESP OFF indicator lamp	
SLIP LAMP (On/Off)	☐	×	SLIP indicator lamp	



# DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< FUNCTION DIAGNOSIS >

[ESP/TCS/ABS]

**NOTE:**

Every 20 seconds momentary switch to OFF.

**ACTIVE TEST MODE**

**CAUTION:**

- Do not perform active test while driving vehicle.
- Make sure to completely bleed air from brake system.
- The active test cannot be performed with the ABS warning lamp, ESP OFF indicator lamp, SLIP indicator lamp and brake warning lamp are on.
- ABS warning lamp, ESP OFF indicator lamp, SLIP indicator lamp and brake warning lamp are on during active test.
- Erase memory of ICC system after implementing active test.

**NOTE:**

- When active test is performed while depressing the pedal, the pedal depression amount will change. This is normal. (Only solenoid valve and ABS motor.)
- "TEST IS STOPPED" is displayed 10 seconds after operation start.
- After "TEST IS STOPPED" is displayed, to perform test again.

Test Item

**ABS SOLENOID VALVE**

- For ABS solenoid valve, touch "UP", "KEEP" and "DOWN". Then use screen monitor to check that solenoid valve operates as shown in the table below.

Test item	Display item	Display		
		UP	KEEP	DOWN
FR RH SOL	FR RH IN SOL	OFF	ON	ON
	FR RH OUT SOL	OFF	OFF	ON*
	USV [FR-RL]	OFF	OFF	OFF
	HSV [FR-RL]	OFF	OFF	OFF
FR LH SOL	FR LH IN SOL	OFF	ON	ON
	FR LH OUT SOL	OFF	OFF	ON*
	USV [FL-RR]	OFF	OFF	OFF
	HSV [FL-RR]	OFF	OFF	OFF
RR RH SOL	RR RH IN SOL	OFF	ON	ON
	RR RH OUT SOL	OFF	OFF	ON*
	USV [FL-RR]	OFF	OFF	OFF
	HSV [FL-RR]	OFF	OFF	OFF
RR LH SOL	RR LH IN SOL	OFF	ON	ON
	RR LH OUT SOL	OFF	OFF	ON*
	USV [FR-RL]	OFF	OFF	OFF
	HSV [FR-RL]	OFF	OFF	OFF

\*: ON for 1 to 2 seconds after the touch, and then OFF.

**NOTE:**

A brief moment of ON/OFF condition occurs every 20 seconds after ignition switch turned ON. This is malfunction because it is an operation for checking.

**ABS SOLENOID VALVE (ACT)**

- For ABS solenoid valve (ACT), touch "UP", "ACT UP" and "ACT KEEP". Then use screen monitor to check that solenoid valve operates as shown in the table below.

# DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< FUNCTION DIAGNOSIS >

[ESP/TCS/ABS]

Test item	Display item	Display		
		UP	KEEP	DOWN
FR RH SOL	FR RH IN SOL	OFF	OFF	OFF
	FR RH OUT SOL	OFF	OFF	OFF
	USV [FR-RL]	OFF	ON	ON
	HSV [FR-RL]	OFF	ON*	OFF
FR LH SOL	FR LH IN SOL	OFF	OFF	OFF
	FR LH OUT SOL	OFF	OFF	OFF
	USV [FL-RR]	OFF	ON	ON
	HSV [FL-RR]	OFF	ON*	OFF
RR RH SOL	RR RH IN SOL	OFF	OFF	OFF
	RR RH OUT SOL	OFF	OFF	OFF
	USV [FL-RR]	OFF	ON	ON
	HSV [FL-RR]	OFF	ON*	OFF
RR LH SOL	RR LH IN SOL	OFF	OFF	OFF
	RR LH OUT SOL	OFF	OFF	OFF
	USV [FR-RL]	OFF	ON	ON
	HSV [FR-RL]	OFF	ON*	OFF

\*: ON for 1 to 2 seconds after the touch, and then OFF.

**NOTE:**

A brief moment of ON/OFF condition occurs every 20 seconds after ignition switch turned ON. This is malfunction because it is an operation for checking.

**ABS MOTOR**

- Touch "ON" and "OFF" on screen. Make sure motor relay and actuator relay operates as shown in table below.

Test item	Display item	Display	
		ON	OFF
ABS MOTOR	MOTOR RELAY	ON	OFF
	ACTUATOR RLY <sup>NOTE</sup>	ON	ON

**NOTE:**

A brief moment of ON/OFF condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.

# C1101, C1102, C1103, C1104 WHEEL SENSOR-1

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

## COMPONENT DIAGNOSIS

### C1101, C1102, C1103, C1104 WHEEL SENSOR-1

#### Description

INFOID:000000001181727

When the sensor rotor rotates, the magnetic field changes. The sensor converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

#### DTC Logic

INFOID:000000001181728

#### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1101	RR RH SENSOR-1	Circuit of rear RH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• Wheel sensor</li><li>• ABS actuator and electric unit (control unit)</li></ul>
C1102	RR LH SENSOR-1	Circuit of rear LH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	
C1103	FR RH SENSOR-1	Circuit of front RH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	
C1104	FR LH SENSOR-1	Circuit of front LH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	

#### DTC CONFIRMATION PROCEDURE

##### 1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
RR RH SENSOR-1
RR LH SENSOR-1
FR RH SENSOR-1
FR LH SENSOR-1

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-99. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

#### Diagnosis Procedure

INFOID:000000001181729

#### **CAUTION:**

**Do not check between wheel sensor terminals.**

#### INSPECTION PROCEDURE

##### 1. CHECK SENSOR AND SENSOR ROTOR

- Check sensor rotor for damage.
- Check wheel sensor for damage, disconnection or looseness.

Are the sensor and sensor rotor normal?

- YES >> GO TO 2.  
NO >> Repair wheel sensor mount or replace sensor rotor. Then perform the self-diagnosis.

##### 2. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.

# C1101, C1102, C1103, C1104 WHEEL SENSOR-1

[ESP/TCS/ABS]

## < COMPONENT DIAGNOSIS >

5. Reconnect connectors and then perform the self-diagnosis. Refer to [BRC-95, "CONSULT-III Function \(ABS\)"](#).

Is any item indicated on the self-diagnosis display?

YES >> GO TO 3.

NO >> Poor connection of connector terminal. Repair or replace connector.

### 3. CHECK WHEEL SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check continuity between terminals. (Also check continuity when steering wheel is turned right and left and when sensor harness inside the wheel house is moved.)

Measurement terminal for power supply circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	9	E39 (Front RH)	2	Existed
	16	E22 (Front LH)		
	8	B41 (Rear RH)		
	6	B44 (Rear LH)		

Measurement terminal for signal circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	10	E39 (Front RH)	1	Existed
	5	E22 (Front LH)		
	19	B41 (Rear RH)		
	17	B44 (Rear LH)		

Measurement terminal for ground circuit

ABS actuator and electric unit (control unit)				Continuity
Connector	Terminal	Connector	Terminal	
E36	10, 9	E36	1, 4	Not existed
	5, 16			
	19, 8			
	17, 6			

5. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning components.

### 4. CHECK WHEEL SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between wheel sensor harness connector power supply terminal and ground.

Wheel sensor		—	Voltage
Connector	Terminal		
E39 (Front RH)	2	Ground	8 V or more
E22 (Front LH)			
B41 (Rear RH)			
B44 (Rear LH)			

# C1101, C1102, C1103, C1104 WHEEL SENSOR-1

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

Is the inspection result normal?

- YES >> Replace applicable wheel sensor.
- NO >> Replace ABS actuator and electric unit (control unit).

## Component Inspection

INFOID:000000001181730

### 1. CHECK DATA MONITOR

On "DATA MONITOR", select "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR", and "RR RH SENSOR", and check the vehicle speed.

Wheel sensor	Vehicle speed (DATA MONITOR)
FR LH SENSOR	Nearly matches the speedometer display ( $\pm 10\%$ or less)
FR RH SENSOR	
RR LH SENSOR	
RR RH SENSOR	

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Go to diagnosis procedure. Refer to [BRC-99, "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:000000001181731

### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-77, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

# C1105, C1106, C1107, C1108 WHEEL SENSOR-2

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

## C1105, C1106, C1107, C1108 WHEEL SENSOR-2

### Description

INFOID:000000001181732

ABS unit continually monitors wheel speed sensors to detect abnormal signals.

### DTC Logic

INFOID:000000001181733

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1105	RR RH SENSOR-2	Signal from rear RH wheel sensor does not match other 3 wheel speed signal.	<ul style="list-style-type: none"><li>• Sensor not installed correctly</li><li>• Sensor rotor or encoder damaged</li><li>• Sensor rotor loose on axle</li><li>• Electrical interference</li><li>• Wheel not turning - e.g. vehicle driven on 2WD dyno</li><li>• Sensor damaged</li><li>• ABS unit damaged</li></ul>
C1106	RR LH SENSOR-2	Signal from rear LH wheel sensor does not match other 3 wheel speed signal.	
C1107	FR RH SENSOR-2	Signal from front RH wheel sensor does not match other 3 wheel speed signal.	
C1108	FR LH SENSOR-2	Signal from front LH wheel sensor does not match other 3 wheel speed signal.	

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
RR RH SENSOR-2
RR LH SENSOR-2
FR RH SENSOR-2
FR LH SENSOR-2

Is above displayed on the self-diagnosis display?

YES >> Proceed to diagnosis procedure. Refer to [BRC-102. "Diagnosis Procedure"](#).

NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000001181734

#### **CAUTION:**

**Do not check between wheel sensor terminals.**

### INSPECTION PROCEDURE

#### 1.CHECK SENSOR AND SENSOR ROTOR

- Check sensor rotor for damage.
- Check wheel sensor for damage, disconnection or looseness.

Are the sensor and sensor rotor normal?

YES >> GO TO 2.

NO >> Repair wheel sensor mount or replace sensor rotor. Then perform the self-diagnosis.

#### 2.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
5. Reconnect connectors and then perform the self-diagnosis. Refer to [BRC-95. "CONSULT-III Function \(ABS\)"](#).

Is any item indicated on the self-diagnosis display?

# C1105, C1106, C1107, C1108 WHEEL SENSOR-2

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

YES >> GO TO 3.

NO >> Poor connection of connector terminal. Repair or replace connector.

## 3. CHECK WHEEL SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check continuity between terminals. (Also check continuity when steering wheel is turned right and left and when sensor harness inside the wheel house is moved.)

Measurement terminal for power supply circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	9	E39 (Front RH)	2	Existed
	16	E22 (Front LH)		
	8	B41 (Rear RH)		
	6	B44 (Rear LH)		

Measurement terminal for signal circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	10	E39 (Front RH)	1	Existed
	5	E22 (Front LH)		
	19	B41 (Rear RH)		
	17	B44 (Rear LH)		

Measurement terminal for ground circuit

ABS actuator and electric unit (control unit)				Continuity
Connector	Terminal	Connector	Terminal	
E36	10, 9	E36	1, 4	Not existed
	5, 16			
	19, 8			
	17, 6			

5. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning components.

## 4. CHECK WHEEL SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between wheel sensor harness connector power supply terminal and ground.

Wheel sensor		—	Voltage
Connector	Terminal		
E39 (Front RH)	2	Ground	8 V or more
E22 (Front LH)			
B41 (Rear RH)			
B44 (Rear LH)			

Is the inspection result normal?

YES >> Replace applicable wheel sensor.

NO >> Replace ABS actuator and electric unit (control unit).

# C1105, C1106, C1107, C1108 WHEEL SENSOR-2

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

## Component Inspection

INFOID:000000001181735

### 1.CHECK DATA MONITOR

On "DATA MONITOR", select "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR", and "RR RH SENSOR", and check the vehicle speed.

Wheel sensor	Vehicle speed (DATA MONITOR)
FR LH SENSOR	Nearly matches the speedometer display ( $\pm 10\%$ or less)
FR RH SENSOR	
RR LH SENSOR	
RR RH SENSOR	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-102, "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:000000001181736

### 1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-77, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END



# C1109 POWER AND GROUND SYSTEM

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

## C1109 POWER AND GROUND SYSTEM

### Description

INFOID:000000001181737

Power is supplied from the battery to ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000001181738

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1109	BATTERY VOLTAGE [ABNORMAL]	When the ABS actuator and electric unit (control unit) power supply is lower than normal and vehicle speed is greater than 6 km/h (4 MPH). Power supply is greater than normal limits.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS unit</li><li>• Fuse</li><li>• Vehicle electrical power system</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
BATTERY VOLTAGE [ABNORMAL]

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-105, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000001181739

### INSPECTION PROCEDURE

#### 1.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform the self-diagnosis. Refer to [BRC-95, "CONSULT-III Function \(ABS\)"](#).

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.  
NO >> Poor connection of connector terminal. Repair or replace connector.

#### 2.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY CIRCUIT AND GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Turn ignition switch ON or OFF and check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Condition	Voltage
Connector	Terminal			
E36	18	Ground	Ignition switch: ON	Battery voltage
			Ignition switch: OFF	Approx. 0 V

4. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

- YES >> GO TO 3.

# C1109 POWER AND GROUND SYSTEM

[ESP/TCS/ABS]

## < COMPONENT DIAGNOSIS >

NO >> Repair or replace malfunctioning components.

### 3. ABS POWER SUPPLY CHECK (UNDER LOAD CONDITIONS)

1. Use 12V lamp (normal rating 10 to 20W) connected between E36 terminals 18 and 4. With ignition switch ON check bulb illuminates correctly.
2. Check ABS motor supply under loaded condition (connector E36 terminals 1 and 2).

#### Is the inspection result normal?

YES >> GO TO 4.

NO >> Check both power supply and ground circuit.

### 4. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	1, 4	Ground	Existed

#### Is the inspection result normal?

YES >> Check battery for terminal looseness, low voltage, etc. if any malfunction is found, repair malfunctioning parts.

NO >> Repair or replace malfunctioning components. (Check ABS earth bolt for tightness and corrosion.)

## Special Repair Requirement

INFOID:000000001181740

### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-77. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

**C1110, C1153, C1170 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)**  
 < COMPONENT DIAGNOSIS > [ESP/TCS/ABS]

**C1110, C1153, C1170 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)**

**Description**

INFOID:000000001181741

ABS unit is continuously monitoring ECU hardware and software for correct operation.

**DTC Logic**

INFOID:000000001181742

**DTC DETECTION LOGIC**

DTC	Display item	Malfunction detected condition	Possible cause
C1110	CONTROLLER FAILURE	Possible internal failure of control unit components.	<ul style="list-style-type: none"> <li>Internal failure of control unit components.</li> <li>ABS solenoid valve or motor power supply / ground abnormal.</li> </ul>
C1153	EMERGENCY BRAKE	Continuous ABS/EBD control for more than 60 seconds.	<ul style="list-style-type: none"> <li>ABS control unit software failure</li> <li>Wheel speed sensor input abnormality.</li> </ul>
C1170	VARIANT CODING	In a case where VARIANT CODING is different.	ABS actuator and electric unit (control unit)

**DTC CONFIRMATION PROCEDURE**

**1. CHECK SELF-DIAGNOSIS RESULTS**

1. Check both ABS solenoid valve and motor supply and ground circuits using a suitable electrical load.
2. Check wheel speed sensor inputs.
3. Check the self-diagnosis results.

Self-diagnosis results
CONTROLLER FAILURE
EMERGENCY BRAKE
VARIANT CODING

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-107, "Diagnosis Procedure"](#).  
 NO >> INSPECTION END

**Diagnosis Procedure**

INFOID:000000001181743

**INSPECTION PROCEDURE**

**1. REPLACE ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)**

**CAUTION:**

Replace ABS actuator and electric unit (control unit) when self-diagnostic result shows items other than those applicable.

>> Replace ABS actuator and electric unit (control unit).

**Special Repair Requirement**

INFOID:000000001181744

**1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION**

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-77, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

# C1111 ABS MOTOR, MOTOR RELAY SYSTEM

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

## C1111 ABS MOTOR, MOTOR RELAY SYSTEM

### Description

INFOID:000000001181745

#### PUMP

The pump returns the brake fluid stored in the reservoir to the master cylinder by reducing the pressure.

#### MOTOR

The motor drives the pump according to the signals transmitted by the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000001181746

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1111	PUMP MOTOR	During the actuator motor operating with ON, when the actuator motor turns OFF, or when the control line for actuator motor relay is open.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit)</li></ul>
		During the actuator motor operating with OFF, when the actuator motor turns ON, or when the control line for relay is shorted to ground.	

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
PUMP MOTOR

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-109, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000001181747

### INSPECTION PROCEDURE

#### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnect, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform the self-diagnosis. Refer to [BRC-95, "CONSULT-III Function \(ABS\)"](#).

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.  
NO >> Poor connection of connector terminal. Replace or repair connector.

#### 2. CHECK ABS MOTOR AND MOTOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between the ABS actuator and electric unit (control unit) harness connector terminal and ground.

# C1111 ABS MOTOR, MOTOR RELAY SYSTEM

[ESP/TCS/ABS]

## < COMPONENT DIAGNOSIS >

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	2	Ground	Battery voltage

4. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

### 3. ABS POWER SUPPLY CHECK (UNDER LOAD CONDITION)

Use 12V lamp (normal rating 10 to 20W) connected between E36 terminals 1 and 2. With ignition switch ON check bulb illuminates correctly.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check both power supply and ground circuit.

### 4. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	1, 4	Ground	Existed

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace malfunctioning components. (Check ABS each bolt for tightness and corrosion.)

## Component Inspection

INFOID:000000001181748

### 1. CHECK ACTIVE TEST

1. On "ACTIVE TEST", select "ABS MOTOR".
2. Touch ON and OFF on screen. Make sure motor relay and actuator relay operates as shown in table below.

Test item	Display item	Display	
		ON	OFF
ABS MOTOR	MOTOR RELAY	ON	OFF
	ACTUATOR RLY <sup>NOTE</sup>	ON	ON

#### NOTE:

A brief moment of ON/OFF condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-109, "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:000000001181749

### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-77, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

# C1111 ABS MOTOR, MOTOR RELAY SYSTEM

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

>> END

A

B

C

D

E

**BRC**

G

H

I

J

K

L

M

N

O

P

# C1114 ACTUATOR RELAY SYSTEM

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

## C1114 ACTUATOR RELAY SYSTEM

### Description

INFOID:000000001181750

Activates or deactivates each solenoid valve according to the signals transmitted by the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000001181751

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1114	MAIN RELAY	During the actuator relay operating with OFF, when the actuator relay turns ON, or when the control line for the relay is shorted to the ground.	<ul style="list-style-type: none"> <li>• Harness or connector</li> <li>• ABS actuator and electric unit (control unit)</li> </ul>
		During the actuator relay operating with ON, when the actuator relay turns ON, or when the control line for the relay is open.	

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
MAIN RELAY

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-112, "Diagnosis Procedure"](#).  
 NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000001181752

### INSPECTION PROCEDURE

#### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform the self-diagnosis. Refer to [BRC-95, "CONSULT-III Function \(ABS\)"](#).

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.  
 NO >> Poor connection of connector terminal. Replace or repair connector.

#### 2. CHECK SOLENOID, ESP SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	3	Ground	Battery voltage

4. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?



# C1114 ACTUATOR RELAY SYSTEM

[ESP/TCS/ABS]

## < COMPONENT DIAGNOSIS >

- YES >> GO TO 3.  
NO >> Repair or replace malfunctioning components.

### 3. ABS POWER SUPPLY CHECK (UNDER LOAD CONDITION)

Use 12V lamp (normal rating 10 to 20W) connected between E36 terminals 1 and 3. With ignition switch ON check bulb illuminates correctly.

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Check both power supply and ground circuit.

### 4. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	1, 4	Ground	Existed

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit).  
NO >> Repair or replace malfunctioning components. (Check ABS each bolt for tightness and corrosion.)

## Component Inspection

INFOID:000000001181753

### 1. CHECK ACTIVE TEST

1. On "ACTIVE TEST", select "ABS MOTOR".
2. Touch ON and OFF on screen. Make sure motor relay and actuator relay operates as shown in table below.

Test item	Display item	Display	
		ON	OFF
ABS MOTOR	MOTOR RELAY	ON	OFF
	ACTUATOR RLY <sup>NOTE</sup>	ON	ON

#### NOTE:

A brief moment of ON/OFF condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Go to diagnosis procedure. Refer to [BRC-33, "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:000000001181754

### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-77, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

# C1115 WHEEL SENSOR

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

## C1115 WHEEL SENSOR

### Description

INFOID:000000001181755

When the sensor rotor rotates, the magnetic field changes. The sensor converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000001181756

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1115	ABS SENSOR [ABNORMAL SIGNAL]	Miss-match between the 4 wheel speed sensor signals.	<ul style="list-style-type: none"><li>• Harness or connector is not a possible cause</li><li>• Other possible causes<ul style="list-style-type: none"><li>- Tire radius (due to wrong size or pressure) interference.</li></ul></li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
ABS SENSOR [ABNORMAL SIGNAL]

Is above displayed on the self-diagnosis display?

YES >> Proceed to diagnosis procedure. Refer to [BRC-114. "Diagnosis Procedure"](#).

NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000001181757

#### **CAUTION:**

**Do not check between wheel sensor terminals.**

### INSPECTION PROCEDURE

#### 1.CHECK SENSOR AND SENSOR ROTOR

- Check sensor rotor for damage.
- Check wheel sensor for damage, disconnection or looseness.

Are the sensor and sensor rotor normal?

YES >> GO TO 2.

NO >> Repair wheel sensor mount or replace sensor rotor. Then perform the self-diagnosis.

#### 2.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
5. Reconnect connectors and then perform the self-diagnosis. Refer to [BRC-95. "CONSULT-III Function \(ABS\)"](#).

Is any item indicated on the self-diagnosis display?

YES >> GO TO 3.

NO >> Poor connection of connector terminal. Repair or replace connector.

#### 3.CHECK WHEEL SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.

# C1115 WHEEL SENSOR

[ESP/TCS/ABS]

## < COMPONENT DIAGNOSIS >

4. Check continuity between terminals. (Also check continuity when steering wheel is turned right and left and when sensor harness inside the wheel house is moved.)

Measurement terminal for power supply circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	9	E39 (Front RH)	2	Existed
	16	E22 (Front LH)		
	8	B41 (Rear RH)		
	6	B44 (Rear LH)		

Measurement terminal for signal circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	10	E39 (Front RH)	1	Existed
	5	E22 (Front LH)		
	19	B41 (Rear RH)		
	17	B44 (Rear LH)		

Measurement terminal for ground circuit

ABS actuator and electric unit (control unit)				Continuity
Connector	Terminal	Connector	Terminal	
E36	10, 9	E36	1, 4	Not existed
	5, 16			
	19, 8			
	17, 6			

5. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning components.

## 4.CHECK WHEEL SENSOR POWER SUPPLY CIRCUIT

- Turn ignition switch ON.
- Check voltage between wheel sensor harness connector power supply terminal and ground.

Wheel sensor		—	Voltage
Connector	Terminal		
E39 (Front RH)	2	Ground	8 V or more
E22 (Front LH)			
B41 (Rear RH)			
B44 (Rear LH)			

Is the inspection result normal?

YES >> Replace applicable wheel sensor.

NO >> Replace ABS actuator and electric unit (control unit).

## Component Inspection

INFOID:000000001181758

## 1.CHECK DATA MONITOR

On "DATA MONITOR", select "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR", and "RR RH SENSOR", and check the vehicle speed.

# C1115 WHEEL SENSOR

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

Wheel sensor	Vehicle speed (DATA MONITOR)
FR LH SENSOR	Nearly matches the speedometer display ( $\pm 10\%$ or less)
FR RH SENSOR	
RR LH SENSOR	
RR RH SENSOR	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-114, "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:000000001181759

### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-77, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

# C1116 STOP LAMP SWITCH

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

## C1116 STOP LAMP SWITCH

### Description

INFOID:000000001181760

The stop lamp switch transmits the stop lamp switch signal (ON/OFF) to the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000001181761

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1116	STOP LAMP SW	When stop lamp switch circuit is open.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• Stop lamp switch</li><li>• ABS actuator and electric unit (control unit)</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
STOP LAMP SW

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-117. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000001181762

### INSPECTION PROCEDURE

#### 1.CHECK STOP LAMPS ILLUMINATE

Check stop lamps illuminate when brake pedal is pressed.

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Check stop lamp circuit.

#### 2.CHECK DATA MONITOR

Using "DATA MONITOR" check both pressure sensor signal and brake lamp switch signal.

Pressure sensor

Condition	PRESS SEN (DATA MONITOR)
Brake pedal released	Approx. 3 bar
Brake pedal pressed	0 to 200 bar

Stop lamp switch

Condition	STOP LAMP SW (DATA MONITOR)
Brake pedal released	OFF
Brake pedal pressed	ON

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace malfunctioning parts.

#### 3.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.

# C1116 STOP LAMP SWITCH

[ESP/TCS/ABS]

## < COMPONENT DIAGNOSIS >

3. Disconnect stop lamp switch connector.
4. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
5. Reconnect connectors securely.
6. Start engine.
7. Repeat pumping brake pedal carefully several times, and perform self-diagnosis. Refer to [BRC-95. "CONSULT-III Function \(ABS\)"](#)

Is any item indicated in the self-diagnosis display?

YES >> GO TO 4.

NO >> Poor connection of connector terminal. Replace or repair connector.

## 4. CHECK STOP LAMP SWITCH

1. Disconnect stop lamp switch connector.
2. Check continuity between stop lamp switch connector terminals.

Stop lamp switch Terminal	Condition	Continuity
1 - 2	Release stop lamp switch (When brake pedal is depressed.)	Existed
	Push stop lamp switch (When brake pedal is released.)	Not existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace stop lamp switch.

## 5. CHECK STOP LAMP SWITCH CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Connect stop lamp switch connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit) Connector		Terminal	Condition	Voltage
E36		20	Brake pedal is depressed	Battery voltage
			Brake pedal is released	Approx. 0 V

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace malfunctioning components.

## Component Inspection

INFOID:000000001181763

## 1. CHECK STOP LAMP SWITCH

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch connector.
3. Check continuity between stop lamp switch connector terminals.

Stop lamp switch Terminal	Condition	Continuity
1 - 2	Release stop lamp switch (When brake pedal is depressed.)	Existed
	Push stop lamp switch (When brake pedal is released.)	Not existed

Is the inspection result normal?

YES >> INSPECTION END

# C1116 STOP LAMP SWITCH

[ESP/TCS/ABS]

< COMPONENT DIAGNOSIS >

NO >> Replace stop lamp switch.

## Special Repair Requirement

INFOID:000000001181764

### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-77. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

**BRC**

# C1120, C1122, C1124, C1126 IN ABS SOL

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

## C1120, C1122, C1124, C1126 IN ABS SOL

### Description

INFOID:000000001181765

The solenoid valve increases, holds or decreases the fluid pressure of each brake caliper according to the signals transmitted by the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000001181766

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1120	FR LH IN ABS SOL	When the control unit detects a malfunction in the front LH inlet solenoid circuit.	ABS actuator and electric unit (control unit)
C1122	FR RH IN ABS SOL	When the control unit detects a malfunction in the front RH inlet solenoid circuit.	
C1124	RR LH IN ABS SOL	When the control unit detects a malfunction in the rear LH inlet solenoid circuit.	
C1126	RR RH IN ABS SOL	When the control unit detects a malfunction in the rear RH inlet solenoid circuit.	

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
FR LH IN ABS SOL
FR RH IN ABS SOL
RR LH IN ABS SOL
RR RH IN ABS SOL

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-120. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000001181767

### INSPECTION PROCEDURE

#### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform the self-diagnosis. Refer to [BRC-95. "CONSULT-III Function \(ABS\)"](#).

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.  
NO >> Poor connection of connector terminal. Replace or repair connector.

#### 2. CHECK SOLENOID, ESP SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.



# C1120, C1122, C1124, C1126 IN ABS SOL

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	3	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Repair or replace malfunctioning components.

## 3.CHECK SOLENOID, ESP SWITCH-OVER VALVE AND ACUATOR RELAY GROUND CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	1, 4	Ground	Existed

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit).  
 NO >> Repair or replace malfunctioning components.

## Component Inspection

INFOID:000000001181768

### 1.CHECK ACTIVE TEST

1. Select each test menu item on "ACTIVE TEST".
2. On the display, touch "UP", "KEEP", and "DOWN", and check that the system operates as shown in the table below.

Test item	Display item	Display		
		UP	KEEP	DOWN
FR RH SOL	FR RH IN SOL	OFF	ON	ON
	FR RH OUT SOL	OFF	OFF	ON*
	USV [FR-RL]	OFF	OFF	OFF
	HSV [FR-RL]	OFF	OFF	OFF
FR LH SOL	FR LH IN SOL	OFF	ON	ON
	FR LH OUT SOL	OFF	OFF	ON*
	USV [FL-RR]	OFF	OFF	OFF
	HSV [FL-RR]	OFF	OFF	OFF
RR RH SOL	RR RH IN SOL	OFF	ON	ON
	RR RH OUT SOL	OFF	OFF	ON*
	USV [FL-RR]	OFF	OFF	OFF
	HSV [FL-RR]	OFF	OFF	OFF
RR LH SOL	RR LH IN SOL	OFF	ON	ON
	RR LH OUT SOL	OFF	OFF	ON*
	USV [FR-RL]	OFF	OFF	OFF
	HSV [FR-RL]	OFF	OFF	OFF

\*: ON for 1 to 2 seconds after the touch, and then OFF.

**NOTE:**

A brief moment of ON/OFF condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.

Is the inspection result normal?

- YES >> INSPECTION END

< COMPONENT DIAGNOSIS >

NO >> Go to diagnosis procedure. Refer to [BRC-120. "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:000000001181769

### **1**.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-77. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

# C1121, C1123, C1125, C1127 OUT ABS SOL

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

## C1121, C1123, C1125, C1127 OUT ABS SOL

### Description

INFOID:000000001181770

The solenoid valve increases, holds or decreases the fluid pressure of each brake caliper according to the signals transmitted by the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000001181771

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1121	FR LH OUT ABS SOL	When the control unit detects a malfunction in the front LH outlet solenoid circuit.	ABS actuator and electric unit (control unit)
C1123	FR RH OUT ABS SOL	When the control unit detects a malfunction in the front RH outlet solenoid circuit.	
C1125	RR LH OUT ABS SOL	When the control unit detects a malfunction in the rear LH outlet solenoid circuit.	
C1127	RR RH OUT ABS SOL	When the control unit detects a malfunction in the rear RH outlet solenoid circuit.	

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
FR LH OUT ABS SOL
FR RH OUT ABS SOL
RR LH OUT ABS SOL
RR RH OUT ABS SOL

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-123. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000001181772

### INSPECTION PROCEDURE

#### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform the self-diagnosis. Refer to [BRC-95. "CONSULT-III Function \(ABS\)"](#).

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.  
NO >> Poor connection of connector terminal. Replace or repair connector.

#### 2. CHECK SOLENOID, ESP SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

# C1121, C1123, C1125, C1127 OUT ABS SOL

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	3	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Repair or replace malfunctioning components.

## 3.CHECK SOLENOID, ESP SWITCH-OVER VALVE AND ACUATOR RELAY GROUND CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	1, 4	Ground	Existed

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit).  
 NO >> Repair or replace malfunctioning components.

## Component Inspection

INFOID:000000001181773

### 1.CHECK ACTIVE TEST

1. Select each test menu item on "ACTIVE TEST".
2. On the display, touch "UP", "KEEP", and "DOWN", and check that the system operates as shown in the table below.

Test item	Display item	Display		
		UP	KEEP	DOWN
FR RH SOL	FR RH IN SOL	OFF	ON	ON
	FR RH OUT SOL	OFF	OFF	ON*
	USV [FR-RL]	OFF	OFF	OFF
	HSV [FR-RL]	OFF	OFF	OFF
FR LH SOL	FR LH IN SOL	OFF	ON	ON
	FR LH OUT SOL	OFF	OFF	ON*
	USV [FL-RR]	OFF	OFF	OFF
	HSV [FL-RR]	OFF	OFF	OFF
RR RH SOL	RR RH IN SOL	OFF	ON	ON
	RR RH OUT SOL	OFF	OFF	ON*
	USV [FL-RR]	OFF	OFF	OFF
	HSV [FL-RR]	OFF	OFF	OFF
RR LH SOL	RR LH IN SOL	OFF	ON	ON
	RR LH OUT SOL	OFF	OFF	ON*
	USV [FR-RL]	OFF	OFF	OFF
	HSV [FR-RL]	OFF	OFF	OFF

\*: ON for 1 to 2 seconds after the touch, and then OFF.

**NOTE:**

A brief moment of ON/OFF condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.

Is the inspection result normal?

- YES >> INSPECTION END

# C1121, C1123, C1125, C1127 OUT ABS SOL

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

NO >> Go to diagnosis procedure. Refer to [BRC-123. "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:000000001181774

### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-77. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

**BRC**

# C1130, C1131, C1132 ENGINE SIGNAL

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

## C1130, C1131, C1132 ENGINE SIGNAL

### Description

INFOID:000000001181775

ABS actuator and electric unit (control unit) receives the engine signal from ECM with CAN communication line.

### DTC Logic

INFOID:000000001181776

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1130	ENGINE SIGNAL 1	ECM signals are invalid or ECM self diagnosis indicates a fault that prevents correct TCS operation.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit)</li><li>• ECM</li><li>• CAN communication line</li></ul>
C1131	ENGINE SIGNAL 2		
C1132	ENGINE SIGNAL 3		

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
ENGINE SIGNAL 1
ENGINE SIGNAL 2
ENGINE SIGNAL 3

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-126, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000001181777

### INSPECTION PROCEDURE

#### 1. CHECK ENGINE SYSTEM

1. Perform ECM self-diagnosis. Repair or replace items indicated, then perform ECM self-diagnosis again.
  - HR16DE (with EURO-OBD): [ECH-89, "CONSULT-III Function"](#).
  - HR16DE (without EURO-OBD): [ECH-419, "CONSULT-III Function"](#).
  - MR20DE (with EURO-OBD): [ECM-91, "CONSULT-III Function"](#).
  - MR20DE (without EURO-OBD): [ECM-425, "CONSULT-III Function"](#).
  - K9K: [ECK-63, "Diagnosis Description"](#).
  - M9R: [ECR-101, "CONSULT-III Function"](#).
2. Perform ABS actuator and electric unit (control unit) self-diagnosis. Refer to [BRC-95, "CONSULT-III Function \(ABS\)"](#).

Is any item indicated on the self-diagnosis display?

- YES >> Repair or replace the affected part.  
NO >> INSPECTION END

### Special Repair Requirement

INFOID:000000001181778

#### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-77, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

# C1142 PRESS SENSOR

[ESP/TCS/ABS]

< COMPONENT DIAGNOSIS >

## C1142 PRESS SENSOR

### Description

INFOID:000000001181779

The pressure sensor converts the brake fluid pressure to an electric signal and transmits it to the ABS actuator and electric unit (control unit). [The pressure sensor is integrated in the ABS actuator and electric unit (control unit).]

### DTC Logic

INFOID:000000001181780

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1142	PRESS SEN CIRCUIT	Pressure sensor signal line is open or shorted, or pressure sensor is malfunctioning.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• Stop lamp switch</li><li>• ABS actuator and electric unit (control unit)</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
PRESS SEN CIRCUIT

Is above displayed on the self-diagnosis display?

YES >> Proceed to diagnosis procedure. Refer to [BRC-127. "Diagnosis Procedure"](#).

NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000001181781

#### INSPECTION PROCEDURE

##### 1.CHECK STOP LAMP SWITCH CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect stop lamp switch connector.
4. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
5. Reconnect connectors securely.
6. Start engine.
7. Repeat pumping brake pedal carefully several times, and perform self-diagnosis.

Is any item indicated on the self-diagnosis display?

YES >> GO TO 2.

NO >> Poor connection of connector terminal. Replace or repair connector.

##### 2.CHECK STOP LAMP SWITCH

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch connector.
3. Check continuity between stop lamp switch connector terminals.

Stop lamp switch Terminal	Condition	Continuity
1 - 2	Release stop lamp switch (When brake pedal is depressed.)	Existed
	Push stop lamp switch (When brake pedal is released.)	Not existed

# C1142 PRESS SENSOR

[ESP/TCS/ABS]

< COMPONENT DIAGNOSIS >

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Replace stop lamp switch.

## 3.CHECK STOP LAMP SWITCH CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Connect stop lamp switch connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		Condition	Voltage
Connector	Terminal		
E36	20	Brake pedal is depressed	Battery voltage
		Brake pedal is released	Approx. 0 V

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit).
- NO >> Repair or replace malfunctioning components.

## Component Inspection

INFOID:000000001181782

### 1.CHECK DATA MONITOR

On "DATA MONITOR", select "PRESS SENSOR" and check the brake fluid pressure.

Condition	PRESS SENSOR (DATA MONITOR)
With ignition switch turned ON and brake pedal released.	Approx. 3 bar
With ignition switch turned ON and brake pedal depressed.	0 to 200 bar

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Go to diagnosis procedure. Refer to [BRC-127, "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:000000001181783

### 1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-77, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END



# C1143, C1144 STEERING ANGLE SENSOR

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

## C1143, C1144 STEERING ANGLE SENSOR

### Description

INFOID:000000001181784

The steering angle sensor detects the rotation amount, angular velocity and direction of the steering wheel, and transmits the data to the ABS actuator and electric unit (control unit) via CAN communication.

### DTC Logic

INFOID:000000001181785

#### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1143	ST ANG SEN CIRCUIT	Neutral position of steering angle sensor is dislocated, or the steering angle sensor is malfunctioning.	• Harness or connector • Steering angle sensor • ABS actuator and electric unit (control unit)
C1144	ST ANG SEN SIGNAL	Neutral position of steering angle sensor is not finished.	

#### DTC CONFIRMATION PROCEDURE

##### 1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
ST ANG SEN CIRCUIT
ST ANG SEN SIGNAL

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-129, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000001181786

#### INSPECTION PROCEDURE

##### 1.CHECK VEHICLE STATE

Check vehicle for any suspension/steering misalignment or damage.

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Correct any damage found.

##### 2.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect steering angle sensor connector.
4. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
5. Reconnect connectors and then perform the self-diagnosis. Refer to [BRC-95, "CONSULT-III Function \(ABS\)"](#)

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 3.  
NO >> Poor connection of connector terminal. Replace or repair connector.

##### 3.CHECK STEERING ANGLE SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect steering angle sensor connector.
3. Check continuity between steering angle sensor harness connector terminal and ground.

# C1143, C1144 STEERING ANGLE SENSOR

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

Steering angle sensor		—	Continuity
Connector	Terminal		
M30	3	Ground	Existed

4. Turn ignition switch ON.
5. Check voltage between steering angle sensor harness connector terminal and ground.

Steering angle sensor		—	Voltage
Connector	Terminal		
M30	1	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair or replace malfunctioning components.

## 4.CHECK DATA MONITOR

1. Connect the steering angle sensor connector and ABS actuator and electric unit (control unit) connector.
2. Select "STR ANGLE SIG" in "DATA MONITOR" and check steering angle sensor signal.

Steering condition	STR ANGLE SIG (DATA MONITOR)
Driving straight	$\pm 2.5^\circ$
Turn 90° to right	Approx. +90°
Turn 90° to left	Approx. -90°

Is the inspection result normal?

- YES >> GO TO 5.  
NO >> Adjust neutral position of steering angle sensor.

## 5.CHECK FOR BACKLASH

1. Check for backlash [turn wheel to left then straight then right then straight (approx. 90)].
2. Check straight position is always similar value.

Is there noticeable backlash?

- YES >> Check sensor is correctly fitted to combination witch.  
NO >> Check sensor output is correct from lock to lock.

## Component Inspection

INFOID:000000001181787

### 1.CHECK DATA MONITOR

Select "STR ANGLE SIG" in "DATA MONITOR" and check steering angle sensor signal.

Steering condition	STR ANGLE SIG (DATA MONITOR)
Driving straight	$\pm 2.5^\circ$
Turn 90° to right	Approx. +90°
Turn 90° to left	Approx. -90°

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Go to diagnosis procedure. Refer to [BRC-129. "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:000000001181788

### 1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the steering angle sensor or the ABS actuator and electric unit (control unit). Refer to [BRC-77. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

# C1143, C1144 STEERING ANGLE SENSOR

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

>> END

A

B

C

D

E

**BRC**

G

H

I

J

K

L

M

N

O

P

# C1145 YAW RATE SENSOR

[ESP/TCS/ABS]

< COMPONENT DIAGNOSIS >

## C1145 YAW RATE SENSOR

### Description

INFOID:000000001181789

The yaw rate sensor detects the yaw rate affecting the vehicle, and transmits the data to the ABS actuator and electric unit (control unit) as an analog voltage signal.

### DTC Logic

INFOID:000000001181790

#### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1145	YAW RATE SENSOR	Yaw rate sensor is malfunctioning, or the yaw rate sensor signal line is open or shorted.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit)</li><li>• Yaw rate sensor</li></ul>

#### DTC CONFIRMATION PROCEDURE

##### 1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
YAW RATE SENSOR

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-132, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000001181791

#### CAUTION:

- Driving on high speed banked corners can also indicate yaw rate sensor malfunction.
- If vehicle is on turn-table at entrance to parking garage, or on other moving surface, VDC OFF indicator lamp may illuminate and CONSULT-III self-diagnosis may indicate yaw rate sensor system malfunction. However, in this case there is no malfunction in yaw rate sensor system. Take vehicle off of turn-table or other moving surface, and start engine. Results will return to normal. And after doing spin turns or acceleration turns with VDC function is being off (VDC OFF switch "ON"), too, the results will return to a normal condition by re-starting vehicle.

#### INSPECTION PROCEDURE

##### 1. CHECK INSTALLATION STATE OF YAW RATE SENSOR

Check yaw rate sensor is correctly attached to vehicle. Refer to [BRC-177, "Exploded View"](#).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace malfunctioning parts.

##### 2. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect yaw rate sensor connector.
4. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
5. Reconnect connectors and then perform the self-diagnosis. Refer to [BRC-95, "CONSULT-III Function \(ABS\)"](#).

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 3.  
NO >> Poor connection of connector terminal. Replace or repair connector.

# C1145 YAW RATE SENSOR

[ESP/TCS/ABS]

< COMPONENT DIAGNOSIS >

## 3. CHECK YAW RATE SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect yaw rate sensor connector.
3. Turn ignition switch ON or OFF and check voltage between yaw rate sensor harness connector terminal and ground.

Yaw rate sensor		—	Condition	Voltage
Connector	Terminal			
M72	4	Ground	Ignition switch: ON	Battery voltage
			Ignition switch: OFF	Approx. 0 V

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning components.

## 4. CHECK YAW RATE SENSOR GROUND CIRCUIT

Check continuity between yaw rate sensor harness connector terminal and ground.

Yaw rate sensor		—	Continuity
Connector	Terminal		
M72	1	Ground	Existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning components.

## 5. CHECK YAW RATE SENSOR HARNESS

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between yaw rate sensor harness connector terminals and ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit)		Yaw rate sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	14	M72	2	Existed
	25		3	

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace malfunctioning components.

## 6. CHECK DATA MONITOR

1. Connect the yaw rate sensor connector and ABS actuator and electric unit (control unit) connector.
2. Select "YAW RATE SEN", in "DATA MONITOR" and check yaw rate sensor signal.

Vehicle condition	YAW RATE SEN (DATA MONITOR)
Stopped	Approx. 0 d/s
Turning right	Negative value
Turning left	Positive value

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Replace yaw rate sensor.

# C1145 YAW RATE SENSOR

[ESP/TCS/ABS]

< COMPONENT DIAGNOSIS >

## Component Inspection

INFOID:000000001181792

### 1.CHECK DATA MONITOR

Select "YAW RATE SEN" in "DATA MONITOR" and check yaw rate sensor signal.

Vehicle condition	YAW RATE SEN (DATA MONITOR)
Stopped	Approx. 0 d/s
Turning right	Negative value
turning left	Positive value

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-132. "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:000000001181793

### 1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-77. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

## C1146 G SENSOR

### Description

INFOID:000000001181794

G sensor detects G affecting the vehicle, and transmits the data to the ABS actuator and electric unit (control unit) as an analog voltage signal.

### DTC Logic

INFOID:000000001181795

#### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1146	SIDE G-SEN CIRCUIT	Side G sensor is malfunctioning, or circuit of side G sensor is open or shorted.	<ul style="list-style-type: none"> <li>Harness or connector</li> <li>ABS actuator and electric unit (control unit)</li> <li>G sensor</li> </ul>

#### DTC CONFIRMATION PROCEDURE

##### 1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
SIDE G-SEN CIRCUIT

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-135, "Diagnosis Procedure"](#).  
 NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000001181796

**CAUTION:**

**Sudden turns (such as spin turns, acceleration turns), drifting, etc., when VDC function is off (VDC OFF switch "ON") may cause G sensor system to indicate a malfunction. However, this is not a malfunction, if normal operation can be resumed after restarting engine. Then erase memory of self-diagnosis.**

#### INSPECTION PROCEDURE

##### 1. CHECK INSTALLATION STATE OF G SENSOR

Check G sensor is correctly attached to vehicle. Refer to [BRC-177, "Exploded View"](#).

Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> Repair or replace malfunctioning parts.

##### 2. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect G sensor connector.
4. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
5. Reconnect connectors and then perform the self-diagnosis. Refer to [BRC-135, "Diagnosis Procedure"](#).

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 3.  
 NO >> Poor connection of connector terminal. Replace or repair connector.

##### 3. CHECK G SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect G sensor connector and ABS actuator and electric unit (control unit) connector.

# C1146 G SENSOR

[ESP/TCS/ABS]

## < COMPONENT DIAGNOSIS >

3. Check continuity between G sensor harness connector terminals and ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit)		G sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	14	M71	1	Existed
	21		2	
	24		3	

### Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning components.

## 4.CHECK DATA MONITOR

1. Connect the G sensor connector and ABS actuator and electric unit (control unit) connector.
2. Select "SIDE G-SENSOR" in "DATA MONITOR" and check G sensor signal.

Vehicle condition	SIDE G-SENSOR (DATA MONITOR)
Stopped	Approx. 0 m/s <sup>2</sup>
Turning right	Negative value
Turning left	Positive value

### Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Replace G sensor.

## Component Inspection

INFOID:000000001181797

## 1.CHECK DATA MONITOR

Select "SIDE G-SENSOR" in "DATA MONITOR" and check G sensor signal.

Vehicle condition	SIDE G-SENSOR (DATA MONITOR)
Stopped	Approx. 0 m/s <sup>2</sup>
Turning right	Negative value
Turning left	Positive value

### Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-135, "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:000000001181798

## 1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-77, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END



# C1147, C1148, C1149, C1150 USV/HSV LINE

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

## C1147, C1148, C1149, C1150 USV/HSV LINE

### Description

INFOID:000000001181799

#### USV1, USV2 (CUT VALVE)

The cut valve shuts off the normal brake fluid path from the master cylinder, when ESP/TCS is activated.

#### HSV1, HSV2 (SUCTION VALVE)

The suction valve supplies the brake fluid from the master cylinder to the pump, when ESP/TCS is activated.

### DTC Logic

INFOID:000000001181800

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1147	USV LINE [FL-RR]	ESP switch-over solenoid valve (USV1) on the primary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground.	• Harness or connector • ABS actuator and electric unit (control unit)
C1148	USV LINE [FR-RL]	ESP switch-over solenoid valve (USV2) on the primary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground.	
C1149	HSV LINE [FL-RR]	ESP switch-over solenoid valve (HSV1) on the primary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground.	
C1150	HSV LINE [FR-RL]	ESP switch-over solenoid valve (HSV2) on the primary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground.	

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
USV LINE [FL-RR]
USV LINE [FR-RL]
HSV LINE [FL-RR]
HSV LINE [FR-RL]

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-137. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000001181801

### INSPECTION PROCEDURE

#### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform the self-diagnosis. Refer to [BRC-95. "CONSULT-III Function \(ABS\)"](#).

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.  
NO >> Poor connection of connector terminal. Replace or repair connector.

# C1147, C1148, C1149, C1150 USV/HSV LINE

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

## 2. CHECK SOLENOID, ESP SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	3	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

## 3. CHECK SOLENOID, ESP SWITCH-OVER VALVE AND ACUATOR RELAY GROUND CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	1, 4	Ground	Existed

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace malfunctioning components.

## Component Inspection

INFOID:000000001181802

### 1. CHECK ACTIVE TEST

1. Select each test menu item on "ACTIVE TEST".
2. On the display, touch "UP", "ACT UP", and "ACT KEEP", and check that the system operates as shown in the table below.

Test item	Display item (Note)	Display		
		UP	ACT UP	ACT KEEP
FR RH SOL	FR RH IN SOL	OFF	OFF	OFF
	FR RH OUT SOL	OFF	OFF	OFF
	USV [FR-RL]	OFF	ON	ON
	HSV [FR-RL]	OFF	ON*	OFF
FR LH SOL	FR LH IN SOL	OFF	OFF	OFF
	FR LH OUT SOL	OFF	OFF	OFF
	USV [FL-RR]	OFF	ON	ON
	HSV [FL-RR]	OFF	ON*	OFF
RR RH SOL	RR RH IN SOL	OFF	OFF	OFF
	RR RH OUT SOL	OFF	OFF	OFF
	USV [FL-RR]	OFF	ON	ON
	HSV [FL-RR]	OFF	ON*	OFF
RR LH SOL	RR LH IN SOL	OFF	OFF	OFF
	RR LH OUT SOL	OFF	OFF	OFF
	USV [FR-RL]	OFF	ON	ON
	HSV [FR-RL]	OFF	ON*	OFF

\*: ON for 1 to 2 seconds after the touch, and then OFF.

**NOTE:**

A brief moment of ON/OFF condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-137, "Diagnosis Procedure"](#).

**Special Repair Requirement**

INFOID:000000001181803

**1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION**

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-77, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

**BRC**

# C1155 BRAKE FLUID LEVEL SWITCH

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

## C1155 BRAKE FLUID LEVEL SWITCH

### Description

INFOID:000000001181804

Brake fluid level switch contacts close when brake fluid level is low. This is detected by the combination meter which sends the status of fluid level to the ABS actuator and electric unit (control unit) via the CAN communication.

### DTC Logic

INFOID:000000001181805

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1155	BR FLUID LEVEL LOW	Ignition switch ON and brake fluid signal low or not available for 10 seconds.	<ul style="list-style-type: none"><li>• Brake fluid level is low</li><li>• Brake fluid level switch</li><li>• Harness or connector</li><li>• CAN communication line</li><li>• Combination meter</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
BR FLUID LEVEL LOW

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-140. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000001181806

#### INSPECTION PROCEDURE

##### 1.CHECK BRAKE FLUID LEVEL

Check the brake fluid level.

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Investigate and fix.

##### 2.CHECK BRAKE WARNING LAMP 1

Check that the brake warning lamp illuminates after the ignition switch is turned ON.

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Check wiring to brake fluid level switch and combination meter.

##### 3.CHECK BRAKE WARNING LAMP 2

Check that the brake warning lamp in the combination meter turns ON/OFF correctly when operating the parking brake.

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Check parking brake switch. Refer to [BRC-144. "Diagnosis Procedure"](#).

##### 4.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect brake fluid level switch connector and combination meter connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.

# C1155 BRAKE FLUID LEVEL SWITCH

[ESP/TCS/ABS]

## < COMPONENT DIAGNOSIS >

4. Reconnect connectors and then perform the self-diagnosis. Refer to [BRC-95. "CONSULT-III Function \(ABS\)".](#)

Is any item indicated on the self-diagnosis display?

YES >> GO TO 5.

NO >> Poor connection of connector terminal. Replace or repair connector.

## 5.CHECK BRAKE FLUID LEVEL SWITCH

1. Turn ignition switch OFF.
2. Disconnect brake fluid level switch connector.
3. Check continuity between brake fluid level switch connector terminals.

Brake fluid level switch		Condition	Continuity
Connector	Terminal		
E37	1 - 2	When brake fluid is full in the reservoir tank.	Not existed
		When brake fluid is empty in the reservoir tank.	Existed

Is the inspection result normal?

YES >> GO TO 6.

NO >> Brake fluid level switch is malfunction. Replace reservoir tank.

## 6.CHECK BRAKE FLUID LEVEL SWITCH CIRCUIT

1. Disconnect combination meter connector.
2. Check continuity between brake fluid level switch harness connector terminals and combination meter harness connector terminal and/or ground.

Combination meter		Brake fluid level switch		Continuity
Connector	Terminal	Connector	Terminal	
M34	27	E37	1	Existed

Combination meter		—	Continuity
Connector	Terminal		
M34	27	Ground	Not existed

Brake fluid level switch		—	Continuity
Connector	Terminal		
E37	2	Ground	Existed

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace malfunctioning components.

## Component Inspection

INFOID:000000001181807

## 1.CHECK BRAKE FLUID LEVEL SWITCH

1. Turn ignition switch OFF.
2. Disconnect brake fluid level switch connector.
3. Check continuity between brake fluid level switch connector terminals.

Brake fluid level switch		—	Condition	Continuity
Connector	Terminal			
E37	1	Ground	When brake fluid is full in the reservoir tank.	Not existed
			When brake fluid is empty in the reservoir tank.	Existed

Is the inspection result normal?

YES >> INSPECTION END

## C1155 BRAKE FLUID LEVEL SWITCH

[ESP/TCS/ABS]

< COMPONENT DIAGNOSIS >

---

NO >> Replace reservoir tank.

### Special Repair Requirement

INFOID:000000001181808

#### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

---

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-77. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

# U1000, U1002 CAN COMM CIRCUIT

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

## U1000, U1002 CAN COMM CIRCUIT

### Description

INFOID:000000001181809

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### DTC Logic

INFOID:000000001181810

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
U1000	CAN COMM CIRCUIT	When ABS actuator and electric unit (control unit) is not transmitting or receiving CAN communication signal for 2 seconds or more.	<ul style="list-style-type: none"><li>CAN communication line</li><li>ABS actuator and electric unit (control unit)</li></ul>
U1002	SYSTEM COMM	When ABS actuator and electric unit (control unit) is not transmitting or receiving CAN communication signal for 2 seconds or less.	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BRC

### Diagnosis Procedure

INFOID:000000001181811

#### INSPECTION PROCEDURE

##### 1. CHECK CONNECTOR

- Turn ignition switch OFF.
- Disconnect ABS actuator and electric unit (control unit) connector.
- Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
- Reconnect connector and perform self-diagnosis.

Self-diagnosis results
CAN COMM CIRCUIT
SYSTEM COMM

Is above displayed on the self-diagnosis display?

- YES >> Go to [LAN-13, "Trouble Diagnosis Flow Chart"](#).  
NO >> INSPECTION END

### Special Repair Requirement

INFOID:000000001181812

##### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-77, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

# PARKING BRAKE SWITCH

[ESP/TCS/ABS]

< COMPONENT DIAGNOSIS >

## PARKING BRAKE SWITCH

### Description

INFOID:000000001181813

The parking brake switch converts the status of the parking brake pedal to an electric signal and transmits it to the ABS actuator and electric unit (control unit).

### Diagnosis Procedure

INFOID:000000001181814

#### 1.CHECK COMBINATION METER INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between combination meter harness connector terminal 26 and ground.

26 – Ground	
Parking brake ON	: Approx. 0 V
Parking brake OFF	: Approx. 5 V

Is the inspection result normal?

YES >> INSPECTION END  
NO >> GO TO 2.

#### 2.CHECK PARKING BRAKE SWITCH SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and parking brake switch connector.
3. Check continuity between combination meter harness connector terminal 26 and parking brake switch harness connector terminal 1.

26 – 1 : Continuity should exist.

4. Check continuity between combination meter harness connector terminal 26 and ground.

26 – Ground : Continuity should not exist.

Is the inspection result normal?

YES >> INSPECTION END  
NO >> Repair harness or connector.

### Component Function Check

INFOID:000000001181815

#### 1.CHECK PARKING BRAKE SWITCH OPERATION

Operate the parking brake pedal. Then check that the brake warning lamp in the combination meter turns on/off correctly.

Condition	Brake warning lamp illumination status
When the parking brake switch is operation	ON
When the parking brake switch is not operation.	OFF

Is the inspection result normal?

YES >> INSPECTION END  
NO >> Go to diagnosis procedure. Refer to [BRC-144, "Diagnosis Procedure"](#).

### Component Inspection

INFOID:000000001181816

#### INSPECTION PROCEDURE

##### 1.CHECK PARKING BRAKE SWITCH

1. Turn ignition switch OFF.
2. Disconnect parking brake switch connector.



# PARKING BRAKE SWITCH

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

3. Check continuity between parking brake switch terminal and ground.

Parking brake switch		—	Condition	Continuity
Connector	Terminal			
M103	1	Ground	When the parking brake switch is operated.	Existed
			When the parking brake switch is not operated.	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace parking brake switch.

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

**BRC**

# ESP OFF SWITCH

[ESP/TCS/ABS]

< COMPONENT DIAGNOSIS >

## ESP OFF SWITCH

### Description

INFOID:000000001181817

ESP OFF switch can deactivate (turn OFF) the ESP/TCS function by pressing the ESP OFF switch.

### Component Function Check

INFOID:000000001181818

#### 1. CHECK ESP OFF SWITCH OPERATION

Turn ON/OFF the ESP OFF switch and check that the ESP OFF indicator lamp in the combination meter turns ON/OFF correctly.

Condition	ESP OFF indicator lamp illumination status
ESP OFF switch: ON	ON
ESP OFF switch: OFF	OFF

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-146. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000001181819

#### 1. CHECK ESP OFF SWITCH

1. Turn ignition switch OFF.
2. Disconnect ESP OFF switch connector.
3. Check continuity between ESP OFF switch connector terminals.

ESP OFF switch		Condition	Continuity
Connector	Terminal		
M5	1 - 2	When ESP OFF switch is hold pressed.	Existed
		When releasing ESP OFF switch.	Not existed

Is the inspection result normal?

YES >> GO TO 2.

NO >> ESP OFF switch is malfunctioning. Replace ESP OFF switch.

#### 2. CHECK ESP OFF SWITCH HARNESS

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between ESP OFF switch connector terminals and ABS actuator and electric unit (control unit) connector terminal and/or ground.

ABS actuator and electric unit (control unit)		ESP OFF switch		Continuity
Connector	Terminal	Connector	Terminal	
E36	21	M5	1	Existed

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	21	Ground	Not existed

ESP OFF switch		—	Continuity
Connector	Terminal		
M5	2	Ground	Existed

Is the inspection result normal?

# ESP OFF SWITCH

[ESP/TCS/ABS]

## < COMPONENT DIAGNOSIS >

- YES >> GO TO 3.  
NO >> If the open or short in harness, repair or replace harness.

### 3.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-25. "Diagnosis Description"](#).

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit).  
NO >> Repair or replace combination meter.

## Component Inspection

INFOID:000000001181820

## INSPECTION PROCEDURE

### 1.CHECK ESP OFF SWITCH

1. Turn ignition switch OFF.
2. Disconnect ESP OFF switch connector.
3. Check continuity between ESP OFF switch connector terminals.

ESP OFF switch		Condition	Continuity
Connector	Terminal		
M5	1 - 2	When ESP OFF switch is hold pressed.	Existed
		When releasing ESP OFF switch.	Not existed

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Replace ESP OFF switch.

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

**BRC**

# ABS WARNING LAMP

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

## ABS WARNING LAMP

### Description

INFOID:000000001181821

×: ON –: OFF

Condition	ABS warning lamp
Ignition switch OFF	–
For 1 second after turning ON ignition switch	×
1 second later after turning ON ignition switch	–
ABS function is malfunctioning.	×
EBD function is malfunctioning.	×

### Component Function Check

INFOID:000000001181822

#### 1.CHECK ABS WARNING LAMP OPERATION

Check that the lamp illuminates for approximately 1 second after the ignition switch is turned ON.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-148, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000001181823

#### 1.CHECK SELF-DIAGNOSIS

Perform ABS actuator and electric unit (control unit) self-diagnosis. Refer to [BRC-95, "CONSULT-III Function \(ABS\)"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check items displayed by self-diagnosis.

#### 2.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-25, "Diagnosis Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace combination meter.

# BRAKE WARNING LAMP

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

## BRAKE WARNING LAMP

### Description

INFOID:000000001181824

×: ON –: OFF

Condition	Brake warning lamp <sup>NOTE 1</sup>
Ignition switch OFF	–
For 1 second after turning ON ignition switch	× <sup>NOTE 2</sup>
1 second later after turning ON ignition switch	× <sup>NOTE 2</sup>
EBD function is malfunctioning.	×

#### NOTE:

- 1: Brake warning lamp will turn on in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).
- 2: After starting engine, brake warning lamp is turned off.

### Component Function Check

INFOID:000000001181825

#### 1. BRAKE WARNING LAMP OPERATION CHECK 1

Check that the lamp illuminates for approximately 1 second after the ignition switch is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Go to diagnosis procedure. Refer to [BRC-149. "Diagnosis Procedure"](#).

#### 2. BRAKE WARNING LAMP OPERATION CHECK 2

Check that the brake warning lamp in the combination meter turns ON/OFF correctly when operating the parking brake pedal.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check parking brake switch. Refer to [BRC-144. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000001181826

#### 1. CHECK PARKING BRAKE SWITCH

Check that the brake warning lamp in the combination meter turns ON/OFF correctly when operating the parking brake pedal.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check parking brake switch. Refer to [BRC-144. "Diagnosis Procedure"](#).

#### 2. CHECK SELF-DIAGNOSIS

Perform ABS actuator and electric unit (control unit) self-diagnosis. Refer to [BRC-95. "CONSULT-III Function \(ABS\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check items displayed by self-diagnosis.

#### 3. CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-25. "Diagnosis Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace combination meter.

# ESP OFF INDICATOR LAMP

[ESP/TCS/ABS]

< COMPONENT DIAGNOSIS >

## ESP OFF INDICATOR LAMP

### Description

INFOID:000000001181827

×: ON –: OFF

Condition	ESP OFF indicator lamp
Ignition switch OFF	–
For 1 second after turning ON ignition switch	×
1 second later after turning ON ignition switch	–
ESP OFF switch turned ON. (ESP function is OFF.)	×
ESP/TCS function is malfunctioning.	×
ABS function is malfunctioning.	×
EBD function is malfunctioning.	×

### Component Function Check

INFOID:000000001181828

#### 1.ESP OFF INDICATOR LAMP OPERATION CHECK 1

Check that the lamp illuminates for approximately 1 second after the ignition switch is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Go to diagnosis procedure. Refer to [BRC-150, "Diagnosis Procedure"](#).

#### 2.ESP OFF INDICATOR LAMP OPERATION CHECK 2

Check that the ESP OFF indicator lamp in the combination meter turns ON/OFF correctly when operating the ESP OFF switch.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check ESP OFF switch. Refer to [BRC-146, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000001181829

#### 1.CHECK SELF-DIAGNOSIS

Perform ABS actuator and electric unit (control unit) self-diagnosis. Refer to [BRC-95, "CONSULT-III Function \(ABS\)"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check items displayed by self-diagnosis.

#### 2.CHECK ESP OFF SWITCH

Check that the ESP OFF indicator lamp in the combination meter turns ON/OFF correctly when operating the ESP OFF switch.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check ESP OFF switch. Refer to [BRC-146, "Diagnosis Procedure"](#).

#### 3.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-25, "Diagnosis Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace combination meter.

# SLIP INDICATOR LAMP

< COMPONENT DIAGNOSIS >

[ESP/TCS/ABS]

## SLIP INDICATOR LAMP

### Description

INFOID:000000001181830

×: ON –: OFF

Condition	SLIP indicator lamp
Ignition switch OFF	–
For 1 second after turning ON ignition switch	×
1 second later after turning ON ignition switch	–
VDC/TCS function is malfunctioning.	×
ABS function is malfunctioning.	×
EBD function is malfunctioning.	×

### Component Function Check

INFOID:000000001181831

#### 1.CHECK SLIP INDICATOR LAMP OPERATION

Check that the lamp illuminates for approximately 1 second after the ignition switch is turned ON.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-151, "Diagnosis Procedure"](#).

#### Diagnosis Procedure

INFOID:000000001181832

#### 1.CHECK SELF-DIAGNOSIS

Perform ABS actuator and electric unit (control unit) self-diagnosis. Refer to [BRC-95, "CONSULT-III Function \(ABS\)"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check items displayed by self-diagnosis.

#### 2.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-25, "Diagnosis Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace combination meter.

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS >

[ESP/TCS/ABS]

## ECU DIAGNOSIS

### ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Reference Value

INFOID:000000001181833

VALUES ON THE DIAGNOSIS TOOL

#### CAUTION:

The display shows the control unit calculation data, so a normal value might be displayed even in the event the output circuit (harness) is open or short-circuited.

Monitor item	Condition		Value/Status
FR LH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running <sup>NOTE 1</sup>	Nearly matches the speed meter display (± 10% or less)
FR RH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running <sup>NOTE 1</sup>	Nearly matches the speed meter display (± 10% or less)
RR LH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running <sup>NOTE 1</sup>	Nearly matches the speed meter display (± 10% or less)
RR RH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running <sup>NOTE 1</sup>	Nearly matches the speed meter display (± 10% or less)
STOP LAMP SW	Stop lamp switch signal status	When brake pedal is depressed	ON
		When brake pedal is not depressed	OFF
BATTERY VOLT	Battery voltage supplied to the ABS actuator and electric unit (control unit)	Ignition switch ON	10 – 16 V
GEAR	Gear position determined by TCM	1st gear	1
		2nd gear	2
		3rd gear	3
		4th gear	4
		5th gear	5
		6th gear	6
SLCT LVR POSI	Selector lever position	P position	P
		R position	R
		N position	N
		D position	D
OFF SW	ESP OFF switch ON/OFF	ESP OFF switch ON (When ESP OFF indicator lamp is ON)	ON
		ESP OFF switch OFF (When ESP OFF indicator lamp is OFF)	OFF
YAW RATE SEN	Yaw rate detected by yaw rate/side G sensor	When vehicle stop	Approx. 0 °/s
		When vehicle turning	-75 to 75 °/s
ACCEL POS SIG	Throttle actuator opening/closing is displayed (linked with accelerator pedal)	Accelerator pedal not depressed (ignition switch is ON)	0 %
		Depress accelerator pedal (ignition switch is ON)	0 - 100 %



# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS >

[ESP/TCS/ABS]

Monitor item	Condition		Value/Status	
SIDE G-SENSOR	Transverse G detected by side G sensor	Vehicle stopped	Approx. 0 m/s <sup>2</sup>	A
		Vehicle turning right	Negative value (m/s <sup>2</sup> )	B
		Vehicle turning left	Positive value (m/s <sup>2</sup> )	
STR ANGLE SIG	Steering angle detected by steering angle sensor	Straight-ahead	Approx. 0°	C
		Steering wheel turned	-720 to 720°	
PRESS SENSOR	Brake fluid pressure detected by pressure sensor	With ignition switch turned ON and brake pedal released	Approx. 3 bar	D
		With ignition switch turned ON and brake pedal depressed	0 to 200 bar	
ENGINE RPM	With engine running	With engine stopped	0 tr/min	E
		Engine running	Almost in accordance with tachometer display	BRC
FLUID LEV SW	Brake fluid level switch signal status	When brake fluid level switch ON	ON	
		When brake fluid level switch OFF	OFF	G
PARK BRAKE SW	Parking brake switch signal status	Parking brake switch is active	ON	
		Parking brake switch is inactive	OFF	
FR RH IN SOL	Operation status of front RH inlet solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (in fail-safe mode)	ON	H
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	OFF	I
FR RH OUT SOL	Operation status of front RH outlet solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (in fail-safe mode)	ON	J
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	OFF	K
FR LH IN SOL	Operation status of front LH inlet solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (in fail-safe mode)	ON	L
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	OFF	M
FR LH OUT SOL	Operation status of front RH inlet solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (in fail-safe mode)	ON	N
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	OFF	O
RR RH IN SOL	Operation status of rear RH inlet solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (in fail-safe mode)	ON	P
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	OFF	

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS >

[ESP/TCS/ABS]

Monitor item	Condition	Value/Status	
RR RH OUT SOL	Operation status of rear RH outlet solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (in fail-safe mode)	ON
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	OFF
RR LH IN SOL	Operation status of rear LH inlet solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (in fail-safe mode)	ON
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	OFF
RR LH OUT SOL	Operation status of rear RH inlet solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (in fail-safe mode)	ON
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	OFF
MOTOR RELAY	Motor and motor relay operation	When the motor relay and motor are operating	ON
		When the motor relay and motor are not operating	OFF
ACTUATOR RLY NOTE 2	Actuator relay operation	When the actuator relay is operating	ON
		When the actuator relay is not operating	OFF
ABS WARN LAMP	ABS warning lamp <sup>NOTE 3</sup>	When ABS warning lamp is ON	ON
		When ABS warning lamp is OFF	OFF
OFF LAMP	ESP OFF indicator lamp <sup>NOTE 3</sup>	When ESP OFF indicator lamp is ON	ON
		When ESP OFF indicator lamp is OFF	OFF
SLIP LAMP	SLIP indicator lamp <sup>NOTE 3</sup>	When SLIP indicator lamp is ON	ON
		When SLIP indicator lamp is OFF	OFF

**NOTE:**

- 1: Confirm tire pressure is normal.
- 2: Every 20 seconds momentary switch to OFF.
- 3: On and off timing for warning lamp and indicator lamp.
- ABS warning lamp: [BRC-148, "Description"](#).
- ESP OFF indicator lamp: [BRC-150, "Description"](#).
- SLIP indicator lamp: [BRC-151, "Description"](#).

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)


< ECU DIAGNOSIS >

[ESP/TCS/ABS]

## Wiring Diagram - BRAKE CONTROL SYSTEM -

INFOID:000000001181834

### BRAKE CONTROL SYSTEM (WITH ESP)



2007/04/27

JCFWA0050GB

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS >

[ESP/TCS/ABS]

## BRAKE CONTROL SYSTEM (WITH ESP)

Connector No.	B11
Connector Name	WIRE TO WIRE
Connector Type	TK10M/W-NSB



Terminal No.	Color of Wire	Signal Name [Specification]
5	G/O	-
6	G/Y	-
7	LG	-
8	V	-[Except 2WD models without ESP]

Connector No.	B41
Connector Name	REAR WHEEL SENSOR RH
Connector Type	RK02FGY




Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
2	V	-[Except 2WD models without ESP]

Connector No.	B44
Connector Name	REAR WHEEL SENSOR LH
Connector Type	RK02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	G/O	-
2	G/Y	-

Connector No.	E13
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	NS18FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
41	P	-

Connector No.	E22
Connector Name	FRONT WHEEL SENSOR LH
Connector Type	RK02MGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-[With ESP]
2	Y	-

Connector No.	E38
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Type	BAA2FB-AH24-LH



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	GND(MTR)
2	Y	+B(MTR)
3	W/R	+B(SOL)
4	B	GND(SOL)
5	R	DS FL
6	G/Y	DP RL
8	V	DP RR
9	W	DP FR
10	B	DS FR
11	O	DIAG-K
14	O	CAN-L(VRS)

Terminal No.	Color of Wire	Signal Name [Specification]
15	P	CAN-L
16	Y	DF FL
17	G/O	DS RL
18	P	IGN
19	LG	DS RR
20	R/W	STOP L SIG
21	G	VDO OFF SW
25	G	CAN-H(VRS)
26	L	CAN-H

Connector No.	E37
Connector Name	BRAKE FLUID LEVEL SWITCH
Connector Type	YV02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	R/B	-
2	B	-

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS >

[ESP/TCS/ABS]


## BRAKE CONTROL SYSTEM (WITH ESP)

Connector No.	E114
Connector Name	STOP LAMP SWITCH
Connector Type	M02FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	W	-

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	T180MW-NS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
44	G	-[With ESP]
51	P	-
52	L	-
53	P	-
54	O	-[With ESP]
55	G	-
60	R/B	-
62	V	-
69	O	-

Connector No.	E118
Connector Name	STOP LAMP SWITCH
Connector Type	M04FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
5	G/O	-
6	G/Y	-
7	LG	-
8	V	-[Except 2WD models without ESP]

Connector No.	E115
Connector Name	STOP LAMP SWITCH
Connector Type	M04FW-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	R/W	-
3	G	-
4	B	-

Connector No.	E118
Connector Name	STOP LAMP SWITCH
Connector Type	M04FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	R/W	-
3	O	-
4	W/L	-

Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW



Terminal No.	Color of Wire	Signal Name [Specification]
7	O	-

Connector No.	M5
Connector Name	ESP OFF SWITCH
Connector Type	TK08FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	B	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BRC

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS >

[ESP/TCS/ABS]


## BRAKE CONTROL SYSTEM (WITH ESP)

Connector No.	M30
Connector Name	STEERING ANGLE SENSOR
Connector Type	TH08FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	W/L	IGN SAS
3	B	GND SAS
4	L	CAN-H
8	P	CAN-L

Connector No.	M103
Connector Name	PARKING BRAKE SWITCH
Connector Type	P01FB-A



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-

Connector No.	M64
Connector Name	COMBINATION METER
Connector Type	SAB40FW




Terminal No.	Color of Wire	Signal Name [Specification]
21	L	CAN-H
22	P	CAN-L
26	V	PARKING BRAKE SW
27	BR	BRAKE FLUID LEVEL SW

Connector No.	M72
Connector Name	YAW RATE SENSOR
Connector Type	AAZ04FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	GND(YRS)
2	O	CAN-L
3	G	CAN-H
4	P	IGN(YRS)

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	TH60FW-NS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
44	G	-[WHL ESP]
51	P	-
52	L	-
53	P	-
54	O	-[WHL ESP]
55	G	-
60	BR	-
62	V	-
68	O	-

## Fail-Safe

### ABS, EBD SYSTEM

In case of electrical malfunctions with the ABS, ABS warning lamp, ESP OFF indicator lamp, SLIP indicator lamp will turn on. In case of electrical malfunctions with the EBD, brake warning lamp, ABS warning lamp, ESP OFF indicator lamp and SLIP indicator lamp will turn on. Simultaneously, the ESP/TCS/ABS become one of the following conditions of the fail-safe function.

JCFWA0053GE

INFOID:000000001181835

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

[ESP/TCS/ABS]

< ECU DIAGNOSIS >

- For malfunction of ABS, only the EBD is activated and the condition of vehicle is the same condition of vehicles without TCS/ABS system.

**NOTE:**

ABS self-diagnosis sound may be heard. That is a normal condition because a self-diagnosis for “Ignition switch ON” and “The first starting” are being performed.

- For malfunction of EBD, EBD and ABS become inoperative, and the condition of vehicle is the same as the condition of vehicles without TCS/ABS, EBD system.

## ESP/TCS SYSTEM

In case of malfunction in the ESP/TCS/ABS system, ESP OFF indicator lamp, SLIP indicator lamp are turned on, and the condition of vehicle is the same as the condition of vehicles without ESP/TCS control.

**CAUTION:**

If the Fail-Safe function is activated, then perform self-diagnosis for ESP/TCS/ABS control system.

## DTC No. Index

INFOID:000000001181836

DTC	Items (CONSULT screen terms)	Reference
C1101	RR RH SENSOR-1	<a href="#">BRC-99, "Description"</a>
C1102	RR LH SENSOR-1	
C1103	FR RH SENSOR-1	
C1104	FR LH SENSOR-1	
C1105	RR RH SENSOR-2	<a href="#">BRC-102, "Description"</a>
C1106	RR LH SENSOR-2	
C1107	FR RH SENSOR-2	
C1108	FR LH SENSOR-2	
C1109	BATTERY VOLTAGE [ABNORMAL]	<a href="#">BRC-105, "Description"</a>
C1110	CONTROLLER FAILURE	<a href="#">BRC-107, "Description"</a>
C1111	PUMP MOTOR	<a href="#">BRC-109, "Description"</a>
C1114	MAIN RELAY	<a href="#">BRC-112, "Description"</a>
C1115	ABS SENSOR [ABNORMAL SIGNAL]	<a href="#">BRC-114, "Description"</a>
C1116	STOP LAMP SW	<a href="#">BRC-117, "Description"</a>
C1120	FR LH IN ABS SOL	<a href="#">BRC-120, "Description"</a>
C1121	FR LH OUT ABS SOL	<a href="#">BRC-123, "Description"</a>
C1122	FR RH IN ABS SOL	<a href="#">BRC-120, "Description"</a>
C1123	FR RH OUT ABS SOL	<a href="#">BRC-123, "Description"</a>
C1124	RR LH IN ABS SOL	<a href="#">BRC-120, "Description"</a>
C1125	RR LH OUT ABS SOL	<a href="#">BRC-123, "Description"</a>
C1126	RR RH IN ABS SOL	<a href="#">BRC-120, "Description"</a>
C1127	RR RH OUT ABS SOL	<a href="#">BRC-123, "Description"</a>
C1130	ENGINE SIGNAL 1	<a href="#">BRC-126, "Description"</a>
C1131	ENGINE SIGNAL 2	
C1132	ENGINE SIGNAL 3	
C1142	PRESS SEN CIRCUIT	<a href="#">BRC-127, "Description"</a>
C1143	ST ANG SEN CIRCUIT	<a href="#">BRC-129, "Description"</a>
C1144	ST ANG SEN SIGNAL	
C1145	YAW RATE SENSOR	<a href="#">BRC-132, "Description"</a>
C1146	SIDE G-SEN CIRCUIT	<a href="#">BRC-135, "Description"</a>

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BRC

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS >

[ESP/TCS/ABS]

DTC	Items (CONSULT screen terms)	Reference
C1147	USV LINE [FL-RR]	<a href="#">BRC-137, "Description"</a>
C1148	USV LINE [FR-RL]	
C1149	HSV LINE [FL-RR]	
C1150	HSV LINE [FR-RL]	
C1153	EMERGENCY BRAKE	<a href="#">BRC-107, "Description"</a>
C1155	BR FLUID LEVEL LOW	<a href="#">BRC-140, "Description"</a>
C1170	VARIANT CORDING	<a href="#">BRC-107, "Description"</a>
U1000	CAN COMM CIRCUIT	<a href="#">BRC-143, "Description"</a>
U1002	SYSTEM COMM	<a href="#">BRC-143, "Description"</a>



# EXCESSIVE ABS FUNCTION OPERATION FREQUENCY

< SYMPTOM DIAGNOSIS >

[ESP/TCS/ABS]

## SYMPTOM DIAGNOSIS

### EXCESSIVE ABS FUNCTION OPERATION FREQUENCY

#### Diagnosis Procedure

INFOID:000000001181837

#### 1. CHECK START

Check front and rear brake force distribution using a brake tester. Refer to [BR-49. "General Specifications"](#) (LHD models), [BR-96. "General Specifications"](#) (RHD models).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check brake system.

#### 2. CHECK FRONT AND REAR AXLE

Make sure that there is no excessive play in the front and rear axles.

- Front: [FAX-7. "Inspection"](#) (2WD models), [FAX-59. "Inspection"](#) (4WD models)
- Rear: [RAX-3. "Inspection"](#) (2WD models), [RAX-9. "Inspection"](#) (4WD models)

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

#### 3. CHECK WHEEL SENSOR AND SENSOR ROTOR

Check the following.

- Wheel sensor installation for damage.
- Sensor rotor installation for damage.
- Wheel sensor connector connection.
- Wheel sensor harness inspection.

Is the inspection result normal?

YES >> GO TO 4.

NO >> 

- Replace wheel sensor or sensor rotor.
- Repair harness.

#### 4. CHECK ABS WARNING LAMP DISPLAY

Make sure that the ABS warning lamp is turned off after the ignition switch is turned ON or when driving.

Is the ABS warning lamp illuminated?

YES >> Perform self-diagnosis. Refer to [BRC-95. "CONSULT-III Function \(ABS\)"](#).

NO >> INSPECTION END

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BRC

# UNEXPECTED PEDAL REACTION

< SYMPTOM DIAGNOSIS >

[ESP/TCS/ABS]

## UNEXPECTED PEDAL REACTION

### Diagnosis Procedure

INFOID:000000001181838

#### 1.CHECK BRAKE PEDAL STROKE

Check brake pedal stroke. Refer to [BR-8, "Inspection and Adjustment"](#) (LHD models), [BR-55, "Inspection and Adjustment"](#) (RHD models).

Is the stroke too large?

- YES >>
- Bleed air from brake tube and hose. Refer to [BR-12, "Bleeding Brake System"](#) (LHD models), [BR-59, "Bleeding Brake System"](#) (RHD models).
  - Check brake pedal, brake booster, and master cylinder for mount play, looseness, brake system fluid leakage, etc.
  - Brake pedal: [BR-17, "Exploded View"](#) (LHD models), [BR-64, "Exploded View"](#) (RHD models).
  - Brake booster: [BR-30, "Exploded View"](#) (LHD models), [BR-77, "Exploded View"](#) (RHD models).
  - Brake master cylinder: [BR-27, "Exploded View"](#) (LHD models), [BR-74, "Exploded View"](#) (RHD models).
  - Brake fluid: [BR-11, "Inspection"](#) (LHD models), [BR-58, "Inspection"](#) (RHD models).

NO >> GO TO 2.

#### 2.CHECK FUNCTION

Disconnect ABS actuator and electric unit (control unit) connector to deactivate ABS. Check if braking force is normal in this condition. Connect connector after inspection.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check brake system.

# THE BRAKING DISTANCE IS LONG

< SYMPTOM DIAGNOSIS >

[ESP/TCS/ABS]

## THE BRAKING DISTANCE IS LONG

### Diagnosis Procedure

INFOID:000000001181839

#### **CAUTION:**

The stopping distance on slippery road surfaces might be longer with the ABS operating than when the ABS is not operating.

#### **1**.CHECK FUNCTION

Turn ignition switch OFF and disconnect ABS actuator and electric unit (control unit) connector to deactivate ABS. In this condition, check stopping distance. After inspection, connect connector.

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Check brake system.

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

**BRC**

## ABS FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[ESP/TCS/ABS]

---

### ABS FUNCTION DOES NOT OPERATE

#### Diagnosis Procedure

INFOID:000000001181840

**CAUTION:**

**ABS does not operate when speed is 10 km/h (6 MPH) or lower.**

**1**.CHECK ABS WARNING LAMP DISPLAY

---

Make sure that the ABS warning lamp turns OFF after ignition switch is turned ON or when driving.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Perform self-diagnosis. Refer to [BRC-95, "CONSULT-III Function \(ABS\)"](#).

# PEDAL VIBRATION OR ABS OPERATION SOUND OCCURS

< SYMPTOM DIAGNOSIS >

[ESP/TCS/ABS]

## PEDAL VIBRATION OR ABS OPERATION SOUND OCCURS

### Diagnosis Procedure

INFOID:000000001181841

#### **CAUTION:**

Under the following conditions, ABS is activated and vibration is felt when brake pedal is lightly depressed (just place a foot on it). However, this is normal.

- When shifting gears
- When driving on slippery road
- During cornering at high speed
- When passing over bumps or grooves [at approximately 50 mm (1.97 in) or more]
- When pulling away just after starting engine [at approximately 10 km/h (6 MPH) or higher]

#### 1. SYMPTOM CHECK 1

Check that there are pedal vibrations when the engine is started.

Do vibrations occur?

YES >> GO TO 2.

NO >> Inspect the brake pedal.

#### 2. SYMPTOM CHECK 2

Check that there are ABS operation noises when the engine is started.

Do the operation noises occur?

YES >> GO TO 3.

NO >> Perform self-diagnosis. Refer to [BRC-95. "CONSULT-III Function \(ABS\)".](#)

#### 3. SYMPTOM CHECK 3

Check symptoms when electrical component (headlamps, etc.) switches are operated.

Do symptoms occur?

YES >> Check if there is a radio, antenna, antenna lead wire, or wiring close to the control unit. If there is, move it farther away.

NO >> INSPECTION END

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BRC

# VEHICLE JERKS DURING ESP/TCS/ABS CONTROL

< SYMPTOM DIAGNOSIS >

[ESP/TCS/ABS]

## VEHICLE JERKS DURING ESP/TCS/ABS CONTROL

### Diagnosis Procedure

INFOID:000000001181842

#### 1. SYMPTOM CHECK

Check if the vehicle jerks during ESP/TCS/ABS control.

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> GO TO 2.

#### 2. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnostic of ABS actuator and electric unit (control unit). Refer to [BRC-95, "CONSULT-III Function \(ABS\)"](#).

Are self-diagnosis results indicated?

- YES >> Check corresponding items, make repairs, and perform ABS actuator and electric unit (control unit) self-diagnosis.
- NO >> GO TO 3.

#### 3. CHECK CONNECTOR

- Turn ignition switch OFF and disconnect ABS actuator and electric unit (control unit) connector and check terminal for deformation, disconnection, looseness, etc.
- Securely connect connectors and perform ABS actuator and electric unit (control unit) self-diagnosis.

Are self-diagnosis results indicated?

- YES >> If poor contact, damage, open or short circuit of connector terminal is found, repair or replace.
- NO >> GO TO 4.

#### 4. CHECK ECM AND TCM SELF-DIAGNOSIS RESULTS

Perform ECM and TCM self-diagnosis.

Are self-diagnosis results indicated?

- YES >> Check the corresponding items.
  - ECM:
    - HR16DE (with EURO-OBD): [ECH-89, "CONSULT-III Function"](#).
    - HR16DE (without EURO-OBD): [ECH-419, "CONSULT-III Function"](#).
    - MR20DE (with EURO-OBD): [ECM-91, "CONSULT-III Function"](#).
    - MR20DE (without EURO-OBD): [ECM-425, "CONSULT-III Function"](#).
    - K9K: [ECK-63, "Diagnosis Description"](#).
    - M9R: [ECR-101, "CONSULT-III Function"](#).
  - TCM: Refer to [TM-432, "CONSULT-III Function \(TRANSMISSION\)"](#).
- NO >> Replace ABS actuator and electric unit (control unit).

# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[ESP/TCS/ABS]

## NORMAL OPERATING CONDITION

### Description

INFOID:000000001181843

Symptom	Result
Slight vibrations are felt on the brake pedal and the operation noises occur, when ESP, TCS or ABS is activated.	This is a normal condition due to the ESP, TCS or ABS activation.
Stopping distance is longer than that of vehicles without ABS when the vehicle drives on rough, gravel, or snow-covered (fresh, deep snow) roads.	
The brake pedal moves and generates noises, when TCS or ESP is activated due to rapid acceleration or sharp turn.	
The brake pedal vibrates and motor operation noises occur from the engine room, after the engine starts and just after the vehicle starts.	This is a normal, and it is caused by the ABS operation check.
Depending on the road conditions, the driver may experience a sluggish feel.	This is normal, because TCS places the highest priority on the optimum traction (stability).
TCS may activate momentarily if wheel speed changes when driving over location where friction coefficient varies, when downshifting, or when fully depressing accelerator pedal.	
The ABS warning lamp, ESP OFF indicator lamp and SLIP indicator lamp may turn ON when the vehicle is subject to strong shaking or large vibration, such as when the vehicle is rotating on a turntable or located on a ship while the engine is running.	In this case, restart the engine on a normal road. If the normal condition is restored, there is no malfunction. At that time, erase the self-diagnosis memory.
ESP may not operate normally or the ABS warning lamp, ESP OFF indicator lamp, and SLIP indicator lamp may illuminate, when running on a special road that is extremely slanted (e.g. bank in a circuit course).	
A malfunction may occur in the yaw rate/side G sensor system, when the vehicle turns sharply, such as during a spin turn, axle turn, or drift driving, while the ESP function is off (ESP OFF indicator lamp illuminated).	
The vehicle speed will not increase even though the accelerator pedal is depressed, when inspecting the speedometer on a 2-wheel chassis dynamometer.	Normal (Deactivate the ESP/TCS function before performing an inspection on a chassis dynamometer.)

A  
B  
C  
D  
E  
**BRC**  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000001583060

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIRBAG" and "SEAT BELT" of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIRBAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.


#### Precaution for Brake System

INFOID:000000001181845

**WARNING:**

**Clean brake pads and shoes with a waste cloth, then wipe with a dust collector.**

- Only use DOT 3 brake fluid. Refer to [MA-27, "Fluids and Lubricants"](#).
- Never to reuse drained brake fluid.
- Never to spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface.
- Never to use mineral oils such as gasoline or light oil. They may damage rubber parts and cause improper operation.
- Always loosen the brake tube flare nut with a flare nut wrench.
- Tighten the brake tube flare nut to the specified torque with a flare nut torque wrench.
- Always conform the specified tightening torque when installing the brake pipes.
- Brake system is an important safety part. If a brake fluid leak is detected, always disassemble the affected part. If a malfunction is detected, replace part with a new one.
- Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) connector or the battery negative terminal before performing the work.



#### Precaution for Brake Control

INFOID:000000001181846

- Just after starting vehicle after ignition switch ON, brake pedal may vibrate or motor operating noise may be heard from engine compartment. This is normal condition.
- When an error is indicated by ABS or another warning lamp, collect all necessary information from customer (what symptoms are present under what conditions) and check for simple causes before starting diagnostic servicing. Besides electrical system inspection, check brake booster operation, brake fluid level, and oil leaks.
- If tire size and type are used in an improper combination, or brake pads are not Genuine NISSAN parts, stopping distance or steering stability may deteriorate.
- ABS might be out of order or malfunctions by putting a radio (wiring inclusive), an antenna and a lead-in wire near the control unit.
- If aftermarket parts (car stereo, CD player, etc.) have been installed, check for incidents such as harness pinches, open circuits, and improper wiring.
- ESP system may not operate normally or a ESP OFF indicator lamp or SLIP indicator lamp may light.



# PRECAUTIONS

< PRECAUTION >

[ESP/TCS/ABS]

- When replacing the following parts with parts other than genuine parts or making modifications: Suspension-related parts (shock absorber, spring, bushing, etc.), tires, wheels (other than specified sizes), brake-related parts (pad, rotor, caliper, etc.), engine-related parts (muffler, ECM, etc.) and body reinforcement-related parts (roll bar, tower bar, etc.).
- When driving with worn or deteriorated suspension, tires and brake-related parts.

A

B

C

D

E

**BRC**

G

H

I

J

K

L

M

N

O


P

PREPARATION

PREPARATION


Special Service Tool

INFOID:000000001181847

Tool number Tool name	Description
<p>GG94310000 Flare nut torque wrench a: 10 mm (0.39 in)/ 12 mm (0.47 in)</p>  <p>S-NT406</p>	<p>Installing each brake piping</p>

**ON-VEHICLE REPAIR****WHEEL SENSOR****FRONT WHEEL SENSOR****FRONT WHEEL SENSOR : Exploded View**

INFOID:000000001181848



1. Front LH wheel sensor

A. White line (slant line)

Refer to GI section [GI-4. "Components"](#) for symbols in the figure.**NOTE:**

The above figure (front side) shows left side. Right side is the mirror image.

**FRONT WHEEL SENSOR : Removal and Installation**

INFOID:000000001181849

**REMOVAL**

Pay attention to the following when removing sensor.

**CAUTION:**

- Do not twist sensor harness as much as possible, when removing it. Pull sensors out without pulling on sensor harness.
- Take care to avoid damaging sensor edges or rotor teeth. Remove wheel sensor first before removing front or rear wheel hub. This is to avoid damage to sensor wiring and loss of sensor function.
- When you see the harness of the wheel sensor from the front side of the vehicle ensure that the white lines (A) are not twisted.

**INSTALLATION**Pay attention to the following when installing wheel sensor. Tighten installation bolts to the specified torques. Refer to [BRC-66. "FRONT WHEEL SENSOR : Exploded View"](#).

- When installing, make sure there is no foreign material such as iron chips on and in the mounting hole of the wheel sensor. Make sure no foreign material has been caught in the sensor rotor. Remove any foreign material and clean the mount.
- When installing wheel sensor, be sure to press rubber grommets in until they lock at locations shown above in the figure. When installed, harness must not be twisted.

**REAR WHEEL SENSOR**


# WHEEL SENSOR

< ON-VEHICLE REPAIR >

[ESP/TCS/ABS]

## REAR WHEEL SENSOR : Exploded View

INFOID:000000001181850



1. Rear LH wheel sensor

A. 2WD models

B. 4WD models

Refer to GI section [GI-4, "Components"](#) for symbols in the figure.

### NOTE:

The above figure (front side) shows left side. Right side is the mirror image.

## REAR WHEEL SENSOR : Removal and Installation

INFOID:000000001181851

### REMOVAL

Pay attention to the following when removing sensor.

#### CAUTION:

- Do not twist sensor harness as much as possible, when removing it. Pull sensors out without pulling on sensor harness.
- Take care to avoid damaging sensor edges or rotor teeth. Remove wheel sensor first before removing front or rear wheel hub. This is to avoid damage to sensor wiring and loss of sensor function.

### INSTALLATION

Pay attention to the following when installing wheel sensor. Tighten installation bolts to the specified torques. Refer to [BRC-67, "REAR WHEEL SENSOR : Exploded View"](#).

- When installing, make sure there is no foreign material such as iron chips on and in the mounting hole of the wheel sensor. Make sure no foreign material has been caught in the sensor rotor. Remove any foreign material and clean the mount.
- When installing wheel sensor, be sure to press rubber grommets in until they lock at locations shown above in the figure. When installed, harness must not be twisted.

< ON-VEHICLE REPAIR >

## SENSOR ROTOR

### FRONT SENSOR ROTOR

#### FRONT SENSOR ROTOR : Exploded View

INFOID:000000001181852

Refer to [FAX-9, "Exploded View"](#) (2WD models), [FAX-61, "Exploded View"](#) (4WD models).

#### FRONT SENSOR ROTOR : Removal and Installation

INFOID:000000001181853

#### REMOVAL

Sensor rotor cannot be disassembled. Remove the sensor rotor together with wheel hub and bearing assembly. Refer to [FAX-9, "Removal and Installation"](#) (2WD models), [FAX-61, "Removal and Installation"](#) (4WD models).

#### INSTALLATION

Sensor rotor cannot be disassembled. Installation the sensor rotor together with wheel hub and bearing assembly. Refer to [FAX-9, "Removal and Installation"](#) (2WD models), [FAX-61, "Removal and Installation"](#) (4WD models).

### REAR SENSOR ROTOR

#### REAR SENSOR ROTOR : Exploded View

INFOID:000000001181854

Refer to [RAX-4, "Exploded View"](#) (2WD models), [RAX-13, "Exploded View"](#) (4WD models).

#### REAR SENSOR ROTOR : Removal and Installation

INFOID:000000001181855

#### 2WD MODELS

##### Removal

Sensor rotor cannot be disassembled. Remove the sensor rotor together with wheel hub and bearing assembly. Refer to [RAX-4, "Removal and Installation"](#).

##### Installation

Sensor rotor cannot be disassembled. Installation the sensor rotor together with wheel hub and bearing assembly. Refer to [RAX-4, "Removal and Installation"](#).

#### 4WD MODELS

For removal and installation of sensor rotor, refer to [RAX-14, "Disassembly and Assembly"](#).

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ON-VEHICLE REPAIR >


[ESP/TCS/ABS]

## ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Exploded View

INFOID:000000001181856

LHD models



1. ABS actuator and electric unit (control unit)

2. Connector

3. Bushing

4. Bracket

A. To front LH brake caliper

B. To rear RH brake caliper

C. To Rear LH brake caliper

D. To front RH brake caliper

E. From master cylinder secondary side

F. From master cylinder primary side

⇐: Vehicle front


Refer to GI section [GI-4, "Components"](#) for symbols in the figure.

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ON-VEHICLE REPAIR >

[ESP/TCS/ABS]

RHD models



- |  |  |                                      |
|--|--|--------------------------------------|
| 1. ABS actuator and electric unit (control unit) | 2. Connector                           | 3. Bushing                           |
| 4. Bracket                                       |  |                                      |
| A. To front LH brake caliper                     | B. To rear RH brake caliper            | C. To Rear LH brake caliper          |
| D. To front RH brake caliper                     | E. From master cylinder secondary side | F. From master cylinder primary side |

←: Vehicle front

Refer to GI section [GI-4. "Components"](#) for symbols in the figure.

## Removal and Installation

INFOID:000000001181857

### LHD MODELS

#### Removal

#### CAUTION:

- Before servicing, disconnect the battery cable from negative terminal.
- To remove brake tube, use a flare nut wrench to prevent flare nuts and brake tube from being damaged. To install, use flare nut crowfoot and torque wrench.
- Do not apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.
- Do not remove and install actuator by holding harness.
- After work is completed, bleed air from brake tube. Refer to [BR-12. "Bleeding Brake System"](#) (LHD models), [BR-59. "Bleeding Brake System"](#) (RHD models).

1. Remove cowl top cover. Refer to [EXT-19. "Exploded View"](#).
2. Remove exhaust manifold.
  - HR16DE: [EX-5. "Exploded View"](#).
  - MR20DE: [EX-10. "Exploded View"](#).
  - K9K: [EX-15. "Exploded View"](#).
  - M9R: [EM-369. "Exploded View"](#).
3. Disconnect ABS actuator and electric unit (control unit) connector.
4. Loosen brake tube flare nuts, then remove brake tubes from ABS actuator and electric unit (control unit).
5. Remove ABS actuator and electric unit (control unit) bracket mounting nut.
6. Remove ABS actuator and electric unit (control unit) from vehicle.

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ON-VEHICLE REPAIR >

[ESP/TCS/ABS]

## Installation

Note the following, and install in the reverse order of removal.

### CAUTION:

- Before servicing, disconnect the battery cable from negative terminal.
- To remove brake tube, use a flare nut wrench to prevent flare nuts and brake tube from being damaged. To install, use flare nut crowfoot and torque wrench.
- Do not apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.
- Do not remove and install actuator by holding harness.
- After work is completed, bleed air from brake tube. Refer to [BR-12, "Bleeding Brake System"](#) (LHD models), [BR-59, "Bleeding Brake System"](#) (RHD models).
- After installing harness connector in the ABS actuator and electric unit (control unit), make sure connector is securely locked.
- When replacing ABS actuator and electric unit (control unit), make sure to adjust neutral position of steering angle sensor. Refer to [BRC-77, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

## RHD MODELS

### Removal

#### CAUTION:

- Before servicing, disconnect the battery cable from negative terminal.
  - To remove brake tube, use a flare nut wrench to prevent flare nuts and brake tube from being damaged. To install, use flare nut crowfoot and torque wrench.
  - Do not apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.
  - Do not remove and install actuator by holding harness.
  - After work is completed, bleed air from brake tube. Refer to [BR-12, "Bleeding Brake System"](#) (LHD models), [BR-59, "Bleeding Brake System"](#) (RHD models).
1. Remove cowl top cover. Refer to [EXT-19, "Exploded View"](#).
  2. Remove air cleaner and air duct.
    - HR16DE: [EM-28, "Exploded View"](#).
    - MR20DE: [EM-145, "Exploded View"](#).
    - K9K: [EM-266, "Exploded View"](#).
    - M9R: [EM-354, "Exploded View"](#).
  3. Disconnect ABS actuator and electric unit (control unit) connector.
  4. Loosen brake tube flare nuts, then remove brake tubes from ABS actuator and electric unit (control unit).
  5. Remove ABS actuator and electric unit (control unit) bracket mounting nut.
  6. Remove ABS actuator and electric unit (control unit) from vehicle.

### Installation

Note the following, and install in the reverse order of removal.

#### CAUTION:


- Before servicing, disconnect the battery cable from negative terminal.
- To remove brake tube, use a flare nut wrench to prevent flare nuts and brake tube from being damaged. To install, use flare nut crowfoot and torque wrench.
- Do not apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.
- Do not remove and install actuator by holding harness.
- After work is completed, bleed air from brake tube. Refer to [BR-12, "Bleeding Brake System"](#) (LHD models), [BR-59, "Bleeding Brake System"](#) (RHD models).
- After installing harness connector in the ABS actuator and electric unit (control unit), make sure connector is securely locked.
- When replacing ABS actuator and electric unit (control unit), make sure to adjust neutral position of steering angle sensor. Refer to [BRC-77, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).



## YAW RATE/SIDE G SENSOR

### Exploded View

INFOID:000000001181858



1. Yaw rate/side G sensor

↔: Vehicle front

Refer to GI section [GI-4. "Components"](#) for symbol makes in the figure.

### Removal and Installation

INFOID:000000001181859

#### REMOVAL

##### CAUTION:

- Do not drop or strike yaw rate/side G sensor, because it has little endurance to impact.
- Do not use power tool etc., because yaw rate/side G sensor is sensitive for the impact.

1. Remove lower instrument cover RH. Refer to [IP-11. "Exploded View"](#).
2. Disconnect yaw rate/side G sensor harness connector.
3. Remove mounting nuts. Remove yaw rate/side G sensor.

#### INSTALLATION

Note the following, and install in the reverse order of removal.

##### CAUTION:

- Do not drop or strike yaw rate/side G sensor, because it has little endurance to impact.
- Do not use power tool etc., because yaw rate/side G sensor is sensitive for the impact.

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# STEERING ANGLE SENSOR


< ON-VEHICLE REPAIR >

[ESP/TCS/ABS]

## STEERING ANGLE SENSOR

Exploded View

INFOID:000000001181860



1. Steering angle sensor

↩: Vehicle front

## Removal and Installation

INFOID:000000001181861

### REMOVAL

1. Remove spiral cable assembly. Refer to [SR-6, "Exploded View"](#).
2. Remove steering angle sensor from spiral cable assembly.

### INSTALLATION

Note the following, and install in the reverse order of removal.

#### **CAUTION:**

**After work, make sure to adjust neutral position of steering angle sensor. Refer to [BRC-77, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).**