

SECTION **IDX**
ALPHABETICAL INDEX

A

B

C

D

E

F

G

H

I

J

K

L

IDX

ALPHABETICAL INDEX

A

A/C - Wiring diagram [ATC-35](#), [MTC-35](#)
 A/C air flow [MTC-22](#)
 A/C component layout [MTC-17](#)
 A/C compressor clutch removal and installation .. [ATC-123](#), [MTC-85](#)
 A/C compressor description [MTC-16](#)
 A/C compressor mounting [ATC-122](#), [MTC-83](#), [MTC-84](#)
 A/C compressor precaution [ATC-9](#), [MTC-9](#)
 A/C compressor special service tool . [ATC-12](#), [MTC-12](#)
 A/C diagnostic work flow (auto A/C) [ATC-31](#)
 A/C diagnostic work flow (manual A/C) [MTC-28](#)
 A/C evaporator [ATC-128](#), [MTC-90](#)
 A/C HFC134a (R134a) system identification [ATC-5](#),
[MTC-4](#)
 A/C HFC134a (R134a) system introduction ... [MTC-16](#)
 A/C HFC134a (R134a) system precaution [ATC-4](#),
[MTC-3](#)
 A/C HFC134a (R134a) system service procedure [ATC-119](#), [MTC-79](#)
 A/C HFC134a (R134a) system service tools .. [ATC-12](#),
[MTC-12](#)
 A/C HFC134a system service equipment precaution ...
[ATC-9](#), [MTC-9](#)
 A/C lubricant (R134a) [ATC-18](#), [MTC-18](#)
 A/C lubrication oil [ATC-18](#), [MTC-18](#)
 A/C operational check [ATC-49](#), [MTC-38](#)
 A/C performance chart [ATC-82](#), [MTC-59](#)
 A/C performance test diagnoses [ATC-79](#), [MTC-58](#)
 A/C self-diagnoses (auto A/C) [ATC-41](#)
 A/C service data specification [ATC-133](#)
 A/C switch [MTC-21](#)
 A/C symptom chart (auto A/C) [ATC-31](#)
 A/C symptom chart (manual A/C) [MTC-28](#)
 A/C trouble diagnoses (auto A/C) [ATC-31](#)
 A/C trouble diagnoses (manual A/C) [MTC-28](#)
 A/C, A - Wiring diagram [ATC-35](#)
 A/C, M - Wiring diagram [MTC-35](#)
 A/T - Wiring diagram [AT-16](#)
 A/T - Wiring diagram - AT - FTS [AT-111](#)
 A/T - Wiring diagram - AT - MAIN [AT-100](#)
 A/T - Wiring diagram - AT - PNP/SW [AT-105](#)
 A/T - Wiring diagram - AT - VSS A/T [AT-117](#)
 A/T fluid temperature sensor [AT-109](#)
 A/T IND - Wiring diagram [DI-41](#)
 A/T indicator [DI-41](#)
 A/T self-diagnoses [AT-40](#), [AT-50](#), [AT-51](#)
 A/T shift lock system [AT-247](#)
 A/T shift lock system - Wiring diagram [AT-248](#)
 A/T Wiring diagram - AT - ENG SS [AT-121](#)
 A/T Wiring diagram AT - 1ST [AT-126](#)
 A/T Wiring diagram AT - 2ND [AT-131](#)
 A/T Wiring diagram AT - 3RD [AT-136](#)
 A/T Wiring diagram AT - 4TH [AT-141](#)
 A/T Wiring diagram AT - BA/FTS [AT-191](#)
 A/T Wiring diagram AT - CAN [AT-187](#)
 A/T Wiring diagram AT - LPSV [AT-161](#)
 A/T Wiring diagram AT - NONDTC [AT-209](#)

A/T Wiring diagram AT - OVRCSV [AT-182](#)
 A/T Wiring diagram AT - SSV/A [AT-167](#)
 A/T Wiring diagram AT - SSV/B [AT-172](#)
 A/T Wiring diagram AT - TCCSIG [AT-153](#)
 A/T Wiring diagram AT - TCV [AT-148](#)
 A/T Wiring diagram AT - TPS [AT-177](#)
 A/T Wiring diagramm AT - VSSMTR .. [AT-198](#), [AT-202](#)
 ABS - Wiring diagram [BRC-12](#)
 Absolute pressure sensor [EC-804](#)
 Accelerator control system [ACC-2](#)
 Accelerator pedal position (APP) sensor [EC-263](#), [EC-269](#), [EC-465](#), [EC-915](#), [EC-922](#), [EC-1125](#)
 Accelerator pedal released position learning ... [EC-668](#)
 Active damper suspension system - Wiring diagram
[FSU-4](#)
 Aiming adjustment [LT-23](#)
 Air bag [SRS-3](#)
 Air bag disposal [SRS-54](#)
 Air bag precautions [GI-3](#)
 Air bleeding (hydraulic clutch)Air bleeding (hydraulic
 clutch) [CL-7](#)
 Air bleeding for brake systemAir bleeding for brake sys-
 tem [BR-9](#)
 Air cleaner and air duct [EM-14](#), [EM-110](#)
 Air cleaner filter replacement [MA-17](#), [MA-24](#)
 Air conditioner - Wiring diagram [ATC-35](#), [MTC-35](#)
 Air conditioner cut control [EC-34](#), [EC-652](#)
 Air conditioning - See A/C [MTC-16](#)
 Air flow meter - See Mass air flow sensor [EC-154](#), [EC-161](#), [EC-387](#), [EC-790](#), [EC-798](#), [EC-1041](#)
 Air mix door control linkage adjustment [ATC-63](#)
 Alternator [SC-33](#)
 Ambient sensor [ATC-103](#)
 Angular tightening application [EM-4](#), [EM-101](#)
 Antenna [AV-26](#)
 Anti-lock brake system - Wiring diagram [BRC-12](#)
 APPS1 - Wiring diagram [EC-271](#), [EC-924](#)
 APPS2 - Wiring diagram [EC-467](#), [EC-1127](#)
 APPS3 - Wiring diagram [EC-265](#), [EC-917](#)
 ASC/BS - Wiring diagram [EC-535](#), [EC-1183](#)
 ASC/SW - Wiring diagram [EC-528](#), [EC-1176](#)
 ASCBOF - Wiring diagram [EC-603](#), [EC-1259](#)
 ASCD [EC-628](#)
 ASCD (automatic speed control device) [EC-1286](#),
[ACS-2](#)
 ASCIND - Wiring diagram [EC-611](#), [EC-1269](#)
 Audio [AV-4](#)
 AUDIO - Wiring diagram [AV-4](#), [AV-8](#)
 Auto air conditioner - Wiring diagram [ATC-35](#)
 Auto anti-dazzling inside mirror [GW-39](#), [GW-40](#)
 Automatic amplifier [ATC-39](#), [ATC-52](#)
 Automatic transaxle number [GI-43](#)
 Automatic transmission fluid replacement [MA-29](#)

B

Back door trim [EI-27](#)
 BACK/L - Wiring diagram [LT-107](#)
 Back-up lamp switch (M/T)Back-up lamp switch [MT-12](#)

ALPHABETICAL INDEX

Basic inspection	EC-84 , EC-705		Closed loop control	EC-32 , EC-442 , EC-650
Battery	SC-4		Closed loop control (Bank 1)	EC-1099
Battery/Starting/Charging System Tester	SC-6 , SC-16 , SC-27		Closed loop control (Bank 2)	EC-1099
Baulk ring (M/T)	MT-20		Clutch coverClutch cover	CL-15
BCM(Body control module)	BCS-3		Clutch discClutch disc	CL-15
Block heater	EM-67 , EM-186		Clutch fluid level	MA-28
Blower motor	ATC-67 , ATC-109 , MTC-49 , MTC-70		Clutch master cylinderClutch master cylinder	CL-8
Blower resistor	MTC-76		Clutch operating cylinderClutch operating cylinder	CL-10
Blower unit	ATC-108 , MTC-69		Clutch pedalClutch pedal	CL-5
Board-on lift	GI-37		Clutch release mechanismClutch release mechanism	
Body alignment	BL-150		CL-13	
Body component parts	BL-139		Coil spring (front)	FSU-9
Body construction	BL-149		Coil spring (rear)Coil spring	RSU-9
Body exterior paint color	BL-138		Collision diagnosis	SRS-61
Body repair	BL-138		Combination lamp, front, removal and installation ..	LT-25
Body sealing	BL-146		Combination lamp, rear, removal and installation ..	LT-122
Brake boosterBrake booster	BR-17		Combination meter	DI-4
Brake control valve (Proportioning valve)Brake control valve (Proportioning valve)	BR-31		Component Location (auto A/C)	ATC-32
Brake fluid changeBrake fluid change	BR-9		Component Location (manual A/C)	MTC-29
Brake fluid level	MA-32		Compressor clutch removal and installation ..	ATC-123 , MTC-85
Brake fluid level and line checkBrake fluid level and line check	BR-9		Compressor mounting	ATC-122 , MTC-83 , MTC-84
Brake hydraulic lineBake hydraulic line	BR-10		Compressor precaution	ATC-9 , MTC-9
Brake inspection	MA-32		Compressor special service tool	ATC-12 , MTC-12
Brake lines and cables inspection	MA-32		Condenser	ATC-126 , MTC-88
Brake master cylinderBrake master cylinder	BR-13		Connector inspection	GI-22
Brake pedalBrake pedal	BR-6		Console box - See Instrument panel	IP-10
Brake switch	EC-549 , EC-1205		CONSULT for engine	EC-106 , EC-730
BRK/SW - Wiring diagram	EC-550 , EC-1206		CONSULT for TCS	BRC-58
Bulb specifications	LT-146		CONSULT general information	GI-35
Bumper, front	EI-13		Contaminated refrigerant	MTC-3
Bumper, rear	EI-15		Control unit	ATC-102 , MTC-67
BYPS/V - Wiring diagram .	EC-512 , EC-520 , EC-1162 , EC-1169		Control units (terminal arrangement)	PG-67
C				
Camshaft	EM-34 , EM-134		Controller Area Network (CAN)	LAN-4 , LAN-8 , LAN-27 , LAN-43
Camshaft inspection	EM-36 , EM-139		Converter housing installation	AT-357
Camshaft position sensor (PHASE) ..	EC-291 , EC-945		COOL/F - Wiring diagram ..	EC-242 , EC-447 , EC-1106
CAN - Wiring diagram ..	EC-139 , EC-764 , LAN-9 , LAN-28 , LAN-44		Coolant mixture ratio	MA-13
CAN (Controller Area Network)	LAN-4 , LAN-8 , LAN-27 , LAN-43		Coolant overtemperarute enrichment photection ..	EC-238
CAN communication	EC-34 , EC-138 , EC-653 , EC-763 , AT-185 , BRC-71 , LAN-4 , LAN-8 , LAN-27 , LAN-43		Coolant replacement	CO-6 , CO-28 , MA-14
Canister-See EVAP canister	EC-617 , EC-1275		Coolant replacementVQ35DE	MA-22
CHARGE - Wiring diagram	SC-26		Cooling circuit (engine)	CO-31
Charging system	SC-25		Cooling fan motor	EC-249 , EC-454 , EC-1113
Chassis and body maintenance	MA-28		Cooling unit (A/C evaporator)	ATC-112 , ATC-128 , MTC-73 , MTC-90
Chassis and body maintenanceSchedule 1	MA-9		Corrosion protection	BL-143
Chassis and body maintenanceSchedule 2	MA-11		Coupling sleeve (M/T)	MT-20
CHIME - Wiring diagram	DI-49		Crankcase ventilation system - See Positive crankcase ventilation	EC-626 , EC-1284
CIGAR - Wiring diagram	WW-28		Crankshaft	EM-68
Cigarette lighter	WW-28		Crankshaft position sensor (POS)	EC-284 , EC-938
Circuit breaker	PG-63		Crash zone sensor	SRS-50
Clearance lamp	LT-109		Cylinder block	EM-67 , EM-186
			Cylinder block boring	EM-87
			Cylinder head	EM-53 , EM-164

IDX

ALPHABETICAL INDEX

Cylinder head bolt tightening	EM-170	Engine oil filter replacementQR25DE ... MA-18 , MA-25
D		
Data link connector	EC-613 , EC-1271	Engine oil precautions GI-3 , GI-6
Data link connector for Consult	EC-108 , EC-732	Engine oil replacementQR25DE MA-17 , MA-24
Daytime light system	LT-28	Engine removal EM-63 , EM-182
Daytime running light - See Daytime light system ..	LT-28	Engine serial number GI-43
Diagnosis sensor unit	SRS-53	ETC1 - Wiring diagram EC-400 , EC-1050
Diagnostic trouble code (DTC) for OBD system	EC-15 , EC-58 , EC-632 , EC-677	ETC2 - Wiring diagram EC-408 , EC-1058
Diagnostic trouble code (DTC) inspection priority chart	EC-81 , EC-701	ETC3 - Wiring diagram EC-412 , EC-1062
Differential gear (FF M/T)	MT-23	EVAP canister EC-1275
Dimensions	GI-43	EVAP canister purge volume control solenoid valve EC-315 , EC-477 , EC-617 , EC-972 , EC-1135 , EC-1275
DLC - Wiring diagram	EC-613 , EC-1271	EVAP canister vent control valve EC-321 , EC-485 , EC-491 , EC-978 , EC-1143 , EC-1149
Door glass	GW-34 , GW-37	EVAP control system (small leak) diagnosis .. EC-307 , EC-341 , EC-349 , EC-475 , EC-498 , EC-963 , EC-998
Door glass Fitting Adjustment(Front)	GW-35	EVAP control system pressure sensor ... EC-328 , EC-334 , EC-985 , EC-991
Door glass Fitting Adjustment(Rear)	GW-38	EVAP control system purge flow monitoring diagnosis . EC-301 , EC-957
Door mirror	GW-61	EVAP vapor lines inspection MA-20 , MA-27
Door trim	EI-27	Evaporative emission (EVAP) system EC-614 , EC-617 , EC-1272
Door, front	BL-75 , GW-34	Evaporator ATC-128 , MTC-90
Door, rear	BL-75 , GW-37	Exhaust manifold EM-116
Drive belt	EM-12	Exhaust system EX-3 , EX-6
Drive belt inspectionQR25DE	MA-14	Exhaust system inspection EX-3 , EX-6 , MA-28
Drive belt inspectionVQ35DE	MA-21	Expansion valve ATC-129 , MTC-91
Drive shaft (front)	FAX-11	
Driver air bag	SRS-39	
Dropping resistor (A/T)	AT-159	
DTC work support	EC-117 , EC-742	
DTRL - Wiring diagram	LT-38	
Duct and grilles	ATC-117 , MTC-77	
E		
ECM input/output signal	EC-99 , EC-722	
ECM power supply	EC-131 , EC-383 , EC-757 , EC-1037	
ECM/PW - Wiring diagram	EC-384	
ECTS - Wiring diagram	EC-174 , EC-813 , EC-818	
Electric sun roof	RF-10	
Electric throttle control actuator	EC-397 , EC-399 , EC-411 , EC-1047 , EC-1049 , EC-1061	
Electrical diagnoses	GI-22	
Electrical load signal circuit	EC-601 , EC-1257	
Electronic ignition (EI) system	EC-33 , EC-651	
EMNT - Wiring diagram	EC-1248	
Engine control circuit diagram	EC-97 , EC-720	
Engine control component parts location ...	EC-93 , EC-714	
Engine control module (ECM)	EC-376 , EC-1030	
Engine control system diagram and chart ..	EC-28 , EC-646	
Engine coolant	CO-32	
Engine coolant temperature sensor (ECTS) ...	EC-172 , EC-177 , EC-811 , EC-816	
Engine fail-safe system	EC-82 , EC-703	
Engine mounting control (Front)	EC-1247	
Engine oil	LU-17	
F		
F/PUMP - Wiring diagram	EC-585 , EC-1241	
Fan control amp.	ATC-116	
Fan switch	MTC-21	
Final drive (FF M/T)	MT-23	
Flow charts	GI-25	
FLS1 - Wiring diagram	EC-359 , EC-1008	
FLS2 - Wiring diagram	EC-366 , EC-1015	
FLS3 - Wiring diagram	EC-508 , EC-1158	
Fluid temperature sensor (A/T)	AT-109	
Fluids	MA-12	
Fluorescent leak detector	ATC-129 , MTC-91	
Flywheel (clutch)Flywheel (clutch)	CL-15	
Fork rod (M/T)	MT-22	
Freeze frame data	EC-59 , EC-678	
Front bumper	EI-13	
Front combination lamp removal and installation ..	LT-25	
Front disc brakeFront disc brake	BR-20	
Front door	BL-75 , GW-34	
Front Door Trim	EI-27	
Front passenger air bag	SRS-43	
Front seat	SE-14	
Front seat belt	SB-3	
Front seat belt pre-tensioner	SB-2 , SRS-3 , SRS-52	
Front side air bag	SRS-47	
FTTS - Wiring diagram	EC-235 , EC-894 , EC-898	
FUEL - Wiring diagram	EC-222 , EC-228	
Fuel cut control (at no load high engine speed) ..	EC-34 , EC-652	
Fuel gauge	DI-4	

ALPHABETICAL INDEX

Fuel injection system	EC-220 , EC-226	
Fuel injection system (Bank 1)	EC-877 , EC-885	A
Fuel injection system (Bank 2)	EC-877 , EC-885	B
Fuel injector and fuel tube	EM-29 , EM-129	C
Fuel level sensor ..	EC-358 , EC-363 , EC-365 , EC-507 , EC-1007 , EC-1012 , EC-1014 , EC-1157	D
Fuel line inspection	FL-3 , MA-17 , MA-24	E
Fuel precautions	GI-3 , GI-5	F
Fuel pressure check	EC-51 , EC-671	G
Fuel pressure release	EC-51 , EC-671	H
Fuel pump	EC-584 , EC-1240	I
Fuel system	FL-3	J
Fuel systemCommercial Service Tools	FL-2	K
Fuel systemPREPARATION	FL-2	L
Fuel tank temperature sensor ...	EC-232 , EC-234 , EC-892 , EC-897	IDX
Fuel tank vacuum relief valve	EC-1275	
FUELB1 - Wiring diagram	EC-879 , EC-887	
FUELB2 - Wiring diagram	EC-880 , EC-888	
Fuse	PG-63 , PG-72	
Fuse block	PG-71	
Fusible link	PG-63 , PG-72	
G		
Garage jack and safety stand	GI-37	
Gear components (M/T)	MT-20	
Generator	SC-33	
Generator - See Alternator	SC-33	
Generic scan tool (GST)	EC-119 , EC-743	
Glass	GW-11 , GW-13 , GW-34 , GW-37	
Glove box lamp	LT-142	
Grease	MA-12	
Ground distribution	PG-26	
H		
H/LAMP - Wiring diagram	LT-12	
Handling precautions for plastics	BL-161	
Harness connector	PG-64	
Harness connector inspection	GI-22	
Harness layout	PG-37	
Hazard warning lamp	LT-80	
Headlamp	LT-5	
Headlamp removal and installation	LT-25	
Heated oxygen sensor 1	EC-185 , EC-191 , EC-200 , EC-416 , EC-422	
Heated oxygen sensor 1 (bank 1)	EC-827 , EC-836 , EC-847 , EC-1066 , EC-1072	
Heated oxygen sensor 1 (bank 2)	EC-827 , EC-836 , EC-847 , EC-1066 , EC-1072	
Heated oxygen sensor 1 heater	EC-144	
Heated oxygen sensor 1 heater (bank 1)	EC-774	
Heated oxygen sensor 1 heater (bank 2)	EC-774	
Heated oxygen sensor 2	EC-207 , EC-213 , EC-428 , EC-435	
Heated oxygen sensor 2 (bank 1)	EC-857 , EC-867 , EC-1079 , EC-1089	
Heated oxygen sensor 2 (bank 2)	EC-857 , EC-867 , 48	
EC-1079	, EC-1089	
Heated oxygen sensor 2 heater	EC-149	
Heated oxygen sensor 2 heater (bank 1)	EC-782	
Heated oxygen sensor 2 heater (bank 2)	EC-782	
Heated seat	SE-12	
HEATER - Wiring diagram	MTC-33	
Heater and cooling unit (Heater core) ..	ATC-112 , ATC-113 , MTC-73 , MTC-74	
Heater system - Wiring diagram	MTC-33	
Heater unit (heater core) ..	ATC-112 , ATC-113 , MTC-73 , MTC-74	
Height (Dimensions)	GI-43	
HFC134a (R134a) system identification ..	ATC-5 , MTC-4	
HFC134a (R134a) system introduction ..	MTC-16	
HFC134a (R134a) system precaution ..	ATC-4 , MTC-3	
HFC134a (R134a) system service procedure ..	ATC-119 , MTC-79	
HFC134a (R134a) system service tools ..	ATC-12 , MTC-12	
HFC134a system service equipment precaution ..	ATC-9 , MTC-9	
HO2S1 - Wiring diaram	EC-187 , EC-194 , EC-203	
HO2S1H - Wiring diagram	EC-146	
HO2S2 - Wiring diagram	EC-209 , EC-215 , EC-430 , EC-437	
HO2S2H - Wiring diagram	EC-151	
Horn	WW-32	
HORN - Wiring diagram	WW-32	
How to erase DTC for OBD system ..	EC-67 , EC-687	
HSEAT - Wiring diagram	SE-13	
I		
IATS - Wiring diagram	EC-169 , EC-808 , EC-822	
Identification	MTC-4	
Identification plate	GI-43	
Idle air volume learning	EC-49 , EC-669	
Idle mixture ratio	EC-39 , EC-658	
Idle speed	EC-39 , EC-84 , EC-658 , EC-705	
Idle speed control (ISC)	EC-372 , EC-374 , EC-1021 , EC-1023	
Ignition coil	EM-26 , EM-126 , EC-554 , EC-1210	
Ignition control system	EC-554 , EC-1210	
Ignition key hole illumination	LT-130	
Ignition timing	EC-39 , EC-84 , EC-658 , EC-705	
IGNSYS - Wiring diagram	EC-555 , EC-1211	
ILL - Wiring diagram	LT-138	
Illumination	LT-131	
Illumination control	LT-142	
In vehicle sensor	ATC-104	
INJECT - Wiring diagram	EC-575 , EC-1231	
Injector	EC-574 , EC-1230	
Input shaft (FF M/T)	MT-20	
Instrument panel	IP-10	
INT/L - Wiring diagram	LT-143	
Intake air temparature sensor	EC-167 , EC-180 , EC-806 , EC-820	
Intake door control linkage adjustment ..	ATC-66 , MTC-48	

ALPHABETICAL INDEX

Intake door motor	ATC-66 , ATC-110 , MTC-47 , MTC-71	689 , EC-1033
Intake manifold	EM-16 , EM-112	Manual air conditioner - Wiring diagram
Intake sensor	ATC-99 , ATC-106 , MTC-65 , MTC-68	MTC-35
Intake valve timing control	EC-141	Manual transaxle number
Intake valve timing control (Bank 1)	EC-766	GI-43
Intake valve timing control (Bank 2)	EC-766	Manual transmission oil replacement
Intake valve timing control solenoid valve	EC-393	MA-28
Interior	EI-29	Mass air flow sensor (MAFS)
Interior lamp	LT-123	EC-154 , EC-161 , EC-387 , EC-790 , EC-798 , EC-1041
IPDM(Intelligent power distribution module engine room)		
		PG-14
IVC - Wiring diagram	EC-394	Master cylinder (brake)Master cylinder (brake)
IVCB1 - Wiring diagram	EC-768	BR-13
IVCB2 - Wiring diagram	EC-770	Master cylinder (clutch)Master cylinder (clutch)
		CL-8
J		
Jacking points	GI-37	METER - Wiring diagram
Junction box (J/B)	PG-71	DI-12 , DI-65
K		
Keyless entry system - See Multi-remote control system		MIL - Wiring diagram
BL-43		EC-380 , EC-1034
Knock sensor (KS)	EC-280 , EC-934	Mirror, door
KS - Wiring diagram	EC-281 , EC-935	GW-61
L		
LAN system circuit	ATC-55	Mirror, out side
Length (Dimensions)	GI-43	GW-61
License lamp	LT-109	Misfire
Lifting points	GI-37	EC-275 , EC-928
Line pressure solenoid valve	AT-159	Mode door control linkage adjustment
Line pressure test (A/T)	AT-65	ATC-60 , MTC-44
Liquid gasket application	EM-5	Mode door motor
Location of electrical units	PG-60	ATC-114 , MTC-75
Lubricant (R134a) A/C	ATC-18 , MTC-18	Model variation
Lubricants	MA-12	GI-43
Lubrication circuit (engine)	LU-15	Multipoint fuel injection (MFI) system
Lubrication oil A/C	ATC-18 , MTC-18	EC-31 , EC-649
Lubrication-locks, hinges and hood latches	MA-35	Multipoint fuel injection precautions
Luggage compartment trim	EI-35	GI-3 , GI-5
M		
M/T major overhaul	MT-23	Multi-remote control system
M/T oil replacementM/T oil replacement	MT-10	BL-43
M/T removal and installationM/T removal and installation	MT-16	
MAFS - Wiring diagram	EC-157 , EC-163 , EC-389 , EC-793 , EC-800 , EC-1043	
Magnet clutch	ATC-123 , MTC-85	
MAIN - Wiring diagram	EC-131 , EC-757	
Mainshaft (M/T)	MT-20	
Maintenance	MA-5	
Maintenance (engine)QR25DE	MA-14	
Maintenance (engine)VQ35DE	MA-21	
Malfunction indicator lamp (MIL)	EC-69 , EC-379 , EC-	
N		
NATS - Wiring diagram		BL-118
NVH troubleshooting (BR)NVH troubleshooting (BR)		BR-5
NVH troubleshooting (CL)NVH troubleshooting (CL)		CL-4
NVH troubleshooting (EM)		EM-10 , EM-107
NVH troubleshooting (FA)		FAX-4
NVH troubleshooting (RA)		RAX-4
NVH troubleshooting (RSU)NVH Troubleshooting (RSU)		RSU-4
NVH troubleshooting (ST)		PS-5
NVH troubleshooting (WT)NVH troubleshooting (WT)		WT-2
O		
O2H1B1 - Wiring diagram		EC-776
O2H1B2 - Wiring diagram		EC-778
O2H2B1 - Wiring diagram		EC-784
O2H2B2 - Wiring diagram		EC-786
O2S1B1 - Wiring diagram	EC-829 , EC-839 , EC-850	
O2S1B2 - Wiring diagram	EC-831 , EC-841 , EC-852	
O2S2B1 - Wiring diagram	EC-859 , EC-869 , EC-1081 , EC-1091	
O2S2B2 - Wiring diagram	EC-861 , EC-871 , EC-1083 , EC-1093	
Oil change (capacity)QR25DE		MA-12
Oil change (capacity)VQ35DE		MA-12
Oil filter		LU-19
Oil pan (engine)		EM-23 , EM-120
Oil pump (engine)		LU-9 , LU-20
On board diagnostic system		EC-54 , EC-673
Operating cylinder (clutch)Operating cylinder (clutch)		CL-10
ORVR (On-board Refueling Vapor Recovery)		EC-620 , EC-1278

ALPHABETICAL INDEX

Out side mirror	GW-61	Refrigerant general precaution	ATC-5, MTC-4
Overdrive control switch	AT-242	Refrigerant lines	ATC-119, MTC-79
Overheat	EC-1103	Refrigerant pressure sensor ..	EC-596, EC-1252, ATC-126, MTC-57, MTC-88
Overrun clutch solenoid valve	AT-180	Refrigeration cycle	MTC-16
P			
Park/Neutral position switch	EC-545, EC-1194	Remote keyless entry system	BL-43
Park/neutral position switch (A/T)	AT-103	Reverse idler shaft (M/T)	MT-20
Park/neutral position switch (M/T)Park/neutral position switch (M/T)	MT-12	Reverse main gear (M/T)	MT-20
Parking brake controlParking brake control	PB-2	Revolution sensor (A/T)	AT-115
Parking drum brakeParking drum brake	PB-5	Road wheel size	GI-43
Parking lamp	LT-109	Rocker cover	EM-32, EM-132
PCV (positive crankcase ventilation)	EC-626, EC-1284	Room lamp	LT-123, LT-129
Periodic maintenance	MA-7	Room lamp - See Interior lamp	LT-123
Personal lamp	LT-129	ROOM/L - Wiring diagram	LT-125
PGC/V - Wiring diagram	EC-317, EC-479, EC-974, EC-1137	RP/SEN - Wiring diagram	EC-597, EC-1253
PHASE - Wiring diagram	EC-292	S	
PHSB1 - Wiring diagram	EC-946	S/SIG - Wiring diagram	EC-581, EC-1237
PHSB2 - Wiring diagram	EC-948	SAE J1930 terminology list	GI-47
Piston ring inspection	EM-195	SAE J1979 - Mode 1 - 7	EC-54, EC-673
Piston to bore clearance	EM-86	SEAT - Wiring diagram	SE-10
PNP/SW - Wiring diagram	EC-547, EC-1196	Seat belt inspection	SB-5, MA-36
POS - Wiring diagram	EC-286, EC-940	Seat belt pre-tensioner disposal	SRS-54
POWER - Wiring diagram	EC-1038, PG-5	Seat belt, front	SB-3
Power seat	SE-10	Seat belt, rear	SB-4
Power steering fluid level	MA-33	Seat, front	SE-14
Power steering oil pressure switch	EC-591	Seat, rear	SE-18
Power steering pressure (PSP) sensor	EC-1025	SEN/PW - Wiring diagram	EC-472, EC-1132
Power supply routing	PG-3	SHIFT - Wiring diagram	AT-248
Power window	GW-15	Shift control components (M/T)	MT-22
PRE/SE - Wiring diagram	EC-330, EC-336, EC-987, EC-993	Shift control components (M/T)Shift control components (M/T)	MT-13
Precations for Leak detection dye	MTC-4	Shift fork (M/T)	MT-22
Precautions (General)	GI-3	Shift lock system	AT-247
Precautions in repairing high strength steel	BL-164	Shift schedule	AT-364
Pressure test (A/T)	AT-65	Shift solenoid valve A (A/T)	AT-165
PS/SEN - Wiring diagram	EC-1026	Shift solenoid valve B (A/T)	AT-170
PST/SW - Wiring diagram	EC-592	Shock absorber (front)	FSU-9
R		Shock absorber (rear)Shock absorber (rear)	RSU-8
R134a - See HFC134a	MTC-3	Side air bag (satellite) sensor	SRS-51
Radiator	CO-34	Side curtain air bag	SRS-48
Rear bumper	EI-15	Side trim	EI-29
Rear combination lamp removal and installation ...	LT-122	SMJ (super multiple junction)	PG-68
Rear disc brakeRear disc brake	BR-26	Spare tire size	GI-43
Rear door	BL-75, GW-37	Spark plug	EM-127
Rear seat	SE-18	Spark plug replacementQR25DE	MA-19, MA-26
Rear seat belt	SB-4	Specification value	EC-126, EC-752
Rear suspensionRear suspension	RSU-5	Speedometer	DI-4
Rear window	GW-13	Spiral cable	SRS-41
Rear window defogger	GW-41	Spot lamp	LT-129
Refrigerant connection precaution	ATC-6, MTC-5	SROOF - Wiring diagram	RF-11
Refrigerant discharging evacuating charging	ATC-119, MTC-79	SRS - See Supplemental Restraint System	SRS-5
		SRS - Wiring diagram	SRS-12
		SRS Trouble diagnoses	SRS-8
		Stabilizer bar (front)	FSU-11
		Stall test (A/T)	AT-61
		Standardized relay	PG-69
		START - Wiring diagram	SC-14

ALPHABETICAL INDEX

Start signal	EC-580 , EC-1236	
Starter	SC-20	
Starting system	SC-9	
Steering gear and linkage inspection	MA-33	
Steering knuckle	FAX-6	
STEP/L - Wiring diagram	LT-104	
Stop lamp switch	EC-549 , EC-1205	
STOP/L - Wiring diagram	LT-100	
Strut (front)	FSU-9	
Sun roof, electric	RF-10	
Sunload sensor	ATC-105	
Sunroof	RF-15	
Supplemental Restraint System	SRS-5	
Supplemental restraint system - Wiring diagram	SRS-12	
Symbols and abbreviations	GI-8 , GI-9 , GI-20	
Symptom matrix chart	EC-89 , EC-710	
Synchronizer (M/T)	MT-20	
System readiness test (SRT) code	EC-59 , EC-679	

T

Tachometer	DI-4
Tail lamp	LT-109
TAIL/L - Wiring diagram	LT-116
TCM circuit diagram	AT-16
TCM inspection table	AT-93
TCS - Wiring diagram	BRC-54
TCS component parts and connector location	BRC-53
TCS control unit	BRC-47
TCS self-diagnosis	BRC-64
TCS wheel sensors	BRC-53
Thermo control amp	ATC-107
Thermostat	CO-20
Three way catalyst	EM-116
Three way catalyst function	EC-297
Three way catalyst function (Bank 1)	EC-953
Three way catalyst function (Bank 2)	EC-953
Three way catalyst precautions	GI-3 , GI-5
Throttle control motor relay	EC-406 , EC-1056
Throttle position sensor (TPS)	EC-250 , EC-257 , EC-455 , EC-461 , EC-463 , EC-901 , EC-908 , EC-1114 , EC-1121 , EC-1123
Throttle position switch	AT-242
Tightening torque of standard bolts	GI-41
Timing chain	EM-45 , EM-146
Tire rotation	MA-31
Tire size	GI-43
Torque converter installation	AT-261 , AT-357
Torque convertor clutch solenoid valve	AT-146
Tow truck towing	GI-40
Towing point	GI-40
TPS1 - Wiring diagram	EC-259 , EC-910
TPS2 - Wiring diagram	EC-457 , EC-1116
TPS3 - Wiring diagram	EC-252 , EC-903
Traction control system - Wiring diagram	BRC-54
Transaxle serial number	GI-43
Transmission case (M/T)	MT-19
TRANSMT - Wiring diagram	BL-135

Tread-FR0R (Dimensions)	GI-43
Trim	EI-29
Trouble diagnoses	GI-9
Trunk lid trim	EI-35
Trunk room lamp	LT-143
Trunk room trim	EI-35
TURN - Wiring diagram	LT-87
Turn signal lamp	LT-80
Two trip detection logic	EC-54 , EC-673
Two-pole lift	GI-37

V

Vacuum cut valve	EC-617 , EC-1173 , EC-1275
Vacuum cut valve bypass valve	EC-510 , EC-517 , EC-617 , EC-1160 , EC-1166 , EC-1275
Vacuum hose (brake system)Vacuum hose (brake system)	BR-19
Vacuum hose drawing (Engine control)	EC-29 , EC-647
Valve clearance	EM-41 , EM-141
Valve guide	EM-59 , EM-178 , EM-179
Valve seat	EM-60 , EM-180
Valve spring	EM-62 , EM-181
Vanity mirror lamp	LT-143
Variable induction air control system (VIAS)	EC-565 , EC-1199 , EC-1222
Vehicle identification number	GI-43
Vehicle recovery (freeing a stuck vehicle)	GI-40
Vehicle speed sensor (VSS)	EC-370 , EC-1019
VENT/V - Wiring diagram	EC-323 , EC-487 , EC-494 , EC-980 , EC-1145 , EC-1152
VIAS - Wiring diagram	EC-567 , EC-1224
VIAS/V - Wiring diagram	EC-1201
Viscosity number (SAE)	MA-13

W

W/Ant - Wiring diagram	AV-27
WARN - Wiring diagram	DI-30
Warning chime	DI-43
Warning lamps	DI-22
Water pump	CO-41
Water temperature gauge	DI-4
Wheel alignment (rear)/Wheel alignment (rear)	RSU-6
Wheel balance	MA-30
Wheel bearing (front axle)	FAX-5
Wheel bearing (rear)	RAX-5
Wheel hub (front)	FAX-5 , FAX-6
Wheel hub (rear)	RAX-5
Wheel size	GI-43
Wheelarch height/Wheelarch height	RSU-11
Wheelbase (Dimensions)	GI-43
Width (Dimensions)	GI-43
WINDOW - Wiring diagram	GW-18
Window, door	GW-34 , GW-37
Window, rear	GW-13
Windshield	GW-11
Wiper and washer	WW-3
Wiring Diagram (Cell code) list	PG-57

ALPHABETICAL INDEX

Wiring diagrams [GI-8, GI-12](#)

A

B

C

D

E

F

G

H

I

J

K

L

IDX