

AUTOMATIC TRANSAXLE

SECTION **AT**

CONTENTS

EURO-OB D

TRUBLE DIAGNOSIS - INDEX	4
Alphabetical & P No. Index for DTC	4

PRECAUTIONS

Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	6
Precautions for On Board Diagnostic (EURO-OB D) System of CVT and Engine.....	6
Precautions	6
Service Notice or Precautions	7
Wiring Diagrams and Trouble Diagnoses.....	8

PREPARATION

Special Service Tools	9
-----------------------------	---

CVT FLUID

Checking CVT Fluid.....	10
Changing CVT Fluid	11

OVERALL SYSTEM

CVT Electrical Parts Location.....	12
Circuit Diagram	13
Cross-sectional View - RE0F06A.....	14
Control System	15

EURO-OB D

ON BOARD DIAGNOSTIC SYSTEM

DESCRIPTION	18
Introduction	18
EURO-OB D Function for CVT System.....	18
EURO-OB D Diagnostic Trouble Code (DTC).....	18
Malfunction Indicator (MI)	21
CONSULT-II	21

EXCEPT FOR EURO-OB D

ON BOARD DIAGNOSTIC SYSTEM	
DESCRIPTION	31

CONSULT-II	31
Diagnostic Procedure Without CONSULT-II.....	35

EURO-OB D

TRUBLE DIAGNOSIS - INTRODUCTION	41
Introduction	41
Work Flow	44

EXCEPT FOR EURO-OB D

TRUBLE DIAGNOSIS - INTRODUCTION	46
Introduction	46
Work Flow	49

TRUBLE DIAGNOSIS - BASIC INSPECTION

CVT Fluid Check	51
Stall Test	51
Line Pressure Test.....	52
Road Test.....	53

TRUBLE DIAGNOSIS - GENERAL

DESCRIPTION	58
TCM Terminals and Reference Value.....	58
TRUBLE DIAGNOSIS FOR POWER SUPPLY	62
Wiring Diagram - AT - MAIN.....	62
TCM Terminals and Reference Value.....	64
Diagnostic Procedure	65

EURO-OB D

DTC P0705 PARK/NEUTRAL POSITION (PNP) SWITCH	66
Description	66
Wiring Diagram - AT - PNP/SW.....	68
Diagnostic Procedure	70
Component Inspection.....	72

DTC P0710 CVT FLUID TEMPERATURE SENSOR CIRCUIT	73
Description	73

CONTENTS (Cont'd)

Wiring Diagram - AT - FTS.....	75	<input type="checkbox"/>	EXCEPT FOR EURO-OB	<input type="checkbox"/>
Diagnostic Procedure	77			
DTC P0715 PRIMARY SPEED SENSOR	79			
Description	79			
Wiring Diagram - AT - PSSA/T	80			
Diagnostic Procedure	82			
Component Inspection.....	83			
DTC P0720 VEHICLE SPEED SENSOR (SECONDARY SPEED SENSOR)	84			
Description	84			
Wiring Diagram - AT - VSSA/T	86			
Diagnostic Procedure	88			
Component Inspection.....	89			
DTC P0725 ENGINE SPEED SIGNAL	90			
Description	90			
Wiring Diagram - AT - ENGSS	91			
Diagnostic Procedure	92			
DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE	94			
Description	94			
Wiring Diagram - AT - TCV.....	96			
Diagnostic Procedure	97			
Component Inspection.....	98			
DTC P0745 LINE PRESSURE SOLENOID VALVE	99			
Description	99			
Wiring Diagram - AT - LPSV.....	101			
Diagnostic Procedure	102			
Component Inspection.....	103			
DTC P1705 THROTTLE POSITION SENSOR	104			
Description	104			
Wiring Diagram - AT - TPS.....	106			
Diagnostic Procedure	108			
Component Inspection.....	111			
DTC P1777 STEP MOTOR - CIRCUIT	112			
Description	112			
Wiring Diagram - AT - STM.....	114			
Diagnostic Procedure	115			
Component Inspection.....	116			
DTC P1778 STEP MOTOR - FUNCTION	117			
Description	117			
Diagnostic Procedure	118			
DTC P1791 LINE PRESSURE SENSOR	119			
Description	119			
Wiring Diagram - AT - LPS	121			
Diagnostic Procedure	123			
Component Inspection.....	124			
<input type="checkbox"/>	<input type="checkbox"/>			
CVT SAFE FUNCTION	125			
Description	125			
Diagnostic Procedure	125			
<input type="checkbox"/>	<input type="checkbox"/>			
VEHICLE SPEED SENSOR CVT (SECONDARY SPEED SENSOR)	126			
Description	126			
Wiring Diagram - AT - VSSA/T	128			
Diagnostic Procedure	130			
PRIMARY SPEED SENSOR	132			
Description	132			
Wiring Diagram - AT - VSSMTR.....	134			
Diagnostic Procedure	136			
THROTTLE POSITION SENSOR	137			
Description	137			
Wiring Diagram - AT - TPS.....	139			
Diagnostic Procedure	141			
Component Inspection.....	145			
STEPPING MOTOR - CIRCUIT	146			
Description	146			
Wiring Diagram - AT - STM.....	147			
Diagnostic Procedure	148			
Component Inspection.....	149			
STEP MOTOR - FUNCTION	150			
Description	150			
Diagnostic Procedure	150			
LINE PRESSURE SENSOR	151			
Description	151			
Wiring Diagram - AT - LPS	153			
Diagnostic Procedure	155			
Component Inspection.....	156			
LINE PRESSURE SOLENOID VALVE	157			
Description	157			
Wiring Diagram - AT - LPSV.....	159			
Diagnostic Procedure	160			
Component Inspection.....	163			
TORQUE CONVERTER CLUTCH SOLENOID VALVE	164			
Description	164			
Wiring Diagram - AT - TCV.....	166			
Diagnostic Procedure	167			
Component Inspection.....	169			
CVT FLUID TEMPERATURE SENSOR CIRCUIT	170			
Description	170			
Wiring Diagram - AT - FTS.....	172			
Diagnostic Procedure	174			
ENGINE SPEED SIGNAL	176			
Description	176			
Wiring Diagram - AT - ENGSS	177			
Diagnostic Procedure	178			
<input type="checkbox"/>	<input type="checkbox"/>			
CONTROL UNIT (RAM), CONTROL UNIT (ROM)	180			
Description	180			
Diagnostic Procedure	181			

CONTENTS (Cont'd)

CONTROL UNIT (EEPROM)	182	ON-VEHICLE SERVICE	204
Description	182	Control Cable Adjustment.....	204
Diagnostic Procedure	183	Park/Neutral Position (PNP) Switch Adjustment	204
TROUBLE DIAGNOSES FOR NON-DETECTABLE ITEMS	184	Differential Side Oil Seal Replacement.....	204
PNP Switch, Stop Lamp Switch and Throttle		REMOVAL AND INSTALLATION	206
Position Switch	184	Removal.....	206
Diagnostic Procedure	184	Inspection.....	206
Wiring Diagram - AT - NONDTC	188	Installation.....	207
TROUBLE DIAGNOSES FOR SYMPTOMS	192	Air Breather Hose.....	208
SPORT Indicator Lamp Does Not Come On	192	CVT Fluid Cooler.....	208
A/T SHIFT LOCK SYSTEM	195	Components.....	209
Description	195	SERVICE DATA AND SPECIFICATIONS (SDS)	210
Shift Lock System Electrical Parts Location.....	195	General Specifications.....	210
Wiring Diagram - SHIFT -	196	Stall Revolution.....	210
Diagnostic Procedure	198	Line Pressure.....	210
KEY INTERLOCK CABLE	202	Removal and Installation	210
Components.....	202	A/T Fluid Temperature Sensor.....	210
Removal.....	202	Solenoid Valves	210
Installation.....	203	Dropping Resistor	210

Alphabetical & P No. Index for DTC

NLAT0001

ALPHABETICAL INDEX FOR DTC

NLAT0001S01

Check if the vehicle is a model with Euro-OBD system or not by the “Type approval number” on the identification plate. Refer to GI section, “IDENTIFICATION PLATE”.

Type approval number	Model
Available	With Euro-OBD system
Not available (blank)	Without Euro-OBD system

Items (CONSULT-II screen terms)	DTC		Reference page
	ECM*1	CONSULT-II GST*2	
ATF TEMP SEN/CIRC	0710	P0710	AT-73
ENG SPEED SIG	0725	P0725	AT-90
LINE PRESSURE SEN	1791	P1791	AT-119
L/PRESS SOL/CIRC	0745	P0745	AT-99
PNP SW/CIRC	0705	P0705	AT-66
PRI SPEED SIG/CIRC	0715	P0715	AT-79
STEP MOTOR/CIRC	1777	P1777	AT-112
STEP MOTOR/FNCTN	1778	P1778	AT-117
TP SEN/CIRC A/T*3	1705	P1705	AT-104
TCC SOLENOID/CIRC	0740	P0740	AT-94
VEH SPD SEN/CIR A/T	0720	P0720	AT-84

*1: In Diagnostic Test Mode II (Self-diagnostic results), these numbers are controlled by NISSAN.

*2: These numbers are prescribed by ISO15031-6.

*3: When the fail-safe operation occurs, the MI illuminates.

TROUBLE DIAGNOSIS — INDEX

EURO-OBD

Alphabetical & P No. Index for DTC (Cont'd)

P NO. INDEX FOR DTC

Check if the vehicle is a model with Euro-OBD system or not by the "Type approval number" on the identification plate. Refer to GI section, "IDENTIFICATION PLATE".

=NLAT0001S02

Type approval number	Model
Available	With Euro-OBD system
Not available (blank)	Without Euro-OBD system

DTC		Items (CONSULT-II screen terms)	Reference page
CONSULT-II GST*2	ECM*1		
P0705	0705	PNP SW/CIRC	AT-66
P0710	0710	ATF TEMP SEN/CIRC	AT-73
P0715	0715	PRI SPEED SIG/CIRC	AT-79
P0720	0720	VEH SPD SEN/CIR AT	AT-84
P0725	0725	ENG SPEED SIG	AT-90
P0740	0740	TCC SOLENOID/CIRC	AT-94
P0745	0745	L/PRESS SOL/CIRC	AT-99
P1705	1705	TP SEN/CIRC A/T*3	AT-104
P1777	1777	STEP MOTOR/CIRC	AT-112
P1778	1778	STEP MOTOR/FNCTN	AT-117
P1791	1791	LINE PRESSURE SEN	AT-119

*1: In Diagnostic Test Mode II (Self-diagnostic results), these numbers are controlled by NISSAN.

*2: These numbers are prescribed by ISO15031-6.

*3: When the fail-safe operation occurs, the MI illuminates.

PRECAUTIONS

Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

The Supplemental Restraint System "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a seat belt, help to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and on the instrument panel on the passenger side), seat belt pre-tensioners, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable. NLAT0002

In addition to the supplemental air bag modules for a frontal collision, the supplemental side air bag used along with the seat belt helps to reduce the risk or severity of injury to the driver and front passenger in a side collision. The supplemental side air bag consists of air bag modules (located in the outer side of front seats), satellite sensor, diagnosis sensor unit (one of components of supplemental air bags for a frontal collision), wiring harness, warning lamp (one of components of supplemental air bags for a frontal collision). Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:


- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified with yellow harness connector (and with yellow harness protector or yellow insulation tape before the harness connectors).

Precautions for On Board Diagnostic (EURO-OBD) System of CVT and Engine

The ECM has an on board diagnostic system. It will light up the malfunction indicator lamp (MI) to warn the driver of a malfunction causing emission deterioration. NLAT0198

CAUTION:

- Be sure to turn the ignition switch "OFF" and disconnect the negative battery terminal before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MI to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MI to light up due to an open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Be sure to route and secure the harnesses properly after work. Interference of the harness with a bracket, etc. may cause the MI to light up due to a short circuit.
- Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MI to light up due to a malfunction of the EGR system or fuel injection system, etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the TCM and ECM before returning the vehicle to the customer.




Precautions


- Before connecting or disconnecting the TCM harness connector, turn ignition switch OFF and disconnect negative battery terminal. Failure to do so may damage the TCM. Because battery voltage is applied to TCM even if ignition switch is turned off. NLAT0003

PRECAUTIONS


Precautions (Cont'd)



- When connecting or disconnecting pin connectors into or from TCM, take care not to damage pin terminals (bend or break).
Make sure that there are not any bends or breaks on TCM pin terminal, when connecting pin connectors.



- Before replacing TCM, perform TCM input/output signal inspection and make sure whether TCM functions properly or not. (See page AT-58.)



- After performing each TROUBLE DIAGNOSIS, perform “DTC (Diagnostic Trouble Code) CONFIRMATION PROCEDURE”.
The DTC should not be displayed in the “DTC CONFIRMATION PROCEDURE” if the repair is completed.

- It is very important to perform functional tests whenever they are indicated.
- Extreme care should be taken to avoid damage to O-rings, seals and gaskets when assembling.
- When the CVT drain plug is removed, only some of the fluid is drained. Old CVT fluid will remain in torque converter and CVT fluid cooling system.
Always follow the procedures under “Changing CVT Fluid” in the MA section when changing CVT fluid.

Service Notice or Precautions

NLAT0004

NLAT0004S01

FAIL-SAFE

The TCM has an electronic Fail-Safe (limp home mode). This allows the vehicle to be driven even if a major electrical input/output device circuit is damaged.

Under Fail-Safe, the vehicle always runs even with a shift lever position of “L” or “D”. The customer may complain of sluggish or poor acceleration.

When the ignition key is turned “ON” following Fail-Safe operation, SPORT indicator lamp blinks for about 8 seconds. [For “TCM SELF-DIAGNOSTIC PROCEDURE (No Tools)”, refer to AT-28.]

The blinking of the SPORT indicator lamp for about 8 seconds will appear only once and be cleared. The customer may resume normal driving conditions.

Always follow the “WORK FLOW” (Refer to AT-44).

PRECAUTIONS

Service Notice or Precautions (Cont'd)

The SELF-DIAGNOSIS results will be as follows:

The first SELF-DIAGNOSIS will indicate damage to the vehicle speed sensor or the revolution sensor. During the next SELF-DIAGNOSIS, performed after checking the sensor, no damages will be indicated.

EURO-OBD SELF-DIAGNOSIS

- CVT self-diagnosis is performed by the TCM in combination with the ECM. The results can be read through the blinking pattern of the SPORT indicator lamp. Refer to the table on AT-22 for the indicator used to display each self-diagnostic result.
- The self-diagnostic results indicated by the MI are automatically stored in both the ECM and TCM memories.

NLAT0004S04

Always perform the procedure “HOW TO ERASE DTC” on AT-19 to complete the repair and avoid unnecessary blinking of the MI.

For details of EURO-OBD, refer to EC section (“ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION”).

- **Certain systems and components, especially those related to EURO-OBD, may use a new style slide-locking type harness connector.**

For description and how to disconnect, refer to EL section, “Description”, “HARNES CONNECTOR”.

Wiring Diagrams and Trouble Diagnoses

NLAT0005

When you read wiring diagrams, refer to the following:

- “HOW TO READ WIRING DIAGRAMS” in GI section
- “POWER SUPPLY ROUTING” for power distribution circuit in EL section

When you perform trouble diagnoses, refer to the following:




- “HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES” in GI section
- “HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT” in GI section

PREPARATION

Special Service Tools



Special Service Tools

NLAT0006

Tool number Tool name	Description
ST2505S001 Oil pressure gauge set 1 ST25051001 Oil pressure gauge 2 ST25052000 Hose 3 ST25053000 Joint pipe 4 ST25054000 Adapter 5 ST25055000 Adapter	 <p>Measuring line pressure and governor pressure</p> <p>NT097</p>
KV31103000 Drift	 <p>Installing differential side oil seal (Use with ST35325000) a: 59 mm (2.32 in) dia. b: 49 mm (1.93 in) dia.</p> <p>NT105</p>
ST35325000 Drift	 <p>Installing differential side oil seal (Use with KV31103000) a: 215 mm (8.46 in) b: 25 mm (0.98 in) dia. c: M12 x 1.5P</p> <p>NT417</p>

CVT FLUID

Checking CVT Fluid



Checking CVT Fluid

NLAT0243

1. Check for fluid leakage.
2. Check fluid level.


Fluid level should be checked using "HOT" range on A/T fluid level gauge at fluid temperatures of 50 to 80°C (122 to 176°F) after vehicle has been driven approximately 10 minutes in urban areas after engine is warmed up. But it can be checked at fluid temperatures of 30 to 50°C (86 to 122°F) using "COLD" range on A/T fluid level gauge for reference after engine is warmed up and before driving. However, fluid level must be rechecked using "HOT" range.

 - a. Park vehicle on level surface and set parking brake.
 - b. Start engine and then move selector lever through reach gear range, ending in "P".
 - c. Check fluid level with engine idling.
 - d. Remove A/T fluid level gauge and wipe it clean with lint-free paper.
 - e. Re-insert A/T fluid level gauge into charging pipe as far as it will go.
 - f. Remove A/T fluid level gauge and note reading. If level is at low side of either range, add fluid through the speedometer cable hole.

Use genuine NISSAN CVT fluid (NS-1) or exact equivalent.

CAUTION:
Do not overfill.

CAUTION:




Firmly fix the A/T fluid level gauge using a lip attached to the fluid charging pipe.

CVT FLUID

Checking CVT Fluid (Cont'd)



3. Check fluid condition.
Check fluid for contamination. If fluid is very dark, smells burned or contains frictional material check operation of CVT. Refer to section AT for checking operation of CVT.



Changing CVT Fluid

NLAT0244

1. Warm up CVT fluid by driving the vehicle for 10 minutes.
2. Drain CVT fluid from radiator cooler hose (return side) and refill with new CVT fluid at charging pipe with the engine running at idle speed.
3. Refill until new CVT fluid comes out from radiator cooler hose (return side).
About 30 to 50% extra fluid will be required for this procedure.

Fluid capacity

Hyper CVT: Approx. 8.1 ℓ (7-1/8 Imp qt)

Drain plug:

 : 23 - 27 N·m (2.4 - 2.8 kg·m, 18 - 20 ft·lb)

CAUTION:


Use genuine NISSAN CVT fluid (NS-1) or exact equivalent.

4. Check fluid level and condition.

OVERALL SYSTEM

CVT Electrical Parts Location

NLAT0008




SAT226K

OVERALL SYSTEM

Circuit Diagram

Circuit Diagram

NLAT0009




YAT172

OVERALL SYSTEM

Cross-sectional View — RE0F06A

Cross-sectional View — RE0F06A

NLAT0011



SAT668J

OVERALL SYSTEM

Control System

Control System

=NLAT0014

OUTLINE

NLAT0014S01

The CVT senses vehicle operating conditions through various sensors. It always controls the optimum shift position and reduces shifting and lock-up shocks.


SWITCHES AND SENSORS		TCM		ACTUATORS
PNP switch Throttle position sensor Closed throttle position switch Wide open throttle position switch Engine speed signal CVT fluid temperature sensor CVT fluid pressure sensor Primary speed sensor Secondary speed sensor Stop lamp switch SPORT mode switch ABS control unit	▶	Shift control Line pressure control Lock-up control Fail-safe control Self-diagnosis CONSULT-II communication line control Duet-EA control On board diagnosis	▶	Step motor Torque converter clutch solenoid valve Line pressure solenoid valve SPORT indicator lamp

OVERALL SYSTEM

Control System (Cont'd)

CONTROL SYSTEM

NLAT0014S02



SAT227K

OVERALL SYSTEM

Control System (Cont'd)

TCM FUNCTION

=NLAT0014S03

The function of the TCM is to:

- Receive input signals sent from various switches and sensors.
- Determine required line pressure, shifting point and lock-up operation.
- Send required output signals to the step motor and the respective solenoids.

INPUT/OUTPUT SIGNAL OF TCM

NLAT0014S04

	Switches, sensors and actuators	Function
Input	PNP switch	Detects select lever position and sends a signal to TCM.
	Throttle position sensor	Detects throttle valve position and sends a signal to TCM.
	Closed throttle position switch	Detects throttle valve's fully-closed position and sends a signal to TCM.
	Wide open throttle position switch	Detects a throttle valve position of greater than 1/2 of full throttle and sends a signal to TCM.
	Engine speed signal	From ECM.
	CVT fluid temperature sensor	Detects transmission fluid temperature and sends a signal to TCM.
	CVT fluid pressure sensor	Detects transmission fluid pressure and sends a signal to TCM.
	Primary speed sensor	Detects primary pulley rpm and sends a signal to TCM.
	Secondary speed sensor	Detects secondary pulley rpm and sends a signal to TCM.
	Stop lamp switch	Sends a signal to the TCM relaying the operation condition of the brake pedal.
	SPORT mode switch	Sends a signal to the TCM relaying the operation condition of the SPORT mode switch.
	ABS control unit	Sends a signal to the TCM operation condition of the ABS.
Output	Step motor	Regulates pulley position in relation to a signal sent from TCM.
	Line pressure solenoid valve	Regulates (or decreases) line pressure suited to driving conditions in relation to a signal sent from TCM.
	Torque converter clutch solenoid valve	Regulates (or decreases) lock-up pressure suited to driving conditions in relation to a signal sent from TCM.
	SPORT indicator lamp	Shows the operation condition of the SPORT mode switch.

Introduction

NLAT0017

The CVT system has two self-diagnostic systems.

The first is the emission-related on board diagnostic system (EURO-OBD) performed by the TCM in combination with the ECM. The malfunction is indicated by the MI (malfunction indicator) and is stored as a DTC in the ECM memory but not the TCM memory.

The second is the TCM original self-diagnosis indicated by the CVT indicator (warning) lamp or SPORT indicator lamp. The malfunction is stored in the TCM memory. The detected items are overlapped with EURO-OBD self-diagnostic items. For detail, refer to AT-28.

EURO-OBD Function for CVT System

NLAT0018

The ECM provides emission-related on board diagnostic (EURO-OBD) functions for the CVT system. One function is to receive a signal from the TCM used with EURO-OBD-related parts of the CVT system. The signal is sent to the ECM when a malfunction occurs in the corresponding EURO-OBD-related part. The other function is to indicate a diagnostic result by means of the MI (malfunction indicator) on the instrument panel. Sensors, switches and solenoid valves are used as sensing elements.

The MI automatically illuminates in Two Trip Detection Logic when a malfunction is sensed in relation to CVT system parts.



EURO-OBD Diagnostic Trouble Code (DTC)

NLAT0020


HOW TO READ DTC AND 1ST TRIP DTC

NLAT0020S01

DTC and 1st trip DTC can be read by the following methods.

1.  **No Tools**) The number of blinks of the malfunction indicator in the Diagnostic Test Mode II (Self-Diagnostic Results) Examples: 0705, 0710, 0715, 0720, etc. For details, refer to EC section ["Malfunction Indicator (MI)", "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION"].
These DTCs are controlled by NISSAN.
2.  **with CONSULT-II or GST**) CONSULT-II or GST (Generic Scan Tool) Examples: P0705, P0710, P0720, P0725, etc.
These DTCs are prescribed by ISO15031-6.
(CONSULT-II also displays the malfunctioning component or system.)
 - **1st trip DTC No. is the same as DTC No.**
 - **Output of the diagnostic trouble code indicates that the indicated circuit has a malfunction. However, in case of the Mode II and GST they do not indicate whether the malfunction is still occurring or occurred in the past and returned to normal. CONSULT-II can identify them as shown below. Therefore, using CONSULT-II (if available) is recommended.**

A sample of CONSULT-II display for DTC is shown at left. DTC or 1st trip DTC of a malfunction is displayed in SELF-DIAGNOSTIC RESULTS mode for "ENGINE" with CONSULT-II. Time data indicates how many times the vehicle was driven after the last detection of a DTC.



If the DTC is being detected currently, the time data will be "0".

SELF-DIAG RESULTS	
DTC RESULTS	TIME
PNP SW/CIRC [P0705]	0

SAT015K

If a 1st trip DTC is stored in the ECM, the time data will be "1t".

SELF-DIAG RESULTS	
DTC RESULTS	TIME
PNP SW/CIRC [P0705]	1 t

SAT016K

Freeze Frame Data and 1st Trip Freeze Frame Data

NLAT0020S0101

The ECM has a memory function, which stores the driving condition such as fuel system status, calculated load value, engine coolant temperature, short term fuel trim, long term fuel trim, engine speed and vehicle speed at the moment the ECM detects a malfunction.

Data which are stored in the ECM memory, along with the 1st trip DTC, are called 1st trip freeze frame data, and the data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT-II or GST. The 1st trip freeze frame data can only be displayed on the CONSULT-II screen, not on the GST. For detail, refer to EC section ("CONSULT-II", "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION").

Only one set of freeze frame data (either 1st trip freeze frame data or freeze frame data) can be stored in the ECM. 1st trip freeze frame data is stored in the ECM memory along with the 1st trip DTC. There is no priority for 1st trip freeze frame data and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data (2nd trip detection/MI on) is stored in the ECM memory, 1st trip freeze frame data is no longer stored. Remember, only one set of freeze frame data can be stored in the ECM.

The ECM has the following priorities to update the data.

Priority	Items	
1	Freeze frame data	Misfire — DTC: P0300 - P0306 (0300 - 0306) Fuel Injection System Function — DTC: P0171 (0171), P0172 (0172), P0174 (0174), P0175 (0175)
2		Except the above items (Includes CVT related items)
3	1st trip freeze frame data	

Both 1st trip freeze frame data and freeze frame data (along with the DTCs) are cleared when the ECM memory is erased.

HOW TO ERASE DTC

NLAT0020S02

The diagnostic trouble code can be erased by CONSULT-II, GST or ECM DIAGNOSTIC TEST MODE as described following.

- If the battery terminal is disconnected, the diagnostic trouble code will be lost within 24 hours.
- When you erase the DTC, using CONSULT-II or GST is easier and quicker than switching the mode selector on the ECM.

EURO-OB Diagnostic Trouble Code (DTC) (Cont'd)

The following emission-related diagnostic information is cleared from the ECM memory when erasing DTC related to EURO-OB. For details, refer to EC section ("Emission-related Diagnostic Information", "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION").

- **Diagnostic trouble codes (DTC)**
- **1st trip diagnostic trouble codes (1st trip DTC)**
- **Freeze frame data**
- **1st trip freeze frame data**
- **System readiness test (SRT) codes**
- **Test values**
- Distance traveled while MI is activated
- Others

Ⓟ HOW TO ERASE DTC (WITH CONSULT-II)

NLAT0020S03

- **If a DTC is displayed for both ECM and TCM, it needs to be erased for both ECM and TCM.**
1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 5 seconds and then turn it "ON" (engine stopped) again.
 2. Turn CONSULT-II "ON" and touch "CVT".
 3. Touch "SELF-DIAG RESULTS".
 4. Touch "ERASE". (The DTC in the TCM will be erased.) Then touch "BACK" twice.
 5. Touch "ENGINE".
 6. Touch "SELF-DIAG RESULTS".
 7. Touch "ERASE". (The DTC in the ECM will be erased.)

How to erase DTC (With CONSULT-II)

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 5 seconds and then turn it "ON" (engine stopped) again.

SELECT SYSTEM
CVT
ENGINE


2. Turn CONSULT-II "ON", and touch "A/T".

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
DTC WORK SUPPORT
TCM PART NUMBER

3. Turn "SELF-DIAG RESULTS".

SELF-DIAG RESULTS
DTC RESULTS
T/C CLUTCH SOL/V

4. Touch "ERASE". (The DTC in the TCM will be erased.)



SELECT SYSTEM
CVT
ENGINE

5. Touch "ENGINE".

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
ACTIVE TEST
DTC & SRT CONFIRMATION
ECM PART NUMBER

6. Touch "SELF-DIAG RESULTS".

SELF-DIAG RESULTS	
DTC RESULTS	TIME
TCC SOLENOID/CIRC [P0740]	0

7. Touch "ERASE". (The DTC in the ECM will be erased.)

SAT251K

 **HOW TO ERASE DTC (WITH GST)**


=NLAT0020S04

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 5 seconds and then turn it "ON" (engine stopped) again.
2. Perform "EURO-OBD SELF-DIAGNOSTIC PROCEDURE (No Tools)". Refer to AT-28. (The engine warm-up step can be skipped when performing the diagnosis only to erase the DTC.)
3. Select Mode 4 with Generic Scan Tool (GST). For details, refer to EC section "Generic Scan Tool (GST)".

 **HOW TO ERASE DTC (NO TOOLS)**

NLAT0020S05

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 5 seconds and then turn it "ON" (engine stopped) again.
2. Perform "TCM SELF-DIAGNOSTIC PROCEDURE (No Tools)". Refer to AT-28. (The engine warm-up step can be skipped when performing the diagnosis only to erase the DTC.)
3. Change the diagnostic test mode from Mode II to Mode I by turning the mode selector on the ECM. Refer to EC section "HOW TO SWITCH DIAGNOSTIC TEST MODES".



Malfunction Indicator (MI)

NLAT0021

1. The malfunction indicator will light up when the ignition switch is turned ON without the engine running. This is for checking the lamp.
 - If the malfunction indicator lamp does not light up, refer to EL section ("Warning Lamps/System Description", "WARNING LAMPS AND CHIME"). (Or see MI & Data Link Connectors in EC section.)
2. When the engine is started, the malfunction indicator lamp should go off.

If the lamp remains on, the on board diagnostic system has detected an emission-related (EURO-OBD) malfunction. For detail, refer to EC section ("ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION").

CONSULT-II



NLAT0022

After performing "SELF-DIAGNOSTIC PROCEDURE (WITH CONSULT-II)" (AT-22), place check marks for results on the "DIAGNOSTIC WORKSHEET", AT-43. Reference pages are provided following the items.

NOTICE:

- Additional CONSULT-II information can be found in the Operation Manual supplied with the CONSULT-II unit.

CONSULT-II (Cont'd)





SELF-DIAGNOSTIC PROCEDURE (WITH CONSULT-II) NLAT0022S02

1. Turn on CONSULT-II and touch "ENGINE" for EURO-OBDD detected items or touch "CVT" for TCM self-diagnosis. If CVT is not displayed, check TCM power supply and ground circuit. Refer to AT-58. If result is NG, refer to EL section ("POWER SUPPLY ROUTING").

2. Touch "SELF-DIAG RESULTS". Display shows malfunction experienced since the last erasing operation. CONSULT-II performs REAL TIME DIAGNOSIS. Also, any malfunction detected while in this mode will be displayed at real time.



SELF-DIAGNOSTIC RESULT TEST MODE NLAT0022S03

Detected items (Screen terms for CONSULT-II, "SELF-DIAG RESULTS" test mode)		Malfunction is detected when ...	TCM self-diagnosis	EURO-OBDD (DTC)
			 Available by SPORT indicator lamp "CVT" on CONSULT-II	 Available by malfunction indicator*2, "ENGINE" on CONSULT-II or GST
"CVT"	"ENGINE"			
PNP switch circuit		<ul style="list-style-type: none"> TCM does not receive the correct voltage signal (based on the gear position) from the switch. 	—	P0705
PNP SW/CIRCUIT	PNP SW/CIRC			
Primary speed sensor		<ul style="list-style-type: none"> TCM does not receive the proper voltage signal from the sensor. 	X	P0715
I/P PULLY SPD SIG	PRI SPEED SIG/CIRC			
Output pulley speed signal		<ul style="list-style-type: none"> TCM does not receive the proper voltage signal from the sensor. 	X	P0720
O/P PULLY SPD SIG	VEH SPD SEN/CIR A/T			
T/C clutch solenoid valve		<ul style="list-style-type: none"> TCM detects an improper voltage drop when it tries to operate the solenoid valve. 	X	P0740
T/C CLUTCH SOL/V	TCC SOLENOID/CIRC			
Line pressure solenoid valve		<ul style="list-style-type: none"> TCM detects an improper voltage drop when it tries to operate the solenoid valve. 	X	P0745
LINE PRESSURE S/V	L/PRESS SOL/CIRC			
Throttle position sensor		<ul style="list-style-type: none"> TCM receives an excessively low or high voltage from the sensor. 	X	P1705
THROTTLE POSI SEN	TP SEN/CIRC A/T			

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

EURO-OB

CONSULT-II (Cont'd)

Detected items (Screen terms for CONSULT-II, "SELF-DIAG RESULTS" test mode)		Malfunction is detected when ...	TCM self-diagnosis	EURO-OB (DTC)
			 Available by SPORT indicator lamp "CVT" on CONSULT-II	 Available by malfunction indicator*2, "ENGINE" on CONSULT-II or GST
"CVT"	"ENGINE"			
Engine speed signal ENGINE SPEED SIG		<ul style="list-style-type: none"> TCM does not receive the proper voltage signal from the ECM. 	X	P0725
CVT fluid temperature sensor FLUID TEMP SEN ATF TEMP SEN/ CIRC		<ul style="list-style-type: none"> TCM receives an excessively low or high voltage from the sensor. 	X	P0710
Stepping motor circuit STEP MOTOR STEP MOTOR/ CIRC		<ul style="list-style-type: none"> Not proper voltage change of the TCM terminal when operating step motor. 	X	P1777
Stepping motor function — STEP MOTOR/ FNCTN		<ul style="list-style-type: none"> Step motor is not operating according to the TCM. 	X	P1778
Line pressure sensor LINE PRESSURE LINE PRESS SEN SEN		<ul style="list-style-type: none"> TCM receives an excessively low or high voltage from the sensor. 	X	P1791
CVT SAFE FUNCTION CVT SAFE FUNC- — TION		<ul style="list-style-type: none"> TCM is malfunctioning. 	X	—
TCM (RAM) CONTROL UNIT — (RAM)		<ul style="list-style-type: none"> TCM memory (RAM) is malfunctioning. 	—	—
TCM (ROM) CONTROL UNIT — (ROM)		<ul style="list-style-type: none"> TCM memory (ROM) is malfunctioning. 	—	—
TCM (EEP ROM) CONTROL UNIT — (EEP ROM)		<ul style="list-style-type: none"> TCM memory (EEP ROM) is malfunctioning. 	—	—
Initial start *INITIAL START* —		<ul style="list-style-type: none"> This is not a malfunction message (Whenever shutting off a power supply to the TCM, this message appears on the screen.) 	X	—
No failure (NO SELF DIAGNOSTIC FAILURE INDICATED FURTHER TESTING MAY BE REQUIRED**)		<ul style="list-style-type: none"> No failure has been detected. 	X	X

X: Applicable

—: Not applicable

*1: These malfunctions cannot be displayed by MI  if another malfunction is assigned to MI.

*2: Refer to EC section ["Malfunction Indicator (MI)", "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION"].

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

EURO-OB

CONSULT-II (Cont'd)

DATA MONITOR MODE (CVT)

NLAT0022S04

Item	Display	Monitor item		Description	Remarks
		TCM input signals	Main signals		
Vehicle speed sensor (Secondary speed sensor)	VHCL SPEED SE [km/h] or [mph]	X	—	<ul style="list-style-type: none"> Vehicle speed computed from signal of revolution sensor is displayed. 	When racing engine in "N" or "P" position with vehicle stationary, CONSULT-II data may not indicate 0 km/h (0 mph).
Throttle position sensor	THRTL POS SEN [V]	X	—	<ul style="list-style-type: none"> Throttle position sensor signal voltage is displayed. 	—
CVT fluid temperature sensor	FLUID TEMP SE [V]	X	—	<ul style="list-style-type: none"> CVT fluid temperature sensor signal voltage is displayed. Signal voltage lowers as fluid temperature rises. 	—
Battery voltage	BATTERY VOLT [V]	X	—	<ul style="list-style-type: none"> Source voltage of TCM is displayed. 	—
Engine speed	ENGINE SPEED [rpm]	X	X	<ul style="list-style-type: none"> Engine speed, computed from engine speed signal, is displayed. 	Engine speed display may not be accurate under approx. 800 rpm. It may not indicate 0 rpm even when engine is not running.
P/N position switch	N POSITION SW [ON/OFF]	X	—	<ul style="list-style-type: none"> ON/OFF state computed from signal of P/N position SW is displayed. 	—
R position switch	R POSITION SW [ON/OFF]	X	—	<ul style="list-style-type: none"> ON/OFF state computed from signal of R position SW is displayed. 	—
D position switch	D POSITION SW [ON/OFF]	X	—	<ul style="list-style-type: none"> ON/OFF state computed from signal of D position SW is displayed. 	—
Sport mode switch	S POSITION SW [ON/OFF]	X	—	<ul style="list-style-type: none"> ON/OFF status, computed from signal of Sport mode SW, is displayed. 	—
L position switch	L POSITION SW [ON/OFF]	X	—	<ul style="list-style-type: none"> ON/OFF status, computed from signal of L position SW, is displayed. 	—
Closed throttle position switch	CLOSED THL/SW [ON/OFF]	X	—	<ul style="list-style-type: none"> ON/OFF status, computed from signal of closed throttle position SW, is displayed. 	—
Wide open throttle position switch	W/O THRL/P-SW [ON/OFF]	X	—	<ul style="list-style-type: none"> ON/OFF status, computed from signal of wide open throttle position SW, is displayed. 	—

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

EURO-OBD


CONSULT-II (Cont'd)

Item	Display	Monitor item		Description	Remarks
		TCM input signals	Main signals		
Selector lever position	SLCT LVR POSI	—	X	<ul style="list-style-type: none"> Selector lever position data, used for computation by TCM, is displayed. 	<ul style="list-style-type: none"> A specific value used for control is displayed if fail-safe is activated due to error.
Vehicle speed	VEHICLE SPEED [km/h] or [mph]	—	X	<ul style="list-style-type: none"> Vehicle speed data, used for computation by TCM, is displayed. 	—
Throttle position	THROTTLE POSI [8]	—	X	<ul style="list-style-type: none"> Throttle position data, used for computation by TCM, is displayed. 	<ul style="list-style-type: none"> A specific value used for control is displayed if fail-safe is activated due to error.
Line pressure duty	LINE PRES DTY [%]	—	X	<ul style="list-style-type: none"> Control value of line pressure solenoid valve, computed by TCM from each input signal, is displayed. 	—
Torque converter clutch solenoid valve duty	TCC S/V DUTY [%]	—	X	<ul style="list-style-type: none"> Control value of torque converter clutch solenoid valve, computed by TCM from each input signal, is displayed. 	—
Self-diagnosis display lamp (SPORT indicator lamp)	PAT MONI LAMP [ON/OFF]	—	X	<ul style="list-style-type: none"> Control status of SPORT indicator lamp is displayed. 	—
Line pressure sensor	LINE PRES-SURE SEN [V]	X	—	<ul style="list-style-type: none"> Line pressure sensor signal voltage is displayed. 	—
Primary pulley speed sensor	I/P PULLY SPD [rpm]	X	X	<ul style="list-style-type: none"> Primary pulley speed computed from signal of primary pulley speed sensor is displayed. 	—
Secondary pulley speed sensor	O/P PULLY SPD [rpm]	—	—	<ul style="list-style-type: none"> Secondary pulley speed computed from signal of secondary speed sensor is displayed. 	—
Stop lamp switch	BRAKE SW [ON/OFF]	X	—	<ul style="list-style-type: none"> ON/OFF position signal of stop lamp switch is displayed. 	—
ABS signal	ABS SIGNAL [ON/OFF]	X	—	<ul style="list-style-type: none"> ABS operation signal (ON/OFF) from ABS control unit is displayed. 	—
CVT ratio	CVT RATIO [—]	—	X	<ul style="list-style-type: none"> Real CVT ratio operated TCM is displayed. 	—
Step	PLY CONT STEP [step]	—	X	<ul style="list-style-type: none"> Step motor position is displayed. 	—

X: Applicable

—: Not applicable


CONSULT-II (Cont'd)




WORK SUPPORT MODE WITH CONSULT-II

NLAT0022S08


1. Turn ignition switch "OFF".
2. Connect CONSULT-II to data link connector which is located in the left side lower dash panel.
3. Turn ignition switch "ON".




4. Touch "START".



5. Touch "CVT".



6. Touch "WORK SUPPORT".



7. Touch "ENGINE BRAKE ADJUSTMENT".
8. Touch "START".

ENGINE BRAKE ADJ.		
ADJ. MONITOR		
ENGINE BRAKE LEVEL	0	
UP	DOWN	

SAT934J

9. Set "ENGINE BRAKE LEVEL" by touching "UP" or "DOWN".

ENGINE BRAKE LEVEL

0: Initial set value (Engine brake level control is activated)

OFF: Engine brake level control is deactivated.

10. Turn ignition switch "OFF", wait at least 5 seconds and then turn ignition switch "ON".

11. Engine brake level set is completed.

CAUTION:

Mode of "+1" "0" "-1" "-2" "OFF" can be selected by pressing the "UP" "DOWN" on CONSULT screen. However, do not select mode other than "0" and "OFF". If the "+1" or "-1" or "-2" is selected, that might cause the abnormality of drivability.

DIAGNOSTIC PROCEDURE WITHOUT CONSULT-II



EURO-OB Self-diagnostic Procedure (With GST) NLAT0022S07

Refer to EC section ["Generic Scan Tool (GST)", "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION"] NLAT0022S0701

EURO-OB Self-diagnostic Procedure (No Tools) NLAT0022S0702

Refer to EC section ["Malfunction Indicator (MI)", "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION"] NLAT0022S0702

CONSULT-II (Cont'd)



TCM Self-diagnostic Procedure (No Tools)

=NLAT0022S0703

Preparation

1. Turn ignition switch to "OFF" position.
2. If throttle opener is equipped, connect the handy type vacuum pump to the throttle opener and apply vacuum -25.3 kPa (-253 mbar, -190 mmHg, -7.48 inHg). (If throttle opener is not equipped, skip this step.)
3. Disconnect the throttle position switch harness connector.
4. Turn ignition switch to "ON" position.
5. Check continuity between terminals 4 and 5 of the closed throttle position switch.

Continuity should exist.

(If continuity does not exist, check throttle opener and closed throttle position switch. Then increase vacuum until closed throttle position switch shows continuity.)


6. Connect the throttle position switch harness connector.
7. Warm up the engine.
8. Turn the ignition switch from ON to OFF two more times, and then turn to OFF.
9. In the "P" position of the selector lever, turn the ignition switch ON, and verify that the CVT warning lamp turns on for about 2 seconds.
10. Turn the ignition switch OFF.
11. Press the brake pedal, and shift the selector lever to the "D" position.
12. Turn the ignition switch ON.
13. Release the brake, and shift the selector lever to the "L" position.
14. Fully depress both brake and accelerator pedals all the way to the floor. Without releasing the brake and accelerator pedals, shift the selector lever to the "D" position.
15. Read the display from the SPORT indicator lamp to complete the diagnosis.

Judgement of Self-diagnosis Code

NLAT0022S0704

SPORT indicator lamp


All judgement flickers are the same.



SAT281K

All circuits that can be confirmed by self-diagnosis are OK.

1st judgement flicker is longer than others.




SAT437FA

Secondary speed sensor (VEHICLE SPEED SENSOR CVT) circuit is short-circuited or disconnected.

⇒ Go to VEHICLE SPEED SENSOR CVT (SECONDARY SPEED SENSOR) (DTC: 0720), AT-84.

SPORT indicator lamp



2nd judgement flicker is longer than others.



SAT439FA

Primary speed sensor circuit is short-circuited or disconnected.
 ⇒ **Go to PRIMARY SPEED SENSOR (DTC: 0715), AT-79.**



3rd judgement flicker is longer than others.



SAT441FA

Throttle position sensor circuit is short-circuited or disconnected.
 ⇒ **Go to THROTTLE POSITION SENSOR (DTC: 1705), AT-104.**



4th judgement flicker is longer than others.



SAT443FA

Step motor circuit is short-circuited or disconnected.
 ⇒ **Go to STEP MOTOR (DTC: 1777), AT-112.**



5th judgement flicker is longer than others.



SAT445FA

Line pressure sensor circuit is short-circuited or disconnected.
 ⇒ **Go to LINE PRESSURE SENSOR (DTC: 1791), AT-119.**



6th judgement flicker is longer than others.



SAT447FA

Line pressure solenoid valve circuit is short-circuited or disconnected.
 ⇒ **Go to LINE PRESSURE SOLENOID VALVE (DTC: 0745), AT-99.**

7th judgement flicker is longer than others.



SAT449FA

Lock up solenoid valve circuit is short-circuited or disconnected.
 ⇒ **Go to TORQUE CONVERTER CLUTCH SOLENOID VALVE (DTC: 0740), AT-94.**

SPORT indicator lamp

<p>8th judgement flicker is longer than others.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">SAT451FA</p> <p>CVT fluid temperature sensor is disconnected or TCM power source circuit is damaged. ⇒ Go to CVT FLUID TEMPERATURE SENSOR (DTC: 0710) AND TCM POWER SOURCE, AT-73.</p>	<p>9th judgement flicker is longer than others.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">SAT453FA</p> <p>Engine speed signal circuit is short-circuited or disconnected. ⇒ Go to ENGINE SPEED SIGNAL (DTC: 0725), AT-90.</p>
<p>10th judgement flicker is longer than others.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">SAT455FA</p> <ul style="list-style-type: none"> ● When “4th judgement flicker” and/or “6th judgement flicker” is displayed, inspect “STEP MOTOR (DTC: 1777)” and/or “LINE PRESSURE SOLENOID VALVE (DTC: 0745)”. ● When neither “4th judgement flicker” nor “6th judgement flicker” are displayed, replace TCM. <p>⇒ Go to CVT SAFE FUNCTION, AT-125.</p>	<p>Flickers as shown below.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">SAT278K</p> <p>Battery voltage is low. Battery has been disconnected for a long time. Battery is connected conversely. (When reconnecting TCM connectors — This is not a problem)</p>
<p>Lamp does not come on.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">SAT653J</p> <p>PNP switch, overdrive control switch or throttle position switch circuit is disconnected or TCM is damaged. ⇒ Go to TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEM, AT-184.</p>	

$t_1 = 2.5$ seconds $t_2 = 2.0$ seconds $t_3 = 1.0$ second $t_4 = 1.0$ second

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

EXCEPT FOR EURO-OB



CONSULT-II

CONSULT-II

After performing "SELF-DIAGNOSTIC PROCEDURE (WITH CONSULT-II)" (AT-31), place check marks for results on the "DIAGNOSTIC WORKSHEET", AT-42. Reference pages are provided following the items.

NOTICE:

- Additional CONSULT-II information can be found in the Operation Manual supplied with the CONSULT-II unit.



SELF-DIAGNOSTIC PROCEDURE (WITH CONSULT-II)

- Turn on CONSULT-II and touch "CVT" for TCM self-diagnosis. If CVT is not displayed, check TCM power supply and ground circuit. Refer to AT-58. If result is NG, refer to EL section ("POWER SUPPLY ROUTING").
- Touch "SELF-DIAG RESULTS". Display shows malfunction experienced since the last erasing operation. CONSULT-II performs REAL-TIME SELF-DIAGNOSIS. Also, any malfunction detected while in this mode will be displayed at real time.

SELF-DIAGNOSTIC RESULT TEST MODE

NLAT0245S02

Detected items (Screen terms for CONSULT-II, "SELF-DIAG RESULTS" test mode)		Malfunction is detected when ...	Remarks
Item	Display		
No failure (NO SELF DIAGNOSTIC FAILURE INDICATED FURTHER TESTING MAY BE REQUIRED**)		<ul style="list-style-type: none"> No failure has been detected. 	
Initial start		<ul style="list-style-type: none"> This is not a malfunction message (Whenever shutting off a power supply to the TCM, this message appears on the screen.) 	
INITIAL START	—		
Output pulley speed signal	O/P PULLY SPD SIG	<ul style="list-style-type: none"> TCM does not receive the proper voltage signal from the sensor. 	
Primary speed sensor	I/P PULLY SPD SIG	<ul style="list-style-type: none"> TCM does not receive the proper voltage signal from the sensor. 	
Throttle position sensor	THROTTLE POSI SEN	<ul style="list-style-type: none"> TCM receives an excessively low or high voltage from the sensor. 	
Stepping motor circuit	STEP MOTOR	<ul style="list-style-type: none"> Not proper voltage change of the TCM terminal when operating step motor. 	

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

EXCEPT FOR EURO-OB

CONSULT-II (Cont'd)

Detected items (Screen terms for CONSULT-II, "SELF-DIAG RESULTS" test mode)		Malfunction is detected when ...	Remarks
Item	Display		
Stepping motor function	—	<ul style="list-style-type: none"> Step motor is not operating according to the TCM. 	
Line pressure sensor	LINE PRESSURE SEN	<ul style="list-style-type: none"> TCM receives an excessively low or high voltage from the sensor. 	
T/C clutch solenoid valve	T/C CLUTCH SOL/V	<ul style="list-style-type: none"> TCM detects an improper voltage drop when it tries to operate the solenoid valve. 	
CVT fluid temperature sensor	FLUID TEMP SEN	<ul style="list-style-type: none"> TCM receives an excessively low or high voltage from the sensor. 	
CVT SAFE FUNCTION	CVT SAFE FUNCTION	<ul style="list-style-type: none"> TCM is malfunctioning. 	
Engine speed signal	ENGINE SPEED SIG	<ul style="list-style-type: none"> TCM does not receive the proper voltage signal from the ECM. 	
Line pressure solenoid valve	LINE PRESSURE S/V	<ul style="list-style-type: none"> TCM detects an improper voltage drop when it tries to operate the solenoid valve. 	
TCM (RAM)	CONTROL UNIT (RAM)	<ul style="list-style-type: none"> TCM memory (RAM) is malfunctioning. 	
TCM (ROM)	CONTROL UNIT (ROM)	<ul style="list-style-type: none"> TCM memory (ROM) is malfunctioning. 	
TCM (EEP ROM)	CONT UNIT (EEP ROM)	<ul style="list-style-type: none"> TCM memory (EEP ROM) is malfunctioning. 	

DATA MONITOR MODE (CVT)

NLAT0245S03

Item	Display	Monitor item		Description	Remarks
		TCM input signals	Main signals		
Vehicle speed sensor (Secondary speed sensor)	VHCL SPEED SE [km/h] or [mph]	X	—	<ul style="list-style-type: none"> Vehicle speed computed from signal of revolution sensor is displayed. 	When racing engine in "N" or "P" position with vehicle stationary, CONSULT-II data may not indicate 0 km/h (0 mph).
Throttle position sensor	THRTL POS SEN [V]	X	—	<ul style="list-style-type: none"> Throttle position sensor signal voltage is displayed. 	—
CVT fluid temperature sensor	FLUID TEMP SE [V]	X	—	<ul style="list-style-type: none"> CVT fluid temperature sensor signal voltage is displayed. Signal voltage lowers as fluid temperature rises. 	—
Battery voltage	BATTERY VOLT [V]	X	—	<ul style="list-style-type: none"> Source voltage of TCM is displayed. 	—
Engine speed	ENGINE SPEED [rpm]	X	X	<ul style="list-style-type: none"> Engine speed, computed from engine speed signal, is displayed. 	Engine speed display may not be accurate under approx. 800 rpm. It may not indicate 0 rpm even when engine is not running.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

EXCEPT FOR EURO-OB

CONSULT-II (Cont'd)

Item	Display	Monitor item		Description	Remarks
		TCM input signals	Main signals		
P/N position switch	N POSITION SW [ON/OFF]	X	—	<ul style="list-style-type: none"> ON/OFF state computed from signal of P/N position SW is displayed. 	—
R position switch	R POSITION SW [ON/OFF]	X	—	<ul style="list-style-type: none"> ON/OFF state computed from signal of R position SW is displayed. 	—
D position switch	D POSITION SW [ON/OFF]	X	—	<ul style="list-style-type: none"> ON/OFF state computed from signal of D position SW is displayed. 	—
Sport mode switch	S POSITION SW [ON/OFF]	X	—	<ul style="list-style-type: none"> ON/OFF status, computed from signal of Sport mode SW, is displayed. 	—
L position switch	L POSITION SW [ON/OFF]	X	—	<ul style="list-style-type: none"> ON/OFF status, computed from signal of L position SW, is displayed. 	—
Closed throttle position switch	CLOSED THL/SW [ON/OFF]	X	—	<ul style="list-style-type: none"> ON/OFF status, computed from signal of closed throttle position SW, is displayed. 	—
Wide open throttle position switch	W/O THRL/ P-SW [ON/OFF]	X	—	<ul style="list-style-type: none"> ON/OFF status, computed from signal of wide open throttle position SW, is displayed. 	—
Selector lever position	SLCT LVR POSI	—	X	<ul style="list-style-type: none"> Selector lever position data, used for computation by TCM, is displayed. 	<ul style="list-style-type: none"> A specific value used for control is displayed if fail-safe is activated due to error.
Vehicle speed	VEHICLE SPEED [km/h] or [mph]	—	X	<ul style="list-style-type: none"> Vehicle speed data, used for computation by TCM, is displayed. 	—
Throttle position	THROTTLE POSI [8]	—	X	<ul style="list-style-type: none"> Throttle position data, used for computation by TCM, is displayed. 	<ul style="list-style-type: none"> A specific value used for control is displayed if fail-safe is activated due to error.
Line pressure duty	LINE PRES DTY [%]	—	X	<ul style="list-style-type: none"> Control value of line pressure solenoid valve, computed by TCM from each input signal, is displayed. 	—
Torque converter clutch solenoid valve duty	TCC S/V DUTY [%]	—	X	<ul style="list-style-type: none"> Control value of torque converter clutch solenoid valve, computed by TCM from each input signal, is displayed. 	—
Self-diagnosis display lamp (SPORT indicator lamp)	PAT MONI LAMP [ON/OFF]	—	X	<ul style="list-style-type: none"> Control status of SPORT indicator lamp is displayed. 	—

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION



EXCEPT FOR EURO-OB

CONSULT-II (Cont'd)

Item	Display	Monitor item		Description	Remarks
		TCM input signals	Main signals		
Line pressure sensor	LINE PRES SEN [V]	X	—	<ul style="list-style-type: none"> CVT fluid pressure sensor signal voltage is displayed. 	—
Primary pulley speed sensor	I/P PULLY SPD [rpm]	X	X	<ul style="list-style-type: none"> Primary pulley speed computed from signal of primary pulley speed sensor is displayed. 	
Secondary pulley speed sensor	O/P PULLY SPD [rpm]	—	—	<ul style="list-style-type: none"> Secondary pulley speed computed from signal of secondary speed sensor is displayed. 	—
Stop lamp switch	BRAKE SW [ON/OFF]	X	—	<ul style="list-style-type: none"> ON/OFF position signal of stop lamp switch is displayed. 	—
ABS signal	ABS SIGNAL [ON/OFF]	X	—	<ul style="list-style-type: none"> ABS operation signal (ON/OFF) from ABS control unit is displayed. 	—
CVT ratio	CVT RATIO [—]	—	X	<ul style="list-style-type: none"> Real CVT ratio operated TCM is displayed. 	—
Step	PLY CONT STEP [step]	—	X	<ul style="list-style-type: none"> Step motor position is displayed. 	—

X: Applicable

—: Not applicable



HOW TO ERASE SELF-DIAGNOSTIC RESULTS (Ⓟ WITH CONSULT-II)


NLAT0245S09

- If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait for at least 3 seconds and then turn it "ON" again.
- Turn CONSULT-II "ON", and touch "CVT".
- Touch "SELF-DIAG RESULTS".


ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

EXCEPT FOR EURO-OB

CONSULT-II (Cont'd)



4. Touch "ERASE". (The self-diagnostic results will be erased.)



Diagnostic Procedure Without CONSULT-II

NLAT0246

⊗ SELF-DIAGNOSTIC PROCEDURE (WITHOUT CONSULT-II)

NLAT0246S01

Preparation


NLAT0246S0101

1. Turn ignition switch to "OFF" position.
2. If throttle opener is equipped, connect the handy type vacuum pump to the throttle opener and apply vacuum -25.3 kPa (-253 mbar, -190 mmHg, -7.48 inHg). (If throttle opener is not equipped, skip this step.)
3. Disconnect the throttle position switch harness connector.
4. Turn ignition switch to "ON" position.
5. Check continuity between terminals 4 and 5 of the closed throttle position switch.

Continuity should exist.

(If continuity does not exist, check throttle opener and closed throttle position switch. Then increase vacuum until closed throttle position switch shows continuity.)



6. Go to "Self-diagnostic procedure (Without CONSULT-II)".




ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

EXCEPT FOR EURO-OB

Diagnostic Procedure Without CONSULT-II (Cont'd)


1	CHECK SPORT INDICATOR LAMP	
<p>1. Start engine and warm it up to normal operating temperature.</p> <p>2. Turn ignition switch ON and OFF more than two times, and then turn OFF.</p> <p>3. Move selector lever to "P" position, and then turn ignition switch ON. Then make sure SPORT indicator lamp turns ON for approximately 2 seconds.</p>		
		
SAT256K		
		
SAT257K		
Yes or No		
Yes	▶	GO TO 2.
No	▶	Go to "SPORT Indicator Lamp Does Not Come On", AT-192.


2	JUDGEMENT PROCEDURE STEP 1	
<p>1. Turn ignition switch to "OFF" position.</p> <p>2. Depress brake pedal and simultaneously release accelerator pedal fully. Then, move selector lever to "D" position.</p> <p>3. Turn ignition switch to "ON" position. (Do not start engine.)</p>		
		
SAT258K		
▶		GO TO 3.


ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

EXCEPT FOR EURO-OB

Diagnostic Procedure Without CONSULT-II (Cont'd)

3	JUDGEMENT PROCEDURE STEP 2
Release brake pedal and move selector lever to "L" position.	
	
SAT259K	
▶ GO TO 4.	

4	JUDGEMENT PROCEDURE STEP 3
While depressing brake pedal with your left foot, depress accelerator to WOT with your right foot. Then, move selector lever to "D" position.	
	
SAT260K	
▶ GO TO 5.	

5	CHECK SELF-DIAGNOSIS CODE
Check SPORT indicator lamp. Refer to JUDGEMENT OF SELF-DIAGNOSIS CODE, AT-38.	
	
SAT257K	
▶ DIAGNOSIS END	

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

EXCEPT FOR EURO-OB


Diagnostic Procedure Without CONSULT-II (Cont'd)

JUDGEMENT OF SELF-DIAGNOSIS CODE

NLAT0246S02

SPORT indicator lamp


All judgement flickers are the same.



SAT281K

All circuits that can be confirmed by self-diagnosis are OK.


1st judgement flicker is longer than others.



SAT437FA

Secondary speed sensor (VEHICLE SPEED SENSOR CVT) circuit is short-circuited or disconnected.
⇒ **Go to VEHICLE SPEED SENSOR CVT (SECONDARY SPEED SENSOR), AT-127.**


2nd judgement flicker is longer than others.



SAT439FA

Primary speed sensor circuit is short-circuited or disconnected.
⇒ **Go to PRIMARY SPEED SENSOR, AT-132.**


3rd judgement flicker is longer than others.



SAT441FA

Throttle position sensor circuit is short-circuited or disconnected.
⇒ **Go to THROTTLE POSITION SENSOR, AT-137.**


4th judgement flicker is longer than others.



SAT443FA

Step motor circuit is short-circuited or disconnected.
⇒ **Go to STEP MOTOR, AT-146.**

5th judgement flicker is longer than others.



SAT445FA

Line pressure sensor circuit is short-circuited or disconnected.
⇒ **Go to LINE PRESSURE SENSOR, AT-151.**



ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

EXCEPT FOR EURO-OB

Diagnostic Procedure Without CONSULT-II (Cont'd)

SPORT indicator lamp

6th judgement flicker is longer than others.





SAT447FA

Line pressure solenoid valve circuit is short-circuited or disconnected.

⇒ **Go to LINE PRESSURE SOLENOID VALVE, AT-157.**

7th judgement flicker is longer than others.



SAT449FA

Lock up solenoid valve circuit is short-circuited or disconnected.

⇒ **Go to TORQUE CONVERTER CLUTCH SOLENOID VALVE, AT-164.**

8th judgement flicker is longer than others.





SAT451FA

CVT fluid temperature sensor is disconnected or TCM power source circuit is damaged.

⇒ **Go to CVT FLUID TEMPERATURE SENSOR AND TCM POWER SOURCE, AT-170.**

9th judgement flicker is longer than others.





SAT285K

Engine speed signal circuit is short-circuited or disconnected.

⇒ **Go to ENGINE SPEED SIGNAL, AT-176.**

10th judgement flicker is longer than others.





SAT455FA

- When "4th judgement flicker" and/or "6th judgement flicker" is displayed, inspect "STEP MOTOR" and/or "LINE PRESSURE SOLENOID VALVE".
- When neither "4th judgement flicker" nor "6th judgement flicker" are displayed, replace TCM.

⇒ **Go to CVT SAFE FUNCTION, AT-125.**

Flickers as shown below.



SAT457FA

Battery voltage is low.

Battery has been disconnected for a long time.

Battery is connected conversely.

(When reconnecting TCM connectors. — This is not a problem.)


ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

EXCEPT FOR EURO-OBD

Diagnostic Procedure Without CONSULT-II (Cont'd)

SPORT indicator lamp


Lamp does not come on.



PNP switch, stop lamp switch or throttle position switch circuit is disconnected or TCM is damaged.

⇒ **Go to TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEM, AT-184.**

$t_1 = 2.5$ seconds $t_2 = 2.0$ seconds $t_3 = 1.0$ second $t_4 = 1.0$ second



Introduction

NLAT0023

The TCM receives a signal from the vehicle speed sensor, throttle position sensor or PNP switch and provides shift control or lock-up control via step motor and CVT solenoid valves.

The TCM also communicates with the ECM by means of a signal sent from sensing elements used with the EURO-OBD-related parts of the CVT system for malfunction-diagnostic purposes. The TCM is capable of diagnosing malfunctioning parts while the ECM can store malfunctions in its memory.

Input and output signals must always be correct and stable in the operation of the CVT system. The CVT system must be in good operating condition and be free of valve seizure, solenoid valve malfunction, etc.



It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.

A visual check only, may not find the cause of the problems. A road test with CONSULT-II (or GST) or a circuit tester connected should be performed. Follow the "Work Flow". Refer to AT-44.

Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such problems, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "Diagnostic Worksheet" like the example (AT-43) should be used.

Start your diagnosis by looking for "conventional" problems first. This will help troubleshoot driveability problems on an electronically controlled engine vehicle.

Also check related Service bulletins for information.



Diagnostic Worksheet

=NLAT0023S0102

1.	<input type="checkbox"/> Read the Fail-safe and listen to customer complaints.	AT-7
2.	<input type="checkbox"/> CHECK CVT FLUID	AT-51
	<input type="checkbox"/> Leakage (Follow specified procedure) <input type="checkbox"/> Fluid condition <input type="checkbox"/> Fluid level	
3.	<input type="checkbox"/> Perform STALL TEST and LINE PRESSURE TEST.	AT-51, 52
	<input type="checkbox"/> Stall test — Mark possible damaged components/others.	
	<input type="checkbox"/> Forward clutch	<input type="checkbox"/> Reverse brake <input type="checkbox"/> Engine <input type="checkbox"/> Line pressure is low.
	<input type="checkbox"/> Line Pressure test — Suspected parts:	
4.	<input type="checkbox"/> Perform all ROAD TEST and mark required procedures.	AT-53
	4-1. Check before engine is started.	AT-54
	<input type="checkbox"/> SELF-DIAGNOSTIC PROCEDURE — Mark detected items.	
	<input type="checkbox"/> PNP switch, AT-66. <input type="checkbox"/> CVT fluid temperature sensor circuit, AT-73. <input type="checkbox"/> Vehicle speed sensor (Output pulley speed signal), AT-84. <input type="checkbox"/> Engine speed signal, AT-90. <input type="checkbox"/> Torque converter clutch solenoid valve, AT-94. <input type="checkbox"/> Line pressure solenoid valve, AT-99. <input type="checkbox"/> Step motor, AT-112, 117. <input type="checkbox"/> Line pressure sensor, AT-119. <input type="checkbox"/> Throttle position sensor, AT-104. <input type="checkbox"/> Primary speed sensor, AT-79. <input type="checkbox"/> CVT SAFE FUNCTION, AT-125. <input type="checkbox"/> CONTROL UNIT (RAM) CONTROL UNIT (ROM), AT-180. <input type="checkbox"/> CONTROL UNIT (EEP ROM), AT-182. <input type="checkbox"/> PNP switch, stop lamp switch, throttle position switch, AT-184. <input type="checkbox"/> Battery <input type="checkbox"/> Others	
5.	<input type="checkbox"/> For self-diagnosis NG items, inspect each component. Repair or replace the damaged parts.	AT-22
6.	<input type="checkbox"/> Perform all ROAD TEST and re-mark required procedures.	AT-53
7.	<input type="checkbox"/> Perform the Diagnostic Procedures for all remaining items marked NG. Repair or replace the damaged parts.	AT-58 AT-70
8.	<input type="checkbox"/> Erase DTC from TCM and ECM memories.	AT-19

Work Flow

HOW TO PERFORM TROUBLE DIAGNOSES FOR QUICK AND ACCURATE REPAIR

=NLAT0024


A good understanding of the malfunction conditions can make troubleshooting faster and more accurate. In general, each customer feels differently about a problem. It is important to fully understand the symptoms or conditions for a customer complaint.

NLAT0024S01

Make good use of the two sheets provided, "INFORMATION FROM CUSTOMER" (AT-42) and "DIAGNOSTIC WORKSHEET" (AT-43), to perform the best troubleshooting possible.

WORK FLOW CHART

=NLAT0024S02



SAT280K

*1: AT-42

*2: AT-43

*3: AT-8

*4: AT-51

*5: AT-51, 52

*6: AT-53

*7: AT-21

*8: AT-18

*9: AT-28




*10: AT-67

*11: AT-125

*12: AT-19

*13: AT-67

*14: AT-125



Introduction

NLATO247

The TCM receives a signal from the vehicle speed sensor, throttle position sensor or PNP switch and provides shift control or lock-up control via CVT solenoid valves.

Input and output signals must always be correct and stable in the operation of the CVT system. The CVT system must be in good operating condition and be free of valve seizure, solenoid valve malfunction, etc.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.

A visual check only, may not find the cause of the problems. A road test with CONSULT-II or a circuit tester connected should be performed. Follow the "Work Flow". Refer to AT-49.

Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such problems, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "Diagnostic Worksheet" like the example (AT-48) should be used.

Start your diagnosis by looking for "conventional" problems first. This will help troubleshoot driveability problems on an electronically controlled engine vehicle.

Also check related Service bulletins for information.

TROUBLE DIAGNOSIS — INTRODUCTION

EXCEPT FOR EURO-OB

Introduction (Cont'd)

DIAGNOSTIC WORKSHEET

Information from Customer

=NLAT0247S01

KEY POINTS

NLAT0247S0101

WHAT Vehicle & CVT model

WHEN..... Date, Frequencies

WHERE..... Road conditions

HOW..... Operating conditions, Symptoms

Customer name MR/MS	Model & Year	VIN
Trans. model	Engine	Mileage
Incident Date	Manuf. Date	In Service Date
Frequency	<input type="checkbox"/> Continuous <input type="checkbox"/> Intermittent (times a day)	
Symptoms	<input type="checkbox"/> Vehicle does not move. (<input type="checkbox"/> Any position <input type="checkbox"/> Particular position)	
	<input type="checkbox"/> Lockup malfunction	
	<input type="checkbox"/> Shift point too high or too low.	
	<input type="checkbox"/> Shift shock or slip (<input type="checkbox"/> N → D <input type="checkbox"/> Lockup <input type="checkbox"/> Any drive position)	
	<input type="checkbox"/> Noise or vibration	
	<input type="checkbox"/> No pattern select	
SPORT indicator lamp	Blinks for about 8 seconds.	
	<input type="checkbox"/> Continuously lit	<input type="checkbox"/> Not lit

TROUBLE DIAGNOSIS — INTRODUCTION

EXCEPT FOR EURO-OBD

Introduction (Cont'd)

Diagnostic Worksheet

=NLAT0247S0102

1.	<input type="checkbox"/> Read the Fail-safe and listen to customer complaints.	AT-7
2.	<input type="checkbox"/> CHECK CVT FLUID <input type="checkbox"/> Leakage (Follow specified procedure) <input type="checkbox"/> Fluid condition <input type="checkbox"/> Fluid level	AT-51
3.	<input type="checkbox"/> Perform STALL TEST and LINE PRESSURE TEST. <input type="checkbox"/> Stall test — Mark possible damaged components/others. <input type="checkbox"/> Forward clutch <input type="checkbox"/> Reverse brake <input type="checkbox"/> Engine <input type="checkbox"/> Line pressure is low. <input type="checkbox"/> Line Pressure test — Suspected parts:	AT-51, 52
4.	<input type="checkbox"/> Perform all ROAD TEST and mark required procedures.	AT-53
4-1.	Check before engine is started. <input type="checkbox"/> SELF-DIAGNOSTIC PROCEDURE — Mark detected items. <input type="checkbox"/> CVT fluid temperature sensor, AT-170. <input type="checkbox"/> Vehicle speed sensor (Output pulley speed signal), AT-126. <input type="checkbox"/> Engine speed signal, AT-176. <input type="checkbox"/> Torque converter clutch solenoid valve, AT-164. <input type="checkbox"/> Line pressure solenoid valve, AT-157. <input type="checkbox"/> Step motor, AT-146, 150. <input type="checkbox"/> Line pressure sensor, AT-151. <input type="checkbox"/> Throttle position sensor, AT-137. <input type="checkbox"/> Primary speed sensor, AT-132. <input type="checkbox"/> CVT save function, AT-125 <input type="checkbox"/> Control unit (RAM), control unit (ROM), AT-180 <input type="checkbox"/> Control unit (EEP ROM), AT-182 <input type="checkbox"/> Battery <input type="checkbox"/> Others	AT-54
5.	<input type="checkbox"/> For self-diagnosis NG items, inspect each component. Repair or replace the damaged parts.	AT-31
6.	<input type="checkbox"/> Perform all ROAD TEST and re-mark required procedures.	AT-53
7.	<input type="checkbox"/> Perform the Diagnostic Procedures for all remaining items marked NG. Repair or replace the damaged parts.	AT-58 AT-130
8.	<input type="checkbox"/> Erase self-diagnosis code from TCM memories.	AT-34

Work Flow

HOW TO PERFORM TROUBLE DIAGNOSES FOR QUICK AND ACCURATE REPAIR

=NLAT0248

A good understanding of the malfunction conditions can make troubleshooting faster and more accurate. In general, each customer feels differently about a problem. It is important to fully understand the symptoms or conditions for a customer complaint.

NLAT0248S01

Make good use of the two sheets provided, "INFORMATION FROM CUSTOMER" (AT-47) and "DIAGNOSTIC WORKSHEET" (AT-48), to perform the best troubleshooting possible.


TROUBLE DIAGNOSIS — INTRODUCTION

EXCEPT FOR EURO-OBD

Work Flow (Cont'd)

WORK FLOW CHART

=NLAT0248S02





SAT272K

*1: AT-47
*2: AT-48
*3: AT-7
*4: AT-51
*5: AT-51, 52

*6: AT-53
*7: AT-31
*8: AT-31
*9: AT-38
*10: AT-127

*11: AT-182
*12: AT-34
*13: AT-127
*14: AT-176



CVT Fluid Check

NLAT0025

FLUID LEAKAGE CHECK

NLAT0025S01

1. Clean area suspected of leaking. — for example, mating surface of converter housing and transmission case.
2. Start engine, apply foot brake, place selector lever in “D” position and wait a few minutes.
3. Stop engine.

4. Check for fluid leakage.

FLUID CONDITION CHECK


NLAT0025S02

Fluid color	Suspected problem
Dark or black with burned odor	Wear of frictional material
Milky pink	Water contamination — Road water entering through filler tube or breather
Varnished fluid, light to dark brown and tacky	Oxidation — Over or under filling, — Overheating

FLUID LEVEL CHECK

NLAT0025S03

Refer to “Checking CVT Fluid”, AT-10.



Stall Test

NLAT0026

STALL TEST PROCEDURE


NLAT0026S01

1. Check CVT fluid and engine oil levels. If necessary, add.
2. Drive vehicle for approx. 10 minutes or until engine oil and CVT fluid reach operating temperature.


**CVT fluid operating temperature:
50 - 80°C (122 - 176°F)**

TROUBLE DIAGNOSIS — BASIC INSPECTION


Stall Test (Cont'd)




SAT513G



SAT514G




SAT771B



Line pressure test port

SAT670J



SAT647B

3. Set parking brake and block wheels.
4. Install a tachometer where it can be seen by driver during test.
 - It is good practice to mark the point of specified engine rpm on indicator.

5. Start engine, apply foot brake, and place selector lever in D position.
6. Accelerate to wide open throttle gradually while applying foot brake.
7. Quickly note the engine stall revolution and immediately release throttle.
 - During test, never hold throttle wide open for more than 5 seconds.

Stall revolution:
2,350 - 2,850 rpm

8. Move selector lever to "N" position.
9. Cool off CVT fluid.
 - Run engine at idle for at least one minute.

Line Pressure Test

LINE PRESSURE TEST PORTS

NLAT0027

NLAT0027S01

Location of line pressure test ports are shown in the illustration.

- Always replace pressure plugs as they are self-sealing bolts.

LINE PRESSURE TEST PROCEDURE

NLAT0027S02


1. Check CVT fluid and engine oil levels. If necessary, add fluid or oil.
2. Drive vehicle for approx. 10 minutes or until engine oil and CVT fluid reach operating temperature.

CVT fluid operating temperature:
50 - 80°C (122 - 176°F)

TROUBLE DIAGNOSIS — BASIC INSPECTION


Line Pressure Test (Cont'd)

3. Install pressure gauge to corresponding line pressure port.



SAT513G

4. Set parking brake and block wheels.
 - Continue to depress brake pedal fully while line pressure test is being performed at stall speed.



SAT493G

5. Start engine and measure line pressure at idle and stall speed.
 - When measuring line pressure at stall speed, follow the stall test procedure.

Line pressure: Refer to SDS, AT-210.

ROAD TEST PROCEDURE

1. Check before engine is started.



2. Cruise test.

SAT692J


Road Test

DESCRIPTION

NLAT0028

NLAT0028S01

- The purpose of the test is to determine overall performance of CVT and analyze causes of problems.
- The road test consists of the following three parts:
 1. Check before engine is started
 2. Cruise test
- Before road test, familiarize yourself with all test procedures and items to check.
- Conduct tests on all items until specified symptom is found. Troubleshoot items which check out No Good after road test. Refer to "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION", AT-18 to AT-28 (EURO-OBD)/AT-31 to AT-38 (Except for EURO-OBD).




SAT496G

TROUBLE DIAGNOSIS — BASIC INSPECTION

Road Test (Cont'd)


1. CHECK BEFORE ENGINE IS STARTED

=NLAT0028S02

1	CHECK SPORT INDICATOR LAMP	
<p>1. Park vehicle on flat surface. 2. Move selector lever to "P" position.</p> <div style="text-align: center;">  <p>The diagram shows two views of the vehicle's interior. On the left, a close-up of the SPORT mode switch with an arrow pointing to it. On the right, the selector lever is shown in the 'P' position, with an arrow pointing to the 'P' label and a dashed arrow indicating the lever's movement.</p> </div> <p>3. Turn ignition switch to "OFF" position. Wait at least 5 seconds. 4. Turn ignition switch to "ON" position. (Do not start engine.) 5. Does SPORT indicator lamp come on for about 2 seconds?</p> <p style="text-align: right;">SAT9671C</p>		
Yes or No		
Yes	▶	GO TO 2.
No	▶	Stop ROAD TEST.

2	CHECK SPORT INDICATOR LAMP	
Does SPORT indicator lamp flicker for about 8 seconds?		
Yes or No		
Yes (EURO-OBD)	▶	Perform self-diagnosis and check NG items on the DIAGNOSTIC WORKSHEET, AT-43. Refer to TCM SELF-DIAGNOSIS PROCEDURE (NO TOOLS), AT-28.
Yes (Except for EURO-OBD)	▶	Perform self-diagnosis and check NG items on the DIAGNOSTIC WORKSHEET, AT-48. Refer to TCM SELF-DIAGNOSIS PROCEDURE (NO TOOLS), AT-35.
No	▶	1. Turn ignition switch to "OFF" position. 2. Perform self-diagnosis and note NG items. Refer to TCM SELF-DIAGNOSIS PROCEDURE (NO TOOLS), AT-28.

3	TEST DRIVE	
Drive the vehicle and verify that there are no abnormalities.		
	▶	TEST END



2. CRUISE TEST

NLAT0028S04

- Check all items listed in Parts 1 through 3.


With CONSULT-II

NLAT0028S0401

- Using CONSULT-II, conduct a cruise test and record the result.
- Print the result and ensure that shifts and lock-ups take place as per Shift Schedule.

TROUBLE DIAGNOSIS — BASIC INSPECTION


Road Test (Cont'd)




CONSULT-II Setting Procedure

NLAT0028S0402


1. Turn ignition switch "OFF".
2. Connect CONSULT-II to data link connector which is located in the left side lower dash panel.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "CVT".



6. Touch "DATA MONITOR".



7. Touch "MAIN SIGNALS" to set recording condition.
8. See "Numerical Display", "Barchart Display" or "Line Graph Display".
9. Touch "START".

TROUBLE DIAGNOSIS — BASIC INSPECTION

Road Test (Cont'd)

DATA MONITOR	
MONITOR	NO DTC
VEHICLE SPEED	XXX km/h
THROTTLE POSI	XXX
SLCTLVR POSI	NP
ENGINE SPEED	XXX rpm
I/P PULLY SPD	XXX rpm
CVT RATIO	XXX
PLY CONT STEP	XXX step
LINE PRES DTY	XXX%
TCC S/V DUTY	XXX%

SAT236K

10. When performing cruise test, touch "Store Data".

DATA MONITOR	
Recording data XXX %	NO DTC
VEHICLE SPEED	XXX km/h
THROTTLE POSI	XXX
SLCTLVR POSI	NP
ENGINE SPEED	XXX rpm
I/P PULLY SPD	XXX rpm
CVT RATIO	XXX
PLY CONT STEP	XXX step
LINE PRES DTY	XXX%
TCC S/V DUTY	XXX%

SAT237K

11. After finishing cruise test part 1, touch "STOP".

REAL-TIME DIAG
NO DTC

SAT254K

12. Touch "STORE".

SAVE DATA	
NOT FOUND SAVE REC DATA	
A/T	1999/1/30 19:59:18
A/T	1999/1/30 19:59:42
A/T	1999/1/30 20:01:04

SAT608J

13. Touch "DISPLAY".

STORE	
SYSTEM	SAVE REC DATA
ENGINE	04/15/1999, 10:34:29
ENGINE	07/15/1999, 15:10:33

SAT238K


14. Touch "PRINT".

15. Check the monitor data printed out.

16. Continue cruise test part 2 and 3.

TROUBLE DIAGNOSIS — BASIC INSPECTION

Road Test (Cont'd)




⊗ Without CONSULT-II

NLAT0028S0403

- Throttle position sensor can be checked by voltage across terminals 41 and 42 of TCM. Refer to "Road Test", AT-53.

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

TCM Terminals and Reference Value



TCM Terminals and Reference Value

NLAT0030


PREPARATION

NLAT0030S01

- Measure voltage between each terminal and terminal 25 or 48 by following "TCM INSPECTION TABLE".

TCM HARNESS CONNECTOR TERMINAL LAYOUT

NLAT0030S02










TCM INSPECTION TABLE (Data are reference values.)

NLAT0030S03

Terminal No.	Wire color	Item	Condition	Judgement standard (Approx.)	
1	R/W	Line pressure solenoid valve		When releasing accelerator pedal after warming up engine.	2.8V
				When depressing accelerator pedal fully after warming up engine.	1.4V
2	P/B	Line pressure solenoid valve (with dropping resistor)		When releasing accelerator pedal after warming up engine.	11.0V
				When depressing accelerator pedal fully after warming up engine.	4.0V
3	GY/R	Torque converter clutch solenoid valve		When CVT performs lock-up.	12.0V
				When CVT does not perform lock-up.	0V
5 *1	Y/R	DT1		—	
6 *1	Y/G	DT2		—	
7 *1	Y/L	DT3		—	
8 *1	BR/W	DT5		—	
9 *1	G/Y	DT4		—	
10	G/W	Power source		When turning ignition switch to "ON".	Battery voltage
				When turning ignition switch to "OFF".	0V









TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

TCM Terminals and Reference Value (Cont'd)

Terminal No.	Wire color	Item	Condition		Judgement standard (Approx.)
11	PU	Step motor A	Within 2 seconds after key switch "ON", the time measurement by using the pulse width measurement function (Hi level) of CONSULT-II. ● CONSULT-II cable connected to data link connector. ● This inspection cannot be measured by circuit tester.		30.0 msec
12	L/W	Step motor B			10.0 msec
13	OR/B	SPORT indicator lamp		When SPORT indicator lamp illuminates	0V
				When SPORT indicator lamp does not illuminate	Battery voltage
15 *1	PU	(EURO-OBD-II)		—	—
16	Y/PU	Closed throttle position switch (in throttle position switch)		When releasing accelerator pedal after warming up engine. Refer to step 1 to 6 of "Preparation", "TCM Self-diagnostic Procedure (No Tools)", AT-28 — EURO-OBD/AT-35 — Except for EURO-OBD.	Battery voltage
				When depressing accelerator pedal after warming up engine. Refer to step 1 to 6 of "Preparation", "TCM Self-diagnostic Procedure (No Tools)", AT-28 — EURO-OBD/AT-35 — Except for EURO-OBD.	0V
17	LG	Wide open throttle position switch (in throttle position switch)		When depressing accelerator pedal more than half-way after warming up engine.	Battery voltage
				When releasing accelerator pedal after warming up engine.	0V
18	BR	ABS control unit		When driving slowly.	Change 0V to battery voltage
19	G/W	Power source		Same as No. 10	
20	L/Y	Step motor C	Within 2 seconds after key switch "ON", the time measurement by using the pulse width measurement function (Hi level) of CONSULT-II. ● CONSULT-II cable connected to data link connector. ● This inspection cannot be measured by circuit tester.		30.0 msec
21	P/L	Step motor D			10.0 msec
22	P	Sport mode switch		When SPORT mode switch in "ON" position.	0V
				When SPORT mode switch in "OFF" position.	10V
23	SB	ABS control unit		When ABS operates.	0V
				When ABS does not operate.	5.6 - 10.0V


TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

TCM Terminals and Reference Value (Cont'd)

Terminal No.	Wire color	Item	Condition		Judgement standard (Approx.)
25	B	Ground		—	—
27	L	PNP switch "L" position		When setting selector lever to "L" position.	Battery voltage
				When setting selector lever to other positions.	0V
28	R/B	Power source (Memory back-up)	 or 	When turning ignition switch to "OFF".	Battery voltage
				When turning ignition switch to "ON".	Battery voltage
29	G/R	Secondary speed sensor	When driving [D position, 20 km/h (12 MPH)], the pulse measurement by using the pulse measurement function of CONSULT-II. <ul style="list-style-type: none"> ● CONSULT-II cable connected to data link connector. ● This inspection cannot be measured by circuit tester. 		600 Hz
30 *2	G/B	(RX)		—	—
31 *2	GY/L	(TX)		—	—
32	R	Throttle position sensor (Power source)		When turning ignition switch to "ON"	4.5 - 5.5V
				When turning ignition switch to "OFF"	0V
34	W/G	PNP switch "D" position		When setting selector lever to "D" position.	Battery voltage
				When setting selector lever to other positions.	0V
35	G/W	PNP switch "R" position		When setting selector lever to "R" position.	Battery voltage
				When setting selector lever to other positions.	0V
36	G	PNP switch "N" or "P" position		When setting selector lever to "N" or "P" position.	Battery voltage
				When setting selector lever to other positions.	0V
37	W	CVT fluid pressure sensor		When engine runs at idle speed.	1.0V
				When engine runs at stall speed.	4.0V
38	G/Y	Primary speed sensor	When driving [L position, 20 km/h (12 MPH)], the pulse measurement by using the pulse measurement function of CONSULT-II. <ul style="list-style-type: none"> ● CONSULT-II cable connected to data link connector. ● This inspection cannot be measured by circuit tester. 		900 Hz
39	L/OR	Engine speed signal		When engine runs at idle speed.	0.5 - 1.5V

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

TCM Terminals and Reference Value (Cont'd)

Terminal No.	Wire color	Item	Condition		Judgement standard (Approx.)
41	GY	Throttle position sensor		When depressing accelerator pedal slowly after warming up engine. (Voltage rises gradually in response to throttle position.)	Fully-closed throttle: 0.5V Fully-open throttle: 4V
42	B	Throttle position sensor (Ground)		—	—
45	R/G	Stop lamp switch		When depressing accelerator pedal	Battery voltage
				When releasing accelerator pedal	0V
46	R/L	CVT fluid pressure sensor (Power source)		—	4.5 - 5.5V
47	BR	CVT fluid temperature sensor		When CVT fluid temperature is 20°C (68°F).	1.5V
				When CVT fluid temperature is 80°C (176°F).	0.5V
48	B	Ground		—	—

*1: This terminal is connected to the ECM.

*2: These terminals are connected to the Data link connector for CONSULT-II.

TROUBLE DIAGNOSIS FOR POWER SUPPLY



Wiring Diagram — AT — MAIN

Wiring Diagram — AT — MAIN MODELS WITH ECM IN ENGINE COMPARTMENT

NLAT0031

NLAT0031S01

AT-MAIN-01



REFER TO THE FOLLOWING.

- (M2) - FUSE BLOCK- JUNCTION BOX (J/B)
- (E55), (E57) - FUSE AND FUSIBLE LINK BOX



YAT173





TROUBLE DIAGNOSIS FOR POWER SUPPLY

Wiring Diagram — AT — MAIN (Cont'd)

MODELS WITH ECM IN CABIN

NLAT0031S03

AT-MAIN-01



YAT212









TROUBLE DIAGNOSIS FOR POWER SUPPLY

TCM Terminals and Reference Value

TCM Terminals and Reference Value

NLAT0329

Remarks: Specification data are reference values.


Terminal No.	Wire color	Item	Condition		Judgement standard (Approx.)
10	G/W	Power source	 	When turning ignition switch to "ON".	Battery voltage
				When turning ignition switch to "OFF".	0V
19	G/W	Power source	 or 	Same as No. 10	
25	B	Ground		—	—
28	R/B	Power source (Memory back-up)	 or 	When turning ignition switch to "OFF".	Battery voltage
				When turning ignition switch to "ON".	Battery voltage
48	B	Ground	 	—	—


TROUBLE DIAGNOSIS FOR POWER SUPPLY

Diagnostic Procedure

Diagnostic Procedure

NLAT0330

1	CHECK TCM POWER SOURCE	<p>1. Turn ignition switch to "ON" position. (Do not start engine.)</p> <p>2. Check voltage between TCM terminals 10, 19, 28 and ground. Voltage: Battery voltage</p> <p>3. Turn ignition switch to "OFF" position.</p> <p>4. Check voltage between TCM terminal 28 and ground. Voltage: Battery voltage</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT332J</p> <p style="text-align: center;">OK or NG</p>
OK	▶	GO TO 2.
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Harness for short or open between ignition switch and TCM terminals 10, 19 and 25 (Main harness) ● Ignition switch and fuse Refer to EL section ("POWER SUPPLY ROUTING").

2	CHECK TCM GROUND CIRCUIT	<p>1. Turn ignition switch to "OFF" position.</p> <p>2. Disconnect TCM harness connector.</p> <p>3. Check continuity between terminals 25, 48 and ground. Continuity should exist.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT333J</p> <p>If OK, check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>
OK	▶	INSPECTION END
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

DTC P0705 PARK/NEUTRAL POSITION (PNP) SWITCH EURO-OB

Description

Description

NLAT0032

- The PNP switch assembly includes a transmission range switch.
- The transmission range switch detects the selector lever position and sends a signal to the TCM.

TCM TERMINALS AND REFERENCE VALUE

NLAT0032S01

Remarks: Specification data are reference values.

Terminal No.	Wire color	Item	Condition	Judgement standard (Approx.)
27	L	PNP switch "L" position	When setting selector lever to "L" position.	Battery voltage
			When setting selector lever to other positions.	0V
34	W/G	PNP switch "D" position	When setting selector lever to "D" position.	Battery voltage
			When setting selector lever to other positions.	0V
35	G/W	PNP switch "R" position	When setting selector lever to "R" position.	Battery voltage
			When setting selector lever to other positions.	0V
36	G	PNP switch "N" or "P" position	When setting selector lever to "N" or "P" position.	Battery voltage
			When setting selector lever to other positions.	0V



ON BOARD DIAGNOSIS LOGIC

NLAT0032S02

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
PIP : PNP SW/CIRC GST : P0705 HO TOOLS : MI Code No. 0705	TCM does not receive the correct voltage signal from the switch based on the gear position.	<ul style="list-style-type: none"> • Harness or connectors (The PNP switch circuit is open or shorted.) • PNP switch

DTC P0705 PARK/NEUTRAL POSITION (PNP) SWITCH

EURO-OB

Description (Cont'd)

SELECT SYSTEM
CVT
ENGINE

SAT250K

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
ACTIVE TEST
DTC & SRT CONFIRMATION
ECM PART NUMBER

SAT255K

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NLAT0032S03

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode for "CVT" with CONSULT-II.
- 2) Make sure that output voltage of CVT fluid temperature sensor is within the range below.

FLUID TEMP SEN: 0.5 - 1.5V

If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid)

- 3) Select "DATA MONITOR" mode for "ENGINE" with CONSULT-II.
- 4) Start engine and maintain the following conditions for at least 15 consecutive seconds.

VHCL SPEED SE: 10 km/h (6 MPH) or more

THRTL POS SEN: More than 1.0/8

Selector lever: D position

ENG SPEED: 450 rpm or more

If the check result is "NG", go to "Diagnostic Procedure", AT-70.

With GST

Follow the procedure "With CONSULT-II".

DTC P0705 PARK/NEUTRAL POSITION (PNP) SWITCH EURO-OBD

Wiring Diagram — AT — PNP/SW


Wiring Diagram — AT — PNP/SW MODELS WITH ECM IN ENGINE COMPARTMENT

NLAT0199

NLAT0199S01

AT-PNP/SW-01


: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC



REFER TO EL-POWER.

PARK/NEUTRAL POSITION (PNP) SWITCH (F6)

TCM (TRANSMISSION CONTROL MODULE) (F15)



REFER TO THE FOLLOWING.

(M1) - FUSE BLOCK-JUNCTION BOX (J/B)

DTC P0705 PARK/NEUTRAL POSITION (PNP) SWITCH EURO-OB





Wiring Diagram — AT — PNP/SW (Cont'd)

MODELS WITH ECM IN CABIN

NLAT0199S02

AT-PNP/SW-01

— : DETECTABLE LINE FOR DTC
— : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M1) - FUSE BLOCK-
 JUNCTION BOX (J/B)

DTC P0705 PARK/NEUTRAL POSITION (PNP) SWITCH

EURO-OBD

Diagnostic Procedure

Diagnostic Procedure

NLAT0033

1	CHECK PNP SWITCH CIRCUIT (With CONSULT-II)										
<p>Ⓟ With CONSULT-II</p> <p>1. Turn ignition switch to "ON" position. (Do not start engine.)</p> <p>2. Select "TCM INPUT SIGNALS" in "DATA MONITOR" mode for "CVT" with CONSULT-II.</p>											
<table border="1" style="margin: auto; border-collapse: collapse;"> <tr><td style="text-align: center;">SELECT SYSTEM</td></tr> <tr><td style="text-align: center;">CVT</td></tr> <tr><td style="text-align: center;">ENGINE</td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;"> </td></tr> </table>				SELECT SYSTEM	CVT	ENGINE					
SELECT SYSTEM											
CVT											
ENGINE											
SAT250K											
<p>3. Read out "P/N", "R", "D" and "L" position switches moving selector lever to each position. Check the signal of the selector lever position is indicated properly.</p> <p style="text-align: center;">OK or NG</p>											
OK	▶	GO TO 3.									
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● PNP switch Refer to "Component Inspection", AT-72. ● Harness for short or open between ignition switch and PNP switch (Main harness) ● Harness for short or open between PNP switch and TCM (Main harness) ● Ignition switch and fuse Refer to EL section ("POWER SUPPLY ROUTING"). 									

2	CHECK PNP SWITCH CIRCUIT (Without CONSULT-II)																															
<p>ⓧ Without CONSULT-II</p> <p>1. Turn ignition switch to "ON" position. (Do not start engine.)</p> <p>2. Check voltage between TCM terminals 27, 34, 35, 36 and ground while moving selector lever through each position.</p> <p style="color: blue;">Voltage: B: Battery voltage 0: 0V</p>																																
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">Lever position</th> <th colspan="4">Terminal No.</th> </tr> <tr> <th>36</th> <th>35</th> <th>34</th> <th>27</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">P, N</td> <td style="text-align: center;">B</td> <td style="text-align: center;">0</td> <td style="text-align: center;">0</td> <td style="text-align: center;">0</td> </tr> <tr> <td style="text-align: center;">R</td> <td style="text-align: center;">0</td> <td style="text-align: center;">B</td> <td style="text-align: center;">0</td> <td style="text-align: center;">0</td> </tr> <tr> <td style="text-align: center;">D</td> <td style="text-align: center;">0</td> <td style="text-align: center;">0</td> <td style="text-align: center;">B</td> <td style="text-align: center;">0</td> </tr> <tr> <td style="text-align: center;">L</td> <td style="text-align: center;">0</td> <td style="text-align: center;">0</td> <td style="text-align: center;">0</td> <td style="text-align: center;">B</td> </tr> </tbody> </table>				Lever position	Terminal No.				36	35	34	27	P, N	B	0	0	0	R	0	B	0	0	D	0	0	B	0	L	0	0	0	B
Lever position	Terminal No.																															
	36	35	34	27																												
P, N	B	0	0	0																												
R	0	B	0	0																												
D	0	0	B	0																												
L	0	0	0	B																												
MTBL0312																																
OK or NG																																
OK	▶	GO TO 3.																														
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● PNP switch Refer to "Component Inspection", AT-72. ● Harness for short or open between ignition switch and PNP switch (Main harness) ● Harness for short or open between PNP switch and TCM (Main harness) ● Ignition switch and fuse Refer to EL section ("POWER SUPPLY ROUTING"). 																														

DTC P0705 PARK/NEUTRAL POSITION (PNP) SWITCH

EURO-OB

Diagnostic Procedure (Cont'd)

3	CHECK DTC
Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-67.	
OK or NG	
OK	▶ INSPECTION END
NG	▶ 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

Component Inspection

=NLAT0034

PARK/NEUTRAL POSITION SWITCH

NLAT0034S01

1. Check continuity between terminals 1 and 3 and between terminals 2 and 4, 5, 6, 7, 8, 9 while moving manual shaft through each position.


Lever position	Terminal No.
P	3 — 7
R	3 — 8
N	3 — 9
D	3 — 6
L	3 — 5

2. If NG, check again with control cable disconnected from manual shaft of CVT assembly. Refer to step 1.
3. If OK on step 2, adjust control cable. Refer to AT-204.
4. If NG on step 2, remove PNP switch from A/T and check continuity of PNP switch terminals. Refer to step 1.
5. If OK on step 4, adjust PNP switch. Refer to AT-204.
6. If NG on step 4, replace PNP switch.

DTC P0710 CVT FLUID TEMPERATURE SENSOR CIRCUIT

EURO-OBD

Description



Description

The CVT fluid temperature sensor detects the CVT fluid temperature and sends a signal to the TCM. NLAT0035

CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

NLAT0035S01

Remarks: Specification data are reference values.

Monitor item	Condition	Specification (Approximately)	
CVT fluid temperature sensor	Cold [20°C (68°F)]	1.5V	2.5 kΩ
	↓ Hot [80°C (176°F)]	↓ 0.5V	↓ 0.3 kΩ

TCM TERMINALS AND REFERENCE VALUE

NLAT0035S02

Remarks: Specification data are reference values.

Terminal No.	Wire color	Item	Condition	Judgement standard (Approx.)
42	B	Throttle position sensor (Ground)	—	—
47	BR	CVT fluid temperature sensor	When CVT fluid temperature is 20°C (68°F).	1.5V
			When CVT fluid temperature is 80°C (176°F).	0.5V

ON BOARD DIAGNOSIS LOGIC

NLAT0035S03

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
: ATF TEMP SEN/CIRC : P0710 : MI Code No. 0710	TCM receives an excessively low or high voltage from the sensor.	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) CVT fluid temperature sensor

DTC P0710 CVT FLUID TEMPERATURE SENSOR CIRCUIT

EURO-OBD

Description (Cont'd)

SELECT SYSTEM
CVT
ENGINE

SAT250K

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
ACTIVE TEST
DTC & SRT CONFIRMATION
ECM PART NUMBER

SAT255K

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NLAT0035S04

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode for "ENGINE" with CONSULT-II.
- 2) Start engine and maintain the following conditions for at least 10 minutes (Total). (It is not necessary to maintain continuously.)

CMPS-RPM (REF): 450 rpm or more

VHCL SPEED SE: 10 km/h (6 MPH) or more

THRTL POS SEN: More than 1.3V

Selector lever: D position

If the check result is NG, go to "Diagnostic Procedure", AT-77.

With GST

Follow the procedure "With CONSULT-II".

DTC P0710 CVT FLUID TEMPERATURE SENSOR CIRCUIT

EURO-OBD

Wiring Diagram — AT — FTS




Wiring Diagram — AT — FTS

MODELS WITH ECM IN ENGINE COMPARTMENT

NLAT0200

NLAT0200S01

AT-FTS-01



YAT175

DTC P0710 CVT FLUID TEMPERATURE SENSOR CIRCUIT



EURO-OBD

Wiring Diagram — AT — FTS (Cont'd)

MODELS WITH ECM IN CABIN

NLAT0200S02

AT-FTS-01



YAT214


DTC P0710 CVT FLUID TEMPERATURE SENSOR CIRCUIT

EURO-OBD

Diagnostic Procedure

Diagnostic Procedure

NLAT0036



1	CHECK CVT FLUID TEMPERATURE SENSOR WITH TERMINAL CORD ASSEMBLY	
<p>1. Turn ignition switch to "OFF" position. 2. Disconnect terminal cord assembly connector in engine compartment. 3. Check resistance between terminals 6 and 7 when CVT is cold.</p> <p style="color: blue;">Resistance: Cold [20°C (68°F)] Approximately 2.5 kΩ</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT229K</p> <p>4. Reinstall any part removed.</p> <p style="text-align: center;">OK or NG</p>		
OK (With CONSULT-II)	▶	GO TO 2.
OK (Without CONSULT-II)	▶	GO TO 3.
NG	▶	Replace CVT assembly.

2	CHECK INPUT SIGNAL OF CVT FLUID TEMPERATURE SENSOR (With CONSULT-II)	
<p>Ⓜ With CONSULT-II</p> <p>1. Start engine. 2. Select "TCM INPUT SIGNALS" in "DATA MONITOR" mode for "CVT" with CONSULT-II. 3. Read out the value of "FLUID TEMP SE".</p> <p style="color: blue;">Voltage: Cold [20°C (68°F)] → Hot [80°C (176°F)]: Approximately 1.5V → 0.5V</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 4.
NG	▶	<p>Check the following item:</p> <ul style="list-style-type: none"> ● Harness for short to ground or short to power or open between TCM, ECM and terminal cord assembly (Main harness) ● Ground circuit for ECM <p>Refer to EC section ("TROUBLE DIAGNOSIS FOR POWER SUPPLY").</p>

DTC P0710 CVT FLUID TEMPERATURE SENSOR CIRCUIT

EURO-OBD

Diagnostic Procedure (Cont'd)

3	CHECK INPUT SIGNAL OF CVT FLUID TEMPERATURE SENSOR (Without CONSULT-II)	
<p>⊗ Without CONSULT-II</p> <p>1. Start engine.</p> <p>2. Check voltage between TCM terminal 47 and ground while warming up CVT.</p> <p style="color: blue;">Voltage: Cold [20°C (68°F)] → Hot [80°C (176°F)]: Approximately 1.5V → 0.5V</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT420JB</p> <p>3. Turn ignition switch to "OFF" position.</p> <p>4. Disconnect TCM harness connector.</p> <p>5. Check continuity between terminal 42 and ground.</p> <p>Continuity should exist.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT421J</p> <p>If OK, check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 4.
NG	▶	<p>Check the following item:</p> <ul style="list-style-type: none"> ● Harness for short to ground or short to power or open between TCM, ECM and terminal cord assembly (Main harness) ● Ground circuit for ECM Refer to EC section ("TROUBLE DIAGNOSIS FOR POWER SUPPLY").

4	CHECK DTC	
Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-74.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	<p>1. Perform TCM input/output signal inspection.</p> <p>2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.</p>

DTC P0715 PRIMARY SPEED SENSOR

EURO-OB

Description

Description

The primary speed sensor detects the primary pulley revolution speed sends a signal to the ECM. NLAT0220

TCM TERMINALS AND REFERENCE VALUE

NLAT0220S01

Remarks: Specification data are reference values.

Terminal No.	Wire color	Item	Condition	Judgement standard (Approx.)
38	G/Y	Primary speed sensor	When driving [L position, 20 km/h (12 MPH)], the pulse measurement by using the pulse measurement function of CONSULT-II. <ul style="list-style-type: none"> ● CONSULT-II cable connected to data link connector. ● This inspection cannot be measured by circuit tester. 	900 Hz

ON BOARD DIAGNOSIS LOGIC

NLAT0220S02

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
<ul style="list-style-type: none"> Ⓜ : PRI SPEED SIG/CIRC Ⓜ : P0715 Ⓜ : MIL Code No. 0715 	TCM does not receive the proper voltage signal from the sensor.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Primary speed sensor

SELECT SYSTEM
CVT
ENGINE

SAT250K

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
TCM PART NUMBER

SAT252K

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
ACTIVE TEST
DTC & SRT CONFIRMATION
ECM PART NUMBER

SAT255K

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NLAT0220S03

CAUTION:

- Always drive vehicle at a safe speed.
- Be careful not to rev engine into the red zone on the tachometer.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

Ⓜ With CONSULT-II

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode for "ENGINE" with CONSULT-II.
- 2) Start engine and maintain the following conditions for at least 5 consecutive seconds.

VHCL SPEED SE: 10 km/h (6 MPH) or more

THRTL POS SEN: More than 1.3V

Selector lever: D position

ENG SPEED: 450 rpm or more

Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.

If the check result is NG, go to "Diagnostic Procedure", AT-82.

Ⓜ With GST

Follow the procedure "With CONSULT-II".

DTC P0715 PRIMARY SPEED SENSOR

EURO-OBD



Wiring Diagram — AT — PSSA/T

Wiring Diagram — AT — PSSA/T MODELS WITH ECM IN ENGINE COMPARTMENT

NLAT0221

NLAT0221S01

AT-PSSAT-01



DTC P0715 PRIMARY SPEED SENSOR



EURO-OBd

Wiring Diagram — AT — PSSA/T (Cont'd)

MODELS WITH ECM IN CABIN

NLAT0221S02

AT-PSSAT-01



YAT215

Diagnostic Procedure

NLAT0222

1	CHECK PRIMARY SPEED SENSOR	
Refer to "Component Inspection", AT-83.		
OK or NG		
OK (With CONSULT-II)	▶	GO TO 2.
OK (Without CONSULT-II)	▶	GO TO 3.
NG	▶	Repair or replace primary speed sensor.


2	CHECK INPUT SIGNAL (With CONSULT-II)	
Ⓢ With CONSULT-II 1. Start engine. 2. Select "TCM INPUT SIGNALS" in "DATA MONITOR" mode for "CVT" with CONSULT-II. 3. Read out the value of "I/P PULLY SPD" while driving. Check the value changes according to driving speed. (Almost same value as engine speed)		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Check the following items: <ul style="list-style-type: none"> ● Harness for short or open between TCM, ECM and primary speed sensor (Main harness) ● Ground circuit for ECM Refer to EC section ("TROUBLE DIAGNOSIS FOR POWER SUPPLY").

3	CHECK DTC	
Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-79.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

DTC P0715 PRIMARY SPEED SENSOR

EURO-OBD

Component Inspection



Component Inspection PRIMARY SPEED SENSOR

NLAT0223

NLAT0223S01

1. Jacking up the vehicle.
2. Check pulse by using the pulse measurement function of CONSULT-II when front wheel rotating.
 - CONSULT-II cable connected to data link connector.

At front wheel rotating [L position 20 km/h (12 MPH)]: Approx. 900 Hz

DTC P0720 VEHICLE SPEED SENSOR (SECONDARY SPEED SENSOR)

EURO-OBDD

Description

Description


The vehicle speed sensor CVT (secondary speed sensor) detects the revolution of the idler gear parking pawl lock gear and emits a pulse signal. The pulse signal is sent to the TCM which converts it into vehicle speed.

NLAT0038

TCM TERMINALS AND REFERENCE VALUE




NLAT0038S01


Remarks: Specification data are reference values.

Terminal No.	Wire color	Item	Condition	Judgement standard (Approx.)
29	G/R	Secondary speed sensor	When driving [D position, 20 km/h (12 MPH)], the pulse measurement by using the pulse measurement function of CONSULT-II. <ul style="list-style-type: none"> CONSULT-II cable connected to data link connector. This inspection cannot be measured by circuit testelr. 	600 Hz
42	B	Throttle position sensor (Ground)		—

ON BOARD DIAGNOSIS LOGIC

NLAT0038S02

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
 : VEH SPD SEN/CIR AT	TCM does not receive the proper voltage signal from the sensor.	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Secondary speed sensor
 : P0720		
 : MI Code No. 0720		



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NLAT0038S03

CAUTION:

- Always drive vehicle at a safe speed.
- Be careful not to rev engine into the red zone on the tachometer.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

DTC P0720 VEHICLE SPEED SENSOR (SECONDARY SPEED SENSOR)

EURO-OB

Description (Cont'd)

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
TCM PART NUMBER

SAT252K

With CONSULT-II

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode for "ENGINE" with CONSULT-II.
- 2) Start engine and maintain the following conditions for at least 12 consecutive seconds.

THRTL POS SEN: More than 1.3V

Selector lever: D position

Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.

If the check result is NG, go to "DIAGNOSTIC PROCEDURE", AT-88.

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
ACTIVE TEST
DTC & SRT CONFIRMATION
ECM PART NUMBER

SAT255K

With GST

Follow the procedure "With CONSULT-II".

DTC P0720 VEHICLE SPEED SENSOR (SECONDARY SPEED SENSOR)

EURO-OBD




Wiring Diagram — AT — VSSA/T

Wiring Diagram — AT — VSSA/T MODELS WITH ECM IN ENGINE COMPARTMENT

NLAT0201

NLAT0201S01

AT-VSSAT-01



YAT177

DTC P0720 VEHICLE SPEED SENSOR (SECONDARY SPEED SENSOR)



EURO-OB

Wiring Diagram — AT — VSSA/T (Cont'd)

MODELS WITH ECM IN CABIN

NLAT0201S02

AT-VSSAT-01



YAT216

DTC P0720 VEHICLE SPEED SENSOR (SECONDARY SPEED SENSOR)

EURO-OBDD

Diagnostic Procedure

Diagnostic Procedure

NLAT0039

1	CHECK SECONDARY SPEED SENSOR	
Refer to "Component Inspection", AT-89.		
OK or NG		
OK (With CONSULT-II)	▶	GO TO 2.
OK (Without CONSULT-II)	▶	GO TO 3.
NG	▶	Repair or replace secondary speed sensor.


2	CHECK INPUT SIGNAL (With CONSULT-II)	
<p>Ⓜ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine. 2. Select "TCM INPUT SIGNALS" in "DATA MONITOR" mode for "CVT" with CONSULT-II. 3. Read out the value of "VHCL/S SE-A/T" while driving. Check the value changes according to driving speed. 		
OK or NG		
OK	▶	GO TO 3.
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Harness for short or open between TCM, ECM and secondary speed sensor (Main harness) ● Ground circuit for ECM <p>Refer to EC section ("TROUBLE DIAGNOSIS FOR POWER SUPPLY").</p>

3	CHECK DTC	
Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-84.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	<ol style="list-style-type: none"> 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

DTC P0720 VEHICLE SPEED SENSOR (SECONDARY SPEED SENSOR)

EURO-OBD

Component Inspection



Component Inspection SECONDARY SPEED SENSOR

NLAT0040

NLAT0040S01

1. Jacking up the vehicle.
2. Check pulse by using the pulse measurement function of CONSULT-II when front wheel rotating.

- CONSULT-II cable connected to data link connector.

At front wheel rotating [D position, 20 km/h (12 MPH)]: Approx. 600 Hz

DTC P0725 ENGINE SPEED SIGNAL

EURO-OBD

Description


Description

The engine speed signal is sent from the ECM to the TCM. NLAT0041

TCM TERMINALS AND REFERENCE VALUE

Remarks: Specification data are reference values.

NLAT0041S01

Terminal No.	Wire color	Item	Condition	Judgement standard (Approx.)
39	L/OR	Engine speed signal		When engine runs at idle speed. 0.5 - 1.5V

ON BOARD DIAGNOSIS LOGIC

NLAT0041S02

Diagnostic trouble code	Malfunction is detected when ...	Check item (Possible cause)
E : ENGINE SPEED SIG GST : P0725 MI TOOLS : MI Code No. 0725	TCM does not receive the proper voltage signal from ECM.	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.)

SELECT SYSTEM
CVT
ENGINE

SAT250K

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
ACTIVE TEST
DTC & SRT CONFIRMATION
ECM PART NUMBER

SAT255K

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NLAT0041S03

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

E With CONSULT-II

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode for "ENGINE" with CONSULT-II.
- 2) Start engine and maintain the following conditions for at least 10 consecutive seconds.

VHCL SPEED SE: 10 km/h (6 MPH) or more

THRTL POS SEN: More than 1.3V

Selector lever: D position

If the check result is "NG", go to "Diagnostic Procedure", AT-92

GST With GST

Follow the procedure "With CONSULT-II".

DTC P0725 ENGINE SPEED SIGNAL


EURO-OB2

Wiring Diagram — AT — ENGSS



Wiring Diagram — AT — ENGSS

NLAT0202

AT-ENGSS-01



— : DETECTABLE LINE FOR DTC
— : NON-DETECTABLE LINE FOR DTC




YAT178

Diagnostic Procedure

NLAT0042

1	CHECK DTC WITH ECM	
Perform diagnostic test mode II (self-diag results) for engine control. Check ignition signal circuit condition.		
OK or NG		
OK (With CONSULT-II)	▶	GO TO 2.
OK (Without CONSULT-II)	▶	GO TO 3.
NG	▶	Check ignition signal circuit for engine control. Refer to EC section (IGNITION SIGNAL).

2	CHECK INPUT SIGNAL (With CONSULT-II)	
<p>Ⓜ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine. 2. Select "TCM INPUT SIGNALS" in "DATA MONITOR" mode for "CVT" with CONSULT-II. 3. Read out the value of "ENGINE SPEED". Check engine speed changes according to throttle position. 		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Check the following items: <ul style="list-style-type: none"> ● Harness for short or open between TCM and ECM ● Resistor and ignition coil Refer to EC section (IGNITION SIGNAL).

3	CHECK INPUT SIGNAL (Without CONSULT-II)	
<p>ⓧ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine. 2. Check voltage between TCM terminal 39 and ground. Voltage (Idle speed): 0.5 - 1.5V 		
		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Check the following items: <ul style="list-style-type: none"> ● Harness for short or open between TCM and ECM ● Resistor and ignition coil Refer to EC section (IGNITION SIGNAL).

SAT424JA

DTC P0725 ENGINE SPEED SIGNAL

EURO-OB

Diagnostic Procedure (Cont'd)

4	CHECK DTC
Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-90.	
OK or NG	
OK	▶ INSPECTION END
NG	▶ 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE

EURO-OBD

Description

Description

The torque converter clutch solenoid valve is activated by the TCM in response to signals sent from the vehicle speed and throttle position sensors. Lock-up piston operation will then be controlled. Lock-up operation, however, is prohibited when CVT fluid temperature is too low.

When the accelerator pedal is depressed (less than 2/8) in lock-up condition, the engine speed should not change abruptly. If there is a big jump in engine speed, there is no lock-up.

NLAT0055

CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

Remarks: Specification data are reference values.


NLAT0055S01

Monitor item	Condition	Specification
Torque converter clutch solenoid valve duty	Lock-up "OFF"	Approximately 4%
	↓	↓
	Lock-up "ON"	Approximately 94%

TCM TERMINALS AND REFERENCE VALUE




Remarks: Specification data are reference values.

NLAT0055S02

Terminal No.	Wire color	Item	Condition	Judgement standard (Approx.)
3	GY/R	Torque converter clutch solenoid valve	 When CVT performs lock-up.	12.0V
			When CVT does not perform lock-up.	0V

ON BOARD DIAGNOSIS LOGIC

NLAT0055S03

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
 : TCC SOLENOID/CIRC	TCM detects an improper voltage drop when it tries to operate the solenoid valve.	<ul style="list-style-type: none"> ● Harness or connectors (The solenoid circuit is open or shorted.) ● T/C clutch solenoid valve
 : P0740		
 : MI Code No. 0740		

SELECT SYSTEM
CVT
ENGINE

SAT250K

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NLAT0055S04

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE

EURO-OBD

Description (Cont'd)

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
ACTIVE TEST
DTC & SRT CONFIRMATION
ECM PART NUMBER

SAT255K

With CONSULT-II

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode for "ENGINE" with CONSULT-II and wait at least 10 seconds.
If the check result is "NG", go to "Diagnostic Procedure", AT-97.

With GST

Follow the procedure "With CONSULT-II".

DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE


EURO-OBDD

Wiring Diagram — AT — TCV




Wiring Diagram — AT — TCV

NLAT0207

AT-TCV-01



— : DETECTABLE LINE FOR DTC
— : NON-DETECTABLE LINE FOR DTC



YAT179

DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE

EURO-OBD

Diagnostic Procedure

Diagnostic Procedure

NLAT0056

1	CHECK GROUND CIRCUIT	
<p>1. Turn ignition switch to "OFF" position. 2. Disconnect terminal cord assembly connector in engine compartment. 3. Check resistance between terminal 9 and ground. Resistance: 10 - 20Ω</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 2.
NG	▶	Replace CVT assembly.

2	CHECK POWER SOURCE CIRCUIT	
<p>1. Turn ignition switch to "OFF" position. 2. Disconnect TCM harness connector. 3. Check continuity between terminal 9 and TCM harness connector terminal 3. Continuity should exist.</p>		
<p>If OK, check harness for short to ground and short to power. 4. Reinstall any part removed.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 3.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.


SAT683JA

3	CHECK DTC	
<p>Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-94.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	INSPECTION END
NG	▶	<p>1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.</p>

DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE

EURO-OBD

Component Inspection



Component Inspection

TORQUE CONVERTER CLUTCH SOLENOID VALVE

NLAT0057

NLAT0057S01


- For removal, refer to AT-206.

Resistance Check

NLAT0057S0101

- Check resistance between two terminals.

Solenoid valve	Terminal No.		Resistance (Approx.)
	9	Ground of TCC solenoid valve	
Torque converter clutch solenoid valve	9	Ground of TCC solenoid valve	10 - 20Ω



Operation Check

NLAT0057S0102

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal and ground of TCC solenoid valve.

Description

NLAT0061

The line pressure solenoid valve regulates the oil pump discharge pressure to suit the driving condition in response to a signal sent from the TCM.

The line pressure duty cycle value is not consistent when the closed throttle position switch is "ON". To confirm the line pressure duty cycle at low pressure, the accelerator (throttle) should be open until the closed throttle position switch is "OFF".

CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

NLAT0061S01

Remarks: Specification data are reference values.

Monitor item	Condition	Specification
Line pressure solenoid valve duty	Small throttle opening (Low line pressure)	Approximately 4%
	↓ Large throttle opening (High line pressure)	↓ Approximately 94%



NOTE:

The line pressure duty cycle value is not consistent when the closed throttle position switch is "ON". To confirm the line pressure duty cycle at low pressure, the accelerator (throttle) should be open until the closed throttle position switch is "OFF".

TCM TERMINALS AND REFERENCE VALUE

NLAT0061S02

Remarks: Specification data are reference values.

Terminal No.	Wire color	Item	Condition	Judgement standard (Approx.)	
1	R/W	Line pressure solenoid valve		When releasing accelerator pedal after warming up engine.	2.8V
				When depressing accelerator pedal fully after warming up engine.	1.4V
2	P/B	Line pressure solenoid valve (with dropping resistor)		When releasing accelerator pedal after warming up engine.	11.0V
				When depressing accelerator pedal fully after warming up engine.	4.0V

ON BOARD DIAGNOSIS LOGIC

NLAT0061S03

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
(P) : L/PRESS SOL/CIRC (SST) : P0745 (NO TOOLS) : MI Code No. 0745	TCM detects an improper voltage drop when it tries to operate the solenoid valve.	<ul style="list-style-type: none"> Harness or connectors (The solenoid circuit is open or shorted.) Line pressure solenoid valve

Description (Cont'd)

SELECT SYSTEM
CVT
ENGINE

SAT250K

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

=NLAT0061S04

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
ACTIVE TEST
DTC & SRT CONFIRMATION
ECM PART NUMBER

SAT255K

With CONSULT-II

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode for "ENGINE" with CONSULT-II.
- 2) Depress accelerator pedal completely and wait at least 5 seconds.
If the check result is "NG", go to "Diagnostic Procedure", AT-102.

With GST

Follow the procedure "With CONSULT-II".

DTC P0745 LINE PRESSURE SOLENOID VALVE




EURO-OB

Wiring Diagram — AT — LPSV

Wiring Diagram — AT — LPSV

NLAT0209

AT-LPSV-01



Diagnostic Procedure


NLAT0062

1	CHECK GROUND CIRCUIT	
1. Turn ignition switch to "OFF" position. 2. Disconnect terminal cord assembly connector in engine compartment. 3. Check resistance between terminal 8 and ground. Resistance: 2.5 - 5Ω <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 2.
NG	▶	Check the following items: <ul style="list-style-type: none"> ● Line pressure solenoid valve Refer to "Component Inspection", AT-103. ● Harness of terminal cord assembly for short or open

2	CHECK POWER SOURCE CIRCUIT	
1. Turn ignition switch to "OFF" position. 2. Disconnect TCM harness connector. 3. Check resistance between terminal 8 and TCM harness connector terminal 2. Resistance: 11.2 - 12.8Ω <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 3.
NG	▶	Check the following items: <ul style="list-style-type: none"> ● Dropping resistor Refer to "Component Inspection", AT-103. ● Harness for short or open between TCM terminal 2 and terminal cord assembly (Main harness)

3	CHECK POWER SOURCE CIRCUIT	
1. Turn ignition switch to "OFF" position. 2. Check continuity between terminal 8 and TCM harness connector terminal 1. Continuity should exist. If OK, check harness for short to ground and short to power. 3. Reinstall any part removed. <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 4.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

4	CHECK DTC	
Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-100. <p style="text-align: center;">OK or NG</p>		
OK	▶	INSPECTION END
NG	▶	1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.



Component Inspection

LINE PRESSURE SOLENOID VALVE

=NLAT0063
NLAT0063S01


- For removal, refer to AT-206.

Resistance Check

NLAT0063S0101

- Check resistance between two terminals.


Solenoid valve	Terminal No.		Resistance (Approx.)
Line pressure solenoid valve	8	Ground of line pressure solenoid valve	2.5 - 5Ω



Operation Check

NLAT0063S0102

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal and ground of line pressure solenoid valve.




DROPPING RESISTOR

NLAT0063S02

- Check resistance between two terminals.

Resistance:
11.2 - 12.8Ω

Description



Description

NLAT0070

- **Throttle position sensor**
The throttle position sensor detects the throttle valve position and sends a signal to the TCM.
- **Throttle position switch**
Consists of a wide open throttle position switch and a closed throttle position switch.
The wide open throttle position switch sends a signal to the TCM when the throttle valve is open at least 1/2 of the full throttle position. The closed throttle position switch sends a signal to the TCM when the throttle valve is fully closed.

CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

NLAT0070S01

Remarks: Specification data are reference values.

Monitor item	Condition	Specification
Throttle position sensor	Fully-closed throttle	Approximately 0.5V
	Fully-open throttle	Approximately 4V

TCM TERMINALS AND REFERENCE VALUE

NLAT0070S02

Remarks: Specification data are reference values.

Terminal No.	Wire color	Item	Condition	Judgement standard (Approx.)
16	Y/PU	Closed throttle position switch (in throttle position switch)	When releasing accelerator pedal after warming up engine. Refer to step 1 to 6 of "Preparation", "TCM Self-diagnostic Procedure (No Tools)", AT-28.	Battery voltage
			When depressing accelerator pedal after warming up engine. Refer to step 1 to 6 of "Preparation", "TCM Self-diagnostic Procedure (No Tools)", AT-28.	0V
17	LG	Wide open throttle position switch (in throttle position switch)	When depressing accelerator pedal more than half-way after warming up engine.	Battery voltage
			When releasing accelerator pedal after warming up engine.	0V
32	R	Throttle position sensor (Power source)	When turning ignition switch to "ON".	4.5 - 5.5V
			When turning ignition switch to "OFF".	0V
41	GY	Throttle position sensor	When depressing accelerator pedal slowly after warming up engine. (Voltage rises gradually in response to throttle position.)	Fully-closed throttle: 0.3V Fully-open throttle: 3V
42	B	Ground (Throttle position sensor)	—	—



DTC P1705 THROTTLE POSITION SENSOR

EURO-OB

Description (Cont'd)

ON BOARD DIAGNOSIS LOGIC

NLAT0070S03

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
(P) : TP SEN/CIRC A/T (GST) : P1705 (HO TOOLS) : MI Code No. 1705	TCM receives an excessively low or high voltage from the sensor.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Throttle position sensor ● Throttle position switch

SELECT SYSTEM
CVT
ENGINE

SAT250K

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NLAT0070S04

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE” has been previously conducted, always turn ignition switch “OFF” and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
TCM PART NUMBER

SAT252K

(P) **With CONSULT-II**

- 1) Turn ignition switch “ON” and select “DATA MONITOR” mode for “CVT” with CONSULT-II.
- 2) Check the following.

Accelerator pedal condition	THRTL POS SEN	CLOSED THL/SW	W/O THRL/P-SW
Fully released	Less than 0.5V	ON	OFF
Partially depressed	0.5 - 1.9V	OFF	OFF
Fully depressed	1.9 - 4.0V	OFF	ON

If the check result is NG, go to “DIAGNOSTIC PROCEDURE”, AT-108.

If the check result is OK, go to following step.

- 3) Turn ignition switch “ON” and select “DATA MONITOR” mode for “ENGINE” with CONSULT-II.
- 4) Start engine and maintain the following conditions for at least 5 consecutive seconds. Then release accelerator pedal completely.

VHCL SPEED SE: 10 km/h (6 MPH) or more
THRTL POSI SEN: Approximately 3V or less
Selector lever: D position

If the check result is NG, go to “DIAGNOSTIC PROCEDURE”, AT-108.

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
ACTIVE TEST
DTC & SRT CONFIRMATION
ECM PART NUMBER

SAT255K

(P) **With GST**

Follow the procedure “With CONSULT-II”.

DTC P1705 THROTTLE POSITION SENSOR

EURO-OBD



Wiring Diagram — AT — TPS

Wiring Diagram — AT — TPS MODELS WITH ECM IN ENGINE COMPARTMENT


NLAT0212

NLAT0212S01

AT-TPS-01



REFER TO THE FOLLOWING.
 (E55), (E57) - FUSE AND FUSIBLE LINK BOX



YAT181

DTC P1705 THROTTLE POSITION SENSOR



EURO-OBD

Wiring Diagram — AT — TPS (Cont'd)

MODELS WITH ECM IN CABIN

NLAT0212S02

AT-TPS-01




YAT217

Diagnostic Procedure

NLAT0071

1	CHECK DTC WITH ECM	
Perform diagnostic test mode II (self-diagnostic results) for engine control. Refer to EC section ["Malfunction Indicator (MI)", "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION"].		
OK or NG		
OK (With CONSULT-II)	▶	GO TO 2.
OK (Without CONSULT-II)	▶	GO TO 3.
NG	▶	Check throttle position sensor circuit for engine control. Refer to EC section ("DTC P0120 THROTTLE POSITION SENSOR").

2	CHECK INPUT SIGNAL (With CONSULT-II)	
Ⓟ With CONSULT-II 1. Turn ignition switch to "ON" position. (Do not start engine.) 2. Select "TCM INPUT SIGNALS" in "DATA MONITOR" mode for "CVT" with CONSULT-II. 3. Read out the value of "THRTL POS SEN". Voltage: Fully-closed throttle: Approximately 0.5V Fully-open throttle: Approximately 4V		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Check harness for short or open between ECM and TCM regarding throttle position sensor circuit. (Main harness)

3	CHECK INPUT SIGNAL (Without CONSULT-II)	
⊗ Without CONSULT-II 1. Turn ignition switch to "ON" position. (Do not start engine.) 2. Check voltage between TCM terminals 41 and 42 while accelerator pedal is depressed slowly. Voltage: Fully-closed throttle valve: Approximately 0.5V Fully-open throttle valve: Approximately 4V (Voltage rises gradually in response to throttle position)		
		
OK or NG		
OK	▶	GO TO 5.
NG	▶	Check harness for short or open between ECM and TCM regarding throttle position sensor circuit. (Main harness)

SAT453J

DTC P1705 THROTTLE POSITION SENSOR

EURO-OB

Diagnostic Procedure (Cont'd)

4		CHECK THROTTLE POSITION SWITCH CIRCUIT (With CONSULT-II)											
<p>Ⓟ With CONSULT-II</p> <ol style="list-style-type: none">1. Refer to steps 1 to 7 of "Preparation", "TCM Self-diagnostic Procedure (No Tools)", AT-28.2. Turn ignition switch to "OFF" position.3. Turn ignition switch to "ON" position. (Do not start engine.)4. Select "TCM INPUT SIGNALS" in "DATA MONITOR" mode for "CVT" with CONSULT-II.5. Read out "CLOSED THL/SW" and "W/O THRL/P-SW" depressing and releasing accelerator pedal. Check the signal of throttle position switch is indicated properly.													
<table border="1"><thead><tr><th rowspan="2">Accelerator pedal condition</th><th colspan="2">Data monitor</th></tr><tr><th>CLOSED THL/SW</th><th>W/O THRL/P-SW</th></tr></thead><tbody><tr><td>Released</td><td>ON</td><td>OFF</td></tr><tr><td>Fully depressed</td><td>OFF</td><td>ON</td></tr></tbody></table>			Accelerator pedal condition	Data monitor		CLOSED THL/SW	W/O THRL/P-SW	Released	ON	OFF	Fully depressed	OFF	ON
Accelerator pedal condition	Data monitor												
	CLOSED THL/SW	W/O THRL/P-SW											
Released	ON	OFF											
Fully depressed	OFF	ON											
MTBL0011													
OK or NG													
OK	▶	GO TO 6.											
NG	▶	Check the following items: <ul style="list-style-type: none">● Throttle position switch — Refer to "Components Inspection", AT-111.● Harness for short or open between ignition switch and throttle position switch (Main harness)● Harness for short or open between throttle position switch and TCM (Main harness)											

DTC P1705 THROTTLE POSITION SENSOR

EURO-OBDD

Diagnostic Procedure (Cont'd)


5 CHECK THROTTLE POSITION SWITCH CIRCUIT (Without CONSULT-II)

⊗ Without CONSULT-II

1. Refer to steps 1 to 7 of "Preparation", "TCM Self-diagnostic Procedure (No Tools)", AT-28.
2. Turn ignition switch to "OFF" position.
3. Turn ignition switch to "ON" position.
(Do not start engine.)
4. Check voltage between TCM terminals 16, 17 and ground while depressing, and releasing accelerator pedal slowly.
(After warming up engine)

Accelerator pedal condition	Voltage	
	Terminal No. 16	Terminal No. 17
Released	Battery voltage	1V or less
Fully depressed	1V or less	Battery voltage

MTBL0137



SAT454JD

OK or NG


OK	▶	GO TO 6.
NG	▶	Check the following items: <ul style="list-style-type: none"> ● Throttle position switch — Refer to "Components Inspection", AT-111. ● Harness for short or open between ignition switch and throttle position switch (Main harness) ● Harness for short or open between throttle position switch and TCM (Main harness)

6 CHECK DTC

Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-105.

OK or NG

OK	▶	INSPECTION END
NG	▶	<ol style="list-style-type: none"> 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.



Component Inspection THROTTLE POSITION SWITCH

=NLAT0072

NLAT0072S01


Closed Throttle Position Switch (Idle position)

NLAT0072S0101

- Check continuity between terminals 4 and 5.
Refer to steps 1 to 6 of "Preparation", "TCM Self-diagnostic Procedure (No Tools)", AT-28.

Accelerator pedal condition	Continuity
Released	Yes
Depressed	No

- To adjust closed throttle position switch, refer to EC section ("Basic Inspection", "TROUBLE DIAGNOSIS — BASIC INSPECTION").



Wide Open Throttle Position Switch

NLAT0072S0102

- Check continuity between terminals 5 and 6.

Accelerator pedal condition	Continuity
Released	No
Depressed	Yes

DTC P1777 STEP MOTOR — CIRCUIT

EURO-OBDD

Description

Description

- The step motor is ON/OFF of 4 aspects changes according to the signal from TCM.
As a result, the flow of line pressure to primary pulley is changed and pulley ratio is controlled.

NLAT0224

CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

Remarks: Specification data are reference values.

NLAT0224S01

Monitor item	Condition	Specification
Step motor	The vehicle runs a safe condition and press/depress accelerator pedal.	ON/OFF

TCM TERMINALS AND REFERENCE VALUE

Remarks: Specification data are reference values.

NLAT0224S02

Terminal No.	Wire color	Item	Condition	Judgement standard (Approx.)
11	PU	Step motor	Within 2 seconds after key switch "ON", the time measurement by using the pulse width measurement function (Hi level) of CONSULT-II. ● CONSULT-II cable connect to data link connector. ● This inspection cannot be measured by circuit tester.	30.0 msec
12	L/W			10.0 msec
20	L/Y			30.0 msec
21	P/L			10.0 msec

ON BOARD DIAGNOSIS LOGIC

NLAT0224S03

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
: STEP MOTOR/CIRC : P1777 : MI Code No. 1777	When in operating step motor ON and OFF, there is no proper change in the voltage of the terminal TCM which corresponds to it.	<ul style="list-style-type: none"> ● Harness or connectors (The step motor circuit is open or shorted.) ● Step motor

DTC P1777 STEP MOTOR — CIRCUIT

EURO-OBD

Description (Cont'd)

SELECT SYSTEM
CVT
ENGINE

SAT250K

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
ACTIVE TEST
DTC & SRT CONFIRMATION
ECM PART NUMBER

SAT255K

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NLAT0224S04

CAUTION:

- Always drive vehicle at a safe speed.
- Be careful not to rev engine into the red zone on the tachometer.

NOTE:

If “DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE” has been previously conducted, always turn ignition switch “OFF” and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II

- 1) Turn ignition switch “ON” and select “DATA MONITOR” mode for “CVT” with CONSULT-II.
- 2) Drive vehicle for at least 5 consecutive seconds.
If the check result is “NG”, go to “Diagnostic Procedure”, AT-115.

With GST

Follow the procedure “With CONSULT-II”.

DTC P1777 STEP MOTOR — CIRCUIT




EURO-OBD

Wiring Diagram — AT — STM

Wiring Diagram — AT — STM

NLAT0225

AT-STM-01



YAT182


Diagnostic Procedure

NLAT0226

1	CHECK POWER SOURCE CIRCUIT
<p>1. Turn ignition switch to "ON" position. 2. Check "SELF-DIAG RESULTS" with CONSULT-II. 3. If "CVT SAFE FUNCTION" activate, refer to "CVT SAFE FUNCTION", AT-125. 4. Turn ignition switch to "OFF" position. 5. Disconnect TCM harness connector. 6. Check continuity between terminal 2, 3, 4, 5 and TCM harness connector terminal 11, 12, 20, 21. Continuity should exist.</p> <div style="text-align: center;"> <p style="text-align: center;">Step motor connector</p> </div> <p style="text-align: right;">SAT655JA</p>	
OK or NG	
OK	▶ GO TO 2.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

2	CHECK DTC
<p>Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-113.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ INSPECTION END
NG	▶ <ol style="list-style-type: none"> 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

Component Inspection



Component Inspection

STEP MOTOR

Resistance Check

- Check resistance between terminals.

=NLAT0227

NLAT0227S01

NLAT0227S0101

Control valve	Terminal No.	Resistance (Approx.)
	2 and 3	28Ω
	4 and 5	
Step motor	2 and ground	14Ω
	3 and ground	
	4 and ground	
	5 and ground	

Description

- The step motor is ON/OFF of 4 aspects changes according to the signal from TCM.
As a result, the flow of line pressure to primary pulley is changed and pulley ratio is controlled.
- This diagnosis item detects when electrical system is OK but, mechanical system is NG.
- This diagnosis item detects when the state that the changing the speed mechanism in unit does not operate normally.

NLAT0228




CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

It is monitoring whether “CVT RATIO: 2.32 - 0.47” changes similarly to “PLY CONT STEP: 3 - 200” by DATA MONITOR mode.

NLAT0228S01

ON BOARD DIAGNOSIS LOGIC

NLAT0228S03

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
 : STEP MOTOR/FNCTN	When not changing the speed according to the instruction of TCM.	<ul style="list-style-type: none"> ● Step motor
 : P1778		
 : MI Code No. 1778		

Description (Cont'd)

SELECT SYSTEM
CVT
ENGINE

SAT250K

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
TCM PART NUMBER

SAT252K

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
ACTIVE TEST
DTC & SRT CONFIRMATION
ECM PART NUMBER

SAT255K

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NLAT0228S04

CAUTION:

- Always drive vehicle at a safe speed.
- Be careful not to rev engine into the red zone on the tachometer.
- Before start “DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE”, confirm “Hi” or “Mid” or “Low” fixation by “I/P PULLY SPD” and “VHCL SPEED SE” on “DATA MONITOR MODE”.
- If hi-gearred fixation, go to diagnostic procedure soon.

NOTE:

If “DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE” has been previously conducted, always turn ignition switch “OFF” and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II

- 1) Turn ignition switch “ON” and select “DATA MONITOR” mode for “CVT” with CONSULT-II.
- 2) Make sure that output voltage of CVT fluid temperature sensor is within the range below.
FLUID TEMP SEN: 0.5 - 1.5V
If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid)
- 3) Select “ENGINE” mode for “ENGINE” with CONSULT-II.
- 4) Start engine and maintain the following conditions for at least 30 consecutive seconds.

TEST START FROM 0 km/h (0 MPH)

CONSTANT ACCELERATION: Keep 30 sec or more

VHCL SPEED SE: 10 km/h (6 MPH) or more

THRTL POS SEN: More than 1.3V

Selector lever: D position

ENG SPEED: 450 rpm or more

If the check result is NG, go to “DIAGNOSTIC PROCEDURE”, AT-118.

With GST

Follow the procedure “With CONSULT-II”.

Diagnostic Procedure

NLAT0230

1	CHECK STEP MOTOR	
	<ul style="list-style-type: none"> ● It is monitoring whether “CVT ratio: 2.32 - 0.47” changes similarly to “PLY CONT STEP: -3 - 200” by DATA MONITOR mode. ● If no CONSULT-II, inspect the engine speed (rise and descend) about vehicle speed and throttle opening angle, and check shift change. 	
	OK or NG	
OK	▶	INSPECTION END
NG	▶	Replace CVT assembly.

DTC P1791 LINE PRESSURE SENSOR

EURO-OB

Description

Description

- The line pressure sensor detects line pressure of CVT, and sends TCM the signal. NLAT0232





CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

Remarks: Specification data are reference values. NLAT0232S01

Monitor item	Condition	Specification
Line pressure sensor	Throttle valve fully closed (PL Duty: 4%)	Approx. 1.0V
	↓ Throttle valve fully depressed (PL Duty: 94%)	↓ Approx. 4.0V




TCM TERMINALS AND REFERENCE VALUE

Remarks: Specification data are reference values. NLAT0232S02

Terminal No.	Wire color	Item	Condition	Judgement standard (Approx.)	
37	W	Line pressure sensor		When engine runs at idle speed.	1.0V
				When engine runs at stall speed.	4.0V
42	B			—	—
46	R/L			—	4.5 - 5.5V

ON BOARD DIAGNOSIS LOGIC

NLAT0232S03

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
 : LINE PRESS SEN  : P1791  : MI Code No. 1791	TCM receives an excessively low or high voltage from the step motor.	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Line pressure sensor

Description (Cont'd)

SELECT SYSTEM
CVT
ENGINE

SAT250K

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
TCM PART NUMBER

SAT252K

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
ACTIVE TEST
DTC & SRT CONFIRMATION
ECM PART NUMBER

SAT255K

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NLAT0232S04

CAUTION:

- Always drive vehicle at a safe speed.
- Be careful not to rev engine into the red zone on the tachometer.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode for "CVT" with CONSULT-II.
- 2) Make sure that output voltage of line temperature sensor is within the range below.
FLUID TEMP SEN: 0.5 - 1.5V
If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid)
- 3) Select "DATA MONITOR" mode for "ENGINE" with CONSULT-II.
- 4) Start engine and maintain the following conditions for at least 5 consecutive seconds.

VHCL SPEED SE: 10 km/h (6 MPH) or more

THRTL POS SEN: 1.3V

Selector lever: D position

ENG SPEED: 450 rpm or more

If the check result is NG, go to "Diagnostic Procedure", AT-123.

With GST

Follow the procedure "With CONSULT-II".

DTC P1791 LINE PRESSURE SENSOR

EURO-OB

Wiring Diagram — AT — LPS




Wiring Diagram — AT — LPS

MODELS WITH ECM IN ENGINE COMPARTMENT

NLAT0233

NLAT0233S01

AT-LPS-01



DTC P1791 LINE PRESSURE SENSOR

EURO-OBD



Wiring Diagram — AT — LPS (Cont'd)

MODELS WITH ECM IN CABIN

NLAT0233S02

AT-LPS-01

: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC



YAT218

Diagnostic Procedure

NLAT0234


1	CHECK PRESSURE SENSOR	
Refer to "Component Inspection", AT-124.		
OK or NG		
OK (With CONSULT-II)	▶	GO TO 2.
OK (Without CONSULT-II)	▶	GO TO 3.
NG	▶	Repair or replace pressure sensor.

2	CHECK INPUT SIGNAL (With CONSULT-II)	
<p>Ⓜ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine. 2. Select "TCM input signals" in "DATA MONITOR" mode for "CVT" with CONSULT-II. 3. Read out the value of "LINE PRES SEN" while driving. <ul style="list-style-type: none"> ● Throttle valve fully closed (PL Duty: 4%): Approx. 1.0V ● Throttle valve fully depressed (PL Duty: 94%): Approx. 4.0V 		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Check the following items: <ul style="list-style-type: none"> ● Harness for short or open between TCM, ECM and line pressure sensor (Main harness) ● Ground circuit for ECM Refer to EC section ("TROUBLE DIAGNOSIS FOR POWER SUPPLY").

3	CHECK INPUT SIGNAL (Without CONSULT-II)	
<p>ⓧ Without CONSULT-II</p> Refer to "Component Inspection", AT-124.		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Check the following items: <ul style="list-style-type: none"> ● Harness for short or open between TCM, ECM and line pressure sensor (Main harness). ● Ground circuit for ECM Refer to EC section ("TROUBLE DIAGNOSIS FOR POWER SUPPLY").

4	CHECK DTC	
Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-120.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	<ol style="list-style-type: none"> 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

Component Inspection



Component Inspection LINE PRESSURE SENSOR

=NLAT0235

NLAT0235S01

- Start engine.
- Check voltage between terminals 1 and 6, 6 and 10.

Terminal No.		Voltage
1	6	Approx. 0.5 - 4.5V
10	6	Approx. 4.5 - 5.5V

CVT SAFE FUNCTION

Description

Description




“CVT SAFE FUNCTION” is function to protect CVT.

NLAT0249

ON BOARD DIAGNOSIS LOGIC

NLAT0249S01

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
(P) : CVT SAFE FUNCTION (X) : 10th judgement flicker	TCM is malfunctioning	TCM



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NLAT0249S02

(P) With CONSULT-II

- 1) Turn ignition switch “ON” and select “DATA MONITOR” mode for CVT with CONSULT-II.
- 2) Start engine.
- 3) Run engine for at least 2 seconds at idle speed.

(X) Without CONSULT-II

- 1) Start engine.
- 2) Perform self-diagnosis. Refer to TCM Self-diagnostic Procedure (No Tools), AT-28 — EURO-OBD/AT-35, Except for EURO-OBD.

Diagnostic Procedure

NLAT0250

1	CHECK INPUT SIGNAL (With CONSULT-II)	
	1. Turn ignition switch to “ON” and select “SELF-DIAG RESULTS” mode for CVT with CONSULT-II. 2. Touch “ERASE”. Perform “DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE” above.	
	Is the “CVT SAFE FUNCTION” displayed again?	
OK	▶	Replace TCM.
NG	▶	INSPECTION END

VEHICLE SPEED SENSOR CVT (SECONDARY SPEED SENSOR)

EXCEPT FOR EURO-OB

Description



Description

The vehicle speed sensor CVT (secondary speed sensor) detects the revolution of the idler gear parking pawl lock gear and emits a pulse signal. The pulse signal is sent to the TCM which converts it into vehicle speed. NLAT0251

TCM TERMINALS AND REFERENCE VALUE

NLAT0251S01

Remarks: Specification data are reference values.

Terminal No.	Wire color	Item	Condition	Judgement standard (Approx.)
29	G/R	Secondary speed sensor		600 Hz
			<p>When moving at 20 km/h (12 MPH), use the CONSULT-II pulse frequency measuring function.*1</p> <p>CAUTION: Connect the diagnosis data link cable to the vehicle diagnosis connector.</p> <p>*1: A circuit tester cannot be used to test this item.</p>	
42	B	Throttle position sensor (Ground)		—

ON BOARD DIAGNOSIS LOGIC



NLAT0251S02

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
<p>Ⓟ : O/P PULLY SPD SIG</p> <p>ⓧ : 1st judgement flicker</p>	TCM does not receive the proper voltage signal from the sensor.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Revolution sensor

VEHICLE SPEED SENSOR CVT (SECONDARY SPEED SENSOR)

EXCEPT FOR EURO-OB

Description (Cont'd)



SELF-DIAGNOSIS CODE CONFIRMATION PROCEDURE

NLAT0251S03

After the repair, perform the following procedure to confirm the malfunction is eliminated.

④ With CONSULT-II

NLAT0251S0301

- 1) Start engine.
- 2) Select "SELF-DIAG RESULTS" mode for CVT with CONSULT-II.
- 3) Drive vehicle under the following conditions:
Selector lever in "D" position, vehicle speed higher than 30 km/h (19 MPH), throttle opening greater than 1/8 of the full throttle position and driving for more than 5 seconds.

⊗ Without CONSULT-II

NLAT0251S0302

- 1) Start engine.
- 2) Drive vehicle under the following conditions:
Selector lever in "D" position, vehicle speed higher than 30 km/h (19 MPH), throttle opening greater than 1/8 of the full throttle position and driving for more than 5 seconds.
- 3) Perform self-diagnosis.
Refer to "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II)", AT-35.

VEHICLE SPEED SENSOR CVT (SECONDARY SPEED SENSOR)

EXCEPT FOR EURO-OBD

Wiring Diagram — AT — VSSA/T




Wiring Diagram — AT — VSSA/T

MODELS WITH ECM IN ENGINE COMPARTMENT

NLAT0252

NLAT0252S01

AT-VSSAT-01



YAT177

VEHICLE SPEED SENSOR CVT (SECONDARY SPEED SENSOR)



EXCEPT FOR EURO-OBD

Wiring Diagram — AT — VSSA/T (Cont'd)

MODELS WITH ECM IN CABIN

NLAT0252S02

AT-VSSAT-01



YAT216

VEHICLE SPEED SENSOR CVT (SECONDARY SPEED SENSOR)

EXCEPT FOR EURO-OB

Diagnostic Procedure

Diagnostic Procedure

NLAT0253

1	CHECK INPUT SIGNAL (With CONSULT-II)																							
<p>Ⓟ With CONSULT-II</p> <p>1. Start engine.</p> <p>2. Select "TCM INPUT SIGNALS" in "DATA MONITOR" mode for "CVT" with CONSULT-II.</p>																								
<table border="1" style="margin: auto; border-collapse: collapse;"> <tr><td style="text-align: center;">SELECT SYSTEM</td></tr> <tr><td style="text-align: center;">CVT</td></tr> <tr><td style="text-align: center;">ENGINE</td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;"> </td></tr> </table>			SELECT SYSTEM	CVT	ENGINE																			
SELECT SYSTEM																								
CVT																								
ENGINE																								
<p>3. Read out the value of "VEHICLE SPEED" while driving. Check the value changes according to driving speed.</p>																								
<table border="1" style="margin: auto; border-collapse: collapse;"> <tr><td colspan="2" style="text-align: center;">DATA MONITOR</td></tr> <tr> <td style="text-align: center;">MONITOR</td> <td style="text-align: center;">NO DTC</td> </tr> <tr> <td>VEHICLE SPEED</td> <td>XXX km/h</td> </tr> <tr> <td>THROTTLE POSI</td> <td>XXX</td> </tr> <tr> <td>SLCTLVR POSI</td> <td>NP</td> </tr> <tr> <td>ENGINE SPEED</td> <td>XXX rpm</td> </tr> <tr> <td>I/P PULLY SPD</td> <td>XXX rpm</td> </tr> <tr> <td>CVT RATIO</td> <td>XXX</td> </tr> <tr> <td>PLY CONT STEP</td> <td>XXX step</td> </tr> <tr> <td>LINE PRES DTY</td> <td>XXX%</td> </tr> <tr> <td>TCC S/V DUTY</td> <td>XXX%</td> </tr> </table>			DATA MONITOR		MONITOR	NO DTC	VEHICLE SPEED	XXX km/h	THROTTLE POSI	XXX	SLCTLVR POSI	NP	ENGINE SPEED	XXX rpm	I/P PULLY SPD	XXX rpm	CVT RATIO	XXX	PLY CONT STEP	XXX step	LINE PRES DTY	XXX%	TCC S/V DUTY	XXX%
DATA MONITOR																								
MONITOR	NO DTC																							
VEHICLE SPEED	XXX km/h																							
THROTTLE POSI	XXX																							
SLCTLVR POSI	NP																							
ENGINE SPEED	XXX rpm																							
I/P PULLY SPD	XXX rpm																							
CVT RATIO	XXX																							
PLY CONT STEP	XXX step																							
LINE PRES DTY	XXX%																							
TCC S/V DUTY	XXX%																							
OK or NG																								
OK	▶	GO TO 3.																						
NG	▶	GO TO 2.																						

SAT250K

SAT236K

2	CHECK SECONDARY SPEED SENSOR (With CONSULT-II)					
<p>Ⓟ With CONSULT-II</p> <p>1. Start engine.</p>						
<table border="1" style="margin: auto; border-collapse: collapse;"> <tr> <td style="width: 70%; text-align: center;">Condition</td> <td style="text-align: center;">Judgement standard (Approx.)</td> </tr> <tr> <td style="text-align: center;"> When driving (D position, 20km/h), the measurement by using the pulse measurement function of CONSULT-II. <ul style="list-style-type: none"> • CONSULT-II cable connected to data link connector. • This inspection cannot be measured by circuit tester. </td> <td style="text-align: center; vertical-align: middle;">600 Hz</td> </tr> </table>			Condition	Judgement standard (Approx.)	When driving (D position, 20km/h), the measurement by using the pulse measurement function of CONSULT-II. <ul style="list-style-type: none"> • CONSULT-II cable connected to data link connector. • This inspection cannot be measured by circuit tester. 	600 Hz
Condition	Judgement standard (Approx.)					
When driving (D position, 20km/h), the measurement by using the pulse measurement function of CONSULT-II. <ul style="list-style-type: none"> • CONSULT-II cable connected to data link connector. • This inspection cannot be measured by circuit tester. 	600 Hz					
<p>• Harness for short or open between TCM and secondary speed sensor (Main harness)</p>						
OK or NG						
OK	▶	GO TO 3.				
NG	▶	Repair or replace damaged parts.				

MTBL0550

VEHICLE SPEED SENSOR CVT (SECONDARY SPEED SENSOR)

EXCEPT FOR EURO-OBD

Diagnostic Procedure (Cont'd)

3	CHECK DTC
Perform Self-diagnosis Code confirmation procedure, AT-127.	
OK or NG	
OK	▶ INSPECTION END
NG	▶ GO TO 4.

4	CHECK TCM INSPECTION
1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.	
OK or NG	
OK	▶ INSPECTION END
NG	▶ Repair or replace damaged parts.

PRIMARY SPEED SENSOR

EXCEPT FOR EURO-OB

Description


Description

The primary speed sensor detects the primary pulley revolution speed and sends a signal to the ECM. NLAT0254

TCM TERMINALS AND REFERENCE VALUE



Remarks: Specification data are reference values.


NLAT0254S01

Terminal No.	Wire color	Item	Condition	Judgement standard (Approx.)
38	G/Y	Primary speed sensor	 <ul style="list-style-type: none">When driving at 20 km/h (12 MPH) with "L" position, use the CONSULT-II pulse frequency measuring function*. <p>CAUTION: Connect the diagnosis data link cable to the vehicle diagnosis connector.</p> <p>*: A circuit tester cannot be used to test this item.</p>	900 Hz

ON BOARD DIAGNOSIS LOGIC

NLAT0254S02

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
 : I/P PULLY SPD	TCM does not receive the proper voltage signal from the sensor.	<ul style="list-style-type: none">Harness or connectors (The sensor circuit is open or shorted.)Vehicle speed sensor
 : 2nd judgement flicker		



SELF-DIAGNOSIS CODE CONFIRMATION PROCEDURE

NLAT0254S03

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II


NLAT0254S0301

- 1) Start engine.
- 2) Select "SELF-DIAG RESULTS" mode for CVT with CONSULT-II.
- 3) Drive vehicle under the following conditions:
Selector lever in "D" position and vehicle speed higher than 20 km/h (12 MPH).

Without CONSULT-II

NLAT0254S0302

- 1) Start engine.
- 2) Drive vehicle under the following conditions:
Selector lever in "D" position and vehicle speed higher than 20 km/h (12 MPH).
- 3) Perform self-diagnosis.
Refer to "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II)", AT-35.



PRIMARY SPEED SENSOR

EXCEPT FOR EURO-OBD



Wiring Diagram — AT — VSSMTR

Wiring Diagram — AT — VSSMTR MODELS WITH ECM IN ENGINE COMPARTMENT

NLAT0255

NLAT0255S01

AT-PSSAT-01



PRIMARY SPEED SENSOR



EXCEPT FOR EURO-OB

Wiring Diagram — AT — VSSMTR (Cont'd)

MODELS WITH ECM IN CABIN

NLAT0255S02

AT-PSSAT-01



YAT215

Diagnostic Procedure

NLAT0256

1 CHECK INPUT SIGNAL

With CONSULT-II


1. Start engine.
2. Select "TCM INPUT SIGNALS" in "DATA MONITOR" mode for "CVT" with CONSULT-II.
3. Read out the value of "I/P PULLY SPD" while driving.
Check the value changes according to driving speed.

DATA MONITOR	
MONITOR	NO DTC
VEHICLE SPEED	XXX km/h
THROTTLE POSI	XXX
SLCTLVR POSI	NP
ENGINE SPEED	XXX rpm
I/P PULLY SPD	XXX rpm
CVT RATIO	XXX
PLY CONT STEP	XXX step
LINE PRES DTY	XXX%
TCC S/V DUTY	XXX%

SAT236K

Without CONSULT-II

1. Start engine.
2. Check voltage between TCM terminal 38 and ground while driving at 20 km/h (12 MPH).
Approx. 900 Hz



SAT263K

OK or NG

OK	▶	GO TO 2.
NG	▶	Check the following items: <ul style="list-style-type: none"> ● Harness for short or open between TCM, ECM and primary speed sensor (Main harness) ● Ground circuit for ECM Refer to EC section ("TROUBLE DIAGNOSIS FOR POWER SUPPLY").

2 CHECK DTC

Perform Self-diagnosis Code confirmation procedure, AT-133.


OK or NG

OK	▶	INSPECTION END
NG	▶	<ol style="list-style-type: none"> 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

THROTTLE POSITION SENSOR

EXCEPT FOR EURO-OB

Description



Description

NLAT0257

- Throttle position sensor
The throttle position sensor detects the throttle valve position and sends a signal to the TCM.
- Throttle position switch
Consists of a wide open throttle position switch and a closed throttle position switch.
The wide open throttle position switch sends a signal to the TCM when the throttle valve is open at least 1/2 of the full throttle position. The closed throttle position switch sends a signal to the TCM when the throttle valve is fully closed.

CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

NLAT0257S01

Remarks: Specification data are reference values.

Monitor item	Condition	Specification
Throttle position sensor	Fully-closed throttle	Approximately 0.5V
	Fully-open throttle	Approximately 4V

TCM TERMINALS AND REFERENCE VALUE

NLAT0257S02

Remarks: Specification data are reference values.

Terminal No.	Wire color	Item	Condition	Judgement standard (Approx.)
16	Y/PU	Closed throttle position switch (in throttle position switch)	When releasing accelerator pedal after warming up engine. Refer to "Preparation", "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II)", AT-35.	Battery voltage
			When depressing accelerator pedal after warming up engine. Refer to "Preparation", "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II)", AT-35.	0V
17	LG	Wide open throttle position switch (in throttle position switch)	When depressing accelerator pedal more than half-way after warming up engine.	Battery voltage
			When releasing accelerator pedal after warming up engine.	0V
32	R	Throttle position sensor (Power source)	When turning ignition switch to "ON".	4.5 - 5.5V
			When turning ignition switch to "OFF".	0V
41	GY	Throttle position sensor	When depressing accelerator pedal slowly after warming up engine. (Voltage rises gradually in response to throttle position.)	Fully-closed throttle: 0.3V Fully-open throttle: 3V
42	B	Ground (Throttle position sensor)	—	—




Description (Cont'd)

ON BOARD DIAGNOSIS LOGIC

NLAT0257S03

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
P : THROTTLE POSI SEN X : 3rd judgement flicker	TCM receives an excessively low or high voltage from the sensor.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Throttle position sensor ● Throttle position switch



SELF-DIAGNOSIS CODE CONFIRMATION PROCEDURE

NLAT0257S04

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II


NLAT0257S0401

- 1) Start engine.
- 2) Select "SELF-DIAG RESULTS" mode for CVT with CONSULT-II.
- 3) Drive vehicle under the following conditions:
Selector lever in "D" position, vehicle speed higher than 10 km/h (6 MPH), throttle opening greater than 1/2 of the full throttle position and driving for more than 3 seconds.

Without CONSULT-II

NLAT0257S0402

- 1) Start engine.
- 2) Drive vehicle under the following conditions:
Selector lever in "D" position, vehicle speed higher than 10 km/h (6 MPH), throttle opening greater than 1/2 of the full throttle position and driving for more than 3 seconds.
- 3) Perform self-diagnosis.
Refer to "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II)", AT-35.



THROTTLE POSITION SENSOR

EXCEPT FOR EURO-OBD

Wiring Diagram — AT — TPS



Wiring Diagram — AT — TPS

MODELS WITH ECM IN ENGINE COMPARTMENT

NLAT0258


NLAT0258S01

AT-TPS-01



REFER TO THE FOLLOWING.

E55, E57 - FUSE AND FUSIBLE LINK BOX



YAT181





THROTTLE POSITION SENSOR EXCEPT FOR EURO-OBD

Wiring Diagram — AT — TPS (Cont'd)

MODELS WITH ECM IN CABIN

NLAT0258S02

AT-TPS-01



YAT217

Diagnostic Procedure

NLAT0259

1	CHECK DTC WITH ECM	
Perform diagnostic test mode II (self-diagnostic results) for engine control. Refer to EC SECTION , "Malfunction Indicator (MI)", "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION".		
OK or NG		
OK (With CONSULT-II)	▶	GO TO 2.
OK (Without CONSULT-II)	▶	GO TO 3.
NG	▶	Check throttle position sensor circuit for engine control. Refer to EC section , "DTC P0120 THROTTLE POSITION SENSOR".

2	CHECK INPUT SIGNAL (WITH CONSULT-II)																							
Ⓟ With CONSULT-II 1. Apply vacuum to the throttle opener then check the following. Refer from step 1 to 5 of "Preparation", "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II)", AT-35. 2. Turn ignition switch to "ON" position. (Do not start engine.) 3. Select "TCM INPUT SIGNALS" in "DATA MONITOR" mode for "CVT" with CONSULT-II.																								
<table border="1" style="margin: auto; border-collapse: collapse;"> <tr><td style="text-align: center;">SELECT SYSTEM</td></tr> <tr><td style="text-align: center;">CVT</td></tr> <tr><td style="text-align: center;">ENGINE</td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;"> </td></tr> </table>			SELECT SYSTEM	CVT	ENGINE																			
SELECT SYSTEM																								
CVT																								
ENGINE																								
4. Read out the value of "THRTL POSI SEN". Voltage: Fully-closed throttle: Approximately 0.5V Fully-open throttle: Approximately 4V																								
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr><th colspan="2">DATA MONITOR</th></tr> <tr><th>MONITOR</th><th>NO DTC</th></tr> </thead> <tbody> <tr><td>VEHICLE SPEED</td><td>XXX km/h</td></tr> <tr><td>THROTTLE POSI</td><td>XXX</td></tr> <tr><td>SLCTLVR POSI</td><td>NP</td></tr> <tr><td>ENGINE SPEED</td><td>XXX rpm</td></tr> <tr><td>I/P PULLY SPD</td><td>XXX rpm</td></tr> <tr><td>CVT RATIO</td><td>XXX</td></tr> <tr><td>PLY CONT STEP</td><td>XXX step</td></tr> <tr><td>LINE PRES DTY</td><td>XXX%</td></tr> <tr><td>TCC S/V DUTY</td><td>XXX%</td></tr> </tbody> </table>			DATA MONITOR		MONITOR	NO DTC	VEHICLE SPEED	XXX km/h	THROTTLE POSI	XXX	SLCTLVR POSI	NP	ENGINE SPEED	XXX rpm	I/P PULLY SPD	XXX rpm	CVT RATIO	XXX	PLY CONT STEP	XXX step	LINE PRES DTY	XXX%	TCC S/V DUTY	XXX%
DATA MONITOR																								
MONITOR	NO DTC																							
VEHICLE SPEED	XXX km/h																							
THROTTLE POSI	XXX																							
SLCTLVR POSI	NP																							
ENGINE SPEED	XXX rpm																							
I/P PULLY SPD	XXX rpm																							
CVT RATIO	XXX																							
PLY CONT STEP	XXX step																							
LINE PRES DTY	XXX%																							
TCC S/V DUTY	XXX%																							
OK or NG																								
OK	▶	GO TO 4.																						
NG	▶	Check harness for short or open between ECM and TCM regarding throttle position sensor circuit. (Main harness)																						


SAT250K

SAT236K

THROTTLE POSITION SENSOR

EXCEPT FOR EURO-OB

Diagnostic Procedure (Cont'd)

3	CHECK INPUT SIGNAL (WITHOUT CONSULT-II)	
<p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Apply vacuum to the throttle opener then check the following. Refer to steps 1 to 5 of "Preparation", "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II)", AT-35. 2. Turn ignition switch to "ON" position. (Do not start engine.) 3. Check voltage between TCM terminals 41 and 42 while accelerator pedal is depressed slowly. <p style="margin-left: 20px;">Voltage:</p> <p style="margin-left: 40px;">Fully-closed throttle valve: Approximately 0.5V</p> <p style="margin-left: 40px;">Fully-open throttle valve: Approximately 4V</p> <p>(Voltage rises gradually in response to throttle position)</p> <div style="text-align: center; margin: 20px 0;">  </div> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 5.
NG	▶	Check harness for short or open between ECM and TCM regarding throttle position sensor circuit. (Main harness)

SAT453J

THROTTLE POSITION SENSOR

EXCEPT FOR EURO-OB

Diagnostic Procedure (Cont'd)

4	CHECK THROTTLE POSITION SWITCH CIRCUIT (WITH CONSULT-II)																							
<p>Ⓟ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Apply vacuum to the throttle opener, then check the following. Refer to steps 1 to 5 of "Preparation", "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II)", AT-35. 2. Turn ignition switch to "ON" position. (Do not start engine.) 3. Select "TCM INPUT SIGNALS" in "DATA MONITOR" mode for "CVT" with CONSULT-II. 4. Read out "CLOSED THL/SW" and "W/O THRL/P-SW" depressing and releasing accelerator pedal. Check the signal of throttle position switch is indicated properly. 																								
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2" style="padding: 5px;">Accelerator pedal condition</th> <th colspan="2" style="padding: 5px;">Data monitor</th> </tr> <tr> <th style="padding: 5px;">CLOSED THL/SW</th> <th style="padding: 5px;">W/O THRL/P-SW</th> </tr> </thead> <tbody> <tr> <td style="padding: 5px;">Released</td> <td style="padding: 5px; text-align: center;">ON</td> <td style="padding: 5px; text-align: center;">OFF</td> </tr> <tr> <td style="padding: 5px;">Fully depressed</td> <td style="padding: 5px; text-align: center;">OFF</td> <td style="padding: 5px; text-align: center;">ON</td> </tr> </tbody> </table>			Accelerator pedal condition	Data monitor		CLOSED THL/SW	W/O THRL/P-SW	Released	ON	OFF	Fully depressed	OFF	ON											
Accelerator pedal condition	Data monitor																							
	CLOSED THL/SW	W/O THRL/P-SW																						
Released	ON	OFF																						
Fully depressed	OFF	ON																						
MTBL0011																								
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="padding: 5px;">DATA MONITOR</th> </tr> <tr> <th style="padding: 5px;">MONITOR</th> <th style="padding: 5px;">NO DTC</th> </tr> </thead> <tbody> <tr><td style="padding: 2px 5px;">L POSITION SW</td><td style="padding: 2px 5px; text-align: center;">OFF</td></tr> <tr><td style="padding: 2px 5px;">D POSITION SW</td><td style="padding: 2px 5px; text-align: center;">OFF</td></tr> <tr><td style="padding: 2px 5px;">N POSITION SW</td><td style="padding: 2px 5px; text-align: center;">ON</td></tr> <tr><td style="padding: 2px 5px;">R POSITION SW</td><td style="padding: 2px 5px; text-align: center;">OFF</td></tr> <tr><td style="padding: 2px 5px;">S POSITION SW</td><td style="padding: 2px 5px; text-align: center;">OFF</td></tr> <tr><td style="padding: 2px 5px;">CLOSED THL/SW</td><td style="padding: 2px 5px; text-align: center;">ON</td></tr> <tr><td style="padding: 2px 5px;">W/O THRL/P-SW</td><td style="padding: 2px 5px; text-align: center;">OFF</td></tr> <tr><td style="padding: 2px 5px;">BRAKE SW</td><td style="padding: 2px 5px; text-align: center;">ON</td></tr> <tr><td style="padding: 2px 5px;">ABS SIGNAL</td><td style="padding: 2px 5px; text-align: center;">OFF</td></tr> </tbody> </table>			DATA MONITOR		MONITOR	NO DTC	L POSITION SW	OFF	D POSITION SW	OFF	N POSITION SW	ON	R POSITION SW	OFF	S POSITION SW	OFF	CLOSED THL/SW	ON	W/O THRL/P-SW	OFF	BRAKE SW	ON	ABS SIGNAL	OFF
DATA MONITOR																								
MONITOR	NO DTC																							
L POSITION SW	OFF																							
D POSITION SW	OFF																							
N POSITION SW	ON																							
R POSITION SW	OFF																							
S POSITION SW	OFF																							
CLOSED THL/SW	ON																							
W/O THRL/P-SW	OFF																							
BRAKE SW	ON																							
ABS SIGNAL	OFF																							
SAT264K																								
OK or NG																								
OK	▶	GO TO 6.																						
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Throttle position switch — Refer to "Components Inspection", AT-145. ● Harness for short or open between ignition switch and throttle position switch (Main harness) ● Harness for short or open between throttle position switch and TCM (Main harness) 																						

THROTTLE POSITION SENSOR

EXCEPT FOR EURO-OB

Diagnostic Procedure (Cont'd)


5 CHECK THROTTLE POSITION SWITCH CIRCUIT (WITHOUT CONSULT-II)

⊗ Without CONSULT-II

1. Apply vacuum to the throttle opener, then check the following. Refer to steps 1 to 5 of "Preparation", "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II)", AT-35.
2. Turn ignition switch to "ON" position.
(Do not start engine.)
3. Check voltage between TCM terminals 16, 17 and ground while depressing, and releasing accelerator pedal slowly.
(After warming up engine)

Accelerator pedal condition	Voltage	
	Terminal No. 16	Terminal No. 17
Released	Battery voltage	1V or less
Fully depressed	1V or less	Battery voltage

MTBL0137



SAT454JA

OK or NG


OK	▶	GO TO 6.
NG	▶	Check the following items: <ul style="list-style-type: none"> Throttle position switch — Refer to "Components Inspection", AT-145. Harness for short or open between ignition switch and throttle position switch (Main harness) Harness for short or open between throttle position switch and TCM (Main harness)

6 CHECK DTC

Perform Self-diagnosis Code confirmation procedure, AT-138.

OK or NG

OK	▶	INSPECTION END
NG	▶	<ol style="list-style-type: none"> 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.



Component Inspection

THROTTLE POSITION SWITCH

=NLAT0260

NLAT0260S01


Closed Throttle Position Switch (Idle position)

NLAT0260S0101

- Check continuity between terminals 4 and 5. [Refer to "Preparation", "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II)", AT-35.]

Accelerator pedal condition	Continuity
Released	Yes
Depressed	No

- To adjust closed throttle position switch, refer to EC section, ("Basic Inspection", "TROUBLE DIAGNOSIS — BASIC INSPECTION".)



Wide Open Throttle Position Switch

NLAT0260S0102

- Check continuity between terminals 5 and 6.

Accelerator pedal condition	Continuity
Released	No
Depressed	Yes

STEPPING MOTOR — CIRCUIT

EXCEPT FOR EURO-OB

Description

Description

The step motor is turned ON/OFF 4 times according to the signal from TCM. As a result, the flow of line pressure to primary pulley is changed and pulley ratio is controlled.

NLAT0261

CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

NLAT0261S05

Remarks: Specification data are reference values.

Monitor item	Condition	Specification
Step motor	The vehicle runs a safe condition and press/depress accelerator pedal.	ON/OFF

TCM TERMINALS AND REFERENCE VALUE

NLAT0261S01



Remarks: Specification data are reference values.

Terminal No.	Wire color	Item	Condition	Judgement standard (Approx.)
11	PU	Step motor	Within 2 seconds after key switch "ON", the time measurement by using the pulse width measurement function (Hi level) of CONSULT-II. <ul style="list-style-type: none"> CONSULT-II cable connect to data link connector. This inspection cannot be measured by circuit tester. 	30.0 msec
12	L/W			10.0 msec
20	L/Y			30.0 msec
21	P/L			10.0 msec

ON BOARD DIAGNOSIS LOGIC

NLAT0261S02

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
<p> : STEP MOTOR</p> <p> : 4th judgement flicker</p>	TCM detects an improper voltage drop when it tries to operate the solenoid valve.	<ul style="list-style-type: none"> Harness or connectors (The solenoid circuit is open or shorted.) Stepping motor circuit



SELF-DIAGNOSIS CODE CONFIRMATION PROCEDURE

NLAT0261S03

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II

NLAT0261S0301

- 1) Start engine.
- 2) Select "SELF-DIAG RESULTS" mode for CVT with CONSULT-II.
- 3) Drive vehicle in D position.

Without CONSULT-II

NLAT0261S0302

- 1) Start engine.
- 2) Drive vehicle in D position.
- 3) Perform self-diagnosis. Refer to "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II)", AT-35.

STEPPING MOTOR — CIRCUIT




EXCEPT FOR EURO-OB

Wiring Diagram — AT — STM

Wiring Diagram — AT — STM

NLAT0262

AT-STM-01




Diagnostic Procedure

NLAT0265

1	CHECK POWER SOURCE CIRCUIT
<ol style="list-style-type: none"> 1. Turn ignition switch to "ON" position. 2. Check "SELF-DIAG RESULTS" with CONSULT-II. 3. If "CVT SAFE FUNCTION" activate, refer to "CVT SAFE FUNCTION", AT-125. 4. Turn ignition switch to "OFF" position. 5. Disconnect TCM harness connector. 6. Check continuity between terminal 2, 3, 4, 5 and TCM harness connector terminal 11, 12, 20, 21. <p style="margin-left: 20px;">Continuity should exist.</p> <div style="text-align: center;"> <p style="text-align: center;">Step motor connector</p> </div> <p style="text-align: right;">SAT655JA</p>	
<p>If OK, check harness for short to ground and short to power.</p> <p>7. Reinstall any part removed.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 2.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

2	CHECK DTC
<p>Perform "SELF-DIAGNOSIS CODE CONFIRMATION PROCEDURE", AT-146.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ INSPECTION END
NG	▶ <ol style="list-style-type: none"> 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.



Component Inspection

STEP MOTOR

Resistance Check

- Check resistance between terminals.

=NLAT0266

NLAT0266S01

NLAT0266S0101

Control valve	Terminal No.	Resistance (Approx.)
Step motor	2 and 3	28Ω
	4 and 5	
Step motor	2 and ground	14Ω
	3 and ground	
	4 and ground	
	5 and ground	

STEP MOTOR — FUNCTION

EXCEPT FOR EURO-OB

Description

Description

- The step motor is ON/OFF of 4 aspects changes according to the signal from TCM. NLAT0267
As a result, the flow of line pressure to primary pulley is changed and pulley ratio is controlled.
- This diagnosis item detects when electrical system is OK but, mechanical system is NG.
- This diagnosis item detects when the state that the changing the speed mechanism in unit does not operate normally.


CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

It is monitoring whether “CVT RATIO: 2.32 - 0.47” changes similarly to “PLY CONT STEP: 3 - 200” by DATA MONITOR mode. NLAT0267S01

ON BOARD DIAGNOSIS LOGIC

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
Ⓟ : STEP MOTOR/FNCTN*	<ul style="list-style-type: none"> ● Step motor is not operating according to the TCM. 	<ul style="list-style-type: none"> ● Step motor

*: This detected item is according to the “SELF-DIAG RESULTS” for “ENGINE” on CONSULT-II.



SELF-DIAGNOSIS CODE CONFIRMATION PROCEDURE

After the repair, perform the following procedure to confirm the malfunction is eliminated. NLAT0267S05

Ⓟ With CONSULT-II

- 1) Start engine. NLAT0267S0501
- 2) Select “SELF-DIAG RESULTS” mode for ENGINE with CONSULT-II.
- 3) Drive vehicle in D position.

Diagnostic Procedure

1	CHECK STEP MOTOR	
	<ul style="list-style-type: none"> ● It is monitoring whether “CVT ratio: 2.32 - 0.47” changes similarly to “PLY CONT STEP: -3 - 200” by DATA MONITOR mode. ● If no CONSULT-II, inspect the engine speed (rise and descend) about vehicle speed and throttle opening angle, and check shift change. 	
	OK or NG	
OK	▶	INSPECTION END
NG	▶	Replace CVT assembly.

Description

- The line pressure sensor detects line pressure of CVT, and sends TCM the signal. NLAT0269

CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

NLAT0269S01





Remarks: Specification data are reference values.

Monitor item	Condition	Specification
Line pressure sensor	Throttle valve fully closed (PL Duty: 4%)	Approx. 1.0V
	↓ Throttle valve fully depressed (PL Duty: 94%)	↓ Approx. 4.0V

TCM TERMINALS AND REFERENCE VALUE

NLAT0269S02

Remarks: Specification data are reference values.



Terminal No.	Wire color	Item	Condition	Judgement standard (Approx.)	
37	W	Line pressure sensor		When engine runs at idle speed.	1.0V
				When engine runs at stall speed.	4.0V
42	B			—	—
46	R/L			—	4.5 - 5.5V

ON BOARD DIAGNOSIS LOGIC

NLAT0269S03

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
Ⓟ : LINE PRESSURE SEN ⓧ : 5th judgement flicker	TCM receives an excessively low or high voltage from the sensor.	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Line pressure sensor

Description (Cont'd)



SELF-DIAGNOSIS CODE CONFIRMATION PROCEDURE NLAT0269S05

After the repair, perform the following procedure to confirm the malfunction is eliminated.

④ With CONSULT-II NLAT0269S0501

- 1) Start engine.
- 2) Select "SELF-DIAG RESULTS" mode for CVT with CONSULT-II.
- 3) Drive vehicle in D position.

⊗ Without CONSULT-II NLAT0269S0502

- 1) Start engine.
- 2) Drive vehicle in D position.
- 3) Perform self-diagnosis.
Refer to "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II)", AT-35.

LINE PRESSURE SENSOR

EXCEPT FOR EURO-OB

Wiring Diagram — AT — LPS






Wiring Diagram — AT — LPS

MODELS WITH ECM IN ENGINE COMPARTMENT

NLAT0270

NLAT0270S01

AT-LPS-01



LINE PRESSURE SENSOR




EXCEPT FOR EURO-OB

Wiring Diagram — AT — LPS (Cont'd)

MODELS WITH ECM IN CABIN

NLAT0270S02

AT-LPS-01



YAT218

Diagnostic Procedure

NLAT0271

1	CHECK PRESSURE SENSOR	
Refer to "Component Inspection", AT-156.		
OK or NG		
OK (With CONSULT-II)	▶	GO TO 2.
OK (Without CONSULT-II)	▶	GO TO 3.
NG	▶	Repair or replace pressure sensor.

2	CHECK INPUT SIGNAL (With CONSULT-II)	
Ⓜ With CONSULT-II 1. Start engine. 2. Select "TCM Input Item Parameter List" in "DATA MONITOR" mode for "CVT" with CONSULT-II. 3. Read out the value of "LINE PRES DTY" while driving. <ul style="list-style-type: none"> ● Throttle valve fully closed (PL Duty: 4%): Approx. 1.0V ● Throttle valve fully depressed (PL Duty: 94%): Approx. 4.0V 		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Check the following items: <ul style="list-style-type: none"> ● Harness for short or open between TCM, ECM and CVT fluid pressure sensor (Main harness) ● Ground circuit for ECM Refer to EC section ("TROUBLE DIAGNOSIS FOR POWER SUPPLY").


3	CHECK INPUT SIGNAL (Without CONSULT-II)	
⊗ Without CONSULT-II Refer to "Component Inspection", AT-156.		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Check the following items: <ul style="list-style-type: none"> ● Harness for short or open between TCM, ECM and CVT fluid pressure sensor (Main harness). ● Ground circuit for ECM Refer to EC section ("TROUBLE DIAGNOSIS FOR POWER SUPPLY").

4	CHECK DTC	
Perform "SELF-DIAGNOSIS CONFIRMATION PROCEDURE", AT-152.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

LINE PRESSURE SENSOR

EXCEPT FOR EURO-OB

Component Inspection



Component Inspection LINE PRESSURE SENSOR

=NLAT0272

NLAT0272S01

- Start engine.
- Check voltage between terminals 1 and 6, 10 and 6.

Terminal No.		Voltage
1	6	Approx. 0.5 - 4.5V
10	6	Approx. 4.5 - 5.5V

LINE PRESSURE SOLENOID VALVE

EXCEPT FOR EURO-OB

Description

Description

The line pressure solenoid valve regulates the oil pump discharge pressure to suit the driving condition in response to a signal sent from the TCM. NLAT0273

The line pressure duty cycle value is not consistent when the closed throttle position switch is "ON". To confirm the line pressure duty cycle at low pressure, the accelerator (throttle) should be open until the closed throttle position switch is "OFF".

CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

NLAT0273S01

Remarks: Specification data are reference values.

Monitor item	Condition	Specification
Line pressure solenoid valve duty	Small throttle opening (Low line pressure)	Approximately 4%
	↓	↓
	Large throttle opening (High line pressure)	Approximately 94%



NOTE:

The line pressure duty cycle value is not consistent when the closed throttle position switch is "ON". To confirm the line pressure duty cycle at low pressure, the accelerator (throttle) should be open until the closed throttle position switch is "OFF".

TCM TERMINALS AND REFERENCE VALUE



NLAT0273S02

Remarks: Specification data are reference values.



Terminal No.	Wire color	Item	Condition	Judgement standard (Approx.)	
1	R/W	Line pressure solenoid valve		When releasing accelerator pedal after warming up engine.	2.8V
				When depressing accelerator pedal fully after warming up engine.	1.4V
2	P/B	Line pressure solenoid valve (with dropping resistor)		When releasing accelerator pedal after warming up engine.	11.0V
				When depressing accelerator pedal fully after warming up engine.	4.0V

ON BOARD DIAGNOSIS LOGIC

NLAT0273S03

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
 : LINE PRESSURE S/V	TCM detects an improper voltage drop when it tries to operate the solenoid valve.	<ul style="list-style-type: none"> • Harness or connectors (The solenoid circuit is open or shorted.) • Line pressure solenoid valve
 : 6th judgement flicker		

Description (Cont'd)



SELF-DIAGNOSIS CODE CONFIRMATION PROCEDURE NLAT0273S04

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II NLAT0273S0401

- 1) Start engine.
- 2) Select "SELF-DIAG RESULTS" mode for CVT with CONSULT-II.
- 3) With brake pedal depressed, shift the lever from "P" → "N" → "D" → "N" → "P" positions.

Without CONSULT-II NLAT0273S0402

- 1) Start engine.
- 2) With brake pedal depressed, shift the lever from "P" → "N" → "D" → "N" → "P" positions.
- 3) Perform self-diagnosis.
Refer to "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II)", AT-35.

LINE PRESSURE SOLENOID VALVE




EXCEPT FOR EURO-OB

Wiring Diagram — AT — LPSV

Wiring Diagram — AT — LPSV

NLAT0274

AT-LPSV-01



YAT180

LINE PRESSURE SOLENOID VALVE

EXCEPT FOR EURO-OB

Diagnostic Procedure

Diagnostic Procedure

NLAT0275

1	CHECK VALVE RESISTANCE
<p>1. Turn ignition switch to "OFF" position. 2. Disconnect terminal cord assembly connector in engine compartment. 3. Check resistance between terminal 8 and ground.</p> <p>Resistance: 2.5 - 5Ω</p> <div data-bbox="598 683 1021 1030" data-label="Diagram"><p>To line pressure solenoid valve</p><p>T.S.</p><p>DISCONNECT</p><p>F4</p></div>	
<p>SAT686JA</p>	
<p>OK or NG</p>	
OK	▶ GO TO 2.
NG	▶ <ul style="list-style-type: none">1. Remove control valve assembly. Refer to AT-206.2. Check the following items:<ul style="list-style-type: none">● Line pressure solenoid valve Refer to "Component Inspection", AT-163.● Harness of terminal cord assembly for short or open

LINE PRESSURE SOLENOID VALVE

EXCEPT FOR EURO-OB


Diagnostic Procedure (Cont'd)

2 CHECK POWER SOURCE CIRCUIT

1. Turn ignition switch to "OFF" position.
2. Disconnect TCM harness connector.
3. Check resistance between terminal 8 and TCM harness connector terminal 2.

Resistance:

11.2 - 12.8Ω



SAT267K

OK or NG

OK ► GO TO 3.

NG ► **Check the following items:**

- Dropping resistor
Refer to "Component Inspection", AT-163.
- Harness for short or open between TCM terminal 2 and terminal cord assembly (Main harness)

LINE PRESSURE SOLENOID VALVE

EXCEPT FOR EURO-OBD

Diagnostic Procedure (Cont'd)


3	CHECK POWER SOURCE CIRCUIT	
<p>1. Turn ignition switch to "OFF" position. 2. Check resistance between terminal 8 and TCM harness connector terminal 1. Resistance: Approx. 0Ω</p>		
SAT268K		
<p>If OK, check harness for short to ground and short to power. 3. Reinstall any part removed.</p>		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

4	CHECK DTC	
<p>Perform Self-diagnosis Code confirmation procedure, AT-158.</p>		
OK or NG		
OK	▶	INSPECTION END
NG	▶	1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

LINE PRESSURE SOLENOID VALVE

EXCEPT FOR EURO-OBD

Component Inspection



Component Inspection

LINE PRESSURE SOLENOID VALVE

=NLAT0276

NLAT0276S01


- For removal, refer to AT-206.

Resistance Check

NLAT0276S0101

- Check resistance between two terminals.


Solenoid valve	Terminal No.		Resistance (Approx.)
	8	Ground	
Line pressure solenoid valve	8	Ground	2.5 - 5Ω



Operation Check

NLAT0276S0102

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal and ground.



DROPPING RESISTOR

NLAT0276S02

- Check resistance between two terminals.

Resistance:
11.2 - 12.8Ω

TORQUE CONVERTER CLUTCH SOLENOID VALVE

EXCEPT FOR EURO-OB

Description

Description

The torque converter clutch solenoid valve is activated, with the gear in "D₄", by the TCM in response to signals sent from the vehicle speed and throttle position sensors. Lock-up piston operation will then be controlled.

Lock-up operation, however, is prohibited when CVT fluid temperature is too low.

When the accelerator pedal is depressed (less than 2/8) in lock-up condition, the engine speed should not change abruptly. If there is a big jump in engine speed, there is no lock-up.

NLAT0277

CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

Remarks: Specification data are reference values.


NLAT0277S01

Monitor item	Condition	Specification
Torque converter clutch solenoid valve duty	Lock-up "OFF"	Approximately 4%
	↓	↓
	Lock-up "ON"	Approximately 94%

TCM TERMINALS AND REFERENCE VALUE

Remarks: Specification data are reference values.

NLAT0277S02

Terminal No.	Wire color	Item	Condition	Judgement standard (Approx.)	
3	GY/R	Torque converter clutch solenoid valve		When CVT performs lock-up.	12.0V
				When CVT does not perform lock-up.	0V

ON BOARD DIAGNOSIS LOGIC


NLAT0277S03

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
P : T/C CLUTCH SOL/V X : 7th judgement flicker	TCM detects an improper voltage drop when it tries to operate the solenoid valve.	<ul style="list-style-type: none"> ● Harness or connectors (The solenoid circuit is open or shorted.) ● T/C clutch solenoid valve

TORQUE CONVERTER CLUTCH SOLENOID VALVE

EXCEPT FOR EURO-OB

Description (Cont'd)



SELF-DIAGNOSIS CODE CONFIRMATION PROCEDURE

NLAT0277S04

After the repair, perform the following procedure to confirm the malfunction is eliminated.

④ With CONSULT-II


NLAT0277S0401

- 1) Start engine.
- 2) Select "SELF-DIAG RESULTS" mode for CVT with CONSULT-II.
- 3) Drive vehicle in D → D lock-up position.

⊗ Without CONSULT-II

NLAT0277S0402

- 1) Start engine.
- 2) Drive vehicle in D → D lock-up position.
- 3) Perform self-diagnosis. Refer to "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II)", AT-35.



TORQUE CONVERTER CLUTCH SOLENOID VALVE

EXCEPT FOR EURO-OBD

Wiring Diagram — AT — TCV

Wiring Diagram — AT — TCV

NLAT0278




AT-TCV-01



: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC

3
GY/R

GY/R



YAT179


TORQUE CONVERTER CLUTCH SOLENOID VALVE

EXCEPT FOR EURO-OB

Diagnostic Procedure

Diagnostic Procedure

NLAT0279

1	CHECK VALVE RESISTANCE
	<p>1. Turn ignition switch to "OFF" position.</p> <p>2. Disconnect terminal cord assembly connector in engine compartment.</p> <p>3. Check resistance between terminal 9 and ground.</p> <p>Resistance: 10 - 20Ω</p> <div data-bbox="678 481 933 795"></div> <p style="text-align: center;">OK or NG</p>
OK	▶ GO TO 2.
NG	▶ <ol style="list-style-type: none">1. Remove oil pan. Refer to AT-206.2. Check the following items:<ul style="list-style-type: none">• Torque converter clutch solenoid valve Refer to "Component Inspection", AT-169.• Harness of terminal cord assembly for short or open

SAT269K

TORQUE CONVERTER CLUTCH SOLENOID VALVE

EXCEPT FOR EURO-OBD

Diagnostic Procedure (Cont'd)


2	CHECK POWER SOURCE CIRCUIT	
<p>1. Turn ignition switch to "OFF" position. 2. Disconnect TCM harness connector. 3. Check continuity between terminal 5 and TCM harness connector terminal 3. Continuity should exist.</p>		
SAT683JA		
<p>If OK, check harness for short to ground and short to power. 4. Reinstall any part removed.</p>		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

3	CHECK DTC	
<p>Perform Self-diagnosis Code confirmation procedure, AT-165.</p>		
OK or NG		
OK	▶	INSPECTION END
NG	▶	1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

TORQUE CONVERTER CLUTCH SOLENOID VALVE

EXCEPT FOR EURO-OBD

Component Inspection



Component Inspection

TORQUE CONVERTER CLUTCH SOLENOID VALVE

NLAT0280

NLAT0280S01


- For removal, refer to AT-206.

Resistance Check

NLAT0280S0101

- Check resistance between two terminals.

Solenoid valve	Terminal No.		Resistance (Approx.)
	9	Ground	
Torque converter clutch solenoid valve	9	Ground	10 - 20Ω



Operation Check


NLAT0280S0102

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal and ground.

CVT FLUID TEMPERATURE SENSOR CIRCUIT

EXCEPT FOR EURO-OB

Description



Description

The CVT fluid temperature sensor detects the CVT fluid temperature and sends a signal to the TCM. NLAT0281

CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

Remarks: Specification data are reference values. NLAT0281S01

Monitor item	Condition	Specification (Approximately)	
CVT temperature sensor	Cold [20°C (68°F)]	1.5V	2.5 kΩ
	↓	↓	↓
	Hot [80°C (176°F)]	0.5V	0.3 kΩ

TCM TERMINALS AND REFERENCE VALUE

Remarks: Specification data are reference values. NLAT0281S02

Terminal No.	Wire color	Item	Condition	Judgement standard (Approx.)
42	B	Ground (CVT fluid temperature sensor)	—	—
47	BR	CVT fluid temperature sensor		When ATF temperature is 20°C (68°F). 1.5V
			When ATF temperature is 80°C (176°F). 0.5V	



ON BOARD DIAGNOSIS LOGIC

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
P1130 : FLUID TEMP SEN P1131 : 8th judgement flicker	TCM receives an excessively low or high voltage from the sensor.	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) CVT fluid temperature sensor

CVT FLUID TEMPERATURE SENSOR CIRCUIT

EXCEPT FOR EURO-OBD

Description (Cont'd)



SELF-DIAGNOSIS CODE CONFIRMATION PROCEDURE

NLAT0281S04

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II

NLAT0281S0401

- 1) Start engine.
- 2) Select "SELF-DIAG RESULTS" mode for CVT with CONSULT-II.
- 3) Drive vehicle under the following conditions:
Selector lever in "D" position, vehicle speed higher than 10 km/h (6 MPH), throttle opening greater than 1/8 of the full open position, engine speed higher than 450 rpm and driving for more than 10 minutes.

Without CONSULT-II

NLAT0281S0402

- 1) Start engine.
- 2) Drive vehicle under the following conditions:
Selector lever in "D" position, vehicle speed higher than 10 km/h (6 MPH), throttle opening greater than 1/8 of the full open position, engine speed higher than 450 rpm and driving for more than 10 minutes.
- 3) Perform self-diagnosis.
Refer to "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II)", AT-35.

CVT FLUID TEMPERATURE SENSOR CIRCUIT

EXCEPT FOR EURO-OBD

Wiring Diagram — AT — FTS




Wiring Diagram — AT — FTS

MODELS WITH ECM IN ENGINE COMPARTMENT

NLAT0282

NLAT0282S01

AT-FTS-01



CVT FLUID TEMPERATURE SENSOR CIRCUIT



EXCEPT FOR EURO-OBD

Wiring Diagram — AT — FTS (Cont'd)

MODELS WITH ECM IN CABIN

NLAT0282S02

AT-FTS-01



YAT214


CVT FLUID TEMPERATURE SENSOR CIRCUIT

EXCEPT FOR EURO-OB

Diagnostic Procedure

Diagnostic Procedure

NLAT0283

1	CHECK A/T FLUID TEMPERATURE SENSOR WITH TERMINAL CORD ASSEMBLY	
<p>1. Turn ignition switch to "OFF" position. 2. Disconnect terminal cord assembly connector in engine compartment. 3. Check resistance between terminals 6 and 7 when CVT is cold.</p> <p style="color: blue;">Resistance: Cold [20°C (68°F)] Approximately 2.5 kΩ</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT229K</p> <p>4. Reinstall any part removed.</p> <p style="text-align: center;">OK or NG</p>		
OK (With CONSULT-II) ▶		GO TO 2.
OK (Without CONSULT-II) ▶		GO TO 3.
NG ▶		Replace CVT assembly.

2	CHECK INPUT SIGNAL OF A/T FLUID TEMPERATURE SENSOR (WITH CONSULT-II)																							
<p>Ⓜ With CONSULT-II</p> <p>1. Start engine. 2. Select "TCM INPUT SIGNALS" in "DATA MONITOR" mode for "CVT" with CONSULT-II. 3. Read out the value of "FLUID TEMP SE".</p> <p style="color: blue;">Voltage: Cold [20°C (68°F)] → Hot [80°C (176°F)]: Approximately 1.5V → 0.5V</p> <div style="text-align: center;"> <table border="1" style="border-collapse: collapse;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITOR</th> <th>NO DTC</th> </tr> </thead> <tbody> <tr> <td>VHCL SPEED SE</td> <td>XXX km/h</td> </tr> <tr> <td>THRTL POS SEN</td> <td>XXX V</td> </tr> <tr> <td>FLUID TEMP SE</td> <td>XXX V</td> </tr> <tr> <td>BATTERY VOLT</td> <td>XXX V</td> </tr> <tr> <td>LINE PRES SEN</td> <td>XXX V</td> </tr> <tr> <td>ENGINE SPEED</td> <td>XXX rpm</td> </tr> <tr> <td>I/P PULLY SPD</td> <td>XXX rpm</td> </tr> <tr> <td>L POSITION SW</td> <td>OFF</td> </tr> <tr> <td>D POSITION SW</td> <td>OFF</td> </tr> </tbody> </table> </div> <p style="text-align: right;">SAT271K</p> <p style="text-align: center;">OK or NG</p>			DATA MONITOR		MONITOR	NO DTC	VHCL SPEED SE	XXX km/h	THRTL POS SEN	XXX V	FLUID TEMP SE	XXX V	BATTERY VOLT	XXX V	LINE PRES SEN	XXX V	ENGINE SPEED	XXX rpm	I/P PULLY SPD	XXX rpm	L POSITION SW	OFF	D POSITION SW	OFF
DATA MONITOR																								
MONITOR	NO DTC																							
VHCL SPEED SE	XXX km/h																							
THRTL POS SEN	XXX V																							
FLUID TEMP SE	XXX V																							
BATTERY VOLT	XXX V																							
LINE PRES SEN	XXX V																							
ENGINE SPEED	XXX rpm																							
I/P PULLY SPD	XXX rpm																							
L POSITION SW	OFF																							
D POSITION SW	OFF																							
OK ▶		GO TO 4.																						
NG ▶		<p>Check the following item:</p> <ul style="list-style-type: none"> ● Harness for short or open between TCM, ECM and terminal cord assembly (Main harness) ● Ground circuit for ECM <p>Refer to EC section, "TROUBLE DIAGNOSIS FOR POWER SUPPLY".</p>																						

CVT FLUID TEMPERATURE SENSOR CIRCUIT

EXCEPT FOR EURO-OB

Diagnostic Procedure (Cont'd)

3 CHECK INPUT SIGNAL OF CVT FLUID TEMPERATURE SENSOR (WITHOUT CONSULT-II)


⊗ Without CONSULT-II

1. Start engine.
2. Check voltage between TCM terminal 47 and ground while warming up CVT.

Voltage:

Cold [20°C (68°F)] → Hot [80°C (176°F)]:


Approximately 1.5V → 0.5V



SAT463J

3. Turn ignition switch to "OFF" position.
4. Disconnect TCM harness connector.
5. Check resistance between terminal 42 and ground.

Continuity should exist.



SAT464J

OK or NG

OK	▶	GO TO 4.
NG	▶	Check the following item: <ul style="list-style-type: none"> Harness for short or open between TCM, ECM and terminal cord assembly (Main harness) Ground circuit for ECM Refer to EC section, "TROUBLE DIAGNOSIS FOR POWER SUPPLY".

4 CHECK DTC

Perform Self-diagnosis Code confirmation procedure, AT-171.

OK or NG

OK	▶	INSPECTION END
NG	▶	<ol style="list-style-type: none"> 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.


Description

Description

The engine speed signal is sent from the ECM to the TCM. NLAT0285


TCM TERMINALS AND REFERENCE VALUE

Remarks: Specification data are reference values. NLAT0285S01

Terminal No.	Wire color	Item	Condition	Judgement standard (Approx.)
39	L/OR	Engine speed signal		When engine runs at idle speed. 0.5 - 1.5V

ON BOARD DIAGNOSIS LOGIC

Diagnostic trouble code	Malfunction is detected when ...	Check item (Possible cause)
P : ENGINE SPEED SIG X : 9th judgement flicker	TCM does not receive the proper voltage signal from ECM.	• Harness or connectors (The sensor circuit is open or shorted.)




SELF-DIAGNOSIS CODE CONFIRMATION PROCEDURE NLAT0285S03

After the repair, perform the following procedure to confirm the malfunction is eliminated.

P With CONSULT-II NLAT0285S0301

- 1) Start engine.
- 2) Select "SELF-DIAG RESULTS" mode for CVT with CONSULT-II.
- 3) Drive vehicle under the following conditions:
Selector lever in "D" position, vehicle speed higher than 10 km/h (6 MPH), throttle opening greater than 1/8 of the full throttle position and driving for more than 10 seconds.



X Without CONSULT-II NLAT0285S0302

- 1) Start engine.
- 2) Drive vehicle under the following conditions:
Selector lever in "D" position, vehicle speed higher than 10 km/h (6 MPH), throttle opening greater than 1/8 of the full throttle position and driving for more than 10 seconds.
- 3) Perform self-diagnosis.
Refer to "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II)", AT-35.

ENGINE SPEED SIGNAL

EXCEPT FOR EURO-OB

Wiring Diagram — AT — ENGSS



Wiring Diagram — AT — ENGSS

NLAT0286

AT-ENGSS-01



— : DETECTABLE LINE FOR DTC
— : NON-DETECTABLE LINE FOR DTC



YAT178

Diagnostic Procedure


NLAT0287

1	CHECK DTC WITH ECM	
Perform diagnostic test mode II (self-diagnostic results) for engine control. Check ignition signal circuit condition.		
OK or NG		
OK (With CONSULT-II)	▶	GO TO 2.
OK (Without CONSULT-II)	▶	GO TO 3.
NG	▶	Check ignition signal circuit for engine control. Refer to EC section, "IGNITION SIGNAL".

2	CHECK INPUT SIGNAL (With CONSULT-II)																							
<p>Ⓜ With CONSULT-II</p> <p>1. Start engine.</p> <p>2. Select "TCM INPUT SIGNALS" in "DATA MONITOR" mode for "CVT" with CONSULT-II.</p>																								
<table border="1" style="margin: auto; border-collapse: collapse;"> <tr><th style="text-align: center;">SELECT SYSTEM</th></tr> <tr><td style="text-align: center;">CVT</td></tr> <tr><td style="text-align: center;">ENGINE</td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;"> </td></tr> </table>			SELECT SYSTEM	CVT	ENGINE																			
SELECT SYSTEM																								
CVT																								
ENGINE																								
<p>3. Read out the value of "ENGINE SPEED". Check engine speed changes according to throttle position.</p>																								
<table border="1" style="margin: auto; border-collapse: collapse;"> <tr><th colspan="2" style="text-align: center;">DATA MONITOR</th></tr> <tr> <th style="text-align: left;">MONITOR</th> <th style="text-align: left;">NO DTC</th> </tr> <tr><td>VHCL SPEED SE</td><td>XXX km/h</td></tr> <tr><td>THRTL POS SEN</td><td>XXX V</td></tr> <tr><td>FLUID TEMP SE</td><td>XXX V</td></tr> <tr><td>BATTERY VOLT</td><td>XXX V</td></tr> <tr><td>LINE PRES SEN</td><td>XXX V</td></tr> <tr><td>ENGINE SPEED</td><td>XXX rpm</td></tr> <tr><td>I/P PULLY SPD</td><td>XXX rpm</td></tr> <tr><td>L POSITION SW</td><td>OFF</td></tr> <tr><td>D POSITION SW</td><td>OFF</td></tr> </table>			DATA MONITOR		MONITOR	NO DTC	VHCL SPEED SE	XXX km/h	THRTL POS SEN	XXX V	FLUID TEMP SE	XXX V	BATTERY VOLT	XXX V	LINE PRES SEN	XXX V	ENGINE SPEED	XXX rpm	I/P PULLY SPD	XXX rpm	L POSITION SW	OFF	D POSITION SW	OFF
DATA MONITOR																								
MONITOR	NO DTC																							
VHCL SPEED SE	XXX km/h																							
THRTL POS SEN	XXX V																							
FLUID TEMP SE	XXX V																							
BATTERY VOLT	XXX V																							
LINE PRES SEN	XXX V																							
ENGINE SPEED	XXX rpm																							
I/P PULLY SPD	XXX rpm																							
L POSITION SW	OFF																							
D POSITION SW	OFF																							
OK or NG																								
OK	▶	GO TO 4.																						
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Harness for short or open between TCM and ECM ● Resistor and ignition coil <p>Refer to EC section, "IGNITION SIGNAL".</p>																						

SAT250K


SAT271K

3	CHECK INPUT SIGNAL (Without CONSULT-II)	
<p>⊗ Without CONSULT-II</p> <p>1. Start engine.</p> <p>2. Check voltage between TCM terminal 39 and ground.</p> <p style="color: blue;">Voltage (Idle speed): Refer to EC section, "IGNITION SIGNAL".</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT424JA</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 4.
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Harness for short or open between TCM and ECM ● Resistor and ignition coil <p>Refer to EC section, "IGNITION SIGNAL".</p>

4	CHECK DTC	
<p>Perform Self-diagnosis Code confirmation procedure, AT-176.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	INSPECTION END
NG	▶	<p>1. Perform TCM input/output signal inspection.</p> <p>2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.</p>

CONTROL UNIT (RAM), CONTROL UNIT (ROM)

Description




Description

The TCM consists of a microcomputer and connectors for signal input and output and for power supply. The unit controls the CVT. NLAT0288

ON BOARD DIAGNOSIS LOGIC

NLAT0288S01

Diagnostic trouble code	Malfunction is detected when ...	Check item (Possible cause)
④ : CONTROL UNIT (RAM) ④ : CONTROL UNIT (ROM)	TCM memory (RAM) or (ROM) is malfunctioning.	TCM



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE


NLAT0288S02

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

④ With CONSULT-II

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode for CVT with CONSULT-II.
- 2) Start engine.
- 3) Run engine for at least 2 seconds at idle speed.



CONTROL UNIT (RAM), CONTROL UNIT (ROM)

Diagnostic Procedure


Diagnostic Procedure

=NLAT0289

1	CHECK DTC
<p>④ With CONSULT-II</p> <p>1. Turn ignition switch "ON" and select "SELF-DIAG RESULTS" mode for CVT with CONSULT-II. 2. Touch "ERASE". PERFORM DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE. See previous page.</p> <p style="text-align: center;">Is the "CONTROL UNIT (RAM) or CONTROL UNIT (ROM)" displayed again?</p>	
Yes	▶ Replace TCM.
No	▶ INSPECTION END

CONTROL UNIT (EEPROM)

Description




Description

The TCM consists of a microcomputer and connectors for signal input and output and for power supply. The unit controls the CVT. NLAT0241

ON BOARD DIAGNOSIS LOGIC

NLAT0241S01

Diagnostic trouble code	Malfunction is detected when ...	Check item (Possible cause)
Ⓟ : CONT UNIT (EEPROM)	TCM memory (EEPROM) is malfunctioning.	TCM



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE


NLAT0241S02

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

Ⓟ With CONSULT-II

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode for CVT with CONSULT-II.
- 2) Start engine.
- 3) Run engine for at least 2 seconds at idle speed.



CONTROL UNIT (EEPROM)

Diagnostic Procedure

Diagnostic Procedure

=NLAT0242

1	CHECK DTC
<p>Ⓟ With CONSULT-II</p> <ol style="list-style-type: none">1. Turn ignition switch "ON" and select "SELF-DIAG RESULTS" mode for CVT with CONSULT-II.2. Move selector lever to "R" position.3. Depress accelerator pedal (Full throttle position).4. Touch "ERASE".5. Turn ignition switch "OFF" position for 10 seconds. <p>PERFORM DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE. See previous page.</p> <p style="text-align: center;">Is the "CONT UNIT (EEPROM)" displayed again?</p>	
Yes	▶ Replace TCM.
No	▶ INSPECTION END

TROUBLE DIAGNOSES FOR NON-DETECTABLE ITEMS

PNP Switch, Stop Lamp Switch and Throttle Position Switch

PNP Switch, Stop Lamp Switch and Throttle Position Switch

NLAT0290

SYMPTOM:

SPORT indicator lamp does not come on in TCM self-diagnostic procedure even the lamp circuit is good.

DESCRIPTION

NLAT0290S01

- PNP switch
- The PNP switch assemble includes a transmission position switch. The transmission position switch detects the selector position and sends a signal to the TCM.
- Stop lamp switch
Detects the stop lamp switch position (ON or OFF) and sends a signal to the TCM
- Throttle position switch.
Consists of a wide open throttle position switch and a closed throttle position switch.
The wide open throttle position switch sends a signal to the TCM when the throttle valve is open at least 1/2 of the full throttle position. The closed throttle position switch sends a signal to the TCM when the throttle valve is fully closed.

Diagnostic Procedure

NLAT0291

1	CHECK PNP SWITCH CIRCUIT (With CONSULT-II)									
	<p>④ With CONSULT-II</p> <p>1. Turn ignition switch to "ON" position. (Do not start engine.)</p> <p>2. Select "TCM INPUT SIGNALS" in "DATA MONITOR" mode for "CVT" with CONSULT-II.</p> <div style="text-align: center; margin: 10px 0;"> <table border="1" style="border-collapse: collapse;"> <tr><td style="text-align: center;">SELECT SYSTEM</td></tr> <tr><td style="text-align: center;">CVT</td></tr> <tr><td style="text-align: center;">ENGINE</td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;"> </td></tr> </table> </div> <p>3. Read out "P/N", "R", "D" and "L" position switches moving selector lever to each position. Check the signal of the selector lever position is indicated properly.</p> <p style="text-align: center;">OK or NG</p>		SELECT SYSTEM	CVT	ENGINE					
SELECT SYSTEM										
CVT										
ENGINE										
OK	▶	GO TO 3.								
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● PNP switch Refer to "Component Inspection", AT-72. ● Harness for short or open between ignition switch and PNP switch (Main harness) ● Harness for short or open between PNP switch and TCM (Main harness) ● Ignition switch and fuse Refer to EL section ("POWER SUPPLY ROUTING"). 								

SAT250K

TROUBLE DIAGNOSES FOR NON-DETECTABLE ITEMS

Diagnostic Procedure (Cont'd)

2	CHECK PNP SWITCH CIRCUIT (Without CONSULT-II)																															
<p>Ⓜ With CONSULT-II</p> <p>1. Turn ignition switch to "ON" position. (Do not start engine.)</p> <p>2. Check voltage between TCM terminals 27, 34, 35, 36 and ground while moving selector lever through each position.</p> <p style="margin-left: 20px;">Voltage: B: Battery voltage 0: 0V</p> <div style="text-align: center; margin: 10px 0;"> <table border="1" style="border-collapse: collapse;"> <thead> <tr> <th rowspan="2" style="padding: 5px;">Lever position</th> <th colspan="4" style="padding: 5px;">Terminal No.</th> </tr> <tr> <th style="padding: 5px;">36</th> <th style="padding: 5px;">35</th> <th style="padding: 5px;">34</th> <th style="padding: 5px;">27</th> </tr> </thead> <tbody> <tr> <td style="padding: 5px;">P, N</td> <td style="padding: 5px; text-align: center;">B</td> <td style="padding: 5px; text-align: center;">0</td> <td style="padding: 5px; text-align: center;">0</td> <td style="padding: 5px; text-align: center;">0</td> </tr> <tr> <td style="padding: 5px;">R</td> <td style="padding: 5px; text-align: center;">0</td> <td style="padding: 5px; text-align: center;">B</td> <td style="padding: 5px; text-align: center;">0</td> <td style="padding: 5px; text-align: center;">0</td> </tr> <tr> <td style="padding: 5px;">D</td> <td style="padding: 5px; text-align: center;">0</td> <td style="padding: 5px; text-align: center;">0</td> <td style="padding: 5px; text-align: center;">B</td> <td style="padding: 5px; text-align: center;">0</td> </tr> <tr> <td style="padding: 5px;">L</td> <td style="padding: 5px; text-align: center;">0</td> <td style="padding: 5px; text-align: center;">0</td> <td style="padding: 5px; text-align: center;">0</td> <td style="padding: 5px; text-align: center;">B</td> </tr> </tbody> </table> </div> <p style="text-align: right; margin-top: 10px;">MTBL0312</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p>				Lever position	Terminal No.				36	35	34	27	P, N	B	0	0	0	R	0	B	0	0	D	0	0	B	0	L	0	0	0	B
Lever position	Terminal No.																															
	36	35	34	27																												
P, N	B	0	0	0																												
R	0	B	0	0																												
D	0	0	B	0																												
L	0	0	0	B																												
OK	▶	GO TO 3.																														
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● PNP switch Refer to "Component Inspection", AT-72. ● Harness for short or open between ignition switch and PNP switch (Main harness) ● Harness for short or open between PNP switch and TCM (Main harness) ● Ignition switch and fuse Refer to EL section ("POWER SUPPLY ROUTING"). 																														

3	CHECK PNP SWITCH CIRCUIT (With CONSULT-II)										
<p>Ⓜ With CONSULT-II</p> <p>1. Turn ignition switch to "ON" position. (Do not start engine.)</p> <p>2. Select "TCM INPUT SIGNALS" in "DATA MONITOR" mode for "CVT" with CONSULT-II.</p> <div style="text-align: center; margin: 10px 0;"> <table border="1" style="border-collapse: collapse;"> <thead> <tr> <th style="padding: 5px;">SELECT SYSTEM</th> </tr> </thead> <tbody> <tr> <td style="padding: 5px; text-align: center;">CVT</td> </tr> <tr> <td style="padding: 5px; text-align: center;">ENGINE</td> </tr> <tr> <td style="padding: 5px;"> </td> </tr> <tr> <td style="padding: 5px;"> </td> </tr> <tr> <td style="padding: 5px;"> </td> </tr> <tr> <td style="padding: 5px;"> </td> </tr> <tr> <td style="padding: 5px;"> </td> </tr> </tbody> </table> </div> <p style="text-align: right; margin-top: 10px;">SAT250K</p> <p>3. Read out "BRAKE SW" moving brake pedal to each position. Check the signal of the brake pedal is indicated properly.</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p>				SELECT SYSTEM	CVT	ENGINE					
SELECT SYSTEM											
CVT											
ENGINE											
OK	▶	GO TO 5.									
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Harness for short or open between fuse block and PNP switch harness terminal 3 ● Fuse ● Ignition switch (Refer to EL section.) 									

TROUBLE DIAGNOSES FOR NON-DETECTABLE ITEMS

Diagnostic Procedure (Cont'd)

4	CHECK STOP LAMP SWITCH CIRCUIT (Without CONSULT-II)	
<p>1. Turn ignition switch to "ON" position. (Do not start engine.)</p> <p>2. Check voltage between stop lamp switch harness terminal 1 and ground. Refer to "Wiring Diagram — CVT — MAIN", AT-62.</p>		
SAT733JA		
Does battery voltage exist?		
OK	▶	GO TO 5.
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Harness for short or open between battery and stop lamp switch harness terminal 1 ● Fuse ● Ignition switch (Refer to EL section.)

5	CHECK THROTTLE POSITION SWITCH CIRCUIT (With CONSULT-II)												
<p>Ⓟ With CONSULT-II</p> <p>1. Refer to steps 1 to 7 of "Preparation", "TCM Self-diagnostic Procedure (No Tools)", AT-28.</p> <p>2. Turn ignition switch to "OFF" position.</p> <p>3. Turn ignition switch to "ON" position. (Do not start engine.)</p> <p>4. Select "TCM INPUT SIGNALS" in "DATA MONITOR" mode for "CVT" with CONSULT-II.</p> <p>5. Read out "CLOSED THL/SW" and "W/O THRL/P-SW" depressing and releasing accelerator pedal. Check the signal of throttle position switch is indicated properly.</p>													
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2" style="padding: 5px;">Accelerator pedal condition</th> <th colspan="2" style="padding: 5px;">Data monitor</th> </tr> <tr> <th style="padding: 5px;">CLOSED THL/SW</th> <th style="padding: 5px;">W/O THRL/P-SW</th> </tr> </thead> <tbody> <tr> <td style="padding: 5px;">Released</td> <td style="padding: 5px; text-align: center;">ON</td> <td style="padding: 5px; text-align: center;">OFF</td> </tr> <tr> <td style="padding: 5px;">Fully depressed</td> <td style="padding: 5px; text-align: center;">OFF</td> <td style="padding: 5px; text-align: center;">ON</td> </tr> </tbody> </table>			Accelerator pedal condition	Data monitor		CLOSED THL/SW	W/O THRL/P-SW	Released	ON	OFF	Fully depressed	OFF	ON
Accelerator pedal condition	Data monitor												
	CLOSED THL/SW	W/O THRL/P-SW											
Released	ON	OFF											
Fully depressed	OFF	ON											
MTBL0011													
OK or NG													
OK	▶	GO TO 7.											
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Throttle position switch — Refer to "Components Inspection", AT-111. ● Harness for short or open between ignition switch and throttle position switch (Main harness) ● Harness for short or open between throttle position switch and TCM (Main harness) 											

TROUBLE DIAGNOSES FOR NON-DETECTABLE ITEMS

Diagnostic Procedure (Cont'd)



6 CHECK THROTTLE POSITION SWITCH CIRCUIT (Without CONSULT-II)

⊗ **Without CONSULT-II**

1. Refer to steps 1 to 7 of "Preparation", "TCM Self-diagnostic Procedure (No Tools)", AT-28.
2. Turn ignition switch to "OFF" position.
3. Turn ignition switch to "ON" position.
(Do not start engine.)
4. Check voltage between TCM terminals 16, 17 and ground while depressing, and releasing accelerator pedal slowly.
(After warming up engine)

Accelerator pedal condition	Voltage	
	Terminal No. 16	Terminal No. 17
Released	Battery voltage	1V or less
Fully depressed	1V or less	Battery voltage

MTBL0137



SAT454JD

OK or NG

OK	▶	GO TO 7.
NG	▶	Check the following items: <ul style="list-style-type: none"> ● Throttle position switch — Refer to "Components Inspection", AT-111. ● Harness for short or open between ignition switch and throttle position switch (Main harness) ● Harness for short or open between throttle position switch and TCM (Main harness)

7 CHECK DTC

1. Perform Diagnostic Trouble Code (DTC) confirmation procedure for PNP switch (AT-67) and throttle position switch (AT-105).
2. Perform stop lamp switch check using step 4 of Diagnostic Procedure, AT-184.

OK or NG

OK	▶	INSPECTION END
NG	▶	<ol style="list-style-type: none"> 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

TROUBLE DIAGNOSES FOR NON-DETECTABLE ITEMS






Wiring Diagram — AT — NONDTC

Wiring Diagram — AT — NONDTC MODELS WITH ECM IN ENGINE COMPARTMENT

NLAT0292

NLAT0292S01

AT-NONDTC-01





REFER TO THE FOLLOWING.

(M1) - FUSE BLOCK-
JUNCTION BOX (J/B)

TROUBLE DIAGNOSES FOR NON-DETECTABLE ITEMS

Wiring Diagram — AT — NONDTC (Cont'd)

AT-NONDTC-02



YAT185

TROUBLE DIAGNOSES FOR NON-DETECTABLE ITEMS





Wiring Diagram — AT — NONDTC (Cont'd)

MODELS WITH ECM IN CABIN

NLAT0292S02

AT-NONDTC-01

: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.



(M1) - FUSE BLOCK-JUNCTION BOX (J/B)

YAT219

TROUBLE DIAGNOSES FOR NON-DETECTABLE ITEMS

Wiring Diagram — AT — NONDTC (Cont'd)

AT-NONDTC-02



REFER TO THE FOLLOWING.


(E1) -ELECTRIC UNITS

(F3) GY

YAT220

TROUBLE DIAGNOSES FOR SYMPTOMS

SPORT Indicator Lamp Does Not Come On



SPORT Indicator Lamp Does Not Come On =NLAT0295

SYMPTOM:
SPORT indicator lamp does not come on for about 2 seconds when turning ignition switch to "ON".

1	CHECK TCM POWER SOURCE	
<ol style="list-style-type: none"> 1. Turn ignition switch to "OFF" position. 2. Check voltage between TCM terminal 28 and ground. Voltage: Battery voltage <p style="text-align: center;">OK or NG</p>		SAT262K
OK	▶	GO TO 2.
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Harness for short or open between battery terminal and TCM terminal 28 (Main harness). ● Refer to "Wiring Diagram — AT — MAIN", AT-62. ● Ignition switch and fuse Refer to EL section, "POWER SUPPLY ROUTING".

TROUBLE DIAGNOSES FOR SYMPTOMS

SPORT Indicator Lamp Does Not Come On (Cont'd)

2	CHECK TCM GROUND CIRCUIT
<p>1. Turn ignition switch to "OFF" position. 2. Disconnect TCM harness connector. 3. Check continuity between TCM terminals 25, 48 and ground.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">SAT468J</p> <p>Continuity should exist. If OK, check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 3.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors. Refer to "Wiring Diagram — AT — MAIN", AT-62.

3	CHECK LAMP CIRCUIT
<p>1. Turn ignition switch to "OFF" position. 2. Check resistance between TCM terminals 13 and 10. Resistance: 50 - 100Ω</p> <div style="text-align: center;"> </div> <p style="text-align: right;">SAT469JD</p> <p>3. Reinstall any part removed.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 4.
NG	▶ Check the following items: <ul style="list-style-type: none"> ● SPORT indicator lamp. Refer to EL section, "METERS AND GAUGES". ● Harness and fuse for short or open between ignition switch and SPORT indicator lamp (Main harness) Refer to EL section, "POWER SUPPLY ROUTING". ● Harness for short or open between sport indicator lamp and TCM.

TROUBLE DIAGNOSES FOR SYMPTOMS

SPORT Indicator Lamp Does Not Come On (Cont'd)

4	CHECK SYMPTOM	
Check again.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	<ol style="list-style-type: none">1. Perform TCM input/output signal inspection.2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

AT SHIFT LOCK SYSTEM

Description


Description

NLAT0316

- The mechanical key interlock mechanism also operates as a shift lock:
With the key switch turned to ON, the selector lever cannot be shifted from "P" (parking) to any other position unless the brake pedal is depressed.
With the key removed, the selector lever cannot be shifted from "P" to any other position.
The key cannot be removed unless the selector lever is placed in "P".
- The shift lock and key interlock mechanisms are controlled by the ON-OFF operation of the shift lock solenoid and by the operation of the rotator and slider located inside the key cylinder.

Shift Lock System Electrical Parts Location

NLAT0317



SAT239K

AT SHIFT LOCK SYSTEM

Wiring Diagram — SHIFT —



Wiring Diagram — SHIFT —

NLAT0318

NLAT0318S01

AT-SHIFT-01

TYPE-1



REFER TO THE FOLLOWING.
 (M1), (M2) - FUSE BLOCK-
 JUNCTION BOX (J/B)

YAT186



A/T SHIFT LOCK SYSTEM

Wiring Diagram — SHIFT — (Cont'd)

TYPE-2

NLAT0318S02

AT-SHIFT-01



REFER TO THE FOLLOWING.
 (M1) , (M2) -FUSE BLOCK-
 JUNCTION BOX (J/B)

YAT221

A/T SHIFT LOCK SYSTEM

Diagnostic Procedure

Diagnostic Procedure

NLAT0319

SYMPTOM 1:


- Selector lever cannot be moved from “P” position with key in ON position and brake pedal applied.
- Selector lever can be moved from “P” position with key in ON position and brake pedal released.
- Selector lever can be moved from “P” position when key is removed from key cylinder.

SYMPTOM 2:

Ignition key cannot be removed when selector lever is set to “P” position. It can be removed when selector lever is set to any position except “P”.

1	CHECK KEY INTERLOCK CABLE	
Check key interlock cable for damage.		
OK or NG		
OK	▶	GO TO 2.
NG	▶	Repair key interlock cable. Refer to AT-202.


2	CHECK SELECTOR LEVER POSITION	
Check selector lever position for damage.		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Check selector lever. Refer to “ON-VEHICLE SERVICE — PNP Switch and Control Cable Adjustment”, AT-204.


3	CHECK POWER SOURCE	
<p>1. Turn ignition switch to “ON” position. (Do not start engine.)</p> <p>2. Check voltage between stop lamp switch harness terminal 1 and ground. Voltage: Battery voltage</p>		
 <p style="text-align: center;">Stop lamp switch harness terminal (MB)</p>		
OK or NG		
OK	▶	GO TO 4.
NG	▶	<p>Check the following items:</p> <ol style="list-style-type: none"> 1. Harness for short or open between battery and stop lamp switch harness terminal 1 2. Fuse 3. Ignition switch (Refer to EL section, “POWER SUPPLY ROUTING”).

SAT240K

A/T SHIFT LOCK SYSTEM


Diagnostic Procedure (Cont'd)

4	CHECK INPUT SIGNAL (A/T DEVICE)	<p>Turn ignition switch to "ON" position. (Do not start engine.)</p> <ul style="list-style-type: none"> Check voltage between A/T device harness terminal 7 and ground. <p>Voltage: Brake pedal depressed: Battery voltage Brake pedal released: 0V</p> <div style="text-align: center;">  <p>A/T device harness terminal (M42)</p> </div> <p style="text-align: right;">SAT241K</p> <p style="text-align: center;">OK or NG</p>
OK	▶	GO TO 5.
NG	▶	<p>Check the following items:</p> <ol style="list-style-type: none"> Harness for short and open between battery and stop lamp switch harness connector 1. Harness for short or open between stop lamp switch harness connector 2 and A/T device harness connector 7. Fuse Stop lamp switch (Refer to "A/T DEVICE CHECK", AT-201.)

5	CHECK GROUND CIRCUIT	<ol style="list-style-type: none"> Turn ignition switch to "OFF" position. Disconnect A/T device harness connector. Check continuity between A/T device harness terminal 6 and ground. <p>Continuity should exist. If OK, check harness for short to ground and short to power.</p> <div style="text-align: center;">  <p>A/T device harness connector (M42)</p> </div> <p style="text-align: right;">SAT242K</p> <p style="text-align: center;">OK or NG</p>
OK	▶	GO TO 6.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

A/T SHIFT LOCK SYSTEM

Diagnostic Procedure (Cont'd)

6	CHECK RELAY CIRCUIT												
<p>1. Turn ignition switch to ON.</p> <ul style="list-style-type: none"> • Check voltage between terminal 5 - 6 and 7 - 6. 													
													
<table border="1" style="margin: auto;"> <thead> <tr> <th>Condition</th> <th>Ignition switch</th> <th>Terminal No.</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td rowspan="2">When selector lever is set in "P" position and depressed brake pedal.</td> <td rowspan="2">ON</td> <td>5 - 6</td> <td>Battery voltage</td> </tr> <tr> <td>7 - 6</td> <td>Battery voltage</td> </tr> </tbody> </table>				Condition	Ignition switch	Terminal No.	Voltage	When selector lever is set in "P" position and depressed brake pedal.	ON	5 - 6	Battery voltage	7 - 6	Battery voltage
Condition	Ignition switch	Terminal No.	Voltage										
When selector lever is set in "P" position and depressed brake pedal.	ON	5 - 6	Battery voltage										
		7 - 6	Battery voltage										
SAT243K													
OK or NG													
OK	▶	GO TO 7.											
NG	▶	Replace A/T device.											

7	CHECK PARK POSITION SWITCH		
Refer to "A/T DEVICE CHECK", AT-201.			
OK or NG			
OK	▶	GO TO 8.	
NG	▶	Replace A/T device.	

8	CHECK SHIFT LOCK SOLENOID		
Refer to "A/T DEVICE CHECK", AT-201.			
OK or NG			
OK	▶	GO TO 9.	
NG	▶	Replace A/T device.	

9	SHIFT LOCK OPERATION		
<p>1. Reconnect shift lock harness connector.</p> <p>2. Turn ignition switch from "OFF" to "ON" position. (Do not start engine.)</p> <p>3. Recheck shift lock operation.</p>			
OK or NG			
OK	▶	INSPECTION END	
NG	▶	<p>1. Perform A/T device input/output signal inspection test.</p> <p>2. If NG, recheck harness connector connection.</p>	

A/T SHIFT LOCK SYSTEM

Diagnostic Procedure (Cont'd)

A/T DEVICE CHECK


=NLAT0319S01

1. Shift Lock Solenoid

NLAT0319S0101

- Check operation sound.
When ignition switch is turned to "ON" position and selector lever is set in "P" position.

Brake pedal	Operation sound
Depressed	Yes
Released	No




2. Park Position Switch

NLAT0319S0102

- Check resistance between A/T device harness terminal 6 and 7.

Condition	Resistance
When selector lever is set in "P" position and selector lever button is released	111Ω
When selector lever is not set in "P" position and selector lever button is released	0Ω



STOP LAMP SWITCH

NLAT0319S02

- Check continuity between terminals 1 and 2.

Condition	Continuity
When brake pedal is depressed	Yes
When brake pedal is released	No


Check stop lamp switch after adjusting brake pedal — refer to BR section, "BRAKE PEDAL AND BRACKET".

KEY INTERLOCK CABLE

Components

Components


NLAT0320



SAT245K

CAUTION:

- Install key interlock cable in such a way that it will not be damaged by sharp bends, twists or interference with adjacent parts.
- After installing key interlock cable to control device, make sure that casing cap and bracket are firmly secured in their positions.



SAT246K


Removal

NLAT0321


1. Unlock slider by squeezing lock tabs on slider from adjuster holder and remove interlock rod from cable.

KEY INTERLOCK CABLE

Removal (Cont'd)




2. Remove lock plate from steering lock assembly and remove key interlock cable.




Installation

NLAT0322

1. Turn ignition key to lock position.
2. Set A/T selector lever to P position.
3. Set key interlock cable to steering lock assembly and install lock plate.
4. Clamp cable to steering column and fix to control cable with band.




5. Insert interlock rod into adjuster holder.



6. Install casing cap to bracket.
7. Move slider in order to fix adjuster holder to interlock rod.

ON-VEHICLE SERVICE

Control Cable Adjustment



Control Cable Adjustment

NLAT0111


Move selector lever from the “P” position to the “L” position. You should be able to feel the detents in each position. If the detents cannot be felt or if the pointer indicating the position is improperly aligned, the control cable needs adjustment.

1. Place selector lever in “P” position.
2. Loosen control cable lock nut and place manual shaft in “P” position.

CAUTION:

Turn wheels more than 1/4 rotations and apply the park lock.

3. Tighten control cable lock nut.
⚙️ : 12 - 14 N·m (1.2 - 1.5 kg-m, 9 - 10 ft-lb)
4. Move selector lever from “P” to “L” position again. Make sure that selector lever moves smoothly.
5. Apply grease to contacting areas of selector lever and control cable. Install any part removed.



Park/Neutral Position (PNP) Switch Adjustment


NLAT0112

1. Remove control cable end from manual shaft.
2. Set manual shaft in “N” position.
3. Loosen PNP switch fixing bolts.

4. Use a 4 mm (0.157 in) pin for this adjustment.
 - a. Insert the pin straight into the manual shaft adjustment hole.
 - b. Rotate PNP switch until the pin can also be inserted straight into hole in PNP switch.
5. Tighten PNP switch fixing bolts.

⚙️ : 4.9 - 6.8 N·m (0.5 - 0.7 kg-m, 44 - 60 in-lb)

6. Remove pin from adjustment hole after adjusting PNP switch.
7. Reinstall any part removed.
8. Adjust control cable. Refer to “Control Cable Adjustment”.
9. Check continuity of PNP switch. Refer to AT-72.




Differential Side Oil Seal Replacement

NLAT0113

1. Remove drive shaft assemblies. Refer to AX section (“Drive Shaft”, “FRONT AXLE”).
2. Remove oil seals.

ON-VEHICLE SERVICE

Differential Side Oil Seal Replacement (Cont'd)



3. Install oil seals.

- **Apply CVT fluid to oil seal surface before installing.**
- **Install oil seals so that dimensions "A" and "B" are within specifications.**


Unit: mm (in)

A	B
5.5 - 6.5 (0.217 - 0.256)	-0.5 to 0.5 (-0.020 to 0.020)

4. Reinstall any part removed.

REMOVAL AND INSTALLATION

Removal



Removal

NLAT0115

CAUTION:


Before separating transaxle from engine, remove the crankshaft position sensor (OBD) from transaxle. Be careful not to damage sensor.

1. Remove battery and bracket.
2. Remove air duct between throttle body and air cleaner.
3. Disconnect control valve harness connector, PNP switch harness connector, secondary speed sensor harness connector, dropping resistor harness connector, primary speed sensor harness connector and body earth harness connector.
4. Remove crankshaft position sensor (OBD) from transaxle.
5. Drain CVT fluid from transaxle.
6. Disconnect control cable from transaxle.
7. Remove exhaust front tube. Refer to FE section ("EXHAUST SYSTEM").
8. Remove drive shafts. Refer to AX section ("Drive Shaft", "FRONT AXLE").
9. Disconnect oil cooler hoses.
10. Remove starter motor from transaxle.

Tighten bolts to specified torque.

 : 41 - 52 N·m (4.2 - 5.3 kg·m, 30 - 38 ft·lb)

11. Support transaxle with a jack.
12. Remove center member.
 - Tighten center member fixing bolts to specified torque, Refer to EM section ("ENGINE REMOVAL").
13. Remove rear plate cover.
14. Remove torque converter bolts.
Rotate crankshaft to gain access to securing bolts.
15. Support engine with a jack.
16. Remove transaxle mount bolt. Refer to EM section ("ENGINE REMOVAL").
17. Remove oil cooler tube (outlet side).
18. Remove transaxle.



Inspection

NLAT0236


- When connecting torque converter to transaxle, measure distance "A" to be certain that they are correctly assembled.

Distance "A":

15.9 mm (0.626 in) or more

REMOVAL AND INSTALLATION

Installation



Installation

NLAT0116

1. Tighten bolts fixing transaxle.

Bolt No.	Tightening torque N-m (kg-m, ft-lb)	Bolt length "ℓ" mm (in)
1	70 - 79 (7.1 - 8.1, 51 - 59)	40 (1.57)
2	31 - 36 (3.1 - 3.7, 23 - 26)	35 (1.38)
3	31 - 36 (3.1 - 3.7, 23 - 26)	47 (1.85)
4	70 - 79 (7.1 - 8.1, 52 - 58)	65 (2.56)
5	75 - 85 (7.6 - 8.7, 55 - 62)	65 (2.56)
6	70 - 79 (7.1 - 8.1, 52 - 58)	45 (1.77)

2. Install torque converter to drive plate.
 - **With converter installed, rotate crankshaft several turns to check that transaxle rotates freely without binding.**




3. Reinstall any part removed.
4. Adjust control cable. Refer to AT-204.
5. Check continuity of PNP switch. Refer to AT-72.
6. Refill transaxle with CVT fluid and check fluid level.
7. Move selector lever through all positions to be sure that transaxle operates correctly. With parking brake applied, idle engine. A slight shock should be felt through the hand gripping the selector each time the transaxle is shifted.
8. Perform road test. Refer to AT-53.

REMOVAL AND INSTALLATION

Air Breather Hose

Air Breather Hose


NLAT0323



SAT283K

CVT Fluid Cooler

NLAT0324




SAT284K

REMOVAL AND INSTALLATION

Components

NLAT0325

SEC. 310•311•312•319



SAT273K

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

General Specifications			NLAT0179
Engine		SR20DE	
Automatic transaxle model		RE0F06A	
Automatic transaxle assembly	Model code number	8E020	
Transaxle gear ratio	D range	Variable	
	Reverse	1.586	
	Final drive	5.473	
Recommended fluid		Nissan CVT fluid NS-1*1	
Fluid capacity		8.1ℓ (7-1/8 Imp qt)	

*1: Refer to MA section ("Fluids and Lubricants", "RECOMMENDED FLUIDS AND LUBRICANTS").
Any other fluid will damage the CVT.

Stall Revolution

Engine	Stall revolution rpm	NLAT0181
(SR20DE)	2,350 - 2,850	

Line Pressure

Engine speed rpm	Line pressure kPa (bar, kg/cm ² , psi)			NLAT0182
	R position	D position	L position	
Idle	598 (5.98, 6.1, 87)			
Stall	4,119 (41.2, 42, 597)			

Removal and Installation

Distance between end of converter housing and torque converter	15.9 (0.626) or more	NLAT0197 Unit: mm (in)

A/T Fluid Temperature Sensor

Condition	Specification (Approximately)		NLAT0326
Cold [20°C (68°F)]	1.5V	2.5 kΩ	
↓	↓	↓	
Hot [80°C (176°F)]	0.5V	0.3 kΩ	

Solenoid Valves

Solenoid valve	Resistance (Approx.)	Terminal number	NLAT0327
Line pressure solenoid	2.5 - 5Ω	8	
Torque converter clutch solenoid	10 - 20Ω	9	

Dropping Resistor

Resistance	11.2 - 12.8Ω	NLAT0328